

XK3118T6-P Technical Manual

1. Main technical parameter:


Excitation voltage for load cell: DC 5V, can connect 1-4 pcs of 350Ω strain gauge load cells

Min input voltage for each verification interval $\geq 1.5\mu\text{V/e}$

Connection with load cell: use 4 wires

Power Supply: AC 110V~220V, 50Hz~60Hz; Can be connect external 6V/7AH free maintenance lead-acid storage battery; (battery should be charged extra)

2. The connection of load cells

	description		
	location	description	code
1	Load cell negative excitation	E-	
2	Load cell negative feedback	F-	
6	Load cell positive excitation	E+	
7	Load cell positive feedback	F+	
8	Load cell signal input -	S-	
9	Load cell signal input +	S+	
5	Shield cable	SHIELD	

If use 4 wires shield cable, must make the short circuit for positive excitation and positive feedback、negative excitation and negative feedback

3. Calibration method

After self-checking, the indicator enter into display interface for weighing ,keeping 15-30 minutes, then open the calibration cover at the back of indicator, dial the switch to up (calibration status), details as following:

Step	Operation	Display	Notes
	Press 【SET】		Turn the switch to calibration location allowed(P2 on the mainboard is in short circuit)
1	Press 【1】 Press 【ENTER】	【d 1】	Input Interval value:1/2/5/10/20/50/100option Default setting in factory: 1
2	Press 【0】 Press 【ENTER】	【dC 0】	Input decimal places:(0~3) Default setting in factory: 0
3	Press 【1】【1】【1】【3】 Press 【ENTER】	【P WXYZ】 【P 1113】	Input system parameter (details is ref. to form 3-1) W: stable judgement range X: zero tracking range Y: manual zero setting range Z: startup zero setting range Default setting in factory: 1113
4	Press 【3】【0】【0】【0】 Press 【ENTER】	【F 3000】	Input max capacity, Press 【ENTER】 . If need calibration, first input F value , then press 【ENTER】 ;if press 【ENTER】 directly then it will turn to Step 7; If press 【WEIGHING】 then return back to weighing status (Note: system overload value=max capacity+9*interval value) Default setting in factory: 3000
5	Press 【ENTER】	【 noLoAd】	To confirm Zero, no loading is on platform now, press 【ENTER】 after stable light is on
6	Press 【2】【0】【0】【0】 Press 【ENTER】	【loAd1】 【 2000】	To load weights which should be no less than 50% of max capacity, more close to max capacity, more accurate.

			Eg.: 2000 After stable light turn on , press 【ENTER】
7	Press 【3】 Press 【ENTER】	【Flt 3】	Filter strength (1~3): 1: weakest; 3: strongest Default setting in factory: 3
8		Weighing status	Ending calibration

Form3-1: Setting method for Pn parameters (F.S: full capacity)

Input Value	0	1	2	3	4	5	6	7	8	9	Unit
W: stable judgement range	0.5	1.0	1.5	2.0	2.5	3.0	3.5	4.0	4.5	5.0	uV
X: zero tracking range	0	0.5	1.0	1.5	2.0	2.5	3.0	3.5	4.0	4.5	e
Y: manual zero setting range	0	2%	4%	10%	20%	100%	—	—	—	—	F.S
Z: startup zero setting range	0	2%	4%	10%	20%	100%	—	—	—	—	F.S

4. Error information prompt

Display	Note
Err 18	Error in parameter setting
Ctnn 0	In 5 th or 6 th Step during calibration, if indicator can not get stable data it will show Err 18. At the moment the operator can input 0 or 1 or 2, their functions are: 0: skip this step into next ; 1: re-collect data; 2: Go on calibration with these unstable data;