

C N C P R O M

Комплетуючі системи ЧПУ

Наш сайт: <http://cnc.prom.ua/>

Тел: +380 (096)-665-71-06

+380 (098)-821-25-90

E-mail: cncprom@ukr.net

Huanyang VFD Inverter Manual 1.5kw 380V (ENG)







Catalogue

| | |
|---|----|
| I Introduction | 1 |
| 1. Checks upon Delivery..... | 2 |
| 2. Nameplate Description of HY Series Inverter..... | 2 |
| I. Safety Precaution | 3 |
| 1. Before the Power-up | 3 |
| 2. During the Power-up..... | 4 |
| 3 During the Operation..... | 4 |
| III Standards and Specifications | 5 |
| 1 Particular Specifications..... | 5 |
| 2. General Specifications..... | 6 |
| N. Storage and Installation | 7 |
| 1. Storage | 7 |
| 2. Installation Site and Environment | 7 |
| 3. Installation and Direction..... | 8 |
| V. Wiring | 9 |
| 1. Main Circuit Wiring Schematic Diagram..... | 9 |
| 1. Description of the Digital Operator..... | 14 |
| 2. Description of Indicator Lamp Status..... | 15 |
| 3. Description of Operation Examples | 16 |
| VI. Commissioning | 17 |
| 1. Checks before the Commissioning..... | 17 |
| 2. Commissioning Methods | 17 |
| VI. Function List | 19 |
| IX. Descriptions of Functions | 26 |
| X. Cara & Maintenance, Fault Information and Troubleshooting | 60 |
| 1. Precautions about Inspection and Maintenance | 60 |
| 2. Periodical Inspection and Maintenance items..... | 60 |
| 3. Fault Indication and Troubleshooting..... | 60 |
| 4. Faults and Analysis..... | 63 |
| XI. Selection of Peripheral Devices and Disposition | 64 |
| 1. Options | 64 |
| 2. Disposition | 65 |
| XI User Preferences Table | 67 |

** The manual is subject to change without notice.*



1. Introduction

Thank you for purchasing and using the general-purpose inverter of HY series of multi-functions and high performance.

Please read carefully the operation manual before putting the inverter to use so as to correctly install and operate the inverter, give full play to its functions and ensure the safety. Please keep the operation manual handy for future reference, maintenance, inspection and repair.

Due to the inverter of a kind of electrical and electronic product it must be installed, tested and adjusted with parameters by specialized engineering persons of motors.

The marks of Danger, Caution and other symbols in the manual remind you of the safety and prevention cautions during the handling, installation, running and inspection. Please follow these instructions to make sure the safe use of the inverter. In case of any doubt please contact our local agent for consultation. Our professional persons are willing and ready to serve you.

The manual is subject to change without notice.

Danger indicates wrong use may kill or injure people.

Caution indicates wrong use may damage the inverter or mechanical system.



- Be sure to turn off the input power supply before wiring.
- Do not touch any internal electrical circuit or component when the charging lamp is still on after the AC power supply is disconnected, which means the inverter still has high voltage inside and it is very dangerous.
- Do not check components and signals on the circuit boards during the operation.
- Do not disassemble or modify any internal connecting cord, wiring or component of the inverter by yourself.
- Be sure to make correct ground connection of the earth terminal of the inverter.
- Never remodel it or exchange control boards and components by yourself. It may expose you to an electrical shock or explosion, etc.




- Do not make any voltage-withstanding test with any component inside the inverter. These semiconductor parts are subject to the damage of high voltage.
- Never connect the AC main circuit power supply to the output terminals U,V,W of the inverter.
- The main electric circuit boards of CMOS and IC of the inverter are subject to the effect and damage of static electricity. Don't touch the main circuit boards.
- Installation, testing and maintenance must be performed by qualified professional personnel.
- The inverter should be discarded as industrial waste. It is forbidden to burn it.

1. Checks upon Delivery

The inverter has been strictly and well packed before ex-work. In consideration of various factors during the transportation special attention should be paid to the following points before the assembly and installation. If there is anything abnormal please notify the dealer or the relevant people of our company.

- Check if the inverter has got any damage or deformation during the transportation and handling.
- Check if there is one piece of HY series inverter and one copy of the instruction manual available when unpacking it.
- Check the information on the nameplate to see if the specifications meet your order (Operating voltage and KVA value).
- Check if there is something wrong with the inner parts, wiring and circuit board.
- Check if each terminal is tightly locked and if there is any foreign article inside the inverter.
- Check if the operator buttons are all right.
- Check if the optional components you ordered are contained.

2. Nameplate Description of HY Series Inverter





II . Safety Precautions

1. Before the Power-up

⚠ Caution

- Check to be sure that the voltage of the main circuit AC power supply matches the input voltage of the inverter.
- The symbol [E] represents ground terminals. Be sure to make correct ground connection of the earth terminals of the motor and the inverter for safety.
- No contactor should be installed between the power supply and the inverter to be used for starting or stopping of the inverter. Otherwise it will affect the service life of the inverter.


⚡ Danger

- R.S.T terminals are power input terminals, never mixed with U.V.W terminals. Be sure that the wiring of the main circuit is correct. Otherwise it will cause damages of the inverter when the power is applied To it.

⚠ Caution

- Do not carry the front cover of the inverter directly when handling. It should be handled with the base to prevent the fall-off of the front cover and avoid the dropping of the inverter, which may possibly cause the injuries to people and the damages to the inverter.
- Mount the inverter on a metal or other noncombustible material to avoid the risk of fire.
- Install the inverter in a safe location, avoiding high temperature, direct sunlight, humid air or water.
- Keep the inverter from the reach of children or persons not concerned.
- The inverter can only be used at the places accredited by our company. Any unauthorized working environment may have the risks of fire, gas explosion, electric shock and other incidents.
- Install a heat sink or other cooling device when installing more than one inverter in the same enclosure so that the temperature inside the enclosure be kept below 40°C to avoid overheat or the risk of fire.
- Be sure to turn off the power supply before disassembling or assembling the operation keypad and fixing the front cover to avoid bad contact causing faults or non-display of the operator.

- Do not install the inverter in a space with explosive gas to avoid the risk of explosion.
- If the inverter is used at or above 1000m above seal level, the cooling efficiency will be worse, so please run it by de-rating.
- Do not install any contactor and other components of capacitor or varistor on the output side of the inverter. Otherwise it will cause malfunctions and damages of components of the inverter. Do not install any switch component like air circuit breaker or contactor at the output of the inverter. If any of such components must be installed because of the requirements of process and others, it must be ensured that the inverter has no output when the switch acts. In addition, it is forbidden to install any capacitor for improvement of power factor or any varistor against thunder at the output. Otherwise it will cause malfunctions, tripping protection and damages of components of the inverter. Please remove them as shown in the below diagram.
- It will affect the service life of the inverter if a contact is connected to the front end of input of the inverter to control its starts and stops. Generally it is required to control it through FOR or REV terminals. Special attention should be paid to its use in the case of frequent starts and stops.
- Please use an independent power supply for the inverter. Do avoid using the common power supply with an electrical welder and other equipment with strong disturbance. Otherwise it will cause the protection or even damage of the inverter.



2. During the Power-up

⚡ Danger

- Do not plug the connectors of the inverter during the power up to avoid any surge into the main control board due to plugging, which might cause the damage of the inverter.
- Always have the protective cover in place before the power up to avoid electrical shock injury.

3. During the Operation

⚡ Danger

- Never connect or disconnect the motor set while the inverter is in running. Otherwise it will cause over-current trip and even burn up the main circuit of the inverter.

⚡ Danger

- Never remove the front cover of the inverter while the inverter is powered up to avoid any injury of electric shock.
- Do not come close to the machine when the fault restart function is used to avoid anything unexpected. The motor may automatically restart after its stop.
- The function of STOP Switch is only valid after setting, which is different with the use of emergent stop switch. Please pay attention to it when using it.





⚠ Caution

- Do not touch the heat sink, braking resistor, or other heat elements to avoid being scald.
- Be sure that the motor and machine is within the applicable speed ranges before starting operation because the inverter is quite easy to run from lower speed to higher speed.
- Do not check the signals on circuit boards while the inverter is running to avoid danger.
- Be careful when changing the inverter settings. The inverter has been adjusted and set before ex-work. Do not adjust it wantonly. Please make proper adjustments according to the required functions.
- Do consider the vibration, noise and the speed limit of the motor bearings and the mechanical devices when the inverter is running at or above the frequency of 50Hz.

III . Standards and Specifications

1. Particular Specifications

| Model | Input Voltage | Power (KW) | Output Current (A) | Suitable Motor (KW) |
|-----------|-----------------------------|------------|--------------------|---------------------|
| HY0D7511B | Single Phase 110V 50Hz | 0.75 | 5.7 | 0.75 |
| HY01D511B | Single Phase 110V 50Hz | 1.5 | 13 | 1.5 |
| HY02D211B | Single Phase 110V 50Hz | 2.2 | 20 | 2.2 |
| HY03D011B | Single Phase 110V 50Hz | 3.0 | 23 | 3.0 |
| HY04D011B | Single Phase 110V 50Hz | 4.0 | 30.6 | 4.0 |
| HY00D423B | Single&Three Phase 220V50Hz | 0.4 | 2.5 | 0.4 |
| HY0D7523B | Single&Three Phase 220V50Hz | 0.75 | 5.0 | 0.75 |
| HY01D523B | Single&Three Phase 220V50Hz | 1.5 | 7.0 | 1.5 |
| HY02D223B | Single&Three Phase 220V50Hz | 2.2 | 10 | 2.2 |
| HY03D023B | Single&Three Phase 220V50Hz | 3.0 | 13 | 3.0 |
| HY04D023B | Single&Three Phase 220V50Hz | 4.0 | 18 | 4.0 |
| HY05D523B | Single&Three Phase 220V50Hz | 5.5 | 21 | 5.5 |
| HY07D523B | Single&Three Phase 220V50Hz | 7.5 | 34 | 7.5 |
| HY001123B | Single&Three Phase 220V50Hz | 11 | 42 | 11 |
| HY0D7543B | 3Φ 380V 50Hz | 0.75 | 2.7 | 0.75 |
| HY01D543B | 3Φ 380V 50Hz | 1.5 | 4.0 | 1.5 |
| HY02D243B | 3Φ 380V 50Hz | 2.2 | 5.0 | 2.2 |
| HY03D043B | 3Φ 380V 50Hz | 3.0 | 7.0 | 3.0 |
| HY04D043B | 3Φ 380V 50Hz | 4.0 | 9.0 | 4.0 |
| HY05D543B | 3Φ 380V 50Hz | 5.5 | 12.5 | 5.5 |

| | | | | |
|-----------|--------------|------|------|------|
| HY07D543B | 3Φ 380V 50Hz | 7.5 | 17.5 | 7.5 |
| HY001143B | 3Φ 380V 50Hz | 11 | 24 | 11 |
| HY001543B | 3Φ 380V 50Hz | 15 | 33 | 15 |
| HY18D543B | 3Φ 380V 50Hz | 18.5 | 40 | 18.5 |
| HY22D243B | 3Φ 380V 50Hz | 22 | 47 | 22 |
| HY30D043B | 3Φ 380V 50Hz | 30 | 65 | 30 |
| HY37D043B | 3Φ 380V 50Hz | 37 | 80 | 37 |
| HY45D043B | 3Φ 380V 50Hz | 45 | 91 | 45 |
| HY55D043B | 3Φ 380V 50Hz | 55 | 110 | 55 |

110V Input, 220V Output Specifications

| Model | Input Voltage (V) | Output Voltage (V) | Power (KW) | Suitable Motor (KW) |
|-------------|------------------------|----------------------------|------------|---------------------|
| HY0D7511B-T | Single Phase 110V 60Hz | Three Phase 0~220V 0~400Hz | 0.75 | 0.4 |
| HY01D511B-T | Single Phase 110V 60Hz | Three Phase 0~220V 0~400Hz | 1.5 | 0.75 |
| HY02D211B-T | Single Phase 110V 60Hz | Three Phase 0~220V 0~400Hz | 2.2 | 1.5 |
| HY03D011B-T | Single Phase 110V 60Hz | Three Phase 0~220V 0~400Hz | 3.0 | 2.2 |
| HY04D011B-T | Single Phase 110V 60Hz | Three Phase 0~220V 0~400Hz | 4.0 | 3.0 |

2. General Specifications

| | | |
|---|---|---|
| Inverter Series | HY-□□ | |
| Control Mode | SPWM | |
| Input Power | 330~440V for 380V power; 170~250 for 220V power; 50Hz/60Hz | |
| 5-Digits Display & Status Indicator Lamp | Displaying frequency, current, revolution, voltage, counter, temperature, forward or reserve running, and fault, etc. | |
| Communication Control | RS-485 | |
| Operation Temperature | -10~40°C | |
| Humidity | 0~95% Relative Humidity (without dew) | |
| Vibration | Below 0.5G | |
| Frequency Control | Range | 0.10~400.00Hz |
| | Accuracy | Digital: 0.01% (-10~40°C) , Analog: 0.1% (25±10°C) |
| | Setting Resolution | Digital: 0.01Hz, Analog: 1% of Max. Operating Frequency |
| | Output Resolution | 0.01Hz |
| | Operator Setting Method | Press directly →[▲][V] to set |
| | Analog Setting Method | External Voltage 0~5V, 0~10V, 4~20mA, 0~20mA. |
| Other Functions | Frequency lower limit, starting frequency, stopping frequency, three skip frequencies can be respectively set. | |



| | | |
|----------------------|---------------------------------|--|
| General Control | Ramp Control | Selectable 4-speed steps ramp-up and -down time (0.1-6500s). |
| | V/F Curve | Set V/F curve at will |
| | Torque Control | Torque increase is settable by max. 10.0%. The starting torque can reach 150% at 1.0Hz. |
| | Multi-Inputs | 6 multi-function input terminals for 8-speed steps control, program operation, switching of 4-speed Ramp, UP-, DOWN function, counter, external emergency stop and other functions. |
| | Multi-Outputs | 5 multi-function output terminals for displaying of running, zero speed, counter, external abnormality, program operation and other information and warnings. |
| | Other Functions | AVR (auto voltage regulation), Deceleration stop or free-stop, DC brake, auto reset and restart, frequency track, PLC control, traverse function, drawing control, auto energy-savings, carrier adjustable by max. 20KHz, etc. |
| Protection Functions | Overload Protection | Electronic relay protection motor Drive (for constant torque 150%/1 min. For the kinds of fan 120%/1 min.) |
| | FUSE Protection | FUSE broken, Motor stops. |
| | Over-voltage | DC Voltage > 400V for 220V class DC Voltage > 800V for 380V class |
| | Low Voltage | DC Voltage < 200V for 220V class DC Voltage < 400V for 380V class |
| | Instant Stop and Restart | Restarted by frequency track after instantaneous stop. |
| | Stall Prevention | Anti-stall during Acc/Dec run |
| | Output End Shorts | Electronic circuit protecting |
| | Other Functions | Fin over-heat protection, restriction of reverse running, direct start after power on, fault reset, parameter lock PID, one-drive-more, etc. |

IV. Storage and Installation

1. Storage

The inverter must be kept in its original package box before installation. Pay attention to the followings when keeping it in storage if the inverter is not used for the time being:

- It must be stored in a dry place without rubbish or dust.
- The suitable temperature for storage is between -20°C and +65°C.
- The relative humidity required is 0-95% without condensation.
- There is no corrosive gas or liquid in the storage ambience.
- It's better to lay the inverter on a rack and keep it in a proper package.

- It is better not to store the inverter for long time. Long time storage of the inverter will lead to the deterioration of electrolytic capacity. If it needs to be stored for a long time make sure to power it up one time within a year and the power-up time should be at least above five hours. When powered up the voltage must be increased slowly with a voltage regulator to the rated voltage value.

2. Installation Site and Environment


The inverter should be installed at the following location:

- Ambient temperature -5°C to 40°C with good ventilation.
- No water drop and low moisture.
- Free from direct sunshine, high temperature and heavy dust fall.
- Free from corrosive gas or liquid.
- Less dust, oil gas and metallic particles
- Free from vibration and easy for service and inspection.
- Free from the interference of electromagnetic noise.

Attention: The ambient conditions of the inverter will affect its service life.

3. Installation and Direction

- There must be enough space left around the inverter for easy maintenance and cooling. See Diagram .
- The inverter must be installed vertically with the smooth ventilation for effective cooling.
- If there is any instability when installing the inverter, please put a flat board under the inverter bottom base and install it again. If the inverter is installed on a loose surface, stress may cause damage of parts in the main circuit so as to damage the inverter.
- The inverter should be installed on non-combustible materials, such as iron plate.
- If several inverters are installed, upper and lower, together in one cabinet, please add heat dissipation plates and leave enough space between the inverters. See Diagram.





V. Wiring

1. Main Circuit Wiring Schematic Diagram



Power supply: Verify that the inverter's rated voltage coincides with the power supply voltage to avoid a damage of the inverter.



No fuse breaker: Refer to the related list.
Ground fault circuit interrupter: Use one of anti-high harmonic.



Electromagnetic contactor:
Note: Do not use the electromagnetic contactor as the on/off button of power supply for the inverter.



AC reactor: It is recommended to install an AC reactor for power factor improvement if the input capacity is more than 1000KVA.



Inverter:

- Be sure to make correct connections of the main circuit wires and control signal wires of the inverter.
- Be sure to make correct setting of parameters for the inverter.



2. Description of Terminal Block

1) Arrangement of Main circuit Terminals

HY0D4043B~HY02D243B HY0D4023B~HY03D4023B

| | | | | | | | | |
|---|---|---|---|----|---|---|---|---|
| R | S | T | P | Pr | U | V | W | E |
| | | | | | | | | |

HY04D043B~HY05D043B HY04D023B

| | | | | | | | | |
|---|---|---|---|---|----|---|---|---|
| E | R | S | T | P | Pr | U | V | W |
| | | | | | | | | |

HY11D043B~HY30D043B

| | | | | | | | | | |
|---|---|---|--|--|---|--|---|---|---|
| R | S | T | | | E | | U | V | W |
| | | | | | | | | | |

Mini Specifications: HY-M□A HY-M□B

The power source is put into through the R.S.T terminals and put out of the U.V.W terminals. The 220v can connect willfully two phase of R.S.T.

(2) Arrangement of Control Circuit Terminals

| | | | | | | | | | | | | | | | |
|-----|-----|-----|-----|------|-----|-----|-----|-----|-----|----|-----|-----|---|---|---|
| UPF | DRV | DCM | SPL | SPM | SPH | RST | REV | FOR | ACM | VO | 10V | J1 | | | |
| | FA | FC | FB | +24V | DCM | — | +5V | ACM | AI | VI | RS+ | RS- | 1 | 2 | 3 |

Notes: Please short circuit the 2-3 foot of J1 terminal when using the board potentiometer .

Like chart:

Please short circuit the 2-3 foot of J1 terminal when using the external connection potentiometer or the external power supply.

Like chart:

Mini inverter terminals

| | | | | | | | | | | | | | | | | |
|----|----|----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|----|-----|----|-----|
| MB | MA | MA | DRV | COM | SPL | SPM | SPH | RST | REV | FOR | RS+ | RS- | AI | GND | VO | +5V |
|----|----|----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|----|-----|----|-----|

Note: AI is the exterior analogue voltage or current input end, joint the parameter menu of Pd070.

3) Function Description of Main circuit Terminals

| Symbol | Function Description |
|--------------|--|
| R.S.T | Input terminal of AC line power. (220V class, for both single/three phase, single phase connected to any two phases) |
| U.V.W | Output terminal of the inverter |
| P.Pr | Connector for braking resistor. |
| P1P | Connector for DC reactor (When using a DC reactor the jumper shall be removed. |
| E | Ground terminal: the third method of grounding for 220V and special grounding for 380 V of Electrical Engineering Regulations. |




4) Function Description of Control Circuit Terminals

| Symbol | Function Description | Factory setting |
|----------------------------|--|---|
| FOR | Multi-Input 1 | Forward run |
| REV | Multi-Input 2 | Reverse run |
| RST | Multi-Input 3 | Reset |
| SPH | Multi-Input 4 | High speed |
| SPM | Multi-Input 5 | Middle Speed |
| SPL | Multi-Input 6 | Low Speed |
| DCM (COM) | Common Terminal of Digital and Control Signals | |
| +10 | Power Supply for Speed Setting | +10V |
| VI | Analog Voltage Frequency Reference Input | 0~+10V corresponding to the highest operating frequency |
| AI | Analog Current Frequency Reference Input | 4~20mA corresponding to the highest operating frequency |
| ACM (GND) | Common Terminal of Analog and Control Signals | |
| DRV | Multi-Output 1 (Optical couple output) | DC24V/100mA |
| UPF | Multi-Output 2 (Optical couple output) | |
| FA(MB) FB(MA) FC(MA) | Multi-Output 3 (N/O or N/C) | 3A/250V |
| VO | Output terminals of digital frequency | 0~10V |
| RS+ RS- | RS485 Communication port | |

3. Basic Connection Diagram

The wiring of the inverter is divided into two parts, main circuit terminal connections and control circuit terminal connections. The user can see the main circuit terminals, and the control circuit terminals after removing the cover of enclosure. The terminals must be connected correctly as the following wiring circuit diagrams.



Note: The above wiring diagram explained that only supplies the reference, take the actual product as the standard. The diagram is subject to change without notice.

4. Precautions on Wiring

1) For the main circuit wiring:

- While wiring the sizes and specifications of wires should be selected and the wiring should be executed according to the electrical engineering regulations to ensure the safety.
- It is better to use shielded wire or wire and conduit for power cord and ground the shielded layer or two ends of wire conduit.
- Be sure to install a Non Fuse Breaker (NFB) between the power supply and the input terminals (R.S.T). (If using ground fault circuit interrupter, please choose one corresponding to high frequency)
- Never connect AC power to the output terminal (U.V.W) of the inverter.
- Output wires mustn't be in touch of the metal part of the inverter enclosure, or it will result in earth short-circuit.
- Phase-shifting capacitors, LC, RC noise filters, etc. can never be connected to the output terminals of the inverter.
- The main circuit wire must be enough far away from other control equipments.
When the wiring between the inverter and the motor exceeds 15 meters for 220V class or 30 meters for 380V class, much higher dV/dT will be produced inside the coil of the motor, which will cause the destruction to the interlay or insulation of the motor. Please use a dedicated AC motor for the inverter or add a reactor at the inverter.




- Please lower the carrier frequency when there is a longer distance between the inverter and the motor. Because the higher the carrier frequency is the bigger the leakage current of high-order harmonics in the cables will be. The leakage current will have unfavorable effect on the inverter and other equipment.

2) For control circuit wiring (signal line)


- The signal line should be separately laid in a different conduit with the main circuit wire to avoid any possible interference.
- Please use the shielded cable with the size of 0.52mm² for signal lines.
- Use the control terminals on the control panel correctly according to your needs.

3) Grounding


- Grounding terminal E. Be sure to make correct grounding
220V class: The third grounding method (Grounding resistance should be 100Ω or lower.)
380V class: The special third grounding method (Grounding resistance should be 10Ω or lower.)
- Choose grounding wires according to the basic length and size of the technical requirements of the electric equipment.
- Do avoid sharing grounding wire with other large power equipment such as electric welder, power machine, etc. The grounding wire should be kept away from the power supply wires for large equipment.
- The grounding method for several inverters together should be done as the first and second diagrams below. Avoid the third loop.
- The grounding wire must be as shorter as possible.



(1) Good





(2) Good



(3) Not good

VI. Instruction of the Digital Operator

1. Description of the Digital Operator



NOTE: The LED main display zone demonstrates by 5 nixietubes, the main display zone 2 demonstrates the 5th digit.
Example: 12345, 1234 digit in the main display zone 1, digit 5 in the main display zone 2.



2. Description of Indicator Lamp Status

1) Description of Indicator Lamp Status

| Indicator lamp | Status | Description |
|----------------|--------|--|
| FOR | on | The motor is in forward rotation. |
| REV | on | The motor is in reverse rotation. |
| HZ | on | Displaying set frequency or output frequency. |
| A | on | Displaying output current. |
| ROTT | on | Displaying rated motor revolution |
| HZ A | on | Displaying DC voltage. |
| A ROTT | on | Displaying AC voltage. |
| HZ ROTT | on | Displaying counting value. |
| HZ A ROTT | on | Displaying internal temperature of the inverter. |

2) Description of Display Items

| Display | Indic.lamp <input type="checkbox"/> on | Meaning |
|---------|---|--|
| F50.00 | HZ A R/min <input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> | Present output frequency is 50.00HZ |
| F50.00 | HZ A R/min <input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> | Present set frequency is 50.00HZ |
| R003.0 | HZ A R/min <input type="checkbox"/> <input type="checkbox"/> <input checked="" type="checkbox"/> | Present set frequency is 50.00HZ 3.0A |
| 01440 | HZ A R/min <input type="checkbox"/> <input type="checkbox"/> <input checked="" type="checkbox"/> | Present output revolution is 1440r/min |
| 0510.1 | HZ A R/min <input type="checkbox"/> <input checked="" type="checkbox"/> <input checked="" type="checkbox"/> | Present DC voltage is 510.1V |
| U380.0 | HZ A R/min <input type="checkbox"/> <input checked="" type="checkbox"/> <input checked="" type="checkbox"/> | Present AC voltage is 380.0V |
| t035.0 | HZ A R/min <input checked="" type="checkbox"/> <input checked="" type="checkbox"/> <input checked="" type="checkbox"/> | Present inverter's temperature is 35.0°C |

| | | |
|-------|--|---|
| 00105 | HZ A R/min <input checked="" type="checkbox"/> <input type="checkbox"/> <input checked="" type="checkbox"/> | Present counter's value is 105 |
| 050.0 | HZ A R/min <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> | Present target value of PID is 50.0% |
| 048.0 | HZ A R/min <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> | Present feedback value of PID is 48.0% |
| 00012 | HZ A R/min <input checked="" type="checkbox"/> <input checked="" type="checkbox"/> <input type="checkbox"/> | Present time of power-on is 12 hours |
| 00108 | HZ A R/min <input type="checkbox"/> <input checked="" type="checkbox"/> <input checked="" type="checkbox"/> | Total run time of inverter is 108 hours |

3. Description of Operation Examples

| Procedures | Display | Indicator Lamp | Explanation |
|---|--|--|---|
| Power up, Operation of power ↓ | Dsp2.0 Flash →Vr2.00 →000.00 | FOR HZ <input checked="" type="checkbox"/> <input checked="" type="checkbox"/> | Self detect when power-up, display version no. (Flashing) and finally set frequency. |
| PRGM ↓ | Pd000 | FOR HZ <input checked="" type="checkbox"/> <input checked="" type="checkbox"/> | Enter programming Display the function of Pd000 |
| ENYER (SET) | 000.00 | FOR HZ <input checked="" type="checkbox"/> <input checked="" type="checkbox"/> | Display the contents of Pd003 |
| ▲ ↓ ← ENYER ↓ PRGM | 50.00 END→50.00 Pd000 050.00 | FOR HZ <input checked="" type="checkbox"/> <input checked="" type="checkbox"/> FOR HZ <input checked="" type="checkbox"/> <input checked="" type="checkbox"/> | Change the content of PD003 Confirm changed value. Display END 50.00 Pd004 Back from programming |
| ↓ RUN | F50.00 | FOR HZ <input checked="" type="checkbox"/> <input checked="" type="checkbox"/> | Display running and operating frequency |
| ↓ DISP (▶) SHIFT | 50.00 F0.00→F50.00 | FOR HZ <input checked="" type="checkbox"/> <input checked="" type="checkbox"/> | Monitor screen switching, display output current |
| ↓ PRGM | F50.00 | FOR HZ <input checked="" type="checkbox"/> <input checked="" type="checkbox"/> | Monitor screen switching, display output current |



| | | | |
|------------|---------|-----------------|---|
| ↓ DISP | 01440 | FOR A □ □ | Monitor screen switching, display revolution |
| ↓ PROG | F 50.00 | FOR ROTT □ □ | Switch back to main screen, display set frequency |
| ↓ JOG | F 50.00 | FOR HZ □ □ | Switch of For.Rev. rotation, display the status of Rev rotation |
| ↓ ▲ | 050.00 | FOR HZ □ □ | Switch to adjustable frequency |
| ↓ ←▲ | 030.00 | FOR HZ □ □ | Adjust set frequency, i.e. the value of Pd003 |
| ↓ ENTER | 030.00 | FOR HZ □ □ | Confirm changed value, write to Pd003 as value |
| ↓ STOP | F 30.00 | FOR HZ ⚡ □ | Stop |

Note:

- ① ⚡ means flashing. □ means bright.
- ② For monitoring AC, DC, T and other items they can be only switched and displayed after the parameter setting.
- ③ When it is powered up again after a power breakdown the inverter will display the screen previous to the power breakdown after its self detection.

VI. Commissioning

1. Important Checks before the Commissioning

If there is any wrong connected wires? Pay special attention to the terminal of U.V.W; Make sure the power supply wires are connected to R.S.T, not U.V.W.

If there is any metal powder or wires left on the base plate of the inverter or the terminal block, which may cause short circuit.

If screws are tightly locked and if the connecting parts are loose.

If there is any short circuit or earth fault at outputs.

2. Commissioning Methods

The procedure of the operator is factory set up for the control mode of HY series. The commissioning can be carried out through the digital operator. Generally, the commissioning can be conducted at 5.00 Hz.

| Procedures | Display | Indicator Lamp | Explanation |
|---------------|-------------------------|----------------|--|
| Power up ↓ | disp1.1→Vr2.0 000.00 | FOR HZ ⚡ □ | Self detect when power up, display version no. and finally set frequency |
| △ | 000.00 | FOR HZ ⚡ □ | Switch to adjustable frequency on the panel |
| ←↓ △ | 050.00 | FOR HZ ⚡ □ | Change set frequency, i.e. The value of Pd003 |
| ↓ ENTER | F 50.00 | FOR HZ ⚡ □ | Confirm changed value |
| ↓ RUN | F 50.00 | FOR HZ □ □ | Run at 50Hz |
| ↓ STOP | F 50.00 | FOR HZ ⚡ □ | Stop |

Note: □ means indicator lamps is on; ⚡ means indicator lamps flash;



VI. Function List

Parameters Function List 1

| Category | Code | Function | Set Range & Function Explanation | Factory Setting |
|-----------------------|-----------------|-------------------------------|---|-----------------|
| Basic Parameters | PD000 | Parameter Lock | 0: Invalid 1: Valid | 0 |
| | PD001 | Source of Run Commands | 0: Operator 1: External terminal 2: Communication port | 0 |
| | PD002 | Source of Operating Frequency | 0: Operator board 1: Simulation amount set(board potentiometer and external potentiometer) 2: Communication port | 0 |
| | PD003 | Main Frequency | 0.00~400.00 Hz | * |
| | PD004 | Base Frequency | 0.01~400.00 Hz | 50.00 |
| | PD005 | Max Operating Frequency | 50.00~400.00 Hz | 50.00 |
| | PD006 | Intermediate Frequency | 0.01~400.00 Hz | 2.50/3.0 |
| | PD007 | Min. Frequency | 0.01~20.00 Hz | 0.50 |
| | PD008 | Max. Voltage | 0.1V----* | 220/380 |
| | PD009 | Intermediate Voltage | 0.1V----* | * |
| | PD010 | Min. Voltage | 0.1~50.0V | * |
| | PD011 | Frequency Lower Limit | 0.00~400.00 Hz | 0 |
| | PD012 | Reserved | | |
| | PD013 | Parameter Reset | 1: Restore the factory setting. No other function. | 00 |
| | PD014 | Accel. Time 1 | 0.1~6500.0S | * |
| | PD015 | Decel. Time 1 | 0.1~6500.0S | * |
| | PD016 | Accel. Time 2 | 0.1~6500.0S | * |
| | PD017 | Decel. Time 2 | 0.1~6500.0S | * |
| | PD018 | Accel. Time 3 | 0.1~6500.0S | * |
| | PD019 | Decel. Time 3 | 0.1~6500.0S | * |
| | PD020 | Accel. Time 4 | 0.1~6500.0S | * |
| | PD021 | Decel. Time 4 | 0.1~6500.0S | * |
| | PD022 | Reserved | | |
| | PD023 | Rev. Rotation Select | 0: Rev Run forbidden; 1: Rev Run Enable | 0 |
| PD024 | STOP key select | 0: STOP Invalid 1: STOP Valid | 1 | |
| Application parameter | PD025 | Starting Mode | 0: Start from Starting Frequency 1: Frequency track start | 0 |
| | PD026 | Stopping Mode | 0: Decelerating stop 1: Coasting stop | 0 |
| | PD027 | Starting Frequency | 0.1~10.0 Hz | 0.5 |
| | PD028 | Stopping Frequency | 0.1~10.0 Hz | 0.5 |

| | | | | |
|--|-------------|--|---------------|-------|
| | PD029 | Braking time at start | 0~25.0 | 0.0 |
| | PD030 | Braking time at stop | 0~25.0 | 0.0 |
| | PD031 | DC Braking level | 0.0~20.0% | 2.0 |
| | PD032 | Frequency track time | 0.1~20.0S | 5.0 |
| | PD033 | Current level for frequency track | 0.0~200.0S | 150.0 |
| | PD034 | Voltage rise time during frequency track | 0.1~10S | 0.5 |
| | PD035~PD040 | Reserved | | |
| | PD041 | Carrier frequency | 0~15 | * |
| | PD042 | Jogging Frequency | 0.00~400.00Hz | 5.00 |
| | PD043 | S-Curve Time | 0~6500S | 0 |

Parameters Function List 2

| Category | Code | Function | Set Range & Function Explanation | Factory Setting | |
|----------------------------|-------|-----------------------|--|---|----|
| Terminals of Input /Output | PD044 | FOR (D1) | 0: Invalid; 1:Run; 2: For rotation; 3: Rev rotation; 4: Stop; 5: FOR/REV; 6: Jog; 7: Jog For rotation; 8: Jog Rev Rotation; 9:Timer1; 10:Timer2; 11:Reserved; 12: Overheat of heat sink or motor; 13:Emergent stop; 14:Reset; 15~16: Reserved ;17: Ramp select 1;18 :Ramp select2;19: Multi-speed1 ; 20: Multi-speed 2; 21: Multi-speed 3; 22: High speed; 23: Middle speed;24: Low speed; 25: PID Start; 26: Reserved; 27: UP function Counter 28: DOWN function; 29: Drawing;30: Reserved;31: Counter; 32: Counter reset | 02 | |
| | PD045 | REV(D2) | | 03 | |
| | PD046 | RST(D3) | | 14 | |
| | PD047 | SPH(D4) | | 22 | |
| | PD048 | SPL(D5) | | 24 | |
| | PD049 | SPM(D6) | | 23 | |
| | PD050 | Y1 Output | | 0: Invalid; 1: Run; 2: Zero Speed; 3: Fault indication; 4: Braking indication; 5: Set Frequency reach; 6: In Accel.; 7: In Decel.; 8: Arbitrary Frequency 1 reach; 9:Arbitrary Frequency 2 reach; | 01 |
| | PD051 | Y2 Output | | 05 | |
| | PD052 | Terminals of FA,FB,FC | | 03 | |
| | | | | | |



| | | | | |
|----------------------------|-----------------|-------------------------|--|------|
| Input and Output Terminals | Pd053 | Terminals of KA, KB | 10: Motor Overload alarm; 11: Over torque alarm; 12: Inverter Overload alarm; 13: Counter reach; 14-16: Reserved; 17: Low voltage alarm; 18: Single stage end indication; 19: Process end indication; 20-26: Reserved; 27: Drawing reach; 28: PID lower limit alarm; 29: PID upper limit alarm; 30: Reserved; 31: Braking resistor act; 32: Fan act. | 03 |
| | PD054 | VO Output | Output of digital frequency signals 0-7 | 0 |
| | PD055 | VO Analog output Gain | 0.0-100.0% | 100 |
| | PD056 | Skip Frequency 1 | 0.00-400.00 Hz | 0.00 |
| | PD057 | Skip Frequency 2 | 0.00-400.00 | 0.00 |
| | PD058 | Skip Frequency 3 | 0.00-400.00 | 0.00 |
| | PD059 | Skip Frequency Range | 0.10-10.00 | 0.50 |
| | PD060 | Uniform Frequency 1 | 0.00-400.00 Hz | 0.00 |
| | PD061 | Uniform Frequency 2 | 0.00-400.00 Hz | 0.00 |
| | PD062 | Uniform Frequency Range | 0.10-10.00 Hz | 0.50 |
| | PD063 | Timer 1 time | 0-10.0 | 0.1 |
| | PD064 | Timer 2 time | 0-100 | 1 |
| | PD065 | Counting value set | 00-65500 | 00 |
| | PD066 | Intermediate Counter | 0-65500 | 0 |
| | PD067- PD069 | Reserved | | |

Parameters Function List 3

| Category | Code | Function | Set Range & Function Explanation | Factory Setting |
|------------------------|-------|---|---|-----------------|
| | PD070 | Analog Input | 0: 0-10V 1: 0-5V 2: 0-20mA 3: 4-20mA 4: 0-10V, stacked 4-20mA Exterior pulse of input | 0 |
| | PD071 | Analog Filtering Constant | 0-50 | 20 |
| | PD072 | Lower Analog Frequency | 0.00-400.00 Hz | 50.00 |
| | PD073 | Higher Analog Frequency | 0.00-400.00 Hz | 0 |
| | Pd074 | Bias Director at Higher Frequency | 0: Positive direction 1: Negative direction | 0 |
| | PD075 | Bias Director at Lower Frequency | 0: Positive direction 1: Negative direction | 0 |
| | PD076 | Analog Negative Bias Reverse | 0: Not allowable. 1: Allowable. | 0 |
| | PD077 | Up/Down Function | 0: Not memorized 1: Memorized | 0 |
| | PD078 | Up/Down Speed | 0: 0.01HZ 1: 0.1HZ | 0 |
| | PD079 | Reserved | | |
| Category | Code | Function | Set Range & Function Explanation | Factory Setting |
| Multi-speeds Operation | PD080 | PLC Operation | 0: Normal run; 1: Internal control 16-speed; 2: External control 4-speed; 3: External control 8-speed 4: Drawing 5: Disturbance; | 0 |
| | PD081 | Internal Control Multi-speeds Operation | 0: Stop after running for one cycle; 1: Cycling run; 2: Auto stop after running for one cycle (STOP for intervention); 3: Auto Run and Cycling (STOP for intervention) | 0 |



| Multi-speeds Operation | PD082 | PLC Before 8 speeds Running Direction | 0-255 (0: For 1: Rev) | 0 |
|------------------------|--------------|---------------------------------------|-------------------------|-------|
| | PD083 | PLC After 8 speeds Running Direction | 0-255 (0: For 1: Rev) | 0 |
| | PD084 | Before 8 speeds PLC Ramp Time | 0-65535 | 0 |
| | PD085 | After 8 speeds PLC Ramp Time | 0-65535 | 0 |
| | PD086 | Frequency 2 | 0.00-400.00 Hz | 15.00 |
| | PD087 | Frequency 3 | 0.00-400.00 Hz | 20.00 |
| | PD088 | Frequency 4 | 0.00-400.00 Hz | 25.00 |
| | PD089 | Frequency 5 | 0.00-400.00 Hz | 30.00 |
| | PD090 | Frequency 6 | 0.00-400.00 Hz | 35.00 |
| | PD091 | Frequency 7 | 0.00-400.00 Hz | 40.00 |
| | PD092 | Frequency 8 | 0.00-400.00 Hz | 0.50 |
| | PD093 | Frequency 9 | 0.00-400.00 Hz | 10.00 |
| | PD094 | Frequency 10 | 0.00-400.00 Hz | 15.00 |
| | PD095 | Frequency 11 | 0.00-400.00 Hz | 20.00 |
| | PD096 | Frequency 12 | 0.00-400.00 Hz | 25.00 |
| | PD097 | Frequency 13 | 0.00-400.00 Hz | 30.00 |
| | PD098 | Frequency 14 | 0.00-400.00 Hz | 35.00 |
| PD099 | Frequency 15 | 0.00-400.00 Hz | 40.00 | |
| PD100 | Frequency 16 | 0.00-400.00 Hz | 45.00 | |
| PD101 | Timer 1 | 0.0-6500.0S | 10.0 | |
| PD102 | Timer 2 | 0.0-6500.0S | 10.0 | |
| PD103 | Timer 3 | 0.0-6500.0S | 0.0 | |
| PD104 | Timer 4 | 0.0-6500.0S | 0.0 | |
| PD105 | Timer 5 | 0.0-6500.0S | 0.0 | |
| PD106 | Timer 6 | 0.0-6500.0S | 0.0 | |
| PD107 | Timer 7 | 0.0-6500.0S | 0.0 | |
| PD108 | Timer 8 | 0.0-6500.0S | 0.0 | |
| PD109 | Timer 9* | 0.0-6500.0S | 0.0 | |
| PD110 | Timer 10 | 0.0-6500.0S | 0.0 | |
| PD111 | Timer 11 | 0.0-6500.0S | 0.0 | |
| PD112 | Timer 12 | 0.0-6500.0S | 0.0 | |
| PD113 | Timer 13 | 0.0-6500.0S | 0.0 | |
| PD114 | Timer 14 | 0.0-6500.0S | 0.0 | |
| PD115 | Timer 15 | 0.0-6500.0S | 0.0 | |
| PD116 | Timer 16 | 0.0-6500.0S | 0.0 | |

Parameters Function List 4

| Category | Code | Function | Set Range & Function Explanation | Factory Setting | |
|---------------------------|-------------------------------------|--|---|-----------------|-----|
| | PD117 | AutoPLC Memory Function | 0-1 | 0 | |
| | PD118 | Over-voltage Stall Prevention | 0-1 | 1 | |
| | PD119 | Stall Prevention Level at Accel. | 0-200 | 150 | |
| | PD120 | Stall Prevention Level at Constant Speed | 0-200 | 0 | |
| | PD121 | The Decel Time of Stall Prevention Level at Constant Speed | 0.1-25.5 | 5 | |
| | PD122 | Stall Prevention Level at Decel. | 0-200 | 150 | |
| | PD123 | Over-torque Detect Mode | 0-3 | 0 | |
| | PD124 | Over-torque Detect Level | 0-200 | 0 | |
| | PD125 | Over-torque Detect Time | 0.1-20.0 | 1.0 | |
| | PD126 | Pulse Counter Memory | 0-1 | 0 | |
| | PD127- PD129 | Reserved | | | |
| | Water Supply with Constant Pressure | PD130 | Number of Auxiliary Pump | 0-2 | 0 |
| | | PD131 | Continuous Operating Time of Aux. Pumps | 1-9000min | 60 |
| | | PD132 | Interlocking Time of Aux. Pumps | 1-250s | 5s |
| | | PD133 | High Speed Running Time | 1-250s | 60s |
| | | PD134 | Low Speed Running Time | 1-250s | 60s |
| PD135 | | Stopping Voltage Level | 1-150% | 95% | |
| PD136 | | Lasting Time of Stopping Voltage Level | 1-250s | 30s | |
| PD137 | | Wakeup Level | 1-150% | 80% | |
| PD138 | | Sleep Frequency | 0.00-400.0 | 20.00 | |
| PD139 | Lasting Time of Sleep Frequency | 1-250s | 20s | | |
| PD140 | Reserved | | | | |
| Motor Function Parameters | PD141 | Rated Motor Voltage | Set according to Motor nameplate | * | |
| | PD142 | Rated Motor Current | Set according to Motor nameplate | * | |
| | PD143 | Motor pole number. | 0210 | 04 | |
| | PD144 | Rated Motor Revolution | 24000 | 1440 | |



| | | | | |
|--|-----------------|----------------------------------|-------------------------------|-----|
| | PD145 | Auto Torque Compensation | 2.0-10.0 | 2.0 |
| | PD146 | Motor no-load current | 0100 | 40 |
| | PD147 | Motor slip compensation | 0.0-100 | 20 |
| | PD148- PD149 | Reserved | | |
| | PD150 | Auto Voltage Regulation | 0-1 | 1 |
| | PD151 | Auto Energy Saving | 0-20 | 0 |
| | PD152 | Fault Restart Time | 0.2-25 | 1 |
| | PD153 | Restart after Instantaneous Stop | 0: Invalid 1: Frequency track | 0 |
| | PD154 | Allowable Power-Breakdown Time | 0.1-5.0S | 0.5 |
| | PD155 | Number of Abnormal Restart | 0-10 | 00 |

Parameters Function List 5

| Category | Code | Function | Set Range & Function Explanation | Factory Setting |
|------------------------|-----------------|---------------------------|---|-----------------|
| PID Parameters | PD156 | Proportional Constant (P) | 0.0-1000.00% | 100% |
| | PD157 | Integral Time (I) | 0.1-3600.00S | 5.0 |
| | PD158 | Differential Time (D) | 0.01-10.00S | 0 |
| | Pd159 | Target value | 0.0-100.0% 0: set by the operator | 0 |
| | Pd160 | Target value select | 1: set by external terminals (0-10V) preset | 0 |
| | PD161 | PID upper limit | 0-100% | 100% |
| | PD162 | PID lower limit | 0-100% | 0% |
| Communication Function | PD163 | Communication Addresses | 0-250 | 0 |
| | PD164 | Communication Baud Rate | 0-3 | 0 |
| | PD165 | Communication Data Method | 0-5 | 0 |
| | Pd166- Pd169 | Reserved | | |

| | | | | |
|------------------|----------|-----------------------------|---------------------------------|---|
| Monitor Function | PD170 | Display Items | 0-5 | 7 |
| | PD171 | Display Items Open | 0-15 | 7 |
| | PD172 | Fault Clear | 00 10(01 for Fault Clear) | * |
| | PD173 | Voltage Rating of Inverter | Set according to the model | * |
| | PD174 | Rated Current of Inverter | Set according to the model | |
| | PD175 | Inverter Model | | |
| | PD176 | Inverter Frequency Standard | 0: 50Hz 1: 60Hz | 0 |
| | PD177 | Fault Record 1 | Note: Means no fault record. | * |
| | PD178 | Fault Record 2 | | — |
| | PD179 | Fault Record 3 | | — |
| | PD180 | Fault Record 4 | | — |
| | PD181 | Software Version | | — |
| | PD182 | Manufacture Date | Year: Month: Week: | * |
| | PD183 | Serial No. | | * |
| Pd184- Pd250 | Reserved | | | |

X. Descriptions of Functions

| |
|---|
| <p>PD000 Parameter Lock Set Range: 0-1 Unit: 1 Factory Setting: 0</p> |
|---|

0: Invalid.
1: Valid, i.e. the parameters are locked. Except this parameter other parameters can not be changed. This parameter is set to prevent non-maintenance personnel from setting other parameters by mistake. After the parameters are locked the operating frequency can be changed by pressing Δ or \square .

| |
|---|
| <p>PD001 Source of Operation Commands Set Range: 0-2 Unit: 1 Factory Setting: 0</p> |
|---|

0: Set by the Operator
Operation commands are given via the digital operator.
1: Set by external terminals.
Operation commands are given via external terminals, i.e. **multi-input terminals**



2: Set by communication ports.
Operation commands are given via communication ports.

| |
|---|
| PD002 Source of Operating Frequency Set Range: 0-3 Unit: 1 Factory Setting: 0 |
|---|

0: Set by the operator. The operating frequency which given via the digital operator is Pd003.
 1: Set by external terminals. Operating frequency is controlled by analog signals input via external terminals. The signal type is determined by PD070. For the related parameters refer to PD070-PD076.
 2: The MODBUS is given. Operating frequency is given via the serial communication.

| |
|---|
| PD003 Main Frequency ** Set Range: 0.00-400.00 Hz Unit: 0.01 Hz Factory Setting: 0.00 |
|---|


In the digital operator mode, the inverter will run at the set value of PD003. During running, the operating frequency can be changed by pressing ▲ or ▼. During multi-speed running, the main frequency is taken as the frequency of Speed 1.
 In the external control multi-speed mode, if PD002 is set to 1, i.e. given by an external terminal, Speed 1 will be given by the analog of the external terminal.
 The setting of main frequency is limited by the maximum operating frequency.
 The related parameters of PD002, PD080 are adjustable during operation.

| |
|--|
| PD004 Base Frequency Set Range: 0.01-400.00 Hz Unit: 0.1 Hz Factory Setting: 50.00 |
|--|

This parameter must be set according to the rated frequency of operating voltage on the motor's nameplate. Under normal conditions do not change the set value of base frequency at will. If it is equipped with a special motor this value should be set properly according to the characteristics of the motor's parameters. Otherwise it may cause the damage to the equipment.

| |
|--|
| PD005 Max. Operating Frequency Set Range: 10.00-400.00 Hz Unit: 0.01 Hz Factory Setting: 50.00 |
|--|

This parameter is set for the maximum operating frequency of the inverter.
 The following are several curves and set values often used for reference. Specific curves must be set according to concrete characteristics of mechanical load.



| |
|--|
| PD006 Intermediate Frequency Set Range: 0.01-400.00 Hz Unit: 0.01 Hz Factory Setting: 2.50 |
|--|

Note: ** means this parameter is adjustable during operation.
 This parameter is set for intermediate frequency of arbitrary V/F curve. If it is set improperly, it will cause over-current or under-torque of the motor, or even tripping of the inverter.
 This set value of intermediate frequency is limited by the set value of base frequency.

| |
|--|
| PD007 Min. Frequency Set Range: 0.12-0.00 Hz Unit: 0.01 Hz Factory Setting: 0.50 |
|--|

This parameter is set for the min. starting frequency of V/F curve.
 The following table has specific factory settings of V/F curve, accel./decel., time and carrier for the inverter of AA-, AB-, AM series:

| Code Model | Pd009 | Pd010 | Pd014 | Pd015 | Pd041 | Code Model | Pd019 | Pd010 | Pd014 | Pd015 | Pd041 |
|------------|-------|-------|-------|-------|-------|------------|-------|-------|-------|-------|-------|
| HY00D423B | 15.0 | 7.5 | 5 | 5 | 9 | 003043A | 17 | 8.5 | 30 | 30 | 4 |
| HY0D7523B | 14.0 | 7 | 8 | 8 | 9 | 003743A | 16 | 8 | 35 | 35 | 4 |
| HY01D523B | 14.0 | 7 | 10 | 10 | 8 | 004543A | 16 | 8 | 40 | 40 | 4 |
| HY02D223B | 13.0 | 6.5 | 10 | 10 | 8 | 005543A | 15 | 7.5 | 45 | 45 | 3 |
| HY03D723B | 13.0 | 6.5 | 15 | 15 | 7 | 007543A | 15 | 7.5 | 50 | 50 | 3 |
| HY0D7543B | 22 | 11 | 8 | 8 | 9 | 022043A | 11 | 5.5 | 250 | 250 | 2 |
| HY01D543B | 22 | 11 | 10 | 10 | 8 | 025043A | 11 | 5.5 | 250 | 250 | 2 |



| Code Model | Pd009 | Pd010 | Pd014 | Pd015 | Pd041 | Code Model | Pd019 | Pd010 | Pd014 | Pd015 | Pd041 |
|------------|-------|-------|-------|-------|-------|------------|-------|-------|-------|-------|-------|
| HY02D243B | 21 | 10.5 | 15 | 15 | 8 | 028043A | 11 | 5.5 | 250 | 250 | 2 |
| HY03D743B | 21 | 10.5 | 15 | 15 | 7 | 030043A | 10 | 5 | 250 | 250 | 2 |
| HY05D643B | 20 | 10 | 15 | 15 | 6 | 031543A | 10 | 5 | 250 | 250 | 2 |
| HY07D643B | 20 | 10 | 20 | 20 | 6 | 034543A | 10 | 5 | 250 | 250 | 2 |
| HY11D043B | 19 | 9.5 | 20 | 20 | 5 | 037543A | 10 | 5 | 250 | 250 | 2 |
| HY15D043B | 19 | 9.5 | 20 | 20 | 5 | 040043A | 10 | 5 | 250 | 250 | 2 |
| HY18D543B | 18 | 9 | 25 | 25 | 5 | 041543A | 10 | 5 | 250 | 250 | 2 |
| HY22D043B | 18 | 9 | 25 | 25 | 5 | | | | | | |

- Note:**
- ① Ramp Time 2 = Ramp Time 1 x 2
 - ② Ramp Time 3 = Ramp Time 2 x 2
 - ③ Ramp Time 4 = Ramp Time 3 x 2
 - ④ Min. Voltage Value = Intermediate Voltage Value/2
 - ⑤ The intermediate frequency is 2.5 for the system of 50Hz.
 - ⑥ The intermediate frequency is 3.0 for the system of 60Hz.

PD008 Max. Voltage
 Set Range: 0.1~* Unit: 0.1V Factory Setting: 220/380V

This parameter should be set according to the rated value of the motor's name plate. The factory setting is 380V for 380V class motor and 220V for 220V class motor. The setting range of this parameter is restricted by the voltage rating of the inverter. In case of the motor relatively far away from the inverter this set value can be increased properly.

PD009 Intermediate voltage
 Set Range: 0.15~10.0V Unit: 0.1V Factory Setting: *

This parameter is set for an intermediate voltage value of arbitrary V/F curve. If it is set improperly, it will cause over-current or under-torque of the motor, or even tripping of the inverter.

When the intermediate frequency is increased the voltage will increase the output torque and at the same time also the output current. When changing this parameter please pay attention to monitoring the output current to avoid the inverter's tripping due to over-current.

The factory setting of intermediate voltage for 220V class inverter is 15, while the factory setting of intermediate voltage of 380V class inverter is 27.5.

This set value of intermediate voltage is limited by the set value of max voltage. When the voltage is increasing to a certain value at intermediate frequency the torque compensation will lose its function.

When adjusting this parameter the output current of the inverter should be increased from low to high slowly according to the load of machines until it meets the starting requirement. Do not be quick to increase it by large amplitude. Otherwise it might cause the tripping of the inverter or the damage of the machines.

PD010 Min. Voltage
 Set Range: 0.1~50.0V Unit: 0.1V Factory Setting: *

This parameter is set for the min. starting voltage of V/F curve. The factory setting of min. voltage for 220V class inverters is 8, and the factory setting of min. voltage for 380V class inverters is 13.5. This set value is limited by the voltage at the max. Frequency.

PD011 Frequency Lower Limit
 Set Range: 0.00~400.00 Unit: 0.01 Hz Factory Setting: 0.00

This is set for preventing workers from false operation to avoid over-heat or some other mechanical faults, which might be caused due to too low operating frequency. The setting of Frequency Lower Limit must be less than the set value of Frequency Upper Limit.

PD012 Reserved

PD013 Parameter Reset

When the value for a parameter is set improper or is abnormal for some reasons this parameter can be set to 01 to restore it to the factory setting and then reset. After the parameters are locked (in case of PD000=1) the parameters can't be reset. They can only be reset after unlock. For related parameters refer to Pd000.

PD014 Accel. Time 1 **
 Set Range: 0.16~500.0S Unit: 0.1S Factory Setting: *

PD015 Decel. Time 1 **
 Set Range: 0.16~500.0S Unit: 0.1S Factory Setting: *

PD016 Accel. Time 2 **
 Set Range: 0.16~500.0S Unit: 0.1S Factory Setting: *

PD017 Decel. Time 2 **
 Set Range: 0.16~500.0S Unit: 0.1S Factory Setting: *

PD018 Accel. Time 3 **
 Set Range: 0.16~500.0S Unit: 0.1S Factory Setting: *


PD019 Decel. Time 3 **
 Set Range: 0.16~500.0S Unit: 0.1S Factory Setting: *

PD020 Accel. Time 4 **
 Set Range: 0.16~500.0S Unit: 0.1S Factory Setting: *

PD021 Decel. Time 4 **
 Set Range: 0.16~500.0S Unit: 0.1S Factory Setting: *



Ramp-up time means the time needed for the inverter to increase the frequency from 0Hz to the maximum operating frequency (See t1 in the diagram). Ramp-down Time means the time needed for the inverter to decrease the frequency from the maximum operating frequency to 0Hz (See t2 in the diagram).



Note:

The versions previous to Vr2.0 took 50Hz as the base of ramp time. HY-A Series inverter have altogether 4 Ramp Times. For Ramp Time 2,3,4 the user can select the different ramp up or down time through the external terminals or switching of ramp time according to the actual needs. In the internal control multi-speed operation, different ramp time can be selected through easy PLC. Generally the default of the inverter is Ramp Time 1, which is factory set depending on the model. Ramp Time 4 is for the jogging ramp time. For the factory setting of parameters refer to the table in Pd007. The related parameters: PD044-PD049 and PD084,PD085

| | |
|-------|------------------|
| PD022 | Factory Reserved |
|-------|------------------|

| | | | | |
|-------|---------------------|----------------|---------|--------------------|
| PD023 | Rev Rotation Select | Set Range: 0-1 | Unit: 1 | Factory Setting: 0 |
|-------|---------------------|----------------|---------|--------------------|

0: Rev Rotation disable
1: Rev Rotation Enable
This function is suitable for the motor, which is not allowed to rotate reversely, to prevent workers from false operation. When the reverse rotation is disabled, the motor can only rotate forward, not reverse.

| | | | | |
|-------|----------|----------------|---------|--------------------|
| PD024 | STOP key | Set Range: 0-1 | Unit: 1 | Factory Setting: 1 |
|-------|----------|----------------|---------|--------------------|

0: STOP invalid.
1: STOP valid.
This parameter set is only valid when PD001 is set to 1 or 2.
When the control mode is set for external terminals or communication control, STOP key on the panel can be chosen to be valid or invalid. When choosing it as valid, STOP key can stop the inverter in running. When it needs to restart, the former running signal must be released before restarting the inverter.


| | | | | |
|-------|---------------|----------------|---------|--------------------|
| PD025 | Starting Mode | Set Range: 0-1 | Unit: 1 | Factory Setting: 0 |
|-------|---------------|----------------|---------|--------------------|

Two starting modes are available for the needs of different equipment.

0: Start from the starting frequency.
When PD029 is set to 0, i.e. DC braking is invalid at start, it starts running from the starting frequency. When PD029 is set to any non-zero value, i.e. DC braking is valid at start, it first performs a DC braking at start, and then starts from the starting frequency.
For the Related parameters refer to PD027, PD029 and PD031.

1: Start by frequency track
This setting can be used for the restarting of large inertia load. When restarting, the inverter will trace the former frequency from the set frequency downward. In case of large inertia equipment, when restarting, it can implement the running command and track the former frequency right away without waiting for the complete stop of the equipment to save time.

Note: When the inverter is restarted by frequency track, it will start tracking the frequency from its set frequency downward, and search it at the highest speed. When restarting, the current becomes higher, and over-current or stall may occur. So attention must be paid to the adjustment of current level of frequency track. Generally, PD033 is adjusted around 100. The concrete value can be set according to the characteristics of mechanical load.



| | | | | |
|-------|---------------|----------------|---------|--------------------|
| PD026 | Stopping Mode | Set Range: 0-1 | Unit: 1 | Factory Setting: 0 |
|-------|---------------|----------------|---------|--------------------|

0: Decelerating Stop
When PD030 is set to 0, DC braking is invalid. When DC braking is invalid, the inverter will decelerate to the stopping frequency, and then stop outputs, and the motor will coast to stop. When PD030 is set to any non-zero value, DC braking is valid, and the inverter will first decelerate to the stopping frequency, and then stop by DC braking.

DC braking at stop is usually used for high position stop or for positioning control. It must be noticed that frequent uses of DC braking will cause over-heat of the motor.
For the related parameters refer to PD028, PD030 and Pd031.

1: Coasting Stop
When the inverter receives a STOP command, it will immediately stop output and the motor will coast to stop. When the coasting stop mode is selected, DC braking is invalid.

| | | | | |
|-------|--------------------|------------------------|-------------|----------------------|
| PD027 | Starting Frequency | Set Range: 0.1-10.0 Hz | Unit: 0.1Hz | Factory Setting: 0.5 |
|-------|--------------------|------------------------|-------------|----------------------|



Starting frequency is the initial frequency when the inverter is started. If the starting frequency is set to 5.0Hz, the inverter will run between 5.0 Hz and the maximum operating frequency after its start at 5.0Hz.

For the related parameters refer to PD025, PD029 and PD031.


| | | | |
|---------------------------------|-------------|----------------------|--|
| PD028 Stopping Frequency | | | |
| Set Range: 0.1–10.0 Hz | Unit: 0.1Hz | Factory Setting: 0.5 | |

When stopping the inverter will decrease its frequency to the stopping frequency and then stop running or start DC braking to stop.

If PD030 is set to 0, DC braking is invalid at stop and the inverter will stop running.

If PD030 is set for valid, the inverter will stop by DC braking when the inverter reduce to PD028. For the related parameters refer to PD026, PD031 and Pd030.

| | | | |
|---------------------------------------|-------------|----------------------|--|
| PD029 DC Braking Time at Start | | | |
| Set Range: 0.02–5.0S | Unit: 0.1 S | Factory Setting: 0.0 | |




This parameter is set for DC braking at start and the lasting time of DC braking current to the motor. If it is set to zero it means DC braking is invalid.

DC braking at start is normally used in the application, in which the load is movable when the machine is at stop, such as windmill. Because of the load existing before the inverter drives, the motor is often in coasting with an uncertain rotation direction. So the DC braking can be executed before starting the motor to prevent the inverter from tripping.

This setting is valid only when PD025 is set to 0. For the related parameters refer to PD025, PD029 and Pd031.

| | | | |
|--------------------------------------|-------------|----------------------|--|
| PD030 DC Braking Time at stop | | | |
| Set Range: 0.0–25.0 | Unit: 0.1 S | Factory Setting: 0.0 | |



Note: When this parameter is set to any non-zero value it starts DC brake at stop and sends the DC braking time to the motor. DC braking at stop is often used for a high-level stop or positioning control. When this parameter is set to zero it closes DC braking at stop.

This setting is valid when PD026 is set to 0. For the related parameters refer to PD026, PD028 and Pd031.

| | | | |
|---------------------------------------|------------|----------------------|--|
| PD031 DC Braking Voltage Level | | | |
| Set Range: 0.0–20.0% | Unit: 0.1% | Factory Setting: 2.0 | |

This parameter is set for the DC braking voltage to the motor at start and stop. It can be adjusted for different braking voltage. When adjusting the parameter it must be increased slowly from lower value to high value until the sufficient braking torque is achieved.

The voltage at maximum frequency is 100% voltage.

| | | | |
|-----------------------------------|-------------|----------------------|--|
| PD032 Frequency Track Time | | | |
| Set Range: 0.12–0.0S | Unit: 0.1 S | Factory Setting: 5.0 | |

This parameter is set as frequency track time when the inverter is started by frequency track after an external abnormality or temporary power breakdown. For starting or stopping of some large inertia load, if restarting a machine after its complete stop, it will waste much time because of its large inertia of load. But if the frequency track is started, it is not necessary to wait for the machine to come to a full stop for restart. The inverter will trace the frequency from high to low with the set frequency. After searching it will continue to accelerate to reach the set frequency.

| | | | |
|--|----------|----------------------|--|
| PD033 Current Level for Frequency Track | | | |
| Set Range: 0–200% | Unit: 1% | Factory Setting: 150 | |

When the inverter is tracing the frequency this set value is taken as the level for output current. When the output current is higher than this level the inverter will decrease the frequency to restore the current below the level and then it will execute the frequency track again.

| | |
|---|----------------------|
| PD034 Inverter Track Time of Up/down | Factory Setting: 0.5 |
|---|----------------------|

When the inverter is started by frequency track, in the track process, the voltage will up, when the voltage up-speed increase, the current will higher, the track process will faster. When the voltage up-speed decrease, the current will lower, the track process will slower. The generally setting way is the low power machine establishes small, the high power machine establishes big.

| |
|-----------------------------|
| PD035 Pd040 Reserved |
|-----------------------------|

| | |
|--------------------------------|--------------------------------------|
| PD041 Carrier Frequency | (Note: 015 corresponds to 020K Hz) |
| Set Range: 0–15 | Unit: 1 Factory Setting: 5 |

The carrier frequency has some relation with the electromagnetic noise of the motor, and mean while the level of the carrier frequency has certain relation with the heating capacity of the inverter and the interference to the environment. See the following table:

| Carrier Frequency | Electromagnetic Noise | Heating Capacity | Interference to the Environment |
|-------------------|-----------------------|------------------|---------------------------------|
| Low | High | Small | Little |
| ↓ | ↓ | ↓ | ↓ |
| High | Low | Large | Great |



Carrier Frequency Corresponding Table

| | | | | | | | | | | | | | | | | |
|------------------------------|-----|---|-----|---|---|---|---|---|---|---|----|----|----|----|----|----|
| Set Value | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 |
| Carrier Frequency Khz | 0.1 | 1 | 1.5 | 2 | 3 | 4 | 5 | 7 | 8 | 9 | 10 | 11 | 13 | 15 | 17 | 20 |

As shown in the table above, the higher the carrier is, the lower the electromagnetic noise of the motor will be, but the stronger its interference to other systems will be and the greater the heating capacity of the inverter will have. Under higher ambient temperature and heavier load of the motor the carrier frequency should be decreased properly to improve the heat characteristics of the inverter. The factory setting of carrier frequency is depending on the model.

| | | | |
|--------------------------------|------------|-----------------------|----|
| PD042 Jogging Frequency | | | ** |
| Set Range: 0.00-400.00 | Unit: 0.01 | Factory Setting: 5.00 | |


The parameter set can realize the jogging function when the inverter is tested. The jogging operation can be only achieved through the external terminals, which can be set by multi-input terminals. Jogging frequency is limited by the frequency upper/lower limits. While the jogging function is implemented, other running commands are invalid. The ramp-up time of jogging frequency is set by Ramp-up Time 4. When the jog button is released the inverter will stop output immediately. In case of jogging function please set the corresponding multi-input terminals to 07 or 08.

This function is only valid at stop. It is invalid at running. For the related parameters refer to PD044-PD049.

| | | |
|---------------------------|---------|--------------------|
| PD043 S-Curve Time | | |
| Set Range: 0-6500S | Unit: 1 | Factory Setting: 1 |

This parameter can be set for no impact slow start or slow stop of the inverter when starting or stopping. When starting S-curve the inverter will make accelerating or decelerating curve of different speed rates according to Ramp Time.

When PD043 is set as 0, S-curve is invalid, i.e. it will accelerate or decelerate in linear. Without consideration of stall the actual accel/decal time = (PD014+PD043)/2. The parameter is only valid when Pd014 is less than Pd043.




| | | |
|-------|-------------------|---------------------|
| PD044 | FOR (D1) Function | Factory Setting: 02 |
| Pd045 | REV (D2) Function | Factory Setting: 03 |
| Pd046 | RST (D3) Function | Factory Setting: 04 |
| Pd047 | SPH (D4) Function | Factory Setting: 07 |
| Pd048 | SPM (D5) Function | Factory Setting: 19 |
| Pd049 | SPL (C6) Function | Factory Setting: 20 |
| | Set Range: 00-32 | Unit: No |

- 01: RUN Running. It can be combined with other terminals to compose multiple control modes.
- 02: FOR Forward Rotation
- 03: REV Reverse Rotation
- 04: STOP Stopping
- 05: FOR/REV Switching of FOR/REV rotation
- 06: JOG Jogging
- 07: Jog FOR
- 08: Jog REV
- 09: External Control Timer 1 Start: When the contact is closed, the timer will start and begin to count time. When the timer reaches the set point the corresponding multi-inputs will act.
- 10: External Control Timer 2 Start .
- 12: Over-heat of heat sink or motor: This contact can be used to detect over-heat of the heat sink or motor to protect the motor and inverter.
- 13: Emergent Stop: Emergent stop. It can receive external emergent stop command or other fault signals.
- 14: Reset: This terminal can be used for reset after a fault is removed.
- 15-16: Reserved.
- 17: Ramp Time 1: This terminal can be used to select the ramp time of the inverter.
- 18: Ramp Time 2: 4 kinds of ramp time are available for choice.
- 19: Multi-speed 1: 8-speed setting can be composed through Multi-speed 1, 2, 3.
- 20: Multi-speed 2
- 21: Multi-speed 3
- 22: High speed: High, middle and low speed can compose three kinds of operation mode
- 23: Middle speed with different frequencies. In the three terminals the high-end signal has
- 24: Low speed priority. Low, Middle and High Speed are determined respectively by Frequency 2,3,4.
- 25: PID Valid: When this contact is closed, PID function starts. PID Function start is only valid during operation.
- 26: PLC Reset Suspend: This contact can be used to achieve the function of AutoPLC clear suspend.
- 27: UP Function: When the switch of this terminal acts the frequency setting of the inverter will be increased or decreased by one unit. When the switch of the terminal is hold the frequency will increase or decrease rapidly to a point and then increase or decrease.




- 28: Down Function at even speed. When the power is up again after the power breakdown the changed frequency will not be memorized.
- 29: Drawing Start When this contact is triggered the drawing action starts.
- 31: Pulse Counter When this terminal is set for the counter it can receive the pulse signal of $\leq 250\text{HZ}$ and counts.
- 32: Counter Reset When this contact acts it will clear the present counting values displayed, restore C00 and restart counting.



Explanation:

1. Three multi-function terminals can be used for the connection method of three-wire system for the realization of switching of FOR/REV rotation, which is extensively applied in the cases of FOR/REV switching of photoelectric switches.

- ① Select the multi-function terminals of D1、D2 and D3
- ② Parameter setting:
PD001=1 for external control PD044=02 for FOR rotation
PD045=03 for REV Rotation PD046=04 for Stop
- ③ Action Description:
When triggering D1, the inverter will rotate forward (start);
When triggering D2, the inverter will rotate reverse;
When pressing STOP, the inverter will stop.



2. RUN, DCM, F/R can be used for Start, Stop and switching of FOR/REV:


- ① Select the terminals of D1 and D2
- ② Parameter setting:
PD001=1 for external control
PD044=01 for RUN function
PD045=05 for switching of F/R
When K2 is opened it rotates forward, while K2 is closed it rotates reverse.

3. Description of Ramp Time 1 and 2:

- ① This function is only valid when PD080 is set to 0, 2 and 3. Under the disturbance and internal control multi-speed it is invalid.
- ② Any two multi-inputs can be combined for 4 kinds of ramp time for selection.
- ③ The related multi-inputs are set for Ramp Time 1, 2. Take the terminals of D4 and D5 as example, when the terminal of D4 PD047 is set to 22 and the terminals of D5 PD048 is set to 23, D4 and D5 are now Ramp Time 1, 2.

| D4 | D5 | Result |
|-----|-----|-------------|
| OFF | OFF | Ramp Time 1 |
| ON | OFF | Ramp Time 2 |
| OFF | ON | Ramp Time 3 |
| ON | ON | Ramp Time 4 |

4. Function description of High, Middle and low speed terminals:




| RUN | D6 | D5 | D4 | Result |
|-----|--------|--------|-----|---|
| ON | OFF | OFF | OFF | Main speed, the frequency runs at the set value of Pd003. |
| ON | ON | OFF | OFF | Low speed, the frequency runs at the set value of Pd086. |
| ON | ON/OFF | ON | OFF | Middle speed, the frequency runs at the set value of Pd087. |
| ON | ON/OFF | ON/OFF | ON | High speed, the frequency runs at the set value of Pd088. |

Note:

- (1) This function is only valid when PD080 is set to 2, i.e. for 4-Speed of external control.
- (2) Ramp time is determined by Ramp Select terminal.
- (3) When all high, middle and low speeds have signal inputs it will give priority in the sequence of high, middle and low speed.



5. Description of UP and DOWN Function:




| UP | DOWN | Result |
|-----|------|--------------------------|
| ON | OFF | Frequency increase |
| OFF | ON | Frequency decrease |
| ON | ON | Not increase or decrease |

Note:

- (1) The function of UP and DOWN is only valid when the operator is selected for the source of the operating frequency, i.e. PD002=0.
- (2) When the UP terminal is closed the frequency of the inverter will increase.
- (3) When the DOWN terminal is closed the frequency of the inverter will decrease.
- (4) When both UP and DOWN terminals are closed at the same time the frequency will neither increase nor decrease. It is regarded as invalid.
- (5) When the frequency reaches the max operating frequency it will stop increasing.
- (6) When the frequency reaches the min frequency or its lower limit, it will stop decreasing.
- (7) After a power breakdown the set value of PD003 will be memorized instead of the frequency.
- (8) When using the function of UP and DOWN, the keys of Δ \square of the panel are valid. After changing the values it needs to press SET (ENTER) key for confirmation and then the inverter can implement the action. Meanwhile the value will write to PD003, which will be memorized after a power breakdown.
- (9) When keeping pressing UP or DOWN, the frequency will increase or decrease rapidly to a point and then increase or decrease at even speed.
- (10) The value changed by UP or DOWN can be set through PD077 for confirmation of whether it should be memorized or not memorized. For details refer to Pd077.

6. Function Description of Counter:



Note:

- (1) The signal width triggered should not be lower than 2 msec ($t1, t2 \geq 2\text{msec}$).
- (2) When the counting value is reached the corresponding multi-output contact will act.
- (3) This counter can only count again after reset.
- (4) When reaching to 65535 the counter will not count again.

| | | |
|------------------|---------------------------|---------------------|
| PD050 | Y1-input Function | Factory Setting: 01 |
| PD051 | Y2-input Function | Factory Setting: 03 |
| PD052 | FA, FB, FC Input Function | Factory Setting: 01 |
| PD053 | Ka, KB Input Function | Factory Setting: 03 |
| Set Range: 00-32 | | Unit: 1 |

- 01: In Run: The contact will act when the inverter has output or receives the running command.
- 02: Zero Speed: The contact will act when the output frequency of the inverter is less than its starting frequency.
- 03: Fault Indication: The contact will act when the inverter detects abnormal conditions.
- 04: DC Braking Indication: The contact will act when the inverter is in DC braking.
- 05: Set Frequency Reach: The contact will act when the output frequency of the inverter reaches the set frequency.
- 06: In Accel: The contact will act when the inverter is in ramp-up.
- 07: In Decel: The contact will act when the inverter is in ramp-down.
- 08: Uniform Frequency 1 Reach: The contact will act when the output frequency of the inverter reaches the designated frequency (PD060).
- 09: Uniform Frequency 2 Reach: The contact will act when the output frequency of the inverter reaches the designated frequency (PD061).
- 10: Motor Overload Alarm: The contact will act when the inverter detects over-load of the motor.




When the output frequency is more than the uniform frequency the corresponding multi-outputs will act. The uniform frequency range acts as a hysteresis loop.

When the inverter is in the operation of multi-pumps, PD060 is used as high speed frequency and PD061 is set as low speed operating frequency. The definitions of the corresponding multi-function contacts are changed.

| | | | |
|------------|--------------|---------|----------------------|
| PD063 | Timer 1 Time | | |
| Set Range: | 0.1 ~ 10.00 | Unit: 1 | Factory Setting: 0.1 |
| PD064 | Timer 2 Time | | |
| Set Range: | 1 ~ 100 | Unit: 1 | Factory Setting: 1 |

Timer 1 is a timer of 0.1s~10.0s and Timer 2 is a timer of 1s~100s. When the timer start at multi-inputs is closed (on) the timer starts to count time. When it reaches the set time the corresponding multi-output contact will act. When the timer start is opened (off) the timer time at the multi-output will be reset.



For example, set PD063=5.0s. When the external control terminal (Multi-Input) is valid the output terminal will be valid after five (5.0) seconds, the signal of which can be used to control other corresponding signals.

| | | | |
|------------|----------------|---------|--------------------|
| PD065 | Counting Value | | ** |
| Set Range: | 0~65500 | Unit: 1 | Factory Setting: 0 |

An external terminal of multi-function can be used as a trigger for the counter. When the counter reaches the set value of PD065 the corresponding multi-output contact will act. After the counter is cleared and reset it will start counting again. A proximity switch or optoelectronic switch can be used for the triggering signals.

| | | | |
|------------|----------------------|---------|--------------------|
| PD066 | Intermediate Counter | | |
| Set Range: | 0~65500 | Unit: 1 | Factory Setting: 0 |

Refer to PD065.

| | |
|-------------|----------|
| PD067 PD069 | Reserved |
|-------------|----------|

| | | | |
|------------|--------------|---------|--------------------|
| PD070 | Analog Input | | |
| Set Range: | 0~4 | Unit: 1 | Factory Setting: 0 |

0: 0~10V 1: 0~5V 2: 0~20mA
 3: 4~20mA 4: 0-10V 4-20mA stacked
 This parameter can be set for different analog input signals.
 When PD070=4, the output frequency = $1/2 (U/U_{max} + I/I_{max}) \times 50\text{Hz}$
 Among which: U: Analog Voltage U_{max} : Maximum Analog Voltage
 I: Analog Current I_{max} : Maximum Analog Current

| | | | |
|------------|---------------------------|---------|---------------------|
| PD071 | Analog Filtering Constant | | |
| Set Range: | 0~50 | Unit: 1 | Factory Setting: 20 |

The setting of this parameter is related to the analog responding speed. The higher the value of PD071 is set, the lower the analog responding speed will be.

| | | | |
|------------|------------------------------------|---------------|------------------------|
| PD072 | Higher Analog Frequency | | |
| Set Range: | 0.00~400.00 Hz | Unit: 0.01Hz | Factory Setting: 50.00 |
| PD073 | Lower Analog Frequency | | |
| Set Range: | 0.00~400.00 Hz | Unit: 0.01 Hz | Factory Setting: 0.00 |
| PD074 | Bias Direction at Higher Frequency | | |
| Set Range: | 0~1 | Unit: 1 | Factory Setting: 0 |
| PD075 | Bias Direction at Lower Frequency | | |
| Set Range: | 0~1 | Unit: 1 | Factory Setting: 0 |


0: Positive direction
 1: Negative direction

Bias direction means the instruction of FOR/REV rotation command. Positive bias indicates forward rotation while negative bias indicates reverse rotation. For details refer to the diagram in Pd076.

| | | | |
|------------|------------------------------|---------|--------------------|
| PD076 | Analog Negative Bias Reverse | | |
| Set Range: | 0~1 | Unit: 1 | Factory Setting: 0 |


0: Negative bias Rev is not allowable.
 1: Negative bias Rev is allowable.

The parameter group is set for the measuring range and zero point of the external analog terminals and can be combined for any kind of curve to control the operation of the motor.




Setting: PD073=50 PD075=1 PD072=50
 PD074=0 PD076=1

Note: this curve can be easily used in complicated applications in combination with other curves. When using it the instruction of FOR/REV run from external terminals is still valid. When switching, the curve will turn reverse.




Setting: PD073=50 PD075=1 PD072=50
PD074=0 PD076=1

Note: this curve is a kind of special application of reverse ramp setting. When using transmitter for the control of pressure, temperature and others and while the control has higher pressure and output signals but requiring the corresponding commands of stop or deceleration on the inverter this curve can satisfy the demand properly.



Setting: PD073=50 PD075=1 PD072=50
PD074=0 PD076=1

Note: this method is used extensively. The user can use it flexibly.



Setting: PD073=10 PD075=1 PD072=50
PD074=0 PD076=0

Note: the signal of 0Hz-40Hz (4-4.8mA) is invalid. It can be used to avoid noise disturbance. In harsh environment it is better not to use signals below 1V for setting the operating frequency of the inverter.

| |
|---|
| PD077 UP/DOWN Function |
| Set Range: 0-1 Unit: 1 Factory Setting: 0 |

0: Not memorized 1: Memorized

This parameter can be set for the selection of whether the values changed by the UP or DOWN shall be memorized or not after stop. The changed values whether to be memorized or not means when they are changed by UP or DOWN during operation and the inverter is restarted after stop these changed values shall be memorized or not after restart. When PD077 is set to 0, the changed value will not be memorized and when it is set to 1, the changed values will be memorized. The set values of PD003 will be memorized after restart.

For the related parameters refer to PD044-PD049.

| |
|---|
| PD078 UP/DOWN Speed |
| Set Range: 0-1 Unit: 1 Factory Setting: 0 |

0: 0.01Hz. Minimum UP/DOWN speed is 0.01Hz.

1: 0.1Hz. Minimum UP/DOWN speed is 0.1Hz.

Through the changes of this set value the UP/DOWN speed unit can be adjusted to meet the needs of different customers.

| |
|---|
| PD079 Reserved |
| PD080 PLC Operation |
| Set Range: 0-5 Unit: 1 Factory Setting: 0 |

0: Normal operation, i.e. the inverter is running in the normal control mode.

1: Internal control Multi-speeds(16-speeds)

Note:

① Main speed and 7-speeds composes 8-speeds.

② The ramp time of each speed step is set by PD084, PD085.

③ Running Time is set by Timer PD101~PD116. For the control steps not to be used the timer can be set to 0.

④ Running direction of each speed step is determined by PD082, PD083.

⑤ In the internal control multi-speed operation the running time and direction are determined by the setting of internal parameters. Any switching of external time and FOR/REV rotation is invalid.

2: External control 4-Speeds (Refer to the function description and diagram of three terminals of high, middle and low speed in PD044~PD049)

3: External control Multi-speeds

| Multi-function Terminals | | | Results |
|--------------------------|---------------|---------------|--|
| Multi-speed 1 | Multi-speed 2 | Multi-speed 3 | |
| OFF | OFF | OFF | Main frequency and frequencies are determined by PD003 or potentiometer. |
| ON | OFF | OFF | Multi-speed 1 and frequency are determined by PD086. |
| OFF | ON | OFF | Multi-speed 2 and frequency are determined by PD087. |
| ON | ON | OFF | Multi-speed 3 and frequency are determined by Pd088. |
| OFF | OFF | ON | Multi-speed 4 and frequency are determined by PD089. |
| ON | OFF | ON | Multi-speed 5 and frequency are determined by PD090. |
| OFF | ON | ON | Multi-speed 6 and frequency are determined by PD091. |
| ON | ON | ON | Multi-speed 7 and frequency are determined by Pd092. |

Note:

① It is only valid to realize the external control 8-Speeds operation when Multi-inputs are set for Multi-speed 1, 2, 3 and PD080 is set to 3.

② Multi-speed 1, 2, 3 can be used to make up 7-Speeds and 8-Speeds adding the main frequency.

③ The frequencies of Speed Step 1~Step 7 are determined by PD086~PD092.

④ Each ramp time is determined by the external multi-function terminal D1-D6.


⑤ The directions of each program operation are determined by the external multi-function terminals D1-D6.

⑥ The main frequency can be set in two ways. One method is to set it through PD003 and another is to set it through the potentiometer. When PD002 is set to 1 the frequency of Main Frequency is set by the potentiometer. For the related parameters refer to PD003, PD002 and PD086~PD092.



4: Drawing

This is a special parameter for the constant speed of unwinding and rewinding. By using this function the linear speed constant in certain accuracy can be realized.



Note:

- ① Through triggering of the external multi-function terminal the drawing action begins.
- ② In implementation of the drawing action the actual running time is $T=PD101 \times 10$.
- ③ when the drawing action is finished the inverter will run at the constant speed of PD087 and the corresponding multi-output contact will act at the same time. Until receiving the STOP command the inverter will stop running and the multi-output contact will reset.

5:Disturbance (Traverse function)

This is a special parameter in the chemical fiber and printing and dyeing industries to realize the traverse function. Except the commands of stop, external faults and emergency stop all other commands are not accepted at running.

Note:


- ① The frequency at each inflection point is determined by PD003 and PD086.
- ② Skip Frequency is determined by PD092.
- ③ Running Time is determined by Timer PD101 and PD102.
- ④ The related parameters: PD003, PD086~PD116.

| |
|---|
| PD081 Auto PLC |
| Set Range: 0-3 Unit: 1 Factory Setting: 0 |

- 0: Stop after the program runs one cycle.
 - 1: Cycling running.
 - 2: Stop after it runs one cycle automatically (STOP for intervention) .
 - 3: Auto running and cycling (STOP for intervention)
- This parameter setting is only valid when PD080 is set to 4. For relevant parameters refer to PD003, Pd080 and CD082~PD116.

Explanation:

1. Stop after the program runs one cycle.
When the command of auto program operation is given, the inverter will run with each set value of internal parameters. It will run for one cycle and then stop automatically. The inverter will not restart and run until it receives another command of operation.
2. Cycling run.
When the command of operation is given, the inverter will run in sequence with the frequency of every speed step and running time set by each of the internal parameters and will recycle. During the cycling run, except the commands of stop, external faults and emergency stop, all other commands will not be accepted.
3. Stop after it runs one cycle automatically (STOP for intervention)



Note:

- ① When the command of auto program operation is given the inverter will run with each parameters. But it will stop first and then restart at changing of each step and will stop automatically after running for one cycle. The inverter will not restart and run until it receives another command of operation.
- ② The frequencies of each speed step are set by PD003 and PD086 ~ PD092.
- ③ The running times of each speed step are set by PD101 ~ PD108.
- ④ The running direction is set by P082

| |
|---|
| PD082 PLC Running Direction of the Front 8-Speeds |
| PD083 PLC Running Direction of the Follow 8-Speeds |
| Set Range: 0-255 Unit: 1 Factory Setting: 0 |

This parameter is only valid when PD080 is set to 1 This parameter setting determine the running direction of each frequency of PD086~PD092 and PD003 in the program operation. The setting method is as follows:
The rotation direction is set first in the binary 8 bits mode, and then converted to a decimal value for the setting of this parameter. For instance:

The parameter value 01001010 is converted to a decimal value:
 $1 \times 2^7 + 1 \times 2^6 + 1 \times 2^2 = 64 + 8 + 2 = 74$
Then PD082=74
PD083 means that set running direction of the follow 8-speeds(the algorithm likes Pd082)

| |
|---------------------------------------|
| PD084 Ramp Time of the Front 8-Speeds |
|---------------------------------------|



| |
|--|
| PD085 Ramp Time of the Follow 8-Speeds |
| Set Range: 0-65535 Unit: 1S Factory Setting: 0 |

This parameter is only valid when PD080 is set to 1.
 This parameter is set to determine the ramp time values for the internal control multi-speed and each speed. The setting method is as follows:

① Determine each Ramp Time in the binary 2 bit mode

| Bit1 | Bit0 | Ramp Time |
|------|------|--------------------------|
| 0 | 0 | Ramp Time 1 PD014, PD015 |
| 0 | 1 | Ramp Time 2 PD016, PD017 |
| 1 | 0 | Ramp Time 3 PD018, PD019 |
| 1 | 1 | Ramp Time 4 PD020, Pd021 |

② Determine the Ramp time of each speed step in the binary 16 bit mode

| Step 8 | Step 7 | Step 6 | Step 5 | Step 4 | Step 3 | Step 2 | Step 1 |
|--------|--------|--------|--------|--------|--------|--------|--------|
| t8 | t7 | t6 | t5 | t4 | t3 | t2 | t1 |
| 0 | 0 | 0 | 0 | 0 | 1 | 1 | 0 |
| 0 | 0 | 0 | 0 | 0 | 0 | 0 | 1 |

t1 Select Ramp Time 4
 t2 Select Ramp Time 1
 t3 Select Ramp Time 3
 t4 Select Ramp Time 2
 t5 Select Ramp Time 1
 t6 Select Ramp Time 1
 t7 Select Ramp Time 1
 t8 Select Ramp Time 1

The setting value:
 $1 \times 2^8 + 1 \times 2^7 + 1 \times 2^6 + 1 \times 2^5 = 99$
 So PD084 is set to 99
 Attach: $2^0=1$ $2^1=2$ $2^2=4$ $2^3=8$
 $2^4=16$ $2^5=32$ $2^6=64$ $2^7=128$

PD085 means that set ramp time of the follow 8-speeds(the algorithm likes Pd084)

| | | | |
|-------|-------------|-----------------|-----|
| PD086 | Frequency 2 | Factory Setting | 15 |
| PD087 | Frequency 3 | Factory Setting | 20 |
| PD088 | Frequency 4 | Factory Setting | 25 |
| PD089 | Frequency 5 | Factory Setting | 30 |
| PD090 | Frequency 6 | Factory Setting | 35 |
| PD091 | Frequency 7 | Factory Setting | 40 |
| PD092 | Frequency 8 | Factory Setting | 0.5 |

| | | | |
|---------------------------|--------------|-----------------|----|
| PD093 | Frequency 9 | Factory Setting | 10 |
| PD094 | Frequency 10 | Factory Setting | 15 |
| PD095 | Frequency 11 | Factory Setting | 20 |
| PD096 | Frequency 12 | Factory Setting | 25 |
| PD097 | Frequency 13 | Factory Setting | 30 |
| PD098 | Frequency 14 | Factory Setting | 35 |
| PD099 | Frequency 15 | Factory Setting | 40 |
| PD100 | Frequency 16 | Factory Setting | 45 |
| Set Range: 0.00-400.00 Hz | | Unit: 0.01 Hz | |

This parameter is set for cooperate the multi-terminals , can choose the external 4-speeds\the external control multi-speeds and the internal control multi-speeds.For the relevant parameter refer to PD080 and PD086-PD100

| | | | |
|-----------------------|----------|-----------------|------|
| PD101 | Timer 1 | Factory Setting | 10.0 |
| PD102 | Timer 2 | Factory Setting | 10.0 |
| PD103 | Timer 3 | Factory Setting | 0.0 |
| PD104 | Timer 4 | Factory Setting | 0.0 |
| PD105 | Timer 5 | Factory Setting | 0.0 |
| PD106 | Timer 6 | Factory Setting | 0.0 |
| PD107 | Timer 7 | Factory Setting | 0.0 |
| PD108 | Timer 8 | Factory Setting | 0.0 |
| PD101 | Timer 9 | Factory Setting | 0.0 |
| PD102 | Timer 10 | Factory Setting | 0.0 |
| PD103 | Timer 11 | Factory Setting | 0.0 |
| PD104 | Timer 12 | Factory Setting | 0.0 |
| PD105 | Timer 13 | Factory Setting | 0.0 |
| PD106 | Timer 14 | Factory Setting | 0.0 |
| PD107 | Timer 15 | Factory Setting | 0.0 |
| PD108 | Timer 16 | Factory Setting | 0.0 |
| Set Range: 0.06500.0S | | Unit: 0.1S | |

This parameter is set for the internal control multi-speeds and the running time of drawing function. For the relevant parameter refer to PD080 and PD101-PD116.

| | | | |
|---------------|---|------------------|---|
| Pd117 | Internal Control Multi-Speeds Memory Function | Factory Setting: | 0 |
| Set Range: 01 | | | |

0: Not memorized
 1: Memorized



This parameter is set to determine whether the inverter is to realize the suspending function in Auto PLC mode. In case of PD115=1 it can memorize the status in which the inverter is running and will memorize it at stop or fail. It will continue to run when returning to normal. In case of PD115=0 it will not memorize.

| | | |
|-------------------------------------|---------|--------------------|
| PD118 Over-voltage Stall Prevention | | |
| Set Range: 0-1 | Unit: 1 | Factory Setting: 1 |

- 0: Over-voltage stall prevention invalid
1: Over-voltage stall prevention valid.

When the inverter is in deceleration, due to the effect of load inertia, the motor will produce a return energy to the inverter and cause the DC voltage of the inverter to increase. So when the function of over-voltage stall prevention is started, if the DC voltage of the inverter becomes too high, the inverter will stop decelerating till the voltage at DC decreases below the set value, then the inverter will go on to decelerate and the ramp-down time will be extended automatically.

| | | |
|---|----------|----------------------|
| PD119 Stall Prevention Level at Ramp-up | | |
| Set Range: 0-200% | Unit: 1% | Factory Setting: 150 |

When the inverter is in ramp-up, due to overload or too short ramp-up time, the output current of the inverter will go up quickly and exceed the set standard level. When this happens, the inverter will stop accelerating. When the current returns under its set value, the inverter will go on to accelerate.

100% current is the rated current of the motor. When this parameter is set to 0, the stall prevention function is invalid.

| | | |
|--|----------|--------------------|
| PD120 Stall Prevention Level at Constant Speed | | |
| Set Range: 0-200% | Unit: 1% | Factory Setting: 0 |

When the inverter is running at constant speed, due to load fluctuation and other reasons, the current will increase. When the current exceeds its set standard value, the inverter will lower the output frequency. When the output current returns to its normal range, the inverter will accelerate again to its set frequency.

100% current is the Rated Current of the motor. When this parameter is set to 0 the stall prevention function is invalid.

| | |
|--|----------------------|
| PD121 Decel. Time for Stall Prevention at Constant Speed | Factory Setting: 5.0 |
|--|----------------------|

When the inverter is used for the loads of kinds of fan and pump PD119 can be set to 120. When the current of the inverter is greater than 120% the output frequency will decrease and the current will also decrease accordingly. After the current returns to normal the frequency will return to normal slowly, so as to achieve the stall prevention function. The decreasing speed of the frequency is determined by PD119. For the Related parameters refer to PD 119.

| | | |
|--|---------|----------------------|
| PD122 Stall Prevention Level at Deceleration | | |
| Set Range: 0-200% | Unit: 1 | Factory Setting: 150 |

Refer to Pd120.

100% current is the rated current of the motor.

| | | |
|-------------------------------|---------|--------------------|
| PD123 Over-torque Detect Mode | | |
| Set Range: 0-3 | Unit: 1 | Factory Setting: 0 |

- 0: When reaching the frequency it starts to detect over-torque and when over-torque is detected it continues to run.
1: When reaching the frequency it starts to detect over-torque and when over-torque is detected it stop running.
2: It detects over-torque during running and when over-torque is detected it continues to run.
3: It detects over-torque during running and when over-torque is detected it stop running.

| | | |
|--------------------------------|----------|--------------------|
| PD124 Over-torque Detect Level | | |
| Set Range: 0-200% | Unit: 1% | Factory Setting: 0 |

When the output current exceeds the over-torque detection level and also exceeds half of the set time of over-torque detection (factory setting: 1.0s), the over-torque detection will indicate, and the corresponding multi-function alarm contact will act. When it exceeds the set time, the inverter will turn to self-protection. When this parameter is set to 0, the over-torque detection will be invalid

| | | |
|-------------------------------|------------|----------------------|
| PD125 Over-torque Detect Time | | |
| Set Range: 0.1-20.0s | Unit: 0.1s | Factory Setting: 1.0 |

When the inverter detects that the output current has exceeded the motor current set value, the inverter begins to calculate the over-torque time. When the over-torque time has exceeded half of the set detect time, the corresponding multi-function output contact will act, and produce the over-torque alarm, while the inverter will keep running. When the over-torque time has exceeded the set detect time (set by PD125), the inverter will turn to self-protection, display the fault information and stop output.

For the related parameters refer to Pd123.

| | | |
|----------------------|---------|--------------------|
| PD126 Counter Memory | | |
| Set Range: 0-1 | Unit: 0 | Factory Setting: 0 |

- 0: Not memorized
1: Memorized

The function of counter memory, the function of inverter power-breakdown memory

| | | |
|---------------------|--|--|
| PD127PD129 Reserved | | |
|---------------------|--|--|

| | | |
|--------------------------------|---------|--------------------|
| PD130 Number of Auxiliary Pump | | |
| Set Range: 0-2 | Unit: 1 | Factory Setting: 0 |


This parameter is set for the number of auxiliary pump. The start or stop of the auxiliary pumps is controlled by using the multi-output contacts and Auxiliary Pump 1 or Auxiliary Pump 2 is controlled through the peripheral control circuit.

| | | |
|--|---------|---------------------|
| PD131 Continuous Running Time of Auxiliary Pumps | | |
| Set Range: 19000 (min) | Unit: 1 | Factory Setting: 60 |

In case of two pumps with only one pump in duty, in order to ensure each pump to work evenly, it will be switched to another pump when its running time reaches the set value of PD131.

| | | |
|---|---------|---------------------|
| PD132 Interlocking Time of Auxiliary Pump | | |
| Set Range: 1-250S | Unit: 1 | Factory Setting: 5S |

This parameter is set to determine the interlocking time of two auxiliary pumps when switching with each other.




PD133 High Speed Running Time
 Set Range: 1-250S Unit: 1 Factory Setting: 60S

In the application of water supply with constant pressure, when the master pump is running at the frequency of high speed (set by PD060) due to larger water volume and the high speed running time is reached, the corresponding multi-function contacts act and the auxiliary pumps start.

PD134 Low Speed Running Time
 Set Range: 1-250S Unit: 1 Factory Setting: 60S

In the application of water supply with constant pressure, when the master pump is running at the frequency of low speed (set by PD061) due to smaller water volume and the low speed running time (PD134) is reached, the corresponding multi-function contacts act and the auxiliary pumps stop.

PD133 and PD134 must be used in combination of PD060, PD061 and multi-outputs. Their main function is to increase or decrease the number of auxiliary pump.



PD135 Stopping Voltage Level
 Set Range: 0-150% Unit: 1 Factory Setting: 95%

This parameter is set for the voltage level of the master pump entering into sleep mode. For details refer to the following description.

PD136 Lasting Time of Stopping Voltage Level
 Set Range: 1-250S Unit: 1 Factory Setting: 30S


This parameter is set for the lasting time under the stopping voltage level before entering into sleep mode. For details refer to the following description.

PD137 Wakeup Voltage Level
 Set Range: 1-150% Unit: 1 Factory Setting: 80%

This parameter is set for the wakeup voltage level from sleep to wakeup.

PD138 Sleep Frequency
 Set Range: 0.00-400.0 Unit: 1 Factory Setting: 20.00

PD139 Lasting Time of Sleep Frequency
 Set Range: 1-250S Unit: 1 Factory Setting: 20S



This parameter is set for the lasting time to run at sleep frequency when entering into sleep mode.

PD140 Reserved

PD141 Rated Motor Voltage Unit: 0.1V Factory Setting: *

It is set according to the rated voltage value of the nameplate of the motor. For the inverters of 230V class the factory setting is 220, while for the inverters of 400 V class the factory setting is 380.

PD142 Rated Motor Current Unit: 0.1 A Factory Setting: *

It is set according to the rated value of the nameplate of the motor. This parameter can be used to restrict the output current of the inverter to prevent over-current and protect the motor. If the current of the motor has exceeded this value the inverter of AC motor will turn to self-protection.

PD143 Motor Pole Number
 Set Range: 02-10 Unit: 1 Factory Setting: 04

This parameter is set for the number of the motor's pole according to the nameplate of the motor.


PD144 Rated Motor Revolution
 Set Range: 0-9999 Unit: 1r/min Factory Setting: 1440

This is set according to the actual revolution of the motor. The displayed value is the same as this set value. It can be used as a monitoring parameter, which is convenient to the user. This set value corresponds to the revolution at 50Hz.

PD145 Auto Torque Compensation
 Set Range: 0.1-10.0% Unit: 0.1% Factory Setting: 2.0%

This parameter can be set for the auto output of extra voltage when the inverter is running to achieve higher torque, which can compensate for the under-torque at lower frequency. The torque compensation should not be too big and it should be set slowly from low to high according to the actual situation.

Insufficient compensation will result in the under-torque of the motor at lower frequency. And over compensation will lead to too bigger torque, which will produce a shock to the machine and even result in a trip of the inverter under serious situation.



| |
|---|
| <p>PD146 Motor No-load Current Set Range: 0-99 Unit: 1 Factory Setting: 40</p> |
|---|

The setting of motor no-load current will affect the value of slip compensation. The current is 100% of the rated current of the motor.

| |
|---|
| <p>PD147 Motor Slip Compensation Set Range: 0.0-10.0 Unit: 0.1 Factory Setting: 20</p> |
|---|

When the inverter drives the motor the slip becomes bigger due to the increase of load. This param can be set for slip compensation to decrease the slip and make the running speed of the motor closer to the synchronous revolution.

| |
|------------------------------------|
| <p>PD148-PD149 Reserved</p> |
|------------------------------------|

| |
|---|
| <p>PD150 Auto Voltage Regulation Set Range: 0-1 Unit: 1 Factory Setting: 1</p> |
|---|

0: Invalid
 1: Valid

When the input power is not stable and if the voltage is too high the operation of the motor with the power exceeding the rated voltage will cause increase of the temperature of the motor, damage of its insulation and unstable output torque. This auto voltage regulation can automatically stabilize the output voltage within the rated voltage range of the motor under the condition of unstable output power supply. When this function is set to invalid the output voltage will fluctuate.

| |
|---|
| <p>PD151 Auto Energy Saving Set Range: 0-10% Unit: 1% Factory Setting: 0</p> |
|---|

When it is set to zero this function is invalid. When Auto energy saving function is started the inverter will run at the full voltage during ramp-up or -down. During the operation at constant speed the inverter can automatically calculate the optimum voltage value according to the power of load and supply power to the load to achieve the goal of energy saving.

| |
|---|
| <p>PD152 Fault Restart Time Factory Setting: 1.0 s</p> |
|---|

When the inverter is set for fault restart and if it has a fault trip with the time exceeding the set value of Pd152 the inverter will restart. When using this function pay more attention to the safety.

| |
|--|
| <p>PD153 Restart after Instantaneous Stop Set Range: 0-1 Unit: 1 Factory Setting: 0</p> |
|--|

0: Invalid, i.e. the inverter will not restart after an instantaneous power breakdown.
 1: Start by frequency track. Refer to PD025.

| |
|--|
| <p>PD154 Allowable Power-Breakdown Time Set Range: 0.1-5.0S Unit: 0.1S Factory Setting: 0.5</p> |
|--|

This parameter is set for the maximum allowable power failure time. If exceeding the set time the inverter will continue to stop output after power on. To restart the inverter it needs to follow the general starting procedures.

| |
|---|
| <p>PD155 Number of Abnormal Restart Set Range: 00-10 Unit: 1 Factory Setting: 00</p> |
|---|

After the abnormal conditions (such as over-current and over-voltage) happens the inverter will automatically reset and restart. If the starting mode is set to normal mode it will start according to the normal procedures. If it is set to start by frequency track it will start in the frequency track mode. After starting it will restore the set number again if there is no more abnormality happened within 60 seconds. If there is still any error and it reaches the set number the inverter will stop output. It can only be started after reset. When PD155 is set to zero the inverter will not carry out the functions of automatic reset and restart.

| |
|---|
| <p>PD156 Proportional Constant (P) ** Set Range: 0.0-1000.0% Unit: 0.1% Factory Setting: 100%</p> |
|---|

This proportional constant is set for the error value gain. In case of I=0, D=0, it is only for proportional control.

| |
|---|
| <p>PD157 Integral Time (I) ** Set Range: 0.1-3600.0s Unit: 0.1s Factory Setting: 5.0s</p> |
|---|

The integral time (I) is set for the responding speed for PID. The larger the I value is set the slower the responding speed will be. To the contrary, if the responding speed is quick but the integral time value is set too small, it will cause oscillation.

| |
|---|
| <p>PD158 Differential Time (D) ** Set Range: 0.01-10.00s Unit: 0.01s Factory Setting: 0</p> |
|---|

This differential time (D) is set for the depression operation of PID. The larger the D value is, the more obvious the depression operation will be. When D is set to zero, this function is invalid.


| |
|--|
| <p>PD159 Target Value ** Set Range: 0-100.0% Unit: 1% Factory Setting: *</p> |
|--|

This target value can be set through external voltage signal or the digital operator. 100% target value is corresponding to the analog frequency at +10V.

PID closed-loop control is usually used in the process control with physical quantity not changing fast, such as the controls of pressure and temperature, etc. The feedback signal is usually taken from temperature transmitter, or pressure transmitter, etc. Under PID control, the feedback signal input path is the analog current signal of 4-20mA.

PID closed-loop control is valid when Multi-input PID is started.



PID Control Block Diagram:





General operating methods of PID control:

- (1) Choose the correct transmitter (with the output specification of standard current signal 4-20mA).
- (2) Set the right target value.
- (3) If the output does not have oscillation, increase the proportional constant (P).
- (4) If the output does not have oscillation, decrease the integral time (Ti).
- (5) If the output do not have oscillation, increase the differential time (Td).
- (6) Concrete applications can be referred to the example application descriptions in Appendix 1.



| | | |
|------------|------------------|--------------------------|
| PD160 | PID Target Value | ** |
| Set Range: | 0-1 | Unit: Factory Setting: 0 |

The target value can be set through the selection of the panel or external analog. The external analog is 0-10V signal or given by the potentiometer.

When PD160=0, the target value of PID is the value set by PD159.

When PD160=1, the target value of PID is the value of the external analog 0-10V (corresponding to 0-100%), the setting of PD159 is invalid.

| | | |
|------------|-----------------|-----------------------------|
| PD161 | PID Upper Limit | ** |
| Set Range: | 0-100% | Unit: Factory Setting: 100% |

When PID feedback value is more than the set value of PD161 the corresponding multi-output will act and the inverter will not stop.

| | | |
|------------|-----------------|---------------------------|
| PD162 | PID Lower Limit | ** |
| Set Range: | 0-100% | Unit: Factory Setting: 0% |

When PID feedback value is less than the set value of PD162 the corresponding multi-output will act and the inverter will not stop.

| | | |
|------------|-------------------------|---------------------------|
| PD163 | Communication Addresses | ** |
| Set Range: | 00-250 | Unit: Factory Setting: 00 |

When the inverter is set for RS-485 Communication interface control, each of the inverters will be set for its individual identification .

- 00: No communication function.
- 01-250: Address for the inverters

| | | |
|------------|-------------------------|--------------------------|
| PD164 | Communication Baud Rate | ** |
| Set Range: | 0-3 | Unit: Factory Setting: 0 |

0: 4800 b/s 1: 9600 b/s 2: 19200 b/s 3: 34800 b/s

| | | |
|------------|---------------------------|----------------------------|
| PD165 | Communication Data Method | ** |
| Set Range: | 0-5 | Unit: 1 Factory Setting: 0 |

0: 8N1 For ASCII 1: 8E1 For ASCII 2: 8O1 For ASCII
3: 8N1 For RTU 4: 8E1 For RTU 5: 8O1 For RTU

| | | |
|-------------|----------|----|
| PD166-PD168 | Reserved | ** |
|-------------|----------|----|

| | | |
|------------|---------------|----------------------------|
| PD170 | Display Items | ** |
| Set Range: | 0-5 | Unit: 1 Factory Setting: 7 |


This parameter is only valid when Bit 2 is set to 1 in PD171. For the details refer to PD171.

- 0: Inverter Temperature
- 1: Counter Value
- 2: PID Target Value
- 3: PID Feedback Value

| | | |
|------------|--------------------|----------------------------|
| PD171 | Display Items Open | ** |
| Set Range: | 0-15 | Unit: 1 Factory Setting: 7 |

This parameter is set for selection of displaying of DC voltage, AC voltage and other items so that the customer can monitor and view them in sequence through the switch key.

It can be is set first in the binary 3 bits mode, and then converted to a decimal value.



In the contents displayed the factory setting is to show output frequency, set frequency, output current and output revolution through the switch key. If it is necessary to view and monitor other items they can be set through PD170 and Pd171.

| | | |
|------------|-------------|-----------------------------|
| PD172 | Fault Clear | ** |
| Set Range: | 00-10 | Unit: 1 Factory Setting: ** |

01 is for fault clear. Others have no function.

| | | |
|------------|----------------------------|------------------------------|
| PD173 | Voltage Rating of Inverter | ** |
| Set Range: | 00-10 | Unit: 1V Factory Setting: ** |

It is factory setting. It is depending on the model. It can be observed, but not set.



| | | | |
|-------|---------------------------|----------|--------------------|
| PD174 | Rated Current of Inverter | Unit: 1A | Factory Setting: * |
|-------|---------------------------|----------|--------------------|

It is depending on the model and can't be changed.

| | | | |
|-------|----------------|---------|--------------------|
| PD175 | Inverter Model | | |
| | Set Range: 01 | Unit: 1 | Factory Setting: 0 |

0: Constant torque 1: For kinds of fan. It can be observed, but not changed.

| | | | |
|-------|-----------------------------|---------|--------------------|
| PD176 | Inverter Frequency Standard | Unit: 1 | Factory Setting: * |
|-------|-----------------------------|---------|--------------------|

0: 50Hz 1: 60Hz It is factory setting. It can be observed, but not set.

| | | |
|-------|----------------|------------------|
| PD177 | Fault Record 1 | Factory Setting: |
| PD178 | Fault Record 2 | Factory Setting: |
| PD179 | Fault Record 3 | Factory Setting: |
| PD180 | Fault Record 4 | Factory Setting: |

When it has no fault record it shows . After access to this parameter the fault display can be checked.

| | | |
|-------|------------------|--------------------|
| PD181 | Software Version | Factory Setting: * |
|-------|------------------|--------------------|

It can be observed, but not set.

| | | |
|-------|------------------|--------------------|
| PD182 | Manufacture date | Factory Setting: * |
|-------|------------------|--------------------|

It is factory setting. It can be observed, but not set.

| | | |
|-------|------------|--------------------|
| PD183 | Serial No. | Factory Setting: * |
|-------|------------|--------------------|

It is factory setting. It can be observed, but not set.

| | |
|-------------|--------------------|
| PD183~PD250 | Factory Setting: * |
|-------------|--------------------|

Note:

* means the said parameter has a variety of set values or should be set specifically according to concrete conditions.

** means the said parameter can be set during the operation.

X. Care & Maintenance, Fault Information and Troubleshooting

Periodical maintenances and inspections will keep your inverter in its normal state for long time.

1. Precautions about Inspection and Maintenance

- Be sure to turn off the power supply to the inverter (R.S.T) first before the inspection and maintenance.
- After confirming the main circuit power supply has been turned off and the display has disappeared, wait until the internal indicator lamp for high voltage goes out before performing the inspection and maintenance.
- During the inspection, do not pull out or wrongly distribute the internal power supply, wires and cables. Otherwise it will cause malfunction or damage to the inverter.
- Do not leave any screw or other part inside the inverter during the installation, or it will result in the short circuit of circuit board.
- Keep the inverter clean, free from dust, oil mist and moisture after the installation.

2. Periodical Inspection and Maintenance Items

- Check whether the power supply voltage conforms to the rated voltage of the inverter. (Pay special attention to that whether there is any damage on the power supply wires and the motor.)
- Check whether the wiring terminals and the connectors are tight (Check whether the power supply wires and terminal connection wires have any broken strand.)
- Check whether there is dust, iron filings or corrosive fluid in the inverter. Measuring the insulation impedance of the inverter is forbidden.
- Examine the output voltage, output current and output frequency of the inverter. (The measuring results should not have too big difference.)
- Check whether the ambient temperature of the inverter is between -5°C and 40°C and whether the installation environment has good ventilation.
- Check whether the humidity is kept below 90% (without condensation).
- Check whether the motor makes unusual noises or abnormal vibration in running. (The inverter should not be installed in a place with high vibration.)
- Please make periodical cleaning of vent holes.

3. Fault Indication and Troubleshooting

The inverter of HLP series is relatively perfective with the protection functions of overload, inter-phase short circuit, earth short circuit, under-voltage, overheating and over-current, etc. When a protection function happens with the inverter please check the reasons of faults according to the information listed in the table below. The inverter can be restarted after the disposal. If the fault cannot be disposed please contact the local distributor.

| Fault Display | Fault Contents & Description | Disposal methods |
|---------------|------------------------------|---|
| OC-1 | Over-current during ramp-up | 1: Check whether the motor has got short circuit or partial short circuit and whether the insulation of output wire is good. 2: Extend the ramp-up time. 3: The configuration of the inverter is not reasonable. The inverter's capacity should be increased. 4: Decrease the torque and increase the set value. |



| | | |
|--------------|--|--|
| OC-1 | Over-current at constant speed | <ol style="list-style-type: none"> 1: Check whether the motor has got short circuit and whether the insulation of the output wires is good. 2: Check whether the motor is blocked and whether there is a sudden change of mechanical load. 3: Check whether the inverter's capacity is too small and increase its capacity. 4: Check whether there is a sudden change in the power supply voltage. |
| OC-2 | Over-current at decel Over-current at stop | <ol style="list-style-type: none"> 1: Check whether the insulation of the output wires is good and whether the motor has got short circuit. 2: Extend the Ramp-down Time. 3: Replace it with an inverter of larger capacity. 4: DC braking is too high. Decrease DC braking. 5: The inverter has failure. Please send it to the factory for repair. |
| OL | Output short circuit | <ol style="list-style-type: none"> 1: Check whether the connection wire of the motor has got short circuit. 2: Check whether the insulation of the output wires is good. 3: Please send it for repair. |
| OU-1 OU-2 | Over-voltage at stop Over-voltage at accel Over-voltage at constant speed Over-voltage at decel | <ol style="list-style-type: none"> 1: Extend the Ramp-down Time or add a braking resistor. 2: Improve the mains supply voltage and check whether there is any sudden change in the voltage. |
| Fb | Fuse break | Fuse break. Please send it to the factory for repair. |
| LV | Low voltage | <ol style="list-style-type: none"> 1: Check whether the input voltage is normal. 2: Check whether there is sudden change in load. 3: Check whether there is any phase missing. |

| | | |
|--|--|--|
| OH | Overheat of inverter | <ol style="list-style-type: none"> 1: Check whether the fan is blocked and whether there is any foreign matter stuck in the cooling fins. 2: Check whether the ambient temperature is normal. 3: Check whether there is enough space for ventilation and good air convection. |
| OL-1 | Inverter overload 150% Per minute | <ol style="list-style-type: none"> 1: Check whether the capacity of the inverter is lower. Otherwise it should be increased. 2: Check whether there is any jamming in the mechanical load. 3: The setting of V/F curve is bad. Set it again. |
| OL-2 | Motor overload 150% Per minute | <ol style="list-style-type: none"> 1: Check whether there is any sudden change in the mechanical load. 2: The equipped motor is too small. 3: The motor is hot and the insulation becomes bad. 4: Check whether the voltage has big fluctuation. 5: Check whether there is any phase missing. 6: The mechanical load is increased. |
| OT | Motor over-torque | <ol style="list-style-type: none"> 1: Check whether there is any fluctuation in the mechanical load. 2: Check whether the equipped motor is smaller. |
| E.b5.A E.b5.n E.b5.d E.b5.S | No feedback from auxiliary coil of the electromagnetic contactor | Please contact the factory. |
| bt | Braking transistor damage | Please send it for repair. |
| CPu | CPU fault | Please contact the factory. |
| E.E.E.S E.E.E.n E.E.E.d E.E.E.A | E ² Prom fault | Please contact the factory. |



| | | |
|-----|------------------------|---------------------------------|
| Er | External interferences | Isolate the interference source |
| ES | Emergency Stop | In Emergency Stop |
| 20 | 4-20mA wire broken | Join the broken wires |
| Pr | Setting error | Correct the setting |
| Dcb | DC braking status | In DC braking |

Note:

(1) Fault Code Form as follows:



(2) Code Comparison Table

| | | | | | | | | | | | | | | | | |
|--|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | B | C | D | E | F | G | H | O | S | N | L | T | P | R | U | 2 |
| | b | c | d | e | f | g | h | o | s | n | l | t | p | r | u | 2 |

4. Faults and Analysis

- (1) When RUN key is pressed, the motor does not run.
- The setting of operation mode is wrong, i.e., under the operation mode of external control terminals, the inverter is started by the digital operator or under the operation mode of the digital operator it is started by the external control terminals.
 - The frequency reference is too low or not set.
 - The peripheral wiring is wrong. For example, the setting of wiring of two-wire system and three-wire system and other related parameters have errors.
 - The setting of multi-function terminals is wrong (in the external control).
 - The inverter is in the fault protection.
 - The motor fails.
 - The inverter fails.

(2) The parameters cannot be set.

- Password locks. Please decrypt it first before resetting.
- The inverter is in running.
- The connection of the connecting parts is abnormal. The communication of the digital operator is abnormal. Take out the operator after power-off and then mount it again for a trial.

(3) The motor cannot rotate reverse.

Reverse rotation is disabled.

(4) The motor rotates in the opposite direction.

The output line is wrongly connected. Please change any two lines of U.V.W over.

(5) The deceleration of the motor is too slow.

- The setting of Ramp-down Time is too long. Decrease Ramp-down Time.
- Add a braking resistor.
- Add a DC brake.

(6) Over-heat of the motor

- The load is too large. The actual torque has exceeded the rated torque of the motor. It is recommended to increase the capacity of the motor.
- The ambient temperature is too high. In a place with higher temperature the motor will be burn out. Please decrease the temperature around the motor.
- The phase to phase withstand voltage of the motor is insufficient.
The switch actions of the inverter will make the winding coil of the motor produce shock wave. Typically the maximum shock voltage will reach 3 times that of input power of the inverter. Please select a motor with higher phase to phase withstand voltage against shock than the maximum shock voltage.

(7) The starting of the inverter interferes other control devices

- Decrease the carrier frequency and reduce the number of actions of internal switches.
- Install a noise filter at the power input of the inverter.
- Install a noise filter at the output of the inverter.
- Make correct grounding for the inverter and the motor.
- Use metal conduit to tube the cable to shield it.
- Make separate wiring for the main circuit wires and control wires.

(8) When the fan starts the inverter detected an over-current stall.

- At start the fan rotates idly. Please set it for DC braking at start.
- When DC braking at start has been set increase the DC braking value.

(9) The machine has the noise of vibration or roar

- The vibration frequency of mechanical system resonates with the carrier. Adjust the carrier to avoid the point of resonance.
- The vibration frequency of mechanical system resonates with the output frequency of the inverter.
A. Set it for skip function to avoid the point of resonance.
B. Put rubber vibration isolator on the base plate of motor.

XI. Selection of Peripheral Devices and Disposition

1. Options

| Description | Functions |
|---|---|
| NFB or Ground fault interrupter for wire connection | Protect the wiring of the inverter. Be sure to install a breaker at the power. Please select a ground fault circuit interrupter against high-order harmonics. |
| Electromagnetic contactor | In order to prevent the braking resistor from burning out, please add an electromagnetic contactor and connect a surge absorber to the coil when using it. |



| | |
|--------------------------------|---|
| Surge absorber | Absorb the switching surge current from the electromagnetic contactor and control relays. |
| Isolating transformer | Its function of isolating the input and output of the inverter is effective to reduce the interference to other electric devices. |
| DC reactor | Improve the input power factor of the inverter. |
| AC reactor | Improve the input power factor of the inverter and prevent the shock of surge voltage. |
| Braking resistor, braking unit | Consume the regenerating energy of the motor and shorten the ramp-down time. |

1) Leakage switch

There is earth static capacity inside of the inverter and the motor as well as the input and output leads. Due to higher carrier frequency of the inverter the inverter has higher earth leakage current, especially for the inverters of large capacity series. When using a leakage switch it may sometimes result in the error action of the protective circuit. So when using a leakage switch attention should be paid to its selection and the proper reduction of carrier frequency and shortening the leads, etc.

2) AC reactors

An AC reactor can constrict the high-order harmonic of input current of the inverter to improve its input power factor and prevent the shock of surge. It is recommended to use an input AC reactor under the following circumstances:

- a: Three-phase power supply is in unbalance.
- b: Any equipment with thyristor or power factor compensation unit with switching control is connected to the same power supply.

3) DC reactors

It is necessary to install a DC reactor when the capacity of power supply is more than 1000 KVA or the mains power capacity is higher than the rated capacity of the inverter. A DC reactor is also needed for the case with higher demand on the improvement of power factor of power supply. This DC reactor can be used together with an AC reactor to achieve the obvious effect of decreasing high-order harmonic at input. If it is necessary to install a DC reactor please contact the local distributor.

Disposition of Braking Resistor

| Inverter Model | Braking resistor Specification | | Braking torque 10%ED | Special Motor KW |
|----------------|--------------------------------|-----|----------------------|------------------|
| | W | Ω | | |
| HY00D423B | 80 | 200 | 125 | 0.4 |
| HY0D7523B | 100 | 200 | 125 | 0.75 |
| HY01D523B | 300 | 100 | 125 | 1.5 |
| HY02D223B | 300 | 70 | 125 | 2.2 |
| HY0D7543B | 80 | 750 | 125 | 0.75 |
| HY01D543B | 300 | 400 | 125 | 1.5 |
| HY02D243B | 300 | 250 | 125 | 2.2 |

| | | | | |
|------------|-------|--------|-----|------|
| HY03D743B | 400 | 150 | 125 | 3.7 |
| HY05D543B | 500 | 100 | 125 | 5.5 |
| HY07D543B | 1000 | 75 | 125 | 7.5 |
| HY11D043B | 1000 | 50 | 125 | 11 |
| HY15D043B | 1500 | 40 | 125 | 15 |
| HY18D543B | 4800 | 32 | 125 | 18.5 |
| HY22D043B | 4800 | 27.2 | 125 | 22 |
| HY30D043B | 6000 | 20 | 125 | 30 |
| HY37D043B | 9600 | 16 | 125 | 37 |
| HY45D043B | 9600 | 13.6 | 125 | 45 |
| HY55D043B | 12000 | 20/2 | 125 | 55 |
| HY75D043B | 18000 | 13.6/2 | 125 | 75 |
| HY90D043B | 18000 | 20/3 | 125 | 90 |
| HY110D043B | 18000 | 20/3 | 125 | 110 |
| HY132D043B | 24000 | 20/4 | 125 | 132 |
| HY160D043B | 36000 | 13.6/4 | 125 | 160 |
| HY200D043B | 45000 | 13.6/5 | 125 | 200 |
| HY220D043B | 48000 | 13.6/5 | 125 | 220 |
| HY315D043B | 57600 | 13.6/6 | 125 | 300 |

For the inverter of above 11 KW to realize quick brake a braking unit must be added.

Note:

- 1: Please select the resistor value and operating frequency given by our company.
- 2: If it causes any damage to the inverter and other devices due to the use of any braking resistor and braking model group not supplied by our company, we will take no responsibility.
- 3: Be sure to consider the safety and ignitability of the environment when installing a braking resistor. The distance to the inverter should be at least 100 mm.
- 4: If it is necessary to change the resistor value and power value, please contact the local distributor.
- 5: In need of a braking resistor a separate order must be placed. Please contact the local distributor for details.

