



LFP 5-10 KWH/LV

51.2V 100/200Ah

RECHARGERABLE LITHIUM BATTERY

User Manual v3.2

Content

STATEMENT OF LAW	1
SAFETY PRECAUTIONS	2
PREFACE	3
1 INTRODUCTION	4
1.1 Brief Introduction	4
1.2 Product Properties.....	4
1.3 Product identity definition.....	5
2 PRODUCT SPECIFICATION	6
2.1 Size and Weight.....	6
2.2 Performance Parameter.....	6
2.3 Interface Definition	6
2.4 Battery Management System (BMS)	8
2.4.1 Voltage Protection	8
2.4.2 Current Protection	9
2.4.3 Temperature Protection.....	9
2.4.4 Other Protection	9
3 INSTALLATION AND CONFIGURATION	10
3.1 Preparations for installation Safety Requirement.....	10
3.1.1 Environmental requirements	10
3.1.2 Tools and data.....	11
3.1.3 Technical preparation	11
3.1.4 Technical preparation	11
3.1.5 Engineering coordination.....	13
3.2 Equipment installation.....	13
3.2.1 Floor installation.....	14
3.2.2 Mounted on the wall.....	15
3.2.3 Electrical installation	17
3.2.4 Battery module DIP switch definition and description.....	20
4 USE, MAINTENANCE AND TROUBLESHOOTING	22
4.1 Battery system usage and operation instructions.....	22
4.2 Alarm description and processing.....	23
4.2.1 Alarm and countermeasure influence system output.....	23
4.2.2 Alarm and countermeasure without affecting the output of the system.....	23
4.3 Analysis and treatment of common faults.....	24
APPENDIX I 5KWH TARGET SIZE	25
APPENDIX II 10KWH TARGET SIZE	26
5 Bluetooth APP Connection Guide	27
5.1 Android and iOS software download and installation.....	27
5.2 User login.....	27
5.3 Device Connection	28
5.4 Display of APP main interface.....	29
5.5 Other interface displays.....	33

Statement of Law

Copyright of this document belongs to **SUNKET® ESS**.

No part of this documentation maybe excerpted, reproduced, translated, annotated or duplicated in any form or by any means without the prior written permission of **SUNKET® ESS** All Rights Reserved.

This product complies with the design requirements of environmental protection and personal safety. The storage, use and disposal of the products shall be carried out in accordance with the product manual, relevant contract or relevant laws and regulations.

Customer can check the related information on the website when the product technology is updated.

Please note that the product can be modified without prior notice.

Manual Version: V3.2

Manual NO.

Revision History

Revision NO.	Revision Date	Revision Reason
1.0	2020.06.17	First Published
2.0	2021.03.20	Modify the shell size of lithium battery
3.0	2022.05.07	Modify the color and content of the nameplate of lithium battery
3.1	2022.07.05	APPENDIX I-II added
3.2	2024.08.16	Nameplate changed

Safety Precautions



Warning

- Please do not put the battery into water or fire, in case of explosion or any other situation that might endanger your life.
- Please connect wires properly while installation, do not reverse connect.
- To avoid short circuit, please do not connect positive and negative poles with conductor (Wires for instance).
- Please do not stab, hit, trample or strike the battery in any other way.
- Please shut off the power completely when removing the device or reconnecting wires during the daily use or it could cause the danger of electric shock.
- Please use dry powder extinguisher to put out the flame when encountering a fire hazard, liquid extinguisher could result in the risk of secondary disaster.
- For your safety, please do not arbitrarily dismantle any component in any circumstances unless a specialist or an authorized one from our company, device breakdown due to improper operation will not be covered under warranty.



Caution

- We have strict inspection to ensure the quality when products are shipped out, however, please contact us if case bulging or another abnormal phenomenon.
- For your safety, device shall be ground connected properly before normal use.
- To assure the proper use please make sure parameters among the relevant device are compatible.
- Please do not mixed-use batteries from different manufacturers, different types and models, as well as old and new together.
- Ambient and storage method could impact the life span and product reliability, please consider the operation environment abundantly to make sure device works in proper condition.
- For long-term storage, the battery should be recharged once every 6 months, and the amount of electric charge shall exceed 80% of the rated capacity.
- Please charge the battery in 18 hours after it discharges fully and starts over - discharging protection.
- Formula of theoretical standby time: $T=C/I$ (T is standby time, C is battery capacity, I is total current of all loads).
- The surface of Power box cabinet is affixed with a torn invalid label. Therefore, before-opening the cover to change the DIP switch mode, you need to contact HERBYTECK and inform the product ID. HERBYTECK will record this battery ID and authorize the opening operation to be performed. Except for changing the DIP switch mode, no other operations are allowed.

Preface

Manual declaration

LFP 5-10kWh/ LV user manual lithium iron phosphate battery is external battery module which can storage the power for home use. When the grid is on, it supplies the home loads and charges the battery meantime. When grid off, the battery discharges to power up the home loads.

LFP 5-10kWh/ LV user manual systematically elaborates device structure, parameters, basic procedure and method of installation, operation, maintenance.

Safety Statement

- Only qualified trained professionals are allowed to install, operate, maintain the device.
- Please comply with local safety regulations and operational rules when installation, operation and maintenance, or it could lead to human injury or device damage.
- Mentioned attentions are only as a supplement to local safety regulations.
- The seller does not undertake any responsibility for device operations or usage violating general safety requirements and safety standards.

Sign explanation

Attention should be paid when configuring or operating LFP 5-10kWh/LV products, which follows below format to explain.



Caution

Neglecting the warnings might cause malfunction.

1 Introduction

1.1 Brief Introduction

LFP 5-10kWh/LV user manual lithium iron phosphate battery is newly power storage products designed according to market demands, supplies reliable power for all kinds of home equipment. It is especially suitable for situations with higher temperatures, less space, higher demand of weight and life span.

LFP 5-10kWh/LV lithium battery carries self-developed battery management system. When the grid is on, it supplies the home loads and charges the battery meantime. When grid off, the battery discharges to power up the home loads.

Batteries can be paralleled to build a module with more capacity to satisfy the longtime energy storage demand.

1.2 Product Properties

LFP 5-10kWh/LV energy storage product's anode materials are lithium iron phosphate, battery cells are managed effectively by BMS with better performance, the systems feature as below:

- Anode materials are lithium iron phosphate (LiFePO_4), safer with longer life span.
- Carries battery management system with better performance, possesses protection function like over-discharge, over-charge, over current, abnormal temperature.
- Self-management on charging and discharging, single core balancing function.
- Intelligent design configures integrated inspection module, with 3 remote functions (remote-measuring, remote-communicating and remote-controlling).
- Flexible configurations allow parallel of multi battery for longer stand by time.
- Self-ventilation with lower system noise.
- Less battery self-discharge, then recharging period can be up to 10 months during the storage.
- No memory effect so that battery can be charged and discharged shallowly.
- With wide range of temperature for working environment, $-10\text{ }^\circ\text{C}\sim+50\text{ }^\circ\text{C}$, circulation span and discharging performance are well under high temperature.
- Less volume, lighter weight, seal grade up to IP65 embedding design for easier installation and maintenance.

1.3 Product identity definition

FIG1-1 Battery Energy Storage System nameplate

SUNKET-ESS LFP 5kWh/LV

RECHARGEABLE LITHIUM BATTERY

Total Energy	5.12kWh
Nominal Capacity	100AH
Voltage Range	43.2~58.4Vd.c
Nominal Voltage	51.2Vd.c.
Max. Charge Voltage	58.4Vd.c
Max. Charge Current	50A
Max. Discharge Current	50A
Storage Temperature	-20 C ~50 C
Operating Temperature	-10 C ~50 C
Protective Class	I
IP Rating	IP 65

CE TÜV UN38.3

⚡ ⚠

WUXI SUNKET NEW ENERGY TECHNOLOGY CO.,LTD
 Add: No.888,DeLin Industry Park, Qinghong Road, E'hu Town, Wuxi, Jiangsu, P.R.C Tel: +86-510-8878 5930 Email: sales@sunket.cn

SUNKET-ESS LFP 10kWh/LV

RECHARGEABLE LITHIUM BATTERY

Total Energy	10.24kWh
Nominal Capacity	200AH
Voltage Range	43.2~58.4Vd.c
Nominal Voltage	51.2Vd.c.
Max. Charge Voltage	58.4Vd.c
Max. Charge Current	100A
Max. Discharge Current	100A
Storage Temperature	-20 C ~50 C
Operating Temperature	-10 C ~50 C
Protective Class	I
IP Rating	IP 65

CE TÜV UN38.3

⚡ ⚠

WUXI SUNKET NEW ENERGY TECHNOLOGY CO.,LTD
 Add: No.888,DeLin Industry Park, Qinghong Road, E'hu Town, Wuxi, Jiangsu, P.R.C Tel: +86-510-8878 5930 Email: sales@sunket.cn



Battery is voltage higher than safe voltage, direct contact with electric shock hazard.



Be careful with your actions and be award of the dangers.



The battery product meets the United Nations regulations on transport of dangerous goods.



The scrapped battery cannot be put into the garbage can and must be professionally recycled.



This battery product meets European directive requirements.



All the parts of the battery meet TUV safety requirements.

2 Product Specification

2.1 Size and Weight

Table 2-1 LFP 5-10kWh/LV Device Model

Product Series	Specification Model	Nominal Voltage	Nominal Capacity	Dimension (mm)	Weight (kg)	IP Level
LFP	5kWh/LV	51.2V	100Ah	550×700×216	58	IP65
LFP	10kWh/LV	51.2V	200Ah	645×995×225	109	IP65

2.2 Performance Parameter

Table 2-2 LFP 5-10kWh/LV performance parameter

Module Type	LFP 5kWh/LV	LFP 10kWh/LV
Total Energy	5.12kWh	10.24kWh
Usable Energy (DC)	4.6kWh	9.2kWh
Nominal Dis-charge Power	2.5kW	5kW
Peak Power (Only Discharge)	2.9kW for 3 seconds	5.8kW for 3 seconds
Constant Current (Only Discharge)	50A	100A
Voltage	43.2~58.4Vd.c.	43.2~58.4Vd.c.
Nominal Voltage	51.2Vd.c	51.2Vd.c
Nominal Current	50A	100A
Max. Charge Voltage	58.4Vd.c	58.4Vd.c
Max. Charge Current	50A	100A
Max. Discharge Current	50A	100A
Safety	CE UN38.3	CE UN38.3

2.3 Interface

This section elaborates on interface functions of the front panel of the device.

Figure2-1 LFP 5-10kWh/LV the sketch of front interface



Table 2-3 Interface Definition

Item	Name	Definition
1	Negative socket	The battery DC output positive pole, which is connected to the negative pole often inverter through the cable.
2	Positive socket	The battery DC output negative pole, which is connected to the negative pole often inverter through the cable.
3	RS485	The RS485 communication interface is used for parallel communication between batteries.
4	CAN	CAN communication interface is used for communication between battery and inverter.
5	LED1	Module capacity status indicator light.
6	LED2	Module capacity status indicator light.
7	LED3	Module capacity status indicator light.
8	LED4	Module capacity status indicator light.
9	ADD switch	Use the switch to adjust the address when the battery is in parallel mode.

10	Reset switch	Press the switch and the battery system turn on. When the battery is in the non-use state such as storage, transportation etc., it needs to be turn off by switch button, and the battery system will automatically sleep after the device without external load power.
11	Main switch	Open or cut off the main circuit, and ensure transportation safety after cutting off.

Table 2-4 LED status indicators (Take LFP 10kWh/ LV as an example)

Flashing 1: bright 0.25s, light out 3.75s

Flashing 2: bright 0.5s, light out 0.5s

Flashing 3: bright 0.5s, light out 1.5s

System state	Running state	RUN	ALM	SOC				Explain
								
Shut down	Dormancy	OFF		OFF	OFF	OFF	OFF	
Standby	Normal	Flashing 1	OFF	OFF	OFF	OFF	OFF	
Charge	Normal	ON	OFF	According to the power prompt				
	Over current alarm	ON	Flashing 2	According to the power prompt				
	Over voltage protection	Flashing 1	OFF	OFF	OFF	OFF	OFF	
	Temperature, Over current protection	Flashing 1	Flashing 1	OFF	OFF	OFF	OFF	
Discharge	Normal	Flashing 3	OFF	According to the power prompt				
	Alarm	Flashing 3	Flashing 3	According to the power prompt				
	Temperature, Over current, Short circuit, protection	OFF	ON	OFF	OFF	OFF	OFF	Stop discharge, Mains offline 48h no action forced sleep.
	Under voltage protection	OFF	OFF	OFF	OFF	OFF	OFF	Stop discharge

2.4 Battery Management System (BMS)

2.4.1 Voltage Protection

Discharging Low Voltage Protection

When any battery cell voltage is lower than the Rated protection value or total voltage below 40V during discharging, the over-discharging protection starts, and the battery buzzer makes an alarm sound. Then battery system stops supplying power to the outside. When the voltage of each cell recovers to rated value and total voltage restored to above 43.2V, the protection is released.

Charging Over Voltage Protection

When charging, the system stops charging when the total voltage of the battery pack is higher than 57.6V or the voltage of any single cell reaches the protection value. When the total voltage returns to below 56.8V and the cell voltage returns to below the rated protection value, the protection is released.

2.4.2 Current Protection

Over Current Protection in Charging:

When the charging current is greater than the protection value, the battery buzzer alarms and the system stops charging. After the system delays the rated time for 1 min, the protection is released.

Over Current Protection in Discharging:

When the discharging current is greater than the protection value, the battery buzzer alarms and the system stops discharging. After the system delays the rated time for 1 min, the protection is released.

Note

The buzzer sound alarm setting can be manually turned off on the background software, and the factory default is on.

2.4.3 Temperature Protection

Less/Overtemperature protection in charging:

When battery's temperature is beyond range of 0 °C~+50 °C during charging, temperature protection starts, device stops charging. The protection is released when it recovers to rated return range.

Less/Overtemperature protection in discharging:

When battery's temperature is beyond range of -10 °C~+50 °C during discharging, temperature protection starts, device stops supplying power to the outside. The protection is released when it recovers to rated return range.

2.4.4 Other Protection

Short Circuit Protection:

When the battery is activated from the off state, if a short circuit occurs, the DC circuit breaker will act first. If the DC circuit breaker does not operate, the BMS will start the short circuit protection function and cut off the external voltage output.

Self Shutdown:

When device connects no external loads for over 72 hours, device will dormant standby automatically.

Caution

The maximum working current of the load which needs to be powered should be less than the maximum discharge current capacity of the battery system.

3 Installation and Configuration

3.1 Preparations for installation

Safety Requirement

This system can only be installed by personnel who have been trained in the power supply system and have sufficient knowledge of the power system.

The safety regulations and local safety regulations listed below should always be followed during the installation.

- All circuits connected to this power system with an external voltage of less than 48V must meet the SELV requirements defined in the IEC60950 standard.
- If operating within the power system cabinet, make sure the power system is not charged. Battery devices should also be switched off.
- Distribution cable wiring should be reasonable and has the protective measures to avoid touching these cables while operation power equipment.
- When installing the battery system, must wear the protective items below:



The isolation gloves



Safety goggles



Safety shoes

3.1.1 Environmental requirements

Working temperature: -10 °C~+50 °C

- Charging temperature range is 0 °C~+50 °C
- Discharging temperature range is -10 °C ~+50 °C

Relative humidity: 4%~100%RH (No condensed water)

Elevation: no more than 4000m

Operating environment: Indoor or outdoor installation, sites avoid the sun and no wind, no conductive dust and corrosive gas.

And the following conditions are met:

- Installation location should be away from the sea to avoid brine and high humidity environment.
- The ground is flat and level.
- There is no flammable explosive near to the installation places.
- The optimal ambient temperature is +15 °C~+30 °C.
- Keep away from dust and messy zones.

3.1.2 Tools and data

Hardware tool

Tools and meters that may be used are shown in table 3-1.

Table 3-1 Tool instrument

Name	
Screwdriver (word, cross)	AVO meter
Wrench	Clamp meter
Inclined pliers	Insulating tape
Needle nose pliers	The thermometer
Clip forceps	Wrist strap
Wire stripper	AVO meter
Electric drill	Tape

3.1.3 Technical preparation

Electrical interface check

Devices that can be connected directly to the battery can be user equipment, power supplies, or other power supplies.

- Confirm whether the user equipment, the PV equipment or other power supply equipment has the DC standby interface, and measure whether the output voltage of the standby interface meets the requirements of the voltage range of table 2-2.
- Verify that the maximum discharge current capacity of the user equipment, the PV equipment or other power supplies, the DC standby interface, and the maximum discharge current shall be greater than the maximum charging current of the products used in table 2-2.
- If the user equipment DC prepared interface maximum discharge capacity is less than the maximum charging current products using table 2-2, the user interface should have the power equipment of DC current limiting function, give priority to ensuring the normal work of user equipment.

The security check

- Firefighting equipment should be provided near the equipment, such as portable dry powder fire extinguisher.
- Automatic fire fighting system shall be provided for the case where necessary.
- No flammable, explosive and other dangerous articles and placed beside the battery.

3.1.4 Technical preparation

- When the equipment arrivals at the installation site, loading and unloading should be carried out according to the rules and regulations, so as to prevent from being exposed to sun and rain.

- Before unpacking, the total number of packages shall be indicated according to the shipping list attached to each package, and the case shall be checked for good condition.
- In the process of unpacking, handle with care and protect the surface coating of the object.
- Open the package, the professional installation person should read the technical documents, verify the list, according to the configuration table and packing list, ensure objects are complete and intact. If the internal packaging is damaged, it must be inspected and recorded in detail.

Packing list is as follows:

 <p style="text-align: center;">Battery ×1</p>	 <p style="text-align: center;">Battery bottom bracket ×1</p>	 <p style="text-align: center;">Support bracket ×1</p>
 <p style="text-align: center;">M6 bolt ×8; Fixing battery box with battery bracket</p>	 <p style="text-align: center;">Power cable ×2 Connect battery with inverter Communication cable</p>	 <p style="text-align: center;">Expansion screw ×4</p>
 <p style="text-align: center;">User manual ×1</p>		

3.1.5 Engineering coordination

Attention should be paid to the following items before construction:

- Powerline specification.
- The power line specification shall meet the requirements of maximum discharge current for each product.
- Mounting space and bearing capacity.
- Make sure that the battery has enough room to install, and that the battery rack and bracket have enough load capacity.
- Wiring.
- Make sure the power line and ground wire are reasonable. Not easy to short-circuit, water and corrosion.


3.2 Equipment installation



Strongly recommended: floor installation;
If it is wall-mounted installation, strictly follow the requirements below.

The wall for battery installation shall be solid brick or cement wall with strong bearing capacity and wall thickness no less than 100mm.

Mounting space requirements:



Floor installation


Mounted on the wall installation

Table 3-2 Installation steps

Step 1	System outage	Ensure that the battery is in a shutdown state
Step 2	Mechanical installation	1. Hanger mounting
		2. Equipment installation
Step 3	Electrical installation	1. Connect the ground cable
		2. Electrical installation
		3. Connect inverter
		4. Communication interface connection

3.2.1 Floor installation

When the battery system is placed directly on the ground, a fixed support must be used to fix the top of the battery box with the wall.



1. Draw the screw holes on the wall according to the positioning drawing on the left (please refer to the appendix for specific dimensions)

2. The bottom of board must be good connection with the ground level while drawing the holes



3. 4 holes with diameter of 10mm shall be opened on the wall with electric drill according to the marked position, and the hole depth shall be greater than 70mm to fit the expansion bolts of M6.



4. Fixing the expansion bolt M6 into the Bottom of the hole on the wall.

5. Use the M6 bolt to fixing the Support bracket to the wall and control the torque at 6NM.



6. Carry the battery box to the Installation site, and place it about 15mm away from the vertical wall surface, fixing the Support bracket and the upper part of the battery box with M6 bolts

3.2.2 Mounted on the wall

The following accessories need to be added when mounted the battery on the wall.




Battery bottom bracket ×1



Expansion screw ×1

Installation procedure:



1. Draw the screw holes on the wall according to the positioning drawing on the left (please refer to the appendix for specific dimensions)
2. The mounting holes must be perpendicular to the ground
3. The battery base must be about 30mm off the ground
4. According to the position of the mark, 8 holes in diameter 10mm and depth of more than 70mm are hit on the wall with an electric drill, which are used for fitting expansion bolt M6.
5. Fixing the expansion bolt M6 into the bottom of the hole on the wall, and fix the support bracket and battery bottom bracket on the wall with M6 bolts, twisting force keeps 6NM.
6. Carry of hoist the battery to the installed battery bottom bracket. Fixing the support bracket and the upper part of the battery with M6 bolts, twisting force keeps 6NM. Then fixing the battery bottom bracket and the bottom part of battery with M6 bolts, twisting force keeps 6NM.

3.2.3 Electrical installation

Before connecting the power cables, using multi meter to measure cable continuity, short circuit, confirm positive and negative, and mark well the cable labels.

Measuring methods:

- Switch off cables: select the buzzer and use the probe to measure the ends of the same color cable. If the buzzer calls, it means the cable is available.
- Short circuit judgment: choose multimeter resistor file, probe the same end of positive and negative pole, if the resistor shows infinity, means that the cable is available.
- After visual testing of power line is connected well, the positive and negative poles of the battery shall be connected respectively to the positive and negative poles of another device.

Connected inverter




If there is any question during installation, please contact your dealer to avoid damage to the equipment.

When the system is used independently:

Note: Before installation, please confirm whether the DIP switch mode of No.1 module in battery is correct according to the inverter used. For specific dialing methods, please refer to "3.2.4 battery module DIP switch definition and description." Except for the inverter specified by the customer's special requirements, the factory default DIP switch mode of Module No.1 is DIP Switch model 1 (ADD: 0000). If the inverter is equipped with other DIP switch mode, open the cover and set DIP switch mode of the module No.1 to the correct mode. Before opening the cover to operate, you must contact **SUNKET® ESS** and inform the ID of Battery. **SUNKET® ESS** records this battery ID and authorizes the opening operation. Except charging the DIP switch mode, no other operation can be done.

- The battery is connected to the inverter, and it is required to use the dedicated power cable and communication cable (as accessories shipped with the cargo, the standard communication cable is a standard network cable. The applicable inverter is marked on the label of the network cable. If the inverter used by the customer is not covered by the standard communication cable, please contact **SUNKET® ESS** for the correct PIN Sequence).
- Keep the battery system at power off state, connect the power cable to the interface on the input side of the inverter first, and then connect the power cable to the interface on the battery side.
- The battery output interface is a quick connector, and the power cable (Positive, Negative) plug can be directly inserted into the battery socket. The power cable has a cross section of 25 mm².



Communication port interface


Connect the CAN Cable of the battery to the CAN communication interface of the inverter using the RJ45 cable.

Factory default CAN communication mode.




Table 3-3 PIN Definition

Foot position	Color	Definition
PIN1	Orange/ White	RS485-B
PIN2	Orange	RS485-A
PIN3	Green/ White	GND
PIN4	Blue	CAN H
PIN5	Blue/ White	CAN L
PIN6	Green	GND
PIN7	Brown/ White	RS485 A
PIN8	Brown	RS485 B



3.2.4 Battery module DIP switch definition and description



Since version 2.0, there is no need for ADD switch The battery can be automatically configured.
This component is reserved for testing purposes only

Table3-4-1 Slave setting

Address	DIP switch position				Instruction
	#1	#2	#3	#4	
1	ON	OFF	OFF	OFF	Slave1
2	OFF	ON	OFF	OFF	Slave2
3	ON	ON	OFF	OFF	Slave3
4	OFF	OFF	ON	OFF	Slave4
5	ON	OFF	ON	OFF	Slave5
6	OFF	ON	ON	OFF	Slave6
7	ON	ON	ON	OFF	Slave7
8	OFF	OFF	OFF	ON	Slave8
9	ON	OFF	OFF	ON	Slave9
10	OFF	ON	OFF	ON	Slave10
11	ON	ON	OFF	ON	Slave11
12	OFF	OFF	ON	ON	Slave12
13	ON	OFF	ON	ON	Slave13
14	OFF	ON	ON	ON	Slave14
15	ON	ON	ON	ON	Slave15

Table3-4-2 Host setting (Table 2)

Number of parallel machines	DIP switch position				Instruction
	#1	#2	#3	#4	
1	ON	OFF	OFF	OFF	parallel 1
2	OFF	ON	OFF	OFF	parallel 2
3	ON	ON	OFF	OFF	parallel 3
4	OFF	OFF	ON	OFF	parallel 4
5	ON	OFF	ON	OFF	parallel 5
6	OFF	ON	ON	OFF	parallel 6
7	ON	ON	ON	OFF	parallel 7
8	OFF	OFF	OFF	ON	parallel 8
9	ON	OFF	OFF	ON	parallel 9
10	OFF	ON	OFF	ON	parallel 10
11	ON	ON	OFF	ON	parallel 11
12	OFF	OFF	ON	ON	parallel 12
13	ON	OFF	ON	ON	parallel 13
14	OFF	ON	ON	ON	parallel 14

Table3-4-3 Parallel dialing code setting example (Table 3)

Number of parallel machines	DIP switch position								Instruction
	#1	#2	#3	#4	#5	#6	#7	#8	
Standalone use	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	Standalone use
Parallel 2	OFF	OFF	OFF	OFF	ON	OFF	OFF	OFF	First host
	ON	OFF							
Parallel 3	OFF	OFF	OFF	OFF	OFF	ON	OFF	OFF	
	ON	OFF							
	OFF	ON	OFF	OFF	OFF	OFF	OFF	OFF	
...
...
Parallel 16	OFF	OFF	OFF	OFF	ON	ON	ON	ON	First host
	ON	OFF	Second slave						
	OFF	ON	OFF	OFF	OFF	OFF	OFF	OFF	Third slave
	ON	ON	OFF	OFF	OFF	OFF	OFF	OFF	Forth slave
	OFF	OFF	ON	OFF	OFF	OFF	OFF	OFF	Fifth slave
	ON	OFF	ON	OFF	OFF	OFF	OFF	OFF	Sixth slave
	OFF	ON	ON	OFF	OFF	OFF	OFF	OFF	Seventh slave
	ON	ON	ON	OFF	OFF	OFF	OFF	OFF	Eighth slave
	OFF	OFF	OFF	ON	OFF	OFF	OFF	OFF	Ninth slave
	ON	OFF	OFF	ON	OFF	OFF	OFF	OFF	Tenth slave
	OFF	ON	OFF	ON	OFF	OFF	OFF	OFF	Eleventh slave
	ON	ON	OFF	ON	OFF	OFF	OFF	OFF	Twelfth slave
	OFF	OFF	ON	ON	OFF	OFF	OFF	OFF	Thirteenth slave
	ON	OFF	ON	ON	OFF	OFF	OFF	OFF	Fourteenth slave
	OFF	ON	ON	ON	OFF	OFF	OFF	OFF	Fifteenth slave
	ON	ON	ON	ON	OFF	OFF	OFF	OFF	Sixteenth slave

DIP switch description

When the battery pack is connected in parallel, the host can communicate with the slave through the RS485 interface. The host summarizes the information of the entire battery system and communicates with the inverter through RS485.

4 Use, maintenance and trouble shooting

4.1 Battery system usage and operation instructions

After completing the electrical installation, follow these steps to start the battery.

- Press the switch, the system self-check, the indicator lights turn on successively (4.1.1).
- The RUN indicator blinks slowly if the battery is not connected to the inverter (4.1.2).
- If the battery is connected with the inverter, the battery start working and the indicator lights up (4.1.3).



4.1.1



4.1.2



4.1.3

Note

After pressing the power button, if the battery status indicator on the front panel continues to be red, please refer to the "4.2 Alarm description and processing". If the failure cannot be eliminated, please contact the dealer timely.

- Use a voltmeter to measure whether the voltage across the BAT+/ BAT- terminals of the inverter is greater than 42V, and check whether the voltage polarity is consistent with the input polarity of the inverter. If the voltage across the terminals BAT + / BAT- of the inverter is greater than 42V, at this time the battery has begun to work normally.
- After confirming that the battery output voltage and polarity are correct, turn on the inverter, then close the circuit breaker switch.
- Check whether the indicator light of the inverter and the battery connection (The communication indicator and the battery access status indicator.) is in normal condition. If normal, the connection between the battery and the inverter is completed. If there is an abnormality in the indicator light, please check the reason or contact the local dealer with the inverter manual.

4.2 Alarm description and processing

When protection start or failure, the ALM indicator on the side panel will alarm, through net management can query specific alarm class and take appropriate action.

4.2.1 Alarm and countermeasure influence system output

If there are any abnormalities affecting the output, such as battery cell in the battery module occurs over-voltage protection or over-current protection during charge/ discharge, under-voltage protection, and temperature protection, in the system, please deal with them according to Table 4-1.

Table 4-1 Main alarm and Protection

Statue	Alarm category	Alarm indication	Processing
Charging state	Cell over-voltage	RUN light flashing 1	Stop charging and release when discharging.
	Over-current when charging	Run light on RED flashing 2	Reduce the charging current below the rated value.
	High temp protection	RED light flashing 1	Stop charging and find out the cause of the trouble.
Discharge state	Over-current protection when discharge	RED light on	Stop discharge and reduce discharge current below rated value.
	High temp protection when discharge	RED light on	Stop discharging and find out the cause of the trouble.
	Total voltage under voltage protection	ALL lights OFF successively	Start charging

4.2.2 Alarm and countermeasure without affecting the output of the system

If a low SOC alarm occurs, the battery system also issues a corresponding alarm signal. Maintainer should check the equipment according to the prompt information, determine the type and location of the fault, and take corresponding countermeasures to ensure that the system is in the best working condition to avoid affecting the system output. The phenomena and countermeasures are shown in Table 4-2.

Table 4-2 minor alarm

Alert category	Alarm indication	Counter measure
5% < SOC ≤ 10%	System operating status: The indicator blinks red slowly	Stop discharge and charging the battery system in time.

4.3 Analysis and treatment of common faults

Analysis and treatment of common faults in the Table 4-3:

Table 4-3 Analysis and treatment of common faults

Item	Fault phenomenon	Reason analysis	Solution
1	The indicator does not respond after power on the system.	Make sure press and hold the power switch (Reset switch) for 3s.	Check the power switch
2	No DC output after power on the system.	Check if the main cable is inserted into the installation position.	Check and ensure the main cable is firmly inserted
3	No DC output and red light flashing.	Battery voltage is too low.	Charging the battery system
4	The battery cannot be fully charged.	Charging voltage is too low.	Adjust charging voltage within 53.5V range
5	The power line sparks once power on and ALM indicated Red light on.	Power connection short-circuit.	Turn off the battery, check the cause of the short circuit


WUXI SUNKET NEW ENERGY TECHNOLOGY CO., LTD

Add: No.888, Delin Industry Park, Qinghong Road, E'hu Town, Wuxi, Jiangsu, P.R.C


Tel: +86-51088785930

Email: sales@sunket.cn

Appendix I 5KWh Target Size



Appendix II 10KWh Target Size



5 Bluetooth APP connection guide

5.1 Android and iOS software download and installation

Android system	https://www.pgyer.com/1a8ce42e6c1a9f2d37dcaa6a790e40c2 Open the webpage using WeChat or a browser, scan the QR code on the webpage for download and installation.
QR code	 <p>After downloading the APK file, click on 'Install'</p>
Latest version	V1.0.17
iOS system	Search for "EN BMS" in the Apple Store (note the space in the middle)
Search interface	

5.2 User login

illustrate	<ol style="list-style-type: none"> 1. Click on the app icon to open the app, click "English" to directly switch to the English interface, as shown in Figure 5.2.1 2. Enter username and password (default username: admin, default password: 111111) 3. Click on 'Login' <p>Steps 1-3 are detailed in Figure 5.2.2</p>
------------	--

LFP 5-10kWh/ LV User Manual

<p>Login interface</p>	
------------------------	--

5.3 Device Connection

<p>illustrate</p>	<ol style="list-style-type: none"> As shown in Figure 2.3.1, after the user logs in, the "Device" interface will display the device name found. -Single machine: BP00 is displayed due to all dialed addresses of the single machine being 0 -Parallel connection: To avoid user connection errors, only the host address BP00 is displayed; The parallel switching operation can be switched on the main page - status bar 6 after entering the app system As shown in Figure 2.3.2, click on "Device BP00" to connect the phone to the battery Bluetooth module In some cases, due to the possibility of the on-site signal being blocked and the Bluetooth signal being unstable, please click on "Re search for devices" to refresh the "Devices" list
<p>Connection interface</p>	

5.4 Display of APP main interface

illustrate	<ol style="list-style-type: none">1. Display the main interface, which can be used to display single machine and parallel machine information.2. Single machine mode can be selected: BP00 (host), BP01~BP15 (slave); Status bar 6 displays "Parallel BPxx"3. When in parallel mode, status bar 6 displays "Parallel Parallel"4. In parallel mode, status bars 1-4 display summary data for parallel operation; The protocol type displayed in status bar 5 is the connection between the host BP00 and the inverter; Status bar 6 is grayed out for "Device Details"/"Configuration Parameters"/"Switch Settings", and cannot be displayed or configured except for the parallel status.5. In single machine mode, the status bars 2-5 are all selected single machine data; Status bar 6 displays the selected single machine number, "Device Details", "Configuration Parameters", and "Switch Settings"; Its "configuration parameters" and "switch settings" can be viewed and modified.
------------	---

LFP 5-10kWh/ LV User Manual

main interface

Multi
Parallel Machines: 2 Online Quantity: 1
Number Of Strings: 16 SOC:31.5% 62.66V 0.0A Remaining Capacity: 31.6Ah
Standby

Status bar 1: Single machine/parallel machine status display; Bluetooth connection status display

Status bar 2: Battery string number, SOC, battery voltage, charging and discharging current, remaining capacity display, battery working status (charging, discharging, standby)

Alarm: 0 Alarm Info Protection: 0 ...

Status bar 3: Alarm and protection item statistics, click to view details. The alarm details are shown in Figure 5.4.2; For protection details, see 5.4.3; Click on the specific alarm/protection entry to display information such as the occurrence time

Battery Type	Rated Capacity	Battery Capacity
LFP	200.0Ah	100.0Ah
Port Voltage	Number Of Cycles	SOH
52.71V	2	100.0%

Status bar 4: Display of basic battery information; Display single machine information during single machine operation and parallel machine statistics during parallel machine operation

Inverter CAN: PN_GDLT
Inverter 485: PN

Status bar 5: Inverter Connection Protocol Display and Settings
-CAN: Supports 6 mainstream options and 10 protocols
-485: Supports 5 different RS485 protocols

Multi-Multi > Device Detail
Set Param Switch Setting

Status bar 6: Parallel/single machine display and master-slave switching, as shown in Figure 5.4.4

Device details: Single machine mode (highlighted) can display battery pack details; Click to view the details, as shown in Figure 5.4.5

Configuration parameters: Single machine mode (highlighted) can display/configure battery pack parameters. Click to view the details, as shown in Figure 5.4.6

Switch setting: Single machine mode (highlighted) can set the battery pack switch. Click to view the details, as shown in Figure 5.4.7

5.4.1

Pls choose device Scan again
Multi
BP00
BP01

5.4.4

Warning

- Temperature sensing failure
- Cell pressure difference failure
- Cell low voltage charging prohibition

5.4.2

Protection

- Single cell overvoltage protection
- Single cell undervoltage protection
- Total voltage undervoltage protection
- Charging under temperature protection

5.4.3

LFP 5-10kWh/ LV User Manual




5.4.5

1. Display the highest/lowest voltage of the battery cell, and all battery cell voltages
2. Display maximum/minimum temperature, all temperatures
3. Display
 Manufacturer information: CAN or RS485 communication, protocol name with inverter
 Component model: Customer board model
 Software version: BMS software version
 Protocol version: Communication protocol version between BMS and APP



5.4.6-1


1. In single machine mode (see Figure 5.4.4 for details of parallel/single machine mode switching), click "Edit" (Figure 5.4.6-1), enter password 111111 (Figure 5.4.6-2) to set configuration parameters, and click Save (Figure 5.4.6-3)
2. After clicking "Save", the system will prompt "Confirm modification". After confirmation, the newly modified parameters will be automatically issued to the BMS board for



5.4.6-2

5.4.6-3

LFP 5-10kWh/ LV User Manual



5.4.7-1

1. In single mode (see Figure 5.4.4 for details of parallel/single mode switching), click "Edit" (Figure 5.4.7-1), enter password 111111 (Figure 5.4.7-2) to modify the function switch, and click Save (Figure 5.4.7-3)

2. After clicking "Save", the system will prompt "Confirm modification". After confirmation, the newly modified parameters will be automatically issued to the BMS board for executionexecution




5.4.7-2



5.4.7-3

5.5 Other interface displays

<p>illustrate</p>	<ol style="list-style-type: none"> 1. Display "About Us" and "Change Password" and log out, as shown in Figure 5.5.1 2. Click on 'About Us', as shown in Figure 5.5.2 3. Click on "Change Password" to modify the login password. Clicking 'Finish' will automatically complete the modifications
<p>screenshot</p>	 <p style="text-align: center;">5.5.1 5.5.2</p>