



# Solis S5 Three Phase Inverter

S5-GR3P(15-20)K **Installation and Operation Manual**

(For Australia)

Ver 1.2

Ginlong Technologies Co., Ltd.

No. 57 Jintong Road, Binhai Industrial Park, Xiangshan, Ningbo,  
Zhejiang, 315712, P.R.China.

Tel: +86 (0)574 6578 1806

Fax: +86 (0)574 6578 1606

Email: info@ginlong.com

Web: www.ginlong.com

Please adhere to the actual products in case of any discrepancies in this user manual.

If you encounter any problem on the inverter, please find out the inverter S/N  
and contact us, we will try to respond to your question ASAP.



Ginlong Technologies Co., Ltd.

|  |           |
|--|-----------|
| <b>1. Introduction</b>                 | <b>2</b>  |
| 1.1 Product Description                | 2         |
| 1.2 Packaging                          | 3         |
| <b>2. Safety Instructions</b>          | <b>4</b>  |
| 2.1 Safety Symbols                     | 4         |
| 2.2 General Safety Instructions        | 4         |
| 2.3 Notice For Use                     | 5         |
| 2.4 Notice for Disposal                | 5         |
| <b>3. Overview</b>                     | <b>6</b>  |
| 3.1 Front Panel Display                | 6         |
| 3.2 LED Status Indicator Lights        | 6         |
| 3.3 Keypad                             | 6         |
| 3.4 LCD                                | 6         |
| <b>4. Product handling and storage</b> | <b>7</b>  |
| 4.1 Product handling                   | 7         |
| 4.2 Product Storage                    | 8         |
| <b>5. Installation</b>                 | <b>9</b>  |
| 5.1 Select Location for the Inverter   | 9         |
| 5.2 Mounting the Inverter              | 11        |
| 5.3 Electrical Connections             | 13        |
| <b>6. Start &amp; Stop</b>             | <b>25</b> |
| 6.1 Start the Inverter                 | 25        |
| 6.2 Stop the Inverter                  | 25        |
| <b>7. Operation</b>                    | <b>26</b> |
| 7.1 Main Menu                          | 26        |
| 7.2 Information                        | 26        |
| 7.3 Settings                           | 28        |
| 7.4 Advanced Info.                     | 29        |
| 7.5 Advanced Settings                  | 33        |
| 7.6 AFCI function                      | 46        |
| <b>8. Maintenance</b>                  | <b>48</b> |
| <b>9. Troubleshooting</b>              | <b>49</b> |
| <b>10. Specifications</b>              | <b>52</b> |
| <b>11. Appendix</b>                    | <b>58</b> |



# 1. Introduction

## 1.1 Product Description

Solis S5 three phase inverters integrate DRM and backflow power control function, that is suitable for smart grid requirement.

This manual covers the three phase inverter model listed below:


S5-GR3P15K, S5-GR3P17K, S5-GR3P20K



# 1. Introduction

## 1.2 Packaging

When you receive the inverter, please ensure that all the parts listed below are included:



If anything is missing, please contact your local Solis distributor.

## 2. Safety Instructions

### 2.1 Safety Symbols

Safety symbols used in this manual, which highlight potential safety risks and important safety information, are listed as follows:



**WARNING:**

WARNING symbol indicates important safety instructions, which if not correctly followed, could result in serious injury or death.



**NOTE:**

NOTE symbol indicates important safety instructions, which if not correctly followed, could result in some damage or the destruction of the inverter.



**CAUTION:**

CAUTION, RISK OF ELECTRIC SHOCK symbol indicates important safety instructions, which if not correctly followed, could result in electric shock.



**CAUTION:**

CAUTION, HOT SURFACE symbol indicates safety instructions, which if not correctly followed, could result in burns.

### 2.2 General Safety Instructions



**WARNING:**

Please don't connect PV array positive(+) or negative(-) to ground, it could cause serious damage to the inverter.



**WARNING:**

Electrical installations must be done in accordance with the local and national electrical safety standards.



**WARNING:**

To reduce the risk of fire, over-current protective devices (OCPD) are required for circuits connected to the Inverter. The DC OCPD shall be installed per local requirements. All photovoltaic source and output circuit conductors shall have disconnects that comply with the NEC Article 690, Part II. All Solis three phase inverters feature an integrated DC switch.



**CAUTION:**

Risk of electric shock. Do not remove cover. There is no user serviceable parts inside. Refer servicing to qualified and accredited service technicians.

## 2. Safety Instructions



**CAUTION:**

The PV array (Solar panels) supplies a DC voltage when they are exposed to sunlight.



**CAUTION:**

Risk of electric shock from energy stored in capacitors of the Inverter. Do not remove cover for 5 minutes after disconnecting all power sources (service technician only). Warranty may be voided if the cover is removed without unauthorized.



**CAUTION:**

The surface temperature of the inverter can exceed 75°C (167°F). To avoid risk of burns, DO NOT touch the surface when inverter is operating. The inverter must be installed out of reach of children.

### 2.3 Notice For Use

The inverter has been constructed according to the applicable safety and technical guidelines. Use the inverter in installations that meet the following specifications only:

1. Permanent installation is required.
2. The electrical installation must meet all the applicable regulations and standards.
3. The inverter must be installed according to the instructions stated in this manual.
4. The inverter must be installed according to the correct technical specifications.
5. To startup the inverter, the Grid Supply Main Switch (AC) must be switched on, before the solar panel's DC isolator shall be switched on. To stop the inverter, the Grid Supply Main Switch (AC) must be switched off before the solar panel's DC isolator shall be switched off.

### 2.4 Notice for Disposal

This product shall not be disposed of with household waste. They should be segregated and brought to an appropriate collection point to enable recycling and avoid potential impacts on the environment and human health. Local rules in waste management shall be respected.



## 3. Overview

### 3.1 Front Panel Display



Figure 3.1 Front Panel Display

### 3.2 LED Status Indicator Lights

|   | Light       | Status   | Description                                       |
|---|-------------|----------|---|
| ① | ● POWER     | ON       | The inverter can detect DC power.                 |
|   |             | OFF      | No DC power or low DC power.                      |
| ② | ● OPERATION | ON       | The inverter is operating properly.               |
|   |             | OFF      | The inverter has stopped to supply power.         |
|   |             | FLASHING | The inverter is initializing.                     |
| ③ | ● ALARM     | ON       | Alarm or fault condition is detected.             |
|   |             | OFF      | The inverter is operating without fault or alarm. |

Table 3.1 Status Indicator Lights

### 3.3 Keypad

There are four keys in the front panel of the Inverter(from left to right): ESC, UP, DOWN and ENTER keys. The keypad is used for:

- Scrolling through the displayed options (the UP and DOWN keys);
- Access to modify the adjustable settings (the ESC and ENTER keys).

### 3.4 LCD

The two-line Liquid Crystal Display (LCD) is located on the front panel of the Inverter, which shows the following information:

- Inverter operation status and data;
- Service messages for operator;
- Alarm messages and fault indications.

## 4. Product handing and storage

### 4.1 Product handling

Please review the instruction below for handling the inverter:

1 The red circles below denote cutouts on the product package.

Push in the cutouts to form handles for moving the inverter (see Figure 4.1).




Figure 4.1 move the inverter

2.Open the carton, then handle both sides of inverter through the area denoted dotted line. ( see figure 4.2).




Figure 4.2 Inverter handles

## 4. Product handing and storage

### 4.2 Product Storage

If the inverter is not to be installed immediately, storage instructions and environmental conditions are below:

- Use the original box to repackage the inverter, seal with adhesive tape with the desiccant inside the box.
- Store the inverter(s) in a clean and dry place, free of dust and dirt.
- Storage temperature must be between -40°C and 70°C and the humidity should be between 0 and 95% non-condensing.
- Stack no more than three (3) inverters high.
- Keep box(es) away from corrosive materials to avoid damage to the inverter enclosure.
- Inspect packaging regularly. If packaging is damaged(wet, pest damage, etc), repackage the inverter immediately.
- Store the inverter(s) on a flat, hard surface - not inclined or upside down.
- After long-term storage, the inverter needs to be fully examined and tested by qualified service or technical personnel before using.
- Restarting after a long period of non-use requires the equipment to be inspected and, in some cases, the removal of oxidation and dust that has settled inside the equipment will be required.

## 5. Installation

### 5.1 Select a Location for the Inverter

To select a location for the inverter, the following criteria should be considered:



#### **WARNING: Risk of fire**

Despite careful construction, electrical devices can cause fires.

- Do not install the inverter in areas containing highly flammable materials or gases.
- Do not install the inverter in potentially explosive atmospheres.

- Do not install in small closed spaces where air can not circulate freely. To avoid overheating, always make sure the flow of air around the inverter is not blocked.
- Exposure to direct sunlight will increase the operational temperature of the inverter and may cause output power limiting. Ginlong recommends inverter installed to avoid direct sunlight or raining.
- To avoid over heating ambient air temperature must be considered when choosing the inverter installation location. Ginlong recommends using a sun shade minimizing direct sunlight when the ambient air temperature around the unit exceeds 104°F/40°C.



Figure 5.1 Recommended Installation locations




#### **NOTE:**


Nothing should be stored on or placed against the inverter.



## 5. Installation



- The visibility of LED status indicator lights and LCD should be considered.
- Install vertically (+/- 5°) or tilted backward (<=15°).
- Don't mount inverter on the tilted forward wall.
- Don't mount inverter on the horizontal.



- Temperature of inverter heat sink might 167°F/75°C.
- Inverter is designed for working extreme environment, operation temperature range: -15°F/25°C~149°F/65°C.
- When 1 or more inverters are installed in one location, a minimum 500mm clearance should be kept between each inverter or other object. The bottom of the inverter should be 500mm clearance to the ground.

## 5. Installation

### 5.2 Mounting the Inverter

Dimensions of mounting bracket:




Figure 5.3 Inverter wall mounting

Refer to figure 5.4 and figure 5.5. Inverter shall be mounted vertically. The steps to mount the inverter are listed below.

1. Refer to Figure 5.4, the holes for expansion bolt based on the hole diameter of bracket (ST6.3\*60 cross recessed hexagon head tapping screws, HJ0108 10\*50mm fished expandable tubular), using the percussion drilling with the 10mm drill need to stay vertically on the wall. And the drill hole must be vertically on the wall. And all drill holes' depth is 60mm.




Figure 5.4 Inverter wall mounting

2. Make sure the bracket is horizontal. And the mounting holes (in Figure 5.4) are marked correctly. Drill the holes into wall at your marks.
3. Use the suitable expansion screws to fix the bracket on the wall.

## 5. Installation



### WARNING:

The inverter must be mounted vertically.




Figure 5.5 Install the inverter

4. Lift the inverter and hang it on the bracket, and fixing both sides of inverter with locking screws (accessories).




Figure 5.6 Fixed the inverter

## 5. Installation

### 5. Anti-theft lock mount(optional)

Anti-theft lock( User-supplied) function is that inverter is fixed in bracket in case theft. The lock is selected by 5mm(the keyhole diameter), and the lock of stainless steel is preferred.




Figure 5.7 Install security lock

### 5.3 Electrical Connections

Inverter designs quick-connect terminal, so top cover needn't open during electrical connection. The sign meaning located the bottom of inverter, as shown below in table 5.1. All electrical connections are suit for the local or national standard.

|           |  |
|-----------|--|
| +         | Positive DC input terminal                           |
| -         | Negative DC input terminal                           |
| DC 1      | DC input terminal                                    |
| DC 2      | DC input terminal                                    |
| DC SWITCH | Switch of DC input terminals                         |
| COM       | RJ45 and terminal block for RS485 communication port |
| GRID      | Connecting terminal of the Grid                      |

Table 5.1 Electrical connection symbols

The electrical connection of the inverter must follow the steps listed below:

1. Switch the Grid Supply Main Switch (AC) OFF.
2. Switch the DC Isolator OFF.
3. Assemble PV input connector to the Inverter.



## 5. Installation

### 5.3.1 Grounding

To effectively protect the inverter, two grounding methods must be performed.  
Connect the AC grounding cable (Please refer to section 5.3.3).  
Connect the external grounding terminal.

To connect the grounding terminal on the heat sink, please follow the steps below:

- 1) Prepare the grounding cable: recommend to use the  $\geq 6\text{mm}^2$  outdoor copper-core cable.
- 2) Prepare OT terminals: M6.



**Important:**

For multiple inverters in parallel, all inverters should be connected to the same ground point to eliminate the possibility of a voltage potential existing between inverter grounds.

- 3) Strip the ground cable insulation to a suitable length (see Figure 5.8).




Figure 5.8 suitable length



**Important:**

B (insulation stripping length) is 2mm~3mm longer than A (OT cable terminal crimping area) 2mm~3mm.

- 4) Insert the stripped wire into the OT terminal crimping area and use the hydraulic clamp to crimp the terminal to the wire (see Figure 5.9).




Figure 5.9 strip wire



**Important:**

After crimping the terminal to the wire, inspect the connection to ensure the terminal is solidly crimped to the wire.

- 5) Remove the screw from the heat sink ground point.
- 6) Connect the grounding cable to the grounding point on the heat sink, and tighten the grounding screw, Torque is 3Nm (see figure 5.10).




Figure 5.10 Fixed cable



**Important:**

For improving anti-corrosion performance, after ground cable installed, apply silicone or paint is preferred to protect.

## 5. Installation

## 5. Installation

### 5.3.2 Connect PV side of inverter



Before connecting inverter, please make sure the PV array open circuit voltage is within the limit of the inverter.



Before connection, please make sure the polarity of the output voltage of PV array matches the “DC+” and “DC-” symbols.



Before connecting inverter, please make sure the PV array open circuit voltage is within the limit of the inverter.




Figure 5.11 DC+ Connector




Figure 5.12 DC- Connector



Please use approved DC cable for PV system.

| Cable type                                  | Cross section (mm <sup>2</sup> ) |                   |
|---|----------------------------------|-------------------|
|   | Range                            | Recommended value |
| Industry generic PV cable<br>(model: PV1-F) | 4.0~6.0<br>(12~10AWG)            | 4.0 (12AWG)       |

The steps to assemble the DC connectors are listed as follows:

1. Strip off the DC wire for about 7mm, Disassemble the connector cap nut. (see Figure 5.13)
2. Insert the wire into the connector cap nut and contact pin. (see Figure 5.14)
3. Crimp the contact pin to the wire using a proper wire crimper. (see Figure 5.15)
4. Insert metal connector into top of connector, and tighten nut with torque 2.5-3 Nm (see figure 5.16).

## 5. Installation

5. Measure PV voltage of DC input with multimeter, verify DC Input cable polar (see figure 5.17), and ensure each string of PV voltage in range of inverter operation. Connect DC connector with inverter until hearing a slight clicking sound indicates connection succeed. (see figure 5.18)



Figure 5.13 Disassemble the Connector Cap nut




Figure 5.14 Insert the Wire into the Connector Cap nut and contact pin



Figure 5.15 Crimp the contact pin to the wire



Figure 5.16 Connector with Cap nut Screwed on



Figure 5.17 Multimeter measurement




Figure 5.18 Connect the DC Connectors to the Inverter



#### Caution:

If DC inputs are accidentally reversely connected or inverter is faulty or not working properly, it is NOT allowed to turn off the DC switch as it will damage the inverter and even leads to a fire disaster.

The correct actions are:

\*Use a clip-on ammeter to measure the DC string current.

\*If it is above 0.5A, please wait for the solar irradiance reduces until the current decreases to below 0.5A.

\*Only after the current is below 0.5A, you are allowed to turn off the DC switches and disconnect the PV strings.

Please note that any damages due to wrong operations are not covered in the device warranty.

## 5. Installation

### 5.3.3 Connect grid side of inverter

For all AC connections, 6-16mm<sup>2</sup>, YJV-0.6/1KV cable is required to be used. Please make sure the resistance of cable is lower than 1.50hm. If the wire is longer than 20m, preferred to 10-16mm<sup>2</sup> cable.



Internal of AC connector signs "L1", "L2", "L3", "N" and "PE" five connection ports (see Figure 5.21). Three live wires are connected the "L1", "L2" and "L3" terminals respectively; ground wire connects "PE"; neutral wire connects "N" terminal:




Figure 5.19 AC connector

|               | Number | Description  |
|---------------|--------|--|
| AC connectors | A      | Socket element                                     |
|               | B      | Adapter  |
|               | C      | Seal ring(Thin:13-20mm cable. Thick:20-26mm cable) |
|               | D      | Swivel nut   |




Figure 5.20 Stripped and bared wire




Figure 5.21 Internal structure of AC connector

## 5. Installation

The steps of AC grid terminal connector for install as follows:

A) Stripped the insulation sleeve of cable for 70mm, so that bared copper-cored connector reaches for 9mm. Cable through nut and sleeve of socket element, insert corresponding terminals and tighten with allen wrench with 1.8-2.5N.m torque(see figure 5.22).




Figure 5.22 Connected cable



Tighten cable with 3.0 mm allen wrench( focus in dotted box, see figure 5.22). Allen screw is easy to drop off, don't screw out completely.



B) Clip plastic fixture (Auxiliary tighten) in socket element , tighten adapter in socket element, then tighten swivel nut with 3.5-4.5N.m torque (see figure 5.23).




Figure 5.23 Assembly AC terminal

C) Connect AC connector with inverter(see figure 5.24), until hearing a slight clicking sound indicates connection succeed.




Figure 5.24 AC connector to inverter

## 5. Installation

### 5.3.4 Max. over current protection device (OCPD)

To protect the inverter's AC grid connection conductors, Solis recommends installing breakers that will protect against overcurrent.

The following table defines OCPD ratings for the Solis three phase inverters.

| Inverter   | Rated voltage(V) | Rated output current (A) | Current for protection device (A) |
|------------|------------------|--------------------------|-----------------------------------|
| S5-GR3P15K | 230/400          | 23.8                     | 32                                |
| S5-GR3P17K | 230/400          | 27.0                     | 40                                |
| S5-GR3P20K | 230/400          | 31.8                     | 40                                |

Table 5.2 Rating of grid OCPD

### 5.3.5 Inverter monitoring connection

The inverter can be monitored via Wi-Fi or GPRS. All Solis communication devices are optional (Figure 5.25). For connection instructions, please refer to the Solis Monitoring Device installation manuals.




Figure 5.25 Wireless communication function

## 5. Installation

### 5.3.6 Meter Connection(optional)

The inverter can work with a three phase smart meter to achieve Export Power Management function and/or 24hour consumption monitoring function.



#### NOTE

To achieve Export Power Management function, the smart meter can be installed on either grid side or load side.

To achieve 24hour consumption monitoring function, the smart meter can only be installed on grid side.

Two types of meters are supported:

Direct Insert Type Meter - Max input current 80A(DTSD1352-Direct Insert Type).

External CT Type Meter - 150A/5A CTs are supplied(DTSD1352-External CT Type).

Customer can place the order for a suitable meter from Solis Sales Reps.

Below are the connection diagrams of different meters connecting to different locations.

Detailed settings please refer to Section 7.5.12







Figure 5.26 Direct Insert Type Meter - "Meter in Grid"



## 5. Installation



## 5. Installation



### 5.3.7 External Residual Current Device(RCD)

All series of Solis inverters are integrated with an internal residual current device to protect against any potential d.c component and a.c component of residual current.

Therefore, all Solis inverters, due to the design, are not able to feed in DC fault current to the system which fully complies with IEC60364-7-712.

If an external RCD is required to be installed by local regulations, Solis recommends installing a Type-ARCD with a threshold current higher than 100mA.



## 5. Installation

### 5.3.8 DRED port connections

DRED means demand response enable device. The AS/NZS 4777.2:2020 required inverter need to support demand response mode(DRM). This function is for inverter that comply with AS/NZS 4777.2:2020 standard.

A RJ45 terminal is used for DRM connection.

| Pin | Assignment for inverters capable of both charging and discharging | Pin | Assignment for inverters capable of both charging and discharging |
|-----|---|-----|---|
| 1   | DRM 1/5   | 5   | RefGen  |
| 2   | DRM 2/6   | 6   | Com/DRM0  |
| 3   | DRM 3/7   | 7   | V+  |
| 4   | DRM 4/8   | 8   | V-  |



#### NOTE:

Solis inverter is designed to provide 12V power for DRED.

Please follow below steps to assemble RJ45 connector.

1. Insert the network cable into the communication connection terminal of RJ45.



Figure 5.30 RJ45 communication connection terminals

2. Use the network wire stripper to strip the insulation layer of the communication cable. According to the standard line sequence of figure 5.31 connect the wire to the plug of RJ45, and then use a network cable crimping tool to make it tight.



#### Correspondence between the cables and the stitches of plug

Pin 1: white and orange ; Pin 2: orange  
Pin 3: white and green ; Pin 4: blue  
Pin 5: white and blue ; Pin 6: green  
Pin 7: white and brown ; Pin 8: brown

Figure 5.31 Strip the insulation layer and connect to RJ45 plug

3. Connect RJ45 to DRM port.

### 5.3.9 Earth Fault Alarm

Solis inverters fully comply with IEC62109-2 in terms of earth fault alarm (PV insulation detection and protection). When the earth fault on PV side happens, the yellow alarm indicator will flash and the alarm code "PVISO-PRO" will show up on the LCD screen.

Inverter should be installed in a high traffic area to ensure the alarm to be noticed.

The inverter can't start to generate until the earth fault is resolved. Please refer to the troubleshooting section of this manual to resolve the earth fault or contact Solis service team for help.

## 6. Start & Stop

### 6.1 Start the Inverter

To start up the Inverter, it is important that the following steps are strictly followed:

1. Switch the grid supply main Switch (AC) ON first.
2. Switch the DC switch ON. If the voltage of PV arrays are higher than start up voltage, the inverter will turn on. The red LED power will light.
3. When both the DC and the AC sides supply to the inverter, it will be ready to generate power. Initially, the inverter will check both its internal parameters and the parameters of the AC grid, to ensure that they are within the acceptable limits. At the same time, the green LED will flash and the LCD displays the information of INITIALIZING.
4. After 30-300 seconds (depending on local requirement), the inverter will start to generate power. The green LED will be on continually and the LCD displays GENERATING.



#### WARNING:

Do not touch the surface when the inverter is operating. It may be hot and cause burns.

### 6.2 Stop the Inverter

To stop the inverter, it is mandatory that the steps below are followed in the exact order outlined.

1. Select "Grid Off" in the Advanced Setting of Inverter LCD.
2. Turn off the AC Switch between Solis inverter and Grid.
3. Wait approximately 30 seconds (during this time, the AC side capacitors are dissipating energy). If the inverter has DC voltage above the start-up threshold, the red POWER LED will be lit. Switch the DC switch OFF.
4. Confirm all LED's switch OFF (~one (1) minute).




#### CAUTION

Although the inverter DC disconnect switch is in the OFF position and all the LED's are OFF, operators must wait five (5) minutes after the DC power source has been disconnected before opening the inverter cabinet. DC side capacitors can take up to five (5) minutes to dissipate all stored energy.

## 7. Operation

In normal operation, LCD screen alternatively shows inverter power and operation status (see Figure 7.1). The screen can be scrolled manually by pressing the UP/DOWN keys. Pressing the ENTER key gives access to Main Menu.



### 7.1 Main Menu

There are four submenus in the Main Menu (see Figure 7.1):

1. **Information**
2. **Settings**
3. **Advanced Info.**
4. **Advanced Settings**

### 7.2 Information

The Solis three Phase S5 Inverter main menu provides access to operational data and information. The information is displayed by selecting "Information" from the menu and then by scrolling up or down.

## 7. Operation

| Display                                    | Duration | Description  |
|--|----------|--|
| V_DC1 350.8V<br>I_DC1 5.1A                 | 10 sec   | V_DC1: Shows input 01 voltage value.<br>I_DC1: Shows input 01 current value.                     |
| V_DC2 350.8V<br>I_DC2 5.1A                 | 10 sec   | V_DC2: Shows input 02 voltage value.<br>I_DC2: Shows input 02 current value.                     |
| V_A 230.4V<br>I_A 8.1A                     | 10 sec   | V_A: Shows the grid's voltage value.<br>I_A: Shows the grid's current value.                     |
| V_C 230.4V<br>I_C 8.1A                     | 10 sec   | V_C: Shows the grid's voltage value.<br>I_C: Shows the grid's current value.                     |
| Status: Generating<br>Power: 1488W         | 10 sec   | Status: Shows instant status of the Inverter.<br>Power: Shows instant output power value.        |
| Grid Frequency<br>F_Grid 50.06Hz           | 10 sec   | F_Grid: Shows the grid's frequency value.  |
| Total Energy<br>0258458 kwh                | 10 sec   | Total generated energy value.  |
| This Month: 0123kwh<br>Last Month: 0123kwh | 10 sec   | This Month: Total energy generated this month.<br>Last Month: Total energy generated last month. |
| Today: 15.1kwh<br>Yesterday: 13.5kwh       | 10 sec   | Today: Total energy generated today.<br>Yesterday: Total energy generated yesterday.             |
| Inverter SN<br>00000000000000              | 10 sec   | Display series number of the inverter.   |

Table 7.1 Information list

### 7.2.1 Lock screen

Pressing the ESC key returns to the Main Menu. Pressing the ENTER key locks (Figure 7.2(a)) or unlocks (Figure 7.2 (b)) the screen.



(a)



(b)

Figure 7.2 Locks and Unlocks the Screen of LCD

## 7. Operation

### 7.3 Settings


The following submenus are displayed when the Settings menu is selected:

#### 1.Set Time

#### 2.Set Address

#### 7.3.1 Set Time

This function allows time and date setting. When this function is selected, the LCD will display a screen as shown in Figure 7.3.




NEXT=<ENT> OK=<ESC>  
01-01-2016 16:37

Figure 7.3 Set Time

Press the UP/DOWN keys to set time and data. Press the ENTER key to move from one digit to the next (from left to right). Press the ESC key to save the settings and return to the previous menu.

#### 7.3.2 Set Address

This function is used to set the address when multi inverters are connected to three monitor. The address number can be assigned from "01" to "99" (see Figure 7.4). The default address number of Solis Three Phase Inverter is "01".



YES=<ENT> NO=<ESC>  
Set Address: 01

Figure 7.4 Set Address

Press the UP/DOWN keys to set the address. Press the ENTER key to save the settings. Press the ESC key to cancel the change and return to the previous menu.

## 7. Operation


### 7.4 Advanced Info - Technicians Only



#### NOTE:

To access to this area is for fully qualified and accredited technicians only. Enter menu "Advanced Info." and "Advanced settings" (need password).

Select "Advanced Info." from the Main Menu. The screen will require the password as below:



YES=<ENT> NO=<ESC>  
Password:0000

Figure 7.5 Enter password

The default password is "0010".

Please press "down" to move the cursor, press "up" to select the number.


After enter the correct password the Main Menu will display a screen and be able to access to the following information.

1. Alarm Message
2. Running message
3. Version
4. Daily Energy
5. Monthly Energy
6. Yearly Energy
7. Daily Record
8. Communication Data
9. Warning Message
10. Inspection

The screen can be scrolled manually by pressing the UP/DOWN keys. Pressing the ENTER key gives access to a submenu. Press the ESC key to return to the Main Menu.

#### 7.4.1 Alarm Message

The display shows the 100 latest alarm messages (see Figure 7.6). Screens can be scrolled manually by pressing the UP/ DOWN keys. Press the ESC key to return to the previous menu.



Alm000: OV-G-V  
T: 00-00 00:00 D: 0000

Figure 7.6 Alarm Message

## 7. Operation


### 7.4.2 Running Message

This function is for maintenance person to get running message such as internal temperature, Standard No.1,2,etc.

Screens can be scrolled manually by pressing the UP/DOWN keys.

### 7.4.3 Version

The screen shows the model version of the inverter. And the screen will show the software ver by pressing the UP and DOWN at the same time.(see Figure 7.7).




Model: 08  
Software Version: D20001

Figure 7.7 Model Version and Software Version

### 7.4.4 Daily Energy


The function is for checking the energy generation for selected day.



YES=<ENT> NO=<ESC>  
Select: 2019-01-01

Figure 7.8 Select date for daily energy

Press DOWN key to move the cursor to day, month and year, press UP key to change the digit. Press Enter after the date is fixed.



2019-01-01: 051.3kWh  
2019-01-01: 061.5kWh


Figure 7.9 Daily energy

Press UP/DOWN key to move one date from another.

## 7. Operation

### 7.4.5 Monthly Energy


The function is for checking the energy generation for selected month.



YES=<ENT> NO=<ESC>  
Select: 2019-01

Figure 7.10 Select month for monthly energy

Press DOWN key to move the cursor to day and month, press UP key to change the digit. Press Enter after the date is fixed.




2019-01: 0510kWh  
2019-01: 0610kWh

Figure 7.11 Month energy

Press UP/DOWN key to move one date from another.

### 7.4.6 Yearly Energy


The function is for checking the energy generation for selected year.



YES=<ENT> NO=<ESC>  
Select: 2015

Figure 7.12 Select year for yearly energy

Press DOWN key to move the cursor to day and year, press UP key to change the digit. Press Enter after the date is fixed.



2015: 0017513kWh  
2014: 0165879kWh

Figure 7.13 Yearly energy

Press UP/DOWN key to move one date from another.




## 7. Operation

### 7.4.7 Daily Record

The screen shows history of changing settings. Only for maintenance personnel.

### 7.4.8 Communication Data

The screen shows the internal data of the Inverter (see Figure 7.14), which is for service technicians only.




01-05: 01 25 E4 9D AA  
06-10: C2 B5 E4 9D 55

Figure 7.14 Communication Data

### 7.4.9 Warning Message

The display shows the 100 latest warn messages (see Figure 7.15). Screens can be scrolled manually by pressing the UP/ DOWN keys. Press the ESC key to return to the previous menu.




Msg000:  
T: 00-00 00:00 D:0000

Figure 7.15 Warning Message


### 7.4.10 Inspection

This information is used to check which standard is current in effective and which working mode is enabled.



Standard NO.  
4777-A

Figure 7.16



Work Mode:  
Volt-Watt

Figure 7.17

## 7. Operation

### 7.5 Advanced Settings - Technicians Only



#### NOTE:


To access to this area is for fully qualified and accredited technicians only. Please follow 7.4 to enter password to access this menu.

Select Advanced Settings from the Main Menu to access the following options:

1. Select Standard
2. Grid ON/OFF
3. 24H Switch
4. Clear Energy
5. Reset Password
6. Power Control
7. Calibrate Energy
8. Special Settings
9. STD. Mode Settings
10. Restore Settings
11. HMI Update
12. Internal EPM Set
13. External EPM Set
14. Restart HMI
15. Debug Parameter
16. DSP Update
17. Power Parameter

#### 7.5.1 Selecting Standard

This function is used to select the grid's reference standard (see Figure 7.18).



YES=<ENT> NO=<ESC>  
Standard:AS4777-A

Figure 7.18

Press the UP/DOWN keys to select the standard 4777-A, 4777-B, 4777-C and 4777-N for compliance with AS/NZS4777.2:2020. The standard AS4777-15 is for AS/NZS4777.2:2015.



#### NOTE:

This function is for technicians use only.



## 7. Operation



### NOTE:

For different countries, the grid standard needs to be set as different according to local requirements. If there is any doubt, please consult Solis service technicians for details.

The default protection settings and setting range for different regions are showing below:

| Region             | Australia A | Australia B | Australia C | New Zealand |               |
|--------------------|-------------|-------------|-------------|-------------|---------------|
| Standard Code Name | 4777-A      | 4777-B      | 4777-C      | 4777-N      | Setting Range |
| OV-G-V1            | 265V        | 265V        | 265V        | 265V        | 230-276V      |
| OVGV1-T            | 1.5S        | 1.5S        | 1.5S        | 1.5S        | 1-2S          |
| OV-G-V2            | 275V        | 275V        | 275V        | 275V        | 230-276V      |
| OVGV2-T            | 0.1S        | 0.1S        | 0.1S        | 0.1S        | 0.1-2S        |
| UN-G-V1            | 180V        | 180V        | 180V        | 180V        | 38-230V       |
| UNGV1-T            | 10S         | 10S         | 10S         | 10S         | 10-11S        |
| UN-G-V2            | 70V         | 70V         | 70V         | 70V         | 38-230V       |
| UNGV2-T            | 1.5S        | 1.5S        | 1.5S        | 1.5S        | 1-2S          |
| OV-G-F1            | 52HZ        | 52HZ        | 55HZ        | 55HZ        | 50-55HZ       |
| OVGF1-T            | 0.1S        | 0.1S        | 0.1S        | 0.1S        | 0.1-2S        |
| OV-G-F2            | 52HZ        | 52HZ        | 55HZ        | 55HZ        | 50-55HZ       |
| OVGF2-T            | 0.1S        | 0.1S        | 0.1S        | 0.1S        | 0.1-2S        |
| UN-G-F1            | 47HZ        | 47HZ        | 45HZ        | 45HZ        | 45-50HZ       |
| UNGF1-T            | 1.5S        | 1.5S        | 5S          | 1.5S        | 1-6S          |
| UN-G-F2            | 47HZ        | 47HZ        | 45HZ        | 45HZ        | 45-50HZ       |
| UNGF2-T            | 1.5S        | 1.5S        | 5S          | 1.5S        | 1-6S          |
| Startup-T          | 60S         | 60S         | 60S         | 60S         | 10-600S       |
| Restore-T          | 60S         | 60S         | 60S         | 60S         | 10-600S       |
| Recover-VH         | 253V        | 253V        | 253V        | 253V        | 230-276V      |
| Recover-VL         | 205V        | 205V        | 205V        | 196V        | 115-230V      |
| Recover-FH         | 50.15Hz     | 50.15Hz     | 50.15Hz     | 50.15Hz     | 50-52Hz       |
| Recover-FL         | 47.5Hz      | 47.5Hz      | 47.5Hz      | 47.5Hz      | 47-50Hz       |
| Start-VH           | 253V        | 253V        | 253V        | 253V        | 230-276V      |
| Start-VL           | 205V        | 205V        | 205V        | 196V        | 115-230V      |
| Start-FH           | 50.15Hz     | 50.15Hz     | 50.15Hz     | 50.15Hz     | 50-52Hz       |
| Start-FL           | 47.5Hz      | 47.5Hz      | 47.5Hz      | 47.5Hz      | 47-50Hz       |

Table 7.2

## 7. Operation

### 7.5.2 Grid ON/OFF

This function is used to start up or stop the power generation of Solis Three Phase Inverter.



Figure 7.19 Set Grid ON/OFF

Screens can be scrolled manually by pressing the UP/DOWN keys. Press the ENTER key to save the setting. Press the ESC key to return to the previous menu.

### 7.5.3 24H Switch

This function controls the 24H hours consumption function enable or disable.




Figure 7.20 Set 24H ON/OFF



### NOTE:

When this is enabled, the inverter LCD will still be alive at night with the power LED light on. If the grid is in malfunction at night, the system can't recover even after the grid is back to normal but the consumption data will still be recorded in the meter. Until the sunrise, the system will start to work again while the meter data can be uploaded to the Solis monitoring system to calibrate the load consumption data.

### 7.5.4 Clear Energy

Clear Energy can reset the history yield of inverter



These two functions are applicable by maintenance personnel only, wrong operation will prevent the inverter from working properly.

## 7. Operation

### 7.5.5 Reset Password

This function is used to set the new password for menu "Advanced info." and "Advanced information".

YES=<ENT> NO=<ESC>  
Password: 0000

Figure 7.21 Set new password

Enter the right password before set new password. Press the DOWN key to move the cursor, Press the UP key to revise the value. Press the ENTER key to execute the setting. Press the ESC key to return to the previous menu.

### 7.5.6 Power Control

Active and reactive power can be set through power setting button.

There are 5 item for this sub menu:

1. Set output power
2. Set Reactive Power
3. Out\_P With Restore
4. Rea\_P With Restore
5. Select PF Curve



This function is applicable by maintenance personnel only, wrong operation will prevent the inverter from reaching maximum power.

### 7.5.7 Calibrate Energy

Maintenance or replacement could clear or cause a different value of total energy. Use this function could allow user to revise the value of total energy to the same value as before. If the monitoring website is used the data will be synchronous with this setting automatically.

YES=<ENT> NO=<ESC>  
Energy:0000000kWh

Figure 7.22 Calibrate energy

Press the DOWN key to move the cursor, Press the UP key to revise the value. Press the ENTER key to execute the setting. Press the ESC key to return to the previous menu.

## 7. Operation

### 7.5.8 Special Settings



This function is applicable by maintenance personnel only, wrong operation will prevent the inverter from reaching maximum power.

### 7.5.9 STD Mode settings

There are 10 settings under STD. Mode Settings.

1. Working Mode Set
2. Power Rate Limit
3. Freq Derate Set
4. 10mins Voltage Set
5. Q3Tau Settings
6. P3Tau Settings
7. Control Switches
8. Power Priority
9. Initial Settings
- 10.DRM Settings

#### 7.5.9.1 Working Mode Set

Solis AU version inverters have the following working mode settings:

1. NULL
2. P Mode Settings
- 3.Q Mode Settings

#### 1. NULL

Description: Inverter will not be under any working mode.

#### 2. P Mode Settings

This P Mode Settings include 1 working mode: Volt-Watt

##### 2.1 Volt-Watt

Description: Inverter will change the active output power based on grid voltage.

## 7. Operation

## 7. Operation




Figure 7.23

Status: Enable/Disable (Note: This is used to enable or disable the Volt-Watt mode)

**Voltage 1:** 207V

**P-Limit 1:** 100%

**Voltage 2:** 220V

**P-Limit 2:** 100%

**Voltage 3 (Vw1):**

235-255V (Default: 4777-A(253V); 4777-B(250V); 4777-C(253V); 4777-N(242V))

**P-Limit 3:** 100%

**Voltage 4 (Vw2):**

240-265V (Default: 4777-A(260V); 4777-B(260V); 4777-C(260V); 4777-N(250V))

**P-Limit 4:** 0%-20% (Default: 20% for 4777-A; 4777-B; 4777-C; 4777-N)

### 3. Q Mode Settings

This Q Mode Settings include 5 working modes:

**Disable, Volt-Var, Fixed-PF, Reac-Power, P-factor**

#### 3.1 Disable

Description: This mode will disable the reactive power response working modes

#### 3.2 Volt-Var

Description: Inverter will change the reactive output power based on grid voltage.




Figure 7.24

**Voltage 1 (Vv1):**

180-230V (Default: 4777-A(207V); 4777-B(205V); 4777-C(215V); 4777-N(207V))

**Voltage 2 (Vv2):**

180-230V (Default: 4777-A(220V); 4777-B(220V); 4777-C(230V); 4777-N(220V))

**Voltage 3 (Vv3):**

230-265V (Default: 4777-A(240V); 4777-B(235V); 4777-C(240V); 4777-N(235V))

**Voltage 4 (Vv4):**

230-265V (Default: 4777-A(258V); 4777-B(255V); 4777-C(255V); 4777-N(244V))

**Leading(Supplying) :**

+30~+60% (Default: 4777-A(+44%); 4777-B(+30%); 4777-C(+44%); 4777-N(+60%))

**Lagging(Absorbing) :**

-30%~-60% (Default: 4777-A(-60%); 4777-B(-40%); 4777-C(-60%); 4777-N(-60%))

## 7. Operation

### 3.3 Fixed PF

Description: This mode is to set a fixed power factor output

Range: -0.8~+0.8

Default: 1

### 3.4 Reac-Power

Description: This mode is to set a fixed reactive power output

Range: -60%~+60%

Default: 0%

### 3.5 Power-PF

Description: This mode is not required in Australia.

### 7.5.9.2 Power Rate Limit

To set the power rate limits for increase and decrease in power level per minute.

Wgra+: 5-100%, Default: 16%

Wgra-: 5-100%, Default: 16%

### 7.5.9.3 Freq Derate Set

To set the frequency response limits for response to a decrease/increase in frequency.

**OVF\_Start(F\_ULCO):** 50.1Hz~50.5Hz

(Default: 4777-A(50.25Hz), 4777-B(50.15Hz), 4777-C(50.5Hz), 4777-N(50.2Hz))

**OVF\_Stop(F\_Pmin):** 51Hz~53Hz

(Default: 4777-A(52Hz), 4777-B(52Hz), 4777-C(53Hz), 4777-N(52Hz))

**UNF\_Start(F\_LLCO):** 49.5Hz~49.9Hz

(Default: 4777-A(49.75Hz), 4777-B(49.85Hz), 4777-C(49.5Hz), 4777-N(49.8Hz))

**UNF\_Stop(F\_Pmax):** 47Hz~49Hz

(Default: 4777-A(48Hz), 4777-B(48Hz), 4777-C(47Hz), 4777-N(48Hz))

### 7.5.9.4 10mins Voltage Set

To set the 10mins average protection limit.

Range: 244V to 258V

Default: 4777-A(258V); 4777-B(258V); 4777-C(258V); 4777-N(249V)

### 7.5.9.5 DRM Settings

"DRM ON/OFF" is used to enabled or disable the functionality of the DRM port.

"AU DRM Q Set" is used to define the reactive power absorption for DRM 3 or DRM 7.

Range: 0~ 60%

## 7. Operation

### 7.5.10 Restore Settings

There are 5 items in initial setting submenu.

Restore setting could set all item in 7.5.8 special setting to default.

The screen shows as below:

Are you sure?  
YES=<ENT> NO=<ESC>

Figure 7.25 Restore Settings

Press the Enter key to save the setting after setting grid off.

Press the ESC key to return the previous mean.

### 7.5.11 HMI Update

This function is used for updating the LCD program.



This function is applicable by maintenance personnel only, wrong operation will prevent the inverter from reaching maximum power.

### 7.5.12 Internal EPM Set



#### NOTE

This section includes two functions related to the smart meter. Please refer to section 5.3.6 for detailed connection diagrams.

#### Function 1: Internal Export Power Management Function

Inverters can work with a smart meter to dynamically limit the export power of the system. Zero injection can be achieved.

Smart meter can be installed either on the grid side OR the load side.

#### Function 2: 24 Hour Consumption Monitoring Function

Only applicable if Solis monitoring system is used.

Inverters can work with a smart meter to monitor the load consumption data for the whole day and the data will be displayed on the Solis monitoring system.

Smart meter can only be installed on the grid side.



## 7. Operation



### NOTE:

Please refer to below instructions for different user scenarios.

#### Scenario 1. Only Function 1 is required

Step 1: Refer to Section 5.3.6 to connect the smart meter on the grid side or load side.

Step 2: Select the Section 7.5.12.1 Mode Select as Option 2(Meter in Load) or Option 3 (Meter in Grid) accordingly.

Step 3: Configure the Section 7.5.12.2 to set the allowed backflow power.

Step 4: Configure the Section 7.5.12.3 to enable the failsafe function (If necessary).

Step 5: Configure the Section 7.5.12.4 to modify the work mode (If necessary).

#### Scenario 2. Both Function 1 and 2 are required

Using a Smart Meter:

Step 1: Refer to Section 5.3.6 to connect the smart meter on the grid side.

Step 2: Select the Section 7.5.12.1 Mode Select as Option 3(Meter in Grid).

Step 3: Select the Section 7.5.3 24H Switch as "Enable".

Step 4: Configure the Section 7.5.12.2 to set the allowed backflow power.

Step 5: Configure the Section 7.5.12.3 to enable the failsafe function (If necessary).

Step 6: Configure the Solis monitoring system (Please refer to the manual of monitoring device).

If customer does not want to enable the export power control function, please change the "backflow power" to the max output power of the inverter in Step 4 OR simply select the mode as "consumption monitor" in Step 2 and skip Step 4-5.

Select EPM Settings from the Main Menu to access the following options:

**1. Mode Select 2. Soft Hard Lmt Set 3. Fail safe ON/OFF 4. Backflow Work Mode**

### 7.5.12.1 Mode Select

There are 4 settings in this menu as below:

**1. OFF 2. Meter in Load 3. Meter in Grid 4. Consumption Monitor**

**OFF:** Functions are disabled

**Meter in Load:** Solis Smart Meter is connected in the load branch circuit.

**Meter in Grid:** Solis Smart Meter is connected in the grid connection point (The backflow power is default as 0W).

**Consumption Monitor:** Solis Smart Meter is connected in the grid connection point (The backflow power setting is not applicable).

## 7. Operation

### 7.5.12.2 Soft Hard Lmt Set

**1. Soft Backflowpower 2. Hard Limit 3. Hard Backflowpower**

->Soft Backflowpower  
Hard Limit

YES=<ENT> NO=<ESC>  
Power:-00000W

Figure 7.26 Soft Backflowpower

Soft Backflowpower  
->Hard Limit

YES=<ENT> NO=<ESC>  
Hard export Lmt: ON

Figure 7.27 Hard Limit

Hard Limit  
->Hard Backflowpower

YES=<ENT> NO=<ESC>  
Power:-00000W

Figure 7.28 Hard Backflowpower



### NOTE:

These settings are designed to comply with AS/NZS4777.2:2020, but the function has not been tested according to AS/NZS4777.2:2020 by third party certification organization. The "soft backflowpower" is to dynamically control the inverter output to meet the system export limit. When "Hard Limit" is set to ON and the "Hard Backflow power" is reached, the inverter will shutdown within 5s and give alarm as "EPM-HardLimit".



### NOTE:

Positive values indicate the amount of power is allowed to export to the grid. Negative values indicate a more strict control to limit the export power in advance thus ensuring exact no power is feeding into the grid.

### 7.5.12.3 Fail safe ON/OFF

This setting is used to give out an alarm (stop inverter generation as well) when the Meter connection is lost during operation.

It can prevent potential backflow power into the grid when the system loses control.

YES=<ENT> NO=<ESC>  
Fail Safe Set:ON

Figure 7.29 Set the Fail Safe ON/OFF



## 7. Operation

It is only mandatory to turn on this function when the inverter is installed in UK due to the G100 regulation. For other regions, customers can enable or disable the function as they desire.



### NOTE:

When the failsafe function is ON and CT/Meter is disconnected somehow, the inverter will stop generation and give "Failsafe" alarm on the LCD.  
When the failsafe function is OFF and CT/Meter is disconnected somehow, the inverter will keep the output power as the last moment when the CT/Meter is still connected. After a restart, the inverter will output at full power without limit.

### 7.5.12.4 Backflow Work Mode

This submenu is used for set backflow work mode: 01, 02. "01" is the default mode.

->Backflow Work Mode

Figure 7.30 Set the Backflow work mode

YES=<ENT> NO=<ESC>  
Mode:01

Figure 7.31

Mode "01", As shown in the figure 7.32, the average limiting mode, the output power of each phase is the average of the three-phase load power, and it is more than the phase of the lowest power in three phases.

Inverter Production  
L1-4500W  
L2-4500W  
L3-4500W




Figure 7.32

## 7. Operation

Mode "02", As shown in the figure 7.33 the per phase limiting mode, the inverter only generate the power that equals to one of three-phase load power that is the lowest load power of a certain phase.

Inverter Production  
L1-4000W  
L2-4000W  
L3-4000W




Figure 7.33

### 7.5.13 External EPM Set

This setting should only be turned on when Solis external EPM device is used. Two options are available : 5G-EPM and Others-EPM.

->5G-EPM  
Others-EPM

Figure 7.34

5G-EPM Failsafe Option should be turned ON when 5G series EPM device is used  
Others-EPM Failsafe Option should be turned ON when 2G series EPM device is used  
Only one option can be activated each time.

### 7.5.14 Restart HMI

The function is used for restart the HMI.



This function is applicable by maintenance personnel only, wrong operation will prevent the inverter from reaching maximum power.

## 7. Operation

### 7.5.15 Debug Parameter

This function is used for manufacturer maintenance personnel only.

### 7.5.16 DSP Update

The function is used for update the DSP.



This function is applicable by maintenance personnel only, wrong operation will prevent the inverter from reaching maximum power.

### 7.5.17 Compensation Set



This function is applicable by maintenance personnel only, wrong operation will prevent the inverter from reaching maximum power.

## 7.6 AFCI function

Solis inverters have the built-in AFCI function which can detect the arc fault on the DC circuit and shut down the inverter to prevent a fire disaster.

### 7.6.1 Enable the AFCI function

The AFCI function can be enabled in the following.

Path: Advanced Setting -> Password: 0010 -> Special Settings -> AFCI Set ->

AFCI ON/OFF -> ON

→ AFCI ON/OFF  
AFCI Level

→ ON  
OFF

Figure 7.35 Set AFCI



#### Warning:

The "AFCI Level" is reserved for Solis technicians ONLY. Do not change the sensitivity otherwise it will lead to frequent false alarms or malfunctions. Solis is not responsible for any further damages caused by unauthorized modifications.

## 7. Operation



#### NOTE:

The setting corresponds to the current status as well which can be used to inspect the ON/OFF state of the AFCI function.

### 7.6.2 Arc Fault

During the normal operation, if an DC arc is detected, the inverter will shut down and give out the following alarm:

ARC-FAULT  
Restart Press ESC 3s

Figure 7.36 Arc Fault

Installer needs to thoroughly inspect the DC circuit to ensure all the cables are correctly fastened.

Once the DC circuit issue has been fixed or it is confirmed to be OK, press "ESC" for 3s and wait for the inverter to restart.

## 8. Maintenance

Solis Three Phase Inverter does not require any regular maintenance. However, cleaning the dust on heat-sink will help the inverter to dissipate the heat and increase its life time. The dust can be removed with a soft brush.



### CAUTION:

Do not touch the inverter's surface when it is operating. Some parts of the inverter may be hot and cause burns. Turn off the inverter (refer to Section 6.2) and wait for a cool-down period before any maintenance or cleaning operation.

The LCD and the LED status indicator lights can be cleaned with a damp cloth if they are too dirty to be read.



### NOTE:


Never use any solvents, abrasives or corrosive materials to clean the inverter.

### 8.1 Fan Maintenance

If the fan does not work properly, the inverter will not be cooled effectively, and it may affect the effective operation of the inverter.

Therefore, it is necessary to clean or replace a broken fan as follows:

1. Disconnect the AC power.
2. Turn the DC switch to "OFF" position.
3. Wait for 10 minutes at least.
4. Disconnect all electric connection.
5. Place the inverter on the platform.
6. Remove the 4 screws on the fan plate and pull out the fan assembly slowly.



7. Disconnect the fan connector carefully and take out the fan.
8. Clean or replace the fan. Assemble the fan on the rack.
9. Connect the electrical wire and reinstall the fan assembly. Restart the inverter.

## 9. Troubleshooting

The inverter is designed in accordance with the most important international grid-tied standards and safety and electromagnetic compatibility requirements. Before delivering to the customer, the inverter has been subjected to several tests to ensure its optimal operation and reliability.

In case of failure, the LCD screen will display an alarm message. In this case, the inverter may stop feeding into the grid. The failure descriptions and their corresponding alarm messages are listed in Table 9.1:

| Alarm Message                      | Failure description                      | Solution   |
|------------------------------------|--|--|
| No power                           | Inverter no power on LCD                 | 1.Check PV input connections<br>2.Check DC input voltage (single phase >120V, three phase >350V)<br>3.Check if PV+/- is reversed           |
| LCD show initializing all the time | Can not start-up                         | 1.Check if the connector on main board or power board are fixed.<br>2.Check if the DSP connector to power board are fixed.                 |
| OV-G-V01/02/03/04                  | Over grid voltage                        | 1.Resistant of AC cable is too high. Change bigger size grid cable<br>2.Adjust the protection limit if it's allowed by electrical company. |
| UN-G-V01/02                        | Under grid voltage                       | 1.Use user define function to adjust the protection limit if it's allowed by electrical company.   |
| OV-G-F01/02                        | Over grid frequency                      |  |
| UN-G-F01/02                        | Under grid frequency                     |  |
| G-IMP                              | High grid impedance                      |  |
| NO-GRID                            | No grid voltage                          | 1.Check connections and grid switch.<br>2.Check the grid voltage inside inverter terminal.   |
| OV-DC01/02/03/04                   | Over DC voltage                          | 1.Reduce the module number in series   |
| OV-BUS                             | Over DC bus voltage                      | 1.Check inverter inductor connection<br>2.Check driver connection  |
| UN-BUS01/02                        | Under DC bus voltage                     |  |
| GRID-INTF01/02                     | Grid interference                        | 1.Restart inverter<br>2.Change power board   |
| OV-G-I                             | Over grid current                        |  |
| IGBT-OV-I                          | Over IGBT current                        |  |
| DC-INTF<br>OV-DCA-I                | DC input overcurrent                     | 1.Restart inverter<br>2.Identify and remove the string to the fault MPPT<br>2.Change power board   |
| IGFOL-F                            | Grid current tracking fail               | 1.Restart inverter or contact installer.   |
| IG-AD                              | Grid current sampling fail               |  |
| INI-FAULT                          | Initialization system fault              | 1.Restart inverter or contact installer.   |
| DSP-B-FAULT                        | Comm. failure between main and slave DSP |  |
| 12Power-FAULT                      | 12V power supply fault                   |  |

## 9. Troubleshooting

| Alarm Message                                   | Failure description           | Solution  |
|---|-------------------------------|---|
| OV-TEM  | Over Temperature              | 1.Check inverter surrounding ventilation.<br>2.Check if there's sunshine direct on inverter in hot weather.   |
| PV ISO-PRO<br>01/02                             | PV isolation protection       | 1.Remove all DC input, reconnect and restart inverter one by one.<br>2.Identify which string cause the fault and check the isolation of the string.   |
| ILeak-PRO<br>01/02/03/04                        | Leakage current protection    | 1.Check AC and DC connection<br>2.Check inverter inside cable connection.   |
| RelayChk-FAIL                                   | Relay check fail              | 1.Restart inverter or contact installer.  |
| DCinj-FAULT                                     | High DC injection current     |   |
| AFCI self-detection<br>(model with AFCI module) | AFCI module self-detect fault | 1.Restart inverter or connect technician.   |
| Arcing protection<br>(model with AFCI module)   | Detect arc in DC circuit      | 1. Check inverter connection whether arc exists and restart inverter.   |
| Screen OFF<br>with DC applied                   | Inverter internally damaged   | 1. Do not turn off the DC switches as it will damage the inverter.<br>2. Please wait for the solar irradiance reduces and confirm the string current is less than 0.5A with a clip-on ammeter and then turn off the DC switches.<br>3. Please note that any damages due to wrong operations are not covered in the device warranty. |

Table 9.1 Fault message and description



### NOTE:

If the inverter displays any alarm message as listed in Table 9.1; please turn off the inverter (refer to Section 6.2 to stop your inverter) and wait for 5 minutes before restarting it (refer to Section 6.1 to start your inverter). If the failure persists, please contact your local distributor or the service center. Please keep ready with you the following information before contacting us.

1. Serial number of Solis Three Phase Inverter;
2. The distributor/dealer of Solis Three Phase Inverter (if available);
3. Installation date.
4. The description of problem (i.e. the alarm message displayed on the LCD and the status of the LED status indicator lights. Other readings obtained from the Information submenu (refer to Section 6.2) will also be helpful.);
5. The PV array configuration (e.g. number of panels, capacity of panels, number of strings , etc.);
6. Your contact details.

## 10. Specifications

| Model                                  | S5-GR3P15K   |
|--|--|
| Max. DC input voltage (Volts)          | 1100   |
| Rated DC voltage (Volts)               | 600  |
| Start-up voltage (Volts)               | 180  |
| MPPT voltage range (Volts)             | 160...1000   |
| Max. input current (Amps)              | 32/32  |
| Max short circuit input current (Amps) | 40/40  |
| MPPT number/Max input strings number   | 2/4  |
| Rated output power (Watts)             | 15000  |
| Max. output power (Watts)              | 15000  |
| Rated apparent output power (VA)       | 15000  |
| Max. apparent output power (VA)        | 15000  |
| Rated grid voltage (Volts)             | 3/N/PE~230/400   |
| Rated output current (Amps)            | 23.8   |
| Max. output current (Amps)             | 23.8   |
| Power Factor (at rated output power)   | 0.8leading~0.8lagging  |
| THDi (at rated output power)           | <2%  |
| Rated grid frequency (Hertz)           | 50   |
| Operating frequency range (Hertz)      | 45...55  |
| Max. efficiency                        | 98.6%  |
| EU efficiency                          | 98.0%  |
| MPPT efficiency                        | >99.5%   |
| Dimensions                             | 310W*563H*219D (mm)  |
| Weight                                 | 18.8kg   |
| Topology                               | Non-Isolated   |
| Self consumption (Night)               | <1 W   |
| Operating ambient temperature range    | -25 ~ +60 °C   |
| Relative humidity                      | 0-100%   |
| Ingress protection                     | IP66   |
| Noise emission (typical)               | <60 dBA  |
| Cooling concept                        | Intelligent redundant fan-cooling  |
| Max. operation altitude                | 2000m  |
| Grid connection standard               | AS/NZS 4777.2:2020, IEC 62116, IEC 61727, IEC 60068, IEC 61683, EN 50530 |
| Safety/EMC standard                    | IEC 62109-1/-2, IEC 61000-6-1/-2/-3/-4                                   |
| DC connection                          | MC4 connector  |
| AC connection                          | Quick connection plug  |
| Display                                | LCD, 2×20 Z.   |
| Communication                          | RS485, Optional: Wi-Fi, GPRS   |
| Warranty                               | 5 Years (Extendable to 20 Years)   |

## 10. Specifications

| Model   | S5-GR3P15K                |
|---|---------------------------|
| Max inverter backfeed current to array (Amps) | 0                         |
| Peak Inrush current (Amps)                    | 2.38                      |
| Peak Inrush Duration (ms)                     | 5                         |
| Max output fault current (Amps)               | 29.75                     |
| Protective Class                              | Class I                   |
| Overvoltage category                          | II(PV), III(MAINS)        |
| Active anti-islanding method                  | Active frequency shifting |
| Decisive voltage class                        | DVC                       |



## 10. Specifications

| Model                                  | S5-GR3P17K   |
|--|--|
| Max. DC input voltage (Volts)          | 1100   |
| Rated DC voltage (Volts)               | 600  |
| Start-up voltage (Volts)               | 180  |
| MPPT voltage range (Volts)             | 160...1000   |
| Max. input current (Amps)              | 32/32  |
| Max short circuit input current (Amps) | 40/40  |
| MPPT number/Max input strings number   | 2/4  |
| Rated output power (Watts)             | 17000  |
| Max. output power (Watts)              | 17000  |
| Rated apparent output power (VA)       | 17000  |
| Max. apparent output power (VA)        | 17000  |
| Rated grid voltage (Volts)             | 3/N/PE~230/400   |
| Rated output current (Amps)            | 27.0   |
| Max. output current (Amps)             | 27.0   |
| Power Factor (at rated output power)   | 0.8leading~0.8lagging  |
| THDi (at rated output power)           | <2%  |
| Rated grid frequency (Hertz)           | 50   |
| Operating frequency range (Hertz)      | 45...55  |
| Max. efficiency                        | 98.7%  |
| EU efficiency                          | 98.1%  |
| MPPT efficiency                        | >99.5%   |
| Dimensions                             | 310W*563H*219D (mm)  |
| Weight                                 | 20.0kg   |
| Topology                               | Non-Isolated   |
| Self consumption (Night)               | <1 W   |
| Operating ambient temperature range    | -25 ~ +60 °C   |
| Relative humidity                      | 0-100%   |
| Ingress protection                     | IP66   |
| Noise emission (typical)               | <60 dBA  |
| Cooling concept                        | Intelligent redundant fan-cooling  |
| Max. operation altitude                | 2000m  |
| Grid connection standard               | AS/NZS 4777.2:2020, IEC 62116, IEC 61727, IEC 60068, IEC 61683, EN 50530 |
| Safety/EMC standard                    | IEC 62109-1/-2, IEC 61000-6-1/-2/-3/-4                                   |
| DC connection                          | MC4 connector  |
| AC connection                          | Quick connection plug  |
| Display                                | LCD, 2×20 Z.   |
| Communication                          | RS485, Optional: Wi-Fi, GPRS   |
| Warranty                               | 5 Years (Extendable to 20 Years)   |

## 10. Specifications

| Model   | S5-GR3P17K                |
|---|---------------------------|
| Max inverter backfeed current to array (Amps) | 0                         |
| Peak Inrush current (Amps)                    | 2.7                       |
| Peak Inrush Duration (ms)                     | 5                         |
| Max output fault current (Amps)               | 33.75                     |
| Protective Class                              | Class I                   |
| Overvoltage category                          | II(PV), III(MAINS)        |
| Active anti-islanding method                  | Active frequency shifting |
| Decisive voltage class                        | DVC                       |

# 10. Specifications

| Model                                  | S5-GR3P20K   |
|--|--|
| Max. DC input voltage (Volts)          | 1100   |
| Rated DC voltage (Volts)               | 600  |
| Start-up voltage (Volts)               | 180  |
| MPPT voltage range (Volts)             | 160...1000   |
| Max. input current (Amps)              | 32/32  |
| Max short circuit input current (Amps) | 40/40  |
| MPPT number/Max input strings number   | 2/4  |
| Rated output power (Watts)             | 20000  |
| Max. output power (Watts)              | 20000  |
| Rated apparent output power (VA)       | 20000  |
| Max. apparent output power (VA)        | 20000  |
| Rated grid voltage (Volts)             | 3/N/PE~230/400   |
| Rated output current (Amps)            | 31.8   |
| Max. output current (Amps)             | 31.8   |
| Power Factor (at rated output power)   | 0.8leading~0.8lagging  |
| THDi (at rated output power)           | <2%  |
| Rated grid frequency (Hertz)           | 50   |
| Operating frequency range (Hertz)      | 45...55  |
| Max. efficiency                        | 98.7%  |
| EU efficiency                          | 98.1%  |
| MPPT efficiency                        | >99.5%   |
| Dimensions                             | 310W*563H*219D (mm)  |
| Weight                                 | 20.0kg   |
| Topology                               | Non-Isolated   |
| Self consumption (Night)               | <1 W   |
| Operating ambient temperature range    | -25 ~ +60 °C   |
| Relative humidity                      | 0-100%   |
| Ingress protection                     | IP66   |
| Noise emission (typical)               | <60 dBA  |
| Cooling concept                        | Intelligent redundant fan-cooling  |
| Max. operation altitude                | 2000m  |
| Grid connection standard               | AS/NZS 4777.2:2020, IEC 62116, IEC 61727, IEC 60068, IEC 61683, EN 50530 |
| Safety/EMC standard                    | IEC 62109-1/-2, IEC 61000-6-1/-2/-3/-4                                   |
| DC connection                          | MC4 connector  |
| AC connection                          | Quick connection plug  |
| Display                                | LCD, 2×20 Z.   |
| Communication                          | RS485, Optional: Wi-Fi, GPRS   |
| Warranty                               | 5 Years (Extendable to 20 Years)   |

# 10. Specifications

| Model   | S5-GR3P20K                |
|---|---------------------------|
| Max inverter backfeed current to array (Amps) | 0                         |
| Peak Inrush current (Amps)                    | 3.18                      |
| Peak Inrush Duration (ms)                     | 5                         |
| Max output fault current (Amps)               | 39.75                     |
| Protective Class                              | Class I                   |
| Overvoltage category                          | II(PV), III(MAINS)        |
| Active anti-islanding method                  | Active frequency shifting |
| Decisive voltage class                        | DVC                       |

# 11. Appendix

---

## 11.1 Built-In DC Isolator Specification

| Model   | NDG3V-50               |
|---|------------------------|
| Rated insulation voltage                              | 1500V                  |
| Rated impulse withstand voltage                       | 8000V                  |
| Suitability for isolation                             | Suitable for isolation |
| Rated operational current                             | 40A at 1100V           |
| Utilization category                                  | DC-PV2                 |
| Rated short-time withstand current(I <sub>cw</sub> )  | 700A                   |
| Rated short-circuit making capacity(I <sub>cm</sub> ) | 1400A                  |
| Rated breaking capacity                               | 4*I <sub>e</sub> 160A  |