



Advanced BMS with active fuse

### **Ultra-efficient**

Support Max. 1C charge & 1C discharge.



Max. 32 units in parallel

# **Easy Maintenance**

Auto-networking, Local monitoring mode for battery, remote monitoring mode for ESS



Integrated PACK: reduced line loss, enhanced energy density



# **Reliable Durability**

Operates reliably in -20°C to 55°C, natural cooling

#### **RESIDENTIAL ESS SOLUTION**




Model		SE-F5 Pro
Main Parameters		
Battery Chemistry		LiFePO <sub>4</sub>
Capacity		100 Ah
Scalability [1]		Max. 32 pcs in parallel
Nominal Voltage		51.2 V
Operating Voltage		44.8 V ~ 57.6 V
Nominal Energy		5.12 kWh
Charge Current [2]	Max. Continuous	100 A
	Peak	150 A ( 120 sec )
Discharge Current [2]	Max. Continuous	100 A
	Peak	150 A ( 120 sec )
Other Parameter		
Recommend Depth of Discharge		90% DoD
Dimension ( W $\times$ H $\times$ D ) (Without hanging board)		404 × 547 × 141 mm
Weight Approximate		44 kg
LED Indicator		LED ( SOC, working, protecting ) & Buzzer
IP Rating of Enclosure		IP21
Operating Temperature		Charge: 0°C~55°C Discharge: -20°C~55°C
Storage Temperature		0~35°C
Relative Humidity		95% (non-condensing)
Altitude		≤3000m
Cycle Life		>6000(25°C±2°C,70%EOL)
Installation		Wall-Mounted, Floor-Mounted, Stack-Mounted
Communication		CAN2.0, RS485, Optional module, (WiFi+Bluetooth+APP)
Warranty Period [3]		10 years
Energy Throughput [3]		16 MWh
Certification		UN38.3, MSDS, CE, CB, VDE2510-50, FCC, UL1973, UL9540A, CEC
[1] May 64 ncs can narallel	with CAN-Roy	

[1] Max. 64 pcs can parallel with CAN-Box.

[3] Conditions apply, refer to Deye Warranty Letter.

<sup>[2]</sup> Operating current is affected by temperature and SOC. This max. continuous current is only supported in lithium battery mode; for lead-acid mode, please refer to the manual for the max. continuous current.

Model SE-F5 Pro



- ◎ -: Battery negative terminal connection position(Quickly plug and unplug).
- ① +: Battery positive terminal connection position(Quickly plug and unplug).
- © SOC: These 5 LEDs are used to display the pack SOC and charge or discharge state.
- © RUN light: green LED lighting to show the battery running status.
- ALM light: red LED lighting to show the battery has been alarmed.
- O Power button: Power on or off the control battery.
- © PCS: Inverter communication terminal:(RJ45port) follow the CAN protocol (baud rate:500kbps), and RS485(baud rate:9600bps), used to output battery information to the inverter.
- © OUT: parallel Communication Terminal:(RJ45port) Connect "IN"Terminal of Next battery, for Communication between multiple parallel batteries.
- ◎ IN: parallel Communication Terminal: (RJ45 port) Connect "OUT" Terminal of Previous battery, for Communication between multiple parallel batteries.
- © Circuit breaker: Used to manually control the connection between the battery rack and external devices.
- © Data acquisition stick interface: The location to connect with your Data Logger that is used for data acquisition via WIFI or Bluetooth.

### **Mounting example**

#### Stacked Wall mounted

Support 6 packs in one cluster parallel connected, allows multiple clusters in parallel





Deve

### \_

SE-F5 Pro Model Selection and Appearance Reference



Config Version: L




**Config Version: E** 



**Config Version: C** 

### **Deye APP**







### **Smarten Up Your Home Energy**

Download Deye APP to join us!

Embrace a seamless, effortless energy experience that's both ecofriendly and budget-friendly with our intelligent assistant













