

Ruijie Reyee RG-EST330F-P, EST350G, EST450G Wireless Bridges

3.0(1)B11P302 Configuration Guide



Copyright

Copyright © 2025 Ruijie Networks

All rights are reserved in this document and this statement.

Any reproduction, excerption, backup, modification, transmission, translation or commercial use of this document or any portion of this document, in any form or by any means, without the prior written consent of Ruijie Networks is prohibited.

Trademarks including  are owned by Ruijie Networks.

All other trademarks or registered trademarks mentioned in this document are owned by their respective owners.

Disclaimer

The products, services, or features you purchase are subject to commercial contracts and terms, and some or all of the products, services, or features described in this document may not be available for you to purchase or use. Except for the agreement in the contract, Ruijie Networks makes no explicit or implicit statements or warranties with respect to the content of this document.

The names, links, descriptions, screenshots, and any other information regarding third-party software mentioned in this document are provided for your reference only. Ruijie Networks does not explicitly or implicitly endorse or recommend the use of any third-party software and does not make any assurances or guarantees concerning the applicability, security, or legality of such software. You should choose and use third-party software based on your business requirements and obtain proper authorization. Ruijie Networks assumes no liability for any risks or damages arising from your use of third-party software.

The content of this document will be updated from time to time due to product version upgrades or other reasons, Ruijie Networks reserves the right to modify the content of the document without any notice or prompt.

This manual is designed merely as a user guide. Ruijie Networks has tried its best to ensure the accuracy and reliability of the content when compiling this manual, but it does not guarantee that the content of the manual is completely free of errors or omissions, and all the information in this manual does not constitute any explicit or implicit warranties.

Preface

Intended Audience

This document is intended for:

- Network engineers
- Technical support and servicing engineers
- Network administrators


Technical Support


- Official Website of Ruijie Reye: <https://reyee.ruijie.com>
- Technical Support Website: <https://reyee.ruijie.com/en-global/support>
- Case Portal: <https://www.ruijienetworks.com/support/caseportal>
- Community: <https://community.ruijienetworks.com>
- Technical Support Email: service_rj@ruijienetworks.com
- Online Robot/Live Chat: <https://reyee.ruijie.com/en-global/rita>


Conventions


1. Signs


The signs used in this document are described as below:

 **Danger**
An alert that calls attention to safety operation instructions that if not understood or followed when operating the device can result in physical injury.

 **Warning**
An alert that calls attention to important rules and information that if not understood or followed can result in data loss or equipment damage.

 **Caution**
An alert that calls attention to essential information that if not understood or followed can result in function failure or performance degradation.

 **Note**
An alert that contains additional or supplementary information that if not understood or followed will not lead to serious consequences.

 **Specification**
An alert that contains a description of product or version support.

2. Note

This manual provides the device installation steps, hardware troubleshooting, module technical specifications, and specifications and usage guidelines for cables and connectors. It is intended for the users who have some experience in installing and maintaining network hardware. At the same time, it is assumed that the users are already familiar with the related terms and concepts.

Contents

Preface	I
1 Change Description.....	1
1.1 3.0(1)B11P302.....	1
1.1.1 Hardware Change.....	1
1.1.2 Software Feature Change.....	1
2 Login.....	2
2.1 Configuration Environment Requirements	2
2.2 Default Configuration	2
2.3 Logging In to Web Interface on a PC	2
2.3.1 Connecting to the Device.....	2
2.3.2 Configuring the IP Address of the Management PC.....	3
2.3.3 Logging in to the Web Interface.....	3
2.4 Initial Setup	4
2.4.1 Configuration Steps	4
2.4.2 Configuring Project Settings	5
2.4.3 Configuring WDS Group Settings.....	5
2.5 Introduction to the Web Interface	9
2.5.1 Frequently-Used Controls on the Web Interface	9
2.5.2 Network-wide Management Interface.....	10
2.5.3 One-Device Web Interface.....	14
2.6 Self-Organizing Network.....	15
2.7 Adding Devices to the Self-Organizing Network	15
2.7.1 The Primary Device on the Self-Organizing Network Is a Bridge	16

2.7.2 The Primary Device on the Self-Organizing Network Is Not a Bridge.....	17
3 Wi-Fi Network Settings.....	19
3.1 Overview	19
3.1.1 BaseStation and CPE	19
3.1.2 WDS Wi-Fi and Management Wi-Fi	19
3.2 Switching Between BaseStation Mode and CPE Mode	19
3.3 Scanning to Pair and Add Devices	22
3.3.1 Overview	22
3.3.2 Configuration Steps	22
3.4 Configuring the WDS Wi-Fi for a Single BaseStation or CPE.....	23
3.4.1 Configuring the Work Mode	23
3.4.2 Setting the WDS SSID	24
3.4.3 Configuring the WDS Password	24
3.4.4 Saving the Settings	25
3.5 Configuring the WDS Password for a LAN.....	25
3.6 Configuring the WDS Password for a WDS Group	26
3.7 Configuring the Management Wi-Fi for a Single BaseStation or CPE.....	27
3.7.1 Selecting the Work Mode.....	28
3.8 Configuring the Management Wi-Fi and Password for a LAN	28
3.9 Displaying WDS Group Information.....	30
3.10 Displaying the Information About a Bridge	31
3.11 Configuring the Country/Region Code for a Bridge.....	32
3.11.1 Getting Started	32
3.11.2 Configuration Steps.....	32

3.12	Setting the Country/Region Code for a WDS Group.....	32
3.12.1	Getting Started.....	32
3.12.2	Configuration Steps	33
3.13	Setting the SSID for a Single Bridge	34
3.13.1	Overview	34
3.13.2	Getting Started.....	34
3.13.3	Configuration Steps	35
3.14	Configuring TDMA Mode	38
3.14.1	Overview	38
3.14.2	Selecting the TDMA Mode.....	38
4	Advanced Settings	42
4.1	Rate Limiting.....	42
4.2	Configuring One-Touch Pairing.....	42
4.2.1	Overview	42
4.2.2	Configuration Steps	42
4.3	Port-based Flow Control.....	43
4.4	Wi-Fi Protection	43
4.4.1	Overview	43
4.4.2	Configuration Steps	44
4.5	PoE Settings.....	44
4.6	Rebooting the Camera.....	44
4.6.1	Rebooting All Cameras	44
4.6.2	Rebooting the Camera Connected to the Current Device.....	45
5	Tools	46

5.1 Antenna Alignment.....	46
5.1.1 Overview	46
5.1.2 Configuration Steps	46
5.2 Spectrum Scan	47
5.2.1 Overview	48
5.2.2 Configuration Steps	48
5.3 Network Test Tool.....	50
5.4 Collecting Fault Info	51
5.5 Bridge Speed Test	51
6 Network Settings	54
6.1 Network Modes	54
6.1.1 Configuring the Network Mode	54
6.1.2 Configuration Steps	54
6.2 Configuring the IPv4 Address of the WAN Port.....	55
6.2.1 Allocating IPv4 Addresses to Bridges on the Network	55
6.2.2 Set the WAN Port IP Address for a Single Online Bridge.....	57
6.2.3 Configuring an IP Address for the WAN Port.....	59
6.3 Changing the IP Address of a LAN Port.....	59
6.4 Changing the MTU.....	61
6.4.1 Changing the MTU of a Single Online Bridge	61
6.4.2 Modifying the MTU of the Current Device	62
6.5 Configuring the DHCP Server	63
6.5.1 Overview	63
6.5.2 Configuring the DHCP Server.....	63

6.6 Blocking Web Access	64
7 Alarm and Fault Diagnosis	66
7.1 Alarm Information and Suggested Action	66
7.1.1 Default Device Name Is Not Modified.....	66
7.1.2 Default WDS Password Is Still Used by All Devices	66
7.1.3 Network Cable Is Disconnected or Incorrectly Connected.....	67
7.1.4 Latency Is High or Bandwidth Is Insufficient.....	67
7.1.5 Radar Signal Interference.....	68
8 System Settings	70
8.1 Configuring Management Password	70
8.2 Configuring Session Timeout Duration.....	71
8.3 Resetting Factory Settings.....	72
8.4 Rebooting the Device	72
8.5 Configuring System Time	73
8.6 Configuring Config Backup and Import.....	73
8.7 Performing Update and Displaying the System Version	74
8.7.1 Online Update	74
8.7.2 Local Update.....	74
8.8 Switching System Language	75
8.9 Configuring SNMP	75
8.9.1 Overview	75
8.9.2 Global Configuration	76
8.9.3 View, Group, Community, User Access Control	77
8.9.4 SNMP Service Typical Configuration Examples.....	85

8.9.5 Configuring Trap Service	91
8.9.6 Trap Service Typical Configuration Examples	95

1 Change Description

This chapter describes the major changes in software and hardware of different versions and related documentation. For details about hardware changes, see the release notes published with software versions.

1.1 3.0(1)B11P302

1.1.1 Hardware Change

The following table lists the applicable hardware models of this version.

Model	Hardware Version
RG-EST350G	V1.xx
RG-EST450G	V1.xx
RG-EST330F-P	V1.xx

1.1.2 Software Feature Change

This is the baseline version, with no changes to software features.

2 Login

2.1 Configuration Environment Requirements

- Browser: Google Chrome, Internet Explorer 9.0, 10.0, and 11.0, and some Chromium/Internet Explorer kernel-based browsers (such as 360 Extreme Explorer) are supported. Exceptions such as garble or format error may occur if an unsupported browser is used.
- Resolution: 1024 x 768 or a higher resolution is recommended. If other resolutions are used, the page fonts and formats may not be aligned, the GUI is less artistic, or other exceptions may occur.

2.2 Default Configuration

Table 2-1 Default Web Configuration

Item	Default Value
IP address	10.44.77.254
Password	You can enter the initial password "admin" to log in, and directly start the configuration after login.

2.3 Logging In to Web Interface on a PC

2.3.1 Connecting to the Device

You can open the management page and complete the bridge configuration only after connecting a PC to the bridge. You can connect a PC to the bridge in either of the following ways.

- Wired Connection

Connect a local area network (LAN) port of the bridge to the network port of the PC, and set the IP address of the PC. See [2.3.2 Configuring the IP Address of the Management PC](#).



- Wireless Connection

On a mobile phone or laptop, search for wireless network **@Ruijie-bXXXX**. (XXXX is the last four digits of the MAC address of each device, and the MAC address can be found at the rear side of each bridge.) In this mode, you do not need to set the IP address of the management PC, and you can skip the operation in [2.3.2 Configuring the IP Address of the Management PC](#).

2.3.2 Configuring the IP Address of the Management PC

Configure an IP address for the management PC in the same network segment as the default IP address of the device (The default device IP address is 10.44.77.254, and the subnet mask is 255.255.255.0.) so that the management PC can access the device. For example, set the IP address of the management PC to 10.44.77.10.

Caution

The IP address of the management PC cannot be set to 10.44.77.253, because this IP address is reserved by the device. If the management PC uses this IP address, it cannot access the device.


2.3.3 Logging in to the Web Interface

- (1) Enter the IP address (10.44.77.254 by default) of the bridge in the address bar of the browser to open the login page.

Note

- By logging in to the IP address 10.44.77.253, you will be redirected to the home page of the primary device on the self-organizing network.
 - If the static IP address of the device is changed, or the device obtains a new dynamic IP address, the new IP address can be used to access the web management system of the device as long as the management PC and the device are in the same network segment of a LAN.
-

- (2) On the web page, enter the password and click **Login** to enter the web management system.



⚠ Caution

- The default password for the device upon first login is admin. To ensure device security, you need to reset the device password after the first login. For details, see [2.4.2 Configuring Project Settings](#)
 - The login page will be locked for 60 seconds if you enter incorrect passwords multiple times. You can press and hold the Reset button on the device for more than 10 seconds when the device is powered on to restore it to factory settings. After the restoration, you can use the default IP address and password for login.
 - Restoring factory settings will delete the existing configuration and you are required to configure the device again at your next login. Therefore, exercise caution when performing this operation.
-

2.4 Initial Setup

✅ Specification

The initial setup page will be displayed only when the device is first configured or restored to factory settings.

2.4.1 Configuration Steps

- (1) Configure project settings. For details, see [2.4.2 Configuring Project Settings](#).
- (2) Configure the WDS group settings. Based on your usage scenario, choose whether to create a new WDS group or to add devices to an existing one. For creating a new WDS group, see [2.4.3 1. Creating a New WDS Group](#). For adding devices to an existing WDS group, see [2.4.3 2. Adding Devices to an Existing WDS Group](#).

2.4.2 Configuring Project Settings

To ensure device security, you need to reset the device password after the first login. Enter the project name and password.

Click **Save**.

Project Settings

* Project Name

* New Password

There are four requirements for setting the password:

- The password must contain 8 to 31 characters.
- The password must contain uppercase and lowercase letters, numbers and three types of special characters.
- The password cannot contain admin.
- The password cannot contain question marks, spaces, and Chinese characters.

* Confirm Password

Save

2.4.3 Configuring WDS Group Settings

✔ Specification

This step will be skipped if the devices are delivered as a pair or have been bridged using the WDS button.

1. Creating a New WDS Group

● Configuration in BaseStation Mode

- (1) Set **Bridge Group** to **Create New Group**.
- (2) Set **Bridge Mode** to **BaseStation**.
- (3) Enter the WDS SSID and WDS password, and click **Create Bridge Group**.

Group Settings

Bridge Group Create New Group Add to Current Group

Bridge Mode


Base Station
On a bridge network, only one BaseStation can be deployed at the network video recorder end.



CPE
On a bridge network, multiple CPEs can be deployed.

* Bridge SSID

* WDS Password Default Password

- **Configuration in CPE Mode**


- (1) Set **Bridge Group** to **Create New Group**.
- (2) Set **Bridge Mode** to **CPE**. A pop-up window is displayed. Click **Switch to CPE Mode**.



Group Settings

Bridge Group Create New Group Add to Current Group

Bridge Mode


CPE
On a bridge network, multiple CPEs can be deployed.

Tip

When creating a new project, you are advised to first add the BaseStation. If the current device needs to serve as a CPE, click Switch to CPE Mode.

- (3) Click **Create Bridge Group**.

Group Settings

Bridge Group Create New Group Add to Current Group

Bridge Mode




Previous

2. Adding Devices to an Existing WDS Group

- (1) Set **Bridge Group** to **Add to Current Group**.
- (2) Select the bridge mode.

Note

To set the device to the BaseStation mode, click **Switch to BaseStation Mode** on the pop-up window that is displayed.



- (3) Click **Add to Current Group**.

Group Settings

Bridge Group Create New Group Add to Current Group

Bridge Mode



Base Station
On a bridge network, only one BaseStation can be deployed at the network video recorder end.



CPE
On a bridge network, multiple CPEs can be deployed.

Previous

Add to Current Group

- (4) The device automatically detects available WDS groups. Select the WDS SSID from the **Bridge Network List**, enter the WDS password, and click **Bridge Device**.

Bridge Network List (1) ×

Search by SSID

Re-scan

SSID	SN	RSSI
@Ruijie-wds-FCEF	[REDACTED]	Good >

No SSID Available?

1. Make sure all devices are powered on and the device mode is correct.
2. If the SSID cannot be scanned, reboot the device or restore it to factory settings.

Please enter the WDS Password. ✕

.....

Default Password

Cancel
Bridge Device

2.5 Introduction to the Web Interface

2.5.1 Frequently-Used Controls on the Web Interface








Table 2-2 Frequently-Used Controls on the Web Interface

No.	Description
①	Navigate to common functions of the device, including network-wide management, device, and system functions.
②	Switch the language of the web interface and exit the web interface.
③	Click the device under the One-Device menu to access the device monitoring or configuration page. <ul style="list-style-type: none"> When Self-Organizing Network (SON) is enabled: The One-Device menu displays the current login device and the primary device on the self-organizing network. If the current login device is the primary device on the self-organizing network, it is indicated by the .

No.	Description
	<p>icon.</p> <ul style="list-style-type: none"> ○ The  icon indicates the primary device on the self-organizing network. ○ The  icon indicates the current login device. ● When SON is disabled: The One-Device menu displays the current login device, indicated by the  icon.
④	Current device information, work mode, SON status, and the reboot button.
⑤	The navigation bar for network-wide management, which includes common functions applicable to all devices on the self-organizing network.
⑥	<ul style="list-style-type: none"> ● Network-Wide: Displays the navigation bar for managing and configuring all devices on the network. ● One-Device: Displays the navigation bar for configuring common functions specific to a single device.
⑦	<p>Device monitoring and configuration interfaces</p> <p>In pane ③, select a device and click Monitor. WDS group information related to the device is displayed.</p>  <p>In pane ③, select a device and click Config. Click a configuration item in pane ⑥ to configure the corresponding function on the device.</p>

2.5.2 Network-wide Management Interface

Click a configuration item under the **Network-Wide** menu on the left navigation bar to manage and configure devices on the self-organizing network. The configuration functions and displayed content on the network-wide management interface vary depending on whether the primary device on the self-organizing network is an RG-EST series bridge.

1. The Primary Device on the Self-Organizing Network Is a Bridge

When the primary device on the self-organizing network is an RG-EST series bridge, the **Network-Wide** menu only include **Devices** and **System** tabs.


- Network-wide device management

Choose **Network-Wide > Devices**.

You can view all devices on the self-organizing network on the device list. Click **Manage** or **Reboot** to configure or reboot the selected device.


Note

Configuration and reboot operations are only supported on devices that have SON enabled. For details, see [2.6 Self-Organizing Network](#).



● Network-wide system settings

Choose **Network-Wide > System**.



Click **System** under the **Network-Wide** menu. Select a tab from the navigation bar on the right to configure and manage devices on the network.

- (1) **Time**: For details, see [8.5 Configuring System Time](#).
- (2) **SNMP**: For details, see [8.9 Configuring SNMP](#).
- (3) **Password**: For details, see [8.1 Configuring Management Password](#).

2. The Primary Device on the Self-Organizing Network Is Not a Bridge

When the primary device on the self-organizing network is not an RG-EST series bridge, the **Network-Wide** menu includes **Workspace**, **Devices**, **Clients** and **System**. In addition, the physical topology of the whole network is displayed on the web interface.

- Network-wide workspace

Choose **Network-Wide > Workspace**.






Table 2-3 Description of the Workspace

No.	Description
①	Displays the project name and whether the project is managed in Ruijie Cloud.
②	<p>Displays the network-wide configuration items, including network-wide service network planning, wireless functions, wired functions, and network-wide system functions. For details about function configuration, follow the steps below:</p> <ol style="list-style-type: none"> (1) Log in to the Reycce official website at https://reycce.ruijie.com/en-global/. (2) Click  on the top right corner, enter the product model in the search box, and press Enter. (3) The product details page is displayed. (4) Click Resources on the page to obtain the configuration guide of the product.
③	<p>Displays the physical topology of the network. Click any device in the topology to access the device configuration interface.</p> <p>Click + Discover Devices on the top right corner to add devices.</p>

- Network-wide device management


Choose **Network-Wide > Devices**.

The device list displays all devices on the self-organizing network. Click **Manage** or **Reboot** to configure or reboot the selected device.




2.5.3 One-Device Web Interface


- Method 1: Click the device under the **One-Device** menu on the left.
- Method 2: Choose **Network-Wide > Devices** on the left, and click **Manage** to manage the device.



Monitoring page: Click **Monitor**. The page displays WDS information on the network.




Configuration page: Click **Config** to manage and configure the selected device.



2.6 Self-Organizing Network

The **Self-Organizing Network** function is enabled by default.



Standalone mode: When the **Self-Organizing Network** function is disabled, the device will not be discovered on the network, and will operate in standalone mode. After logging into the web interface, you can only configure and manage the current login device. If you only need to configure one device or do not wish to apply global configurations to the device, you can disable the **Self-Organizing Network** function.

Self-Organizing Network mode: When the **Self-Organizing Network** function is enabled, the device can be discovered on the network, and can discover other devices on the network. These devices connect with each other based on their status to form a network, and synchronize global configurations. You can log in to any device on the network to configure and manage all devices on the network. Enabling this function enhances network management efficiency. You are advised to keep this function enabled.

When the device works in Self-Organizing Network mode, the web interface provides two configuration modes: Network-Wide mode and One-Device mode. For details, see [2.5.2 Network-wide Management](#) and [2.5.3 One-Device Web Interface](#).

2.7 Adding Devices to the Self-Organizing Network


✔ Specification

When the **Self-Organizing Network** function is enabled, the ability to discover and add devices is subject to the primary device. If the primary device is an RG-EST series bridge, only other bridges on the network can be discovered and added. If the primary device is not an RG-EST series bridge, all types of Reyee devices can be discovered and added.


2.7.1 The Primary Device on the Self-Organizing Network Is a Bridge

Choose **Network-Wide > Devices**.


- (1) A prompt is displayed under **Device List**. Click **Handle** to add the unconnected devices or other networks to the current network.



- (2) After you are redirected to the network list page, expand **Other Network** to select the target devices and click **Add to My Network**.




- (3) You do not need to enter a password if the device hasn't been configured previously. If the device already has a password, you must enter the device's management password. Adding the device will fail if the password entered is incorrect.



2.7.2 The Primary Device on the Self-Organizing Network Is Not a Bridge

(1) Add devices to a network:


- Method 1: When a new device joins the network via a wired connection, the system prompts that there are other devices not yet connected. Click **Handle** to add the unconnected devices or other networks to the current network.




- Method 2: Choose **Network-Wide > Workspace > Physical Topology**, and click **+ Discover Devices**.



- Method 3: Choose **Network-Wide > Devices**. A prompt is displayed under **Device List**. Click **Handle** to add unconnected devices or other networks to the current network.



(2) After you are redirected to the network list page, expand **Other Network** to select the devices to be added and click **Add to My Network**.



- (3) You do not need to enter a password if the device hasn't been configured previously. If the device already has a password, you must enter the device's management password. Adding the device will fail if the password entered is incorrect.

Add Device to My Network



* Password

[Forgot Password](#)

[Add](#)

3 Wi-Fi Network Settings

3.1 Overview

3.1.1 BaseStation and CPE

Wireless bridges purchased in pairs can be automatically paired after power-on. The wireless bridge also supports manual pairing by connecting to the Wi-Fi signal broadcast by another bridge. For details, see [3.3 Scanning to Pair and Add Devices](#). In a paired WDS group, bridges can work in BaseStation or Customer Premises Equipment (CPE) mode.

- **BaseStation:** A bridge sending bridging signals is generally connected to the NVR end in a surveillance room. A WDS group can contain at most one BaseStation.
- **CPE:** A bridge that enables customers to access ISP's communication services is generally connected to the camera end. A WDS group can contain multiple CPE.

3.1.2 WDS Wi-Fi and Management Wi-Fi

- **WDS Wi-Fi:** A BaseStation broadcasts the WDS Wi-Fi signal. A CPE accesses the WDS Wi-Fi and upload videos or other data to the BaseStation.
- **Management Wi-Fi:** Both the BaseStation and the CPE can broadcast a dedicated management Wi-Fi network for device management purposes. You can connect to this network to configure and manage your devices.

3.2 Switching Between BaseStation Mode and CPE Mode

✓ Specification

The CPE functions are available only when the wireless bridge switches from the BaseStation mode to the CPE mode.

If the original BaseStation fails, you need to set the new device to BaseStation mode to replace the faulty device. If multiple CPE are required, a newly added device joining the WDS group must be switched to CPE mode.

- (1) You can check the current mode in the upper right corner of the web page and click **Switch Mode** to switch the mode.



- (2) In the displayed dialog box, click **Start**.

Note ×

! You can reset the device to restore default pairing status.

Country/Region: *

Pairing Status: Default

Work Mode: Camera (CPE)

WDS SSID: @Ruijie-wds-0808

Custom:

- 1. Support one-to-many (one AP to many CPEs).
- 2. Replace the paired device.

Start

(3) Click **Next**.

Country/Region ×

The country/region you select here must be the same as the country/region of the WDS network.

Country/Region:

Previous

Next

(4) Select a mode from the **Work Mode** drop-down list.

Mode Switchover ×


Work Mode:

Previous


- NVR (BaseStation)**
- Camera (CPE)

Next

(5) Click **Scan**. A list of camera (CPE) is displayed. Select the target camera (CPE), enter the WDS password, and click **Next**.



(6) Verify the settings on the **Setup** page. Then, click **Save**.



⚠ Caution

Switching the mode will reboot the device. Therefore, exercise caution when performing this operation.

3.3 Scanning to Pair and Add Devices

3.3.1 Overview


When a wireless bridge is added to a WDS group or connected to another wireless bridge, you can scan the surrounding wireless bridges, compare their models, serial numbers, and other information, and then select the bridging target.

3.3.2 Configuration Steps

Choose **One-Device > Monitor > WDS Group Info**.

1. Scanning Surrounding Devices

Go to the home page and click **Scan Device**.



2. Selecting a Device for Pairing

Select the desired device, enter the bridging password in the **WDS Password** field, and click **Bridge Device**. The selected device will be bridged.

If no device is displayed, click **Re-scan**.

Other Devices (2) ×

<input type="checkbox"/>	Model	SN	RSSI	Device Info	WDS Password
<input checked="" type="checkbox"/>	EST350F-E	1234567891 235	Medium	default/Ruijie e	Default Password
<input type="checkbox"/>	AIRMETRO4 60F	1234942570 021	Poor	default/Ruijie e	Default Password

Tips

1. If you failed to find the target device, scan the SSID to add the target device or make sure all devices are powered on and the device mode is correct,
2. If you forgot the password, restore the device to factory settings.
3. Click [WDS](#) to add devices by scanning the SSID.

3.4 Configuring the WDS Wi-Fi for a Single BaseStation or CPE

3.4.1 Configuring the Work Mode

Choose **One-Device > Config > Wireless > WDS**.

Select the work mode as **BaseStation** or **CPE**.

WDS

Work Mode ^

* WDS SSID ?

WDS Password Default Password

3.4.2 Setting the WDS SSID

Go to the configuration page:

- Method 1: **Choose One-Device > Config > Wireless > WDS.**

- Method 2: **Choose One-Device > Monitor > WDS Group Info > BaseStation/CPE.**

◇ **BaseStation**

To prevent network exceptions, you are advised to keep the default WDS SSID unless otherwise specified.

If a new WDS SSID is set for a device in a WDS group, other bridges in the group need to change to the new SSID as well to connect with this device.

When a new device is connected, you can either configure a new WDS SSID or click **Scan** to select a target WDS SSID.

To check the WDS SSIDs of WDS groups, choose **One-Device > Monitor > WDS Group Info**. For details, see [3.9 Displaying WDS Group Information](#).

⚠ Caution

Configuring a WDS SSID will disconnect the WDS link. Incorrect WDS SSID will cause a WDS connection failure. Therefore, exercise caution when performing this operation.

3.4.3 Configuring the WDS Password

Choose **One-Device > Config > Wireless > WDS**.

A correct WDS password is required for a successful WDS link. To prevent unauthorized devices from connecting to the WDS Wi-Fi network, high-security passwords are used for devices by default, and the password for devices of the same model is the same. You are advised to change the password for devices in the entire network or in a WDS group to prevent others from accessing the network using a device of the same model.

The screenshot shows the WDS configuration page. At the top, there's a 'WDS' header. Below it, 'Work Mode' is set to 'BaseStation'. The '* WDS SSID' is '@Ruijie-wds-8DF9' with a 'Scan' button and a help icon. The 'WDS Password' section has a checkbox for 'Default Password' which is highlighted with a red box. Below the checkbox is a password input field with a red box around it. At the bottom is a blue 'Save' button.

⚠ Caution

- WDS passwords can be configured only for CPE devices, and not for the BaseStation.
- Configuring a WDS password will disconnect the WDS link. An incorrect WDS password will cause a WDS connection failure. Therefore, exercise caution when performing this operation.

3.4.4 Saving the Settings

After changing the WDS SSID or password, click **Save** to activate settings at once.


3.5 Configuring the WDS Password for a LAN

Choose **One-Device > Monitor > WDS Group Info**.

(1) Click **Bridge Workspace**.

The screenshot shows the 'WDS Group Info' page. At the top, there are 'Monitor' and 'Config' tabs. Below is an 'Alarm' section. The main content area is titled 'WDS Group Info' and shows 'WDS Groups : 3'. There are three radio buttons for 'Local Performance Mode': 'High Bandwidth Mode', 'Normal Mode' (selected), and 'Anti-Interference Mode'. A 'Bridge Workspace' button is highlighted with a red box. Below this, there's a 'WDS Group1' section with a 'Change WDS Password' link. It displays 'BaseStation: 1 (Bridge)' with various performance metrics like Frequency, Latency, Jitter, Freezes, Bandwidth, Interference, and RSSI. Below that, there's a 'BaseStation' and 'CPE' section with a signal strength diagram showing 'Strong Signal', 'Medium Signal', and 'Poor Signal'. The diagram shows a connection between a BaseStation and a CPE with various metrics like Distance, Latency, Rate, Flow, and Active Time.

(2) Click **WDS Password**.



Tip: The above functions apply to all bridges on the network.

(3) Enter the password in the displayed dialog box, and click **Save**.

WDS Password
×

(Change the bridge passwords of the devices in all bridge groups.)

* Password

* Confirm Password

Caution


- When configuring the WDS password for the entire network, ensure that all devices in the network are online. Otherwise, the WDS passwords of the devices will be inconsistent.
- Configuring the WDS password for the entire network will reconnect all devices in the network. Therefore, exercise caution when performing this operation.
- If there is an unbridged device in the network, the WDS password cannot be configured.

3.6 Configuring the WDS Password for a WDS Group

Choose **One-Device > Monitor > WDS Group Info**.

The default WDS password of devices is the same. Changing the WDS password can prevent others from illegally accessing the user network by using a device of the same model.

When configuring the WDS password for bridges in the entire network is unavailable or unnecessary, you can click **Change WDS Password** to configure the WDS password for bridges in the WDS group. If there is an unbridged device in the group, the **Change WDS Password** function will be unavailable.



Change WDS Password ✕

(Change the bridge password of the devices in this group.)

* Password

* Confirm Password

⚠ Caution

When configuring the WDS password for a WDS group, ensure that all devices in the group are online. Otherwise, WDS passwords of the devices will be inconsistent.

Configuring the WDS password for a WDS group will reconnect devices in the group. Therefore, exercise caution when performing this operation.

If there is an unbridged device in the WDS group, this function will be unavailable.

3.7 Configuring the Management Wi-Fi for a Single BaseStation or CPE

Choose **One-Device > Config > Wireless > Manage SSID**.

i Note

The management SSID is used only for accessing the web interface and managing devices. It cannot be used for Internet access, and is isolated from the service network.

3.7.1 Selecting the Work Mode

1. Default Configuration

When Default Settings is selected, the management SSID of the device will automatically be hidden after 2 hours, making it inaccessible for connection.

2. Custom Configuration

SSID: Indicates the Wi-Fi name to which the mobile phone or management PC connects for access.

Security: The options include **Open**, **WPA-PSK**, **WPA2-PSK**, and **WPA_WPA2-PSK**. You are advised to choose **WPA_WPA2-PSK** and set a password for security purpose.

Hide SSID: When the **Hide SSID** switch is toggled on, mobile phones or PCs cannot discover the SSID. You need to manually enter the SSID and password for access. This can prevent the SSID from being accessed by unauthorized users.

You can view the network-wide management SSID for each bridge group at **One-Device > Monitor > WDS Group Info > Bridge Workspace > SSID**. For details, see [3.8 Configuring the Management Wi-Fi and Password for a LAN](#).

Manage SSID

Wi-Fi settings Default settings Custom settings

* SSID:

Security:

Hide SSID: (The SSID must be manually entered exactly.)


3.8 Configuring the Management Wi-Fi and Password for a LAN

Choose **One-Device > Monitor > WDS Group Info**.


Note

The management SSID is used only for accessing the web interface and managing devices. It cannot be used for Internet access, and is isolated from the service network.

(1) Click **Bridge Workspace**.




(2) Click **SSID**.



Tip: The above functions apply to all bridges on the network.

(3) Set related parameters.



The default SSID for device management is @Ruijie-bXXXX. (XXXX is the last four digits of the MAC address of each device, and the default management SSID varies with each device.) Click **SSID** on the page to set the same management SSID and password for all bridges in the LAN.

Enable Wi-Fi: Choose whether to enable the management Wi-Fi for all devices in the network.

SSID: The SSID is the name of the management Wi-Fi network.

Security: The options include **Open**, **WPA-PSK**, **WPA2-PSK**, and **WPA_WPA2-PSK**. You are advised to choose **WPA_WPA2-PSK** and set a password for security purpose.


Hide SSID: When the **Hide SSID** switch is toggled on, mobile phones or PCs cannot discover the SSID. Users need to manually enter the SSID and password for access. This can prevent the SSID from being accessed by unauthorized users.


Caution

After the configuration is saved, the BaseStation and CPE devices in the network will be reconnected. Therefore, exercise caution when performing this operation.

3.9 Displaying WDS Group Information

Choose **One-Device > Monitor > WDS Group Info**.

Displayed WDS group information includes the number of Base Stations and CPE in the group, current working channel, SSID, latency, interference, wireless bandwidth and quality, RSSI and quality, data rate, real-time traffic, and uptime. Hover the cursor over  to view the detailed information of every item.



Hostname	MAC	Latency
Ruijie	00:10:f9:50:67:66	0ms


Latency ? Fluent(1) Jitter(0) Freeze(0)


Note

BaseStation is at the NVR end, while CPE is at the camera end.

3.10 Displaying the Information About a Bridge

Choose **One-Device > Monitor > WDS Group Info > BaseStation** or **CPE**.

Click the  icon of a device to display the basic information about the device in the right panel of the page, including the hostname, uptime, model, SN, MAC address, software and hardware versions, IP address, subnet mask, LAN port status, noise floor/utilization, distance, frequency, transmit power, channel width, RSSI, and band.



The screenshot shows the Ruijie RCycc interface. The main panel displays 'WDS Group Info' with a table of WDS groups. The first group is selected, showing details for a BaseStation (Bridge) and CPE 1. A 'Local' icon is visible next to the BaseStation entry. On the right, a detailed device information panel is open, showing the following data:

- Device: Group 1 / BaseStation / B...
- Settings: WAN, WDS, Reboot
- HOSTNAME: Bridge
- Uptime: 1Day16hr56Min06Sec
- Model: EST
- SN: G
- Software Ver: AP_3.0(1)B
- Hardware Ver: 1.00
- MAC: e2...
- IP Address: 192.168.110.73
- Subnet Mask: 255.255.255.0
- LAN1: Disconnected
- Noise Floor/Utilization: -91dBm / 2%
- Distance: 150M
- Frequency: 5765MHz
- Transmit Power: 29.0dBm
- Channel Width: 40MHz
- RSSI: --
- Band: 5G

Specification

The device at the NVR end does not involve channel width and RSSI, and only the device at the camera end does.

3.11 Configuring the Country/Region Code for a Bridge

3.11.1 Getting Started

The country/region code switch will take effect on a single device. Configuring the country/region code for a single device in bridging state will result in bridge disconnection. For network-wide country/region code configuration, please refer to [3.12 Setting the Country/Region Code for a WDS Group](#) for details.

⚠ Caution

If you change the country/region code in the case of device disconnection, WDS connection may fail.

3.11.2 Configuration Steps

Choose **One-Device > Config > Wireless > Country/Region**.

Choose the target country/region from the drop-down list, and click **Save**.

Country/Region

United States (US) ▼

Save


⚠ Caution

- After the country/region code is changed, the Wi-Fi network will restart, and the BaseStation and the camera will be reconnected after the Wi-Fi network is restarted.
 - The current channel may be switched to **Auto** because it is not supported by the country/region. Therefore, exercise caution when performing this operation.
-

3.12 Setting the Country/Region Code for a WDS Group

3.12.1 Getting Started

The country/region code switch will take effect on all devices on the network, including those listed on the homepage of the web interface. Therefore, before configuring the country/region code, you are advised to go to the homepage and check whether the target devices are on the current network and their bridging status is normal.




⚠ Caution

If the target device is not on the network or if the bridge is disconnected during the country/region code switch, it may lead to the device being unable to bridge properly.


3.12.2 Configuration Steps

Choose **One-Device > Monitor > WDS Group Info**.

- (1) Click **Bridge Workspace**.



- (2) Click **Country/Region**.



Tip: The above functions apply to all bridges on the network.

- (3) After setting the country/region code, click **Save**.

Country/Region ×

Country/Region ? ▼

3.13 Setting the SSID for a Single Bridge

3.13.1 Overview


The device detects the surrounding wireless environment and selects the appropriate configuration upon power-on. However, network freezing caused by wireless environment changes cannot be prevented. You can also analyze the wireless environment around the bridge and manually select appropriate parameters.

3.13.2 Getting Started

Go to the configuration page:

- Method 1: Choose **One-Device > Config > Wireless > Frequency & Transmit Power**.
- Method 2: Choose **One-Device > Monitor > WDS Group Info > BaseStation** or **CPE > WDS > Frequency & Transmit Power**.


◇ BaseStation



Before configuration, you can check the interference in the current environment in the following way to find the optimal frequency.

Click **Interference** to view the interference of each frequency. The frequency with the smallest interference is the optimal frequency.

To view the interference details of each frequency, go to the **Spectrum Scan** page. For details, see [5.2 Spectrum Scan](#).




3.13.3 Configuration Steps

1. Configuring the Frequency

(1) Frequency Settings

Automatic frequency selection is enabled by default, that is, the device automatically selects a frequency based on the surrounding environment when it is powered on.

Excessive wireless clients connected to a frequency can cause strong wireless interference. Choose the optimal frequency identified through the proceeding analysis. Click **Save** to make the configuration take effect immediately.



Once the frequency is adjusted at the NVR end, the CPE end will follow the frequency configuration of the NVR end automatically. Independent frequency settings are not supported on the CPE end.

Note

- The available frequencies are subject to the country/region code. Select the country or region where the device will be used.
- The preceding figure shows the frequency configuration for 5 GHz, and that for 2.4 GHz is the same.
- The bridge that supports only the 2.4 GHz frequency band does not support the 5 GHz frequency configuration.

Caution

Changing the frequency will cause the BaseStation to disconnect and then reconnect to the CPE. Exercise caution when performing this operation.

2. Configuring the Channel Width

If the interference is severe in the wireless environment, choose a narrower channel width to avoid network stalling.


The 5 GHz bridge supports 20 MHz, 40 MHz, and 80 MHz, while the 2.4 GHz bridge supports 20 MHz and 40 MHz.

A narrower channel width indicates a more stable network with a smaller bandwidth. Conversely, a wider channel width indicates a less stable network but with a larger bandwidth. The default value is 20 MHz for 2.4 GHz and 40 MHz for 5 GHz. The default settings are recommended.

After setting the channel width, click **Save** to make the configuration take effect immediately.

Caution

Changing the channel will cause the BaseStation to disconnect and then reconnect to the CPE. Exercise caution when performing this operation.




3. Configuring the Transmit Power

Higher transmit power provides greater coverage but may introduce stronger interference to surrounding wireless devices.


The default value is **Auto**, indicating that the transmit power is automatically adjusted. In scenarios where wireless devices are densely deployed, lower power is recommended.

Lower, Low, Medium, and High correspond to 25%, 50%, 75%, and 100% of the transmit power.



4. Configuring the Distance

The default setting automatically measures the distance between the NVR end and the camera end after they are bridged. In manual mode, you are advised to set the distance slightly greater than the actual distance. Setting a small distance may degrade wireless performance and lead to bridging failure.



✔ Specification

The maximum distance vary with the devices: 5 km for the RG-EST350G, 3 km for the RG-EST450G, and RG-EST330F-P.

3.14 Configuring TDMA Mode

✔ Specification

This function is supported only in the BaseStation mode.

3.14.1 Overview

Time Division Multiple Access (TDMA) is specifically designed to address the challenge of CPE nodes being hidden from each other over long distances. In the traditional Wi-Fi mechanism utilizing Carrier Sense Multiple Access with Collision Detection (CSMA/CD), the nodes are unable to listen to each other, leading to significant performance degradation. With the TDMA mode enabled, the traffic of each node remains unaffected by long distances, ensuring high performance.

3.14.2 Selecting the TDMA Mode

Choose **One-Device > Config > Wireless > TDMA**.

1. Flexible mode

The flexible mode is the default TDMA mode. When enabled, it employs an algorithm to automatically calculate the necessary time slots for each CPE or BaseStation. Additionally, the ratio between BaseStation and CPE is dynamically adjusted to optimize uplink and downlink traffic for maximum efficiency.

TDMA

TDMA

Mode ? Flexible Fix

Advanced v

Expert Mode

When expert mode is enabled, time slots will be allocated for each station in the bridge group based on actual traffic conditions. However, in this mode, the time slot is fixed, which may compromise station performance. Exercise caution when using the expert mode.

* Max Latency ms

Save

2. Fixed mode

The fixed mode is designed for scenarios that require traffic balance, consistent latency, and consistent uplink and downlink throughput for each node. By utilizing fix intervals (such as 5 ms, 8 ms, and 10 ms), the duration of each frame can be fixed to achieve a consistent latency. In terms of the uplink and downlink throughput, you can set the uplink and downlink ratio accordingly. Currently, there are five ratios available: 1:1, 1:2, 1:3, 2:1, and 3:1, which can be selected from the provided drop-down menu.

TDMA

TDMA

Mode [?] Flexible Fix

TDD Ratio

The time slot of downlink and uplink base on 1:1

TDD Time Slot

Advanced >

Save

3. Expert mode

Expand **Advanced** and toggle on **Expert Mode**.

TDMA

TDMA

Advanced ▾

Expert Mode

When expert mode is enabled, time slots will be allocated for each station in the bridge group based on actual traffic conditions. However, in this mode, the time slot is fixed, which may compromise station performance. Exercise caution when using the expert mode.

Enter the time slot value (1 ms or greater). The total time slots of all devices must not exceed 60 ms. [Reset](#)

BaseStation/Bridge ms
G1S09BK000625

Save

 Caution

The expert mode is designed for situations where a specific node requires a dedicated and fixed time slot, unaffected by algorithm adjustments. In this mode, the desired time slot can be set by the customer. However, it is important to note that the expert mode is not recommended for general customers and should only be configured by individuals with relevant professional knowledge. Incorrect configuration in this mode may result in the device failing to go online.

4 Advanced Settings

4.1 Rate Limiting

Enable rate limiting on broadcast or multicast packets to avoid congestion on the air interface.

The device supports rate limiting on specified broadcast packets (ARP and DHCP), specified multicast packets (MDNS and SSDP), or all broadcast and multicast packets.

Caution

Rate limiting takes effect on all devices over the network, that is, all bridges capable of rate limiting on the homepage.

Choose **One-Device > Config > Advanced > Rate Limiting**.

Packet-based Rate Limiting
This function allows users to limit the rate of downlink broadcast and multicast traffic. Exercise caution when configuring this function, as it could result in packet loss.

[Network-wide Packet-based Rate Limiting](#)

Broadcast Traffic Disable Limit All Limit Part

ARP Packets DHCP Packets

Multicast Traffic Disable Limit All Limit Part

MDNS Packets SSDP Packets

* Rate Limit Kbps

Current: 0 Kbps. Range: 1-1700000 Kbps

4.2 Configuring One-Touch Pairing

4.2.1 Overview


When the One-Touch Pairing feature is enabled, a simple press of the One-Touch Pairing button on the device triggers the mesh operation. During the mesh process, the BaseStation promptly forms a mesh connection with the factory-configured and unbridged CPE, streamlining the networking process.

4.2.2 Configuration Steps

Choose **One-Device > Config > Advanced > One-Touch Pairing**

Toggle on **Enable** and click **Save**.

Check whether the bridge is in BaseStation mode or CPE mode. If the bridge is currently in BaseStation mode, pressing the One-Touch Pairing button on the wireless bridge will bridge it to all nearby devices operating in CPE mode. If the device is currently in CPE mode, pressing the **One-Touch Pairing** button will switch it to BaseStation mode and continue bridging with all nearby devices operating in CPE mode.




✔ Specification

The One-Touch Pairing feature is enabled by default.

4.3 Port-based Flow Control

Choose **One-Device > Config > Advanced > Flow Control**.

Flow control can relieve the data congestion caused by ports at different speeds and improve the network speed. This function is enabled by default and can be manually disabled.



4.4 Wi-Fi Protection

✔ Specification

This feature protects the network against de-authentication attacks. It is successfully enabled only when enabled on both the BaseStation and the CPE devices.


4.4.1 Overview

When there is any attacker in the operational environment of the bridge, the attacker will transmit authentication attack packets to the bridge, resulting in abnormal disconnection of the bridge. Enabling **Wi-Fi Protection** can safeguard the bridge from authentication attacks.

4.4.2 Configuration Steps

Choose **One-Device > Config > Advanced > Wi-Fi Protection**.

This function is enabled by default. You can manually disable the Wi-Fi protection function. Click **Save**.






4.5 PoE Settings

✓ Specification

PoE setting is only supported on the RG-EST330F-P.

Choose **One-Device > Config > Advanced > PoE**.

You can view the maximum power consumption, current power consumption, remaining power consumption and PoE status. Hover the cursor over  to display the PoE switch .



4.6 Rebooting the Camera


✓ Specification

Camera restart is only supported on the RG-EST330F-P.

4.6.1 Rebooting All Cameras

Choose **Advanced > Restart Camera**.

You can reboot all cameras by check **All Cameras** and then clicking **Restart Camera**.

Restart Camera
 If you uncheck All Cameras, only the camera powered by DC/PoE power source via the current device will be restarted. If you check All Cameras, all cameras powered by DC/PoE power source via all devices in the network will be restarted.

All Cameras

Restart Camera


 **Caution**

Only the cameras connected to the online devices supporting this function will be restarted.
Please keep the device powered on during reboot. Otherwise, the device may be damaged.

4.6.2 Rebooting the Camera Connected to the Current Device

Choose **Advanced > Restart Camera**.

Uncheck **All Cameras** and click **Restart Camera**.

Restart Camera
 If you uncheck All Cameras, only the camera powered by DC/PoE power source via the current device will be restarted. If you check All Cameras, all cameras powered by DC/PoE power source via all devices in the network will be restarted.

All Cameras

Restart Camera

5 Tools

5.1 Antenna Alignment

✓ Specification

If the current device is in the BaseStation mode, you can view information about all devices in the CPE mode. If the current device is in the CPE mode, you can only view information about the current device and the device in the BaseStation mode.

5.1.1 Overview

The **Antenna Alignment** tool can be used only when the device is in normal bridging state. Proper alignment can help you achieve the best bridging signal. When the device moves in the horizontal and vertical directions, the RSSI changes in real time.

5.1.2 Configuration Steps

Go to the configuration page:

- Method 1: Choose **One-Device > Config > Tools > Antenna Alignment**.

Click **Antenna Alignment**. The RSSI of all CPEs in the bridge group will be displayed. Click any CPE to display the details of the bridging link.

Antenna Alignment
Ensure proper alignment of the antennas by observing the fluctuations in signal strength.

NVR (BaseStation)

Ruijie
SN: MACCSST350FE1
Local

-54 dBm

👆 -54 dBm

V -66dBm


H -54dBm


ⓘ The difference between the V value and the H value should be below 5 dBm.

Camera (CPE)

Ruijie
SN: MACCSST460F18

-50 dBm

👆 -50 dBm

V -50dBm


H -60dBm


ⓘ The difference between the V value and the H value should be below 5 dBm.

CPES View Details

Ruijie
SN:MACCSST460F18

-50 dBm

Ruijie
SN:G1SS60D00098B


-76 dBm

- Method 2: Choose **One-Device > Monitor > WDS Group Info**.

Click an RSSI value on the **WDS Group Info** page.



The bridge group information that can be viewed includes the maximum vertical and horizontal values of the BaseStation and camera in the bridge group, the optimal historical RSSI, and the real-time vertical and horizontal RSSIs.



⚠ Caution

The left pane displays details about the BaseStation device, while the right pane shows information about the CPE device.


5.2 Spectrum Scan

✓ Specification


- This function is supported only in the BaseStation mode.
- Bridges will be disconnected during spectrum scanning. Exercise caution when performing this operation.

⚠ Caution

The spectrum scan cannot be used together with the fast scan on the Frequency & Transmit Power configuration page. For quick scan configurations, see Section 3.13.2 [Getting Started](#).



After the spectrum scan is complete, if the color of certain channels is gray, it indicates that they are unavailable. Use a channel with a different color.



5.2.1 Overview


When a bridge is installed outdoors, outdoor base stations from other networks may cause wireless interference that will impact the bridge's performance. Spectrum scan provides details on interference across all frequencies. A higher interference score indicates severer interference on that frequency.

5.2.2 Configuration Steps


Go to the configuration page:

- Method 1: Choose **One-Device** > **Config** > **Tools** > **Spectrum Scan**.
- Method 2: Choose **One-Device** > **Monitor** > **WDS Group Info** > **BaseStation** > **Spectrum Scan**.

◇ BaseStation




Click **Spectrum Scan**, and then click **OK** on the pop-up window. The **Spectrum Scan** page is displayed.




Tip




Switching the channel scan may take up to a few minutes, during which the device may experience a temporary disconnection. Continue?




You can click the **20 MHz**, **40 MHz**, or **80 MHz** tabs to view the frequency interference. The color gradient from left to right indicates the level of interference, ranging from low to high. Each row represents the frequencies used by a device.



Hovering the mouse over it will display detailed information about the current frequency, including throughput and estimated number of cameras that can be supported.



To change frequencies, click on the target frequencies, and then click **Change**. A pop-up window is displayed. Click **OK**.



Tip ×

The network service will be unavailable for a while. Do you want to continue?

5.3 Network Test Tool

Choose **One-Device > Config > Tools > Network Tools**.

When you select the ping tool, you can enter the IP address or URL and click **Start** to test the connectivity between the bridge and the IP address or URL. The message "Ping failed" indicates that the bridge cannot reach the IP address or URL.

The Traceroute tool displays the network path to a specific IP address or URL.

The DNS Lookup tool displays the DNS server address used to resolve a URL.

Network Tools

Tool Ping Traceroute DNS Lookup

* IP Address/Domain

* Ping Count

* Packet Size

Result

5.4 Collecting Fault Info

Choose **One-Device > Config > Tools > Fault Collection**.

Click **Start** to collect fault information and compress it into a file for engineers to identify fault.

Fault Collection
Compress the configuration into a file for engineers to identify fault.

Caution

If the issue persists despite following the troubleshooting methods provided in this section, you may require remote support from a technician who will enable developer mode to resolve the issue. We will ensure your data is protected during this process.


5.5 Bridge Speed Test

Specification


- The speed test is only supported on paired bridges.
 - Before the speed test, ensure that the peer device is online. Otherwise, speed test cannot be performed.
-

Choose **One-Device > Config > Tools > Bridge Speed Test**.

(1) Select a test device and click **Change Device**. You can select the peer device that has been bridged.





(2) Set speed test parameters.



- **Type:** Select the downlink or uplink rates for the test (multiple selections are supported):
 - **Downlink speed:** Data transmission rate from the peer device to the local device (indicated by the green arrow).
 - **Uplink speed:** Data transmission rate from the local device to the peer device (indicated by the blue arrow).
- **Packet Size:** Using smaller packets is more suited for evaluating network latency and connectivity, whereas larger packets help test bandwidth utilization and the capacity of network devices.
- **Test Duration:** A short duration reflects the peak rate, while a long duration reflects the stable rate.
- **Maximum Latency:** The maximum acceptable network latency during the speed test. A lower acceptable latency indicates a higher requirement for the network environment. The default value is 0 ms.

(3) Click **Start Speed Test**.

(4) After the speed test is complete, the test results will be displayed on the page. Click **Back** to return to the speed test page.



Speed Test Parameters

Packet Size	Test Duration	Maximum Latency	Time
1500 byte	10 s	0 ms	2024-09-13 14:32:47

6 Network Settings

6.1 Network Modes

6.1.1 Configuring the Network Mode

The device supports two network modes: bridge mode and router mode. The system menu and functions vary with the network mode. A bridge is in bridge mode by default.

1. Bridge Mode

The device performs Layer 2 forwarding, and does not support the DHCP address pool function. In bridge mode, it is used in combination with a routing device for networking. The downlink devices' IP addresses are uniformly allocated and managed by the uplink device (with a DHCP address pool). The bridge only performs transparent transmission.

If the network is already connected to the Internet, you are advised to select the bridge mode.

2. Router Mode

The device has the routing function, and supports NAT routing and forwarding. The IP address of the downlink device can be allocated by the bridge. Data is forwarded by the bridge and NAT is supported.

In router mode, the device supports DHCP and static IP for Internet connection, and can directly connect to the uplink device.

Caution

After the device is switched to the router mode, its network settings will be changed. The IP address of the LAN port will be changed to 192.168.130.1, and the DHCP server will be enabled. You are advised to set the PC to automatically obtain an IP address, and to log in to 10.44.77.254 to configure the device in router mode. Router mode is supported only when the bridge acts as a CPE.

6.1.2 Configuration Steps

Choose **One-Device > Config > Network > Network Mode**.

Select the required network mode. Hover the mouse over the  icon to view the help information.

| Network Mode

Network Mode  Bridge Route

6.2 Configuring the IPv4 Address of the WAN Port

In bridge mode, the IPv4 address of the WAN port is only used for accessing the web interface, and does not affect the service network.


6.2.1 Allocating IPv4 Addresses to Bridges on the Network

1. Static IP Address


Choose **One-Device > Monitor > WDS Group Info**.

When a large number of devices on the network need to be configured with static IP addresses, you can use the IP Allocation feature to automatically allocate a static IP address to each device.

(1) Click **Bridge Workspace**.



(2) Click **IP Allocation**.



Tip: The above functions apply to all bridges on the network.

(3) In the dialog box that appears, select **Static IP Address** from the **Internet** drop-down list, enter the start IP address, subnet mask, gateway IP address, and DNS server IP address. Then, click **OK**.

Hover the mouse over the  icon to view the help information.

×

IP Allocation
(Change the IP addresses of all devices.)

Internet

* Start IP Address ?

* Subnet Mask

* Gateway

* DNS Server

IP Count 253

 **Caution**


- The start IP address cannot be on the same network segment as the current IP address. Otherwise, the configuration will fail.
 - After the configuration is saved, the device IP address will change, and you may fail to access the device's web interface. In this case, you need to enter the new IP address in the browser's address bar for login. Ensure that the IP addresses of the management PC and the device are on the same network segment. If they are not on the same network segment, change the management PC's IP address. For details, see [2.3.2 Configuring the IP Address of the Management PC](#). Therefore, exercise caution when performing this operation.
-

2. DHCP


Choose **One-Device > Monitor > WDS Group Info**.

When a large number of devices on the network require dynamic IP addresses, you can configure dynamic IP addresses for all devices on the network, so that each device can dynamically obtain an IP address.

- (1) Click **Bridge Workspace**.




(2) Click **IP Allocation**.



Tip: The above functions apply to all bridges on the network.

(3) Select **DHCP** from the **Internet** drop-down list. Then, click **OK**.




6.2.2 Set the WAN Port IP Address for a Single Online Bridge

Choose **One-Device > Monitor > WDS Group Info > BaseStation** or **CPE**.

You can set an IP address for a single device using the **Network-wide Management** menu.

Click . Select **WAN** from the drop-down list. For details, see [6.2.1 Allocating IPv4 Addresses to Bridges](#).

◇ BaseStation



WAN



Internet

DHCP does not require an account.

IP Address 192.168.110.77

Subnet Mask 255.255.255.0

Gateway 192.168.110.1

DNS Server 192.168.110.1

* MTU

⚠ Caution

After the IP address and subnet mask are changed, you may fail to access the device's web interface. In this case, you need to enter the new IP address in the browser's address bar for login. Ensure that the IP addresses of the management PC and the device are on the same network segment. If they are not on the same network segment, change the management PC's IP address. For details, see [2.3.2 Configuring the IP Address of the Management PC](#). Therefore, exercise caution when performing this operation.

6.2.3 Configuring an IP Address for the WAN Port

Choose **One-Device > Config > Network > WAN**.

Select the Internet connection type. You are advised to select **DHCP** for networks with a DHCP server, or **Static IP** for networks without a DHCP server.

If **Static IP** is selected, enter the IP address, subnet mask, gateway IP address, and DNS server address. Click **Save**.

WAN

Internet

DHCP does not require an account.

IP Address 192.168.110.77

Subnet Mask 255.255.255.0

Gateway 192.168.110.1

DNS Server 192.168.110.1

* MTU

Save

Caution

After the IP address and subnet mask are changed, you may fail to access the device's web interface. In this case, you need to enter the new IP address in the browser's address bar for login. Ensure that the IP addresses of the management PC and the device are on the same network segment. If they are not on the same network segment, change the management PC's IP address. For details, see [2.3.2 Configuring the IP Address of the Management PC](#). Therefore, exercise caution when performing this operation.

6.3 Changing the IP Address of a LAN Port

Specification

This function is supported only when the network mode of the device is set to router mode.

Choose **One-Device > Config > Network > Base Configuration > LAN**.

Enter the IP address and subnet mask, and click **Save**. After changing the IP address of the LAN port, enter the new IP address in the browser to access the web interface of the device for configuration and management.

LAN

* IP Address

* Subnet Mask

DHCP Server

* Start IP Address

* IP Count

* Lease Time (Min)

Block Web Access (?)

Table 6-1 LAN Configuration Parameters

Parameter	Description
IP Address	This IP address is the default gateway IP address for devices connected to the internet through this LAN.
Subnet Mask	Subnet mask of devices on the LAN.
DHCP Server	After this function is enabled, devices on the LAN can automatically obtain IP addresses. You need to configure the start IP address to be assigned, number of IP addresses to be assigned, and address lease time for the DHCP server, as well as other DHCP server options. For details, see 6.5 Configuring the DHCP Server .
Start IP Address	Start IP address of the IP address range automatically allocated by the DHCP server. The start address should be on the network segment calculated based on the IP address and the subnet mask.

Parameter	Description
IP Count	The number of assignable IP addresses, which is determined by the LAN segment and the start IP address.
Lease Time (Min)	Lease time of the automatically assigned IP addresses. When the lease time expires, devices on the LAN will obtain IP addresses again.
Block Web Access	After this function is enabled, you cannot log in to the web interface of the CPE through the LAN port. You can only log in to the web interface of the CPE by connecting to the SSID or connecting to the NVR (BaseStation) to access the web interface of the CPE.


6.4 Changing the MTU


WAN port MTU indicates the maximum transmission unit (MTU) allowed by the WAN port. The default value is 1500 bytes. However, at times, ISP networks may limit the speed of large data packets or block their transmission. This can lead to slow network speeds or even disconnections. In such cases, you are advised to set a smaller MTU value.

6.4.1 Changing the MTU of a Single Online Bridge

Choose **One-Device > Monitor > WDS Group Info > BaseStation** or **CPE**.

The MTU of a single device can be configured using the **Network-wide Management** menu.

Click . Select **WAN** from the drop-down menu. On the page that is displayed, enter the MTU value, and click **Save**.



WAN ×

Internet

DHCP does not require an account.

IP Address ✱

Subnet Mask 0.0.0.0

Gateway 0.0.0.0

DNS Server 0.0.0.0

* MTU

Save

6.4.2 Modifying the MTU of the Current Device

Choose **One-Device > Config > Network > WAN**.

On the **WAN** page, enter the MTU value and click **Save**.

| WAN

Internet

DHCP



DHCP does not require an account.

IP Address 192.168.110.77

Subnet Mask 255.255.255.0

Gateway 192.168.110.1

DNS Server 192.168.110.1

* MTU

1500

Save

6.5 Configuring the DHCP Server

✓ Specification

This function is supported only when the network mode of the device is set to router mode.

6.5.1 Overview

In router mode, the DHCP server function can be enabled on the device to automatically assign IP addresses to clients, so that clients connected to the LAN ports of the device can obtain IP addresses for Internet access.

6.5.2 Configuring the DHCP Server

Choose **One-Device > Config > Network > LAN**.

DHCP Server: This function is enabled by default when the network mode of the device is set to router mode. When the device is used as the only routing device on the network, you are advised to keep this function enabled. When multiple routing devices are connected to the uplink device through the LAN port, you are advised to disable this function.

⚠ Caution

If the DHCP Server function is disabled on all devices on the network, clients cannot automatically obtain IP addresses. You need to enable the DHCP Server function on one device or manually configure a static IP address for each client for Internet access.

Start IP Address: Start IP address of the DHCP address pool. A client obtains an IP address from the address pool. If all the addresses in the address pool are used up, no IP address will be assigned to the clients.

IP Count: Number of IP addresses in the address pool.

Lease Time (Min): Lease time of IP addresses. When a client is connected, the leased IP address is automatically renewed. If a leased IP address is not renewed due to client disconnection or network instability, the IP address will be reclaimed after the lease time expires. After the client connection is restored, the client can request for an IP address again. The default lease time is 30 minutes.

| LAN

* IP Address


* Subnet Mask

DHCP Server

* Start IP Address

* IP Count

* Lease Time (Min)

Block Web Access 

Save

6.6 Blocking Web Access

✓ Specification

This function is supported only when the network mode of the device is set to router mode.

Choose **One-Device > Config > Network > LAN**.

After this function is enabled, you cannot log in to the web interface of the camera through the LAN port of the PC. You can only access the web interface of the camera through the SSID or by connecting to the BaseStation.

LAN

* IP Address

* Subnet Mask

DHCP Server

* Start IP Address

* IP Count

* Lease Time (Min)

Block Web Access ?


Save

7 Alarm and Fault Diagnosis

7.1 Alarm Information and Suggested Action


When bridges fail or lack some necessary security configuration, the system prompts key alarms about the bridges on the homepage, so that users can handle the exceptions promptly.


Choose **One-Device > Monitor > Alarm**.



7.1.1 Default Device Name Is Not Modified

Modifying device names can help you better distinguish each bridge. Unless otherwise specified, you are advised to modify default device names.

When viewing the alarm, hover the cursor over the orange number of the prompt and click  in the displayed dialog box to modify the name of each device. (The orange number, 2 in the figure, indicates the number of devices that still use the default name in the network.) Enter the new device name and click **OK** to make the change take effect immediately.



7.1.2 Default WDS Password Is Still Used by All Devices

The default WDS password of devices of the same model is the same. Changing the WDS password can prevent others from illegally accessing the network by using a device of the same model.

Click **Click here to configure WDS Password**, enter the new password, and click **Save** to change the WDS password for the entire network.

Alarm

Configuration is uninitialized.

Hostname Not Set: 4 . ⓘ

Admin Password Not Set or The Management Password is Inconsistent: Click [here](#) to change the password.

The network is using the default password. For security, please change the network WDS Password. [Click here to configure WDS Password](#)

Time Zone: (GMT+8:00)Asia/Shanghai ⓘ

Network error

Cable Connection Error: 2 . [Suggested Actions](#)

Caution

- When configuring the WDS password for the entire network, ensure that all devices are online. Otherwise, WDS passwords of the devices will be inconsistent.
- Configuring the WDS password for the entire network will reconnect all devices in the network. Therefore, exercise caution when performing this operation.
- If there is an unbridged device in the network, the function of configuring the WDS password for the entire network will be disabled.

7.1.3 Network Cable Is Disconnected or Incorrectly Connected

Hover the cursor over the orange number of the prompt to display the alarm details.

Click the suggested action to check the solution.

Alarm

Configuration is uninitialized.

Hostname Not Set: 4 . ⓘ

Admin Password Not Set or The Management Password is Inconsistent: Click [here](#) to change the password.

The network is using the default password. For security, please change the network WDS Password. [Click here to configure WDS Password](#)

Time Zone: (GMT+8:00)Asia/Shanghai ⓘ

Network error

Cable Connection Error: 2 . [Suggested Actions](#) { Please check cable connection and then re-plug or replace the cable.

7.1.4 Latency Is High or Bandwidth Is Insufficient


First, check whether the device latency is too high. If yes, the interference in the environment may be severe. Then, you are advised to change to a frequency with smaller interference.

If not, increase the channel width. For frequency settings, see [3.13.3 1. Configuring the Frequency](#). For channel width settings, see [3.13.3 2. Configuring the Channel Width](#).

To check whether the latency is too high, perform as follows:

Hover the cursor over the orange number of the prompt to display all WDS groups, and click a group to display the details.

On the **Overview** page, check whether **Latency** is **Freeze**. If so, the latency is too high. Otherwise, the latency is normal.



High latency or low bandwidth may cause the camera image to freeze.

- 3 . [Suggested Actions](#)




Caution

Frequency and channel width settings described in this section are performed on the local device. You can click the IP address of a device to open the management page of the device and set the frequency and channel width.

7.1.5 Radar Signal Interference

When the device detects a radar signal in a channel, it generates an alarm. Hover the cursor over the orange number of the prompt to display alarm details.



Network error

Cable Connection Error: 1 . [Suggested Actions](#)

Radar Signal Interference Alarm 1 [Suggested Actions](#) It is recommended to select a non-DFS channel (36-48/149-165) to maintain the WDS connection.

Network error

Cable Connection Error: [2](#) · [Suggest](#)
 Radar Signal Interference Alarm [1](#) [?](#)

WDS Group	Hostname	Backoff Channel	Backoff Time	SN
WDS Group2	Ruijie ?	60	2022-02-21 14:57:26	CANL63300035S

According to the information about the WDS group and back-off channel in the alarm record, check whether the current working frequency in the WDS group (group 2 in the example) is consistent with that of back-off channels. (See [3.9 Displaying WDS Group Information](#).) If so, manually switch the frequency to a non-dynamic frequency selection (DFS) channel. For details, see [3.13.3 1. Configuring the Frequency](#).

Note

- Non-DFS channels include channels 36–48 and 149–165, corresponding to 5180 MHz to 5260 MHz and 5745 MHz to 5825 MHz.
- Automatic frequency switching upon detection of radar signals is supported on RG-EST350G, EST450G, EST330F-P.

Caution


If the preceding troubleshooting steps fail to resolve the issue, and remote assistance from technical support is needed, you can contact them to assist in enabling the developer mode. The technical support team can then perform diagnostics to identify and address the issue effectively.

8 System Settings


8.1 Configuring Management Password

Choose **One-Device** > **Monitor** > **WDS Group Info**.

(1) Click **Bridge Workspace**.



(2) Click **Admin Password** to change the login password for all devices.



Tip: The above functions apply to all bridges on the network.

If there is an unbridged device in the network, the link will be unavailable.

×

Admin Password
Change the management passwords of all devices.
Devices not on the network are discovered. Add them to My Network before configuring the network-wide web password. Add to My Network

* Old Password

* New Password

There are four requirements for setting the password:

- The password must contain 8 to 31 characters.
- The password must contain uppercase and lowercase letters, numbers and three types of special characters.
- The password cannot contain admin.
- The password cannot contain question marks, spaces, and Chinese characters.

* Confirm Password

⚠ Caution

This password is used to log in to web interface of any device in the network.

If there is an unbridged network in the network, the function of configuring the admin password will be disabled.

8.2 Configuring Session Timeout Duration

Choose **One-Device > Config > System > Management > Session Timeout**.

If no operation is performed on the page within a period of time, the session will be down. When you need to perform operations again, enter the password to open the configuration page. The default timeout duration is 3600 seconds, that is, 1 hour.

Backup & Import Reset Session Timeout

i **Session Timeout**

* Session Timeout Sec

Save

8.3 Resetting Factory Settings

Choose **One-Device > Config > System > Management > Reset**

Click **Reset** to restore factory settings.

Backup & Import Reset Session Timeout

i **Reset**
Resetting the device will clear the current configuration. If you want to keep the configuration, please [Export Config](#) first.

Reset

⚠ Caution

This operation will clear existing settings and restart the device. Therefore, exercise caution when performing this operation. If there is any configuration in the current system, please export the configuration before resetting the device.

8.4 Rebooting the Device

Choose **One-Device > Config > System > Reboot**.

Click **Reboot** to reboot the device immediately.

i **Reboot**
Please keep the device powered on during reboot.

Reboot

Caution

Please keep the device powered on during reboot. Otherwise, the device may be damaged.

8.5 Configuring System Time

Choose **Network-Wide > System > Time**.

You can view the current system time. If the time is incorrect, check and select the local time zone. If the time zone is correct but time is still incorrect, click **Edit** to manually set the time. In addition, the bridge supports Network Time Protocol (NTP) servers. By default, multiple servers serve as the backup of each other. You can add or delete local servers as required.

Time
Configure and view time (The device has no RTC module. The time settings will not be saved upon reboot).

Current Time 2022-02-18 22:14:28 [Edit](#)

* Time Zone (GMT+8:00)Asia/Shanghai [v](#)

* NTP Server

0.cn.pool.ntp.org	Add
1.cn.pool.ntp.org	Delete
cn.pool.ntp.org	Delete
pool.ntp.org	Delete
asia.pool.ntp.org	Delete
europa.pool.ntp.org	Delete
ntp1.aliyun.com	Delete

[Save](#)

8.6 Configuring Config Backup and Import

Choose **One-Device > Config > System > Management > Backup & Import**.

Configure backup: Click **Backup** to download a configuration file locally.

Configure import: Click **Browse**, select a configuration file backup on the local PC, and click **Import** to import the configuration file. The device will restart.

[Backup & Import](#)[Reset](#)[Session Timeout](#)**Backup & Import**

If the target version is much later than the current version, some configuration may be missing. It is recommended to choose [Reset](#) before importing the configuration. The device will be rebooted automatically later.

Backup Config

Backup Config

[Backup](#)**Import Config**

File Path

[Browse](#)[Import](#)

8.7 Performing Update and Displaying the System Version

8.7.1 Online Update

Choose **One-Device > Config > System > Update > Online Update**.

If there a new version available, you can click it for an update.

Caution

After being updated, the device will reboot. Therefore, exercise caution when performing this operation.

If no version update is detected or online update cannot be performed, check whether the bridge is connected to the Internet.

**Online Update**

Online update will keep the current configuration. Please do not refresh the page or close the browser. You will be redirected to the login page automatically after update.

Current Version AP_3.0(1)B11

8.7.2 Local Update

Choose **One-Device > Config > System > Update > Local Update**.

You can view the current software version, hardware version and device model. If you want to update the device with the configuration retained, check **Keep Config**. Click **Browse**, select an update package on the local PC, and click **Upload** to upload the file. The device will be updated.

Local Update
Please do not refresh the page or close the browser.

Model

Version


Keep Config (If the target version is much later than the current version, it is recommended not to keep the configuration.)

Update File


Caution

After being updated, the device will reboot. Therefore, exercise caution when performing this operation.

8.8 Switching System Language

Click  in the upper right corner of the page.

Select the target language from the drop-down list.



Note

Only Chinese and English are available.

8.9 Configuring SNMP

Specification

SNMP is supported on RG-EST350G and RG-EST450G only.

8.9.1 Overview

The Simple Network Management Protocol (SNMP) is a protocol for managing network devices. Based on the client/server model, it can achieve remote monitoring and control of network devices.

SNMP uses a manager and agent architecture. The manager communicates with agents through the SNMP protocol to retrieve information such as device status, configuration details, and performance data. It can also be used to configure and manage devices.

SNMP can be used to manage various network devices, including routers, switches, servers, firewalls, etc. You can achieve user management through the SNMP configuration interface and monitor and control devices through the third-party software.

8.9.2 Global Configuration

1. Overview

The purpose of global configuration is to enable the SNMP service and make the SNMP protocol version (v1/v2c/v3) take effect, so as to achieve basic configuration of local port, device location, and contact information.

SNMP v1: As the earliest version of SNMP, SNMP v1 has poor security, and only supports simple community string authentication. SNMP v1 has certain flaws, such as plaintext transmission of community strings and vulnerability to attacks. Therefore, SNMP v1 is not recommended for modern networks.


SNMP v2c: As an improved version of SNMP v1, SNMP v2c supports richer functions and more complex data types, with enhanced security. SNMP v2c performs better than SNMP v1 in terms of security and functionality, and is more flexible. It can be configured according to different needs.

SNMP v3: As the newest version, SNMP v3 supports security mechanisms such as message authentication and encryption compared to SNMP v1 and SNMP v2c. SNMP v3 has achieved significant improvements in security and access control.

2. Configuration Steps

Choose **Network-Wide > System > SNMP > Global Config**

(1) Enable the SNMP service.



When it is enabled for the first time, SNMP v3 is enabled by default. Click **OK**.

(2) Set SNMP service global configuration parameters.

[Global Config](#) [View/Group/Community/Client Access Control](#) [Trap Settings](#)

SNMP Service

* SNMP Version v1 v2c v3

* Local Port

* Device Location

* Contact Info

Save

Table 8-1 Global Configuration Parameters

Parameter	Description
SNMP Server	Indicates whether SNMP service is enabled.
SNMP Version	Indicates the SNMP protocol version, including v1, v2c, and v3 versions.
Local Port	The port range is 1 to 65535.
Device Location	1~64 characters. Chinese characters, full-width characters, question marks, and spaces are not allowed.
Contact Info	1~64 characters. Chinese characters, full-width characters, question marks, and spaces are not allowed.

(3) After the SNMP service is enabled, click **Save** to make basic configurations such as the SNMP protocol version number take effect.

8.9.3 View, Group, Community, User Access Control

1. Configuring Views

- Overview

Management Information Base (MIB) can be regarded as a database storing the status information and performance data of network devices. It contains a large number of object identifiers (OIDs) to identify the status information and performance data of these network devices.


Views in SNMP can limit the range of MIB nodes that the management system can access, thereby improving the security and reliability of network management. Views are an indispensable part of SNMP and need to be configured or customized according to specific management requirements.

A view can have multiple subtrees. The management system can only access MIB nodes in these subtrees, and cannot access other unauthorized MIB nodes. This can prevent unauthorized system administrators from accessing sensitive MIB nodes, thereby protecting the security of network devices. Moreover, views can also improve the efficiency of network management and speed up the response from the management system.

- Configuration Steps

Choose **Network-Wide > System > SNMP > View/Group/Community/Client Access Control**.

(1) Click **Add** under the **View List** to add a view.



(2) Configure basic information of a view.




Table 8-2 View Configuration Parameters

Parameter	Description
View Name	Indicates the name of the view. 1~32 characters. Chinese or full width characters are not allowed.
OID	Indicates the range of OIDs included in the view, which can be a single OID or a subtree of OIDs.

Parameter	Description
Type	<p>There are two types of rules: included and excluded rules.</p> <p>The included rule only allows access to OIDs within the OID range. Click Add Included Rule to set this type of view.</p> <p>Excluded rules allow access to all OIDs except those in the OID range. Click Add Excluded Rule to configure this type of view.</p>

Note

A least one OID rule must be configured for a view. Otherwise, an alarm message will appear.

(3) Click **OK**.

2. Configuring v1 and v2c Users

- Overview

When the SNMP version is set to v1/v2c, user configuration is required.

[Global Config](#) [View/Group/Community/Client Access Control](#) [Trap Settings](#)

SNMP Service

* SNMP Version v1 v2c v3

* Local Port

* Device Location

* Contact Info

Note

Select the SNMP protocol version, and click **Save**. The corresponding configuration options will appear on the **View/Group/Community/User Access Control** page.

- Configuration Steps

Choose **Network-Wide > System > SNMP > View/Group/Community/Client Access Control**.

(1) Click Add in the SNMP v1/v2c Community Name List pane.

(2) Add a v1/v2c user.

Table 8-3 v1/v2c User Configuration Parameters

Parameter	Description
Community Name	<ul style="list-style-type: none"> ● 8~32 characters. ● It must contain at least three character categories, including uppercase and lowercase letters, digits, and special characters. ● Admin, public or private community names are not allowed. ● Question marks, spaces, and Chinese characters are not allowed.
Access Mode	Indicates the access permission (read-only or read & write) for the community name.
MIB View	The options under the drop-down box are configured views (default: all, none).

Note

- Community names cannot be the same among v1/v2c users.
- Click **Add View** to add a view.

3. Configuring v3 Groups

- Overview

SNMP v3 introduces the concept of grouping to achieve better security and access control. A group is a group of SNMP users with the same security policies and access control settings. With SNMP v3, multiple groups can be configured, each with its own security policies and access control settings. Each group can have one or more users.

- Prerequisites

When the SNMP version is set to v3, the v3 group configuration is required.

[Global Config](#) [View/Group/Community/Client Access Control](#) [Trap Settings](#)

SNMP Service

* SNMP Version v1 v2c v3

* Local Port

* Device Location

* Contact Info

Save

Note

Select the SNMP protocol version, and click **Save**. The corresponding configuration options will appear on the **View/Group/Community/User Access Control** page.

- Configuration Steps

Choose **Network-Wide > System > SNMP > View/Group/Community/Client Access Control**.

(1) Click **Add** in the **SNMP v3 Group List** pane to create a group.

SNMP v3 Group List

Up to 20 entries are allowed.

<input type="checkbox"/>	Group Name	Security Level	Read-Only View	Read & Write View	Notification View	Action
<input type="checkbox"/>	default_group	Auth & Security	all	none	none	Edit Delete

(2) Configure v3 group parameters.

Add ✕

* Group Name

* Security Level

* Read-Only View [Add View +](#)

* Read & Write View [Add View +](#)

* Notification View [Add View +](#)

Table 8-4 v3 Group Configuration Parameters

Parameter	Description
Group Name	Indicates the name of the group. 1~32 characters. Chinese characters, full-width characters, question marks, and spaces are not allowed.
Security Level	Indicates the minimum security level (authentication and encryption, authentication but no encryption, no authentication and encryption) of the group.
Read-Only View	The options under the drop-down box are configured views (default: all, none).

Parameter	Description
Read & Write View	The options under the drop-down box are configured views (default: all, none).
Notify View	The options under the drop-down box are configured views (default: all, none).

Note

- A group defines the minimum security level, read and write permissions, and scope for users within the group.
- The group name must be unique. To add a view, click **Add View**.

(3) Click **OK**.

4. Configuring v3 Users

- Prerequisites

When the SNMP version is set to v3, the v3 group configuration is required.

[Global Config](#) [View/Group/Community/Client Access Control](#) [Trap Settings](#)

SNMP Service

* SNMP Version v1 v2c v3

* Local Port

* Device Location

* Contact Info

Save


Note

Select the SNMP protocol version, and click **Save**. The corresponding configuration options will appear on the **View/Group/Community/User Access Control** page.

- Configuration Steps

Choose **Network-Wide > System > SNMP > View/Group/Community/Client Access Control**.

(1) Click **Add** in the **SNMP v3 Client List** pane to add a v3 user.



(2) Configure v3 user parameters.




Table 8-5 v3 User Configuration Parameters

Parameter	Description
Username	Username <ul style="list-style-type: none"> ● 8~32 characters. ● It must contain at least three character categories, including uppercase and lowercase letters, digits, and special characters. ● Admin, public or private community names are not allowed. ● Question marks, spaces, and Chinese characters are not allowed.
Group Name	Indicates the group to which the user belongs.
Security Level	Indicates the security level (authentication and encryption, authentication but no encryption, and no authentication and encryption) of the user.

Parameter	Description
Auth Protocol, Auth Password	<p>Authentication protocols supported: MD5/SHA/SHA224/SHA256/SHA384/SHA512.</p> <p>Authentication password: 8~31 characters. Chinese characters, full-width characters, question marks, and spaces are not allowed. It must contain at least three character categories, including uppercase and lowercase letters, digits, and special characters.</p> <p>Note: This parameter is mandatory when the security level is authentication and encryption, or authentication but no encryption.</p>
Encryption Protocol, Encryption Password	<p>Encryption protocols supported: DES/AES/AES192/AES256.</p> <p>Encryption password: 8~31 characters. Chinese characters, full-width characters, question marks, and spaces are not allowed.</p> <p>It must contain at least three character categories, including uppercase and lowercase letters, digits, and special characters.</p> <p>Note: This parameter is mandatory when the security level is authentication and encryption.</p>

Note

- The security level of v3 users must be greater than or equal to that of the group.
- There are three security levels, among which authentication and encryption requires the configuration of authentication protocol, authentication password, encryption protocol, and encryption password. Authentication but no encryption only requires the configuration of authentication protocol and encryption protocol, while no authentication and encryption does not require any configuration.

8.9.4 SNMP Service Typical Configuration Examples

1. Configuring SNMP v2c

- Application Scenario

You only need to monitor the device information, but do not need to set and deliver it. A third-party software can be used to monitor the data of nodes like 1.3.6.1.2.1.1 if v2c version is configured.

- Configuration Specification

According to the user's application scenario, the requirements are shown in the following table:

Table 8-6 User Requirement Specification

Item	Description
View range	Included rule: the OID is .1.3.6.1.2.1.1, and the custom view name is "system".
Version	For SNMP v2c, the custom community name is "public", and the default port number is 161.

Item	Description
Read & write permission	Read-only permission.

- Configuration Steps

(2) In the global configuration interface, select v2c and set other settings as default. Then, click **Save**.

[Global Config](#) [View/Group/Community/Client Access Control](#) [Trap Settings](#)

SNMP Service

* SNMP Version v1 v2c v3

* Local Port

161

* Device Location

Company

* Contact Info

Ruijie@Ruijie.com

Save

(3) Add a view on the View/Group/Community/Client Access Control interface.

- Click **Add** in the **View List** pane to add a view.
- Enter the view name and OID in the pop-up window, and click **Add Included Rule**.
- Click **OK**.

Add ×

* View Name

OID

Rule/OID List

Up to **100** entries are allowed.

<input type="checkbox"/>	Rule	OID	Action
<input type="checkbox"/>	Included	.1.3.6.1.2.1.1	Delete

Total 1 Go to page

- (4) On the View/Group/Community/Client Access Control interface, enter the SNMP v1/v2c community name.
 - a Click **Add** in the **SNMP v1/v2c Community Name List** pane.
 - b Enter the group name, access mode, and view in the pop-up window.
 - c Click **OK**.

Add ×

* Community Name

* Access Mode

* MIB View [Add View +](#)

2. Configuring SNMP v3

- Application Scenario

You need to monitor and control devices, and use the third-party software to monitor and deliver device information to public nodes (1.3.6.1.2.1). The security level of v3 is authentication and encryption.

- Configuration Specification

According to the user's application scenario, the requirements are shown in the following table:

Table 8-7 User Requirement Specification

Item	Description
View range	Included rule: the OID is .1.3.6.1.2.1, and the custom view name is "public_view".
Group configuration	Group name: group Security level: authentication and encryption Select public_view for a read-only view. Select public_view for a read & write view. Select none for a notify view.
Configuring v3 Users	User name: v3_user Group name: group Security level: authentication and encryption Authentication protocol/password: MD5/Ruijie123 Encryption protocol/password: AES/Ruijie123
Version	For SNMP v3, the default port number is 161.

- Configuration Steps

(2) On the global configuration interface, select v3, and change the port number to 161. Set other settings to defaults. Then, click **Save**.

SNMP Service

* SNMP Version v1 v2c v3

* Local Port

* Device Location

* Contact Info

Save

- (3) Add a view on the View/Group/Community/Client Access Control interface.
 - a Click **Add** in the **View List** pane.
 - b Enter the view name and OID in the pop-up window, and click **Add Included Rule**.
 - c Click **OK**.

Add

×

* View Name

OID

Add Included Rule

Add Excluded Rule

Rule/OID List

Delete Selected

Up to 100 entries are allowed.

<input type="checkbox"/>	Rule	OID	Action
<input type="checkbox"/>	Included	.1.3.2.6.1.2.1	Delete

Total 1 Go to page

Cancel OK

- (4) On the View/Group/Community/Client Access Control interface, add an SNMP v3 group.
 - a Click **Add** in the **SNMP v3 Group List** pane.
 - b Enter the group name and security level on the pop-up window. As this user has read and write permissions, select public_view for read-only and read & write views, and select none for notify views.
 - c Click **OK**.

Add
×

* Group Name

* Security Level

* Read-Only View [Add View +](#)

* Read & Write View [Add View +](#)

* Notification View [Add View +](#)

- (5) On the View/Group/Community/Client Access Control interface, add an SNMP v3 user.
 - a Click **Add** in the **SNMP v3 Client List** pane.
 - b Enter the user name and group name in the pop-up window. As the user's security level is authentication and encryption, enter the authentication protocol, authentication password, encryption protocol, and encryption password.
 - c Click **OK**.

Add
×

* Username

* Group Name

* Security Level

* Auth Protocol * Auth Password

* Encryption Protocol * Encrypted Password

8.9.5 Configuring Trap Service


Trap is a notification mechanism of the Simple Network Management Protocol (SNMP) protocol. It is used to report the status and events of network devices to administrators, including device status, faults, performance, configuration, and security management. Trap provides real-time network monitoring and fault diagnosis services, helping administrators discover and solve network problems in a timely manner.

1. Enabling Trap Service

Enable the trap service and select the effective trap version, including v1, v2c, and v3 versions.

Choose **Network-Wide > System > SNMP > Trap Setting**.

(1) Enable the trap service.



When the trap service is enabled for the first time, the system will pop up a prompt message. Click **OK**.

Global Config View/Group/Community/Client Access Control **Trap Settings**

Trap Service

* Trap Version v1 v2c v3

Save

(2) Set the trap version.

The trap versions include v1, v2c, and v3.

(3) Click **OK**.

After the trap service is enabled, click **Save** for the configuration to take effect.

2. Configuring Trap v1 and v2c Users

- Overview

Trap is a notification mechanism that is used to send alerts to administrators when important events or failures occur on devices or services. Trap v1/v2c are two versions in the SNMP protocol for network management and monitoring.

Trap v1 is the first version that supports basic alert notification functionality. Trap v2c is the second version, which supports more alert notification options and advanced security features.

By using trap v1/v2c, administrators can promptly understand problems on the network and take corresponding measures.


- Prerequisites

Once trap v1 and v2c versions are selected, it is necessary to add trap v1/v2c users.

- Procedure

Choose **Network-Wide > System > SNMP > Trap Setting**.

(1) Click **Add** in the **Trap v1/v2c Client List** pane to add a trap v1/v2c user.



(2) Configure trap v1/v2c user parameters.

Add ×

* Dest Host IP

* Version Number

* Port ID

* Community
Name/Username

Table 8-8 Trap v1/v2c User Configuration Parameters

Parameter	Description
Dest Host IP	IP address of the trap peer device. An IPv4 or IPv6 address is supported.
Version Number	Trap version, including v1 and v2c.
Port ID	The port range of the trap peer device is 1 to 65535.
Community name/User name	Community name of the trap user. <ul style="list-style-type: none"> ● 8~32 characters. ● It must contain at least three character categories, including uppercase and lowercase letters, digits, and special characters. ● Admin, public or private community names are not allowed. ● Question marks, spaces, and Chinese characters are not allowed.

 **Note**

- The destination host IP address of trap v1/ v1/v2c users cannot be the same.
- Community names of trap v1/ v1/v2c users cannot be the same.

(3) Click **OK**.

3. Configuring Trap v3 Users

- Overview

Trap v3 is a network management mechanism based on the SNMP protocol. It is used to send alert notifications to administrators. Unlike previous versions, trap v3 provides more secure and flexible configuration options, including authentication and encryption features.

Trap v3 offers custom conditions and methods for sending alerts, as well as the recipients and notification methods for receiving alerts. This enables administrators to have a more accurate understanding of the status of network devices and to take timely measures to ensure the security and reliability of the network.

- Prerequisites

When the v3 version is selected for the trap service, it is necessary to add a trap v3 user.

- Configuration Steps

Choose **Network-Wide > System > SNMP > Trap Setting**.

(1) Click **Add** in the **Trap v3 Client List** pane to add a trap v3 user.

Global Config View/Group/Community/Client Access Control **Trap Settings**

Trap Service

* Trap Version v1 v2c v3

Save

Trap v3 Client List + Add Delete Selected

Up to 20 entries are allowed.

<input type="checkbox"/>	Dest Host IP	Port ID	Username	Security Level	Auth Password	Encrypted Password	Action
No Data							

(2) Configure trap v3 user parameters.

Add ×

* Dest Host IP <input type="text" value="Support IPv4/IPv6"/>	* Port ID <input type="text"/>
* Username <input type="text"/>	* Security Level <input type="text" value="Auth & Security"/>
* Auth Protocol <input type="text" value="MD5"/>	* Auth Password <input type="text"/>
* Encryption Protocol <input type="text" value="AES"/>	* Encrypted Password <input type="text"/>

Table 8-9 Trap v3 User Configuration Parameters

Parameter	Description
Dest Host IP	IP address of the trap peer device. An IPv4 or IPv6 address is supported.
Port ID	The port range of the trap peer device is 1 to 65535.
Username	Name of the trap v3 user. <ul style="list-style-type: none"> ● 8~32 characters. ● It must contain at least three character categories, including uppercase and lowercase letters, digits, and special characters. ● Admin, public or private community names are not allowed. ● Question marks, spaces, and Chinese characters are not allowed.
Security Level	Indicates the security level of the trap v3 user. The security levels include authentication and encryption, authentication but no encryption, and no authentication and encryption.

Parameter	Description
Auth Protocol, Auth Password	<p>Authentication protocols supported: MD5/SHA/SHA224/SHA256/SHA384/SHA512.</p> <p>Authentication password: 8~31 characters. Chinese characters, full-width characters, question marks, and spaces are not allowed. It must contain at least three character categories, including uppercase and lowercase letters, digits, and special characters.</p> <p>Note: This parameter is mandatory when the security level is authentication and encryption, or authentication but no encryption.</p>
Encryption Protocol, Encryption Password	<p>Encryption protocols supported: DES/AES/AES192/AES256.</p> <p>Encryption password: 8~31 characters. Chinese characters, full-width characters, question marks, and spaces are not allowed.</p> <p>It must contain at least three character categories, including uppercase and lowercase letters, digits, and special characters.</p> <p>Note: This parameter is mandatory when the security level is authentication and encryption.</p>

Note

The destination host IP address of trap v1/ v1/v2c users cannot be the same.

8.9.6 Trap Service Typical Configuration Examples

1. Configuring Trap v2c

- Application Scenarios

During device monitoring, if the device is suddenly disconnected or encounters an abnormality, and the third-party monitoring software cannot detect and handle the abnormal situation in a timely manner, you can configure the device with a destination IP address of 192.168.110.85 and a port number of 166 to enable the device to send a v2c trap in case of an abnormality.

- Configuration Specification


According to the user's application scenario, the requirements are shown in the following table:

Table 8-10 User Requirement Specification

Item	Description
IP address and port number	The destination host IP is 192.168.110.85, and the port number is 166.
Version	Select the v2 version.
Community name/User name	Trap_user

- Configuration Steps

(2) Select the v2c version in the **Trap Setting** interface and click **Save**.



(3) Click **Add** in the Trap v1/v2c Client List to add a trap v2c user.

(4) Enter the destination host IP address, version, port number, user name, and other information. Then, click **OK**.

Add ×

* Dest Host IP

* Version Number

* Port ID

* Community

Name/Username

2. Configuring Trap v3

- Application Scenarios

During device monitoring, if the device is suddenly disconnected or encounters an abnormality, and the third-party monitoring software cannot detect and handle the abnormal situation in a timely manner, you can configure the device with a destination IP address of 192.168.110.87 and a port number of 167 to enable the device to send a v3 trap, which is a safer trap compared with v1/v2c traps.

- Configuration Specification

According to the user's application scenario, the requirements are shown in the following table:

Table 8-11 User Requirement Specification

Item	Description
IP address and port number	The destination host IP is 192.168.110.87, and the port number is 167.
Version and user name	Select the v3 version and trapv3_user for the user name.
Authentication protocol/authentication password	Authentication protocol/password: MD5/Ruijie123
Encryption protocol/encryption password	Encryption protocol/password: AES/Ruijie123

● Configuration Steps

(2) Select the v3 version in the **Trap Setting** interface and click **Save**.

Global Config View/Group/Community/Client Access Control Trap Settings

Trap Service

* Trap Version v1 v2c v3

Save

Trap v3 Client List + Add Delete Selected

Up to 20 entries are allowed.

<input type="checkbox"/>	Dest Host IP	Port ID	Username	Security Level	Auth Password	Encrypted Password	Action
No Data							

Total 0 < 1 > Go to page

(3) Click **Add** in the Trap v3 Client List to add a trap v3 user.

(4) Enter the destination host IP address, port number, user name, and other information. Then, click **OK**.

Add ×

* Dest Host IP * Port ID

* Username * Security Level

* Auth Protocol * Auth Password

* Encryption Protocol * Encrypted Password

