


Solar inverter

USER GUIDE

Solar Inverter

IVEM Series(8KVA~12KVA)



Contents

ABOUT THIS MANUAL	01
Purpose	01
Scope	01
Safety instructions.....	01
WARNING MARKS	02
INTRODUCTION	03
Features	03
Basic system architecture	03
PRODUCT OVERVIEW	04
SPECIFICATIONS	05
INSTALLATION	08
Safety guidance.....	08
Unpacking and inspection	08
Preparation	09
Mounting the unit	09
Battery connection	10
AC input /output connection	11
PV connection	14
Components for PV connectors and Tools.....	15
Final assembly.....	16
Dry contact signal.....	17
Inverter and computer connection	17
Wiring System for Inverter	18
OPERATION	19
Power ON/OFF	19
Operation and display panel.....	19
LCD display icons.....	20
LCD operation flow chart	22
Base information Page	23
Setting Page	25
Energy stored data Page.....	31
BMS information Page	32
Rated information Page	33
Generator Port Use Setup Page	34
Lithium Battery Communication.....	35
PARALLEL INSTALLATION GUIDE	37
Introduction	37
Mounting the Unit	37
LCD Setting and Display	40
Commissioning	40
WARNING CODE TABLE	42
FAULT CODE TABLE	42
The Wi-Fi operation Guide in APP	46
Introduction.....	46
Download and install APP.....	46

ABOUT THIS MANUAL

Purpose

This manual describes the assembly, installation, operation, warning code and fault code of this unit. Please read this manual carefully before installations and operations. Keep this manual for future reference.

Scope

This manual provides safety and installation guidelines as well as information on tools and wiring.

Safety instructions











WARNING: This chapter contains important safety and operating instructions. Read and keep this manual for future reference.

- Before using the unit, read all instructions and cautionary markings on the unit, the batteries and all appropriate sections of this manual.
- CAUTION** --To reduce risk of injury, charge only deep-cycle lead acid type rechargeable batteries. Other types of batteries may burst, causing personal injury and damage.
- Do not disassemble the unit. Take it to a qualified service center when service or repair is required. Incorrect re-assembly may result in a risk of electric shock or fire.
- To reduce risk of electric shock, disconnect all wirings before attempting any maintenance or cleaning. Turning off the unit will not reduce this risk.
- CAUTION** – Only qualified personnel can install this device with battery.
- NEVER** charge a frozen battery.
- For optimum operation of this inverter/charger, please follow required spec to select appropriate cable size. It's very important to correctly operate this inverter/charger.
- Be very cautious when working with metal tools on or around batteries. A potential risk exists to drop a tool to spark or short circuit batteries or other electrical parts and could cause an explosion.
- Please strictly follow installation procedure when you want to disconnect AC or DC terminals. Please refer to INSTALLATION section of this manual for the details.
- Fuse is provided as over-current protection for the battery supply.
- GROUNDING INSTRUCTIONS** -This inverter/charger should be connected to a permanent grounded wiring system. Be sure to comply with local requirements and regulation to install this inverter.
- NEVER** cause AC output and DC input short circuited. Do NOT connect to the mains when DC input short circuits.
- Warning!!** Only qualified service persons are able to service this device. If errors still persist after following troubleshooting table, please send this inverter/charger back to local dealer or service center for maintenance.

WARNING MARKS

Warning marks inform users of conditions which can cause serious physical injury or death, or damage to the device. They also tell users how to prevent the dangers. The warning marks used in this operation manual are shown below:

Mark	Name	Instruction	Abbreviation
 Danger	Danger	Serious physical injury or even death may occur if not follow relevant requirements.	
 Warning	Warning	Physical injury or damage to the device may occur if not follow relevant requirements.	
 Forbid	Electrostatic sensitive	Damage may occur if relevant requirements are not followed.	
 Hot	High temperature	Do not touch the base of the inverter as it will become hot.	
Note	Note	The procedures taken for ensuring proper operation.	Note

INTRODUCTION

This is a multi-function inverter/charger, combining functions of inverter, MPPT solar charge and battery charger to offer uninterruptible power support with portable size. Its comprehensive LCD display offers user-configurable and easy-accessible button operation such as battery charging current, AC/solar charger priority, and acceptable input voltage based on different applications.

Features

- Pure sine wave inverter
- Built-in MPPT solar charge controller (Supports 2 strings of solar input)
- Built-in Wi-Fi for mobile monitoring (APP is required)
- Configurable input voltage range for home appliances and personal computers via LCD setting
- Configurable battery charging current based on applications via LCD setting
- Configurable AC/Solar Charger priority via LCD setting
- Compatible to mains voltage or generator power
- The generator input port can be changed to a smart output port
- Control smart output port can customize output duration
- Auto restart while AC is recovering
- Overload / Over temperature/ short circuit protection
- Inverter running without battery
- Lithium battery activation function
- Cold start function
- Parallel connection quantity up to 6units(Battery must be connected).


Basic System Architecture

The following illustration shows basic application for this inverter/charger. It also includes following devices to have a complete running system:



- Generator or Utility.
- PV modules (option)

Consult with your system integrator for other possible system architectures depending on your requirements.


This inverter can power all kinds of appliances in home or office environment, including motor-type appliances such as tube light, fan, refrigerator and air conditioner.



PRODUCT OVERVIEW



IVEM8048II



IVEM12048II

- 1. LCD display
- 2. Charging indicator
- 3. Utility bypass indicator
- 4. Inverter indicator
- 5. Fault or warning indicator
- 6. Esc button
- 7. Up button
- 8. Down button
- 9. Enter button
- 10. AC input breaker
- 11. Switch
- 12. PE
- 13. AC input port
- 14. AC output port
- 15. Parallel communication port
- 16. WIFI antenna
- 17. PV input connection port
- 18. Current sharing port
- 19. RS-232 communication port
- 20. CAN communication port
- 21. RS-485 communication port
- 22. Dry contact
- 23. Battery connection port
- 24. Air outlet

* 20 The BMS communication port only supports Felicitysolar batteries

SPECIFICATIONS

Line Mode Specifications		
Model	IVEM8048 II	IVEM12048 II
Rated Output Power	8000VA	12000VA
	8000W	12000W
Nominal DC Input Voltage	48V	
Input Voltage Waveform	Sinusoidal (utility or generator)	
Nominal Input Voltage	230Vac	
Low Line Voltage Disconnect	170Vac±7V (UPS); 90Vac±7V (Appliances)	
Low Loss Voltage Re-connect	180Vac±7V (UPS); 100Vac±7V (Appliances)	
High Line Voltage Disconnect	280Vac±7V	
High Line Voltage Re-connect	270Vac±7V	
Max AC Input Voltage	280Vac	
Nominal Input Frequency	50Hz / 60Hz (Auto detection)	
Low Line Frequency Disconnect	40±1Hz	
Low Line Frequency Re-connect	42±1Hz	
High Line Frequency Disconnect	65±1Hz	
High Line Frequency Re-connect	63±1Hz	
Output Voltage Waveform	As same as input waveform	
Output Short Circuit Protection	Line mode: Circuit Breaker Battery mode: Electronic Circuits	
Efficiency (Line Mode)	>95% (Rated R load, battery full charged)	
Transfer Time (Single unit)	10ms typical (UPS); 20ms typical (Appliances)	
Transfer Time (Parallel)	50ms typical	
Pass Through Without Battery	Yes	
Output power derating	When AC input voltage drops to 180V, the output power will be de-rated.	
	When DC input voltage drops to 55V, the output power will be de-rated.	no derating
Max. Bypass Overload Current	53A	78A

Max. Inverter/Rectifier Current	40A/8000W	60A/12000W
Max. Smart Load Output Current	40A	60A
Utility Charging Mode Specifications /Generator Charging Mode Specifications		
Nominal Input Voltage	230Vac	
Input Voltage Range	90-280Vac	
Nominal Output Voltage	Dependent on battery type	
Max. Charge Current	150A	240A
Charge Current Regulation	10-150A (Adjustable unit is 1A)	10-240A (Adjustable unit is 1A)
Over Charge Protection	Yes	
Solar Charging & Grid Charging or GEN Charging		
Max. PV Open Circuit Voltage	500V	
PV Voltage Working Range	90V-450V	
Max. Input Power	10000W(5000W for single PV)	15000W(7500W for single PV)
Max. Solar Charging Current	150A	240A
Max. Charging Current(PV+Grid or GEN)	150A	240A
Max. Input Current	20A×2(MAX 40A)	27A×2(MAX 54A)
Min. Startup Voltage	100V	









Charge Algorithm			
Algorithm	Three stage: Boost CC (Constant current stage) -> Boost CV (Constant voltage stage) -> Float (Constant voltage stage)		
Charging Curve			
Battery Type Setting	Battery Type	Boost CC/CV	Float
	AGM	56.4V	54V
	Flooded	58.4V	54V
	Self - defined	Adjustable, up to 60V	
	Lithium		

Inverter Mode Specifications		
Model	IVEM8048 II	IVEM12048 II
Rated Output Power	8000VA	12000VA
	8000W	12000W
Nominal DC Input Voltage	48V	
Output Voltage Waveform	Pure sine wave	
Nominal Output Voltage	230Vac±5%	
Nominal Output Frequency (Hz)	50±0.3Hz/60Hz±0.3Hz (Adjustable)	
Parallel capability	Yes, up to 6 units	
Peak Efficiency	94.5%	
Over-Load Protection (SMPS load)	5s@ ≥150% load; 10s@105%~150%load	
Surge Rating	2* rated power for 5s	
Capable of Starting Electric	Yes	
Output Short Circuit Protection	Yes	
Cold Start Voltage	46V	
Low Battery Alarm Load < 50%	45.0V	
	@Load ≥ 50% 44.0V	
Low Battery Alarm Recovery Load < 50%	47.0V	
	@Load ≥ 50% 46.0V	
Low DC Input Shut-down Load < 50%	43.0V	
	@Load ≥ 50% 42.0V	
High DC Input Alarm & Fault	62V±0.4V	
High DC Input Recovery	56.4V±0.4V	
General Specifications		
Operating Temperature	-10C°~50C°	
Range Storage Temperature	-15C°~60C°	
Net Weight (Kg)	23.7KG	26.8Kg
Product Size (D*W*H)	607×464×141MM	634×476×141MM
Package Dimension (D*W*H)	712×582×259MM	726×594×258MM

INSTALLATION



Safety Guidance

Warning marks inform users of conditions which can cause serious physical injury or death, or damage to the device. They also tell users how to prevent the dangers. The warning marks used in this operation manual are shown below:

	<ul style="list-style-type: none"> After receiving this product, first confirm the product package is intact. If any question, contact the logistic company or local distributor immediately. The installation and operation of inverter must be carried out by professional technicians who have received professional trainings and thoroughly familiar with all the contents in this manual and the safety requirements of the electrical system.
	<ul style="list-style-type: none"> Do not carry out connection/disconnection, unpacking inspection and unit replacement operations on the inverter when power source is applied. Before wiring and inspection, users must confirm the breakers on DC and AC side of inverter are disconnected and wait for at least 5 minutes.
	<ul style="list-style-type: none"> Ensure there is no strong electromagnetic interference caused by other electronic or electrical devices around the installation site. Do not refit the inverter unless authorized. All the electrical installation must conform to local and national electrical standards
	<ul style="list-style-type: none"> Do not touch the housing of the inverter or the radiator to avoid scald as they may become hot during operation.
	<ul style="list-style-type: none"> Ground with proper technics before operation.
	<ul style="list-style-type: none"> Do not open the surface cover of the inverter unless authorized. The electronic components inside the inverter are electrostatic sensitive. Do take proper anti-electrostatic measures during authorized operation.
	<ul style="list-style-type: none"> The inverter needs to be reliably grounded.
	<ul style="list-style-type: none"> Ensure that DC and AC side circuit breakers have been disconnected and wait at least 5 minutes before wiring and checking.


Unpacking and Inspection

Before installation, please inspect the unit. Be sure that nothing inside the package is damaged. You should have received the following items inside of package:



Preparation


Before connecting all wirings, please take off bottom cover by removing five screws as shown below.



Mounting the Unit


Consider the following points before selecting where to install:

- Do not mount the inverter on flammable construction materials.
- Mount on a solid surface
- Install this inverter at eye level in order to allow the LCD display to be read at all times.
- The ambient temperature should be between -10°C and 55°C to ensure optimal operation.
- The recommended installation position is to be adhered to the wall vertically.
- Be sure to keep other objects and surfaces as shown in the right diagram to guarantee sufficient heat dissipation and to have enough space for removing wires.



SUITABLE FOR MOUNTING ON CONCRETE OR OTHER NON-COMBUSTIBLE SURFACE ONLY.

Install the unit by screwing two screws. It's recommended to use M4 or M5 screws.



Battery Connection

CAUTION: For safety operation and regulation compliance, it's requested to install a separate DC over-current protector or disconnect device between battery and inverter. It may not be requested to have a disconnect device in some applications, however, it's still requested to have over-current protection installed. Please refer to typical amperage in below table as required fuse or breaker size.

WARNING! All wiring must be performed by a qualified personnel.


WARNING! It's very important for system safety and efficient operation to use appropriate cable for battery connection. To reduce risk of injury, please use the proper recommended cable and terminal size as below.

Recommended battery cable and terminal size:

Model	Wire Size	Cable (mm ²)	Torque Value(Max)
8KVA	1*1AWG	50	12.5Nm
12KVA	1*4/0AWG	95	12.5Nm

Please follow below steps to implement battery connection:

1. Assemble battery ring terminal based on recommended battery cable and terminal size.
2. Connect all battery packs as units requires. It's suggested to connect at least 200Ah capacity battery.
3. insert the ring terminal of battery cable flatly into battery connector of inverter and make sure the bolts are tightened with torque of 12.5 Nm. Make sure polarity at both the battery and the inverter/charge is correctly connected and ring terminals are tightly screwed to the battery terminals.



WARNING: Shock Hazard
Installation must be performed with care due to high battery voltage in series.

CAUTION!! Do not place anything between the flat part of the inverter terminal and the ring terminal. Otherwise, overheating may occur.
CAUTION!! Do not apply anti-oxidant substance on the terminals before terminals are connected tightly.
CAUTION!! Before making the final DC connection or closing DC breaker/disconnector, be sure positive (+) must be connected to positive (+) and negative (-) must be connected to negative (-).

AC Input/Output Connection

CAUTION!! Before connecting to AC input power source, please install a separate AC breaker between inverter and AC input power source. This will ensure the inverter can be securely disconnected during maintenance and fully protected from over current of AC input, The recommended spec of AC breaker is 63A for 8KVA model and 100A for 12KVA model.

CAUTION!! There are two terminal blocks with "IN" and "OUT" markings. Please do NOT mis-connect input and output connectors.

WARNING! All wiring must be performed by qualified personnel.

WARNING! It's very important for system safety and efficient operation to use appropriate cable for AC input connection. To reduce risk of injury, please use the proper recommended cable size as below.

Suggested cable requirement for AC wires

Model	Gauge	Cable (mm ²)	Torque Value
8KVA	8 AWG	10	1.4~ 1.6Nm
12KVA	6AWG	16	1.8~2.0Nm

Please follow below steps to implement AC input/output connection:




1. Before making AC input/output connection, be sure to open DC protector or disconnector first.
2. Remove insulation sleeve 10mm for six conductors. And shorten phase L and neutral conductor N 3 mm.

3. Insert AC input wires according to polarities indicated on terminal block and tighten the terminal screws. Be sure to connect PE protective conductor (⊕) first.

⊕ → **Ground (yellow-green)**

GRID-L → **LINE (brown or black)**

GRID-N → **Neutral (blue)**



WARNING: Be sure that AC power source is disconnected before attempting to hardwire it to the unit.



4. Generator interface operation
The generator interface has two multiplexing modes: generator input and smart load output. The default is input mode. If you want to switch to output mode, refer to the "LCD Settings" section for details
Insert AC output / AC input wires according to polarities indicated on terminal block and tighten terminal screws.

Be sure to connect PE protective conductor (⊕) first.

⊕ → **Ground (yellow-green)**

GEN-L → **LINE (brown or black)**

GEN-N → **Neutral (blue)**






5. Insert AC output wires according to polarities indicated on terminal block and tighten terminal screws.

Be sure to connect PE protective conductor (⊕) first.

⊕ → **Ground (yellow-green)**

Output-L → **LINE (brown or black)**

Output-N → **Neutral (blue)**



6. Make sure the wires are securely connected.

CAUTION: Important

Be sure to connect AC wires with correct polarity. If L and N wires are connected reversely, it may cause utility short-circuited when these inverters are worked in parallel operation.

CAUTION: Appliances such as air conditioner are required at least 2~3 minutes to restart because it's required to have enough time to balance refrigerant gas inside of circuits. If a power shortage occurs and recovers in a short time, it will cause damage to your connected appliances. To prevent this kind of damage, please check manufacturer of air conditioner if it's equipped with time-delay function before installation. Otherwise, this inverter/charger will trig overload fault and cut off output to protect your appliance but sometimes it still causes internal damage to the air conditioner.

PV Connection



CAUTION: Before connecting to PV modules, please install separately a 600VDC/30A circuit breaker between inverter and PV modules.

WARNING! All wiring must be performed by qualified personnel.

WARNING! It's very important for system safety and efficient operation to use appropriate cable for PV module connection. To reduce risk of injury, please use the proper recommended cable size as below.

Model	Cable Size	Cable (mm ²)	Torque
8KVA/12KVA	10~12AWG	4~6	1.4~1.6 Nm

WARNING: Because this inverter is non-isolated, are accepted: single crystalline, poly crystalline with class A-rated and CIGS modules. To avoid any malfunctions, do not connect any PV modules with possible current leakage to the inverter. For example, grounded PV modules will cause current leakage to the inverter. When using CIGS modules, please be sure NO grounding connection.

CAUTION: It's requested to use PV junction box with surge protection. Otherwise, it will cause damage on inverter when lightning occurs on PV modules.

PV Module Selection:

When selecting proper PV modules, please be sure to consider below parameters:

1. Open circuit Voltage (Voc) of PV modules not exceeds max. PV array open circuit voltage of inverter.
2. Max. power voltage (Vmp) should be during PV array MPPT voltage range.

Solar Charging Mode	
INVERTER MODEL	8KVA/12KVA
Max. PV Array Open Circuit Voltage	500V
PV Array MPPT Voltage Range	100Vdc~450Vdc

Please follow below steps to implement PV module connection:

Step 1: Check the input voltage of PV array modules. This system is applied with two strings of PV array.

CAUTION: Exceeding the maximum input voltage can destroy the unit!! Check the system before wire connection.

Step 2: Disconnect the circuit breaker and switch off the DC switch.


Step 3: Assemble provided PV connectors with PV modules by the following steps.

Components for PV connectors and Tools:

Female connector housing and female terminal	
Male connector housing and male terminal	
Crimping tool and spanner	

Prepare the cable and follow the connector assembly process:

1. Strip cable 8 mm on the end sides and be careful NOT to nick conductors.



2. Insert striped cable into female terminal and crimp female terminal as shown below.




3. Insert assembled cable into female connector housing as shown below.



4. Insert striped cable into male terminal and crimp male terminal as shown below.




5. Insert assembled cable into male connector housing as shown below




Step 4: Check correct polarity of connection cable from PV modules and PV input connectors. Then, connect positive pole (+) of connection cable to positive pole (+) of PV input connector. Connect negative pole (-) of connection cable to negative pole (-) of PV input connector.

IVEM8048II:




IVEM12048II:



Step 5: Make sure the wires are securely connected.

Final Assembly

After connecting all wirings, please put bottom cover back by screwing five screws as shown below.




Dry Contact Signal

There is one dry contact (3A/250VAC) available on the inverter.

Unit Status	Condition	Dry contact port:	
		NC & C	NO & C
Power Off	Unit is off and no output is powered.	Close	Open
Power On	Battery voltage < Setting value in Program 12	Open	Close
	Battery voltage > Setting value in Program 13 or battery charging reaches floating stage	Close	Open

Inverter and computer connection




Pin Assignment for RS232 Communication Port

	PIN 1	PIN 2	PIN 3	PIN 4	PIN 5	PIN 6	PIN 7	PIN 8	
RS232	RS232TX	RS232RX	+12V	GND	NC	NC	NC	GND	

*Users need to purchase their own RS232 conversion USB interface cable to connect the computer
 *If you need to update the firmware library, please contact after-sales personnel

Wiring System for Inverter



NOTE 1: Before starting up inverters, please connect all N wires of AC output together
NOTE 2: Do not connect the AC input Neutral (N) wire to the AC output Neutral (N) wire

OPERATION
Power ON/OFF



Once the unit has been properly installed and the batteries are connected well, simply press On/Off switch (located on the bottom of the case) to turn on the unit.

Operation and Display Panel


The operation and display panel, shown in below chart, is on the front panel of the inverter. It includes three indicators, four function keys and a LCD display, indicating the operating status and input/output power information.



Function Key	Icon	Description
ESC		To previous page
UP		To go to previous selection
DOWN		To go to next selection
ENTER		To confirm the selection or go to next page

LED Indicator	Icon	Color	State	Description
Battery		Green	Solid	The battery is full.
			Flashing	The battery is charging.
			Dim	The battery is not charged.
Utility		Green	Solid	Inverter is running in utility mode.
			Dim	Inverter is not running in utility mode.
Inverter		Green	Solid	Inverter is running in off-grid mode.
			Dim	Inverter is not running in off-grid mode.
Fault		Red	Solid	Inverter works in fault event.
			Flashing	Inverter works in warning event.
			Dim	Inverter works normally.
Buzzer Information				
Buzzer beep	Turn on/off the inverter, the buzzer will last for 2.5s. Press any button, the buzzer will last for 0.1s. Hold on the "ENTER" button, the buzzer will last for 3s. If in fault event, the buzzer will keep going. If in warning event, the buzzer will beep discontinuous (Check more information on the chapter of "Warning Code Table").			


LCD Display Icons



Icon	Function description
Input Source Information	
	Indicate input voltage, input frequency, PV voltage, PV power, battery voltage and charger current, GEN port.
Configuration Program and Fault Information	
	Indicates the setting programs.
	Indicates the warning and fault codes.
	Warning: flashing with warning code.
	Fault: lighting with fault code

Output Information	
	Indicate output voltage, output frequency, load percent, load in VA, load in Watt and discharging current.
Battery Information	
	Indicates battery level by 0-24%, 25-49%, 50-74% and 75-100%.
	Indicates Lithium battery type.
	Indicates communication is built between inverter and battery.
Mode Operation Information	
	Indicates the utility.
BYPASS	Indicates load is supplied by utility directly.
	Indicates the inverter/charger is working.
	Indicates the PV panels.
	Indicates PV MPPT is working.
	Indicates the WIFI link
	Indicates the AC output
	Indicates the smart load output
	Indicates the generator input
PV1 PV2	Which PV is lit indicates that it is working
Mute Operation	
	Indicates unit alarm is disabled.

LCD operation flow chart














On base information page, pressing and holding "ENTER" key for 3 sec, the unit will enter parameters page. Press "UP" or "DOWN" key to switch the selection and press "ENTER" key to enter selected page. Press "ESC" key to back to previous page.

Base information Page

The base information will be switched by pressing "UP" or "DOWN" key. The selectable information is switched as below order:

<p>Input voltage / Output voltage Utility voltage is 230V, output voltage is 230V</p>	<p>Input frequency / Output voltage Utility frequency is 50.0Hz, output voltage is 230V</p>
<p>Battery voltage / Output voltage Battery voltage is 50.0V, output voltage is 230V</p>	<p>Charging current / Output voltage Charging current is 10A, output voltage is 230V</p>
<p>PV1 voltage PV1 voltage is 360V</p>	<p>PV1 power PV1 power is 3.00kW</p>
<p>PV2 voltage PV2 voltage is 360V</p>	<p>PV2 power PV2 power is 3.00kW</p>





<p>Battery voltage / Output frequency Battery voltage is 50.0V, output frequency is 50.0Hz</p>  <p>IVEM8048-II 8KW IVEM12048-II 12KW</p>	<p>Battery voltage / Load percentage Battery voltage is 50.0V, load percentage is 40%</p>  <p>IVEM8048-II 8KW IVEM12048-II 12KW</p>
<p>Battery voltage / Load VA 1. Battery voltage is 50.0V, output wattage is 2.00kVA</p>  <p>IVEM8048-II 8KW IVEM12048-II 12KW</p>	<p>Battery voltage / Load wattage Battery voltage is 50.0V output wattage is 2.00kW</p>  <p>IVEM8048-II 8KW IVEM12048-II 12KW</p>
<p>Battery voltage / Discharging current Battery voltage is 50.0V, discharging current is 80A</p>  <p>IVEM8048-II 8KW IVEM12048-II 12KW</p>	<p>Generator voltage/generator power Indicates the generator input 230V, input 2KW power</p>  <p>IVEM8048-II 8KW IVEM12048-II 12KW</p>
<p>Generator frequency/Generator current Indicates that the generator input frequency is 60HZ and the inpuitt current is 8.7A</p>  <p>IVEM8048-II 8KW IVEM12048-II 12KW</p>	<p>Smart load Voltage / Smart load power Indicates that the smart load output 230V, output 2KW power</p>  <p>IVEM8048-II 8KW IVEM12048-II 12KW</p>

<p>Smart load frequency/Smart lode current Indicates that the Smart load output frequency is 60HZ and the output current is 8.7A</p>  <p>IVEM8048-II 8KW IVEM12048-II 12KW</p>	<p>Date 2022-01-01</p>  <p>IVEM8048-II 8KW IVEM12048-II 12KW</p>
<p>Time 09: 58: 55</p>  <p>IVEM8048-II 8KW IVEM12048-II 12KW</p>	

Setting Page

Press "UP" or "DOWN" button to select setting programs. And then, press "ENTER" button to confirm the selection or ESC button to exit.

Setting items:

		Selectable option	
00	Exit setting		
01	Output voltage setting	220V 	Output voltage configuration
		230V (Default) 	
		240V 	

02	Output frequency setting	50Hz (Default) OPF [02] 50 ^{Hz}	Output frequency configuration
		60Hz OPF [02] 60 ^{Hz}	
03	Utility input range setting	Appliance mode (Default) AC [03] APL	APL should be selected, when the utility is not well.
		UPS mode AC [03] UPS	
04	Output source priority	Utility or GEN >> PV >> Battery (Default) OPS [04] USB	Utility or generator provides power to the loads first, PV and battery will provide power to loads only when utility is not available. Tip: When utility and generator exist at the same time, utility charging is preferred
		PV >> Utility or GEN >> Battery OPS [04] SUB	PV provides power to the loads first. If PV is not sufficient, utility or generator will supply power the loads at the same time. Battery will provide power to loads only when utility is not available. Tip: When utility and generator exist at the same time, utility charging is preferred
		PV >> Battery >> Utility or GEN OPS [04] SUBU	PV provides power to the loads first. If PV is not sufficient, battery will supply power to the loads at the same time. Utility or generator provides power to the loads only when battery voltage drops to the setting point in program 12. Tip: When utility and generator exist at the same time, utility charging is preferred
05	Charger priority	If inverter is working in utility mode, charger priority can be set as below. However, when inverter is working in Battery mode, only PV can charge battery.	
		PV first (Default) CHS [05] CSO	The PV will charge the battery first. Only when PV is not available will the utility or generator charge the battery. Tip: When utility and generator exist at the same time, utility charging is preferred
		PV and Utility or GEN CHS [05] SNU	PV and utility or generator will charge battery together. Tip: When utility and generator exist at the same time, utility charging is preferred
		PV Only CHS [05] OSO	Only PV can charge the battery

06	Max charging current (Utility charge current + PV charging current)	60A (Default) bCC [06] 60 ^A	Setting range is from 10A to 150A for 8KVA model; Setting range is from 10A to 240A for 12KVA model; Increment of each click is 1A.
07	Max utility charging current setting	30A (Default) CHC [07] 30 ^A	Setting range is from 10A to 150A for 8KVA model; Setting range is from 10A to 240A for 12KVA model; Increment of each click is 1A.
08	Battery type setting	The battery type is AGM (Default) bAt [08] AGM	If "Self-defined" or "Lib" is selected, battery charge voltage and low DC cut-off voltage can be set up in program 9, 10 and 11. If "Lib" is selected, inverter can charge Lithium battery when the Lithium battery need to be activated. Please make sure Lithium battery is connected before you start up inverter. If inverter doesn't connect battery or Lithium battery, do not select "Lib" battery type.
		The battery type is Flooded bAt [08] FLD	
		The battery type is self-defined bAt [08] USE	
	The battery type is Lib bAt [08] LIB		
09	Bulk charging voltage setting (C.V voltage)	Default : 56.4V [C] [09] 56.4 ^V	If "self-defined" is selected in program 8, this program is enabled. Setting range is from 48.0V to 60V. Increment of each click is 0.1V
10	Floating charging voltage	Default : 54.0V FLU [10] 54.0 ^V	If "self-defined" is selected in program 8, this program is enabled. Setting range is from 48.0V to 60.0V. Increment of each click is 0.1V
11	Low DC cut-off voltage or Low SOC	If battery power is only power source available, inverter will shut down. If PV energy and battery power are available, inverter will charge battery without AC output. If PV energy, battery power and utility are all available, inverter will transfer to line mode and provide output power to loads.	
		Default : 42.0V bC ^U [11] 42.0 ^V	If "self-defined" is selected in program 8, this program is enabled. Setting range is from 42.0V to 54.0V. Increment of each click is 0.1V
		SOC 0% (default for Lithium) bC ^U [11] 0 [%]	If or "Lib" is selected in program 8, this program is enabled. Setting range is from 0% to 90%. Increment of each click is 5%.

12	Setting battery voltage point back to utility when selecting "SBU priority" in program 4	Default : 46.0V bUv [12] 46.0v	Setting range is from 44.0V to 54.0V. Increment of each click is 0.1V
		SOC 10% (default for Lithium) bUv [12] 10%	Setting range is from 5% to 95%. Increment of each click is 5%.
13	Setting battery voltage point back to battery mode when selecting "SBU priority" in program 4	Fully charged bbv [13] FUL	Battery should be charged to float charging stage.
		Default : 54V bbv [13] 54.0v	Setting range is from 48.0V to 60.0V. Increment of each click is 0.1V
		SOC 30% (default for Lithium) bbv [13] 30%	Setting range is from 10% to 100%. Increment of each click is 5%.
14	Overload bypass function	Disable (Default) LbP [14] d15	If it is enabled, the inverter will switch to utility mode if overload happens in battery mode.
		Enable LbP [14] ENA	
15	Overload restart function	Disable (Default) OLr [15] d15	If it is enabled, the inverter will auto restart when overload occurs.
		Enable OLr [15] ENA	
16	Over temperature restart function	Disable (Default) Otr [16] d15	If it is enabled, the inverter will auto restart when over temperature occurs.
		Enable Otr [16] ENA	
17	Backlight of LCD	Disable bL [17] d15	If selected, LCD backlight will be off after no button is pressed for 60s.
		Enable (Default) bL [17] ENA	If selected, LCD backlight will be always-on.





18	Auto return to the first page of display screen	Disable bFP [18] d15	If selected, the display screen will stay at latest screen user finally switches.
		Enable (Default) bFP [18] ENA	If selected, it will automatically return to the first page of display screen (Input voltage/ output voltage) after no button is pressed for 60s.
19	Buzzer Alarm	Disable bEP [19] d15	If selected, buzzer is not allowed to beep.
		Enable (Default) bEP [19] ENA	If selected, buzzer is allowed to beep.
21	Energy stored data for PV and Load	Disable ESd [21] d15	If selected, inverter will erase all historical data of PV and Load energy, and stop record historical data for PV and Load energy.
		Enable (Default) ESd [21] ENA	If selected, inverter will record historical data for PV and Load energy. NOTE: Before selected, please double check if date and time is correct, if incorrect, please set date and time in program 22~27.
Items 22 to 27 set world time			
22	Time setting- Year	Year yEA [22] 22	Setting range is from 22 to 99.
23	Time setting- Month	Month mON [23] 1	Setting range is from 1 to 12
24	Time setting- Day	Day dAY [24] 1	Setting range is from 1 to 31
25	Time setting- Hour	Hour HOu [25] 9	Setting range is from 0 to 23
26	Time setting- Minute	Minute mIN [26] 58	Setting range is from 0 to 59







27	Time setting- Second	Second SEC [27] 30	Setting range is from 0 to 59
<p>Item 30 to 33 Sets the the smart load output interval. If the setting range is from 00:00 to 08:59, the smart load output will be turned on until 09:00. During this period, if the set value in item 34 or 35/36 is triggered, it will be turned off. (If the 34 time Settings work for 30 minutes, then 00:31, the the smart load output is off)</p>			
30	Start time setting-Hour	Default : 0 hour StH [30] 0	Setting rage is from 0 to 23.Increment of each click is 1 hour.
31	Start time setting-Minute	Default : 0 minute Stn [31] 0	Setting rage is from 0 to 59.Increment of each click is 1 minute.
32	End time setting-Hour	Default : 0 hour EnH [32] 0	Setting rage is from 0 to 23.Increment of each click is 1 hour.
33	End time setting-Minute	Default : 0 minute Enn [33] 0	Setting rage is from 0 to 59.Increment of each click is 1 minute.
34	Setting discharge time on the smart load output if "Single" is selected in program 28.	Disable (Default) tln [34] dis	Setting range is from 0 min to 990 min. Increment of each click is 5 minute. This item is disabled by default. 'dis' indicates disabled *If the battery discharge time achieves the setting time in program 30,31,32 and 33 and the program 35 or 36 function is not triggered, the output will be turned off.
35	Setting cut-off voltage point on the smart load output if "Single" is selected in program 28.	Default : 54V nlv [35] 54.0 ^v	If "User-defined" is selected in program 08, this setting range is from 42.0V to 54.0V for 48V model. Increment of each click is 0.1V.
36	Setting SOC percentage on the smart load output if "Single" is selected in program 28.	Default : 60% nlS [36] 60%	If "Lib" is selected in program 08, this parameter value will be displayed in percentage and value setting is based on battery capacity percentage. Setting range is from 0% to 95%. Increment of each click is 5%.

37	Turn on the second output when the inverter is back to Line Mode or Bypass Mode	Disable OPL [37] dis	If selected, there is no effect on the second output When the inverter back to Line Mode or Bypass Mode
		Enable (Default) OPL [37] ENA	If selected, the output will turn on if second output is cut off due to setting in program 35 or 36

Energy stored data Page



The energy stored data will be switched by pressing "UP" or "DOWN" key. The selectable information is switched as below order:





<p>PV generated energy today 99 kWh</p> 	<p>PV generated energy this month 99 kWh</p> 
<p>PV generated energy this year 99 kWh</p> 	<p>PV generated energy current in total 340 kWh</p> 

<p>Load consumed energy today 79 kWh</p> 	<p>Load consumed energy this month 79 kWh</p> 
<p>Load consumed energy this year 80 kWh</p> 	<p>Load consumed energy in total 272 kWh</p> 
<p>Load consumed energy this year 80 kWh</p> 	<p>Load consumed energy in total 272 kWh</p> 

BMS information Page



The BMS information will be switched by pressing "UP" or "DOWN" key. The selectable information is switched as below order:

<p>Mean SOC/ Battery pack number / BMS status PV generated energy this month</p> <p>Mean SOC is 97%, Connected Battery pack number is 4, BMS status is 51 (Check detail in warning code table). If BMS status occurred, it will be rolled with battery pack number automatically.</p>	
	


<p>BMS version / SOC BMS version is 100, SOC is 99% on battery pack of address 1</p> 	<p>BMS voltage / current BMS voltage is 54.0V, current is 1A on battery pack of address 1</p> 
<p>BMS highest temperature / lowest temperature BMS highest temperature is 25°C, lowest temperature is -10°C on battery pack of address 1</p> 	<p>BMS fault code / flag BMS fault code is 0, flag is 000 on battery pack of address 1</p> 

Rated information Page

The rated information will be switched by pressing "UP" or "DOWN" key. The selectable information is switched as below order:

<p>Rated VA / WATT Rated VA is 8KVA, WATT is 8KW</p> 	<p>Rated battery voltage / Max. charge current Rated battery voltage is 48V, Max. charge current is 150A</p> 
---	---

Firmware version
Firmware version is 2104



Generator Port Use Setup Page

Press "UP" or "DOWN" button to select setting programs. And then, press "ENTER" button to confirm the selection or ESC button to exit.


Setting items:

		Selectable option	
00	Exit setting	ESC	
01	Generator and smart load switching	POT GEN	The generator port can be switched to the smart load port, the default is the generator port "GEN". If you want to switch, first turn off the inverter switch so that the inverter is in standby state, and then switch to "SLd" when entering the interface.
		POT SLd	
02	Generator charging enable	CHG d15	This option is used by default, if you choose not to use, the generator cannot be charged
		CHG ENA	
03	Generator charging power setting	1 PL 03 080 ^{kW}	Press the "ENTER" key each time to select the value to change; Use the "UP" key to decrease the value and the "DOWN" key to increase the value The maximum setting value is 50KW and the minimum setting value is 0.5KW Default value is 8KW

Lithium Battery Communication

It's allowed to connect lithium battery and build communication only which it has been configured. Please follow below steps to configure communication between lithium battery and inverter.

1. Connect power cables between lithium battery and inverter. Please pay attention to the terminals of positive and negative. Make sure the positive terminal of battery is connected to the positive terminal of inverter, and the negative terminal of battery is connected to the negative terminal of inverter.
2. The communication cable is bundled with lithium battery. Both sides are RJ45 port. One port is connected to the Rs485 port of inverter and another one is connected to the COMM port of lithium battery.



Pin Assignment for Inverter CAN/RS485 Communication Port


	CAN	RS485	
PIN 1	NC	COM-GND	
PIN 2	NC	NC	
PIN 3	NC	CAN.L	
PIN 4	CAN.H	CAN.H	
PIN 5	CAN.L	RS485-B	
PIN 6	COM-GND	RS485-A	
PIN 7	RS485-A	NC	
PIN 8	RS485-B	NC	

Note: That the use of lithium mode should ensure that the inverter and battery pack communication is normal


3. Configure battery type to "Lib" in LCD setting No. 08.




And then LCD will show you "Li" icon.



4. Power up lithium battery and inverter. Wait a moment, if the communication is built between them, LCD will show you "C" icon as below.



5. Roll LCD real time information pages by pressing "UP" or "DOWN" button, as below page, you can see the parameters of SOC and battery pack units in the communication system.



This page means SOC is 88% and battery pack units are 8.

Parallel Installation Guide

Introduction

This inverter can be used in parallel with two different operation modes:

1. Parallel operation in single phase with up to 6 units.

The supported maximum output power of 8KVA model is 48KW/48KVA.

The supported maximum output power of 12KVA model is 72KW/72KVA.

2. Maximum six units work together to support three-phase equipment. Four units support one phase maximum.

The supported maximum output power of 8KVA model is 48KW/48KVA and one phase can be up to 32KW/32KVA.


The supported maximum output power of 12KVA model is 72KW/72KVA and one phase can be up to 48KW/48KVA.

NOTE 1: If this unit is bundled with share current cable and parallel cable, this inverter is default supported parallel operation. You may skip section 2.

NOTE 2: Under parallel operation modes, battery must be connected with inverters.


NOTE 3: Before starting up inverters, please connect all N wires of AC output together.

Mounting the Unit




NOTE: For proper air circulation to dissipate heat, allow a clearance of approx. 20 cm to the side and approx. 50 cm above and below the unit. Be sure to install each unit in the same level.

Single Phase Parallel connection diagram for three inverters in parallel



- NOTE 1: Before starting up inverters, please connect all N wires of AC output together
- NOTE 2: Do not connect the AC input Neutral (N) wire to the AC output Neutral (N) wire
- NOTE 3: Before starting up inverters, please connect all negative (-) wires of battery together.

Three Phase Parallel connection diagram for three inverters in parallel



- NOTE 1: Before starting up inverters, please connect all N wires of AC output together
- NOTE 2: Do not connect the AC input Neutral (N) wire to the AC output Neutral (N) wire
- NOTE 3: Before starting up inverters, please connect all negative (-) wires of battery together.

LCD Setting and Display

Setting Program

28	AC output mode	Single 	<p>When the units are used in parallel with single phase, please select "PAL" in program 28.</p> <p>It is required to have at least 3 inverters or maximum six inverters to support three-phase equipment.</p> <p>It's required to have at least one inverter in each phase or it's up to four inverters in one phase.</p> <p>Please select "3P1" in program 28 for the inverters connected to L1 phase, "3P2" in program 28 for the inverters connected to L2 phase and "3P3" in program 28 for the inverters connected to L3 phase.</p> <p>Do NOT connect share current cable between units on different phases.</p> <p>Before starting up inverters, please connect all N wires of AC output together.</p>
		Parallel 	
		L1 Phase 	
		L2 Phase 	
		L3 Phase 	

Commissioning

Parallel in single phase

Step 1: Check the following requirements before commissioning:

- Correct wire connection.
 - Ensure all breakers in Line wires of load side are open and each Neutral wires of each unit are connected together.
- Step 2: Turn on each unit and set "PAL" in LCD setting program 28 of each unit. And then shut down all units.

NOTE: To be safe, it's better to turn off switch when setting LCD program.

Step 3: Turn on each unit.

LCD display in Master unit 	LCD display in Slave unit
--------------------------------	-------------------------------

NOTE: Master and slave units are randomly defined.

Step 4: Switch on all AC breakers of Line wires in AC input. It's better to have all inverters connect to utility at the same time. However, these inverters will automatically restart. If detecting AC connection, they will work normally.

LCD display in Master unit 	LCD display in Slave unit
--------------------------------	-------------------------------

Step 5: If there is no more fault alarm, the parallel system is completely installed.

Step 6: Please switch on all breakers of Line wires in load side. This system will start to provide power to the load.

Support three-phase equipment

Step 1: Check the following requirements before commissioning:

- Correct wire connection
- Ensure all breakers in Line wires of load side are open and each Neutral wires of each unit are connected together.

Step 2: Turn on all units and configure LCD program 28 as P1, P2 and P3 sequentially. And then shut down all units.

NOTE: To be safe, it's better to turn off switch when setting LCD program.

Step 3: Turn on all units sequentially.

LCD display in L1-phase unit 	LCD display in L2-phase unit 	LCD display in L3-phase unit
----------------------------------	----------------------------------	----------------------------------

Step 4: Switch on all AC breakers of Line wires in AC input. If AC connection is detected and three phases are matched with unit setting, they will work normally. Otherwise, the AC icon will flash and they will not work in line mode.

LCD display in L1-phase unit 	LCD display in L2-phase unit 	LCD display in L3-phase unit
----------------------------------	----------------------------------	----------------------------------


Step 5: If there is no more fault alarm, the system to support 3-phase equipment is completely installed.

Step 6: Please switch on all breakers of Line wires in load side. This system will start to provide power to the load.

Note 1: To avoid overload occurring, before turning on breakers in load side, it's better to have whole system in operation first.


Note 2: Transfer time for this operation exists. Power interruption may happen to critical devices, which cannot bear transfer time.

Warning Code Table

When fault event happens, the fault LED is flashing. At the same time, warning code, icon  is shown on the LCD screen.

Warning Code	Warning Information	Audible Alarm	Trouble Shooting
01	Fan is locked.	Beep three times every second	Check if the Fans wiring connected well. Replace the fan.
02	Overload	Beep twice every second	Reduce the loads.
03	Low battery	Beep once every second	The battery voltage is too low, it should be charging.
04	Grid anomaly	Grid icon blinking	Check whether the input is overvoltage or overfrequency
05	Three-phase input missing phase	Fault LED flashing	Check whether the three-phase mains input is normal
06	The three-phase parallel is abnormal	Fault LED flashing	Verify that the three-phase communication is normal
07	Generator anomaly	Generator icon blinking	Check whether the input is overvoltage or overfrequency
08	Three-phase parallel generator input phase deficiency	Fault LED flashing	Check whether the three-phase mains input is normal
50	BMS firmware version is not matched.		Upgrade the firmware of BMS.
51	BMS doesn't allow inverter to charge battery.		Inverter will stop charging battery automatically.
52	BMS doesn't allow inverter to discharge battery.		Inverter will stop discharging battery automatically.
53	BMS require inverter to charge battery.		Inverter will charge battery automatically.
54~65	BMS detect something wrong happened.		If the code is keeping for long time, please contact with your installer.
80	The BMS communication is abnormal	Beep once every second	Check whether the BMS communication cable is connected

Fault Code Table

When fault event happens, inverter will cut off output, and the fault LED is solid on. At the same time, fault code, icon  and **ERROR** are shown on the LCD screen.

Fault Code	Fault information	Trouble Shooting
01	Bus voltage is too high	AC Surge or internal components failed. Restart the unit, if the error happens again, please return to repair center.

02	Bus voltage is too low	Restart the unit, if the error happens again, please return to repair center.
03	Bus soft start fail	Internal components failed. Restart the unit, if the error happens again, please return to repair center.
04	Inverter soft start fail	Internal components failed. Restart the unit, if the error happens again, please return to repair center.
05	Over current or surge detected by Software	Restart the unit, if the error happens again, please return to repair center.
06	Over current or surge detected by hardware	Restart the unit, if the error happens again, please return to repair center.
07	Output voltage is too low	Reduce the connected load. Restart the unit, if the error happens again, please return to repair center.
08	Output voltage is too high	Restart the unit, if the error happens again, please return to repair center.
09	Output short circuited	Check if wiring is connected well and remove abnormal load.
10	Overload time out	Reduce the connected load by switching off some equipment.
11	Battery voltage is too high	Check if spec and quantity of batteries are meet requirements.
12	Over current happen at DC/DC circuit	Restart the unit, if the error happens again, please return to repair center.
13	PV voltage is too high	Reduce the number of PV modules in series.
14	Short circuited happen at PV port	Check if wiring is connected well.
15	PV power is abnormal	Reduce the number of PV modules.
16	Over current happen at PV port	Restart the unit, if the error happens again, please return to repair center.
17	Fan is locked	Check if wiring is connected well. Replace the fan.
18	Over temperature happen at PV circuit	The temperature of internal PV component is over the limitation. Check whether the air flow of the unit is blocked or whether the ambient temperature is too high.
19	Over temperature happen at Convert L circuit	The temperature of Convert L battery converter component is over the limitation. Check whether the air flow of the unit is blocked or whether the ambient temperature is too high.
20	Over temperature happen at INV circuit	The temperature of internal INV component is over the limitation. Check whether the air flow of the unit is blocked or whether the ambient temperature is too high.

21	The inner temperature over	The inner temperature is over the limitation. Check whether the air flow of the unit is blocked or whether the ambient temperature is too high.
22	DCDC current sensor failed	Restart the unit, if the error happens again, please return to repair center.
23	No.2 DCDC current sensor failed	Restart the unit, if the error happens again, please return to repair center.
24	Inverter current sensor failed	Restart the unit, if the error happens again, please return to repair center.
25	OP current sensor failed	Restart the unit, if the error happens again, please return to repair center.
26	Sharing current sensor failed	Restart the unit, if the error happens again, please return to repair center.
27	The AC input and output wires are inversely connected	1. Please check AC input and output wires are connected correctly. 2. If this error happens during parallel installation, please check wires connection. If they are connected correctly, please finish parallel installation first, and then restart inverters. 3. If the problem remains, please contact your installer.
28	Single unit is installed to parallel system	1. Please check if single unit is installed to parallel system. 2. If this error happens during parallel installation, please check wires connection. If they are connected correctly, please finish parallel installation first, and then restart inverters. 3. If the problem remains, please contact your installer.
29	DC/DC soft start fail.	Restart the unit, if the error happens again, please return to repair center.
31	Over temperature happen at convert H circuit	The temperature of internal convert H component is over the limitation. Check whether the air flow of the unit is blocked or whether the ambient temperature is too high.
32	Over temperature happen at LLC TX	The temperature of internal DC/DC TX is over the limitation. Check whether the air flow of the unit is blocked or whether the ambient temperature is too high.
33	Over current happen at LLC circuit	Restart the unit, if the error happens again, please return to repair center
34	DC/DC hardware overflows	Restart the unit, if the error happens again, please return to repair center.
35	Overvoltage occurs in BUS	1.AC surge or PV surge or internal components failed. 2.Restart the unit, if the error happens again, please return to repair center.
40	CAN data loss	1. Check if communication cables are connected well and restart the inverter. 2. If the problem remains, please contact your installer.
41	Host data loss	
42	Synchronization data loss	


43	Current feedback into the inverter is detected.	1. Restart the inverter. 2. Check if L/N cables are not connected reversely in all inverters. 3. For parallel system in single phase, make sure the sharing cables are connected in all inverters. For supporting three-phase system, make sure the sharing cables are connected in the inverters in the same phase, and disconnected in the inverters in different phases. 4. If the problem remains, please contact your installer.
44	The firmware version of each inverter is not the same.	1. Update all inverter firmware to the same version. 2. Check the version of each inverter via LCD setting and make sure the CPU versions are same. If not, please contact your installer to provide the firmware to update. 3. After updating, if the problem still remains, please contact your installer.
45	The output current of each inverter is different.	1. Check if sharing cables are connected well and restart the inverter. 2. If the problem remains, please contact your installer.
46	AC output mode setting is different.	1. Switch off the inverter and check LCD setting program 28. 2. For parallel system in single phase, make sure no 3P1, 3P2 or 3P3 is set on program 28. For supporting three-phase system, make sure no "PAL" is set on program 28. 3. If the problem remains, please contact your installer.
47	Generator current sensor failed	Restart the unit, if the error happens again, please return to repair center.

The Wi-Fi operation Guide in APP

Introduction

Wireless communication between the off-grid inverter and the APP can be realized through the Wi-Fi module. The APP supports Android and iOS devices.

Delivers device status during normal operation.
Allows device Settings to be configured on the APP.
Notifies users when a warning or alarm occurs.
Allows users to query inverter history data.



The status of the Wi-Fi sign on the LCD display
After the APP is successfully connected, Wi-Fi indicator light remains constantly on

Download and install APP

Operating system requirement for your smart phone:

- 🍏 iOS system supports iOS 11.0 and above
- 🤖 Android system supports Android 5.0 above

APP Download
Please scan the following QR code with your smartphone to download the App.



The QR code supports Android system and iOS system

Operation Manual
Please scan the following QR code with your smartphone to view the App Operation Manual



The QR code supports Android system and iOS system