



Installer manual
NIBE™ F2040
Air/water heat pump

Table of Contents

1 Important information _____	2	Connections _____	17
Safety information _____	2	6 Commissioning and adjusting _____	19
2 Delivery and handling _____	5	Preparations _____	19
Transport and storage _____	5	Filling and venting the heating medium system _____	19
Assembly _____	5	Compressor heater _____	19
Supplied components _____	7	Start-up and inspection _____	20
Removing the covers _____	7	Readjusting, heating medium side _____	20
Removing the front panel _____	8	Adjustment, charge flow _____	21
Removing the side panel _____	8	7 Disturbances in comfort _____	22
3 The heat pump design _____	9	Troubleshooting _____	22
General _____	9	8 Accessories _____	25
Electrical connection _____	11	9 Technical data _____	26
4 Pipe connections _____	13	Dimensions and setting-out coordinates _____	26
General _____	13	Sound pressure levels _____	27
Pipe coupling heating medium circuit _____	13	Technical specifications _____	28
Docking alternatives _____	15	Electrical circuit diagram _____	31
5 Electrical connections _____	16	Item register _____	33
General _____	16		

1 Important information

Safety information

This manual describes installation and service procedures for implementation by specialists.

This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.

Rights to make any design or technical modifications are reserved.

©NIBE 2013.

Symbols



NOTE

This symbol indicates danger to machine or person.



Caution

This symbol indicates important information about what you should observe when maintaining your installation.



TIP


This symbol indicates tips on how to facilitate using the product.

Marking

The CE marking means that NIBE ensures that the product meets all regulations that are placed on it based on relevant EU directives. The CE mark is obligatory for most products sold in the EU, regardless where they are made.

Serial number

The serial number for F2040 can be found on the side of the foot.



Serial number



Caution

Always give the product's serial number when reporting a fault.

Country specific information

Installer manual

This installer manual must be left with the customer.

Inspection of the installation

Current regulations require the heating installation to be inspected before it is commissioned. The inspection must be carried out by a suitably qualified person. Fill in the page for information about installation data in the User manual.

✓	Description	Notes	Signature	Date
	System flushed			
	System vented			
	Particle filter			
	Shut-off and drain valve			
	Charge flow set			
	Fuses property			
	Safety breaker			
	Communication cable connected			
	Miscellaneous			

Contact information

AT KNV Energietechnik GmbH, Gahberggasse 11, 4861 Schörfling

Tel: +43 (0)7662 8963-0 Fax: +43 (0)7662 8963-44 E-mail: mail@knv.at www.knv.at

CH NIBE Wärmetechnik AG, Winterthurerstrasse 710, CH-8247 Flurlingen

Tel: (52) 647 00 30 Fax: (52) 647 00 31 E-mail: info@nibe.ch www.nibe.ch

CZ Druzstevni zavody Drazice s.r.o., Drazice 69, CZ - 294 71 Benatky nad Jizerou

Tel: +420 326 373 801 Fax: +420 326 373 803 E-mail: nibe@nibe.cz www.nibe.cz

DE NIBE Systemtechnik GmbH, Am Reiherpfahl 3, 29223 Celle

Tel: 05141/7546-0 Fax: 05141/7546-99 E-mail: info@nibe.de www.nibe.de

DK Vølund Varmeteknik A/S, Member of the Nibe Group, Brogårdsvej 7, 6920 Videbæk

Tel: 97 17 20 33 Fax: 97 17 29 33 E-mail: info@volundvt.dk www.volundvt.dk

FI NIBE Energy Systems OY, Juurakkotie 3, 01510 Vantaa

Puh: 09-274 697 0 Fax: 09-274 697 40 E-mail: info@nibe.fi www.nibe.fi

FR AIT France, 10 rue des Moines, 67000 Haguenau

Tel : 03 88 06 24 10 Fax : 03 88 06 90 15 E-mail: info@nibe.fr www.nibe.fr

GB NIBE Energy Systems Ltd, 3C Broom Business Park, Bridge Way, Chesterfield S41 9QG

Tel: 0845 095 1200 Fax: 0845 095 1201 E-mail: info@nibe.co.uk www.nibe.co.uk

NL NIBE Energietechnik B.V., Postbus 2, NL-4797 ZG WILLEMSTAD (NB)

Tel: 0168 477722 Fax: 0168 476998 E-mail: info@nibenl.nl www.nibenl.nl

NO ABK AS, Brobekkveien 80, 0582 Oslo, Postadresse: Postboks 64 Vollebakk, 0516 Oslo

Tel. sentralbord: +47 23 17 05 20 E-mail: post@abkklima.no www.nibeenergysystems.no

PL NIBE-BIAWAR Sp. z o. o. Aleja Jana Pawła II 57, 15-703 BIAŁYSTOK

Tel: 085 662 84 90 Fax: 085 662 84 14 E-mail: sekretariat@biawar.com.pl www.biawar.com.pl

RU © "EVAN" 17, per. Boynovskiy, Nizhny Novgorod

Tel./fax +7 831 419 57 06 E-mail: info@evan.ru www.nibe-evan.ru

SE NIBE AB Sweden, Box 14, Hannabadsvägen 5, SE-285 21 Markaryd

Tel: +46-(0)433-73 000 Fax: +46-(0)433-73 190 E-mail: info@nibe.se www.nibe.se

For countries not mention in this list, please contact Nibe Sweden or check www.nibe.eu for more information.


2 Delivery and handling

Transport and storage


F2040 must be transported and stored vertically.

Assembly

- Place F2040 outdoors on a solid level base that can take the weight, preferably a concrete foundation. If concrete slabs are used they must rest on asphalt or shingle.
- The concrete foundation or slabs must be positioned so that the lower edge of the evaporator is at the level of the average local snow depth, although a minimum of 300 mm.
- The F2040 should not be positioned next to sensitive walls, for example, next to a bedroom.
- Also ensure that the placement does not inconvenience the neighbours.
- F2040 must not be placed so that recirculation of the outdoor air can occur. This causes lower output and impaired efficiency.
- The evaporator should be sheltered from direct wind. Place F2040 protected from wind against the evaporator.
- Large amounts of condensation water as well as melt water from defrosting can be produced. Condensation water must be led off to a drain or similar (see page 6).
- Care must be exercised so that the heat pump is not scratched during installation.



If there is a risk of snow slip from roof, a protective roof or cover must be erected to protect the heat pump, pipes and wiring.



Do not place F2040 directly on the lawn or other non solid surface.

Condensation run off

Condensation water trough

The condensation water trough is used to collect and lead away condensation water from the heat pump.



NOTE

It is important to the heat pump function that condensation water is led away and that the drain for the condensation water run off is not positioned so that it can cause damage to the house.



NOTE

Pipe with heating cable for draining the condensation water trough are not included.



NOTE

To ensure this function the accessory KVR 10 should be used.



NOTE

The electrical installation and wiring must be carried out under the supervision of an authorised electrician.



NOTE

Self regulating heating cables must not be connected.



Caution

If none of the recommended alternatives is used good lead off of condensation water must be assured.

- The condensation water (up to 50 litres/day) collected in the trough should be routed by pipe to an appropriate drain, it is recommended that the shortest outdoor stretch possible is used.
- The section of the pipe that can be affected by frost must be heated by the heating cable to prevent freezing.
- Route the pipe downward from F2040.
- The outlet of the condensation water pipe must be at a depth that is frost free or alternatively indoors (with reservation for local ordinances and regulations).
- Use a water trap for installations where air circulation may occur in the condensation water pipe.
- The insulation must be tight against the bottom of the condensation water trough.


Drain pan heater, control

The drain pan heater is supplied with power when one of the following conditions is met:

1. Operating mode "Heating" or "Hot water" is activated.
2. The compressor has been in operation for at least 30 minutes after last start.
3. The ambient temperature is lower than 1 C.

Recommended alternatives


Stone caisson



If the house has a cellar the stone caisson must be positioned so that condensation water does not affect the house. Otherwise the stone caisson can be positioned directly under the heat pump.

The outlet of the condensation water pipe must be at frost free depth.

Drain indoors




The condensation water is lead to an indoor drain (subject to local rules and regulations).

Route the pipe downward from F2040.

The condensation water pipe must have a water seal to prevent air circulation in the pipe.

Gutter drainage




The outlet of the condensation water pipe must be at frost free depth.

Route the pipe downward from F2040.

The condensation water pipe must have a water seal to prevent air circulation in the pipe.

Installation area

The distance between F2040 and the house wall must be at least 150 mm. Clearance in front of F2040 should be at least one metre.



Supplied components




2 flexible hoses (R25) with 4 seals




Particle filter R25 (HQ1).


Removing the covers



Removing the front panel






Removing the side panel



3 The heat pump design

General



Pipe connections

QM35	Service valve, liquid side
QM36	Service valve, gas side
XL1	Connection, heating medium out of F2040, G3/4" (Ø22 mm)
XL2	Connection, heating medium in to F2040, G3/4" (Ø22 mm)

Sensors etc.

BP1 (63H1)	High pressure pressostat
BT3	Temperature sensor, heating medium return line
BT12	Temperature sensor, condenser supply line
BT15	Temperature sensor, fluid pipe
BP2 (LPT)	Low pressure transmitter
BP4	High pressure sensor

Electrical components

AA23	Communication board
AA23-X1	Terminal block, incoming supply
AA23-X4	Terminal block, communication
EB10 (CH)	Connection, compressor heater
EB11 (DH)	Connection, drip tray heater
F	Main fuse compressor unit
F3	Fuse for external heating cable (250 mA), max 45 W.
GQ1 (FM01)	Fan
PWB1	Control board
PWB2	Inverter board
PWB3	Filter board
TB	Terminal block, electricity and communica- tion
X1	Terminal block incoming

Cooling components

QN2 (20S)	4-way valve
GQ10 (CM)	Compressor
QN3 (EEV-C)	Expansion valve, cooling
QN1 (EEV-H)	Expansion valve, heating
EP1	Evaporator
EP2	Condenser
HS1	Drying filter


Miscellaneous


PF1	Type plate
PF3	Serial number
UB1	Cable gland, incoming supply
UB2	Cable grommet, communication
UB3	Cable grommet, heating cable (EB14)
W1	Cable, incoming supply

Electrical connection

Electrical components

- AA23 Communication board
- AA23-X1 Terminal block, incoming supply
- AA23-X4 Terminal block, communication
- EB10 (CH) Connection, compressor heater
- EB11 (DH) Connection, drip tray heater
- F Main fuse compressor unit
- F3 Fuse for external heating cable (250 mA), max 45 W.
- GQ1 (FM01) Fan
- PWB1 Control board
- PWB2 Inverter board
- PWB3 Filter board
- TB Terminal block, electricity and communication
- X1 Terminal block incoming





4 Pipe connections

General

Pipe installation must be carried out in accordance with current norms and directives.

F2040 can only operate up to a return temperature of about 55 °C and an outgoing temperature of about 58 °C from the heat pump.

F2040 is not equipped with external shut off valves on the water side; these must be installed to facilitate any future servicing. The return temperature is limited by the return line sensor.

Water volumes

When docking with F2040 a minimum available system volume of at least 10 litres water per kW output on the heat pump (A7W45) is recommended.






NOTE

The pipe work must be flushed before the heat pump is connected, so that any contaminants do not damage the components parts.

Pipe coupling heating medium circuit

- F2040 can be connected directly to the heating system see the section "Docking" or according to one of the system solutions that can be downloaded from the website www.nibe.eu.
- The heat pump must be vented by the upper connection (QM20) using the venting nipple on the enclosed flexible hose.
- Install the supplied particle filter (HQ1) before the inlet, i.e. the connection (XL2, HM-in) on F2040.
- All outdoor pipes must be thermally insulated with at least 19mm thick pipe insulation.
- Install shutoff valves (QM31 and QM32) and drain valves (QM1) so that F2040 can be emptied in the event of prolonged power failures. Shutoff - (QM31 and QM32) and drain valve (QM31) are not part of the delivery





Docking alternatives

F2040 can be installed in several different ways. The requisite safety equipment must be installed in accordance with current regulations for all docked options.

See www.nibe.eu for more docking options.

When docking with F2040 a minimum available system volume of at least 10 litres water per kW output on the heat pump (A7W45) is recommended.

Connecting accessories

Instructions for connecting accessories are in the installation instructions provided for the respective accessory. See page 25 for the list of the accessories that can be used with F2040.



5 Electrical connections

General

- A heat pump must not be connected without the permission of the electricity supplier and must be connected under the supervision of a qualified electrician.
- If a miniature circuit breaker is used this should have motor characteristic "C" (compressor operation). For MCB size see "Technical Specifications".
- F2040 does not include an omnipolar circuit breaker on the incoming power supply. The heat pump's supply cable must be connected to a circuit-breaker with at least a 3 mm breaking gap. When the building is equipped with an earth-fault breaker the heat pump should be equipped with a separate one. Incoming supply must be 230 V 50Hz via distribution boards with fuses.
- If an insulation test is to be carried out in the building, disconnect the heat pump.
- Communication cable (W2) is inserted from the rear side through UB2.
- Connect communication cable (W2) from terminal block (AA23-X4) to the indoor section.

 **NOTE** Electrical installation and service must be carried out under the supervision of a qualified electrician. Electrical installation and wiring must be carried out in accordance with the stipulations in force.

 **NOTE** The external control must be taken into consideration when connecting.





Connections



NOTE

To prevent interference, unshielded communication and/or sensor to external connections cables must not be laid closer than 20 cm to high voltage cables when cable routing.

Power connection




Incoming supply cable (W1) is supplied and factory connected to terminal block X1. Approx. 1.8 m cable is accessible outside the heat pump.

Connect communication cable (W2) (provided by installer) to terminal block AA23-X4 and secure with two cable ties, see image.

For connection of accessory KVR 10, heating cable (EB14) is connected via cable grommet UB3, see External heating cable KVR 10 (Accessory) on page 18.

List of components

- UB1 Cable gland, incoming supply
- UB2 Cable grommet, communication
- UB3 Cable grommet, heating cable (EB14)
- W1 Cable, incoming supply



External heating cable KVR 10 (Accessory)


F2040 is equipped with a plinth for external heating cable EB14 (not supplied). The connection is fused with 250 mA (F3 on the communication board AA23). If another cable is to be used, the fuse must be replaced with a suitable one (see table).

NOTE
 Self regulating heating cables must not be connected.

Length (m)	Total power (W)	Fuse (F3)	NIBE Part no. Fuse
1	15	T100mA/250V	718085
3	45	T250mA/250V	518900*
6	90	T500mA/250V	718086

* Fitted at the factory.


Connect external heating cable (EB14) to terminal block X1:4–6 according to following image:



NOTE
 The pipe must be able to withstand the heat from the heating cable.
 To ensure this function the accessory KVR 10 should be used.

Cable routing

The following image shows recommended cable routing from distribution box to condensation water pipe. Route the heating cable (EB14) through the grommet underneath and secure with two cable ties at the electrical connection. Transfer between electrical cable and heating cable must occur after the lead-in to the condensation water pipe.




Ambient temperature sensor

An ambient temperature sensor (Tho-A) is located on the rear of F2040.

Communication

F2040 can communicate with NIBE indoor modules, by connecting the indoor module to the terminal block X4:4–6 according to the following image:



For connection of indoor module, see relevant manual on www.nibe.eu.


6 Commissioning and adjusting

Preparations

- Before commissioning, check that the charge circuit and climate system are filled and well vented.
- Check the pipe system for leaks.

Filling and venting the heating medium system

1. The heating medium system is filled with water to the required pressure.
2. Vent the system using the venting nipple (QM20) on the enclosed flexible hose and possibly the circulation pump.



Compressor heater

F2040 is equipped with a compressor heater that heats the compressor before start-up and when the compressor is cold.



NOTE

The compressor heater must have been connected for 6 – 8 hours before the first start, see the section “Start-up and inspection” in the installer manual for the indoor section


Start-up and inspection

1. The compressor heater (CH) must have been operational for at least 6 - 8 hours before the compressor start can be initiated. This is done by switching on the control voltage and disconnecting the communication cable.
2. The communication cable on the terminal block AA23-X4 must not be connected.
3. Turn the isolator switch on.
4. Ensure that the F2040 is connected to the power source.
5. After 6 – 8 hours the communication cable (W2) is connected on AA23-X4.
6. Restart the indoor module. Follow the instructions for "Start-up and inspection" in the installation manual for the indoor module.

The heat pump starts 30 minutes after the outdoor unit is powered and the communication cable (W2) is connected, if necessary.

Readjusting, heating medium side

Air is initially released from the hot water and venting may be necessary. If bubbling sounds can be heard from the heat pump, the circulation pump and radiators the entire system will require further venting. When the system is stable (correct pressure and all air eliminated) the automatic heating control system can be set as required.



Caution

Do not start any electrical work until at least two minutes after cutting the power.

Adjustment, charge flow

Instructions for adjusting hot water charging are in the installation manual for the respective indoor section. See page 25 for the list of the indoor sections and accessories that can be used with F2040.

7 Disturbances in comfort

Troubleshooting



NOTE

Work behind covers secured by screws may only be carried out by, or under the supervision of, a qualified installation engineer.



NOTE

As F2040 can be connected to a large number of external units, these should also be checked.



NOTE

In the event of action to rectify malfunctions that require work within screwed hatches the incoming electricity must be isolated at the safety switch.



NOTE

Alarms are acknowledged on NIBE SMO or NIBE indoor module.

The following tips can be used to rectify comfort disruption:

Basic actions

Start by checking the following possible fault sources:

- That the heat pump is running or that the supply cable to F2040 is connected.
- Group and main fuses of the accommodation.
- The property's earth circuit breaker.
- The heat pump's motor circuit breaker (F).

Low hot water temperature or a lack of hot water

This part of the fault-tracing chapter only applies if the heat pump is docked to the hot water heater.

- Large hot water consumption.
 - Wait until the hot water has heated up.
- Incorrect settings in the NIBE indoor module.
 - See the manual for the indoor module.

Low room temperature

- Closed thermostats in several rooms.
 - Set the thermostats to max in as many rooms as possible.
- External switch for changing the room heating activated.
 - Check any external switches.

- Incorrect settings in NIBE SMO or NIBE indoor module
 - See the manual for the indoor module.

High room temperature

- External switch for changing the room heating activated.
 - Check any external switches.
- Incorrect settings in NIBE SMO or NIBE indoor module
 - See the manual for the indoor module.


F2040 is not operational

F2040 communicates all alarms to the indoor module.

- Ensure that the F2040 is connected to the power source.
- Check the indoor module. See section "Disturbances in comfort" in the installation manual for the indoor module.

Sensor placement


Connection to card (PWB1)




Sensors etc.

- QM2 (20S) 4-way valve
- GQ10 (CM) Compressor
- CT Current sensor
- BP1 (63H1) High pressure pressostat
- BP2 (LPT) Low pressure transmitter
- BP4 Pressure sensor, condenser
- BT3 Temperature sensor, heating medium return line
- BT12 Temperature sensor, condenser supply line
- BT14 (Tho-D) Temperature sensor, hot gas
- BT15 Temperature sensor, fluid pipe
- BT16 (Tho-R1) Temperature sensor, heat exchanger out
- BT17 (Tho-S) Temperature sensor, suction gas
- BT28 (Tho-A) Temperature sensor, ambient
- EP2 Condenser
- GQ1 (FM01) Fan
- HQ1 Particle filter
- HS1 Drying filter
- Tho-R2 Temperature sensor, heat exchanger, in

Connection to card (AA23)




Sensor placement in F2040




Data for sensor in F2040


Tho-D



Tho-S, Tho-R1, Tho-R2




Tho-A



Data for return line temperature sensor (BT3), condenser supply (BT12) and fluid pipe (BT15)


Temperature (°C)	Resistance (kOhm)	Voltage (VDC)
-40	351.0	3.256
-35	251.6	3.240
-30	182.5	3.218
-25	133.8	3.189
-20	99.22	3.150
-15	74.32	3.105
-10	56.20	3.047
-5	42.89	2.976
0	33.02	2.889
5	25.61	2.789
10	20.02	2.673
15	15.77	2.541
20	12.51	2.399
25	10.00	2.245
30	8.045	2.083
35	6.514	1.916
40	5.306	1.752
45	4.348	1.587
50	3.583	1.426
55	2.968	1.278
60	2.467	1.136
65	2.068	1.007
70	1.739	0.891
75	1.469	0.785
80	1.246	0.691
85	1.061	0.607
90	0.908	0.533
95	0.779	0.469
100	0.672	0.414

8 Accessories




VVM 310

Indoor module.
Part no. 069 084



VVM 500

Indoor module.
Part no. 069 400



Ground stand F2040

Part no. 015 268



Wall mounting F2040

Part no. 067210



KVR 10 F2040

Condensation water pipe,
different lengths.
Earth circuit breaker 1-
phase.

KVR 10-10 F2040, 1 m
Part no. 067 233

KVR 10-30 F2040, 2.5 m
Part no. 067 235

KVR 10-60 F2040, 5 m
Part no. 067 237



VPA

Double-jacketed hot water
cylinder

VPA 300/200

Part no. 088 710

VPA 450/300

Part no. 088 660

VPAS 300/450 Copper

Part no. 087 720

VPAS 300/450 Enamel

Part no. 087 710



VPB

Hot water heater with
charge coil

VPB 500* Part no. 083 220

VPB 750-2 Part no. 083 231

VPB 1000 Part no. 083 240



SMO 20

Control module
Part no. 067 224





SMO 40

Control module
Part no. 067 225

9 Technical data

Dimensions and setting-out coordinates




* Accessory KVR 10 is required.

Sound pressure levels

F2040 is usually placed next to a house wall, which gives a directed sound distribution that should be considered. Accordingly, you should always attempt when positioning to choose the side that faces the least sound sensitive neighbouring area.

The sound pressure levels are further affected by walls, bricks, differences in ground level, etc and should therefore only be seen as guide values.

F2040 adjusts the fan speed depending on the ambient temperature and evaporation temperature.



F2040 12 kW		
Sound power level* According to EN12102 at 7/45 (nominal)	$L_W(A)$	63.5
Sound pressure level at 2 m free standing.*	dB(A)	49.5
Sound pressure level at 6 m free standing.*	dB(A)	40.0
Sound pressure level at 10 m free standing.*	dB(A)	35.5

* Free space.

Technical specifications


F2040 12 kW		
Heating	Outd. temp: / Supply temp.	Nominal
Output data according to EN14511 $\Delta T5K$ Specified/supplied power/COP	7/35 °C (floor)	4.81/1.07/4.52
	2/35 °C (floor)	6.46/1.75/3.69
	-7/35 °C (floor)	8.92/3.10/2.87
	2/55 °C	6.49/2.55/2.54
	7/45 °C	4.72/1.30/3.62
	2/45 °C	6.67/2.18/3.06
	-7/45 °C	9.04/3.71/2.44
	-15/45 °C	9.12/4.56/2.00
	7/55 °C	4.49/1.57/2.86
-7/55 °C	9.38/4.69/2.00	
Cooling	Outd. temp: / Supply temp.	Nominal
Output data according to EN14511 $\Delta T5K$ Specified/supplied power/EER	27/7 °C	8.75/1.86/4.72
	27/18 °C	10.82/2.21/4.91
	35/7 °C	6.98/2.54/2.75
	35/18 °C	9.37/2.64/3.56
Electrical data		
Rated voltage		230V 50 Hz, 230V 2AC 50Hz
Max operating current, heat pump	A_{rms}	23
Max operating current, compressor	A_{rms}	22
Starting current	A_{rms}	5
Max permitted impedance at connection point ¹⁾	Ohm	-
Nominal output, fan	W	86
Fuse ²⁾	A_{rms}	25
Refrigerant circuit		
Type of refrigerant		R410A
Type of compressor		Twin Rotary
Volume	kg	2.9
Cut-out value pressostat HP	MPa	4.15 (41.5 bar)
Cut-out value pressostat LP	MPa	0.079 (0.79 bar)
Brine		
Airflow	m ³ /h	4380
Max/Min air temp	°C	-20/43
Defrosting system		reverse cycle
Heating medium		
Min/Max system pressure heating medium	MPa	0.05/0.25 (0.5/2.5bar)
Min volume, climate system, heating/cooling	l	80
Min volume, climate system, under floor cooling	l	100
Max flow, climate system	l/s	0.57
Min flow, climate system, at 100% circulation pump speed (defrosting flow)	l/s	0.29
Min flow, heating	l/s	0.15

F2040 12 kW		
Min flow, cooling	l/s	0.20
Internal pressure drop at nominal flow 0.22 l/s	kPa	3.5
Max/Min heating medium temp continuous operation	°C	58/25
Connection heating medium ext thread		G1"
Dimensions and weight		
Width	mm	1145
Depth	mm	452
Height with stand	mm	995 (+50/-0)
Weight (excl. packaging)	kg	105
Miscellaneous		
Enclosure class		IP 24
Colour		dark grey
Part No.		064 092

¹)Max. permitted impedance in the mains connected point in accordance with EN 61000-3-11. Start currents can cause short voltage dips that could affect other equipment in unfavourable conditions. If the impedance in the mains connection point is higher than that stated it is possible that interference will occur. If the impedance in the mains connection point is higher than that stated check with the power supplier before purchasing the equipment.


²)Specified output is limited with lower fusing.


Working range, compressor operation - heating



During shorter time it is allowed to have lower working temperatures on the water side, e.g. during start up.

Working range, compressor operation - cooling





10 Item register

Item register

A

- Accessories, 25
- Adjustment, charge flow, 21
- Ambient temperature sensor, 18
- Assembly, 5

C

- Commissioning and adjusting, 19
 - Adjustment, charge flow, 21
 - Compressor heater, 19
 - Filling and venting the heating medium system, 19
 - Preparations, 19
 - Readjusting, heating medium side, 20
 - Start-up and inspection, 20
- Communication, 18
- Compressor heater, 19
- Connecting accessories, 15
- Connections, 17
- Contact information, 4

D

- Delivery and handling, 5
 - Assembly, 5
 - Installation area, 7
 - Removing the covers, 7
 - Removing the front panel, 8
 - Removing the side panel, 8
 - Supplied components, 7
 - Transport and storage, 5
- Dimensions and setting-out coordinates, 26
- Disturbances in comfort, 22
 - Troubleshooting, 22
- Docking alternatives, 15

E

- Electrical circuit diagram, 31
- Electrical connection, 11
- Electrical connections, 16
 - Ambient temperature sensor, 18
 - Communication, 18
 - Connecting accessories, 15
 - Connections, 17
 - External heating cable (KVR 10), 18
 - General, 16
 - Power connection to rear side (standard) or underneath (alternative), 17
- External heating cable (KVR 10), 18

F

- Filling and venting the heating medium system, 19

I

- Important information, 2
 - Safety information, 2
- Inspection of the installation, 3
- Installation area, 7

M

- Marking, 2

P

- Pipe connections, 13
 - Docking alternatives, 15
 - General, 13
 - Pipe coupling heating medium circuit, 13
 - Water volumes, 13
- Pipe coupling heating medium circuit, 13
- Power connection to rear side (standard) or underneath (alternative), 17
- Preparations, 19

R

- Readjusting, heating medium side, 20
- Removing the covers, 7
- Removing the front panel, 8
- Removing the side panel, 8


S

- Safety information, 2
 - Contact information, 4
 - Inspection of the installation, 3
 - Marking, 2
 - Serial number, 2
 - Symbols, 2
- Sensor placement, 23
- Serial number, 2
- Sound pressure levels, 27
- Start-up and inspection, 20
- Supplied components, 7
- Symbols, 2

T

- Technical data, 26
 - Dimensions and setting-out coordinates, 26
 - Electrical circuit diagram, 31
 - Sound pressure levels, 27
 - Technical Data, 28
- Technical Data, 28
- The heat pump design, 9
 - Component locations, 9
 - Electrical components, 11
 - Electrical connection, 11
 - List of components, 9
 - Transport and storage, 5
 - Troubleshooting, 22
 - Sensor placement, 23

NIBE AB Sweden
Hannabadvägen 5
Box 14
SE-285 21 Markaryd
info@nibe.se
www.nibe.eu



231030