

[Перейти на сайт](#)

USER MANUAL

RACK MOUNT 1/2/3/6kVA



Table of Contents

1. Introduction	1
2. Safety Instructions.....	2
3. System Description	4
3.1 <i>Display Panel</i>	4
3.2 <i>Rear Panel</i>	5
4. Maintenance.....	7
4.1 <i>Operation Environment</i>	7
4.2 <i>Battery Application</i>	7
4.3 <i>Troubleshooting</i>	7
5. Technical Data.....	9
5.1 <i>Electrical Specification</i>	9
5.2 <i>Typical Stored Energy Time</i>	9
5.3 <i>Mechanical Data</i>	9
5.4 <i>Standards Conformity</i>	10
5.5 <i>Communication Port</i>	10
5.5.1 <i>RS232 Interface</i>	11
5.5.2 <i>AS400 Interface</i>	11

1. INTRODUCTION

This series is an industry rack-mount design of an advanced true-online sinewave Uninterruptible Power System. It protects your systems by supplying battery backup when power fails. By using with WinPower software, the uninterruptible power system (UPS) will safely save current data and gracefully shut down the operating system before the battery is fully discharged. It provides perfect protection specifically for file servers, minicomputers, Internet hubs, telecommunication systems and other mission-critical applications. It can auto restart while AC source restored after discharge shutdown and it also can support the automatic transfer or re-transfer to Inverter mode after the overload is cleared.

This rack-mount series includes: C1KR(S), C2KR(S), C3KR(S), C6KR. The models with suffix "S" allow for extending runtime by simply plugging in additional battery packs. In this manual, hereafter, 1K(S) represents model C1KR(S), 2K(S) represents model C2KR(S), 3K(S) represents model C3KR(S), and 6K represents model C6KR.

2. SAFETY INSTRUCTIONS

PLEASE READ THIS USER MANUAL AND THE SAFETY INSTRUCTIONS BEFORE INSTALLING THE UNIT AND STARTING IT UP!

Transport

- Please transport the UPS system only in the original packaging (to protect against shock and impact).

Set-up

- Condensation may occur if the UPS system is moved directly from a cold to a warm environment. The UPS system must be absolutely dry before being installed. Please allow an acclimatization time of at least two hours.
- Do not install the UPS system near water or in damp environment.
- Do not install the UPS system where it would be exposed to direct sunlight or near heat.
- Do not block air vents in the front, in the back or on the sides of the UPS.

Installation

- Do not connect appliances or items of equipment which would overload the UPS system (e.g. laser printers) to the UPS outlet socket.
- Place cables in such a way that no one can step on or trip over them.
- Do not connect household appliances such as hair dryers to the UPS output sockets.
- The UPS can be operated by any individuals with no previous training.

Following for 1K(S)/2K(S)/3K(S) only

- Connect the UPS system only to an earthed shockproof socket outlet.
- The utility power socket-outlet (shockproof socket-outlet) must be easily accessible and close to the UPS system.
- During the installation of this equipment it should be assured that the sum of the leakage current of the UPS and the connected loads does not exceed 3.5mA.

Following for 6K only

- **Warning** - This is a product for designated sales distribution to authorized partners. Installation or additional measures should be carried out by qualified personnel to prevent disturbances.
- A readily accessible disconnection device shall be incorporated in the building installation wiring and the disconnection device must be easily accessible and close to the UPS system.
- Only qualified maintenance personnel may carry out installations.

2. SAFETY INSTRUCTIONS

Operation

- The UPS system features its own, internal current source (batteries). The UPS output sockets may contain hazardous voltage through operation from the battery even if the UPS system is not connected to the utility power socket-outlet.
- In order to fully disconnect the UPS system, first press the Standby switch then disconnect the mains .
- Ensure that no fluids or other foreign objects can enter the UPS system.


Maintenance, servicing and faults

- The UPS system operates with hazardous voltages. Repairs should be carried out only by qualified maintenance personnel.
- **Caution** - risk of electric shock. Even after the unit is disconnected from the mains power supply (utility power socket -outlet), components inside the UPS system are still connected to the battery and still present hazardous voltage.
- Before carrying out any kind of servicing and/or maintenance, disconnect the batteries and verify that no current is present and no hazardous voltage exists in the terminals of high capability capacitors such as BUS capacitors.
- The batteries can present a risk of high voltage and high current. Replacement or maintenance of the batteries should be carried out by qualified service personnel who are knowledgeable about batteries. No other persons should handle the batteries.
- **Caution** - risk of electric shock. The battery circuit is not isolated from the input voltage. Hazardous voltages may occur between the battery terminals and the ground. Before touching, please verify that no hazardous voltage is present!
- Batteries may cause electric shock and have a high short-circuit current. Please take the precautionary measures specified below and any other measures necessary when working with batteries:
 - remove wristwatches, rings and other metal objects
 - use only tools with insulated grips and handles.
- When replacing the batteries, install the same number and the same type of the batteries.
- Do not incinerate batteries, they may explode.
- Do not open or mutilate batteries, released electrolyte is highly poisonous and harmful to the skin and eyes.
- Please replace the fuse only with a fuse of the same type and same amperage in order to avoid fire hazards.

3. SYSTEM DESCRIPTION

3.1 DISPLAY PANEL

The power control and the operating indicators are located on the front panel of the UPS.



ON-SWITCH

- The UPS can be turned on by pressing ON-SWITCH button for 1 second.
- An acoustic alarm can be deactivated by pressing ON-SWITCH button again in battery mode.
- To perform self-diagnosis, by Pressing ON-SWITCH again in utility power mode.

STANDBY-SWITCH

- The inverter can be turned off by pressing STANDBY-SWITCH. The output can be provided by the mains power via the BYPASS.

AC INPUT LED

- Lights up when the mains power is available.
- Blinks and the BATTERY-LED lights up at the same time when the mains power is out of tolerance.
- Blinks when the input polarity of the live conductor(L) and the neutral conductor (N) of site wiring reversed.

UPS ON LED

- Lights up when output power is supplied by the mains power via the inverter.

BATTERY LED

- Lights up when the mains power fails and the inverter is powered by the batteries.

BYPASS LED

- Lights up when output power is provided by the mains power via the bypass.

ALARM LED

- Lights up when the UPS system is in fault condition, at the same time, the acoustic alarm beeps continuously or beeps every second according to the different fault conditions.

3. SYSTEM DESCRIPTION



INDICATOR 1-5

- Shows the load level in utility power mode.
- Shows the battery level in battery mode.


	load level	battery level
INDICATOR 1	96%-105%	1%-35%
INDICATOR 2	76%-95%	36%-55%
INDICATOR 3	56%-75%	56%-75%
INDICATOR 4	36%-55%	76%-95%
INDICATOR 5	1%-35%	96%-100%

3.2 REAR PANEL


The rear panels of the UPS and the battery packs are shown as below:




3. SYSTEM DESCRIPTION




2KS/3K(S)



6K



Battery Pack for 1KS/2K(S)/3K(S)



Battery Pack for 6K

3. SYSTEM DESCRIPTION

Surge Protection(RJ45 Port): This is a transient voltage surge-suppressor for network or fax/modem protection.

Communication Port: WinPower software can be used with the UPS for power management. Standard serial interface cable is compatible with 1K(S)/2K(S)/3K(S) UPS, however, only the special cable supplied with the UPS can be used on 6K UPS.

Input/Output: If socket is available, just insert compatible cable plug. If terminal is available, qualified electrician should be required for wiring and installation.

Note: Terminal cover should be put back for safety reason after wiring completed.

Input Breaker: If the breaker is tripped, reduce the load connected to the UPS and reset the breaker.

External Battery Socket: Dedicated battery power cable is supplied with the battery pack. Insert the cable into the external battery socket on the UPS and battery pack output socket separately to connect battery pack to the UPS. The same battery packs can be daisy chained together to achieve desired run time.

Notes: It is suggested that one battery pack can be connected with one UPS main unit. Only the identical battery packs can be connected in parallel to the models with suffix "S" to extend the backup time .Please consult the distributor for further information.

4.1 OPERATION ENVIRONMENT

Ambient Temperature: 0°C to 40°C

Height of sea level < 1000m

Relative humidity: <95%

4.2 BATTERY APPLICATION

Simply connect the UPS to the mains to fully charge the batteries for 12 hours prior to use is recommended. It can also be used immediately without charging the batteries first but the backup time will be less than standard level.

Under normal conditions, the battery life lasts 3 to 5 years. In case if the battery is found not in good condition, earlier replacement should be made. The replacement of the battery should be carried out by qualified service personnel . Please contact the distributor .

The battery should be charged once every three months for at least 12 hours. In areas with higher temperatures, the battery should be charged once every two months and each charging period shall be at least 12 hours.

4. MAINTENANCE

4.3 TROUBLESHOOTING

The troubleshooting chart covers most of the difficulties that you may encounter under normal working condition. Such information can be used to determine whether the fault is caused by external factors or how to tackle the problem. If the UPS still fails to operate properly, please contact the service centre as soon as possible. Be sure you have the following information when contacting the service personnel:

1. Model number, serial number
2. Date on which the problem occurred
3. Description in detail of the problem

PROBLEM	POSSIBLE CAUSE	CORRECTIVE ACTION
No indication, no audible alarm even though the UPS is connected to mains power supply	No input voltage	Check building wiring socket-outlet, input power cable, input breaker.
AC INPUT LED blinks	Maybe reversed polarity (L/N) of site wiring.	Please check the polarity of site wiring or building wiring.
AC INPUT LED blinks and BATTERY LED lights up	Input power and/or frequency are out of tolerance	The UPS is now running in battery mode. To save your data and then close the applications, ensure that mains power is within the input voltage/frequency range of the UPS
AC INPUT and BYPASS LED light up even though the power supply is available	Inverter not switched on	Press On button "I"
UPS ON LED lights up, warning sound at intervals of every 1 or 4 seconds	Mains power supply has failed	In battery mode operation; warning sound at intervals of 1 second means battery discharge near ending
ALARM LED lights up, warning sound once a second	Overloaded	Reduce number of loads connected to the UPS
ALARM -LED lights up, the alarm beeps continuously	Maybe the UPS has internal faults	Call for services
Battery discharge time diminishes	Batteries not fully charged / batteries aged/batteries defected	Charge the batteries for at least 12 hours. Please consult the distributor or call for battery replacement

5. TECHNICAL DATA

5.1 ELECTRICAL SPECIFICATIONS

Model	C1KR/ C1KRS	C2KR/ C2KRS	C3KR/C3KRS	C6KR
INPUT				
Voltage	220VAC			
Frequency	46 Hz ~ 54 Hz（Adjustable）			
Amperage (maximum)	5A	10A/12A	15 A	30A
OUTPUT				
Power rating	1kVA 0.7k W	2kVA 1.4kW	3kVA 2.1kW	6kVA 4.2kW
Voltage	220VAC			
Frequency	50Hz±0.2Hz(Battery Mode)			50 Hz(1±0.1%) (Battery Mode)
Wave form	Sinusoidal			
BATTERIES(STANDARD)				
Number and type	3x12V7.2Ah	8x12V7.2Ah		20x12V7.2Ah
Nominal voltage	36VDC	96VDC		240VDC



5.2 TYPICAL BACKUP TIME (BATTERY MODE)

Typical values at 25°C in minutes:

Model	100 % Load	50 % Load
C 1 K R	5	14
C 2 K R	9	21
C 3 K R	5	15
C 6 K R	8	23

Notes: Backup time of "S" models, please consult the distributor.

5.3 MECHANICAL DATA

Model	Net Weight(kg)	Dimention (mm)
C 1 K R	16.3	 <p>Depth: 450</p>
C 1 K R S	9.1	
Battery Pack 36VDC	22.5	
C 2 K R	10.3	
C 2 K R S	11.5	
C 3 K R	11.2	
C 3 K R S	12.3	 <p>Depth: 600</p>
Battery Pack 96VDC	27.8	
C 6 K R	18.3	
Battery Pack 240VDC	64.2	

5. TECHNICAL DATA

5.4 STANDARDS CONFORMITY

1K(S)/2K(S)/3K(S)

Conducted Emission: EN50091-2 Class B

Radiated Emission: EN50091-2 Class B

Harmonic Current: EN61000-3-2

Voltage Fluctuations and Flicker: EN61000-3-3

EMS: EN61000-4-2(ESD) Level 4

 EN61000-4-3(RS) Level 3

 EN61000-4-4(EFT) Level 4

 EN61000-4-5(Lighting Surge) Level 4

 EN61000-2-2(Immunity to low frequency signals)

6K

Conducted Emission:

 EN50091-2 Rated output current exceeding 25A limits

Radiated Emission:

 EN50091-2 Rated output current exceeding 25A limits

EMS: EN61000-4-2(ESD) Level 4

 EN61000-4-3(RS) Level 3

 EN61000-4-4(EFT) Level 4

 EN61000-4-5(Lighting Surge) Level 4

 EN61000-2-2(Immunity to low frequency signals)

5.5 COMMUNICATION PORT

The UPS is equipped with a standard RS232 port to communicate with a host computer. The RS232 communication port transmits both utility power and UPS status to the host computer, providing the host computer with proprietary command sequence to monitor the utility power and the UPS status and to control the UPS through WinPower software.

The data format of RS232 :

Baud Rate : 2400 bps

Data Length : 8 bits

Ending Bit : 1 bit


Parity Bit : none

5. TECHNICAL DATA

5.5.1 RS232 INTERFACE

The following is the pin assignment and description of DB-9 connector.

Pin#	Description	I/O
2	RS232 Tx	Output
3	RS232 Rx	Input
5	Ground	Input




RS232 Interface

5.5.2 AS400 INTERFACE

Except for the communication protocol as mentioned above, this series UPS has an optional AS400 card for AS400 communication protocol. Please contact your local distributor for details.

The following is the pin assignment and description of DB-9 connector in AS400 card.

Pin#	Description	I/O type
1	UPS Failure	Output
2	Summary Alarm	Output
3	GND	
4	Remote shutdown	Input
5	Common	
6	Bypass	Output
7	Battery Low	Output
8	UPS ON	Output
9	Utility power failure(Line Loss)	Output



DB9 Interface of AS400 communication protocol