

KACO PREMIUM P

blueplanet 20.0 TL3

Operating Instructions

■ English translation of German original





Operating Instructions

Contents

1	General information4	7.6	Connecting the interfaces	23
1.1	About this document4	7.7	Sealing the connection area	27
1.2	Layout of Instructions4	7.8	Switching on the device	28
1.3	Target group5	8	Configuration and Operation	29
2	Safety5	8.1	Controls	29
2.1	Proper use6	8.2	Initial start-up	32
2.2	Protection features6	8.3	Menu structure	32
2.3	More information6	8.4	Monitor inverter	43
3	Description7	8.5	Performing the software update	45
3.1	Mode of Operation7	9	Maintenance/Troubleshooting	46
3.2	Diagram7	9.1	Visual inspection	46
4	Technical Data10	9.2	Cleaning the housing	46
4.1	Electrical data10	9.3	Replacing or cleaning the fans	46
4.2	Mechanical data11	9.4		
4.3	Identification11		troubleshooting	
5	Transportation and Delivery12	9.5	Disconnecting connections	48
5.1	Delivery12	9.6	Faults	49
5.2	Transportation12	9.7	"Fault" messages on the display/LED	
6	Mounting13	10	Service	55
6.1	Unpacking14	11	Shutdown/Disassembly	55
6.2	Installing the unit15	11.1	Switching off the unit	55
7	Electrical connection16	11.2	Uninstalling the device	56
7.1	Preparing the AC connection16	11.3	Disassembling the unit	56
7.2	Connection to the power grid18	11.4	Packaging the unit	56
7.3	Preparing the DC connection19	11.5	Storing the unit	56
7.3 7.4	Connecting the PV generator20	12	Disposal	56
7.5 7.5	Grounding the housing23	13	Appendix	57
, .5	Grounding the flouding23	13.1	EU Declaration of Conformity	57

KACC



General information

About this document 1.1



WARNING



EN

Improper handling of the device can be hazardous!

> You must read and understand the operating instructions so that you can install and use the device safely!

1.1.1 Other applicable documents

During installation, observe all assembly and installation instructions for components and other parts of the system. These instructions also apply to the equipment, related components and other parts of the system.

Some of the documents which are required for the registration and approval of your photovoltaic (PV) system are included with the operating instructions.

1.1.2 Storing the documents

These instructions and other documents must be stored near the system and be available at all times. The content of these instructions is revised on a regular basis and updated if necessary. You can download the current version of the operating instructions at www.kaco-newenergy.com.

English translation of German original 1.1.3

These operating instructions have been produced in several languages. The German-language version of the operating instructions is the original version. All other language versions are translations of the original operating instructions.

1.2 Layout of Instructions

1.2.1 Symbols used



General hazard



Risk of fire or explosion



High voltage



Risk of burns

Authorised electrician symbol!

Only authorised electricians are permitted to carry out tasks indicated with this

Safety warnings symbols guide 1.2.2



DANGER

Failure to observe this warning will lead directly to serious bodily injury or death.





WARNING

Potential risk

Failure to observe this warning may lead to serious bodily injury or death.





CAUTION

Low-risk hazard

Failure to observe this warning will lead to minor or moderate bodily injury.



CAUTION

Risk of damage to property

Failure to observe this warning will lead to property damage.

1.2.3 Additional information symbols



NOTE

Useful information and notes

EN Country-specific function

Functions restricted to one or more countries are labelled with country codes in accordance with ISO 3166-1.

1.2.4 Instructions symbols guide

Instructions

- U Prerequisites before carrying out the following instructions (optional)
- Carry out step.
- (Additional steps, if applicable)
- » Result of the step(s) (optional)

1.3 Target group

All activities described in the document may only be carried out by specially trained personnel with the following qualifications:

- Knowledge about how an inverter functions and operates
- Training in the handling of hazards and risks during the installation and operation of electrical units and systems
- Education concerning the installation and startup of electrical units and systems
- · Knowledge of applicable standards and directives
- Knowledge and adherence to this document with all safety notices.

2 Safety



🚹 DANGER

Lethal voltages are still present in the terminals and cables of the inverter even after the inverter has been switched off and disconnected.

Severe injuries or death will occur when touching the cables and terminals in the inverter.

Only appropriately qualified and authorised electricians may open, install or maintain the inverter.

- > Keep the inverter closed when the unit is in operation.
- > Do not touch the cables and/or terminals when switching the unit on and off.
- > Do not make any modifications to the inverter.

The electrician is responsible for observing all existing standards and regulations.

- Keep unauthorised persons away from the inverter and PV system.
- In particular, be sure to observe the standard IEC-60364-7-712:2002 "Requirements for special installations or locations solar photovoltaic (PV) power supply systems".
- Ensure operational safety by providing proper grounding, conductor dimensioning and appropriate protection against short circuiting.





- Observe all safety instructions on the inverter and in these operating instructions.
- Switch off all voltage sources and secure them against being inadvertently switched back on before performing visual inspections and maintenance.
- When taking measurements while the inverter is live:
 - Do not touch the electrical connections.
 - Remove all jewellery from your wrists and fingers.
 - Ensure that the testing equipment is in safe operating condition.
- · Stand on an insulated surface when working on the inverter.
- Modifications to the surroundings of the inverter must comply with the applicable national and local standards.
- When working on the PV generator, it is also necessary to switch off the DC voltage with the DC isolator switch in addition to disconnecting the PV generator from the grid.

2.1 Proper use

The inverter converts the DC voltage generated by the PV modules into AC voltage and feeds it into the grid. The inverter is built according to the latest technological standards and safety regulations. Nevertheless, improper use may cause lethal hazards for the operator or third parties, or may result in damage to the unit and other property.

Operate the inverter only with a permanent connection to the public power grid.

Any other or additional use of the device shall be regarded as improper. This includes:

- · Mobile use,
- Use in rooms where there is a risk of explosion,
- Use in outdoor areas if the inverter is exposed to direct sunlight, rain or a storm
- Use in rooms where the humidity is higher than 95%
- · Operation outside of the specifications intended by the manufacturer
- · Modifying the device
- · Standalone operation.

2.2 Protection features

The following monitoring and protection functions are built-in:

- Overvoltage conductors/varistors to protect the power semiconductors from high-energy transients on the grid and generator side
- · Temperature monitoring of the heat sink
- EMC filters to protect the inverter from high-frequency grid interference
- Grid-side grounded varistors to protect the inverter against burst and surge pulses
- · Islanding detection according to the current standards.

2.3 More information



NOTE

The EU Declaration of Conformity can be found in the appendix.

For information on grid coupling, grid protection and safety parameters along with more detailed instructions see our web site at http://www.kaco-newenergy.de/.

3 Description

3.1 Mode of Operation

The inverter converts the DC voltage generated by the PV modules into AC voltage and feeds it into the grid. The starting procedure begins when there is sufficient sunlight and a specific minimum voltage is present in the inverter. The feed-in process begins once the PV generator has passed the insulation test and the grid parameters are within the requirements imposed by the grid operator for a specific monitoring time. If, as it gets dark, the voltage drops below the minimum voltage value, feed-in operation ends and the inverter switches off.

3.2 Diagram




Figure 1: Inverter diagram

Key

1	Housing with control panel	4	Connection board
2	Cover for the connection area	5	USB interface
3	DC isolator switch	6	Mounting plate

3.2.1 Mechanical components

DC isolator switch

The DC isolator switch is located on the bottom side of the inverter housing. The DC isolator switch is used to disconnect the inverter from the PV generator in order to carry out service.



Figure 2: DC isolator switch

Disconnecting the inverter from the PV generator

Switch the DC isolator switches from 1 (ON) to 0 (OFF).

Connecting the inverter to the PV generator

Switch the DC isolator switches from 0 (OFF) to 1 (ON).

3.2.2 Electrical functions

A potential-free relay contact is integrated in the inverter. Use this contact for one of the following functions:





Fault signal relay

The potential-free relay contact closes as soon as there is a fault during operation. You use this function, for example, to signal a fault visually or acoustically.

Priwatt

The energy that is provided by the PV system can be put to use directly by the appliances that are connected in your home.

The potential-free contact can switch larger appliances (e.g. air conditioning units) on and off with the "priwatt" function activated. This requires an external power supply and an external load relay.

When the function is active, either the remaining runtime (in hours and minutes) or the shutdown threshold (in kW) is displayed on the start screen depending on the operating mode selected. The "priwatt" function is not active in the unit's delivery state. The option can be configured in the Settings menu.

3.2.3 Interfaces

You configure the interfaces and the web server in the Settings menu.

The inverter has the following interfaces for communication and remote monitoring:

Ethernet interface

Monitoring can occur directly on the unit using the integrated Ethernet interface. A local web server is installed in the unit for this purpose.

For monitoring a system comprising several inverters, we recommend you use an external data logging and monitoring system.

RS485 interface

In addition to the monitoring via the Ethernet interface, the monitoring can be executed via the RS485 interface. For monitoring your PV system using the RS485 interface, KACO new energy GmbH offers monitoring devices:

USB interface

The USB connection of the inverter is a type A socket. It is located on the connection board on the underside of the inverter under a cover. The USB connection is specified to draw 100 mA of power. Use the USB interface to read out stored operating data and to load software updates using a FAT32-formatted USB stick.

"Inverter Off" input

If Powador protect is installed as a central grid and system protection, the fail-safe disconnection of suitable KACO inverters from the public grid can be initiated by a digital signal instead of tie circuit-breakers. This requires the inverters in the photovoltaic system to be connected to the Powador protect.

If a Powador-protect is used for fast shutdown, it must be used as grid protection. The RS485 interface is not required for this.

Information on installation and use can be found in this manual, in the Powador protect manual and in the instructions for use of the Powador protect on the KACO web site.



3.2.4 Inverter as part of a PV system




Figure 3: Circuit diagram of a system with two inverters

Key	Definition / Information about the connection
PV generator	The PV generator, i.e. the PV modules, converts the radiant energy of sunlight into electrical energy.
Inverter with:	
- DC connection	The PV generator is connected directly to the inverter's DC connection. Two strings can be connected to the DC connection.
- DC isolator switch	Use the DC isolator switch to disconnect the inverter from all power sources on the PV generator side.
Circuit breaker	A circuit breaker is an overcurrent protection device.
Feed-in meter	The feed-in meter is to be specified and installed by the power supply company. Some power supply companies also allow the installation of your own calibrated meters.
Selective main switch	The selective main switch is to be specified by the power supply company.



4 Technical Data

4.1 Electrical data

Product name: KACO blueplanet	20.0 TL3		
Input levels			
Recommended power range of the generator [kW]	24		
MPP@Pnom from [V] to [V]	515 800		
Operating range from [V] to [V]	200 950		
Starting voltage [V] *	250		
No-load voltage (U _{OC max}) [V]	1,000 (start up to 1,000)		
Max. input current [A]	2 x 20		
Max. power per MPP tracker [W]	15,000		
Number of strings	2 x 2		
Number of MPP trackers	2		
max. short-circuit current (I _{SC max}) [A]	2 x 32		
max. input source feedback current [A]	0		
Polarity safeguard	Short-circuit diode		
Output levels			
Rated power [VA]	20000 @230 V		
Grid voltage [V]	400/230 (3/N/PE)		
Gild Voltage [V]	380/220 (3/N/PE)		
Rated current [A]	3 x 29		
Contribution to peak short-circuit current [A]	56,76		
Initial short-circuit alternating current (lk" first single period effective value) [A]	18.6		
Start-up current [A]	4.52		
Rated frequency [Hz]	50/60		
cos phi	0.30 inductive 0.30 capacitive		
Number of feed-in phases	3		
Distortion factor (THD) [%]	2.22		
General electrical data			
Max. efficiency [%]	97,9		
European efficiency [%]	97.6		
Self consumption: night [W]	1.5		
Feed-in starts at [W]	20		
Circuit design	Transformerless		
Grid monitoring	Country-specific		
Table 1: Electrical data			



4.2 Mechanical data

Product name: KACO blueplanet	20.0 TL3
Display	Graphical LCD, 3 LEDs
Controls	4-way button, 2 buttons
Interfaces	2x Ethernet, USB, RS485, Error-Relais, Via the additional modules as an option: 4-DI
Fault signal relay	Potential-free NO contact, 30 V / 1 A
AC connections: PCB terminal	PCB terminals inside the unit (max. cross section: 16 mm²)
AC connections: Cable connection	Cable connection via M40 cable fitting
DC connections	8 (2 x 4) MC-4-compatible plug connections
Ethernet connection: Cable connection	Cable connection via M25 cable fitting
Ambient temperature range [°C]	-25 +60, power derating from +40
Humidity range (non-condensing) [%]	0 95
Maximum installation elevation [m above sea level]	2,000
Temperature monitoring	Yes
Cooling (free convection (K)/fan (L))	L
Protection rating according to EN 60529	IP65
Degree of contamination	2
Noise emission [dB(A)]	<53
DC isolator switch	Built-in
Housing	Cast aluminium
H x W x D [mm]	690 x 420 x 200
Total weight [kg]	46.6
CE conformity	Yes

Table 2: Mechanical data

4.3 Identification

Identifying the unit

- U You will find the name plate with product-specific data for service and other requirements specific to installation on the right side panel of the inverter. This data includes:
- Product name
- · Part no.
- Serial no.
- Date of manufacture
- Technical Data
- Disposal information
- Certification marking, CE marking.



Figure 4: Name plate

^{*} The DC starting voltage can be set in the menu if needed.





5 Transportation and Delivery

5.1 Delivery

Every inverter leaves our factory in proper electrical and mechanical condition. Special packaging ensures that the units are transported safely. The shipping company is responsible for any transport damage that occurs.

Scope of delivery

- 1 inverter
- 1 wall bracket
- 1 installation kit
- 1 set of documentation (DE, EN, quick start guide in other languages)

Checking your delivery

- 1. Inspect your inverter thoroughly.
- 2. Immediately notify the shipping company in case of the following:
 - Damage to the packaging that indicates that the inverter may have been damaged
 - Obvious damage to the inverter
- 3. Send a damage report to the shipping company immediately.

The damage report must be received by the shipping company in writing within six days following receipt of the inverter. We will be glad to help you if necessary.


5.2 Transportation

CAUTION

Impact hazard, risk of breakage to the inverter

- > Pack the inverter securely for transport.
- > Carefully transport the inverter using the carrying handles of the packaging box.
- > Do not subject the inverter to shocks.

For safe transportation of the inverter, use the holding openings in the carton.



Packaging
(folding cartons)
(H x W x D (mm)) 290 x 480 x 750
Total weight [kg] 52

Figure 5: Transportation of the inverter

Table 3: Dimensions and weight

6 Mounting

<u>^</u>

DANGER

Risk of fatal injury from fire or explosions



Fire caused by flammable or explosive materials in the vicinity of the inverter can lead to serious injuries.

Do not mount the inverter in an area at risk of explosion or in the vicinity of highly flammable materials

Installation location

- As dry as possible, climate-controlled, the waste heat must be dissipated away from the inverter
- Unobstructed air circulation
- · When installing the unit in a control cabinet, provide forced ventilation for sufficient heat dissipation
- · Access to the inverter must also be possible without additional tools
- For outdoor installation, fit the inverters in such a way to ensure that they are protected against direct sunlight, moisture and dust penetration
- · For easy operation, ensure during installation that the display is slightly below eye level.

Wall surface

- · With sufficient load-bearing capacity
- · Accessible for installation and maintenance
- Made from heat-resistant material (up to 90 °C),
- · Flame resistant
- · Minimum clearances to be observed during assembly: see Figure 10 on page 15.



NOTE

Access by maintenance personnel for service

Any additional costs arising from unfavourable structural or mounting conditions shall be billed to the customer.

CAUTION

Property damage due to gases that have an abrasive effect on surfaces when they come into contact with ambient humidity caused by weather conditions.

The inverter housing can be severely damaged by gases (ammonia, sulphur, etc.) if it comes into contact with ambient humidity caused by weather conditions.

If the inverter is exposed to gases, it must be mounted so that it can be seen at all times.

- > Perform regular visual inspections.
- > Immediately remove any moisture from the housing.
- > Take care to ensure sufficient ventilation of the inverter.
- > Immediately remove dirt, especially on vents.
- > Failure to observe these warnings may lead to inverter damage which is not covered by KACO's manufacturer warranty.



NOTE

Power reduction due to heat accumulation.

If the recommended minimum clearances are not observed, the inverter can go into power regulation mode or protective shutdown due to insufficient ventilation and the resulting heat buildup.

- > Maintain minimum clearances.
- > Provide for sufficient heat dissipation.








Figure 6: Instructions for wall mounting

Figure 7: Inverter for outdoor installation

CAUTION

Use suitable mounting parts.

- > Use only the supplied mounting parts.
- > Mount the inverter upright on a vertical wall only.
- > For a free-standing mounting an incline of 20° is allowed.


6.1 **Unpacking**

CAUTION

The inverter is very heavy – risk of injury!



- > Observe the weight of the inverter during transport.
- > Select suitable mounting location and mounting base.
- > Use mounting material corresponding to or included with the base for mounting the inverter.
- > Transport and install the inverter with at least 2 persons.






Figure 8: Unpack inverter

Figure 9: Lifting the inverter

ı	K	e	


re			
1	Carton	4	Centre of gravity of the inverter
2	Protective packaging	5	Positions for lifting
3	inverter	6	Protective covers

EN

Unpack inverter

- 1. Open carton at the front.
- 2. Remove installation material and documentation.
- 3. Slide the unit aside the housing out of the carton.
- 4. Remove upper and lower protective packaging from housing.
- 5. Place the protective packaging back into the carton.
- 6. Lift the inverters to the intended positions (see Figure 9).
- » Continue mounting the inverter.

6.2 Installing the unit



1386

Figure 10: Minimum clearances/mounting plate

Figure 11: Drilling separation (in mm)

Key

1	Fixings for mounting	4	Detachment protector
2	Wall bracket	5	Suspension brackets (back of housing)
3	Screws for mounting		

Installing the mounting plate and the unit

- Mark the positions of the drill holes using the slots in the wall holder.
 NOTE: The minimum clearances between two inverters, or the inverter and the ceiling/floor have already been taken into account in the diagram.
- 2. Fix mounting plate to the wall with the supplied mounting fixtures. Make sure that the mounting plate is oriented correctly.
- 3. Hang the inverter on the wall holder using the suspension brackets on the back of the housing.
- 4. Fix the inverter with the enclosed screws to the detachment protector at the connection area.
- » The mounting of the inverter is complete. Continue with the installation.

FN

Authorised electrician

7 Electrical connection

DANGER

Lethal voltages are still present in the terminals and cables of the inverter even after the inverter has been switched off and disconnected!

Severe injuries or death will occur when touching the cables and terminals in the inverter.



- Only appropriately qualified and authorised electricians may open and install the inverter.
- Observe all safety regulations and the current technical connection specifications from the relevant power supply company.
- > The inverter must be mounted in a fixed position before being connected electrically.
- > Disconnect the AC and DC side.
- Secure the inverter against reconnection.
- > Ensure that the AC and DC sides are completely voltage free.

7.1 Preparing the AC connection

7.1.1 Open connection area




Figure 12: Connection area: Open connection cover

Key					
1	Connection cover	3	Screws for mounting (short)		
2	Screws for mounting (long)				

Open connection area

- You have mounted the inverter on the wall.
- 1. Unscrew the four Torx screws on the front side of the connection cover (blue).
- 2. Pull down the connection cover.
- » Make the electrical connections.



NOTE

Remove only the connection cover (blue). Opening the housing cover (grey) will invalidate the warranty.

EN

Authorised electrician

7.1.2 Surveying the connection area

Make the connection to the PV generator via the plug connectors and the grid connection via the PCB terminals in the connection area of the inverter.




Figure 13: Connection area: Electrical connection

Key	1		
1	DC isolator switch	3	AC connection terminals
2	8 (2 x 4) MC4-compatible DC plug connector for	4	Cable fitting (M40) for AC connection
	PV generator	5	Cable fittings (M16) for housing ground connection

7.1.3 Cable and fuse requirements



NOTE

Select the following specifications in accordance with the following master conditions:

- Country specific installation standards
- Line length
- Type of line installation
- Local temperatures

	AC connection	DC connection
Max. conductor cross-section without wire sleeves	16 mm ²	
Max. conductor cross-section with wire sleeves	10 mm ²	dependent on the plugthat is used
Length of insulation to be stripped off	18 mm	— tilat is useu

Table 4: Recommended conductor cross-section

	AC connection	DC connection	
Overvoltage protection	no		
Overvoltage conductor (SPD)		-	
String fuses	-	To be provided externally on-site	
Combiner box	-	To be provided externally on-site	
Protection class	3	3	
Overvoltage category	III	II	
Fuse protection: gL safety fuses or comparable automatic circuit breakers	32 A for 6.0 mm ² conductor cross-section	-	

Table 5: Integrated and recommended protective devices

7.2 Connection to the power grid

The power connection wires are connected on the right of the connection area (see Figure 13 on page 17),



DANGER

Danger to life from electric shock!

Severe injury or death will result if the live connections are touched.



- > Switch off all power sources to the inverter before you insert the grid power cable into the unit.
- Make sure that the device is isolated from the public power supply and the system power supply before starting work.

NOTE



If the cable impedance is high (i.e. long grid-side cables), the voltage at the grid terminals of the inverter will increase during feed-in to the grid. The inverter monitors this voltage. If it exceeds the country-specific grid overvoltage limit value, the inverter switches off.

• Ensure that the conductor cross-sections are sufficiently large or that the cable lengths are sufficiently short.

Making the grid connection

- Use cables with five wires (L1, L2, L3, N, PE).
- 1. Unscrew the cable fitting.
- 2. Remove the outer cladding of the AC cables.
- 3. Insert the AC cables through the cable fitting into the connection area.
- 4. Strip the insulation from the AC cables.
- 5. Open the locks for the PCB terminals.
- 6. Connect the cables in accordance with the label on the PCB terminals (Figure 14 on page 18).
- 7. Close the locks for the PCB terminals.
- 8. Check secure fit of all connected cables.
- 9. Tighten the cable fitting.
- » The inverter is now connected to the power grid.




Figure 14: AC connection terminals

(i)

NOTE

An AC-side disconnection unit must be provided during the final installation stage. This cut-off mechanism must be installed so that it can be accessed at any time without obstruction.



NOTE

If a residual current circuit breaker is necessary due to the installation specification, a type A residual current circuit breaker must be used.


If an A-type RCD is used, the insulation threshold value in the "parameter" menu must be over (>) 200kOhm.

For questions regarding the appropriate type, please contact your installer or our KACO new energy customer service.



7.3 Preparing the DC connection

7.3.1 Configuring the DC plug connector






Figure 15: Insert wires

Figure 16: Slide insert into sleeve

Figure 17: Check fastening

Key

	•			
1	Wire for DC connection	5	cable fitting	
2	Spring	6	Contact plug	
3	Insert	7	Coupling	
1	Sleeve			

Configuring the DC plug connector

NOTE: Before proceeding with the isolation ensure that you don't cut any individual wires.

- 1. Isolate wire for DC connection by 15 mm.
- 2. Insert isolated wire with twisted ends carefully up to the end stop.

NOTE: Wire ends must be visible in the spring.

- 3. Close the spring so that the spring latches.
- 4. Slide insert into sleeve.
- 5. Tighten cable fitting with the help of a 15 mm fork wrench applying a torque of 2 Nm.
- 6. Join insert with contact plug.
- 7. Check latch by lightly pulling on the coupling.
- » Make the electrical connection.



NOTE

The permissible bending radius of at least 4x the cable diameter should be observed during installation. Excessive bending force may negatively impact the protection rating.

- > All mechanical loads must be absorbed in front of the plug connection.
- » Rigid adaptations are not permitted on DC plug connectors.

7.3.2 Checking the PV generator for a ground fault

DANGER

Danger to life from electric shock!



Severe injury or death will result if the live connections are touched. When there is solar radiation, DC voltage will be present at the open ends of the DC cables.

- > Only touch the PV generator cables on the insulation. Do not touch the exposed ends of the cables.
- » Avoid short circuits.
- > Do not connect any strings with a ground fault to the unit.



1. Determine the DC voltage between:

Checking the PV generator for a ground fault

- protective earth (PE) and the positive cable of the PV generator
- protective earth (PE) and the negative cable of the PV generator

If stable voltages can be measured, there is a ground fault in the DC generator or its wiring. The ratio between the measured voltages gives an indication as to the location of this fault.

- 2. Rectify any faults before taking further measurements.
- 3. Determine the electrical resistance between:
 - protective earth (PE) and the positive cable of the PV generator
 - protective earth (PE) and the negative cable of the PV generator

In addition, ensure that the PV generator has a total insulation resistance of more than 2.0 MOhm, since the inverter will not feed in if the insulation resistance is too low.

4. Rectify any faults before connecting the DC generator.



NOTE

The threshold value from which the insulation monitor reports a fault can be set in the "Parameter" menu.

7.3.3 Designing the PV generator



NOTE

Connected PV modules must be dimensioned for the DC system voltage in accordance with IEC 61730 Class A, but at least for the value of the AC grid voltage

	P _{max}	I _{rated max} . MPP tracker	I _{SC max} . MPP tracker
MPP tracker	<24 kW	<20 A	<32 A

7.4 Connecting the PV generator

Connect the PV generator to the 4 DC positive and the 4 DC negative connection plugs on the underside of the housing (see Figure 18 on page 21). Note the wiring examples given below. The inverter detects these typical configurations automatically. In individual cases, you need to set the selected DC connection after installation in the menu.

DANGER

Risk of fatal injury due to contact voltages.



Removing the plug connection before disconnecting the inverter from the PV generator may lead to injuries and damage the unit.

- During installation: Electrically disconnect the DC positive and DC negative from the protective earth (PE).
- > Remove the plug connector.

CAUTION

Damage to the device in case of faulty configuration of the DC connector.

A faulty configuration of the DC connector (polarity +/-) causes equipment damages in the DC connection if it is connected permanently.

- Please check polarity (+/-) of the DC connector before connecting the DC generator
- The DC voltage must not exceed 1000V at any time.

EN

Authorised electrician




Figure 18: Connections for DC positive and DC negative

Key				
Α	MPP tracker A	В	MPP tracker B	
1.2	DC-Plus/DC-Minus-Connections to MPP tracker A	3.4	DC-Plus/DC-Minus-Connections to MPP tracker B	

7.4.1 **Maximum input power**

The input power of the inverter is limited only by the maximum rated current of 20.0 A per input. This causes the maximum input power per path to increase with the input voltage.




NOTE

The overall power of the unit continues to be limited. If one input is connected to more than P(D-Cmax)/2, the maximum input power of the second input decreases accordingly. Take care that the maximum input power is not exceeded.

7.4.2 Connection



DANGER





Wrong assignment of MPP trackers will seriously damage the inverter

Severe injury or death will result if the live connections are touched.

- Make sure that each MPP tracker can be disconnected from all poles.
- Observe recommended standard connection.

· 1.) Standard connection -Two generators each on one MPP tracker

2.) Unconnected inputs for unused MPP trackers

Equal MPP voltages must be applied to input 1 and 2, as well as inputs 3 and 4. The MPP voltages of the two DC paths can be different. They are tracked by separate, inde-test of the unit and the feed-in operation is not guaranpendently operating MPP trackers (MPP trackers A and B). teed. $(n_1=n_2, n_3=n_4).$

If one of the MPP trackers (A or B) is not used, then it must be short-circuited, otherwise faults can occur in the self-

The short-circuiting of an MPP tracker does not result in the device being damaged.




Figure 19: Recommended standard connection

Figure 20: Parallel input with Y-adapter, short-circuits the unused MPP Tracker B

Electrical data

Connecting Number of modules per string: $_1=n_2$, $n_3=n_4$ Number of modules per string: $n_1=n_2=n_m$ the DC inputs

P_{max} per string < 0.5 * max. recommended PV generator power generator power per string < 0.5 * max. recommended PV generator power per tracker MPP tracker A+B together < max. recommended PV generator power per tracker mended PV generator power

Amperage per tracker < max. rated current < max. rated current (DC) (DC)

DANGER

Danger to life from electric shock!



Severe injury or death will result if the live connections are touched. When there is solar radiation, DC voltage will be present at the open ends of the DC cables.

- > Do not touch the exposed ends of the cables.
- Avoid short circuits.

Connecting the PV generator

- 1. Remove protective caps from the DC connection plugs.
- 2. Connect PV generator to the DC plug connectors on the underside of the housing.
- 3. Ensure that the unused plug connectors are sealed with protective caps.
- » The inverter is connected to the PV generator.

7.5 Grounding the housing

DANGER

Dangerous voltage due to two operating voltages!

Severe injuries or death may occur if the cables and terminals in the device are touched.

The discharge time of the capacitors is up to 5 minutes.



- > Only appropriately qualified and authorised electricians may open and maintain the inverter.
- > Before opening the unit: Disconnect the PV generator and grid and wait at least 5 minutes.
- > Establish ground connection under all circumstances before connecting the supply circuit.
- > Make sure that the device is isolated from the public power supply and the system power supply before starting work.

An optional grounding of the housing is possible at the grounding point provided for that purpose in the connection area of the inverter. Please observe any national installation regulations in this regard.

Ground the housing of the inverter, if necessary, at the grounding point provided for that purpose in the connection field of the inverter




Figure 21: Grounding point in the connection area

Grounding the housing

- 1. Detach cable fitting for grounding the housing.
- 2. Remove the outer cladding from the grounding cable.
- 3. Insert the grounding cable through the cable fitting into the connection area.
- 4. Remove the insulation from the grounding cable.
- 5. Furnish the stripped cable with an M4 ring cable lug.
- 6. Screw the ring cable lug to the grounding point with an M4/TX30 screw.
- 7. Check that the cable is secure.
- » Tighten the cable fitting.

7.6 Connecting the interfaces

All interfaces are located on the connection circuit board behind the cover for the connection area. Use the cable fittings and plug connections provided (see Figure 22 on page 24).

CAUTION

Damage to the unit from electrostatic discharge

Components inside the unit can be damaged beyond repair by static discharge.

- Note the ESD protective measures.
- Earth yourself before touching a component by touching a grounded object.

EN





NOTE

When routing the interface connection cable, note that too little clearance to the DC or AC cables can cause interference during data transfer.




Figure 22: Connection area: Connection and assignment of the interfaces

Key				
1 Cable fitting for RS485 connection cable	4 Interface connections / pin assignment			
2 Cable fitting (M25) for Ethernet connection cable	5 DIP switch for terminating resistor Ra			
3 USB interface with cover				

<u>^</u>

DANGER



Danger to life from electric shock!

Severe injury or death may result from improper use of the interface connections and failure to observe protection class III.

> The SELV circuits (SELV: safety extra low voltage) can only be connected to other SELV circuits with protection class III.

7.6.1 Connecting the fault signal relay

The contact is designed as an N/O contact and is labelled "ERR" on the circuit board.

30 V/1 A

Maximum contact load

DC

Connecting the fault signal relay

- 1. Unscrew the cable fitting.
- 2. Thread the connection cables through the cable fitting.
- 3. Attach the connection cables to the terminal clamps.
- 4. Tighten the cable fitting.

7.6.2 Connecting the Ethernet interface



NOTE

The connection plug of an RJ45 cable is larger than the opening of an M25 cable fitting when it is installed. For this reason, remove the sealing insert before installation and thread the Ethernet cable outside of the cable fitting through the sealing insert.



NOTE

Use a suitable category 5 network cable. The maximum length of a network segment is 100 m. Ensure that the cable is correctly assigned. The Ethernet connection of the inverter supports auto-sensing. You can use both crossed and 1:1 protectively-wired Ethernet connection cables.

Connecting an Ethernet cable to the inverter

- 1. Loosen and remove the cover of the cable fitting (see Figure 22 on page 24).
- 2. Remove the sealing insert.
- 3. Thread the connection cable through the cover of the cable fitting and the sealing insert.
- 4. Insert the sealing insert into the cable fitting.
- 5. Connect the connection cable to Ethernet interface.
- 6. Attach and tighten the cover of the cable fitting.

Connecting the inverter to the network

- Connect the Ethernet cable to the inverter.
- U Configure the Ethernet interface in the configuration menu.
- Connect the Ethernet cable to the network or a computer.
- Configure the Ethernet settings and the web server in the Settings/Network menu.

7.6.3 Connecting the S0 output

An SO pulse output is located on the communication board. Use this output to control accessories such as a large display, for example. The pulse rate of the output is adjustable.

Connecting the S0 output

- 1. Unscrew the cable fitting (see Figure 22 on page 24).
- 2. Thread the connection cables through the cable fitting.
- 3. Attach the connection cables to the terminal clamps.
- 4. Tighten the cable fitting.

7.6.4 Connecting the RS485 bus

NOTE



Ensure that the DATA+ and DATA- wires are properly connected. Communication is not possible if the wires are reversed.

Different manufacturers do not always interpret the standard on which the RS485 protocol is based in the same way. Note that the wire designations (DATA- and DATA+) for wires A and B may vary from one manufacturer to another.

EN

FN

Authorised electrician

Wiring diagram




Figure 23: RS485 interface wiring diagram

Properties of the RS485 data line				
Maximum length of the RS485 bus line	The maximum permitted length of the RS485 bus is 1200 m. This length can be reached only under optimum conditions. Cable lengths exceeding 500m generally require a repeater or a hub.			
Maximum number of con- nected bus devices	30 inverters + 1 data monitoring unit			
Data line	Twisted, shielded. Recommendations:			
	LI2YCYv (twisted pair) black for laying cable outside and in the ground, 2 x 2 x 0.5			
	LI2YCY (twisted pair) grey for dry and damp indoor spaces, 2 x 2 x 0.5			

Connecting the RS485 bus

- To prevent interference during data transmission:
- Observe the wire pairing when connecting DATA+ and DATA- (see Figure 22 on page 24).
- U Do not lay RS485 bus lines in the vicinity of live DC/AC cables.
- 1. Connect the connection cable to the corresponding connection terminals (Figure 23).
- 2. The following must be connected to all inverters and to the data monitor unit in the same way:
 - Wire A (-) to wire A (-)
 - Wire B (+) to wire B (+) and
 - GND with GND (see Figure 23 on page 26)
- 3. Tighten the cable fitting.
- 4. Activate the terminating resistor on the terminal unit.




Figure 24: Assignment of twisted-pair wires



NOTE

When using the RS485 bus system, assign a unique address to every bus device (inverter, sensor) and terminate the terminal units (see the "Settings" menu).

Activating the terminating resistor

- U Check whether one of the inverters represents the terminal unit.
- Only activate the terminating resistor on the communication circuit board of the terminal unit using the DIP switch. (See Figure 22 on page 24)
- » Close the connection area or connect "inverter off".

EN

Authorised electrician

7.6.5 Connecting "Inverter Off" (optional)



NOTE

The Powador-protect digital output can only be used with suitable KACO inverters. When using devices from other manufacturers or in combination with KACO inverters, bus coupler circuit-breakers as a minimum must be used for shutting down devices from other manufacturers.

Connecting and activating "INV OFF" digital input

- Can only be used with suitable KACO inverters.
- 1. Connect wire A (+) to the terminal marked "INV+" on the first inverter via the "DO1" terminal of the Powador-protect.
- 2. Connect wire B (-) to the terminal marked "INV-" on the first inverter via the "GND" terminal of the Powador-protect.
- 3. Connect the other inverters to one another as follows:
 - wire A (+) to wire A (+) and wire B (-) to wire B (-).
- 4. Tighten the cable fitting.
- 5. After commissioning: Activate the support for Powador protect in the parameter menu under the "Powador-protect" menu item.




Figure 25: Powador-protect

7.7 Sealing the connection area

- 1. The requirements of protection rating IP65 are met by closing the unused cable fittings with blind caps.
- 2. Place the connection cover on the connection area of the inverter.
- 3. Screw in the four Torx screws on the front side of the connection cover (blue).
- » The inverter has been mounted and installed.
- » Start up the inverter.



EN

7.8 Switching on the device



DANGER



Lethal voltages are still present in the terminals and cables of the inverter even after the inverter has been switched off and disconnected.

Severe injuries or death will occur when touching the cables and terminals in the inverter. Only appropriately qualified and authorised electricians may start up the inverter.



CAUTION



Risk of burns from hot housing components.

The housing surface and the heat sink can adopt a surface temperature of 75° in operation.

- > Do not touch the housing surface or heat sink during and immediately after operation.
- › Allow the device to cool down before touching the housing surface.



Attachment of safety label in accordance with UTE C 15-712-1

The code of practice UTE C 15-712-1 requires that, upon connection to the French low-voltage distribution network, a safety sticker showing a warning to isolate both power sources when working on the device must be attached to each inverter.

Attach the provided safety sticker visibly to the outside of the inverter housing.



- U The inverter has been mounted and electrically installed.
- U The PV generator supplies a voltage above the configured start voltage.
- 1. Connect the grid voltage using the external circuit breakers.
- 2. Connect the PV generator using the DC isolator switch $(0 \rightarrow 1)$.
- » The inverter begins to operate.
- » During initial start-up: Follow the instructions of the New Connection Wizard.



8 Configuration and Operation

8.1 Controls

The inverter has a backlit LCD as well as three status LEDs. The inverter is operated using six buttons.



Figure 26: Control panel

Key				
1	"Operating" LED	5	4-way button	
2	"Feed-in" LED	6	"Enter" key	
3	"Fault" LED	7	"ESC" key	
4	LCD			

8.1.1 LED indicators

The 3 LEDs on the front of the inverter show the different operating states. The LEDs can display the following states:



The LED indicators show the following operating status:

Operating status	LEDs		Display	Description
Start				The green "Operating" LED is illuminated
		V		if an AC voltage is present,
				(independently of the DC voltage).
Feed-in start			Power fed into the grid	The green "Operating" LED is lit.
			or measured values	The green "Feed-in" LED is illuminated after the country-specific waiting period*.
		A		The unit is ready to feed in, i.e. is on the grid.
				You can hear the grid relay switch on.
Feed-in operation			Power fed into the grid	The green "Operating" LED is lit.
		• ○	or measured values	The green "Feed-in" LED is illuminated.
				The "Feed-in" icon appears on the LC display.
		* 1		The unit feeds into the grid.
*The waiting period ens	ures that a	II netw	ork parameters are in the pe	ermissible ranges.

KAC

EN

Authorised electrician

Operating status	LEDs	Display	Description
Non-grid feed mode		Status message	The display shows the corresponding message.
		\uparrow	
Fault		Fault message	The display shows the corresponding message.
			The red "Fault" LED is illuminated.

8.1.2 Graphical display

The graphical display shows measured values and data and allows the configuration of the inverter using a graphical menu. In normal operation, the backlighting is switched off. As soon as you press one of the control buttons, the backlighting is activated. If no button is pressed for an adjustable period of time, it switches off again. You can also activate or deactivate the backlighting permanently.




Figure 27: Desktop

Key

1	Current date	5	Annual yield
2	Current power	6	Status bar
3	Menu indicator	7	Current time
4	Daily yield	8	Feed-in indicator

After being switched on and after initial commissioning is complete, the inverter displays the start screen (the desktop). If you are in the menu and do not touch the control buttons for two minutes, the inverter returns to the desktop.

For initial commissioning, see section 8.2 on page 32





Depending on the tolerances of the measuring elements, the measured and displayed values are not always the actual values. However, the measuring elements ensure maximum solar yield. Due to these tolerances, the daily yields shown on the display may deviate from the values on the grid operator's feed-in meter by up to 15%.



NOTE

Calculating efficiency by measuring the current and voltage values can lead to misleading results due to the tolerances of the measurement devices. The sole purpose of these measured values is to monitor the basic operation of the system.

8.1.3 Control buttons

The inverter is operated using the 4-way button and the Enter and ESC buttons.

Desktop

Opening the menu

- U The inverter is operating.
- The LCD is showing the desktop.
- Press the right arrow button.
- » The main menu opens.



EN

Displaying the daily output

- U The inverter is operating.
- U The LCD is showing the desktop.
- Press the down arrow button.
- » The LCD displays the daily yield in a diagram.
- To return to the desktop, press any button.



Inverter menu

Selecting a menu option

- You have left the desktop. The inverter displays the menu.
- Use the up and down arrow buttons.



Opening a menu item or a setting

Use the right arrow button and the Enter button.



Jump to the next higher menu level/discard changes

Press the left arrow button or the ESC button.



Selecting an option

Use the right and left arrow buttons.



Changing an option/the value of an input field

Use the up and down arrow buttons.



Saving changed settings

Press the Enter button.





8.2 Initial start-up

When started for the first time, the inverter displays the configuration assistant. It takes you through the settings necessary for the initial start-up.



NOTE

After configuration is completed, the configuration assistant does not appear again when the inverter is restarted. You can then change the country setting only in the password-protected parameter menu. The other settings can still be changed in the Settings menu.



NOTE

The DC and AC power supply must be guaranteed during configuration.

The sequence of the settings required for initial start-up is preset in the configuration assistant.

Navigation

- In order to select a setting, press the up and down buttons.
- To select the next menu item, press the Enter button.
- To return to the most recently selected menu item, press the ESC button.
- Set the required settings.
- Press the Enter button in the last menu item.

Initial configuration

- Select the menu language.
- Select the country of operation with grid type.
- Set the date and time.
- To store the set operator country and grid type permanently, confirm these settings with "Yes".
- » You have completed the initial configuration. The inverter begins to operate.

8.3 Menu structure

8.3.1 Display on the LCD




Figure 28: Main menu

Key

1	Selected menu item	3	Menu items of the active menu level
2	Name of the active menu level	4	Menu items of the next lower menu level



8.3.2 Menu structure



NOTE

The menu items displayed on screen are dependent on the country and network settings, and may vary according to the type of device.

Icons used:				
1 2 3 4 Me	nu level (0,	1, 2, 3)		∟ Submenu available
Display menu			EN Country-specific setting	
Option menu		ı	FR-HTA Country and grid type-specific setting	
Password protected menu (password			an b	e requested from KACO Service)
Coun- Menu Display/settings try-spec. level setting				Action in this menu/meaning
	Desktop	Desktop	↳	Press the right arrow button.
	1 2 3 4	"Measurements" menu	L	Open the menu: Press the right arrow button or the Enter button.
	1 2 3 4	Generator	•	Displays the DC-side voltage, amperage and power.
	1-2-3-4	Grid		Displays the AC-side voltage, amperage and power
	1-2-3-4	Power control	0	Displays the current value of the external power limitation by the grid operator.
	1 2 3 4	cos-phi	0	Indicates the status of the reactive power control.
	1 2 3 4	Unit temperature	•	Displays the temperature in the inverter housing.
	1 2 3 4	Yield counter		Displays the yield in kWh.
All countries				Reset the counter using the "Reset" key.
	1-2-3-4	Yield today	0	Displays the cumulative yield for the current day.
	1 2 3 4	Total yield	•	Displays the total yield up to now.
	1 2 3 4	CO2 savings	•	Displays the calculated CO ₂ savings (in kg).
	1 2 3 4	3H4 Oper hrs cotr		Displays the duration of operation in hours.
				Reset the counter using the "Reset" key.
	1 2 3 4	Oper. time today		Displays the duration of operation on today's date.
	1-2-3-4	Total oper. time	•	Displays the total operating time.
	1-2-3-4	Log data display	Ŀ	 Open the menu: Press the right arrow button or the Enter button. Measurement data can be transferred to a USB stick by selecting it and moving it.



Coun- try-spec. setting	Menu level	Display/settings	Action in this menu/meaning
All countries	1-2-3-4	Day display	Displays the recorded operating data graphically. 1. Select the measured value to be displayed. Supported measured values: • Grid power P(grid) • DC power per string P(PV) 1-2 • DC voltage per string U(PV) 1-2 • Unit temperature 2. Select a day. 3. Press the Enter button. » The display shows the selected data. Press any button to return to the previous menu.
	1 2 3 4	Month display	Displays the recorded operating data graphically. 1. Select a month. 2. Press the Enter button. 3. The display shows the selected data. 4. Press any button to return to the previous menu.
	1-2-3-4	Year display	Displays the recorded operating data graphically. 1. Select a year. 2. Press the Enter button. 3. The display shows the selected data. 4. Press any button to return to the previous menu.
	1-2-3-4	CSV log data	Open the menu: Press the right arrow button or the Enter button.
	1 2 3 4	Decimal separator	Select decimal sign for export of saved operating data.
	1 2 3 4	Save to USB	In this menu, you can export the saved operating data to a connected USB flash storage device. O You have connected a USB flash storage device to the inverter. Select the data to be exported (year, month or day). Press the Enter button. The inverter writes the data to a connected USB flash storage device.
All countries	1-2-3-4	"Settings" menu	 Open the menu: Press the right arrow button or the Enter button.
	1 2 3 4	Language	Select the desired language for the user interface.
	1 2 3 4	Def. total yield	 Set the total yield to any value. (If you want to continue the recording from the present value on a replacement unit). Select the "Save" button and confirm with the Enter button.

Ε	N

Coun- try-spec. setting	Menu level	Display/settings		Action in this menu/meaning
All countries	1-2-3-4	Interface	°00	 Assign a unique RS485 bus address ("RS485 address" menu option). NOTE: The address must not be the same as that of any other inverter or a monitor device.
	1 2 3 4	Priwatt	↦	Open the menu: Press the right arrow button or the Enter button.
	1 2 3 4	Activation mode	000	 Activate/deactivate the "Priwatt" function Select operating mode NOTE: Re-activation depends on the operating mode selected and on the activation conditions.
	1 2 3 4	Monitoring time		Set time span during which the power threshold must be exceeded without interruption.
	1 2 3 4	Power threshold		Set power threshold from which the monitoring time up to activation begins.
	1-2-3-4	Operation mode	© .	 Power-dependent: the function remains active until below the set power threshold. Time-dependent: The function is active depending on the sunlight for the set operating time.
	1-2-3-4	Operation time	© 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	NOTE: The menu option is only available in the "Time-dependent" operation mode. After connection, the function is active for the set operating time.
	1-2-3-4	Quick start		Reduce the waiting time during the self-test by pressing the "Activate" key.
	1-2-3-4	Logging interval		 Specify the time period between 2 log data recordings.
	1-2-3-4	Log data backup		NOTE: The unit supports the backing up of all recorded yield data to a connected USB storage device. Activate or deactivate log data backup.
	1-2-3-4	Display		 Configure the contrast setting for the display. Set the length of time without user input after which the backlighting switches off. Alternatively: Permanently activate or deactivate the backlighting by selecting "On" or "Off".
	1-2-3-4	Date & time		Set the date and time. NOTE: For self-diagnostic purposes, the inverter carries out a daily restart at midnight. To avoid having a restart occur during feed-in operation and to always obtain reliable log data, ensure that the time is correctly set.
	1 2 3 4	Network	↳	Open the menu: Press the right arrow button or the Enter button.



Coun- try-spec. setting	Menu level	Display/settings	Action in this menu/meaning
All countries	1 2 3 4	DHCP	Activate or deactivate DHCP. On: Activate DHCP. Once the DHCP server becomes available, the IP address, subnet mask, gateway and DNS server are automatically applied and the aforementioned menu items are hidden. Off: DHCP deactivated, make settings manually.
			NOTE: The "IP address", "Subnet masks", "Gateway" and "DNS server" menu options are only displayed with the DHCP deactivated.
	1 2 3 4	IP address	Allocate a unique IPv4 address in the network.
	1 2 3 4	Subnet mask	Assign a subnet mask.
	1 2 3 4	Gateway	Enter IPv4 address of gateway.
	1 2 3 4	DNS server	Enter IPv4 address of DNS server.
	1 2 3 4	Web server	 Open the menu: Press the right arrow button or the Enter button.
	1 2 3 4	Operation mode	Activate or deactivate the integrated web server.
	1 2 3 4	Port	Set the accessible port on the web server.
	1 2 3 4	Remote config	If necessary, activate the remote configuration (on/ off)
	1 2 3 4	Remote update	If necessary, activate the remote update (on/off)
	1-2-3-4	Powador-web	 On: The inverter attempts to connect to the Powador-web web portal. Off: The connection to Powador web is deactivated.
	1 2 3 4	Portal	Set the portal configuration
	1-2-3-4	Modbus TCP	 Open the menu: Press the right arrow button or the Enter button
	1 2 3 4	Operation mode	 Activate/deactivate function.
	1 2 3 4	Port	
	1-2-3-4	Connection status	Indicates the status of the network connection:



Coun-	Menu	Display/settings		Action in this menu/meaning
try-spec. setting	level	Display/settings		reason in and menu/meaning
Jetting				Press the right arrow button or the Enter button.
	1 2 3 4	"Parameters" menu	-	NOTE: The inverter does not display the "Parameters" menu in the standard configuration. To display the Parameters menu:
				1. Open the menu.
011				2. Simultaneously hold down the up and down buttons for several seconds.
All countries				 Enter the four-digit password using the 4-way button. The password is unit-specific.
				2. Confirm the entry with the Enter button.
	1 2 3 4	Country		3. Set the desired country setting.
				NOTE: This option influences the country-specific operating settings of the inverter. Please consult KACO service for further information.
DE, CH, ES, FR, GB, GR, IT, TH, ZA	1 2 3 4	Grid type/guideline		Select the grid type for the inverter's installation location.
UD	1 2 3 4	Nominal grid volt- age		 Set the specified grid voltage for the site where the unit is used (please contact KACO Service)
All countries	1 2 3 4	Grid parameters	Ŀ	Open the menu: Press the right arrow button or the Enter button.
DE-NS, AT, BE, BG, CY, CH-NS, CZ, FR (except FR-HTA), IE, IT, PL, UD	1 2 3 4	Overvoltage shut- down, 10 minute mean value		 Activate or deactivate password protection. (Specify the shutdown threshold for overvoltage shutdown. The 10-minute average for the measured voltage as per EN50160 is used. Set period from occurrence of the fault to shutdown of the inverter.
CZ, BG, FR (except FR-HTA), UD	1-2-3-4	Voltage drop		The voltage drop between the inverter and the feed-in meter is added to the limit value that was set for grid shut-
DE MC AT				11 V).
DE-MS, AT, CH-MS,	1-2-3-4	Overvoltage shut-		 Specify the shutdown threshold for fast and slow overvoltage shutdown.
ES-661, ES1699, ES-PO123		down		Set period from occurrence of the fault to shutdown of the inverter.
FR-HTA, GB-G59/3,	TA, 59/3,	Undervoltage shut- down		Specify the shutdown threshold for fast and slow undervoltage shutdown.
HR, HU, IE, IL, IN, IT, PL, RO, TH, ZA, UD				Set period from occurrence of the fault to shutdown of the inverter.
AT, FR-HTA, GB-G59/3, IE, IT, PL, RO, TH, ZA, UD	1 2 3 4	Overfrequency shut- down	000	Set limit value for the slow and fast overfrequency shutdown.



Coun-	Menu level	Display/settings	Action in this menu/meaning	
try-spec. setting	ievei			
AT, FR-HTA, GB-G59-3, PL, RO, IE, IN, IT, TH, UD, ZA	1 2 3 4	Underfrequency shutdown	Set limit value for the slow and fast underfrequence shutdown.	су
AU, ES-1663, GR, PT, KR	1 2 3 4	Voltage shutdowns	The inverter is equipped with redundant 3-phase monitoring. If the grid frequency exceeds or drops below the configured values, the inverter switches off. The minimisswitch-off threshold can be set in 1 V increments. Configure the switch-off values for undervoltage and overvoltage. Where necessary, set period from occurrence of the fault to shutdown of the inverter.	e um nd
DE-MS, AU, BG, CH-MS, CZ, DE-MS, ES, FR (except FR-HTA), GR, HU, IL, KR, PT	1 2 3 4	Frequency shut- downs	The inverter continuously monitors the grid frequency the grid frequency exceeds or drops below the configural values, the inverter switches off. Set limit values for underfrequency and overfrequency in 0.1 Hz increments. Set period from occurrence of the fault to shutdow of the inverter.	ıred
AT, CH-MS, DE-MS, FR-HTA, IE, IL, IN, IT, PL, RO, TH, ZA, UD	1 2 3 4	Connection cond.	The inverter checks mains voltage and frequency. The greed operation begins if the measured values are within the set ranges. Set minimum and maximum values for the switching on.	n
AT, CH, DE, DK, BE, FR-HTA, GB, IL, IN, IT, IE, CY, Z, PL, RO, ES-PO123, TH, TW, ZA, UD	1121314	Connect time	Set period for grid observation (in seconds) when switching on and reconnection after a fault.	
Further information on: Grid param- eters	1 2 3 4		If the value U< (slow undervoltage shutdown) is se to a value which is greater than the value of Ucon,r (minimum restart voltage) using the LC display, the the value of Ucon, min. is automatically set to the value of U<.	min

_	\mathbf{n}
_	
_	

Coun- try-spec. setting	Menu level	Display/settings		Action in this menu/meaning
	1 2 3 4			 If the value U> (slow overvoltage shutdown) is set to a value which is smaller than the value of Ucon, max (maximum restart voltage) using the LC display, then the value of Ucon, max. is automatically set to the value of U>. If the value f< (slow underfrequency shutdown) is set to a value which is greater than the value of fcon,min (minimum restart frequency) using the LC display, then the value of fcon, min. is automatically set to the value of U<.
				If the value f> (slow overfrequency shutdown) is set to a value which is smaller than the value of fcon,max. (maximum restart frequency) using the LC display, then the value of fcon, max. is automatically set to the value of f>.
	1 2 3 4	DC starting volt.		The inverter begins feed-in as soon as this DC voltage is present. Set the starting voltage.
All countries	1 2 3 4	DC connection	000	 Select between automatic detection and manual setting. Note the connection examples!
	1 2 3 4 Const. vo	Const. volt. ctrl.		Lets you deactivate the MPP seek mode in order to operate the inverter with a constant DC voltage. Activate or deactivate function.
				Set value for constant voltage control.
				The output power of the inverter can be set permanently to a lower value than the maximum output power by the internal power limiting.
		Power limitation		This may be necessary in order to limit the maximum power rating of the system at the grid connection point, upon the grid operator's request.
All countries	1-2-3-4			The value can be protected from the very first output limitation entry. After setting a limitation, the value can only be changed by entering a device-specific password.
Air countries				The output power can be regulated using via an external power limitation using an extension module and remote control periphery from the grid operator.
				Internal:
				1. Activate password protection if necessary.
				2. Specify the activation status.
				3. Specify the limit value for maximum feed-in power.
				4. Confirm the entry with the OK button.



Coun- try-spec. setting	Menu level	Display/settings		Action in this menu/meaning
	1 2 3 4			2 Specify the power limitation levels (only if activation
All countries		Powador-protect		 ador-protect integrated into the photovoltaic system. On: The digital signal of the Powador protect must be present to the digital input of the inverter for the inverter to start with feed-in. Off: The inverter does not check whether a Powador-protect is integrated into the PV system.
	1 2 3 4	Power reduction P(f)	© © ©	Open the menu: Press the right arrow button or the Enter button)
	1 2 3 4	P(f) Operation mode P (f) Activation threshold	-	 Set operation mode (mode 1 / mode 2 / off) (not for IL, IT) Specify activation threshold (if mode 1 or mode 2 is active)
All countries	P (f) Deactive	P (f) Deactivation		Specify deactivation threshold (if "mode 1" is active)
All Countries	1 2 3 4	P(f) Deactivation time		Specify the time taken to shut down the power reduction function in mode 1 (not for IL, IT)
	1-2-3-4	P(f) Gradient		Set gradient of power limit function with increasing frequency in % / Hz. This percentage relates to the nominal frequency of 50 Hz (If "mode 1" or "mode 2" active).
	1 2 3 4	P(f) Deliberate delay		Set the power reduction delay in seconds (If "mode 1" or "mode 2" active).

Coun- try-spec. setting	Menu level	Display/settings		Act	tion in this menu/meaning
	1 2 3 4	Fault ride-through (FRT)	000	Rid	e inverter supports dynamic grid stabilisation (Fault e-Through). Open the menu: Press the right arrow tton or the Enter button.
DE-MS, AT ,CH-MS,	1 2 3 4	Operation mode		F	Specify the operation mode
ES-PO123, FR-HTA, PL,	1 2 3 4	Dead band		F	Set the dead band
IE, RO, TH, ZA-NERSA,	1 2 3 4	Dead band mode		F	Specify the dead band mode
UD	1 2 3 4	Constant k		G	Set constant k
	1-2-3-4	Dynamic blind cur- rent		G	Activate dynamic blind current
		Reactive power		G	Open the menu: Press the right arrow button or the Enter button.
	<u> </u>		L	F	Activating idle power process: select process and press Enter. The active process is highlighted.
				G	Configure power factor.
	1-2-3-4	cos-phi specification		F	If a power factor not equal to 1 is selected: Select the type of phase shift (under-excited/over-excited).
				9	Set the idle power Q (in %) to a fixed value.
	1 2 3 4	Q const.		F	Select the type of phase shift (under-excited/over-excited).
	1-2-3-4	cos-phi(P/Pn)	L.	F	Open the menu: Press the right arrow button or the Enter button.
All countries	1 2 3 4	Lock-in voltage		G	Set rated voltage, where the network support process
	1-2-3-4	Lock-out voltage			is active.
	1 2 3 4	Number of support points		def of o	s option defines how many support points can be fined in the subsequent menu. The maximum number configurable support points depends on the selected d type. Specify the number of support points for the idle
		1.,, 10. Support		F	power characteristic curve. Specify the power factor for the 1. , , 10. support point
	1-2-3-4 1.,, point			Ţ	If a power factor not equal to 0 is selected: Select the type of phase shift (under-excited/over-excited).



Coun- try-spec. setting	Menu level	Display/settings		Action in this menu/meaning
	1 2 3 4	Q(U) 10 support points	Ļ	Open the menu: Press the right arrow button or the Enter button.
	1 2 3 4	Lock-in power		Power range set as % of rated power, in which the net-
	1 2 3 4	Lock-out power		work support process is active.
	1 2 3 4	Transient time		Set the response speed of the control.
All countries	1 2 3 4	Dead time		Set the deliberate delay for the start of the Q(U) function.
	1 2 3 4	Resetting the curve		Resetting the active curve to reduce active power
		1 10 Comment		Specify reactive power in %Snom for the 1st.,, 10. support point
	1 2 3 4	1., , 10. Support point		If reactive power not equal to 1 is selected: Select the type of phase shift (under-excited/over-excited).
BE, CH-NS,				Display of grid faults.
CY, DE-NS, UD, TW	11112113114	Line error		To show the last 5 grid fault messages, select the "Dis- play" key.
AT, BE, CH-NS,				Display of essential protection parameters.
CY, DE-NS, GB-G83-2, UD	1-2-3-4	Protection parameters		To show the protection parameters, select the "Display" key.
	1-2-3-4	"Information" menu		Open the menu: Press the right arrow button or the Enter button.
		-		Displays the type designation of the inverter.
	1-2-3-4	Inv. type	•	If feed-in power is actively limited: display maximum power in kW.
All countries	1 2 3 4	SW version	•	Displays the installed software version.
· · · · · · · · · · · · · · · · · · ·	1 2 3 4	Serial no.	•	Displays the serial number of the inverter.
	1 2 3 4	Display country	(Displays the selected country setting. Optional: Displays the grid type if a grid type has been selected.
	1 2 3 4	"Manufacturer" menu	Ļ	The display shows information about the unit manufacturer.



8.4 Monitor inverter

The inverter has an integrated web server. This makes it possible to monitor and record the operating state and yield of your PV system.

You can display the recorded data using:

- The integrated LCD
- · The integrated web server using an Internet-capable device connected to the Ethernet interface of the inverter
- A storage medium connected to the USB interface, for example, a USB stick.

8.4.1 USB interface

Use an external USB storage device to read operating data saved in the inverter.

Reading log data



NOTE

The USB interface is approved solely for use with USB flash storage devices ("USB sticks"). The maximum available current is 100 mA. If a device with a higher power requirement is used, the power supply for the USB interface automatically shuts down to protect the inverter from damage.

Reading data

- 1. Connect a suitable USB storage device to the USB interface on the underside of the inverter.
- 2. Open the "Log data display" menu.
- 3. Select the "Save to USB" item.
- 4. Select the desired log data using the 4-way button.
- 5. Press the Enter button.
- » The inverter saves the selected log data to the USB storage device.

8.4.2 Web server

The inverter has an integrated web server. After configuring the network and activating the web server in the Settings menu, you can open the web server from an Internet browser. The language version of the website delivered by the web server is adapted dynamically to the pre-set language preferences in your Internet browser. If your Internet browser requests a language that is unknown to the inverter, the web server uses the menu language set in the inverter.

Setting up the web server

Configuring the Ethernet interface

- U You have connected the inverter to your network.
- When using a DHCP server: Activate DHCP.
- For manual configuration (DHCP off):
- 1. Open the Settings/Network menu.
- 2. Assign a unique IP address.
- 3. Assign a subnet mask.
- 4. Assign a gateway.
- 5. Assign DNS server.
- 6. Save your settings.

Using the web server

To avoid problems with incompatibility, use the most recent version of your Internet browser. JavaScript must be enabled in the browser settings to display the web server correctly.



ΕN



NOTE

You can also access the web server of the inverter via the Internet. To do this, additional settings of your network configuration, particularly your Internet router, are required. Note that communication with the inverter is carried out over an unsecured connection, particularly in the case of a connection over the Internet.

Calling up the web server

- Configure the Ethernet interface.
- U Connect the Ethernet interface.
- 1. Open an Internet browser.
- 2. In the address field of the Internet browser, enter the IP address of the inverter and open the site.
- » The Internet browser displays the start screen of the web server.

After it has opened, the web server displays information about the inverter as well as the current yield data. The web server enables the following measurement data and yield data to be displayed:

 Feed-in power 	 Generator power
 Status 	 Generator voltage
 Grid power 	 Unit temperature

Grid voltage

In order to display and export yield data, proceed as follows:

Select the display period

- 1. Open the web server.
- 2. Select the display period by choosing either daily view, monthly view, yearly view or overview.

Filtering display data (daily view only)

- 1. Open the web server.
- 2. Select daily view.
- 3. To show or hide measured values, select or deselect the corresponding checkboxes in the "Select display" area.

Exporting data

- 1. Filter the display data if necessary.
- 2. Select the display period if applicable (daily, monthly, yearly or overview).
- 3. Press the "Export data" button.
- 4. Save the file.



NOTE

Regardless of the display data selected in the "Select display" area, an export file always contains all measurement data and yield data available for the selected period.

8.5 Performing the software update

You can update the software of the inverter to a new version using the integrated USB interface. Use a FAT32-formatted USB stick to do this. Do not use any storage media with an external power supply (for example: an external hard disk).



NOTE

Ensure that the AC and DC inverter power supply is active. It is only possible to update all of the inverter's components to the most current software version in this operating state.

CAUTION

Damage to the inverter

The update can fail if the power supply is interrupted during the update process. Parts of the software or of the inverter itself can then be damaged.

- » Never disconnect the DC and AC power supply during a software update.
- » Do not remove the USB stick during a software update.

Preparing for the software update

- 1. Download the software update file from the KACO web site and store it on your hard disk.
- 2. Copy the update file (.KUF) onto the USB stick.
- » Perform software update.



NOTE

The update can take several minutes. The "Operating" LED flashes during the update process. The inverter may restart several times.

The following message appears if the DC power supply is too low: "DC power supply too low! Perform update anyway?".

In this case, select "No" and perform the update with a stable voltage supply.

Performing the software update

- U Prepare for the software update.
- 1. Connect the USB stick to the inverter.
- » The message "Software found. Would you like to load it?" appears on the display.
- 2. If you would like to perform the update, select the "Yes" button. In the case of "No", pressing the "Enter" button stops the update process and the unit goes into feed-in mode.
- » The inverter begins the update.
 - The update has been imported in full once the message "Software update successful" appears.
 - The update has failed if the message "Software update incomplete" appears.
- 3. When a fault occurs, the update process must be repeated.

Alternatively, you can check to see if the update was successful in the menu:

Displaying the software version

- Open the Information / Software Version menu.
- » The inverter will display the versions and checksums of the software that is currently loaded.





9 Maintenance/Troubleshooting

9.1 Visual inspection

Inspect the inverter and the cables for exterior visible damage and note the operating status display of the inverter. In case of damage, notify your installer. Repairs may only be carried out by authorised electricians.



NOTE

The inverter should be checked for proper operation by a qualified electrician at regular intervals.

9.2 Cleaning the housing



DANGER



Lethal voltages in the inverter.

Serious injuries or death can result if moisture enters the system.

- > Only use completely dry objects to clean the inverter.
- > Only the exterior of the inverter should be cleaned.

Cleaning the inverter

- Do not use compressed air.
- Use a vacuum cleaner or a soft brush to remove dust from the fan cover, between the cooling fins and from the top side of the inverter on a regular basis.
- Remove dust from the ventilation inlets if necessary.
- If necessary, remove the fan cover and remove deposits.

9.3 Replacing or cleaning the fans

The unit is equipped with an axial fan. This is located in the upper area of the housing. Replace the fan:

- In case of heavy soiling
- If it is defective

Dismount the fan

- U Ensure complete disconnection on the AC and DC sides.
- 1. Wait until the fan is no longer turning.
- 2. Unscrew the Torx screws on the side of the fan cover (figure 24 on page 45).
- 3. Take down the fan cover with the fan.
- 4. Unplug the fan plug.
- 5. Remove the fan from the cover by pulling it out of the cover or dismount the fan from the cover using the fastening screws. (see position 1 & 2 in figure "Figure 30: Unplugging the fan" on page 47)
- » Install the replacement fan.




Figure 29: Removing the cover and fan from the housing

Authorised electrician

Installing the replacement fan

- U You have removed the defective fan.
- Replace the fan only with a fan recommended by KACO new energy. If necessary, contact KACO service.
- 1. Place the new fan in the holding fixture (Figure 30 or Figure 31).
- 2. Press the fan into the holding fixture or mount the fan with the fastening screws. (see position 1 & 2 in figure-Figure 31)
- 3. Place the cover on the fan.
- 4. Secure the unit with the Torx screws.
- Check if the connections are secure and that the connections are wellseated.
- » You have completed the fan replacement.




Figure 30: Unplugging the fan




Figure 31: Mounting the fan


9.4 Shutting down for maintenance and troubleshooting

DANGER

Lethal voltages are still present in the terminals and cables of the inverter even after the inverter has been switched off and disconnected.

Severe injuries or death will occur when touching the cables and terminals in the inverter.

When there is solar radiation, DC voltage will be present at the open ends of the DC cables. Arcing may occur if the DC cables are disconnected while they are still live.





- > Observe all safety regulations and the current technical connection specifications from the relevant power supply company.
- > Disconnect the AC and DC sides.
- > Secure the AC and DC sides from being inadvertently switched back on.
- > Do not touch the exposed ends of the cables.
- > Avoid short circuits.
- > Do not open the inverter until these two steps are complete.
- > After shutdown, wait at least five minutes before working on the inverter.

KACO



CAUTION

Destruction of the DC connections or fuse holders

The connection terminals or fuse holders can be destroyed by arcing if disconnected or if the fuses are removed.

> It is absolutely essential that the shutdown sequence is carried out in the correct order.

Shutting down the inverter

- 1. Switch off the grid voltage by turning off the external circuit breakers.
- 2. Disconnect the PV generator using the DC isolator switch.

DANGER! The DC cables are still live.

Ensure that there is no voltage present on the grid connection terminals.

9.5 Disconnecting connections

9.5.1 Disconnecting the AC connection

DANGER

Danger to life from electric shock!



Never disconnect the connection plug and plug connector under load.

- Switch off the grid voltage by turning off the external circuit breakers before you detach the AC cables from the screw terminal.
- Make sure that the device is isolated from the public power supply and the system power supply before starting work.

Latch

Disconnecting the AC connection

- U Ensure there is no AC/DC voltage present.
- 1. Open the connection area.
- 2. Switch off the grid voltage by turning off the external circuit breakers.
- 3. Detach cables (L1/L2/L3/N/PEN) from the AC connection terminal.
- 4. Detach the PE line from the earthing bolt.
- 5. Loosen the cable fitting and pull the cables out through the cable fitting.

9.5.2 Disconnecting the DC connection




Figure 32: Disconnect connector

Key

1 Screwdriver



Disconnect DC plug connection

- U Ensure there is no AC/DC voltage present.
- 1. Disconnect the PV generator using the DC isolator switch.
- 2. Use a screwdriver (blade width 3 mm) to push down the latch on the coupling.
- 3. Leave the screwdriver in place.
- 4. Disconnect the DC connector from the DC socket.

DANGER! The DC cables are still live.

Ensure that there is no voltage present on the grid connection terminals.

9.6 Faults

9.6.1 Procedure



<u>^</u>

DANGER

Lethal voltages are still present in the terminals and cables of the inverter even after the inverter has been switched off and disconnected.

Severe injuries or death will occur when touching the cables and terminals in the inverter.

- When a fault occurs, notify an appropriately authorised and qualified electrician or KACO new energy GmbH Service.
- The operator can only carry out actions marked with a B.
- In case of power failure, wait for the system to automatically restart.
- Notify your electrician if there is an extended power failure.

B = Action of the operator

E = The indicated work may only be carried out by an authorised electrician.

K = The indicated work may only be carried out by a service employee of KACO new energy GmbH!

9.6.2 Rectifying a fault

Fault	Cause of fault	Explanation/remedy	Ву
The display is blank and the LEDs do not	Grid voltage not available	Check whether the DC and AC voltages are within the permitted limits (see Technical Data).	E
light up.		Notify KACO Service.	E
The inverter stops feeding into the	Faulty grid sepa- ration relay in the	If the grid separation relay is defective, the inverter will recognise this during the self-test.	
grid shortly after being switched on, even though there is sunlight present.	inverter.	Ensure that there is sufficient PV generator power.	E
		If the grid separation relay is defective, have it replaced by KACO Service.	K
		Motify KACO Service.	
The inverter is active but is not feeding into the grid. The	Grid-feed is inter- rupted due to a grid fault.	Due to a grid fault (grid impedance too high, over/undervoltage, over/underfrequency), the inverter stopped the feed-in process and disconnected from the grid for safety reasons.	
display indicates a line failure.		Change the line parameters within the permitted operating limits (see the "Start-Up" section).	E



ΕN

Fault	Cause of fault	Explanation/remedy	Ву
The grid fuse trips.	The grid fuse capacity is too low.	In case of a high level of solar radiation, the inverter exceeds its rated current for a short period, depending on the PV generator.	
		Select the capacity of the inverter's pre-fuse to be somewhat higher than the maximum feed-in current (see the "Installation" section).	E
		 Contact the grid operator if the grid failure continues to occur. 	E
The grid fuse trips.	Damage to the inverter's hardware.	If the grid fuse trips immediately when the inverter goes into feed-in mode (after the start-up period is complete), the inverter's hardware is probably damaged.	
		Contact KACO Service to test the hardware.	E
The inverter displays an impossible daily peak value.	Faults in the grid.	The inverter continues to operate as normal without losses to the yield, even when an erroneous daily peak value is displayed. The value is reset overnight.	
		To reset the value immediately, switch the inverter off by disconnecting it from the grid and switching off the DC, then switch it back on.	E
Daily yields do not correspond to the yields on the feed-in meter.	Tolerances of the measuring elements in the inverter.	The measuring elements of the inverter have been selected to ensure maximum yields. Due to these tolerances, the daily yields shown may deviate from the values on the feed-in meter by up to 15%.	
			-
The inverter is active but is not feeding	 Generator volt- age too low 	 The PV generator voltage or power is not sufficient for feed-in (solar radiation is too low). 	
into the grid. Display: "Waiting for feed-in"	 Grid voltage or PV generator voltage unsta- ble. 	 The inverter checks the grid parameters before the feed-in process begins. The length of time it takes to switch back on again differs from country to country, depending on applicable standards and regulations, and may be several minutes. 	
		The starting voltage may have been set incorrectly.	
		Adjust starting voltage in the Parameter menu if required.	Ε
In spite of high radiation levels, the inverter does not feed the maximum	The device is too hot and the system limits the power.	Because the temperatures inside the unit are too high, the inverter reduces its power to prevent damage to the unit. Note the technical data. Ensure that the convection cooling is not impeded from the exterior. Do not cover the cooling fins.	
power into the grid.		Ensure sufficient cooling of the unit.Do not cover the cooling fins.	В,



Fault	Cause of fault	Explanation/remedy	Ву
Noise emission Particular ambient conditions.		When there are certain ambient conditions, the units may emit audible noises.	
	 Grid interference or grid failure caused by particular loads (motors, machines, etc.) which are either connected to the same point on the grid or located in the vicinity of the inverter. 		
	 In cases of volatile weather conditions (frequent switching between sunny and cloudy conditions) or strong solar radiation, a light hum may be audible due to the increased power. 		
	 Under particular grid conditions, resonances may form between the unit's input filter and the grid; these may be audible even when the inverter is switched off. 		
		These noise emissions do not affect the operation of the inverter. They do not lead to loss of performance, failure, damage or to a shortening of the unit's service life.	
		People with very sensitive hearing (particularly children) are able to hear the high-frequency hum caused by the inverter's operating frequency of approximately 17 kHz.	
		→ No action	

"Fault" messages on the display/LED 9.7

Many fault signals indicate a fault in the grid. They are not operational faults of the inverter. The triggering levels are defined in standards, e.g. VDE0126-1-1. The inverter shuts down if the values exceed or fall below the approved levels.

9.7.1 Display of status and fault messages

Display	Fault LED (red)		
FS (fault status)		ON	Fault signal relay has switched.Feed-in was ended due to a fault.
OS (operating status)	O A	OFF	 The fault signal relay releases again. The inverter feeds back into the grid again after a country-specific time period.

Details regarding the fault or operating status can be found either on the display or in the data that was recorded through the RS485 interface.

Status and fault signals 9.7.2

The following table lists the possible status and fault signals that the inverter shows on the LCD and the LEDs.

BS = operating status, FS = fault status;

B = Action of the operator

E = The indicated work may only be carried out by an authorised electrician.

K = The indicated work may only be carried out by a service employee of KACO new energy GmbH!

Status	Display	Ā	⚠	Explanation	Action
OS 1	Waiting for feed-in	0	0	Self-test: The grid parameters and generator voltage are being checked.	-
Table 6:	Operating status and	fault m	nocca	ges on the display	



Stat	tus	Display	Ā	\triangle	Explanation	Ac	tion	
OS	2	Generator voltage too low	0	0	Insufficient generator voltage and power, status before the transition to night shutdown	-		-
os	8	Self-test	0	0	Checks the shutdown of the power electronics as well as the grid relay before feed-in mode.	-		-
FS	10	Temperature in unit too high	0		In case of overheating, the inverter switches off. Possible causes: Excessively high ambient temperature, Fan covered, Inverter defective.	6 6	Cool off the area around the inverter. Uncover the fans. Notify your authorised electrician.	B B E
os	11	Measured values		0	Power limitation: If the generator power itself to the maximum power (e.g. aroun is too large).			
FS	17	Shutting down Powador-protect	0		The activated grid and system protection has been tripped.	G	Wait for reactivation. Notify your authorised electrician if the fault occurs several times.	E
FS	18	Resid. current shut- down	0		Residual current was detected. The feed-in was interrupted.	F	Notify your author- ised electrician.	E
FS	19	Generator insula- tion fault	0		There is an insulation fault on the PV generator. The feed-in was interrupted.	G	Notify your authorised electrician if the fault occurs several times.	E
FS	30	Fault Transformer fault	0		The current and voltage measure- ments in the inverter are not within acceptable range.	-		-
FS	32	Fault Self-test	0		The internal grid separation relay test has failed.	G	Notify your authorised electrician if the fault occurs several times.	E
FS	33	Fault DC feed-in	0		The DC feed-in has exceeded the permitted value. This DC feed-in can be caused by grid conditions and may not necessarily indicate a fault.	F	Notify your authorised electrician if the fault occurs several times.	E
FS	34	Internal communication error	0		A communication error has occurred in the internal data transmission.	· · · · · · · · · · · · · · · · · · ·	Notify your authorised electrician. Check the data cable.	E
FS	35	Protection shut- down SW	0		Protective shutdown of the software (AC overvoltage, AC overcurrent, DC link overvoltage, DC overvoltage, DC overtemperature).	do	ot a fault Grid-related sh wn, the grid connects a tomatically.	
FS	36	Protection shut- down HW	0		Protective shutdown of the hardware (AC overvoltage, AC overcurrent, DC link overvoltage).	do	ot a fault Grid-related sh wn, the grid connects a tomatically.	

Stat	tus	Display	Ā	⚠	Explanation	Ac	tion	
FS	38	Generator overvolt- age error	0		The voltage of the DC generator is too high. The PV generator is configured incorrectly.	G	Notify your authorised electrician.	E
FS	41 42	Line failure: Under voltage L1, Over voltage L1,	0		The voltage of a grid phase is too low; the grid cannot be fed into. The phase experiencing failure is displayed.	G	Notify your authorised electrician.	E
	43 44	Under voltage L2, Over voltage L2,						
	45 46	Under voltage L3, Over voltage L3,						
FS	47	Grid failure phase- to-phase voltage	0		The measured line-to-line voltage is outside of the tolerance limits.			
FS	48	Line failure Underfrequency	0		Grid frequency is too low. This fault may be grid-related.	F	Notify your author- ised electrician.	E
FS	49	Line failure Overfrequency	0		Grid frequency is too high. This fault may be grid-related.	F	Notify your author- ised electrician.	E
FS	50	Line failure average voltage	0		The grid voltage measurement according to EN 50160 has exceeded the maximum permitted limit value. This fault may be grid-related.	G	Notify your authorised electrician.	E
FS	57	Waiting for reactivation	0		Waiting time of the inverter after a fault.	Inverter does not switch on again until the country-specif time has elapsed.		
FS	58	Overtemperature Control card	0		The temperature inside the unit was too high. The inverter switches off to prevent damage to the hardware.	F	Provide for sufficient ventilation.	E
FS	59	Self test error	0		A fault occurred during a self-test.	F	Disconnect device an wait 5 Minutes for restart.	В
						S	Notify your author- ised electrician.	E
os	60	Generator voltage too high	0		The inverter does not begin feeding into the grid until the PV voltage falls below a specified value.	-		-
OS	61	External limit (%)	***	0	The external limit <i>Power control</i> was acti inverter limits its power.	vate	d by the grid operator.	.The
os	63	Measured values		0	P(f)/frequency-dependent power reduct power reduction will be activated when of Energy and Water Industries) Medium effect. Power reduction starts at a freque	the Vol	BDEW (German Associtage Directive goes into	ation
os	64	Measured values		0	Output current limiting: The AC current maximum value has been reached.	is lir	nited once the specifie	d
FS	67	Fault at power section 1		0	There is a fault in the power section.	G	Notify your authorised electrician.	E
FS	70	Fan error			The fan is malfunctioning.	9	Replace defective	Е



Stat	tus	Display	Ā	⚠	Explanation	Ac	tion	
FS	73	Standalone grid err.	0		Standalone mode was detected.	-		-
os	74	External idle power requirement	***	0	The grid operator limits the feed-in power of the inverter.	-		-
os	79	Insulation meas- urement	0	0	PV generator's insulation is being measured	-		-
FS	80	Insulation meas. not possible	0		The insulation measurement cannot be performed because the generator voltage is too volatile.	-		-
FS	81, 82, 83	Protection shut- down line volt. L1, L2, L3	0		Overvoltage has been detected on a conductor. An internal protective mechanism has disconnected the device to protect it against damage.	G	In case of repeated occurrence: Notify your authorised electrician.	E
FS	84	Protection shut- down undervolt. DC link	0		A voltage deviation has been found in the DC link. An internal protective mechanism has disconnected the	F	In case of repeated occurrence: Notify your author-	E
FS	85	Protect. shutdown overvolt. DC link	0		device to protect it against damage.		ised electrician.	E
FS	86	Protect. shutdown DC link asymmetry	0		Overvoltage has been found in the DC link. An internal protective mechanism has disconnected the device to protect it against damage.	G	In case of repeated occurrence: Notify your authorised electrician.	E
FS	87, 88, 89	Protection shut- down overcurrent L1, L2, L3	0		A current that has been found on a conductor is too high. An internal protective mechanism has disconnected the device to protect it against damage.	F	In case of repeated occurrence: Notify your authorised electrician.	E
FS	93, 94	Self test error Buffer 1, Buffer 2	0		The control board is defective.	G	Notify authorised electrician / KACO Service	E/K
FS	95, 96	Self test error Relay 1, Relay 2	0		The power section is defective.	G	Notify KACO Service	K

Table 6: Operating status and fault messages on the display

Sta	tus	Display	Ā	⚠	Explanation	Ac	tion	
FS	97	Protection shut- down overcurrent HW	0		Too much power has been fed into the grid. Complete disconnection of the device.	G	Notify authorised electrician / KACO Service	E/K
FS	98	Protect. shutdown HW gate driver	0		An internal protective mechanism has disconnected the device to protect it against damage. Complete disconnection of the device.	F	Notify authorised electrician / KACO Service	E/K
FS	99	Protect. shutdown: HW buffer free	0		An internal protective mechanism has disconnected the device to protect it against damage. Complete disconnection of the device.	F	Notify authorised electrician / KACO Service	E/K
FS	100	Protect. shutdown HW overheating	0		The device has been switched off because the temperatures in the housing were too high.	G G	Check to make sure that the fans are working. Replace fan if nec- essary.	B E
FS	101 to 106	Temperature plausibility error, efficiency, DC link, AFI module, relay, DC/DC converter	0		The unit has shut down because of implausible internal measured values.	G	Notify KACO Service	K

Table 6: Operating status and fault messages on the display

10 Service

If you need help solving a technical problem with one of our KACO products, please contact our service hotline.

Please have the following information ready so that we can help you quickly and efficiently:

- · Device name / serial number
- Date of installation / Start-up report
- Fault message shown on the display / Description of the fault / Did you notice anything unusual? / What has already been done to analyse the fault?
- Module type and string circuit
- · Consignment identification / Delivery address / Contact person (with telephone number)
- Information about the accessibility of the installation site.

 Any additional costs arising from unfavourable structural or mounting conditions shall be billed to the customer.

You can find the following items and other information at our web site http://www.kaco-newenergy.de/:

- · our current warranty conditions,
- · a complaint form,
- the option for registering your device with us. In this manner, you can assist us in providing you with the quickest service possible.

Note: The maximum length of the warranty is based on the currently applicable national warranty conditions.

Service hotline	Technical troubleshooting	Technical consultation
inverter	+49 (0) 7132/3818-660	+49 (0) 7132/3818-670
Data logging and accessories	+49 (0) 7132/3818-680	+49 (0) 7132/3818-690
Customer Service	Monday to Friday 08:00 a.m. to 12:00 p.m. (CET) and 01:00 p.m. to 5:00	



11 Shutdown/Disassembly

11.1 Switching off the unit

DANGER

Lethal voltages are still present in the terminals and cables of the inverter even after the inverter has been switched off and disconnected.



Severe injuries or death will occur when touching the cables and terminals in the inverter.

When there is solar radiation, DC voltage will be present at the open ends of the DC cables. Arcing may occur if the DC cables are disconnected while they are still live.

- > It is absolutely essential that the shutdown sequence be carried out in the correct order.
- > After shutdown, wait at least 30 minutes before working on the inverter.
- When working on photovoltaic modules, in addition to disconnecting from the grid, always disconnect the DC main switch on the generator junction box at all poles (or the DC plug connectors).
 Simply disconnecting the grid voltage is not sufficient!



CAUTION

Risk of burns from hot housing components.



The housing surface and the heat sink can adopt a surface temperature of 75° in operation.

- » Do not touch the housing surface or heat sink during and immediately after operation.
- Allow the device to cool down before touching the housing surface.

DANGER

Destruction of the DC plug connectors



DC plug connectors can be destroyed by arcing if disconnected while still live. It is absolutely essential that the following shutdown sequence be carried out in the correct order:

- 1. Switch off the grid voltage by turning off the external circuit breakers.
- 2. Switch off the PV generator using the DC isolator switch.

DANGER! The DC cables are still live!

3. Ensure that there is no voltage present on the grid connection terminals.

11.2 Uninstalling the device

- U Inverter disconnected and secured against restart.
- 1. Open the connection area.
- 2. Remove the interface cable.
- 3. Detach DC connection plug.
- 4. Detach AC connection cables for the connection terminals.
- 5. Open the cable fittings.
- 6. Pull out the cables.
- » The inverter is uninstalled. Proceed with disassembly.

11.3 Disassembling the unit

- 1. Unit has been switched off and uninstalled.
- 2. Unscrew the detachment protector.
- 3. Take the unit down from the mounting plate.
- 4. Securely pack up the unit if it is to be used later, or have the unit disposed of in the correct manner.



11.4 Packaging the unit

- The inverter is uninstalled.
- 1. If possible, always pack the inverter in the original packaging. If this is no longer available, an alternative is to use equivalent packaging.
- 2. You must be able to close the box completely and it must be able to accommodate the weight and size of the inverter.

11.5 Storing the unit

- ☼ The inverter is packed.
- Store the inverter in a dry place, in accordance with the ambient temperature range (see chapter 4.2 on page 11.

12 Disposal

CAUTION

Risk to the environment if disposal is not carried out in the correct manner

For the most part, both the inverter and the corresponding transport packaging are made from recyclable raw materials.

Unit: Do not dispose of faulty inverters or accessories together with household waste. Ensure that the old unit and any accessories are disposed of in a proper manner.

Packaging: Ensure that the transport packaging is disposed of properly.





13 Appendix

13.1 EU Declaration of Conformity

Manufacturer's name and address KACO new energy GmbH

Carl-Zeiss-Strasse 1

74172 Neckarsulm, Germany

Product description Photovoltaic feed-in inverter

Type designation blueplanet 20.0 TL3 - INT

This is to confirm that the units listed above comply with the protection requirements set forth in the Directive of the Council of the European Union of 26th February 2014 on the harmonisation of the laws of the member states relating to Electromagnetic Compatibility (2014/30/EU) and the Low Voltage Directive (2014/35/EU).

The units conform to the following standards:

2014/35/EU

"Directive relating to electrical equipment designed for use within certain voltage limits"

2014/30/EU

"Directive relating to electromagnetic compatibility"

Safety of the unit

IEC 62109-1:2010 IEC 62109-2:2011

Interference immunity

EN 61000-6-1:2007 EN 61000-6-2:2005

Emitted interference

EN 61000-6-3:2007 + A1:2011 EN 61000-6-4:2007 + A1:2011

Secondary effects on the grid

EN 61000-3-2:2006* + A1:2009 + A2:2009

EN 61000-3-3:2008*

EN 61000-3-11:2000**

EN 61000-3-12:2011**


* valid for device types with a nominal current ≤16 A

** valid for device types with a nominal current ≥16 A

The types mentioned above are therefore labelled with the CE mark.

Unauthorised modifications to the supplied units and/or any use of the units that is contrary to their intended use render this Declaration of Conformity null and void.

Neckarsulm, 20/04/2016 KACO new energy GmbH



Management team for technology / CTO

