Product UserInstructions

⚠ WARNING!

Improper use may cause injury,choking,fire,or electric shock.Keep out of reach of children under 16 years of age.Do not use if damaged or modified.Do not expose to extreme heat,open flame,or prolonged moisture.

SAFETY INFORMATION

Read all instructions before use and retain for future reference.This is NOT a toy.No unsupervised use by children or persons with reduced physical,sensory,or mental capabilities.Avoid contact with eyes,mouth, or open wounds.Disconnect power and stop operation before cleaning or maintenance.Seek immediate medical assistance if injury occurs.

Product Name:Electric Bike Parts &Accessories
Model:None
Brand:None
Manufacturer:Foshan Lanyixingchen E-commerce Co.,Ltd.
EU Responsible Person:MJCM SARL
Address: France, 78 avenue des Champs-Elysees Bureau 326
Intended Use:For repair only
Age Recommendation:18 years and older

Correct Operation Steps:
1.Unpack and inspect for any damage.
2.Prepare removal tools (e.g.,screwdriver,pry bar).
3.Remove the old parts.
4.Prepare the new parts,identify the connection interface,and connect them correctly.
5.Use the tools to reassemble the parts onto the scooter.
6.Post-use:Test to verify proper functionality.

Usage Restrictions:
Not intended for children under 18 years of age.
Do not use near fire or corrosive chemicals.
Do notimmerse in water.
Not compatible with scooters of mismatched models.
Care &Maintenance:
Clean only with a dry cloth.Store in a cool,dry place away from direct immediately if parts malfunction,crack,or break.
Clean only with a dry cloth.Store in a cool,dry place away from direct immediately if parts malfunction,