Product Manual

Product Description

Product Structure

1) back clip fixation hook
2) USB data interface
3) Rear pull camera interface
4) Mode selection key
5) upward selection button
6) OK key / power supply key
7) down select button
8) menu button
9) LCD screen
10) TF card slot
11) REST
12) lens
13)horn

Key function description:

1) back clip fixation hook

Fixed video recording instrument

2) USB data interface

USB data interface, which is used to connect the PC transmission data; II is used to connect the external power supply to the battery charge or provide work power;

3) Rear pull camera interface

4) Mode selection key

Press this key to switch between camera / photo / playback;

5) upward selection button

Menu options, down regulation function keys;

6) OK key / power supply key

Short press on / off;

Video and photo confirmation button, video mode, press this button to start the video, press the video button again to stop the video; press this button to shoot photos;

7) down select button

Menu option, down select the function key;

8) menu button

press this key to call up the menu

Menu mode for confirmation;

9) LCD screen

Image display

10) TF card slot

Memory card slot

11) REST

Restart recovery hole;

12) lens

Viewing window;

13) horn

Play video or sound amplification hole files, operating sound warning;

Special function:

automatic on / off

Support the connection of vehicle power, the car starts automatically on the video, the automatic save video and turn off;

L do not leak seconds

- motion detection

In the case of the standby condition, the moving process is recorded automatically when the target is moved.

Camera / photo basic operating instructions:

The start-up and shutdown.

L press the power button first boot, the blue indicator light exhibit of lanterns at boot time;

Press the power button again, and the blue indicator light goes out;

Note: the video device will be automatically shut down when the battery is low.

- camera mode

Short press mode select key / menu key button, switch to camera mode, the upper left corner of the screen displays the camera icon;

Press OK key to start the camera, the camera icon will appear flashing red dot, indicating the video work;

- camera mode

Short press mode select button / menu button, switch to camera mode, the upper left corner of the screen to display the camera icon;

Press OK button to take a picture, the screen flashes once, said the photo was completed.

Video / photo playback

Short press mode select button / menu key button, switch to playback mode, the upper left corner of the screen display playback icon;

Short press key to select the file;

Press the key to select the file;

Short press OK key to play the selected video files;

L set menu

Press the mode select button / menu button to enter the video setting state, this time the "video Icon" of the bar is a yellow background, short press mode select button / menu key button, exit the setting state.

In the set up of the call, by short press key, you can choose to switch on the set up and down, and press the OK key to enter the setting;

- time setting

Press the mode select key / menu button to enter the setting state, the short press OK key to enter, can be in the year / month / day / time / time / sub / second to switch between each other by adjusting the need for numerical value, press OK to confirm the change;

USB model

The USB line and the computer connection, press the starting button, the driving recorder will automatically pop up the USB menu. There are two models available for selection:

1:USB-Disk

In this mode can be video files or photo file access;

2:PC camera

Select this mode will pop up USB video equipment, can be real-time camera or video chat;

Battery charge description

There are three kinds of methods can be used to charge the battery, charging the red indication lantern in the process of charging is lit, the charging time is about 180 minutes, charging the red indicator is automatically extinguished after charging is completed.

1: use the power adapter to charge

2: use PC-USB charging

3: the use of on-board power charging

Note: when using this product due to improper operation caused by the phenomenon of crash, you can remove the battery or press the reset button and then boot, you can return to normal.

Product specificat

Product name
Product features
Color
Display
Camera lens
Language
File format
Video resolution
Video format
Loop video
Switch machine
Mobile detection function
Days and days
Photographic mode
Photo format
Memory card
Microphone
Built in stereo
Video format
Current frequenc
USB function
Power supply interface
Battery

Difficult soluti

Is under normal
refer to the sol

L can't take ph

Check the TF ca

- video, it wil

Because of the h
card and SDHC c