

WaveVision®  
Bullseye®

**Monosem WaveVision and Bullseye Seed Tube Modification**

Precision Planting®

## Monosem WaveVision and Bullseye Seed Tube Modification

If you have purchased the Monosem WaveVision (700260) or Bullseye (700158) seed tubes before 2019 they may need to be modified in order to install vSet 2 on a Monosem row unit. If your seed tubes already have the below modifications nothing further is needed.

Previously purchased WaveVision and Bullseye seed tubes will need the same modification. Follow the below steps:

- 1) To the right you will see the unmodified Monosem seed tube. Both corners that need modification are circled.
- 2) See the images below for the trimming instructions.
- 3) Measure and mark one inch from the pin side (front) of the tube to the rear of the tube on each side (see green mark).
- 4) Measure down from your one inch mark .875 inches, keeping parallel with the pin side (front) of the tube, and make another mark (see blue mark).
- 5) Follow the .875 inch mark to the rear of the tube, keeping parallel with the top of the tube, and make one more mark (see red mark).
- 6) Trim the corners between the green mark and the red mark (see red dotted line).
- 7) Repeat these steps on all Monosem seed tubes that don't already have the corners trimmed correctly.

