

FERRO CONCEPTS

Back Panel Charge Quivers

Table of Contents

Product Overview	1
Back Panel Charge Quivers Fitment	2-4
Back Panel Charge Quivers Exterior Installation	5-8
Back Panel Charge Quivers Interior Installation	9-11



Back Panel Charge Quivers
on FCPC (Exterior Mount)



Back Panel Charge Quivers | Product Overview

The Back Panel Charge Quivers are a modular set of left and right sleeves built to carry door charges, flags, recovery straps, and more. Designed to zip to the exterior of your FCPC and back panel, or run on the interior for a slicker setup. Made from rugged X-Pac with bungee retention points and customizable top and bottom closures for secure carry and quick access.

Features:

- Set of two (left + right)
- Zips onto FCPC between back panel
- Rugged X-Pac construction
- Dual bungee retention for charges and gear
- Configurable top and bottom closures
- Updated zipper pull retention
- Interior and Exterior configuration onto FCPC
- Lightweight, low-profile, mission-ready
- Length: 11.5" - Diameter: 2"
- Made in USA

Components:

- Back Panel Charge Quivers (Left and Right)



Back Panel Charge Quivers
Left and Right (Front)



Back Panel Charge Quivers
Left and Right (Back)

Back Panel Charge Quivers | Fitment

Fitting and Securing item



1. To retain your items, start by placing items into the Back Panel Charge Quivers.



2. Pull shock cord on top to desired retention located on the backside of the Back Panel Charge Quivers.

Back Panel Charge Quivers | Fitment

Fitting and Securing item



3. Pull shock cord on bottom to desired retention located on the backside of the Back Panel Charge Quivers.



4. Once your item is secure, you can now install it onto the FCPC.

Back Panel Charge Quivers | Fitment

Fitting and Securing item



5. The bottom of the Back Panel Charge Quivers can be closed by routing a zip tie or shock cord through the two bottom holes.



6. Once your zip tie or shock cord is secured, trim the end to reduce any snag hazard.

Back Panel Charge Quivers | Exterior Installation

Installing the Back Panel Charge Quivers on the FCPC (Exterior)



1. Start by zipping the Back Panel Charge Quiver (Left) on the left rear side of the FCPC.



2. Ensure that your zipper is all the way to the bottom of the FCPC.

Back Panel Charge Quivers | Exterior Installation

Installing the Back Panel Charge Quivers on the FCPC (Exterior)



3. Pinch and pass the bow tie zipper retention through the zipper pull.



4. Ensure that your bow tie zipper retention is fully passed through the zipper pull to prevent zipper walk.

Back Panel Charge Quivers | Exterior Installation

Installing the Back Panel Charge Quivers on the FCPC (Exterior)



5. Zip the Back Panel Charge Quiver (Right) on the right rear side of the FCPC. Then repeat steps 2-4.



6. Once the bow tie zipper retention is completed on both Back Panel Charge Quivers, zip your back panel on both sides.

Back Panel Charge Quivers | Exterior Installation

Installing the Back Panel Charge Quivers on the FCPC (Exterior)



7. This completes the Back Panel Charge Quivers Exterior Installation on the FCPC.

Back Panel Charge Quivers | Interior Installation

Installing the Back Panel Charge Quivers on the FCPC (Interior)



1. Start by zipping the Back Panel Charge Quiver (Left) on the right rear side of the FCPC. Ensure that your zipper is all the way to the bottom of the FCPC.



2. Zip on the Back Panel Charge Quiver (Right) on the left rear side of the FCPC. Ensure that your zipper is all the way to the bottom of the FCPC.

Back Panel Charge Quivers | Interior Installation

Installing the Back Panel Charge Quivers on the FCPC (Interior)



3. Pinch and pass the bow tie zipper retention through the zipper pull on both Back Panel Charge Quivers.



4. Ensure that your bow tie zipper retention is fully passed through the zipper pull to prevent zipper walk.

Back Panel Charge Quivers | Interior Installation

Installing the Back Panel Charge Quivers on the FCPC (Interior)



5. Once the bow tie zipper retention is completed on both Back Panel Charge Quivers, zip your back panel on both sides. Both Back Panel Charge Quivers should be on the interior underneath the Back Panel.



6. This completes the Back Panel Charge Quivers Interior Installation on the FCPC.