

модель	Завод	бренд
AL 109 X (IT)	STABILIMENTO COMUNANZA	ARISTON
AL 109 X (IT)		ARISTON
AL 89 X (IT)	STABILIMENTO COMUNANZA	ARISTON
AL 89 X (IT)		ARISTON
AL 68 X (IT)	STABILIMENTO COMUNANZA	ARISTON
AL 68 X (IT)		ARISTON
AB 108 X (IT)		ARISTON
AB 88 X (IT)	STABILIMENTO COMUNANZA	ARISTON
AB 88 X (IT)		ARISTON
ALS 109 X (IT)	STABILIMENTO COMUNANZA	ARISTON
ALS 109 X (IT)		ARISTON
ALS 89 XS (IT)	STABILIMENTO COMUNANZA	ARISTON
ALS 89 XS (IT)		ARISTON
ALS 89 X (IT)	STABILIMENTO COMUNANZA	ARISTON
ALS 89 X (IT)		ARISTON
ALS 68 X (IT)	STABILIMENTO COMUNANZA	ARISTON
ALS 68 X (IT)		ARISTON
AB 84 (PT)	STABILIMENTO TEVEROLA	ARISTON
AB 84 (PT)		ARISTON
AL 68 X (PT)	STABILIMENTO COMUNANZA	ARISTON
AL 68 X (PT)		ARISTON
AB 83 (TK)	STABILIMENTO TEVEROLA	ARISTON
AB 83 (TK)		ARISTON
AB 84 X (TK)		ARISTON
AB 104 X (TK)		ARISTON
AL 108 X (TK)	STABILIMENTO COMUNANZA	ARISTON
AL 108 X (TK)		ARISTON
AL 88 X (EU)	STABILIMENTO COMUNANZA	ARISTON
AL 88 X (EU)		ARISTON
AL 109 X (EU)	STABILIMENTO COMUNANZA	ARISTON
AL 109 X (EU)		ARISTON
AL 129 X (EU)	STABILIMENTO COMUNANZA	ARISTON
AL 129 X (EU)		ARISTON
AL 149 X (EX)	STABILIMENTO COMUNANZA	ARISTON
AL 149 X (EX)		ARISTON
ALS 88 X (EU)	STABILIMENTO COMUNANZA	ARISTON
ALS 88 X (EU)		ARISTON
ALS 109 X (EU)	STABILIMENTO COMUNANZA	ARISTON
ALS 109 X (EU)		ARISTON
ALS 129 X (EU)	STABILIMENTO COMUNANZA	ARISTON
ALS 129 X (EU)		ARISTON
AL 108 XS (TK)	STABILIMENTO COMUNANZA	ARISTON
AL 108 XS (TK)		ARISTON
W 93 T (EX)	STABILIMENTO TEVEROLA	INDESIT
W 93 T (EX)		INDESIT
W 83 T (EX)	STABILIMENTO TEVEROLA	INDESIT
W 83 T (EX)		INDESIT

W 83 (SP)	STABILIMENTO TEVEROLA	INDESIT
W 83 (SP)		INDESIT
W 83 (TK)	STABILIMENTO TEVEROLA	INDESIT
W 83 (TK)		INDESIT
W 73 (FR)		INDESIT
W 104 T (EX)	STABILIMENTO TEVEROLA	INDESIT
W 104 T (EX)		INDESIT
WS 84 TX (EX)	STABILIMENTO COMUNANZA	INDESIT
WS 84 TX (EX)		INDESIT
WS 105 TX (EX)	STABILIMENTO COMUNANZA	INDESIT
WS 105 TX (EX)		INDESIT
W 145 TX (EX)	STABILIMENTO COMUNANZA	INDESIT
W 145 TX (EX)		INDESIT
W 104 (NL)	STABILIMENTO TEVEROLA	INDESIT
W 104 (NL)		INDESIT
W 108 X (SP)	STABILIMENTO COMUNANZA	INDESIT
W 108 X (SP)		INDESIT
W 84 X (SP)	STABILIMENTO COMUNANZA	INDESIT
W 84 X (SP)		INDESIT
W 84 TX (TK)		INDESIT
W 104 TX (TK)		INDESIT
W 123 X (NL)		INDESIT
W 143 X (NL)	STABILIMENTO COMUNANZA	INDESIT
W 143 X (NL)		INDESIT
W 124 X (NL)	STABILIMENTO COMUNANZA	INDESIT
W 124 X (NL)		INDESIT
W 144 X (NL)	STABILIMENTO COMUNANZA	INDESIT
W 144 X (NL)		INDESIT
AL 108 X (BE)	STABILIMENTO COMUNANZA	ARISTON
AL 108 X (BE)		ARISTON
AL 128 X (BE)		ARISTON
AB 95 (EU)	STABILIMENTO TEVEROLA	ARISTON
AB 95 (EU)		ARISTON
AB 88 X (EX)	STABILIMENTO COMUNANZA	ARISTON
AB 88 X (EX)		ARISTON
AL 68 X (EX)	STABILIMENTO COMUNANZA	ARISTON
AL 68 X (EX)		ARISTON
AB 63 (EX) 220-50/60	STABILIMENTO TEVEROLA	ARISTON
AB 63 (EX) 220-50/60		ARISTON
AL 129 SL (BE)	STABILIMENTO COMUNANZA	ARISTON
AL 129 SL (BE)		ARISTON
W 104 (SP)	STABILIMENTO TEVEROLA	INDESIT
W 104 (SP)		INDESIT
W 128 X (SP)	STABILIMENTO COMUNANZA	INDESIT
W 128 X (SP)		INDESIT
W 125 X (FR)	STABILIMENTO COMUNANZA	INDESIT
W 125 X (FR)		INDESIT
W 84 XS (SP)	STABILIMENTO COMUNANZA	INDESIT

W 84 XS (SP)		INDESIT
W 83 (NL)		INDESIT
W 103 (NL)	STABILIMENTO TEVEROLA	INDESIT
W 103 (NL)		INDESIT
AL 109 X (EX) 220/60		ARISTON
W 144 XS (NL)	STABILIMENTO COMUNANZA	INDESIT
W 144 XS (NL)		INDESIT
W 104 TXS (TK)		INDESIT
WE 12 X (NL)		INDESIT
WE 14 X (NL)	STABILIMENTO COMUNANZA	INDESIT
WE 14 X (NL)		INDESIT
W 165 X (NL)	STABILIMENTO COMUNANZA	INDESIT
W 165 X (NL)		INDESIT
W 63 T (EX) 50-60 HZ	STABILIMENTO TEVEROLA	INDESIT
W 63 T (EX) 50-60 HZ		INDESIT
WE 125 X (EX)	STABILIMENTO COMUNANZA	INDESIT
WE 125 X (EX)		INDESIT
W 165 TX (EX)	STABILIMENTO COMUNANZA	INDESIT
W 165 TX (EX)		INDESIT
W 682 X S (IT)		INDESIT
W 842 X S (IT)	STABILIMENTO COMUNANZA	INDESIT
W 842 X S (IT)		INDESIT
WS 682 X S (IT)	STABILIMENTO COMUNANZA	INDESIT
WS 682 X S (IT)		INDESIT
W 83 (DE)	STABILIMENTO TEVEROLA	INDESIT
W 83 (DE)		INDESIT
W 104 (DE)	STABILIMENTO TEVEROLA	INDESIT
W 104 (DE)		INDESIT
W 125 X (DE)	STABILIMENTO COMUNANZA	INDESIT
W 125 X (DE)		INDESIT
W 125 XS (DE)	STABILIMENTO COMUNANZA	INDESIT
W 125 XS (DE)		INDESIT
W 126 X (DE)	STABILIMENTO COMUNANZA	INDESIT
W 126 X (DE)		INDESIT
W 144 X (DE)	STABILIMENTO COMUNANZA	INDESIT
W 144 X (DE)		INDESIT
W 145 X (DE)	STABILIMENTO COMUNANZA	INDESIT
W 145 X (DE)		INDESIT
W 146 X (DE)	STABILIMENTO COMUNANZA	INDESIT
W 146 X (DE)		INDESIT
LE 869 X (IT)	STABILIMENTO COMUNANZA	ARISTON
LE 869 X (IT)		ARISTON
LES 669 X (IT)	STABILIMENTO COMUNANZA	ARISTON
LES 669 X (IT)		ARISTON
LES 869 X (IT)	STABILIMENTO COMUNANZA	ARISTON
LES 869 X (IT)		ARISTON
AB 63 X (GR)		ARISTON
AL 169 X (EU)	STABILIMENTO COMUNANZA	ARISTON

AL 169 X (EU)		ARISTON
AB 88 D (EX)	STABILIMENTO COMUNANZA	ARISTON
AB 88 D (EX)		ARISTON
AL 88 D (EX)	STABILIMENTO COMUNANZA	ARISTON
AL 88 D (EX)		ARISTON
AL 108 D (EX)	STABILIMENTO COMUNANZA	ARISTON
AL 108 D (EX)		ARISTON
AL 118 D (TK)	STABILIMENTO COMUNANZA	ARISTON
AL 118 D (TK)		ARISTON
AL 128 D (EX)	STABILIMENTO COMUNANZA	ARISTON
AL 128 D (EX)		ARISTON
WD 84 T (EX)	STABILIMENTO COMUNANZA	INDESIT
WD 84 T (EX)		INDESIT
WD 105 T (EX)	STABILIMENTO COMUNANZA	INDESIT
WD 105 T (EX)		INDESIT
WD 125 T (EX)	STABILIMENTO COMUNANZA	INDESIT
WD 125 T (EX)		INDESIT
WH 96 TX (E)	STABILIMENTO COMUNANZA	INDESIT
WH 96 TX (E)		INDESIT
W 9521 (E)	STABILIMENTO TEVEROLA	INDESIT
W 104 T (BE)	STABILIMENTO TEVEROLA	INDESIT
W 104 T (BE)		INDESIT
WD 106 (FR)	STABILIMENTO COMUNANZA	INDESIT
WD 106 (FR)		INDESIT
AAX 126 L (FR)	STABILIMENTO COMUNANZA	ARISTON
AAX 126 L (FR)		ARISTON
AC 106 B (FR)	STABILIMENTO COMUNANZA	ARISTON
AC 106 B (FR)		ARISTON
AC 128 L (FR)	STABILIMENTO COMUNANZA	ARISTON
AC 128 L (FR)		ARISTON
B653X PH.IT		Whirlpool
B853X PH.IT		Whirlpool
B1053X PH.IT		Whirlpool
B1253X PH.IT		Whirlpool
WA1010 ELEC.D		Whirlpool
WA1012 ELEC.D		Whirlpool
WA16-1200 ELEC.D		Whirlpool
AL 109 X (SK)	STABILIMENTO COMUNANZA	ARISTON
AL 109 X (SK)		ARISTON
N842X PH.EXP		Whirlpool
AAX 149 L (FR)	STABILIMENTO COMUNANZA	ARISTON
AAX 149 L (FR)		ARISTON
N1042X PH.EXP		Whirlpool
N842X PH.P		Whirlpool
WT70 FR		INDESIT
WT82T FR	STABILIMENTO BREMBATE	INDESIT
WAT6 (IT)	STABILIMENTO BREMBATE	INDESIT
WAT8 (IT)	STABILIMENTO BREMBATE	INDESIT

AL 169 X (SK)		ARISTON
W 146 XS (DE)		INDESIT
W 166 X (DE)	STABILIMENTO COMUNANZA	INDESIT
W 166 X (DE)		INDESIT
N860X PH.P		Whirlpool
B853X PH.P		Whirlpool
B880X PH.P		Whirlpool
B653X PH.P		Whirlpool
B1253X PH.P		Whirlpool
N1242X PH.EXP		Whirlpool
B1253X PH.EXP		Whirlpool
AD 1200 (IT)	STABILIMENTO COMUNANZA	ARISTON
AD 1200 (IT)		ARISTON
B653X PH.EXP		Whirlpool
B853X PH.EXP		Whirlpool
B1053X PH.EXP		Whirlpool
LMW1000X		
FOURLIS.GR		Whirlpool
AD 1600 (IT)	STABILIMENTO COMUNANZA	ARISTON
AD 1600 (IT)		ARISTON
AC 80 L (IT)	STABILIMENTO COMUNANZA	ARISTON
AC 80 L (IT)		ARISTON
AC 120 L (IT)	STABILIMENTO COMUNANZA	ARISTON
AC 120 L (IT)		ARISTON
WT82 EX	STABILIMENTO BREMBATE	INDESIT
WT82 EX		INDESIT
WT102 EX	STABILIMENTO BREMBATE	INDESIT
WT102 EX		INDESIT
WA 6 (IT)	STABILIMENTO TEVEROLA	INDESIT
WA 8 (IT)	STABILIMENTO TEVEROLA	INDESIT
WA 10 (IT)	STABILIMENTO TEVEROLA	INDESIT
WA 6 X (IT)	STABILIMENTO COMUNANZA	INDESIT
WA 6 X (IT)		INDESIT
WA 10 X (IT)	STABILIMENTO COMUNANZA	INDESIT
WA 10 X (IT)		INDESIT
WES 9 X (R)	STABILIMENTO COMUNANZA	INDESIT
WES 9 X (R)		INDESIT
WT80 (CSI)	STABILIMENTO BREMBATE	INDESIT
WT80 (CSI)		INDESIT
WT90 (CSI)	STABILIMENTO BREMBATE	INDESIT
WT100 (CSI)	STABILIMENTO BREMBATE	INDESIT
WT100 (CSI)		INDESIT
WA 8 XS (IT)	STABILIMENTO COMUNANZA	INDESIT
WA 8 XS (IT)		INDESIT
WE 8 X (R)	STABILIMENTO COMUNANZA	INDESIT
WE 8 X (R)		INDESIT
LBE 12 X	STABILIMENTO COMUNANZA	ARISTON
LBE 12 X		ARISTON

LBE 6 X	STABILIMENTO COMUNANZA	ARISTON
LBE 6 X		ARISTON
LBE 8 X	STABILIMENTO COMUNANZA	ARISTON
LBE 8 X		ARISTON
WT67 (EU)	STABILIMENTO BREMBATE	INDESIT
AB 66 X (IT)		ARISTON
WAS 6 X (IT)	STABILIMENTO COMUNANZA	INDESIT
WAS 6 X (IT)		INDESIT
WAS 8 X (IT)	STABILIMENTO COMUNANZA	INDESIT
WAS 8 X (IT)		INDESIT
WE 14 (DE)	STABILIMENTO COMUNANZA	INDESIT
WE 14 (DE)		INDESIT
BF853X BENDIX.F		Whirlpool
W 105 TX (R) (BG)	STABILIMENTO BREMBATE	INDESIT
W 105 TX (R) (BG)		INDESIT
AL 65 (PT)	STABILIMENTO TEVEROLA	ARISTON
AB 107 (PT)	STABILIMENTO TEVEROLA	ARISTON
AT 85 (FR)	STABILIMENTO BREMBATE	ARISTON
ATD 90 (FR)		ARISTON
ATD 100 (FR)	STABILIMENTO BREMBATE	ARISTON
ATD 120 (FR)	STABILIMENTO BREMBATE	ARISTON
AT62 (IT)	STABILIMENTO BREMBATE	ARISTON
AT82 (IT)	STABILIMENTO BREMBATE	ARISTON
ATD84 (IT)	STABILIMENTO BREMBATE	ARISTON
ATD104 (IT)	STABILIMENTO BREMBATE	ARISTON
ATD120 (EX)	STABILIMENTO BREMBATE	ARISTON
WE 12 S (DE)	STABILIMENTO COMUNANZA	INDESIT
WE 12 S (DE)		INDESIT
WE 14 S (DE)	STABILIMENTO COMUNANZA	INDESIT
WE 14 S (DE)		INDESIT
WE 16 (DE)	STABILIMENTO COMUNANZA	INDESIT
WE 16 (DE)		INDESIT
WD 125 TS (EX)	STABILIMENTO COMUNANZA	INDESIT
WD 125 TS (EX)		INDESIT
AD 1600 (FR)		ARISTON
ALD 100 (EX)		ARISTON
ALD 120 (EX)	STABILIMENTO COMUNANZA	ARISTON
ALD 120 (EX)		ARISTON
ALD 120 (FR)		ARISTON
ALD 130 (FR)		ARISTON
AD 1600 PXU (IT)		ARISTON
ALD 100 (IT)		ARISTON
ALD 120 (IT)		ARISTON
AD 1200 (TK)	STABILIMENTO COMUNANZA	ARISTON
AD 1200 (TK)		ARISTON
CDE 12 X	STABILIMENTO COMUNANZA	ARISTON
CDE 12 X		ARISTON
WME 6 X	STABILIMENTO COMUNANZA	INDESIT

WME 6 X		INDESIT
WME 12 X	STABILIMENTO COMUNANZA	INDESIT
WME 12 X		INDESIT
WDE 12 X	STABILIMENTO COMUNANZA	INDESIT
WDE 12 X		INDESIT
MLE 12 X	STABILIMENTO COMUNANZA	SCHOLTES
MLE 12 X		SCHOLTES
MLSE 12 X	STABILIMENTO COMUNANZA	SCHOLTES
MLSE 12 X		SCHOLTES
AL 102 P (FR)	STABILIMENTO TEVEROLA	ARISTON
ADS 1200 (EX)		ARISTON
W 84 TX (EX) (BG)	STABILIMENTO BREMBATE	INDESIT
W 84 TX (EX) (BG)		INDESIT
WD 105 T (EX) 220-60	STABILIMENTO COMUNANZA	INDESIT
WD 105 T (EX) 220-60		INDESIT
AL 78 X (PT)	STABILIMENTO COMUNANZA	ARISTON
AL 78 X (PT)		ARISTON
AL 78 XS (PT)	STABILIMENTO COMUNANZA	ARISTON
AL 78 XS (PT)		ARISTON
AL 98 X (PT))	STABILIMENTO COMUNANZA	ARISTON
AL 98 X (PT))		ARISTON
AL 98 XS (PT))	STABILIMENTO COMUNANZA	ARISTON
AL 98 XS (PT))		ARISTON
AT 84 (EX)	STABILIMENTO BREMBATE	ARISTON
AT 84 (EX)		ARISTON
ATD 104 (EX)	STABILIMENTO BREMBATE	ARISTON
ATD 104 (EX)		ARISTON
WA 6 (PT)	STABILIMENTO TEVEROLA	INDESIT
WA 8 (PT)	STABILIMENTO TEVEROLA	INDESIT
WA 10 (PT)	STABILIMENTO TEVEROLA	INDESIT
WE 8 (EX)	STABILIMENTO TEVEROLA	INDESIT
WE 10 (EX)	STABILIMENTO TEVEROLA	INDESIT
WE 10 (EX)		INDESIT
WA 6 XS (PT)	STABILIMENTO COMUNANZA	INDESIT
WA 6 XS (PT)		INDESIT
WA 8 XS (PT)	STABILIMENTO COMUNANZA	INDESIT
WA 8 XS (PT)		INDESIT
W 85 (FR)	STABILIMENTO TEVEROLA	INDESIT
W 105 (FR)	STABILIMENTO TEVEROLA	INDESIT
W 128 X (FR)	STABILIMENTO COMUNANZA	INDESIT
W 128 X (FR)		INDESIT
AXD 120 (FR)		ARISTON
WT 102 T (FR)	STABILIMENTO BREMBATE	INDESIT
ALDS 120 (EX)	STABILIMENTO COMUNANZA	ARISTON
ALDS 120 (EX)		ARISTON
ALD 140 (EX)	STABILIMENTO COMUNANZA	ARISTON
ALD 140 (EX)		ARISTON
WP 67 (EX)	STABILIMENTO TEVEROLA	INDESIT

WP 100 (EX)	STABILIMENTO TEVEROLA	INDESIT
AD 1000 (EX)	STABILIMENTO COMUNANZA	ARISTON
AD 1000 (EX)		ARISTON
ALD 128 D (EX)		ARISTON
AXD 80 (EU)	STABILIMENTO BREMBATE	ARISTON
AXD 100 (EU)	STABILIMENTO BREMBATE	ARISTON
AXD 100 (EU)		ARISTON
ALD 120 (BE)	STABILIMENTO COMUNANZA	ARISTON
ALD 120 (BE)		ARISTON
ALD 140 (BE)	STABILIMENTO COMUNANZA	ARISTON
ALD 140 (BE)		ARISTON
ALD 160 (EU)	STABILIMENTO COMUNANZA	ARISTON
ALD 160 (EU)		ARISTON
AXD 120 (IT)	STABILIMENTO BREMBATE	ARISTON
AXD 120 (IT)		ARISTON
ALD 100 (TK)		ARISTON
W46.08TL (CSI)	STABILIMENTO BREMBATE	Whirlpool
W46.08TL (CSI)		Whirlpool
W46.10TL (CSI)	STABILIMENTO BREMBATE	Whirlpool
W46.10TL (CSI)		Whirlpool
ALDS 100 (IT)		ARISTON
LE 1069 X (IT)		ARISTON
AB 67 X (IT)	STABILIMENTO COMUNANZA	ARISTON
AB 67 X (IT)		ARISTON
AB 87 X (IT)	STABILIMENTO COMUNANZA	ARISTON
AB 87 X (IT)		ARISTON
ALD 140 (FR)		ARISTON
ALDS 105 (FR)		ARISTON
AB 104 (IT)	STABILIMENTO TEVEROLA	ARISTON
AB 84 (IT)	STABILIMENTO TEVEROLA	ARISTON
LWD1053X (EX)		Whirlpool
S842X (EX)		Whirlpool
W60T10 (CSI)	STABILIMENTO BREMBATE	Whirlpool
W42T10 (CSI)	STABILIMENTO BREMBATE	Whirlpool
W 42.08 (CSI)	STABILIMENTO BREMBATE	Whirlpool
S 1053 X (EX)		Whirlpool
W 42.10 (CSI)	STABILIMENTO BREMBATE	Whirlpool
W 123 X (NL) (BG)	STABILIMENTO BREMBATE	INDESIT
WDS 105 T (R)	STABILIMENTO BREMBATE	INDESIT
WDS 105 T (R)		INDESIT
W 53.10 (CSI)	STABILIMENTO BREMBATE	Whirlpool
WDE 12 X (NL)	STABILIMENTO COMUNANZA	INDESIT
WDE 12 X (NL)		INDESIT
ALDS 80 (EX)	STABILIMENTO COMUNANZA	ARISTON
ALDS 80 (EX)		ARISTON
ALD 80 (EX)	STABILIMENTO COMUNANZA	ARISTON
ALD 80 (EX)		ARISTON
ABS 66 X (IT)	STABILIMENTO COMUNANZA	ARISTON

ABS 66 X (IT)		ARISTON
AT 104 (EX)	STABILIMENTO BREMBATE	ARISTON
WT 120 (EX)	STABILIMENTO BREMBATE	INDESIT
W 106 X.1 (DE)	STABILIMENTO COMUNANZA	INDESIT
W 106 X.1 (DE)		INDESIT
AT 105 (FR)	STABILIMENTO BREMBATE	ARISTON
AB 66 (IT)	STABILIMENTO TEVEROLA	ARISTON
AAB 1300 (FR)	STABILIMENTO COMUNANZA	ARISTON
AAB 1300 (FR)		ARISTON
AX 100 (EX)	STABILIMENTO BREMBATE	ARISTON
AX 120 (EX)	STABILIMENTO BREMBATE	ARISTON
WE 8 (IT).1	STABILIMENTO TEVEROLA	INDESIT
WE 10 (IT).1	STABILIMENTO TEVEROLA	INDESIT
WES 8 X (IT).1		INDESIT
WAT10 (IT)	STABILIMENTO BREMBATE	INDESIT
LNA 856 (FR)	STABILIMENTO TEVEROLA	INDESIT
AB 95 (TK)	STABILIMENTO TEVEROLA	ARISTON
AB 105 (TK)	STABILIMENTO TEVEROLA	ARISTON
AB 103 M (TK)	STABILIMENTO TEVEROLA	ARISTON
WAP 61 (EX)	STABILIMENTO TEVEROLA	INDESIT
W 84 T (TK)	STABILIMENTO TEVEROLA	INDESIT
WE 10 XS (IT)		INDESIT
W 104 T (TK)	STABILIMENTO TEVEROLA	INDESIT
WAX 80 (EX)	STABILIMENTO BREMBATE	INDESIT
AVL 68 (IT)	STABILIMENTO COMUNANZA	ARISTON
AVL 88 (IT)	STABILIMENTO COMUNANZA	ARISTON
AVSL 68 (IT)	STABILIMENTO COMUNANZA	ARISTON
AVSL 88 (IT)	STABILIMENTO COMUNANZA	ARISTON
AVD 108 (IT)	STABILIMENTO COMUNANZA	ARISTON
AVSL 100 X (FR)	STABILIMENTO COMUNANZA	ARISTON
AVL 120 X (FR)	STABILIMENTO COMUNANZA	ARISTON
AVD 130 X (FR)	STABILIMENTO COMUNANZA	ARISTON
AVL 80 (R)	STABILIMENTO COMUNANZA	ARISTON
AVL 100 (R)	STABILIMENTO COMUNANZA	ARISTON
AV 82 (TK)	STABILIMENTO TEVEROLA	ARISTON
AVL 85 (TK)	STABILIMENTO TEVEROLA	ARISTON
AV 102 (TK)	STABILIMENTO TEVEROLA	ARISTON
AVL 105 (TK)	STABILIMENTO TEVEROLA	ARISTON
AVXL 105 (TK)	STABILIMENTO BREMBATE	ARISTON
AVD 8 (TK)	STABILIMENTO TEVEROLA	ARISTON
AVD 10 (TK)	STABILIMENTO TEVEROLA	ARISTON
AVD 10 (TK)		ARISTON
AVD 10 S (TK)	STABILIMENTO COMUNANZA	ARISTON
AT 125 (FR)	STABILIMENTO BREMBATE	ARISTON
AVL 85 X (TK)	STABILIMENTO COMUNANZA	ARISTON
AVL 105 X (TK)	STABILIMENTO COMUNANZA	ARISTON
AVD 8 X (TK)	STABILIMENTO COMUNANZA	ARISTON
AVD 10 X (TK)	STABILIMENTO COMUNANZA	ARISTON

AVXL 108 (IT)	STABILIMENTO BREMBATE	ARISTON
AVSL 80 (R)	STABILIMENTO COMUNANZA	ARISTON
AVSL 100 (R)	STABILIMENTO COMUNANZA	ARISTON
AB 66 X (IT) (BG)	STABILIMENTO BREMBATE	ARISTON
AV 102 X (TK)	STABILIMENTO COMUNANZA	ARISTON
AV 82 X (TK)	STABILIMENTO COMUNANZA	ARISTON
WT 80 (FR)	STABILIMENTO BREMBATE	INDESIT
WT 92 (FR)	STABILIMENTO BREMBATE	INDESIT
WT 112 (FR)	STABILIMENTO BREMBATE	INDESIT
WT 124 (FR)	STABILIMENTO BREMBATE	INDESIT
W 83 (FR)	STABILIMENTO TEVEROLA	INDESIT
W 83 (FR)		INDESIT
W 95 (FR)		INDESIT
W 107 (FR)	STABILIMENTO TEVEROLA	INDESIT
W 129 X (FR)	STABILIMENTO COMUNANZA	INDESIT
W 129 X (FR)		INDESIT
AVD 88 (IT)	STABILIMENTO COMUNANZA	ARISTON
AL 68 (EU)	STABILIMENTO TEVEROLA	ARISTON
AL 88 (EU)	STABILIMENTO TEVEROLA	ARISTON
AL 109 (EU)	STABILIMENTO TEVEROLA	ARISTON
W 53.12 (CSI)	STABILIMENTO BREMBATE	Whirlpool
AVSD 88 (IT)	STABILIMENTO COMUNANZA	ARISTON
AVSD 88 (IT)		ARISTON
AVL 68 (IT) (TE)	STABILIMENTO TEVEROLA	ARISTON
AVSL 66 (IT)	STABILIMENTO COMUNANZA	ARISTON
AT 109 (FR)	STABILIMENTO BREMBATE	ARISTON
AVXL 100 (FR)	STABILIMENTO BREMBATE	ARISTON
AVXL 100 (FR)		ARISTON
AVSD 108 S (IT)	STABILIMENTO COMUNANZA	ARISTON
LNA 1000 (FR)	STABILIMENTO TEVEROLA	INDESIT
LNA 1000 (FR)		INDESIT
AT 95 (FR)	STABILIMENTO BREMBATE	ARISTON
AT 95 (FR)		ARISTON
ATD 102 (FR)	STABILIMENTO BREMBATE	ARISTON
ATD 102 (FR)		ARISTON
ATD 122 (FR)	STABILIMENTO BREMBATE	ARISTON
ATD 122 (FR)		ARISTON
AT 110 (FR)	STABILIMENTO BREMBATE	ARISTON
AT 110 (FR)		ARISTON
WAX 100 (EX)	STABILIMENTO BREMBATE	INDESIT
AVD 108 S (IT)	STABILIMENTO COMUNANZA	ARISTON
AVL 130 X (FR)	STABILIMENTO COMUNANZA	ARISTON
W 120 (EU)	STABILIMENTO BREMBATE	INDESIT
WE 12 (DE)	STABILIMENTO COMUNANZA	INDESIT
AVXL 88 (IT)	STABILIMENTO BREMBATE	ARISTON
W 81 (EX)	STABILIMENTO TEVEROLA	INDESIT
W 101 (EX)	STABILIMENTO TEVEROLA	INDESIT
WP 80 (EX)	STABILIMENTO TEVEROLA	INDESIT

W 123 (NL)	STABILIMENTO BREMBATE	INDESIT
AVXL 88 (EU)	STABILIMENTO BREMBATE	ARISTON
AVXL 105 (EX)	STABILIMENTO BREMBATE	ARISTON
AVXL 125 (EX)	STABILIMENTO BREMBATE	ARISTON
AVSD 107 (EX)	STABILIMENTO COMUNANZA	ARISTON
AVD 107 (EX)	STABILIMENTO COMUNANZA	ARISTON
AVD 127 (EX)	STABILIMENTO COMUNANZA	ARISTON
AVSD 127 (EX)	STABILIMENTO COMUNANZA	ARISTON
AVL 125 (EU)	STABILIMENTO BREMBATE	ARISTON
AVL 95 (EX)	STABILIMENTO BREMBATE	ARISTON
AVL 65 (EU)	STABILIMENTO COMUNANZA	ARISTON
AVL 105 (EX)	STABILIMENTO COMUNANZA	ARISTON
AVL 105 (EX)		ARISTON
AVL 85 (EU)	STABILIMENTO COMUNANZA	ARISTON
AVL 145 (EU)	STABILIMENTO COMUNANZA	ARISTON
AVL 85 S (EU)	STABILIMENTO COMUNANZA	ARISTON
AVL 84 (EU)	STABILIMENTO BREMBATE	ARISTON
AVL 84 (EU)		ARISTON
AVL 105 (EU)	STABILIMENTO BREMBATE	ARISTON
AVD 88 S (EX)	STABILIMENTO COMUNANZA	ARISTON
AVSL 85 (EU)	STABILIMENTO COMUNANZA	ARISTON
AVSD 88 (EU)	STABILIMENTO COMUNANZA	ARISTON
AVSD 88 (EU)		ARISTON
AVD 88 (EX)	STABILIMENTO COMUNANZA	ARISTON
AVSL 105 (EU)	STABILIMENTO COMUNANZA	ARISTON
LISA 100 (FR)	STABILIMENTO TEVEROLA	INDESIT
WI 10 (FR)	STABILIMENTO TEVEROLA	INDESIT
WI 10 (FR)		INDESIT
WIL 12 (FR)	STABILIMENTO TEVEROLA	INDESIT
AVSL 125 (EU)	STABILIMENTO COMUNANZA	ARISTON
AVL 6 E (IT)	STABILIMENTO TEVEROLA	ARISTON
AVL 8 E (IT)		ARISTON
AVSL 8 E (IT)	STABILIMENTO COMUNANZA	ARISTON
AVD 88 (EU)	STABILIMENTO BREMBATE	ARISTON
AVL 62 (EX)	STABILIMENTO BREMBATE	ARISTON
AVL 62 (EX)		ARISTON
WISL 86 (IT)	STABILIMENTO COMUNANZA	INDESIT
AVL 66 P (IT)	STABILIMENTO TEVEROLA	ARISTON
AVL 86 P (IT)	STABILIMENTO TEVEROLA	ARISTON
WI 8 (FR)	STABILIMENTO TEVEROLA	INDESIT
WIL 14 (FR)	STABILIMENTO COMUNANZA	INDESIT
WISL 10 (FR)	STABILIMENTO COMUNANZA	INDESIT
WISL 66 (IT)	STABILIMENTO COMUNANZA	INDESIT
WIL 106 (IT)	STABILIMENTO TEVEROLA	INDESIT
WIL 86 (IT)	STABILIMENTO TEVEROLA	INDESIT
WIL 66 (IT)	STABILIMENTO TEVEROLA	INDESIT
AVL 105 (SK)	STABILIMENTO TEVEROLA	ARISTON
AVL 82 (EU)	STABILIMENTO BREMBATE	ARISTON

WIXL 128 (IT)	STABILIMENTO BREMBATE	INDESIT
WIE 107 (IT)	STABILIMENTO TEVEROLA	INDESIT
WIE 87 (IT)	STABILIMENTO TEVEROLA	INDESIT
WIE 87 (IT)		INDESIT
WIXL 106 (IT)	STABILIMENTO BREMBATE	INDESIT
WIXL 86 (IT)	STABILIMENTO BREMBATE	INDESIT
WIV 80 (IT)	STABILIMENTO TEVEROLA	INDESIT
WIV 60 (IT)	STABILIMENTO TEVEROLA	INDESIT
WISE 107 (IT)	STABILIMENTO COMUNANZA	INDESIT
WIL 105 (EU)	STABILIMENTO TEVEROLA	INDESIT
WIL 85 (EU)	STABILIMENTO TEVEROLA	INDESIT
WILM 64 (IT)	STABILIMENTO TEVEROLA	INDESIT
W 16 GE	STABILIMENTO COMUNANZA	INDESIT
W 14 GE	STABILIMENTO COMUNANZA	INDESIT
W 12 GE	STABILIMENTO TEVEROLA	INDESIT
AVSL 85 (PL)	STABILIMENTO COMUNANZA	ARISTON
AVSD 88 (PL)	STABILIMENTO COMUNANZA	ARISTON
AVSL 105 (PL)	STABILIMENTO COMUNANZA	ARISTON
WI 81 (EX)	STABILIMENTO TEVEROLA	INDESIT
WI 82 (EX)	STABILIMENTO TEVEROLA	INDESIT
WIL 85 (EX)	STABILIMENTO TEVEROLA	INDESIT
WI 101 (EX)	STABILIMENTO TEVEROLA	INDESIT
WIL 105 (EX)	STABILIMENTO TEVEROLA	INDESIT
AVL 100 P (R)	STABILIMENTO TEVEROLA	ARISTON
AVL 145 (DE)	STABILIMENTO COMUNANZA	ARISTON
AVL 145 (DE)		ARISTON
AVL 125 (DE)	STABILIMENTO BREMBATE	ARISTON
AVL 125 (DE)		ARISTON
WI 84 X (R)	STABILIMENTO COMUNANZA	INDESIT
WI 84 X (R)		INDESIT
WI 104 X (R)	STABILIMENTO COMUNANZA	INDESIT
WI 104 X (R)		INDESIT
WISE 107 S (EX)	STABILIMENTO COMUNANZA	INDESIT
WIL 126 (NL)	STABILIMENTO TEVEROLA	INDESIT
WIE 128 (NL)	STABILIMENTO TEVEROLA	INDESIT
WIE 128 (NL)		INDESIT
WIL 146 (NL)	STABILIMENTO COMUNANZA	INDESIT
WIL 166 (NL)	STABILIMENTO COMUNANZA	INDESIT
WIE 148 (NL)		INDESIT
WIE 168 (NL)	STABILIMENTO COMUNANZA	INDESIT
WIE 168 (NL)		INDESIT
WIL 105 (DE)	STABILIMENTO TEVEROLA	INDESIT
WIL 125 (DE)	STABILIMENTO TEVEROLA	INDESIT
WIE 127 (DE)	STABILIMENTO TEVEROLA	INDESIT
WIL 145 (DE)	STABILIMENTO COMUNANZA	INDESIT
WIL 165 (DE)	STABILIMENTO COMUNANZA	INDESIT
WIL 162 (DE)	STABILIMENTO COMUNANZA	INDESIT
WIE 127 S (DE)	STABILIMENTO COMUNANZA	INDESIT

WIE 147 (DE)	STABILIMENTO COMUNANZA	INDESIT
WIE 167 (DE)	STABILIMENTO COMUNANZA	INDESIT
WISL 125 (DE)	STABILIMENTO COMUNANZA	INDESIT
WI 70 (TK)	STABILIMENTO TEVEROLA	INDESIT
WI 80 (TK)	STABILIMENTO TEVEROLA	INDESIT
WI 100 (TK)	STABILIMENTO TEVEROLA	INDESIT
WIL 81 (TK)	STABILIMENTO TEVEROLA	INDESIT
WIL 101 (TK)	STABILIMENTO TEVEROLA	INDESIT
WIXL 101 (TK)	STABILIMENTO BREMBATE	INDESIT
WT 100 (FR)	STABILIMENTO BREMBATE	INDESIT
WI 82 (SING)	STABILIMENTO TEVEROLA	INDESIT
WI 82 (SING)		INDESIT
WT 118 (FR)	STABILIMENTO BREMBATE	INDESIT
WI 102 (PL)	STABILIMENTO TEVEROLA	INDESIT
AVL 120 (FR)	STABILIMENTO BREMBATE	ARISTON
AVL 120 (FR)		ARISTON
WI 105 (EX)	STABILIMENTO TEVEROLA	INDESIT
WI 102 (EX)	STABILIMENTO TEVEROLA	INDESIT
WI 122 (EX)	STABILIMENTO TEVEROLA	INDESIT
WIL 62 (EX)	STABILIMENTO TEVEROLA	INDESIT
WIL 62 X (EX)	STABILIMENTO COMUNANZA	INDESIT
WIL 63 (PL)	STABILIMENTO BREMBATE	INDESIT
WIL 85 X (EX)	STABILIMENTO COMUNANZA	INDESIT
WIL 85 XS (EX)	STABILIMENTO COMUNANZA	INDESIT
WIL 85 (PL)	STABILIMENTO BREMBATE	INDESIT
WIL 85 (PL)		INDESIT
WIDL 126 (FR)	STABILIMENTO COMUNANZA	INDESIT
WIL 105 (PL)	STABILIMENTO BREMBATE	INDESIT
WIL 105 X (EX)	STABILIMENTO COMUNANZA	INDESIT
WIL 125 (EX)	STABILIMENTO TEVEROLA	INDESIT
WIL 125 X (EX)	STABILIMENTO COMUNANZA	INDESIT
WIL 145 X (EX)	STABILIMENTO COMUNANZA	INDESIT
WIL 145 X (EX)		INDESIT
WIL 165 X (EX)	STABILIMENTO COMUNANZA	INDESIT
WIL 165 X (EX)		INDESIT
WIE 87 (EX)	STABILIMENTO TEVEROLA	INDESIT
WIE 87 (PL)	STABILIMENTO BREMBATE	INDESIT
WIE 107 (PL)	STABILIMENTO BREMBATE	INDESIT
WIE 107 (EX)	STABILIMENTO TEVEROLA	INDESIT
WIE 107 XS (EX)	STABILIMENTO COMUNANZA	INDESIT
WIE 127 XS (EX)	STABILIMENTO COMUNANZA	INDESIT
WIE 127 (EX)	STABILIMENTO TEVEROLA	INDESIT
WIE 127 X (EX)	STABILIMENTO COMUNANZA	INDESIT
WIE 127 X (EX)		INDESIT
WIE 147 X (EX)	STABILIMENTO COMUNANZA	INDESIT
WISL 62 X (EX)	STABILIMENTO COMUNANZA	INDESIT
WISL 65 (PL)	STABILIMENTO COMUNANZA	INDESIT
WISL 105 (PL)	STABILIMENTO COMUNANZA	INDESIT

WISL 125 X (EX)	STABILIMENTO COMUNANZA	INDESIT
WISL 85 (PL)	STABILIMENTO COMUNANZA	INDESIT
WISL 85 X (EX)	STABILIMENTO COMUNANZA	INDESIT
WISL 105 X (EX)	STABILIMENTO COMUNANZA	INDESIT
WISE 87 (PL)	STABILIMENTO COMUNANZA	INDESIT
WISE 107 (PL)	STABILIMENTO COMUNANZA	INDESIT
WIDL 126 (EX)	STABILIMENTO COMUNANZA	INDESIT
WISE 107 X (EX)	STABILIMENTO COMUNANZA	INDESIT
WIDL 146 (EX)	STABILIMENTO COMUNANZA	INDESIT
WISE 127 X (EX)	STABILIMENTO COMUNANZA	INDESIT
WIXE 127 (EX)	STABILIMENTO BREMBATE	INDESIT
AML 85 (EX)	STABILIMENTO COMUNANZA	ARISTON
AML 85 (EX)		ARISTON
WIXL 85 (EX)	STABILIMENTO BREMBATE	INDESIT
WIXL 85 (PL)	STABILIMENTO BREMBATE	INDESIT
WIXL 85 (PL)		INDESIT
AML 105 (EX)	STABILIMENTO COMUNANZA	ARISTON
WIXL 105 (EX)	STABILIMENTO BREMBATE	INDESIT
WIXL 125 (EX)	STABILIMENTO BREMBATE	INDESIT
AML 125 (EX)	STABILIMENTO COMUNANZA	ARISTON
WISL 85(CSI)		INDESIT
WISL 105(CSI)		INDESIT
AT 8 E (IT)	STABILIMENTO BREMBATE	ARISTON
AVL 64 (EU)	STABILIMENTO TEVEROLA	ARISTON
AVL 65 (PT)	STABILIMENTO TEVEROLA	ARISTON
WD 1400 (GE)	STABILIMENTO COMUNANZA	INDESIT
AVL 68 (IT) (BG)	STABILIMENTO BREMBATE	ARISTON
AVL 68 (IT) (BG)		ARISTON
AVL 88 (IT) (BG)	STABILIMENTO BREMBATE	ARISTON
WIL 105 S (EX)	STABILIMENTO COMUNANZA	INDESIT
WI 142 (EU)	STABILIMENTO COMUNANZA	INDESIT
WIL 95 (EX) (CO)	STABILIMENTO COMUNANZA	INDESIT
WI 8 (EU)	STABILIMENTO TEVEROLA	INDESIT
WI 102 (EU)	STABILIMENTO TEVEROLA	INDESIT
WI 122 (EU)	STABILIMENTO TEVEROLA	INDESIT
WIXL 104 (EU)	STABILIMENTO BREMBATE	INDESIT
WIDL 86(EX)	STABILIMENTO COMUNANZA	INDESIT
WIDL 106 (EX)	STABILIMENTO COMUNANZA	INDESIT
WI 600 (IT)	STABILIMENTO TEVEROLA	INDESIT
AV 102 (CSI)	STABILIMENTO TEVEROLA	ARISTON
WIDL 146 (DE)	STABILIMENTO COMUNANZA	INDESIT
WIDL 126 (DE)	STABILIMENTO COMUNANZA	INDESIT
WIDL 126 S (DE)	STABILIMENTO COMUNANZA	INDESIT
WIDE 126 (DE)	STABILIMENTO COMUNANZA	INDESIT
WIDL 126 S (EX)	STABILIMENTO COMUNANZA	INDESIT
WT 119 (FR)	STABILIMENTO BREMBATE	INDESIT
WIL 123 (DE)	STABILIMENTO TEVEROLA	INDESIT
WIL 143 (DE)	STABILIMENTO TEVEROLA	INDESIT

WIL 163 (DE)	STABILIMENTO COMUNANZA	INDESIT
LBE 68 (ALL)	STABILIMENTO COMUNANZA	ARISTON
LBE 88 (ALL)	STABILIMENTO COMUNANZA	ARISTON
WIL 146 (NL) (TE)	STABILIMENTO TEVEROLA	INDESIT
WIE 148 (NL) (TE)	STABILIMENTO TEVEROLA	INDESIT
WIE 148 (NL) (TE)		INDESIT
LISA 111 (FR)	STABILIMENTO TEVEROLA	INDESIT
WI 11 (FR)	STABILIMENTO TEVEROLA	INDESIT
WIL 13 (FR)	STABILIMENTO TEVEROLA	INDESIT
WIL 145 (DE) (TE)	STABILIMENTO TEVEROLA	INDESIT
WIE 147 (DE) (TE)	STABILIMENTO TEVEROLA	INDESIT
AVL 145 (DE) (TE)	STABILIMENTO TEVEROLA	ARISTON
AVL 145 (DE) (TE)		ARISTON
WI 140 B (DE) (CO)	STABILIMENTO COMUNANZA	INDESIT
AVL 66 P (IT) (BG)	STABILIMENTO BREMBATE	ARISTON
AVTL 62 (EU)	STABILIMENTO BREMBATE	ARISTON
AVTL 82 (EU)	STABILIMENTO BREMBATE	ARISTON
AVTL 83 (EU)	STABILIMENTO BREMBATE	ARISTON
AVTL 104 (EU)	STABILIMENTO BREMBATE	ARISTON
AVTF 104 (EU)	STABILIMENTO BREMBATE	ARISTON
WIXL 84 (EX)	STABILIMENTO BREMBATE	INDESIT
WIL 85 (EX) (BG)	STABILIMENTO BREMBATE	INDESIT
WIL 105 (EX) (BG)	STABILIMENTO BREMBATE	INDESIT
AVL 145 (EU) (TE)	STABILIMENTO TEVEROLA	ARISTON
WIL 103 (IT)	STABILIMENTO TEVEROLA	INDESIT
WIL 145 (EU)	STABILIMENTO TEVEROLA	INDESIT
WIE 147 (EU)	STABILIMENTO TEVEROLA	INDESIT
WIL 126 (IT)	STABILIMENTO BREMBATE	INDESIT
WITL 106 (IT)	STABILIMENTO BREMBATE	INDESIT
WIA 122 (EX)	STABILIMENTO TEVEROLA	INDESIT
AVTL 62 (IT) N	STABILIMENTO BREMBATE	ARISTON
WITP 83 (IT)	STABILIMENTO BREMBATE	INDESIT
WITP 103 (IT)	STABILIMENTO BREMBATE	INDESIT
WITL 66 (IT)	STABILIMENTO BREMBATE	INDESIT
WITL 86 (IT)	STABILIMENTO BREMBATE	INDESIT
WITL 126 (IT)	STABILIMENTO BREMBATE	INDESIT
WITL 85 (FR)	STABILIMENTO BREMBATE	INDESIT
WITL 88 (FR)	STABILIMENTO BREMBATE	INDESIT
WITL 88 (FR)		INDESIT
WITL 90 (FR)	STABILIMENTO BREMBATE	INDESIT
WITL 100 (FR)	STABILIMENTO BREMBATE	INDESIT
WITL 120 (FR)	STABILIMENTO BREMBATE	INDESIT
WIL 12 (NL)	STABILIMENTO TEVEROLA	INDESIT
WIL 12 (NL)		INDESIT
WIL 14 (NL)	STABILIMENTO TEVEROLA	INDESIT
WIL 14 (NL)		INDESIT
AV 6 (EU)	STABILIMENTO TEVEROLA	ARISTON
AVSF 88 (PL)	STABILIMENTO COMUNANZA	ARISTON

AVF 10 (TK)	STABILIMENTO TEVEROLA	ARISTON
AVF 10 S (TK)	STABILIMENTO COMUNANZA	ARISTON
WIL 166 SP (IT)	STABILIMENTO COMUNANZA	INDESIT
WIL 146 SP (IT)	STABILIMENTO TEVEROLA	INDESIT
AVF 8 (TK)	STABILIMENTO TEVEROLA	ARISTON
AVSF 88 (EU)	STABILIMENTO COMUNANZA	ARISTON
AVSF 88 (EU)		ARISTON
AVF 88 (EU)	STABILIMENTO BREMBATE	ARISTON
WIL 14 (FR) (TE)	STABILIMENTO TEVEROLA	INDESIT
WIL 14 (FR) (TE)		INDESIT
WITL 86 (EU)	STABILIMENTO BREMBATE	INDESIT
WITP 82 (EU)	STABILIMENTO BREMBATE	INDESIT
WITP 102 (EU)	STABILIMENTO BREMBATE	INDESIT
WITL 105 (EU)	STABILIMENTO BREMBATE	INDESIT
WITL 106 (EU)	STABILIMENTO BREMBATE	INDESIT
WITE 87 (EU)	STABILIMENTO BREMBATE	INDESIT
WITE 107 (EU)	STABILIMENTO BREMBATE	INDESIT
WITL 62 (EU)	STABILIMENTO BREMBATE	INDESIT
WITL 85 (EU)	STABILIMENTO BREMBATE	INDESIT
WITL 125 (EU)	STABILIMENTO BREMBATE	INDESIT
WITL 125 (EU)		INDESIT
WITE 127 (EU)	STABILIMENTO BREMBATE	INDESIT
AVXF 120 (FR)	STABILIMENTO BREMBATE	ARISTON
WIAV 60 (IT)	STABILIMENTO TEVEROLA	INDESIT
WIA 600 (EU)	STABILIMENTO TEVEROLA	INDESIT
WIAV 80 (IT)	STABILIMENTO TEVEROLA	INDESIT
WIA 60 (TK)	STABILIMENTO TEVEROLA	INDESIT
WIA 82 (EX)	STABILIMENTO TEVEROLA	INDESIT
WIA 80 (TK)	STABILIMENTO TEVEROLA	INDESIT
WIA 8 (EU)	STABILIMENTO TEVEROLA	INDESIT
WIA 100 (TK)	STABILIMENTO TEVEROLA	INDESIT
WIA 102 (PL)	STABILIMENTO TEVEROLA	INDESIT
WIA 102 (PL)		INDESIT
WIA 102 (EX)	STABILIMENTO TEVEROLA	INDESIT
WIA 101 (EU)	STABILIMENTO TEVEROLA	INDESIT
WIA 102 (CH)	STABILIMENTO TEVEROLA	INDESIT
WIA 121 (EU)	STABILIMENTO TEVEROLA	INDESIT
WIL 8 (FR)	STABILIMENTO TEVEROLA	INDESIT
WIL 11 (FR)	STABILIMENTO TEVEROLA	INDESIT
LISA 10 (FR)	STABILIMENTO TEVEROLA	INDESIT
WIE 12 (FR)	STABILIMENTO TEVEROLA	INDESIT
WIXL 12 (FR)	STABILIMENTO BREMBATE	INDESIT
WIL 1000 OT (EU)		INDESIT
WIL 1200 OT (EU)	STABILIMENTO TEVEROLA	INDESIT
WIL 1200 OT (EU)		INDESIT
AVL 14 (FR)	STABILIMENTO TEVEROLA	ARISTON
WIA 81 (EX)	STABILIMENTO TEVEROLA	INDESIT
WIA 101 (EX)	STABILIMENTO TEVEROLA	INDESIT

WIL 82 X (R)	STABILIMENTO COMUNANZA	INDESIT
WIL 102 X (R)	STABILIMENTO COMUNANZA	INDESIT
WIU 61 (CSI)		INDESIT
WIU 81 (CSI)		INDESIT
WIU 102 (CSI)		INDESIT
WIXXL 86 (EU)	KINMEL FACTORY TO SERVICE	INDESIT
WIU 82 (CSI)		INDESIT
WIL 10 (FR)	STABILIMENTO TEVEROLA	INDESIT
WIE 10 (FR)	STABILIMENTO TEVEROLA	INDESIT
WISL 92 (CSI)	Lipetsk Washing	INDESIT
WISL 92 (CSI)		INDESIT
WIE 107 (EX) (BG)	STABILIMENTO BREMBATE	INDESIT
WIE 107 (EX) (BG)		INDESIT
WISA 82 (CSI)		INDESIT
WISA 62 (CSI)		INDESIT
WISE 87 X (EU)	STABILIMENTO COMUNANZA	INDESIT
WISL 62 (CSI)	Lipetsk Washing	INDESIT
WISL 62 (CSI)		INDESIT
WISL 82 (CSI)	Lipetsk Washing	INDESIT
WISL 82 (CSI)		INDESIT
WISL 83 (CSI)	Lipetsk Washing	INDESIT
WISL 83 (CSI)		INDESIT
WISL 103 (CSI)	Lipetsk Washing	INDESIT
WISL 103 (CSI)		INDESIT
WIL 85 (EX) (TE)	STABILIMENTO TEVEROLA	INDESIT
AVL 62 (EX) (TE)	STABILIMENTO TEVEROLA	ARISTON
AVL 82 (EU) (TE)	STABILIMENTO TEVEROLA	ARISTON
AVL 88 (IT) (TE)	STABILIMENTO TEVEROLA	ARISTON
WITL 126 (DE)	STABILIMENTO BREMBATE	INDESIT
AVL 14 (FR) (CO)	STABILIMENTO COMUNANZA	ARISTON
AVL 145 (EU) (CO)	STABILIMENTO COMUNANZA	ARISTON
WIE 147 (DE) (CO)	STABILIMENTO COMUNANZA	INDESIT
WIE 147 (EU) (CO)	STABILIMENTO COMUNANZA	INDESIT
WIL 13 (FR) (CO)	STABILIMENTO COMUNANZA	INDESIT
WIL 14 (FR) (CO)	STABILIMENTO COMUNANZA	INDESIT
WIL 14 (NL) (CO)	STABILIMENTO COMUNANZA	INDESIT
WIL 143 (DE) (CO)	STABILIMENTO COMUNANZA	INDESIT
WIL 145 (EU) (CO)	STABILIMENTO COMUNANZA	INDESIT
WIL 146 SP (IT) (CO)	STABILIMENTO COMUNANZA	INDESIT
AVF 88 (EU) (TE)	STABILIMENTO TEVEROLA	ARISTON
AVL 66 P (IT) (TE)	STABILIMENTO TEVEROLA	ARISTON
AVL 84 (EU) (TE)	STABILIMENTO TEVEROLA	ARISTON
WIL 105 (EX) (TE)	STABILIMENTO TEVEROLA	INDESIT
WIL 85 (PL) (TE)	STABILIMENTO TEVEROLA	INDESIT
WIUL 83 (CSI)	Lipetsk Washing	INDESIT
WIUL 83 (CSI)		INDESIT
WIUL 103 (CSI)	Lipetsk Washing	INDESIT
WIUL 103 (CSI)		INDESIT

AV 8 (IT)	STABILIMENTO TEVEROLA	ARISTON
AV 8 (IT)		ARISTON
AV 10 (IT)	STABILIMENTO TEVEROLA	ARISTON
AV 10 (IT)		ARISTON
WIL 145 (DE) (CO)	STABILIMENTO COMUNANZA	INDESIT
WIL 125 (NL)	STABILIMENTO TEVEROLA	INDESIT
WIL 145 (NL)	STABILIMENTO COMUNANZA	INDESIT
WIL 124 (NL)	STABILIMENTO TEVEROLA	INDESIT
WIL 144 (NL)	STABILIMENTO COMUNANZA	INDESIT
WIL 164 (NL)	STABILIMENTO COMUNANZA	INDESIT
WITL 80 (FR)	STABILIMENTO BREMBATE	INDESIT
AVL 95 (EX) (TE)	STABILIMENTO TEVEROLA	ARISTON
AVL 125 (EU) (TEV)	STABILIMENTO TEVEROLA	ARISTON
WIA 110 (EU)	STABILIMENTO TEVEROLA	INDESIT
WIL 105 (PL) (TE)	STABILIMENTO TEVEROLA	INDESIT
WIL 126 (IT) (TE)	STABILIMENTO TEVEROLA	INDESIT
WIL 126 (IT) (TE)		INDESIT
AVL 105 (EU) (TE)	STABILIMENTO TEVEROLA	ARISTON
WIE 107 (PL) (TE)	STABILIMENTO TEVEROLA	INDESIT
WIE 87 (PL) (TE)	STABILIMENTO TEVEROLA	INDESIT
WIDL 146 (FR)	STABILIMENTO COMUNANZA	INDESIT
WIA 80 (CSI)		INDESIT
WIA 100 (CSI)		INDESIT
WIA 102 (CSI)		INDESIT
WIL 63 (PL) (TE)	STABILIMENTO TEVEROLA	INDESIT
AVL 120 (FR) (TEVE)	STABILIMENTO TEVEROLA	ARISTON
WIL 106 SP (EU)	STABILIMENTO TEVEROLA	INDESIT
WIXL 86 (EU)	STABILIMENTO BREMBATE	INDESIT
WIXL 106 (EU)	STABILIMENTO BREMBATE	INDESIT
AVTL 120 (FR)	STABILIMENTO BREMBATE	ARISTON
WILB 12 (EU)	STABILIMENTO TEVEROLA	INDESIT
AVL 16 (FR)	STABILIMENTO COMUNANZA	ARISTON
WIA 64 (IT)	STABILIMENTO TEVEROLA	INDESIT
WIE 167 E (EU)	STABILIMENTO COMUNANZA	INDESIT
AVTL 110 (FR)	STABILIMENTO BREMBATE	ARISTON
WIA 9 (FR)	STABILIMENTO TEVEROLA	INDESIT
WISL 106 (IT)	STABILIMENTO COMUNANZA	INDESIT
WIXL 1200 OT (EU)	STABILIMENTO BREMBATE	INDESIT
LISA 11 (FR)	STABILIMENTO TEVEROLA	INDESIT
WISL 1000 OT (EU)	STABILIMENTO COMUNANZA	INDESIT
WIL 1400 OT (EU)	STABILIMENTO COMUNANZA	INDESIT
WIXL 125 (ME)	STABILIMENTO BREMBATE	INDESIT
WIXL 125 (ME)		INDESIT
WIL 140 B (DE)	STABILIMENTO COMUNANZA	INDESIT
WISL 85 (SL) (CSI)	Lipetsk Washing	INDESIT
WISL 85 (SL) (CSI)		INDESIT
WISL 105 (SL) (CSI)	Lipetsk Washing	INDESIT
WISL 105 (SL) (CSI)		INDESIT

WISL 102 (CSI)	Lipetsk Washing	INDESIT
WISL 102 (CSI)		INDESIT
WIDE 146 (DE)	STABILIMENTO COMUNANZA	INDESIT
WIXL 1200 OT (FR)	STABILIMENTO BREMBATE	INDESIT
WIL 1400 OT (FR)	STABILIMENTO COMUNANZA	INDESIT
AQXL 105/1 (IT)	STABILIMENTO COMUNANZA	ARISTON
AQXL 85 (EU)	STABILIMENTO COMUNANZA	ARISTON
AQXL 105 (EX)	STABILIMENTO COMUNANZA	ARISTON
AQXF 125 (EU)	STABILIMENTO COMUNANZA	ARISTON
AQXL 105 (CSI)	STABILIMENTO COMUNANZA	ARISTON
AQSL 85 (CSI)	STABILIMENTO COMUNANZA	ARISTON
AQSF 105 (CSI)	STABILIMENTO COMUNANZA	ARISTON
WISE 8 (CSI)	Lipetsk Washing	INDESIT
WISE 8 (CSI)		INDESIT
WISE 10 (CSI)	Lipetsk Washing	INDESIT
WISE 10 (CSI)		INDESIT
WISE 12 (CSI)	Lipetsk Washing	INDESIT
WISE 12 (CSI)		INDESIT
WIUE 10 (CSI)	Lipetsk Washing	INDESIT
WIUE 10 (CSI)		INDESIT
WITE 110 (FR)	STABILIMENTO BREMBATE	INDESIT
LISA 12 (FR)	STABILIMENTO TEVEROLA	INDESIT
WIXE 12 (FR)	STABILIMENTO BREMBATE	INDESIT
AVXL 14 (FR)	STABILIMENTO COMUNANZA	ARISTON
WILX 1200 OT (DE)	STABILIMENTO BREMBATE	INDESIT
WITE 100 (FR)	STABILIMENTO BREMBATE	INDESIT
WITE 120 (FR)	STABILIMENTO BREMBATE	INDESIT
AQXD 145 (EU)	STABILIMENTO COMUNANZA	ARISTON
WISE 107 (EX) (V)	STABILIMENTO COMUNANZA	INDESIT
WISL 86 (IT) (V)	STABILIMENTO COMUNANZA	INDESIT
WISL 66 (IT) (V)	STABILIMENTO COMUNANZA	INDESIT
WISL 105 (PL) (V)	STABILIMENTO COMUNANZA	INDESIT
WISL 85 (PL) (V)	STABILIMENTO COMUNANZA	INDESIT
WISE 107 (PL) (V)	STABILIMENTO COMUNANZA	INDESIT
WISE 87 (PL) (V)	STABILIMENTO COMUNANZA	INDESIT
WISL 62 (EX) (V)	STABILIMENTO COMUNANZA	INDESIT
WISE 127 (EX) (V)	STABILIMENTO COMUNANZA	INDESIT
WISL 125 (DE) (V)	STABILIMENTO COMUNANZA	INDESIT
WISL 10 (FR) (V)	STABILIMENTO COMUNANZA	INDESIT
WISL 65 (PL) (V)	STABILIMENTO COMUNANZA	INDESIT
WISL 1000 OT (EU)(V)	STABILIMENTO COMUNANZA	INDESIT
AVSL 66 (IT) (V)	STABILIMENTO COMUNANZA	ARISTON
AVSL 88 (IT) (V)	STABILIMENTO COMUNANZA	ARISTON
AVSL 68 (IT) (V)	STABILIMENTO COMUNANZA	ARISTON
AVSL 105 (EU) (V)	STABILIMENTO COMUNANZA	ARISTON
AVL 800 (CIS)	STABILIMENTO TEVEROLA	ARISTON
AVL 1000 (CIS)	STABILIMENTO TEVEROLA	ARISTON
WIL 82 (R)	STABILIMENTO TEVEROLA	INDESIT

WIL 102 (R)	STABILIMENTO TEVEROLA	INDESIT
WIXL 106 (IT) (V)		INDESIT
WIXE 12 (FR) (V)		INDESIT
AQSL 105 (IT)	STABILIMENTO COMUNANZA	ARISTON
AVTL 125 (SK)	STABILIMENTO BREMBATE	ARISTON
AQXL 125 (EU)	STABILIMENTO COMUNANZA	ARISTON
AQXL 145 (EU)	STABILIMENTO COMUNANZA	ARISTON
WIU 80 (CSI)		INDESIT
WIU 100 (CSI)		INDESIT
WISA 61 (CSI)		INDESIT
WISA 81 (CSI)		INDESIT
WISA 101 (CSI)		INDESIT
WISL 106 (IT) (V)	STABILIMENTO COMUNANZA	INDESIT
WISL 105 (EX) (V)	STABILIMENTO COMUNANZA	INDESIT
WISL 85 (EX) (V)	STABILIMENTO COMUNANZA	INDESIT
WISE 107 S (EX) (V)	STABILIMENTO COMUNANZA	INDESIT
SIXL 125 S (EU)		INDESIT
AVXL 108 (IT) (V)	STABILIMENTO COMUNANZA	ARISTON
WIXE 13 (FR)	STABILIMENTO COMUNANZA	INDESIT
WIL 145 (DE) (TEV)	STABILIMENTO TEVEROLA	INDESIT
WIL 14 (FR) (TEV)	STABILIMENTO TEVEROLA	INDESIT
WIL 145 (NL) (TEV)	STABILIMENTO TEVEROLA	INDESIT
WIE 147 (EU) (TEV)	STABILIMENTO TEVEROLA	INDESIT
WIL 145 (EU) (TEV)	STABILIMENTO TEVEROLA	INDESIT
WIL 146 SP (IT) (TEV)	STABILIMENTO TEVEROLA	INDESIT
WIL 143 (DE) (TEV)	STABILIMENTO TEVEROLA	INDESIT
WIL 13 (FR) (TEV)	STABILIMENTO TEVEROLA	INDESIT
WIAL 143 (EU)	STABILIMENTO TEVEROLA	INDESIT
WIE 147 (DE) (TEV)	STABILIMENTO TEVEROLA	INDESIT
WIL 140 B (DE) (TEV)	STABILIMENTO TEVEROLA	INDESIT
WIL 144 (NL) (TEV)	STABILIMENTO TEVEROLA	INDESIT
AVSL 105 (PL) (V)	STABILIMENTO COMUNANZA	ARISTON
AVSL 85 (EU) (V)	STABILIMENTO COMUNANZA	ARISTON
AVSL 85 (PL) (V)	STABILIMENTO COMUNANZA	ARISTON
AVSD 1070 (EX) (V)	STABILIMENTO COMUNANZA	ARISTON
WITL 130 (FR)	STABILIMENTO BREMBATE	INDESIT
WITL 145 (EU)	STABILIMENTO BREMBATE	INDESIT
AVTL 135 (FR)	STABILIMENTO BREMBATE	ARISTON
AVSF 88 (PL) (V)	STABILIMENTO COMUNANZA	ARISTON
AVSD 1270 (EX) (V)	STABILIMENTO COMUNANZA	ARISTON
AVSL 1000 (CSI) (V)	STABILIMENTO COMUNANZA	ARISTON
AVSL 800 (CSI) (V)	STABILIMENTO COMUNANZA	ARISTON
AVXL 140 (EU)	STABILIMENTO COMUNANZA	ARISTON
WIXL 165 (EX)	STABILIMENTO COMUNANZA	INDESIT
WISE 87 (EU) (V)	STABILIMENTO COMUNANZA	INDESIT
WIA 500 (EU)	STABILIMENTO TEVEROLA	INDESIT
WIA 602 (EU)	STABILIMENTO TEVEROLA	INDESIT
WIA 61 (IT)	STABILIMENTO TEVEROLA	INDESIT

SIXL 146 S (EU)	STABILIMENTO COMUNANZA	INDESIT
SIXL 146 (EU)	STABILIMENTO COMUNANZA	INDESIT
SIXL 126 (EU)	STABILIMENTO COMUNANZA	INDESIT
SIXL 106 S (EU)	STABILIMENTO COMUNANZA	INDESIT
SIXL 106 (EU)	STABILIMENTO COMUNANZA	INDESIT
SISL 126 S (EU)	STABILIMENTO COMUNANZA	INDESIT
SISL 126 (EU)	STABILIMENTO COMUNANZA	INDESIT
SISL 106 S (EU)	STABILIMENTO COMUNANZA	INDESIT
SISL 106 (EU)	STABILIMENTO COMUNANZA	INDESIT
WIXE 127 S (EX)	STABILIMENTO COMUNANZA	INDESIT
WIXL 16 (NL)	STABILIMENTO COMUNANZA	INDESIT
WIN 81 (EX)	STABILIMENTO TEVEROLA	INDESIT
WIN 101 (EX)	STABILIMENTO TEVEROLA	INDESIT
WIN 110 (EU)	STABILIMENTO TEVEROLA	INDESIT
WINV 60 (IT)	STABILIMENTO TEVEROLA	INDESIT
WIN 600 (EU)	STABILIMENTO TEVEROLA	INDESIT
WINV 80 (IT)	STABILIMENTO TEVEROLA	INDESIT
WINV 80 (IT)		INDESIT
WIN 8 (EU)	STABILIMENTO TEVEROLA	INDESIT
WIN 500 (EU)	STABILIMENTO TEVEROLA	INDESIT
WIN 602 (EU)	STABILIMENTO TEVEROLA	INDESIT
WIN 122 (EX)	STABILIMENTO TEVEROLA	INDESIT
WIN 60 (TK)	STABILIMENTO TEVEROLA	INDESIT
WIN 82 (EX)	STABILIMENTO TEVEROLA	INDESIT
WIN 80 (TK)	STABILIMENTO TEVEROLA	INDESIT
WIN 100 (TK)	STABILIMENTO TEVEROLA	INDESIT
WIN 102 (EX)	STABILIMENTO TEVEROLA	INDESIT
WIN 101 (EU)	STABILIMENTO TEVEROLA	INDESIT
WIN 121 (EU)	STABILIMENTO TEVEROLA	INDESIT
WIXL 135 (EU)	STABILIMENTO TEVEROLA	INDESIT
WIXL 125 S (EU)	STABILIMENTO COMUNANZA	INDESIT
WIXL 115 (EU)	STABILIMENTO TEVEROLA	INDESIT
WIXXL 127 (EU)	KINMEL FACTORY TO SERVICE	INDESIT
WIXL 85 (EU)	STABILIMENTO TEVEROLA	INDESIT
WIXL 105 (EU)	STABILIMENTO TEVEROLA	INDESIT
ARMXXL 125 (EU)		ARISTON
LISA XL 11 (FR)	STABILIMENTO BREMBATE	INDESIT
SIXL 126 S (EU)	STABILIMENTO COMUNANZA	INDESIT
ARMXXF 145 (EU)		ARISTON
SIXL 125 (FR)	STABILIMENTO COMUNANZA	INDESIT
SIXL 145 S (FR)	STABILIMENTO COMUNANZA	INDESIT
WIL 12 (FR) /1	STABILIMENTO TEVEROLA	INDESIT
WIXL 145 (EU) (TEV)	STABILIMENTO TEVEROLA	INDESIT
WIL 106 (FR)	STABILIMENTO TEVEROLA	INDESIT
LISA XL 11 (FR) (TE)	STABILIMENTO TEVEROLA	INDESIT
AQXL 105 (CSI)/HA	STABILIMENTO COMUNANZA	Hotpoint-Ariston
AQXL 105 (IT)/HA	STABILIMENTO COMUNANZA	Hotpoint-Ariston
WIA 60 (CSI)		INDESIT

WIA 62 (CSI)		INDESIT
WIXL 12 (FR) (TE)	STABILIMENTO TEVEROLA	INDESIT
LISA XL 12 (FR) (TE)	STABILIMENTO TEVEROLA	INDESIT
WIXL 125 (EX) (TE)	STABILIMENTO TEVEROLA	INDESIT
WIXE 147 (EU) (TE)	STABILIMENTO TEVEROLA	INDESIT
WIXL 105 (DE)	STABILIMENTO TEVEROLA	INDESIT
WIXL 125 (DE)	STABILIMENTO TEVEROLA	INDESIT
WIXL 145 (DE)	STABILIMENTO TEVEROLA	INDESIT
AQSL 85 (IT)/HA	STABILIMENTO COMUNANZA	Hotpoint-Ariston
ARXL 108(IT)	STABILIMENTO TEVEROLA	Hotpoint-Ariston
AQSL 85 (CSI)/HA	STABILIMENTO COMUNANZA	Hotpoint-Ariston
AQSF 105 (CSI)/HA	STABILIMENTO COMUNANZA	Hotpoint-Ariston
AVTL 62 (IT) N/HA	STABILIMENTO BREMBATE	Hotpoint-Ariston
AQXL 85 (EU)/HA	STABILIMENTO COMUNANZA	Hotpoint-Ariston
ARXXL 105 (IT)	KINMEL FACTORY TO SERVICE	Hotpoint-Ariston
AVTL 104 (EU)/HA	STABILIMENTO BREMBATE	Hotpoint-Ariston
AVTL 82 (EU)/HA	STABILIMENTO BREMBATE	Hotpoint-Ariston
AVTL 83 (EU)/HA	STABILIMENTO BREMBATE	Hotpoint-Ariston
AVTF 104 (EU)/HA	STABILIMENTO BREMBATE	Hotpoint-Ariston
WIXL 12 (NL)	STABILIMENTO TEVEROLA	INDESIT
WIXL 14 (NL)	STABILIMENTO TEVEROLA	INDESIT
AVTL 62/HA (EU)	STABILIMENTO BREMBATE	Hotpoint-Ariston
AQXL 105 (EX)/HA	STABILIMENTO COMUNANZA	Hotpoint-Ariston
IWDE 12 (EU)	STABILIMENTO COMUNANZA	INDESIT
WIXL 126 (IT) (TEV)	STABILIMENTO TEVEROLA	INDESIT
WIXL 86 (IT) (TEV)	STABILIMENTO TEVEROLA	INDESIT
LBE 68 (ALL)/HA	STABILIMENTO COMUNANZA	Hotpoint-Ariston
LBE 88 (ALL)/HA	STABILIMENTO COMUNANZA	Hotpoint-Ariston
AQXL 125 (EU)/HA	STABILIMENTO COMUNANZA	Hotpoint-Ariston
AQXL 145 (EU)/HA	STABILIMENTO COMUNANZA	Hotpoint-Ariston
ARXXF 125 (FR)/AR	STABILIMENTO COMUNANZA	ARISTON
ARXXL 125 (EU)/AR	STABILIMENTO COMUNANZA	ARISTON
ARXL 105 (CIS)	STABILIMENTO TEVEROLA	Hotpoint-Ariston
ARX 68 (IT)	STABILIMENTO TEVEROLA	Hotpoint-Ariston
AR 63 (IT)	STABILIMENTO TEVEROLA	Hotpoint-Ariston
ARXF 125 (CSI)	STABILIMENTO TEVEROLA	Hotpoint-Ariston
WINV 70 (IT)	STABILIMENTO TEVEROLA	INDESIT
WIA 82 (CSI)		INDESIT
WIL 83 (CSI) (LIP)	Lipetsk Washing	INDESIT
WIL 83 (CSI) (LIP)		INDESIT
WIL 103 (CSI) (LIP)	Lipetsk Washing	INDESIT
WIL 103 (CSI) (LIP)		INDESIT
ARSL 88 (IT)	STABILIMENTO COMUNANZA	Hotpoint-Ariston
ARSL 108 (IT)	STABILIMENTO COMUNANZA	Hotpoint-Ariston
AR 83 (IT)	STABILIMENTO TEVEROLA	Hotpoint-Ariston
AR 103(IT)	STABILIMENTO TEVEROLA	Hotpoint-Ariston
ARXL 88 (IT)	STABILIMENTO TEVEROLA	Hotpoint-Ariston
WIUN 61 (CSI)	Lipetsk Washing	INDESIT

WIUN 81 (CSI)	Lipetsk Washing	INDESIT
WIUN 102 (CSI)	Lipetsk Washing	INDESIT
WIUN 82 (CSI)	Lipetsk Washing	INDESIT
WIUN 80 (CSI)	Lipetsk Washing	INDESIT
WIUN 100 (CSI)	Lipetsk Washing	INDESIT
WIUN 100 (CSI)		INDESIT
WISN 82 (CSI)	Lipetsk Washing	INDESIT
WISN 82 (CSI)		INDESIT
WISN 62 (CSI)		INDESIT
WISN 61 (CSI)	Lipetsk Washing	INDESIT
WISN 81 (CSI)	Lipetsk Washing	INDESIT
WISN 101 (CSI)	Lipetsk Washing	INDESIT
WIN 80 (CSI)	Lipetsk Washing	INDESIT
WIN 100 (CSI)	Lipetsk Washing	INDESIT
WIN 102 (CSI)	Lipetsk Washing	INDESIT
WIN 60 (CSI)		INDESIT
WIN 62 (CSI)	Lipetsk Washing	INDESIT
WIN 62 (CSI)		INDESIT
WITL 90 (EU)	STABILIMENTO BREMBATE	INDESIT
WITL 100 (EU)	STABILIMENTO BREMBATE	INDESIT
ARS 68 (IT)	STABILIMENTO COMUNANZA	Hotpoint-Ariston
WIXE 107 (EX)	STABILIMENTO TEVEROLA	INDESIT
WIXL 104 (EU) (TEV)		INDESIT
WIXL 106 (EU) (TEV)	STABILIMENTO TEVEROLA	INDESIT
ARXL 85 (EU)	STABILIMENTO TEVEROLA	Hotpoint-Ariston
ARXL 105 (EU)	STABILIMENTO TEVEROLA	Hotpoint-Ariston
ARXXL 105 (EU)	STABILIMENTO BREMBATE	Hotpoint-Ariston
ARXXL 88 (EU)	STABILIMENTO BREMBATE	Hotpoint-Ariston
WIXL 106 (FR) (TEV)	STABILIMENTO TEVEROLA	INDESIT
ARXL 85 (CSI)	STABILIMENTO TEVEROLA	Hotpoint-Ariston
ARXF 105 (CSI)	STABILIMENTO TEVEROLA	Hotpoint-Ariston
ARSF 85 (EU)	STABILIMENTO COMUNANZA	Hotpoint-Ariston
AR6L 65 (EX)	STABILIMENTO TEVEROLA	ARISTON
ARMXXL 105 (EU)	STABILIMENTO COMUNANZA	Hotpoint-Ariston
AR6L 85 (EX)	STABILIMENTO TEVEROLA	ARISTON
AR6F 85 (EX)	STABILIMENTO TEVEROLA	ARISTON
AR6L 95 (EX)	STABILIMENTO TEVEROLA	ARISTON
AR6L 105 (EX)	STABILIMENTO TEVEROLA	ARISTON
AR6L 125 (EX)	STABILIMENTO TEVEROLA	ARISTON
AR6F 105 (EX)	STABILIMENTO TEVEROLA	ARISTON
ARSF 125 (CIS)	STABILIMENTO COMUNANZA	Hotpoint-Ariston
ARSF 1050 (CIS)	STABILIMENTO COMUNANZA	Hotpoint-Ariston
ARSL 850 (CIS)	STABILIMENTO COMUNANZA	Hotpoint-Ariston
AR 61 (EU)		Hotpoint-Ariston
ARSL 1050 (CIS)	STABILIMENTO COMUNANZA	Hotpoint-Ariston
ARM7L 85 (EX)	STABILIMENTO COMUNANZA	ARISTON
ARM7L 105 (EX)	STABILIMENTO COMUNANZA	ARISTON
ARXL 145 (EU)	STABILIMENTO TEVEROLA	Hotpoint-Ariston

ARXL 95 (EU)	STABILIMENTO TEVEROLA	Hotpoint-Ariston
ARXL 125 (EU)	STABILIMENTO TEVEROLA	Hotpoint-Ariston
ARL 105 (EU)	STABILIMENTO TEVEROLA	Hotpoint-Ariston
ARXF 125 (EU)	STABILIMENTO TEVEROLA	Hotpoint-Ariston
ARXF 145 (EU)	STABILIMENTO TEVEROLA	Hotpoint-Ariston
ARL 125 (FR)	STABILIMENTO TEVEROLA	Hotpoint-Ariston
ARXL 125 (FR)		Hotpoint-Ariston
ARL 145 (FR)		Hotpoint-Ariston
ARXF 125 (FR)	STABILIMENTO TEVEROLA	Hotpoint-Ariston
ARXL 145 (FR)	STABILIMENTO TEVEROLA	Hotpoint-Ariston
ARL 62 (TK)	STABILIMENTO TEVEROLA	Hotpoint-Ariston
AR7L 85 S (EX)	STABILIMENTO COMUNANZA	ARISTON
ARL 85 (TK) 2EV	STABILIMENTO TEVEROLA	Hotpoint-Ariston
ARL 105 (TK) 2EV	STABILIMENTO TEVEROLA	Hotpoint-Ariston
ARXL 85 (TK) 2EV	STABILIMENTO TEVEROLA	Hotpoint-Ariston
ARXL 105 (TK) 2EV	STABILIMENTO TEVEROLA	Hotpoint-Ariston
ARXX F 106 S (TK)	STABILIMENTO COMUNANZA	Hotpoint-Ariston
ARSF 125 (FR)	STABILIMENTO COMUNANZA	Hotpoint-Ariston
ARMXD 145 (FR)	STABILIMENTO COMUNANZA	Hotpoint-Ariston
ARMXXL 125 (FR)	STABILIMENTO COMUNANZA	Hotpoint-Ariston
ARSL 85 (EU)	STABILIMENTO COMUNANZA	Hotpoint-Ariston
ARSL 105 (EU)	STABILIMENTO COMUNANZA	Hotpoint-Ariston
ARMXXL 125 (EU)/HA	STABILIMENTO COMUNANZA	Hotpoint-Ariston
ARXF 105 (EU)	STABILIMENTO TEVEROLA	Hotpoint-Ariston
ARXL 125 (SK)		Hotpoint-Ariston
WIXE 12 (FR).1	STABILIMENTO TEVEROLA	INDESIT
WIXE 14 (FR).1	STABILIMENTO TEVEROLA	INDESIT
WIXE 127 (DE)	STABILIMENTO TEVEROLA	INDESIT
WIXXL 86 (EU).1	STABILIMENTO COMUNANZA	INDESIT
WIXXL 106 (EU).1	STABILIMENTO COMUNANZA	INDESIT
WIXXL 126 (EU).1	STABILIMENTO COMUNANZA	INDESIT
WIXE 147 (DE)	STABILIMENTO TEVEROLA	INDESIT
WIXXE 14 (NL)	STABILIMENTO COMUNANZA	INDESIT
WIXXE 14 (FR).1	STABILIMENTO COMUNANZA	INDESIT
WIDXE 126 (DE)	STABILIMENTO COMUNANZA	INDESIT
WIDXE 146 (DE)	STABILIMENTO COMUNANZA	INDESIT
WIXE 167 (DE)	STABILIMENTO COMUNANZA	INDESIT
WIXE 127 S (DE)	STABILIMENTO COMUNANZA	INDESIT
ARMXXF 145 (FR)	STABILIMENTO COMUNANZA	Hotpoint-Ariston
AQSF 120 (FR)		Hotpoint-Ariston
AQXF 145 (EU)	STABILIMENTO COMUNANZA	Hotpoint-Ariston
AQXL 105 (EU)	STABILIMENTO COMUNANZA	Hotpoint-Ariston
ARMXL 135 (FR)	STABILIMENTO COMUNANZA	Hotpoint-Ariston
WIUL 103 (EU)		INDESIT
WIXE 10 (CSI)	Lipetsk Washing	INDESIT
AR 83 (EU)	STABILIMENTO TEVEROLA	Hotpoint-Ariston
AR 103 (EU)	STABILIMENTO TEVEROLA	Hotpoint-Ariston
WIXE 8 (CSI)	Lipetsk Washing	INDESIT

WIXL 103 (CSI)	Lipetsk Washing	INDESIT
WIXL 103 (CSI)		INDESIT
WIXL 83 (CSI)	Lipetsk Washing	INDESIT
WIXL 83 (CSI)		INDESIT
WIXL 105 (SL) (CSI)	Lipetsk Washing	INDESIT
WIXL 85 (SL) (CSI)	Lipetsk Washing	INDESIT
AR7F 105 (EX)	STABILIMENTO BREMBATE	ARISTON
AR7L 125 (EX)	STABILIMENTO BREMBATE	ARISTON
ARXXF 125 (EU)	STABILIMENTO BREMBATE	Hotpoint-Ariston
ARXXL 125 (FR)	STABILIMENTO COMUNANZA	Hotpoint-Ariston
ARXXF 145 (FR)	STABILIMENTO COMUNANZA	Hotpoint-Ariston
ARXXF 125 (FR)	STABILIMENTO BREMBATE	Hotpoint-Ariston
ARXXL 85 (TK)	STABILIMENTO COMUNANZA	Hotpoint-Ariston
ARXXF 106 (TK)	STABILIMENTO COMUNANZA	Hotpoint-Ariston
AVTL 120 (FR)/HA	STABILIMENTO BREMBATE	Hotpoint-Ariston
AVTL 135 (FR)/HA	STABILIMENTO BREMBATE	Hotpoint-Ariston
AVTL 110 (FR)/HA		Hotpoint-Ariston
AVTL 125 (SK)/HA	STABILIMENTO BREMBATE	Hotpoint-Ariston
AWM 108 (EU)	STABILIMENTO COMUNANZA	Hotpoint-Ariston
WIXXL 146 (FR)	STABILIMENTO COMUNANZA	INDESIT
WIXXE 127 (EU)	STABILIMENTO COMUNANZA	INDESIT
WIXXE 110 (FR)	STABILIMENTO COMUNANZA	INDESIT
ARXF 105 (CSI).L	Lipetsk Washing	Hotpoint-Ariston
ARSL 85 (CSI) L.	Lipetsk Washing	Hotpoint-Ariston
ARXL 105 (CSI).L	Lipetsk Washing	Hotpoint-Ariston
ARXL 85 (CSI).L	Lipetsk Washing	Hotpoint-Ariston
ARSL 100 (CSI).L	Lipetsk Washing	Hotpoint-Ariston
ARSF 80 (CSI).L	Lipetsk Washing	Hotpoint-Ariston
ARSF 100 (CSI).L	Lipetsk Washing	Hotpoint-Ariston
ARL 95 (CSI).L	Lipetsk Washing	Hotpoint-Ariston
ARSL 80 (CSI).L	Lipetsk Washing	Hotpoint-Ariston
ARSF 105 (CSI).L	Lipetsk Washing	Hotpoint-Ariston
ARL 100 (CSI).L	Lipetsk Washing	Hotpoint-Ariston
ARSF 120 (CIS).L	Lipetsk Washing	Hotpoint-Ariston
ARSL 105 (CSI).L	Lipetsk Washing	Hotpoint-Ariston
SIXL 106 (EX) 60 HZ		INDESIT
SIXL 126 D (EX) 60HZ		INDESIT
ARGF 125 (EU).R	Radomsko Washing	Hotpoint-Ariston
ARGF 125 (FR). R	Radomsko Washing	Hotpoint-Ariston
ARXXF 135 (FR).R		Hotpoint-Ariston
ARXXF 125 (EU).R	Radomsko Washing	Hotpoint-Ariston
ARXXF 125 (FR).R	Radomsko Washing	Hotpoint-Ariston
ARXXF 145 (EU).R	Radomsko Washing	Hotpoint-Ariston
ARXXL 105 (IT).R	Radomsko Washing	Hotpoint-Ariston
ARXXL 88 (EU).R	Radomsko Washing	Hotpoint-Ariston
ARXXF 145 (FR).R	Radomsko Washing	Hotpoint-Ariston
ARXXL 125 (FR).R	Radomsko Washing	Hotpoint-Ariston
ARXXL 105 (EU).R	Radomsko Washing	Hotpoint-Ariston

ARXXL 125 (EU).R	Radomsko Washing	Hotpoint-Ariston
WIXE 127 (EX).R	Radomsko Washing	INDESIT
ARSL 105 (EU).T	STABILIMENTO TEVEROLA	Hotpoint-Ariston
ARSL 105 (EU).T		Hotpoint-Ariston
AQXXL 125 (FR)	STABILIMENTO COMUNANZA	Hotpoint-Ariston
AQXL 85 (TK)/HA	STABILIMENTO COMUNANZA	Hotpoint-Ariston
AQXL 105 (TK)/HA	STABILIMENTO COMUNANZA	Hotpoint-Ariston
WIN 82 (CSI)	Lipetsk Washing	INDESIT
AWM 88 (EU)	STABILIMENTO COMUNANZA	Hotpoint-Ariston
WISN 80 (CSI)	Lipetsk Washing	INDESIT
WISN 100 (CSI)	Lipetsk Washing	INDESIT
WISN 100 (CSI)		INDESIT
ARUSL 85 (CIS)	Lipetsk Washing	Hotpoint-Ariston
ARGL 105 (EU).R	Radomsko Washing	Hotpoint-Ariston
ARTL 104 (EU)	STABILIMENTO BREMBATE	Hotpoint-Ariston
ARTF 104 (EU)	STABILIMENTO BREMBATE	Hotpoint-Ariston
AR7F 105 (EX).C	STABILIMENTO COMUNANZA	ARISTON
AR7L 125 (EX).C	STABILIMENTO COMUNANZA	ARISTON
ARTL 83 (EU)	STABILIMENTO BREMBATE	Hotpoint-Ariston
WITL 6 (EU)	STABILIMENTO BREMBATE	INDESIT
ARXF 165 (DE)	STABILIMENTO COMUNANZA	Hotpoint-Ariston
ARTL 82 (EU)	STABILIMENTO BREMBATE	Hotpoint-Ariston
ARTL 125 (SK)	STABILIMENTO BREMBATE	Hotpoint-Ariston
IWB 5083 (CIS)	Lipetsk Washing	INDESIT
IWB 5103 (CIS)	Lipetsk Washing	INDESIT
IWB 6085 (CIS)	Lipetsk Washing	INDESIT
IWB 6105 (CIS)	Lipetsk Washing	INDESIT
IWC 5083 (CIS)	Lipetsk Washing	INDESIT
IWC 5103 (CIS)	Lipetsk Washing	INDESIT
IWC 6085 B (CIS)	Lipetsk Washing	INDESIT
IWC 6105 B (CIS)	Lipetsk Washing	INDESIT
IWE 6105 B (CIS)	Lipetsk Washing	INDESIT
ARTL 135 (FR)	STABILIMENTO BREMBATE	Hotpoint-Ariston
ARTL 62 (EU)	STABILIMENTO BREMBATE	Hotpoint-Ariston
ARTL 63 (EX)	STABILIMENTO BREMBATE	ARISTON
ARTL 82 (EX)	STABILIMENTO BREMBATE	ARISTON
ARXL 100 (CSI).L	Lipetsk Washing	Hotpoint-Ariston
ARSF 125 (CSI).L	Lipetsk Washing	Hotpoint-Ariston
AR7L 85 (EX).C	STABILIMENTO COMUNANZA	ARISTON
AR7L 105 (EX).C	STABILIMENTO COMUNANZA	ARISTON
IWSB 5063 (CIS)	Lipetsk Washing	INDESIT
IWSB 5063 (CIS)		INDESIT
IWD 5085 (CIS)	Lipetsk Washing	INDESIT
IWD 5105 (CIS)	Lipetsk Washing	INDESIT
IWSE 5125 (CIS)	Lipetsk Washing	INDESIT
IWSE 5105 (CIS)	Lipetsk Washing	INDESIT
IWSD 5085 (CIS)	Lipetsk Washing	INDESIT
IWSD 5105 (CIS)	Lipetsk Washing	INDESIT

IWSB 5085 (CIS)	Lipetsk Washing	INDESIT
IWSB 5093 (CIS)	Lipetsk Washing	INDESIT
IWSB 5105 (CIS)	Lipetsk Washing	INDESIT
IWSC 5085 (CIS)	Lipetsk Washing	INDESIT
IWSC 5085 SL (CIS)	Lipetsk Washing	INDESIT
IWSC 5105 (CIS)	Lipetsk Washing	INDESIT
IWSC 5105 SL (CIS)	Lipetsk Washing	INDESIT
IWUB 4085 (CIS)	Lipetsk Washing	INDESIT
IWUB 4105 (CIS)	Lipetsk Washing	INDESIT
IWUC 4085 (CIS)	Lipetsk Washing	INDESIT
IWUC 4105 (CIS)	Lipetsk Washing	INDESIT
IWUC 4105 (EU)	Lipetsk Washing	INDESIT
IWUC 4105 (EU)		INDESIT
IWUD 4085 (CIS)	Lipetsk Washing	INDESIT
IWUD 4105 (CIS)	Lipetsk Washing	INDESIT
IWUD 4105 (EU)	Lipetsk Washing	INDESIT
IWUD 4105 (EU)		INDESIT
IWUD 4125 (EU)	Lipetsk Washing	INDESIT
IWUE 4105 (CIS)	Lipetsk Washing	INDESIT
ARUSL 105 (CIS)	Lipetsk Washing	Hotpoint-Ariston
ARXL 85 (EU).N	STABILIMENTO TEVEROLA	Hotpoint-Ariston
AWM 108 (EU).N	STABILIMENTO COMUNANZA	Hotpoint-Ariston
ARXL 88 (EU).L	Lipetsk Washing	Hotpoint-Ariston
ARSL 88 (EU).L	Lipetsk Washing	Hotpoint-Ariston
ARTL 1047 (RU)	STABILIMENTO BREMBATE	Hotpoint-Ariston
ARTF 1047 (RU)	STABILIMENTO BREMBATE	Hotpoint-Ariston
ARTL 837 (RU)	STABILIMENTO BREMBATE	Hotpoint-Ariston
WITL 867 (RU)	STABILIMENTO BREMBATE	INDESIT
WITL 67 (RU)	STABILIMENTO BREMBATE	INDESIT
WITE 1077 (RU)	STABILIMENTO BREMBATE	INDESIT
WITE 877 (RU)	STABILIMENTO BREMBATE	INDESIT
ARTL 827 (RU)	STABILIMENTO BREMBATE	Hotpoint-Ariston
WITXE 1077 (RU)	STABILIMENTO BREMBATE	INDESIT
WITL 1057 (RU)		INDESIT
WISL 103 (CIS)	Lipetsk Washing	INDESIT
WISL 104 (CIS)	Lipetsk Washing	INDESIT
	STABILIMENTO CARINARO	
WITL 867 (RU)	WASHING	INDESIT
	STABILIMENTO CARINARO	
WITE 1077 (RU)	WASHING	INDESIT
	STABILIMENTO CARINARO	
WITE 877 (RU)	WASHING	INDESIT
	STABILIMENTO CARINARO	
WITE 107 (EU)	WASHING	INDESIT
WISXE 10 (CIS)	Lipetsk Washing	INDESIT
AWM 1081 EU	STABILIMENTO COMUNANZA	Hotpoint-Ariston