

Ready 2016/1628 EU
STAGE V
conforme / compliant



PORTABLE RANGE PORTABLE POWER

50HZ

2kW - 20kW

GENERATING SETS | WELDING SETS | WATER PUMPS

KOHLER[®]
SDMO[®]

PW-PR-D0-EN-191

Accessories and options

Mobiles single phase generating sets

	Generating set	Differential protection		Automatic starting	Remote control	Trolley kit	Road trailer	Protection cover	Maintenance kit	Storage tray	Lifting eye
		Factory-fitted	Removable								
INTENS	HX 3000 C5	R01	RKD1	-	-	R06	-	RH0	R18	-	-
	HXC 3000 C5	R01	RKD1	-	-	R06	-	RH0	-	-	-
	HX 4000 C5	R01	RKD1	-	-	RKB2	-	RH1	R33	-	-
	HXC 4000 C5	R01	RKD1	-	-	RKB2	-	RH1	-	-	-
	HX 6000 C5	R02	-	-	-	RKB2	-	RH1	R19	-	-
	HXC 6000 C5	R02	-	-	-	RKB2	-	RH1	-	-	-
PERFORM	PERFORM 3000 C5	R01	RKD1	-	-	RKB1HD	-	RH0	RKS1	RBAC	RLIFT1
	PERFORM 4500 C5	R01	RKD1	-	-	RKB1HD	-	RH1	RKS2	-	RLIFT
	PERFORM 6500 C5	R02	-	-	-	RKB1HD	-	RH1	RKS2	RBAC	RLIFT2
	PERFORM 3000 GAZ C5	R01	RKD1	-	-	RKB1HD	-	RH0	RKS1	RBAC	RLIFT1
	PERFORM 4500 GAZ C5	R01	RKD1	-	-	RKB1HD	-	RH1	RKS2	-	RLIFT
	PERFORM 6500 GAZ C5	R02	-	-	-	RKB1HD	-	RH1	RKS2	RBAC	RLIFT2
PERFORM XL	PERFORM 3000 XL C5	R01	RKD1	-	-	RKB1HD	-	RH0	RKS1	-	RLIFT1
	PERFORM 4500 XL C5	R01	RKD1	-	-	RKB1HD	-	RH1	RKS2	-	RLIFT2
	PERFORM 4500 XL AVR C5	R01	RKD1	-	-	RKB1HD	-	RH1	RKS2	-	RLIFT2
	PERFORM 6500 XL C5	R02	-	-	-	RKB1HD	-	RH1	RKS2	-	RLIFT2
TECHNIC	TECHNIC 6500 E C5	R02B	-	-	-	RKB1HD	-	RH1	RKS2	-	RLIFT2
	TECHNIC 6500 E AVR C5	R02B	-	-	-	RKB1HD	-	RH1	RKS2	-	RLIFT2
	TECHNIC 6500 A AVR C5	R02B	-	-	RSTART2	RKB1HD	-	RH1	RKS2	-	RLIFT2
	TECHNIC 10000 A C5	R02B	-	-	RSTART2	RKB2	-	RH2	RKS5	-	-
	TECHNIC 10000 A AVR C5	R02B	-	-	RSTART2	RKB2	-	RH2	RKS5	-	-
PRESTIGE	INVERTER PRO 2000 C5	-	RKD1	-	-	-	-	-	RYS2	-	-
	INVERTER PRO 3000 E C5	-	-	-	-	as standard	-	-	RYS3	-	-
	PRESTIGE 3000 C5	-	-	-	-	R06	-	RH0	R30	-	-
DIESEL	DIESEL 4000 C5	R01	RKD1	-	-	RKB1HD	-	RH1	RKDS1	RBAC	-
	DIESEL 4000 EXPORT	R01	RKD1	-	-	RKB1HD	-	RH1	RKDS1	RBAC	-
	DIESEL 4000 E XL C5	R01	RKD1	-	-	RKB1HD	-	RH1	RKDS1	RBAC	-
	DIESEL 4000 E XL EXPORT	R01	RKD1	-	-	RKB1HD	-	RH1	RKDS1	RBAC	-
	DIESEL 6000 A XL C5	R02	-	-	-	RKB1HD	-	RH1	RKDS1	RBAC	-
	DIESEL 6000 A XL C	R02	-	VERSO50M40A	RSTART2	RKB1HD	-	RH1	RKDS1	RBAC	-
	DIESEL 10000 A XL C5	R02B	-	VERSO50M40A	RSTART2	RKB2	-	RH2	RKDS3	-	-
	DIESEL 10000 A XL EXPORT	R02B	-	VERSO50M40A	RSTART2	RKB2	-	RH2	RKDS3	-	-
DIESEL SILENCE	DIESEL 6000 A SILENCE C5	R02B	-	VERSO50M40A	RSTART2	RKB3	-	-	RKDS2	-	-
	DIESEL 6000 A SILENCE AVR C5	R02B	-	VERSO50M40A	RSTART2	RKB3	-	-	RKDS2	-	-
	DIESEL 10000 A SILENCE C5	R02B	-	VERSO50M40A	RSTART2	RKB5	R08E	-	RKDS3	-	-
	DIESEL 10000 A SILENCE EXPORT	R02B	-	VERSO50M40A	RSTART2	RKB5	R08E	-	RKDS3	-	-
	DIESEL 10000 A SILENCE AVR C5	R02B	-	VERSO50M40A	RSTART2	RKB5	R08E	-	RKDS3	-	-
	DIESEL 10000A SILENCE AVR EXPORT	R02B	-	VERSO50M40A	RSTART2	RKB5	R08E	-	RKDS3	-	-

Mobiles three phase generating sets

	Generating set	Differential protection Factory-fitted	Automatic starting	Remote control	Trolley kit	Road trailer	Protection cover	Maintenance kit	Storage tray	Lifting eye
IN-INTENS	HX 7500 T C5	R03	-	-	RKB2	-	RH1	R19	-	-
	HXC 7500 T C5	R03	-	-	RKB2	-	RH1	-	-	-
PERFORM	PERFORM 5500 T C5	R03	-	-	RKB1HD	-	RH1	RKS2	-	RLIFT1
	PERFORM 7500 T C5	R03	-	-	RKB1HD	-	RH1	RKS2	RBAC	RLIFT
PERFORM XL	PERFORM 5500 T XL C5	R03	-	-	RKB1HD	-	RH1	RKS2	-	RLIFT1
	PERFORM 7500 T XL C5	R03	-	-	RKB1HD	-	RH1	RKS2	-	RLIFT2
TECHNIC	TECHNIC 7500 TE C5	R03B	-	-	RKB1HD	-	RH1	RKS2	-	RLIFT2
	TECHNIC 7500 TE AVR C5	R03B	-	-	RKB1HD	-	RH1	RKS2	-	RLIFT2
	TECHNIC 7500 TA AVR C5	R03B	-	-	RKB1HD	-	RH1	RKS2	-	RLIFT2
	TECHNIC 15000 TA C5	R03B	-	RSTART2	RKB2	-	RH2	RKS5	-	-
	TECHNIC 15000 TA AVR C5	R03B	-	RSTART2	RKB2	-	RH2	RKS5	-	-
	TECHNIC 20000 TA AVR C5	R03B	-	RSTART2	RKB2	-	-	RKS5	-	-
DIESEL	DIESEL 6500 TE XL C5	R03	VERSO50T25A	-	RKB1HD	-	RH1	RKDS1	RBAC	-
	DIESEL 6500 TA XL C5	R03	VERSO50T25A	-	RKB1HD	-	RH1	RKDS1	RBAC	-
	DIESEL 15000 TA XL C	R03B	VERSO50T25A	-	RKB2	-	RH2	RKDS3	-	-
	DIESEL 15000 TA XL EXPORT	R03B	VERSO50T25A	-	RKB2	-	RH2	RKDS3	-	-
	DIESEL 20000 TA XL AVR EXPORT	R03B	VERSO50T25A	-	-	-	RH2	RKDS3	-	-
DIESEL SILENCE	DIESEL 6500 TA SILENCE C5	R03B	VERSO50T25A	-	RKB3	-	-	RKDS2	-	-
	DIESEL 6500 TA SILENCE AVR C5	R03B	VERSO50T25A	-	RKB3	-	-	RKDS2	-	-
	DIESEL 15000 TA SILENCE C5	R03B	VERSO50T25A	-	RKB5	R08E	-	RKDS3	-	-
	DIESEL 15000TA SILENCE EXPORT	R03B	VERSO50T25A	-	RKB5	R08E	-	RKDS3	-	-
	DIESEL 15000 TE SILENCE AVR	R03B	VERSO50T25A	-	RKB5	R08E	-	RKDS3	-	-
	DIESEL 15000TA SILENCE AVR EXPORT	R03B	VERSO50T25A	-	RKB5	R08E	-	RKDS3	-	-

Welding sets

	Welding set	Differential protection						
		Factory-fitted	Removable	Trolley kit	Welding kit	Protection cover	Maintenance kit	Storage tray
GASOLINE	VX 200/4 C5	R01	RKD1	RKB2	R10	RH2	R19	<i>as standard</i>
	VXC 200/4 C5	R01	RKD1	RKB2	R10	RH2	-	<i>as standard</i>
	WELDARC 200 C5	R01	RKD1	RKB1HD	R10	RH1	RKS2	<i>as standard</i>
	VXC 220/7.5 C5	-	-	RKB2	R10	RH2	-	<i>as standard</i>
	WELDARC 220 T C5	-	-	RKB1HD	R10	RH2	RKS2	<i>as standard</i>
	WELDARC 300 TE XL C5	<i>as standard</i>	<i>as standard</i>	RKB2	-	RH2	RKS5	-
DIESEL	WELDARC 180 DE EXPORT	R01	RKD1	RKB1HD	R10	RH1	RKDS1	<i>as standard</i>
	WELDARC 300 TDE XL C5	<i>as standard</i>	<i>as standard</i>	RKB2	-	RH2	RKDS3	-
	WELDARC 300 TDE XL EXPORT	<i>as standard</i>	<i>as standard</i>	RKB2	-	RH2	RKDS3	-

Water pumps

	Water pump	Pipe kit	Quickrelease connections	Protection cover	Trolley kit
INTENS	CLEAR 1.7 C5	R16	-	-	-
	ST 2.36 C5	R11	R13	RH0	-
	ST 3.60 C5	R12	R14	RH0	-
	TR 2.36 C5	R11	R13	RH0	-
	TR 3.60 C5	R12	R14	RH0	-
SPECIALIST	HP 2.26 C5	R09	R09	RH0	-
	XT 3.78 C5	R12	R14	RH0	-
	TRASH 3 C5	R12	<i>as standard</i>	RH1	RKB2
	TRASH 4 C5	R21	<i>as standard</i>	RH1	RKB2

Stationary generating sets

	Generating set	Differential protection Factory-fitted	Remote control	Automatic starting
SINGLE	XP-K6M-ALIZE	<i>as standard</i>	CA308	VERSO M
	XP-T9KM-ALIZE	<i>as standard</i>	CA308	VERSO M
THREE	XP-K16H-ALIZE	<i>as standard</i>	CA308	VERSO T
	XP-K9-ALIZE	<i>as standard</i>	CA308	VERSO T
	XP-T12K-ALIZE	<i>as standard</i>	CA308	VERSO T
	XP-T16K-ALIZE	<i>as standard</i>	CA308	VERSO T

Type	Désignation
VERSO 50 M 40A	Automatic transfer switch suitable to connect a generator to a house. For single phase generator only 40 A.(battery charger) Requires a control Panel MODYS/APM202.
VERSO 50 M 100A	Automatic transfer switch suitable to connect a generator to a house. For single phase generator only 100 A.(battery charger) Requires a control Panel MODYS/APM202.
VERSO 50 T 25A	Automatic transfer switch suitable to connect a generator to a house. For three phase generator only 25 A.(battery charger) Requires a control Panel MODYS/APM202.
VERSO 50 T 40A	Automatic transfer switch suitable to connect a generator to a house. For three phase generator only 40 A.(battery charger) Requires a control Panel MODYS/APM202.
RKD1	Kit 2 adapters for earth leakage protection removable. Possibility of solutions with non-removable and hour meter.
R05M	Manuel transfer switch suitable to connect a generator to a house. For single phase generator only.
R06	Trolley kit for 2/3 Kw HONDA generators - Wheel diameter : 187 mm
RKB1HD	Trolley kit for <=6 Kw KOHLER generators - 4 handles and puncture-proof wheel diameter : 290 mm
RKB2	Trolley kit for Kohler > 6 kW generators et Honda > 4 kW generators with 4 handles and 2 puncture-proof wheel (Ø 290 mm).
RKB3	Trolley kit with 1 handle and 2 puncture-proof wheel (Ø 290 mm) for Diesel 6000 E SILENCE and Diesel 6500 TE SILENCE.
RKB5	Trolley kit with 1 handle and 2 puncture-proof wheel (Ø 300 mm) for diesel 1000 silence and 15000 TE silence.
RAP	16A industrial socket adapter to 10 / 16A household socket.
RSTART2	Wireless remote control with on / off button. Require a genset with an APM202.
RCC	Coupling cable for connecting 2 INVERTER PRO 2000 gensets to give a total rating of 3 kW. For INVERTER PRO 2000 only.
RLIFT1	Central lifting point for genset PERFORM 3000 and PERFORM 3000XL.
RLIFT2	Central lifting point for genset PERFORM >= 4 kW (unless PERFORM 45000/5500T) and TECHNIC 6500/7500.
RLIFT	Central lifting point for genset PERFORM 4500 and PERFORM 5500T.
R10	Welding kit including a 2x5 m cable, 1 earth clip, 1 electrode holder, 1 hammer, 1 brush and screen.
R09	Hose kit for HP 2.26 H water pump including pipe 5 m in, pipe 25 m out, coupling and hose (jet-spray-stop).
R16	Pipe kit for water pumps 1> included 5 m in (armed PVC) + 10 m out (flat PVC) (not suitable for high pressure).
R11	Pipe kit for water pumps 2> included 5 m in (armed PVC) + 25 m out (flat PVC) (not suitable for high pressure).
R12	Pipe kit for water pumps 3> included 5 m in (armed PVC) + 25 m out (flat PVC) (not suitable for high pressure).
R21	Pipe kit for water pumps 4> included 3 m in (armed PVC) + 25 m out (flat PVC) (not suitable for high pressure).
R13	Quick coupling for 2" water pumps.
R14	Quick coupling for 3" water pumps.
RPQ	Earth stick - Galvanized - 1m long - delivered with 2m cables (10mm²).
RPM	Male sockets kit (2 x 16A / 230 v, 1 x CEE : 16A / 230 v, 1 x 32A / 230 v, 1 x 16A / 400 v).
R18	Maintenance kit for Honda engine GX160 & GX200 (except Water Pumps) including oil, spark plug, air filter.
R19	Maintenance kit for Honda engine GX390 including oil, spark plug, air filter.
R30	Maintenance kit for PRESTIGE 30000 genset including oil, spark plug, air filter.
R33	Maintenance kit for Honda engine GX270 including oil, spark plug, air filter.
RKS1	Maintenance kit for Kohler gasoline engine, including oil, spark plug, air filter.
RKS2	Maintenance kit for Kohler CH395 and CH440 gasoline engine, including oil, spark plug, air filter.
RKS5	Maintenance kit for Kohler CH680 gasoline engine, including oil, spark plug, air filter and oil filter.
RKDS1	Maintenance kit for Kohler KD350/440 open engine, including oil filter, air filter and fuel filter.
RKDS2	Maintenance kit for Kohler KD15-440 canopy engine, including oil filter, fuel prefilter and fuel filter, air filter.
RKDS3	Maintenance kit for Kohler KD425-2 engine, including oil filter, air filter and fuel filter.
RYS2	Maintenance kit for Yamaha engine MZ80 including 0.5 L of oil, spark plug, air filter.
RYS3	Maintenance kit for Yamaha engine MZ175 including 2x0.5 L of oil, spark plug, air filters.
RBH 0.5	0,5 L oil bottle by 24 in carton box (SAE 15W40).
RBH 1	1 L oil bottle by 20 in carton box (SAE 15W40).
RBAC	Removable storage box to fix on the top of the genset.
RHO->2	Protection cover for generators, welding sets and Water Pumps
R01	This set includes a 30mA differential switch and an hour meter for generators up to 4 kW included.
R02	This set includes a 30mA differential switch, an hour meter, for generators > 4 kW
R02B	This set includes a 30mA differential switch for generators.
R03	This set includes a 30mA differential switch, a thermal circuit breaker and an hour meter for three phase generators.
R03B	This set includes a 30mA differential switch for three phase generators
CA308	Remote control in a separate box with on/off switch (or key for Alize), indicator lights for on and generator fault, delivered without cables.
VERSO M	Automatic start (included coolant heater, battery charger, automatic transfer switch).
VERSO T	Automatic start (included coolant heater, battery charger, automatic transfer switch).
R08E	Light Road trailer with hinged drawbar - Laden weight <500 kg with registration plates - Dimensions with generator (Lxlxh) 3,007 x 1,298 x 1,432 m Road trailer net weight : 143 kg.

Accessoires livrés séparément (en complément de groupes électrogènes, groupes de soudage ou motopompes)

Options montées en usine