

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

AEG	CLARA1047	914512206	AEG	CLARA847	914756211
AEG	L1045E	914512104	AEG	L1045E	914512100
AEG	L1045EL	914756508	AEG	L1045EL	914512202
AEG	L1046EL	914756518	AEG	L10500VI	914510105
AEG	L1245EL	914512203	AEG	L1245EL	914756509
AEG	L1246EL	914756519	AEG	L12500VI	914510103
AEG	L12500VI	914510113	AEG	L12500VI	914510104
AEG	L12620	914601646	AEG	L12620	914601107
AEG	L12700VIT	914601901	AEG	L12700VIT	914601903
AEG	L12700VIT	914601907	AEG	L12710	914653300
AEG	L12710	914653301	AEG	L1280	914602904
AEG	L12820	914601623	AEG	L14720	914601645
AEG	L14720	914601644	AEG	L14810	914601600
AEG	L14810	914601614	AEG	L14810	914601803
AEG	L14810	914601622	AEG	L14810	914601604

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

AEG	L14820	914601647	AEG	L16810	914601608
AEG	L16810	914601626	AEG	L16810	914601601
AEG	L16810	914601603	AEG	L16810	914601620
AEG	L16810	914601602	AEG	L16810	914601618
AEG	L16810	914601807	AEG	L16820	914602101
AEG	L16820	914602103	AEG	L16820	914602105
AEG	L16866	914602701	AEG	L60600	914515045
AEG	L60610	914515055	AEG	L60621	914514539
AEG	L60637	914515210	AEG	L60688	914514531
AEG	L60699	914512787	AEG	L60820	914514533
AEG	L62560	914515212	AEG	L62622	914515209
AEG	L62699	914515208	AEG	L64550	914515211
AEG	L64560	914515213	AEG	L66530	914515206
AEG	L66560	914515214	AEG	L70786VT	914510303
AEG	L72766VT	914510305	AEG	L72786VT	914510304

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

AEG	L86401	914002696	AEG	LAV13.50	914002320
AEG	LAV13.50	914002268	AEG	LAV13.50	914002280
AEG	LAV13.50	914002287	AEG	LAV13.50	914002312
AEG	LAV1402	914002386	AEG	LAV1402	914002426
AEG	LAV1403	914002484	AEG	LAV15.50	914002313
AEG	LAV15.50	914002281	AEG	LAV15.50	914002288
AEG	LAV15.50	914002321	AEG	LAV15.50	914002267
AEG	LAV15.50	914002306	AEG	LAV1600 SL-W	914002269
AEG	LAV22450	914002777	AEG	LAV24450	914002655
AEG	LAV3200	914002780	AEG	LAV3400	914002781
AEG	LAV50165	914002761	AEG	LAV50200	914003204
AEG	LAV50200	914003112	AEG	LAV50265	914002760
AEG	LAV50430-W	914002184	AEG	LAV50435-W	914002186
AEG	LAV50465	914002759	AEG	LAV50550	914002684
AEG	LAV50565	914002762	AEG	LAV50600	914003111

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

AEG	LAV50600	914003162	AEG	LAV50600	914003107
AEG	LAV50600	914003132	AEG	LAV50630	914002185
AEG	LAV50630-W	914002185	AEG	LAV50800	914003161
AEG	LAV50800	914003103	AEG	LAV51165	914002768
AEG	LAV51365	914002758	AEG	LAV51465	914002769
AEG	LAV51665	914002757	AEG	LAV5210	914003065
AEG	LAV5210	914003134	AEG	LAV5220	914003082
AEG	LAV52435-W	914002190	AEG	LAV52550	914002682
AEG	LAV52560	914002658	AEG	LAV52565	914002755
AEG	LAV52569	914002659	AEG	LAV52600	914003064
AEG	LAV52600	914003160	AEG	LAV52600	914003020
AEG	LAV52600	914003113	AEG	LAV52600	914003131
AEG	LAV52600	914003105	AEG	LAV52607	914003185
AEG	LAV52608	914003108	AEG	LAV52665	914002754
AEG	LAV52800	914003146	AEG	LAV53601	914003184

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

AEG	LAV5410	914003135	AEG	LAV5410	914003063
AEG	LAV5420	914003083	AEG	LAV54550	914002683
AEG	LAV54560	914002660	AEG	LAV54569	914002661
AEG	LAV54600	914003043	AEG	LAV54600	914003061
AEG	LAV54600	914003172	AEG	LAV54600	914003081
AEG	LAV54608	914003109	AEG	LAV54609	914003062
AEG	LAV54609	914003197	AEG	LAV54665	914002756
AEG	LAV54800	914003159	AEG	LAV58600	914003234
AEG	LAV60200	914003203	AEG	LAV60800	914003158
AEG	LAV60800	914003130	AEG	LAV60800	914003102
AEG	LAV6240	914003084	AEG	LAV62600	914003060
AEG	LAV62600	914003219	AEG	LAV62600	914003195
AEG	LAV62600	914003129	AEG	LAV62600	914003183
AEG	LAV62730	914002300	AEG	LAV62730-W	914002300
AEG	LAV62800	914003171	AEG	LAV62800	914003128

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

AEG	LAV62800	914003157	AEG	LAV62800	914003019
AEG	LAV62800	914003080	AEG	LAV62804	914003034
AEG	LAV62806	914003033	AEG	LAV63600	914003137
AEG	LAV63600	914003196	AEG	LAV63805	914003182
AEG	LAV63809	914003145	AEG	LAV6410	914003205
AEG	LAV6410	914003059	AEG	LAV64130-W	914002291
AEG	LAV6420	914003206	AEG	LAV6420	914003058
AEG	LAV6440	914003079	AEG	LAV64530	914002293
AEG	LAV64530	914002790	AEG	LAV64530-W	914002293
AEG	LAV64600	914003170	AEG	LAV64600	914003056
AEG	LAV64600	914003143	AEG	LAV64600	914003181
AEG	LAV64600	914003209	AEG	LAV64600	914003217
AEG	LAV64607	914003245	AEG	LAV64608	914003220
AEG	LAV64608	914003110	AEG	LAV64609	914003057
AEG	LAV64609	914003221	AEG	LAV64630	914002410

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

AEG	LAV64630-W	914002311	AEG	LAV646EX	914003231
AEG	LAV64730	914002294	AEG	LAV64730-W	914002294
AEG	LAV64735	914002490	AEG	LAV64780	914002526
AEG	LAV64800	914003078	AEG	LAV64800	914003035
AEG	LAV64800	914003169	AEG	LAV64806	914003036
AEG	LAV64809	914003144	AEG	LAV65600	914003136
AEG	LAV6610	914003227	AEG	LAV66600	914003208
AEG	LAV66600	914003055	AEG	LAV66600	914003153
AEG	LAV666EX	914003232	AEG	LAV66800	914003141
AEG	LAV66800	914003168	AEG	LAV66800	914003077
AEG	LAV66800	914003233	AEG	LAV66805	914003180
AEG	LAV66806	914003244	AEG	LAV66809	914003142
AEG	LAV70230-W	914002076	AEG	LAV70230-W	914002100
AEG	LAV70240	914002513	AEG	LAV70240	914002521
AEG	LAV70260	914002654	AEG	LAV70330	914002153

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

AEG	LAV70330-W	914002152	AEG	LAV70330-W	914002179
AEG	LAV70330-W	914002146	AEG	LAV70330-W	914002153
AEG	LAV70330-W	914002083	AEG	LAV70330-W	914002247
AEG	LAV70330-W	914002077	AEG	LAV70339 WB-W	914002164
AEG	LAV70339-W	914002164	AEG	LAV70340	914002412
AEG	LAV70340-W	914002370	AEG	LAV70340-W	914002412
AEG	LAV70360	914002647	AEG	LAV70435-W	914002207
AEG	LAV70435-W	914002234	AEG	LAV70530-W	914002113
AEG	LAV70530-W	914002062	AEG	LAV70530-W	914002063
AEG	LAV70530-W	914002032	AEG	LAV70530-W	914002022
AEG	LAV70539-W	914002021	AEG	LAV70560	914002770
AEG	LAV70560	914002692	AEG	LAV70610-W	914002084
AEG	LAV70630-W	914002332	AEG	LAV70630-W	914002132
AEG	LAV70630-W	914002075	AEG	LAV70630-W	914002145
AEG	LAV70633-W	914002068	AEG	LAV70638-W	914002158

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

AEG	LAV70640	914002411	AEG	LAV70640	914002512
AEG	LAV70640	914002398	AEG	LAV70660	914002651
AEG	LAV70730-W	914002020	AEG	LAV70730-W	914002033
AEG	LAV70730-W	914002144	AEG	LAV70733-W	914002205
AEG	LAV70740	914002394	AEG	LAV70740-W	914002282
AEG	LAV70740-W	914002348	AEG	LAV70760	914002646
AEG	LAV70780-W	914002200	AEG	LAV70780-W	914002253
AEG	LAV70790	914002663	AEG	LAV70800	914003156
AEG	LAV70800	914003202	AEG	LAV71330	914002101
AEG	LAV71330-W	914002101	AEG	LAV71330-W	914002106
AEG	LAV71739-W	914002019	AEG	LAV71749-W	914002283
AEG	LAV7200	914002482	AEG	LAV7200	914002590
AEG	LAV72330-W	914002051	AEG	LAV72330-W	914002151
AEG	LAV72330-W	914002027	AEG	LAV72330-W	914002116
AEG	LAV72330-W	914002108	AEG	LAV72334-W	914002052

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

AEG	LAV72335-W	914002055	AEG	LAV72337-W	914002192
AEG	LAV72338-W	914002277	AEG	LAV72356	914002629
AEG	LAV72401	914002709	AEG	LAV72530-W	914002061
AEG	LAV72530-W	914002028	AEG	LAV72530-W	914002050
AEG	LAV72534	914002402	AEG	LAV72534-W	914002138
AEG	LAV72534JADE	914002388	AEG	LAV72537-W	914002049
AEG	LAV72550	914002632	AEG	LAV7256	914002630
AEG	LAV72630	914002092	AEG	LAV72630-W	914002208
AEG	LAV72630-W	914002105	AEG	LAV72630-W	914002047
AEG	LAV72630-W	914002130	AEG	LAV72630-W	914002135
AEG	LAV72630-W	914002092	AEG	LAV72630-W	914002096
AEG	LAV72630-W	914002117	AEG	LAV72630-W	914002133
AEG	LAV72630-W A	914002130	AEG	LAV72636	914002455
AEG	LAV72638-W	914002048	AEG	LAV72640	914002396
AEG	LAV72640	914002399	AEG	LAV72640	914002416

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

AEG	LAV72640-W	914002304	AEG	LAV72650	914002748
AEG	LAV72660	914002636	AEG	LAV72660	914002699
AEG	LAV72660	914002637	AEG	LAV72660	914002771
AEG	LAV72660	914002693	AEG	LAV72666	914002649
AEG	LAV72730-W	914002026	AEG	LAV72730-W	914002143
AEG	LAV72730-W	914002060	AEG	LAV72730-W	914002074
AEG	LAV72730-W	914002085	AEG	LAV72730-W	914002150
AEG	LAV72730-W	914002017	AEG	LAV72730-W D	914002017
AEG	LAV72738-W	914002086	AEG	LAV72740	914002511
AEG	LAV72740	914002349	AEG	LAV72740-W	914002284
AEG	LAV72740-W	914002336	AEG	LAV72740-W	914002349
AEG	LAV72748	914002369	AEG	LAV72750	914002480
AEG	LAV72760	914002616	AEG	LAV72760	914002523
AEG	LAV72760	914002652	AEG	LAV72760	914002704
AEG	LAV72760	914002568	AEG	LAV72768	914002665

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

AEG	LAV72769	914002569	AEG	LAV72769	914002524
AEG	LAV72780-W	914002198	AEG	LAV72785	914002498
AEG	LAV72800	914003101	AEG	LAV72800	914003119
AEG	LAV72800	914003155	AEG	LAV72800	914003201
AEG	LAV72800	914003076	AEG	LAV72800	914003021
AEG	LAV72808	914003024	AEG	LAV73330-W	914002109
AEG	LAV73330-W	914002154	AEG	LAV73330-W	914002118
AEG	LAV73360	914002638	AEG	LAV73530	914002119
AEG	LAV73530-W	914002119	AEG	LAV73550	914002626
AEG	LAV73567	914002642	AEG	LAV73569	914002643
AEG	LAV73630-W	914002045	AEG	LAV73630-W	914002089
AEG	LAV73630-W	914002104	AEG	LAV73633-W	914002046
AEG	LAV73639-W	914002163	AEG	LAV73664	914002650
AEG	LAV73738-W	914002016	AEG	LAV73739-W	914002015
AEG	LAV73743	914002475	AEG	LAV73748-W	914002330

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

AEG	LAV73749-W	914002285	AEG	LAV73758	914002487
AEG	LAV7400	914002591	AEG	LAV7400	914002481
AEG	LAV7401	914002745	AEG	LAV7403	914002483
AEG	LAV7405	914002694	AEG	LAV7407	914002587
AEG	LAV74330	914002204	AEG	LAV74330	914002272
AEG	LAV74330-W	914002099	AEG	LAV74330-W	914002204
AEG	LAV74330-W	914002272	AEG	LAV74339	914002120
AEG	LAV74339	914002239	AEG	LAV74339 WB-W	914002120
AEG	LAV74339-W	914002120	AEG	LAV74339-W	914002239
AEG	LAV74352	914002628	AEG	LAV74401	914002710
AEG	LAV7450	914002714	AEG	LAV74530-W	914002030
AEG	LAV74530-W	914002044	AEG	LAV7456	914002631
AEG	LAV74560	914002634	AEG	LAV74560	914002633
AEG	LAV74569	914002644	AEG	LAV74600	914003246
AEG	LAV74630	914002093	AEG	LAV74630-W	914002093

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

AEG	LAV74630-W	914002121	AEG	LAV74630-W	914002246
AEG	LAV74630-W	914002043	AEG	LAV74630-W	914002103
AEG	LAV74630-W	914002097	AEG	LAV74639	914002162
AEG	LAV74639	914002347	AEG	LAV74639 WB-W	914002162
AEG	LAV74640	914002397	AEG	LAV74640	914002400
AEG	LAV74640	914002305	AEG	LAV74640-W	914002305
AEG	LAV74650	914002479	AEG	LAV74650	914002747
AEG	LAV74651	914002641	AEG	LAV74660	914002635
AEG	LAV74665	914002648	AEG	LAV74730	914002439
AEG	LAV74730-W	914002059	AEG	LAV74730-W	914002014
AEG	LAV74730-W	914002029	AEG	LAV74730-W	914002328
AEG	LAV74730-W	914002136	AEG	LAV74730-W	914002149
AEG	LAV74730-W	914002329	AEG	LAV74734-W	914002042
AEG	LAV74738-W	914002041	AEG	LAV74740	914002286
AEG	LAV74740-W	914002286	AEG	LAV74740-W	914002350

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

AEG	LAV74740-W	914002335	AEG	LAV74744	914002440
AEG	LAV74748	914002357	AEG	LAV74750	914002478
AEG	LAV74760	914002615	AEG	LAV74760	914002703
AEG	LAV74760	914002567	AEG	LAV74760	914002592
AEG	LAV74760	914002750	AEG	LAV74760	914002685
AEG	LAV74760	914002499	AEG	LAV74768	914002666
AEG	LAV74769	914002566	AEG	LAV74769	914002500
AEG	LAV74780-W	914002331	AEG	LAV747EX	914002537
AEG	LAV74800	914003114	AEG	LAV74800	914003100
AEG	LAV74800	914003167	AEG	LAV74800	914003054
AEG	LAV74800	914003075	AEG	LAV74800	914003179
AEG	LAV74800	914003025	AEG	LAV74800	914003152
AEG	LAV74800	914003154	AEG	LAV74803	914003133
AEG	LAV74804	914003022	AEG	LAV74808	914003026
AEG	LAV74809	914003207	AEG	LAV75530-W	914002122

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

AEG	LAV75550	914002627	AEG	LAV75639 WB-W	914002161
AEG	LAV75639-W	914002161	AEG	LAV75666	914002653
AEG	LAV75735-W	914002054	AEG	LAV75737-W	914002040
AEG	LAV75747	914002401	AEG	LAV75807	914003178
AEG	LAV7650	914002713	AEG	LAV76560	914002621
AEG	LAV76600	914003247	AEG	LAV76630	914002090
AEG	LAV76630	914002123	AEG	LAV76630-W	914002102
AEG	LAV76630-W	914002090	AEG	LAV76630-W	914002123
AEG	LAV76639 WB-W	914002160	AEG	LAV76639-W	914002160
AEG	LAV76639-W	914002243	AEG	LAV76640	914002395
AEG	LAV76640	914002579	AEG	LAV76640	914002442
AEG	LAV76654	914002640	AEG	LAV76660	914002623
AEG	LAV76665	914002622	AEG	LAV76665	914002624
AEG	LAV76669	914002625	AEG	LAV76689	914002454
AEG	LAV76730	914002023	AEG	LAV76730-W	914002023

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

AEG	LAV76730-W	914002058	AEG	LAV76730-W	914002155
AEG	LAV76730-W	914002039	AEG	LAV76730-W	914002202
AEG	LAV76730-W	914002142	AEG	LAV76730-W	914002031
AEG	LAV76740	914002316	AEG	LAV76740-W	914002316
AEG	LAV76760	914002617	AEG	LAV76760	914002673
AEG	LAV76760	914002588	AEG	LAV76768	914002667
AEG	LAV76769	914002501	AEG	LAV76769	914002580
AEG	LAV76780	914002393	AEG	LAV76780-W	914002199
AEG	LAV76785	914002497	AEG	LAV76790	914002705
AEG	LAV767EX	914002776	AEG	LAV76800	914003225
AEG	LAV76800	914003052	AEG	LAV76800	914003027
AEG	LAV76800	914003177	AEG	LAV76800	914003074
AEG	LAV76800	914003166	AEG	LAV76808	914003028
AEG	LAV76809	914003053	AEG	LAV76809	914003226
AEG	LAV76809	914003218	AEG	LAV76820	914003251

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

AEG	LAV7685M	914003249	AEG	LAV78800	914003165
AEG	LAV78800	914003018	AEG	LAV78800	914003073
AEG	LAV78800	914003051	AEG	LAV78800	914003224
AEG	LAV82730-W	914002073	AEG	LAV82730-W	914002270
AEG	LAV82730-W	914002232	AEG	LAV82730-W	914002141
AEG	LAV82730-W	914002231	AEG	LAV82740-W	914002289
AEG	LAV82740-W	914002327	AEG	LAV82741	914002559
AEG	LAV82741	914002510	AEG	LAV82741	914002378
AEG	LAV82741	914002561	AEG	LAV82800	914003116
AEG	LAV82800	914003072	AEG	LAV82800	914003149
AEG	LAV83739-W	914002230	AEG	LAV83749-W	914002290
AEG	LAV84730-W	914002072	AEG	LAV84730-W	914002082
AEG	LAV84730-W	914002037	AEG	LAV84730-W	914002013
AEG	LAV84740-W	914002264	AEG	LAV84740-W	914002323
AEG	LAV84741	914002509	AEG	LAV84741	914002558

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

AEG	LAV84760	914002414	AEG	LAV84760	914002495
AEG	LAV84760	914002573	AEG	LAV84760	914002578
AEG	LAV84760	914002565	AEG	LAV84800	914003148
AEG	LAV84800	914003127	AEG	LAV84800	914003071
AEG	LAV84800	914003115	AEG	LAV84800	914003050
AEG	LAV84800	914003215	AEG	LAV84800	914003099
AEG	LAV85730-W	914002081	AEG	LAV85738-W	914002165
AEG	LAV85739-W	914002012	AEG	LAV85739-W	914002191
AEG	LAV85748-W	914002266	AEG	LAV85749-W	914002371
AEG	LAV85749-W	914002265	AEG	LAV85769	914002563
AEG	LAV85769	914002415	AEG	LAV8650	914002676
AEG	LAV86660	914002557	AEG	LAV86660	914002514
AEG	LAV86730-W	914002148	AEG	LAV86730-W	914002034
AEG	LAV86730-W	914002095	AEG	LAV86730-W	914002140
AEG	LAV86730-W	914002131	AEG	LAV86730-W	914002128

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

AEG	LAV86730-W	914002011	AEG	LAV86730-W	914002079
AEG	LAV86730-W	914002271	AEG	LAV86734-W	914002226
AEG	LAV86738-W	914002080	AEG	LAV86740	914002404
AEG	LAV86740	914002417	AEG	LAV86740-W	914002339
AEG	LAV86740-W	914002338	AEG	LAV86740-W	914002324
AEG	LAV86740-W	914002263	AEG	LAV86741	914002560
AEG	LAV86741	914002405	AEG	LAV86741	914002377
AEG	LAV86744-W	914002342	AEG	LAV86748-W	914002341
AEG	LAV86760	914002493	AEG	LAV86760	914002535
AEG	LAV86760	914002577	AEG	LAV86760	914002656
AEG	LAV86760	914002564	AEG	LAV86760	914002494
AEG	LAV86760	914002413	AEG	LAV86760	914002618
AEG	LAV86764	914002572	AEG	LAV86768	914002575
AEG	LAV86800	914003117	AEG	LAV86800	914003176
AEG	LAV86800	914003098	AEG	LAV86800	914003070

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

AEG	LAV86800	914003164	AEG	LAV86800	914003194
AEG	LAV86800	914003029	AEG	LAV86800	914003049
AEG	LAV86804	914003032	AEG	LAV86807	914003031
AEG	LAV86808	914003030	AEG	LAV86809	914003122
AEG	LAV87656	914002765	AEG	LAV87739-W	914002024
AEG	LAV88730-W	914002036	AEG	LAV88730-W	914002038
AEG	LAV88730-W	914002098	AEG	LAV88739 WB-W	914002159
AEG	LAV88739-W	914002159	AEG	LAV88740-W	914002354
AEG	LAV88749	914002381	AEG	LAV88800	914003047
AEG	LAV88800	914003139	AEG	LAV88800	914003017
AEG	LAV88800	914003147	AEG	LAV88800	914003175
AEG	LAV88800	914003068	AEG	LAV88800	914003200
AEG	LAV88809	914003048	AEG	LAV88809	914003140
AEG	LAV88830-W	914002315	AEG	LAV88830-W	914002078
AEG	LAV88830-W	914002147	AEG	LAV88830-W	914002094

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

AEG	LAV88830-W	914002071	AEG	LAV88830-W	914002127
AEG	LAV88830-W	914002137	AEG	LAV88830-W	914002139
AEG	LAV88830-W	914002201	AEG	LAV88830-W	914002035
AEG	LAV88830-W	914002010	AEG	LAV88830-W	914002129
AEG	LAV88830-W	914002107	AEG	LAV88830-W	914002134
AEG	LAV88830-W	914002057	AEG	LAV88840	914002508
AEG	LAV88840	914002456	AEG	LAV88840	914002706
AEG	LAV88840	914002380	AEG	LAV88840	914002373
AEG	LAV88840	914002387	AEG	LAV88840	914002589
AEG	LAV88840	914002409	AEG	LAV88840	914002379
AEG	LAV88840	914002385	AEG	LAV88840	914002376
AEG	LAV88840-W	914002337	AEG	LAV88840-W	914002326
AEG	LAV88840-W	914002334	AEG	LAV88840-W	914002325
AEG	LAV88840-W	914002262	AEG	LAVALOGIC1400	914002773
AEG	LAVALOGIC1400	914002611	AEG	LAVALOGIC1400	914002612

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

AEG	LAVALOGIC1400	914002549	AEG	LAVALOGIC1400	914002730
AEG	LAVALOGIC1400	914002731	AEG	LAVALOGIC1410	914003125
AEG	LAVALOGIC1410	914003198	AEG	LAVALOGIC1410	914003046
AEG	LAVALOGIC1410	914003042	AEG	LAVALOGIC1600	914002548
AEG	LAVALOGIC1600	914002766	AEG	LAVALOGIC1600	914002734
AEG	LAVALOGIC1600	914002772	AEG	LAVALOGIC1600	914002732
AEG	LAVALOGIC1600	914002735	AEG	LAVALOGIC1600	914002749
AEG	LAVALOGIC1600	914002733	AEG	LAVALOGIC1600	914002613
AEG	LAVALOGIC1600	914002614	AEG	LAVALOGIC1610	914003123
AEG	LAVALOGIC1610	914003097	AEG	LAVALOGIC1610	914003045
AEG	LAVALOGIC1610	914003138	AEG	LAVALOGIC1610	914003124

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

AEG	LAVALOGIC1610	914003041	AEG	LAVALOGIC1800	914002547
AEG	LAVALOGIC1800	914002729	AEG	LAVALOGIC1800	914002608
AEG	LAVALOGIC1800	914002726	AEG	LAVALOGIC1800	914002728
AEG	LAVALOGIC1800	914002727	AEG	LAVALOGIC1800	914002609
AEG	LAVALOGIC1810	914003118	AEG	LAVALOGIC1810	914003163
AEG	LAVALOGIC1810	914003044	AEG	LAVALOGIC1810	914003126
AEG	LAVALOGIC1810	914003016	AEG	LAVB3050	914002470
AEG	LAVB3250	914002469	AEG	LAVB3450	914002473
AEG	LAVBELLA	914002066	AEG	LAVBELLA	914003040
AEG	LAVBELLA	914002723	AEG	LAVBELLA	914002645
AEG	LAVBELLA	914002389	AEG	LAVBELLA	914002691
AEG	LAVBELLA	914002238	AEG	LAVBELLA-W	914002238
AEG	LAVBELLA-W	914002066	AEG	LAVBELLA3051	914003241

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

AEG	LAVBELLA3251	914003240	AEG	LAVBELLA3251	914002619
AEG	LAVBELLA3451	914003238	AEG	LAVBELLA3452	914003239
AEG	LAVCENTURY	914002662	AEG	LAVCL L-W	914002236
AEG	LAVCL S-W	914002237	AEG	LAVCL SL-W	914002235
AEG	LAVDERBYLINE	914002430	AEG	LAVDIPLOMATE	914002088
AEG	LAVDIPLOMAT-W	914002088	AEG	LAVDOMINA	914002064
AEG	LAVDOMINA M-W	914002064	AEG	LAVESSENTIAL	914002571
AEG	LAVEURO1200	914002358	AEG	LAVEURO1500	914002355
AEG	LAVEUROLINEL	914002368	AEG	LAVEUROLINEL	914002375
AEG	LAVEUROLINES	914002367	AEG	LAVEUROLINES	914002374
AEG	LAVEUROLINES	914002441	AEG	LAVGENIUS SL	914002550
AEG	LAVGENIUSL	914002551	AEG	LAVGENIUSS	914002552
AEG	LAVMARYLINEL	914002528	AEG	LAVP5050	914002467

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

AEG	LAVP5250	914002468	AEG	LAVPRINCESS	914002390
AEG	LAVPRINCESS	914002690	AEG	LAVPRINCESS	914002722
AEG	LAVPRINCESS	914003038	AEG	LAVPRINCESS	914002065
AEG	LAVPRINCESS-W	914002065	AEG	LAVPRINCESS 5051	914003243
AEG	LAVPRINCESS5251	914003242	AEG	LAVR2550F	914002472
AEG	LAVR2650	914002471	AEG	LAVR2850	914002474
AEG	LAVREGINA	914002574	AEG	LAVREGINA	914002340
AEG	LAVREGINA	914003039	AEG	LAVREGINA-W	914002067
AEG	LAVREGINA1850	914002610	AEG	LAVREGINA18 51	914003235
AEG	LAVREGINA2651	914003237	AEG	LAVREGINA28 51	914003236
AEG	LAVSOUPLESSE10	914002303	AEG	LAVSOUPLESS E12	914002302
AEG	LAVSOUPLESSE14	914002301	AEG	LAVSPIRIT L	914002187
AEG	LAVSPIRIT L-W	914002187	AEG	LAVSPIRIT S- W	914002220

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

AEG	LAVSPIRIT S-W	914002188	AEG	LAVSTARLIGH T-W	914002180
AEG	LAVSUCCESS	914002240	AEG	LAVTRIATHLO N	914002721
AEG	LAVTROPHY ELEC-	914002087	AEG	LAVW1000	914002502
AEG	LAVW1030	914002169	AEG	LAVW1030	914002181
AEG	LAVW1030-W	914002156	AEG	LAVW1030-W	914002173
AEG	LAVW1030-W	914002168	AEG	LAVW1030-W	914002193
AEG	LAVW1030-W	914002203	AEG	LAVW1030-W	914002233
AEG	LAVW1030-W	914002181	AEG	LAVW1030-W	914002172
AEG	LAVW1030-W	914002216	AEG	LAVW1030-W	914002169
AEG	LAVW1035-W	914002213	AEG	LAVW1036-W	914002196
AEG	LAVW1037	914002227	AEG	LAVW1037-W	914002227
AEG	LAVW1039	914002176	AEG	LAVW1039-W	914002176
AEG	LAVW1039-W	914002215	AEG	LAVW1040-W	914002260
AEG	LAVW1047	914002503	AEG	LAVW1049-W	914002261

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

AEG	LAVW1050	914002434	AEG	LAVW1050	914002607
AEG	LAVW1050	914002418	AEG	LAVW1050	914015018
AEG	LAVW1050	914002519	AEG	LAVW1050	914002536
AEG	LAVW1050	914002581	AEG	LAVW1050	914002457
AEG	LAVW1050	914002443	AEG	LAVW1050	914002504
AEG	LAVW1050	914002595	AEG	LAVW1055	914002599
AEG	LAVW1057	914002542	AEG	LAVW1059	914002679
AEG	LAVW1059	914002458	AEG	LAVW1137	914002598
AEG	LAVW1150	914002774	AEG	LAVW1159	914002477
AEG	LAVW1159	914002583	AEG	LAVW1200	914002403
AEG	LAVW1201	914002605	AEG	LAVW1230	914002209
AEG	LAVW1230-W	914002171	AEG	LAVW1230-W	914002170
AEG	LAVW1230-W	914002195	AEG	LAVW1230-W	914002194
AEG	LAVW1230-W	914002182	AEG	LAVW1230-W	914002209
AEG	LAVW1230-W	914002212	AEG	LAVW1236-W	914002197

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

AEG	LAVW1238-W	914002178	AEG	LAVW1239-W	914002177
AEG	LAVW1240-W	914002257	AEG	LAVW1240-W	914002254
AEG	LAVW1241	914002604	AEG	LAVW1248-W	914002259
AEG	LAVW1249-W	914002258	AEG	LAVW1250	914002419
AEG	LAVW1250	914002657	AEG	LAVW1250	914002428
AEG	LAVW1250	914002436	AEG	LAVW1250	914002597
AEG	LAVW1250	914002505	AEG	LAVW1250	914002582
AEG	LAVW1250	914002600	AEG	LAVW1250	914002518
AEG	LAVW1250	914002459	AEG	LAVW1255	914002664
AEG	LAVW1255	914002593	AEG	LAVW1256	914002435
AEG	LAVW1258	914002420	AEG	LAVW1259	914002485
AEG	LAVW1259	914002421	AEG	LAVW1260	914002742
AEG	LAVW1350	914002775	AEG	LAVW1440	914002256
AEG	LAVW1440-W	914002353	AEG	LAVW1440-W	914002256
AEG	LAVW1441	914002606	AEG	LAVW1449	914002466

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

AEG	LAVW1450	914002422	AEG	LAVW1450	914002437
AEG	LAVW1450	914002460	AEG	LAVW1450	914002520
AEG	LAVW1450	914002427	AEG	LAVW1450	914002585
AEG	LAVW1450	914002596	AEG	LAVW1451	914002488
AEG	LAVW1455	914002594	AEG	LAVW1456	914002438
AEG	LAVW1459	914002423	AEG	LAVW1459	914002486
AEG	LAVW1460	914015031	AEG	LAVW1460	914002739
AEG	LAVW720-W	914002183	AEG	LAVW730-W	914002175
AEG	LAVW730-W	914002217	AEG	LAVW800	914002507
AEG	LAVW808-W	914002228	AEG	LAVW830	914002210
AEG	LAVW830	914002174	AEG	LAVW830-W	914002167
AEG	LAVW830-W	914002211	AEG	LAVW830-W	914002210
AEG	LAVW830-W	914002174	AEG	LAVW830-W	914002189
AEG	LAVW831-W	914002166	AEG	LAVW833-W	914002218
AEG	LAVW834-W	914002219	AEG	LAVW835	914002229

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

AEG	LAVW835-W	914002214	AEG	LAVW835-W	914002229
AEG	LAVW850	914002525	AEG	LAVW850	914002570
AEG	LAVW850	914002506	AEG	LAVW853	914002602
AEG	LAVW855	914002603	AEG	LAVW857	914002541
AEG	LAVW859	914002540	AEG	LAVW880-W	914002157
AEG	LAVW937	914002601	AEG	LAVWSOFT 10-W	914002351
AEG	LAVWSOFT 12-W	914002352	AEG	LTRIATHLON	914514534
AEG	REG3610WT	914601689	AEG	REG3610WT	914601615
Corbero	LC1080E	914211036	Corbero	LC1080E	914211123
Corbero	LC1090E	914211145	Corbero	LC680	914261108
Corbero	LC680	914261028	Corbero	LC880E	914281049
Corbero	LC880E	914281128	Corbero	LC8821	914281129
Corbero	LC8821	914281055	Electrolux	BRILJANT	914512847
Electrolux	CLARA1048	914756540	Electrolux	CLARA1048	914756524
Electrolux	CLARA1068	914515234	Electrolux	CLARA1068	914515239

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Electrolux	CLARA1248	914756525	Electrolux	CLARA1248	914756541
Electrolux	CLARA868	914515238	Electrolux	CLARA868	914515231
Electrolux	CMF616	914517342	Electrolux	COMPLESSO	914653312
Electrolux	ELU EWF 1090 SU-UKR-	914901402	Electrolux	EW1030F	914791145
Electrolux	EW1030F	914791376	Electrolux	EW1066W	914602000
Electrolux	EW1067F	914512777	Electrolux	EW1069F	914510603
Electrolux	EW1075F	914512025	Electrolux	EW1075F	914002763
Electrolux	EW1077F	914002718	Electrolux	EW1077F	914512810
Electrolux	EW1077F	914512722	Electrolux	EW1078F	914512832
Electrolux	EW1078F	914514502	Electrolux	EW1079F	914510609
Electrolux	EW1079F	914510608	Electrolux	EW1079F	914510602
Electrolux	EW1080F	914517249	Electrolux	EW1080F	914900023
Electrolux	EW1080F	914517006	Electrolux	EW1080F	914002767
Electrolux	EW1097F	914510600	Electrolux	EW1200F	914002308
Electrolux	EW1224I	914510101	Electrolux	EW1230F	914791146

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Electrolux	EW1232I	914510100	Electrolux	EW1232I	914510110
Electrolux	EW1233I	914510902	Electrolux	EW1233I	914510928
Electrolux	EW1259W	914602012	Electrolux	EW1259W	914602004
Electrolux	EW1266W	914602001	Electrolux	EW1277F	914512723
Electrolux	EW1277F	914512811	Electrolux	EW1277F	914002717
Electrolux	EW1278F	914514503	Electrolux	EW1279F	914513513
Electrolux	EW1279F	914513514	Electrolux	EW1280F	914517504
Electrolux	EW1287W	914601408	Electrolux	EW1288W	914602517
Electrolux	EW1289W	914601674	Electrolux	EW1289W	914601625
Electrolux	EW1289W	914601617	Electrolux	EW1289W	914601627
Electrolux	EW1289W	914601814	Electrolux	EW1289W	914601663
Electrolux	EW1289W	914601816	Electrolux	EW1289W	914602902
Electrolux	EW1290W	914601630	Electrolux	EW1290W	914601691
Electrolux	EW1290W	914601687	Electrolux	EW1290W	914601635
Electrolux	EW1290W	914601641	Electrolux	EW1310F	914002298

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Electrolux	EW1400F	914002297	Electrolux	EW1430F	914791147
Electrolux	EW1447W	914602506	Electrolux	EW1447W	914602518
Electrolux	EW1477F	914002716	Electrolux	EW1477F	914512744
Electrolux	EW1480F	914002778	Electrolux	EW1490W	914601632
Electrolux	EW1500F	914002309	Electrolux	EW1677F	914002715
Electrolux	EW1677F	914512724	Electrolux	EW1677F	914512812
Electrolux	EW1680F	914002779	Electrolux	EW550F	914900012
Electrolux	EW550F	914900053	Electrolux	EW560F	914900111
Electrolux	EW560F	914900016	Electrolux	EW560F	914900109
Electrolux	EW647F	914834205	Electrolux	EW647F	914834207
Electrolux	EW660F	914900018	Electrolux	EW670F	914900020
Electrolux	EW670F	914792708	Electrolux	EW770F	914791157
Electrolux	EW847F	914834208	Electrolux	EW847F	914834206
Electrolux	EW876F	914514543	Electrolux	EW880F	914780734
Electrolux	EW880F	914792505	Electrolux	EW880F	914792707

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Electrolux	EW880F	914900021	Electrolux	EW880F	914900054
Electrolux	EWD1300	914601667	Electrolux	EWD1300	914601661
Electrolux	EFW 1180-W	914002346	Electrolux	EFW 1380-W	914002345
Electrolux	EFW 1386-W	914002372	Electrolux	EFW 1580-W	914002343
Electrolux	EFW 1780-W	914002344	Electrolux	EFW1000	914792018
Electrolux	EFW1005	914780918	Electrolux	EFW1005	914780909
Electrolux	EFW1005	914211037	Electrolux	EFW1005	914211101
Electrolux	EFW1010	914792517	Electrolux	EFW1010	914792532
Electrolux	EFW1010	914791189	Electrolux	EFW1020	914780784
Electrolux	EFW1020	914517425	Electrolux	EFW1020	914517203
Electrolux	EFW1020	914517429	Electrolux	EFW1020	914780763
Electrolux	EFW1020	914517221	Electrolux	EFW1025	914517100
Electrolux	EFW1025	914517020	Electrolux	EFW1028	914780824
Electrolux	EFW1028	914780770	Electrolux	EFW1029	914791211
Electrolux	EFW1029	914780819	Electrolux	EFW1029	914791327

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Electrolux	EWF1029	914791159	Electrolux	EWF1030	914517473
Electrolux	EWF1030	914517209	Electrolux	EWF1030	914791212
Electrolux	EWF1030	914780774	Electrolux	EWF1030	914780823
Electrolux	EWF1034	914516313	Electrolux	EWF1035	914517407
Electrolux	EWF1035	914517343	Electrolux	EWF1035	914517018
Electrolux	EWF1035	914517413	Electrolux	EWF1035	914517295
Electrolux	EWF1040	914517712	Electrolux	EWF1040	914517704
Electrolux	EWF1045	914517019	Electrolux	EWF1045	914516309
Electrolux	EWF1045	914517299	Electrolux	EWF1045	914517408
Electrolux	EWF1045S	914517409	Electrolux	EWF1045S	914517047
Electrolux	EWF1050	914517727	Electrolux	EWF1050	914517722
Electrolux	EWF1060	914211100	Electrolux	EWF1060	914780910
Electrolux	EWF1060	914211041	Electrolux	EWF1060	914780919
Electrolux	EWF1080	914002425	Electrolux	EWF1081	914002753
Electrolux	EWF1082	914003351	Electrolux	EWF1084	914900125

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Electrolux	EWF1086	914016014	Electrolux	EWF1086	914003210
Electrolux	EWF1088	914517012	Electrolux	EWF1090	914016097
Electrolux	EWF1090	914901403	Electrolux	EWF1090	914900033
Electrolux	EWF1090	914003350	Electrolux	EWF1090	914524018
Electrolux	EWF1092	914900068	Electrolux	EWF1096	914841815
Electrolux	EWF1098	914900073	Electrolux	EWF1145	914517088
Electrolux	EWF1145	914517046	Electrolux	EWF1182	914016393
Electrolux	EWF1182	914525132	Electrolux	EWF1210	914792518
Electrolux	EWF1210	914791201	Electrolux	EWF12115	914900089
Electrolux	EWF12115	914900056	Electrolux	EWF1215	914791262
Electrolux	EWF1220	914517278	Electrolux	EWF1220	914517215
Electrolux	EWF1220	914517367	Electrolux	EWF1220	914517392
Electrolux	EWF1220	914517275	Electrolux	EWF1220	914517360
Electrolux	EWF1220	914780785	Electrolux	EWF1220	914517273
Electrolux	EWF1220	914780764	Electrolux	EWF1221	914517400

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Electrolux	EWF1221	914517206	Electrolux	EWF1222	914517268
Electrolux	EWF1222	914517427	Electrolux	EWF1225	914517005
Electrolux	EWF1225	914517021	Electrolux	EWF1225	914517369
Electrolux	EWF1225	914517098	Electrolux	EWF1225	914517271
Electrolux	EWF1229	914517349	Electrolux	EWF1229	914517415
Electrolux	EWF1230	914517050	Electrolux	EWF1230	914517053
Electrolux	EWF1230	914791267	Electrolux	EWF1230	914791392
Electrolux	EWF1230	914517363	Electrolux	EWF1230	914517319
Electrolux	EWF1230	914517210	Electrolux	EWF1232	914791196
Electrolux	EWF1234	914516304	Electrolux	EWF1234	914516307
Electrolux	EWF1234	914516314	Electrolux	EWF1234	914516362
Electrolux	EWF1234	914516377	Electrolux	EWF1235	914791197
Electrolux	EWF1235	914791377	Electrolux	EWF1236	914516375
Electrolux	EWF1236	914516338	Electrolux	EWF1240	914517705
Electrolux	EWF1240	914517713	Electrolux	EWF1244	914517371

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Electrolux	EWF1244	914517296	Electrolux	EWF1245	914516310
Electrolux	EWF1245	914517508	Electrolux	EWF1245	914517551
Electrolux	EWF1245	914517500	Electrolux	EWF1245	914517507
Electrolux	EWF1246	914517546	Electrolux	EWF1246	914517540
Electrolux	EWF1249	914517538	Electrolux	EWF1249	914517549
Electrolux	EWF1250	914517724	Electrolux	EWF1250	914517721
Electrolux	EWF1255	914516329	Electrolux	EWF1255	914516346
Electrolux	EWF1268	914517077	Electrolux	EWF1268	914517043
Electrolux	EWF1274	914515047	Electrolux	EWF1280	914016099
Electrolux	EWF1280	914003352	Electrolux	EWF1280	914525133
Electrolux	EWF1284	914003250	Electrolux	EWF1284	914016005
Electrolux	EWF1284	914003005	Electrolux	EWF1284	914016414
Electrolux	EWF1286	914016015	Electrolux	EWF1286	914003211
Electrolux	EWF1287	914517410	Electrolux	EWF1287	914003096
Electrolux	EWF1287	914517305	Electrolux	EWF1288	914517013

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Electrolux	EWF1288	914517081	Electrolux	EWF1289	914517536
Electrolux	EWF1289	914003095	Electrolux	EWF1289	914517545
Electrolux	EWF1295	914517109	Electrolux	EWF1297	914517117
Electrolux	EWF1373	914510705	Electrolux	EWF1387	914525135
Electrolux	EWF1387	914016132	Electrolux	EWF1387	914003389
Electrolux	EWF1410	914517376	Electrolux	EWF1410	914517451
Electrolux	EWF14115	914900088	Electrolux	EWF14115	914900052
Electrolux	EWF14118	914900086	Electrolux	EWF14118	914900050
Electrolux	EWF14118	914900102	Electrolux	EWF1412	914791406
Electrolux	EWF1420	914517276	Electrolux	EWF1420	914517366
Electrolux	EWF1420	914517279	Electrolux	EWF1420	914517361
Electrolux	EWF1420	914517216	Electrolux	EWF1420	914517393
Electrolux	EWF1421	914517207	Electrolux	EWF1422	914517312
Electrolux	EWF1422	914517205	Electrolux	EWF1422	914517428
Electrolux	EWF1423	914517099	Electrolux	EWF1423	914517204

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Electrolux	EWF1423	914517039	Electrolux	EWF1424	914517250
Electrolux	EWF1425	914517011	Electrolux	EWF1425	914517063
Electrolux	EWF1425	914517272	Electrolux	EWF1425	914517095
Electrolux	EWF1425	914517370	Electrolux	EWF1426	914516316
Electrolux	EWF1426	914516364	Electrolux	EWF1427	914517108
Electrolux	EWF1429	914517350	Electrolux	EWF1429	914517416
Electrolux	EWF1430	914517320	Electrolux	EWF1430	914517065
Electrolux	EWF1430	914517051	Electrolux	EWF1430	914517054
Electrolux	EWF1430	914517364	Electrolux	EWF1430	914517317
Electrolux	EWF1430	914517094	Electrolux	EWF1430	914517390
Electrolux	EWF1434	914516315	Electrolux	EWF1434	914516305
Electrolux	EWF1434	914516378	Electrolux	EWF1434	914516363
Electrolux	EWF1434	914516308	Electrolux	EWF1435	914517388
Electrolux	EWF1435	914517057	Electrolux	EWF1436	914516339
Electrolux	EWF1436	914516376	Electrolux	EWF1440	914517530

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Electrolux	EWF1440	914517532	Electrolux	EWF1444	914517372
Electrolux	EWF1444	914517297	Electrolux	EWF1444	914517541
Electrolux	EWF1445	914517501	Electrolux	EWF1445	914517509
Electrolux	EWF1445	914517503	Electrolux	EWF1447	914517534
Electrolux	EWF1447	914517547	Electrolux	EWF1449	914517550
Electrolux	EWF1449	914517539	Electrolux	EWF1455	914516330
Electrolux	EWF1455	914516347	Electrolux	EWF1474	914515048
Electrolux	EWF1480-W	914002553	Electrolux	EWF1481	914003355
Electrolux	EWF1481	914016101	Electrolux	EWF1481	914525207
Electrolux	EWF1484	914003004	Electrolux	EWF1484	914016004
Electrolux	EWF1486	914003212	Electrolux	EWF1486	914016016
Electrolux	EWF1487	914003002	Electrolux	EWF1488	914003193
Electrolux	EWF1488	914016013	Electrolux	EWF1489	914003094
Electrolux	EWF1490	914003354	Electrolux	EWF1490	914016100
Electrolux	EWF1490	914525134	Electrolux	EWF1495	914900030

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Electrolux	EWF1499	914517554	Electrolux	EWF1620	914517280
Electrolux	EWF1620	914517362	Electrolux	EWF1620	914517394
Electrolux	EWF1620	914517277	Electrolux	EWF1621	914517264
Electrolux	EWF1623	914517266	Electrolux	EWF1625	914517096
Electrolux	EWF1625	914517064	Electrolux	EWF1629	914517351
Electrolux	EWF1629	914517417	Electrolux	EWF1630	914517391
Electrolux	EWF1630	914517055	Electrolux	EWF1630	914517321
Electrolux	EWF1630	914517052	Electrolux	EWF1630	914517365
Electrolux	EWF1634	914516306	Electrolux	EWF1636	914516367
Electrolux	EWF1636	914516340	Electrolux	EWF1640	914517803
Electrolux	EWF1640	914516355	Electrolux	EWF1640	914517804
Electrolux	EWF1644	914517298	Electrolux	EWF1644	914517373
Electrolux	EWF1645	914517813	Electrolux	EWF1645	914517526
Electrolux	EWF1645	914517502	Electrolux	EWF1645	914517824
Electrolux	EWF1645	914517817	Electrolux	EWF1645	914517510

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Electrolux	EWF1645	914517814	Electrolux	EWF1646	914517527
Electrolux	EWF1646	914517820	Electrolux	EWF1647	914517801
Electrolux	EWF1647	914517821	Electrolux	EWF1649	914517808
Electrolux	EWF1649	914517822	Electrolux	EWF1649	914517816
Electrolux	EWF1649	914517812	Electrolux	EWF1655	914517815
Electrolux	EWF1655	914517807	Electrolux	EWF1680	914525321
Electrolux	EWF1680	914003356	Electrolux	EWF1680	914016102
Electrolux	EWF1684	914003003	Electrolux	EWF1686	914016017
Electrolux	EWF1686	914003216	Electrolux	EWF1687	914016001
Electrolux	EWF1687	914003001	Electrolux	EWF1688	914016012
Electrolux	EWF1688	914003192	Electrolux	EWF1688	914517014
Electrolux	EWF1689	914003085	Electrolux	EWF1870	914524317
Electrolux	EWF1870	914016370	Electrolux	EWF1880	914524314
Electrolux	EWF1880	914003357	Electrolux	EWF1880	914016103
Electrolux	EWF549	914900060	Electrolux	EWF549	914900134

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Electrolux	EWF549	914900041	Electrolux	EWF551	914900043
Electrolux	EWF551	914900118	Electrolux	EWF551	914900135
Electrolux	EWF551	914900062	Electrolux	EWF600	914780229
Electrolux	EWF630	914791215	Electrolux	EWF668	914791338
Electrolux	EWF668	914791250	Electrolux	EWF672	914900107
Electrolux	EWF695	914841100	Electrolux	EWF734	914516311
Electrolux	EWF735	914791285	Electrolux	EWF735	914517411
Electrolux	EWF735	914517341	Electrolux	EWF771	914900105
Electrolux	EWF800	914792016	Electrolux	EWF800	914792029
Electrolux	EWF800	914792040	Electrolux	EWF805	914281053
Electrolux	EWF805	914780917	Electrolux	EWF805	914281100
Electrolux	EWF805	914780908	Electrolux	EWF810	914791188
Electrolux	EWF820	914780762	Electrolux	EWF820	914780783
Electrolux	EWF830	914791216	Electrolux	EWF830	914517208
Electrolux	EWF831	914285105	Electrolux	EWF831	914285206

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Electrolux	EWF840	914517703	Electrolux	EWF840	914517711
Electrolux	EWF860	914900151	Electrolux	EWF860	914900064
Electrolux	EWF860	914900100	Electrolux	EWF860	914900200
Electrolux	EWF861	914900119	Electrolux	EWF882	914900067
Electrolux	EWF888	914900110	Electrolux	EWF888	914900071
Electrolux	EWF890	914900036	Electrolux	EWF895	914841101
Electrolux	EWF896	914841816	Electrolux	EWF900	914517455
Electrolux	EWF900	914517245	Electrolux	EWF925	914516317
Electrolux	EWF925	914516379	Electrolux	EWF934	914516312
Electrolux	EWF935	914517294	Electrolux	EWF935	914517017
Electrolux	EWF935	914517342	Electrolux	EWF935	914517412
Electrolux	EWF935	914517406	Electrolux	EWF936S	914517414
Electrolux	EWF936S	914517344	Electrolux	EWF984	914900123
Electrolux	EWF984	914900129	Electrolux	EWI1235	914510905
Electrolux	EWI1235	914510929	Electrolux	EWS1000	914756210

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Electrolux	EWS1001	914756225	Electrolux	EWS1001	914756220
Electrolux	EWS1020	914756550	Electrolux	EWS1020	914756501
Electrolux	EWS1020	914756503	Electrolux	EWS1021	914756534
Electrolux	EWS1021	914756521	Electrolux	EWS1030	914756555
Electrolux	EWS1030	914756502	Electrolux	EWS1030	914756551
Electrolux	EWS1045	914512101	Electrolux	EWS1046	914512102
Electrolux	EWS1046	914512110	Electrolux	EWS1050	914901900
Electrolux	EWS1050	914756563	Electrolux	EWS1051	914901700
Electrolux	EWS1200	914756505	Electrolux	EWS1200	914756545
Electrolux	EWS1221	914756535	Electrolux	EWS1221	914756522
Electrolux	EWS1230	914756537	Electrolux	EWS1230	914512209
Electrolux	EWS1230	914756504	Electrolux	EWS1230	914756520
Electrolux	EWS1230	914756552	Electrolux	EWS1240	914756561
Electrolux	EWS1247	914512111	Electrolux	EWS1247	914512109
Electrolux	EWS1250	914901901	Electrolux	EWS1250	914756564

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Electrolux	EWS1251	914901701	Electrolux	EWS646F	914756212
Electrolux	EWS646F	914756226	Electrolux	EWS800	914756517
Electrolux	EWS800	914756549	Electrolux	EWS845	914756705
Electrolux	EWV1000	914601128	Electrolux	EWV1000	914601106
Electrolux	EWV1210	914601629	Electrolux	EWV1210	914601678
Electrolux	EWV1230I	914601912	Electrolux	EWV1290	914603303
Electrolux	EWV1290	914603306	Electrolux	EWV1292	914603107
Electrolux	EWV1292	914603109	Electrolux	EWV1400	914601682
Electrolux	EWV1400	914601628	Electrolux	EWV1440	914601650
Electrolux	EWV1440	914601665	Electrolux	EWV1495	914601686
Electrolux	EWV1649	914601624	Electrolux	EWV1649	914601685
Electrolux	EWV1690	914603104	Electrolux	EWX1237	914601228
Electrolux	EWX1237	914601229	Electrolux	EWX1237	914601216
Electrolux	EWX1237	914601204	Electrolux	F1025	914791202
Electrolux	F1215	914791232	Electrolux	F1225	914791121

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Electrolux	F1225	914791203	Electrolux	F1247	914791382
Electrolux	F1415	914791233	Electrolux	F1425	914791204
Electrolux	F1425	914791122	Electrolux	F900	914791343
Electrolux	FA1026HDRO	914211040	Electrolux	FAE1025V	914211044
Electrolux	FAE1026V	914205110	Electrolux	FAE1026V	914205201
Electrolux	FD1026	914516008	Electrolux	FD1216	914515051
Electrolux	FD1226	914516009	Electrolux	FD1226	914517235
Electrolux	FD1416	914515052	Electrolux	FD1426	914516010
Electrolux	FD1426	914517236	Electrolux	FD1616	914515053
Electrolux	FD1626	914517237	Electrolux	FD1626	914516011
Electrolux	FE1024N	914756511	Electrolux	FE1614	914515054
Electrolux	FE925N	914756510	Electrolux	FXC1206	914792730
Electrolux	FXC1206	914792718	Electrolux	FXC1206	914792711
Electrolux	FXC1406	914792712	Electrolux	JWT8013	914601913
Electrolux	JWT8014	914601220	Electrolux	JWV7813	914510115

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Electrolux	JWV7814	914510919	Electrolux	JWV7814	914510904
Electrolux	L 6415	914903101	Electrolux	L1045EL	914756526
Electrolux	L1045EL	914756558	Electrolux	L1046EL	914756528
Electrolux	L1046EL	914756532	Electrolux	L1049	914756531
Electrolux	L1049	914756538	Electrolux	L10500VI	914510118
Electrolux	L10500VI	914510906	Electrolux	L1060EL	914515251
Electrolux	L1070EL	914756569	Electrolux	L1245EL	914756536
Electrolux	L1245EL	914756527	Electrolux	L1246EL	914756533
Electrolux	L1246EL	914756529	Electrolux	L1249	914756562
Electrolux	L1249	914756539	Electrolux	L1249	914756530
Electrolux	L12500VI	914510119	Electrolux	L12500VI	914510123
Electrolux	L12500VI	914510120	Electrolux	L12500VI	914510908
Electrolux	L12510VI	914510920	Electrolux	L12510VI	914510907
Electrolux	L1260EL	914515252	Electrolux	L12620	914601121
Electrolux	L12620	914601656	Electrolux	L12620	914653326

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Electrolux	L12620	914653336	Electrolux	L12620	914601679
Electrolux	L12620	914601112	Electrolux	L12620	914653329
Electrolux	L12700VIT	914601212	Electrolux	L12700VIT	914601916
Electrolux	L12700VIT	914601919	Electrolux	L12700VIT	914601915
Electrolux	L12700VIT	914601914	Electrolux	L12710VIT	914601227
Electrolux	L1271EL	914756902	Electrolux	L12720	914601688
Electrolux	L12720VIT	914601225	Electrolux	L12720VIT	914601208
Electrolux	L12810VI	914510927	Electrolux	L12810VI	914510913
Electrolux	L14510VI	914510915	Electrolux	L14510VI	914510924
Electrolux	L14510VI	914510925	Electrolux	L14510VI	914510914
Electrolux	L14710VIT	914601211	Electrolux	L14710VIT	914601215
Electrolux	L14710VIT	914601230	Electrolux	L14710VIT	914601219
Electrolux	L14720	914601655	Electrolux	L14720	914601664
Electrolux	L14720	914601673	Electrolux	L14720	914601653
Electrolux	L14720	914601654	Electrolux	L14800VI	914511104

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Electrolux	L14800VIT	914601233	Electrolux	L14820	914601657
Electrolux	L14820	914601680	Electrolux	L16820	914602116
Electrolux	L16820	914602117	Electrolux	L16820	914602121
Electrolux	L16820	914602106	Electrolux	L16820	914602135
Electrolux	L16820	914602112	Electrolux	L16820	914602128
Electrolux	L16820	914602133	Electrolux	L16820	914602107
Electrolux	L16820	914602132	Electrolux	L16820	914602127
Electrolux	L16820	914602130	Electrolux	L16820	914602131
Electrolux	L16820	914602126	Electrolux	L16820	914602108
Electrolux	L16820	914602109	Electrolux	L16820	914602110
Electrolux	L16825	914602134	Electrolux	L16866	914602703
Electrolux	L16866	914602702	Electrolux	L5011	914841808
Electrolux	L5011	914841803	Electrolux	L5011	914841800
Electrolux	L5016	914841813	Electrolux	L5019	914524008
Electrolux	L5019	914524007	Electrolux	L50210	914524041

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Electrolux	L50212	914524033	Electrolux	L50212	914524000
Electrolux	L50610	914524047	Electrolux	L50612	914524034
Electrolux	L50612	914524001	Electrolux	L508	914520206
Electrolux	L50800	914524037	Electrolux	L50820	914841807
Electrolux	L510	914520207	Electrolux	L512S	914780241
Electrolux	L516S	914780236	Electrolux	L5211	914515221
Electrolux	L5212	914841809	Electrolux	L5212	914841804
Electrolux	L5212	914841801	Electrolux	L5214	914524023
Electrolux	L52400	914524048	Electrolux	L52400	914903002
Electrolux	L52408	914903008	Electrolux	L52600	914524002
Electrolux	L52600	914903011	Electrolux	L52608	914524030
Electrolux	L52609	914524010	Electrolux	L52610	914524050
Electrolux	L52610	914903004	Electrolux	L52610	914903006
Electrolux	L52612	914524035	Electrolux	L52612	914524004
Electrolux	L52810	914524025	Electrolux	L52810	914524039

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Electrolux	L52810	914841900	Electrolux	L52820	914525002
Electrolux	L53600	914515244	Electrolux	L53600	914515225
Electrolux	L53601	914524031	Electrolux	L54106	914524046
Electrolux	L5411	914515222	Electrolux	L5412	914841802
Electrolux	L5412	914841805	Electrolux	L54400	914903003
Electrolux	L54400	914524049	Electrolux	L54408	914903009
Electrolux	L54600	914903012	Electrolux	L54600	914524003
Electrolux	L54600	914524019	Electrolux	L54609	914524020
Electrolux	L54610	914903005	Electrolux	L54610	914524051
Electrolux	L54610	914903007	Electrolux	L54619	914903010
Electrolux	L54811	914524021	Electrolux	L58210	914841810
Electrolux	L58212	914841812	Electrolux	L58213	914841811
Electrolux	L58220	914524011	Electrolux	L58222	914524012
Electrolux	L58223	914524013	Electrolux	L58820	914525000
Electrolux	L58828	914525001	Electrolux	L60210	914525164

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Electrolux	L60610	914524107	Electrolux	L60610	914903103
Electrolux	L60610	914515058	Electrolux	L60800	914515258
Electrolux	L60800	914515250	Electrolux	L60805	914524145
Electrolux	L60810	914525163	Electrolux	L60810	914525165
Electrolux	L60820	914525158	Electrolux	L60822	914515228
Electrolux	L60822	914515242	Electrolux	L60824	914525149
Electrolux	L60825	914524156	Electrolux	L60827	914525151
Electrolux	L60828	914525152	Electrolux	L60829	914525122
Electrolux	L60829	914525123	Electrolux	L60890	914515240
Electrolux	L60890	914515226	Electrolux	L60895	914524154
Electrolux	L60900	914524160	Electrolux	L61825	914525153
Electrolux	L6215	914903100	Electrolux	L62605	914524159
Electrolux	L62610	914903104	Electrolux	L62610	914524108
Electrolux	L62610	914903108	Electrolux	L62610	914903128
Electrolux	L62680	914515260	Electrolux	L62800	914903144

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Electrolux	L62800	914524128	Electrolux	L62806	914524131
Electrolux	L62806	914903145	Electrolux	L62809	914903146
Electrolux	L62809	914524139	Electrolux	L62810	914524114
Electrolux	L62810	914525111	Electrolux	L62810	914524137
Electrolux	L62810	914525166	Electrolux	L62812	914525128
Electrolux	L62820	914903130	Electrolux	L62822	914515229
Electrolux	L62822	914515243	Electrolux	L62825	914524146
Electrolux	L62828	914525154	Electrolux	L62890	914515227
Electrolux	L62890	914515235	Electrolux	L62890	914515241
Electrolux	L62890	914515230	Electrolux	L62895	914524155
Electrolux	L63600	914903141	Electrolux	L63600	914524134
Electrolux	L63800	914524142	Electrolux	L63803	914903142
Electrolux	L63803	914524135	Electrolux	L63805	914903143
Electrolux	L63805	914524136	Electrolux	L63812	914524123
Electrolux	L63813	914524106	Electrolux	L63815	914524112

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Electrolux	L63815	914524105	Electrolux	L6415	914903101
Electrolux	L6415	914524162	Electrolux	L6420	914903126
Electrolux	L64540	914515236	Electrolux	L64540	914515232
Electrolux	L64560	914515249	Electrolux	L64560	914515219
Electrolux	L6460	914903127	Electrolux	L64600	914903109
Electrolux	L64600	914524110	Electrolux	L64606	914524151
Electrolux	L64610	914903110	Electrolux	L64617	914903114
Electrolux	L64618	914903112	Electrolux	L64619	914903113
Electrolux	L6461EX	914903116	Electrolux	L64620	914903132
Electrolux	L6465N	914903118	Electrolux	L6466N	914903120
Electrolux	L64680	914515259	Electrolux	L6480	914524152
Electrolux	L64800	914525100	Electrolux	L64800	914903300
Electrolux	L64806	914525101	Electrolux	L64806	914903301
Electrolux	L64810	914524116	Electrolux	L64810	914525145
Electrolux	L64810	914524124	Electrolux	L64811	914524117

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Electrolux	L64819	914525117	Electrolux	L64819	914525121
Electrolux	L64819	914525118	Electrolux	L64820	914903133
Electrolux	L64822	914525155	Electrolux	L64823	914525156
Electrolux	L65800	914524153	Electrolux	L65825	914525157
Electrolux	L6615	914903102	Electrolux	L66560	914515220
Electrolux	L66561	914515233	Electrolux	L66561	914515237
Electrolux	L66610	914903105	Electrolux	L66610	914903111
Electrolux	L66617	914903115	Electrolux	L6661EX	914524163
Electrolux	L6661EX	914903117	Electrolux	L66680	914515261
Electrolux	L66800	914524130	Electrolux	L66800	914903147
Electrolux	L66811	914524118	Electrolux	L66815	914524308
Electrolux	L66820	914903134	Electrolux	L70786VT	914510309
Electrolux	L70786VT	914510307	Electrolux	L70810	914525167
Electrolux	L70810	914525124	Electrolux	L72600	914524147
Electrolux	L72610	914903106	Electrolux	L72766VT	914510306

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Electrolux	L72766VT	914510311	Electrolux	L72786VT	914510308
Electrolux	L72786VT	914510310	Electrolux	L72800	914903148
Electrolux	L72800	914524120	Electrolux	L72805	914524102
Electrolux	L72805	914515253	Electrolux	L72810	914525168
Electrolux	L72810	914525125	Electrolux	L72810	914903139
Electrolux	L72812	914524100	Electrolux	L72815 VERS.SILVER	914525170
Electrolux	L72815 VERS.WHITE	914525170	Electrolux	L72818	914903302
Electrolux	L72818	914525140	Electrolux	L72880	914525161
Electrolux	L72900	914526312	Electrolux	L74600	914903119
Electrolux	L74800	914525148	Electrolux	L74800	914524121
Electrolux	L74800	914903149	Electrolux	L74803	914903150
Electrolux	L74803	914524125	Electrolux	L7481	914903153
Electrolux	L74810	914525126	Electrolux	L74810	914525146
Electrolux	L74810	914525162	Electrolux	L74810	914525137
Electrolux	L74810	914525108	Electrolux	L74810	914525112

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Electrolux	L74810	914525138	Electrolux	L74810	914903121
Electrolux	L74810SPOR	914524164	Electrolux	L74810SPOR	914903123
Electrolux	L74812	914524101	Electrolux	L74812	914524144
Electrolux	L74818	914903303	Electrolux	L74818	914525141
Electrolux	L74819	914525139	Electrolux	L74819	914525119
Electrolux	L74819	914903304	Electrolux	L74819	914525109
Electrolux	L74819	914903124	Electrolux	L74820	914525106
Electrolux	L74825	914525147	Electrolux	L74900	914526301
Electrolux	L74900	914526304	Electrolux	L74900	914526306
Electrolux	L74900	914526305	Electrolux	L74900	914526310
Electrolux	L74900	914526303	Electrolux	L74900	914526309
Electrolux	L74900	914526300	Electrolux	L74900	914526302
Electrolux	L74900	914526308	Electrolux	L75605	914524143
Electrolux	L75805	914903151	Electrolux	L75805	914525113
Electrolux	L75805	914525144	Electrolux	L75805	914524126

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Electrolux	L75817	914525324	Electrolux	L7680	914903138
Electrolux	L76800	914524309	Electrolux	L76810	914525302
Electrolux	L76810	914903122	Electrolux	L76810	914525304
Electrolux	L76811	914525328	Electrolux	L76815	914525325
Electrolux	L76815	914525326	Electrolux	L76818	914525316
Electrolux	L76819	914525303	Electrolux	L76819	914903125
Electrolux	L76819	914525315	Electrolux	L76820	914525327
Electrolux	L76820	914525107	Electrolux	L76820	914525318
Electrolux	L76830	914525337	Electrolux	L76840	914525338
Electrolux	L76850	914525339	Electrolux	L76880	914525333
Electrolux	L76910	914524304	Electrolux	L84810	914525204
Electrolux	L84810	914525209	Electrolux	L84810	914525208
Electrolux	L84812	914525200	Electrolux	L84820	914525202
Electrolux	L86810	914525347	Electrolux	L86810	914525305
Electrolux	L86812	914525308	Electrolux	L86818	914525348

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Electrolux	L86820	914525317	Electrolux	L86820	914525345
Electrolux	L86820	914525203	Electrolux	L86820	914525336
Electrolux	L86820	914525322	Electrolux	L86820	914525340
Electrolux	L88810	914524322	Electrolux	L88810	914524324
Electrolux	L88810	914524318	Electrolux	L88820	914524315
Electrolux	L88820	914524316	Electrolux	LAV50210	914016271
Electrolux	LAV50210	914003532	Electrolux	LAV50212	914003523
Electrolux	LAV50212	914016262	Electrolux	LAV50600	914003314
Electrolux	LAV50600	914003628	Electrolux	LAV50600	914016160
Electrolux	LAV50600	914016357	Electrolux	LAV50600	914003420
Electrolux	LAV50610	914003447	Electrolux	LAV50610	914016187
Electrolux	LAV50610	914016203	Electrolux	LAV50610	914003463
Electrolux	LAV50612	914016261	Electrolux	LAV50612	914003522
Electrolux	LAV50800	914016391	Electrolux	LAV50800	914003421
Electrolux	LAV50810	914003508	Electrolux	LAV50810	914016247

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Electrolux	LAV50900	914003557	Electrolux	LAV50900	914016296
Electrolux	LAV51900	914003558	Electrolux	LAV51900	914016297
Electrolux	LAV5210	914003296	Electrolux	LAV5210	914016055
Electrolux	LAV5210	914003297	Electrolux	LAV5210	914016054
Electrolux	LAV5220	914003320	Electrolux	LAV52600	914003422
Electrolux	LAV52600	914003265	Electrolux	LAV52600	914003379
Electrolux	LAV52600	914003313	Electrolux	LAV52600	914016122
Electrolux	LAV52600	914016162	Electrolux	LAV52600	914016037
Electrolux	LAV52608	914016136	Electrolux	LAV52608	914016040
Electrolux	LAV52608	914003396	Electrolux	LAV52608	914003276
Electrolux	LAV52610	914003448	Electrolux	LAV52610	914016397
Electrolux	LAV52610	914016204	Electrolux	LAV52610	914003464
Electrolux	LAV52612	914016263	Electrolux	LAV52612	914003524
Electrolux	LAV52680	914003223	Electrolux	LAV52680	914016019
Electrolux	LAV52800	914016169	Electrolux	LAV52800	914003429

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Electrolux	LAV52810	914003618	Electrolux	LAV52810	914016362
Electrolux	LAV52810	914016337	Electrolux	LAV52810	914003603
Electrolux	LAV52810	914016354	Electrolux	LAV52820	914003252
Electrolux	LAV52820	914016024	Electrolux	LAV52900	914003556
Electrolux	LAV52900	914016295	Electrolux	LAV53601	914016152
Electrolux	LAV53601	914003412	Electrolux	LAV53900	914016298
Electrolux	LAV53900	914003559	Electrolux	LAV5410	914016052
Electrolux	LAV5410	914003293	Electrolux	LAV5410	914003292
Electrolux	LAV5410	914016051	Electrolux	LAV5420	914016073
Electrolux	LAV5420	914003321	Electrolux	LAV54400	914003507
Electrolux	LAV5450	914016408	Electrolux	LAV5460	914016383
Electrolux	LAV54600	914016153	Electrolux	LAV54600	914003413
Electrolux	LAV54600	914016036	Electrolux	LAV54600	914003311
Electrolux	LAV54600	914016121	Electrolux	LAV54600	914003264
Electrolux	LAV54600	914003378	Electrolux	LAV54608	914003283

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Electrolux	LAV54608	914016043	Electrolux	LAV54609	914016044
Electrolux	LAV54609	914003284	Electrolux	LAV54609	914016146
Electrolux	LAV54609	914003406	Electrolux	LAV54610	914016404
Electrolux	LAV54610	914003465	Electrolux	LAV54610	914016205
Electrolux	LAV54680	914003222	Electrolux	LAV54680	914016018
Electrolux	LAV54800	914003428	Electrolux	LAV54800	914016168
Electrolux	LAV54810	914003604	Electrolux	LAV54810	914016338
Electrolux	LAV58200	914003487	Electrolux	LAV58200	914016226
Electrolux	LAV58202	914016227	Electrolux	LAV58202	914003488
Electrolux	LAV58203	914003497	Electrolux	LAV58203	914016236
Electrolux	LAV58600	914003419	Electrolux	LAV58800	914016225
Electrolux	LAV58800	914016390	Electrolux	LAV58800	914003486
Electrolux	LAV58808	914003485	Electrolux	LAV58808	914016224
Electrolux	LAV60210	914003531	Electrolux	LAV60210	914016270
Electrolux	LAV60600	914003457	Electrolux	LAV60610	914016398

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Electrolux	LAV60610	914003446	Electrolux	LAV60610	914016186
Electrolux	LAV60800	914016388	Electrolux	LAV60800	914003423
Electrolux	LAV60800	914016223	Electrolux	LAV60800	914003483
Electrolux	LAV60804	914003480	Electrolux	LAV60804	914016220
Electrolux	LAV60806	914003575	Electrolux	LAV60807	914003482
Electrolux	LAV60807	914016222	Electrolux	LAV60809	914003481
Electrolux	LAV60809	914016221	Electrolux	LAV60810	914003530
Electrolux	LAV60810	914003590	Electrolux	LAV60810	914003506
Electrolux	LAV60810	914016324	Electrolux	LAV60810	914016245
Electrolux	LAV60810	914016269	Electrolux	LAV60814	914003591
Electrolux	LAV60814	914016325	Electrolux	LAV60816	914016351
Electrolux	LAV60816	914003615	Electrolux	LAV60817	914003593
Electrolux	LAV60817	914016327	Electrolux	LAV60819	914016326
Electrolux	LAV60819	914003592	Electrolux	LAV60900	914003562
Electrolux	LAV60900	914016301	Electrolux	LAV61805	914003479

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Electrolux	LAV61815	914003595	Electrolux	LAV61815	914016329
Electrolux	LAV61900	914003563	Electrolux	LAV61900	914016302
Electrolux	LAV6240	914003312	Electrolux	LAV62600	914003456
Electrolux	LAV62605	914003439	Electrolux	LAV62605	914016179
Electrolux	LAV62610	914003399	Electrolux	LAV62610	914016191
Electrolux	LAV62610	914016124	Electrolux	LAV62610	914016399
Electrolux	LAV62610	914016139	Electrolux	LAV62610	914003381
Electrolux	LAV62610	914003451	Electrolux	LAV62800	914003424
Electrolux	LAV62800	914016358	Electrolux	LAV62800	914016413
Electrolux	LAV62800	914003310	Electrolux	LAV62800	914003627
Electrolux	LAV62800	914016389	Electrolux	LAV62800	914016035
Electrolux	LAV62800	914003263	Electrolux	LAV62806	914003346
Electrolux	LAV62806	914016093	Electrolux	LAV62808	914016218
Electrolux	LAV62808	914003478	Electrolux	LAV62809	914016231
Electrolux	LAV62809	914003492	Electrolux	LAV62810	914003505

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Electrolux	LAV62810	914016345	Electrolux	LAV62810	914003397
Electrolux	LAV62810	914003611	Electrolux	LAV62810	914003529
Electrolux	LAV62810	914003466	Electrolux	LAV62810	914003580
Electrolux	LAV62810	914016268	Electrolux	LAV62810	914016206
Electrolux	LAV62810	914016244	Electrolux	LAV62810	914003577
Electrolux	LAV62810	914016315	Electrolux	LAV62810	914016137
Electrolux	LAV62818	914016323	Electrolux	LAV62818	914003589
Electrolux	LAV62900	914003561	Electrolux	LAV62900	914016300
Electrolux	LAV63600	914003316	Electrolux	LAV63600	914016085
Electrolux	LAV63600	914003337	Electrolux	LAV63600	914016071
Electrolux	LAV63610	914003402	Electrolux	LAV63610	914016142
Electrolux	LAV63613	914016249	Electrolux	LAV63613	914003510
Electrolux	LAV63800	914016416	Electrolux	LAV63805	914016310
Electrolux	LAV63805	914003573	Electrolux	LAV63815	914003373
Electrolux	LAV63815	914016116	Electrolux	LAV63819	914003371

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Electrolux	LAV63900	914016299	Electrolux	LAV63900	914003560
Electrolux	LAV6410	914016057	Electrolux	LAV6410	914003299
Electrolux	LAV6420	914003298	Electrolux	LAV6420	914016056
Electrolux	LAV6440	914003309	Electrolux	LAV6440	914016064
Electrolux	LAV6460	914016285	Electrolux	LAV6460	914003546
Electrolux	LAV64600	914003253	Electrolux	LAV64600	914003583
Electrolux	LAV64600	914016025	Electrolux	LAV64600	914016317
Electrolux	LAV64606	914003489	Electrolux	LAV64606	914016228
Electrolux	LAV64608	914003281	Electrolux	LAV64608	914016042
Electrolux	LAV64610	914003469	Electrolux	LAV64610	914016131
Electrolux	LAV64610	914016141	Electrolux	LAV64610	914016209
Electrolux	LAV64610	914003401	Electrolux	LAV64610	914003388
Electrolux	LAV64617	914003387	Electrolux	LAV64617	914016130
Electrolux	LAV64618	914003384	Electrolux	LAV64618	914016127
Electrolux	LAV64619	914003385	Electrolux	LAV64619	914016128

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Electrolux	LAV6461EX	914003383	Electrolux	LAV6461EX	914016126
Electrolux	LAV6465N	914003440	Electrolux	LAV6465N	914003362
Electrolux	LAV6465N	914016180	Electrolux	LAV64680	914003230
Electrolux	LAV64680	914016022	Electrolux	LAV6480	914016384
Electrolux	LAV6480	914016407	Electrolux	LAV64800	914003262
Electrolux	LAV64800	914016034	Electrolux	LAV64800	914003308
Electrolux	LAV64802	914003475	Electrolux	LAV64802	914016215
Electrolux	LAV64803	914003476	Electrolux	LAV64803	914016216
Electrolux	LAV64806	914016092	Electrolux	LAV64806	914003345
Electrolux	LAV64810	914016412	Electrolux	LAV64810	914016207
Electrolux	LAV64810	914003394	Electrolux	LAV64810	914003602
Electrolux	LAV64810	914003467	Electrolux	LAV64810	914016336
Electrolux	LAV64810	914016353	Electrolux	LAV64810	914003617
Electrolux	LAV64810	914016134	Electrolux	LAV64812	914016322
Electrolux	LAV64812	914003588	Electrolux	LAV64813	914003587

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Electrolux	LAV64813	914016321	Electrolux	LAV64819	914016115
Electrolux	LAV64819	914003372	Electrolux	LAV65600	914016070
Electrolux	LAV65600	914003315	Electrolux	LAV65800	914016415
Electrolux	LAV65805	914003477	Electrolux	LAV65805	914016217
Electrolux	LAV65813	914003509	Electrolux	LAV65813	914016248
Electrolux	LAV65815	914003594	Electrolux	LAV65815	914016328
Electrolux	LAV6610	914003279	Electrolux	LAV6610	914016041
Electrolux	LAV66600	914016229	Electrolux	LAV66600	914003455
Electrolux	LAV66600	914003490	Electrolux	LAV66610	914016400
Electrolux	LAV66610	914003442	Electrolux	LAV66610	914003382
Electrolux	LAV66610	914016125	Electrolux	LAV66617	914003386
Electrolux	LAV66617	914016129	Electrolux	LAV6661EX	914003380
Electrolux	LAV6661EX	914016123	Electrolux	LAV66680	914003229
Electrolux	LAV66800	914003340	Electrolux	LAV66800	914016088
Electrolux	LAV66800	914003336	Electrolux	LAV66810	914016208

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Electrolux	LAV66810	914016334	Electrolux	LAV66810	914003398
Electrolux	LAV66810	914016138	Electrolux	LAV66810	914003468
Electrolux	LAV66810	914003600	Electrolux	LAV66813	914016352
Electrolux	LAV66813	914003616	Electrolux	LAV66815	914016135
Electrolux	LAV66815	914003395	Electrolux	LAV66819	914003400
Electrolux	LAV66819	914016140	Electrolux	LAV70800	914003454
Electrolux	LAV70800	914003426	Electrolux	LAV70800	914016166
Electrolux	LAV70800	914016194	Electrolux	LAV70810	914003564
Electrolux	LAV70810	914016303	Electrolux	LAV70810	914003528
Electrolux	LAV70810	914016267	Electrolux	LAV72600	914016154
Electrolux	LAV72600	914003414	Electrolux	LAV72800	914003261
Electrolux	LAV72800	914003427	Electrolux	LAV72800	914003307
Electrolux	LAV72800	914003472	Electrolux	LAV72800	914016033
Electrolux	LAV72800	914016212	Electrolux	LAV72805	914016392
Electrolux	LAV72808	914003349	Electrolux	LAV72810	914003565

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Electrolux	LAV72810	914003584	Electrolux	LAV72810	914016304
Electrolux	LAV72810	914016266	Electrolux	LAV72810	914016318
Electrolux	LAV72810	914016355	Electrolux	LAV72810	914003527
Electrolux	LAV72810	914003622	Electrolux	LAV72812	914016260
Electrolux	LAV72812	914003521	Electrolux	LAV72818	914003513
Electrolux	LAV72818	914016252	Electrolux	LAV72880	914003361
Electrolux	LAV72880	914016106	Electrolux	LAV74600	914016038
Electrolux	LAV74600	914003274	Electrolux	LAV74610	914016185
Electrolux	LAV74610	914003445	Electrolux	LAV74800	914003260
Electrolux	LAV74800	914003370	Electrolux	LAV74800	914016114
Electrolux	LAV74800	914003453	Electrolux	LAV74800	914003620
Electrolux	LAV74800	914016165	Electrolux	LAV74800	914016306
Electrolux	LAV74800	914016151	Electrolux	LAV74800	914016214
Electrolux	LAV74800	914003306	Electrolux	LAV74800	914003411
Electrolux	LAV74800	914016359	Electrolux	LAV74800	914016032

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Electrolux	LAV74800	914003568	Electrolux	LAV74800	914003474
Electrolux	LAV74800	914003425	Electrolux	LAV74803	914016181
Electrolux	LAV74803	914003441	Electrolux	LAV74808	914003348
Electrolux	LAV74809	914003342	Electrolux	LAV74810	914016290
Electrolux	LAV74810	914003461	Electrolux	LAV74810	914003576
Electrolux	LAV74810	914016201	Electrolux	LAV74810	914016403
Electrolux	LAV74810	914003551	Electrolux	LAV74810	914016314
Electrolux	LAV74810	914003502	Electrolux	LAV74810	914003585
Electrolux	LAV74810	914003374	Electrolux	LAV74810	914016117
Electrolux	LAV74810	914016241	Electrolux	LAV74810	914016333
Electrolux	LAV74810	914003567	Electrolux	LAV74810	914016305
Electrolux	LAV74810	914016319	Electrolux	LAV74810	914003579
Electrolux	LAV74810	914003599	Electrolux	LAV74810SPOR T	914016316
Electrolux	LAV74810SPORT	914003582	Electrolux	LAV74812	914003520
Electrolux	LAV74812	914016259	Electrolux	LAV74815	914016410

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Electrolux	LAV74818	914016251	Electrolux	LAV74818	914003512
Electrolux	LAV74819	914016387	Electrolux	LAV74819	914003511
Electrolux	LAV74819	914016250	Electrolux	LAV74820	914003491
Electrolux	LAV74820	914016230	Electrolux	LAV74825	914016417
Electrolux	LAV74880	914003228	Electrolux	LAV74880	914016365
Electrolux	LAV74880	914003391	Electrolux	LAV74900	914003555
Electrolux	LAV74900	914016294	Electrolux	LAV75605	914003612
Electrolux	LAV75605	914016346	Electrolux	LAV75805	914003501
Electrolux	LAV75805	914016309	Electrolux	LAV75805	914016240
Electrolux	LAV75805	914003572	Electrolux	LAV75807	914003410
Electrolux	LAV75807	914016150	Electrolux	LAV75817	914016291
Electrolux	LAV75817	914003552	Electrolux	LAV76600	914003275
Electrolux	LAV76600	914016039	Electrolux	LAV7680	914016385
Electrolux	LAV76800	914003409	Electrolux	LAV76800	914016149
Electrolux	LAV76800	914003259	Electrolux	LAV76800	914016031

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Electrolux	LAV76800	914003322	Electrolux	LAV76808	914003347
Electrolux	LAV76809	914003341	Electrolux	LAV76810	914003548
Electrolux	LAV76810	914003500	Electrolux	LAV76810	914016287
Electrolux	LAV76810	914016239	Electrolux	LAV76810	914016363
Electrolux	LAV76810	914003375	Electrolux	LAV76810	914016118
Electrolux	LAV76810	914003462	Electrolux	LAV76810	914016405
Electrolux	LAV76810	914016335	Electrolux	LAV76810	914003601
Electrolux	LAV76810	914016202	Electrolux	LAV76815	914016409
Electrolux	LAV76818	914016253	Electrolux	LAV76818	914003514
Electrolux	LAV76819	914003515	Electrolux	LAV76819	914003376
Electrolux	LAV76819	914016386	Electrolux	LAV76819	914016119
Electrolux	LAV76819	914016254	Electrolux	LAV76820	914016394
Electrolux	LAV7685M	914003294	Electrolux	LAV7685M	914016053
Electrolux	LAV76880	914016349	Electrolux	LAV76880	914003581
Electrolux	LAV76910	914016418	Electrolux	LAV76910	914016406

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Electrolux	LAV78800	914003305	Electrolux	LAV78810	914003377
Electrolux	LAV78810	914016120	Electrolux	LAV82810	914016158
Electrolux	LAV82810	914003418	Electrolux	LAV84610	914003443
Electrolux	LAV84610	914016183	Electrolux	LAV84810	914016030
Electrolux	LAV84810	914016265	Electrolux	LAV84810	914003324
Electrolux	LAV84810	914003526	Electrolux	LAV84810	914016242
Electrolux	LAV84810	914016155	Electrolux	LAV84810	914003289
Electrolux	LAV84810	914003415	Electrolux	LAV84810	914003258
Electrolux	LAV84810	914003503	Electrolux	LAV84812	914016258
Electrolux	LAV84812	914003519	Electrolux	LAV84820	914003598
Electrolux	LAV84820	914016332	Electrolux	LAV84820	914016366
Electrolux	LAV85805	914003504	Electrolux	LAV85805	914016243
Electrolux	LAV86800	914016360	Electrolux	LAV86800	914016213
Electrolux	LAV86800	914003625	Electrolux	LAV86800	914003473
Electrolux	LAV86810	914016320	Electrolux	LAV86810	914016364

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Electrolux	LAV86810	914003257	Electrolux	LAV86810	914003304
Electrolux	LAV86810	914016029	Electrolux	LAV86810	914003499
Electrolux	LAV86810	914016238	Electrolux	LAV86810	914003408
Electrolux	LAV86810	914003586	Electrolux	LAV86810	914003460
Electrolux	LAV86810	914016200	Electrolux	LAV86810	914003535
Electrolux	LAV86810	914016274	Electrolux	LAV86810	914003287
Electrolux	LAV86810	914016148	Electrolux	LAV86812	914003518
Electrolux	LAV86812	914016257	Electrolux	LAV86818	914016086
Electrolux	LAV86818	914003338	Electrolux	LAV86819	914003286
Electrolux	LAV86820	914003597	Electrolux	LAV86820	914016368
Electrolux	LAV86820	914003553	Electrolux	LAV86820	914016292
Electrolux	LAV86820	914016331	Electrolux	LAV86829	914016367
Electrolux	LAV88810	914016113	Electrolux	LAV88810	914016156
Electrolux	LAV88810	914003416	Electrolux	LAV88810	914016028
Electrolux	LAV88810	914016157	Electrolux	LAV88810	914003256

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Electrolux	LAV88810	914003404	Electrolux	LAV88810	914016147
Electrolux	LAV88810	914003369	Electrolux	LAV88810	914003525
Electrolux	LAV88810	914016075	Electrolux	LAV88810	914016144
Electrolux	LAV88810	914003407	Electrolux	LAV88810	914003417
Electrolux	LAV88810	914003323	Electrolux	LAV88810	914016264
Electrolux	LAV88819	914003405	Electrolux	LAV88819	914016145
Electrolux	LAV88820	914003554	Electrolux	LAV88820	914016293
Electrolux	LAV88820	914003549	Electrolux	LAV88820	914016288
Electrolux	LAV88829	914016289	Electrolux	LAV88829	914003550
Electrolux	LAVALOGIC1420	914016189	Electrolux	LAVALOGIC1420	914003288
Electrolux	LAVALOGIC1420	914003449	Electrolux	LAVALOGIC1420	914016048
Electrolux	LAVALOGIC1600	914015016	Electrolux	LAVALOGIC1600	914002797
Electrolux	LAVALOGIC1620	914016170	Electrolux	LAVALOGIC1620	914016396
Electrolux	LAVALOGIC1620	914003403	Electrolux	LAVALOGIC1620	914016348

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Electrolux	LAVALOGIC1620	914003255	Electrolux	LAVALOGIC1620	914003368
Electrolux	LAVALOGIC1620	914003626	Electrolux	LAVALOGIC1620	914003578
Electrolux	LAVALOGIC1620	914016027	Electrolux	LAVALOGIC1620	914016143
Electrolux	LAVALOGIC1620	914003303	Electrolux	LAVALOGIC1620	914003430
Electrolux	LAVALOGIC1620	914016045	Electrolux	LAVALOGIC1620	914003285
Electrolux	LAVALOGIC1620	914003450	Electrolux	LAVALOGIC1620	914003498
Electrolux	LAVALOGIC1620	914016112	Electrolux	LAVALOGIC1620	914016237
Electrolux	LAVALOGIC1620	914016361	Electrolux	LAVALOGIC1630	914003547
Electrolux	LAVALOGIC1630	914016286	Electrolux	LAVALOGIC1820	914016026
Electrolux	LAVALOGIC1820	914016395	Electrolux	LAVALOGIC1820	914003254
Electrolux	LAVALOGIC1820	914016199	Electrolux	LAVALOGIC1820	914003596

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Electrolux	LAVALOGIC1820	914003459	Electrolux	LAVALOGIC1820	914016330
Electrolux	LAVALOGIC1820	914003291	Electrolux	LAVALOGIC1820	914016050
Electrolux	LAVALOGIC1820	914003444	Electrolux	LAVALOGIC1822	914003517
Electrolux	LAVALOGIC1822	914016256	Electrolux	LAVBELLA	914003534
Electrolux	LAVBELLA	914003343	Electrolux	LAVBELLA	914016273
Electrolux	LAVBELLA3051	914003540	Electrolux	LAVBELLA3051	914016279
Electrolux	LAVBELLA3251	914003538	Electrolux	LAVBELLA3251	914016277
Electrolux	LAVBELLA3451	914016280	Electrolux	LAVBELLA3451	914003541
Electrolux	LAVBELLA3452N	914016283	Electrolux	LAVBELLA3452N	914003544
Electrolux	LAVBELLA3850	914016369	Electrolux	LAVMARATHON	914003516
Electrolux	LAVMARATHON	914016255	Electrolux	LAVPRINCESS	914016272
Electrolux	LAVPRINCESS	914003533	Electrolux	LAVPRINCESS	914003367

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Electrolux	LAVPRINCESS5051	914003545	Electrolux	LAVPRINCESS 5051	914016284
Electrolux	LAVPRINCESS5251	914003542	Electrolux	LAVPRINCESS 5251	914016281
Electrolux	LAVREGINA	914003339	Electrolux	LAVREGINA	914016087
Electrolux	LAVREGINA1851	914016282	Electrolux	LAVREGINA18 51	914003543
Electrolux	LAVREGINA2551F	914003268	Electrolux	LAVREGINA25 52F	914003390
Electrolux	LAVREGINA2552F	914003539	Electrolux	LAVREGINA25 52F	914016278
Electrolux	LAVREGINA2651	914016276	Electrolux	LAVREGINA26 51	914003537
Electrolux	LAVREGINA2851	914003536	Electrolux	LAVREGINA28 51	914016275
Electrolux	LB3051	914525129	Electrolux	LB3251	914525130
Electrolux	LB3451	914525131	Electrolux	LB3452N	914525136
Electrolux	LB3850	914524313	Electrolux	LB45	914780234
Electrolux	LB46	914780274	Electrolux	LB46	914780235
Electrolux	LB48	914780237	Electrolux	LB48	914780275

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Electrolux	LB560	914520204	Electrolux	LB580	914520205
Electrolux	LBELLA	914903306	Electrolux	LBELLA	914525143
Electrolux	LF5	914789206	Electrolux	LF6	914789207
Electrolux	LI100E	914511102	Electrolux	LI100E	914511100
Electrolux	LI101JE	914510117	Electrolux	LI120JE	914510912
Electrolux	LI120JE	914510926	Electrolux	LL1620	914525341
Electrolux	LL1620	914525342	Electrolux	LL1620	914525335
Electrolux	LL1620	914525300	Electrolux	LL1630	914525323
Electrolux	LL1820	914524323	Electrolux	LL1820	914524325
Electrolux	LL1820	914524302	Electrolux	LL1820	914524320
Electrolux	LL1822	914524319	Electrolux	LMARATHON	914524119
Electrolux	LMARATHON	914903152	Electrolux	LP5051	914524016
Electrolux	LP5251	914524017	Electrolux	LPRINCESS	914525142
Electrolux	LPRINCESS	914903305	Electrolux	LR1851	914524312
Electrolux	LR2552F	914525320	Electrolux	LR2651	914525319

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Electrolux	LR2851	914524305	Electrolux	LREGINA	914525349
Electrolux	LV4060	914281142	Electrolux	LV4080	914281143
Electrolux	LV4100	914211144	Electrolux	LV5080	914285209
Electrolux	LV5100	914205211	Electrolux	QUARZOII	914780711
Electrolux	QUARZOII	914780719	Electrolux	QW 12650	914002296
Electrolux	QW 13600	914002250	Electrolux	QW 15600	914002391
Electrolux	QW 15600	914002249	Electrolux	QW 17600	914002248
Electrolux	QW10600	914002295	Electrolux	QW1225HT	914601412
Electrolux	QW12400	914003363	Electrolux	QW12400	914003366
Electrolux	QW12400	914016110	Electrolux	QW12400	914524024
Electrolux	QW12400	914016107	Electrolux	QW12600	914002251
Electrolux	QW12625	914002544	Electrolux	QW12625	914002307
Electrolux	QW12650	914002431	Electrolux	QW12650	914002392
Electrolux	QW12650	914002545	Electrolux	QW12670	914016079
Electrolux	QW12670	914016105	Electrolux	QW12670	914003328

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Electrolux	QW12670	914003359	Electrolux	QW12670	914525102
Electrolux	QW1270	914513500	Electrolux	QW1275	914513520
Electrolux	QW1275	914002720	Electrolux	QW12755	914002789
Electrolux	QW13600	914002546	Electrolux	QW13655	914002786
Electrolux	QW13680	914003331	Electrolux	QW13680	914525103
Electrolux	QW13680	914016081	Electrolux	QW14500	914525003
Electrolux	QW14500	914003364	Electrolux	QW14500	914016108
Electrolux	QW1450HT	914602514	Electrolux	QW1455HT	914601821
Electrolux	QW14560	914002787	Electrolux	QW14600	914002788
Electrolux	QW1460HT	914601660	Electrolux	QW1460HT	914601681
Electrolux	QW14660	914515256	Electrolux	QW14700	914512900
Electrolux	QW1475	914513521	Electrolux	QW1475	914002719
Electrolux	QW14760	914016104	Electrolux	QW14760	914016343
Electrolux	QW14760	914003333	Electrolux	QW14760	914003609
Electrolux	QW14760	914525104	Electrolux	QW14760	914003358

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Electrolux	QW14761	914903136	Electrolux	QW14780	914526311
Electrolux	QW14790	914003569	Electrolux	QW14790	914525201
Electrolux	QW14790	914016307	Electrolux	QW14800	914003607
Electrolux	QW14800	914525206	Electrolux	QW14800	914016341
Electrolux	QW14800	914003326	Electrolux	QW14810	914003438
Electrolux	QW14810	914016178	Electrolux	QW15600	914002543
Electrolux	QW15650	914002432	Electrolux	QW15655	914002785
Electrolux	QW15770	914003608	Electrolux	QW15770	914003334
Electrolux	QW15770	914525105	Electrolux	QW15770	914016342
Electrolux	QW16700	914016340	Electrolux	QW16700	914003606
Electrolux	QW16700	914525329	Electrolux	QW16700	914003365
Electrolux	QW16900	914016339	Electrolux	QW16900	914525330
Electrolux	QW16900	914003325	Electrolux	QW16900	914003605
Electrolux	QW17650	914002433	Electrolux	QW18800	914003330
Electrolux	QW18800	914016344	Electrolux	QW18800	914003610

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Electrolux	R100A	914780801	Electrolux	R100A	914780769
Electrolux	R12	914520202	Electrolux	R1200ITS	914517520
Electrolux	R16	914520203	Electrolux	R1600ITS	914517521
Electrolux	R60A	914520200	Electrolux	R65A	914520201
Electrolux	R70A	914780767	Electrolux	R800AXC	914791295
Electrolux	R800AXC	914791404	Electrolux	R80A	914780768
Electrolux	R80A	914780800	Electrolux	R8400TS	914900004
Electrolux	R8400TS	914900082	Electrolux	RE100	914791227
Electrolux	RE120	914791228	Electrolux	RE160EX	914791243
Electrolux	RE313E	914780736	Electrolux	RE316E	914791244
Electrolux	RE6100XC	914517401	Electrolux	RE6100XC	914517323
Electrolux	RE6120XC	914517324	Electrolux	RE6120XC	914517402
Electrolux	RE680XC	914517322	Electrolux	RE7	914780726
Electrolux	RE70	914791224	Electrolux	RE80	914791225
Electrolux	RE90	914791226	Electrolux	REG3610WT	914601119

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Electrolux	RI1000XC	914517030	Electrolux	RI1200XC	914517031
Electrolux	RI700	914517229	Electrolux	RI7000	914517062
Electrolux	RI7000	914517087	Electrolux	RI7200TS	914517809
Electrolux	RI7210TS	914517818	Electrolux	RI7600TS	914517819
Electrolux	RI7600TS	914517810	Electrolux	RI800XC	914517041
Electrolux	RIL1000XC	914662105	Electrolux	RIL1000XC	914662109
Electrolux	RIL1400XC	914662106	Electrolux	RIL1400XC	914662110
Electrolux	RIL7200	914603401	Electrolux	RIL7600	914603402
Electrolux	RK1000	914756232	Electrolux	RK1000	914756224
Electrolux	RK1000A	914756702	Electrolux	RK500	914756216
Electrolux	RK65	914756222	Electrolux	RK65	914756233
Electrolux	RK650	914756217	Electrolux	RK650A	914756700
Electrolux	RK850	914756218	Electrolux	RK850	914756231
Electrolux	RK850A	914756701	Electrolux	RKI1000	914756515
Electrolux	RKI1000AL	914756507	Electrolux	RKI1000AL	914756554

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Electrolux	RKI1200	914756506	Electrolux	RKI1200	914756553
Electrolux	RL130EX	914792032	Electrolux	RL50	914789203
Electrolux	RL50A	914780240	Electrolux	RL60	914789204
Electrolux	RL60A	914780233	Electrolux	RL60A	914780266
Electrolux	RL65	914789205	Electrolux	RL65	914789238
Electrolux	RL650	914780242	Electrolux	RL850	914780264
Electrolux	RL850	914780238	Electrolux	RQ1100IXC	914517026
Electrolux	RQ99E	914791229	Electrolux	RUBINOII	914780720
Electrolux	RUBINOII	914780712	Electrolux	T160SP	914520210
Electrolux	T16SP	914789208	Electrolux	T20SP	914789209
Electrolux	T20SP	914789237	Electrolux	T620SP	914521015
Electrolux	T720SP	914522001	Electrolux	W1206	914653334
Electrolux	W1207	914601675	Electrolux	ZAFFIROII	914780713
Electrolux	ZAFFIROII	914780721	Electrolux	ZE12	914517226
Electrolux	ZE14	914517227	Electrolux	ZE16	914517228

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Electrolux	ZWF1000	914780737	Electrolux	ZWF1200	914780738
Electrolux	ZWF1400	914791246	Electrolux	ZWF14109	914900087
Electrolux	ZWF14109	914900051	Elektro Helios	KT2250	914603203
Elektro Helios	TF1020E	914211130	Elektro Helios	TF1020E	914214006
Elektro Helios	TF1032E	914791134	Elektro Helios	TF1050E	914514525
Elektro Helios	TF1050E	914514542	Elektro Helios	TF1052E	914791136
Elektro Helios	TF1232E	914791135	Elektro Helios	TF1232E	914791148
Elektro Helios	TF1232E	914791388	Elektro Helios	TF1232E	914791390
Elektro Helios	TF1234E	914520003	Elektro Helios	TF1250E	914514526
Elektro Helios	TF1252E	914791137	Elektro Helios	TF1252E	914791389
Elektro Helios	TF1254E	914521014	Elektro Helios	TF1432E	914791260
Elektro Helios	TF1432E	914791391	Elektro Helios	TF1434E	914521013

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Elektro Helios	TF1440E	914514527	Elektro Helios	TF1462E	914517234
Elektro Helios	TF1462E	914517424	Elektro Helios	TF1464E	914521107
Faure	FKF2120	914653324	Faure	FKF2120	914653338
Faure	FKF2126	914603200	Faure	FWF150	914251108
Faure	FWF150	914251048	Faure	FWF160	914261033
Faure	FWF280	914281117	Faure	FWF280	914281065
Faure	FWF3103	914211137	Faure	FWF3105	914211047
Faure	FWF3105	914211140	Faure	FWF3113	914780818
Faure	FWF3115	914211119	Faure	FWF3115	914211048
Faure	FWF3117	914211138	Faure	FWF3125	914215206
Faure	FWF3125	914215103	Faure	FWF3126	914215104
Faure	FWF3135	914780746	Faure	FWF3135	914780802
Faure	FWF380	914281118	Faure	FWF380	914281066
Faure	FWF393	914281137	Faure	FWG3126	914215213
Faure	FWG3136	914225206	Faure	FWG5136	914517465

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Faure	LFD1156	914653317	Faure	LFV1060	914211027
Faure	LFV1260	914780715	Faure	LFV1360	914780725
Faure	LFV860	914281052	FORS	WA1200	914002783
FORS	WA1200	914015034	FORS	WA1400	914015033
FORS	WA1400	914002782	FORS	WA1600	914015035
FORS	WA1600	914002784	FORS	WE1400	914002795
FORS	WE1400	914015037	FORS	WE1600	914002796
FORS	WE1600	914015038	Fust	WA1656	914003614
Privileg	000678_20412	914003621	Privileg	000678_20524	914016356
Privileg	004541_20332	914780760	Privileg	004541_20556	914780812
Privileg	017127_20714	914791431	Privileg	017848_20169	914792513
Privileg	018454_20068	914791111	Privileg	025894_20305	914517283
Privileg	029055_20331	914517302	Privileg	051667_20140	914512837
Privileg	053468_20142	914512838	Privileg	060854_20170	914792514
Privileg	072349_20682	914517474	Privileg	077791_20167	914792516

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Privileg	092676_20203	914791178	Privileg	118907_20263	914517243
Privileg	118907_20567	914517449	Privileg	141799_20340	914515224
Privileg	145386_20776	914521143	Privileg	147230_20205	914791180
Privileg	156647_20326	914517060	Privileg	164079_20083	914512820
Privileg	175401_20350	914791294	Privileg	179947_20268	914516319
Privileg	181507_20358	914517331	Privileg	194632_20187	914512205
Privileg	204404_20267	914791239	Privileg	206304_20125	914791123
Privileg	210865_20294	914780741	Privileg	210865_20553	914780815
Privileg	212234_20163	914791175	Privileg	212234_20508	914791349
Privileg	220052_20162	914791346	Privileg	220052_20162	914791172
Privileg	222714_20697	914521122	Privileg	224579_20700	914522113
Privileg	228525_20390	914003570	Privileg	228525_20526	914016308
Privileg	232515_20458	914517453	Privileg	233629_20270	914517528
Privileg	236247_20237	914792527	Privileg	237296_20339	914515223
Privileg	237296_20568	914515245	Privileg	238549_20231	914517212

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Privileg	238913_20256	914780723	Privileg	239359_20731	914521020
Privileg	247084_20805	914521145	Privileg	247101_20806	914521146
Privileg	266391_20060	914791112	Privileg	266412_20062	914791115
Privileg	266471_20064	914791117	Privileg	268027_20289	914512850
Privileg	282129_20778	914521121	Privileg	289046_20291	914517263
Privileg	294128_20303	914002791	Privileg	294128_20303	914015036
Privileg	294128_20582	914016378	Privileg	308637_20161	914791345
Privileg	308637_20161	914791171	Privileg	312292_20665	914517469
Privileg	316134_20668	914517467	Privileg	323219_20428	914281083
Privileg	323219_20615	914281134	Privileg	324885_20357	914510901
Privileg	324885_20539	914510917	Privileg	340593_20307	914517385
Privileg	340593_20307	914517282	Privileg	342703_20078	914601819
Privileg	348172_20123	914513533	Privileg	360614_20287	914517260
Privileg	362442_20077	914601818	Privileg	362749_20405	914520006
Privileg	382523_20259	914517225	Privileg	390368_20377	914517335

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Privileg	390368_20513	914517386	Privileg	391777_20274	914016010
Privileg	391777_20274	914003150	Privileg	39177_20274	914016010
Privileg	403168_20284	914512849	Privileg	412330_20314	914516336
Privileg	412330_20517	914516357	Privileg	418352_20410	914002801
Privileg	424747_20359	914517332	Privileg	435555_20266	914517040
Privileg	447022_20308	914517056	Privileg	452546_20202	914791177
Privileg	455411_20315	914516337	Privileg	455411_20518	914516358
Privileg	460004_20768	914791428	Privileg	460514_20740	914521116
Privileg	460640_20695	914521127	Privileg	477164_20271	914756512
Privileg	477164_20271	914756542	Privileg	477164_20981	914756572
Privileg	477164_20981	914756566	Privileg	478556_20411	914003619
Privileg	478557_20192	914015006	Privileg	478588_20527	914016371
Privileg	490781_20416	914791363	Privileg	490781_20560	914791396
Privileg	494279_20394	914281077	Privileg	494279_20580	914281136
Privileg	497203_20404	914520005	Privileg	503663_20310	914515215

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Privileg	504456_20698	914521119	Privileg	534877_20143	914512839
Privileg	541762_20188	914512204	Privileg	543976_20701	914900079
Privileg	546750_20441	914517468	Privileg	558504_20195	914002746
Privileg	562803_20239	914512211	Privileg	577716_20190	914512843
Privileg	577808_20264	914517251	Privileg	582603_20225	914780722
Privileg	597085_20290	914517262	Privileg	599161_20278	914601827
Privileg	601996_20234	914792528	Privileg	604382_20233	914517214
Privileg	605515_20273	914016011	Privileg	605515_20273	914003151
Privileg	610348_20333	914780761	Privileg	610348_20557	914780813
Privileg	610636_20699	914521120	Privileg	614643_20063	914791116
Privileg	617772_20213	914601419	Privileg	628210_20111	914513524
Privileg	628649_20265	914517252	Privileg	630029_20238	914512210
Privileg	637187_20214	914601826	Privileg	637773_20206	914791181
Privileg	637774_20204	914791179	Privileg	639863_20021	914512103
Privileg	639863_20085	914512105	Privileg	651591_20118	914792501

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Privileg	657648_20269	914516320	Privileg	658783_20644	914791412
Privileg	674467_20313	914516335	Privileg	674467_20516	914516356
Privileg	675493_20076	914601409	Privileg	679310_20934	914523302
Privileg	694479_20824	914521149	Privileg	695864_20666	914517115
Privileg	706187_20679	914780828	Privileg	706187_20773	914780828
Privileg	708759_20296	914792717	Privileg	724401_20457	914517452
Privileg	732075_20693	914521125	Privileg	732613_20825	914521150
Privileg	736913_20277	914601421	Privileg	743422_20155	914791158
Privileg	746699_20733	914521154	Privileg	746699_20733	914521148
Privileg	746752_20165	914791174	Privileg	746752_20510	914791420
Privileg	746752_20510	914791348	Privileg	747943_20199	914512846
Privileg	751604_20710	914791425	Privileg	756177_20160	914002695
Privileg	756177_20521	914016374	Privileg	757299_20415	914791362
Privileg	757299_20415	914791395	Privileg	758765_20321	914601109
Privileg	758765_20544	914601123	Privileg	760844_20279	914601828

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Privileg	762327_20380	914517333	Privileg	765348_20393	914517072
Privileg	765348_20515	914517083	Privileg	767644_20311	914515216
Privileg	767684_20685	914516383	Privileg	774127_20084	914512821
Privileg	774813_20082	914512819	Privileg	775542_20312	914515217
Privileg	775600_20306	914517281	Privileg	775600_20306	914517384
Privileg	779310_20116	914512107	Privileg	782160_20323	914601652
Privileg	782160_20546	914601671	Privileg	783016_20406	914520004
Privileg	790215_20429	914211061	Privileg	790215_20616	914211132
Privileg	795519_20455	914791402	Privileg	795954_20147	914512840
Privileg	799243_20325	914517301	Privileg	805251_20272	914756543
Privileg	805251_20272	914756513	Privileg	805251_20982	914756567
Privileg	805251_20982	914756573	Privileg	809880_20373	914002798
Privileg	809880_20583	914016377	Privileg	813435_20122	914513532
Privileg	821084_20680	914780829	Privileg	827409_20141	914015002
Privileg	829880_20065	914791114	Privileg	833658_20775	914521144

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Privileg	840604_20113	914512833	Privileg	842040_20166	914791347
Privileg	842040_20166	914791173	Privileg	865147_20066	914791109
Privileg	868028_20732	914521021	Privileg	873750_20235	914791206
Privileg	874894_8457	914015004	Privileg	879436_20667	914517466
Privileg	914345_20232	914517213	Privileg	919470_20456	914517464
Privileg	922987_20713	914791430	Privileg	926084_20285	914756514
Privileg	926084_20536	914756544	Privileg	926084_20983	914756574
Privileg	926084_20983	914756568	Privileg	927146_20236	914792526
Privileg	928643_20694	914521126	Privileg	930777_20061	914791113
Privileg	932587_20164	914791176	Privileg	932587_20509	914791350
Privileg	933910_20376	914791302	Privileg	933910_20507	914791344
Privileg	934693_20519	914016375	Privileg	943365_20257	914780724
Privileg	945101_20067	914791110	Privileg	946137_20356	914517383
Privileg	946137_20356	914517330	Privileg	954713_20322	914601651
Privileg	954713_20545	914601670	Privileg	959720_20117	914792500

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Privileg	969048_20434	914780810	Privileg	969048_20617	914780811
Privileg	969048_20771	914780811	Privileg	970068_20355	914517329
Privileg	970068_20355	914517382	Privileg	971534_20378	914517336
Privileg	971534_20514	914517387	Privileg	976357_20395	914211058
Privileg	976357_20581	914211135	Privileg	980545_20354	914517381
Privileg	980545_20354	914517328	Privileg	993401_20168	914791170
Privileg	995211_20420	914002802	Privileg	995211_20618	914016379
Privileg	DYNAMIC5910, 20069	914002444	Privileg	DYNAMIC5912, 20070	914002445
Privileg	DYNAMIC5914, 20071	914002446	Privileg	DYNAMIC5920, 20119	914002554
Privileg	DYNAMIC5922, 20120	914002555	Privileg	DYNAMIC5924, 20121	914002556
Privileg	DYNAMIC5930, 20171	914002674	Privileg	DYNAMIC5932, 20172	914002675
Privileg	DYNAMIC6810, 20072	914002447	Privileg	DYNAMIC6810 SL, 20158	914002677
Privileg	DYNAMIC6812, 20073	914002448	Privileg	DYNAMIC6812, 20207	914002687

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Privileg	DYNAMIC6812SL, 20159	914002678	Privileg	DYNAMIC6814, 20074	914002449
Privileg	DYNAMIC6814, 20141	914002527	Privileg	DYNAMIC6814, 20208	914002688
Privileg	DYNAMIC6816, 20075	914002450	Privileg	DYNAMIC6816, 20209	914002689
Privileg	DYNAMIC7420, 20210	914002686	Privileg	DYNAMIC7420, 8457	914002273
Privileg	DYNAMIC7440, 8458	914002274	Privileg	DYNAMIC7460, 8459	914002275
Privileg	DYNAMIC7480, 8460	914002276	Privileg	DYNAMIC7640, 20131	914002534
Privileg	DYNAMIC7640, 20191	914002670	Privileg	DYNAMIC7640, 20211	914002680
Privileg	DYNAMIC7640, 20411	914016347	Privileg	DYNAMIC7660, 20132	914002533
Privileg	DYNAMIC7660, 20212	914002681	Privileg	DYNAMIC7660, 20192	914002671
Privileg	DYNAMIC7680, 20133	914002532	Privileg	DYNAMIC7680, 20193	914002672
Privileg	PPROF1400, 20135	914002539	Privileg	PPROF1401, 20181	914002668

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Privileg	PPROF1600, 20136	914002538	Privileg	PPROF1601, 20182	914002669
Privileg	PRIVILEG 5160,20126	914002515	Privileg	PRIVILEG5140, 8474	914002310
Privileg	PRIVILEG9215, 20156	914002639	Rex	LB650	914792012
Rex	LB850	914792013	Rex	LI101JE	914510106
Rex	RE100	914791162	Rex	RE120	914791163
Rex	RE160EX	914791194	Rex	RE313E	914780717
Rex	RE316E	914791192	Rex	RE65	914791160
Rex	RE80	914791161	Rex	RI1000	914514545
Rex	RI1000XC	914517001	Rex	RI1200XC	914517002
Rex	RI121LA	914601411	Rex	RI1600XC	914517003
Rex	RI800XC	914517000	Rex	RIE391	914514544
Rex	RIL1000XC	914662100	Rex	RIL1400XC	914662101
Rex	RK500	914756201	Rex	RK650	914756202
Rex	RK800	914756203	Rex	RKI100	914512600

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Rex	RKI1000	914756500	Rex	RL130EX	914792028
Rex	RL40A	914780213	Rex	RL50A	914780214
Rex	RL60A	914780215	Rex	RL65A	914792011
Rex	RQ1109I	914517009	Rex	RQ99E	914791193
Rosenlew	RTF3100	914791235	Rosenlew	RTF3101	914780733
Rosenlew	RTF3101	914780806	Rosenlew	RTF3102	914780832
Rosenlew	RTF3103	914780834	Rosenlew	RTF3110	914780838
Rosenlew	RTF3120	914791238	Rosenlew	RTF3121	914792714
Rosenlew	RTF3121	914792733	Rosenlew	RTF3122	914791237
Rosenlew	RTF3122	914791385	Rosenlew	RTF3123	914791236
Rosenlew	RTF3124	914780833	Rosenlew	RTF3125	914780831
Rosenlew	RTF3126	914791417	Rosenlew	RTF3141	914791306
Rosenlew	RTF3141	914791387	Rosenlew	RTF3143	914780830
Rosenlew	RTF3146	914791416	Rosenlew	RTF4050	914515038
Rosenlew	RTF4220	914792033	Rosenlew	RTF4220	914792043

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Rosenlew	RTF4250	914515039	Rosenlew	RTF4260	914515041
Rosenlew	RTF4360	914512817	Rosenlew	RTF4450	914515040
Rosenlew	RTF4460	914512818	Rosenlew	RTF5120	914517246
Rosenlew	RTF5120	914517421	Rosenlew	RTF5121	914517355
Rosenlew	RTF5121	914517420	Rosenlew	RTF5122	914521115
Rosenlew	RTF5126	914521113	Rosenlew	RTF5140	914517247
Rosenlew	RTF5140	914517422	Rosenlew	RTF5141	914517038
Rosenlew	RTF5141	914517097	Rosenlew	RTF5142	914521114
Rosenlew	RTF5147	914522111	Rosenlew	RTF5361	914517071
Rosenlew	RTF5361	914517107	Rosenlew	RTF5362	914522112
Zanker	444_607_09	914516370	Zanker	556_767_09	914791300
Zanker	888_079_05	914517431	Zanker	888_079_09	914517430
Zanker	888_400_09	914521128	Zanker	888_404_09	914521129
Zanker	888_412_09	914521130	Zanker	888_558_09	914791422
Zanker	CF4000	914515003	Zanker	CF4200	914515001

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Zanker	CF4250	914515004	Zanker	CF4450	914515005
Zanker	CF4450	914515002	Zanker	CF4650	914515014
Zanker	DF2200	914791296	Zanker	DF2400	914791297
Zanker	DF2600	914791298	Zanker	DF4229	914791258
Zanker	DF4240	914791263	Zanker	DF4240	914791423
Zanker	DF4242	914791426	Zanker	DF4242S	914791427
Zanker	DF4429	914791259	Zanker	DF4440	914791264
Zanker	DF4440B	914791265	Zanker	DF4440S	914791394
Zanker	DF4440S	914791266	Zanker	DFX4240	914792720
Zanker	DFX4240	914792737	Zanker	DFX4440	914792721
Zanker	DFX4640	914791422	Zanker	EF3200	914517303
Zanker	EF3200	914517462	Zanker	EF3400	914517304
Zanker	EF3600	914517327	Zanker	EF4240	914517284
Zanker	EF4242	914517337	Zanker	EF4244	914517434
Zanker	EF4244	914517356	Zanker	EF4244 (PRIVILEG)	914517356

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Zanker	EF4246	914521128	Zanker	EF4440	914517285
Zanker	EF4442	914517338	Zanker	EF4444	914517435
Zanker	EF4444	914517357	Zanker	EF4444 (PRIVILEG)	914517357
Zanker	EF4446	914521129	Zanker	EF4642	914517334
Zanker	EF4644	914517358	Zanker	EF4644	914517436
Zanker	EF4644 (PRIVILEG)	914517358	Zanker	EF4646	914521130
Zanker	EF6440	914517286	Zanker	EF6440S	914517288
Zanker	EF6640	914517289	Zanker	EF7281	914516359
Zanker	EF7281	914516371	Zanker	EF7480	914516323
Zanker	EF7481	914516360	Zanker	EF7481	914516372
Zanker	EF7680	914516324	Zanker	EF7681	914516384
Zanker	EFX6250FML	914517306	Zanker	EFX6250SFM	914517307
Zanker	EFX6450FML	914517308	Zanker	EFX6450FML	914517432
Zanker	EFX6650FML	914517309	Zanker	EFX6650FML	914517433
Zanker	EFXX4242	914522114	Zanker	F7DFXX4040	914792734

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Zanker	FAMILY7DFXX4040	914792724	Zanker	FAMILY7DFXX4240	914792725
Zanker	FAMILY7DFXX4440	914792726	Zanker	FR2241	914512212
Zanker	IF9250	914516368	Zanker	IF9250	914516345
Zanker	IF9450	914516369	Zanker	IF9450	914516322
Zanker	IF9650	914516370	Zanker	IF9650	914516341
Zanker	KWG3100	914520011	Zanker	KWG3120	914520012
Zanker	KWG5120	914520105	Zanker	KWG5140	914520106
Zanker	PF2445	914791208	Zanker	PF4050	914515006
Zanker	PF4225	914791209	Zanker	PF4227	914791234
Zanker	PF4250	914515007	Zanker	PF4350	914517217
Zanker	PF4350S	914517218	Zanker	PF4425	914791231
Zanker	PF4450	914517254	Zanker	PF4450	914515008
Zanker	PF4450S	914517255	Zanker	PF5050	914515031
Zanker	PF5250	914515019	Zanker	PF5425	914512841
Zanker	PF5450	914515020	Zanker	PF6450	914512741

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Zanker	PF6620	914512848	Zanker	PF6650	914512742
Zanker	PF7350	914513510	Zanker	PF7550	914513511
Zanker	PF7690	914002799	Zanker	PF7690	914015040
Zanker	SF1251	914791222	Zanker	SF2000	914792030
Zanker	SF2200	914791300	Zanker	SF2200	914792031
Zanker	SF2201	914791277	Zanker	SF2400	914791411
Zanker	SF2400	914791301	Zanker	SF2400N	914521033
Zanker	SF2401	914791278	Zanker	SF4000	914791185
Zanker	SF4200	914791186	Zanker	SF4229	914791256
Zanker	SF4400	914791187	Zanker	SF4426	914791240
Zanker	SF4429	914791257	Zanker	SF5400	914791248
Zanker	SF5600	914517259	Zanker	SF6250	914517200
Zanker	SF6260	914517256	Zanker	SF6450	914517201
Zanker	SF6460	914517257	Zanker	SF6650	914517202
Zanker	SF6660	914517258	Zanker	SFX2400	914791299

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Zanker	SFX2400 (PRIVILEG)	914791299	Zanker	SFX4040	914792719
Zanker	WTF4250	914601520	Zanker	WTF4250	914601521
Zanker	WTF6450	914601515	Zanussi	ADV106	914211059
Zanussi	ADV106	914211133	Zanussi	ADV86	914281081
Zanussi	ADV86	914281135	Zanussi	BONUX	914791323
Zanussi	BONUX	914791330	Zanussi	BRILJANT	914512806
Zanussi	COMPLESSO	914653325	Zanussi	COMPLESSO	914653335
Zanussi	F1015	914791125	Zanussi	F1025	914791105
Zanussi	F1025	914791132	Zanussi	F1026	914791129
Zanussi	F1046	914780775	Zanussi	F1046	914780804
Zanussi	F1046	914520001	Zanussi	F1213	914791127
Zanussi	F1214	914780716	Zanussi	F1215	914780820
Zanussi	F1215	914791126	Zanussi	F1215	914780709
Zanussi	F1225	914791106	Zanussi	F1225	914791133
Zanussi	F1226	914791130	Zanussi	F1227	914791268

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Zanussi	F1246	914520002	Zanussi	F1246	914780805
Zanussi	F1246	914780776	Zanussi	F1247	914791312
Zanussi	F1247	914521009	Zanussi	F1415	914780821
Zanussi	F1415	914780710	Zanussi	F1425	914791107
Zanussi	F1426	914791131	Zanussi	F1427	914791269
Zanussi	F1446	914521008	Zanussi	F1446	914791379
Zanussi	F1446	914791315	Zanussi	F1447	914521010
Zanussi	F1447	914791313	Zanussi	F1447	914791383
Zanussi	F1626	914791293	Zanussi	F1626	914791401
Zanussi	F1645	914791311	Zanussi	F1645	914521016
Zanussi	F1645	914791380	Zanussi	F1646	914521012
Zanussi	F1647	914791384	Zanussi	F1647	914521011
Zanussi	F1647	914791361	Zanussi	F1648	914521017
Zanussi	FA1025E	914211023	Zanussi	FA1025E	914211126
Zanussi	FA1026HDRO	914211040	Zanussi	FA1026HYDR	914780907

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Zanussi	FA1026HYDR	914211104	Zanussi	FA1026HYDR	914780923
Zanussi	FA1031E	914211038	Zanussi	FA1035E	914211033
Zanussi	FA1035E	914211128	Zanussi	FA1055E	914211035
Zanussi	FA1084E	914211039	Zanussi	FA423VARIO	914241102
Zanussi	FA423VARIO	914241027	Zanussi	FA5022	914251042
Zanussi	FA523VARIO	914251102	Zanussi	FA523VARIO	914251046
Zanussi	FA615E	914281029	Zanussi	FA615E	914281034
Zanussi	FA624VARIO	914780255	Zanussi	FA624VARIO	914780250
Zanussi	FA624VARIO	914261101	Zanussi	FA624VARIO	914261032
Zanussi	FA678E	914281132	Zanussi	FA678E	914281062
Zanussi	FA825E	914281031	Zanussi	FA825E	914281035
Zanussi	FA825E	914281072	Zanussi	FA826HYDRO	914281061
Zanussi	FA826HYDRO	914281104	Zanussi	FA826HYDRO	914780906
Zanussi	FA826HYDRO	914780922	Zanussi	FA831E	914281054
Zanussi	FA835E	914281051	Zanussi	FA878E	914281063

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Zanussi	FA884E	914281056	Zanussi	FAE1025V	914780927
Zanussi	FAE1025V	914780905	Zanussi	FAE1025V	914211024
Zanussi	FAE1025V	914780903	Zanussi	FAE1025V	914780921
Zanussi	FAE1025V	914211028	Zanussi	FAE1025V	914211103
Zanussi	FAE1025V	914211141	Zanussi	FAE1025V	914780900
Zanussi	FAE1025V	914211029	Zanussi	FAE1226	914780822
Zanussi	FAE625	914281041	Zanussi	FAE625	914780901
Zanussi	FAE625	914281032	Zanussi	FAE825V	914281033
Zanussi	FAE825V	914780902	Zanussi	FAE825V	914281042
Zanussi	FAE825V	914780920	Zanussi	FD1016	914515021
Zanussi	FD1016	914515029	Zanussi	FD1216	914515027
Zanussi	FD1216	914515032	Zanussi	FD1216	914515022
Zanussi	FD1416	914515028	Zanussi	FD1416	914515023
Zanussi	FD1416	914515033	Zanussi	FD1616	914515034
Zanussi	FD1616	914515030	Zanussi	FE1002	914901405

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Zanussi	FE1002	914901401	Zanussi	FE1004	914514519
Zanussi	FE1004	914788601	Zanussi	FE1004	914514547
Zanussi	FE1004	914514512	Zanussi	FE1004	914514514
Zanussi	FE1005	914517426	Zanussi	FE1005	914517248
Zanussi	FE1006	914517714	Zanussi	FE1006	914517706
Zanussi	FE1014	914515024	Zanussi	FE1014N	914512601
Zanussi	FE1024N	914512200	Zanussi	FE1024N	914756548
Zanussi	FE1024N	914756511	Zanussi	FE1025G	914792508
Zanussi	FE1025G	914792534	Zanussi	FE1026N	914756547
Zanussi	FE1026N	914756516	Zanussi	FE1027G	914522004
Zanussi	FE1200	914510604	Zanussi	FE1204	914514515
Zanussi	FE1204	914514513	Zanussi	FE1204	914514548
Zanussi	FE1204	914514523	Zanussi	FE1205	914517211
Zanussi	FE1205	914517359	Zanussi	FE1205	914514540
Zanussi	FE1206	914517707	Zanussi	FE1206	914517715

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Zanussi	FE1214	914516000	Zanussi	FE1214	914515025
Zanussi	FE1215	914516015	Zanussi	FE1404	914514524
Zanussi	FE1405	914514517	Zanussi	FE1405	914515057
Zanussi	FE1405	914514541	Zanussi	FE1405	914515046
Zanussi	FE1406	914517716	Zanussi	FE1406	914517708
Zanussi	FE1414	914515026	Zanussi	FE1414	914516001
Zanussi	FE1414	914515036	Zanussi	FE1415	914516016
Zanussi	FE1416	914517239	Zanussi	FE1416	914517418
Zanussi	FE1446	914521123	Zanussi	FE1614	914515037
Zanussi	FE1646	914521124	Zanussi	FE802	914901404
Zanussi	FE802	914901400	Zanussi	FE804	914788600
Zanussi	FE825G	914792728	Zanussi	FE825G	914792723
Zanussi	FE827G	914522003	Zanussi	FE925N	914512201
Zanussi	FE925N	914756546	Zanussi	FE925N	914756510
Zanussi	FJE1204G	914516807	Zanussi	FJE1205	914516381

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Zanussi	FJE1205	914516318	Zanussi	FJE1207	914513508
Zanussi	FJE1236	914516800	Zanussi	FJE1436	914516809
Zanussi	FJE1436	914516801	Zanussi	FJE1605	914512835
Zanussi	FJE1635	914516361	Zanussi	FJE1635	914516300
Zanussi	FJE1636	914516810	Zanussi	FJE1636	914516802
Zanussi	FJE904	914516380	Zanussi	FJE904	914516303
Zanussi	FL1008	914791255	Zanussi	FL1015	914791251
Zanussi	FL1018	914791249	Zanussi	FL1089	914513528
Zanussi	FL1089ALU	914513530	Zanussi	FL1090	914517032
Zanussi	FL1090ALU	914517033	Zanussi	FL1108	914791144
Zanussi	FL1108ALU	914791247	Zanussi	FL1201	914512772
Zanussi	FL1208	914791198	Zanussi	FL1231	914791242
Zanussi	FL1289	914513529	Zanussi	FL1290	914517034
Zanussi	FL708	914791139	Zanussi	FL708	914791140
Zanussi	FL708ALU	914791374	Zanussi	FL708ALU	914791241

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Zanussi	FL708ALU	914791141	Zanussi	FL889	914515044
Zanussi	FL908	914791143	Zanussi	FL908	914791142
Zanussi	FLN1009	914514501	Zanussi	FV1035N	914756223
Zanussi	FV1035N	914756236	Zanussi	FV504	914780211
Zanussi	FV825N	914756200	Zanussi	FV825N	914756237
Zanussi	FV832	914792010	Zanussi	FV832	914792044
Zanussi	FV850N	914756221	Zanussi	FV850N	914756227
Zanussi	FWF1400	914780826	Zanussi	QUARZO II	914780702
Zanussi	RUBINO II	914780703	Zanussi	UMBRIA	914603202
Zanussi	W1106	914653318	Zanussi	WD1009	914603001
Zanussi	WD1009	914603002	Zanussi	WD1010	914653315
Zanussi	WD1210	914653316	Zanussi	WD1215	914653310
Zanussi	WD1245	914653341	Zanussi	WD1245	914653330
Zanussi	WD1601	914602513	Zanussi	WD1601INPT	914602519
Zanussi	WE1200	914602905	Zanussi	WIJ1209	914601900

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Zanussi	WJE1200	914602009	Zanussi	WJE1207	914602010
Zanussi	WJE1207	914602008	Zanussi	WJE1207	914602013
Zanussi	WJE1300	914602511	Zanussi	WJE1407G	914602520
Zanussi	WJE1407G	914602510	Zanussi	ZAFFIRO II	914780704
Zanussi	ZE12	914517701	Zanussi	ZE12	914517717
Zanussi	ZE14	914517718	Zanussi	ZE14	914517702
Zanussi	ZE16	914517293	Zanussi	ZE16	914517399
Zanussi	ZE16	914517267	Zanussi	ZE16	914517374
Zanussi	ZIF520SKD	914517119	Zanussi	ZIWD220SKD	914603212
Zanussi	ZKF220	914653313	Zanussi	ZKF221	914662103
Zanussi	ZKG2100	914653327	Zanussi	ZKG2100	914653339
Zanussi	ZKG2120	914653328	Zanussi	ZKG2120	914653340
Zanussi	ZKU220	914515403	Zanussi	ZTI1029	914511101
Zanussi	ZTI1029	914511103	Zanussi	ZWD381	914901406
Zanussi	ZWD5106	914901601	Zanussi	ZWD586	914901600

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Zanussi	ZWF1000	914780755	Zanussi	ZWF1000	914780775
Zanussi	ZWF1000	914791418	Zanussi	ZWF1026	914520212
Zanussi	ZWF1038	914520100	Zanussi	ZWF1200	914791355
Zanussi	ZWF1200	914780756	Zanussi	ZWF1200	914791316
Zanussi	ZWF1200	914791328	Zanussi	ZWF1210	914791413
Zanussi	ZWF1210	914791407	Zanussi	ZWF1220	914521151
Zanussi	ZWF1226	914520008	Zanussi	ZWF1238	914520101
Zanussi	ZWF1400	914791329	Zanussi	ZWF1400	914791356
Zanussi	ZWF1400	914791317	Zanussi	ZWF1400	914780757
Zanussi	ZWF1410	914791414	Zanussi	ZWF1410	914791408
Zanussi	ZWF1420	914521152	Zanussi	ZWF1438	914520104
Zanussi	ZWF1438	914520102	Zanussi	ZWF1440	914520103
Zanussi	ZWF1600	914791419	Zanussi	ZWF1620	914521153
Zanussi	ZWF250	914251110	Zanussi	ZWF250	914251049
Zanussi	ZWF260	914261115	Zanussi	ZWF3100	914211049

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Zanussi	ZWF3100	914211120	Zanussi	ZWF3102	914780827
Zanussi	ZWF3102	914211057	Zanussi	ZWF3102	914780749
Zanussi	ZWF3102	914211121	Zanussi	ZWF3120	914780777
Zanussi	ZWF3120	914780786	Zanussi	ZWF3122	914780750
Zanussi	ZWF3122	914780787	Zanussi	ZWF360	914281119
Zanussi	ZWF360	914281067	Zanussi	ZWF365	914285106
Zanussi	ZWF365	914285203	Zanussi	ZWF380	914281120
Zanussi	ZWF380	914281068	Zanussi	ZWF380- 60000039FOXT R	914780732
Zanussi	ZWF382	914281122	Zanussi	ZWF382	914281078
Zanussi	ZWF384	914281123	Zanussi	ZWF384	914281079
Zanussi	ZWF386	914285107	Zanussi	ZWF386	914281124
Zanussi	ZWF386	914285204	Zanussi	ZWF388	914281116
Zanussi	ZWF826	914520211	Zanussi	ZWG3101	914205104
Zanussi	ZWG3101	914205204	Zanussi	ZWG3102	914205106
Zanussi	ZWG3102	914780751	Zanussi	ZWG3102	914205205

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Zanussi	ZWG3103	914205105	Zanussi	ZWG3103	914205209
Zanussi	ZWG3104	914205108	Zanussi	ZWG3104	914205206
Zanussi	ZWG3105	914791274	Zanussi	ZWG3105	914205101
Zanussi	ZWG3105	914205203	Zanussi	ZWG3105A	914791368
Zanussi	ZWG3105A	914791275	Zanussi	ZWG3106	914205208
Zanussi	ZWG3106	914205111	Zanussi	ZWG3106	914205207
Zanussi	ZWG3107	914205212	Zanussi	ZWG3121	914215209
Zanussi	ZWG3121	914215110	Zanussi	ZWG3122	914215111
Zanussi	ZWG3122	914780788	Zanussi	ZWG3122	914215208
Zanussi	ZWG3122	914780752	Zanussi	ZWG3123	914791357
Zanussi	ZWG3123	914791283	Zanussi	ZWG3125	914215207
Zanussi	ZWG3125	914791276	Zanussi	ZWG3125	914215101
Zanussi	ZWG3126	914215113	Zanussi	ZWG3126	914215210
Zanussi	ZWG3128	914215215	Zanussi	ZWG3129	914215214
Zanussi	ZWG3142	914780790	Zanussi	ZWG3142	914780754

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Zanussi	ZWG3143	914791358	Zanussi	ZWG3143	914791281
Zanussi	ZWG3144	914780753	Zanussi	ZWG3144	914791340
Zanussi	ZWG3162	914791332	Zanussi	ZWG3162	914791280
Zanussi	ZWG3163	914791359	Zanussi	ZWG3163	914791282
Zanussi	ZWG3164	914791279	Zanussi	ZWG3164	914791331
Zanussi	ZWG385	914285101	Zanussi	ZWG385	914791272
Zanussi	ZWG385	914285202	Zanussi	ZWG385A	914791273
Zanussi	ZWG390	914791205	Zanussi	ZWG5141	914517396
Zanussi	ZWG5141	914517291	Zanussi	ZWG5141	914521132
Zanussi	ZWG5161	914517397	Zanussi	ZWG5161	914521133
Zanussi	ZWG5161	914517292	Zanussi	ZWG5249	914521157
Zanussi	ZWG6121	914517470	Zanussi	ZWG6141	914521134
Zanussi	ZWG6141	914517471	Zanussi	ZWG6141	914517457
Zanussi	ZWG6161	914517458	Zanussi	ZWG6161	914521135
Zanussi	ZWG6161	914517472	Zanussi	ZWH5102	914522005

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Zanussi	ZWH5105	914522107	Zanussi	ZWH5105A	914522108
Zanussi	ZWH5125	914522109	Zanussi	ZWH520	914517015
Zanussi	ZWS1020	914756235	Zanussi	ZWS1030	914756560
Zanussi	ZWS1040	914756565	Zanussi	ZWS150	914756070
Zanussi	ZWS290	914756071	Zanussi	ZWS3102	914901801
Zanussi	ZWS3102	914901804	Zanussi	ZWS3122	914901805
Zanussi	ZWS3122	914901802	Zanussi	ZWS382	914901803
Zanussi	ZWS382	914901800	Zanussi	ZWS820	914756234
Zanussi	ZWS830	914756559	Zanussi	ZWU6120	914601666
Zanussi	ZWW1202	914603208	Zoppas	L10	914211031
Zoppas	L8	914281047	Zoppas	P1000EM	914792522
Zoppas	P1000EM	914792701	Zoppas	P100E	914780913
Zoppas	P100E	914780926	Zoppas	P100E	914211030
Zoppas	P100E	914211055	Zoppas	P100E	914211116
Zoppas	P106M	914205202	Zoppas	P106M	914791907

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Zoppas	P106M	914205102	Zoppas	P107XD	914517073
Zoppas	P107XD	914517066	Zoppas	P107XD	914517085
Zoppas	P1200EMD	914517004	Zoppas	P1200EMD	914517008
Zoppas	P127XLCD	914517086	Zoppas	P127XLCD	914517067
Zoppas	P127XLCD	914517074	Zoppas	P4	914241020
Zoppas	P5	914251107	Zoppas	P5	914251028
Zoppas	P5	914780258	Zoppas	P6	914261104
Zoppas	P6	914780246	Zoppas	P6	914261023
Zoppas	P6	914780259	Zoppas	P65	914281048
Zoppas	P650	914281045	Zoppas	P65E	914281074
Zoppas	P65E	914780924	Zoppas	P65E	914281114
Zoppas	P65E	914281043	Zoppas	P660	914780243
Zoppas	P76M	914285102	Zoppas	P76M	914285200
Zoppas	P8	914792039	Zoppas	P8	914792035
Zoppas	P800EM	914792700	Zoppas	P800EM	914792521

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Zoppas	P80E	914780925	Zoppas	P80E	914780912
Zoppas	P80E	914281115	Zoppas	P80E	914281044
Zoppas	P80E	914281075	Zoppas	P850	914281046
Zoppas	P86M	914285201	Zoppas	P86M	914791906
Zoppas	P86M	914285103	Zoppas	P87X	914792739
Zoppas	P87X	914792722	Zoppas	P8EM	914791230
Zoppas	PL1000	914756209	Zoppas	PL1000	914756230
Zoppas	PL104E	914756704	Zoppas	PL400	914756205
Zoppas	PL500	914756228	Zoppas	PL500	914756206
Zoppas	PL650	914756207	Zoppas	PL800	914756229
Zoppas	PL800	914756208	Zoppas	PL84E	914756703
Zoppas	PLA1200B	914601822	Zoppas	PLA1400EMD	914662111
Zoppas	PLA1400EMD	914662102	Zoppas	PLA147D	914603400
Zoppas	PO665B	914834204	Zoppas	Z110C	914251116
Zoppas	Z120C	914261034	Zoppas	Z120C	914261105

ТЭН 1950W L=231мм, с отверстием, с бортиком, с предохранителем (Kawai)

Zoppas	Z16	914281140	Zoppas	Z20	914211139
Zoppas	Z616	914285208	Zoppas	Z620	914205210
Zoppas	ZL160SC	914281069	Zoppas	ZL160SC	914281113
Zoppas	ZL200SC	914211050	Zoppas	ZL200SC	914211115