

Ident No.: 11015

Bar Code: 4006825613858

The Einhell cordless GE-CS 18 Li - Solo Chainsaw Sharpener restores the cutting edge to your chainsaw and saves you money. Why buy an expensive new chain when you can re-sharpen the one you already have? The chainsaw sharpener is ideal for quickly sharpening standard chains without excessive abrasion. A depth stop protects the chain from excessive material removal. The angle gauge and chain tensioner ensure the chain is ideally positioned for fast, precision grinding. The sharpener is supplied without a battery and charger which are available separately.

Features

- Depth stop
- Scala for precise setting of the grinding angle
- Clamping device
- Grinding wheel
- LED light
- No battery and no charger

Technical Data

- Idle speed

- Number of accumulators

6500 min^-1 0 Pieces

285 x 220 x 170 mm

590 x 460 x 190 mm

1940 | 3880 | 4728

1.68

1.98


4 Pieces

8.7 kg

Logistic Data

- Product weight (kg)
- Gross weight (kg)
- Dimensions single packaging
- Pieces per export carton
- Gross weight of export carton
- Dimensions export carton
- Container quantity (20"/40"/40"HC)









Illustrations can contain accessories, which are not included in standard extent of delivery Illustration similar (in design), production-wise modifications reserved GS mark belongs to the product itself only, excluded accessory Generated at: 20.06.2016 08:00 Pane 1

Available as special accessories



Grinding Disc 4,5 mm Accessory garden technique Item No.: 4500071 Bar Code: 4006825548853 Einhell Grey



Grinding Disc Kit 3,2 mm Accessory garden technique Item No.: 4500076 Bar Code: 4006825548860 Einhell Grey