



ORDERING CODES

Solenoid Valf Solenoid Valve Nominal Ölçü Nominal Bore(mm) Hidrolik Şema Tablo 1 Hydraulic Schema Table 1 Kontrol Şekilleri / Type of Control Solenoid / Solenoid1 Hidrolik / Hydraulic2 Mekanik / Mechanic4 Pnematik / Pneumatic6 Manual / Manual7	RH				Modifikasyon Modification Voltaj/ Voltage Frekans/ Frequency [V] [Hz] 12 00 24 00 110 50 220/380 50
---	------------------	---------	---------	---------	---



HİDROLİK ŞEMA (Tablo 1) HYDRAULIC SCHEMA (Table 1)

SİPARİŞ KODU / ORDERING CODE	SEMBOL / SYMBOL	SİPARİŞ KODU / ORDERING CODE	SEMBOL / SYMBOL	SİPARİŞ KODU / ORDERING CODE	SEMBOL / SYMBOL
00		16		39	
01		17		40	
02		18		41	
04		20*		42	
05		21		45	
06		24		61	
08		26		62	
10		27		64	
11		28		68	
12		32		70	
13		33		83	
14		36		20*-with detent	




Montaj Arayüzü: ISO 4401-AV-03-4-A
Mounting Interface: ISO 4401-AV-03-4-A





RH06.../220V AC






RH06.../12V;24V DC



Montaj Arayüzü: ISO 4401-AC-05--4-A
Mounting Interface: ISO 4401-AC-05--4-A
Unit: mm



RH10.../220V AC



Montaj Arayüzü: ISO 4401-AC-05--4-A
Mounting Interface: ISO 4401-AC-05--4-A
Unit: mm

RH10.../12V;24V DC

