




























# LV20021702T

## Гриль-барбекю вугільний

### Інструкція




1		X2	11		X2
2		X1	12		X1
3		X1	13		X2
4		X1	14		X1
5		X1	15		X1
6		X2	16		X1
7		X2	17		X1
8		X1	18		X1
9		X4	19		X1
10		X2	20		X1

A	 (M5x12)	X1	E		X2
B	 (M6)	X9	F	 (M5)	X2
C	 (M6x12)	X11	G	 (M6)	X1
D	 (M8)	X2			


Á

Κροκά




Á Á


Άκροά




Άκροά




Άκροά




### АкроА



### АкроА



### КрокА



### АкроА

