









































LV20021704B


Гриль-барбекю вугільний Інструкція



1		X2	10		X1	19		X4
2		X1	11		X1	20		X1
3		X1	12		X1	21		X1
4		X1	13		X1	22		X1
5		X1	14		X3	23		X2
6		X2	15		X3	24		X1
7		X1	16		X2	25		X2
8		X2	17		X2	26		X1
9		X1	18		X1	27		X1
						28		X2


A		M6x50	X4	G		M5	X22
B		M8	X2	H		M6x20	X4
C		M6x12	X14	I		M5x40	X2
D		M6	X17	J		M5x12	X8
E		M6	X2	K		M6x12	X2
F		M5x20	X12				

Крок 1




Á Á


Крок 2




Крок 3




Крок 4



Крок 5




Крок 6




- C ⊕ M6x12 X4
- D ⊙ M6 X4
- F ⊕ M5x15 X12
- G ⊙ M5 X12

Крок 7



- J ⊕ M5x12 X2
- G ⊙ M5 X2
- H ⊕ M6x20 X2

Крок 8



- J ⊕ M5x12 X6
- G ⊙ M5 X8
- H ⊕ M6x20 X2
- I ⊕ M5x40 X2
- K ⊕ M6X12 X2

Крок 9

