













LV20021707K








Гриль-барбекю вугільний Інструкція












УВАГА! При використанні гриля-барбекю вугільного необхідно дотримуватися всіх правил безпеки, наведених в інструкції.







a	 M6*40	12
b	 M6*12	9
c	 M6*12	2
d	 M6	19
e	 M5*30	6
f	M8	2
g	M5	6

A		1
B		1
C		1
D		1
E		1
F		1
G		1


H	 337X246.5mm	1
I		2
G	 355X220mm	1
K		1
L		1
M		1
N		1

O		2
P		2
Q		2
R		1
S		1
T		1
U		2
V		2







7




8




9



10



11



12

