

# **Acrel Three phase Meter Installation**

Model: ACR10R-D10TE4/C45



## 01

### **INTRODUCTION**

Acrel Smart Meter is designed with high precision small dimensions, convenient operation and installation.

It is available for both single-phase and three-phase grid system connection to detect voltage, current, power and energy.


Any fault or damage caused by misoperation or disobeyal against the rules on manual is beyond Acrel warrenty cover range.

#### **NOTE:**


Only suitable for RS485 cable connection on RJ45 port of sermatec hybrid inverters.

#### 02

# **INSTALLATION**



#### WIRING FOR THREE-PHASE METER (Model: ACR10R-D10TE4/C45) 03





(1) Make sure AC cable is totally isolated from AC power before connecting Meter and CT.

(2)Incorrect connection or direction will cause incorrect data.