


WC4-301 Beretta M84



1-01	Frame(L)	1	1-19	Recoil Spring	1	7-01	Valve Ring	1
1-02	Frame(R)	1	1-20	BB Stopper Spring	1	7-02	Valve Seal	1
1-03	Trigger	1	1-21	Fixing Guide Spring	1	7-03	Piercer Seal	1
1-04	Safety	1	1-22	Trigger Spring	1	7-04	Valve Chamber	1
1-05	Recoil Spring Stopper	1	1-23	Safety Spring	1	7-05	Valve Cover	1
1-06	Safety Level	1	1-24	Mag. Catch Spring	1	7-06	Valve Spring	1
1-07	Mag. Catch	1	1-25	Attacked Block	1	7-07	Valve	1
1-08	Safety Parts	1	1-26	BB Stopper	1	7-08	Copper Ring	1
						7-09	Filter	1
						7-10	Piercer	1
						7-11	Fixing Ring	1
						8A	Knob Combination	1
						8-02	Co2 Cartridge House	1

3-01	Barrel Seat(R)	1
3-02	Barrel Seat(L)	1
3-03	Ejector(R)	1
3-04	Ejector(L)	1
3-05	Ejector Spring	1
3-06	Internal Barrel	1
3-08	Screw	1
3-09	C Washer	1
3-10	Screw	2
5-01	Mag. Body	1
5-02	Mag. Cover	1
5-03	BB Follower	1
5-04	BB Guide	1
5-06	Mag. Spring	1
5-07	BB Guide Spring	1