

HYDROSTATY DANFOSS NUMERY KATALOGOWE

www.bibusmenos.pl

**MAMY PRODUKT,
KTÓREGO SZUKASZ!**



By dowiedzieć się więcej
zapraszamy do kontaktu z naszymi handlowcami.

**KONTAKT
HYDRAULIKA**

**OFERTA
HYDRAULIKA**

Numer kat.	Opis produktu	Kod produktu	Linia produkcyjna	Typ produktu
000075	PUMP-VAR-DISPL CW 20PV052	SPV2/052--R3Z-PS123-A1	SERIES 20	S20-052PV
000083	PUMP-VAR-DISPL CCW 20PV052	SPV2/052--L3Z-PS123-A1	SERIES 20	S20-052PV
000091	MOTOR-FIXED-DISPL 20MF052	SMF2/052--B3Z-MS35352-A1	SERIES 20	S20-052MF
000117	PUMP-VAR-DISPL CW 20PV070	SPV2/070--R3Z-PS183-B1	SERIES 20	S20-070PV
000125	PUMP-VAR-DISPL CCW 20PV070	SPV2/070--L3Z-PS183-B1	SERIES 20	S20-070PV
000133	MOTOR-FIXED-DISPL 20MF070	SMF2/070--B3Z-MS35352-A1	SERIES 20	S20-070MF
000158	PUMP-VAR-DISPL CW 20PV089	SPV2/089--R3Z-PS183-B1	SERIES 20	S20-089PV
000166	PUMP-VAR-DISPL CCW 20PV089	SPV2/089--L3Z-PS183-B1	SERIES 20	S20-089PV
000174	MOTOR-FIXED-DISPL 20MF089	SMF2/089--B3Z-MS35352-A1	SERIES 20	S20-089MF
000497	LOZISKO VNUT.KR.24 BMF22KEGELR.L.G.I.R.2		SERIES 20	PARTS - S20 - Purchased Parts
001297	KOLIK 9,53 X 25,4 BOLZEN		SERIES 20	PARTS - S20 - Purchased Parts
005363	HRIADEL WELLE F.FUELLP.		SERIES 20	PARTS - S20 - Purchased Parts
006791	PLATE GR SPR		SERIES 20	PARTS - S20 - Unique
007542	PISTON		SERIES 20	PARTS - S20 - Unique
008102	MOTOR-FIXED-DISPL 20MF089	SMF2/089--B3Z-VXX-A1	SERIES 20	S20-089MF
016790	MOTOR-FIXED-DISPL 20MF070	SMF2/070--B3Z-MS28282-A1	SERIES 20	S20-070MF
016832	MOTOR-FIXED-DISPL 20MF052	SMF2/052--B3Z-AM01000-A1	SERIES 20	S20-052MF
018903	PUMP-VAR-DISPL CCW 20PV052	SPV2/052--L3Z-PS183-A1	SERIES 20	S20-052PV
018952	MOTOR-FIXED-DISPL 20MF089	SMF2/089--B3Z-AM01000-A1	SERIES 20	S20-089MF
037994	MOTOR-FIXED-DISPL 20MF070	SMF2/070--B3Z-MS42422-A1	SERIES 20	S20-070MF
038539	WELLE,PU.15 17Z.		LIGHT DUTY	PARTS - Low Power
039156	SHAFT		LIGHT DUTY	PARTS - Low Power
039644	SHAFT PUMP		SERIES 20	PARTS - S20 - Unique
046102	LOZISKO VNUT.KR. KEGELR.LG.I.R.DI		SERIES 20	PARTS - S20 - Purchased Parts
047027	GASKET		LIGHT DUTY	PARTS - Low Power
048165	FLANSCH		LIGHT DUTY	PARTS - Low Power
048579	MOTOR-FIXED-DISPL 20MF052	SMF2/052--B3Z-MS24242-A1	SERIES 20	S20-052MF
049502	COMPRESSION SPRING		SERIES 20	PARTS - S20 - Purchased Parts
050021	SHIM PACK		SERIES 20	PARTS - S20 - Unique
051193	SHAFT		LIGHT DUTY	PARTS - Low Power
051219	SWASH PLATE		LIGHT DUTY	PARTS - Low Power
051797	COVER		LIGHT DUTY	PARTS - Low Power
052423	SERVICE-DICHT.-SATZ F.SMF 18		LIGHT DUTY	PARTS - Low Power
059154	PUMP-VAR-DISPL CCW 20PV089	SPV2/089--L3A-PS123-A1	SERIES 20	S20-089PV
062794	HOUSING		SERIES 20	PARTS - S20 - Unique

070318	SHAFT SEAL		LIGHT DUTY	PARTS - Low Power
071217	SHAFT		LIGHT DUTY	PARTS - Low Power
071258	WELLE,PU.15		LIGHT DUTY	PARTS - Low Power
071373	SHAFT		LIGHT DUTY	PARTS - Low Power
072280	MOTOR-FIXED-DISPL 20MF089	SMF2/089--B3A-MS35352-A1	SERIES 20	S20-089MF
077719	MOTOR-FIXED-DISPL 20MF070	SMF2/070--B3Z-MS38382-A1	SERIES 20	S20-070MF
079947	SHAFT		LIGHT DUTY	PARTS - Low Power
080002	SHAFT SEAL		LIGHT DUTY	PARTS - Low Power
080010	SHAFT SEAL		LIGHT DUTY	PARTS - Low Power
083824	MOTOR-FIXED-DISPL 20MF070	SMF2/070--B3Z-AM2000-241-A1	SERIES 20	S20-070MF
085852	SHAFT SEAL		LIGHT DUTY	PARTS - Low Power
087494	SEAL KIT		LIGHT DUTY	PARTS - Low Power
087577	SHAFT		LIGHT DUTY	PARTS - Low Power
1010367-2003	CONTROL-VALVE 2/119 ASSY		SERIES 20	PARTS - S20 - Purchased Parts
1020276	SHAFT		SERIES 20	PARTS - S20 - Unique
1030155-SA	PLUG ASSY		SERIES 20	PARTS - S20 - Unique
1030421	DICHTUNG		LP SHARED PARTS	LP SHARED PARTS
11000243	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A3-C2-N-D5-G-G2-H4-L-42-L-42-L-M-30-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
11000286	HOUSING-PUMP MPT025		LIGHT DUTY	PARTS - Low Power
11000292	PUMP-VAR-DISPL CW 42PV41	42-R-41-D-F2NN-73-J-2-G-2-F-N-N-28-28-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
11000296	PUMP-VAR-DISPL CW 90PV055	90R055-KA-5-NN-60-S-3-C6-D-03-GBA-42-42-24	SERIES 90	S90-055PV
11000359	PUMP-VAR-DISPL MPV046	MPV-046-C-B-A-H-L-B-A-AA-A-A-BFF-CD-A-GG-A-NNN	M46	M46-046PV
11000402	PUMP-VAR-DISPL CW 90PV055	90R055-HF-5-AB-60-L-4-C6-D-03-GBA-29-29-20	SERIES 90	S90-055PV
11000503	PUMP-VAR-DISPL MPV046	MPV-046-C-B-B-H-R-B-S-AA-A-A-BFF-CB-A-GG-A-NNN	M46	M46-046PV
11000550	PUMP-VAR-DISPL CCW 90PV055	90L055-KA-5-BC-60-P-3-S1-D-03-GBA-17-17-20	SERIES 90	S90-055PV
11000566	PUMP-VAR-DISPL CW 90PV055	90R055-PB-5-AB-60-S-3-C6-C-04-GBA-21-21-20	SERIES 90	S90-055PV
11000650	PUMP-VAR-DISPL CW 90PV055	90R055-KA-5-NN-80-S-4-C6-C-03-GBA-32-32-24	SERIES 90	S90-055PV
11000653	PUMP-VAR-DISPL CCW H1PV165	H1-P-165-L-C-A3-C2-N-D6-G-G3-H3-L-42-L-42-L-L-20-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
11000659	COVER-PORT H1P060-100 DN25		H1-HP PUMPS	PARTS - H1-PV
11000663	PUMP-VAR-DISPL CCW 90PV055	90L055-KA-5-NN-80-P-3-C6-C-00-EEB-29-29-24	SERIES 90	S90-055PV
11000668	PUMP-VAR-DISPL CW 42PV41	42-R-41-D-ANNB-03-B-2-G-2-C-N-B-30-30-N-A-A-NNN-NNN	SERIES 42	S42-041PV/051PV
11000672	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A2-C2-N-D8-G-G2-NN-L-42-L-42-A-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
11000673	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A2-C2-N-D8-G-G2-NN-L-42-L-42-A-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
11000805	PUMP-VAR-DISPL CCW 90PV055	90L055-KA-5-NN-80-P-3-C6-C-03-GBA-38-38-24	SERIES 90	S90-055PV
11000806	PUMP-VAR-DISPL MPV035	MPV-035-D-B-A-G-W-S-E-BA-A-A-BFF-DR-A-FF-A-NNN	M35/44	035PV
11000821	PUMP-VAR-DISPL MPV046	MPV-046-C-B-B-L-B-J-BA-A-A-BFF-CE-A-JJ-C-NNN	M46	M46-046PV

11000837	PUMP-VAR-DISPL CCW 90PV055	90L055-HF-5-NN-60-S-4-S1-C-03-GBA-23-23-24	SERIES 90	S90-055PV
11000840	PUMP-VAR-DISPL CCW 90PV055	90L055-HF-5-CD-60-S-4-C6-C-03-GBA-23-23-24	SERIES 90	S90-055PV
11000847	MOTOR-FIXED-DISPL 90MF130	90-M-130-NC-0-N-8-N-0-F1-W-00-EBA-00-00-E6	SERIES 90	S90-130MF
11000849	PUMP-VAR-DISPL CW 42PV28	42-R-28-D-E1A6-02-B-D-B-2-C-N-A-30-30-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
11000850	PUMP-VAR-DISPL CW 42PV28	42-R-28-D-E1A6-02-B-D-B-2-C-N-V-30-30-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
11000868	PUMP-VAR-DISPL MPV035	MPV-035-D-B-A-G-5-S-G-AA-A-A-BJJ-DR-A-FF-A-NNN	M35/44	035PV
11000946	PUMP-VAR-DISPL CCW 90PV055	90L055-KA-P-AB-60-S-3-S1-C-03-GBA-48-48-24	SERIES 90	S90-055PV
11000955	PUMP-VAR-DISPL CCW 90PV055	90L055-KA-5-NN-80-R-4-C6-D-03-GBA-26-26-22	SERIES 90	S90-055PV
11000962	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A2-C3-N-D8-H-G9-H5-L-42-L-42-C-P-20-PN-C03-NNN	H1-HP PUMPS	H1-069PV/078PV
11000966	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A8-C2-C-D8-H-G9-NN-K-45-K-45-N-E-28-P1-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
11001000	PUMP-VAR-DISPL MPV035	MPV-035-D-B-A-Y-R-S-F-AA-A-A-CMA-DR-A-FF-C-NNN	M35/44	035PV
11001025	PUMP-VAR-DISPL CW 42PV41	42-R-41-D-E1A6-03-B-2-G-2-C-N-V-34-34-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
11001026	PUMP-VAR-DISPL CCW 90PV055	90L055-KA-5-NN-80-S-3-S1-D-05-GBA-40-40-20	SERIES 90	S90-055PV
11001027	PUMP-VAR-DISPL CCW 90PV055	90L055-KA-5-CD-60-P-3-S1-C-04-GBA-26-26-20	SERIES 90	S90-055PV
11001077	PUMP-VAR-DISPL MPV046	MPV-046-C-B-B-K-R-B-A-AA-A-A-BJJ-CB-A-GG-B-NNN	M46	M46-046PV
11001079	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A2-C2-N-D3-G-G3-H2-L-20-L-20-A-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
11001080	PUMP-VAR-DISPL CW 42PV28	42-R-28-G-E1A6-02-B-2-G-2-C-N-N-17-14-B-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
11001093	PUMP-VAR-DISPL CCW 90PV055	90L055-KA-5-BG-80-S-3-S1-D-03-GBA-42-42-28	SERIES 90	S90-055PV
11001137	PUMP-VAR-DISPL CW 90PV055	90R055-KN-5-AB-60-S-3-C6-C-42-GBA-42-42-24	SERIES 90	S90-055PV
11001140	PUMP-VAR-DISPL CW 90PV055	90R055-FC-2-AB-60-S-7-C6-D-B1-GLA-45-45-30	SERIES 90	S90-055PV
11001147	MOTOR-FIXED-DISPL 90MF130	90-M-130-NC-0-N-8-N-0-C8-W-00-EAD-00-00-G3-P040	SERIES 90	S90-130MF
11001188	PUMP-VAR-DISPL CCW 42PV41	42-L-41-C-E1A6-02-B-2-B-2-F-N-A-30-30-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
11001190	PUMP-VAR-DISPL CW 90PV055	90R055-EA-5-NN-60-S-4-T1-C-01-GBA-35-35-20	SERIES 90	S90-055PV
11001275	PUMP-VAR-DISPL CW 90PV055	90R055-HF-5-AB-60-S-3-C6-D-03-GBA-29-29-24	SERIES 90	S90-055PV
11001296	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A2-C2-N-D8-G-G2-H6-L-42-L-42-A-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
11001462	PUMP-VAR-DISPL CCW 42PV41	42-L-41-D-F2NN-73-J-D-G-2-C-N-A-21-21-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
11001488	MOTOR-FIXED-DISPL 90MF130	90-M-130-NC-0-N-8-N-0-C8-W-00-EBA-00-00-E6	SERIES 90	S90-130MF
11001489	PUMP-VAR-DISPL CW 42PV28	42-R-28-D-E1A6-03-B-2-B-2-F-N-B-34-34-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
11001527	MOTOR-FIXED-DISPL 90MF130	90-M-130-NC-0-N-8-N-0-C8-W-00-NNN-00-00-G3-P040	SERIES 90	S90-130MF
11001532	PUMP-VAR-DISPL CCW 90PV055	90L055-KA-5-NN-80-R-3-S1-C-03-GBA-26-26-24	SERIES 90	S90-055PV
11001673	PUMP-VAR-DISPL CCW 90PV055	90L055-KA-5-BB-60-R-3-C6-C-02-GBA-35-35-24	SERIES 90	S90-055PV
11001728	PUMP-VAR-DISPL MPV046	MPV-046-C-B-B-K-R-B-A-AA-A-A-BHH-CD-A-GG-B-NNN	M46	M46-046PV
11001896	PUMP-VAR-DISPL CW 90PV055	90L055-KP-5-CD-80-S-4-S1-C-03-GBA-29-29-20	SERIES 90	S90-055PV
11001897	PUMP-VAR-DISPL CW 90PV055	90L055-KP-5-AD-80-S-4-S1-C-03-GBA-29-29-20	SERIES 90	S90-055PV
11001911	PUMP-VAR-DISPL MPV046	MPV-046-C-B-B-K-S-B-B-BA-A-A-BJJ-BA-A-HH-B-NNN	M46	M46-046PV
11001961	PUMP-VAR-DISPL CCW H1PV078	H1-P-078-L-A-A2-C2-N-D3-H-G9-H2-L-30-L-30-C-M-20-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV

11001994	PUMP-VAR-DISPL CW 90PV055	90R055-KA-5-CD-80-S-3-C6-C-03-GBA-42-42-24	SERIES 90	S90-055PV
11002065	PUMP-VAR-DISPL CCW H1PV078	H1-P-078-L-A-A3-C2-N-F6-H-G9-H6-L-42-L-42-C-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
11002066	PUMP-VAR-DISPL CCW H1PV078	H1-P-078-L-A-A3-C2-N-D6-H-G1-NN-L-42-L-42-C-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
11002067	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A2-C2-B-D8-G-G3-NN-L-42-L-42-A-P-30-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
11002103	PUMP-VAR-DISPL CW 42PV041	42-R-41-D-G1A1-72-J-3-C-3-F-5-V-34-34-N-0-0-NNN-NNN	SERIES 42	S42-041PV/051PV
11002124	PUMP-VAR-DISPL CCW 90PV130	90L130-FH-V-NV-8E-R-7-F4-F-B9-GB7-45-45-30	SERIES 90	S90-130PV
11002147	PUMP-VAR-DISPL CW 90PV055	90R055-KA-5-NN-80-S-3-C6-C-03-GBA-26-26-24	SERIES 90	S90-055PV
11002165	PUMP-VAR-DISPL CW 90PV055	90R055-KA-5-NN-60-S-3-C6-C-03-GBA-38-38-20	SERIES 90	S90-055PV
11002327	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A2-C2-N-D3-G-G3-NN-L-35-L-20-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
11002445	PUMP-VAR-DISPL CCW 90PV055	90L055-DD-5-BC-60-S-3-S1-B-50-GBA-38-38-24	SERIES 90	S90-055PV
11002450	PUMP-VAR-DISPL CW 90PV055	90R055-MA-5-CD-80-P-3-C6-C-05-GBA-26-26-24	SERIES 90	S90-055PV
11002495	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A4-C3-N-E8-G-G2-H3-L-42-L-42-L-L-30-PN-NNN-G25	H1-HP PUMPS	H1-147PV/165PV
11002561	PUMP-VAR-DISPL CW 90PV055	90R055-MA-5-BC-60-S-4-C6-C-C5-FAB-42-42-24	SERIES 90	S90-055PV
11002586	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A8-C2-C-D8-H-G9-H5-L-42-L-42-N-E-24-P1-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
11002609	PUMP-VAR-DISPL CCW H1PV165	H1-P-165-R-C-A2-C2-N-D8-G-G3-H5-L-33-L-33-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
11002612	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A2-C2-N-D3-G-G3-H6-L-35-L-35-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
11002631	PUMP-VAR-DISPL CW 90PV055	90R055-KA-5-NN-80-P-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
11002898	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A3-C2-N-D9-G-G3-H4-L-45-L-45-L-L-30-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
11003501	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A2-C2-N-D8-G-G2-H6-L-38-L-38-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
11004018	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A2-C2-N-D6-H-G9-H3-L-45-L-45-C-L-20-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
11004439	PUMP-VAR-DISPL CCW H1PV147	H1-P-147-L-C-A3-C2-B-D6-G-G3-NN-L-25-L-25-L-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
11005254	PUMP-VAR-DISPL CCW H1PV165	H1-P-165-L-C-A3-C3-N-D6-G-G3-H2-L-42-L-42-L-L-20-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
11005448	PUMP-VAR-DISPL CCW H1PV165	H1-P-165-L-C-A5-C2-B-D3-G-G3-H6-L-35-L-35-A-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
11005450	PUMP-VAR-DISPL CCW H1PV147	H1-P-147-L-C-A5-C2-N-D8-G-G3-H6-L-42-L-42-A-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
11005451	PUMP-VAR DISPL CCW H1PV165	H1-P-165-L-C-A4-C2-N-D8-G-G3-H6-L-38-L-38-A-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
11005463	PUMP-VAR DISPLM CCW H1PV147	H1-P-147-L-C-A2-C2-N-D3-G-G3-H6-L-35-L-35-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
11005673	PUMP-VAR-DISPL CCW H1PV147	H1-P-147-L-C-A4-C2-N-D3-G-G3-H3-L-30-L-30-A-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
11006033	MOTOR-FIXED-DISPL 90MF130	90-M-130-NC-0-N-8-N-0-F1-N-00-EBA-00-00-00	SERIES 90	S90-130MF
11006037	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A2-C2-N-D3-G-G2-NN-L-42-L-42-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
11006191	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A2-C2-N-D6-G-G3-H3-L-42-L-42-L-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
11006212	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A2-C2-N-D9-G-G2-H4-L-42-L-42-L-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
11006484	PUMP-VAR-DISPL CCW H1PV078	H1-P-078-L-A-A2-C2-N-F5-H-F1-H6-L-33-L-33-C-P-28-PN-C07-NNN	H1-HP PUMPS	H1-069PV/078PV
11006880	PUMP-VAR-DISPL CCW H1PV165	H1-P-165-L-C-A5-C2-B-D3-G-G3-H6-L-35-L-35-A-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
11007567	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A4-C3-N-D3-G-G2-H2-L-42-L-42-L-M-30-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
11007568	PUMP-VAR-DISPL CCW H1PV147	H1-P-147-L-C-A2-C2-N-D6-G-G3-H3-L-42-L-42-A-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
11007657	PUMP-VAR-DISPL CCW H1PV165	H1-P-165-L-C-A5-C2-N-D8-G-G3-H6-L-35-L-35-A-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV

11008314	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A8-C2-C-D8-H-G9-H2-K-45-K-45-N-E-28-P1-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
11009112	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A5-C2-N-D7-G-G2-H4-L-42-L-42-A-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
11009115	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A2-C2-N-D8-G-G2-H2-L-35-L-35-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
11009620	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A3-C2-N-F6-H-G9-H6-L-42-L-42-C-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
11009635	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A8-C2-C-D8-H-G9-H3-K-48-K-48-C-P-28-P1-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
11009785	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A4-C3-N-E8-G-G2-H3-L-42-L-42-L-L-30-PN-NNN-G25	H1-HP PUMPS	H1-147PV/165PV
11009797	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A2-C2-N-D3-G-G3-H6-L-42-L-42-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
11009798	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A8-C2-C-D3-H-G9-H3-L-42-L-42-C-M-24-P1-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
11010006	MOTOR-VAR-DISPL H1B080	H1-B-080-A-M1-CA-N-B-RB-CS-AS-S-A-10-NN-000-N-00-NNN	H1-HP MOTORS	H1-080MB1
11010281	MOTOR-FIXED-DISPL 90MF130	90-M-130-NC-0-N-8-N-0-F1-W-00-EEA-00-00-G0	SERIES 90	S90-130MF
11010347	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A4-C2-N-D5-G-G3-H4-L-40-L-40-A-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
11010724	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-B8-C2-C-D3-G-A9-H6-L-40-L-40-A-M-30-P1-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
11012378	END CAP, H1B110 SP 6162-2 P25M 2POS		H1-HP MOTORS	PARTS - H1-MV
11012744	MOTOR-FIXED-DISPL 90MF130	90-M-130-NC-0-N-8-N-0-C8-W-00-NNN-00-00-E6	SERIES 90	S90-130MF
11013493	MOTOR-FIXED-DISPL 90MF130	90-M-130-NC-0-N-8-N-0-F1-W-00-EBA-00-00-B0	SERIES 90	S90-130MF
11013614	SOLENOID-PROP-THREAD H1B 24V DT04-2P		H1-HP MOTORS	PARTS - H1-MV
11013645	EDC KIT, S20 MCV104A5923		SERIES 20	PARTS - S20 - Unique
11014185	CAP-PLASTIC-SOLENOID-PROP H1B		H1-HP MOTORS	PARTS - H1-MV
11014821	MOTOR-FIXED-DISPL 90MF130	90-M-130-NC-0-N-8-N-0-F1-W-00-NNN-00-00-E6	SERIES 90	S90-130MF
11014822	MOTOR-FIXED-DISPL 90MF130	90-M-130-NC-0-N-8-N-0-F1-W-00-NNN-00-00-G0	SERIES 90	S90-130MF
11016228	SPOOL-VALVE PCOR H1B		H1-HP MOTORS	PARTS - H1-MV
11016348	MOTOR-VAR-DISPL 51MV160	51V160-V-F1-N-H4-B3-R-J-N2-NNN-032-AA-NN-C2-21	SERIES 51	S51-160MV
11016349	MOTOR-VAR-DISPL 51MV250	51V250-V-F2-N-H4-B3-R-J-N2-NNN-050-AA-NN-C2-21	SERIES 51	S51-250MV
11017352	MOTOR-FIXED-DISPL TMM089	TMM089B-3C35-NNC-D-A3F-BDN	TMM / TMP	TMM089
11017691	MOTOR-FIXED-DISPL 90MF130	90-M-130-NC-0-N-8-N-0-C8-W-00-EEA-00-00-F3	SERIES 90	S90-130MF
11018273	HDC KIT, S20 HR MCV106A6905		SERIES 20	PARTS - S20 - Unique
11018283	HDC KIT, S20 POR HR MCV106A8904		SERIES 20	PARTS - S20 - Unique
11018349	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A3-C2-N-D7-G-G3-H4-L-42-L-42-A-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
11018924	PUMP-VAR-DISPL CCW H1PV165	H1-P-165-L-C-A2-C2-N-D4-G-G3-NN-L-42-L-42-L-C-32-PN-NNN-G25	H1-HP PUMPS	H1-147PV/165PV
11020078	MOTOR-FIXED-DISPL 90MF130	90-M-130-NC-0-N-Z-N-0-C8-D-00-HAC-00-00-NH	SERIES 90	S90-130MF
11020417	SERVO-PISTON 2POS H1B110 ASSY		H1-HP MOTORS	PARTS - H1-MV
11021256	VALVE-SEGMENT 2POS H1B110 ASSY		H1-HP MOTORS	PARTS - H1-MV
11021257	REGLER SATZ MPV046 (KUNDENSPEC RANSOMES)		M46	PARTS - M46
11023293	PUMP-VAR-DISPL CCW H1PV165	H1-P-165-L-C-A2-C2-B-D6-G-F3-NN-L-48-L-48-A-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
11023296	PUMP-VAR-DISPL CCW H1PV078	H1-P-078-L-A-B8-C2-C-D3-H-G9-NN-L-38-L-38-C-M-24-P1-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
11023402	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A7-C2-C-D6-K-G1-H3-L-42-L-42-C-L-24-P2-NNN-D01	H1-HP PUMPS	H1-069PV/078PV

11023567	MOTOR-FIXED-DISPL 90MF100	90-M-100-NC-0-N-8-N-0-S1-W-00-NNN-00-00-H0	SERIES 90	S90-100MF
11024201	END CAP, H1B080 AP 6162-2 P25M 2POS		H1-HP MOTORS	PARTS - H1-MV
11024212	END CAP, H1B080 SP 6162-2 P25M 2POS		H1-HP MOTORS	PARTS - H1-MV
11025270	MOTOR-FIXED-DISPL 90MF130	90-M-130-NC-0-N-8-N-0-F1-W-00-NNN-00-00-E4	SERIES 90	S90-130MF
11025494	PUMP-VAR-DISPL SPV15		LIGHT DUTY	S10-015PV
11025841	MOTOR-VAR-DISPL H1B110	H1-B-110-A-M1-CA-N-A-RB-CS-JS-S-A-15-NN-000-N-00-NNN	H1-HP MOTORS	H1-110MB1
11025865	MOTOR-VAR-DISPL H1B110	H1-B-110-A-K2-K2-N-A-RA-VN-DN-N-N-NN-NN-022-N-18-NNN	H1-HP MOTORS	H1-110MB1
11027905	MOTOR-FIXED-DISPL 20MF227	SMF2/227-B6Z-MR42422-A1	SERIES 20	S20-227MF
11027907	MOTOR-FIXED-DISPL 20MF166	SMF2/166-B6Z-MR42422-A1	SERIES 20	S20-166MF
11030634	MOTOR-FIXED-DISPL 90MF100	90-M-100-NC-0-N-8-N-0-C7-W-00-EFA-00-00-E6	SERIES 90	S90-100MF
11032931	PUMP VAR CCW		LIGHT DUTY	S10-015PV
11035928	PUMP-VAR-DISPL CW 90PV130	90R130-NA-Z-NV-8K-V-3-C4-F-04-GB9-42-42-30-L003	SERIES 90	S90-130PV
11039118	MOTOR-VAR-DISPL H1B110#	H1-B-110-A-P1-D1-N-C-TA-DN-KN-N-A-15-NN-030-Z-24-N06	H1-HP MOTORS	H1-110MB1
11039184	ADAPTER SAE-C 90PV130 2-BOLT		SERIES 90	PARTS - S90
11039872	MOTOR-FIXED-DISPL TMM089	TMM089B-6C42-NNN-D-A3M-BDN	TMM / TMP	TMM089
11039873	MOTOR-FIXED-DISPL TMM070	TMM070B-6C42-NNN-D-A3M-BDN	TMM / TMP	TMM070
11039877	MOTOR-FIXED-DISPL TMM089	TMM089B-6MNN-NNN-D-D2M-BDN	TMM / TMP	TMM089
11039879	MOTOR-FIXED-DISPL TMM070	TMM070B-6MNN-NNN-D-D2M-BDN	TMM / TMP	TMM070
11040311	MOTOR-VAR-DISPL H1B110	H1-B-110-A-L1-BA-N-N-PA-VS-DS-S-A-15-NN-000-N-00-NNN	H1-HP MOTORS	H1-110MB1
11040312	MOTOR-VAR-DISPL H1B080	H1-B-080-A-L1-BA-N-N-PB-VS-AS-S-A-10-NN-000-N-00-NNN	H1-HP MOTORS	H1-080MB1
11040384	MOTOR-FIXED-DISPL 90MF100	90-M-100-NC-0-N-X-N-0-C7-W-00-CBF-00-00-B3	SERIES 90	S90-100MF
11041110	PUMP-VAR-DISPL SPV15		LIGHT DUTY	S10-015PV
11041474	MOTOR-VAR-DISPL H1B080	H1-B-080-A-M1-CA-N-A-RB-CS-HS-S-A-10-NN-000-N-00-NNN	H1-HP MOTORS	H1-080MB1
11041573	MOTOR-VAR-DISPL H1B110#	H1-B-110-A-P1-D1-N-A-TA-DN-JN-N-A-15-NN-048-Z-24-N11	H1-HP MOTORS	H1-110MB1
11042843	MOTOR-VAR-DISPL H1B110	H1-B-110-A-K1-K1-N-C-RA-DS-KS-S-A-15-NN-042-N-24-NNN	H1-HP MOTORS	H1-110MB1
11043125	VALVE-SEGMENT 2POS H1B060 ASSY		H1-HP MOTORS	PARTS - H1-MV
11043127	KIT-CYLINDER-BLOCK H1B060 ASSY		H1-HP MOTORS	PARTS - H1-MV
11043187	SHAFT-SP H1B060 14T DIN5480 ASSY (GS)		H1-HP MOTORS	PARTS - H1-MV
11044425	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-A-A2-C2-N-D8-H-G9-H2-L-45-L-45-M-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
11044427	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A2-C2-N-D8-H-G9-H2-L-45-L-45-M-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
11046243	MOTOR-FIXED-DISPL 90MF100	90-M-100-NC-0-N-8-N-0-C7-W-00-NNN-00-00-G3	SERIES 90	S90-100MF
11046631	PISTON-SERVO 90PV130 ASSY NFPE		SERIES 90	PARTS - S90
11047944	MOTOR-FIXED-DISPL 90MF100	90-M-100-NC-0-N-7-N-0-K3-N-00-NNN-00-00-00	SERIES 90	S90-100MF
11050997	MOTOR-FIXED-DISPL 90MF100	90-M-100-NC-0-N-8-N-0-K3-W-00-EAA-00-00-F3	SERIES 90	S90-100MF
11051756	TRANSMISSION LDU 20 U-STYLE CW	LDU-20D-R-A-L-S-JJ-J-A-N-07-N-28N-28N-NNN-NNN	DDC20/LDU20	OSK-020U - DO NOT USE
11052595	MOTOR-FIXED-DISPL 90MF100	90-M-100-NC-0-N-8-N-0-C7-W-00-EGL-00-00-H0	SERIES 90	S90-100MF

11052982	PUMP-VAR-DISPL CCW 20PV166	SPV2/166-L6P-PS193-VAD500-A1	SERIES 20	S20-166PV
11054402	SERVICE VALVE-SEGMENT 2POS H1B160 ASSY		H1-HP MOTORS	PARTS - H1-MV
11055627	PUMP-VAR, CCW		LIGHT DUTY	S10-015PV
11056369	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-NN-60-R-4-S1-E-03-GBA-26-26-24	SERIES 90	S90-075PV
11056664	PUMP-VAR DISPL, MPV046	MPV-046-C-B-A-B-R-B-A-AA-G-A-BFF-AB-U-BD-A-NNN	M46	M46-046PV
11057787	BEARING-SLIPPER GUIDE 90PV055		SERIES 90	PARTS - S90
11058342	MOTOR-FIXED-DISPL 90MF100	90-M-100-NC-0-N-8-N-0-S1-W-00-NNN-00-00-G3	SERIES 90	S90-100MF
11058518	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-1-NN-80-S-4-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
11058846	PUMP-VAR DISPL, CW 90PV250	90-R-250-KA-5-AB-80-T-3-F1-K-03-NNN-35-35-28	SERIES 90	S90-250PV
11058857	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-1-CD-60-S-4-S1-E-33-GBA-26-26-30	SERIES 90	S90-075PV
11058858	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-BC-60-S-4-S1-E-33-GBA-26-26-30	SERIES 90	S90-075PV
11059655	MOTOR-FIXED DISPL, 90MF075	90-M-075-NC-0-N-8-N-0-C6-N-00-NNN-00-00-00	SERIES 90	S90-075MF
11059805	MOTOR-FIXED-DISPL 90MF100	90-M-100-NC-0-N-7-N-0-C7-W-00-NNN-00-00-G3	SERIES 90	S90-100MF
11060218	MOTOR-FIXED-DISPL 90MF100	90-M-100-NC-0-N-7-N-0-S1-W-00-NNN-00-00-F0	SERIES 90	S90-100MF
11060521	PUMP-VAR DISPL, CW 90PV130	90-R-130-KA-1-CD-80-S-3-F1-F-33-GBA-32-32-24	SERIES 90	S90-130PV
11060834	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-BC-80-R-4-F1-F-03-GBA-38-38-24	SERIES 90	S90-100PV
11060899	PUMP-VAR DISPL, MPV046	MPV-046-C-B-A-G-R-B-A-AA-A-A-BJJ-AB-U-CF-C-NNN	M46	M46-046PV
11060901	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-1-BC-80-S-4-S1-D-02-GBA-32-32-24	SERIES 90	S90-075PV
11060912	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MC-1-BC-60-S-3-S1-E-02-GBA-32-32-24	SERIES 90	S90-100PV
11061958	VALVE-ORIFICED CHECK (0.81MM)		SERIES 90	PARTS - S90
11061981	VALVE-ORIFICED CHECK (1.37MM)		SERIES 90	PARTS - S90
11061993	VALVE-ORIFICED CHECK (1.57MM)		SERIES 90	PARTS - S90
11062150	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-NN-60-R-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-075PV
11062266	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HS-1-BC-60-R-3-S1-D-03-GBA-42-42-30	SERIES 90	S90-055PV
11062268	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-1-BC-60-R-3-S1-E-03-GBA-42-42-30	SERIES 90	S90-100PV
11062322	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-BC-60-R-3-F1-F-03-GBA-42-42-30	SERIES 90	S90-100PV
11062607	PUMP-VAR DISPL, CW 90PV130	90-R-130-KA-1-NN-80-R-3-F1-F-03-GBA-42-42-42	SERIES 90	S90-130PV
11064283	PUMP-VAR DISPL, CCW 90PV250	90-L-250-KA-1-NN-80-S-3-F1-J-03-NNN-35-35-28	SERIES 90	S90-250PV
11064284	PUMP-VAR DISPL, CCW 90PV250	90-L-250-HS-1-CD-80-S-3-F1-J-03-NNN-35-35-28	SERIES 90	S90-250PV
11064364	PUMP-VAR DISPL, CW 90PV250	90-R-250-HS-5-CD-80-T-3-F1-K-03-NNN-23-23-24	SERIES 90	S90-250PV
11064968	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-1-AB-60-S-3-S1-C-33-GBA-26-26-30	SERIES 90	S90-055PV
11065260	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-NN-80-L-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
11065603	MOTOR-VAR DISPL, 51MV160	51V160-R-F1-N-TA-C2-L-N-K7-NNN-064-AA-E4-00-A6	SERIES 51	S51-160MV
11065604	MOTOR-VAR DISPL, 51MV110	51V110-R-F1-N-TA-C2-L-N-K7-NNN-044-AA-E4-00-A6	SERIES 51	S51-110MV-1
11065605	MOTOR-VAR DISPL, 51MV080	51V080-R-S1-N-TA-C2-L-N-K7-NNN-032-AA-E4-00-A6	SERIES 51	S51-080MV
11065656	PUMP-VAR DISPL, CW 90PV130	90-R-130-KA-5-BC-80-P-4-F1-H-03-GBA-35-35-24	SERIES 90	S90-130PV

11065820	MOTOR-FIXED-DISPL 90MF100	90-M-100-NC-0-N-8-N-0-C7-W-00-EFA-00-00-G0	SERIES 90	S90-100MF
11066703	PUMP-VAR DISPL, CW 90PV180	90-R-180-KA-1-NN-80-S-M-C8-H-03-FAC-35-35-28	SERIES 90	S90-180PV
11066712	PUMP-VAR DISPL, CW 90PV180	90-R-180-KN-5-DE-80-S-M-C8-H-33-FAC-42-42-24	SERIES 90	S90-180PV
11066714	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-1-NN-60-S-4-C6-D-03-GBA-35-35-24	SERIES 90	S90-055PV
11067339	MOTOR-FIXED DISPL, 90MF130	90-M-130-NC-0-N-8-N-0-F1-N-00-NNN-00-00-00	SERIES 90	S90-130MF
11067556	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-1-AB-60-P-3-C7-D-03-GBA-42-42-24	SERIES 90	S90-075PV
11068410	PUMP-TANDEM-VAR DISPL S42PT28		SERIES 42	S42-028PT/032PT Bolted Tandem
11068825	PUMP-VAR DISPL, CW 90PV180	90-R-180-KP-5-EG-80-T-M-C8-H-03-FAC-24-24-24	SERIES 90	S90-180PV
11068826	PUMP-VAR DISPL, CW 90PV180	90-R-180-KP-5-NN-80-T-M-C8-H-03-NNN-24-24-24	SERIES 90	S90-180PV
11068998	MOTOR-VAR DISPL, 51MV110	51V110-R-F1-N-HS-A2-A-H-E1-NNN-040-AA-F0-16-30	SERIES 51	S51-110MV-1
11069441	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-CD-60-L-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
11069614	MOTOR-FIXED DISPL, 90MF055	90-M-055-NC-0-N-8-N-0-C6-W-00-EBA-00-00-F0	SERIES 90	S90-055MF
11069964	PUMP-VAR DISPL, MPV046	MPV-046-C-B-A-B-R-B-A-AA-A-A-BFF-AB-U-ED-A-NNN	M46	M46-046PV
11069965	PUMP-VAR DISPL, MPV046	MPV-046-C-B-A-D-R-B-A-AA-A-A-BFF-AB-U-ED-B-NNN	M46	M46-046PV
11070109	PUMP-VAR DISPL, MPV046	MPV-046-C-B-B-A-R-B-A-AA-A-C-BFF-CD-A-JJ-C-NNN	M46	M46-046PV
11070159	SEAL-LIP-PPS 55X70X7.0 W/O DUST-SEAL-LIP		SERIES 51	PARTS - S51
11071356	ASSY-RETAINED PISTON 38CC K		LIGHT DUTY	PARTS - Low Power
11071650	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HS-1-BB-60-R-3-F1-F-03-GBA-42-42-30	SERIES 90	S90-100PV
11071663	PUMP-VAR DISPL, CW 90PV075	90-R-075-CA-1-NN-80-R-4-S1-D-00-GBA-35-35-24	SERIES 90	S90-075PV
11071944	MOTOR-FIXED-DISPL 90MF100	90-M-100-NC-0-N-8-N-0-C6-W-00-EFA-00-00-F3	SERIES 90	S90-100MF
11072091	PVG32 4BK PVEH CC PC BABC OPSP	PVG324BK PVEH CC PVP BABC OPSP-159U7502	PVG32/120	PVG 32 Valve Stack
11072103	PVG32 1BKPVEH CC PVP B OSP 11032865F	PVG32 1BKPVEH CC PVP B OSP-11032865F	PVG32/120	PVG 32 Valve Stack
11072104	PVG32 1BKPVEH CC PVP C OSP 11043516F	PVG32 1BKPVEH CC PVP C OSP-11043516F	PVG32/120	PVG 32 Valve Stack
11072365	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-AB-60-L-4-S1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
11072401	PUMP-VAR DISPL, CW 90PV180	90-R-180-KA-1-NN-80-T-M-F1-H-03-FAC-26-26-28	SERIES 90	S90-180PV
11072856	MOTOR-FIXED DISPL, 90MF075	90-M-075-NC-0-N-8-N-0-S1-N-00-EBA-00-00-00	SERIES 90	S90-075MF
11074206	PUMP-VAR DISPL, MPV046	MPV-046-C-B-B-V-S-B-B-AA-G-A-BFF-CG-A-HH-C-NNN	M46	M46-046PV
11074579	PUMP-VAR DISPL, MPV046	MPV-046-C-B-B-A-R-B-S-AA-A-A-BDD-BB-A-ED-A-NNN	M46	M46-046PV
11075276	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-D-E1A4-02-C-4-N-N-D-N-B-21-21-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
11075277	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-C-E1A4-02-C-4-A-3-D-N-N-21-21-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
11075278	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-D-E1A6-03-C-2-A-2-F-N-B-30-30-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
11075279	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-C-E1A6-03-C-2-A-2-F-N-N-30-30-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
11075280	PUMP-VAR-DISPL 42PV041 CCW	42-L-41-E-E1A5-03-B-2-X-N-E-N-V-34-34-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
11075281	PUMP-VAR-DISPL 42PV041 CCW	42-L-41-D-E1A5-03-B-2-X-A-E-N-Z-34-34-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
11075282	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-D-E1A6-03-C-2-A-2-F-N-B-25-25-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
11075283	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-C-E1A6-03-C-2-A-2-F-N-N-25-25-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV

11075284	PUMP-VAR-DISPL 42PV041 CCW	42-L-51-K-E1A5-01-B-D-G-3-H-N-V-36-36-N-N-N-NNN-NDD	SERIES 42	S42-041PV/051PV
11075285	PUMP-VAR-DISPL 42PV041 CCW	42-L-51-D-E1A5-01-B-D-G-3-H-N-B-36-36-N-N-N-NNN-NDD	SERIES 42	S42-041PV/051PV
11075817	SHAFT-PUMP-2/089-23T		SERIES 20	PARTS - S20 - Unique
11076829	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-NN-60-S-4-C7-E-03-GBA-38-38-24	SERIES 90	S90-100PV
11076999	PUMP-VAR DISPL, CW 90PV075	90-R-075-HS-1-BB-60-S-4-S1-E-03-GBA-32-32-24	SERIES 90	S90-075PV
11077000	PUMP-VAR DISPL, CW 90PV075	90-R-075-HS-1-CD-60-S-4-S1-E-03-GBA-32-32-24	SERIES 90	S90-075PV
11077392	PUMP-VAR-DISPL CW DDC20	DDC-20-A-R-RB-LSA-NN-A-2-N-BA-AAN9-A-07-21A-21A-NNN-NNN	DDC20/LDU20	OSK-020PV - DO NOT USE
11077638	HIGH PRESSURE HOUSE 370L-KIT		SERIES 20	PARTS - S20 - "No Name"
11077676	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KN-1-CD-80-S-4-S1-D-03-GBA-24-14-20	SERIES 90	S90-075PV
11078301	SEAL-SHAFT-S20-2/089 ASSY		SERIES 20	PARTS - S20 - Unique
11078746	DISPLACEMENT 2/089 COMPL		SERIES 20	PARTS - S20 - Unique
11078754	SHAFT-PUMP-23T 2/089 M10		SERIES 20	PARTS - S20 - Unique
11078755	CONTROL-ANLR-ST 2/033-070 SEAL-ST-LEVER		SERIES 20	PARTS - S20 - Unique
11078934	PUMP-VAR-DISPL CW 20PV089	SPV2/089--R6Z-PS183-507-B1	SERIES 20	S20-089PV
11078935	PUMP-VAR-DISPL CW 20PV089	SPV2/089--R6Z-PS183-506-B1	SERIES 20	S20-089PV
11079112	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-AB-60-S-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
11079473	PUMP-VAR-DISPL CW TMP089	TMP-089-EDC024A-R-M42-20G22-N-G-NCN-BDN	TMM / TMP	TMP089
11079475	PVG32 3BK MAN CC PVP E CL OP SP 159U7463	PVG32 3BK MAN CC PVP E CL OPSP-159U7463	PVG32/120	PVG 32 Valve Stack
11079522	ASSY-RETAINED PISTON, 15 SERIES		LIGHT DUTY	PARTS - Low Power
11079772	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-1-NN-60-S-4-C6-C-03-GBA-29-29-20	SERIES 90	S90-055PV
11079913	PUMP-VAR DISPL, MPV046	MPV-046-C-B-A-H-R-B-A-AA-A-A-BDD-AB-U-ED-A-NNN	M46	M46-046PV
11079959	SERVO-SLEEVE-TMP-NFPE-070-ASSY		TMM / TMP	PARTS - TMM/TMP
11080049	PUMP-VAR DISPL CW 90PV055	90R055-DD-1-AB-60-P-4-S1-D-G4-GBA-35-35-20	SERIES 90	S90-055PV
11080051	PUMP-VAR DISPL CW 90PV055	90R055-DD-1-NN-60-P-4-S1-C-GB-GBA-42-42-24	SERIES 90	S90-055PV
11080055	PUMP-VAR DISPL CW 90PV055	90R055-DD-1-NN-60-P-4-S1-D-G4-GBA-35-35-20	SERIES 90	S90-055PV
11080056	PUMP-VAR DISPL CW 90PV055	90R055-DD-1-AB-60-S-4-S1-D-G4-GBA-35-35-20	SERIES 90	S90-055PV
11080057	PUMP-VAR DISPL CW 90PV055	90R055-DD-1-NN-60-S-4-S1-D-G4-GBA-35-35-20	SERIES 90	S90-055PV
11080076	PUMP-VAR DISPL, CW 90PV100	90-R-100-DD-1-CD-80-L-4-F1-E-03-GBA-30-30-24	SERIES 90	S90-100PV
11080077	PUMP-VAR DISPL, CW 90PV100	90-R-100-DD-1-BC-80-L-4-S1-E-03-GBA-30-30-24	SERIES 90	S90-100PV
11080311	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-CD-60-L-4-F1-E-03-GBA-30-30-24	SERIES 90	S90-100PV
11080382	PUMP-VAR DISPL, CW 90PV180	90-R-180-KA-1-CD-80-T-C-C8-J-03-FAC-42-42-30	SERIES 90	S90-180PV
11080876	SYSTEM H1P078R + H1P045R	SYSTEM H1P078R + H1P045R	H1-HP PUMPS	H1-069PT/078PT
11082056	PUMP-VAR DISPL, MPV046	MPV-046-C-B-A-D-R-B-J-AA-A-A-BGG-AB-U-ED-B-NNN	M46	M46-046PV
11082285	PUMP-VAR DISPL, CW 90PV075	90-R-075-HF-1-CD-60-S-4-S1-D-03-GBA-24-24-24	SERIES 90	S90-075PV
11082287	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-AC-60-L-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-075PV
11082291	PUMP-VAR-DISPL CW TMP070	TMP-070-EDC024A-R-M42-20G22-A-G-NCN-BDN	TMM / TMP	TMP070

11082302	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-CD-60-L-4-T2-E-03-GBA-35-35-24	SERIES 90	S90-075PV
11082306	PUMP-VAR-DISPL CW TMP089	TMP-089-EDC024A-R-M42-20G22-A-G-NCN-BDN	TMM / TMP	TMP089
11082791	SHAFT,TMP 21T_16/32-SAE-BB		TMM / TMP	PARTS - TMM/TMP
11082887	PUMP-VAR DISPL, CW 90PV100	90-R-100-HF-1-CD-60-S-3-F1-E-03-GBA-39-39-24	SERIES 90	S90-100PV
11082952	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-NN-60-S-4-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
11083716	MOTOR-VAR DISPL, 51MV160	51V160-A-F1-N-TH-C2-L-N-K7-NNN-032-AA-NN-00-B0	SERIES 51	S51-160MV
11083759	PUMP-VAR DISPL, MPV046	MPV-046-C-B-B-V-S-B-B-AA-A-A-BFF-CG-A-HH-C-NNN	M46	M46-046PV
11084563	PUMP-VAR DISPL, CCW 90PV130	90-L-130-HS-5-NN-80-S-3-F1-H-03-GBA-39-39-24	SERIES 90	S90-130PV
11085387	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-NN-60-S-4-S1-E-00-GBA-14-14-24	SERIES 90	S90-100PV
11085397	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-BC-60-S-3-S1-F-00-GBA-30-30-30	SERIES 90	S90-100PV
11085841	PUMP-VAR DISPL, CCW 90PV130	90-L-130-DD-5-DE-80-R-4-F1-H-03-GBA-26-26-24	SERIES 90	S90-130PV
11085862	PUMP-VAR DISPL, CCW 90PV130	90-L-130-DD-5-CD-80-R-4-F1-H-03-GBA-24-24-24	SERIES 90	S90-130PV
11086044	PUMP-VAR-DISPL	MPV-035-D-B-A-A-R-S-E-AA-A-A-BFF-DR-A-FF-A-NNN	M35/44	035PV
11086848	PUMP-VAR DISPL, CCW 90PV130	90-L-130-MA-5-CD-80-S-4-F1-H-03-GBA-39-39-24	SERIES 90	S90-130PV
11086954	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HF-1-CD-60-R-3-S1-C-00-GBA-23-23-24	SERIES 90	S90-055PV
11087011	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MA-1-NN-60-S-4-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
11087040	PUMP-VAR-DISPL 42PV041 CCW	42-L-41-E-E2D8-03-A-N-A-2-E-N-N-28-28-B-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
11087280	PUMP-VAR DISPL, CW 90PV100	90-R-100-DD-1-BC-80-R-4-S1-E-03-GBA-30-30-24	SERIES 90	S90-100PV
11087281	PUMP-VAR DISPL, CW 90PV100	90-R-100-DD-1-CD-80-R-4-F1-E-03-GBA-30-30-24	SERIES 90	S90-100PV
11088024	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-CD-80-R-4-F1-E-03-GBA-30-30-24	SERIES 90	S90-100PV
11088317	PUMP-VAR-DISPL CCW 20PV089	SPV2/089--L3K-PS183-509-B1	SERIES 20	S20-089PV
11088388	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-NN-60-R-4-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
11088820	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-2-NN-80-S-3-C6-E-02-GBA-42-42-24	SERIES 90	S90-075PV
11088954	PUMP-VAR-DISPL CW TMP089	TMP-089-MDCNNNN-R-M42-20G22-N-C-NCN-BDN	TMM / TMP	TMP089
11089408	PUMP-VAR-DISPL	MPV-035-D-B-A-A-R-S-F-AA-A-A-BDD-DR-A-FF-F-NNN	M35/44	035PV
11090795	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-2-CD-60-P-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
11090796	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-2-BC-60-P-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-055PV
11090852	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HS-1-CD-60-S-3-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
11090853	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HS-1-NN-60-S-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
11091051	PUMP-VAR, CCW		LIGHT DUTY	S10-015PV
11091573	PUMP-VAR DISPL, CCW 90PV100	90-L-100-CB-1-NN-80-S-4-F1-E-00-GBA-35-35-24	SERIES 90	S90-100PV
11092365	MOTOR-VAR DISPL, 51MV160	51V160-R-F1-N-TH-C2-L-N-G0-NNN-080-AA-NN-00-A6	SERIES 51	S51-160MV
11092681	PUMP-VAR-DISPL CCW 90PV130	90L130-MB-1-DH-80-P-3-C8-H-03-GBA-42-42-24	SERIES 90	S90-130PV
11092958	PVG32 4BKMAN CC PVP F OSP 159S6602	PVG32 4BKMAN CC PVP F OSP-159S6602	PVG32/120	PVG 32 Valve Stack
11092976	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-AB-80-S-4-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
11093425	PUMP-VAR DISPL, CW 90PV130	90-R-130-DD-5-DE-80-R-4-F1-H-03-GBA-24-24-24	SERIES 90	S90-130PV

11093651	PUMP-VAR DISPL, CW 90PV130	90-R-130-KA-5-BC-80-R-4-F1-H-03-GBA-26-26-24	SERIES 90	S90-130PV
11094257	PUMP-VAR DISPL, MPV046	MPV-046-C-B-B-D-R-B-J-AA-G-A-BGG-CG-A-HH-B-NNN	M46	M46-046PV
11095026	PUMP-VAR DISPL, CW 90PV130	90-R-130-KA-1-BC-80-P-4-F1-H-03-GBA-38-38-24	SERIES 90	S90-130PV
11095027	MOTOR-VAR DISPL, 51MV160	51V160-A-F1-N-ES-A5-K-Y-A6-NNN-080-AA-F0-70-00	SERIES 51	S51-160MV
11095071	SYSTEM, 90R075+90R075		SERIES 90	PARTS - S90
11095402	PUMP-VAR DISPL, CW 90PV180	90-R-180-HS-1-BC-80-S-3-F1-H-03-FAC-35-35-28	SERIES 90	S90-180PV
11096058	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-1-CD-60-P-4-S1-C-03-GBA-38-38-24	SERIES 90	S90-055PV
11096117	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MA-1-NN-60-P-4-S1-E-03-GBA-32-32-24	SERIES 90	S90-100PV
11096393	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HS-1-CD-80-S-4-S1-C-00-GBA-32-32-24	SERIES 90	S90-055PV
11096429	MOTOR-VAR DISPL, 51MV110	51V110-R-C8-E-F2-A2-A-N-G1-NNN-040-AA-F3-03-21	SERIES 51	S51-110MV-1
11096430	MOTOR-VAR DISPL, 51MV160	51V160-R-C8-N-F2-A2-A-N-G1-NNN-058-AA-F3-03-21	SERIES 51	S51-160MV
11096577	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-E2C8-00-A-N-A-2-D-N-B-C4-C4-N-A-A-NNN-ENN	SERIES 42	S42-028PV/032PV
11096578	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-E2C8-00-A-N-A-2-D-N-A-C4-C4-N-A-A-NNN-ENN	SERIES 42	S42-028PV/032PV
11099083	PUMP-VAR DISPL, CCW 90PV180	90-L-180-KA-5-CD-80-S-3-C8-J-03-FAC-32-32-24	SERIES 90	S90-180PV
11099084	PUMP-VAR DISPL, CCW 90PV180	90-L-180-KA-5-NN-80-S-3-C8-J-03-FAC-32-32-24	SERIES 90	S90-180PV
11099282	SERVO PRESSURE SUPPLY, H1B (EA)		H1-HP MOTORS	PARTS - H1-MV
11099337	MOTOR-FIXED-DISPL TMM084	TMM084B-6MNN-9HN-D-D2M-BDN	TMM / TMP	TMM089
11099785	SEAL-SHAFT-S20-2-070-ASSY		SERIES 20	PARTS - S20 - Unique
11099841	PUMP-VAR DISPL, MPV046	MPV-046-C-B-A-B-S-B-AA-A-A-BGG-AB-U-ED-A-NNN	M46	M46-046PV
11100109	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-1-NN-80-S-3-C6-D-03-GBA-35-35-24	SERIES 90	S90-055PV
11100110	PUMP-VAR DISPL, CCW 90PV055	90-L-055-MA-1-NN-80-S-3-C6-D-03-GBA-35-35-24	SERIES 90	S90-055PV
11100394	MOTOR-VARIABLE DISPL SAE_K	K-V-45DS-A-RNF-F09-S-N-N-CF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
11100666	PUMP-VAR DISPL, CW 90PV055	90-R-055-HS-1-CD-60-S-4-S1-C-03-GBA-24-24-24	SERIES 90	S90-055PV
11101271	PUMP-VAR DISPL, CW 90PV100	90-R-100-HS-1-BC-60-S-3-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
11101436	PUMP-VAR DISPL, CW 90PV100	90-R-100-HS-1-CD-60-S-4-F1-E-03-GBA-37-37-22	SERIES 90	S90-100PV
11101437	PUMP-VAR DISPL, CW 90PV100	90-R-100-HS-1-CD-60-S-4-S1-F-03-GBA-37-37-30	SERIES 90	S90-100PV
11101504	PUMP-VAR DISPL, CW 90PV075	90-R-075-DD-1-AB-60-P-4-C6-D-GB-GBA-21-21-24	SERIES 90	S90-075PV
11101798	PUMP-VAR-DISPL CW 20PV089	SPV2/089--R6Z-PS183-515-B1	SERIES 20	S20-089PV
11101902	PUMP-VAR-DISPL CW 20PV070	SPV2/070--R6Z-PS183-516-B1	SERIES 20	S20-070PV
11102574	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-NN-60-S-4-S1-D-00-GBA-35-35-24	SERIES 90	S90-075PV
11102630	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-5-NN-60-S-4-C7-F-03-FAC-32-32-24	SERIES 90	S90-100PV
11102837	PUMP-VAR DISPL, CW 90PV100	90-R-100-HF-1-BC-80-P-4-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
11103870	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-1-AB-60-P-4-C6-D-03-GBA-21-21-24	SERIES 90	S90-075PV
11104184	PUMP-VAR DISPL, CW 90PV130	90-R-130-KA-5-DE-80-R-4-F1-F-03-EEB-26-26-24	SERIES 90	S90-130PV
11104185	PUMP-VAR DISPL, CW 90PV130	90-R-130-KA-5-CD-80-R-4-F1-F-03-EEB-26-26-24	SERIES 90	S90-130PV
11104187	PUMP-VAR DISPL, CW 90PV250	90-R-250-KN-1-NN-80-T-3-F1-J-03-NNN-29-29-24	SERIES 90	S90-250PV

11104484	MOTOR-FIX DISPL, CARTRIDGE	90-K-055-NC-0-N-8-N-0-S1-W-00-NNN-00-00-E6	SERIES 90	S90-055MF
11104632	MOTOR-FIX DISPL, CARTRIDGE	90-K-055-NC-0-N-8-N-0-S1-W-00-EHD-00-00-E6	SERIES 90	S90-055MF
11105180	PUMP-VAR DISPL, CW 90PV100	90-R-100-HF-1-AB-60-S-4-S1-F-01-GBA-23-23-28+ 111.20.136.00	SERIES 90	S90-100PV
11106340	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MA-1-NN-80-S-3-F1-D-03-GBA-42-42-24	SERIES 90	S90-100PV
11106517	SCREW-SET, PER 9007713 M12x40		HP OTHER PARTS	HP SHARED PARTS
11106585	PUMP-VAR-DISPL CW TMP089	TMP-089-MDCNNNN-R-M42-20G22-N-G-NCN-BDN	TMM / TMP	TMP089
11106587	PUMP-VAR-DISPL CW TMP089	TMP-089-MDCA24A-R-M42-20G22-N-G-NCN-BDN	TMM / TMP	TMP089
11106750	PUMP-VAR DISPL, MPV046	MPV-046-C-B-B-G-R-B-A-AA-A-A-BFF-BA-A-HH-C-NNN	M46	M46-046PV
11106972	PUMP-VAR DISPL, MPV046	MPV-046-C-B-A-A-R-B-A-AA-A-A-BFF-AB-U-ED-C-NNN	M46	M46-046PV
11107351	MOTOR-VAR DISPL, 51MV160	51V160-A-C8-N-ES-A5-K-Y-A6-ACA-080-AA-F0-70-00	SERIES 51	S51-160MV
11107476	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-1-NN-80-S-3-C6-D-03-GBA-35-35-24	SERIES 90	S90-055PV
11107689	PUMP-VAR DISPL, CW 90PV250	90-R-250-KN-1-NN-80-S-3-F1-J-03-NNN-29-29-28	SERIES 90	S90-250PV
11108102	MOTOR-FIXED DISPL, 90MF055	90-M-055-NC-0-N-8-N-0-K1-W-00-EBA-00-00-24	SERIES 90	S90-055MF
11108670	MOTOR-VAR DISPL, 51MV110	51V110-R-F1-N-HS-A2-A-E-E1-NNN-055-AA-NN-02-13	SERIES 51	S51-110MV-1
11108845	MOTOR-FIX DISPL, CARTRIDGE	90-K-055-NC-0-N-8-N-0-S1-W-00-NNN-00-00-G0	SERIES 90	S90-055MF
11110548	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-BB-60-R-3-F1-F-03-GBA-42-42-30	SERIES 90	S90-100PV
11110856	PUMP-VAR DISPL, CCW 90PV130	90-L-130-KA-5-CD-80-R-4-F1-F-03-EEB-26-26-24	SERIES 90	S90-130PV
11110967	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-2-AB-80-S-3-C6-E-03-GBA-42-42-24	SERIES 90	S90-075PV
11111899	PUMP-VAR DISPL, CCW 90PV130	90-L-130-MA-5-NN-80-S-3-F1-H-03-GBA-42-42-24	SERIES 90	S90-130PV
11112514	PUMP-VAR DISPL, MPV046	MPV-046-C-B-A-H-T-B-A-AA-A-A-BJJ-AB-U-ED-A-NNN	M46	M46-046PV
11114424	TMT 470 HYDRAULIC MOTOR		LARGE MOTORS	MOTOR TMT
11114962	PLATE-RETAINER, 90PV180-250		SERIES 90	PARTS - S90
11115317	COVER-PORT, ISO6162-2 DN32 METRIC		SERIES 90	PARTS - S90
11115615	SCREW-HEX, ISO4014 M14x60 8.8		SERIES 90	PARTS - S90
11116039	PUMP-VAR DISPL, CCW 90PV130	90-L-130-KA-5-AB-80-L-4-F1-F-03-EEB-26-26-24	SERIES 90	S90-130PV
11117287	PUMP-VAR DISPL, MPV046	MPV-046-C-B-A-H-R-B-A-AA-A-A-BFF-AB-U-ED-A-NNN	M46	M46-046PV
11118403	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-2-NN-80-S-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-075PV
11118570	MOTOR-FIX DISPL, CARTRIDGE	90-K-055-NC-0-N-8-N-0-S1-W-00-NNN-00-00-F3	SERIES 90	S90-055MF
11119379	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-NN-60-L-3-F1-F-03-GBA-30-30-24	SERIES 90	S90-100PV
11120637	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HF-1-NN-80-S-4-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
11120654	MOTOR-FIX DISPL, CARTRIDGE	90-K-055-NC-0-N-8-N-0-S1-N-00-JAG-00-00-00	SERIES 90	S90-055MF
11121205	PUMP-VAR-DISPL CW TMP089	TMP-089-MDCA24A-R-M42-20G22-N-C-NCN-BDN	TMM / TMP	TMP089
11121460	PUMP-VAR DISPL, CW 90PV130	90-R-130-KA-5-NN-80-R-3-F1-H-00-GBA-23-29-24	SERIES 90	S90-130PV
11121822	MOTOR-FIX DISPL, CARTRIDGE	90-K-055-NC-0-N-7-N-0-S1-W-00-NNN-00-00-F0	SERIES 90	S90-055MF
11122573	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-5-NN-60-L-3-C6-E-03-FAD-38-38-24	SERIES 90	S90-075PV
11122780	ENDCAP-TMP-NFPE-R-W/EXPANDER		TMM / TMP	PARTS - TMM/TMP

11122806	PVG32 5BK MAN LS CC PVP EEEEE O&CSP	PVG32 5BK MAN LS CC PVP EEEEE-O&CSP 159S6682	PVG32/120	PVG 32 Valve Stack
11123081	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-1-NN-60-S-4-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV
11123243	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-BC-80-S-3-C6-E-02-GBA-23-23-24	SERIES 90	S90-075PV
11125165	PUMP-VAR DISPL, CCW 90PV075	90-L-075-CB-1-NN-80-S-4-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
11125447	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-NN-80-S-4-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
11125450	MOTOR-FIX DISPL, CARTRIDGE	90-K-055-NC-0-N-8-N-0-C6-N-00-NNN-00-00-00	SERIES 90	S90-055MF
11125684	PVG32 1 BK PVH CC DET E OSP	PVG32	PVG32/120	PVG 32 Valve Stack
11125968	MOTOR-FIX DISPL, CARTRIDGE	90-K-055-NC-0-N-8-N-0-S1-W-00-EEA-00-00-F3	SERIES 90	S90-055MF
11125969	MOTOR-FIX DISPL, CARTRIDGE	90-K-055-NC-0-N-8-N-0-S1-N-00-NNN-00-00-00	SERIES 90	S90-055MF
11126145	PVG32 1BK PVH CC PC D OSP	PVG32 1BK PVH CC PC D OSP	PVG32/120	PVG 32 Valve Stack
11126436	MOTOR-FIX DISPL, CARTRIDGE	90-K-055-NC-0-N-8-N-0-S1-W-00-EFA-00-00-F0	SERIES 90	S90-055MF
11126511	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-CD-60-S-3-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
11126742	PUMP-VAR DISPL, CW 90PV130	90-R-130-KA-1-NN-80-R-4-F1-F-03-GBA-23-29-24	SERIES 90	S90-130PV
11126876	PUMP-VAR DISPL, CW 90PV130	90-R-130-KA-5-CD-80-L-3-C8-H-03-GBA-42-42-24	SERIES 90	S90-130PV
11127208	PUMP-VAR DISPL, CW 90PV130	90-R-130-KA-1-NN-80-R-4-F1-F-03-GBA-35-35-24	SERIES 90	S90-130PV
11127501	MOTOR-FIX DISPL, CARTRIDGE	90-K-055-NC-0-N-8-N-0-S1-W-00-EBA-00-00-20	SERIES 90	S90-055MF
11127513	PUMP-VAR DISPL, CW 90PV180	90-R-180-KA-5-AB-80-S-C-C8-J-03-FAC-32-32-24	SERIES 90	S90-180PV
11127522	MOTOR-FIX DISPL, CARTRIDGE	90-K-055-NC-0-N-8-N-0-S1-W-00-EEA-00-00-24	SERIES 90	S90-055MF
11127523	MOTOR-FIX DISPL, CARTRIDGE	90-K-055-NC-0-N-8-N-0-S1-W-00-NNN-00-00-F0	SERIES 90	S90-055MF
11127526	MOTOR-FIX DISPL, CARTRIDGE	90-K-055-NC-0-N-8-N-0-S1-W-00-NNN-00-00-20	SERIES 90	S90-055MF
11128601	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-BC-60-S-3-F1-E-33-GBA-26-26-24	SERIES 90	S90-100PV
11129511	MOTOR-VAR DISPL, 51MV160	51V160-R-C8-N-EQ-A5-K-Y-A6-NNN-107-AA-H0-50-00	SERIES 51	S51-160MV
11129913	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-AB-80-S-4-F1-E-02-GBA-32-32-20	SERIES 90	S90-100PV
11131125	PUMP CLOSED LOOP	42-R-41-C-E1A6-03-B-5-G-2-C-N-B-34-34-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
11135791	PUMP-VAR DISPL, CCW 90PV130	90-L-130-KA-1-NN-80-P-3-F1-F-04-GBA-40-40-20	SERIES 90	S90-130PV
11136039	MOTOR-FIX DISPL, CARTRIDGE	90-K-055-NC-0-N-7-N-0-S1-W-00-EBA-00-00-F3	SERIES 90	S90-055MF
11137358	MOTOR-VAR DISPL, 51MV160	51V160-A-F1-N-HS-A2-C-E-G6-ABA-032-AA-NN-15-20	SERIES 51	S51-160MV
11137449	MOTOR-VAR DISPL, 51MV160	51V160-A-F1-N-HS-A2-C-E-G6-ABA-032-AA-NN-15-20	SERIES 51	S51-160MV
11137650	MOTOR-VAR DISPL, 51MV160	51V160-A-F1-N-HS-A2-C-E-G6-NNN-032-AA-NN-15-20	SERIES 51	S51-160MV
11137849	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HF-1-AB-80-L-4-S1-E-02-GBA-29-29-24	SERIES 90	S90-100PV
11137902	PUMP-VAR DISPL, MPV046	MPV-046-C-B-B-R-B-R-AA-A-A-BJJ-CE-A-HH-A-NNN	M46	M46-046PV
11139100	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-CD-60-S-F-S1-F-33-GBA-26-26-30	SERIES 90	S90-100PV
11140158	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-BC-60-S-3-F1-F-00-GBA-26-26-24	SERIES 90	S90-100PV
11140160	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-BC-60-S-3-F1-F-00-GBA-26-26-24	SERIES 90	S90-100PV
11140372	PUMP-VAR DISPL, CCW 90PV180	90-L-180-KA-5-NN-80-S-C-F1-J-03-FAC-32-32-24	SERIES 90	S90-180PV
11140434	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-2-AB-80-S-3-C6-E-03-GBA-42-42-24	SERIES 90	S90-075PV

11141592	PUMP-VAR DISPL, CW 90PV100	90-R-100-DC-1-CD-80-L-4-F1-E-G4-GBA-42-42-24	SERIES 90	S90-100PV
11143369	PUMP- VAR CW		LIGHT DUTY	S10-015PV
11143575	VALVE-CONT-PV-ANLR, 2/033-070-KIT		SERIES 20	PARTS - S20 - Unique
11145047	PUMP-VAR DISPL, CW 90PV130	90-R-130-KA-5-NN-80-S-3-F1-F-03-GBA-42-42-24	SERIES 90	S90-130PV
11145502	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-1-NN-80-S-4-S1-C-03-GBA-26-26-24	SERIES 90	S90-055PV
11146194	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HS-1-NN-60-S-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-075PV
11146599	PUMP-VAR DISPL, CW 90PV180	90-R-180-KP-1-CD-80-S-M-F1-J-03-FAC-42-42-28	SERIES 90	S90-180PV
11146901	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-CD-80-S-3-C7-E-00-GBA-42-42-24	SERIES 90	S90-100PV
11147632	PUMP-VAR DISPL, CW 90PV100	90-R-100-KN-1-BC-60-S-4-S1-E-02-GBA-21-21-24	SERIES 90	S90-100PV
11148364	PUMP-VAR-DISPL	MPV-035-D-B-A-A-R-S-G-AA-A-A-BGG-DR-A-FF-A-NNN	M35/44	035PV
11148539	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-1-NN-80-S-4-S1-C-03-GBA-32-32-24	SERIES 90	S90-055PV
11149143	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-NN-60-S-4-F1-F-03-FAC-32-32-24	SERIES 90	S90-100PV
11149172	PUMP-VAR DISPL, CCW 90PV130	90-L-130-KA-5-NN-80-S-4-C8-H-03-GCS-38-38-24	SERIES 90	S90-130PV
11150104	PUMP-VAR DISPL, CCW 90PV130	90-L-130-MA-5-NN-80-R-3-F1-H-02-EEB-35-35-24	SERIES 90	S90-130PV
11150596	PVG32 3BK PVMR CC E CSP W/CAST IRON PVM		PVG32/120	PVG 32 Valve Stack
11150926	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-NN-80-P-3-S1-E-00-GBA-32-37-24	SERIES 90	S90-075PV
11150927	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-CD-80-P-3-S1-E-00-GBA-32-32-24	SERIES 90	S90-075PV
11150928	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-CD-80-P-3-C7-E-00-GBA-35-35-24	SERIES 90	S90-100PV
11151923	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-1-NN-60-S-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
11152107	PVG32 4BK MAN OC LS PC EFDD OSP		PVG32/120	PVG 32 Valve Stack
11152108	PVG32 4BK MAN OC LS PC DDDD OSP		PVG32/120	PVG 32 Valve Stack
11152523	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-NN-60-S-4-S1-E-03-GBA-35-35-20	SERIES 90	S90-100PV
11153524	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-AB-60-L-4-S1-F-03-GBA-23-23-24	SERIES 90	S90-100PV
11153896	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-CD-60-S-4-S1-E-33-GBA-26-26-30	SERIES 90	S90-100PV
11154523	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-S6-C3-C-E8-G-G2-NN-K-DC-K-DC-L-L-32-PN-C06-G18	H1-HP PUMPS	H1-147PV/165PV
11154704	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-2-NN-80-S-3-C6-C-03-GBA-42-42-24	SERIES 90	S90-055PV
11156421	PUMP-VAR DISPL, CW 90PV055	90-R-055-HF-1-NN-60-S-3-C6-D-03-GBA-35-35-24	SERIES 90	S90-055PV
11156540	MOTOR-FIXED DISPL, 90MF100	90-M-100-NC-0-N-8-N-0-S1-W-00-EBA-00-00-24	SERIES 90	S90-100MF
11157186	PUMP-VAR DISPL, MPV046	MPV-046-C-B-B-H-R-B-A-BA-A-A-BDD-CG-A-HH-A-NNN	M46	M46-046PV
11158023	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-NN-80-S-4-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
11158037	PUMP-VAR DISPL, MPV046	MPV-046-C-B-A-D-R-B-J-AA-G-A-BHH-AB-U-CB-C-NNN	M46	M46-046PV
11159270	PUMP-VAR DISPL, CW 90PV075	90-R-075-HF-2-NN-80-S-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-075PV
11159380	PUMP-VAR DISPL, CW 90PV055	90-R-055-HF-1-CD-60-R-4-S1-C-03-GBA-24-24-24	SERIES 90	S90-055PV
11160179	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-NN-60-P-4-F1-E-03-GBA-16-16-24	SERIES 90	S90-100PV
11162063	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-NN-60-S-3-S1-E-03-GBA-17-17-24	SERIES 90	S90-100PV
11162214	PUMP-VAR DISPL, CW 90PV055	90-R-055-HF-1-AB-60-P-4-S1-C-02-GBA-21-21-20	SERIES 90	S90-055PV

11162221	PUMP-VAR DISPL, CW 90PV180	90-R-180-HF-1-AB-80-T-C-C8-H-02-FAC-21-21-20	SERIES 90	S90-180PV
11162824	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-CD-80-S-3-C6-E-03-GBA-32-32-24	SERIES 90	S90-075PV
11163354	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-CD-80-S-3-F1-F-00-GBA-42-42-24	SERIES 90	S90-100PV
11164086	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MA-1-NN-80-S-4-S1-E-02-GBA-42-42-24	SERIES 90	S90-100PV
11164133	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-1-CD-80-P-3-S1-C-00-GBA-40-40-24	SERIES 90	S90-055PV
11164601	PUMP-VAR-DISPL CW 90PV042	90R042-MB-1-BC-80-L-4-C3-B-03-GBA-42-42-20	SERIES 90	S90-042PV
11164792	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HS-1-BC-60-S-4-F1-E-02-GBA-29-29-24	SERIES 90	S90-100PV
11165277	MOTOR-VAR DISPL, 51MV160	51V160-A-F1-N-TA-C2-L-N-K7-NNN-070-AA-NN-00-B0	SERIES 51	S51-160MV
11167537	SYSTEM-90R100+H1PV089	90-R-100-LV-1-CD-60-S-3-C7-E-03-GBA-38-38-24	SERIES 90	S90-100PT
11168311	PUMP-VAR-DISPL	90-L-180-HS-1-BC-80-T-M-F1-J-02-FAC-38-38-28	SERIES 90	S90-180PV
11168655	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-NN-80-S-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
1400731	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A2-C3-N-D1-F-G8-H8-38-38-38-38-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
1400732	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A2-C3-N-D1-F-G8-H8-30-30-30-30-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
1400733	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A2-C3-N-D1-F-G8-H8-35-35-35-35-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
1400734	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A2-C3-B-D1-F-G5-H3-30-30-18-18-N-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
1400736	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A2-C3-N-E7-F-G5-H1-25-25-25-25-N-P-22-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
1400737	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A2-C3-N-D1-F-G5-H1-25-25-25-25-N-P-22-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
1400740	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A2-C3-N-D1-F-G5-H3-35-35-35-35-N-P-28-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
1400741	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A2-C3-N-D1-F-G5-H3-35-35-35-35-N-P-28-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
1401230	PUMP-TANDEM, VAR DISPL CCW H1T045L	H1-T-045-L-A-N-B6-C1-B-E7-F-G5-NN-25-25-40-40-N-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
1401232	PUMP-TANDEM, VAR DISPL CCW H1T045L	H1-T-045-L-A-N-A2-C3-N-E7-F-G5-H2-35-35-35-35-N-P-28-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
1401233	PUMP-TANDEM, VAR DISPL CCW H1T045L	H1-T-045-L-A-N-A5-C3-N-E7-F-G1-H5-40-40-40-40-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
1401234	PUMP-TANDEM, VAR DISPL CCW H1T045L	H1-T-045-L-A-N-A2-C3-N-D1-F-G5-H2-40-40-40-40-N-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
1401235	PUMP-TANDEM, VAR DISPL CCW H1T045L	H1-T-045-L-A-N-A3-C2-N-E7-F-G5-H3-25-25-25-25-N-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
1401731	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-N-A2-C3-N-D1-F-G7-H8-38-38-38-38-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
1401732	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-N-A2-C3-N-E7-F-G5-H2-28-28-28-28-N-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
1401733	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-N-A2-C3-N-D1-F-G5-H3-35-35-35-35-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
1401734	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-N-A2-C3-N-E7-F-G5-NN-30-30-30-30-N-P-20-PN-C03-NNN	H1-MP PUMPS	H1-045PT/053PT
1401735	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-N-A2-C3-N-D1-F-G8-H8-38-38-38-38-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
1401736	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-N-A2-C3-N-E7-F-G1-H3-35-35-35-35-N-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
1401740	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-N-A4-C2-N-E7-F-G5-H3-23-23-23-23-N-P-22-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
1403032	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A2-C3-N-F1-F-G5-NN-K-35-K-35-B-L-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
1403332	PUMP-VAR DISPL CCW H1P053L	H1-P-053-L-A-A3-C2-N-D6-F-G5-H2-L-38-L-38-B-L-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
1403632	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A2-C3-N-F1-F-G5-NN-K-35-K-35-B-L-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
1403633	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A8-C2-C-D8-F-G5-H3-L-38-L-38-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
1403634	PUMP-VAR DISPL CCW H1P053R	H1-P-053-R-A-A3-C3-N-E6-F-F2-H3-L-20-L-20-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV

140520	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A2-C2-N-D3-G-G2-H2-L-42-L-42-L-M-30-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
140925	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A2-C2-N-D3-H-G1-H2-L-42-L-42-C-M-28-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
141323	CONTROL-EDC 24V, DTSCH CONN, 052SP(D0A3)		H1-MP PUMPS	PARTS - H1-MP PUMPS and MOTOR
141399	CONTROL-NFPE 12V DTSC CONN (D0A8)		H1-MP PUMPS	PARTS - H1-MP PUMPS and MOTOR
141583	AUX MTG A FLANGE, 9T W/SHPNG COV (K0H2)		H1-MP PUMPS	PARTS - H1-MP PUMPS and MOTOR
141585	AUX MTG B FLANGE, 15T W/SHPNG COV (K0H5)		H1-MP PUMPS	PARTS - H1-MP PUMPS and MOTOR
141911	SPRING-HELICAL-COMP 5.60x45.60x74.40		LIGHT DUTY	PARTS - Low Power
142216	ORIFICE		LIGHT DUTY	PARTS - Low Power
148197	SHAFT		LIGHT DUTY	PARTS - Low Power
148353	KIT RELIEF VALVE		LIGHT DUTY	PARTS - Low Power
148627	SHAFT		LIGHT DUTY	PARTS - Low Power
148742	END CAP		LIGHT DUTY	PARTS - Low Power
148759	END CAP		LIGHT DUTY	PARTS - Low Power
148940	COMPRESSION SPRING		DAIKIN	PARTS - OPV
15-2044	PUMP VAR CW		LIGHT DUTY	S10-015PV
15-2058	PUMP-VAR-DISPL SPV15	SPV15-2058R	LIGHT DUTY	S10-015PV
15-2066	PUMP VAR CW		LIGHT DUTY	S10-015PV
15-2072	PUMP VAR CW		LIGHT DUTY	S10-015PV
15-2076	PUMP-VAR-DISPL SPV15	SPV15-2076L	LIGHT DUTY	S10-015PV
15-2077	PUMP-VAR-DISPL SPV15	SPV15-2077R	LIGHT DUTY	S10-015PV
15-2078	PUMP VAR CW		LIGHT DUTY	S10-015PV
15-2095	PUMP-VAR-DISPL SPV15	SPV15-2095L	LIGHT DUTY	S10-015PV
15-2135	PUMP VAR CW	SPV15-2135CW	LIGHT DUTY	S10-015PV
15-2150	PUMP-VAR-DISPL SPV15	SPV15-2150L	LIGHT DUTY	S10-015PV
15-2163	PUMP-VAR-DISPL SPV15	SPV15-2163R	LIGHT DUTY	S10-015PV
15-2167	PUMP-VAR-DISPL SPV15	SPV15-2167R	LIGHT DUTY	S10-015PV
15-2211	PUMP-VAR-DISPL SPV15	SPV15-2211R	LIGHT DUTY	S10-015PV
15-2215	PUMP-VAR-DISPL SPV15	SPV15-2215R	LIGHT DUTY	S10-015PV
15-2216	PUMP-VAR-DISPL SPV15	SPV15-2216R	LIGHT DUTY	S10-015PV
15-2219	PUMP-VAR-DISPL SPV15	SPV15-2219R	LIGHT DUTY	S10-015PV
15-2220	PUMP- VAR CCW		LIGHT DUTY	S10-015PV
15-2229	PUMP-VAR, CCW		LIGHT DUTY	S10-015PV
15-2232	PUMP-VAR CCW	SPV15-2232	LIGHT DUTY	S10-015PV
15-2233	PUMP-VAR-DISPL SPV15	SPV15-2233R	LIGHT DUTY	S10-015PV
15-2234	PUMP-VAR-DISPL SPV15	SPV15-2234R	LIGHT DUTY	S10-015PV
15-2246	PUMP-VAR-DISPL SPV15	SPV15-2246R.	LIGHT DUTY	S10-015PV

15-2280	PUMP- VAR CW		LIGHT DUTY	S10-015PV
15-2282	PUMP-VAR, CW		LIGHT DUTY	S10-015PV
15-2310	PUMP-VAR-DISPL SPV15	SPV15-2310	LIGHT DUTY	S10-015PV
15-2317	PUMP-VAR-DISPL SPV15	SPV15-2317L	LIGHT DUTY	S10-015PV
15-2321	PUMP-VAR-DISPL SPV15	SPV15-2321R	LIGHT DUTY	S10-015PV
15-2323	PUMP- VAR CW	SPV15-15-2323	LIGHT DUTY	S10-015PV
15-3021	MOTOR-FIXED-DISPL SMF15	SMF15-3021	LIGHT DUTY	S10-015MF
15-3022	MOTOR-FIXED-DISPL SMF15	SMF15-3022	LIGHT DUTY	S10-015MF
15-3052	MOTOR-FIXED		LIGHT DUTY	S10-015MF
15-3054	MOTOR FIXED		LIGHT DUTY	S10-015MF
1711951	PLATE-VALVE PUMP 2/089 R		SERIES 20	PARTS - S20 - Unique
1713261	SHAFT-PUMP 2/119		SERIES 20	PARTS - S20 - Unique
1713291	SHAFT-PUMP 2/119		SERIES 20	PARTS - S20 - Unique
1722192	VALVE PLATE(LH) PV35		M35/44	PARTS - 035/044
1735284	HANDLE(CONTROL SHAFT)		SERIES 20	PARTS - S20 - Unique
1741147	SHIM		COMPACT GEARS -	PARTS - BM - OSK
1743313	THRUST PLATE		M35/44	PARTS - 035/044
304907	ADAPTER		M46	PARTS - M46
304964	GEROTORSATZ 1/015		LIGHT DUTY	PARTS - Low Power
305201	COVER		M46	PARTS - M46
305300	SEAL KIT		M46	PARTS - M46
305649	DISPLACEMENT LIMITER		M46	PARTS - M46
312082	MOTOR-FIXED-DISPL 90MF100	90-M-100-NC-0-N-8-N-0-C7-W-00-NNN-00-00-F3	SERIES 90	S90-100MF
312231	MOTOR-FIXED-DISPL 90MF100	90-M-100-NC-0-N-7-N-0-C7-W-00-NNN-00-00-F3	SERIES 90	S90-100MF
312389	COVER		M46	PARTS - M46
312579	DISPLACEMENT CONTROL		SERIES 20	PARTS - S20 - Unique
315267	DISPLACEMENT CONTROL		SERIES 20	PARTS - S20 - Unique
318865	MOTOR-FIXED-DISPL 90MF100	90-M-100-NC-0-N-8-N-0-F1-W-00-NNN-00-00-F3	SERIES 90	S90-100MF
320069	HYDR.DISPLACEMENT CONTROL ASSY.		SERIES 20	PARTS - S20 - Unique
320242	RING GEROTOR		M46	PARTS - M46
322875	KEY		LP SHARED PARTS	LP SHARED PARTS
325084	SEAL KIT-SPV4/023		M46	PARTS - M46
328708	PUMP-VAR-DISPL CW 20PV070	SPV2/070--R6Z-PS183-CXX-B1	SERIES 20	S20-070PV
328724	PUMP-VAR-DISPL CCW 20PV089	SPV2/089--L6Z-PS183-CXX-B1	SERIES 20	S20-089PV
328740	MOTOR-FIXED-DISPL 20MF070	SMF2/070--B6Z-MS42422-A1	SERIES 20	S20-070MF
328773	MOTOR-FIXED-DISPL 20MF089	SMF2/089--B6A-MS42422-CXX-A1	SERIES 20	S20-089MF

330795	PUMP-VAR-DISPL MPV046	MPV-046-C-B-A-H-R-A-A-BC-A-A-BHH-AB-U-ZJ-A-NNN	M46	M46-046PV
331025	PUMP-VAR-DISPL CW 20PV166	SPV2/166--R6Z-972972-PS333-B1	SERIES 20	S20-166PV
331033SK	PUMP-VAR-DISPL CCW 20PV166	SPV2/166--L6Z-972972-PS333-B1	SERIES 20	S20-166PV
331041SK	PUMP-VAR-DISPL CW 20PV227	SPV2/227--R6Z-972972-PS333-A1	SERIES 20	S20-227PV
331058SK	PUMP-VAR-DISPL CCW 20PV227	SPV2/227--L6Z-972972-PS333-B1	SERIES 20	S20-227PV
331066	PUMP-VAR-DISPL CW 20PV334	SPV2/334--R6Z-PS66X-268-A1	SERIES 20	S20-334PV
331074SK	PUMP-VAR-DISPL CCW 20PV334	SPV2/334--L6Z-972972-PS663-B1	SERIES 20	S20-334PV
332130	MOTOR-FIXED-DISPL 20MF166	SMF2/166--B6Z-MS35352-KXX-B1	SERIES 20	S20-166MF
332148	MOTOR-FIXED-DISPL 20MF227	SMF2/227--B6Z-MS35352-KXX-B1	SERIES 20	S20-227MF
332155	MOTOR-FIXED-DISPL 20MF334	SMF2/334--B6Z-MS35352-KXX-B1	SERIES 20	S20-334MF
334359	SEAL KIT		LIGHT DUTY	PARTS - Low Power
334672	MOTOR-FIXED-DISPL 90MF055	90-M-055-NC-0-N-7-N-0-C6-W-00-NNN-00-00-F3	SERIES 90	S90-055MF
335943	KIT CONTROL VALVE		M46	PARTS - M46
3360022424	SADA TESNENI PRE SPV 23		SERIES 20	PARTS - S20 - "No Name"
3360034454	SADA TESNENI PRE SPV 24		SERIES 20	PARTS - S20 - "No Name"
3360035654	SADA TESNENI PRE SPV21		SERIES 20	PARTS - S20 - "No Name"
336263	DRUCKBEGR.VENTIL 175 BAR 4/023		LIGHT DUTY	PARTS - Low Power
336719	PLUG		M46	PARTS - M46
337196	ENDGEH.PU.1/038		LIGHT DUTY	PARTS - Low Power
337279	KEY		M46	PARTS - M46
337980	HOUSING		LIGHT DUTY	PARTS - Low Power
342048	CYLINDER BLOCK KIT		LIGHT DUTY	PARTS - Low Power
342113	END CAP		LIGHT DUTY	PARTS - Low Power
342808	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-NN-60-P-3-C7-E-02-GBS-42-42-20	SERIES 90	S90-100PV
343236	MOTOR-FIXED-DISPL 90MF100	90-M-100-NC-0-N-8-N-0-C7-W-00-NNN-00-00-F3	SERIES 90	S90-100MF
345678	PUMP-VAR-DISPL MPV046	MPV-046-C-B-B-H-R-B-A-AA-A-A-BJJ-DB-A-SS-A-NNN	M46	M46-046PV
350355	PUMP-VAR-DISPL CW 90PV055	90R055-EA-1-AB-60-S-4-C6-D-04-GBA-42-42-24-F001	SERIES 90	S90-055PV
351965	PUMP-VAR-DISPL CW 90PV130	90R130-MA-1-NN-80-S-3-C8-H-04-GBA-42-42-20	SERIES 90	S90-130PV
352740	PUMP-VAR-DISPL CW 90PV042	90R042-MA-1-AB-80-S-3-C3-C-03-GBA-42-42-20	SERIES 90	S90-042PV
354811	MOTOR-FIXED-DISPL 20MF166	SMF2/166--B6Z-MS38382-KDX-B1	SERIES 20	S20-166MF
357319	DISPLACEMENT CONTROL		SERIES 20	PARTS - S20 - Unique
358994	PUMP-VAR-DISPL CW 20PV334	SPV2/334--R6Z-976976-PS663-VES138	SERIES 20	S20-334PV
359158	PUMP-VAR-DISPL CCW 20PV070	SPV2/070--L3Z-PS183-VML145-082-A1	SERIES 20	S20-070PV
361295	MOTOR-FIXED-DISPL 20MF166	SMF2/166--B6Z-MS42422-KXX-B1	SERIES 20	S20-166MF
367573	IMPLEMENTVENTIL COMPL. SPV1/015		LIGHT DUTY	PARTS - Low Power
377408	SHIM RING		HP OTHER PARTS	HP SHARED PARTS

377416	SHIM RING		HP OTHER PARTS	HP SHARED PARTS
4007039	NFPE-12V, AMP CONN, INT, 42P (DG2A1)		SERIES 42	PARTS - S42
4007200	CHG PMP-11CC, CW, 42P41/51 (G0002)		SERIES 42	PARTS - S42
412-000003	PUMP CLOSED LOOP	42-R-41-D-G3AN-53-P-3-G-2-F-1-A-21-21-B-1-1-NNN-NNN	SERIES 42	S42-041PV/051PV
4251212	CPRV SETTING-18 BAR (260 PSI) (H000C)		M46	PARTS - M46
4251215	CPRV SETTING-14BAR (200 PSI) ADJ, (H00V)		LIGHT DUTY	PARTS - Low Power
4252001	PUMP-VARIABLE DISPL	LPV-B-A-A-A-A-E-AA-C-A-BDD-DR-A-FF-B-NNN-***	LPV	LPV
4252002	PUMP-VARIABLE DISPL	LPV-B-A-A-B-A-E-AA-C-A-BFF-DR-A-FF-A-NNN-***	LPV	LPV
4252003	PUMP-VARIABLE DISPL	LPV-B-A-A-C-A-E-AA-C-A-BFF-DR-A-FF-A-NNN-***	LPV	LPV
4252004	PUMP-VARIABLE DISPL	LPV-B-A-A-D-A-E-AA-C-A-BFF-DR-A-FF-A-NNN-***	LPV	LPV
4252005	PUMP-VARIABLE DISPL	LPV-B-A-A-E-A-E-AA-C-A-BFF-DR-A-FF-A-NNN-***	LPV	LPV
4252006	PUMP-VARIABLE DISPL	LPV-B-A-B-F-A-E-AA-C-A-BFF-DR-A-FF-B-NNN-***	LPV	LPV
4253000	MOTOR-FIXED-DISPL MMF025	MMF-025-C-A-E-G-A-B-NNN-***	LIGHT DUTY	025MF
4253001	MOTOR-FIXED-DISPL MMF025	MMF-025-C-A-E-G-A-C-NNN-***	LIGHT DUTY	025MF
4253002	MOTOR-FIXED-DISPL MMF025	MMF-025-C-A-E-R-A-B-NNN-***	LIGHT DUTY	025MF
4253007	MOTOR-FIXED-DISPL MMF025	MMF-025-C-A-E-R-C-D-NNN-***	LIGHT DUTY	025MF
4253010	MOTOR-FIXED-DISPL MMF025	MMF-025-C-A-E-B-A-B-NNN-***	LIGHT DUTY	025MF
4253011	MOTOR-FIXED DISPL	MMF-025-C-A-N-G-A-C-NNN-***	LIGHT DUTY	025MF
4253012	MOTOR-FIXED-DISPL MMF025	MMF-025-C-A-N-R-A-B-NNN-***	LIGHT DUTY	025MF
4253015	MOTOR-FIXED DISPL	MMF-025-C-A-E-R-A-C-NNN-***	LIGHT DUTY	025MF
4253016	MOTOR-FIXED-DISPL MMF025	MMF-025-C-A-E-G-C-F-NNN-***	LIGHT DUTY	025MF
4253017	MOTOR-FIXED-DISPL MMF025	MMF-025-C-A-E-G-C-J-NNN-***	LIGHT DUTY	025MF
4253018	MOTOR-FIXED DISPL	MMF-025-C-A-E-B-A-C-NNN-***	LIGHT DUTY	025MF
4253019	MOTOR-FIXED DISPL	MMF-025-C-A-E-G-C-C-NNN-***	LIGHT DUTY	025MF
4253020	MOTOR-FIXED-DISPL MMF025	MMF-025-C-A-N-5-A-B-NNN-***	LIGHT DUTY	025MF
4253021	MOTOR-FIXED DISPL	MMF-025-C-A-E-B-C-B-NNN-***	LIGHT DUTY	025MF
4253022	MOTOR-FIXED DISPL	MMF-025-C-A-E-G-C-B-NNN-***	LIGHT DUTY	025MF
4253023	MOTOR-FIXED DISPL	MMF-025-C-A-E-G-C-N-NNN-***	LIGHT DUTY	025MF
4253024	MOTOR-FIXED-DISPL MMF025	MMF-025-C-A-E-G-C-D-NNN-***	LIGHT DUTY	025MF
4253025	MOTOR-FIXED-DISPL MMF025	MMF-025-C-A-N-G-A-B-NNN-***	LIGHT DUTY	025MF
4253026	MOTOR-FIXED DISPL	MMF-025-C-A-E-R-C-B-NNN-***	LIGHT DUTY	025MF
4253027	MOTOR-FIXED DISPL	MMF-025-C-A-2-G-A-B-NNN-***	LIGHT DUTY	025MF
4253028	MOTOR-FIXED DISPL	MMF-025-C-A-E-M-C-J-NNN-***	LIGHT DUTY	025MF
4253030	MOTOR-FIXED-DISPL MMF025	MMF-025-C-A-E-R-C-F-NNN-***	LIGHT DUTY	025MF
4253031	MOTOR-FIXED DISPL	MMF-025-C-A-N-B-A-B-NNN-***	LIGHT DUTY	025MF
4253032	MOTOR-FIXED DISPL	MMF-025-C-A-E-B-C-D-NNN-***	LIGHT DUTY	025MF

4253033	MOTOR-FIXED DISPL	MMF-025-C-A-E-5-C-D-NNN-***	LIGHT DUTY	025MF
4253034	MOTOR-FIXED DISPL	MMF-025-C-A-E-B-C-C-NBJ-***	LIGHT DUTY	025MF
4253036	MOTOR-FIXED DISPL	MMF-025-C-A-5-G-F-B-NNN-***	LIGHT DUTY	025MF
4253037	MOTOR-FIXED-DISPL MMF025	MMF-025-C-A-S-B-A-B-NNN-***	LIGHT DUTY	025MF
4253039	MOTOR-FIXED DISPL	MMF-025-C-A-S-G-A-B-NNN-***	LIGHT DUTY	025MF
4253040	MOTOR-FIXED-DISPL MMF025	MMF-025-C-A-E-M-A-C-NNN-***	LIGHT DUTY	025MF
4253041	MOTOR-FIXED DISPL	MMF-025-C-A-S-R-A-B-NNN-***	LIGHT DUTY	025MF
4253042	MOTOR-FIXED DISPL	MMF-025-C-A-E-M-C-F-NNN-***	LIGHT DUTY	025MF
4253043	MOTOR-FIXED DISPL	MMF-025-C-A-4-G-F-B-NNN-***	LIGHT DUTY	025MF
4253051	MOTOR-FIXED DISPL	MMF-025-C-A-E-G-A-B-NBJ-***	LIGHT DUTY	025MF
4254110	MOTOR-VARIABLE DISPL	L-V-30DN-A-RNF-F06-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254111	MOTOR-VARIABLE DISPL	L-V-25CN-A-RNF-F07-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254112	MOTOR-VARIABLE DISPL	L-V-30DN-A-YNF-F95-S-N-N-AF-F18-NNN-NNT	LV / KV MOTORS	L/K-MV
4254113	MOTOR-VARIABLE DISPL	L-V-35EN-A-RNF-F01-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254114	MOTOR-VARIABLE DISPL	L-V-30DN-A-RNF-F09-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254115	MOTOR-VARIABLE DISPL	L-V-30DN-A-YNF-F08-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254116	MOTOR-VARIABLE DISPL	L-V-30DN-A-YNF-F00-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254117	MOTOR-VAR-DISPL LV35	L-V-35EN-A-YNF-F01-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254118	MOTOR-VARIABLE DISPL	L-V-30DN-A-YNF-F11-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254119	MOTOR-VARIABLE DISPL	L-V-25CN-A-RNF-F11-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254120	MOTOR-VARIABLE DISPL	L-V-35EN-A-YNF-F11-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254121	MOTOR-VAR-DISPL LV25	L-V-25CN-A-YNF-F11-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254122	MOTOR-VARIABLE DISPL	L-V-30DN-A-YNF-F10-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254124	MOTOR-VARIABLE DISPL	L-V-25CN-A-RNF-F06-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254125	MOTOR-VARIABLE DISPL	L-V-25CN-A-YNF-F01-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254126	MOTOR-VARIABLE DISPL	L-V-35EN-A-RNF-F07-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254127	MOTOR-VARIABLE DISPL	L-V-30DN-A-RNF-F08-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254128	MOTOR-VARIABLE DISPL	L-V-35EN-A-YNF-F08-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254129	MOTOR-VARIABLE DISPL	L-V-25CN-A-RNF-F75-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254130	MOTOR-VARIABLE DISPL	L-V-25CN-A-RNF-F09-T-N-X-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254131	MOTOR-VARIABLE DISPL	L-V-35EN-A-YNF-F07-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254132	MOTOR-VARIABLE DISPL	L-V-25CN-A-RNF-FX1-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254133	MOTOR-VARIABLE DISPL	L-V-30DN-A-RNF-F01-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254134	MOTOR-VARIABLE DISPL	L-V-30DN-A-RNF-F75-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254135	MOTOR-VARIABLE DISPL	L-V-30DN-A-YNF-F75-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254136	MOTOR-VARIABLE DISPL	L-V-30DN-A-RNF-F07-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV

4254137	MOTOR-VAR-DISPL LV35	L-V-35EN-A-RNF-F09-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254138	MOTOR-VARIABLE DISPL	L-V-30DS-A-RNF-F07-S-N-N-CF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254139	MOTOR-VARIABLE DISPL	L-V-35EN-A-YNF-F06-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254141	MOTOR-VARIABLE DISPL	L-V-35ES-A-RNF-F07-S-N-N-BF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254142	MOTOR-VARIABLE DISPL	L-V-35ES-A-YNF-F11-S-N-N-CF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254143	MOTOR-VARIABLE DISPL	L-V-25CS-A-RNF-FX1-S-N-N-CF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254144	MOTOR-VARIABLE DISPL	L-V-35EN-A-RNF-F10-T-N-X-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254145	MOTOR-VARIABLE DISPL	L-V-35EN-A-YNF-F01-T-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254146	MOTOR-VAR-DISPL LV35	L-V-35EN-A-YNF-F10-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254147	MOTOR-VARIABLE DISPL	L-V-35EN-A-YNF-F11-T-N-X-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254148	MOTOR-VARIABLE DISPL	L-V-30DN-A-RNF-F11-T-N-X-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254149	MOTOR-VARIABLE DISPL	L-V-25CN-A-RNF-F11-T-N-X-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254150	MOTOR-VARIABLE DISPL	L-V-35ES-A-RNF-F09-S-N-N-CF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254151	MOTOR-VARIABLE DISPL	L-V-30DN-A-YNF-F01-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254152	MOTOR-VARIABLE DISPL	L-V-25CS-E-RNF-F10-S-N-N-BF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254153	MOTOR-VARIABLE DISPL	L-V-25CN-E-RNF-F13-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254154	MOTOR-VARIABLE DISPL	L-V-25CS-A-RNF-F01-S-N-N-CF-F15-NNN-NNN	LV / KV MOTORS	L/K-MV
4254155	MOTOR-VARIABLE DISPL	L-V-30DN-E-RNF-F10-S-N-N-AF-F18-NNN-NVT	LV / KV MOTORS	L/K-MV
4254156	MOTOR-VARIABLE DISPL	L-V-35EN-A-RNF-F11-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254157	MOTOR-VARIABLE DISPL	L-V-25CS-E-RNF-F10-S-N-N-BF-F17-NNN-NNN	LV / KV MOTORS	L/K-MV
4254158	MOTOR-VARIABLE DISPL	L-V-30DN-A-YNF-F85-S-N-3-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254159	MOTOR-VARIABLE DISPL	L-V-25CN-A-RNF-F00-S-N-N-AF-F15-NNN-NNN	LV / KV MOTORS	L/K-MV
4254160	MOTOR-VARIABLE DISPL	L-V-35ES-A-RNF-F11-S-N-N-BF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254161	MOTOR-VARIABLE DISPL	L-V-30DN-A-YNF-F11-S-N-N-AF-F16-NNN-NNN	LV / KV MOTORS	L/K-MV
4254162	MOTOR-VARIABLE DISPL	L-V-30DN-A-YNF-F06-S-N-N-AF-F16-NNN-NNN	LV / KV MOTORS	L/K-MV
4254163	MOTOR-VARIABLE DISPL	L-V-30DN-A-RNF-F00-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254164	MOTOR-VARIABLE DISPL	L-V-30DN-E-YNF-F01-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254165	MOTOR-VARIABLE DISPL	L-V-30DN-A-YNF-F10-S-N-N-AF-F16-NNN-NNN	LV / KV MOTORS	L/K-MV
4254166	MOTOR-VARIABLE DISPL	L-V-25CN-A-RNF-F09-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254167	MOTOR-VARIABLE DISPL	L-V-35ES-A-RNF-F07-T-N-X-CF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254168	MOTOR-VARIABLE DISPL	L-V-30DN-E-RNF-F01-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254169	MOTOR-VARIABLE DISPL	L-V-25CS-A-RNF-F10-S-N-N-CF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254170	MOTOR-VARIABLE DISPL	L-V-25CN-C-YNF-F11-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254171	MOTOR-VARIABLE DISPL	L-V-25CS-E-RNF-F13-S-N-N-BF-F14-NNN-NVT	LV / KV MOTORS	L/K-MV
4254172	MOTOR-VARIABLE DISPL	L-V-30DS-A-RNF-F09-S-N-N-BF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254173	MOTOR-VARIABLE DISPL	L-V-25CS-A-RNF-F10-S-N-N-CF-F15-NNN-NNN	LV / KV MOTORS	L/K-MV

4254174	MOTOR-VARIABLE DISPL	L-V-25CN-E-RNF-F01-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254175	MOTOR-VARIABLE DISPL	L-V-35EN-A-Y1F-F11-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254176	MOTOR-VARIABLE DISPL	L-V-35EN-A-R1F-F11-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254177	MOTOR-VARIABLE DISPL	L-V-30DN-A-YNF-F01-S-N-N-AF-F17-NNN-NNN	LV / KV MOTORS	L/K-MV
4254178	MOTOR-VARIABLE DISPL	L-V-25CS-E-RNF-F12-S-N-N-BF-F13-NNN-NVT	LV / KV MOTORS	L/K-MV
4254179	MOTOR-VARIABLE DISPL	L-V-25CN-E-YNF-F13-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254180	MOTOR-VARIABLE DISPL	L-V-30DN-A-RNF-F11-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254181	MOTOR-VARIABLE DISPL	L-V-25CN-A-YNF-F09-S-N-2-AF-F16-NNN-NNN	LV / KV MOTORS	L/K-MV
4254182	MOTOR-VARIABLE DISPL	L-V-30DN-E-RNF-F06-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254558	SHAFT-LV MTR, 15T/NONE (D00E)		LV / KV MOTORS	PARTS - L/K-MV
4254702	MOTOR-CARTRIDGE	L-C-35EN-E-RNF-F11-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254703	MOTOR-CARTRIDGE	L-C-30DN-E-RNF-F08-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254704	MOTOR-CARTRIDGE	L-C-25CN-E-RNF-F08-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254705	MOTOR-CARTRIDGE	L-C-35EN-E-RNF-F08-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254706	MOTOR-CARTRIDGE	L-C-30DN-A-RNF-F08-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254708	MOTOR-CARTRIDGE	L-C-25CN-A-ANF-F65-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254709	MOTOR-CARTRIDGE	L-C-30DN-A-RNF-F10-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254710	MOTOR-CARTRIDGE	L-C-25CN-E-RNF-F11-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254711	MOTOR-CARTRIDGE	L-C-25CN-A-RNF-F11-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254712	MOTOR-CARTRIDGE	L-C-30DN-A-RNF-F01-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254713	MOTOR-CARTRIDGE	L-C-25CN-E-RNF-F06-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254714	MOTOR-CARTRIDGE	L-C-30DN-E-RNF-F06-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254715	MOTOR-CARTRIDGE	L-C-35EN-E-RNF-F06-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254716	MOTOR-CARTRIDGE	L-C-25CN-E-RNF-F07-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254717	MOTOR-CARTRIDGE	L-C-30DN-E-RNF-F07-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254718	MOTOR-CARTRIDGE	L-C-35EN-E-RNF-F07-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254719	MOTOR-CARTRIDGE	L-C-35EN-A-RNF-F10-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254720	MOTOR-CARTRIDGE	L-C-35EN-A-RNF-F07-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254721	MOTOR-CARTRIDGE	L-C-25CN-E-RNF-F55-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254722	MOTOR-CARTRIDGE	L-C-35EN-A-RNF-F08-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254723	MOTOR-CARTRIDGE	L-C-25CN-A-RNF-F06-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254726	MOTOR-CARTRIDGE	L-C-35EN-A-R1F-F09-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254801	MOTOR-VARIABLE	K-C-45DN-E-RNF-F55-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254805	MOTOR-VARIABLE	K-C-45DN-E-RNF-F11-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254806	MOTOR-VARIABLE	K-C-45DN-E-RNF-F06-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254807	MOTOR-VARIABLE	K-C-38CN-E-RNF-F11-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV

4254808	MOTOR-VARIABLE	K-C-38CN-E-RNF-F07-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254809	MOTOR-VARIABLE	K-C-45DN-E-RNF-F07-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254810	MOTOR-VARIABLE	K-C-45DN-A-RNF-F11-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254811	MOTOR-VARIABLE	K-C-45DN-A-RNF-F06-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254812	MOTOR-VARIABLE	K-C-45DN-E-RNF-F65-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254813	MOTOR-VARIABLE	K-C-45DN-E-RNF-F08-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254814	MOTOR-VARIABLE	K-C-38CN-E-R2F-F11-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254815	MOTOR-VARIABLE	K-C-38CN-E-R1F-F11-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254816	MOTOR-VARIABLE	K-C-38CN-A-RNF-F06-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254817	MOTOR-VARIABLE	K-C-45DN-E-RNF-F12-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254818	MOTOR-VARIABLE	K-C-45DN-E-RNF-F09-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254819	MOTOR-VARIABLE	K-C-45DN-A-RNF-F07-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254820	MOTOR-VARIABLE	K-C-38CN-A-RNF-F07-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254821	MOTOR-VARIABLE	K-C-38CN-E-RNF-F09-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254822	MOTOR-VARIABLE	K-C-45DN-E-R3F-F11-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254823	MOTOR-VARIABLE	K-C-45DN-E-R2F-F11-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254824	MOTOR-VARIABLE	K-C-45DN-E-R1F-F11-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254825	MOTOR-VARIABLE	K-C-38CS-E-RNF-F11-S-N-N-CF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254826	MOTOR-VARIABLE	K-C-45DS-E-RNF-F65-S-N-N-CF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254827	MOTOR-VARIABLE	K-C-38CN-E-RNF-F10-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254828	MOTOR-VARIABLE	K-C-38CN-E-RNF-F08-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254829	MOTOR-VARIABLE	K-C-38CN-E-RNF-F01-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254830	MOTOR-VARIABLE	K-C-38CS-E-RNF-F06-S-N-N-CF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254900	MOTOR-VARIABLE	K-V-45DN-A-YNF-F11-S-N-N-AF-F16-NNN-NNT	LV / KV MOTORS	L/K-MV
4254901	MOTOR-VARIABLE	K-V-45DN-A-YNF-F55-S-N-N-AF-F16-NNN-NNN	LV / KV MOTORS	L/K-MV
4254905	MOTOR-VARIABLE DISPL	K-V-45DN-A-YNF-F09-S-N-N-AF-F16-NNN-NNN	LV / KV MOTORS	L/K-MV
4254906	MOTOR-VARIABLE DISPL	K-V-38CN-A-RNF-F00-T-N-X-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254907	MOTOR-VARIABLE DISPL	K-V-45DN-A-RNF-F09-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254908	MOTOR-VARIABLE DISPL	K-V-45DN-A-YNF-F09-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254909	MOTOR-VARIABLE DISPL	K-V-45DN-A-YNF-F08-S-N-N-AF-F18-NNN-PNN	LV / KV MOTORS	L/K-MV
4254910	MOTOR-VARIABLE DISPL	K-V-45DN-A-YNF-F07-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254911	MOTOR-VARIABLE DISPL	K-V-45DN-E-RNF-F09-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254912	MOTOR-VARIABLE DISPL	K-V-45DN-E-RNF-F09-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254913	MOTOR-VARIABLE DISPL	K-V-38CN-A-RNF-F11-S-N-N-AF-F16-NNN-NNN	LV / KV MOTORS	L/K-MV
4254914	MOTOR-VARIABLE DISPL	K-V-45DN-E-RNF-F00-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254915	MOTOR-VARIABLE DISPL	K-V-38CN-E-RNF-F08-T-N-X-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV

4254916	MOTOR-VARIABLE DISPL	K-V-38CN-E-YNF-F08-T-N-X-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254917	MOTOR-VARIABLE DISPL	K-V-45DN-A-RNF-F55-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254918	MOTOR-VARIABLE DISPL	K-V-38CN-E-RNF-F85-T-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254919	MOTOR-VARIABLE DISPL	K-V-45DN-A-RNF-F08-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254920	MOTOR-VARIABLE DISPL	K-V-45DN-A-YNF-F10-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254921	MOTOR-VARIABLE DISPL	K-V-45DN-A-RNF-F65-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254922	MOTOR-VARIABLE DISPL	K-V-38CN-A-RNF-F06-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254923	MOTOR-VARIABLE DISPL	K-V-45DN-A-RNF-F06-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254924	MOTOR-VARIABLE DISPL	K-V-45DN-A-RNF-F11-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254925	MOTOR-VARIABLE DISPL	K-V-45DN-E-RNF-F10-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254926	MOTOR-VARIABLE DISPL	K-V-45DN-A-YNF-F07-S-N-N-AF-F15-NNN-NNN	LV / KV MOTORS	L/K-MV
4254927	MOTOR-VARIABLE DISPL	K-V-38CN-A-RNF-F09-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254928	MOTOR-VARIABLE DISPL	K-V-45DN-E-YNF-F11-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254929	MOTOR-VARIABLE DISPL	K-V-45DN-E-RNF-F75-T-N-X-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254930	MOTOR-VARIABLE DISPL	K-V-45DN-A-RNF-F10-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254931	MOTOR-VARIABLE DISPL	K-V-45DN-E-YNF-F13-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254932	MOTOR-VARIABLE DISPL	K-V-38CN-E-RNF-F11-S-N-N-AF-F16-NNN-NNN	LV / KV MOTORS	L/K-MV
4254933	MOTOR-VARIABLE DISPL	K-V-38CN-E-RNF-F09-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254934	MOTOR-VARIABLE DISPL	K-V-38CN-E-YNF-F09-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254935	MOTOR-VARIABLE DISPL	K-V-45DN-E-RNF-F11-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254936	MOTOR-VARIABLE DISPL	K-V-45DN-A-Y1F-F07-S-N-N-AF-F15-NNN-NNN	LV / KV MOTORS	L/K-MV
4254937	MOTOR-VARIABLE DISPL	K-V-38CN-E-YNF-F11-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254938	MOTOR-VARIABLE DISPL	K-V-38CN-E-YNF-F11-T-N-X-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254939	MOTOR-VARIABLE DISPL	K-V-45DN-A-RNF-F01-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254940	MOTOR-VARIABLE DISPL	K-V-45DN-E-YNF-F55-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254941	MOTOR-VARIABLE DISPL	K-V-45DN-A-R2F-F01-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254942	MOTOR-VARIABLE DISPL	K-V-45DN-E-R1F-F09-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254943	MOTOR-VARIABLE DISPL	K-V-45DS-E-R1F-F09-S-N-N-CF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254944	MOTOR-VARIABLE DISPL	K-V-45DS-A-YNF-F01-S-N-N-CF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254945	MOTOR-VARIABLE DISPL	K-V-45DS-A-YNF-F06-S-N-N-CF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254946	MOTOR-VARIABLE DISPL	K-V-45DN-A-R2F-F07-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254947	MOTOR-VARIABLE DISPL	K-V-38CN-E-YNF-F55-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254948	MOTOR-VARIABLE DISPL	K-V-45DN-A-R1F-F10-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254949	MOTOR-VARIABLE DISPL	K-V-38CN-E-RNF-F12-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4254950	MOTOR-VARIABLE DISPL	K-V-45DN-A-R1F-F08-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
4280087	SCREW-SOC HD, M10 X1 - 92.9 NFP SPCL		SERIES 42	PARTS - S42

4280271	CHG PMP-11CC, CCW, 42P28 (G0002)		SERIES 42	PARTS - S42
4281722	PUMP-VAR-DISPL, CW, S42PV028, NFPH	42-R-28-D-G3AN-52-P-2-C-2-H-1-B-38-38-N-8-8-NNN-NNN	SERIES 42	S42-028PV/032PV
4281723	PUMP-VAR-DISPL, CW, S42PV028, NFPH	42-R-28-C-G3AN-52-P-2-C-2-H-1-B-38-38-N-8-8-NNN-NNN	SERIES 42	S42-028PV/032PV
4281728	PUMP-VAR DISPL, CW	42-R-28-D-E1B6-03-C-2-A-2-F-N-A-25-25-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
4281729	PUMP-VAR-DISPL, CW, S42PV028, MDC	42-R-28-C-ANN3-03-C-3-A-2-F-N-N-25-25-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
4281736	PUMP-VAR-DISPL, CW, S42PV028, MDC	42-R-28-D-ANNA-10-C-3-A-3-E-N-N-38-38-B-N-N-NNN-NGJ	SERIES 42	S42-028PV/032PV
4281737	PUMP-VAR-DISPL, CW, S42PV028, MDC	42-R-28-D-ANN3-03-C-2-A-3-F-N-B-34-34-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
4281739	PUMP-VAR-DISPL, CW, S42PV028, MDC	42-R-28-D-LNN3-07-C-3-A-2-F-N-A-34-34-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
4281750	PUMP-VAR-DISPL, CW, S42PV028, MDC	42-R-28-C-ANNB-02-C-2-A-2-E-N-N-25-25-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
4281751	PUMP-VAR-DISPL, CW, S42PV028, MDC	42-R-28-D-LNN3-11-C-3-A-2-F-N-A-34-34-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
4281766	PUMP-VAR-DISPL, CW, S42PV028, MDC	42-R-28-D-ANNA-10-B-3-B-3-E-N-N-38-38-B-N-N-NNN-NGJ	SERIES 42	S42-028PV/032PV
4281767	PUMP-VAR-DISPL, CW, S42PV028, MDC	42-R-28-C-A3NB-03-A-N-N-N-F-N-A-19-19-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
4281777	PUMP-VAR-DISPL, CW, S42PV028, FNR	42-R-28-D-F6NN-52-U-D-G-2-F-N-A-34-34-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
4281781	PUMP-VAR-DISPL, CW, S42PV028, FNR	42-R-28-D-F6NN-52-U-5-G-2-C-N-A-34-34-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
4281782	PUMP-VAR-DISPL, CW, S42PV028, FNR	42-R-28-D-F8NN-53-U-3-X-A-F-5-Z-34-34-N-1-1-NNN-NNN	SERIES 42	S42-028PV/032PV
4281786	PUMP-VAR-DISPL, CW, S42PV028, FNR	42-R-28-C-F6NN-53-U-2-X-N-P-1-A-25-25-N-8-8-NNN-NNN	SERIES 42	S42-028PV/032PV
4281787	PUMP-VAR-DISPL, CW, S42PV028, NFPE	42-R-2A-D-G2A1-52-U-2-G-2-F-5-A-34-34-B-0-0-AAA-NNN	SERIES 42	S42-028PV/032PV
4281788	PUMP-VAR-DISPL, CW, S42PV028, NFPE	42-R-2A-D-G2A1-52-U-2-G-2-F-5-A-41-41-B-0-0-AAA-NNN	SERIES 42	S42-028PV/032PV
4281792	PUMP-VAR-DISPL CW 42PV028	42-R-28-D-G3AN-52-P-3-G-2-F-1-B-19-19-B-1-1-NNN-NNN	SERIES 42	S42-028PV/032PV
4281793	PUMP-VAR-DISPL, CW, S42PV028, NFPH	42-R-28-D-G3AN-52-P-3-G-2-F-1-B-23-23-B-1-1-NNN-NNN	SERIES 42	S42-028PV/032PV
4281794	PUMP-VAR-DISPL, CW, S42PV028, NFPH	42-R-28-C-G3AN-52-P-3-G-2-F-1-A-23-23-B-1-1-NNN-NNN	SERIES 42	S42-028PV/032PV
4281796	PUMP-VAR-DISPL, CW, S42PV028, NFPE	42-R-28-D-G2A2-53-V-N-F-2-H-2-T-28-28-N-T-T-NNN-NNN	SERIES 42	S42-028PV/032PV
4281798	PUMP-VAR-DISPL CW 42PV028	42-R-28-D-LNN3-11-C-3-A-2-F-N-A-28-28-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
4281800	PUMP-VAR-DISPL, CW, S42PV028, NFPE	42-R-28-D-G2A1-53-V-N-Q-2-F-2-A-25-25-N-T-T-NNN-NNN	SERIES 42	S42-028PV/032PV
4281806	PUMP-VAR-DISPL CW 42PV028	42-R-28-D-ANNB-02-C-5-A-2-C-N-A-28-28-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
4281813	PUMP-VAR-DISPL CW 42PV028	42-R-28-D-ANNB-03-C-5-A-2-C-N-A-34-34-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
4281819	PUMP-VAR-DISPL CW 42PV028	42-R-28-C-G3AN-52-P-3-G-2-F-1-A-21-21-B-0-0-NNN-NNN	SERIES 42	S42-028PV/032PV
4281820	PUMP-VAR-DISPL, CW, S42PV028, NFPH	42-R-28-C-G3AN-50-P-2-B-2-H-1-B-30-30-N-0-0-NNN-NNN	SERIES 42	S42-028PV/032PV
4281821	PUMP-VAR-DISPL, CW, S42PV028, NFPH	42-R-28-D-G3AN-50-P-2-B-2-H-1-B-30-30-N-0-0-NNN-NNN	SERIES 42	S42-028PV/032PV
4281822	PUMP-VAR-DISPL, CW, S42PV028, MDC	42-R-28-D-ANNB-02-C-2-A-2-E-N-N-34-34-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
4281837	PUMP-VAR-DISPL, CW, S42PV028, NFPH	42-R-28-C-G3AN-52-P-3-C-2-F-1-T-34-34-N-1-1-NNN-NNN	SERIES 42	S42-028PV/032PV
4281838	PUMP-VAR-DISPL, CW, S42PV028, NFPH	42-R-28-D-G3AN-52-P-3-C-2-F-1-B-34-34-N-1-1-NNN-NNN	SERIES 42	S42-028PV/032PV
4282064	PUMP-VAR-DISPL CCW 42PV028	42-L-28-D-E1A6-02-B-3-G-2-H-N-B-25-25-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
4282073	PUMP-VAR-DISPL CCW 42PV028	42-L-28-D-E1A6-02-B-5-X-N-C-N-A-21-21-B-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
4282088	PUMP-VAR-DISPL CCW 42PV028	42-L-28-D-ANN3-02-A-N-A-2-C-N-A-34-34-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
4282123	PUMP-VAR-DISPL CCW 42PV028	42-L-28-D-E1A6-03-C-2-A-2-F-N-B-25-25-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV

4282124	PUMP-VAR-DISPL CCW 42PV028	42-L-28-C-E1A6-03-C-2-A-2-F-N-N-25-25-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
4282147	PUMP-VAR-DISPL CCW 42PV028	42-L-28-C-E1A6-02-A-N-A-2-F-N-N-34-34-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
4282162	PUMP-VAR-DISPL CCW 42PV028	42-L-28-D-NDNN-NN-B-D-G-2-C-N-N-00-00-B-N-N-NNN-BNN	SERIES 42	S42-028PV/032PV
4282166	PUMP-VAR-DISPL, CW, S42PV028, MDC	42-L-28-C-ANNB-03-C-3-A-2-F-N-A-34-34-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
4282172	PUMP-VAR-DISPL, CCW, S42PV028, MD	42-L-28-C-ANNB-03-A-N-A-2-F-N-B-34-34-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
4282201	PUMP-VAR-DISPL CCW 42PV028	42-L-28-D-E1A6-02-C-4-A-2-D-N-N-28-28-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
4282238	PUMP-VAR-DISPL, CCW, S42PV028, NFPE	42-L-28-C-G2A1-53-V-N-F-2-G-5-N-28-28-N-1-1-NNN-NNN	SERIES 42	S42-028PV/032PV
4282252	PUMP-VAR-DISPL CCW 42PV028	42-L-28-D-LNN3-11-C-3-A-2-F-N-B-34-34-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
4282253	PUMP-VAR-DISPL CCW 42PV028	42-L-28-D-LNN3-11-C-3-A-2-F-N-A-34-34-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
4282287	PUMP-VAR-DISPL, CCW, S42PV028, NFPE	42-L-28-C-G2A1-50-U-2-B-3-F-5-B-38-38-N-1-1-NNN-NNN	SERIES 42	S42-028PV/032PV
4282518	PUMP-VAR-DISPL CW 42PV028	42-R-28-D-ANNB-02-B-5-X-A-C-N-Z-41-41-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
4282519	PUMP-VAR-DISPL CW 42PV028	42-R-28-C-E1A6-02-B-5-X-N-C-N-B-41-41-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
4282521	PUMP-VAR-DISPL CW 42PV028	42-R-28-C-E1A6-03-A-N-N-N-C-N-B-41-41-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
4282526	PUMP-VAR-DISPL CW 42PV028	42-R-28-D-ANN3-02-A-N-A-2-C-N-A-34-34-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
4282527	PUMP-VAR-DISPL CW 42PV028	42-R-28-D-ANN3-02-B-3-G-2-C-N-A-34-34-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
4282528	PUMP-VAR-DISPL CW 42PV028	42-R-28-D-ANN3-02-A-N-A-2-C-N-B-21-21-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
4282529	PUMP-VAR-DISPL CW 42PV028	42-R-28-C-ANN3-02-A-N-N-N-C-N-A-21-21-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
4282531	PUMP-VAR-DISPL CW 42PV028	42-R-28-D-ANN3-02-B-3-G-2-C-N-N-28-28-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
4282535	PUMP-VAR-DISPL CW 42PV028	42-R-28-D-E1A6-02-B-3-G-2-H-N-B-25-25-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
4282536	PUMP-VAR-DISPL CW 42PV028	42-R-28-D-E1A6-02-B-5-G-2-C-N-N-28-28-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
4282543	PUMP-VAR-DISPL CW 42PV028	42-R-28-C-G3AN-52-P-3-G-2-F-1-A-28-28-B-1-1-NNN-NNN	SERIES 42	S42-028PV/032PV
4282544	PUMP-VAR-DISPL CW 42PV028	42-R-28-C-G3AN-52-T-N-M-N-F-1-A-28-28-B-1-1-NNN-NNN	SERIES 42	S42-028PV/032PV
4282545	PUMP-VAR-DISPL CW 42PV028	42-R-28-D-G3AN-52-P-3-G-2-F-1-B-28-28-B-1-1-NNN-NNN	SERIES 42	S42-028PV/032PV
4282553	PUMP-VAR-DISPL CW 42PV028	42-R-28-C-NDNN-NN-B-D-G-2-C-N-N-00-00-B-N-N-NNN-CNN	SERIES 42	S42-028PV/032PV
4282556	PUMP-VAR-DISPL CW 42PV028	42-R-28-C-LNN3-03-C-2-N-N-F-N-A-38-38-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
4282565	PUMP-VAR-DISPL CW 42PV028	42-R-28-D-LNN3-05-B-3-G-2-F-N-A-34-34-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
4282566	PUMP-VAR-DISPL CW 42PV028	42-R-28-D-ANNB-02-B-5-G-2-C-N-A-34-34-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
4282637	PUMP-VAR-DISPL CW 42PV028	42-R-28-D-ANNB-03-A-N-A-2-F-N-A-34-34-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
4282639	PUMP-VAR-DISPL CW 42PV028	42-R-28-D-G3AN-52-P-3-G-2-F-1-B-34-34-N-1-1-NNN-NNN	SERIES 42	S42-028PV/032PV
4282640	PUMP-VAR-DISPL CW 42PV028	42-R-28-C-G3AN-52-P-3-G-2-F-1-A-34-34-N-1-1-NNN-NNN	SERIES 42	S42-028PV/032PV
4282641	PUMP-VAR-DISPL CW 42PV028	42-R-28-D-LNNA-03-C-2-N-A-F-N-Z-34-34-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
4282645	PUMP-VAR-DISPL CW 42PV028	42-R-28-D-E1A6-03-C-2-A-2-F-N-A-34-34-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
4282650	PUMP-VAR-DISPL CW 42PV028	42-R-28-D-LNBA-03-C-2-N-N-F-N-A-34-34-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
4282669	PUMP-VAR-DISPL CW 42PV028	42-R-28-D-E1A6-02-A-N-N-N-F-N-A-25-25-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
4282670	PUMP-VAR-DISPL CW 42PV028	42-R-28-D-LNBA-03-A-N-A-2-F-N-N-38-38-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
4282671	PUMP-VAR-DISPL, CW, S42PV028, NFPH	42-R-28-G-G3AN-53-P-D-G-2-F-1-A-21-21-B-0-0-NNN-NNN	SERIES 42	S42-028PV/032PV

4282675	PUMP-VAR-DISPL, CW, S42PV028, MDC	42-R-28-C-LNBA-07-B-D-B-2-F-N-N-41-41-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
4282685	PUMP-VAR-DISPL, CW, S42PV028, MDC	42-R-28-C-LNBA-07-B-D-B-2-F-N-A-41-41-B-N-N-NNN-BNN	SERIES 42	S42-028PV/032PV
4282686	PUMP-VAR-DISPL CW 42PV028	42-R-28-D-E1A6-03-B-2-B-2-F-N-A-34-34-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
4282692	PUMP-VAR-DISPL CW 42PV028	42-R-28-C-G3AN-52-P-3-B-2-F-1-A-34-34-B-0-0-NNN-NNN	SERIES 42	S42-028PV/032PV
4282731	PUMP-VAR-DISPL CW 42PV028	42-R-28-D-E1A6-02-A-N-N-A-P-N-Z-NN-NN-N-N-N-BAA-NNN	SERIES 42	S42-028PV/032PV
4282735	PUMP-VAR-DISPL CW 42PV028	42-R-28-D-NDNN-NN-B-D-G-2-C-N-N-00-00-B-N-N-NNN-CNN	SERIES 42	S42-028PV/032PV
4282739	PUMP-VAR-DISPL CW 42PV028	42-R-28-D-E1A6-02-B-4-B-2-C-N-T-34-34-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
4282741	PUMP-VAR-DISPL, CW, S42PV028, FNR	42-R-28-D-F8NN-53-U-3-X-A-F-5-Z-34-34-N-1-1-NNN-NNN	SERIES 42	S42-028PV/032PV
4282743	PUMP-VAR-DISPL CW 42PV028	42-R-28-D-LNN3-05-B-3-G-2-F-N-A-34-34-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
4282747	PUMP-VAR-DISPL CW 42PV028	42-R-28-C-L2B3-10-C-3-A-2-F-N-A-34-34-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
4282751	PUMP-VAR-DISPL CW 42PV028	42-R-28-D-L3A3-10-C-3-A-2-F-N-A-38-38-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
4282752	PUMP-VAR-DISPL CW 42PV028	42-R-28-D-G3AN-52-K-N-M-N-F-5-A-34-34-N-1-1-NNN-BNN	SERIES 42	S42-028PV/032PV
4282753	PUMP-VAR-DISPL, CW, S42PV028, FNR	42-R-28-C-F7NN-53-U-D-G-2-C-N-N-NN-NN-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
4282755	PUMP-VAR-DISPL, CW, S42PV028, MDC	42-R-28-D-ANNA-10-C-3-A-2-F-N-N-34-34-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
4282778	PUMP-VAR-DISPL CW 42PV028	42-R-28-C-ANNB-02-C-4-A-2-D-N-N-34-34-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
4282783	PUMP-VAR-DISPL, CW, S42PV028, MDC	42-R-28-C-ANNB-02-A-N-A-2-F-N-A-25-25-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
4282786	PUMP-VAR-DISPL, CW, S42PV028, NFPE	42-R-28-D-G2A1-53-V-N-F-2-F-5-A-25-25-N-0-0-NNN-NNN	SERIES 42	S42-028PV/032PV
4282791	PUMP-VAR-DISPL CW 42PV028	42-R-28-C-G3AN-53-P-3-G-2-F-1-A-21-21-B-0-0-NNN-NNN	SERIES 42	S42-028PV/032PV
4282811	PUMP-VAR-DISPL, CW, S42PV028, FNR/NFPE	42-R-28-C-MDNN-53-U-3-G-2-F-N-N-28-28-N-A-A-NNN-CNN	SERIES 42	S42-028PV/032PV
4282820	PUMP-VAR-DISPL CW 42PV028	42-R-28-D-LNBA-03-C-2-A-2-F-N-A-34-34-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
4282829	PUMP-VAR-DISPL CW 42PV028	42-R-28-D-L2B8-11-C-3-A-2-F-N-N-25-25-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
4282833	PUMP-VAR-DISPL, CW, S42PV028, MDC	42-R-28-C-ANN3-03-C-5-A-2-C-N-A-21-21-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
4282837	PUMP-VAR-DISPL, CW, S42PV028, MDC	42-R-28-C-ANN3-03-A-N-A-2-C-N-N-23-23-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
4282849	PUMP-VAR DISPL, CW, S42PV028	42-R-28-D-A1NB-03-B-D-C-2-H-N-V-34-34-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
4282851	PUMP-VAR-DISPL CW 42PV028	42-R-28-D-G1A1-72-J-2-G-2-F-5-A-41-41-B-0-0-AAA-NNN	SERIES 42	S42-028PV/032PV
4282860	PUMP-VAR-DISPL CW 42PV028	42-R-28-D-L3A3-10-C-2-A-3-F-N-B-38-38-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
4282865	PUMP-VAR-DISPL CW 42PV028	42-R-28-C-ANN3-03-C-2-A-2-F-N-A-30-30-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
4282867	PUMP-VAR-DISPL, CW, S42PV028, FNR	42-R-28-C-F6NN-53-U-2-X-N-P-1-A-25-25-N-8-8-NNN-NNN	SERIES 42	S42-028PV/032PV
4282869	PUMP-VAR-DISPL, CW, S42PV028, NFPE	42-R-28-D-G2A1-53-V-N-F-2-H-2-A-34-34-N-T-T-NNN-NNN	SERIES 42	S42-028PV/032PV
4282870	PUMP-VAR-DISPL, CW, S42PV028, MDC	42-R-28-D-ANN3-07-A-N-A-2-D-N-A-28-28-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
4282877	PUMP-VAR-DISPL CW 42PV028	42-R-28-C-G3AN-52-T-N-M-N-F-1-A-21-21-N-0-0-NNN-NNN	SERIES 42	S42-028PV/032PV
4282880	PUMP-VAR-DISPL CW 42PV028	42-R-28-G-ANN3-02-C-5-A-2-C-N-B-14-14-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
4282881	PUMP-VAR-DISPL CW 42PV028	42-R-28-C-ANN3-02-C-5-A-2-C-N-N-14-14-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
4282887	PUMP-VAR-DISPL CW 42PV028	42-R-28-D-E1A6-03-B-D-G-2-C-N-A-34-34-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
4282889	PUMP-VAR-DISPL, CW, S42PV028, MDC	42-R-28-D-A1N5-03-A-N-A-2-F-N-B-34-34-B-H-H-NNN-NNN	SERIES 42	S42-028PV/032PV
4282890	PUMP-VAR-DISPL, CW, S42PV028, MDC	42-R-28-C-A1N5-03-A-N-A-2-F-N-A-34-34-B-H-H-NNN-NNN	SERIES 42	S42-028PV/032PV

4282895	PUMP-VAR-DISPL CW 42PV028	42-R-28-C-G3AN-52-T-N-M-N-F-1-A-21-21-B-0-0-NNN-NNN	SERIES 42	S42-028PV/032PV
4286201	DISPL LMTR-SIDE 1, FULL, 42P(L000A)		SERIES 42	PARTS - S42
4286251	DISPL LMTR-SIDE 2, FULL, 42P(M000A)		SERIES 42	PARTS - S42
4350439	SHAFT-MF, 13T (D00A)		M35/44	PARTS - 035/044
4350441	SHAFT-MF, 15T (D00F)		M35/44	PARTS - 035/044
4350445	END CAP-MF,TWIN W/LOOP 2X.055 ORI (E00M)		M35/44	PARTS - 035/044
4350468	SHAFT-PV, 15T 16/32 (E00G)		M35/44	PARTS - 035/044
4350519	DIRECT-DISPL CONT-LEFT SIDE (N0DL)		M35/44	PARTS - 035/044
4350526	AUX.FLANGE-SAE B, 13T SPLINE (S00B)		M35/44	PARTS - 035/044
4350545	CHARGE PUMP-19.7 CC/REV (1.2CIR)(G00S)		M35/44	PARTS - 035/044
4352025	PUMP-VAR DISPL	MPV-035-D-B-A-G-R-S-G-AA-A-A-BDD-DL-A-FF-D-NNN-***	M35/44	035PV
4352026	PUMP-VAR-DISPL MPV035	MPV-035-D-B-A-A-R-S-F-AA-A-A-BGG-DR-A-FF-A-NNN-***	M35/44	035PV
4352027	PUMP-VAR DISPL	MPV-035-D-B-A-A-R-S-F-AA-A-A-BBB-DR-A-FF-C-NNN-***	M35/44	035PV
4352028	PUMP-VAR DISPL	MPV-035-D-B-A-G-R-S-F-AA-A-A-AAA-DL-A-FF-A-NNN-***	M35/44	035PV
4352029	PUMP-VAR DISPL	MPV-035-D-B-A-Y-R-S-G-AA-A-A-BCC-DR-A-FF-A-NNN-***	M35/44	035PV
4352030	PUMP-VAR DISPL	MPV-035-D-B-A-A-R-S-G-BA-A-A-BMM-DL-A-FF-A-NNN-***	M35/44	035PV
4352031	PUMP-VAR DISPL	MPV-035-D-B-A-A-L-S-E-AA-A-A-BDD-DL-A-FF-A-NNN-***	M35/44	035PV
4352032	PUMP-VAR DISPL	MPV-035-D-B-A-A-R-S-G-AA-A-A-BFF-DR-A-FF-A-NNN-***	M35/44	035PV
4352033	PUMP-VAR DISPL	MPV-035-D-B-A-Y-L-S-F-AA-A-A-BDD-DR-A-FF-C-NNN-***	M35/44	035PV
4352034	PUMP-VAR DISPL	MPV-035-D-B-A-A-R-S-G-AA-A-A-BEE-DR-A-FF-A-NNN-***	M35/44	035PV
4352035	PUMP-VAR-DISPL MPV035	MPV-035-D-B-A-G-L-S-G-AA-A-A-BBB-DL-A-FF-B-NNN-***	M35/44	035PV
4352036	PUMP-VAR DISPL	MPV-035-D-B-A-Y-R-S-F-AA-A-A-BBB-DL-A-FF-C-NNN-***	M35/44	035PV
4352039	PUMP-VAR DISPL	MPV-035-D-B-A-G-R-S-F-AA-A-A-BFF-DL-A-FF-B-NNN-***	M35/44	035PV
4352040	PUMP-VAR DISPL	MPV-035-D-B-A-G-L-S-F-AA-A-A-BFF-DL-A-FF-B-NNN-***	M35/44	035PV
4352041	PUMP-VAR DISPL	MPV-035-D-B-A-G-R-A-G-NN-A-A-BJM-DL-A-FF-B-NNN-***	M35/44	035PV
4352042	PUMP-VAR DISPL	MPV-035-D-B-A-A-R-S-G-AA-A-A-BJJ-DR-A-FF-B-NNN-***	M35/44	035PV
4352043	PUMP-VAR DISPL	MPV-035-D-B-A-A-R-S-G-AA-A-A-BDD-DR-A-FF-A-NNN-***	M35/44	035PV
4352044	PUMP-VAR DISPL	MPV-035-D-B-A-A-L-S-G-AA-A-A-BGG-DR-A-FF-C-NNN-***	M35/44	035PV
4352046	PUMP-VAR DISPL	MPV-035-D-B-A-G-R-S-G-BA-A-A-BFF-DL-A-FF-A-NNN-***	M35/44	035PV
4352047	PUMP-VAR DISPL	MPV-035-D-B-A-G-L-A-G-NN-A-A-BGG-DR-A-FF-C-NNN-***	M35/44	035PV
4352048	PUMP-VAR DISPL	MPV-035-D-B-A-G-L-A-G-NN-A-A-BGG-DL-A-FF-C-NNN-***	M35/44	035PV
4352049	PUMP-VAR DISPL	MPV-035-D-B-A-G-R-S-G-BA-A-A-BFF-DR-A-FF-D-NNN-***	M35/44	035PV
4352050	PUMP-VAR DISPL	MPV-035-D-B-A-G-L-S-G-AA-A-A-BGG-DR-A-FF-C-NNN-***	M35/44	035PV
4352051	PUMP-VAR DISPL	MPV-035-D-B-A-G-L-S-G-AA-A-A-BGG-DL-A-FF-C-NNN-***	M35/44	035PV
4352052	PUMP-VAR DISPL	MPV-035-D-B-A-Y-L-S-G-AA-A-A-BDD-DR-A-FF-C-NNN-***	M35/44	035PV
4352053	PUMP-VAR DISPL	MPV-035-D-B-A-Y-L-S-G-AA-A-A-BDD-DL-A-FF-C-NNN-***	M35/44	035PV

4352056	PUMP-VAR DISPL	MPV-035-D-B-A-G-R-S-G-AA-A-A-BBB-DR-A-FF-A-NNN-***	M35/44	035PV
4352058	PUMP-VAR DISPL	MPV-035-D-B-A-A-W-S-G-AA-A-A-BMM-DR-A-FF-A-NNN-***	M35/44	035PV
4352059	PUMP-VAR DISPL	MPV-035-D-B-A-A-R-S-F-AA-A-A-BDD-DR-A-FF-C-NNN-***	M35/44	035PV
4352061	PUMP-VAR-DISPL MPV035	MPV-035-D-B-A-G-R-S-F-AA-A-A-BJJ-DR-A-FF-A-NNN-***	M35/44	035PV
4352062	PUMP-VAR-DISPL MPV035	MPV-035-D-B-A-A-R-A-G-NN-A-A-BDD-DL-A-FF-A-NNN-***	M35/44	035PV
4352063	PUMP-VAR DISPL	MPV-035-D-B-A-A-R-A-F-NN-A-A-BFF-DR-A-FF-A-NNN-***	M35/44	035PV
4352065	PUMP-VAR-DISPL MPV035	MPV-035-D-B-A-A-L-S-F-AA-A-A-BGG-DR-A-FF-A-NNN-***	M35/44	035PV
4352066	PUMP-VAR DISPL	MPV-035-D-B-A-A-R-S-F-AA-A-A-BFF-DL-A-FF-A-NNN-***	M35/44	035PV
4352068	PUMP-VAR DISPL	MPV-035-D-B-A-G-R-S-G-AA-A-A-BGG-DL-A-FF-B-NNN-***	M35/44	035PV
4352069	PUMP-VAR-DISPL MPV035	MPV-035-D-B-A-G-R-S-C-BA-A-A-BFF-DL-A-FF-A-NNN-***	M35/44	035PV
4352072	PUMP-VAR DISPL	MPV-035-D-B-A-Y-L-S-G-AA-A-A-BCC-DL-A-FF-A-NNN-***	M35/44	035PV
4352073	PUMP-VAR-DISPL MPV035	MPV-035-D-B-A-G-R-S-N-AA-A-A-BHH-DL-A-FF-A-NNN-***	M35/44	035PV
4352074	PUMP-VAR DISPL	MPV-035-D-B-A-A-L-S-G-AA-A-A-BMM-DL-A-FF-C-NNN-***	M35/44	035PV
4352075	PUMP-VAR DISPL	MPV-035-D-B-A-A-R-S-G-AA-A-A-BFF-DL-A-FF-A-NNN-***	M35/44	035PV
4352076	PUMP-VAR DISPL	MPV-035-D-B-A-G-R-S-E-AA-A-A-BDD-DL-A-FF-C-NNN-***	M35/44	035PV
4352077	PUMP-VAR-DISPL MPV035	MPV-035-D-B-A-G-R-S-W-BA-A-A-BHH-DL-A-FF-A-NNN-***	M35/44	035PV
4352078	PUMP-VAR DISPL	MPV-035-D-B-A-G-R-S-G-AA-A-A-BBB-DL-A-FF-D-NNN-***	M35/44	035PV
4352079	PUMP-VAR DISPL	MPV-035-D-B-A-G-R-S-G-AA-A-A-BFF-DR-A-FF-A-NNN-***	M35/44	035PV
4352080	PUMP-VAR DISPL	MPV-035-D-B-A-G-R-A-G-NN-A-A-BFF-DR-A-FF-A-NNN-***	M35/44	035PV
4352081	PUMP-VAR DISPL	MPV-035-D-B-A-A-R-S-G-AA-A-A-BFF-DL-A-FF-B-NNN-***	M35/44	035PV
4352082	PUMP-VAR DISPL	MPV-035-D-B-A-Y-R-S-G-AA-A-A-BDD-DL-A-FF-A-NNN-***	M35/44	035PV
4352084	PUMP-VAR DISPL	MPV-035-D-B-A-G-L-S-E-AA-A-A-BGG-DR-A-FF-C-NNN-***	M35/44	035PV
4352085	PUMP-VAR DISPL	MPV-035-D-B-A-G-L-S-E-AA-A-A-BGG-DL-A-FF-C-NNN-***	M35/44	035PV
4352086	PUMP-VAR DISPL	MPV-035-D-B-A-G-R-S-G-AA-A-A-BFF-DR-A-FF-C-NNN-***	M35/44	035PV
4352087	PUMP-VAR DISPL	MPV-035-D-B-A-A-L-S-G-AA-A-A-BDD-DR-A-FF-A-NNN-***	M35/44	035PV
4352088	PUMP-VAR DISPL	MPV-035-D-B-A-A-R-S-G-BA-A-A-BFF-DL-A-FF-A-NNN-***	M35/44	035PV
4352089	PUMP-VAR DISPL	MPV-035-D-B-A-A-R-S-G-AA-A-A-BBB-DR-A-FF-A-NNN-***	M35/44	035PV
4352090	PUMP-VAR DISPL	MPV-035-D-B-A-A-R-S-E-AA-A-A-BHH-DR-A-FF-A-NNN-***	M35/44	035PV
4352091	PUMP-VAR DISPL	MPV-035-D-B-A-Y-R-S-G-AA-A-A-BJJ-DR-A-FF-A-NNN-***	M35/44	035PV
4352092	PUMP-VAR DISPL	MPV-035-D-B-A-A-R-S-G-AA-A-A-BEE-DL-A-FF-A-NNN-***	M35/44	035PV
4352094	PUMP-VAR DISPL	MPV-035-D-B-A-A-R-A-G-NN-A-A-BBB-DL-A-FF-A-NNN-***	M35/44	035PV
4352095	PUMP-VAR-DISPL MPV035	MPV-035-D-B-A-G-R-S-G-AA-A-A-BJJ-DR-A-FF-B-NNN-***	M35/44	035PV
4352096	PUMP-VAR DISPL	MPV-035-D-B-A-Y-R-S-G-AA-A-A-BMM-DR-A-FF-A-NNN-***	M35/44	035PV
4352097	PUMP-VAR DISPL	MPV-035-D-B-A-G-R-S-G-BA-A-A-BJJ-DL-A-FF-C-NNN-***	M35/44	035PV
4352098	PUMP-VAR DISPL	MPV-035-D-B-A-A-R-S-G-AA-A-A-BDD-DR-A-FF-B-NNN-***	M35/44	035PV
4352099	PUMP-VAR DISPL	MPV-035-D-B-A-G-R-S-E-AA-A-A-BJJ-DR-A-FF-A-NNN-***	M35/44	035PV

4352100	PUMP-VAR DISPL	MPV-035-D-B-A-A-R-A-G-NN-A-A-BJJ-DR-A-FF-A-NNN-***	M35/44	035PV
4352101	PUMP-VAR DISPL	MPV-035-D-B-A-A-R-A-G-NN-A-A-BFF-DR-A-FF-A-NNN-***	M35/44	035PV
4352102	PUMP-VAR DISPL	MPV-035-D-B-A-A-L-S-G-AA-A-A-BGG-DL-A-FF-A-NNN-***	M35/44	035PV
4352103	PUMP-VAR DISPL	MPV-035-D-B-A-A-L-S-G-AA-A-A-BGG-DR-A-FF-A-NNN-***	M35/44	035PV
4352106	PUMP-VAR-DISPL MPV035	MPV-035-D-B-A-A-R-A-C-NN-A-A-BMM-DL-A-FF-A-NNN-***	M35/44	035PV
4352107	PUMP-VAR DISPL	MPV-035-D-B-A-G-L-S-G-AA-A-A-BFF-DL-A-FF-C-NNN-***	M35/44	035PV
4352108	PUMP-VAR DISPL	MPV-035-D-B-A-A-R-S-E-BA-A-A-BFF-DR-A-FF-A-NNN-***	M35/44	035PV
4352109	PUMP-VAR DISPL	MPV-035-D-B-A-G-R-S-G-BA-A-A-BJJ-DR-A-FF-B-NNN-***	M35/44	035PV
4352110	PUMP-VAR DISPL	MPV-035-D-B-A-G-R-S-C-BA-A-A-BHH-DL-A-FF-D-NNN-***	M35/44	035PV
4352111	PUMP-VAR DISPL	MPV-035-D-B-A-G-R-S-G-AA-A-A-BDD-DL-A-FF-A-NNN-***	M35/44	035PV
4352112	PUMP-VAR DISPL	MPV-035-D-B-A-A-R-S-G-AA-A-A-BJJ-DL-A-FF-B-NNN-***	M35/44	035PV
4352113	PUMP-VAR DISPL	MPV-035-D-B-A-A-L-S-G-AA-A-A-BFF-DL-A-FF-C-NNN-***	M35/44	035PV
4352114	PUMP-VAR DISPL	MPV-035-D-B-A-A-R-S-G-BA-A-A-BGG-DL-A-FF-A-NNN-***	M35/44	035PV
4352115	PUMP-VAR DISPL	MPV-035-D-B-A-G-R-S-E-BA-A-A-BJJ-DR-A-FF-B-NNN-***	M35/44	035PV
4352116	PUMP-VAR DISPL	MPV-035-D-B-A-A-R-S-G-AA-A-A-BJJ-DL-A-FF-A-NNN-***	M35/44	035PV
4352117	PUMP-VAR DISPL	MPV-035-D-B-A-A-R-S-G-BA-A-A-BGG-DL-A-FF-C-NNN-***	M35/44	035PV
4352118	PUMP-VAR-DISPL MPV035	MPV-035-D-B-A-A-R-S-G-AA-A-A-BFF-DL-A-FF-C-NNN-***	M35/44	035PV
4352120	PUMP-VAR DISPL	MPV-035-D-B-A-A-W-S-F-AA-A-A-BJJ-DL-A-FF-A-NNN-***	M35/44	035PV
4352122	PUMP-VAR DISPL	MPV-035-D-B-A-Y-R-S-G-AA-A-A-BBB-DL-A-FF-A-NNN-***	M35/44	035PV
4352123	PUMP-VAR DISPL	MPV-035-D-B-A-A-L-S-F-AA-A-A-BJJ-DR-A-FF-A-NNN-***	M35/44	035PV
4352124	PUMP-VAR DISPL	MPV-035-D-B-A-N-R-S-G-AA-A-A-BHH-DR-A-FF-A-NNN-***	M35/44	035PV
4352126	PUMP-VAR DISPL	MPV-035-D-B-A-A-R-S-W-AA-A-A-BJJ-DR-A-FF-A-NNN-***	M35/44	035PV
4352129	PUMP-VAR DISPL	MPV-035-D-B-A-G-R-S-F-BA-A-A-BFF-DL-A-FF-F-NNN-***	M35/44	035PV
4352130	PUMP-VAR DISPL	MPV-035-D-B-A-A-R-S-F-AA-A-A-BJJ-DR-A-FF-C-NNN-***	M35/44	035PV
4352131	PUMP-VAR DISPL	MPV-035-D-B-A-Y-L-S-G-AA-A-A-BMM-DR-A-FF-C-NNN-***	M35/44	035PV
4352133	PUMP-VAR DISPL	MPV-035-D-B-A-A-R-S-G-BA-A-A-BDD-DR-A-FF-C-NNN-***	M35/44	035PV
4352136	PUMP-VAR DISPL	MPV-035-D-B-A-A-W-S-G-AA-A-A-BGG-DL-A-FF-A-NNN-***	M35/44	035PV
4352137	PUMP-VAR DISPL	MPV-035-D-B-A-Y-R-S-G-AA-A-A-BDD-DR-A-FF-C-NNN-***	M35/44	035PV
4352138	PUMP-VAR DISPL	MPV-035-D-B-A-G-L-S-G-AA-A-A-BHB-DL-A-FF-B-NNN-***	M35/44	035PV
4352140	PUMP-VAR DISPL	MPV-035-D-B-A-Y-R-S-G-AA-A-A-BJJ-DR-A-FF-C-NNN-***	M35/44	035PV
4352141	PUMP-VAR DISPL	MPV-035-D-B-A-A-L-S-F-AA-A-A-BFF-DR-A-FF-A-NNN-***	M35/44	035PV
4352142	PUMP-VAR DISPL	MPV-035-D-B-A-A-R-S-G-AA-A-A-BBB-DL-A-FF-A-NNN-***	M35/44	035PV
4352143	PUMP-VAR DISPL	MPV-035-D-B-A-A-R-S-E-AA-A-A-BGG-DR-A-FF-C-NNN-***	M35/44	035PV
4352144	PUMP-VAR DISPL	MPV-035-D-B-A-Y-W-S-G-AA-A-A-BFF-DR-A-FF-A-NNN-***	M35/44	035PV
4352145	PUMP-VAR DISPL	MPV-035-D-B-A-A-L-S-G-AA-A-A-BJJ-DR-A-FF-C-NNN-***	M35/44	035PV
4352146	PUMP-VAR DISPL	MPV-035-D-B-A-A-L-S-G-AA-A-A-BJJ-DL-A-FF-C-NNN-***	M35/44	035PV

4352148	PUMP-VAR DISPL	MPV-035-D-B-A-Y-R-S-G-AA-A-A-BGG-DR-A-FF-A-NNN-***	M35/44	035PV
4352149	PUMP-VAR DISPL	MPV-035-D-B-A-A-R-S-G-AA-A-A-BMM-DL-A-FF-C-NNN-***	M35/44	035PV
4352150	PUMP-VAR DISPL	MPV-035-D-B-A-A-L-S-F-AA-A-A-BHH-DR-A-FF-A-NNN-***	M35/44	035PV
4352151	PUMP-VAR DISPL	MPV-035-D-B-A-Y-L-S-G-AA-A-A-BCC-DR-A-FF-A-NNN-***	M35/44	035PV
4352152	PUMP-VAR DISPL	MPV-035-D-B-A-G-L-S-G-AA-A-A-BJJ-DR-A-FF-C-NNN-***	M35/44	035PV
4352158	PUMP-VAR DISPL	MPV-035-D-B-A-Y-R-S-F-AA-A-A-BMM-DL-A-FF-A-NNN-***	M35/44	035PV
4352160	PUMP-VAR DISPL	MPV-035-D-B-A-Y-R-S-G-AA-A-A-BCC-DR-A-FF-B-NNN-***	M35/44	035PV
4352161	PUMP-VAR DISPL	MPV-035-D-B-A-A-W-S-G-AA-A-A-BFF-DR-A-FF-B-NNN-***	M35/44	035PV
4352163	PUMP-VAR DISPL	MPV-035-D-B-A-G-L-S-C-AA-A-A-BCC-DR-A-FF-C-NNN-***	M35/44	035PV
4352164	PUMP-VAR DISPL	MPV-035-D-B-A-Y-R-S-G-AA-A-A-BHH-DL-A-FF-A-NNN-***	M35/44	035PV
4352165	PUMP-VAR DISPL	MPV-035-D-B-A-A-R-S-G-AA-A-A-BDD-DR-A-FF-C-NNN-***	M35/44	035PV
4352166	PUMP-VAR DISPL	MPV-035-D-B-A-A-R-S-E-AA-A-A-BMM-DL-A-FF-C-NNN-***	M35/44	035PV
4352167	PUMP-VAR-DISPL MPV035	MPV-035-D-B-A-G-R-S-G-AA-A-A-BFF-DL-A-FF-A-NNN-***	M35/44	035PV
4352168	PUMP-VAR DISPL	MPV-035-D-B-A-A-L-S-G-AA-A-A-BGG-DR-A-FF-B-NNN-***	M35/44	035PV
4352169	PUMP-VAR DISPL	MPV-035-D-B-A-A-R-S-G-AA-A-A-BJJ-DR-A-FF-A-NNN-***	M35/44	035PV
4352170	PUMP-VAR-DISPL MPV035	MPV-035-D-B-A-A-R-S-C-AA-A-A-BFF-DR-A-FF-A-NNN-***	M35/44	035PV
4352171	PUMP-VAR DISPL	MPV-035-D-B-A-A-R-S-G-AA-A-A-BCC-DR-A-FF-A-NNN-***	M35/44	035PV
4352172	PUMP-VAR DISPL	MPV-035-D-B-A-G-R-S-G-BA-A-A-BEE-DR-A-FF-A-NNN-***	M35/44	035PV
4352173	PUMP-VAR DISPL	MPV-035-D-B-A-A-R-S-H-AA-A-A-BFF-DR-A-FF-A-NNN-***	M35/44	035PV
4352175	PUMP-VAR DISPL	MPV-035-D-B-A-A-R-S-G-AA-A-A-BBB-DR-A-FF-C-NNN-***	M35/44	035PV
4352176	PUMP-VAR DISPL	MPV-035-D-B-A-A-L-A-F-NN-A-A-BJJ-DR-A-FF-B-NNN-***	M35/44	035PV
4352177	PUMP-VAR DISPL	MPV-035-D-B-A-G-R-S-F-BA-A-A-BJJ-DL-A-FF-B-NNN-***	M35/44	035PV
4352178	PUMP-VAR DISPL	MPV-035-D-B-A-G-R-A-G-NN-A-A-BHH-DR-A-FF-A-NNN-***	M35/44	035PV
4352179	PUMP-VAR DISPL	MPV-035-D-B-A-G-W-A-G-NN-A-A-BHH-DR-A-FF-D-NNN-***	M35/44	035PV
4352180	PUMP-VAR DISPL	MPV-035-D-B-A-A-W-S-F-AA-A-A-BGG-DR-A-FF-A-NNN-***	M35/44	035PV
4353025	MOTOR-FIXED-DISPL MMF035	MMF-035-D-A-A-G-A-B-NNR-***	M35/44	035MF
4353026	MOTOR-FIXED-DISPL MMF035	MMF-035-D-A-F-A-A-B-NNN-***	M35/44	035MF
4353027	MOTOR-FIXED-DISPL MMF035	MMF-035-D-A-A-A-A-B-NNN-***	M35/44	035MF
4353028	MOTOR-FIXED-DISPL MMF035	MMF-035-D-A-F-B-A-B-NNN-***	M35/44	035MF
4353029	MOTOR-FIXED-DISPL MMF035	MMF-035-D-A-A-B-A-B-NNN-***	M35/44	035MF
4353030	MOTOR-FIXED-DISPL MMF035	MMF-035-D-A-S-A-A-B-NNN-***	M35/44	035MF
4353031	MOTOR-FIX DISPL	MMF-035-D-B-C-C-A-B-NNN-***	M35/44	035MF
4353032	MOTOR-FIX DISPL	MMF-035-D-A-S-B-A-B-NNN-***	M35/44	035MF
4353033	MOTOR-FIXED-DISPL MMF035	MMF-035-D-A-S-B-A-B-NNR-***	M35/44	035MF
4353034	MOTOR-FIXED-DISPL MMF035	MMF-035-D-A-A-A-A-B-NNR-***	M35/44	035MF
4353035	MOTOR-FIX DISPL	MMF-035-D-A-F-E-A-B-NNN-***	M35/44	035MF

4353036	MOTOR-FIX DISPL	MMF-035-D-A-A-E-A-B-NNN-***	M35/44	035MF
4353037	MOTOR-FIX DISPL	MMF-035-D-A-F-U-A-B-NNN-***	M35/44	035MF
4353038	MOTOR-FIX DISPL	MMF-035-D-A-A-U-A-B-NNN-***	M35/44	035MF
4353039	MOTOR-FIXED-DISPL MMF035	MMF-035-D-A-S-E-A-B-NNN-***	M35/44	035MF
4353040	MOTOR-FIX DISPL	MMF-035-D-B-C-F-A-B-NNN-***	M35/44	035MF
4353041	MOTOR-FIX DISPL	MMF-035-D-A-S-U-A-B-NNN-***	M35/44	035MF
4353042	MOTOR-FIX DISPL	MMF-035-D-A-S-U-A-B-NNR-***	M35/44	035MF
4353043	MOTOR-FIX DISPL	MMF-035-D-A-A-E-A-B-NNR-***	M35/44	035MF
4353044	MOTOR-FIXED-DISPL MMF035	MMF-035-D-A-A-G-A-B-NNN-***	M35/44	035MF
4353045	MOTOR-FIXED-DISPL MMF035	MMF-035-D-A-A-M-A-B-NNN-***	M35/44	035MF
4353046	MOTOR-FIXED-DISPL MMF035	MMF-035-D-A-F-M-A-B-NNN-***	M35/44	035MF
4353047	MOTOR-FIX DISPL	MMF-035-D-B-C-C-C-D-NNN-***	M35/44	035MF
4353048	MOTOR-FIX DISPL	MMF-035-D-A-L-A-A-B-NNN-***	M35/44	035MF
4353049	MOTOR-FIXED-DISPL MMF035	MMF-035-D-A-S-M-A-B-NNR-***	M35/44	035MF
4353050	MOTOR-FIX DISPL	MMF-035-D-A-N-B-A-B-NNN-***	M35/44	035MF
4353051	MOTOR-FIX DISPL	MMF-035-D-A-A-A-C-D-NNN-***	M35/44	035MF
4353053	MOTOR-FIXED-DISPL MMF035	MMF-035-D-A-A-M-A-B-NNR-***	M35/44	035MF
4353054	MOTOR-FIX DISPL	MMF-035-D-A-F-G-A-B-NNN-***	M35/44	035MF
4353056	MOTOR-FIX DISPL	MMF-035-D-A-A-H-A-B-NNN-***	M35/44	035MF
4353057	MOTOR-FIX DISPL	MMF-035-D-A-F-A-C-D-NNN-***	M35/44	035MF
4353058	MOTOR-FIX DISPL	MMF-035-D-A-F-Y-A-B-NNN-***	M35/44	035MF
4353059	MOTOR-FIXED-DISPL MMF035	MMF-035-D-A-A-1-A-B-NNN-***	M35/44	035MF
4353060	MOTOR-FIX DISPL	MMF-035-D-A-F-A-C-G-NNN-***	M35/44	035MF
4353061	MOTOR-FIX DISPL	MMF-035-D-A-A-B-C-D-NNN-***	M35/44	035MF
4353062	MOTOR-FIX DISPL	MMF-035-D-A-A-4-C-K-NBJ-***	M35/44	035MF
4353063	MOTOR-FIXED-DISPL MMF035	MMF-035-D-A-L-G-C-F-NNR-***	M35/44	035MF
4353064	MOTOR-FIX DISPL	MMF-035-D-A-F-G-C-D-NNN-***	M35/44	035MF
4353065	MOTOR-FIX DISPL	MMF-035-D-A-F-U-C-G-NNN-***	M35/44	035MF
4353066	MOTOR-FIX DISPL	MMF-035-D-A-N-A-A-B-NNN-***	M35/44	035MF
4353067	MOTOR-FIX DISPL	MMF-035-D-A-A-H-C-K-NNN-***	M35/44	035MF
4353068	MOTOR-FIXED-DISPL MMF035	MMF-035-D-A-A-A-C-F-NNN-***	M35/44	035MF
4353069	MOTOR-FIXED-DISPL MMF035	MMF-035-D-A-S-M-C-F-NNR-***	M35/44	035MF
4353071	MOTOR-FIX DISPL	MMF-035-D-A-A-H-C-D-NNN-***	M35/44	035MF
4353072	MOTOR-FIX DISPL	MMF-035-D-A-F-H-A-B-NNN-***	M35/44	035MF
4353073	MOTOR-FIX DISPL	MMF-035-D-A-F-H-C-K-NNN-***	M35/44	035MF
4353074	MOTOR-FIX DISPL	MMF-035-D-A-N-1-C-G-NNN-***	M35/44	035MF

4353075	MOTOR-FIX DISPL	MMF-035-D-A-S-H-C-G-NNN-***	M35/44	035MF
4353076	MOTOR-FIX DISPL	MMF-035-D-B-N-C-A-B-NNN-***	M35/44	035MF
4353079	MOTOR-FIX DISPL	MMF-035-D-B-N-C-A-G-NNN-***	M35/44	035MF
4353080	MOTOR-FIX DISPL	MMF-035-D-A-N-U-C-P-NNN-***	M35/44	035MF
4353081	MOTOR-FIX DISPL	MMF-035-D-A-N-U-C-D-NNN-***	M35/44	035MF
4353082	MOTOR-FIX DISPL	MMF-035-D-A-F-H-C-D-NNN-***	M35/44	035MF
4353083	MOTOR-FIX DISPL	MMF-035-D-A-F-U-C-D-NNN-***	M35/44	035MF
4353084	MOTOR-FIX DISPL	MMF-035-D-A-F-G-C-G-NBJ-***	M35/44	035MF
4353085	MOTOR-FIX DISPL	MMF-035-D-A-A-U-C-G-NBJ-***	M35/44	035MF
4353086	MOTOR-FIX DISPL	MMF-035-D-A-F-E-C-G-NNN-***	M35/44	035MF
4353087	MOTOR-FIX DISPL	MMF-035-D-A-S-H-A-B-NNN-***	M35/44	035MF
4353088	MOTOR-FIX DISPL	MMF-035-D-A-A-1-C-D-NNN-***	M35/44	035MF
4353089	MOTOR-FIXED-DISPL MMF035	MMF-035-D-A-F-G-C-S-NBJ-***	M35/44	035MF
4353090	MOTOR-FIX DISPL	MMF-035-D-A-F-U-A-G-NNN-***	M35/44	035MF
4353091	MOTOR-FIXED-DISPL MMF035	MMF-035-D-A-N-U-A-B-NNN-***	M35/44	035MF
4353092	MOTOR-FIX DISPL	MMF-035-D-A-A-E-C-G-NNN-***	M35/44	035MF
4353093	MOTOR-FIX DISPL	MMF-035-D-A-A-M-C-P-NNN-***	M35/44	035MF
4353094	MOTOR-FIX DISPL	MMF-035-D-A-N-G-A-B-NNN-***	M35/44	035MF
4353095	MOTOR-FIX DISPL	MMF-035-D-A-S-G-A-B-NNN-***	M35/44	035MF
4353096	MOTOR-FIX DISPL	MMF-035-D-A-A-G-A-S-NNN-***	M35/44	035MF
4353098	MOTOR-FIX DISPL	MMF-035-D-A-S-M-A-B-NNN-***	M35/44	035MF
4353099	MOTOR-FIXED-DISPL MMF035	MMF-035-D-A-S-1-A-B-NNR-***	M35/44	035MF
4353101	MOTOR-FIX DISPL	MMF-035-D-A-F-1-A-B-NNN-***	M35/44	035MF
4353102	MOTOR-FIX DISPL	MMF-035-D-A-A-H-C-G-NNN-***	M35/44	035MF
4353103	MOTOR-FIX DISPL	MMF-035-D-A-N-H-A-B-NNN-***	M35/44	035MF
4353106	MOTOR-FIX DISPL	MMF-035-D-A-F-G-A-S-NNN-***	M35/44	035MF
4353107	MOTOR-FIX DISPL	MMF-035-D-A-A-G-A-S-NNR-***	M35/44	035MF
4354025	MOTOR-VAR-DISPL MMV035	MMV-035-D-A-A-D-R-R-NNN-***	M35/44	035MV
4354026	MOTOR-VAR DISPL	MMV-035-D-A-A-J-R-R-NNN-***	M35/44	035MV
4354027	MOTOR-VAR-DISPL MMV035	MMV-035-D-A-A-D-L-R-NNR-***	M35/44	035MV
4354028	MOTOR-VAR DISPL	MMV-035-D-A-A-D-L-R-NNN-***	M35/44	035MV
4354029	MOTOR-VAR DISPL	MMV-035-D-A-A-J-L-R-NNN-***	M35/44	035MV
4354030	MOTOR-VAR-DISPL MMV035	MMV-035-D-A-A-V-R-R-NNN-***	M35/44	035MV
4355026	PUMP-TANDEM, VAR DISPL	MPT-035-D-A-R-R-G-AA-B-A-A-A-BEE-DL-A-FF-B-C-A-A-BEE-DL-A-FF-A-NNN-**	M35/44	035PT
4355033	PUMP-TANDEM, VAR DISPL	MPT-035-D-G-R-A-G-NN-B-A-A-A-BEE-DL-A-FF-B-C-A-A-BEE-DL-A-FF-H-GNJ-**	M35/44	035PT
4355034	PUMP-TANDEM, VAR DISPL	MPT-035-D-G-R-A-G-NN-B-A-A-A-BEE-DL-A-FF-B-C-A-A-BEE-DL-A-FF-H-GNK-**	M35/44	035PT

4355039	PUMP-TANDEM, VAR DISPL	MPT-035-D-G-W-A-N-NN-B-A-A-A-BDD-DR-A-FF-B-C-A-A-BDD-DL-A-FF-J-NNN-	M35/44	035PT
4355043	PUMP-TANDEM, VAR DISPL	MPT-035-D-G-L-R-A-AA-B-A-A-A-BJJ-DR-A-FF-B-C-A-A-BJJ-DR-A-FF-H-GNS-***	M35/44	035PT
4355044	PUMP-TANDEM, VAR DISPL	MPT-035-D-A-R-A-G-NN-B-A-A-A-BEE-DL-A-FF-B-C-A-A-BEE-DL-A-FF-A-NNN-**	M35/44	035PT
4355045	PUMP-TANDEM, VAR DISPL	MPT-035-D-G-R-A-G-NN-B-A-A-A-BEE-DL-A-FF-B-C-A-A-BEE-DL-A-FF-A-NNN-**	M35/44	035PT
4355051	PUMP-TANDEM, VAR DISPL	MPT-035-D-A-R-R-E-BA-B-A-A-A-BFF-DL-A-FF-B-C-A-A-BFF-DL-A-FF-A-NNN-***	M35/44	035PT
4355052	PUMP-TANDEM, VAR DISPL	MPT-035-D-A-R-R-G-AA-B-A-A-A-BMM-DR-A-FF-B-C-A-A-BMM-DR-A-FF-A-NNN-	M35/44	035PT
4355053	PUMP-TANDEM-VAR-DISPL MPT035	MPT-035-D-A-R-A-A-NN-B-A-A-A-BJJ-DR-A-FF-B-C-A-A-BJJ-DW-A-FF-K-NNN-**	M35/44	035PT
4355062	PUMP-TANDEM, VAR DISPL	MPT-035-D-A-L-R-G-AA-B-A-A-A-BFF-DR-A-FF-B-C-A-A-BFF-DR-A-FF-C-NNN-**	M35/44	035PT
4355068	PUMP-TANDEM, VAR DISPL	MPT-035-D-A-L-R-G-AA-B-A-A-A-BGG-DR-A-FF-B-A-A-A-BGG-DR-A-FF-C-NNN-*	M35/44	035PT
4355075	PUMP-TANDEM, VAR DISPL	MPT-035-D-A-R-R-A-BA-B-A-A-A-BFF-DL-A-FF-B-C-A-A-BFF-DL-A-FF-A-NNN-***	M35/44	035PT
4355080	PUMP-TANDEM, VAR DISPL	MPT-035-D-A-R-R-C-BA-B-A-A-A-BFF-DL-A-FF-B-C-A-A-BFF-DL-A-FF-A-NNN-***	M35/44	035PT
4355099	PUMP-TANDEM, VAR DISPL	MPT-035-D-A-R-A-E-NN-B-A-A-A-BBB-DR-A-FF-B-C-A-A-BBB-DL-A-FF-A-NNN-*	M35/44	035PT
4355100	PUMP-TANDEM, VAR DISPL	MPT-035-D-A-W-A-E-NN-B-A-A-A-BHH-DR-A-FF-B-C-A-A-BHH-DL-A-FF-D-NNN-	M35/44	035PT
4355102	PUMP-TANDEM, VAR DISPL	MPT-035-D-A-W-A-E-NN-B-A-A-A-BHH-DL-A-FF-B-C-A-A-BHH-DL-A-FF-K-NNN-	M35/44	035PT
4355109	PUMP-TANDEM, VAR DISPL	MPT-035-D-G-W-A-R-NN-B-A-A-A-BHH-DL-A-FF-B-C-A-A-BHH-DL-A-FF-D-NNN-	M35/44	035PT
4355110	PUMP-TANDEM, VAR DISPL	MPT-035-D-C-R-R-G-AA-B-A-A-A-BBB-DR-A-FF-B-C-A-A-BBB-DR-A-FF-A-NNN-*	M35/44	035PT
4355112	PUMP-TANDEM, VAR DISPL	MPT-035-D-A-R-S-G-AA-B-A-A-A-BBB-DR-A-FF-B-C-A-A-BBB-DR-A-FF-A-NNN-*	M35/44	035PT
4355113	PUMP-TANDEM, VAR DISPL	MPT-035-D-A-R-S-G-AA-B-A-A-A-BDD-DR-A-FF-B-C-A-A-BDD-DR-A-FF-D-NNN-*	M35/44	035PT
4355120	PUMP-TANDEM, VAR DISPL	MPT-035-D-G-R-A-J-NN-B-A-A-A-BEE-DL-A-FF-B-C-A-A-BEE-DL-A-FF-H-GSX-***	M35/44	035PT
4355121	PUMP-TANDEM-VAR-DISPL MPT035	MPT-035-D-A-R-R-G-AA-B-A-A-A-BGG-DR-A-FF-B-C-A-A-BGG-DL-A-FF-A-NNN-*	M35/44	035PT
4355122	PUMP-TANDEM, VAR DISPL	MPT-035-D-C-W-R-H-BA-C-A-A-A-BJJ-DL-A-FF-C-C-A-A-BJJ-DL-A-FF-B-NNN-***	M35/44	035PT
4355126	PUMP-TANDEM, VAR DISPL	MPT-035-D-A-R-A-G-NN-B-A-A-A-BGG-DL-A-FF-B-C-A-A-BGG-DL-A-FF-A-NNN-*	M35/44	035PT
4355127	PUMP-TANDEM, VAR DISPL	MPT-035-D-G-L-A-J-NN-B-A-A-A-BEE-DL-A-FF-B-C-A-A-BEE-DL-A-FF-A-NNN-***	M35/44	035PT
4355129	PUMP-TANDEM, VAR DISPL	MPT-035-D-A-R-R-G-BA-B-A-A-A-BDD-DR-A-FF-B-C-A-A-BDD-DR-A-FF-D-NNN-*	M35/44	035PT
4355131	PUMP-TANDEM, VAR DISPL	MPT-035-D-G-L-R-G-AA-B-A-A-A-BMM-DL-A-FF-B-C-A-A-BFF-DL-A-FF-A-NNN-*	M35/44	035PT
4355133	PUMP-TANDEM, VAR DISPL	MPT-035-D-A-R-S-G-AA-B-A-A-A-BDD-DR-A-FF-B-C-A-A-BDD-DL-A-FF-B-NNN-*	M35/44	035PT
4355134	PUMP-TANDEM, VAR DISPL	MPT-035-D-A-W-A-E-NN-B-A-A-A-BDD-DR-A-FF-B-C-A-A-BDD-DY-A-FF-J-NNN-	M35/44	035PT
4355137	PUMP-TANDEM-VAR-DISPL MPT035	MPT-035-D-A-L-S-G-AA-B-A-A-A-BJJ-DR-A-FF-B-C-A-A-BJJ-DR-A-FF-C-NNN-***	M35/44	035PT
4355138	PUMP-TANDEM, VAR DISPL	MPT-035-D-A-R-A-G-NN-H-A-A-A-BGG-DL-A-FF-H-C-A-A-BGG-DL-A-FF-A-NOP-*	M35/44	035PT
4355139	PUMP-TANDEM, VAR DISPL	MPT-035-D-A-R-R-G-AA-B-A-A-A-BDD-DR-A-FF-B-C-A-A-BDD-DR-A-FF-C-NNN-*	M35/44	035PT
4355141	PUMP-TANDEM, VAR DISPL	MPT-035-D-G-R-A-J-NN-B-A-A-A-BEE-DL-A-FF-B-C-A-A-BEE-DL-A-FF-H-GUG-**	M35/44	035PT
4355142	PUMP-TANDEM, VAR DISPL	MPT-035-D-V-L-A-F-NN-G-A-A-A-BFF-DR-A-FF-G-C-A-A-BFF-DR-A-FF-6-NND-**	M35/44	035PT
4355144	PUMP-TANDEM, VAR DISPL	MPT-035-D-V-R-R-A-BA-H-A-A-A-BJJ-DL-A-FF-H-C-A-A-BJJ-DL-A-FF-B-NOD-***	M35/44	035PT
4355145	PUMP-TANDEM, VAR DISPL	MPT-035-D-A-L-A-G-NN-H-A-A-A-BGG-DL-A-FF-H-C-A-A-BGG-DL-A-FF-A-NOP-*	M35/44	035PT
4355147	PUMP-TANDEM, VAR DISPL	MPT-035-D-G-R-A-J-NN-B-A-A-A-BEE-DL-A-FF-B-C-A-A-BEE-DL-A-FF-A-NNN-**	M35/44	035PT
4355150	PUMP-TANDEM, VAR DISPL	MPT-035-D-G-R-A-J-NN-B-A-A-A-BFF-DL-A-FF-B-C-A-A-BFF-DL-A-FF-H-GNK-***	M35/44	035PT

4355151	PUMP-TANDEM, VAR DISPL	MPT-035-D-G-R-A-J-NN-B-A-A-A-BFF-DL-A-FF-B-C-A-A-BFF-DL-A-FF-A-NNN-***	M35/44	035PT
4355152	PUMP-TANDEM, VAR DISPL	MPT-035-D-G-R-A-J-NN-B-A-A-A-BFF-DL-A-FF-B-C-A-A-BFF-DL-A-FF-H-GSX-***	M35/44	035PT
4355153	PUMP-TANDEM, VAR DISPL	MPT-035-D-G-R-A-J-NN-B-A-A-A-BFF-DL-A-FF-B-C-A-A-BFF-DL-A-FF-H-GUG-***	M35/44	035PT
4355156	PUMP-TANDEM, VAR DISPL	MPT-035-D-A-R-A-G-NN-H-A-A-A-BJJ-DL-A-FF-H-C-A-A-BJJ-DL-A-FF-A-NNN-***	M35/44	035PT
4355157	PUMP-TANDEM, VAR DISPL	MPT-035-D-A-R-R-E-AA-B-A-A-A-BDD-DR-A-FF-B-C-A-A-BDD-DR-A-FF-B-NNN-*	M35/44	035PT
4355159	PUMP-TANDEM, VAR DISPL	MPT-035-D-A-R-R-G-BA-B-A-A-A-BHH-DR-A-FF-B-A-A-A-BHH-DR-A-FF-A-NNN-*	M35/44	035PT
4355160	PUMP-TANDEM, VAR DISPL	MPT-035-D-A-R-R-J-BA-B-A-A-A-BHH-DR-A-FF-B-C-A-A-BHH-DR-A-FF-A-NNN-*	M35/44	035PT
4355161	PUMP-TANDEM, VAR DISPL	MPT-035-D-A-L-R-G-BA-B-A-A-A-BHH-DR-A-FF-B-C-A-A-BHH-DR-A-FF-C-NNN-*	M35/44	035PT
4355163	PUMP-TANDEM, VAR DISPL	MPT-035-D-C-Y-A-E-NN-B-A-A-A-BJJ-DT-A-FF-B-C-A-A-BJJ-DT-A-FF-J-NNN-***	M35/44	035PT
4355164	PUMP-TANDEM, VAR DISPL	MPT-035-D-C-Y-A-E-NN-B-A-A-A-BJJ-DS-A-FF-B-C-A-A-BJJ-DN-A-FF-J-NNN-***	M35/44	035PT
4400076	SHAFT-LC/KC MOTOR 13 TOOTH (D000A)		LV / KV MOTORS	PARTS - L/K-MV
4410093	K-HUELSE 13Z.-16/32 42P041		SERIES 42	PARTS - S42
4412030	PUMP-VAR-DISPL, CCW, S42PV041, XDC	42-L-41-D-NDNN-NN-B-D-G-2-C-N-N-00-00-B-N-N-NNN-CNN	SERIES 42	S42-041PV/051PV
4412087	PUMP-VAR-DISPL, CCW, S42PV041, MDC	42-L-41-D-ANAB-03-A-N-A-3-F-N-B-NN-NN-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
4412088	PUMP-VAR-DISPL, CCW, S42PV041, MDC	42-L-41-C-ANAB-03-A-N-A-3-F-N-N-NN-NN-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
4412096	PUMP-VAR-DISPL, CCW, S42PV041, FNR	42-L-41-C-F4NN-73-J-D-C-2-F-N-N-34-34-N-A-A-NNN-NNN	SERIES 42	S42-041PV/051PV
4412124	PUMP-VAR-DISPL, CCW, S42PV041, MDC	42-L-41-D-ANA3-03-B-2-C-2-F-N-N-28-14-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
4412143	PUMP-VAR-DISPL, CCW, S42PV041, NFPE	42-L-41-D-G1A1-70-J-3-G-3-F-5-A-34-34-B-0-0-0-NNN-NNN	SERIES 42	S42-041PV/051PV
4412151	PUMP-VAR-DISPL, CCW, S42PV041, NFPE	42-L-41-G-G1A1-70-J-3-G-3-F-5-A-34-34-B-0-0-0-NNN-NNN	SERIES 42	S42-041PV/051PV
4412158	PUMP-VAR-DISPL, CCW, S42PV041, MDC	42-L-41-D-ANA3-11-B-3-B-3-F-N-N-28-28-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
4412189	PUMP-VAR-DISPL 42PV041 CCW	42-L-41-E-ANNB-02-A-N-A-2-F-N-V-34-34-N-D-D-NNN-ENN	SERIES 42	S42-041PV/051PV
4412190	PUMP-VAR-DISPL 42PV041 CCW	42-L-41-D-ANNB-02-A-N-A-2-F-N-N-34-34-N-D-D-NNN-ENN	SERIES 42	S42-041PV/051PV
4412193	PUMP-VAR-DISPL, CCW, S42PV041, MDC	42-L-51-D-ANN5-03-B-2-B-2-F-N-N-34-34-N-N-N-NNN-NGJ	SERIES 42	S42-041PV/051PV
4412197	PUMP-VAR-DISPL, CCW, S42PV041, FNR	42-L-41-C-F4NN-73-J-D-B-2-F-N-N-21-21-N-A-A-NNN-NNN	SERIES 42	S42-041PV/051PV
4412199	PUMP-VAR-DISPL, CCW, S42PV041, FNR	42-L-51-E-F4NN-73-J-3-B-3-F-N-V-21-21-B-A-A-NNN-NNN	SERIES 42	S42-041PV/051PV
4412204	PUMP-VAR-DISPL, CCW, S42PV041, FNR	42-L-41-E-F2NN-73-J-5-B-3-D-N-B-21-21-B-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
4412206	PUMP-VAR-DISPL, CCW, S42PV041, FNR	42-L-41-C-F2NN-73-J-5-B-3-D-N-A-21-21-B-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
4412540	PUMP-VAR-DISPL, CW, S42PV041, XDC	42-R-41-C-NDNN-NN-B-D-G-2-C-N-N-00-00-B-N-N-NNN-CNN	SERIES 42	S42-041PV/051PV
4412546	PUMP-VAR DISPL, CW	42-R-41-C-ANNB-03-B-5-G-2-C-N-N-30-30-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
4412558	PUMP-VAR-DISPL, CW, S42PV041, FNR	42-R-41-D-F2NN-72-J-5-G-2-C-N-A-28-28-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
4412560	PUMP-VAR-DISPL CW 42PV041	42-R-41-D-G3AN-52-P-2-X-N-F-5-A-34-34-N-0-0-0-NNN-NNN	SERIES 42	S42-041PV/051PV
4412563	PUMP-VAR-DISPL CW 42PV041	42-R-41-D-G1A1-76-M-N-A-2-G-5-N-38-38-B-0-0-0-NNN-NNN	SERIES 42	S42-041PV/051PV
4412564	PUMP-VAR-DISPL, CW, S42PV041, NFPE	42-R-41-D-G1A1-76-M-N-A-2-G-5-N-30-30-B-0-0-0-NNN-NNN	SERIES 42	S42-041PV/051PV
4412573	PUMP-VAR-DISPL, CW, S42PV041, XDC	42-R-41-D-NDNN-NN-B-D-G-2-C-N-N-00-00-B-N-N-NNN-CNN	SERIES 42	S42-041PV/051PV
4412576	PUMP-VAR-DISPL, CW, S42PV041, FNR	42-R-41-D-F5NN-75-J-D-X-A-F-5-Z-34-34-N-1-1-NNN-NNN	SERIES 42	S42-041PV/051PV
4412599	PUMP-VAR-DISPL, CW, S42PV041, NFPH	42-R-41-C-G3AN-50-P-3-G-2-F-1-A-28-28-B-1-1-NNN-NNN	SERIES 42	S42-041PV/051PV

4412600	PUMP-VAR-DISPL, CW, S42PV041, NFPH	42-R-41-D-G3AN-50-P-3-G-2-F-1-B-28-28-B-1-1-NNN-NNN	SERIES 42	S42-041PV/051PV
4412602	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-G3AN-53-P-3-G-2-F-1-A-34-34-B-0-0-NNN-NNN	SERIES 42	S42-041PV/051PV
4412605	PUMP-VAR-DISPL CW 42PV041	42-R-41-G-G3AN-50-P-D-G-2-H-5-A-41-41-N-0-0-NNN-NNN	SERIES 42	S42-041PV/051PV
4412610	PUMP-VAR-DISPL, CW, S42PV041, MDC	42-R-41-C-ANNB-03-B-3-G-2-F-N-N-34-34-N-A-A-NNN-NNN	SERIES 42	S42-041PV/051PV
4412637	PUMP-VAR-DISPL CW 42PV041	42-R-41-D-F5NN-74-J-D-B-2-P-1-V-34-34-N-8-8-NNN-BCB	SERIES 42	S42-041PV/051PV
4412639	PUMP-VAR-DISPL, CW, S42PV041, FNR	42-R-41-C-F2NN-72-J-2-G-2-C-N-N-34-34-N-A-A-NNN-NNN	SERIES 42	S42-041PV/051PV
4412661	PUMP-VAR-DISPL, CW, S42PV041, MDC	42-R-41-D-LNN3-03-B-5-G-2-C-N-B-21-21-B-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
4412671	PUMP-VAR DISPL, CW	42-R-41-D-ANN3-03-B-2-G-3-F-N-B-34-34-B-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
4412677	PUMP-VAR-DISPL, CW, S42PV041, NFPE	42-R-41-D-G1A1-72-J-D-C-3-H-1-A-25-25-N-0-0-NNN-NNN	SERIES 42	S42-041PV/051PV
4412683	PUMP-VAR-DISPL, CW, S42PV041, MDC	42-R-51-K-ANN5-02-A-N-A-3-C-N-T-30-30-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
4412685	PUMP-VAR-DISPL, CW, S42PV041, NFPE	42-R-4A-D-G1A1-72-J-2-G-2-F-5-A-41-41-B-0-0-AAA-NNN	SERIES 42	S42-041PV/051PV
4412688	PUMP-VAR-DISPL CW 42PV041	42-R-41-D-F4NN-73-J-3-C-2-F-N-N-28-28-N-A-A-NNN-NNN	SERIES 42	S42-041PV/051PV
4412701	PUMP-VAR-DISPL, CW, S42PV041, FNR	42-R-41-D-F2NN-72-J-D-G-2-F-N-B-30-30-N-C-C-NNN-NNN	SERIES 42	S42-041PV/051PV
4412704	PUMP-VAR-DISPL, CW, S42PV041, NFPE	42-R-41-C-G1A1-72-J-D-B-3-H-1-B-34-34-B-0-0-NNN-NNN	SERIES 42	S42-041PV/051PV
4412705	PUMP-VAR-DISPL, CW, S42PV041, NFPH	42-R-41-E-G3AN-52-P-3-B-3-H-1-V-34-34-N-0-0-NNN-NNN	SERIES 42	S42-041PV/051PV
4412706	PUMP-VAR-DISPL, CW, S42PV041, NFPH	42-R-41-D-G3AN-52-P-2-B-3-H-1-B-34-34-N-0-0-NNN-NNN	SERIES 42	S42-041PV/051PV
4412717	PUMP-VAR-DISPL, CW, S42PV041, NFPE	42-R-4A-D-G1A1-72-J-2-B-2-F-5-A-30-30-B-0-0-AAA-NNN	SERIES 42	S42-041PV/051PV
4412724	PUMP-VAR-DISPL, CW, S42PV041, NFPH	42-R-41-C-G3AN-53-P-D-B-2-F-1-A-34-34-N-1-1-NNN-NNN	SERIES 42	S42-041PV/051PV
4412725	PUMP-VAR-DISPL, CW, S42PV041, NFPH	42-R-41-C-G3AN-53-P-3-G-3-F-1-B-25-25-N-0-0-NNN-NNN	SERIES 42	S42-041PV/051PV
4412731	PUMP-VAR-DISPL, CW, S42PV041, NFPE	42-R-41-C-G1A1-73-J-D-B-2-F-1-A-21-21-B-0-0-NNN-NNN	SERIES 42	S42-041PV/051PV
4412747	PUMP-VAR-DISPL, CW, S42PV041, MDC	42-R-41-C-ANNB-03-A-N-A-2-F-N-N-34-34-N-A-A-NNN-NNN	SERIES 42	S42-041PV/051PV
4412759	PUMP-VAR-DISPL, CW, S42PV041, FNR	42-R-41-D-F2NN-72-J-D-G-2-F-N-A-34-34-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
4412760	PUMP-VAR-DISPL, CW, S42PV041, FNR	42-R-41-D-F2NN-72-J-D-G-2-F-N-N-38-38-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
4412766	PUMP-VAR-DISPL, CW, S42PV041, MDC	42-R-41-D-ANNA-03-B-3-G-2-F-N-A-34-34-B-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
4412767	PUMP-VAR-DISPL, CW, S42PV041, MDC	42-R-41-D-ANNB-02-C-D-A-2-E-N-B-30-30-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
4412772	PUMP-VAR-DISPL, CW, S42PV041, FNR	42-R-41-D-F2NN-75-J-D-G-2-F-N-A-28-28-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
4412773	PUMP-VAR-DISPL, CW, S42PV041, MDC	42-R-51-C-ANN5-02-D-N-F-3-D-N-N-32-32-N-N-N-NNN-ENN	SERIES 42	S42-041PV/051PV
4412789	PUMP-VAR-DISPL, CW, S42PV041, NFPH	42-R-41-C-G3AN-52-P-3-G-2-F-1-A-34-34-B-1-1-NNN-NNN	SERIES 42	S42-041PV/051PV
4412790	PUMP-VAR-DISPL, CW, S42PV041, FNR	42-R-51-D-F2NN-73-J-D-B-2-F-N-N-30-NN-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
4412805	PUMP-VAR-DISPL, CW, S42PV041, NFPH	42-R-41-C-G3AN-50-P-3-G-2-F-1-A-34-34-B-1-1-NNN-NNN	SERIES 42	S42-041PV/051PV
4412811	PUMP-VAR-DISPL, CW, S42PV041, NFPE	42-R-41-C-G1A1-73-J-3-B-3-F-5-B-38-38-B-0-0-NNN-NNN	SERIES 42	S42-041PV/051PV
4412812	PUMP-VAR-DISPL, CW, S42PV041, NFPE	42-R-4A-C-G1A1-72-J-2-G-2-F-5-A-30-25-B-0-0-AAA-NNN	SERIES 42	S42-041PV/051PV
4412816	PUMP-VAR-DISPL, CW, S42PV041, MDC	42-R-41-D-ANNB-03-A-N-A-2-C-N-N-NN-NN-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
4412818	PUMP-VAR-DISPL, CW, S42PV041, MDC	42-R-41-K-ANK5-02-C-2-A-2-H-N-B-25-25-N-N-N-NNN-ENN	SERIES 42	S42-041PV/051PV
4412822	PUMP-VAR-DISPL, CW, S42PV041, FNR	42-R-41-C-F4NN-73-J-D-B-2-F-N-N-34-34-N-A-A-NNN-NNN	SERIES 42	S42-041PV/051PV
4412826	PUMP-VAR-DISPL, CW, S42PV041, NFPH	42-R-41-C-G3AN-50-P-3-B-2-H-1-B-38-38-B-1-1-NNN-NNN	SERIES 42	S42-041PV/051PV

4412827	PUMP-VAR-DISPL, CW, S42PV041, NFPH	42-R-41-D-G3AN-50-P-3-B-2-H-1-B-38-38-B-1-1-NNN-NNN	SERIES 42	S42-041PV/051PV
4412829	PUMP-VAR-DISPL, CW, S42PV041, MDC	42-R-41-D-A1NB-02-B-2-X-N-G-N-V-34-34-B-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
4412831	PUMP-VAR-DISPL, CW, S42PV041, MDC	42-R-51-K-ANN5-03-A-N-A-3-H-N-T-28-28-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
4412833	PUMP-VAR-DISPL, CW, S42PV041, FNR	42-R-41-D-F2NN-72-J-3-X-A-G-N-Z-34-34-N-A-A-NNN-NNN	SERIES 42	S42-041PV/051PV
4412839	PUMP-VAR-DISPL, CW, S42PV041, NFPH	42-R-41-D-G3AN-50-P-3-B-2-H-1-B-34-34-B-1-1-NNN-NNN	SERIES 42	S42-041PV/051PV
4412840	PUMP-VAR-DISPL, CW, S42PV041, NFPH	42-R-41-C-G3AN-50-P-3-B-2-H-1-B-34-34-B-1-1-NNN-NNN	SERIES 42	S42-041PV/051PV
4412841	PUMP-VAR-DISPL, CW, S42PV041, MDC	42-R-41-E-ANN3-03-B-3-G-3-F-N-N-34-34-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
4412845	PUMP-VAR-DISPL, CW, S42PV041, FNR	42-R-41-D-F5NN-74-J-D-B-2-P-1-N-34-34-N-8-8-NNN-NNN	SERIES 42	S42-041PV/051PV
4412846	PUMP-VAR-DISPL, CW, S42PV041, MDC	42-R-41-K-ANK5-01-C-2-A-3-H-N-B-21-21-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
4416175	SHAFT-13T, 42P(C000C)		SERIES 42	PARTS - S42
4416176	SHAFT-15T,42(C000D)		SERIES 42	PARTS - S42
4440353	SWASHPLATE GROUP-3/4SQ TRUN TAPPED(Q00J)		M35/44	PARTS - 035/044
4442050	PUMP-VAR DISPL	MPV-044-D-B-A-G-W-A-G-NN-A-A-BJJ-DR-A-FF-A-NNN-***	M35/44	044PV
4442051	PUMP-VAR DISPL	MPV-044-D-B-A-G-W-S-G-AA-A-A-BJJ-DL-A-FF-D-NNN-***	M35/44	044PV
4442053	PUMP-VAR DISPL	MPV-044-D-B-A-G-W-S-G-AA-A-A-BEE-DR-A-FF-D-NNN-***	M35/44	044PV
4442054	PUMP-VAR DISPL	MPV-044-D-B-A-G-W-A-G-NN-A-A-BDD-DL-A-FF-A-NNN-***	M35/44	044PV
4442055	PUMP-VAR-DISPL MPV044	MPV-044-D-B-A-G-W-S-G-AA-A-A-BJJ-DR-A-FF-A-NNN-***	M35/44	044PV
4442056	PUMP-VAR DISPL	MPV-044-D-B-A-A-W-S-E-BA-A-A-BFF-DR-A-FF-A-NNN-***	M35/44	044PV
4442058	PUMP-VAR DISPL	MPV-044-D-B-A-G-W-S-E-AA-A-A-BJJ-DR-A-FF-B-NNN-***	M35/44	044PV
4442059	PUMP-VAR DISPL	MPV-044-D-B-A-N-W-S-E-AA-A-A-BJJ-DR-A-FF-C-NNN-***	M35/44	044PV
4442061	PUMP-VAR DISPL	MPV-044-D-B-A-A-W-S-G-BA-A-A-BFF-DR-A-FF-A-NNN-***	M35/44	044PV
4442062	PUMP-VAR DISPL	MPV-044-D-B-A-G-W-S-G-AA-A-A-BEE-DR-A-FF-B-NNN-***	M35/44	044PV
4442063	PUMP-VAR DISPL	MPV-044-D-B-A-G-W-S-E-AA-A-A-BFF-DR-A-FF-D-NNN-***	M35/44	044PV
4442064	PUMP-VAR DISPL	MPV-044-D-B-A-G-W-S-G-AA-A-A-BJJ-DR-A-FF-C-NNN-***	M35/44	044PV
4442069	PUMP-VAR DISPL	MPV-044-D-B-A-G-W-S-E-AA-A-A-BFF-DL-A-FF-D-NNN-***	M35/44	044PV
4442070	PUMP-VAR DISPL	MPV-044-D-H-A-G-R-S-G-AA-A-A-BHH-DL-A-FF-C-NNN-***	M35/44	044PV
4442073	PUMP-VAR DISPL	MPV-044-D-H-A-G-R-S-C-AA-A-A-BHH-DL-A-FF-C-NNN-***	M35/44	044PV
4442075	PUMP-VAR DISPL	MPV-044-D-B-A-G-W-S-G-AA-A-A-BDD-DL-A-FF-A-NNN-***	M35/44	044PV
4442077	PUMP-VAR DISPL	MPV-044-D-H-A-G-R-S-S-AA-A-A-BHH-DL-A-FF-C-NOP-***	M35/44	044PV
4442080	PUMP-VAR DISPL	MPV-044-D-H-A-G-R-A-S-NN-A-A-BHH-DL-A-FF-H-NOP-***	M35/44	044PV
4442082	PUMP-VAR DISPL	MPV-044-D-B-A-G-W-S-G-AA-A-A-BDD-DL-A-FF-D-NNN-***	M35/44	044PV
4442083	PUMP-VAR DISPL	MPV-044-D-B-A-G-W-S-G-BA-A-A-BBB-DL-A-FF-A-NNN-***	M35/44	044PV
4442085	PUMP-VAR DISPL	MPV-044-D-B-A-Y-R-S-G-AA-A-A-BBB-DR-A-FF-A-NNN-***	M35/44	044PV
4442087	PUMP-VAR DISPL	MPV-044-D-B-A-G-W-S-C-AA-A-A-BHH-DR-A-FF-A-NNN-***	M35/44	044PV
4442088	PUMP-VAR DISPL	MPV-044-D-B-A-A-R-S-G-BA-A-A-BGG-DR-A-FF-C-NNN-***	M35/44	044PV
4442089	PUMP-VAR DISPL	MPV-044-D-B-A-G-Y-S-G-AA-A-A-BEE-DR-A-FF-B-NNN-***	M35/44	044PV

4442090	PUMP-VAR DISPL	MPV-044-D-B-A-G-Y-S-G-AA-A-A-BJJ-DR-A-FF-C-NNN-***	M35/44	044PV
4442091	PUMP-VAR DISPL	MPV-044-D-B-A-A-R-S-E-BA-A-A-BMM-DR-A-FF-A-NNN-***	M35/44	044PV
4442092	PUMP-VAR DISPL	MPV-044-D-B-A-Y-Y-S-C-AA-A-A-BBB-DR-A-FF-A-NNN-***	M35/44	044PV
4443027	MOTOR-FIX DISPL	MMF-044-D-A-F-M-C-D-NNN-***	M35/44	044MF
4443028	MOTOR-FIXED-DISPL MMF044	MMF-044-D-A-F-M-C-D-NNR-***	M35/44	044MF
4443030	MOTOR-FIX DISPL MMF044D	MMF-044-D-A-F-U-A-B-NNN-***	M35/44	044MF
4443031	MOTOR-FIXED-DISPL MMF044	MMF-044-D-A-A-U-A-B-NNN-***	M35/44	044MF
4443033	MOTOR-FIXED-DISPL MMF044	MMF-044-D-A-F-M-A-B-NNN-***	M35/44	044MF
4443034	MOTOR-FIX DISPL	MMF-044-D-B-C-F-C-D-NNN-***	M35/44	044MF
4443035	MOTOR-FIXED-DISPL MMF044	MMF-044-D-A-A-H-A-B-NNN-***	M35/44	044MF
4443036	MOTOR-FIX DISPL	MMF-044-D-B-C-F-A-B-NNN-***	M35/44	044MF
4443037	MOTOR-FIXED-DISPL MMF044	MMF-044-D-A-F-E-A-B-NNN-***	M35/44	044MF
4443038	MOTOR-FIXED-DISPL MMF044	MMF-044-D-A-A-E-A-B-NNN-***	M35/44	044MF
4443039	MOTOR-FIX DISPL	MMF-044-D-A-A-H-C-F-NNN-***	M35/44	044MF
4443040	MOTOR-FIX DISPL	MMF-044-D-A-F-9-A-B-NNN-***	M35/44	044MF
4443041	MOTOR-FIX DISPL	MMF-044-D-A-F-H-C-F-NNN-***	M35/44	044MF
4443042	MOTOR-FIX DISPL	MMF-044-D-A-A-G-A-B-NNN-***	M35/44	044MF
4443043	MOTOR-FIX DISPL	MMF-044-D-A-F-G-A-B-NNN-***	M35/44	044MF
4443045	MOTOR-FIX DISPL	MMF-044-D-A-F-E-C-G-NNN-***	M35/44	044MF
4443047	MOTOR-FIXED-DISPL MMF044	MMF-044-D-A-F-8-A-B-NNN-***	M35/44	044MF
4443049	MOTOR-FIXED-DISPL MMF044	MMF-044-D-A-A-1-A-B-NNN-***	M35/44	044MF
4443050	MOTOR-FIX DISPL	MMF-044-D-A-A-U-C-D-NNN-***	M35/44	044MF
4443051	MOTOR-FIX DISPL	MMF-044-D-A-N-U-A-B-NNN-***	M35/44	044MF
4443052	MOTOR-FIXED-DISPL MMF044	MMF-044-D-A-S-U-A-B-NNN-***	M35/44	044MF
4443053	MOTOR-FIX DISPL	MMF-044-D-A-A-1-C-D-NNN-***	M35/44	044MF
4443054	MOTOR-FIX DISPL	MMF-044-D-A-F-U-C-D-NNN-***	M35/44	044MF
4443055	MOTOR-FIX DISPL	MMF-044-D-B-3-D-A-B-NGA-***	M35/44	044MF
4443056	MOTOR-FIX DISPL	MMF-044-D-A-N-U-C-D-NNN-***	M35/44	044MF
4443057	MOTOR-FIXED-DISPL MMF044	MMF-044-D-A-F-Y-A-B-NNN-***	M35/44	044MF
4443058	MOTOR-FIXED-DISPL MMF044	MMF-044-D-A-S-E-A-B-NNN-***	M35/44	044MF
4443059	MOTOR-FIX DISPL	MMF-044-D-A-N-G-A-B-NNN-***	M35/44	044MF
4443060	MOTOR-FIX DISPL	MMF-044-D-A-F-H-C-G-NNN-***	M35/44	044MF
4443061	MOTOR-FIX DISPL	MMF-044-D-A-A-E-C-K-NBJ-***	M35/44	044MF
4443062	MOTOR-FIXED-DISPL MMF044	MMF-044-D-A-F-1-A-B-NNN-***	M35/44	044MF
4443065	MOTOR-FIX DISPL	MMF-044-D-A-F-G-C-D-NNN-***	M35/44	044MF
4443066	MOTOR-FIXED-DISPL MMF044	MMF-044-D-A-F-M-A-B-NNR-***	M35/44	044MF

4443067	MOTOR-FIXED-DISPL MMF044	MMF-044-D-A-F-H-A-B-NNN-***	M35/44	044MF
4443068	MOTOR-FIX DISPL	MMF-044-D-A-F-E-A-B-NNR-***	M35/44	044MF
4443069	MOTOR-FIXED-DISPL MMF044	MMF-044-D-A-S-M-A-B-NNN-***	M35/44	044MF
4443070	MOTOR-FIX DISPL	MMF-044-D-A-F-J-A-B-NNN-***	M35/44	044MF
4443071	MOTOR-FIX DISPL	MMF-044-D-A-L-E-A-B-NNN-***	M35/44	044MF
4443072	MOTOR-FIX DISPL	MMF-044-D-A-A-9-A-B-NNN-***	M35/44	044MF
4443074	MOTOR-FIXED-DISPL MMF044	MMF-044-D-A-F-1-C-D-NNN-***	M35/44	044MF
4443075	MOTOR-FIX DISPL	MMF-044-D-A-S-G-A-B-NNN-***	M35/44	044MF
4443076	MOTOR-FIX DISPL	MMF-044-D-A-S-E-C-D-NNN-***	M35/44	044MF
4443077	MOTOR-FIXED-DISPL MMF044	MMF-044-D-A-A-M-A-B-NNN-***	M35/44	044MF
4443078	MOTOR-FIX DISPL	MMF-044-D-A-S-H-A-B-NNN-***	M35/44	044MF
4443079	MOTOR-FIX DISPL	MMF-044-D-A-F-H-C-D-NNN-***	M35/44	044MF
4443080	MOTOR-FIX DISPL	MMF-044-D-A-A-U-G-B-NNN-***	M35/44	044MF
4443081	MOTOR-FIX DISPL	MMF-044-D-A-A-E-G-B-NNN-***	M35/44	044MF
4443082	MOTOR-FIX DISPL	MMF-044-D-A-F-E-G-B-NNN-***	M35/44	044MF
4443083	MOTOR-FIXED-DISPL MMF044	MMF-044-D-A-6-G-A-U-NNN-***	M35/44	044MF
4443084	MOTOR-FIX DISPL	MMF-044-D-A-6-E-A-B-NNN-***	M35/44	044MF
4443085	MOTOR-FIX DISPL	MMF-044-D-A-N-1-A-B-NNN-***	M35/44	044MF
4443086	MOTOR-FIX DISPL	MMF-044-D-A-A-M-C-D-NNN-***	M35/44	044MF
4443087	MOTOR-FIX DISPL	MMF-044-D-A-S-G-C-D-NNN-***	M35/44	044MF
4443088	MOTOR-FIX DISPL	MMF-044-D-A-A-H-C-D-NNN-***	M35/44	044MF
4443089	MOTOR-FIX DISPL	MMF-044-D-A-A-G-C-D-NNN-***	M35/44	044MF
4443090	MOTOR-FIX DISPL	MMF-044-D-A-6-G-A-B-NNN-***	M35/44	044MF
4443091	MOTOR-FIX DISPL	MMF-044-D-A-F-G-G-B-NNN-***	M35/44	044MF
4443092	MOTOR-FIX DISPL	MMF-044-D-A-F-9-A-B-NNR-***	M35/44	044MF
4443093	MOTOR-FIX DISPL	MMF-044-D-A-F-J-A-B-NNR-***	M35/44	044MF
4443094	MOTOR-FIX DISPL	MMF-044-D-A-6-1-C-D-NNN-***	M35/44	044MF
4443096	MOTOR-FIX DISPL	MMF-044-D-A-F-U-A-B-NBJ-***	M35/44	044MF
4443097	MOTOR-FIX DISPL	MMF-044-D-A-F-E-A-B-NBJ-***	M35/44	044MF
4443098	MOTOR-FIX DISPL	MMF-044-D-A-A-E-A-B-NBC-***	M35/44	044MF
4443099	MOTOR-FIX DISPL	MMF-044-D-A-F-E-A-B-NBC-***	M35/44	044MF
4443100	MOTOR-FIX DISPL	MMF-044-D-A-A-E-A-B-NBJ-***	M35/44	044MF
4443101	MOTOR-FIX DISPL	MMF-044-D-A-F-G-A-B-NGA-***	M35/44	044MF
4443102	MOTOR-FIX DISPL	MMF-044-D-A-F-G-A-B-NBJ-***	M35/44	044MF
4443103	MOTOR-FIX DISPL	MMF-044-D-A-A-E-A-B-NDD-***	M35/44	044MF
4443104	MOTOR-FIX DISPL	MMF-044-D-A-A-E-C-D-NNN-***	M35/44	044MF

4443110	MOTOR-FIX DISPL	MMF-044-D-A-F-H-A-B-XXX-***	M35/44	044MF
4444027	MOTOR-VAR-DISPL MMV044	MMV-044-D-A-A-D-L-R-NNN-***	M35/44	044MV
4444028	MOTOR-VAR DISPL	MMV-044-D-A-A-D-R-R-NNN-***	M35/44	044MV
4445026	PUMP-TANDEM, VAR DISPL	MPT-044-D-A-W-A-G-NN-B-A-A-A-BGG-DL-A-FF-B-C-A-A-BGG-DL-A-FF-K-NNN-	M35/44	044PT
4445027	PUMP-TANDEM, VAR DISPL	MPT-044-D-A-W-R-G-BA-B-A-A-A-BEE-DR-A-FF-B-C-A-A-BEE-DL-A-FF-A-NNN-*	M35/44	044PT
4445030	PUMP-TANDEM, VAR DISPL	MPT-044-D-A-W-R-G-AA-B-A-A-A-BEE-DR-A-FF-B-C-A-A-BEE-DR-A-FF-A-NNN-*	M35/44	044PT
4445032	PUMP-TANDEM, VAR DISPL	MPT-044-D-A-R-A-G-NN-B-A-A-A-BGG-DL-A-FF-B-C-A-A-BGG-DL-A-FF-K-NNN-*	M35/44	044PT
4445035	PUMP-TANDEM, VAR DISPL	MPT-044-D-A-R-R-E-AA-B-A-A-A-BGG-DR-A-FF-B-C-A-A-BGG-DR-A-FF-D-NNN-*	M35/44	044PT
4445072	PUMP-TANDEM, VAR DISPL	MPT-044-D-A-L-R-G-AA-B-A-A-A-BDD-DL-A-FF-B-C-A-A-BDD-DL-A-FF-A-NNN-*	M35/44	044PT
4445080	PUMP-TANDEM, VAR DISPL	MPT-044-D-A-R-R-A-BA-B-A-A-A-BJJ-DR-A-FF-B-C-A-A-BJJ-DL-A-FF-A-NNN-***	M35/44	044PT
4445093	PUMP-TANDEM, VAR DISPL	MPT-044-D-C-L-R-E-AA-B-A-A-A-BJJ-DR-A-FF-B-C-A-A-BJJ-DR-A-FF-C-NNN-***	M35/44	044PT
4445101	PUMP-TANDEM, VAR DISPL	MPT-044-D-G-L-R-A-AA-B-A-A-A-BJJ-DR-A-FF-B-C-A-A-BJJ-DR-A-FF-A-NNN-***	M35/44	044PT
4445103	PUMP-TANDEM, VAR DISPL	MPT-044-D-A-R-R-G-AA-B-A-A-A-BGG-DR-A-FF-B-C-A-A-BGG-DL-A-FF-A-NNN-*	M35/44	044PT
4445105	PUMP-TANDEM, VAR DISPL	MPT-044-D-G-L-R-A-AA-B-A-A-A-BJJ-DR-A-FF-B-C-A-A-BJJ-DR-A-FF-H-GNS-***	M35/44	044PT
4445107	PUMP-TANDEM, VAR DISPL	MPT-044-D-C-L-R-H-BA-B-A-A-A-BJJ-DL-A-FF-B-C-A-A-BJJ-DL-A-FF-1-NNN-***	M35/44	044PT
4445112	PUMP-TANDEM, VAR DISPL	MPT-044-D-A-L-S-H-AA-B-A-A-A-BDD-DL-A-FF-B-C-A-A-BDD-DL-A-FF-A-NNN-*	M35/44	044PT
4445118	PUMP-TANDEM, VAR DISPL	MPT-044-D-A-L-S-H-BA-B-A-A-A-BDD-DL-A-FF-B-C-A-A-BDD-DL-A-FF-A-NNN-*	M35/44	044PT
4445123	PUMP-TANDEM-VAR-DISPL MPT044	MPT-044-D-A-5-A-C-NN-B-A-A-A-BGG-DL-A-FF-B-C-A-A-BGG-DL-A-FF-K-NNN-*	M35/44	044PT
4445131	PUMP-TANDEM, VAR DISPL	MPT-044-D-A-L-R-G-BA-B-A-A-A-BDD-DR-A-FF-B-A-A-A-BDD-DR-A-FF-C-NNN-*	M35/44	044PT
4445133	PUMP-TANDEM, VAR DISPL	MPT-044-D-A-L-R-G-AA-B-A-A-A-BDD-DR-A-FF-B-A-A-A-BDD-DR-A-FF-C-NNN-*	M35/44	044PT
4445135	PUMP-TANDEM, VAR DISPL	MPT-044-D-A-L-A-G-NN-B-A-A-A-BJJ-DR-A-FF-B-C-A-A-BJJ-DR-A-FF-B-NNN-***	M35/44	044PT
4445136	PUMP-TANDEM, VAR DISPL	MPT-044-D-A-R-R-G-AA-B-A-A-A-BRR-DR-A-FF-B-C-A-A-BGG-DL-A-FF-A-NNN-*	M35/44	044PT
4445145	PUMP-TANDEM, VAR DISPL	MPT-044-D-G-Y-R-2-BA-B-A-A-A-BJJ-DR-A-FF-B-C-A-A-BJJ-DR-A-FF-A-NNN-***	M35/44	044PT
4445148	PUMP-TANDEM, VAR DISPL	MPT-044-D-A-W-R-G-AA-B-A-A-A-BGG-DR-A-FF-B-C-A-A-BGG-DL-A-FF-B-NNN-	M35/44	044PT
4445149	PUMP-TANDEM, VAR DISPL	MPT-044-D-A-W-A-G-NN-B-A-A-A-BGG-DR-A-FF-B-C-A-A-BGG-DL-A-FF-B-NNN-	M35/44	044PT
4445159	PUMP-TANDEM, VAR DISPL	MPT-044-D-V-R-A-G-NN-G-A-A-A-BHH-DL-A-FF-G-C-A-A-BHH-DL-A-FF-A-NOP-*	M35/44	044PT
4445166	PUMP-TANDEM, VAR DISPL	MPT-044-D-V-L-A-F-NN-G-A-A-A-BDD-DL-A-FF-G-C-A-A-BDD-DL-A-FF-6-DNN-*	M35/44	044PT
4445167	PUMP-TANDEM, VAR DISPL	MPT-044-D-C-W-S-J-AA-B-A-A-A-BRR-DL-A-FF-B-C-A-A-BRR-DL-A-FF-B-NNN-*	M35/44	044PT
4445184	PUMP-TANDEM, VAR DISPL	MPT-044-D-A-W-S-J-AA-B-A-A-A-BDD-DR-A-FF-B-C-A-A-BDD-DL-A-FF-A-NNN-*	M35/44	044PT
4445191	PUMP-TANDEM, VAR DISPL	MPT-044-D-A-R-A-G-NN-G-A-A-A-BGG-DL-A-FF-G-C-A-A-BGG-DL-A-FF-A-NNN-	M35/44	044PT
4445199	PUMP-TANDEM, VAR DISPL	MPT-044-D-V-R-A-F-NN-H-A-A-A-BHH-DA-A-FF-H-C-A-A-BHH-DB-A-FF-7-FVG-*	M35/44	044PT
4445206	PUMP-TANDEM, VAR DISPL	MPT-044-D-V-R-A-R-NN-H-A-A-A-BEE-DA-A-FF-H-C-A-A-BEE-DB-A-FF-H-EVG-*	M35/44	044PT
4445207	PUMP-TANDEM, VAR DISPL	MPT-044-D-V-R-A-F-NN-H-A-A-A-BHH-DA-A-FF-H-C-A-A-BHH-DB-A-FF-H-FVG-*	M35/44	044PT
4445213	PUMP-TANDEM, VAR DISPL	MPT-044-D-A-R-R-G-BA-B-A-A-A-BHH-DR-A-FF-B-C-A-A-BHH-DL-A-FF-C-NNN-*	M35/44	044PT
4445223	PUMP-TANDEM, VAR DISPL	MPT-044-D-A-W-S-J-AA-B-A-A-A-BDD-DR-A-FF-B-C-A-A-BDD-DL-A-FF-C-NNN-*	M35/44	044PT
4445238	PUMP-TANDEM, VAR DISPL	MPT-044-D-A-W-S-J-BA-B-A-A-A-BDD-DR-A-FF-B-C-A-A-BDD-DL-A-FF-A-NNN-*	M35/44	044PT

4445239	PUMP-TANDEM, VAR DISPL	MPT-044-D-A-W-R-J-AA-B-A-A-A-BGG-DL-A-FF-B-C-A-A-BGG-DL-A-FF-B-NNN-*	M35/44	044PT
4460512-AB	CONT-MDC, STD LIGHT DUTY (NOAB)		M46	PARTS - M46
4460514-ED	CONT ORF MDC .054/.046+NONE (ROED)		M46	PARTS - M46
4460514-GG	CONT ORF EDC/HDC .055/.055 (ROGG)		M46	PARTS - M46
4460976	CONT-MDC, HD(35),(4) HL T HDL, MTR(NOGB)		M46	PARTS - M46
4464500	MOTOR-VAR DISPL CARTRIDGE	MMC-046-C-A-E-H-G-AF-NNN-***	M46	M46-046MMC
4464502	MOTOR-VAR DISPL CARTRIDGE	MMC-046-C-A-E-S-G-AF-NNN-***	M46	M46-046MMC
4464503	MOTOR-VAR DISPL CARTRIDGE	MMC-046-C-A-E-H-T-AF-NNN-***	M46	M46-046MMC
4464504	MOTOR-VAR DISPL CARTRIDGE	MMC-046-C-A-E-J-U-AF-NNN-***	M46	M46-046MMC
4464506	MOTOR-VAR DISPL CARTRIDGE	MMC-046-C-A-E-B-G-AG-NNN-***	M46	M46-046MMC
4464509	MOTOR-VAR DISPL CARTRIDGE	MMC-046-C-A-E-D-G-AJ-NNN-***	M46	M46-046MMC
4464510	MOTOR-VAR DISPL CARTRIDGE	MMC-046-C-A-E-D-G-AF-NNN-***	M46	M46-046MMC
4464511	MOTOR-VAR DISPL CARTRIDGE	MMC-046-C-A-E-D-G-AK-NNN-***	M46	M46-046MMC
4464512	MOTOR-VAR DISPL CARTRIDGE	MMC-046-C-A-E-H-U-AF-NNN-***	M46	M46-046MMC
4464514	MOTOR-VAR DISPL CARTRIDGE	MMC-046-C-A-E-A-G-AH-NNN-***	M46	M46-046MMC
4464516	MOTOR-VAR DISPL CARTRIDGE	MMC-046-C-A-E-D-G-AH-NNN-***	M46	M46-046MMC
4464517	MOTOR-VAR DISPL CARTRIDGE	MMC-046-C-A-E-J-U-AK-NNN-***	M46	M46-046MMC
4464518	MOTOR-VAR DISPL CARTRIDGE	MMC-046-C-A-E-H-T-AK-NNN-***	M46	M46-046MMC
4464519	MOTOR-VAR DISPL CARTRIDGE	MMC-046-C-A-E-B-T-AK-NNN-***	M46	M46-046MMC
4464520	MOTOR-VAR DISPL CARTRIDGE	MMC-046-C-A-A-B-G-AF-NNN-***	M46	M46-046MMC
4464521	MOTOR-VAR DISPL CARTRIDGE	MMC-046-C-A-A-B-G-AH-NNN-***	M46	M46-046MMC
4464522	MOTOR-VAR DISPL CARTRIDGE	MMC-046-C-A-A-B-G-AG-NNN-***	M46	M46-046MMC
4464523	MOTOR-VAR DISPL CARTRIDGE	MMC-046-C-A-A-D-G-AH-NNN-***	M46	M46-046MMC
4464524	MOTOR-VAR DISPL CARTRIDGE	MMC-046-C-A-E-B-G-AK-NNN-***	M46	M46-046MMC
4464526	MOTOR-VAR DISPL CARTRIDGE	MMC-046-C-A-E-B-G-AF-NNN-***	M46	M46-046MMC
4464528	MOTOR-VAR DISPL CARTRIDGE	MMC-046-C-A-E-L-G-AH-NNN-***	M46	M46-046MMC
4464529	MOTOR-VAR DISPL CARTRIDGE	MMC-046-C-A-A-B-G-AK-NNN-***	M46	M46-046MMC
4464530	MOTOR-VAR DISPL CARTRIDGE	MMC-046-C-A-E-E-G-AK-NNN-***	M46	M46-046MMC
4464531	MOTOR-VAR DISPL CARTRIDGE	MMC-046-C-A-E-F-G-AH-NNN-***	M46	M46-046MMC
4464532	MOTOR-VAR DISPL CARTRIDGE	MMC-046-C-A-E-F-G-AK-NNN-***	M46	M46-046MMC
4464533	MOTOR-VAR DISPL CARTRIDGE	MMC-046-C-A-E-D-G-AG-NNN-***	M46	M46-046MMC
4464534	MOTOR-VAR DISPL CARTRIDGE	MMC-046-C-A-E-A-G-AL-NNN-***	M46	M46-046MMC
4464535	MOTOR-VAR DISPL CARTRIDGE	MMC-046-C-A-E-A-G-AK-NNN-***	M46	M46-046MMC
4464536	MOTOR-VAR DISPL CARTRIDGE	MMC-046-C-A-E-D-G-AL-NNN-***	M46	M46-046MMC
4465000	PUMP-TANDEM-VAR-DISPL MPT046	MPT-046-C-A-V-C-B-AA-B-B-A-A-BDD-CB-A-GG-B-D-A-A-BDD-CB-A-GG-B-NNN-	M46	M46-046PT
4465001	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-Z-C-B-AA-B-B-A-A-BJJ-BA-A-JJ-B-D-A-A-BJJ-BA-A-JJ-D-NNN-***	M46	M46-046PT

4465003	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-S-AA-B-A-A-B-BJJ-AK-D-CF-B-C-A-B-BJJ-AK-D-CF-Y-GDB-***	M46	M46-046PT
4465008	PUMP-TANDEM, VAR DISPL	MPT-046-C-T-Z-C-J-BA-B-B-A-A-BJJ-CE-A-HH-B-D-A-A-BJJ-CE-A-HH-B-NNN-***	M46	M46-046PT
4465011	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-V-C-B-BA-B-A-A-B-BHH-AB-U-FF-B-C-A-B-BHH-AB-D-FF-C-ANN-*	M46	M46-046PT
4465012	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-S-AA-B-A-A-A-BJJ-GH-U-CF-B-C-A-A-BJJ-GH-D-CF-B-NNN-***	M46	M46-046PT
4465013	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-V-C-S-AA-B-A-A-A-BJJ-GH-U-CF-B-C-A-A-BJJ-GH-D-CF-B-NNN-***	M46	M46-046PT
4465014	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-B-AA-B-A-A-A-BGG-AB-U-ED-B-C-A-A-BMM-AB-D-ED-A-NBN	M46	M46-046PT
4465015	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-Z-C-B-AA-B-B-A-A-BGG-CE-A-HH-B-D-A-A-BGG-CE-A-HH-C-NNN-	M46	M46-046PT
4465016	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-C-C-A-BA-B-A-A-B-BHH-AB-U-FF-B-C-A-B-BHH-AB-D-FF-C-NAA-*	M46	M46-046PT
4465020	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-B-AA-B-B-A-A-BDD-CE-A-JJ-B-D-A-A-BDD-CE-A-JJ-B-NNN-***	M46	M46-046PT
4465021	PUMP-TANDEM-VAR-DISPL MPT046	MPT-046-C-A-V-C-B-AA-B-A-A-A-BGG-AB-D-ED-B-C-A-A-BMM-AB-D-ED-A-NNN	M46	M46-046PT
4465022	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-Z-C-B-BA-B-B-B-A-BFF-CB-A-GG-B-D-B-A-BFF-CB-A-GG-A-ANN-*	M46	M46-046PT
4465023	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-J-AA-B-B-A-A-BEF-CE-A-GG-B-D-A-A-BMM-CE-A-GG-D-NNN-	M46	M46-046PT
4465024	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-V-C-M-AA-B-B-A-A-BRR-BC-A-HH-B-D-A-A-BRR-BC-A-HH-B-NNN-	M46	M46-046PT
4465025	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-V-C-S-AA-B-A-D-A-BHH-GG-B-KF-B-C-B-A-BHH-GG-B-KF-B-NNN-*	M46	M46-046PT
4465026	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-B-BA-B-A-A-A-BJJ-AB-D-CD-B-C-A-A-BJJ-AB-U-CD-B-NNN-***	M46	M46-046PT
4465027	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-S-A-B-BC-B-A-G-A-BHH-AB-D-DD-B-C-G-A-BHH-AB-D-DD-D-ANN-	M46	M46-046PT
4465028	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-B-AA-B-B-A-A-BDD-CB-A-GG-B-D-A-A-BDD-CB-A-GG-A-NNN-	M46	M46-046PT
4465033	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-B-AA-B-A-A-A-BHH-AK-U-CF-B-C-A-A-BHH-AK-D-CF-B-NNN-*	M46	M46-046PT
4465034	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-S-AA-B-A-A-A-BJJ-AK-U-CF-B-C-A-A-BJJ-AK-D-CF-B-NNN-***	M46	M46-046PT
4465035	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-B-BA-B-B-G-A-BCC-CE-A-HH-B-D-G-A-BCC-CE-A-HH-C-NNN-*	M46	M46-046PT
4465038	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-Z-C-B-BA-B-B-A-A-BHH-CB-A-HH-B-D-A-A-BHH-CB-A-HH-C-NNN-	M46	M46-046PT
4465040	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-B-AA-B-A-A-A-BEE-AB-U-DD-B-C-A-A-BEE-AB-D-DD-A-NNN-*	M46	M46-046PT
4465042	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-S-AA-B-B-A-A-BJD-BB-A-HH-B-D-A-A-BJJ-BB-A-HH-D-NNN-*	M46	M46-046PT
4465045	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-V-C-J-AA-B-B-A-C-BJJ-CE-A-RR-B-D-A-C-BHH-CE-A-RR-A-NNN-***	M46	M46-046PT
4465046	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-V-C-J-AA-B-B-A-C-BJJ-CE-A-RR-B-D-A-C-BHH-CE-A-RR-A-NNN-***	M46	M46-046PT
4465049	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-B-AA-B-A-A-A-BHH-AK-D-CF-B-C-A-A-BHH-AK-U-CF-B-NNN-*	M46	M46-046PT
4465050	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-S-AA-B-A-A-A-BJJ-AK-D-CF-B-C-A-A-BJJ-AK-U-CF-B-NNN-***	M46	M46-046PT
4465053	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-J-AA-B-B-A-A-BEF-CE-A-GG-B-D-A-A-BBM-CE-A-GG-D-NNN-*	M46	M46-046PT
4465054	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-V-C-B-BA-B-A-R-A-BJJ-AB-D-BB-B-C-R-A-BJJ-AB-U-BB-A-ANN-***	M46	M46-046PT
4465055	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-M-AA-B-A-A-B-BJJ-AK-D-CF-B-C-A-B-BJJ-AK-D-CF-Y-GDB-***	M46	M46-046PT
4465056	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-B-AA-B-A-A-A-BJJ-AB-D-CD-B-C-A-A-BJJ-AB-U-CD-B-NNN-***	M46	M46-046PT
4465058	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-Z-C-B-AA-B-B-A-A-BHH-CE-A-GG-B-D-A-A-BHH-CE-A-GG-C-NNN-	M46	M46-046PT
4465059	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-J-AA-B-B-A-A-BJJ-CE-A-GG-B-D-A-A-BBM-CE-A-GG-D-NNN-*	M46	M46-046PT
4465060	PUMP-TANDEM-VAR-DISPL MPT046	MPT-046-C-A-V-C-K-BA-B-B-A-A-BJJ-BA-A-GG-B-D-A-A-BJJ-BA-A-GG-A-NNN-*	M46	M46-046PT
4465061	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-J-AA-B-B-G-A-BDD-CB-A-GG-B-D-G-A-BDD-CB-A-GG-C-NNN-	M46	M46-046PT
4465062	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-J-AA-B-B-A-A-BJJ-CE-A-GG-B-D-A-A-BBB-CE-A-GG-D-NNN-*	M46	M46-046PT

4465063	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-Z-C-B-AA-B-B-A-A-BJJ-CE-A-JJ-B-D-A-A-BJJ-CE-A-JJ-C-NNN-***	M46	M46-046PT
4465065	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-Z-C-B-BA-B-B-A-B-BGG-CB-A-GG-B-D-A-B-BGG-CB-A-GG-C-NNN-	M46	M46-046PT
4465066	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-B-AA-B-A-A-A-BJJ-GE-U-DF-B-C-A-A-BJJ-GE-D-DF-B-NNN-***	M46	M46-046PT
4465070	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-V-C-J-AA-B-A-A-A-BJJ-AB-U-CD-B-C-A-A-BHH-AB-U-CD-A-NNN-*	M46	M46-046PT
4465071	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-Z-C-B-AA-B-B-A-A-BHH-CB-A-GG-B-D-A-A-BBB-CB-A-GG-A-NNN-	M46	M46-046PT
4465074	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-Z-C-B-AA-B-B-A-A-BHH-CB-A-GG-B-D-A-A-BHH-CB-A-GG-A-NNN-	M46	M46-046PT
4465075	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-V-C-B-AA-B-B-A-A-BRR-BC-A-HH-B-D-A-A-BRR-BC-A-HH-B-NNN-*	M46	M46-046PT
4465076	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-B-AA-B-A-A-A-BJJ-GB-B-FF-B-C-A-A-BJJ-GB-B-FF-B-NNN-***	M46	M46-046PT
4465080	PUMP-TANDEM, VAR DISPL	MPT-046-C-T-Z-C-J-BA-B-B-A-B-BJJ-CE-A-HH-B-D-A-B-BJJ-CE-A-HH-B-NNN-***	M46	M46-046PT
4465081	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-Z-C-B-AA-B-B-A-A-BJJ-CE-A-HH-B-D-A-A-BJJ-CE-A-HH-C-NNN-***	M46	M46-046PT
4465082	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-B-BA-B-B-A-A-BJJ-CE-A-GG-B-D-A-A-BJJ-CE-A-GG-B-NNN-***	M46	M46-046PT
4465083	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-B-BA-B-B-A-A-BGG-AB-U-BB-B-C-A-A-BGG-AB-U-BB-C-NNN-	M46	M46-046PT
4465084	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-V-C-S-AA-B-A-R-A-BGG-GG-B-KF-B-C-R-A-BGG-GG-B-KF-Y-GDG-*	M46	M46-046PT
4465085	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-V-C-S-AA-B-A-R-A-BGG-GG-B-KF-B-C-R-A-BGG-GG-B-KF-B-NNA-*	M46	M46-046PT
4465086	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-V-C-S-AA-B-A-R-A-BGG-GG-B-KF-B-C-R-A-BGG-GG-B-KF-Y-GDH-*	M46	M46-046PT
4465087	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-V-C-B-BA-B-B-A-A-BHH-BC-A-JJ-B-D-A-A-BHH-BC-A-JJ-A-NNN-***	M46	M46-046PT
4465088	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-J-AA-B-B-V-A-BFF-CB-A-HH-B-D-V-A-BFF-CB-A-HH-C-NNN-***	M46	M46-046PT
4465089	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-Z-C-B-BA-B-B-A-A-BJJ-CE-A-GG-B-D-A-A-BJJ-CE-A-GG-A-NNN-***	M46	M46-046PT
4465090	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-J-BA-B-B-A-A-BJJ-CB-A-HH-B-D-A-A-BJJ-CB-A-HH-A-NNN-***	M46	M46-046PT
4465091	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-Z-C-S-AA-B-B-B-A-BGG-BB-A-HH-B-D-B-A-BGG-BB-A-HH-D-NNN-	M46	M46-046PT
4465092	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-Z-C-B-BA-B-B-A-A-BJJ-CE-A-HH-B-D-A-A-BJJ-CE-A-HH-B-NNN-***	M46	M46-046PT
4465093	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-M-AA-B-A-A-B-BJJ-AK-D-CF-B-C-A-B-BJJ-AK-D-CF-B-NNN-***	M46	M46-046PT
4465097	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-B-AA-B-B-A-A-BDD-BA-A-HH-B-D-A-A-BDD-BA-A-HH-B-NNN-	M46	M46-046PT
4465098	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-J-BA-B-B-A-A-BDD-BA-A-GG-B-D-A-A-BDD-BA-A-GG-A-NNN-	M46	M46-046PT
4465099	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-V-C-B-AA-B-A-A-A-BRR-AB-U-AA-B-C-A-A-BRR-AB-D-AA-B-NNN-*	M46	M46-046PT
4465100	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-B-AA-B-A-A-A-BJJ-GB-B-EF-B-C-A-A-BJJ-GB-B-EF-B-NNN-***	M46	M46-046PT
4465101	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-Z-C-B-AA-B-B-A-A-BEE-CB-A-GG-B-D-A-A-BEE-CB-A-GG-B-NNN-*	M46	M46-046PT
4465103	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-V-C-B-BA-B-B-G-A-BHH-BA-A-RR-B-D-G-A-BHH-BA-A-RR-A-NNN-	M46	M46-046PT
4465104	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-B-BA-B-B-A-A-BDD-AB-U-AA-B-C-A-A-BDD-AB-U-AA-A-NNN-	M46	M46-046PT
4465105	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-Z-C-B-BA-B-B-A-A-BBB-CE-A-HH-B-D-A-A-BBB-CE-A-HH-A-NNN-*	M46	M46-046PT
4465106	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-Z-C-B-BA-B-B-A-A-BBB-CE-A-GG-B-D-A-A-BBB-CE-A-GG-B-NNN-*	M46	M46-046PT
4465107	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-B-BA-B-B-A-A-BHH-AB-U-DD-B-C-A-A-BHH-AB-U-DD-C-NNN-	M46	M46-046PT
4465108	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-V-C-B-BA-B-B-V-A-BJJ-CG-A-GG-B-D-V-A-BJJ-CG-A-GG-D-ANN-***	M46	M46-046PT
4465118	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-J-BA-B-A-G-A-BJJ-AB-U-ED-B-C-G-A-BJJ-AB-U-ED-B-NNN-***	M46	M46-046PT
4465119	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-Z-C-J-AA-B-A-A-A-BJJ-AB-U-ED-B-C-A-A-BJJ-AB-U-ED-A-NNN-***	M46	M46-046PT
4465120	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-Z-C-B-BA-B-B-A-A-BDD-CB-A-HH-B-D-A-A-BDD-CB-A-HH-C-NNN-	M46	M46-046PT

4465121	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-V-C-B-AA-B-B-A-A-BDD-BC-A-HH-B-D-A-A-BDD-BC-A-HH-A-NNN-	M46	M46-046PT
4465123	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-K-AA-B-B-A-A-BHH-AK-D-CF-B-C-A-A-BHH-AK-U-CF-B-NNN-*	M46	M46-046PT
4465126	PUMP-TANDEM, VAR DISPL	MPT-046-C-D-Z-C-S-AA-B-B-B-A-BGG-BB-A-HH-B-D-B-A-BGG-BB-A-HH-D-NNN-	M46	M46-046PT
4465127	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-J-BA-B-B-A-A-BBB-CB-A-JJ-B-D-A-A-BBB-CB-A-JJ-B-NNN-***	M46	M46-046PT
4465128	PUMP-TANDEM, VAR DISPL	MPT-046-C-D-Z-C-J-AA-B-B-B-A-BGG-BB-A-HH-B-D-B-A-BGG-BB-A-HH-D-NNN-	M46	M46-046PT
4465129	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-V-C-B-BA-B-B-A-A-BHH-CE-A-GG-B-D-A-A-BHH-CE-A-GG-B-NNN-	M46	M46-046PT
4465131	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-V-C-S-AA-B-A-R-A-BJJ-GG-B-KF-B-C-R-A-BJJ-GG-B-KF-Y-GDH-***	M46	M46-046PT
4465132	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-V-C-S-AA-B-A-R-A-BJJ-GG-B-KF-B-C-R-A-BJJ-GG-B-KF-B-NNA-***	M46	M46-046PT
4465135	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-Z-C-J-BA-B-A-V-A-BBB-AB-U-BB-B-C-V-A-BBB-AB-U-BB-D-NNN-*	M46	M46-046PT
4465136	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-Z-C-J-BA-B-B-V-A-BBB-CB-A-HH-B-D-V-A-BBB-CB-A-HH-D-NNN-*	M46	M46-046PT
4465137	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-D-C-D-BA-B-A-A-A-BHH-AB-D-DD-B-C-A-A-BHH-AB-U-DD-A-ANN	M46	M46-046PT
4465138	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-Z-C-B-AA-B-B-A-A-BCC-CE-A-HH-B-D-A-A-BCC-CE-A-HH-C-NNN-*	M46	M46-046PT
4465143	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-D-C-A-AA-B-B-A-A-BGG-CB-A-GG-B-D-A-A-BGG-CB-A-GG-A-NNC	M46	M46-046PT
4465145	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-Z-C-B-AA-B-B-A-A-BGG-CB-A-GG-B-D-A-A-BGG-CB-A-GG-A-NNA	M46	M46-046PT
4465148	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-Z-C-B-BA-B-B-A-A-BEE-CB-A-GG-B-D-A-A-BEE-CB-A-GG-C-NNN-*	M46	M46-046PT
4465149	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-B-BA-B-A-G-A-BHH-AB-U-AA-B-C-G-A-BCC-AB-U-AA-C-NNN-	M46	M46-046PT
4465150	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-B-BA-B-B-G-A-BHH-CG-A-GG-B-C-G-A-BCC-AB-U-AA-C-NNN-	M46	M46-046PT
4510065	DISPL LIMIT KIT. SIDE 2 ALL CONTROLS		SERIES 42	PARTS - S42
4526014	CONTR TYPE-MDC,NSS+BAS,12VNOR,4T(FDLEB)		SERIES 42	PARTS - S42
462-000029	PUMP-VAR DISPL, MPV046	MPV-046-C-B-B-D-L-B-A-BA-A-A-BFF-BA-A-HH-A-NNN	M46	M46-046PV
462-000036	PUMP-VAR DISPL, MPV046	MPV-046-C-B-B-A-R-B-J-AA-G-A-BJJ-BA-A-HH-C-NNN	M46	M46-046PV
462-000044	PUMP-VAR DISPL, MPV046	MPV-046-C-B-B-D-R-B-J-AA-D-A-BHH-BB-A-HH-B-NNN	M46	M46-046PV
462-000047	PUMP-VAR DISPL, MPV046	MPV-046-C-B-A-H-R-B-B-AA-A-A-BFF-AB-U-ED-C-NNN	M46	M46-046PV
462-000053	PUMP-VAR DISPL, MPV046	MPV-046-C-B-B-W-R-B-J-BA-G-A-BBB-CG-A-HH-A-NNN	M46	M46-046PV
462-020008	PUMP-VAR DISPL, MPV046	MPV-046-C-B-A-D-R-B-B-AA-A-A-BGG-AB-U-ED-B-NNN	M46	M46-046PV
500033	SHAFT		LIGHT DUTY	PARTS - Low Power
5000358	PIN-STRAIGHT, .1253 X 1.750 W/CONE END		SERIES 90	PARTS - S90
500095	PUMP-VAR-DISPL CCW 90PV042	90L042-PB-1-BB-80-R-3-C3-B-03-GBA-35-35-24	SERIES 90	S90-042PV
500292	PUMP-VAR-DISPL CW 90PV130	90R130-EA-5-CL-80-P-3-C8-F-04-GBS-42-42-20	SERIES 90	S90-130PV
500375	MOTOR-VAR-DISPL 51MV110	51V110-R-C8-N-H1-A3-C-E-E5-NNN-034-AA-F3-24-20-051	SERIES 51	S51-110MV
500378	MOTOR-VAR-DISPL 51MV080	51V080-R-C7-N-HS-A4-C-E-C5-NNN-044-AA-F0-17-22	SERIES 51	S51-080MV
500379	MOTOR-VAR-DISPL 51MV080	51V080-R-C7-N-N2-NN-N-A0-NNN-044-AA-F0-00-00	SERIES 51	S51-080MV
500401	PUMP-VAR-DISPL CCW 90PV042	90L042-MA-1-BC-80-P-3-C3-B-03-GBA-42-42-24	SERIES 90	S90-042PV
500402	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-NN-80-P-3-C3-C-03-GBA-20-20-18	SERIES 90	S90-042PV
500592	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-E2-A5-A-N-A6-NNN-050-AA-G0-03-00	SERIES 51	S51-160MV
500714	MOTOR-VAR-DISPL 51MV110	51V110-A-C8-N-EQ-A5-J-Y-J1-AAC-038-AA-A3-35-00-021	SERIES 51	S51-110MV

500941	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-E1-A5-A-N-A6-NNN-050-AA-H0-03-00	SERIES 51	S51-250MV
500995	MOTOR-FIXED-DISPL 20MF052	SMF2/052--B3H-YCX-A1	SERIES 20	S20-052MF
501028	PUMP-VAR-DISPL CCW 90PV130	90L130-MA-1-BB-80-P-3-C8-F-04-GCA-42-42-24	SERIES 90	S90-130PV
501244	MOTOR-VAR-DISPL 51MV110	51V110-A-C8-N-E1-A5-A-N-A6-NNN-080-AA-F0-03-00	SERIES 51	S51-110MV
501286	MOTOR-FIXED-DISPL 90MF055	90-M-055-NC-0-N-8-N-0-C6-W-00-NNN-00-00-18	SERIES 90	S90-055MF
501355	MOTOR-VAR-DISPL 51MV080	51V080-R-C7-N-N2-NN-N-N-A0-NNN-016-AA-F0-00-00	SERIES 51	S51-080MV
501391	MOTOR-FIXED-DISPL 90MF130	90-M-130-NC-0-N-8-N-0-F1-W-00-NNN-00-00-F3	SERIES 90	S90-130MF
501496	PUMP-VAR-DISPL CCW 90PV042	90L042-CB-5-NN-80-S-3-C3-C-00-GBA-42-42-24-G005	SERIES 90	S90-042PV
501497	PUMP-VAR-DISPL CW 90PV042	90R042-CB-5-NN-80-S-3-C3-C-00-GBA-42-42-24-G005	SERIES 90	S90-042PV
501503	PUMP-VAR-DISPL CCW 90PV075	90L075-CB-5-NN-60-S-3-C7-D-00-GBA-42-42-24-G005	SERIES 90	S90-075PV
501504	PUMP-VAR-DISPL CW 90PV075	90R075-CB-5-NN-60-S-3-S1-D-00-GBA-42-42-24-G005	SERIES 90	S90-075PV
501505	PUMP-VAR-DISPL CCW 90PV075	90L075-CB-5-NN-80-S-3-C7-D-00-GBA-42-42-24-G005	SERIES 90	S90-075PV
501506	PUMP-VAR-DISPL CW 90PV075	90R075-CB-5-NN-80-S-3-S1-D-00-GBA-42-42-24-G005	SERIES 90	S90-075PV
501507	PUMP-VAR-DISPL CCW 90PV100	90L100-CB-5-NN-60-S-3-C7-E-00-GBA-42-42-24-G005	SERIES 90	S90-100PV
501508	PUMP-VAR-DISPL CW 90PV100	90R100-CB-5-NN-60-S-3-S1-E-00-GBA-42-42-24-G005	SERIES 90	S90-100PV
501509	PUMP-VAR-DISPL CCW 90PV100	90L100-CB-5-NN-80-S-3-C7-E-00-GBA-42-42-24-G005	SERIES 90	S90-100PV
501511	PUMP-VAR-DISPL CW 90PV100	90R100-CB-5-NN-80-S-3-S1-E-00-GBA-42-42-24-G005	SERIES 90	S90-100PV
501512	PUMP-VAR-DISPL CCW 90PV130	90L130-CB-5-NN-80-S-3-C8-H-00-GBA-42-42-24-G005	SERIES 90	S90-130PV
501513	PUMP-VAR-DISPL CW 90PV130	90R130-CB-5-NN-80-S-3-C8-H-00-GBA-42-42-24-G005	SERIES 90	S90-130PV
501539	PUMP-VAR-DISPL CW 90PV180	90R180-KA-1-NN-80-R-3-C8-H-05-HCA-35-35-20	SERIES 90	S90-180PV
501540	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-N2-NN-N-N-A0-NNN-125-AA-F3-00-00	SERIES 51	S51-250MV
501560	PUMP-VAR-DISPL CW 90PV075	90R075-HF-1-NN-60-P-3-D9-D-03-GBA-35-35-18	SERIES 90	S90-075PV
501714	MOTOR-VAR-DISPL 51MV080	51V080-R-C7-N-HS-A4-C-E-C5-NNN-025-AA-F0-17-22	SERIES 51	S51-080MV
501739	PUMP-VAR-DISPL CW 90PV042	90R042-EA-1-AB-80-P-4-C3-C-28-GBA-42-35-24-F001	SERIES 90	S90-042PV
501829	MOTOR-FIXED-DISPL 90MF100	90-M-100-NC-0-N-7-N-0-C7-W-00-CBA-00-00-B3	SERIES 90	S90-100MF
501921	PUMP-VAR-DISPL MPV025	MPV-025-C-B-A-A-W-A-G-NN-A-A-BGG-DL-A-FF-A-NNN	LIGHT DUTY	025PV
502142	VORSTEUERVENT. PCP MCV116A1102		SERIES 20	PARTS - S20 - Unique
502145	VORSTEUERVENT. PCP MCV116A2101		SERIES 20	PARTS - S20 - Unique
502157	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-N-HS-A3-C-N-E5-NNN-070-AA-F0-27-26	SERIES 51	S51-160MV
502203	SCREW		LIGHT DUTY	PARTS - Low Power
502237	BUSHING		LIGHT DUTY	PARTS - Low Power
502331	MOTOR-VAR-DISPL 51MV060	51V060-R-C6-N-E1-A5-A-N-A6-NNN-042-AA-E4-03-00	SERIES 51	S51-060MV
502351	CONNECTING HEAD		LIGHT DUTY	PARTS - Low Power
502363	MOTOR-VAR-DISPL 51MV060	51V060-R-S1-N-HZ-B1-A-N-C2-NNN-026-AA-E4-03-00	SERIES 51	S51-060MV
502372	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-EQ-A2-J-Y-H2-NNN-064-AA-G3-40-33	SERIES 51	S51-160MV
502381	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-BC-80-P-3-C8-F-04-GBS-42-42-24	SERIES 90	S90-130PV

502390	MOTOR-VAR-DISPL 51MV080	51V080-R-C7-N-E1-A5-A-N-A6-NNN-057-AA-F3-03-00	SERIES 51	S51-080MV
502441	PUMP-VAR-DISPL CW 90PV042	90R042-DC-1-NN-80-S-3-T3-C-Z2-GBA-45-45-28	SERIES 90	S90-042PV
502479	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-E2-A5-A-N-A6-NNN-080-AA-G0-03-00	SERIES 51	S51-160MV
502537	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-HS-L2-B-E-A8-NNN-024-AA-N6-05-28	SERIES 51	S51-080MV
502574	PUMP-VAR-DISPL CW 90PV055	90R055-MA-2-NN-60-S-3-C6-C-61-FAB-45-45-24	SERIES 90	S90-055PV
502906	ADAPTER		LIGHT DUTY	PARTS - Low Power
503044	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-E2-A3-A-N-E5-NNN-032-AA-F3-03-32	SERIES 51	S51-160MV
503056	MOTOR-VAR-DISPL 51MV110	51V110-R-F1-N-HS-L2-B-E-A8-NNN-042-AA-A0-07-19	SERIES 51	S51-110MV
503109	PUMP-VAR-DISPL CW 90PV100	90R100-MB-1-BC-80-R-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
503140	PUMP-VAR-DISPL CCW 90PV130	90L130-MB-1-CD-80-R-3-F1-F-03-GBA-42-42-24	SERIES 90	S90-130PV
503141	PUMP-VAR-DISPL CCW 90PV180	90L180-MB-1-CD-80-R-3-F1-J-05-NNN-42-42-24	SERIES 90	S90-180PV
503173	PUMP-VAR-DISPL MPV046	MPV-046-C-B-B-G-L-B-A-AA-G-A-BHH-DA-A-ZD-C-NNN	M46	M46-046PV
503210	MOTOR-FIXED-DISPL 20MF089	SMF2/089--B3H-MS3535X-449-A1	SERIES 20	S20-089MF
503212	MOTOR-FIXED-DISPL 20MF070	SMF2/070--B3L-MS3535X-449-A1	SERIES 20	S20-070MF
503274	MOTOR-VAR-DISPL 51MV080	51V080-R-C7-N-E1-A5-A-N-A6-NNN-030-AA-F3-03-00	SERIES 51	S51-080MV
503275	MOTOR-VAR-DISPL 51MV110	51V110-R-C8-N-E1-A5-A-N-A6-NNN-038-AA-F3-03-00	SERIES 51	S51-110MV
503288	MOTOR-VAR-DISPL 51MC060	51C060-R-D1-N-E1-A3-A-N-E5-NNN-035-AA-F0-03-17	SERIES 51	S51-060MV
503624	PUMP-VAR-DISPL CW 90PV075	90R075-CB-5-NN-60-S-3-C7-D-00-GBA-42-42-24-G005	SERIES 90	S90-075PV
503625	PUMP-VAR-DISPL CCW 90PV075	90L075-CB-5-NN-60-S-3-S1-D-00-GBA-42-42-24-G005	SERIES 90	S90-075PV
503626	PUMP-VAR-DISPL CW 90PV075	90R075-CB-5-NN-80-S-3-C7-D-00-GBA-42-42-24-G005	SERIES 90	S90-075PV
503627	PUMP-VAR-DISPL CCW 90PV075	90L075-CB-5-NN-80-S-3-S1-D-00-GBA-42-42-24-G005	SERIES 90	S90-075PV
503628	PUMP-VAR-DISPL CW 90PV100	90R100-CB-5-NN-60-S-3-C7-E-00-GBA-42-42-24-G005	SERIES 90	S90-100PV
503629	PUMP-VAR-DISPL CCW 90PV100	90L100-CB-5-NN-60-S-3-S1-E-00-GBA-42-42-24-G005	SERIES 90	S90-100PV
503630	PUMP-VAR-DISPL CW 90PV100	90R100-CB-5-NN-80-S-3-C7-E-00-GBA-42-42-24-G005	SERIES 90	S90-100PV
503632	PUMP-VAR-DISPL CCW 90PV100	90L100-CB-5-NN-80-S-3-S1-E-00-GBA-42-42-24-G005	SERIES 90	S90-100PV
503882	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-NN-80-L-3-S1-D-00-GBA-32-32-24	SERIES 90	S90-075PV
504084	MOTOR-VAR-DISPL 51MV160	51V160-A-C8-N-EQ-A5-J-Y-J1-AAC-050-AA-B3-35-00-021	SERIES 51	S51-160MV
504169	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-E2-A2-A-N-E1-NNN-050-AA-F3-03-35	SERIES 51	S51-250MV
504219	MOTOR-FIXED-DISPL 20MF052	SMF2/052--B3N-MS3535X-449-A1	SERIES 20	S20-052MF
504250	PUMP-VAR-DISPL MPV046	MPV-046-C-B-B-J-S-A-T-BC-S-A-BDD-DB-A-TT-A-NNN	M46	M46-046PV
504345	PUMP-VAR-DISPL CW 42PV028	42-R-28-D-ANN3-03-A-3-A-2-F-N-A-34-34-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
504380	PUMP-VAR-DISPL CW 90PV075	90R075-MA-2-BC-60-S-3-C6-D-02-FAB-42-42-24	SERIES 90	S90-075PV
504430	PUMP-VAR-DISPL CW 90PV075	90R075-EA-1-AB-60-S-8-C7-C-26-GCA-23-23-24-F001	SERIES 90	S90-075PV
504479	PUMP-VAR-DISPL CW 90PV180	90R180-CB-1-NN-80-S-3-F1-H-00-NNN-35-35-24	SERIES 90	S90-180PV
504636	PUMP-VAR-DISPL CW 90PV042	90R042-EA-1-AB-80-S-3-C3-B-03-GBA-20-20-18	SERIES 90	S90-042PV
504711	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-E2-A2-A-N-E1-NNN-080-AA-F3-03-20	SERIES 51	S51-160MV

504909	PUMP-VAR-DISPL CW 90PV075	90R075-DD-1-NN-80-S-4-S1-E-GB-FAD-42-42-24-F001	SERIES 90	S90-075PV
504946C	PUMP-VAR-DISPL CW 90PV100	90-R-100-MA-1-CD-80-S-3-C7-F-03-FAD-42-42-24	SERIES 90	S90-100PV
505000	MOTOR-VAR-DISPL 51MD110	51D110-A-D4-N-J1-K1-D-E-H4-NNN-032-AA-F0-20-20	SERIES 51	S51-110MV
505010	PUMP-VAR-DISPL CW 90PV100	90R100-DD-1-NN-60-S-4-S1-E-GF-GBA-35-35-24-F001	SERIES 90	S90-100PV
505025	PUMP-VAR-DISPL CCW 90PV042	90L042-EA-1-NN-80-R-3-C3-B-03-GBA-42-42-24	SERIES 90	S90-042PV
505052/P	ENDCAP 90PV100 SP 1-6000 ASSY (67)		SERIES 90	PARTS - S90
505053	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-N-F2-L4-A-N-E8-NNN-070-AA-F0-03-26	SERIES 51	S51-160MV
505054	PUMP-VAR-DISPL CW 90PV075	90R075-HF-1-CD-60-P-3-D9-D-03-GBA-35-35-18	SERIES 90	S90-075PV
505063	PUMP-VAR-DISPL CCW 90PV130	90L130-EA-1-NN-80-S-3-C8-F-04-GBA-38-38-28	SERIES 90	S90-130PV
505064	PUMP-VAR-DISPL CCW 90PV130	90L130-EA-1-AB-80-S-3-C8-F-04-GBA-38-38-28	SERIES 90	S90-130PV
505066	PUMP-VAR-DISPL CCW 90PV130	90L130-EA-1-BC-80-S-3-C8-F-04-GBA-38-38-28	SERIES 90	S90-130PV
505125	MOTOR-VAR-DISPL 51MD110	51D110-R-D4-N-HS-R4-B-E-D5-NNN-035-AA-F0-08-25	SERIES 51	S51-110MV
505170	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-EQ-A1-J-Y-E2-NNN-056-AA-F0-15-28	SERIES 51	S51-160MV
505209	PUMP-VAR-DISPL CCW 90PV042	90L042-EA-1-NN-80-D-3-C3-N-03-FAD-42-42-24	SERIES 90	S90-042PV
505213	PUMP-VAR-DISPL CW 90PV100	90R100-EA-1-NN-80-S-3-S1-E-03-FAD-42-42-24	SERIES 90	S90-100PV
505219	PUMP-VAR-DISPL CCW 90PV042	90L042-DD-1-NN-80-D-4-C3-N-GB-FAD-42-42-24	SERIES 90	S90-042PV
505377	PUMP-VAR-DISPL CW 90PV100	90R100-KA-1-NN-60-S-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
505378	MOTOR-VAR-DISPL 51MV060	51V060-A-D1-N-J1-K1-D-E-H4-NNN-021-AA-E6-20-16	SERIES 51	S51-060MV
505385	MOTOR-VAR-DISPL 51MV110	51V110-R-C8-N-HS-A2-B-E-E1-NNN-050-AA-F0-05-23	SERIES 51	S51-110MV
505452	MOTOR-VAR-DISPL 51MV080	51V080-A-C7-N-J1-K1-D-E-H4-NNN-025-AA-E6-20-22	SERIES 51	S51-080MV
505523	MOTOR-VAR-DISPL 51MV080	51V080-R-C7-N-E1-L2-A-N-A8-NNN-032-AA-F3-03-25	SERIES 51	S51-080MV
505524	MOTOR-VAR-DISPL 51MV110	51V110-R-C8-N-E1-L2-A-N-A8-NNN-049-AA-F3-03-25	SERIES 51	S51-110MV
505677	MOTOR-FIXED-DISPL 20MF052	SMF2/052--B3H-YXX-A1	SERIES 20	S20-052MF
505941	COVER		LIGHT DUTY	PARTS - Low Power
505966	CYLINDER		LIGHT DUTY	PARTS - Low Power
506074	PUMP-VAR-DISPL MPV046	MPV-046-C-B-B-S-T-B-J-BA-S-A-BFF-DB-A-TT-B-NNR	M46	M46-046PV
506152	MOTOR-VAR-DISPL 51MC110	51C110-R-D4-N-N2-NN-N-N-A0-NNN-038-AA-F3-00-00	SERIES 51	S51-110MV
506209	MOTOR-VAR-DISPL 51MV110	51V110-R-C8-N-HS-A3-C-E-B9-NNN-040-AA-F0-22-24	SERIES 51	S51-110MV
506219	PUMP-VAR-DISPL CCW 90PV042	90L042-DC-1-NN-80-S-3-C3-C-GB-GLA-35-35-24	SERIES 90	S90-042PV
506266	PUMP-VAR-DISPL CW 90PV075	90R075-KA-1-AB-80-S-3-C6-D-41-FAC-32-32-20	SERIES 90	S90-075PV
506362	PUMP-VAR-DISPL MPV046	MPV-046-C-B-B-R-B-A-AA-R-A-BFF-CB-A-HH-H-NNN	M46	M46-046PV
506393	MOTOR-FIXED-DISPL 20MF070	SMF2/070--B3H-YCS-A1	SERIES 20	S20-070MF
506404	PUMP-VAR-DISPL CCW 90PV042	90L042-MA-1-NN-80-S-3-C3-B-03-GBA-42-42-24	SERIES 90	S90-042PV
5064055	MOTOR-VAR-DISPL 51MV060	51V060-R-S1-N-N2-NN-N-N-A0-NNN-020-AA-F3-00-00	SERIES 51	S51-060MV
5064058	MOTOR-VAR-DISPL 51MV060	51V060-A-S1-N-HZ-B2-B-H-K1-NNN-015-AA-NN-06-00	SERIES 51	S51-060MV
5064060	MOTOR-VAR-DISPL 51MV060	51V060-R-S1-N-HZ-B1-B-H-G5-ABA-012-AA-NN-06-00	SERIES 51	S51-060MV

5064061	MOTOR-VAR-DISPL 51MV060	51V060-A-S1-N-HZ-B1-B-H-G5-ABA-012-AA-NN-06-00	SERIES 51	S51-060MV
5064062	MOTOR-VAR-DISPL 51MV060	51V060-R-S1-A-HZ-B1-A-H-G5-NNN-030-AA-NN-05-00	SERIES 51	S51-060MV
5064063	MOTOR-VAR-DISPL 51MV060	51V060-R-S1-N-HZ-B1-B-H-G5-ABA-016-AA-NN-06-00	SERIES 51	S51-060MV
5064064	MOTOR-VAR-DISPL 51MV060	51V060-A-S1-N-HZ-B1-B-H-G5-ABA-016-AA-NN-06-00	SERIES 51	S51-060MV
506409	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-NN-60-S-3-C7-D-01-GBA-45-45-24	SERIES 90	S90-100PV
506460	PUMP-VAR-DISPL CW 90PV250	90R250-MA-1-CD-80-S-3-C8-K-03-NNN-35-35-24	SERIES 90	S90-250PV
5065005	MOTOR-VAR-DISPL 51MV060-1	51V060-1--R-S1-N-TA-CA-N-N-X1-ABA-015-AA-E6-00-28	SERIES 51	S51-060MV-1
5065007	MOTOR-VAR-DISPL 51MV060-1	51V060-1--R-S1-N-F1-B1-N-N-U1-NNN-012-AA-E4-00-00	SERIES 51	S51-060MV-1
5065010	MOTOR-VAR-DISPL 51MV060-1	51V060-1--R-S1-N-E1-B1-N-N-U1-NNN-036-AA-E6-00-00	SERIES 51	S51-060MV-1
5065012	MOTOR-VAR-DISPL 51MV060-1	51V060-1--R-S1-N-N1-NN-N-N-U1-NNN-019-AA-E4-00-00	SERIES 51	S51-060MV-1
5065013	MOTOR-VAR-DISPL 51MV060-1	51V060-1--A-S1-N-E1-B1-N-N-U1-NNN-036-AA-E4-00-00	SERIES 51	S51-060MV-1
5065014	MOTOR-VAR-DISPL 51MV060-1	51V060-1--A-S1-N-T1-C2-N-N-X1-ABA-015-AA-E4-00-15	SERIES 51	S51-060MV-1
5065027	MOTOR-VAR-DISPL 51MV060-1	51V060-1--R-S1-N-N1-NN-N-N-U1-ABA-030-AA-NN-00-00	SERIES 51	S51-060MV-1
506529	PUMP-VAR-DISPL CCW 90PV042	90L042-KA-1-AB-80-S-3-C3-B-26-GBA-42-42-24	SERIES 90	S90-042PV
5065605	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-N-N1-NN-N-N-U1-ABA-012-AA-NN-00-00	SERIES 51	S51-060MV-1
5065607	MOTOR-VAR-DISPL 51MC060-1	51C060-1--A-D1-N-N1-NN-N-N-U1-NNN-015-AA-E6-00-00	SERIES 51	S51-060MV-1
5065611	MOTOR-VAR-DISPL 51MC060	51C060-1--R-D1-N-E2-B1-N-N-U1-ABA-015-AA-E6-00-00	SERIES 51	S51-060MV-1
5065614	MOTOR-VAR-DISPL 51MC060-1	51C060-1--A-D1-N-N1-NN-N-N-U1-ACB-015-AA-E6-00-00	SERIES 51	S51-060MV-1
5065616	MOTOR-VAR-DISPL 51MC060	51C060-1--R-D1-N-E1-B1-N-N-U1-NNN-012-AA-E4-00-00	SERIES 51	S51-060MV-1
5065618	MOTOR-VAR-DISPL 51MC060-1	51C060-1--A-D1-N-N1-NN-N-N-U1-NNN-015-AA-E4-00-00	SERIES 51	S51-060MV-1
5065619	MOTOR-VAR-DISPL 51MC060-1	51C060-1--A-D1-N-N1-NN-N-N-U1-ACB-015-AA-E4-00-00	SERIES 51	S51-060MV-1
5065621	MOTOR-VAR-DISPL 51MC060	51C060-1--R-D1-N-E1-B1-N-N-U1-ABA-012-AA-E4-00-00	SERIES 51	S51-060MV-1
5065622	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-N-E1-B1-N-N-U1-ABA-012-AA-NN-00-00	SERIES 51	S51-060MV-1
5065623	MOTOR-VAR-DISPL 51MC060	51C060-1--R-D1-N-N1-NN-N-N-U1-NNN-022-AA-E6-00-00	SERIES 51	S51-060MV-1
5065624	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-N-TA-D7-N-N-X1-ABA-015-AA-E6-00-28	SERIES 51	S51-060MV-1
5065626	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-B-N1-NN-N-N-U1-ACG-016-AA-E4-00-00	SERIES 51	S51-060MV-1
5065629	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-S1-N-E1-B1-N-N-U1-NNN-026-AA-F0-00-00	SERIES 51	S51-060MV-1
5065631	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-N-E1-B1-N-N-U1-NNN-026-AA-E6-00-00	SERIES 51	S51-060MV-1
5065632	MOTOR-VAR-DISPL 51MC060	51C060-1--R-D1-B-N1-NN-N-N-U1-ACB-016-AA-E4-00-00	SERIES 51	S51-060MV-1
5065634	MOTOR-VAR-DISPL 51MC060	51C060-1--R-D1-N-N1-NN-N-N-U1-NNN-020-AA-E6-00-00	SERIES 51	S51-060MV-1
5065635	MOTOR-VAR-DISPL 51MC060	51C060-1--R-D1-B-E1-B1-N-N-U1-ABA-026-AA-F0-00-00	SERIES 51	S51-060MV-1
5065636	MOTOR-VAR-DISPL 51MC060	51C060-1--R-D1-N-N1-NN-N-N-U1-ABA-012-AA-E4-00-00	SERIES 51	S51-060MV-1
5065900	MOTOR-VAR-DISPL 51MD060-1	51D060-1--R-D1-N-TA-C2-N-N-X1-NNN-040-AA-E6-00-21	SERIES 51	S51-060MV-1
506621	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-EQ-A1-J-U-E2-NNN-052-AA-F0-30-31	SERIES 51	S51-160MV
506759	MOTOR-VAR-DISPL 51MV160	51V160-A-C8-N-H1-A3-C-E-F7-NNN-053-AA-F3-25-23	SERIES 51	S51-160MV
506863	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-N2-NN-N-N-A0-NNN-107-AA-NN-00-00	SERIES 51	S51-160MV

506987	PUMP-VAR-DISPL CW 90PV042	90R042-EA-1-NN-80-R-3-C3-C-05-FAP-35-35-30	SERIES 90	S90-042PV
506989	PUMP-VAR-DISPL CW 90PV075	90R075-EA-1-NN-80-R-3-G1-E-05-FAP-35-35-30	SERIES 90	S90-075PV
507073	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-B-N2-NN-N-N-A0-NNN-110-AA-F3-00-00	SERIES 51	S51-250MV
507075	MOTOR-VAR-DISPL 51MV060	51V060-R-C6-N-J1-K2-C-E-H4-NNN-022-AA-F0-19-26	SERIES 51	S51-060MV
507119	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-E1-A2-A-N-E1-ABA-026-AA-E6-03-37	SERIES 51	S51-080MV
507166	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-EQ-A2-J-Y-M2-NNN-060-AA-G3-30-37	SERIES 51	S51-160MV
507184	PUMP-VAR-DISPL CCW 90PV100	90L100-EA-5-CD-60-P-3-C7-F-04-EAS-42-42-28	SERIES 90	S90-100PV
507362	MOTOR-VAR-DISPL 51MD110	51D110-A-D3-N-JA-NN-C-E-K3-NNN-048-AA-F0-13-26	SERIES 51	S51-110MV
507453	MOTOR-VAR-DISPL 51MD110	51D110-A-D3-N-HS-L4-B-E-E8-NNN-043-AA-F3-09-37	SERIES 51	S51-110MV
507487	MOTOR-FIXED-DISPL 90MF100	90-M-100-NC-0-N-F-N-0-C7-W-00-PAA-00-00-F3	SERIES 90	S90-100MF
507499	PUMP-VAR-DISPL CW 90PV250	90R250-MB-1-BC-80-T-3-F1-K-03-NNN-35-35-24	SERIES 90	S90-250PV
507501	PUMP-VAR-DISPL CW 90PV075	90R075-MB-1-CD-80-R-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
507531	MOTOR-VAR-DISPL 51MV060	51V060-R-C6-N-E2-A2-A-N-E1-ADA-015-AA-E6-03-30	SERIES 51	S51-060MV
507556	MOTOR-FIXED-DISPL 20MF227	SMF2/227--B6Z-MS42421-KXX-A1	SERIES 20	S20-227MF
507630	MOTOR-VAR-DISPL 51MC080	51C080-R-D3-N-N2-NN-N-N-A0-ADA-034-AA-F3-00-00	SERIES 51	S51-080MV
507631	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-1-NN-80-S-3-S1-C-02-FAC-42-42-24	SERIES 90	S90-075PV
507635	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-1-BC-80-S-3-C7-C-02-FAC-42-42-24	SERIES 90	S90-075PV
507636	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-1-CD-80-S-3-C7-C-02-FAC-42-42-24	SERIES 90	S90-075PV
507803	PUMP-VAR-DISPL MPV046	MPV-046-C-B-B-H-R-A-M-BC-G-A-BJJ-DA-A-ZD-A-NNN	M46	M46-046PV
507910	PUMP-VAR-DISPL CW 90PV250	90R250-KA-1-BC-80-S-3-C8-K-03-NNN-38-38-30	SERIES 90	S90-250PV
507929	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-NN-80-T-3-C8-J-04-NNN-42-42-24	SERIES 90	S90-180PV
507943	PUMP-VAR-DISPL CW 90PV180	90R180-KA-1-CD-80-S-3-C8-J-05-NNN-42-42-24	SERIES 90	S90-180PV
508008	PUMP-VAR-DISPL CW 90PV100	90R100-M8-1-CD-80-S-3-C7-E-03-FAD-42-42-24	SERIES 90	S90-100PV
508069	WASHER		DAIKIN	PARTS - OPV
508075	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-L2-B1-V-A-J1-ADA-072-AA-G3-B2-00	SERIES 51	S51-160MV
508135	COMPRESSION SPRING		LIGHT DUTY	PARTS - Low Power
508246	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-L2-B1-V-A-M3-ANA-043-AA-F0-B2-00	SERIES 51	S51-160MV
508275	LOCK NUT		DAIKIN	Daikin Parts
508333	SHAFT TRUNNION		DAIKIN	PARTS - OPV
508359	PUMP-VAR-DISPL CCW 90PV250	90L250-CB-5-NN-80-S-3-C8-K-00-NNN-42-42-24-G005	SERIES 90	S90-250PV
508360	PUMP-VAR-DISPL CW 90PV250	90R250-CB-5-NN-80-S-3-C8-K-00-NNN-42-42-24-G005	SERIES 90	S90-250PV
508361	PUMP-VAR-DISPL CCW 90PV180	90L180-CB-5-NN-80-S-3-C8-J-00-NNN-42-42-24-G005	SERIES 90	S90-180PV
508362	PUMP-VAR-DISPL CW 90PV180	90R180-CB-5-NN-80-S-3-C8-J-00-NNN-42-42-24-G005	SERIES 90	S90-180PV
508363	MOTOR-FIXED-DISPL 90MF042	90-M-042-NC-0-N-8-N-0-C3-W-00-NNN-00-00-E6	SERIES 90	S90-042MF
508378	MOTOR-FIXED-DISPL 90MF075	90-M-075-NC-0-N-7-N-0-E7-W-00-MAA-00-00-F0	SERIES 90	S90-075MF
5084069	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-E2-A5-A-N-G0-NNN-034-AA-E6-03-00	SERIES 51	S51-080MV

5084091	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-HZ-B1-A-N-G0-NNN-051-AA-F0-03-00-048	SERIES 51	S51-080MV
5084092	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-HZ-B1-A-N-G0-ACB-051-AA-F0-03-00-048	SERIES 51	S51-080MV
5084125	MOTOR-VAR-DISPL 51MV080	51V080-A-S1-N-E1-A5-A-N-G0-NNN-032-AA-E6-03-00	SERIES 51	S51-080MV
5084151	MOTOR-VAR-DISPL 51MV080	51V080-R-C7-N-E2-A5-A-N-A6-NNN-030-AA-E6-03-00	SERIES 51	S51-080MV
508416	RING RETAINING		DAIKIN	PARTS - OPV
5084175	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-TH-C2-L-N-G0-NNN-025-AA-E4-00-B3	SERIES 51	S51-080MV
5084180	MOTOR-VAR-DISPL 51MV080	51V080-A-S1-N-E1-A5-A-N-G0-NNN-032-AA-F0-03-00	SERIES 51	S51-080MV
5084182	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-T2-C2-L-N-G0-NNN-025-AA-F3-00-B6	SERIES 51	S51-080MV
5084183	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-ES-A5-J-Y-G5-NNN-030-AA-E4-30-00	SERIES 51	S51-080MV
5084184	MOTOR-VAR-DISPL 51MV080	51V080-A-S1-N-N2-NN-N-N-A0-ABA-016-AA-F0-00-00	SERIES 51	S51-080MV
5084185	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-E1-A5-A-N-A6-NNN-030-AA-G0-03-00	SERIES 51	S51-080MV
5084186	MOTOR-VAR DISPL 51MV080	51V080-R-S1-N-E2-A5-A-N-G0-NNN-020-AA-G0-03-00	SERIES 51	S51-080MV
5084189	MOTOR-VAR-DISPL 51V080	51V080-R-S1-N-HZ-B1-B-E-G5-NNN-020-AA-NN-07-00	SERIES 51	S51-080MV
5084191	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-EQ-A5-K-Y-G5-NNN-026-AA-F0-50-00	SERIES 51	S51-080MV
5084193	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-HE-B2-B-E-N6-NNN-029-AA-F0-09-00	SERIES 51	S51-080MV
5084195	MOTOR-VAR-DISPL 51MV080	51V080-A-S1-N-JA-NN-B-E-K3-NNN-034-AA-F3-08-24	SERIES 51	S51-080MV
5084197	MOTOR-VAR-DISPL 51MV080	51V080-A-S1-N-JA-NN-B-E-K3-NNN-034-AA-G0-08-24	SERIES 51	S51-080MV
5084198	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-ES-A5-J-Y-G5-NNN-035-AA-E4-30-00	SERIES 51	S51-080MV
5084208	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-EQ-A2-K-Y-G0-NNN-030-AA-E4-85-32	SERIES 51	S51-080MV
5084211	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-HE-B2-B-E-N6-NNN-029-AA-F0-09-00	SERIES 51	S51-080MV
5084212	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-EQ-A2-K-Y-G0-NNN-030-AA-E4-85-31	SERIES 51	S51-080MV
5084213	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-EQ-A5-K-Y-G5-ABA-038-AA-F3-50-00	SERIES 51	S51-080MV
5084214	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-HZ-B1-A-N-C2-ABA-050-AA-G0-05-00	SERIES 51	S51-080MV
508424	PIN-SPRING-SLOTTED 8.00x20.00 DIN1481		DAIKIN	PARTS - OPV
5084654	MOTOR-VAR-DISPL 51MC080	51C080-R-D3-N-HZ-B1-B-E-G5-NNN-028-AA-F0-07-00	SERIES 51	S51-080MV
5084658	MOTOR-VAR-DISPL 51MC080	51C080-R-D2-N-HZ-B1-A-N-G0-NNN-051-AA-F0-03-00-048	SERIES 51	S51-080MV
5084679	MOTOR-VAR-DISPL 51MC080	51C080-R-D3-N-HZ-B1-A-N-G0-ACE-028-AA-F0-03-00	SERIES 51	S51-080MV
5084699	MOTOR-VAR-DISPL 51MC080	51C080-R-D2-N-HE-B2-B-E-K1-NNN-031-AA-F0-09-00	SERIES 51	S51-080MV
5084703	MOTOR-VAR-DISPL 51MC080	51C080-R-D3-N-HZ-B1-B-E-G5-ACA-030-AA-F0-07-00	SERIES 51	S51-080MV
5084704	MOTOR-VAR-DISPL 51MC080	51C080-R-D2-N-N2-NN-N-N-A0-ABA-016-AA-NN-00-00	SERIES 51	S51-080MV
5084705	MOTOR-VAR-DISPL 51MC080	51C080-R-D3-N-N2-NN-N-N-A0-ABA-016-AA-NN-00-00	SERIES 51	S51-080MV
5084706	MOTOR-VAR-DISPL 51MC080	51C080-R-D2-N-L3-B1-W-B-G0-ANA-016-AA-F0-D4-00	SERIES 51	S51-080MV
5084714	MOTOR-VAR-DISPL 51MC080	51C080-R-D2-N-HZ-B1-A-E-G0-NNN-016-AA-F0-03-00	SERIES 51	S51-080MV
5084715	MOTOR-VAR-DISPL 51MC080	51C080-R-D3-N-HZ-B1-B-E-G5-NNN-038-AA-F0-07-00	SERIES 51	S51-080MV
5084717	MOTOR-VAR-DISPL 51MC080	51C080-R-D3-N-L3-B1-W-B-G0-ANA-016-AA-F0-D4-00	SERIES 51	S51-080MV
5084718	MOTOR-VAR-DISPL 51MC080	51C080-R-D2-N-HZ-B2-A-N-K1-ADA-027-AA-E4-03-00	SERIES 51	S51-080MV

5084725	MOTOR-VAR-DISPL 51MC080	51C080-R-D3-N-HZ-B1-B-E-G5-NNN-065-AA-F0-07-00	SERIES 51	S51-080MV
508493	PUMP-VAR-DISPL CW 90PV075	90R075-NA-1-NN-80-L-3-C7-D-03-GBA-42-42-24	SERIES 90	S90-075PV
5085015	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-S1-N-T2-C2-N-N-X1-NNN-048-AA-F0-00-28	SERIES 51	S51-080MV-1
5085017	MOTOR-VAR-DISPL 51MV080	51V080-1--R-S1-N-T7-CA-N-N-X1-NNN-016-AA-E6-00-18	SERIES 51	S51-080MV-1
5085019	MOTOR-VAR-DISPL 51MV080	51V080-1--A-S1-N-N1-NN-N-N-U1-ABA-016-AA-NN-00-00	SERIES 51	S51-080MV-1
5085021	MOTOR-VAR-DISPL 51MV080	51V080-1--R-S1-N-N1-NN-N-N-U1-NNN-048-AA-E6-00-00	SERIES 51	S51-080MV-1
5085022	MOTOR-VAR-DISPL 51MV080	51V080-1--R-S1-N-TA-C2-N-N-X1-NNN-040-AA-E6-00-22	SERIES 51	S51-080MV-1
5085023	MOTOR-VAR-DISPL 51MV080	51V080-1--A-S1-N-E1-B1-N-N-U2-NNN-037-AA-F0-00-00	SERIES 51	S51-080MV-1
5085028	MOTOR-VAR-DISPL 51MV080	51V080-1--A-S1-N-TA-CA-N-N-X1-NNN-016-AA-E6-00-28	SERIES 51	S51-080MV-1
5085030	MOTOR-VAR-DISPL 51MV080	51V080-1--R-S1-N-E2-B1-N-N-U1-NNN-044-AA-G0-00-00	SERIES 51	S51-080MV-1
5085031	MOTOR-VAR-DISPL 51MV080	51V080-1--R-S1-N-E1-B1-N-N-U1-NNN-026-AA-E4-00-00	SERIES 51	S51-080MV-1
5085032	MOTOR-VAR-DISPL 51MV080	51V080-1--R-S1-N-E2-B1-N-N-U1-NNN-033-AA-F0-00-00	SERIES 51	S51-080MV-1
5085033	MOTOR-VAR-DISPL 51MV080	51V080-1--R-S1-N-N1-NN-N-N-U1-NNN-030-AA-E6-00-00	SERIES 51	S51-080MV-1
5085034	MOTOR-VAR-DISPL 51MV080	51V080-1--R-S1-N-TH-C2-N-N-X1-NNN-040-AA-E4-00-13	SERIES 51	S51-080MV-1
5085035	MOTOR-VAR-DISPL 51MV080	51V080-1--A-S1-N-TA-C2-N-N-X1-NNN-040-AA-E6-00-24	SERIES 51	S51-080MV-1
5085036	MOTOR-VAR-DISPL 51MV080	51V080-1--R-S1-N-E2-B1-N-N-U1-NNN-054-AA-F0-00-00	SERIES 51	S51-080MV-1
5085037	MOTOR-VAR-DISPL 51MV080	51V080-1--A-S1-N-TA-C2-N-N-X1-NNN-054-AA-F3-00-21	SERIES 51	S51-080MV-1
5085038	MOTOR-VAR-DISPL 51MV080	51V080-1--R-S1-N-N1-NN-N-N-U1-NNN-016-AA-F3-00-00	SERIES 51	S51-080MV-1
5085040	MOTOR-VAR-DISPL 51MV080	51V080-1--R-S1-N-E1-B1-N-N-U1-NNN-040-AA-F0-00-00	SERIES 51	S51-080MV-1
5085041	MOTOR-VAR-DISPL 51MV080-1	51V080-1--A-S1-N-E1-B1-N-N-U1-NNN-040-AA-F0-00-00	SERIES 51	S51-080MV-1
5085042	MOTOR-VAR-DISPL 51MV080	51V080-1--R-S1-N-N1-NN-N-N-U1-NNN-016-AA-NN-00-00	SERIES 51	S51-080MV-1
5085043	MOTOR-VAR-DISPL 51MV080	51V080-1--R-S1-N-TH-C2-N-N-X1-NNN-016-AA-F0-00-20	SERIES 51	S51-080MV-1
5085045	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-S1-N-E2-B1-N-N-U1-NNN-054-AA-G0-00-00	SERIES 51	S51-080MV-1
5085046	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-S1-N-TA-C2-N-N-X1-NNN-030-AA-E4-00-20	SERIES 51	S51-080MV-1
5085048	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-S1-N-N1-NN-N-N-U1-ANC-051-AA-F0-00-00	SERIES 51	S51-080MV-1
5085054	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-S1-N-E1-B1-N-N-U1-NNN-026-AA-F3-00-00	SERIES 51	S51-080MV-1
5085060	MOTOR-VAR-DISPL 51MV080-1	51V080-1--A-S1-N-N1-NN-N-N-U1-NNN-054-AA-NN-00-00	SERIES 51	S51-080MV-1
5085061	MOTOR-VAR-DISPL 51MV080	51V080-1--A-S1-N-N1-NN-N-N-U1-NNN-040-AA-F3-00-00	SERIES 51	S51-080MV-1
5085063	MOTOR-VAR-DISPL 51MV080-1	51V080-1--A-S1-N-N1-NN-N-N-U1-NNN-040-AA-NN-00-00	SERIES 51	S51-080MV-1
5085069	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-S1-N-E2-B1-N-N-U1-ABA-042-AA-F0-00-00	SERIES 51	S51-080MV-1
5085071	MOTOR-VAR-DISPL 51MC080-1	51V080-1--R-D3-N-N1-NN-N-N-U1-NNN-047-AA-E4-00-00	SERIES 51	S51-080MV-1
5085072	MOTOR-VAR-DISPL 51MV080	51V080-1--R-S1-N-E2-B1-N-N-U1-NNN-054-AA-F3-00-00	SERIES 51	S51-080MV-1
508530	MOTOR-VAR-DISPL 51MD160	51D160-A-D4-N-HS-A7-B-N-E1-CCA-060-AA-F0-08-16	SERIES 51	S51-160MV
508553	MOTOR-VAR-DISPL 51MC060-1	51C060-1--H-D1-A-B7-B3-N-N-U3-AKA-012-AA-E6-00-00	SERIES 51	S51-060MV-1
5085600	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D3-N-N1-NN-N-N-U1-DDD-026-AA-F0-00-00	SERIES 51	S51-080MV-1
5085603	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D3-N-N1-NN-N-N-U1-ABA-016-AA-NN-00-00	SERIES 51	S51-080MV-1

5085605	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-D2-N-N1-NN-N-N-U1-NNN-030-AA-F0-00-00	SERIES 51	S51-080MV-1
5085607	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D3-N-N1-NN-N-N-U1-NNN-032-AA-F0-00-00	SERIES 51	S51-080MV-1
5085610	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D2-N-TA-C2-N-N-X1-NNN-037-AA-E6-00-18	SERIES 51	S51-080MV-1
5085611	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D3-N-N1-NN-N-N-U1-NNN-030-AA-F0-00-00	SERIES 51	S51-080MV-1
5085612	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D2-N-N1-NN-N-N-U1-NNN-040-AA-NN-00-00	SERIES 51	S51-080MV-1
5085614	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-S1-N-TA-C2-N-N-X1-NNN-040-AA-F0-00-17	SERIES 51	S51-080MV-1
5085615	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D2-N-N1-NN-N-N-U1-NNN-030-AA-E4-00-00	SERIES 51	S51-080MV-1
5085617	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D3-N-N1-NN-N-N-U1-ANC-026-AA-F0-00-00	SERIES 51	S51-080MV-1
5085620	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D2-N-E1-B1-N-N-U1-ABA-016-AA-NN-00-00	SERIES 51	S51-080MV-1
5085622	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D3-N-N1-NN-N-N-U1-NNN-040-AA-F3-00-00	SERIES 51	S51-080MV-1
508584	PUMP-VAR-DISPL CW 90PV100	90R100-KA-1-AB-80-S-3-C7-E-03-GBA-42-42-28	SERIES 90	S90-100PV
508589	PUMP-VAR-DISPL CW 90PV100	90R100-KA-1-NN-60-L-3-T6-E-03-GBA-42-42-26	SERIES 90	S90-100PV
508661	MOTOR-VAR-DISPL 51MV110	51V110-A-D3-N-JA-NN-C-E-K3-NNN-055-AA-F3-22-20	SERIES 51	S51-110MV
508698	PUMP-VAR-DISPL CW 90PV100	90R100-KA-1-CD-60-S-3-C7-E-03-FAB-42-42-28	SERIES 90	S90-100PV
508746	MOTOR-VAR-DISPL 51MD110	51D110-A-D4-N-J1-K1-D-E-H4-NNN-027-AA-E6-20-22	SERIES 51	S51-110MV
508773	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-TA-C2-L-N-G0-NNN-100-AA-G3-00-C5	SERIES 51	S51-160MV
508797	PUMP-VAR-DISPL CW 90PV250	90R250-KA-1-NN-80-T-3-C8-K-03-NNN-23-23-20	SERIES 90	S90-250PV
508859	PUMP-VAR-DISPL CW 90PV100	90R100-KP-6-BC-60-P-3-C7-E-06-EDE-45-45-18	SERIES 90	S90-100PV
508868	PUMP-VAR-DISPL CCW 90PV042	90L042-KA-1-NN-80-P-3-C3-C-03-GBA-35-35-20	SERIES 90	S90-042PV
508995	PUMP-VAR-DISPL CW 90PV042	90R042-CA-1-NN-80-P-4-TL-B-00-GBA-35-35-20-F001	SERIES 90	S90-042PV
509010	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-P-BB-60-P-3-C7-E-03-GBA-48-48-24	SERIES 90	S90-075PV
509011	PUMP-VAR-DISPL CW 90PV100	90R100-KA-1-NN-60-S-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
509041	MOTOR-VAR-DISPL 51MD060	51D060-R-D1-N-N2-NN-N-N-A0-NNN-012-AA-E4-00-00	SERIES 51	S51-060MV
509043	MOTOR-VAR-DISPL 51MD060	51D060-R-D2-N-N2-NN-N-N-A0-NNN-012-AA-E4-00-00	SERIES 51	S51-060MV
509045	MOTOR-VAR-DISPL 51MD060	51D060-A-D2-N-N2-NN-N-N-A0-NNN-012-AA-E4-00-00	SERIES 51	S51-060MV
509046	MOTOR-VAR-DISPL 51MD080	51D080-R-D2-N-N2-NN-N-N-A0-NNN-016-AA-E6-00-00	SERIES 51	S51-080MV
509049	MOTOR-VAR-DISPL 51MD080	51D080-A-D3-N-N2-NN-N-N-A0-NNN-016-AA-E6-00-00	SERIES 51	S51-080MV
509050	MOTOR-VAR-DISPL 51MD110	51D110-R-D3-N-N2-NN-N-N-A0-NNN-022-AA-F0-00-00	SERIES 51	S51-110MV
509051	MOTOR-VAR-DISPL 51MD110	51D110-R-D4-N-N2-NN-N-N-A0-NNN-022-AA-F0-00-00	SERIES 51	S51-110MV
509052	MOTOR-VAR-DISPL 51MD110	51D110-A-D3-N-N2-NN-N-N-A0-NNN-022-AA-F0-00-00	SERIES 51	S51-110MV
509054	MOTOR-VAR-DISPL 51MD160	51D160-R-D4-N-N2-NN-N-N-A0-NNN-032-AA-F0-00-00	SERIES 51	S51-160MV
509055	MOTOR-VAR-DISPL 51MD160	51D160-R-D5-N-N2-NN-N-N-A0-NNN-032-AA-F0-00-00	SERIES 51	S51-160MV
509057	MOTOR-VAR-DISPL 51MD160	51D160-A-D5-N-N2-NN-N-N-A0-NNN-032-AA-F0-00-00	SERIES 51	S51-160MV
509058	MOTOR-VAR-DISPL 51MV060	51V060-R-S1-N-N2-NN-N-N-A0-NNN-012-AA-E4-00-00	SERIES 51	S51-060MV
509060	MOTOR-VAR-DISPL 51MV060	51V060-R-C6-N-N2-NN-N-N-A0-NNN-012-AA-E4-00-00	SERIES 51	S51-060MV
509063	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-N2-NN-N-N-A0-NNN-016-AA-E6-00-00	SERIES 51	S51-080MV

509064	MOTOR-VAR-DISPL 51MV080	51V080-R-C7-N-N2-NN-N-N-A0-NNN-016-AA-E6-00-00	SERIES 51	S51-080MV
509065	MOTOR-VAR-DISPL 51MV080	51V080-A-S1-N-N2-NN-N-N-A0-NNN-016-AA-E6-00-00	SERIES 51	S51-080MV
509066	MOTOR-VAR-DISPL 51MV080	51V080-A-C7-N-N2-NN-N-N-A0-NNN-016-AA-E6-00-00	SERIES 51	S51-080MV
509068	MOTOR-VAR-DISPL 51MV110	51V110-R-C8-N-N2-NN-N-N-A0-NNN-022-AA-F0-00-00	SERIES 51	S51-110MV
509069	MOTOR-VAR-DISPL 51MV110	51V110-R-F1-N-N2-NN-N-N-A0-NNN-022-AA-F0-00-00	SERIES 51	S51-110MV
509070	MOTOR-VAR-DISPL 51MV110	51V110-A-C8-N-N2-NN-N-N-A0-NNN-022-AA-F0-00-00	SERIES 51	S51-110MV
509072	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-N2-NN-N-N-A0-NNN-032-AA-F0-00-00	SERIES 51	S51-160MV
509073	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-N2-NN-N-N-A0-NNN-032-AA-F0-00-00	SERIES 51	S51-160MV
509074	MOTOR-VAR-DISPL 51MV160	51V160-A-C8-N-N2-NN-N-N-A0-NNN-032-AA-F0-00-00	SERIES 51	S51-160MV
509077	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-N2-NN-N-N-A0-NNN-050-AA-F3-00-00	SERIES 51	S51-250MV
509078	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-N2-NN-N-N-A0-NNN-050-AA-F3-00-00	SERIES 51	S51-250MV
509079	MOTOR-VAR-DISPL 51MV250	51V250-A-C8-N-N2-NN-N-N-A0-NNN-050-AA-F3-00-00	SERIES 51	S51-250MV
509080	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-N-N2-NN-N-N-A0-NNN-050-AA-F3-00-00	SERIES 51	S51-250MV
509089	PUMP-VAR-DISPL CW 90PV075	90R075-MH-1-NN-60-P-3-T2-D-03-FAB-42-42-20	SERIES 90	S90-075PV
509092	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-1-NN-60-S-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
509093	PUMP-VAR-DISPL CW 90PV075	90R075-KA-1-NN-60-P-3-C7-E-05-GBA-35-42-24	SERIES 90	S90-075PV
509138	PUMP-VAR-DISPL CCW 90PV075	90L075-MA-1-AB-80-P-3-C7-D-03-GBA-42-42-24	SERIES 90	S90-075PV
509151	VENTILPLATTE OPV L		DAIKIN	PARTS - OPV
509172	PUMP-VAR-DISPL CW 90PV100	90R100-DD-1-NN-80-S-3-G1-E-G1-GBA-35-35-30	SERIES 90	S90-100PV
509173	DRUCKB.EINHEIT 210 BAR (EINBAUSATZ18/18)		LIGHT DUTY	PARTS - Low Power
509179	PUMP-VAR-DISPL CCW 90PV055	90-L-055-KA-1-AB-60-P-4-C6-C-28-FAP-42-35-24	SERIES 90	S90-055PV
509202	PUMP-VAR-DISPL CW 90PV100	90R100-EA-5-BC-60-P-3-S1-F-04-EAS-42-42-28	SERIES 90	S90-100PV
509272	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-1-AB-80-S-7-C8-F-04-GCA-38-38-30	SERIES 90	S90-130PV
509332	PUMP-VAR-DISPL CW 90PV100	90R100-KA-1-NN-80-P-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
509333	PUMP-VAR-DISPL CW 90PV130	90R130-KA-1-DE-80-L-3-C8-F-04-GBA-35-35-24	SERIES 90	S90-130PV
509336	PUMP-VAR-DISPL CW 90PV042	90R042-DC-1-BB-80-S-3-C3-C-GB-GBA-42-42-28	SERIES 90	S90-042PV
509337	PUMP-VAR-DISPL CCW 90PV075	90L075-ME-1-NN-80-S-3-S1-D-03-GBA-35-35-20	SERIES 90	S90-075PV
509344	PUMP-VAR-DISPL CW 90PV100	90R100-KA-1-CD-80-P-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
509363	MOTOR-VAR-DISPL 51MV110	51V110-R-C8-N-T1-C0-L-N-K7-NNN-034-AA-A0-00-B2	SERIES 51	S51-110MV
509459	MOTOR-VAR-DISPL 51MD110	51D110-A-D3-N-JA-NN-C-H-M4-NNN-046-AA-A0-13-28	SERIES 51	S51-110MV
509464	PUMP-VAR-DISPL CW 90PV042	90R042-KA-1-NN-80-P-3-C3-C-03-GBA-42-42-24	SERIES 90	S90-042PV
509481	MOTOR-FIXED-DISPL 90MF100	90-M-100-NC-0-N-8-N-0-T2-N-00-NNN-00-00-00	SERIES 90	S90-100MF
509488	PUMP-VAR-DISPL CW 90PV075	90R075-KA-6-BC-60-R-3-C6-E-06-EFG-43-43-30	SERIES 90	S90-075PV
509506	PUMP-VAR-DISPL CW 90PV130	90R130-KA-1-NN-80-S-4-C8-F-04-GBA-26-26-24	SERIES 90	S90-130PV
509551	MOTOR-VAR-DISPL 51MV060	51V060-R-C6-N-E2-A5-A-N-A6-ADA-031-AA-F0-03-00	SERIES 51	S51-060MV
509582	PUMP-VAR-DISPL CCW 90PV130	90L130-MB-1-NN-80-S-3-C8-H-05-GBA-35-35-20	SERIES 90	S90-130PV

509614	MOTOR-VAR-DISPL 51MD080	51D080-R-D2-N-T1-R5-L-N-G0-NNN-065-AA-E6-00-B8	SERIES 51	S51-080MV
509696	PUMP-VAR-DISPL CW 90PV100	90R100-HK-1-CD-60-D-3-C7-L-03-GBA-38-38-24	SERIES 90	S90-100PV
509740	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-1-NN-60-R-3-S1-F-05-GBA-35-35-22	SERIES 90	S90-100PV
509775	PUMP-VAR-DISPL CW 90PV100	90R100-KA-1-BC-60-L-3-C7-F-21-FAB-45-45-28	SERIES 90	S90-100PV
509790	PUMP-VAR-DISPL CW 90PV130	90R130-KA-1-NN-80-S-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-130PV
509915	PUMP-VAR-DISPL CW 90PV075	90R075-NA-6-NN-60-P-3-C7-D-03-GBA-42-42-24	SERIES 90	S90-075PV
509965	MOTOR-VAR-DISPL 51MD160	51D160-A-D4-N-T1-C0-L-N-K7-NNN-045-AA-A0-00-B0	SERIES 51	S51-160MV
509966	PUMP-VAR-DISPL CW 20PV070	SPV2/070--R6Z-PS183-447-B1	SERIES 20	S20-070PV
509983	PUMP-VAR-DISPL CCW 90PV042	90L042-DC-1-NN-80-D-4-C3-N-Z1-GBA-35-35-22	SERIES 90	S90-042PV
509987	PUMP-VAR-DISPL CW 90PV250	90R250-KA-1-NN-80-S-3-C8-K-03-NNN-23-23-28	SERIES 90	S90-250PV
509989	PUMP-VAR-DISPL CW 90PV100	90R100-DD-1-NN-80-S-4-S1-E-GB-FAD-42-42-24	SERIES 90	S90-100PV
510044	MOTOR-FIXED-DISPL 90MF100	90-M-100-NC-0-N-7-N-0-C6-W-00-NNN-00-00-F3	SERIES 90	S90-100MF
510063	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-C8-N-E1-B1-N-N-U1-NNN-044-AA-F0-00-00	SERIES 51	S51-110MV-1
510085	PUMP-VAR-DISPL CW 90PV130	90R130-M8-1-CD-80-S-3-C8-F-03-GBA-42-42-24	SERIES 90	S90-130PV
510087	MOTOR-FIXED-DISPL 20MF089	SMF2/089--B3G-MS3535X-449-A1	SERIES 20	S20-089MF
510089	MOTOR-FIXED-DISPL 20MF070	SMF2/070--B3A-MS3535X-449-A1	SERIES 20	S20-070MF
510090	PUMP-VAR-DISPL CCW 20PV070	SPV2/070--L3Z-PS123-VML311-A1	SERIES 20	S20-070PV
510092	PUMP-VAR-DISPL CCW 20PV089	SPV2/089--L3N-PS183-A1	SERIES 20	S20-089PV
510172	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-1-NN-80-S-3-C7-C-02-FAC-42-42-24	SERIES 90	S90-075PV
510262	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-C8-N-E1-B1-N-N-U2-DBA-053-AA-F3-00-00	SERIES 51	S51-110MV-1
510314	PUMP-VAR-DISPL CW 90PV075	90R075-KA-1-NN-80-S-3-C6-D-02-FAD-29-29-20	SERIES 90	S90-075PV
510319	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-E2-A7-A-N-E1-CCA-130-AA-F0-03-18	SERIES 51	S51-250MV
510320	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-E2-A7-A-N-E1-CCA-050-AA-F0-03-35	SERIES 51	S51-250MV
510323	MOTOR-VAR-DISPL 51MD080	51D080-A-D2-N-J1-K1-D-E-H4-NNN-017-AA-E6-20-26	SERIES 51	S51-080MV
510324	MOTOR-VAR-DISPL 51MD110	51D110-A-D4-N-J1-K1-D-E-H4-NNN-024-AA-E6-20-22	SERIES 51	S51-110MV
510383	PUMP-VAR-DISPL CW 90PV042	90R042-KP-6-BC-80-S-3-C3-C-03-GBA-48-48-24	SERIES 90	S90-042PV
510385	PUMP-VAR-DISPL CW 90PV075	90R075-MA-2-BC-60-S-4-C6-E-03-FAX-45-45-28	SERIES 90	S90-075PV
510443	PUMP-VAR-DISPL CW 90PV100	90R100-MA-7-BC-60-S-4-D7-E-03-GBA-45-45-24-F040	SERIES 90	S90-100PV
510463	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-L2-B1-V-A-J1-ADA-054-AA-G3-B2-00	SERIES 51	S51-160MV
510486	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-CD-60-P-3-C7-F-03-EAS-42-42-24	SERIES 90	S90-100PV
510492	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-1-NN-80-S-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-075PV
510513	PUMP-VAR-DISPL CW 90PV100	90R100-NA-1-AB-80-L-3-C7-D-76-GBA-42-42-26	SERIES 90	S90-100PV
510539	PUMP-VAR-DISPL CW 90PV100	90R100-NA-1-NN-80-L-3-C7-D-76-GBA-42-42-26	SERIES 90	S90-100PV
510564	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-C7-N-E1-B1-N-N-U1-NNN-025-AA-F0-00-00	SERIES 51	S51-080MV-1
510569	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-NN-80-R-3-C8-H-03-GBA-42-42-20	SERIES 90	S90-130PV
510573	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-1-CD-80-S-3-C7-D-03-GBA-35-35-24	SERIES 90	S90-075PV

510577	PUMP-VAR-DISPL CW 90PV130	90R130-EA-5-DE-80-P-3-C8-F-04-GBS-42-42-20	SERIES 90	S90-130PV
510579	PUMP-VAR-DISPL CCW 90PV042	90L042-KA-1-BB-80-S-3-C3-C-03-GBA-35-35-24	SERIES 90	S90-042PV
510583	PUMP-VAR-DISPL CCW 90PV075	90L075-MB-1-CD-80-R-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
510599	PUMP-VAR-DISPL CW 90PV075	90R075-MB-1-BB-60-R-3-C6-D-03-GBA-38-38-20	SERIES 90	S90-075PV
510600	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-2-CD-60-P-3-C7-E-03-FAB-45-45-24	SERIES 90	S90-075PV
510603	PUMP-VAR-DISPL CCW 90PV042	90L042-KA-1-AB-80-S-3-C3-C-06-FAC-26-26-20	SERIES 90	S90-042PV
510604	PUMP-VAR-DISPL CW 90PV100	90R100-KA-1-NN-80-S-3-C7-E-02-FAB-42-42-20	SERIES 90	S90-100PV
510660	PUMP-VAR-DISPL CW 90PV075	90R075-DC-1-AB-80-D-4-S1-L-Z1-GBA-42-42-20-F033	SERIES 90	S90-075PV
510684	DICHTUNGSSATZ 20 SONDER.F.SERVOVENT.		SERIES 20	PARTS - S20 - Unique
510709	PUMP-VAR-DISPL CW 90PV075	90R075-MA-1-AB-60-S-3-C6-D-03-GBA-42-42-24	SERIES 90	S90-075PV
510710	PUMP-VAR-DISPL CW 90PV075	90R075-KA-1-CD-80-P-3-C7-D-04-GBA-42-42-24	SERIES 90	S90-075PV
510711	PUMP-VAR-DISPL CW 90PV100	90R100-KA-1-BC-80-S-4-C7-E-01-GBA-42-42-24	SERIES 90	S90-100PV
510715	PUMP-VAR-DISPL CW 90PV042	90R042-MA-1-NN-80-S-3-C3-C-03-GBA-42-42-24	SERIES 90	S90-042PV
510728	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-1-AB-60-P-3-C7-E-04-GBA-42-42-XX-B012	SERIES 90	S90-075PV
510785	MOTOR-VAR-DISPL 51MV160	51V160-A-C8-N-JA-NN-B-H-M1-NNN-043-AA-B3-10-29	SERIES 51	S51-160MV
510794	PUMP-VAR-DISPL CW 90PV042	90R042-MA-1-BB-80-S-4-C3-C-02-GBA-42-42-24	SERIES 90	S90-042PV
510795	PUMP-VAR-DISPL CW 90PV042	90R042-MA-1-BC-80-S-4-C3-C-02-GBA-42-42-24	SERIES 90	S90-042PV
510830	PUMP-VAR-DISPL CW 20PV070	SPV2/070--R3Z-PS123-VML311-A1	SERIES 20	S20-070PV
510873	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-C8-N-E1-B1-N-N-U2-DBA-030-AA-A3-00-00	SERIES 51	S51-110MV-1
510906	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-1-NN-80-L-3-C7-E-03-GBA-42-42-30	SERIES 90	S90-100PV
510911	MOTOR-FIXED-DISPL 90MF130	90-M-130-NC-0-N-8-N-0-C8-W-00-NNN-00-00-F3	SERIES 90	S90-130MF
510967	PUMP-VAR-DISPL MPV046	MPV-046-C-B-B-G-R-B-A-AA-A-A-BGG-CB-A-GG-C-NNN	M46	M46-046PV
510970	PUMP-VAR-DISPL CW 90PV075	90R075-KA-2-NN-80-S-3-C6-D-24-FAC-32-32-20	SERIES 90	S90-075PV
510979	MOTOR-VAR-DISPL 51MD110-1	51D110-1--A-D4-N-T1-CA-N-N-X1-NNN-028-AA-N6-00-27	SERIES 51	S51-110MV-1
510997	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-BC-80-R-C-C8-H-04-FAT-42-42-24	SERIES 90	S90-180PV
511-000008	MOTOR-VAR DISPL, 51MV110	51V110-A-F1-N-HS-A2-B-G-E1-NNN-042-AA-NN-05-23	SERIES 51	S51-110MV-1
511007	PUMP-VAR-DISPL CW 90PV100	90R100-MA-1-AB-60-S-3-C7-F-06-GBA-42-42-24	SERIES 90	S90-100PV
511015	PUMP-VAR-DISPL CW 90PV042	90R042-MA-1-AB-80-S-3-C3-B-03-GBA-35-35-24	SERIES 90	S90-042PV
511063	WASHER		LIGHT DUTY	PARTS - Low Power
511070	PUMP-VAR-DISPL CW 90PV075	90R075-KA-1-CD-60-R-3-C7-E-03-EFD-42-42-24	SERIES 90	S90-075PV
511071	LIMITER		LIGHT DUTY	PARTS - Low Power
511116	MOTOR-VAR-DISPL 51MV110	51V110-R-C8-N-J1-K5-B-E-L1-NNN-045-AA-F0-10-18	SERIES 51	S51-110MV
511160	PUMP-VAR-DISPL CW 90PV100	90R100-FA-1-CD-60-P-7-C7-E-B1-EAB-42-42-28	SERIES 90	S90-100PV
511190	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-N-E2-L2-A-N-E4-NNN-050-AA-F3-03-30	SERIES 51	S51-250MV
511248	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-1-NN-60-R-3-C7-E-03-GBA-38-38-28	SERIES 90	S90-100PV
511251	PUMP-VAR-DISPL CW 90PV100	90R100-MA-2-BC-60-S-4-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV

511252	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-1-AB-60-R-3-C7-E-03-GBA-38-38-28	SERIES 90	S90-100PV
511254	PUMP-VAR-DISPL CW 90PV042	90R042-FA-1-AB-80-S-7-C3-B-B1-EFD-42-42-26	SERIES 90	S90-042PV
511259	WELLE OPV1/038 ZYL/PASSF. (1720431)		DAIKIN	PARTS - OPV
511271	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-1-AB-60-L-4-T2-E-02-FAB-42-42-24	SERIES 90	S90-100PV
511272	MOTOR-VAR-DISPL 51MD060	51D060-R-D2-N-HA-B2-C-E-E6-NNN-031-AA-E4-14-00	SERIES 51	S51-060MV
511288	MOTOR-VAR-DISPL 51MC110-1	51C110-1--R-D3-N-E1-B1-N-N-U2-ABA-030-AA-A0-00-00	SERIES 51	S51-110MV-1
511309	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-C8-N-E2-B1-N-N-U1-NNN-055-AA-F3-00-00	SERIES 51	S51-110MV-1
511380	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D3-N-B2-B3-N-N-U3-ADA-026-AA-F3-00-00	SERIES 51	S51-080MV-1
5114091	MOTOR-VAR-DISPL 51MV110	51V110-R-F1-N-E2-A5-A-N-G0-ADB-061-AA-F0-03-00-P040	SERIES 51	S51-110MV
511412	PUMP-VAR-DISPL CW 90PV042	90R042-DD-1-NN-80-D-4-C3-L-Z1-GBA-40-40-26	SERIES 90	S90-042PV
5114167	MOTOR-VAR-DISPL 51MV110	51V110-A-F1-N-N2-NN-N-N-A0-ABA-022-AA-NN-00-00	SERIES 51	S51-110MV
5114172	MOTOR-VAR-DISPL 51MV110	51V110-R-F1-N-HZ-B1-B-H-G5-NNN-030-AA-F3-05-00	SERIES 51	S51-110MV
5114173	MOTOR-VAR-DISPL 51MV110	51V110-A-F1-N-HZ-B1-B-H-G5-NNN-030-AA-F3-05-00	SERIES 51	S51-110MV
5114175	MOTOR-VAR-DISPL 51MV110	51V110-R-F1-N-HZ-B1-C-H-C2-NNN-030-AA-F0-15-00	SERIES 51	S51-110MV
5114178	MOTOR-VAR-DISPL 51MV110	51V110-R-F1-N-T1-C2-L-N-K7-NNN-050-AA-F0-00-B4	SERIES 51	S51-110MV
5114183	MOTOR-VAR-DISPL 51MV110	51V110-R-F1-N-HZ-B1-B-H-C2-NNN-058-AA-F0-07-00	SERIES 51	S51-110MV
5114185	MOTOR-VAR-DISPL 51MV110	51V110-R-F1-N-HZ-B1-C-H-G5-NNN-030-AA-NN-15-00	SERIES 51	S51-110MV
5114186	MOTOR-VAR-DISPL 51MV110	51V110-R-F1-N-TH-C2-L-N-G0-NNN-055-AA-F0-00-C1	SERIES 51	S51-110MV
5114197	MOTOR-VAR DISPL	51V110-R-F1-N-D8-M1-R-J-M4-ACA-033-AA-E6-C2-25	SERIES 51	S51-110MV
5114198	MOTOR-VAR-DISPL 51MV110	51V110-R-F1-N-N2-NN-N-N-A0-ABA-047-AA-F3-00-00	SERIES 51	S51-110MV
511427	MOTOR-FIXED-DISPL 20MF052	SMF2/052--B3H-MS3535X-449-A1	SERIES 20	S20-052MF
511441	MOTOR-FIXED-DISPL 20MF089	SMF2/089--B6G-MS2121X-449-A1	SERIES 20	S20-089MF
511443	MOTOR-FIXED-DISPL 20MF089	SMF2/089--B3G-MS3535X-453-A1	SERIES 20	S20-089MF
511446	VENT.BL.2/#A=450B=450ND=10+/-0,5 BAR HUS		SERIES 20	PARTS - S20 - Unique
511448	MOTOR-FIXED-DISPL 20MF089	SMF2/089--B3A-MS3535X-449-A1	SERIES 20	S20-089MF
5114763	MOTOR-VAR-DISPL 51MC110	51C110-R-D3-N-L3-B1-W-B-G0-ANA-022-AA-F0-D4-00	SERIES 51	S51-110MV
5114764	MOTOR-VAR-DISPL 51MC110	51C110-R-D3-N-HZ-B1-A-N-G0-ABA-055-AA-F0-03-00	SERIES 51	S51-110MV
5114765	MOTOR-VAR-DISPL 51MC110	51C110-R-D3-N-L7-B1-W-B-G0-ABA-037-AA-F0-D4-00	SERIES 51	S51-110MV
5114766	MOTOR-VAR-DISPL 51MC110	51C110-R-D3-N-E2-A5-A-N-K7-NNN-039-AA-F0-03-00	SERIES 51	S51-110MV
5114769	MOTOR-VAR-DISPL 51MC110	51C110-R-D3-N-TH-C2-L-N-G0-NNN-052-AA-F0-00-B7	SERIES 51	S51-110MV
511479	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-CD-60-P-3-S1-E-04-GBS-42-42-20	SERIES 90	S90-075PV
511480	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-NN-60-P-3-S1-E-04-GBS-42-42-20	SERIES 90	S90-075PV
5115001	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-N1-NN-N-N-U1-ABA-022-AA-NN-00-00	SERIES 51	S51-110MV-1
5115005	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-TA-C2-N-N-X1-NNN-041-AA-F3-00-32	SERIES 51	S51-110MV-1
5115009	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-E2-B1-N-N-U1-NNN-074-AA-F3-00-00	SERIES 51	S51-110MV-1
5115010	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-TA-C2-N-N-X1-NNN-050-AA-F3-00-22	SERIES 51	S51-110MV-1

5115012	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-E1-B1-N-N-U1-NNN-060-AA-F0-00-00	SERIES 51	S51-110MV-1
5115015	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-E1-B1-N-N-U1-ABA-041-AA-F0-00-00	SERIES 51	S51-110MV-1
5115019	MOTOR-VAR-DISPL 51MV110-1	51V110-1--A-F1-N-TA-C2-N-N-X1-NNN-060-AA-F3-00-22	SERIES 51	S51-110MV-1
5115021	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-N1-NN-N-N-U1-NNN-074-AA-F0-00-00	SERIES 51	S51-110MV-1
5115022	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-T2-D2-N-N-X1-NNN-047-AA-G0-00-21	SERIES 51	S51-110MV-1
5115023	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-TA-C2-N-N-X1-NNN-044-AA-G0-00-21	SERIES 51	S51-110MV-1
5115024	MOTOR-VAR-DISPL 51MV110-1	51V110-1--A-F1-N-N1-NN-N-N-U1-NNN-054-AA-NN-00-00	SERIES 51	S51-110MV-1
5115025	MOTOR-VAR-DISPL 51MV110-1	51V110-1--A-F1-N-N1-NN-N-N-U1-ABA-054-AA-NN-00-00	SERIES 51	S51-110MV-1
5115026	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-T1-D1-N-N-X1-NNN-047-AA-G0-00-21	SERIES 51	S51-110MV-1
5115027	MOTOR-VAR-DISPL 51MV110-1	51V110-1--A-F1-N-N1-NN-N-N-U1-NNN-060-AA-F3-00-00	SERIES 51	S51-110MV-1
5115029	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-TH-C2-N-N-X1-NNN-055-AA-F0-00-20	SERIES 51	S51-110MV-1
5115031	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-TA-C2-N-N-X1-NNN-022-AA-NN-00-14	SERIES 51	S51-110MV-1
5115032	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-E1-B1-N-N-U1-NNN-060-AA-E6-00-00	SERIES 51	S51-110MV-1
5115033	MOTOR-VAR-DISPL 51MV110-1	51V110-1--A-F1-N-T1-C2-N-N-X1-ABA-042-AA-F0-00-25	SERIES 51	S51-110MV-1
5115034	MOTOR-VAR-DISPL 51MV110-1	51V110-1--A-F1-N-F1-B1-N-N-U1-NNN-074-AA-F0-00-00	SERIES 51	S51-110MV-1
5115040	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-E1-B1-N-N-U1-NNN-070-AA-F0-00-00	SERIES 51	S51-110MV-1
5115041	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-TA-C2-N-N-X1-NNN-064-AA-F0-00-34	SERIES 51	S51-110MV-1
5115048	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-TA-C2-N-N-X1-NNN-064-AA-F0-00-21	SERIES 51	S51-110MV-1
5115051	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-C8-N-N1-NN-N-N-U1-NNN-046-AA-E6-00-00	SERIES 51	S51-110MV-1
511529	MOTOR-VAR-DISPL 51MD110-1	51D110-1--R-D4-N-E1-B1-N-N-U2-NNN-030-AA-A3-00-00	SERIES 51	S51-110MV-1
5115600	MOTOR-VAR-DISPL 51MC110-1	51C110-1--R-D3-N-N1-NN-N-N-U1-ABA-022-AA-NN-00-00	SERIES 51	S51-110MV-1
5115602	MOTOR-VAR-DISPL 51MC110-1	51C110-1--A-D3-N-TH-C2-N-N-X1-ANA-026-AA-E6-00-24	SERIES 51	S51-110MV-1
5115604	MOTOR-VAR-DISPL 51MC110-1	51C110-1--R-D3-N-N1-NN-N-N-U1-NNN-031-AA-F0-00-00	SERIES 51	S51-110MV-1
5115611	MOTOR-VAR-DISPL 51MC110-1	51C110-1--R-D3-N-E1-B1-N-N-U1-ABA-065-AA-F0-00-00	SERIES 51	S51-110MV-1
5115612	MOTOR-VAR-DISPL 51MC110-1	51C110-1--R-D3-N-E1-B1-N-N-U1-ABA-048-AA-F0-00-00	SERIES 51	S51-110MV-1
511580	MOTOR-VAR-DISPL 51MD110-1	51D110-1--H-D4-N-B7-B3-N-N-U3-AKD-032-AA-F3-00-00	SERIES 51	S51-110MV-1
511586	MOTOR-VAR-DISPL 51MD160	51D160-A-D4-N-T1-C0-L-N-L4-NNN-040-AA-A0-00-B6	SERIES 51	S51-160MV
5115901	MOTOR-VAR-DISPL 51MD110-1	51D110-1--R-D4-B-TA-C2-N-N-X1-NNN-055-AA-E6-00-30	SERIES 51	S51-110MV-1
5115902	MOTOR-VAR-DISPL 51MD110-1	51D110-1--R-D3-N-TA-D1-N-N-X1-NNN-055-AA-F0-00-35	SERIES 51	S51-110MV-1
5115903	MOTOR-VAR-DISPL 51MD110-1	51D110-1--R-D3-N-TH-C2-N-N-X1-NNN-037-AA-E6-00-35	SERIES 51	S51-110MV-1
511674	PUMP-VAR-DISPL CW 90PV130	90R130-HD-D-BC-8C-S-E-C8-U-33-GBT-42-42-30-G004	SERIES 90	S90-130PV
511685	MOTOR-VAR-DISPL 51MD110-1	51D110-1--R-D4-N-E1-B1-N-N-U2-ABA-030-AA-A3-00-00	SERIES 51	S51-110MV-1
511712	MOTOR-VAR-DISPL 51MV110	51V110-R-C8-N-EQ-A5-J-Y-J1-ADA-022-AA-G3-30-00	SERIES 51	S51-110MV
511783	MOTOR-FIXED-DISPL 90MF100	90-M-100-NC-O-N-7-N-O-TJ-W-00-NNN-00-00-G0	SERIES 90	S90-100MF
511786	MOTOR-VAR-DISPL 51MV160	51V160-A-C8-N-EQ-A5-J-Y-J1-NNN-035-AA-NN-30-00	SERIES 51	S51-160MV
511787	MOTOR-VAR-DISPL 51MV160	51V160-A-C8-N-EQ-A5-J-Y-J1-ADA-035-AA-NN-30-00	SERIES 51	S51-160MV

511797	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-1-AB-60-P-3-T2-D-03-GBA-38-14-24	SERIES 90	S90-075PV
511803	PUMP-VAR-DISPL CW 90PV075	90R075-ME-1-BB-60-D-3-C7-L-04-GBA-42-42-28	SERIES 90	S90-075PV
511871	PUMP-VAR-DISPL CW 90PV100	90R100-MN-1-CD-60-R-7-C7-D-04-FAB-42-42-28	SERIES 90	S90-100PV
511897	PUMP-VAR-DISPL CW 90PV100	90R100-FB-5-BC-60-P-7-S1-F-B1-GCS-42-42-28	SERIES 90	S90-100PV
511901	MOTOR-VAR-DISPL 51MD080	51D080-R-D2-N-JA-NN-B-E-K3-NNN-027-AA-A0-09-17	SERIES 51	S51-080MV
511924	MOTOR-FIXED-DISPL 90MF100	90-M-100-NC-0-N-8-N-0-C7-W-00-NNN-00-00-E6	SERIES 90	S90-100MF
511957	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-EQ-A2-J-Y-H2-NNN-057-AA-G3-40-33-025	SERIES 51	S51-160MV
511976	MOTOR-VAR-DISPL 51MV110	51V110-R-C8-N-E2-A5-A-N-A6-NNN-053-AA-A3-03-00	SERIES 51	S51-110MV
512019	MOTOR-FIXED-DISPL 20MF089	SMF2/089--B3H-MS3535X-453-A1	SERIES 20	S20-089MF
512032	MOTOR-VAR-DISPL 51MD110	51D110-R-D4-N-HS-A2-B-E-E1-NNN-031-AA-A3-08-25	SERIES 51	S51-110MV
512033	MOTOR-VAR-DISPL 51MV110	51V110-R-C8-N-E2-A5-A-N-A6-ACB-068-AA-A3-03-00	SERIES 51	S51-110MV
512068	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-HB-B1-B-E-C2-NNN-023-AA-F0-11-00	SERIES 51	S51-080MV
512069	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-HA-B1-B-E-C2-NNN-023-AA-F0-11-00	SERIES 51	S51-080MV
512070	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-HB-B1-B-E-C2-NNN-032-AA-F0-11-00	SERIES 51	S51-080MV
512071	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-HA-B1-B-E-C2-NNN-032-AA-F0-11-00	SERIES 51	S51-080MV
512105	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-HS-A7-B-N-F1-CCA-130-AA-F0-08-15	SERIES 51	S51-250MV
512106	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-HZ-B1-B-E-C2-NNN-052-AA-B3-08-00	SERIES 51	S51-160MV
512107	MOTOR-VAR-DISPL 51MV110	51V110-R-C8-N-HZ-B1-B-E-C2-NNN-036-AA-A3-08-00	SERIES 51	S51-110MV
512118	MOTOR-VAR-DISPL 51MV160	51V160-A-C8-N-JA-NN-B-E-K3-NNN-032-AA-A0-08-28	SERIES 51	S51-160MV
512133	PUMP-VAR-DISPL CW 90PV075	90R075-KA-1-AB-80-P-3-S1-D-04-GBA-42-42-24	SERIES 90	S90-075PV
512174	PUMP-VAR-DISPL CCW 20PV070	SPV2/070--L3Z-PS18X-VML311-458-A1	SERIES 20	S20-070PV
512177	PUMP-VAR-DISPL CW 20PV070	SPV2/070--R3H-PS12X-VML311-456-A1	SERIES 20	S20-070PV
512193	MOTOR-VAR-DISPL 51MV110	51V110-A-C8-N-JA-NN-B-E-K3-NNN-032-AA-A0-08-28	SERIES 51	S51-110MV
512216	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-1-AB-80-S-3-C6-D-C2-FAC-32-32-20	SERIES 90	S90-075PV
512224	PUMP-VAR-DISPL CCW 20PV052	SPV2/052--L3Z-PS18X-VML309-459-A1	SERIES 20	S20-052PV
512226	PUMP-VAR-DISPL CCW 20PV052	SPV2/052--L3Z-PS12X-VES313-456-A1	SERIES 20	S20-052PV
512231	PUMP-VAR-DISPL CW 20PV089	SPV2/089--R3H-PS12X-VML311-456-A1	SERIES 20	S20-089PV
512232	PUMP-VAR-DISPL CCW 20PV089	SPV2/089--L3H-PS12X-VML311-RNU331-456--A1	SERIES 20	S20-089PV
512234	PUMP-VAR-DISPL CCW 20PV089	SPV2/089--L3H-PS186-VML311-A1	SERIES 20	S20-089PV
512235	PUMP-VAR-DISPL CW 20PV089	SPV2/089--R3H-PS18X-VML308-458-A1	SERIES 20	S20-089PV
512264	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-NN-80-D-3-S1-N-04-FAD-42-42-24	SERIES 90	S90-075PV
512332	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-1-BC-60-S-3-C7-E-04-GBA-42-42-30	SERIES 90	S90-100PV
512333	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-1-BC-80-S-3-C8-F-05-GBA-45-45-30	SERIES 90	S90-130PV
512337	MOTOR-VAR-DISPL 51MC110-1	51C110-1--R-D3-E-E1-B1-N-N-U2-DBA-030-AA-A0-00-00	SERIES 51	S51-110MV-1
512421	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-5-AB-80-S-3-C8-J-04-EFI-42-42-28	SERIES 90	S90-250PV
512422	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-1-CD-80-S-3-C8-J-04-GLA-42-42-28	SERIES 90	S90-250PV

512446	PUMP-VAR-DISPL CW 90PV075	90R075-KA-1-NN-80-S-4-C7-E-03-GBA-35-35-20	SERIES 90	S90-075PV
512447	PUMP-VAR-DISPL CW 90PV130	90R130-FB-5-DE-80-P-7-C8-F-B1-GBS-40-40-30	SERIES 90	S90-130PV
512458	MOTOR-FIXED-DISPL 20MF052	SMF2/052--B3H-MR3535X-449-A1	SERIES 20	S20-052MF
512462	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-C8-N-E1-B1-N-N-U1-NNN-030-AA-A0-00-00	SERIES 51	S51-110MV-1
512486	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-C8-N-E1-B1-N-N-U1-NNN-045-AA-F3-00-00	SERIES 51	S51-110MV-1
512501C	PUMP-VAR-DISPL CW 90PV100	90-R-100-HF-1-BC-80-L-3-S1-F-03-GBA-35-35-20	SERIES 90	S90-100PV
512513	PUMP-VAR-DISPL CCW 20PV070	SPV2/070--L3H-PS12X-VML311-456-A1	SERIES 20	S20-070PV
512518	PUMP-VAR-DISPL CW 90PV130	90R130-KA-1-NN-80-L-3-TH-F-03-GBA-42-42-26	SERIES 90	S90-130PV
512529	MOTOR-FIXED-DISPL 20MF070	SMF2/070--B3Z-MS4242X-457-A1	SERIES 20	S20-070MF
512555	MOTOR-VAR-DISPL 51MV160	51V160-A-C8-N-EQ-A5-J-Y-J1-ADE-060-AA-B3-35-00-021	SERIES 51	S51-160MV
512565	PUMP-VAR-DISPL CW 90PV130	90R130-MB-1-BC-80-R-3-F1-H-03-GBA-42-42-24	SERIES 90	S90-130PV
512623	PUMP-VAR-DISPL CW 90PV180	90R180-KA-1-NN-80-S-3-C8-J-03-NNN-42-42-24	SERIES 90	S90-180PV
512625	PUMP-VAR-DISPL CCW 90PV075	90L075-DC-1-AB-60-S-3-C7-D-GB-GBA-42-42-24	SERIES 90	S90-075PV
512647	PUMP-VAR-DISPL CW 90PV100	90R100-MA-2-BB-60-P-4-D7-F-03-FAX-45-38-30-F003	SERIES 90	S90-100PV
512648	PUMP-VAR-DISPL CW 90PV075	90R075-MA-1-BC-60-P-4-D7-E-03-FAX-45-45-28	SERIES 90	S90-075PV
512693	PUMP-VAR-DISPL CW 90PV100	90R100-FD-5-CD-60-P-7-C7-D-B1-EFM-42-42-28	SERIES 90	S90-100PV
512733	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-N-N1-NN-N-N-U1-ACB-024-AA-NN-00-00	SERIES 51	S51-060MV-1
512748	MOTOR-VAR-DISPL 20MV089	SMV2/089--B3H-048-MS35354-VML311-A1	SERIES 20	S20-089SMV
512750	MOTOR-VAR-DISPL 51MC110-1	51C110-1--H-D3-N-B7-B3-N-N-U3-AKA-032-AA-F0-00-00	SERIES 51	S51-110MV-1
512796	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-1-BC-60-R-3-C7-E-03-GBA-38-38-28	SERIES 90	S90-100PV
512797	PUMP-VAR-DISPL CW 90PV100	90R100-MB-1-NN-80-L-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
512799	PUMP-VAR-DISPL CW 90PV180	90R180-MB-1-NN-80-T-3-C8-J-03-NNN-42-42-24	SERIES 90	S90-180PV
512800	PUMP-VAR-DISPL CW 90PV075	90R075-MB-1-NN-80-P-3-C7-D-03-GBA-42-42-24	SERIES 90	S90-075PV
512801	PUMP-VAR-DISPL CW 90PV075	90R075-KA-1-NN-80-P-3-C7-D-03-GBA-42-42-24	SERIES 90	S90-075PV
512805	MOTOR-VAR-DISPL 51MC110-1	51C110-1--R-D3-N-B2-B3-N-N-U3-ADA-030-AA-NN-00-00	SERIES 51	S51-110MV-1
512809	PUMP-VAR-DISPL CW 90PV130	90R130-KA-1-NN-80-S-3-C8-H-03-GBA-42-42-24	SERIES 90	S90-130PV
512813	PUMP-VAR-DISPL CW 20PV089	SPV2/089--R6H-PS12X-VML309-464-A1	SERIES 20	S20-089PV
512873	MOTOR-FIXED-DISPL TMM070	TMM070B-64NN-NNNO	TMM / TMP	TMM070
512874	MOTOR-FIXED-DISPL TMM070	TMM070B-33NN-NNNO	TMM / TMP	TMM070
512902	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-EQ-A3-J-Y-E5-NNN-050-AA-B0-15-27	SERIES 51	S51-250MV
512903	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-E2-A5-A-N-A6-NNN-140-AA-F3-03-00	SERIES 51	S51-250MV
512904	PUMP-VAR-DISPL CW 90PV130	90R130-FH-5-CD-80-R-7-C8-F-B1-EFM-35-35-28	SERIES 90	S90-130PV
512982	PUMP-VAR-DISPL CW 90PV180	90R180-PA-1-BB-80-S-3-F1-H-A3-NNN-42-42-24	SERIES 90	S90-180PV
512990	MOTOR-VAR-DISPL 51MD160	51D160-A-D5-N-L1-B2-W-B-H7-ADA-032-AA-A3-D4-00	SERIES 51	S51-160MV
512991	MOTOR-VAR-DISPL 51MV160	51V160-A-C8-N-T1-C0-L-N-K7-NNN-053-AA-B0-00-B3	SERIES 51	S51-160MV
512999	PUMP-VAR-DISPL CW 90PV100	90R100-MA-7-BC-60-S-4-D7-E-04-FAB-45-45-24	SERIES 90	S90-100PV

513000	MOTOR-FIXED-DISPL 90MF075	90-M-075-NC-0-N-8-N-0-C6-W-00-NNN-00-00-A0	SERIES 90	S90-075MF
513013	MOTOR-VAR-DISPL 20MV089	SMV2/089--B3H-048-MS3535X-VAE531-449-A1	SERIES 20	S20-089SMV
513129	PUMP-VAR-DISPL CW 90PV250	90R250-KA-1-NN-80-S-3-C8-K-03-NNN-42-42-24	SERIES 90	S90-250PV
513136	MOTOR-FIXED-DISPL 20MF334	SMF2/334--B6Z-MS42421-KXX-A1	SERIES 20	S20-334MF
513159	MOTOR-VAR-DISPL 51MD110-1	51D110-1--R-D4-N-B7-B3-N-N-U3-ABA-067-AA-F0-00-00	SERIES 51	S51-110MV-1
513160	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-N-B7-B3-N-N-U3-ABA-036-AA-F0-00-00	SERIES 51	S51-060MV-1
513181	MOTOR-VAR-DISPL 51MD160	51D160-R-D4-E-L7-B1-W-B-G0-ABA-073-AA-H0-D4-00	SERIES 51	S51-160MV
513190	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-S1-N-N1-NN-N-N-U1-ABA-016-AA-NN-00-00	SERIES 51	S51-080MV-1
513191	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D2-N-N1-NN-N-N-U1-ABA-016-AA-NN-00-00	SERIES 51	S51-080MV-1
513212	MOTOR-VAR-DISPL 51MV080	51V080-R-C7-N-HS-A2-B-E-E1-ABA-050-AA-A3-10-25	SERIES 51	S51-080MV
513215	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-N-T2-D2-N-N-X1-ADA-027-AA-NN-00-27	SERIES 51	S51-060MV-1
513217	PUMP-VAR-DISPL CW 90PV100	90R100-RU-5-BD-80-D-3-C7-S-A8-FAD-40-40-22	SERIES 90	S90-100PV
513221	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-1-AB-80-S-4-C7-E-35-GCB-42-42-24	SERIES 90	S90-075PV
513231	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-1-BC-80-S-3-C7-E-35-FAC-42-42-24	SERIES 90	S90-075PV
513232	PUMP-VAR-DISPL CW 90PV075	90R075-MN-1-BB-60-R-3-C7-C-04-FAD-42-42-26	SERIES 90	S90-075PV
513233	PUMP-VAR-DISPL CW 90PV100	90R100-MN-1-CD-60-R-3-C7-D-04-FAD-42-42-26	SERIES 90	S90-100PV
513237	MOTOR-FIXED-DISPL 90MF075	90-M-075-NC-0-N-8-N-0-C6-N-00-NNN-00-00-00	SERIES 90	S90-075MF
513252	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-N-B2-B3-N-N-U3-ADA-024-AA-F3-00-00	SERIES 51	S51-060MV-1
513256	MOTOR-VAR-DISPL 51MV110	51V110-A-C8-N-EQ-A1-J-Y-M6-ADE-038-AA-A3-35-32-021	SERIES 51	S51-110MV
513257	MOTOR-VAR-DISPL 51MV160	51V160-A-C8-N-EQ-A1-J-Y-M6-ADE-050-AA-B3-35-32-021	SERIES 51	S51-160MV
513258	MOTOR-VAR-DISPL 51MV160	51V160-A-C8-N-EQ-A1-J-Y-M6-ADE-060-AA-B3-35-35-021	SERIES 51	S51-160MV
513260	MOTOR-VAR-DISPL 51MV250	51V250-A-C8-N-EQ-A1-J-Y-M6-ADE-078-AA-B3-35-37-021	SERIES 51	S51-250MV
513285	PUMP-VAR-DISPL CW 90PV075	90R075-KA-1-BP-60-S-3-C7-S-03-FAD-42-42-22	SERIES 90	S90-075PV
513286	PUMP-VAR-DISPL CW 90PV075	90R075-KA-1-CU-60-S-3-C7-S-03-FAD-42-42-22	SERIES 90	S90-075PV
513287	PUMP-VAR-DISPL CW 90PV100	90R100-KA-1-CU-80-S-3-C7-S-03-FAD-38-38-22	SERIES 90	S90-100PV
513407	MOTOR-VAR-DISPL 51MD160	51D160-A-D4-N-T3-C0-L-N-L4-NNN-040-AA-A0-00-B6	SERIES 51	S51-160MV
513426	PUMP-VAR-DISPL CW 90PV130	90R130-KM-A-DF-89-R-3-J5-R-33-EAT-42-42-JD-N180	SERIES 90	S90-130PV
513450	PUMP-VAR-DISPL CW 90PV250	90R250-MA-1-NN-80-T-4-C8-J-03-NNN-26-26-24	SERIES 90	S90-250PV
513451	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-NN-80-D-4-S1-N-03-FAD-38-38-26	SERIES 90	S90-100PV
513452	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-1-BC-80-S-3-C7-E-03-FAC-42-42-24	SERIES 90	S90-100PV
513459	PUMP-VAR-DISPL CW 20PV070	SPV2/070--R6Z-PS183-XCX-B1	SERIES 20	S20-070PV
513461	MOTOR-FIXED-DISPL 20MF070	SMF2/070--B6Z-MS42422-XCX-A1	SERIES 20	S20-070MF
513494	PUMP-VAR-DISPL CW 90PV130	90R130-FH-5-BC-80-P-7-F1-F-B1-GCS-42-42-28	SERIES 90	S90-130PV
513495	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-J4-K1-C-E-H4-ADA-060-AA-B3-14-27	SERIES 51	S51-160MV
513541	MOTOR-VAR-DISPL 51MC160	51C160-R-F1-N-E2-A2-A-N-G1-NNN-080-AA-F3-03-25	SERIES 51	S51-160MV
513555	PUMP-VAR-DISPL CW 90PV250	90R250-KA-1-EG-80-S-3-C8-K-03-NNN-23-23-28	SERIES 90	S90-250PV

513559	PUMP-VAR-DISPL CW 90PV130	90R130-FG-1-NN-80-L-7-C8-H-B1-EFI-38-38-30	SERIES 90	S90-130PV
513576	PUMP-VAR-DISPL CW 90PV100	90R100-KA-1-BC-60-L-4-C7-F-21-FAB-45-45-28	SERIES 90	S90-100PV
513597	PUMP-VAR-DISPL CW 90PV042	90R042-KA-1-NN-80-S-H-T8-B-03-FAP-26-26-26	SERIES 90	S90-042PV
513599	PUMP-VAR-DISPL CW 90PV075	90R075-KA-1-NN-80-S-H-T6-C-03-FAP-23-23-26	SERIES 90	S90-075PV
513603	MOTOR-FIXED-DISPL 90MF042	90-M-042-NC-0-N-8-N-0-C3-W-00-NNN-00-00-N6	SERIES 90	S90-042MF
513613	MOTOR-FIXED-DISPL 90MF055	90-M-055-NC-0-N-8-N-0-K1-W-00-NNN-00-00-F0	SERIES 90	S90-055MF
513618	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-J4-K1-C-E-M7-ADA-056-AA-G3-14-30	SERIES 51	S51-160MV
513621	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-J4-K1-C-E-M7-ADA-060-AA-G3-14-30	SERIES 51	S51-160MV
513623	MOTOR-VAR-DISPL 51MV110	51V110-R-C8-N-J1-K5-B-E-L1-NNN-038-AA-F0-10-27	SERIES 51	S51-110MV
513635	MOTOR-FIXED-DISPL 90MF130	90-M-130-NC-0-N-8-N-0-C8-W-00-JAB-00-00-A3	SERIES 90	S90-130MF
513650	MOTOR-VAR-DISPL 20MV070	SMV2/070--B3H-038-MS3535X-VAE531-449-A1	SERIES 20	S20-070SMV
513651	MOTOR-VAR-DISPL 20MV089	SMV2/089--B3H-034-MS3838X-VAE531-449-A1	SERIES 20	S20-089SMV
513654	PUMP-VAR-DISPL CW 90PV100	90R100-KA-1-CD-60-S-3-C7-F-04-GBA-42-42-28	SERIES 90	S90-100PV
513656	PUMP-VAR-DISPL CW 90PV130	90R130-CA-5-BC-80-P-7-F1-F-00-GLS-42-42-30	SERIES 90	S90-130PV
513672	MOTOR-VAR-DISPL 51MD110-1	51D110-1--A-D4-N-T1-CA-N-N-X1-NNN-036-AA-F0-00-18	SERIES 51	S51-110MV-1
513673	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-N-E2-A7-A-N-E1-CCA-050-AA-A3-03-32	SERIES 51	S51-250MV
513708	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-2-BB-60-P-3-C7-E-03-FAB-45-45-24	SERIES 90	S90-075PV
513710	PUMP-VAR-DISPL CW 90PV130	90R130-FB-5-CL-80-P-7-C8-F-B1-GBS-40-40-30	SERIES 90	S90-130PV
513714	PUMP-VAR-DISPL CW 90PV250	90R250-HS-1-NN-80-T-3-C8-J-03-NNN-42-42-24	SERIES 90	S90-250PV
513715	MOTOR-VAR-DISPL 51MD160	51D160-A-D4-N-E2-A7-A-N-E1-CCA-035-AA-A3-03-16	SERIES 51	S51-160MV
513717	PUMP-VAR-DISPL CW 90PV042	90R042-MB-1-NN-80-P-3-C3-C-03-GBA-42-42-24	SERIES 90	S90-042PV
513720	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D3-N-T2-D2-N-N-X1-ADA-026-AA-NN-00-27-P010	SERIES 51	S51-080MV-1
513773	PUMP-VAR-DISPL CCW 90PV042	90L042-DC-1-NN-80-S-3-C3-B-Z2-GBA-42-29-28	SERIES 90	S90-042PV
513779	MOTOR-FIXED-DISPL 90MF100	90-M-100-NC-0-N-8-N-0-C7-W-00-EFA-00-00-A3	SERIES 90	S90-100MF
513782	MOTOR-FIXED-DISPL 90MF100	90-M-100-NC-0-N-8-N-0-C7-W-00-NNN-00-00-B3	SERIES 90	S90-100MF
513823	MOTOR-VAR-DISPL 51MV080	51V080-R-C7-N-E5-A4-J-Y-M8-NNN-016-AA-A0-15-30	SERIES 51	S51-080MV
513866	PUMP-VAR-DISPL CW 90PV100	90R100-MA-2-CD-80-S-3-C7-E-04-GBA-48-48-24	SERIES 90	S90-100PV
513867	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-T1-C0-L-N-K7-NNN-088-AA-F3-00-B5	SERIES 51	S51-160MV
513878	ENDCAP-TMM-089-INCH-6		TMM / TMP	PARTS - TMM/TMP
513897	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-S1-N-E2-B1-N-N-U1-NNN-024-AA-E6-00-00	SERIES 51	S51-080MV-1
513904	MOTOR-FIXED-DISPL 90MF100	90-M-100-NC-0-N-T-N-0-C7-W-00-CBC-00-00-B3	SERIES 90	S90-100MF
513908	PUMP-VAR-DISPL CW 90PV075	90R075-KA-1-CD-60-L-3-C7-E-03-FAC-42-42-24	SERIES 90	S90-075PV
513909	PUMP-VAR-DISPL CW 90PV075	90R075-KA-1-CD-60-R-3-C7-E-03-FAC-42-42-24	SERIES 90	S90-075PV
513919	PUMP-VAR-DISPL CW 90PV042	90R042-DC-1-NN-80-D-4-C3-N-Z1-GBA-35-35-22	SERIES 90	S90-042PV
513921	PUMP-VAR-DISPL MPV046	MPV-046-C-B-A-D-T-B-B-AA-A-A-BHH-AB-U-ED-B-NNN	M46	M46-046PV
513922	PUMP-VAR-DISPL MPV046	MPV-046-C-B-A-K-S-B-B-AA-G-A-BHH-AB-U-ED-B-NNN	M46	M46-046PV

513924	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-NN-80-L-3-C7-F-03-GBA-42-42-28	SERIES 90	S90-100PV
513926	PUMP-VAR-DISPL CW 90PV042	90R042-PA-5-BB-80-S-3-C3-C-03-GBA-29-29-28	SERIES 90	S90-042PV
513935	MOTOR-VAR-DISPL 51MV110	51V110-R-C8-N-EQ-A5-K-Y-A6-NNN-022-AA-F0-85-00	SERIES 51	S51-110MV
513950	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-1-NN-60-S-3-C7-D-03-GBA-23-23-24	SERIES 90	S90-075PV
513957	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-R-BB-60-P-P-C7-D-03-FAC-35-BP-20-E107	SERIES 90	S90-075PV
513962	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-NN-60-S-3-S1-D-03-GBA-42-42-20	SERIES 90	S90-075PV
513992	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-F-CD-80-L-7-C8-F-44-GCG-35-35-30	SERIES 90	S90-130PV
514372	WASHER		LIGHT DUTY	PARTS - Low Power
514570	COMPRESSION SPRING		M46	PARTS - M46
515080	DROSSELWELLE F.FAHRAUTOM.		LIGHT DUTY	PARTS - Low Power
515250	MOTOR-VAR-DISPL 20MV166	SMV2/166--B6F-099-MS4242X-VAE530-449-A1	SERIES 20	S20-166SMV
515283	CLANOK 6.5ST. VEL.070 GELENKSTUECK 6.5		SERIES 20	PARTS - S20 - Unique
515306	PUMP-VAR-DISPL CW 20PV166	SPV2/166--R6F-972972-PS33X-A1	SERIES 20	S20-166PV
515331	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-E2-B1-N-N-U1-NNN-050-AA-F3-00-00	SERIES 51	S51-110MV-1
515332	MOTOR-VAR-DISPL 51MC110-1	51C110-1--R-D3-N-E2-B1-N-N-U1-NNN-045-AA-NN-00-00	SERIES 51	S51-110MV-1
515335	PUMP-VAR-DISPL CW 90PV130	90R130-CF-D-NN-8C-S-E-F1-U-33-EEE-42-42-30-G004	SERIES 90	S90-130PV
515340	MOTOR-VAR-DISPL 20MV070	SMV2/070--B3Z-034-MS3535X-VAE531-449-A1	SERIES 20	S20-070SMV
515341	PUMP-VAR-DISPL CCW 20PV052	SPV2/052--L3Z-PS12X-VES311-456-A1	SERIES 20	S20-052PV
515352	PUMP-VAR-DISPL CW 20PV089	SPV2/089--R3H-PS18X-VML300-458-A1	SERIES 20	S20-089PV
515355	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-1-BC-80-S-3-C8-H-03-GBA-42-42-28	SERIES 90	S90-130PV
515358	MOTOR-VAR-DISPL 51MV110	51V110-R-C8-N-HS-A3-B-E-E5-NNN-036-AA-E6-07-28	SERIES 51	S51-110MV
515382	PUMP-VAR-DISPL CW 90PV100	90R100-FD-5-CD-60-P-7-C7-F-B1-GCS-42-42-28	SERIES 90	S90-100PV
515390	MOTOR-VAR-DISPL 51MD160	51D160-A-D4-N-J3-K1-C-H-H4-ABA-036-AA-N4-12-30	SERIES 51	S51-160MV
515394	PUMP-VAR-DISPL CW 90PV042	90R042-FC-5-BC-80-S-7-C3-C-B4-EFI-45-45-32	SERIES 90	S90-042PV
515397	PUMP-VAR-DISPL CW 90PV100	90R100-FD-1-CD-60-P-7-C7-E-B1-GCS-42-42-28	SERIES 90	S90-100PV
515400	MOTOR-FIXED-DISPL 90MF130	90-M-130-NC-0-N-8-N-0-C8-W-00-NNN-00-00-A3	SERIES 90	S90-130MF
515401	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-1-CD-80-S-3-C7-D-42-GBA-42-42-24	SERIES 90	S90-075PV
515407	PUMP-VAR-DISPL CW 90PV100	90R100-KA-1-NN-80-S-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
515414	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-J4-K1-C-E-H4-ADA-054-AA-B3-14-29	SERIES 51	S51-160MV
515426	PUMP-VAR-DISPL CCW 90PV100	90L100-FB-5-CD-60-P-7-C7-F-B1-GCS-42-42-28	SERIES 90	S90-100PV
515427	PUMP-VAR-DISPL MPV046	MPV-046-C-B-B-J-S-A-T-BC-W-A-BDD-DB-A-TT-A-NNN	M46	M46-046PV
515436	PUMP-VAR-DISPL CW 90PV100	90R100-MA-6-NN-60-S-4-C7-F-03-FAW-48-48-30	SERIES 90	S90-100PV
515439	PUMP-VAR-DISPL CW 90PV075	90R075-EA-5-CD-60-P-7-C7-E-00-GLS-42-42-30	SERIES 90	S90-075PV
515440	PUMP-VAR-DISPL CW 90PV100	90R100-EA-5-CD-60-P-7-C7-F-00-GLS-42-42-30	SERIES 90	S90-100PV
515441	PUMP-VAR-DISPL CW 90PV130	90R130-EA-5-CD-80-P-7-C8-H-00-GLS-42-42-30	SERIES 90	S90-130PV
515477	MOTOR-FIXED-DISPL 90MF075	90-M-075-NC-0-N-8-N-0-C6-W-00-EFA-00-00-F0	SERIES 90	S90-075MF

515479	MOTOR-FIXED-DISPL 90MF100	90-M-100-NC-0-N-8-N-0-C7-W-00-EFA-00-00-F3	SERIES 90	S90-100MF
515480	MOTOR-VAR-DISPL 51MD080-1	51D080-1--A-D3-N-T7-D7-N-N-X1-NNN-020-AA-N4-00-25	SERIES 51	S51-080MV-1
515481	MOTOR-VAR-DISPL 51MV110	51V110-A-C8-N-E2-A5-A-N-A6-NNN-055-AA-A3-03-00	SERIES 51	S51-110MV
515495	MOTOR-VAR-DISPL 51MD110-1	51D110-1--A-D3-N-T1-R5-N-N-X1-NNN-068-AA-A3-00-25	SERIES 51	S51-110MV-1
515497	PUMP-VAR-DISPL CCW 90PV130	90L130-HF-1-NN-80-S-3-C8-H-03-GBA-42-42-24	SERIES 90	S90-130PV
515499	MOTOR-FIXED-DISPL 90MF042	90-M-042-NC-0-N-8-N-0-C2-N-00-NNN-00-00-00	SERIES 90	S90-042MF
515507	MOTOR-FIXED-DISPL 90MF055	90-M-055-NC-0-N-8-N-0-C6-W-00-EFA-00-00-F3	SERIES 90	S90-055MF
515531	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-C7-N-E1-B1-N-N-U1-NNN-041-AA-A3-00-00	SERIES 51	S51-080MV-1
515535	HOUSING 42PV028 B TO B		SERIES 42	PARTS - S42
515539	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-N-E2-B1-N-N-U1-NNN-022-AA-E6-00-00	SERIES 51	S51-060MV-1
515540	PUMP-VAR-DISPL CCW 90PV100	90L100-MA-1-BB-80-S-3-C7-D-04-GCS-42-42-24	SERIES 90	S90-100PV
515541	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-E2-A5-A-N-A6-NNN-100-AA-F3-03-00	SERIES 51	S51-160MV
515543	MOTOR-VAR-DISPL 51MV110	51V110-R-C8-N-ES-A6-J-Y-H7-NNN-045-AA-F0-30-00	SERIES 51	S51-110MV
515565	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-D8-M1-R-J-M4-ADA-060-AA-G3-C2-30	SERIES 51	S51-160MV
515603	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-AB-80-P-3-F1-F-03-GBA-29-29-24	SERIES 90	S90-130PV
515610	PUMP-VAR-DISPL CW 90PV180	90R180-FH-5-DE-80-T-7-C8-H-B1-NNN-38-38-30	SERIES 90	S90-180PV
515620	MOTOR-VAR-DISPL 51MV110	51V110-A-C8-N-EQ-A2-J-Z-H5-NNN-057-AA-G3-40-37	SERIES 51	S51-110MV
515622	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-5-NN-80-T-3-F1-J-03-NNN-38-38-24	SERIES 90	S90-250PV
515631	PUMP-VAR-DISPL CW 90PV100	90R100-DD-5-CD-80-L-7-C7-E-G1-GCA-35-35-30	SERIES 90	S90-100PV
515632	PUMP-VAR-DISPL CW 90PV100	90R100-DD-5-NN-80-L-7-S1-E-G1-GCA-35-35-30	SERIES 90	S90-100PV
515633	MOTOR-FIXED-DISPL TMM089	TMM089B-642N-NNN0	TMM / TMP	TMM089
515666	PUMP-VAR-DISPL CW 90PV100	90R100-FC-5-BC-80-P-7-C7-E-B1-EAB-42-42-28	SERIES 90	S90-100PV
515706	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-NN-80-S-3-C3-C-05-FAP-35-35-42	SERIES 90	S90-042PV
515707	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-NN-80-S-3-G1-E-05-FAP-35-35-42	SERIES 90	S90-075PV
515709	PUMP-VAR-DISPL CW 90PV130	90R130-KA-F-NN-80-S-3-C8-H-44-GLA-35-35-42	SERIES 90	S90-130PV
515710	PUMP-VAR-DISPL CW 90PV180	90R180-KA-F-NN-80-S-C-C8-J-44-GLA-35-35-42	SERIES 90	S90-180PV
515711	PUMP-VAR-DISPL CW 90PV180	90R180-HF-5-BC-80-S-3-C8-H-03-NNN-38-20-24	SERIES 90	S90-180PV
515713	PUMP-VAR-DISPL CW 90PV100	90R100-FA-5-NN-60-S-7-F1-E-B1-EFI-35-35-30	SERIES 90	S90-100PV
515719	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-5-AB-80-T-3-F1-K-03-NNN-35-35-28	SERIES 90	S90-250PV
515721	PUMP-VAR-DISPL CW 90PV180	90R180-HF-5-NN-80-T-3-F1-H-03-NNN-32-32-24	SERIES 90	S90-180PV
515722	PUMP-VAR-DISPL CW 90PV250	90R250-HF-5-EF-80-T-3-C8-J-03-NNN-32-32-24	SERIES 90	S90-250PV
515723	PUMP-VAR-DISPL CW 90PV075	90R075-KN-5-NN-80-L-3-C7-D-03-GBA-42-42-24	SERIES 90	S90-075PV
515747	PUMP-VAR-DISPL CW 90PV075	90R075-MB-5-BB-60-D-3-S1-L-C6-GBA-42-42-28	SERIES 90	S90-075PV
515766	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-AB-60-S-3-C7-F-04-GBA-42-42-24	SERIES 90	S90-100PV
515768	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-A-E1-A5-A-N-A6-NNN-058-AA-A3-03-00	SERIES 51	S51-160MV
515770	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-CD-80-T-3-F1-H-03-FAC-26-26-24	SERIES 90	S90-180PV

515782	PUMP-VAR-DISPL CW 90PV100	90R100-MA-5-NN-60-S-3-C7-F-C6-GBA-42-42-24	SERIES 90	S90-100PV
515797	MOTOR-FIXED-DISPL 90MF130	90-M-130-NC-0-N-U-N-0-F1-H-00-LAA-00-00-NH	SERIES 90	S90-130MF
515832	MOTOR-VAR-DISPL 51MV110	51V110-R-C8-N-J2-K5-B-E-L1-NNN-045-AA-F3-05-21	SERIES 51	S51-110MV
515856	SERVOVENT.2/119 (SMV/O.RINGKANAL)		SERIES 20	PARTS - S20 - Purchased Parts
515860	MOTOR-VAR-DISPL 51MD080-1	51D080-1--R-D2-N-E1-B1-N-N-U1-NNN-025-AA-NN-00-00	SERIES 51	S51-080MV-1
515864	PUMP-VAR-DISPL CCW 90PV075	90L075-PB-5-NN-60-S-3-C7-E-00-GBA-38-38-20	SERIES 90	S90-075PV
515872	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-CD-60-D-3-C7-L-02-FAD-42-42-24	SERIES 90	S90-100PV
515884	PUMP-VAR-DISPL CW 90PV100	90R100-DD-5-NN-80-D-4-S1-N-99-FAD-35-35-26	SERIES 90	S90-100PV
515886	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D2-N-TA-C2-N-N-X1-NNN-048-AA-F3-00-37	SERIES 51	S51-080MV-1
515891	PUMP-VAR-DISPL CW 90PV250	90R250-MB-5-CD-80-T-3-C8-K-C5-NNN-26-26-24	SERIES 90	S90-250PV
515917	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-DG-80-L-3-C8-F-03-GBA-42-42-24	SERIES 90	S90-130PV
515918	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-CD-80-L-3-C8-F-03-GBA-42-42-24	SERIES 90	S90-130PV
515938	MOTOR-VAR-DISPL 51MC110-1	51C110-1--R-D3-N-B1-B3-N-N-U3-DBA-030-AA-F0-00-00	SERIES 51	S51-110MV-1
515939	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-EQ-A2-J-Y-E1-ADA-100-AA-G0-30-28	SERIES 51	S51-250MV
515975	PUMP-VAR-DISPL CW 90PV130	90R130-CB-D-AB-84-5-7-F1-H-00-GCA-38-38-24	SERIES 90	S90-130PV
515976	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-C8-N-B1-B3-N-N-U3-ADD-053-AA-F3-00-00	SERIES 51	S51-110MV-1
515977	MOTOR-VAR-DISPL 51MC110-1	51C110-1--R-D3-N-B1-B3-N-N-U3-ADD-022-AA-F0-00-00	SERIES 51	S51-110MV-1
516023	MOTOR-FIXED-DISPL 90MF100	90-M-100-NC-0-N-U-N-0-F1-B-00-PAA-00-00-H0	SERIES 90	S90-100MF
516031	PUMP-VAR-DISPL CW 90PV100	90R100-KA-2-BC-60-S-4-D7-E-04-FAB-45-45-24	SERIES 90	S90-100PV
516034	MOTOR-VAR-DISPL 51MD110-1	51D110-1--A-D3-N-T7-D7-N-N-X1-NNN-036-AA-E6-00-16	SERIES 51	S51-110MV-1
516044	MOTOR-VAR-DISPL 51MV110-1	51V110-1--A-F1-N-T7-L5-N-N-X1-ADA-042-AA-N6-00-19	SERIES 51	S51-110MV-1
516045	PUMP-VAR-DISPL CW 90PV042	90R042-FC-P-BB-80-R-7-T8-B-B1-EFI-48-48-30	SERIES 90	S90-042PV
516061	PUMP-VAR-DISPL CW 90PV042	90R042-CA-5-NN-80-S-7-C3-C-00-EEG-42-42-32	SERIES 90	S90-042PV
516064	PUMP-VAR-DISPL CW 90PV055	90-R-055-CA-5-NN-60-S-7-C6-C-00-EEG-42-42-32	SERIES 90	S90-055PV
516065	PUMP-VAR-DISPL CCW 90PV055	90-L-055-CA-5-NN-60-S-7-C6-C-33-EEG-42-42-32	SERIES 90	S90-055PV
516066	PUMP-VAR-DISPL CW 90PV075	90R075-CA-5-NN-60-S-7-C7-D-00-EEG-42-42-32	SERIES 90	S90-075PV
516068	PUMP-VAR-DISPL CW 90PV100	90R100-CA-5-NN-60-S-7-C7-E-00-EEG-42-42-32	SERIES 90	S90-100PV
516071	PUMP-VAR-DISPL CW 90PV130	90R130-CA-5-NN-80-S-7-C8-F-00-EEG-42-42-32	SERIES 90	S90-130PV
516085	PUMP-VAR-DISPL CCW 90PV075	90L075-CA-5-NN-60-S-7-C6-D-00-GLA-42-42-30	SERIES 90	S90-075PV
516086	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-CD-80-S-3-F1-H-03-GBA-29-29-24	SERIES 90	S90-130PV
516087	PUMP-VAR-DISPL CW 90PV180	90R180-MB-5-BB-80-T-3-F1-J-C5-NNN-42-42-24	SERIES 90	S90-180PV
516090	PUMP-VAR-DISPL CCW 90PV130	90L130-MA-5-BB-80-P-3-C8-F-C6-GBA-42-42-24	SERIES 90	S90-130PV
516091	PUMP-VAR-DISPL CW 90PV042	90R042-MB-5-BB-80-R-3-C3-C-C5-GBA-35-35-24	SERIES 90	S90-042PV
516099	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-BC-80-S-3-C8-J-05-NNN-42-42-24	SERIES 90	S90-180PV
516103	MOTOR-FIXED-DISPL 90MF130	90-M-130-NC-0-N-8-N-0-F1-W-00-GBG-00-00-G3	SERIES 90	S90-130MF
516130	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-NN-80-L-3-F1-F-03-GBA-42-42-34	SERIES 90	S90-100PV

516167	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D3-N-E2-B1-N-N-U1-ADA-032-AA-E6-00-00	SERIES 51	S51-080MV-1
516189	MOTOR-VAR-DISPL 51MD080	51D080-R-D2-N-JA-NN-B-E-K3-NNN-034-AA-NN-09-32	SERIES 51	S51-080MV
516193	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-NN-60-P-3-C7-E-02-GBA-26-26-24	SERIES 90	S90-100PV
516210	MOTOR-FIXED-DISPL 90MF100	90-M-100-NC-0-N-8-N-0-K3-W-00-NNN-00-00-F3	SERIES 90	S90-100MF
516213	MOTOR-VAR-DISPL 51MC080	51C080-R-D2-N-N2-NN-N-N-A0-ADA-016-AA-E6-00-00	SERIES 51	S51-080MV
516251	MOTOR-VAR-DISPL 51MD110	51D110-A-D4-N-L2-B1-V-A-J1-ADA-043-AA-F0-B2-00	SERIES 51	S51-110MV
516284	PUMP-VAR-DISPL CW 90PV042	90R042-DC-5-NN-80-D-4-C3-N-Z1-GBA-42-42-26	SERIES 90	S90-042PV
516302	PLNIACE CERPADLO R		SERIES 20	PARTS - S20 - Unique
516311	PUMP-VAR-DISPL CCW 90PV042	90L042-KA-2-BC-80-P-4-C3-B-04-GBA-29-29-24	SERIES 90	S90-042PV
516312	MOTOR-FIXED-DISPL 90MF130	90-M-130-NC-0-N-8-N-0-C8-W-00-NNN-00-00-F0	SERIES 90	S90-130MF
516313	PUMP-VAR-DISPL CCW 90PV130	90L130-PB-5-NN-80-L-3-C8-H-03-GBA-42-42-30	SERIES 90	S90-130PV
516314	MOTOR-VAR-DISPL 51MV110	51V110-R-C8-N-L2-B1-V-A-J1-ADA-043-AA-F0-B2-00	SERIES 51	S51-110MV
516320	PUMP-VAR-DISPL CW 90PV075	90R075-NA-2-BB-60-S-3-C6-D-02-FAB-42-42-24	SERIES 90	S90-075PV
516321	PUMP-VAR-DISPL CW 90PV075	90R075-NA-2-BC-60-S-3-C6-D-02-FAB-42-42-24	SERIES 90	S90-075PV
516325	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-NN-80-S-7-C7-E-09-FAW-35-35-30	SERIES 90	S90-100PV
516341	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-S1-N-N1-NN-N-N-U1-ACE-050-AA-F0-00-00	SERIES 51	S51-080MV-1
516343	PUMP-VAR-DISPL MPV046	MPV-046-C-B-A-A-S-A-T-BC-A-A-BHH-AU-U-CD-C-NNN	M46	M46-046PV
516347	PUMP-VAR-DISPL CW 90PV130	90R130-CB-5-AB-80-S-4-F1-F-00-GBA-35-35-24	SERIES 90	S90-130PV
516360	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-NN-60-R-4-C7-E-04-FAL-35-35-20	SERIES 90	S90-100PV
516361	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-CD-80-L-3-F1-F-26-GBA-42-42-30	SERIES 90	S90-130PV
516375	MOTOR-VAR-DISPL 51MD160	51D160-A-D4-N-D7-M1-S-K-M4-ADA-032-AA-E4-F4-30	SERIES 51	S51-160MV
516381	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-N-E1-A5-A-N-G0-ACD-058-AA-G0-03-00	SERIES 51	S51-160MV
516394	MOTOR-VAR-DISPL 51MD080-1	51D080-1--A-D2-N-T7-D7-N-N-X1-NNN-019-AA-F0-00-23	SERIES 51	S51-080MV-1
516395	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-HZ-B1-B-E-C2-NNN-040-AA-E6-08-00	SERIES 51	S51-160MV
516404	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-CD-80-D-C-C8-L-03-FAC-40-40-22	SERIES 90	S90-180PV
516406	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D3-N-B7-B3-N-N-U3-ADA-023-AA-H0-00-00	SERIES 51	S51-080MV-1
5164105	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-HZ-B1-B-H-G5-NNN-070-AA-G0-08-00	SERIES 51	S51-160MV
5164128	MOTOR-VAR-DISPL 51MV160	51V160-R-F2-N-E1-A5-A-N-G0-NNN-075-AA-F0-03-00	SERIES 51	S51-160MV
5164136	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-T2-C2-L-N-G0-NNN-080-AA-F0-00-B5	SERIES 51	S51-160MV
5164190	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-W-HS-A2-B-H-W4-NNN-063-AA-A0-10-28	SERIES 51	S51-160MV
5164201	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-EQ-A2-J-Z-K4-NNN-088-AA-F3-15-34	SERIES 51	S51-160MV
516422	MOTOR-VAR-DISPL 51MD110-1	51D110-1--H-D4-N-B7-B3-N-N-U3-ADH-032-AA-F3-00-00	SERIES 51	S51-110MV-1
5164246	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-TA-C2-L-N-G0-NNN-063-AA-G0-00-A8	SERIES 51	S51-160MV
5164257	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-N-N2-NN-N-N-A0-ABA-032-AA-NN-00-00	SERIES 51	S51-160MV
5164260	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-TA-C2-L-N-G0-NNN-043-AA-F3-00-C6	SERIES 51	S51-160MV
5164261	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-E1-A5-A-N-G0-NNN-049-AA-F0-03-00	SERIES 51	S51-160MV

5164264	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-N-HZ-B1-A-N-G0-ACA-032-AA-F3-03-00	SERIES 51	S51-160MV
5164267	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-L7-B1-W-B-G5-ABA-079-AA-F3-D4-00	SERIES 51	S51-160MV
5164270	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-N-F2-A5-A-N-G0-ACA-089-AA-G0-03-00	SERIES 51	S51-160MV
516428	MOTOR-VAR-DISPL 51MC060-1	51C060-1--H-D1-N-B7-B3-N-N-U3-ADJ-017-AA-E6-00-00	SERIES 51	S51-060MV-1
5164282	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-T1-C0-L-N-K7-NNN-084-AA-F3-00-B3	SERIES 51	S51-160MV
5164288	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-T1-C0-L-N-G0-ACA-048-AA-F0-00-B7	SERIES 51	S51-160MV
5164292	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-N-TH-C2-L-N-K4-ABA-032-AA-F3-00-B8	SERIES 51	S51-160MV
5164293	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-H1-A5-B-E-G5-NNN-070-AA-F3-08-00	SERIES 51	S51-160MV
5164294	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-HZ-B1-B-N-C2-NNN-115-AA-F3-06-00	SERIES 51	S51-160MV
5164295	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-HZ-B1-A-N-G0-ABA-034-AA-F0-03-00	SERIES 51	S51-160MV
5164296	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-N-HZ-B1-A-N-G0-NNN-047-AA-F3-03-00	SERIES 51	S51-160MV
5164297	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-EQ-A5-J-Y-G5-NNN-032-AA-F0-15-00	SERIES 51	S51-160MV
5164298	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-T1-C2-L-N-G0-NNN-060-AA-G0-00-C7	SERIES 51	S51-160MV
5164299	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-HZ-B1-C-H-C2-NNN-032-AA-F3-15-00	SERIES 51	S51-160MV
5164301	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-T1-C0-L-N-K7-NNN-078-AA-F3-00-B9	SERIES 51	S51-160MV
5164305	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-E2-A5-A-N-G0-NNN-065-AA-F0-03-00	SERIES 51	S51-160MV
5164306	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-N-E1-A5-A-N-G0-ACD-076-AA-F3-03-00	SERIES 51	S51-160MV
5164307	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-TA-C2-L-N-G0-NNN-036-AA-G0-00-B6	SERIES 51	S51-160MV
5164308	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-T1-C2-L-N-K7-NNN-065-AA-F3-00-B4	SERIES 51	S51-160MV
5164309	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-T1-C2-L-N-K7-NNN-050-AA-F3-00-B2	SERIES 51	S51-160MV
5164310	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-E1-A5-A-N-G0-NNN-107-AA-F0-03-00	SERIES 51	S51-160MV
5164312	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-T2-C0-L-N-G0-NNN-078-AA-G0-00-B9	SERIES 51	S51-160MV
5164313	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-TA-C2-L-N-G0-NNN-078-AA-F0-00-B1	SERIES 51	S51-160MV
5164314	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-T1-C2-L-N-K7-NNN-050-AA-G0-00-B5	SERIES 51	S51-160MV
5164315	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-T1-C0-L-N-G0-NNN-098-AA-G0-00-B8	SERIES 51	S51-160MV
5164316	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-EQ-R4-K-Y-C7-NNN-063-AA-G3-75-31	SERIES 51	S51-160MV
5164317	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-HZ-B1-A-N-G0-NNN-107-AA-F0-03-00	SERIES 51	S51-160MV
5164319	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-T1-C2-L-N-G0-NNN-040-AA-G0-00-B8	SERIES 51	S51-160MV
5164320	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-TH-C2-L-N-G0-NNN-080-AA-F0-00-C1	SERIES 51	S51-160MV
5164324	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-T1-C0-L-N-K7-NNN-084-AA-G3-00-C2	SERIES 51	S51-160MV
5164326	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-HZ-B1-B-E-G0-NNN-067-AA-G0-10-00	SERIES 51	S51-160MV
516433	PUMP-VAR DISPL, CCW 90PV130	90L130-MA-5-BC-80-R-3-C8-H-C5-GBA-42-42-24	SERIES 90	S90-130PV
5164332	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-N-HZ-B1-A-N-G0-ACA-065-AA-G0-03-00	SERIES 51	S51-160MV
5164334	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-N-F2-A5-A-N-G0-ACA-045-AA-G0-03-00	SERIES 51	S51-160MV
516434	MOTOR-VAR-DISPL 51MV110	51V110-A-F1-N-E2-A5-A-N-A6-ADA-036-AA-E6-03-00	SERIES 51	S51-110MV
5164349	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-E1-A5-A-N-G0-NNN-080-AA-F0-03-00	SERIES 51	S51-160MV

5164353	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-N2-NN-N-N-A0-ABA-032-AA-NN-00-00	SERIES 51	S51-160MV
5164356	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-TA-C2-L-N-G0-NNN-057-AA-F0-00-B1	SERIES 51	S51-160MV
516436	MOTOR-VAR-DISPL 51MV110	51V110-A-F1-N-E2-A5-A-N-A6-NNN-036-AA-E6-03-00	SERIES 51	S51-110MV
5164360	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-HS-A2-B-E-G6-NNN-070-AA-H0-08-37	SERIES 51	S51-160MV
5164362	MOTOR-VAR DISPL 51MV160	51V160-R-F1-N-TA-C2-L-N-G0-NNN-060-AA-F0-00-B6	SERIES 51	S51-160MV
5164363	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-HZ-B1-A-N-G0-NNN-080-AA-NN-03-00	SERIES 51	S51-160MV
5164364	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-T1-C0-L-N-G0-NNN-084-AA-G3-00-C2	SERIES 51	S51-160MV
5164366	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-E1-A5-A-N-G0-NNN-065-AA-F3-03-00	SERIES 51	S51-160MV
5164373	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-EQ-A2-J-Y-G6-ABA-032-AA-F0-15-28	SERIES 51	S51-160MV
5164375	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-T2-C0-L-N-K7-NNN-107-AA-F3-00-C0	SERIES 51	S51-160MV
5164377	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-N-TH-C2-L-N-K4-ABA-M32-AA-F0-00-B8	SERIES 51	S51-160MV
5164379	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-N-HS-A2-B-V-N8-ABA-M32-AA-F0-07-28	SERIES 51	S51-160MV
5164380	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-EQ-A5-J-Z-G5-ABA-035-AA-F3-15-00	SERIES 51	S51-160MV
5164381	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-E1-A5-A-N-G0-NNN-050-AA-F0-03-00	SERIES 51	S51-160MV
5164385	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-HZ-B1-A-N-G0-NNN-050-AA-G3-03-00	SERIES 51	S51-160MV
5164387	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-HZ-B1-A-N-C2-NNN-115-AA-G0-03-00	SERIES 51	S51-160MV
5164388	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-HZ-B1-A-N-C2-NNN-035-AA-G0-03-00	SERIES 51	S51-160MV
5164390	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-HZ-B1-B-E-C2-NNN-090-AA-F0-06-00	SERIES 51	S51-160MV
5164391	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-E1-A5-A-N-K7-NNN-080-AA-H0-03-00	SERIES 51	S51-160MV
5164392	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-L2-B1-V-A-C0-ANA-032-AA-G0-B2-00	SERIES 51	S51-160MV
5164396	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-T1-C0-L-N-K7-NNN-091-AA-G3-00-C2	SERIES 51	S51-160MV
516440	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-CD-60-S-3-C6-D-06-GBA-42-42-20	SERIES 90	S90-075PV
5164404	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-TA-C2-L-N-K7-NNN-080-AA-G0-00-A4	SERIES 51	S51-160MV
516444	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-N-B7-B3-N-N-U3-ABA-036-AA-F3-00-00	SERIES 51	S51-060MV-1
516447	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-BB-60-S-4-C7-D-21-GBA-45-45-24	SERIES 90	S90-100PV
516449	MOTOR-FIXED-DISPL 20MF119	SMF2/119--B3P-AM08000-A1	SERIES 20	S20-119MF
516451	MOTOR-FIXED-DISPL 20MF166	SMF2/166--B6F-MS3535X-449-A1	SERIES 20	S20-166MF
516452	MOTOR-FIXED-DISPL 20MF227	SMF2/227--B6F-MS3838X-476-A1	SERIES 20	S20-227MF
516454	PUMP-VAR-DISPL CCW 20PV334	SPV2/334--L6S-PS66X-268-A1	SERIES 20	S20-334PV
516469	PUMP-VAR-DISPL CCW 90PV042	90L042-KA-5-BB-80-S-3-C3-B-03-GBA-26-26-24	SERIES 90	S90-042PV
516470	PUMP-VAR-DISPL CCW 90PV042	90L042-DD-5-BB-80-S-3-C5-B-50-GBA-38-38-24	SERIES 90	S90-042PV
516471	PUMP-VAR-DISPL CCW 90PV042	90L042-KA-5-BC-80-S-3-C3-B-03-GBA-29-29-24	SERIES 90	S90-042PV
5164828	MOTOR-VAR-DISPL 51MC160	51C160-R-D5-N-HZ-B1-A-N-G0-ABA-060-AA-G0-03-00	SERIES 51	S51-160MV
5164829	MOTOR-VAR-DISPL 51MC160	51C160-R-D5-N-E2-A5-A-N-G0-ABA-107-AA-G0-03-00	SERIES 51	S51-160MV
516504	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-N-B2-B3-N-N-U3-ADA-036-AA-NN-00-00	SERIES 51	S51-060MV-1
516507	MOTOR-VAR-DISPL 51MC110-1	51C110-1--R-D3-N-B2-B3-N-N-U3-ADA-030-AA-H0-00-00	SERIES 51	S51-110MV-1

516508	PUMP-VAR-DISPL MPV046	MPV-046-C-B-B-A-S-A-M-BC-X-A-BJJ-DB-A-HH-C-NNR	M46	M46-046PV
516514	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-D8-M1-R-J-M1-ADA-060-AA-G3-C2-27	SERIES 51	S51-160MV
516516	MOTOR-FIXED-DISPL 90MF075	90-M-075-NC-0-N-8-N-0-C6-W-00-EFA-00-00-F3	SERIES 90	S90-075MF
516529	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-C-T1-L5-L-N-G0-NNN-092-AA-C0-00-B8	SERIES 51	S51-160MV
516530	MOTOR-VAR-DISPL 51MV110-1	51V110-1--A-F1-B-T1-L5-N-N-X1-NNN-070-AA-B3-00-28	SERIES 51	S51-110MV-1
516552	MOTOR-VAR-DISPL 51MV060-1	51V060-1--R-C6-N-E1-B1-N-N-U1-NNN-018-AA-F0-00-00	SERIES 51	S51-060MV-1
516554	PUMP-VAR-DISPL CCW 90PV042	90L042-EA-1-BB-80-L-3-C3-B-03-GBA-32-32-20	SERIES 90	S90-042PV
516595	PUMP-VAR-DISPL CW 90PV075	90R075-DC-5-BB-60-S-4-S1-E-GF-GBA-38-38-24	SERIES 90	S90-075PV
516628	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-S1-N-E2-B1-N-N-U1-NNN-040-AA-F0-00-00	SERIES 51	S51-080MV-1
516629	MOTOR-VAR-DISPL 51MD160	51D160-R-D4-N-E2-A2-A-N-G1-NNN-080-AA-F3-03-25	SERIES 51	S51-160MV
516651	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-BB-60-L-3-C7-C-C1-FAD-42-42-28	SERIES 90	S90-075PV
516661	MOTOR-FIXED-DISPL 20MF227	SMF2/227--B6F-MS3535X-449-A1	SERIES 20	S20-227MF
516662	MOTOR-FIXED-DISPL 20MF334	SMF2/334--B6S-MS3535X-449-A1	SERIES 20	S20-334MF
516667	MOTOR-FIXED-DISPL 20MF119	SMF2/119--B3F-MS3131X-449-A1	SERIES 20	S20-119MF
516668	MOTOR-FIXED-DISPL 20MF119	SMF2/119--B3F-MS3535X-478-A1	SERIES 20	S20-119MF
516669	PUMP-VAR-DISPL CW 20PV334	SPV2/334--R6S-PS66X-268-A1	SERIES 20	S20-334PV
516718	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-NN-60-S-3-C7-E-03-FAB-42-42-24	SERIES 90	S90-100PV
516777	PUMP-VAR-DISPL CW 90PV130	90R130-MA-5-NN-80-L-3-C8-H-00-GBA-42-42-24	SERIES 90	S90-130PV
516784	MOTOR-VAR-DISPL 51MD060	51D060-R-D2-N-HS-A3-C-E-B9-NNN-039-AA-F0-20-21	SERIES 51	S51-060MV
516785	PUMP-VAR-DISPL CCW 90PV042	90L042-HK-5-BB-80-D-3-C3-L-03-FAD-42-42-24	SERIES 90	S90-042PV
516788	MOTOR-VAR-DISPL 51MD110-1	51D110-1--R-D4-N-E1-B1-N-N-U2-NNN-035-AA-F3-00-00	SERIES 51	S51-110MV-1
516801	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-L7-B1-W-B-G0-ADA-058-AA-A3-D4-00	SERIES 51	S51-160MV
516867	MOTOR-VAR-DISPL 51MC110-1	51C110-1--R-D3-N-E2-B1-N-N-U1-ACB-050-AA-E6-00-00	SERIES 51	S51-110MV-1
516868	MOTOR-VAR-DISPL 51MD110-1	51D110-1--R-D3-N-E2-B1-N-N-U1-NNN-050-AA-E6-00-00	SERIES 51	S51-110MV-1
516877	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-BC-80-S-4-C8-H-01-GBA-42-42-24	SERIES 90	S90-130PV
516886	MOTOR-FIXED-DISPL 90MF130	90-M-130-NC-0-N-8-N-0-C8-W-00-EEA-00-00-G3	SERIES 90	S90-130MF
516918	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-NN-80-R-3-F1-H-03-GBA-42-42-24	SERIES 90	S90-130PV
516925	MOTOR-FIXED-DISPL 20MF227	SMF2/227--B6F-AM08000-XCX-A1	SERIES 20	S20-227MF
516940	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-C8-E-B1-B3-N-N-U3-DBA-053-AA-A3-00-00	SERIES 51	S51-110MV-1
516964	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-C8-E-B1-B3-N-N-U3-DBA-030-AA-A3-00-00	SERIES 51	S51-110MV-1
516967	MOTOR-VAR-DISPL 51MV110	51V110-R-C8-N-L7-B1-W-B-G0-ADA-030-AA-F3-D4-00	SERIES 51	S51-110MV
516975	PUMP-VAR-DISPL CW 90PV100	90R100-PB-5-CD-80-L-4-C7-E-00-GBA-26-35-24-F003	SERIES 90	S90-100PV
516984	PUMP-VAR-DISPL CW 90PV075	90R075-PB-5-CP-80-L-4-S1-E-00-GBA-30-30-24-F003	SERIES 90	S90-075PV
516985	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-BC-80-L-4-C8-H-21-GDA-45-45-28	SERIES 90	S90-130PV
516986	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-J3-K3-B-H-J5-NNN-062-BB-G3-07-36	SERIES 51	S51-160MV
516991	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-CD-80-P-3-C7-E-03-FAS-42-42-20	SERIES 90	S90-100PV

517012	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-BC-60-S-3-C7-D-04-GBA-42-42-24	SERIES 90	S90-075PV
517013	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-N-E2-A5-A-N-G0-NNN-060-AA-F3-03-00	SERIES 51	S51-250MV
517017	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-AB-80-S-3-C8-H-04-GBA-45-45-24	SERIES 90	S90-130PV
517034	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-J3-K3-B-H-J5-NNN-080-BB-G3-07-36	SERIES 51	S51-160MV
517048	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-CD-80-S-3-C7-F-04-GBA-42-42-28	SERIES 90	S90-100PV
517077	PUMP-VAR-DISPL CW 90PV250	90R250-DD-5-NN-80-S-3-C8-J-G1-NNN-35-35-28	SERIES 90	S90-250PV
517079	MOTOR-VAR-DISPL 51MD080-1	51D080-1--A-D2-N-T7-D7-N-N-X1-NNN-020-AA-F0-00-23	SERIES 51	S51-080MV-1
517141	MOTOR-VAR-DISPL 51MD160	51D160-R-D4-E-L7-B1-W-B-G0-ADA-038-AA-H0-D4-00	SERIES 51	S51-160MV
517147	PUMP-VAR-DISPL CCW 90PV130	90L130-CB-5-AB-80-R-4-F1-F-00-GBA-35-35-24	SERIES 90	S90-130PV
517159	PUMP-VAR-DISPL CW 90PV250	90R250-HS-5-NN-80-S-3-C8-K-03-NNN-42-42-28	SERIES 90	S90-250PV
517165	MOTOR-VAR-DISPL 51MV160	51V160-A-C8-N-D8-M1-R-J-M4-ADA-058-AA-G3-C2-25	SERIES 51	S51-160MV
517166	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-BB-60-S-3-C7-D-04-FAD-29-29-20	SERIES 90	S90-075PV
517178	PUMP-VAR-DISPL CW 90PV100	90R100-RS-5-CD-80-S-3-C7-F-03-GBA-42-42-24	SERIES 90	S90-100PV
517206	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-S1-N-E2-B1-N-N-U1-NNN-030-AA-E6-00-00	SERIES 51	S51-080MV-1
517207	PUMP-VAR-DISPL CW 90PV100	90R100-HF-5-CD-60-S-3-F1-E-00-GBA-42-42-30	SERIES 90	S90-100PV
517232	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-BC-80-S-3-C7-E-35-EFD-42-42-24	SERIES 90	S90-075PV
517238	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-D8-M1-R-J-N1-NNN-134-AA-G3-C2-30	SERIES 51	S51-250MV
517244	MOTOR-FIXED-DISPL 90MF100	90-M-100-NC-0-N-7-N-0-C7-W-00-NNN-00-00-B3	SERIES 90	S90-100MF
517246	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-NN-80-S-4-C6-C-03-FAD-29-29-20	SERIES 90	S90-075PV
517255	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-NN-80-L-3-C8-H-03-EFC-42-42-24	SERIES 90	S90-130PV
517280	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-HZ-B1-B-H-G5-ABA-050-AA-G3-07-00	SERIES 51	S51-250MV
517305	MOTOR-VAR-DISPL 51MV080	51V080-A-C7-N-J1-K1-D-N-H4-NNN-028-AA-F0-20-22	SERIES 51	S51-080MV
517316	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-AB-60-S-3-C7-E-03-FAB-42-42-24	SERIES 90	S90-100PV
517322	MOTOR-VAR-DISPL 51MD080-1	51D080-1--R-D3-N-E2-B1-N-N-U1-NNN-040-AA-E6-00-00	SERIES 51	S51-080MV-1
517323	MOTOR-VAR-DISPL 51MD110-1	51D110-1--R-D3-N-E2-B1-N-N-U1-NNN-040-AA-E6-00-00	SERIES 51	S51-110MV-1
517324	MOTOR-VAR-DISPL 51MC110-1	51C110-1--R-D3-N-E2-B1-N-N-U1-ACB-040-AA-E6-00-00	SERIES 51	S51-110MV-1
517325	MOTOR-VAR-DISPL 51MC110-1	51C110-1--R-D3-N-E2-B1-N-N-U1-ACB-035-AA-E6-00-00	SERIES 51	S51-110MV-1
517327	PUMP-VAR-DISPL CCW 90PV100	90L100-MA-5-CD-80-S-3-C7-E-04-GBS-42-42-24	SERIES 90	S90-100PV
517337	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-CD-60-L-3-C7-D-21-FAD-42-42-28	SERIES 90	S90-100PV
517368	MOTOR-VAR-DISPL 51MD110	51D110-A-D4-N-L1-B2-W-B-H7-ADA-022-AA-G0-D4-00	SERIES 51	S51-110MV
517385	PUMP-VAR-DISPL CW 90PV075	90R075-RS-5-CD-80-S-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-075PV
517386	PUMP-VAR-DISPL CW 90PV130	90R130-RS-5-CD-80-S-3-C8-H-03-GBA-42-42-24	SERIES 90	S90-130PV
517387	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-C8-N-T2-D2-N-N-X1-ADA-045-AA-F3-00-21	SERIES 51	S51-110MV-1
517393	MOTOR-VAR-DISPL 51MV080	51V080-R-C7-N-H2-A2-B-E-E1-ABA-050-AA-F3-10-25	SERIES 51	S51-080MV
517404	MOTOR-VAR-DISPL 51MD080-1	51D080-1--R-D3-N-B7-B3-N-N-U3-ADA-045-AA-F0-00-00	SERIES 51	S51-080MV-1
517412	PUMP-VAR-DISPL CW 90PV075	90R075-MA-5-BC-60-S-3-C7-D-C5-FAB-42-42-24	SERIES 90	S90-075PV

517413	PUMP-VAR-DISPL CW 90PV100	90R100-NA-7-BC-60-S-4-D7-E-03-FAX-45-45-28	SERIES 90	S90-100PV
517416	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-CD-80-L-3-C7-F-03-GBA-42-42-28	SERIES 90	S90-100PV
517422	MOTOR-VAR-DISPL 51MC080	51C080-R-D2-N-E1-A2-A-N-E1-NNN-026-AA-E6-03-37	SERIES 51	S51-080MV
517455	PUMP-VAR-DISPL CW 90PV100	90R100-FH-5-CD-60-P-7-C7-F-BB-GBS-42-42-28	SERIES 90	S90-100PV
517461	PUMP-VAR-DISPL CCW 90PV130	90L130-MA-5-NN-80-S-3-C8-H-C6-GBA-42-42-20	SERIES 90	S90-130PV
517476	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-B-N2-NN-N-N-A0-NNN-140-AA-H0-00-00	SERIES 51	S51-250MV
517547	MOTOR-VAR-DISPL 51MV110	51V110-R-C8-N-L2-B1-V-A-J2-AHA-022-AA-F0-B2-00	SERIES 51	S51-110MV
517548	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-L2-B1-V-A-J2-AHA-032-AA-F3-B2-00	SERIES 51	S51-160MV
517549	MOTOR-VAR-DISPL 51MD080-1	51D080-1--H-D3-N-B7-B3-N-N-U3-ADJ-023-AA-F0-00-00	SERIES 51	S51-080MV-1
517570	PUMP-VAR-DISPL CCW 90PV130	90L130-CA-5-BC-80-S-3-C8-F-00-GBA-20-20-30	SERIES 90	S90-130PV
517575	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-NN-80-T-3-C8-J-03-NNN-42-42-24	SERIES 90	S90-180PV
517576	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-NN-80-L-3-C8-H-03-GBA-42-42-24	SERIES 90	S90-130PV
517577	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-NN-80-L-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
517578	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-NN-80-P-4-C7-D-03-GBA-42-42-24	SERIES 90	S90-075PV
517585	MOTOR-VAR-DISPL 51MD080-1	51D080-1--H-D3-N-B7-B3-N-N-U3-AKA-032-AA-F0-00-00	SERIES 51	S51-080MV-1
517587	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-2-BB-60-S-4-C7-D-21-GBA-45-45-24	SERIES 90	S90-075PV
517594	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-AB-80-P-3-C8-F-04-GBA-35-35-24	SERIES 90	S90-130PV
517600	MOTOR-FIXED-DISPL 90MF075	90-M-075-NC-0-N-8-N-0-C7-W-00-NNN-00-00-F3	SERIES 90	S90-075MF
517602	MOTOR-FIXED-DISPL 90MF100	90-M-100-NC-0-N-8-N-0-C7-W-00-NNN-00-00-F0	SERIES 90	S90-100MF
517603	MOTOR-FIXED-DISPL 90MF100	90-M-100-NC-0-N-8-N-0-C7-W-00-NNN-00-00-H0	SERIES 90	S90-100MF
517606	MOTOR-FIXED-DISPL 90MF130	90-M-130-NC-0-N-8-N-0-C8-W-00-NNN-00-00-G0	SERIES 90	S90-130MF
517614	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-B-E2-B1-N-N-U1-ACG-018-AA-E4-00-00	SERIES 51	S51-060MV-1
517633	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-C8-N-T1-L5-N-N-X1-NNN-080-AA-H0-00-35	SERIES 51	S51-110MV-1
517634	MOTOR-VAR-DISPL 51MD110-1	51D110-1--R-D4-N-B7-B3-N-N-U3-NNN-040-AA-F0-00-00	SERIES 51	S51-110MV-1
517635	MOTOR-VAR-DISPL 51MD110-1	51D110-1--R-D3-B-B7-B3-N-N-U3-ADA-036-AA-F0-00-00	SERIES 51	S51-110MV-1
517636	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-N-B7-B3-N-N-U3-NNN-033-AA-F0-00-00	SERIES 51	S51-060MV-1
517637	PUMP-VAR-DISPL CW 90PV100	90R100-MA-5-AB-60-S-3-C7-E-C5-FAX-42-42-24	SERIES 90	S90-100PV
517640	MOTOR-VAR-DISPL 51MC160	51C160-R-D5-N-N2-NN-N-N-A0-NNN-092-AA-H0-00-00	SERIES 51	S51-160MV
517641	MOTOR-VAR-DISPL 51MC080	51C080-R-D2-N-N2-NN-N-N-A0-NNN-038-AA-F3-00-00	SERIES 51	S51-080MV
517643	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-BR-80-D-3-C7-S-42-FAD-40-40-22	SERIES 90	S90-075PV
517644	PUMP-VAR-DISPL CCW 90PV042	90L042-DD-5-BC-80-S-3-C3-B-50-GBA-42-42-24	SERIES 90	S90-042PV
517648	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-CD-80-S-3-C7-E-03-FAP-38-38-24	SERIES 90	S90-075PV
517652	PUMP-VAR-DISPL CCW 90PV100	90L100-HF-5-NN-60-S-3-C7-E-03-GBA-32-32-24	SERIES 90	S90-100PV
517655	PUMP-VAR-DISPL CW 90PV100	90R100-FD-5-NN-60-P-7-C7-F-B1-EFI-38-38-28	SERIES 90	S90-100PV
517657	PUMP-VAR-DISPL CW 90PV130	90R130-MB-5-NN-80-L-3-C8-H-C5-GBA-42-42-24	SERIES 90	S90-130PV
517679	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-NN-80-D-4-C3-N-02-GBA-42-42-26	SERIES 90	S90-042PV

517686	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-AB-60-S-4-C7-E-03-FAB-42-42-24	SERIES 90	S90-100PV
517687	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-CD-80-S-3-C8-H-03-GBA-42-42-24	SERIES 90	S90-130PV
517702	MOTOR-VAR-DISPL 51MC110-1	51C110-1--R-D3-N-E2-B1-N-N-U1-NNN-040-AA-E6-00-00	SERIES 51	S51-110MV-1
517712	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-N-B2-B3-N-N-U3-ADA-024-AA-NN-00-00	SERIES 51	S51-060MV-1
517713	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-NN-80-L-3-C7-D-03-GBA-32-32-28	SERIES 90	S90-075PV
517726	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-NN-80-T-4-C8-J-03-NNN-35-35-24	SERIES 90	S90-180PV
517735	MOTOR-VAR-DISPL 51MD110	51D110-A-D3-N-L7-B1-W-B-J1-NNN-040-AA-F0-D4-00	SERIES 51	S51-110MV
517740	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-N-JA-NN-B-H-K3-NNN-050-AA-G3-07-35	SERIES 51	S51-250MV
517742	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-D8-M1-R-J-M1-ADA-062-AA-F3-C2-32	SERIES 51	S51-160MV
517812	PUMP-VAR-DISPL CW 90PV130	90R130-FH-5-BC-80-P-7-C8-F-B1-EFI-42-42-30	SERIES 90	S90-130PV
517825	MOTOR-VAR-DISPL 51MC110-1	51C110-1--R-D3-N-E2-B1-N-N-U1-NNN-050-AA-E6-00-00	SERIES 51	S51-110MV-1
517826	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-1-CD-80-S-3-C7-C-64-GCB-26-26-18	SERIES 90	S90-075PV
517865	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-1-AB-80-S-3-C8-J-04-EEB-38-38-28	SERIES 90	S90-250PV
517903	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-NN-60-S-3-C7-F-03-GBA-35-35-20	SERIES 90	S90-100PV
517909	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-AB-80-S-4-C7-D-03-GBA-32-32-24	SERIES 90	S90-075PV
517910	MOTOR-VAR-DISPL 51MC110	51C110-R-D3-N-TA-C2-L-N-G0-NNN-040-AA-F0-00-A3	SERIES 51	S51-110MV
517913	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-AB-80-P-3-C7-E-02-GBA-42-42-24	SERIES 90	S90-100PV
517949	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-N-B7-B3-N-N-U3-ADA-017-AA-F0-00-00	SERIES 51	S51-060MV-1
517954	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-N-B7-B3-N-N-U3-ADA-021-AA-F0-00-00	SERIES 51	S51-060MV-1
517974	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-BC-80-S-3-C8-H-03-GBA-26-26-24	SERIES 90	S90-130PV
517975	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-AB-80-S-3-C8-H-03-GBA-26-26-24	SERIES 90	S90-130PV
518030	PUMP-VAR-DISPL CW 90PV075	90R075-MA-1-NN-60-S-3-C7-D-03-GBA-26-26-24	SERIES 90	S90-075PV
518031	MOTOR-VAR-DISPL 51MV060-1	51V060-1--A-C6-N-TA-C2-N-N-X1-NNN-025-AA-E6-00-18	SERIES 51	S51-060MV-1
518039	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-BB-80-S-3-C3-L-03-GBA-45-45-28	SERIES 90	S90-042PV
518045	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-BC-80-R-3-C8-F-03-GBA-29-29-24	SERIES 90	S90-130PV
518108	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-S1-N-E2-B1-N-N-U1-ACB-030-AA-E4-00-00	SERIES 51	S51-080MV-1
518109	MOTOR-VAR-DISPL 51MD060-1	51D060-1--R-D2-N-E2-B1-N-N-U1-NNN-025-AA-E4-00-00	SERIES 51	S51-060MV-1
518115	PUMP-VAR-DISPL CW 90PV100	90R100-FC-5-BC-80-P-7-C7-E-B1-EFD-42-42-30	SERIES 90	S90-100PV
518117	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-EQ-A2-J-Y-G6-ACA-032-AA-F0-15-28	SERIES 51	S51-160MV
518119	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-EQ-A2-J-Y-G6-ACA-050-AA-G0-15-32	SERIES 51	S51-250MV
518127	PUMP-VAR-DISPL CCW 90PV100	90L100-KP-V-NN-8E-L-3-F1-F-03-GB1-42-42-36	SERIES 90	S90-100PV
518156	PUMP-VAR-DISPL CW 90PV130	90R130-MA-5-NN-80-R-3-C8-H-C4-GBA-42-42-24	SERIES 90	S90-130PV
518160	PUMP-VAR-DISPL CW 90PV250	90R250-MA-5-CD-80-S-3-C8-J-C5-NNN-26-26-24	SERIES 90	S90-250PV
518171	MOTOR-FIXED-DISPL 90MF130	90-M-130-NC-O-N-U-N-O-F1-H-00-LAA-00-00-K0	SERIES 90	S90-130MF
518172	MOTOR-FIXED-DISPL 90MF100	90-M-100-NC-O-N-U-N-O-F1-B-00-PAA-00-00-B4	SERIES 90	S90-100MF
518190	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-CD-60-S-3-C7-F-03-GBA-42-42-24	SERIES 90	S90-100PV

518272	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-E2-A5-A-N-G0-NNN-105-AA-G3-03-00	SERIES 51	S51-160MV
518279	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-BB-60-S-3-S1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
518283	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-NN-80-S-3-C6-D-02-FAD-42-42-20	SERIES 90	S90-075PV
518287	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-HZ-B1-B-E-C2-NNN-052-AA-F3-08-00	SERIES 51	S51-160MV
518288	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-CD-80-P-3-C7-E-05-GBA-42-42-24	SERIES 90	S90-100PV
518292	PUMP-VAR-DISPL CW 90PV075	90R075-MA-5-CD-60-P-3-C7-D-C5-GBA-42-42-24	SERIES 90	S90-075PV
518294	PUMP-VAR-DISPL CW 90PV075	90R075-MA-5-AB-60-P-3-S1-D-C5-GBA-30-30-24	SERIES 90	S90-075PV
518295	MOTOR-FIXED-DISPL 90MF130	90-M-130-NC-0-N-8-N-0-C8-W-00-EEA-00-00-G0	SERIES 90	S90-130MF
518296	PUMP-VAR-DISPL CW 90PV130	90R130-CA-5-BC-80-D-3-C8-L-00-GCA-32-32-24	SERIES 90	S90-130PV
518300	PUMP-VAR-DISPL CCW 90PV042	90L042-MA-N-BB-80-P-P-C3-B-02-GBA-BP-42-24-E111	SERIES 90	S90-042PV
518301	PUMP-VAR-DISPL CW 90PV100	90R100-MA-P-BB-60-P-4-D7-F-C5-FAX-48-48-30	SERIES 90	S90-100PV
518302	MOTOR-FIXED-DISPL 90MF075	90-M-075-NC-0-N-8-N-0-C7-W-00-EFA-00-00-F3	SERIES 90	S90-075MF
518307	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-C2-80-S-3-C7-E-00-GBA-42-42-24	SERIES 90	S90-100PV
518312	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-AB-80-L-3-G1-E-03-GBA-42-42-30	SERIES 90	S90-100PV
518313	PUMP-VAR-DISPL CW 90PV075	90R075-NA-1-NN-80-L-3-T6-D-03-GBA-42-42-26	SERIES 90	S90-075PV
518314	PUMP-VAR-DISPL CW 90PV130	90R130-NA-1-NN-80-L-3-T7-F-03-GLA-42-42-30	SERIES 90	S90-130PV
518315	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-CD-80-P-3-C7-E-02-GBA-26-26-24	SERIES 90	S90-075PV
518319	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-BB-80-L-3-C7-F-03-GBA-45-45-28	SERIES 90	S90-100PV
518336	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-BC-80-L-3-C8-H-21-GDA-45-45-28	SERIES 90	S90-130PV
518337	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-E2-A5-A-N-A6-NNN-045-AA-F3-03-00	SERIES 51	S51-160MV
518362	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-NN-80-T-3-C8-J-03-NNN-42-42-28	SERIES 90	S90-180PV
518372	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-CD-60-S-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-100PV
518374	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-BC-60-S-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-100PV
518375	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-CD-80-L-3-C8-H-03-GBA-42-42-28	SERIES 90	S90-130PV
518400	MOTOR-FIXED-DISPL 90MF100	90-M-100-NC-0-N-7-N-0-F1-W-00-NNN-00-00-G0	SERIES 90	S90-100MF
518402	PUMP-VAR-DISPL CCW 90PV042	90L042-DC-5-NN-80-P-3-C3-C-GB-GBA-23-23-24	SERIES 90	S90-042PV
518451	MOTOR-VAR-DISPL 51MD080-1	51D080-1--R-D3-N-E2-B1-N-N-U1-NNN-032-AA-E6-00-00	SERIES 51	S51-080MV-1
518459	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-V-NV-8E-L-3-F4-F-03-GB2-42-42-36	SERIES 90	S90-130PV
518528	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-CD-80-T-4-C8-K-03-NNN-35-35-24	SERIES 90	S90-250PV
518543	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-T1-C2-N-N-X1-ABA-065-AA-F0-00-36	SERIES 51	S51-110MV-1
518552	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-BC-80-S-4-T7-F-04-GBA-42-42-24	SERIES 90	S90-130PV
518558	MOTOR-VAR-DISPL 51MV160	51V160-A-C8-N-J4-K3-B-E-J5-ADA-042-AA-F3-10-37	SERIES 51	S51-160MV
518616	MOTOR-VAR-DISPL 51MD080-1	51D080-1--A-D2-N-T2-D2-N-N-X1-NNN-018-AA-E6-00-30	SERIES 51	S51-080MV-1
518618	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D3-N-B2-B3-N-N-U3-ADA-026-AA-E6-00-00	SERIES 51	S51-080MV-1
518619	PUMP-VAR-DISPL CW 90PV042	90R042-FB-1-BC-80-S-7-C3-B-B1-EFD-42-42-26	SERIES 90	S90-042PV
518620	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D3-N-B2-B3-N-N-U3-ADA-034-AA-E6-00-00	SERIES 51	S51-080MV-1

518623	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-BC-80-R-3-C3-C-02-GBA-42-42-24	SERIES 90	S90-042PV
518624	PUMP-VAR-DISPL CW 90PV100	90R100-KA-P-CD-80-S-3-C7-F-03-GBA-48-48-24	SERIES 90	S90-100PV
518625	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-HS-A1-C-E-A2-NNN-088-AA-F3-20-30	SERIES 51	S51-250MV
518626	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-1-BB-80-S-3-C7-C-02-FAC-42-42-24	SERIES 90	S90-075PV
518652	PUMP-VAR-DISPL CCW 90PV180	90L180-KP-5-NN-80-T-C-F5-H-03-FAC-32-32-24	SERIES 90	S90-180PV
518661	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-C8-N-P8-P8-N-N-X1-ADA-045-AA-F3-00-AA	SERIES 51	S51-110MV-1
518664	BOLZEN 7,62 X 11,05 ANGEFLACHT AUF 3,18		LIGHT DUTY	PARTS - Low Power
518681	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-NN-60-S-4-S1-D-00-GBA-36-36-24	SERIES 90	S90-075PV
518692	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-CD-80-S-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
518693	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-CD-80-S-3-T6-D-03-GBA-42-42-24	SERIES 90	S90-075PV
518699	PUMP-VAR-DISPL CW 90PV042	90R042-KA-P-AB-80-S-3-C3-C-03-GBA-48-48-24	SERIES 90	S90-042PV
518700	PUMP-VAR-DISPL CW 90PV075	90R075-KA-2-BC-60-S-3-C6-D-02-GBA-42-42-24	SERIES 90	S90-075PV
518702	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-E2-A5-A-N-A6-NNN-100-AA-G0-03-00	SERIES 51	S51-160MV
518703	MOTOR-VAR-DISPL 51MD160	51D160-A-D5-N-HZ-B1-B-H-C2-NNN-080-AA-F0-09-00	SERIES 51	S51-160MV
518705	MOTOR-VAR-DISPL 51MD160	51D160-A-D5-N-HZ-B1-B-H-C2-NNN-063-AA-F0-09-00	SERIES 51	S51-160MV
518706	PUMP-VAR-DISPL CW 90PV100	90R100-KA-P-BC-80-S-4-C7-E-02-GBA-48-48-24	SERIES 90	S90-100PV
518707	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-P-AB-60-P-3-C7-D-01-GBA-48-48-24	SERIES 90	S90-075PV
518708	PUMP-VAR-DISPL CW 90PV075	90R075-KA-P-BC-80-P-3-C7-D-02-GBA-48-48-24	SERIES 90	S90-075PV
518709	PUMP-VAR-DISPL CW 90PV075	90R075-KA-P-BC-80-S-4-C7-D-03-GBA-48-48-24	SERIES 90	S90-075PV
518716	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-NN-60-L-3-C7-E-03-GBA-40-40-24	SERIES 90	S90-075PV
518717	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-CD-60-L-3-C7-E-03-GBA-40-40-24	SERIES 90	S90-075PV
518718	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-NN-60-L-3-C7-E-03-GBA-40-40-24	SERIES 90	S90-100PV
518724	MOTOR-VAR-DISPL 51MV110	51V110-R-C8-N-HE-B2-C-E-E6-NNN-052-AA-F3-12-00	SERIES 51	S51-110MV
518726	PUMP-VAR-DISPL CW 90PV075	90R075-MA-5-BC-60-S-3-C6-D-C6-FAX-35-35-24	SERIES 90	S90-075PV
518741	PUMP-VAR-DISPL CW 90PV130	90R130-FG-5-BC-80-P-7-C8-F-B1-EFI-42-42-30	SERIES 90	S90-130PV
518745	PUMP-VAR-DISPL CW 90PV130	90R130-FH-5-DG-80-S-7-C8-F-B1-GBA-42-42-28	SERIES 90	S90-130PV
518747	PUMP-VAR-DISPL CW 90PV130	90R130-FH-5-CD-80-S-7-C8-F-B1-GBA-42-42-28	SERIES 90	S90-130PV
518749	MOTOR-VAR-DISPL 51MV080	51V080-R-C7-N-E1-L4-A-N-E8-NNN-047-AA-F3-03-25	SERIES 51	S51-080MV
518750	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-N-E1-A5-A-N-G0-NNN-080-AA-NN-03-00	SERIES 51	S51-160MV
518751	PUMP-VAR-DISPL CW 90PV075	90R075-DC-5-CD-60-S-3-S1-D-GB-GBA-32-32-24	SERIES 90	S90-075PV
518754	MOTOR-VAR-DISPL 51MD080-1	51D080-1--A-D3-N-P7-P7-N-N-X1-NNN-040-AA-E4-00-AA	SERIES 51	S51-080MV-1
518757	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-T2-C0-L-N-G0-ABA-078-AA-G0-00-B5	SERIES 51	S51-250MV
518758	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-N-HS-A2-B-V-G6-ABA-032-AA-F3-07-28	SERIES 51	S51-160MV
518760	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-T2-C0-L-N-G0-NNN-078-AA-G0-00-B5	SERIES 51	S51-250MV
518762	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-CD-80-S-C8-J-03-EFI-42-42-22	SERIES 90	S90-180PV
518764	MOTOR-VAR-DISPL 51MC110-1	51C110-1--R-D3-N-T2-N5-N-N-X1-ADA-054-AA-F3-00-21	SERIES 51	S51-110MV-1

518768	PUMP-VAR-DISPL CW 90PV075	90R075-DC-5-BC-80-S-4-S1-D-GB-GBA-42-42-24	SERIES 90	S90-075PV
518784	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-BC-80-T-4-C8-K-03-NNN-38-38-24	SERIES 90	S90-250PV
518799	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-E2-A5-A-N-A6-NNN-045-AA-G0-03-00	SERIES 51	S51-160MV
518800	MOTOR-VAR-DISPL 51MD080-1	51D080-1--A-D2-N-P7-P7-N-N-X1-NNN-020-AA-E4-00-AA	SERIES 51	S51-080MV-1
518802	MOTOR-VAR-DISPL 51MD110-1	51D110-1--A-D4-N-P7-P7-N-N-X1-NNN-024-AA-E6-00-AA	SERIES 51	S51-110MV-1
518818	MOTOR-VAR-DISPL 51MD110	51D110-A-D3-N-JA-NN-C-H-N4-NNN-046-AA-A0-13-28	SERIES 51	S51-110MV
518827	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-NN-80-R-3-F5-F-03-GCA-32-32-24	SERIES 90	S90-130PV
518830	MOTOR-VAR-DISPL 51MV110	51V110-R-C8-N-E1-A3-A-N-E5-NNN-034-AA-E6-03-20	SERIES 51	S51-110MV
518831	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-TA-C2-N-N-X1-NNN-022-AA-NN-00-21	SERIES 51	S51-110MV-1
518892	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D3-N-E2-B1-N-N-U1-ADA-040-AA-E6-00-00	SERIES 51	S51-080MV-1
518893	PUMP-VAR-DISPL CCW 90PV075	90L075-MB-5-AB-80-S-3-C7-D-C5-GBA-35-35-24	SERIES 90	S90-075PV
518918	MOTOR-VAR-DISPL 51MV080	51V080-R-C7-N-E1-A5-A-N-A6-NNN-050-AA-F3-03-00	SERIES 51	S51-080MV
518919	MOTOR-VAR-DISPL 51MV110	51V110-R-C8-N-E1-L2-A-N-A8-NNN-049-AA-F3-03-20	SERIES 51	S51-110MV
518946	MOTOR-VAR-DISPL 51MV060	51V060-R-S1-D-L1-B1-W-B-C0-NNN-032-AA-NN-D4-00	SERIES 51	S51-060MV
518947	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D2-N-E2-B1-N-N-U1-ADA-032-AA-NN-00-00	SERIES 51	S51-080MV-1
518956	PUMP-VAR-DISPL CW 90PV042	90R042-FC-5-BC-80-S-7-C3-C-B4-EFI-38-38-32	SERIES 90	S90-042PV
518960	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-TH-C2-L-N-G0-NNN-050-AA-F0-00-B7	SERIES 51	S51-160MV
518970	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-NN-80-T-3-C8-K-05-NNN-20-20-24	SERIES 90	S90-250PV
518971	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-L1-B1-W-B-G0-NNN-078-AA-F0-D4-00	SERIES 51	S51-250MV
518972	PUMP-VAR-DISPL CCW 90PV075	90L075-MA-P-BB-80-S-3-C7-D-C6-GBA-48-48-24	SERIES 90	S90-075PV
518973	PUMP-VAR-DISPL CCW 90PV042	90L042-DC-5-AB-80-S-3-C3-B-GB-GBA-42-42-20	SERIES 90	S90-042PV
519023	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-DE-80-T-3-C8-K-01-NNN-14-38-30	SERIES 90	S90-250PV
519024	PUMP-VAR-DISPL MPV044	MPV-044-D-B-A-G-W-S-G-AA-A-A-BJJ-DR-A-FF-A-NNN	M35/44	044PV
519043	MOTOR-VAR-DISPL 51MV080	51V080-R-C7-N-E2-A5-A-N-A6-NNN-030-AA-NN-03-00	SERIES 51	S51-080MV
519045	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-NN-60-P-3-TG-D-29-FAB-42-42-20	SERIES 90	S90-100PV
519049	MOTOR-VAR-DISPL 51MC080-1	51C080-1--A-D2-N-TH-C2-N-N-X1-ADA-054-AA-G0-00-34	SERIES 51	S51-080MV-1
519056	MOTOR-FIXED-DISPL 90MF130	90-M-130-NC-0-N-8-N-0-F3-W-00-EGF-00-00-F3	SERIES 90	S90-130MF
519062	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-EQ-A5-J-Y-A6-NNN-035-AA-F0-30-00	SERIES 51	S51-160MV
519080	PUMP-VAR-DISPL CW 90PV075	90R075-KA-P-BC-60-P-3-S1-E-04-FAP-45-45-26	SERIES 90	S90-075PV
519088	MOTOR-VAR-DISPL 51MV080-1	51V080-1--A-C7-N-T1-D1-N-N-X1-NNN-054-AA-F3-00-25	SERIES 51	S51-080MV-1
519093	PUMP-VAR-DISPL CW 90PV075	90R075-KA-6-BC-80-P-4-C7-D-03-GBA-48-48-24	SERIES 90	S90-075PV
519094	PUMP-VAR-DISPL CW 90PV100	90R100-KA-6-BC-80-P-3-C7-E-03-GBA-48-48-24	SERIES 90	S90-100PV
519095	PUMP-VAR-DISPL CW 90PV130	90R130-KA-6-BC-80-P-3-C8-H-03-GBA-48-48-24	SERIES 90	S90-130PV
519096	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-BC-80-S-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
519121	MOTOR-VAR-DISPL 51MC080	51C080-R-S1-N-L3-B1-W-B-G0-ANA-016-AA-F0-D4-00	SERIES 51	S51-080MV
519163	PUMP-VAR-DISPL CW 90PV250	90R250-MA-5-CD-80-T-3-C8-J-C5-NNN-26-26-24	SERIES 90	S90-250PV

519164	PUMP-VAR-DISPL CW 90PV075	90R075-MB-5-BC-80-S-3-C7-D-C5-GBA-42-42-24	SERIES 90	S90-075PV
519171	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-BB-80-T-3-C8-J-O5-NNN-35-35-30	SERIES 90	S90-250PV
519172	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-N-E1-B1-N-N-U1-NNN-032-AA-E6-00-00	SERIES 51	S51-060MV-1
519174	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-N-E1-B1-N-N-U1-ADA-032-AA-E6-00-00	SERIES 51	S51-060MV-1
519210	MOTOR-VAR-DISPL 51MV250	51V250-A-C8-N-HS-A3-C-E-E5-NNN-140-AA-H0-13-30	SERIES 51	S51-250MV
519211	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-C7-N-B1-B3-N-N-U3-NNN-054-AA-F3-00-00	SERIES 51	S51-080MV-1
519216	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-E2-B1-N-N-U1-NNN-038-AA-F0-00-00	SERIES 51	S51-110MV-1
519227	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-N1-NN-N-N-U1-ACF-062-AA-F0-00-00-P040	SERIES 51	S51-110MV-1
519228	MOTOR-VAR-DISPL 51MD160	51D160-A-D4-N-T3-C0-L-N-J1-ADA-040-AA-E6-00-B1	SERIES 51	S51-160MV
519229	MOTOR-VAR-DISPL 51MC080	51C080-R-D2-N-E2-A2-A-N-E1-NNN-026-AA-E6-03-37	SERIES 51	S51-080MV
519239	MOTOR-VAR-DISPL 51MV080-1	51V080-1--A-C7-N-TH-CA-N-N-X1-NNN-030-AA-F3-00-25	SERIES 51	S51-080MV-1
519291	MOTOR-VAR-DISPL 51MC060	51C060-V-D1-N-Y7-B1-S-L-J1-AWB-M12-AA-E6-F4-00	SERIES 51	S51-060MV
519328	MOTOR-VAR-DISPL 51MD110-1	51D110-1--A-D3-N-TH-CA-N-N-X1-NNN-045-AA-F0-00-37	SERIES 51	S51-110MV-1
519335	MOTOR-VAR-DISPL 51MD110-1	51D110-1--R-D4-N-E1-B1-N-N-U1-NNN-025-AA-E6-00-00	SERIES 51	S51-110MV-1
519338	PUMP-VAR-DISPL CW 90PV075	90R075-HF-5-NN-80-S-3-C7-E-03-GBA-42-42-28	SERIES 90	S90-075PV
519367	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-V-NV-8E-L-R-F4-F-03-GB4-42-42-36	SERIES 90	S90-130PV
519376	PUMP-VAR-DISPL CCW 90PV075	90L075-KP-5-BB-80-P-3-S1-D-03-GBA-35-35-20	SERIES 90	S90-075PV
519377	PUMP-VAR-DISPL CCW 90PV075	90L075-KP-5-CD-80-P-3-S1-D-03-GBA-35-35-20	SERIES 90	S90-075PV
519391	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D3-N-B1-B3-N-N-U3-ADA-054-AA-B3-00-00	SERIES 51	S51-080MV-1
519394	PUMP-VAR-DISPL CW 90PV075	90R075-HF-P-CD-80-S-3-C7-E-38-GBA-48-48-24	SERIES 90	S90-075PV
519395	PUMP-VAR-DISPL CW 90PV075	90R075-HF-P-BC-80-S-3-S1-E-03-GBA-48-48-24	SERIES 90	S90-075PV
519396	MOTOR-VAR-DISPL 51MD110-1	51D110-1--A-D4-N-T1-L5-N-N-X1-NNN-037-AA-F3-00-30	SERIES 51	S51-110MV-1
519397	VENTILPLATTE 25 PVO L		DAIKIN	PARTS - OPV
519398	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D3-N-T1-C2-N-N-X1-NNN-048-AA-F3-00-30	SERIES 51	S51-080MV-1
519399	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-N-T1-C2-N-N-X1-NNN-025-AA-NN-00-30	SERIES 51	S51-060MV-1
519403	MOTOR-VAR-DISPL 51MD110-1	51D110-1--R-D3-N-E1-B1-N-N-U1-NNN-039-AA-F3-00-00	SERIES 51	S51-110MV-1
519411	PUMP-VAR-DISPL CW 90PV075	90R075-MA-5-NN-60-S-4-S1-D-C4-GBA-20-20-20	SERIES 90	S90-075PV
519412	PUMP-VAR-DISPL CW 90PV075	90R075-MA-5-CD-60-S-4-S1-D-C4-GBA-20-20-20	SERIES 90	S90-075PV
519422	PUMP-VAR-DISPL CCW 90PV042	90L042-KA-5-BB-80-P-4-C3-C-03-GBA-42-42-24	SERIES 90	S90-042PV
519425	PUMP-VAR-DISPL CCW 90PV042	90L042-KA-5-NN-80-D-4-C3-L-03-GBA-42-42-24	SERIES 90	S90-042PV
519426	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-BC-80-P-3-C7-E-04-GBA-42-42-24	SERIES 90	S90-100PV
519441	MOTOR-VAR-DISPL 51MV110-1	51V110-1--A-F1-N-E2-B1-N-N-U1-NNN-036-AA-F0-00-00	SERIES 51	S51-110MV-1
519442	MOTOR-VAR-DISPL 51MV110-1	51V110-1--A-F1-N-E2-B1-N-N-U1-ADA-036-AA-F0-00-00	SERIES 51	S51-110MV-1
519450	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-HB-B1-B-E-C2-ADA-073-AA-F3-10-00	SERIES 51	S51-160MV
519451	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-TA-C2-L-N-G0-NNN-135-AA-H0-00-B5	SERIES 51	S51-250MV
519453	MOTOR-VAR-DISPL 51MV060-1	51V060-1--A-S1-N-E1-B1-N-N-U1-ACB-036-AA-E4-00-00	SERIES 51	S51-060MV-1

519457	MOTOR-VAR-DISPL 51MV110	51V110-R-C8-N-HA-B1-B-E-C2-NNN-048-AA-F3-10-00	SERIES 51	S51-110MV
519461	PUMP-VAR-DISPL CCW 90PV075	90L075-MA-5-NN-60-S-4-S1-D-C4-GBA-20-20-20	SERIES 90	S90-075PV
519462	MOTOR-FIXED-DISPL 20MF334	SMF2/334--B6Z-AM01000-A1	SERIES 20	S20-334MF
519464	PUMP-VAR-DISPL CW 90PV130	90R130-FH-2-AB-80-L-B-C8-H-B1-EFI-42-42-34	SERIES 90	S90-130PV
519482	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-BC-60-P-3-C7-E-03-GBA-45-45-24	SERIES 90	S90-100PV
519483	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-S1-N-E2-B1-N-N-U1-NNN-016-AA-NN-00-00	SERIES 51	S51-080MV-1
519484	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-L2-B1-V-A-C0-NNN-016-AA-NN-B2-00	SERIES 51	S51-080MV
519485	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-CD-80-P-3-S1-D-03-GBA-32-32-30	SERIES 90	S90-075PV
519487	MOTOR-VAR-DISPL 51MV110	51V110-R-F1-N-L2-B1-V-A-C0-NNN-022-AA-NN-B2-00	SERIES 51	S51-110MV
519522	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-T3-R5-L-N-C0-FCB-068-AA-G3-00-B5	SERIES 51	S51-250MV
519532	MOTOR-FIXED-DISPL 90MF100	90-M-100-NC-0-N-U-N-0-F1-C-00-PAA-00-00-H0	SERIES 90	S90-100MF
519560	PUMP-VAR-DISPL CW 90PV100	90R100-MB-5-BC-80-S-3-C7-E-C7-GBA-42-42-24	SERIES 90	S90-100PV
519562	PUMP-VAR-DISPL CW 90PV075	90R075-HF-5-BC-80-P-3-C7-D-H9-GBA-42-42-18	SERIES 90	S90-075PV
519700	PUMP-VAR-DISPL CW 90PV100	90R100-FG-5-BC-80-P-7-C7-E-B1-EFD-42-42-30	SERIES 90	S90-100PV
519734	PUMP-VAR-DISPL MPV046	MPV-046-C-B-B-H-S-B-B-AA-3-A-BFF-DA-A-RR-A-NNN	M46	M46-046PV
519738	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-NN-80-T-C-F1-H-03-NNN-42-42-24	SERIES 90	S90-180PV
519747	PUMP-VAR-DISPL CW 90PV075	90R075-HF-5-NN-80-S-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-075PV
519748	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-DE-80-S-C-C8-H-04-NNN-32-14-24	SERIES 90	S90-180PV
519749	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-BC-80-L-3-F1-F-04-GBA-35-26-24	SERIES 90	S90-130PV
519750	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-EG-80-S-C-C8-H-04-NNN-32-14-24	SERIES 90	S90-180PV
519752	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-BC-80-S-C-C8-H-04-GCA-35-26-24	SERIES 90	S90-180PV
519757	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-HS-A2-B-H-C1-NNN-042-AA-NN-10-13	SERIES 51	S51-080MV
519759	MOTOR-VAR-DISPL 51MV060	51V060-R-S1-N-HS-A2-B-H-C1-NNN-028-AA-NN-10-13	SERIES 51	S51-060MV
519763	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-NN-80-L-3-C8-F-45-GBA-42-42-28	SERIES 90	S90-130PV
519823	PUMP-VAR-DISPL CW 90PV075	90R075-FL-5-CD-80-D-7-C7-L-B6-GME-40-40-30	SERIES 90	S90-075PV
519834	PUMP-VAR-DISPL CW 90PV042	90R042-KP-1-BB-80-S-3-C5-L-00-GBA-35-35-20-P000	SERIES 90	S90-042PV
519836	PUMP-VAR-DISPL CW 90PV042	90R042-KP-1-NN-80-S-3-C3-L-00-GBA-35-35-20-P000	SERIES 90	S90-042PV
519837	PUMP-VAR-DISPL CW 90PV042	90R042-KP-1-BB-80-P-3-C3-L-00-GBA-35-35-20-P000	SERIES 90	S90-042PV
519851	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-BB-80-R-3-F1-F-03-EFC-35-35-20	SERIES 90	S90-100PV
519865	MOTOR-FIXED-DISPL 90MF100	90-M-100-NC-0-N-U-N-0-F1-C-00-PAA-00-00-B4	SERIES 90	S90-100MF
519871	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-2-NN-80-S-3-C8-F-03-GBA-42-42-24	SERIES 90	S90-130PV
519875	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-2-NN-80-S-3-C8-F-03-EFC-42-42-24	SERIES 90	S90-130PV
519881	MOTOR-VAR-DISPL 51MD160	51D160-R-D5-N-EF-B1-T-M-C0-AWM-070-AA-F3-B2-00	SERIES 51	S51-160MV
519886	MOTOR-VAR-DISPL 51MD160	51D160-A-D4-N-T3-C0-L-N-J1-NNN-035-AA-F0-00-B1	SERIES 51	S51-160MV
519888	MOTOR-VAR-DISPL 51MC080-1	51C080-1--A-D2-N-TA-C2-N-N-X1-NNN-037-AA-E6-00-18	SERIES 51	S51-080MV-1
519894	MOTOR-VAR-DISPL 51MV080-1	51V080-1--A-C7-N-T1-L5-N-N-X1-NNN-047-AA-F3-00-25	SERIES 51	S51-080MV-1

519901	MOTOR-FIXED-DISPL 90MF130	90-M-130-NC-0-N-U-N-0-F1-D-00-LAA-00-00-K0	SERIES 90	S90-130MF
519908	PUMP-VAR-DISPL CW 90PV075	90R075-FK-5-BB-80-P-7-S1-D-B6-GME-42-42-30	SERIES 90	S90-075PV
519998	PUMP-VAR-DISPL CW 90PV075	90R075-FM-5-BB-60-S-7-C6-D-B6-GMD-45-45-30	SERIES 90	S90-075PV
519999	PUMP-VAR-DISPL CW 90PV075	90R075-FM-5-BT-60-S-7-C6-D-B6-GMD-45-45-30	SERIES 90	S90-075PV
520015	PUMP-VAR-DISPL CW 20PV089	SPV2/089--R3A-PS12X-VML311-456-A1	SERIES 20	S20-089PV
520055SK	MOTOR-VAR-DISPL 20MV089	SMV2/089--B3G-034-MS35354-VML311-A1	SERIES 20	S20-089SMV
520066	MOTOR-VAR-DISPL 20MV334	SMV2/334--B6S-163-MS3838X-VAE531-449-A1	SERIES 20	S20-334SMV
520113	MOTOR-FIXED-DISPL TMM089	TMM089B-6NNN-NNN0	TMM / TMP	TMM089
520134	PUMP-VAR-DISPL CW 20PV334	SPV2/334--R6S-PS66X-VML100-RNU321-A1	SERIES 20	S20-334PV
520142	PUMP-VAR-DISPL CCW 20PV227	SPV2/227--L6P-972972-PS33X-A1	SERIES 20	S20-227PV
520180SK	PUMP-VAR-DISPL CW 20PV227	SPV2/227--R6F-972972-PS66X-384-A1	SERIES 20	S20-227PV
520181SK	PUMP-VAR-DISPL CW 20PV119	SPV2/119--R3F-972972-PS333-384-A1	SERIES 20	S20-119PV
520184SK	MOTOR-VAR-DISPL 20MV089	SMV2/089--B3A-063-MS3535X-VML311-A1	SERIES 20	S20-089SMV
520187	PUMP-VAR-DISPL CW 20PV166	SPV2/166--R6F-972972-PS663-VES347-A1	SERIES 20	S20-166PV
520238	PUMP-VAR-DISPL CW 20PV166	SPV2/166--R6F-972972-PS66X-VES347-A1	SERIES 20	S20-166PV
520326	PUMP-VAR-DISPL CW 90PV130	90R130-KP-P-BC-80-L-1-F1-H-04-GBA-45-45-24	SERIES 90	S90-130PV
520345	MOTOR-VAR-DISPL 51MV080	51V080-R-C7-N-Y7-B1-S-L-J1-ACB-046-AA-F3-F4-00	SERIES 51	S51-080MV
520348	MOTOR-VAR-DISPL 51MV060	51V060-R-C6-N-Y7-B1-S-L-J1-NNN-028-AA-F3-F4-00	SERIES 51	S51-060MV
520362	PUMP-VAR-DISPL CW 90PV075	90R075-HF-5-NN-60-S-4-S1-D-00-GBA-38-38-24	SERIES 90	S90-075PV
520363	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-NN-60-S-4-S1-D-00-GBA-38-38-24	SERIES 90	S90-075PV
520373	PUMP-VAR-DISPL CW 90PV100	90R100-KA-1-CD-60-S-4-C7-E-00-GBA-38-38-24	SERIES 90	S90-100PV
520375	PUMP-VAR-DISPL CW 90PV042	90R042-FC-5-NN-80-R-H-C3-C-B1-EFI-42-42-28	SERIES 90	S90-042PV
520376	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-BC-80-S-3-C8-F-02-GBA-42-42-24	SERIES 90	S90-130PV
520378	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-D7-M1-S-K-N2-NNN-030-AA-F0-F4-20	SERIES 51	S51-080MV
520380	MOTOR-VAR-DISPL 51MC110-1	51C110-1--R-D3-E-E1-B1-N-N-U2-DBA-022-AA-A0-00-00	SERIES 51	S51-110MV-1
520381	MOTOR-VAR-DISPL 51MC110-1	51C110-1--R-D3-N-B1-B3-N-N-U3-DBA-022-AA-F0-00-00	SERIES 51	S51-110MV-1
520383	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-C7-N-E2-B1-N-N-U1-NNN-030-AA-E6-00-00	SERIES 51	S51-080MV-1
520384	PUMP-VAR-DISPL CCW 90PV180	90L180-MA-5-BC-80-T-C-C8-J-C5-NNN-42-42-24	SERIES 90	S90-180PV
520385	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-F2-A2-A-N-E1-NNN-050-AA-H0-03-27	SERIES 51	S51-250MV
520386	MOTOR-VAR-DISPL 51MV160	51V160-A-C8-N-HZ-B1-A-E-C2-NNN-032-AA-F0-04-00	SERIES 51	S51-160MV
520388	PUMP-VAR-DISPL CW 90PV075	90R075-MA-5-BC-60-S-2-C7-D-C5-GBA-34-38-24	SERIES 90	S90-075PV
520389	PUMP-VAR-DISPL CW 90PV100	90R100-MA-5-NN-60-S-3-C7-F-C5-GBA-42-42-24	SERIES 90	S90-100PV
520390	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-S1-N-E1-B1-N-N-U2-DBA-022-AA-A0-00-00	SERIES 51	S51-080MV-1
520394	MOTOR-VAR-DISPL 51MV110	51V110-R-C8-N-HZ-B1-A-E-C2-NNN-022-AA-F0-04-00	SERIES 51	S51-110MV
520396	PUMP-VAR-DISPL CW 90PV100	90R100-FC-5-AB-80-P-7-C7-E-B1-EAB-45-45-28	SERIES 90	S90-100PV
520399	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-BB-80-P-3-C3-C-03-GBA-45-45-28	SERIES 90	S90-042PV

520400	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-NN-80-S-3-C3-L-03-GBA-45-45-28	SERIES 90	S90-042PV
520408	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-S1-N-N1-NN-N-N-U1-NNN-022-AA-F0-00-00	SERIES 51	S51-080MV-1
520409	MOTOR-VAR-DISPL 51MV160	51V160-A-C8-N-JS-NN-B-E-P2-AAA-050-AA-F3-10-32	SERIES 51	S51-160MV
520413	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-Y3-B1-S-K-J1-NNN-090-AA-G3-F4-00	SERIES 51	S51-160MV
520418	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-S1-N-E2-B1-N-N-U1-ACB-040-AA-NN-00-00	SERIES 51	S51-080MV-1
520423	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-BB-80-P-3-C7-E-02-GBA-42-42-24	SERIES 90	S90-100PV
520424	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-S1-N-E2-B1-N-N-U1-ACB-040-AA-F0-00-00	SERIES 51	S51-080MV-1
520427	PUMP-VAR-DISPL CW 90PV100	90R100-MA-P-CD-80-S-3-C7-E-04-GBA-48-48-24	SERIES 90	S90-100PV
520433	PUMP-VAR-DISPL CW 90PV130	90R130-HF-5-BC-80-S-3-C8-H-03-GBA-42-42-24	SERIES 90	S90-130PV
520448	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-S1-N-E2-B1-N-N-U1-ACB-029-AA-F0-00-00	SERIES 51	S51-080MV-1
520451	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-BC-60-S-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-075PV
520454	PUMP-VAR-DISPL CW 90PV042	90R042-PA-5-BB-80-S-3-C3-C-03-GBA-42-42-28	SERIES 90	S90-042PV
520455	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-P-AB-60-P-3-C7-D-46-GBA-48-48-24	SERIES 90	S90-075PV
520456	PUMP-VAR-DISPL CW 90PV130	90R130-FH-5-BC-80-P-7-F1-F-B1-GBS-42-42-28	SERIES 90	S90-130PV
520461	PUMP-VAR-DISPL CW 90PV130	90R130-MA-5-NN-80-P-3-C8-F-C5-GBA-35-35-24	SERIES 90	S90-130PV
520463	PUMP-VAR-DISPL CW 90PV075	90R075-NA-1-NN-80-L-3-T6-D-03-GLA-42-42-26	SERIES 90	S90-075PV
520465	PUMP-VAR-DISPL CW 90PV100	90R100-NA-1-NN-80-L-3-T6-E-A4-GLA-42-42-26	SERIES 90	S90-100PV
520466	PUMP-VAR-DISPL CW 90PV130	90R130-NA-1-AB-80-L-3-T7-F-03-GLA-42-42-30	SERIES 90	S90-130PV
520467	MOTOR-VAR-DISPL 51MD160	51D160-A-D4-B-TW-C0-L-N-J2-NNN-042-AA-F0-00-B7	SERIES 51	S51-160MV
520468	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-TA-C2-L-N-G0-NNN-080-AA-G0-00-B3	SERIES 51	S51-160MV
520469	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-E2-A5-A-N-G0-NNN-125-AA-G3-03-00	SERIES 51	S51-160MV
520470	MOTOR-VAR-DISPL 51MV060	51V060-R-S1-D-L1-B1-W-B-C0-ADA-032-AA-NN-D4-00	SERIES 51	S51-060MV
520471	PUMP-VAR-DISPL CW 90PV100	90R100-MA-7-CD-60-S-4-D7-E-03-GBA-45-45-24-F040	SERIES 90	S90-100PV
520474	PUMP-VAR-DISPL CW 90PV100	90R100-KN-5-CD-80-P-3-C7-E-03-GBA-42-42-20	SERIES 90	S90-100PV
520475	PUMP-VAR-DISPL CW 90PV100	90R100-KN-5-AB-80-P-3-S1-E-03-GBA-42-42-20	SERIES 90	S90-100PV
520479	MOTOR-FIXED-DISPL 90MF100	90-M-100-NC-0-N-7-N-0-F1-W-00-NNN-00-00-H0	SERIES 90	S90-100MF
520483	MOTOR-VAR-DISPL 51MD160	51D160-R-D5-N-TA-C2-L-N-K7-NNN-095-AA-NN-00-A9	SERIES 51	S51-160MV
520484	PUMP-VAR-DISPL CW 90PV075	90R075-MB-5-BB-60-R-3-C7-D-C5-GBA-42-42-24	SERIES 90	S90-075PV
520488	MOTOR-VAR DISPL, CARTRIDGE (51C110)	51C110-R-D3-N-TH-C2-L-N-G0-NNN-057-AA-F0-00-B7	SERIES 51	S51-110MV
520489	PUMP-VAR-DISPL CW 90PV075	90R075-KA-P-CD-80-P-4-C7-D-03-GBA-48-48-24	SERIES 90	S90-075PV
520490	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-NN-80-R-3-C8-H-03-GCA-35-35-24	SERIES 90	S90-130PV
520492	PUMP-VAR-DISPL MPV046	MPV-046-C-B-B-R-B-A-AA-G-A-AAA-CB-A-HH-A-NNN	M46	M46-046PV
520496	PUMP-VAR-DISPL CW 90PV100	90R100-KA-P-BB-80-P-3-C7-E-03-GBA-48-48-24	SERIES 90	S90-100PV
520497	PUMP-VAR-DISPL CW 90PV075	90R075-KA-P-BB-80-P-4-C7-D-03-GBA-48-48-24	SERIES 90	S90-075PV
520498	PUMP-VAR-DISPL CW 90PV130	90R130-KA-P-BB-80-P-3-C8-H-03-GBA-48-48-24	SERIES 90	S90-130PV
520499	MOTOR-VAR-DISPL 51MV160	51V160-R-F2-N-E2-A6-A-N-A9-NNN-055-AA-H0-03-00	SERIES 51	S51-160MV

520500	MOTOR-VAR-DISPL 51MD160	51D160-A-D4-N-T2-C0-L-N-L4-NNN-038-AA-E6-00-C2	SERIES 51	S51-160MV
520501	PUMP-VAR-DISPL CW 90PV100	90R100-HF-5-NN-60-S-3-C7-F-05-GBA-42-42-24	SERIES 90	S90-100PV
520503	PUMP-VAR-DISPL CW 90PV100	90R100-PB-5-CD-60-P-3-F1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
520504	PUMP-VAR-DISPL CW 90PV100	90R100-PB-5-CD-60-P-3-S1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
520505	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-TH-C2-N-N-X1-NNN-080-AA-G0-00-18	SERIES 51	S51-110MV-1
520506	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-CD-60-R-3-C7-D-03-GCS-35-35-20	SERIES 90	S90-075PV
520507	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-CD-60-S-3-C7-E-04-GCS-42-42-20	SERIES 90	S90-075PV
520508	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-CD-60-S-3-S1-E-04-GCS-42-42-20	SERIES 90	S90-075PV
520509	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-NN-80-R-4-T6-F-03-GBA-29-29-24	SERIES 90	S90-100PV
520511	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-F2-A2-A-N-A7-NNN-050-AA-NN-03-20	SERIES 51	S51-250MV
520512	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-CD-60-S-3-C6-D-06-GBA-35-35-24	SERIES 90	S90-075PV
520513	PUMP-VAR-DISPL CW 90PV100	90R100-FC-5-BC-80-P-7-C7-E-B1-EFI-42-42-30	SERIES 90	S90-100PV
520514	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-C7-N-E2-B1-N-N-U1-NNN-016-AA-F0-00-00	SERIES 51	S51-080MV-1
520515	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-AB-80-L-3-C7-F-03-GBA-42-42-28	SERIES 90	S90-100PV
520520	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-C8-N-E2-B1-N-N-U1-NNN-022-AA-F0-00-00	SERIES 51	S51-110MV-1
520521	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-DE-80-T-4-C8-K-01-NNN-14-38-30	SERIES 90	S90-250PV
520522	MOTOR-VAR-DISPL 51MV250	51V250-A-C8-N-HS-A3-C-E-E5-NNN-150-AA-H0-12-35	SERIES 51	S51-250MV
520523	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-BB-80-T-3-C8-J-05-NNN-42-42-30	SERIES 90	S90-250PV
520525	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-CD-80-R-3-C7-E-04-GBA-45-45-24	SERIES 90	S90-100PV
520526	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-N-E1-B1-N-N-U1-NNN-032-AA-E6-00-00	SERIES 51	S51-060MV-1
520529	PUMP-VAR-DISPL CW 90PV180	90R180-MA-5-BC-80-S-C-C8-J-C5-NNN-35-35-24	SERIES 90	S90-180PV
520530	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-C7-N-E2-B1-N-N-U1-ACB-041-AA-F0-00-00	SERIES 51	S51-080MV-1
520531	MOTOR-VAR-DISPL 51MV160	51V160-R-F2-N-E2-A5-A-N-A6-NNN-055-AA-H0-03-00	SERIES 51	S51-160MV
520534	PUMP-VAR-DISPL CW 90PV130	90R130-FG-5-NN-80-P-7-C8-H-B1-EFI-42-42-30	SERIES 90	S90-130PV
520539	HOSE DN6/2SNX370 DKJ/DKJ W/CONNECT.740204		SERIES 20	PARTS - S20 - Purchased Parts
520568	UMBRELLA-TMP		TMM / TMP	PARTS - TMM/TMP
520574	MOTOR-FIXED-DISPL 20MF334	SMF2/334--B6Z-AM08000-XCX-A1	SERIES 20	S20-334MF
520581SK	MOTOR-VAR-DISPL 20MV227	SMV2/227--B6F-188-MS3510X-VAE531-449-A1	SERIES 20	S20-227SMV
520610SK	PUMP-VAR-DISPL CW 20PV334	SPV2/334--R6Z-PS663-VHA610-RNU335-A1	SERIES 20	S20-334PV
520626SK	MOTOR-FIXED-DISPL 20MF119	SMF2/119--B3Z-MS24242-XCX-A1	SERIES 20	S20-119MF
520632SK	PUMP-VAR-DISPL CW 20PV119	SPV2/119--R3Z-PS193-VML100-A1	SERIES 20	S20-119PV
520689	MOTOR-FIXED-DISPL 20MF070	SMF2/070--B4Z-MA3131X-479-A1	SERIES 20	S20-070MF
520690SK	MOTOR-FIXED-DISPL 20MF070	SMF2/070--B4Z-MA3535X-479-A1	SERIES 20	S20-070MF
520702SK	MOTOR-FIXED-DISPL 20MF089	SMF2/089--B3A-MD3535X-479-A1	SERIES 20	S20-089MF
520728SK	PUMP-VAR-DISPL CCW 20PV089	SPV2/089--L3Z-PS12X-VML611-484-A1	SERIES 20	S20-089PV
520738	PUMP-VAR-DISPL CW 20PV070	SPV2/070--R3D-PS18X-VML700-481-A1	SERIES 20	S20-070PV

520787	PUMP-VAR-DISPL CW TMP070	TMP070-NFPE24-RMNFNNNNN1	TMM / TMP	TMP070
520794	PUMP-VAR-DISPL CW TMP089	TMP089-NFPE24-RMNFNNNNN1	TMM / TMP	TMP089
520796	PUMP-VAR-DISPL CCW TMP089	TMP089-NFPE24-LMNFN1NNN1	TMM / TMP	TMP089
520797	PUMP-VAR-DISPL CCW TMP089	TMP089-NFPE24-LMNFNNNNN1	TMM / TMP	TMP089
520798	PUMP-VAR-DISPL CW TMP089	TMP089-NFPE24-RMNCNNNNN1	TMM / TMP	TMP089
520800	PUMP-VAR-DISPL CW TMP089	TMP089-NFPE12-RMNFNNNNN1	TMM / TMP	TMP089
520803	PUMP-VAR-DISPL CW 20PV334	SPV2/334--R6Z-PS663-VES310-RNU330-A1	SERIES 20	S20-334PV
520820	PUMP-VAR-DISPL CCW TMP070	TMP070-NFPE24-LMAFNNNNN1	TMM / TMP	TMP070
520828	PUMP-VAR-DISPL CW TMP089	TMP089-NFPE24-RMAFNNNNN1	TMM / TMP	TMP089
520829	PUMP-VAR-DISPL CW TMP089	TMP089-NFPE24-RMACNNNNN1	TMM / TMP	TMP089
520830	PUMP-VAR-DISPL CCW TMP089	TMP089-NFPE24-LMAFNNNNN1	TMM / TMP	TMP089
520831	PUMP-VAR-DISPL CW TMP089	TMP089-NFPE24-RMVFNNNNN1	TMM / TMP	TMP089
520834	PUMP-VAR-DISPL CW TMP089	TMP089-NFPE24-RMBFNNNNN1	TMM / TMP	TMP089
520837	PUMP-VAR-DISPL CW TMP089	TMP089-NFPE12-RMBCNNNNN1	TMM / TMP	TMP089
520839	PUMP-VAR-DISPL CW TMP089	TMP089-NFPE24-RMVDNNNNN1	TMM / TMP	TMP089
520943	PUMP-VAR-DISPL CW 90PV075	90R075-FM-D-BC-6U-S-7-C6-D-B6-GMC-45-45-30	SERIES 90	S90-075PV
520972	PUMP-VAR-DISPL CW 90PV075	90R075-FM-S-CD-8D-P-7-C6-D-B6-GMC-48-48-30	SERIES 90	S90-075PV
520980	PUMP-VAR-DISPL CW 90PV075	90R075-FM-D-BC-6U-P-7-C6-D-B6-GMC-45-45-30	SERIES 90	S90-075PV
520984	MOTOR-VAR-DISPL 51MD080-1	51D080-1--H-D3-N-B7-B3-N-N-U3-AWG-036-AA-F0-00-00	SERIES 51	S51-080MV-1
521000	PUMP-VAR-DISPL CW 90PV075	90R075-FM-5-BB-80-D-7-C7-L-B6-WAA-42-42-24	SERIES 90	S90-075PV
521012	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-BC-80-S-4-C8-H-03-GBA-42-42-24	SERIES 90	S90-130PV
521033	PUMP-VAR-DISPL CW 90PV100	90R100-FH-5-BC-60-P-7-C7-F-BB-GBS-42-42-28	SERIES 90	S90-100PV
521035	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-C7-N-E2-B1-N-N-U1-AAA-016-AA-F0-00-00	SERIES 51	S51-080MV-1
521037	PUMP-VAR-DISPL CW 90PV180	90R180-CB-5-NN-80-S-C-C8-J-00-NNN-42-42-24-G005	SERIES 90	S90-180PV
521038	PUMP-VAR-DISPL CCW 90PV180	90L180-CB-5-NN-80-S-C-C8-J-00-NNN-42-42-24-G005	SERIES 90	S90-180PV
521060	PUMP-VAR-DISPL CW 90PV075	90R075-FM-6-BC-80-R-7-C7-E-B6-ELC-48-48-30	SERIES 90	S90-075PV
521174	DRUCKB. VENTIL KIT 360 BAR		M46	PARTS - M46
521192	PUMP-VAR-DISPL CW 90PV075	90R075-FK-P-NN-60-S-7-C7-D-B6-GME-48-48-30	SERIES 90	S90-075PV
521193	MOTOR-VAR-DISPL 51MD110-1	51D110-1--A-D3-N-T1-CA-N-N-X1-ADA-028-AA-N6-00-27	SERIES 51	S51-110MV-1
521194	MOTOR-VAR-DISPL 51MD080-1	51D080-1--A-D3-N-T7-L5-N-N-X1-NNN-037-AA-F0-00-25	SERIES 51	S51-080MV-1
521196	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-NN-80-P-3-C7-D-03-GBA-42-42-24	SERIES 90	S90-075PV
521197	PUMP-VAR-DISPL CW 90PV100	90R100-MA-2-BB-60-S-4-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
521204	PUMP-VAR-DISPL CW 90PV075	90R075-FM-U-NN-80-D-7-C7-N-B6-GMD-48-48-30	SERIES 90	S90-075PV
521212	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D3-C-T1-C2-N-N-X1-NNN-048-AA-F3-00-25	SERIES 51	S51-080MV-1
521213	PUMP-VAR-DISPL CW 90PV075	90R075-MA-5-CD-60-S-2-C7-D-C5-GBA-38-38-24	SERIES 90	S90-075PV
521236	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-BB-80-T-C-C8-H-04-NNN-42-42-24	SERIES 90	S90-180PV

521240	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-B-N1-NN-N-N-U1-AWH-016-AA-E4-00-00	SERIES 51	S51-060MV-1
521258	PUMP-VAR-DISPL CCW 90PV100	90L100-MA-1-BC-60-S-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
521266	PUMP-VAR-DISPL CW 90PV130	90R130-FH-5-NN-80-S-7-C8-H-B1-EFI-42-42-32	SERIES 90	S90-130PV
521267	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-D8-M1-R-J-N1-NNN-065-AA-F3-C2-24	SERIES 51	S51-250MV
521270	MOTOR-VAR-DISPL 51MV110	51V110-R-F1-N-TA-C7-L-N-J1-NNN-036-AA-NN-00-B5	SERIES 51	S51-110MV
521272	PUMP-VAR-DISPL CCW 90PV130	90L130-MA-5-AB-80-S-3-F1-F-C5-GBA-42-42-24	SERIES 90	S90-130PV
521280	PUMP-VAR-DISPL CW 90PV250	90R250-PB-5-BC-80-T-3-F1-K-03-NNN-32-32-24	SERIES 90	S90-250PV
521281	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-NN-80-S-3-C8-K-03-NNN-30-30-24	SERIES 90	S90-250PV
521291	MOTOR-VAR-DISPL 51MV110	51V110-R-F1-N-L2-B1-V-A-C0-NNN-050-AA-NN-B2-00	SERIES 51	S51-110MV
521292	PUMP-VAR-DISPL CW 90PV100	90R100-MB-5-BB-60-R-3-C6-D-03-FAD-38-38-20	SERIES 90	S90-100PV
521299	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-N-L2-B1-V-A-C0-NNN-115-AA-NN-B2-00	SERIES 51	S51-250MV
521300	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-N-L2-B1-V-A-C0-NNN-115-AA-NN-B2-00	SERIES 51	S51-160MV
521301	PUMP-VAR-DISPL CW 90PV075	90R075-FL-S-BC-8D-S-7-C6-E-B6-GMC-42-42-30	SERIES 90	S90-075PV
521308	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-E-N1-NN-N-N-U1-AWH-014-AA-E4-00-00	SERIES 51	S51-060MV-1
521389	PUMP-VAR-DISPL CW 90PV180	90R180-PB-5-EG-80-S-C-C8-H-03-NNN-42-42-24	SERIES 90	S90-180PV
521390	PUMP-VAR-DISPL CW 90PV180	90R180-PB-5-CD-80-S-C-C8-H-03-NNN-42-42-24	SERIES 90	S90-180PV
521402	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-S1-N-N1-NN-N-N-U1-ACH-026-AA-F0-00-00	SERIES 51	S51-080MV-1
521403	MOTOR-VAR-DISPL 51MC110-1	51C110-1--R-D3-N-N1-NN-N-N-U1-AWF-030-AA-F0-00-00	SERIES 51	S51-110MV-1
521407	ADAPTER SAE-B 4/046 (JOHN DEERE)		LIGHT DUTY	PARTS - Low Power
521409	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-L2-B1-V-A-G5-NNN-054-AA-NN-B2-00	SERIES 51	S51-080MV
521410	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-E2-A2-A-N-E1-ABA-026-AA-E6-03-37	SERIES 51	S51-080MV
521411	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-L1-B1-W-B-J1-ADA-082-AA-G3-D4-00	SERIES 51	S51-250MV
521422	PUMP-VAR-DISPL CCW 90PV075	90L075-KE-4-AB-6W-8-3-C6-E-33-GCC-41-41-JD	SERIES 90	S90-075PV
521430	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-N-E2-B1-N-N-U1-NNN-032-AA-E6-00-00	SERIES 51	S51-060MV-1
521432	PUMP-VAR-DISPL CW 90PV075	90R075-FN-5-BC-60-P-7-C6-D-B6-ELA-38-38-28	SERIES 90	S90-075PV
521433	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-S1-N-N1-NN-N-N-U1-ACH-043-AA-F0-00-00	SERIES 51	S51-080MV-1
521434	MOTOR-VAR-DISPL 51MV060-1	51V060-1--R-S1-N-E1-B1-N-N-U1-NNN-030-AA-F3-00-00	SERIES 51	S51-060MV-1
521437	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-S1-N-E1-B1-N-N-U1-NNN-036-AA-F0-00-00	SERIES 51	S51-080MV-1
521438	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D3-N-B2-B3-N-N-U3-ADA-024-AA-A3-00-00	SERIES 51	S51-080MV-1
521439	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-BB-80-P-3-C3-C-03-GBA-38-38-24	SERIES 90	S90-042PV
521440	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-NN-80-D-3-C3-L-03-GBA-38-38-28	SERIES 90	S90-042PV
521444	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-1-AB-80-S-3-S1-C-02-GBA-42-42-24	SERIES 90	S90-075PV
521447	PUMP-VAR-DISPL CW 90PV042	90R042-FC-P-AB-80-R-7-T8-B-B1-EFI-48-48-30	SERIES 90	S90-042PV
521451	PUMP-VAR-DISPL CW 90PV250	90R250-MA-5-EG-80-S-3-C8-K-C5-NNN-35-35-24	SERIES 90	S90-250PV
521452	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-AB-80-S-M-C8-H-04-NNN-35-35-24	SERIES 90	S90-180PV
521454	MOTOR-VAR-DISPL 51MD060-1	51D060-1--R-D1-A-TA-C2-N-N-X1-NNN-026-AA-NN-00-13	SERIES 51	S51-060MV-1

521455	MOTOR-VAR-DISPL 51MD080-1	51D080-1--R-D2-A-TA-C2-N-N-X1-NNN-038-AA-NN-00-13	SERIES 51	S51-080MV-1
521464	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-CD-80-T-4-C8-J-00-NNN-42-42-28	SERIES 90	S90-180PV
521471	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-BC-80-T-4-C8-K-00-NNN-38-38-30	SERIES 90	S90-250PV
521473	PUMP-VAR-DISPL CW 90PV075	90R075-FM-P-NN-80-D-D-S1-N-B6-GME-48-48-30	SERIES 90	S90-075PV
521479	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-CD-80-S-4-S1-D-04-GBA-38-38-20	SERIES 90	S90-075PV
521480	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-CD-80-S-M-C8-H-03-FAC-26-26-24	SERIES 90	S90-180PV
521481	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-CD-80-T-4-C8-K-09-NNN-14-23-24	SERIES 90	S90-250PV
521485	MOTOR-VAR-DISPL 51MD160	51D160-R-D4-N-E1-A5-A-N-G0-NNN-032-AA-G0-03-00	SERIES 51	S51-160MV
521486	PUMP-VAR-DISPL CW 90PV100	90R100-HF-5-NN-60-L-4-C7-E-00-GCA-42-42-24	SERIES 90	S90-100PV
521487	MOTOR-VAR-DISPL 51MD110-1	51D110-1--R-D4-N-E2-B1-N-N-U1-ABA-040-AA-E6-00-00	SERIES 51	S51-110MV-1
521489	MOTOR-VAR-DISPL 51MD080	51D080-A-D2-N-HE-B2-C-E-H7-ACA-041-AA-G0-12-00	SERIES 51	S51-080MV
521490	MOTOR-VAR-DISPL 51MV110	51V110-A-C8-N-HZ-B1-A-E-C2-NNN-022-AA-F0-04-00	SERIES 51	S51-110MV
521491	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-E2-B1-N-N-U1-NNN-044-AA-NN-00-00	SERIES 51	S51-110MV-1
521493	PUMP-VAR-DISPL CW 90PV075	90R075-FM-5-CD-60-P-7-C7-D-B6-EFP-42-42-30	SERIES 90	S90-075PV
521495	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-CD-80-S-C-C8-J-03-FAC-38-38-24	SERIES 90	S90-180PV
521496	MOTOR-VAR-DISPL 51MV060-1	51V060-1--R-C6-N-T2-CA-N-N-X1-ADA-040-AA-E6-00-37	SERIES 51	S51-060MV-1
521499	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-T1-R5-L-N-K7-NNN-088-AA-F3-00-B5	SERIES 51	S51-160MV
521505	MOTOR-VAR-DISPL 51MD110-1	51D110-1--A-D4-N-TH-C2-N-N-X1-ADA-074-AA-G3-00-37	SERIES 51	S51-110MV-1
521508	MOTOR-VAR-DISPL 51MV160	51V160-A-C8-N-Y3-B1-S-K-J1-NNN-062-AA-G3-F4-00	SERIES 51	S51-160MV
521509	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-NN-80-S-3-C7-D-C1-GBA-45-45-24	SERIES 90	S90-075PV
521552	PUMP-VAR-DISPL CW 90PV075	90R075-FK-5-BC-80-P-7-C7-D-B6-GME-45-45-30	SERIES 90	S90-075PV
521553	PUMP-VAR-DISPL CW 90PV042	90R042-MA-5-NN-80-L-4-C3-C-03-GBA-42-42-24-F008	SERIES 90	S90-042PV
521555	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-CD-80-S-3-F1-F-03-GBA-42-42-24	SERIES 90	S90-130PV
521556	PUMP-VAR-DISPL CW 90PV075	90R075-FM-5-BC-60-P-7-S1-D-B6-GME-29-29-24	SERIES 90	S90-075PV
521561	PUMP-VAR-DISPL CW 90PV075	90R075-FK-2-CP-60-S-7-C7-E-B6-ELB-42-42-30	SERIES 90	S90-075PV
521562	MOTOR-VAR-DISPL 51MD110	51D110-A-D3-N-D7-M1-S-K-M1-NNN-040-AA-F0-F4-21	SERIES 51	S51-110MV
521566	PUMP-VAR-DISPL CW 90PV075	90R075-MA-5-BC-60-R-4-S1-D-C5-GBA-29-29-24	SERIES 90	S90-075PV
521568	MOTOR-VAR-DISPL 51MV060-1	51V060-1--R-S1-N-E2-B1-N-N-U1-AWM-024-AA-NN-00-00	SERIES 51	S51-060MV-1
521569	PUMP-VAR-DISPL CW 90PV130	90R130-HS-5-AB-80-R-4-C8-H-03-GBA-30-30-30	SERIES 90	S90-130PV
521572	MOTOR-VAR-DISPL 51MV110-1	51V110-1--A-C8-N-T2-D2-N-N-X1-NNN-035-AA-NN-00-28	SERIES 51	S51-110MV-1
521574	PUMP-VAR-DISPL CCW 90PV042	90L042-DC-5-AB-80-S-3-C3-B-Z1-GBA-36-36-20	SERIES 90	S90-042PV
521653	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-EQ-A2-K-Y-G0-ANA-030-AA-E4-85-31	SERIES 51	S51-080MV
521686	PUMP-VAR-DISPL CW 90P100	90R100-DD-2-AB-60-S-7-D7-E-G1-GLA-30-30-30	SERIES 90	S90-100PV
521694	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-HS-A2-C-H-E1-NNN-054-AA-G0-19-26	SERIES 51	S51-160MV
521695	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D2-N-E1-B1-N-N-U1-NNN-016-AA-E4-00-00	SERIES 51	S51-080MV-1
521696	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D2-N-E1-B1-N-N-U1-NNN-016-AA-NN-00-00	SERIES 51	S51-080MV-1

521698	PUMP-VAR-DISPL CW 90P075	90R075-KA-5-BB-60-S-3-C6-D-04-FAX-42-42-26	SERIES 90	S90-075PV
521700	PUMP-VAR-DISPL CCW 90P130	90L130-MB-5-BC-80-R-4-F1-F-C5-GBA-36-36-30	SERIES 90	S90-130PV
521705	MOTOR-VAR-DISPL 51MD160	51D160-A-D5-N-E1-A5-A-N-G0-NNN-050-AA-F0-03-00	SERIES 51	S51-160MV
521908	PUMP-VAR-DISPL CW 20PV070	SPV2/070--R3D-PS18X-VML500-491-A1	SERIES 20	S20-070PV
521912	PUMP-VAR-DISPL CW 20PV089	SPV2/089--R3D-PS18X-VML500-492-A1	SERIES 20	S20-089PV
521960	PUMP-VAR-DISPL CW TMP089	TMP089-NFPE12-RNNCNNNNN1	TMM / TMP	TMP089
521968	PUMP-VAR-DISPL CW 20PV089	SPV2/089--R3A-PS183-VML111-B1	SERIES 20	S20-089PV
521969	PUMP-VAR-DISPL CW 20PV089	SPV2/089--R6Z-PS183-VES318-A1	SERIES 20	S20-089PV
521970	PUMP-VAR-DISPL CCW 20PV089	SPV2/089--L6Z-PS183-VES318-A1	SERIES 20	S20-089PV
522086	DOSKA KRYCIA ABDECKPLATTE SMF		SERIES 20	PARTS - S20 - Unique
5254056	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-E2-A5-A-N-G0-NNN-060-AA-F3-03-00	SERIES 51	S51-250MV
5254079	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-E2-A5-A-N-G0-NNN-125-AA-F3-03-00	SERIES 51	S51-250MV
5254128	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-T2-R5-L-N-G0-ANB-058-AA-G3-00-B2	SERIES 51	S51-250MV
5254130	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-TA-C2-L-N-G0-NNN-072-AA-G0-00-A6	SERIES 51	S51-250MV
5254132	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-TA-C2-L-N-G0-NNN-064-AA-G0-00-B0	SERIES 51	S51-250MV
5254137	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-N-TA-C2-L-N-G0-NNN-168-AA-G0-00-B0	SERIES 51	S51-250MV
5254138	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-T1-C0-L-N-G0-ACA-050-AA-G0-00-A9	SERIES 51	S51-250MV
5254139	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-T2-C0-L-N-G0-ACB-145-AA-F0-00-B1	SERIES 51	S51-250MV
5254147	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-N-HS-A1-C-H-G7-NNN-110-AA-H0-12-14	SERIES 51	S51-250MV
5254149	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-E2-A5-A-N-G0-NNN-168-AA-G0-03-00	SERIES 51	S51-250MV
5254152	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-HZ-B1-A-N-G0-NNN-095-AA-G0-03-00	SERIES 51	S51-250MV
5254155	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-ES-L4-J-Y-C8-ACA-074-AA-H0-15-28	SERIES 51	S51-250MV
5254156	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-T1-C0-L-N-G0-NNN-050-AA-F0-00-B0	SERIES 51	S51-250MV
5254157	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-TA-C2-L-N-G0-NNN-120-AA-H0-00-C7	SERIES 51	S51-250MV
5254158	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-N2-NN-N-N-A0-ABA-050-AA-G0-00-00	SERIES 51	S51-250MV
5254159	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-N-HS-A2-B-E-G6-NNN-083-AA-G3-05-34	SERIES 51	S51-250MV
5254161	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-E1-A5-A-N-K7-NNN-100-AA-G0-03-00	SERIES 51	S51-250MV
5254162	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-E2-A5-A-N-G0-NNN-103-AA-H0-03-00	SERIES 51	S51-250MV
5254163	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-TH-C2-L-N-G0-NNN-050-AA-NN-00-B3	SERIES 51	S51-250MV
5254168	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-HZ-B1-B-N-C2-NNN-066-AA-G3-07-00	SERIES 51	S51-250MV
5254169	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-E2-A5-A-N-G0-NNN-145-AA-G0-03-00	SERIES 51	S51-250MV
5254175	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-TA-C2-L-N-K7-NNN-085-AA-G3-00-B4	SERIES 51	S51-250MV
5254178	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-EQ-A2-J-Y-G6-ABA-050-AA-G0-15-32	SERIES 51	S51-250MV
5254180	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-N-TH-C0-L-N-G0-NNN-090-AA-F0-00-B1	SERIES 51	S51-250MV
5254186	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-T1-C0-L-N-G0-ACA-110-AA-G0-00-C5	SERIES 51	S51-250MV
5254187	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-D-HZ-B1-B-H-G5-NNN-050-AA-F3-11-00	SERIES 51	S51-250MV

5254189	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-HZ-B1-C-H-C2-NNN-065-AA-NN-15-00	SERIES 51	S51-250MV
5254193	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-E2-A5-A-N-G0-NNN-160-AA-G0-03-00	SERIES 51	S51-250MV
5254194	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-N-T1-C0-L-N-G0-ACA-050-AA-F0-00-A9	SERIES 51	S51-250MV
5254195	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-T1-C0-L-N-G0-ACA-168-AA-G0-00-C5	SERIES 51	S51-250MV
5254199	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-N-HZ-B1-A-N-G0-NNN-050-AA-G0-03-00	SERIES 51	S51-250MV
525691	SHAFT		LIGHT DUTY	PARTS - Low Power
535104	COVER		LIGHT DUTY	PARTS - Low Power
550/1/39341	C44.0/17.0L39341		DYNAMATIC SWN	DYNAMATIC SWN Finished Units
554709	END CAP		LIGHT DUTY	PARTS - Low Power
555631	BUSHING		LIGHT DUTY	PARTS - Low Power
555664	CHARGE PUMP KIT		LIGHT DUTY	PARTS - Low Power
556357	END CAP		LIGHT DUTY	PARTS - Low Power
560250	EYE BOLT		LIGHT DUTY	PARTS - Low Power
572875	INTERMEDIATE FLANGE		LIGHT DUTY	PARTS - Low Power
575811	SEAL KIT		LIGHT DUTY	PARTS - Low Power
576140	MANIFOLD BLOC		LIGHT DUTY	PARTS - Low Power
579797	GASKET-HOUSING, SPV18		LIGHT DUTY	PARTS - Low Power
585497	PUMP-VAR-DISPL CW 20PV119	SPV2/119--R3Z-PS333-VML132-A1	SERIES 20	S20-119PV
585687	SEAL KIT		LIGHT DUTY	PARTS - Low Power
585745	SEAL KIT		LIGHT DUTY	PARTS - Low Power
592253	SHAFT		SERIES 20	PARTS - S20 - Unique
59235333	MOTOR-FIXED-DISPL 90MF055	90-M-055-NC-0-N-8-N-0-C6-W-00-EAG-00-00-24	SERIES 90	S90-055MF
596437	HOUSING		LIGHT DUTY	PARTS - Low Power
596874	END CAP		SERIES 20	PARTS - S20 - Unique
598110	HOUSING		LIGHT DUTY	PARTS - Low Power
599308	END CAP		LIGHT DUTY	PARTS - Low Power
600107	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-EG-80-S-3-C8-J-06-NNN-26-42-24	SERIES 90	S90-180PV
600108	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-NN-80-S-3-C8-J-06-NNN-26-42-24	SERIES 90	S90-180PV
600509	PUMP-VAR-DISPL CCW 42PV28	42-L-28-C-E1A6-03-B-2-G-2-F-N-N-34-34-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
600716	PUMP-VAR-DISPL CW 90PV075	90R075-HF-5-NN-60-P-4-C7-D-04-GBA-32-32-20	SERIES 90	S90-075PV
600728	MOTOR-VAR-DISPL 51MD110	51D110-A-D4-N-J1-K1-D-E-H4-NNN-040-AA-E6-20-22	SERIES 51	S51-110MV
600805	PUMP-VAR-DISPL CW 90PV042	90R042-EA-1-BB-80-S-3-C3-C-03-GBA-35-35-20	SERIES 90	S90-042PV
600950	PUMP-VAR-DISPL CW 42PV041	42-R-41-E-LNN3-03-B-5-G-2-C-N-B-21-21-B-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
601065	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-BC-80-S-3-C8-F-04-GBA-38-38-28	SERIES 90	S90-130PV
601077	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-CD-60-P-3-C7-D-03-GBA-35-35-24	SERIES 90	S90-075PV
601085	PUMP-VAR-DISPL CW 90PV100	90R100-FD-6-CD-60-S-7-C7-F-B1-GLS-45-45-30	SERIES 90	S90-100PV

601094	PUMP-VAR-DISPL CW 90PV042	90R042-KA-1-NN-80-P-3-C3-C-03-GBA-23-23-18	SERIES 90	S90-042PV
601166	PUMP-VAR-DISPL CW 90PV042	90R042-DD-5-BB-80-S-4-C3-C-03-GCA-42-42-24	SERIES 90	S90-042PV
601182	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-L2-B1-V-A-J1-ADA-054-AA-F3-B2-00	SERIES 51	S51-160MV
601183	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-L2-B1-V-A-J1-ADA-060-AA-F3-B2-00	SERIES 51	S51-160MV
601202	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-BB-80-S-3-C7-F-03-GBA-38-38-24	SERIES 90	S90-100PV
601223	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-NN-80-T-3-C8-J-09-NNN-35-35-28	SERIES 90	S90-250PV
601242	PUMP-VAR-DISPL CW 90PV100	90R100-HF-1-BC-60-S-4-C7-F-04-GBA-26-26-18-F003	SERIES 90	S90-100PV
601261	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-BB-80-S-C-C8-H-05-NNN-38-38-20	SERIES 90	S90-180PV
601264	PUMP-VAR-DISPL CW 42PV41	42-R-41-D-E1A6-02-B-D-G-2-D-N-A-25-25-B-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
601304	PUMP-VAR-DISPL CW 42PV41	42-R-41-D-E1A6-03-B-2-G-2-F-N-V-34-34-B-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
601365	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-CD-80-S-C-C8-H-05-NNN-38-38-20	SERIES 90	S90-180PV
601366	PUMP-VAR-DISPL CCW 90PV055	90L055-KA-5-BK-80-S-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
601367	PUMP-VAR-DISPL CCW 90PV042	90L042-KA-5-AB-80-S-3-C3-B-03-GBA-35-35-24	SERIES 90	S90-042PV
601368	PUMP-VAR-DISPL CCW 90PV042	90L042-KA-5-BC-80-S-3-C3-B-03-GBA-35-35-24	SERIES 90	S90-042PV
601370	MOTOR-VAR-DISPL 51MC110-1	51C110-1--R-D3-N-B7-B3-N-N-U3-NNN-030-AA-NN-00-00	SERIES 51	S51-110MV-1
601388	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-DE-80-S-3-T4-H-03-GBA-38-38-24	SERIES 90	S90-130PV
601389	PUMP-VAR-DISPL CW 90PV130	90R130-DD-5-CD-80-S-4-F1-H-02-GBA-38-38-28-F001	SERIES 90	S90-130PV
601390	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-BC-80-S-4-S1-E-03-GBA-21-07-24-F001	SERIES 90	S90-100PV
601403	PUMP-VAR-DISPL CW 42PV28	42-R-28-D-ANNB-03-B-3-G-2-F-N-A-25-25-B-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
601407	PUMP-VAR-DISPL CW 42PV41	42-R-41-D-E1A6-02-B-4-G-2-D-N-B-34-34-B-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
601416	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-NN-80-T-3-C8-J-05-NNN-35-35-24	SERIES 90	S90-180PV
601417	PUMP-VAR-DISPL CW 90PV055	90R055-KA-5-AD-80-S-3-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV
601432	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-BC-80-S-3-C8-F-03-GBA-42-42-24	SERIES 90	S90-130PV
601460	PUMP-VAR-DISPL CCW 90PV042	90L042-KA-5-AB-80-S-3-C3-C-03-GBA-35-35-24	SERIES 90	S90-042PV
601470	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-NN-80-S-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
601504	PUMP-VAR-DISPL CW 90PV100	90R100-HF-5-NN-60-L-4-C7-E-00-FAD-26-26-20-F001	SERIES 90	S90-100PV
601511	PUMP-VAR-DISPL CW 90PV100	90R100-PA-5-CD-80-S-3-C7-E-06-GBA-43-43-28	SERIES 90	S90-100PV
601514	PUMP-VAR-DISPL CW 90PV042	90R042-HF-5-NN-80-P-4-C3-C-00-FAD-29-29-20	SERIES 90	S90-042PV
601954	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-5-CD-80-T-3-C8-K-03-NNN-42-42-24	SERIES 90	S90-250PV
601958	MOTOR-FIXED-DISPL 90MF100	90-M-100-NC-O-N-8-N-O-TJ-W-00-NNN-00-00-E6	SERIES 90	S90-100MF
601962	PUMP-VAR-DISPL CW 90PV042	90R042-MA-5-AB-80-S-3-C3-C-03-GBA-42-42-24	SERIES 90	S90-042PV
601978	PUMP-VAR-DISPL CW 90PV042	90R042-PA-5-BB-80-S-4-C3-C-03-GBA-42-42-32-F019	SERIES 90	S90-042PV
604744	HOUSING		LIGHT DUTY	PARTS - Low Power
607143	PUMP-VAR-DISPL CW 20PV070	SPV2/070--R3Z-PS183-VES302-A1	SERIES 20	S20-070PV
613331	PUMP-VAR-DISPL CW 20PV089	SPV2/089--R3Z-PS183-VHA602-A1	SERIES 20	S20-089PV
613976	PUMP-VAR-DISPL CW 20PV166	SPV2/166--R6Z-PS333-VES302-A1	SERIES 20	S20-166PV

618207	COMPRESSION SPRING		LIGHT DUTY	PARTS - Low Power
620658	SEAL KIT		LIGHT DUTY	PARTS - Low Power
624684	END CAP		M46	PARTS - M46
627745	DISPLACEMENT CONTROL		SERIES 20	PARTS - S20 - Unique
627760	DISPLACEMENT CONTROL		SERIES 20	PARTS - S20 - Unique
627778	DISPLACEMENT CONTROL		SERIES 20	PARTS - S20 - Unique
627802	DISPLACEMENT CONTROL		SERIES 20	PARTS - S20 - Unique
627851	DISPLACEMENT CONTROL		SERIES 20	PARTS - S20 - Unique
627893	DISPLACEMENT CONTROL		SERIES 20	PARTS - S20 - "No Name"
628438	SPOOL BUSHING		M46	PARTS - M46
628479	ORIFICE		M46	PARTS - M46
629220	EL.HYDR.SERVOVERST. MCV104A-07-06-07-11		SERIES 20	PARTS - S20 - "No Name"
629600	DISPLACEMENT CONTROL		SERIES 20	PARTS - S20 - Unique
631903	SEAL KIT		LIGHT DUTY	PARTS - Low Power
636811	HOUSING		LIGHT DUTY	PARTS - Low Power
636829	HOUSING		LIGHT DUTY	PARTS - Low Power
637165	SEAL KIT		LIGHT DUTY	PARTS - Low Power
638098	SEAL KIT		LIGHT DUTY	PARTS - Low Power
642686	SEAL KIT		M46	PARTS - M46
642736	DISPLACEMENT CONTROL		SERIES 20	PARTS - S20 - Unique
642876	EL.HY.SERVOVERST. MCV104A-02-03-06-00		SERIES 20	PARTS - S20 - Unique
643122	PUMP-OPEN-CIRCUIT-VAR OPV1/052	OPV1/052--L3Z-RNU900-180-B1	DAIKIN	052PV - L50 - OPV 1
643148	MOTOR-FIXED-DISPL 20MF089	SMF2/089--B3A-MS42422-A1	SERIES 20	S20-089MF
646711	PUMP-VAR-DISPL CW 20PV052	SPV2/052--R3Z-PS123-VES309-A1	SERIES 20	S20-052PV
650424	MOTOR-FIXED-DISPL 20MF070	SMF2/070--B3Z-MS21112-149-A1	SERIES 20	S20-070MF
652032	PLUG		M46	PARTS - M46
656132	SEAL KIT MMF046		M46	PARTS - M46
656744	SEAL KIT		LIGHT DUTY	PARTS - Low Power
657817	HRIADEL, MOT.2/334 WELLE MO.2/334 4		SERIES 20	PARTS - S20 - Unique
658815	END CAP		DAIKIN	PARTS - OPV
659391	ADJUSTING SCREW		DAIKIN	PARTS - OPV
660019	COVER		DAIKIN	PARTS - OPV
660027	COVER		DAIKIN	PARTS - OPV
660316	KIT CONTROL VALVE		LIGHT DUTY	PARTS - Low Power
665406	PUMP-VAR-DISPL MPV046	MPV-046-C-B-A-G-L-B-B-AA-A-A-BFF-AB-U-ED-C-NNN	M46	M46-046PV
667493	SEAL KIT		LIGHT DUTY	PARTS - Low Power

673244	TURCON-GLYDRING		M46	PARTS - M46
674606	HYDR.DISPLACEMENT CONTROL ASSY.		SERIES 20	PARTS - S20 - "No Name"
674614	HYDR.DISPLACEMENT CONTROL		SERIES 20	PARTS - S20 - Unique
675637	MOTOR-FIXED-DISPL 90MF075	90-M-075-NC-0-N-7-N-0-C7-W-00-NNN-00-00-F0	SERIES 90	S90-075MF
679654	PUMP-VAR-DISPL CW 20PV089	SPV2/089--R6Z-PS183-CXX-B1	SERIES 20	S20-089PV
684373	CONNECTOR		M46	PARTS - M46
686626	SHAFT SEAL		LIGHT DUTY	PARTS - Low Power
689729	PUMP-VAR-DISPL CW 90PV075	90R075-MA-1-BC-80-S-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-075PV
689729C	PUMP-VAR-DISPL CW 90PV075	90-R-075-MA-1-BC-80-S-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-075PV
692343	SEAL KIT		M46	PARTS - M46
700011	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-1-AB-60-S-3-C7-F-21-GBA-42-42-24	SERIES 90	S90-100PV
700014	PUMP-VAR-DISPL CCW 42PV41	42-L-41-D-ANNB-02-B-3-G-2-H-N-N-25-25-B-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
700016	PUMP-VAR-DISPL CCW 90PV055	90L055-KA-2-BB-60-S-3-C6-C-04-GBA-35-35-24	SERIES 90	S90-055PV
700019	MOTOR-VAR-DISPL 51MV110	51V110-R-C8-N-HS-A1-B-E-E2-NNN-054-AA-F3-10-25	SERIES 51	S51-110MV
700025	PUMP-VAR-DISPL CW 42PV41	42-R-41-D-ANNB-02-B-2-G-2-H-N-B-34-34-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
700026	PUMP-VAR-DISPL CCW 42PV41	42-L-41-D-E1A6-02-B-3-G-2-F-N-V-30-30-B-A-A-NNN-NNN	SERIES 42	S42-041PV/051PV
700030	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-2-AB-60-S-4-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
700032	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-BC-80-S-3-C8-H-03-GBA-45-45-24	SERIES 90	S90-130PV
700034	PUMP-VAR-DISPL CW 90PV042	90R042-KA-1-BB-80-S-3-C3-C-03-GBA-42-42-24	SERIES 90	S90-042PV
700035	PUMP-VAR-DISPL CW 90PV100	90R100-KA-1-BC-60-S-3-S1-E-03-GBA-42-42-30	SERIES 90	S90-100PV
700038	PUMP-VAR-DISPL CW 90PV130	90R130-MA-5-BC-80-S-4-C8-H-02-GBA-42-42-24	SERIES 90	S90-130PV
700041	PUMP-VAR-DISPL CW 42PV28	42-R-28-D-E1A6-02-B-D-G-2-C-N-A-25-25-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
700043	PUMP-VAR-DISPL CW 90PV075	90R075-DD-5-NN-60-S-4-S1-D-G8-FAB-42-42-24	SERIES 90	S90-075PV
700045	PUMP-VAR-DISPL CW 90PV180	90R180-MA-1-BC-80-S-4-C8-J-02-NNN-42-42-26	SERIES 90	S90-180PV
700046	PUMP-VAR-DISPL CCW 90PV075	90L075-HF-5-NN-60-P-3-D9-D-03-GBA-35-35-18	SERIES 90	S90-075PV
700048	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-BC-80-L-4-F1-F-03-GBA-29-20-20	SERIES 90	S90-130PV
700051	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-AB-60-P-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-075PV
700052	PUMP-VAR-DISPL CW 42PV28	42-R-28-D-E1A6-02-C-3-A-2-F-N-A-34-34-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
700053	PUMP-VAR-DISPL CCW 42PV28	42-L-28-D-E1A6-02-B-D-G-2-C-N-N-17-17-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
700056	PUMP-VAR-DISPL CW 90PV100	90R100-DD-1-CD-60-S-4-T2-E-02-FAC-42-42-24	SERIES 90	S90-100PV
700057	PUMP-VAR-DISPL CW 90PV042	90R042-KA-1-NN-80-S-4-C3-C-03-GBA-35-35-24	SERIES 90	S90-042PV
700059	PUMP-VAR-DISPL CW 90PV055	90R055-KA-1-BC-60-S-4-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV
700060	PUMP-VAR-DISPL CW 90PV075	90R075-KA-6-BB-60-P-3-C7-E-03-GBA-48-48-24	SERIES 90	S90-075PV
700061	PUMP-VAR-DISPL CW 90PV055	90R055-KA-1-NN-60-S-3-C6-C-04-GBA-32-32-24	SERIES 90	S90-055PV
700062	DISPLACEMENT CONTROL		M46	PARTS - M46
700064	PUMP-VAR-DISPL CCW 90PV042	90L042-KA-1-NN-80-S-3-C3-C-35-GBA-45-45-24	SERIES 90	S90-042PV

700065	PUMP-VAR-DISPL CW 90PV075	90R075-KA-1-BC-60-P-3-C7-E-04-GBA-45-45-24	SERIES 90	S90-075PV
700066	PUMP-VAR-DISPL CW 90PV130	90R130-MA-5-DE-80-L-4-C8-F-05-GBA-35-35-24	SERIES 90	S90-130PV
700067	PUMP-VAR-DISPL CW 90PV130	90R130-MA-5-CD-80-L-4-F1-F-C7-GBA-35-35-24	SERIES 90	S90-130PV
700069	PUMP-VAR-DISPL CW 90PV100	90R100-MA-1-BC-60-S-4-C7-F-03-GBA-38-38-24	SERIES 90	S90-100PV
700071	PUMP-VAR-DISPL CW 90PV075	90R075-MA-1-BB-60-S-3-C6-D-04-FAX-42-42-26	SERIES 90	S90-075PV
700075	PUMP-VAR-DISPL CW 42PV41	42-R-41-D-ANNB-02-B-D-G-2-F-N-B-34-34-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
700082	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-NN-80-L-4-C7-E-03-GBA-29-29-24	SERIES 90	S90-100PV
700083	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-BC-80-L-3-C8-F-04-GBA-42-42-24	SERIES 90	S90-130PV
700085	PUMP-VAR-DISPL CCW 90PV055	90L055-MA-1-AB-60-S-3-T1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
700089	PUMP-VAR-DISPL CW 90PV130	90R130-MA-5-BC-80-S-4-F1-F-02-GBA-42-42-24	SERIES 90	S90-130PV
700090	PUMP-VAR-DISPL CW 90PV130	90R130-MA-5-BC-80-S-4-F1-H-04-GBA-42-42-24	SERIES 90	S90-130PV
700092	PUMP-VAR-DISPL CW 90PV130	90R130-HF-5-CD-80-S-3-C8-H-02-GBA-38-38-24	SERIES 90	S90-130PV
700093	PUMP-VAR-DISPL CW 90PV100	90R100-HF-5-CD-60-S-3-C7-E-02-GBA-38-38-24	SERIES 90	S90-100PV
700097	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-AB-60-S-4-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
700098	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-AB-80-S-4-C3-C-03-GBA-42-42-24	SERIES 90	S90-042PV
700099	PUMP-VAR-DISPL CCW 90PV042	90L042-KA-5-AB-80-S-4-C3-C-03-GBA-42-42-24	SERIES 90	S90-042PV
700101	PUMP-VAR-DISPL CCW 90PV100	90L100-MA-5-NN-60-R-3-F1-E-03-FAB-42-42-28	SERIES 90	S90-100PV
700102	PUMP-VAR-DISPL CCW 90PV055	90L055-KA-5-AB-60-S-4-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV
700103	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-BB-60-S-3-C7-D-03-GBA-35-35-24	SERIES 90	S90-075PV
700106	PUMP-VAR-DISPL CCW 90PV055	90L055-DD-5-NN-80-S-4-C6-C-G4-FAD-20-20-20	SERIES 90	S90-055PV
700107	PUMP-VAR-DISPL CW 90PV055	90R055-MA-5-NN-60-P-4-C6-C-05-GBA-32-32-24	SERIES 90	S90-055PV
700109	PUMP-VAR-DISPL CW 90PV055	90R055-KA-5-NN-60-S-4-S1-B-04-GBA-30-30-24	SERIES 90	S90-055PV
700119	PUMP-VAR-DISPL CCW 90PV075	90L075-MA-2-BC-60-S-3-C7-D-03-GBA-14-32-24	SERIES 90	S90-075PV
700121	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-NN-80-S-3-C8-F-03-GBA-38-38-30	SERIES 90	S90-130PV
700123	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-2-AB-80-T-3-F1-J-03-NNN-42-42-24	SERIES 90	S90-180PV
700124	PUMP-VAR-DISPL CW 90PV055	90R055-KA-5-BC-60-S-3-C6-C-03-GBA-42-42-24	SERIES 90	S90-055PV
700128	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-2-BB-80-S-3-C8-F-04-GBA-42-42-24	SERIES 90	S90-130PV
700129	PUMP-VAR-DISPL CCW 42PV41	42-L-41-D-E1A6-03-B-2-G-2-C-N-B-21-21-B-E-E-NNN-NNN	SERIES 42	S42-041PV/051PV
700130	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-AB-80-S-3-C8-H-04-GBA-45-14-24	SERIES 90	S90-130PV
700132	PUMP-VAR-DISPL CW 90PV075	90R075-KP-5-CD-60-P-3-T2-D-03-GBA-38-14-24	SERIES 90	S90-075PV
700133	PUMP-VAR-DISPL CCW 90PV100	90L100-MA-5-NN-60-S-3-C7-E-02-GBA-42-42-28	SERIES 90	S90-100PV
700134	PUMP-VAR-DISPL CW 90PV250	90R250-MA-5-EG-80-S-4-C8-K-02-NNN-42-42-24	SERIES 90	S90-250PV
700136	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-DG-80-S-3-C8-H-03-GBA-42-42-24	SERIES 90	S90-130PV
700143	PUMP-VAR-DISPL CW 42PV41	42-R-41-D-E1A6-02-B-3-G-2-C-N-A-25-25-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
700144	PUMP-VAR-DISPL CW 90PV075	90R075-MA-5-BC-60-S-4-C6-E-02-GBA-42-42-24	SERIES 90	S90-075PV
700148	PUMP-VAR-DISPL CW 90PV055	90R055-KA-1-BC-60-S-4-S1-D-02-GBA-42-42-24	SERIES 90	S90-055PV

700149	PUMP-VAR-DISPL CW 42PV41	42-R-41-D-ANN5-02-B-2-G-2-F-N-V-34-34-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
700150	PUMP-VAR-DISPL CW 42PV41	42-R-41-D-ANN5-02-B-2-G-2-F-N-A-34-34-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
700154	PUMP-VAR-DISPL CCW 90PV042	90L042-KA-5-BC-80-S-3-C3-B-03-GBA-42-42-24	SERIES 90	S90-042PV
700158	PUMP-VAR-DISPL CW 90PV075	90R075-DC-5-CD-80-S-4-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
700159	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-AB-60-S-3-C7-D-03-GBA-35-35-24	SERIES 90	S90-075PV
700160	PUMP-VAR-DISPL CW 42PV04A	42-R-4A-D-G1A1-72-J-2-G-2-F-5-B-28-28-B-0-0-NNN-NNN	SERIES 42	S42-041PV/051PV
700162	PUMP-VAR-DISPL CCW 90PV180	90L180-MA-5-BC-80-S-4-C8-J-C5-NNN-35-35-24	SERIES 90	S90-180PV
700164	PUMP-VAR-DISPL CW 90PV055	90R055-HF-5-CD-80-S-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
700166	MOTOR-VAR-DISPL 51MD110	51D110-R-D4-N-N2-NN-N-N-A0-NNN-042-AA-F0-00-00	SERIES 51	S51-110MV
700170	PUMP-VAR-DISPL CW 90PV055	90R055-FC-5-AB-60-P-7-C6-C-B1-EFI-32-32-30	SERIES 90	S90-055PV
700171	PUMP-VAR-DISPL CW 90PV130	90R130-MA-5-NN-80-L-3-C8-F-03-GBA-42-42-24	SERIES 90	S90-130PV
700172	PUMP-VAR-DISPL CW 42PV41	42-R-41-D-E1A6-02-B-D-G-2-C-N-A-34-34-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
700173	PUMP-VAR-DISPL CW 42PV41	42-R-41-D-F2NN-72-J-D-G-2-C-N-A-34-34-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
700182	PUMP-VAR-DISPL CW 90PV100	90R100-MA-5-AB-60-S-4-C7-F-C5-GBA-38-38-24	SERIES 90	S90-100PV
700183	PUMP-VAR-DISPL CW 90PV100	90R100-MA-5-NN-80-R-4-C7-E-03-GBA-20-20-30	SERIES 90	S90-100PV
700185	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-AB-80-S-3-C3-C-00-GBA-35-35-24	SERIES 90	S90-042PV
700186	PUMP-VAR-DISPL CW 90PV055	90R055-KA-5-BC-60-P-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
700189	PUMP-VAR-DISPL CW 42PV41	42-R-41-D-F2NN-72-J-3-G-2-C-N-N-34-34-B-A-A-NNN-NNN	SERIES 42	S42-041PV/051PV
700198	PUMP-VAR-DISPL CW 90PV042	90R042-CA-5-AB-80-P-7-C3-C-00-EEG-32-32-20	SERIES 90	S90-042PV
700200	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-BB-80-R-3-C8-H-03-GBA-30-30-24	SERIES 90	S90-130PV
700206	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-CD-80-P-3-C8-H-03-GBA-30-30-24	SERIES 90	S90-130PV
700208	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-DE-80-L-3-C8-H-03-GBA-42-42-24	SERIES 90	S90-130PV
700210	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-AB-80-L-3-F1-H-03-GBA-42-42-24	SERIES 90	S90-130PV
700218	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-NN-60-S-3-C7-D-04-GBA-35-35-24	SERIES 90	S90-075PV
700219	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-AB-60-R-3-S1-E-03-GBA-42-42-26	SERIES 90	S90-100PV
700220	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-BB-60-R-3-S1-E-03-GBA-42-42-26	SERIES 90	S90-100PV
700221	PUMP-VAR-DISPL CW 42PV41	42-R-41-C-E1A6-02-B-2-B-2-E-N-A-25-25-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
700225	PUMP-VAR-DISPL CW 42PV41	42-R-41-D-ANN5-02-B-2-B-2-C-N-A-25-25-B-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
700227	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-BC-80-S-3-C8-H-03-GBA-42-42-24	SERIES 90	S90-130PV
700230	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-NN-60-R-4-C7-F-04-GBA-42-42-24	SERIES 90	S90-100PV
700231	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-NN-80-S-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-100PV
700232	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-NN-80-S-3-C8-H-03-GBA-35-35-24	SERIES 90	S90-130PV
700233	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-NN-80-S-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-075PV
700236	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-BC-80-S-3-C8-J-03-NNN-42-42-30	SERIES 90	S90-180PV
700246	PUMP-VAR-DISPL CCW 90PV055	90L055-KA-5-AB-60-S-3-S1-C-03-GBA-29-29-24	SERIES 90	S90-055PV
700247	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-CD-80-S-3-C8-H-03-FAD-45-45-24	SERIES 90	S90-130PV

700254	PUMP-VAR-DISPL MPV035	MPV-035-D-B-A-A-L-S-F-AA-A-A-BDD-DR-A-FF-A-NNN	M35/44	035PV
700255	PUMP-VAR-DISPL CCW 90PV180	90L180-MA-5-NN-80-S-3-C8-J-C5-NNN-42-42-24	SERIES 90	S90-180PV
700259	MOTOR-VAR-DISPL 51MV110-1	51V110-1--A-C8-N-T2-CA-N-N-X1-NNN-038-AA-F3-00-32	SERIES 51	S51-110MV-1
700264	PUMP-VAR-DISPL CCW 90PV130	90L130-HF-5-BC-80-L-3-F1-H-03-GBA-32-32-24	SERIES 90	S90-130PV
700266	PUMP-VAR-DISPL CW 90PV130	90R130-HF-5-DE-80-L-3-C8-H-03-GBA-32-32-24	SERIES 90	S90-130PV
700270	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-D-T1-L5-L-N-G0-NNN-092-AA-G0-00-B8	SERIES 51	S51-160MV
700274	PUMP-VAR-DISPL CW 42PV41	42-R-41-D-ANNB-03-B-D-G-2-C-N-A-21-21-B-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
700275	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-NN-80-P-3-C8-H-03-GBA-42-42-24	SERIES 90	S90-130PV
700276	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-B-N2-NN-N-N-A0-NNN-032-AA-F0-00-00	SERIES 51	S51-160MV
700280	PUMP-VAR-DISPL CCW 90PV042	90L042-KA-5-BB-80-S-4-C3-C-03-GBA-30-30-24	SERIES 90	S90-042PV
700281	PUMP-VAR-DISPL CCW 90PV130	90L130-MA-5-BC-80-S-3-C8-H-04-GBA-35-35-24	SERIES 90	S90-130PV
700282	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-CD-80-S-3-C8-J-03-NNN-35-35-24	SERIES 90	S90-180PV
700283	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-E2-A5-A-N-G0-ADA-032-AA-G0-03-00	SERIES 51	S51-080MV
700290	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-NN-80-S-4-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
700300	PUMP-VAR-DISPL CW 90PV075	90R075-KA-6-BB-60-P-3-C7-E-03-FAB-48-48-24	SERIES 90	S90-075PV
700303	PUMP-VAR-DISPL CCW 90PV180	90L180-MA-5-NN-80-T-3-C8-J-03-NNN-42-42-24	SERIES 90	S90-180PV
700306	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-NN-80-S-3-C3-C-03-GBA-35-35-18	SERIES 90	S90-042PV
700307	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-AB-60-S-3-S1-F-03-GBA-32-32-20	SERIES 90	S90-100PV
700308	PUMP-VAR-DISPL CW 90PV075	90R075-KA-1-AB-60-S-3-S1-E-03-GBA-20-20-24	SERIES 90	S90-075PV
700309	PUMP-VAR-DISPL CW 90PV042	90R042-DC-1-BC-80-S-3-C3-C-GB-GBA-38-32-28	SERIES 90	S90-042PV
700311	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-NN-80-S-3-C3-C-03-GBA-35-35-20	SERIES 90	S90-042PV
700314	PUMP-VAR-DISPL CW 90PV180	90R180-MA-5-CD-80-T-4-C8-J-05-NNN-32-32-24	SERIES 90	S90-180PV
700315	PUMP-VAR-DISPL CCW 90PV130	90L130-MA-5-NN-80-S-4-C8-H-03-GBA-35-35-24	SERIES 90	S90-130PV
700327	PUMP-VAR-DISPL CW 90PV130	90R130-DD-5-NN-80-L-7-C8-F-00-GCG-35-35-30	SERIES 90	S90-130PV
700330	PUMP-VAR-DISPL CW 90PV055	90R055-MA-5-AB-60-P-4-T1-C-C5-GBA-32-32-24	SERIES 90	S90-055PV
700335	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-E2-A2-A-N-F1-NNN-100-AA-G0-03-25	SERIES 51	S51-250MV
700337	PUMP-VAR-DISPL CCW 90PV055	90L055-KA-5-NN-60-S-3-C6-C-03-GBA-42-42-24	SERIES 90	S90-055PV
700338	PUMP-VAR-DISPL CW 90PV055	90R055-KA-5-CD-80-S-3-S1-D-03-GBA-32-32-22	SERIES 90	S90-055PV
700342	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-CD-80-T-C-C8-J-03-NNN-26-26-24	SERIES 90	S90-180PV
700343	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-CD-80-S-3-C8-J-09-NNN-35-35-28	SERIES 90	S90-250PV
700345	PUMP-VAR-DISPL CW 42PV28	42-R-28-D-ANN3-02-B-3-G-2-C-N-A-25-25-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
700347	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-HZ-B1-A-N-C2-NNN-050-AA-E6-05-00	SERIES 51	S51-080MV
700354	PUMP-VAR-DISPL CCW 90PV075	90L075-KP-5-AB-80-S-3-T6-D-00-EFC-38-14-24	SERIES 90	S90-075PV
700356	PUMP-VAR-DISPL CCW 90PV042	90L042-HF-5-NN-80-S-4-C3-B-03-GBA-35-35-24	SERIES 90	S90-042PV
700361	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-E1-A5-A-N-G0-NNN-040-AA-F0-03-00	SERIES 51	S51-080MV
700365	PUMP-VAR-DISPL CCW 90PV130	90L130-MA-5-CD-80-S-3-C8-F-C6-GBA-35-35-24	SERIES 90	S90-130PV

700366	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-BC-80-S-4-C8-F-03-GBA-42-42-24	SERIES 90	S90-130PV
700367	PUMP-VAR-DISPL CW 90PV042	90R042-DD-2-AB-80-S-3-C3-C-GB-GBA-29-29-20	SERIES 90	S90-042PV
700374	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-NN-80-R-4-G1-E-05-FAP-35-35-42	SERIES 90	S90-075PV
700376	PUMP-VAR-DISPL CW 90PV042	90R042-FC-5-AB-80-S-7-C3-C-B4-EFI-42-42-32	SERIES 90	S90-042PV
700379	MOTOR-VAR-DISPL 51MD080-1	51D080-1--A-D2-N-P7-P7-N-N-X1-NNN-022-AA-F3-00-AA	SERIES 51	S51-080MV-1
700380	MOTOR-VAR-DISPL 51MD110-1	51D110-1--A-D3-N-P7-P7-N-N-X1-NNN-068-AA-F3-00-AA	SERIES 51	S51-110MV-1
700381	MOTOR-VAR-DISPL 51MD060-1	51D060-1--A-D1-N-P7-P7-N-N-X1-NNN-022-AA-F3-00-AA	SERIES 51	S51-060MV-1
700384	MOTOR-VAR-DISPL 51MV110	51V110-R-F1-N-EQ-A5-K-Y-A6-NNN-022-AA-F0-38-00	SERIES 51	S51-110MV
700385	PUMP-VAR-DISPL CW 42PV41	42-R-41-D-E1A6-01-B-3-G-2-F-N-N-34-34-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
700386	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-EG-80-T-3-C8-J-03-NNN-32-32-24	SERIES 90	S90-180PV
700389	PUMP-VAR-DISPL CCW 90PV055	90L055-KA-5-NN-80-S-3-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV
700391	PUMP-VAR-DISPL CCW 90PV130	90L130-HF-5-BC-80-S-4-F1-H-03-GBA-42-42-30	SERIES 90	S90-130PV
700394	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-CD-80-S-4-C8-J-03-NNN-42-42-24	SERIES 90	S90-180PV
700395	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-BC-60-S-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
700396	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-AB-60-S-4-C7-F-03-GBA-38-38-24	SERIES 90	S90-100PV
700399	PUMP-VAR-DISPL MPV046	MPV-046-C-B-B-B-S-B-AA-A-A-BGG-CB-A-GG-A-NNN	M46	M46-046PV
700404	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-CD-80-R-3-C8-H-03-GBA-35-35-24	SERIES 90	S90-130PV
700406	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-NN-60-S-3-C6-D-03-GBA-42-42-24	SERIES 90	S90-075PV
700412	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-CD-80-S-4-C8-H-03-GBA-38-38-24	SERIES 90	S90-130PV
700413	PUMP-VAR-DISPL CW 90PV130	90R130-MA-5-BC-80-S-3-C8-H-C6-GBA-42-42-24	SERIES 90	S90-130PV
700414	PUMP-VAR-DISPL CW 42PV41	42-R-41-D-ANN3-02-B-2-B-2-C-N-A-23-23-B-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
700420	PUMP-VAR-DISPL CW 90PV075	90R075-KA-1-NN-80-L-3-S1-D-00-GBA-42-42-24	SERIES 90	S90-075PV
700421	PUMP-VAR-DISPL CW 90PV075	90R075-KA-1-CD-80-L-3-S1-D-00-GBA-42-42-24	SERIES 90	S90-075PV
700423	MOTOR-FIXED-DISPL 90MF075	90-M-075-NC-0-N-7-N-0-C6-W-00-EFA-00-00-F3	SERIES 90	S90-075MF
700424	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-NN-60-P-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
700425	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-AB-80-T-4-C8-J-05-NNN-32-32-24	SERIES 90	S90-180PV
700427	MOTOR-FIXED-DISPL 90MF042	90-M-042-NC-0-N-8-N-0-K4-W-00-EFA-00-00-F0	SERIES 90	S90-042MF
700428	PUMP-VAR-DISPL CCW 90PV130	90L130-MA-5-NN-80-S-3-C8-H-03-GBA-30-30-24	SERIES 90	S90-130PV
700429	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-CD-80-P-3-F1-E-03-GBA-20-20-24	SERIES 90	S90-100PV
700430	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-CD-80-L-3-T4-H-04-GBA-38-14-24	SERIES 90	S90-130PV
700432	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-NN-60-S-3-C7-F-00-GBA-37-37-24	SERIES 90	S90-100PV
700434	PUMP-VAR-DISPL CW 90PV075	90R075-KP-5-AB-80-L-3-S1-D-00-EAS-38-14-24	SERIES 90	S90-075PV
700438	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-AB-80-S-3-C8-H-03-GBA-42-42-24	SERIES 90	S90-130PV
700441	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-BC-60-S-3-C7-E-03-GBA-23-23-24	SERIES 90	S90-075PV
700444	PUMP-VAR-DISPL CW 42PV28	42-R-28-D-E1A6-02-B-2-C-2-C-N-A-21-21-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
700446	PUMP-VAR-DISPL CCW 42PV28	42-L-28-D-E1A6-03-C-2-A-2-F-N-A-30-30-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV

700448	PUMP-VAR-DISPL CW 90PV042	90R042-PB-5-BC-80-S-3-C3-C-09-GBA-42-42-24	SERIES 90	S90-042PV
700449	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-BC-60-R-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
700454	PUMP-VAR-DISPL CW 90PV055	90R055-KA-5-BC-60-S-3-C6-D-04-GBA-35-35-24	SERIES 90	S90-055PV
700460	PUMP-VAR-DISPL CW 42PV41	42-R-41-D-E1A6-02-A-N-A-3-H-N-A-25-25-N-N-N-NNN	SERIES 42	S42-041PV/051PV
700461	PUMP-VAR-DISPL CW 42PV28	42-R-28-C-E1A6-03-B-3-G-2-C-N-N-34-34-N-N-N-NNN	SERIES 42	S42-028PV/032PV
700462	MOTOR-VAR-DISPL 51MV080	51V080-R-C7-N-E2-A5-A-N-A6-ADA-016-AA-E6-03-00	SERIES 51	S51-080MV
700465	PUMP-VAR-DISPL CCW 90PV075	90L075-DD-5-CD-60-P-3-C7-D-02-GBA-35-35-24	SERIES 90	S90-075PV
700466	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-BC-60-P-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
700467	PUMP-VAR-DISPL CCW 90PV075	90L075-DD-5-BC-60-P-3-C7-D-02-GBA-35-35-24	SERIES 90	S90-075PV
700469	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-BC-80-P-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
700470	PUMP-VAR-DISPL CW 90PV130	90R130-CA-5-BC-80-S-7-C8-F-00-GBS-38-38-32	SERIES 90	S90-130PV
700472	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-NN-60-S-4-C7-D-03-GBA-21-26-24	SERIES 90	S90-075PV
700480	PUMP-VAR-DISPL CW 90PV100	90R100-PB-5-BC-80-R-3-C7-E-00-GBA-32-14-24	SERIES 90	S90-100PV
700481	PUMP-VAR-DISPL CW 90PV100	90R100-PB-5-CD-80-R-3-C7-E-00-GBA-32-14-24	SERIES 90	S90-100PV
700482	PUMP-VAR-DISPL CW 90PV075	90R075-PB-1-AB-80-R-4-S1-D-00-GBA-32-14-24	SERIES 90	S90-075PV
700484	PUMP-VAR-DISPL CW 90PV055	90R055-KA-5-CD-80-S-3-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV
700486	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-BB-80-P-3-C7-E-03-GBA-42-42-26	SERIES 90	S90-075PV
700494	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-AB-80-S-3-C8-J-04-NNN-42-42-24	SERIES 90	S90-180PV
700503	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-NN-80-S-3-F1-F-02-GBA-26-26-28	SERIES 90	S90-130PV
700506	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-NN-80-S-4-C7-F-03-GBA-32-32-24	SERIES 90	S90-100PV
700510	PUMP-VAR-DISPL CCW 90PV055	90L055-KA-5-BC-60-S-3-C6-C-01-GBA-42-42-24	SERIES 90	S90-055PV
700511	MOTOR-VAR-DISPL 51MD110-1	51D110-1--R-D4-N-E2-B1-N-N-U1-NNN-040-AA-F0-00-00	SERIES 51	S51-110MV-1
700517	PUMP-VAR-DISPL CCW 90PV042	90L042-KA-5-NN-80-S-3-C3-C-03-GBA-42-42-24	SERIES 90	S90-042PV
700520	MOTOR-VAR-DISPL 51MV110	51V110-R-C8-N-HZ-B1-B-E-C2-NNN-050-AA-G0-05-00	SERIES 51	S51-110MV
700522	PUMP-VAR-DISPL CW 90PV100	90R100-MA-5-BB-60-S-3-C7-E-C6-GBA-45-45-24	SERIES 90	S90-100PV
700529	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-CD-80-T-3-C8-J-03-NNN-29-29-24	SERIES 90	S90-180PV
700530	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-NN-80-S-3-S1-D-03-GBA-32-32-24	SERIES 90	S90-075PV
700531	PUMP-VAR-DISPL CW 90PV250	90R250-MA-5-BC-80-S-3-C8-J-C6-NNN-42-42-28	SERIES 90	S90-250PV
700536	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-BB-60-R-3-C7-D-03-GBA-42-42-28	SERIES 90	S90-075PV
700538	PUMP-VAR-DISPL CCW 90PV130	90L130-PB-5-BB-80-S-3-C8-H-03-GBA-42-42-24	SERIES 90	S90-130PV
700541	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-NN-80-R-3-S1-E-03-GBA-42-42-20	SERIES 90	S90-075PV
700543	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-CD-80-S-C-C8-H-04-NNN-42-42-30	SERIES 90	S90-180PV
700547	PUMP-VAR-DISPL MPV046	MPV-046-C-B-B-S-B-S-BA-A-C-BHH-CD-A-GG-A-NNN	M46	M46-046PV
700551	MOTOR-VAR-DISPL 51MD110-1	51D110-1--A-D3-N-T2-R5-N-N-X1-NNN-039-AA-A3-00-28	SERIES 51	S51-110MV-1
700552	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-S1-N-E2-B1-N-N-U1-ADA-040-AA-G0-00-00	SERIES 51	S51-080MV-1
700553	PUMP-VAR-DISPL CW 42PV04A	42-R-4A-C-G1A1-72-J-2-G-2-F-5-A-30-23-B-0-0-ABA-NNN	SERIES 42	S42-041PV/051PV

700554	PUMP-VAR-DISPL CCW 90PV100	90L100-MA-5-BC-60-S-3-C7-E-01-GBA-42-42-24	SERIES 90	S90-100PV
700555	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-2-BC-80-S-3-C8-J-03-NNN-29-29-24	SERIES 90	S90-180PV
700558	PUMP-VAR-DISPL CW 90PV130	90R130-FH-5-DG-80-S-B-C8-F-B1-GBS-38-38-32	SERIES 90	S90-130PV
700559	PUMP-VAR-DISPL CW 90PV130	90R130-CA-5-BC-80-S-B-C8-F-00-GBS-38-38-32	SERIES 90	S90-130PV
700560	PUMP-VAR-DISPL CW 90PV130	90R130-KN-5-CD-80-L-3-C8-H-03-GBA-23-23-24	SERIES 90	S90-130PV
700562	PUMP-VAR-DISPL CW 90PV100	90R100-CA-5-AB-80-L-3-C7-F-00-GBA-40-40-24	SERIES 90	S90-100PV
700565	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-BB-80-S-4-C8-J-03-NNN-35-35-24	SERIES 90	S90-180PV
700566	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-BC-80-S-4-C8-J-03-NNN-42-42-24	SERIES 90	S90-180PV
700574	PUMP-VAR-DISPL CW 90PV055	90R055-PB-5-BK-80-S-3-S1-D-09-GBA-42-42-24	SERIES 90	S90-055PV
700575	PUMP-VAR-DISPL CW 90PV055	90R055-KA-5-NN-60-S-3-C6-C-03-GBA-20-20-24	SERIES 90	S90-055PV
700576	MOTOR-FIXED-DISPL 90MF100	90-M-100-NC-0-N-8-N-0-S1-W-00-NNN-00-00-00	SERIES 90	S90-100MF
700580	PUMP-VAR-DISPL CW 90PV130	90R130-DD-1-BC-80-L-3-T7-H-G4-GBA-29-29-24	SERIES 90	S90-130PV
700581	PUMP-VAR-DISPL CW 90PV042	90R042-HF-5-NN-80-R-4-C3-C-00-FAD-29-29-20	SERIES 90	S90-042PV
700584	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-NN-80-L-4-F1-H-03-GBA-42-42-24	SERIES 90	S90-130PV
700590	PUMP-VAR-DISPL CW 90PV100	90R100-FD-5-CD-60-L-3-C7-F-B1-EAB-38-38-30	SERIES 90	S90-100PV
700594	MOTOR-VAR-DISPL 51MC080-1	51C080-1--A-D3-N-T2-D2-N-N-X1-NNN-033-AA-F3-00-28	SERIES 51	S51-080MV-1
700595	MOTOR-VAR-DISPL 51MC060	51C060-A-D2-N-EQ-A1-J-Y-E2-ADA-012-AA-E6-15-28	SERIES 51	S51-060MV
700596	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-NN-60-S-3-C7-E-02-GBA-42-42-24	SERIES 90	S90-100PV
700599	PUMP-VAR-DISPL CW 90PV100	90R100-HF-5-NN-60-S-3-C7-E-03-GBA-26-26-24	SERIES 90	S90-100PV
700603	MOTOR-VAR-DISPL 51MC160	51C160-R-D5-N-HZ-B1-A-N-G0-NNN-065-AA-F0-03-00	SERIES 51	S51-160MV
700604	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-CD-60-P-3-C7-D-03-GBA-30-30-24	SERIES 90	S90-075PV
700605	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-CD-60-P-3-S1-D-03-GBA-30-30-24	SERIES 90	S90-075PV
700610	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-NN-80-S-3-C8-F-03-GBA-30-30-24	SERIES 90	S90-130PV
700611	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-AB-60-R-3-T6-D-02-GBA-42-42-24	SERIES 90	S90-075PV
700612	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-C8-N-T2-CA-N-N-X1-ADA-040-AA-E6-00-28	SERIES 51	S51-110MV-1
700613	PUMP-VAR-DISPL CW 90PV055	90R055-KA-5-BC-60-S-3-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV
700614	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-HZ-B1-A-N-G0-NNN-030-AA-E6-05-00	SERIES 51	S51-080MV
700615	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-NN-80-S-3-C7-F-03-GBA-30-30-24	SERIES 90	S90-100PV
700622	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-E2-A1-A-N-E2-NNN-070-AA-F3-03-26	SERIES 51	S51-160MV
700624	PUMP-VAR-DISPL CW 90PV100	90R100-CB-5-NN-80-S-3-S1-F-00-GBA-42-42-24	SERIES 90	S90-100PV
700626	PUMP-VAR-DISPL CCW 42PV28	42-L-28-C-E1A6-03-C-2-A-2-F-N-A-14-14-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
700627	PUMP-VAR-DISPL CW 90PV250	90R250-KA-2-NN-80-S-3-C8-K-03-NNN-42-42-28	SERIES 90	S90-250PV
700634	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-NN-80-S-3-C8-H-03-GBA-35-35-24	SERIES 90	S90-130PV
700635	PUMP-VAR-DISPL CW 90PV250	90R250-MA-5-NN-80-S-4-C8-J-03-NNN-20-20-24	SERIES 90	S90-250PV
700638	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-AB-60-S-3-C7-E-04-GBA-42-42-30	SERIES 90	S90-100PV
700640	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-NN-60-S-4-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV

700642	PUMP-VAR-DISPL CCW 90PV055	90L055-KA-5-BC-60-S-4-C6-C-03-GBA-23-23-24	SERIES 90	S90-055PV
700648	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-NN-80-S-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
700650	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-EQ-A3-K-Y-E5-ABA-102-AA-H0-70-25	SERIES 51	S51-250MV
700651	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-BC-80-S-3-C8-J-03-NNN-38-20-24	SERIES 90	S90-250PV
700652	MOTOR-VAR-DISPL 51MD160	51D160-A-D4-N-E2-A7-A-N-E1-CCA-075-AA-F3-03-16	SERIES 51	S51-160MV
700653	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-AB-80-S-4-C3-C-03-GBA-29-29-24	SERIES 90	S90-042PV
700654	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-C8-N-T1-C2-N-N-X1-NNN-022-AA-F3-00-14	SERIES 51	S51-110MV-1
700655	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-5-NN-80-S-3-C8-K-03-NNN-35-35-24	SERIES 90	S90-250PV
700664	PUMP-VAR-DISPL CCW 42PV41	42-L-41-D-E1A6-02-B-3-G-2-H-N-N-25-25-B-A-A-NNN-NNN	SERIES 42	S42-041PV/051PV
700665	PUMP-VAR-DISPL CW 90PV100	90R100-FA-P-CD-80-D-7-C7-L-B1-EFD-48-48-42	SERIES 90	S90-100PV
700667	MOTOR-VAR-DISPL 51MV110	51V110-R-F1-N-JA-NN-B-E-K3-NNN-038-AA-F0-12-31	SERIES 51	S51-110MV
700668	PUMP-VAR-DISPL CW 90PV075	90R075-MA-1-BB-80-L-4-C7-D-05-GBA-32-32-24	SERIES 90	S90-075PV
700669	PUMP-VAR-DISPL CW 90PV055	90R055-KA-5-CD-60-S-3-C6-C-03-GBA-42-42-24	SERIES 90	S90-055PV
700671	MOTOR-FIXED-DISPL 90MF100	90-M-100-NC-0-N-8-N-0-C6-W-00-NNN-00-00-F3	SERIES 90	S90-100MF
700673	PUMP-VAR-DISPL CW 90PV075	90R075-DD-5-BB-60-L-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-075PV
700675	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-NN-60-S-4-C7-E-03-GBA-20-20-24	SERIES 90	S90-100PV
700676	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-CD-80-S-3-C8-H-04-GBA-42-42-24	SERIES 90	S90-130PV
700677	PUMP-VAR-DISPL CW 90PV100	90R100-KA-P-BC-80-S-4-C7-E-02-GBA-48-48-24	SERIES 90	S90-100PV
700679	PUMP-VAR-DISPL CW 90PV042	90R042-KN-5-BC-80-R-3-C3-C-03-GBA-29-29-24	SERIES 90	S90-042PV
700685	PUMP-VAR-DISPL CW 90PV042	90R042-FC-5-AB-80-S-7-C3-C-B1-GBA-42-42-28	SERIES 90	S90-042PV
700686	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-5-NN-80-T-3-C8-J-09-NNN-35-35-24	SERIES 90	S90-250PV
700687	PUMP-VAR-DISPL CW 90PV180	90R180-MA-5-NN-80-S-C-F1-J-C4-NNN-42-42-30	SERIES 90	S90-180PV
700692	PUMP-VAR-DISPL CW 90PV075	90R075-KN-5-CD-60-R-3-C7-D-04-GBA-17-17-24	SERIES 90	S90-075PV
700695	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-CD-80-S-3-C8-F-03-GBA-42-42-24	SERIES 90	S90-130PV
700696	PUMP-VAR-DISPL CW 90PV055	90R055-HF-5-AD-80-P-3-S1-C-03-GBA-30-30-24	SERIES 90	S90-055PV
700699	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-HZ-B1-C-H-C2-NNN-016-AA-G3-20-00	SERIES 51	S51-080MV
700702	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-CD-60-S-3-S1-D-03-GBA-26-26-24	SERIES 90	S90-075PV
700704	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-CD-60-P-3-C7-E-03-GBA-23-23-24	SERIES 90	S90-100PV
700715	PUMP-VAR-DISPL CW 90PV055	90R055-KA-5-NN-60-P-3-C6-C-03-EBC-23-23-24	SERIES 90	S90-055PV
700717	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-NN-80-T-M-F1-J-03-NNN-38-38-24	SERIES 90	S90-180PV
700718	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-HS-A3-B-E-E5-ADA-050-AA-F3-05-35	SERIES 51	S51-250MV
700719	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-BC-80-S-3-D8-H-03-EFC-42-42-24	SERIES 90	S90-130PV
700720	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-N-N2-NN-N-N-A0-AHA-115-AA-NN-00-00	SERIES 51	S51-160MV
700722	MOTOR-VAR-DISPL 51MV110	51V110-R-F1-N-HZ-B1-C-H-C2-NNN-022-AA-G0-20-00	SERIES 51	S51-110MV
700736	PUMP-VAR-DISPL CCW 90PV055	90L055-KA-5-NN-60-S-4-S1-C-03-GBA-35-35-30	SERIES 90	S90-055PV
700738	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-AB-60-P-3-C6-D-03-GBA-38-38-24	SERIES 90	S90-075PV

700741	PUMP-VAR-DISPL CW 90PV180	90R180-MA-5-CD-80-S-C-C8-H-C5-NNN-32-32-24	SERIES 90	S90-180PV
700743	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-CD-80-L-4-C8-H-03-GBA-42-42-24	SERIES 90	S90-130PV
700748	PUMP-VAR-DISPL CW 90PV250	90R250-MA-5-NN-80-S-4-C8-K-C5-NNN-32-32-24	SERIES 90	S90-250PV
700750	PUMP-VAR-DISPL CW 90PV130	90R130-MA-5-AB-80-L-4-C8-H-05-GBA-32-32-24	SERIES 90	S90-130PV
700753	PUMP-VAR-DISPL CW 90PV130	90R130-FH-5-CD-80-S-7-C8-H-B1-EFI-42-42-32	SERIES 90	S90-130PV
700754	MOTOR-VAR-DISPL 51MV110	51V110-R-C8-N-E1-A5-A-N-A6-NNN-080-AA-G3-03-00	SERIES 51	S51-110MV
700756	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-F2-A3-A-N-E5-NNN-050-AA-F0-03-24	SERIES 51	S51-250MV
700761	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-NN-60-R-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
700763	PUMP-VAR-DISPL CW 90PV055	90R055-KA-5-NN-80-S-3-C6-D-03-GBA-26-26-24	SERIES 90	S90-055PV
700766	MOTOR-VAR-DISPL 51MC110-1	51C110-1--R-D3-N-E2-B1-N-N-U1-NNN-045-AA-E6-00-00	SERIES 51	S51-110MV-1
700769	PUMP-VAR-DISPL CW 90PV180	90R180-MA-5-DE-80-S-4-C8-J-05-NNN-42-42-24	SERIES 90	S90-180PV
700771	PUMP-VAR-DISPL CW 90PV075	90R075-MB-5-BB-60-R-3-C7-D-C6-GBA-35-35-24	SERIES 90	S90-075PV
700772	PUMP-VAR-DISPL CW 90PV100	90R100-PB-5-NN-80-R-3-C7-E-03-GBA-21-21-24	SERIES 90	S90-100PV
700775	MOTOR-VAR-DISPL 51MV080	51V080-R-C7-N-HZ-B1-B-E-C2-NNN-035-AA-E6-10-00	SERIES 51	S51-080MV
700776	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-BB-80-S-3-C8-F-03-GBA-42-42-24	SERIES 90	S90-130PV
700783	MOTOR-VAR-DISPL 51MV060-1	51V060-1--R-C6-N-T7-L5-N-N-X1-NNN-030-AA-F0-00-27	SERIES 51	S51-060MV-1
700785	PUMP-VAR-DISPL CCW 90PV100	90L100-DD-1-NN-60-R-4-C7-F-03-GBA-32-32-24	SERIES 90	S90-100PV
700789	MOTOR-VAR-DISPL 51MD110-1	51D110-1--R-D4-N-E1-B1-N-N-U1-NNN-055-AA-E6-00-00	SERIES 51	S51-110MV-1
700790	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-T2-CA-N-N-X1-NNN-050-AA-F0-00-20	SERIES 51	S51-110MV-1
700791	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-CD-80-P-3-F1-H-02-GBA-30-30-24	SERIES 90	S90-130PV
700793	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-NN-80-L-3-F1-H-05-GBA-35-35-24	SERIES 90	S90-130PV
700794	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-DE-80-T-4-C8-J-05-GLA-32-32-24	SERIES 90	S90-250PV
700797	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-T2-C2-N-N-X1-NNN-062-AA-F3-00-13	SERIES 51	S51-110MV-1
700798	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-T2-C2-L-N-G0-NNN-076-AA-F0-00-B1	SERIES 51	S51-160MV
700800	PUMP-VAR-DISPL CCW 90PV055	90L055-KA-5-AB-60-S-3-C6-C-03-GBA-42-42-24	SERIES 90	S90-055PV
700804	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-C-T1-L5-L-N-G0-NNN-092-AA-C0-00-B8	SERIES 51	S51-160MV
700805	PUMP-VAR-DISPL CCW 42PV28	42-L-28-D-E1A6-02-B-3-G-2-H-N-A-34-34-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
700806	PUMP-VAR-DISPL CW 90PV055	90R055-KA-5-AB-60-P-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
700808	PUMP-VAR-DISPL CW 90PV180	90R180-KN-5-BC-80-T-M-F1-J-03-NNN-42-42-24	SERIES 90	S90-180PV
700809	PUMP-VAR-DISPL CW 90PV075	90R075-DC-5-CD-60-S-4-C7-D-02-GBA-48-48-24	SERIES 90	S90-075PV
700810	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-C8-N-T2-CA-N-N-X1-NNN-036-AA-F3-00-18	SERIES 51	S51-110MV-1
700816	PUMP-VAR-DISPL CCW 90PV130	90L130-MA-5-AB-80-S-3-C8-H-C5-GBA-42-42-24	SERIES 90	S90-130PV
700817	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-CD-60-S-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
700818	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-BC-80-R-3-C8-H-03-GBA-42-42-24	SERIES 90	S90-130PV
700821	MOTOR-VAR-DISPL 51MV080-1	51V080-1--A-C7-N-E1-B1-N-N-U1-NNN-032-AA-F0-00-00	SERIES 51	S51-080MV-1
700822	MOTOR-VAR-DISPL 51MV080-1	51V080-1--A-C7-N-N1-NN-N-N-U1-NNN-032-AA-F0-00-00	SERIES 51	S51-080MV-1

700824	MOTOR-VAR-DISPL 51MD060-1	51D060-1--R-D2-N-T1-C2-N-N-X1-NNN-025-AA-E4-00-24	SERIES 51	S51-060MV-1
700825	PUMP-VAR-DISPL CCW 90PV180	90L180-KN-5-NN-80-S-C-C8-J-03-NNN-42-42-24	SERIES 90	S90-180PV
700829	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-NN-80-S-M-C8-H-03-NNN-29-23-24	SERIES 90	S90-180PV
700836	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-CD-80-R-3-C8-F-04-GBA-42-42-24	SERIES 90	S90-130PV
700837	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-CD-80-S-3-C8-J-03-NNN-42-42-24	SERIES 90	S90-180PV
700839	PUMP-VAR-DISPL CCW 90PV130	90L130-EA-1-NN-80-S-3-C8-H-03-GBA-35-35-24	SERIES 90	S90-130PV
700841	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-TH-C7-L-N-G0-NNN-072-AA-F3-00-C0	SERIES 51	S51-250MV
700842	PUMP-VAR-DISPL CW 90PV042	90R042-HF-5-BB-80-S-4-C3-C-03-GBA-35-35-24	SERIES 90	S90-042PV
700843	PUMP-VAR-DISPL CCW 42PV28	42-L-28-C-F7NN-53-U-3-G-2-C-N-N-25-25-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
700844	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-NN-60-S-3-C7-E-02-GBA-42-42-24	SERIES 90	S90-100PV
700845	PUMP-VAR-DISPL CW 90PV055	90R055-PB-5-BK-80-S-3-S1-D-09-GBA-26-26-20	SERIES 90	S90-055PV
700846	PUMP-VAR-DISPL CW 90PV042	90R042-FC-5-NN-80-S-7-C3-C-B4-GLA-45-45-32	SERIES 90	S90-042PV
700848	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-5-NN-80-S-3-C8-K-03-NNN-42-42-24	SERIES 90	S90-250PV
700853	PUMP-VAR-DISPL CW 90PV130	90R130-KN-5-BC-80-S-3-C8-H-03-GBA-23-23-24	SERIES 90	S90-130PV
700855	PUMP-VAR-DISPL CCW 90PV042	90L042-HF-1-AB-80-S-4-C3-C-03-GBA-38-38-24	SERIES 90	S90-042PV
700859	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-NN-60-S-3-C7-D-03-GBA-29-29-24	SERIES 90	S90-075PV
700860	MOTOR-VAR-DISPL 51MV080	51V080-A-C7-N-EQ-A1-J-Y-E2-NNN-016-AA-F3-20-32	SERIES 51	S51-080MV
700861	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-BB-60-S-3-C6-D-01-GBA-42-42-24	SERIES 90	S90-075PV
700863	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-CD-80-R-3-C7-F-44-GBA-30-30-26	SERIES 90	S90-100PV
700865	PUMP-VAR-DISPL CW 90PV100	90R100-KA-6-BB-60-P-3-C7-F-03-FAB-48-48-24	SERIES 90	S90-100PV
700868	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-CD-80-L-4-C8-H-03-GBA-23-23-24	SERIES 90	S90-130PV
700869	PUMP-VAR-DISPL CCW 90PV130	90L130-MA-5-AB-80-S-3-C8-F-C6-GBA-20-20-20	SERIES 90	S90-130PV
700871	PUMP-VAR-DISPL CW 90PV250	90R250-MA-5-NN-80-S-3-C8-J-C5-NNN-26-26-24	SERIES 90	S90-250PV
700873	PUMP-VAR-DISPL CW 90PV180	90R180-MA-5-NN-80-S-3-C8-J-C5-NNN-42-42-28	SERIES 90	S90-180PV
700874	MOTOR-VAR-DISPL 51MD110-1	51D110-1--R-D3-N-P8-P8-N-N-X1-NNN-044-AA-G3-00-AA	SERIES 51	S51-110MV-1
700875	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-HS-A2-A-E-E1-NNN-050-AA-F3-03-35	SERIES 51	S51-250MV
700876	PUMP-VAR-DISPL CW 90PV055	90R055-KA-5-AD-80-S-3-C6-C-03-GBA-42-42-24	SERIES 90	S90-055PV
700881	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-BC-60-S-3-T2-E-03-GBA-42-42-30	SERIES 90	S90-100PV
700882	PUMP-VAR-DISPL CCW 90PV042	90L042-DC-1-NN-80-S-4-C3-C-02-GBA-35-35-24	SERIES 90	S90-042PV
700884	PUMP-VAR-DISPL CCW 90PV042	90L042-HF-5-NN-80-P-3-C3-C-03-GBA-32-32-24	SERIES 90	S90-042PV
700885	PUMP-VAR-DISPL CW 90PV130	90R130-MA-5-CD-80-S-3-C8-H-C5-GBA-26-26-24	SERIES 90	S90-130PV
700886	PUMP-VAR-DISPL CW 90PV250	90R250-MA-5-CD-80-S-3-C8-J-C5-NNN-32-32-24	SERIES 90	S90-250PV
700887	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-NN-80-S-3-C8-K-03-NNN-42-42-24	SERIES 90	S90-250PV
700888	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-CD-80-T-C-C8-J-00-NNN-17-17-24	SERIES 90	S90-180PV
700889	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-BC-80-S-3-C8-J-03-NNN-42-42-30	SERIES 90	S90-180PV
700890	MOTOR-FIXED-DISPL 90MF100	90-M-100-NC-0-N-8-N-0-C7-W-00-EFA-00-00-F0	SERIES 90	S90-100MF

700891	PUMP-VAR-DISPL CW 90PV130	90R130-HF-5-NN-80-S-3-C8-H-03-GBA-42-42-24	SERIES 90	S90-130PV
700892	MOTOR-VAR-DISPL 51MD110-1	51D110-1--R-D3-N-B2-B3-N-N-U3-NNN-050-AA-E6-00-00	SERIES 51	S51-110MV-1
700894	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-AB-80-S-3-C7-F-03-GBA-38-38-26	SERIES 90	S90-100PV
700895	PUMP-VAR-DISPL CW 42PV28	42-R-28-D-E1A6-02-B-2-G-2-F-N-A-34-34-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
700897	PUMP-VAR-DISPL CW 90PV055	90R055-KA-5-NN-80-R-3-C6-C-05-GBA-35-35-30	SERIES 90	S90-055PV
700898	PUMP-VAR-DISPL CW 42PV28	42-R-28-C-E1A6-02-B-2-G-2-F-N-B-34-34-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
700899	PUMP-VAR-DISPL CW 42PV28	42-R-28-C-E1A6-02-B-2-G-2-F-N-A-34-34-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
700900	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-EG-80-T-3-C8-K-03-NNN-26-26-24	SERIES 90	S90-250PV
700901	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-NN-80-T-3-C8-K-03-NNN-26-26-24	SERIES 90	S90-250PV
700902	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-N2-NN-N-N-A0-NNN-032-AA-G0-00-00	SERIES 51	S51-160MV
700904	PUMP-VAR-DISPL CW 90PV075	90R075-KA-P-AB-80-S-4-C7-D-03-GBA-48-48-24	SERIES 90	S90-075PV
700905	MOTOR-VAR-DISPL 51MD080-1	51D080-1--R-D3-N-T1-R5-N-N-X1-NNN-025-AA-E6-00-20	SERIES 51	S51-080MV-1
700907	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-NN-80-S-3-C3-C-03-GBA-30-30-24	SERIES 90	S90-042PV
700908	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-BB-80-S-3-C3-C-03-GBA-30-30-24	SERIES 90	S90-042PV
700911	PUMP-VAR-DISPL CW 42PV41	42-R-41-D-E1A6-02-B-D-G-2-H-N-B-25-25-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
700912	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-AB-80-S-3-C6-D-03-GBA-45-45-24	SERIES 90	S90-075PV
700913	MOTOR-VAR-DISPL 51MV160	51V160-A-C8-N-D7-M1-S-K-N1-ABA-062-AA-G3-F4-26	SERIES 51	S51-160MV
700915	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-CD-80-P-3-S1-E-03-GBA-26-26-24	SERIES 90	S90-100PV
700916	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-CD-80-P-3-C7-E-03-GBA-26-26-24	SERIES 90	S90-100PV
700917	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-EQ-A1-J-Y-E2-NNN-050-AA-G0-15-27	SERIES 51	S51-250MV
700918	PUMP-VAR-DISPL CW 90PV250	90R250-DD-5-BC-80-S-3-C8-K-03-NNN-29-29-30	SERIES 90	S90-250PV
700923	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-HS-A2-B-N-E1-NNN-050-AA-G0-08-27	SERIES 51	S51-250MV
700924	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D3-N-TA-C2-N-N-X1-NNN-016-AA-NN-00-18	SERIES 51	S51-080MV-1
700927	PUMP-VAR-DISPL CW 90PV055	90R055-FD-5-AD-80-R-7-C6-C-B2-EBC-42-42-24	SERIES 90	S90-055PV
700928	PUMP-VAR-DISPL CCW 90PV100	90L100-MA-5-AB-60-S-4-C7-D-C5-GBA-32-32-24	SERIES 90	S90-100PV
700929	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-C7-N-T2-CA-N-N-X1-NNN-025-AA-F3-00-30	SERIES 51	S51-080MV-1
700932	PUMP-VAR-DISPL CCW 90PV100	90L100-HF-5-CD-80-S-3-T2-E-03-GBA-42-42-24	SERIES 90	S90-100PV
700933	MOTOR-VAR-DISPL 51MV110	51V110-R-C8-N-D8-M1-R-J-N2-NNN-022-AA-F3-C2-37	SERIES 51	S51-110MV
700934	PUMP-VAR-DISPL CCW 90PV055	90L055-KA-5-AB-60-P-3-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV
700938	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-BC-80-P-3-S1-E-03-GBA-26-26-24	SERIES 90	S90-100PV
700940	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-AB-60-S-3-C7-D-03-GBA-42-42-24	SERIES 90	S90-075PV
700941	PUMP-VAR-DISPL CW 90PV130	90R130-MA-5-NN-80-S-4-C8-H-C5-GBA-29-29-24	SERIES 90	S90-130PV
700944	PUMP-VAR-DISPL CCW 90PV042	90L042-HF-5-AB-80-P-3-C3-C-03-GBA-32-32-24	SERIES 90	S90-042PV
700945	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-N2-NN-N-N-A0-NNN-032-AA-G0-00-00	SERIES 51	S51-160MV
700946	MOTOR-VAR-DISPL 51MV110	51V110-R-F1-N-HZ-B1-C-H-C2-NNN-032-AA-NN-20-00	SERIES 51	S51-110MV
700949	PUMP-VAR-DISPL CCW 90PV042	90L042-KA-P-NN-80-P-4-C3-C-03-FAB-48-48-24	SERIES 90	S90-042PV

700950	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-CD-60-S-3-C7-F-04-GBA-35-35-24	SERIES 90	S90-100PV
700951	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-NN-60-S-3-S1-F-04-GBA-35-35-24	SERIES 90	S90-100PV
700952	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-BC-80-S-3-C3-C-03-GBA-35-35-24	SERIES 90	S90-042PV
700953	PUMP-VAR-DISPL CW 90PV100	90R100-DD-5-NN-60-S-4-C7-E-01-GBA-20-20-24	SERIES 90	S90-100PV
700956	PUMP-VAR-DISPL CCW 90PV055	90L055-KA-5-CD-80-S-3-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV
700960	PUMP-VAR-DISPL CCW 90PV055	90L055-KA-5-AD-80-S-3-C6-C-03-GBA-23-23-20	SERIES 90	S90-055PV
700961	PUMP-VAR-DISPL CCW 90PV042	90L042-MA-5-AB-80-P-4-C3-B-C6-GBA-35-35-24	SERIES 90	S90-042PV
700962	PUMP-VAR-DISPL CW 90PV042	90R042-HF-5-BB-80-P-3-C3-C-03-GBA-32-32-24	SERIES 90	S90-042PV
700964	PUMP-VAR-DISPL CW 90PV042	90R042-HF-5-AB-80-P-3-C3-C-03-GBA-32-32-24	SERIES 90	S90-042PV
700965	PUMP-VAR-DISPL CW 90PV180	90R180-HF-5-BC-80-S-M-C8-J-03-NNN-35-35-24	SERIES 90	S90-180PV
700966	PUMP-VAR-DISPL CCW 90PV130	90L130-DD-5-BB-80-S-3-C8-F-03-GBA-42-42-24	SERIES 90	S90-130PV
700967	PUMP-VAR-DISPL CCW 90PV130	90L130-DD-5-AB-80-S-3-C8-F-03-GBA-42-42-24	SERIES 90	S90-130PV
700968	MOTOR-VAR-DISPL 51MV110-1	51V110-1--A-C8-N-T1-L5-N-N-X1-NNN-080-AA-H0-00-30	SERIES 51	S51-110MV-1
700969	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-BB-60-S-3-C6-D-03-GBA-42-42-24	SERIES 90	S90-075PV
700970	PUMP-VAR-DISPL CCW 42PV28	42-L-28-D-E1A6-03-C-2-A-2-F-N-A-14-14-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
700972	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-NN-80-S-3-S1-E-03-GBA-32-32-30	SERIES 90	S90-075PV
700973	PUMP-VAR-DISPL CCW 42PV28	42-L-28-D-E1A4-02-B-4-G-2-H-N-N-30-30-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
700975	PUMP-VAR-DISPL CW 90PV130	90R130-MA-2-BC-80-S-3-C8-F-03-GBA-42-42-24	SERIES 90	S90-130PV
700980	PUMP-VAR-DISPL CW 90PV180	90R180-PA-5-CD-80-S-3-F1-H-GT-NNN-42-42-24	SERIES 90	S90-180PV
700981	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-AB-80-T-4-C8-K-03-NNN-42-42-24	SERIES 90	S90-250PV
700982	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-CD-80-S-3-C8-F-03-GBA-42-42-30	SERIES 90	S90-130PV
700984	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-HS-A3-B-E-E5-NNN-050-AA-F3-05-35	SERIES 51	S51-250MV
700986	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-E2-A5-A-N-A6-ADA-043-AA-F3-03-00	SERIES 51	S51-160MV
700987	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-CD-80-P-3-C7-D-03-GBA-42-42-26	SERIES 90	S90-075PV
700991	MOTOR-VAR-DISPL 51MD110	51D110-A-F1-N-EQ-A5-K-U-A6-NNN-032-AA-F0-50-00	SERIES 51	S51-110MV
700993	PUMP-VAR-DISPL CW 42PV28	42-R-28-C-ANNB-03-B-3-G-2-C-N-N-21-21-B-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
700994	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-F2-A3-A-N-E5-NNN-079-AA-H0-03-30	SERIES 51	S51-250MV
700996	PUMP-VAR-DISPL CW 90PV130	90R130-MA-5-CD-80-L-3-C8-F-C5-GBA-42-42-24	SERIES 90	S90-130PV
700998	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-BB-80-S-3-S1-E-03-GBA-29-29-24	SERIES 90	S90-100PV
700999	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-CD-80-S-3-C8-F-03-GBA-45-45-24	SERIES 90	S90-130PV
701000	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-NN-80-L-3-C8-H-03-GBA-38-38-24	SERIES 90	S90-130PV
701001	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-B-N2-NN-N-N-A0-NNN-054-AA-NN-00-00	SERIES 51	S51-160MV
701002	PUMP-VAR-DISPL CW 90PV100	90R100-MA-5-NN-80-R-4-C7-E-C5-GBA-32-32-30	SERIES 90	S90-100PV
701006	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-5-CD-80-S-3-F1-K-00-NNN-35-35-24	SERIES 90	S90-250PV
701007	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-5-CD-80-S-3-F1-K-00-NNN-35-14-30	SERIES 90	S90-250PV
701008	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-6-NN-80-S-3-C7-E-03-GBA-48-48-24	SERIES 90	S90-100PV

701009	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-NN-80-S-3-S1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
701010	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-6-BB-80-S-3-C7-E-03-GBA-48-48-24	SERIES 90	S90-100PV
701012	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-P-CD-80-S-3-C8-H-03-GBA-48-48-24	SERIES 90	S90-130PV
701013	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-P-NN-80-S-3-C8-H-03-GBA-48-48-24	SERIES 90	S90-130PV
701014	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-CD-80-T-C-F1-J-00-NNN-35-14-30	SERIES 90	S90-180PV
701015	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-BC-80-T-C-F1-J-00-NNN-35-14-30	SERIES 90	S90-180PV
701017	PUMP-VAR-DISPL CW 90PV075	90R075-HF-5-BC-60-S-3-C7-D-03-GBA-26-26-18	SERIES 90	S90-075PV
701018	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-NN-80-P-3-C8-H-03-GBA-29-29-24	SERIES 90	S90-130PV
701019	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-NN-80-P-3-C7-E-03-GBA-29-29-24	SERIES 90	S90-100PV
701020	PUMP-VAR-DISPL CW 90PV130	90R130-FG-5-AB-80-L-7-C8-H-B1-EFI-30-30-32	SERIES 90	S90-130PV
701022	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-NN-80-S-3-C8-J-03-NNN-42-42-24	SERIES 90	S90-180PV
701023	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-C8-N-TA-C2-N-N-X1-NNN-074-AA-F3-00-17	SERIES 51	S51-110MV-1
701025	PUMP-VAR-DISPL CW 90PV055	90R055-MA-5-BC-60-S-3-S1-C-C5-GBA-35-35-24	SERIES 90	S90-055PV
701026	PUMP-VAR-DISPL CW 90PV180	90R180-MA-5-CD-80-S-3-C8-H-C6-NNN-42-42-24	SERIES 90	S90-180PV
701027	PUMP-VAR-DISPL CW 90PV075	90R075-KP-5-AB-80-L-3-T6-D-00-EFC-38-14-24	SERIES 90	S90-075PV
701028	MOTOR-VAR-DISPL 51MD110	51D110-A-D4-N-HA-B2-C-E-H7-NNN-060-AA-G0-12-00	SERIES 51	S51-110MV
701030	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-BC-80-P-3-C7-D-03-GBA-42-42-24	SERIES 90	S90-075PV
701031	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-CD-80-S-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
701033	MOTOR-VAR-DISPL 51MC110	51C110-R-D4-N-HS-A2-B-E-E1-NNN-050-AA-F0-05-23	SERIES 51	S51-110MV
701034	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-HS-A2-B-E-E1-NNN-050-AA-F3-05-23	SERIES 51	S51-250MV
701035	PUMP-VAR-DISPL CCW 90PV180	90L180-DD-5-NN-80-T-3-C8-J-GB-NNN-42-42-22	SERIES 90	S90-180PV
701036	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-BC-80-L-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
701038	PUMP-VAR-DISPL CW 90PV180	90R180-DD-5-CD-80-S-3-C8-J-03-NNN-35-35-24	SERIES 90	S90-180PV
701039	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-NN-80-S-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-075PV
701043	PUMP-VAR-DISPL CW 90PV075	90R075-HF-5-CD-80-P-4-C7-E-03-GBA-42-42-24	SERIES 90	S90-075PV
701046	PUMP-VAR-DISPL CW 90PV130	90R130-HF-5-CS-80-L-3-F1-H-03-GBA-42-42-24	SERIES 90	S90-130PV
701047	PUMP-VAR-DISPL CW 90PV130	90R130-HF-5-DE-80-L-3-C8-H-03-GBA-42-42-24	SERIES 90	S90-130PV
701048	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-NN-60-S-4-S1-D-05-GLA-26-26-24	SERIES 90	S90-075PV
701051	PUMP-VAR-DISPL CCW 90PV100	90L100-MA-5-CD-60-L-3-C7-F-C5-GBA-35-35-24	SERIES 90	S90-100PV
701055	PUMP-VAR-DISPL CW 90PV055	90R055-KN-5-NN-60-S-3-C6-D-03-GBA-29-29-24	SERIES 90	S90-055PV
701056	PUMP-VAR-DISPL CW 90PV130	90R130-DD-5-CD-80-L-4-C8-H-C5-GBA-42-42-24	SERIES 90	S90-130PV
701061	PUMP-VAR-DISPL MPV046	MPV-046-C-B-A-B-S-B-AA-B-A-BFF-AB-U-BD-A-NNN	M46	M46-046PV
701062	PUMP-VAR-DISPL CW 90PV250	90R250-MA-5-AB-80-T-4-C8-J-C6-NNN-32-32-24	SERIES 90	S90-250PV
701063	PUMP-VAR-DISPL CW 90PV250	90R250-HF-5-BC-80-S-3-C8-K-03-NNN-42-42-24	SERIES 90	S90-250PV
701064	MOTOR-VAR-DISPL 51MD110-1	51D110-1--A-D4-N-T1-L5-N-N-X1-NNN-063-AA-F3-00-25	SERIES 51	S51-110MV-1
701067	PUMP-VAR-DISPL CCW 90PV075	90L075-HF-5-BB-80-P-3-C7-D-03-GCS-42-42-24	SERIES 90	S90-075PV

701069	PUMP-VAR-DISPL CCW 90PV075	90L075-MA-5-NN-80-P-4-C6-D-C4-GBA-35-35-24	SERIES 90	S90-075PV
701070	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-BC-80-S-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-100PV
701072	PUMP-VAR-DISPL MPV046	MPV-046-C-B-B-H-R-B-A-AA-G-A-BJJ-DA-A-JJ-A-NNN	M46	M46-046PV
701073	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-AB-80-R-3-C8-H-03-GBA-42-42-24	SERIES 90	S90-130PV
701076	PUMP-VAR-DISPL CCW 90PV100	90L100-MA-5-NN-60-S-3-C7-F-C6-GBA-42-42-30	SERIES 90	S90-100PV
701080	PUMP-VAR-DISPL CCW 90PV055	90L055-DD-5-NN-60-S-4-S1-B-03-GBA-38-38-20	SERIES 90	S90-055PV
701082	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-AB-80-P-3-C7-D-03-GBA-42-42-24	SERIES 90	S90-075PV
701085	PUMP-VAR-DISPL CCW 90PV100	90L100-MB-5-CD-80-S-3-C7-E-C5-GBA-45-45-24	SERIES 90	S90-100PV
701087	MOTOR-VAR-DISPL 51MC060-1	51C060-1--A-D1-N-TA-C2-N-N-X1-NNN-024-AA-E6-00-18	SERIES 51	S51-060MV-1
701089	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-HS-A2-B-E-E1-NNN-050-AA-NN-10-37	SERIES 51	S51-250MV
701090	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-EQ-A5-J-Y-A6-NNN-032-AA-G0-40-00	SERIES 51	S51-160MV
701091	PUMP-VAR-DISPL CW 90PV075	90R075-DD-5-AB-60-S-4-C7-D-02-FAC-42-42-24	SERIES 90	S90-075PV
701092	PUMP-VAR-DISPL CW 90PV250	90R250-MA-5-NN-80-S-4-C8-K-C5-NNN-29-29-24	SERIES 90	S90-250PV
701095	PUMP-VAR-DISPL CW 90PV130	90R130-MA-5-NN-80-S-4-C8-H-C5-GBA-23-23-24	SERIES 90	S90-130PV
701096	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-NN-80-S-4-C7-E-03-GBA-35-35-24	SERIES 90	S90-100PV
701103	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-BB-80-R-3-C8-H-46-GBA-30-30-24	SERIES 90	S90-130PV
701104	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-CD-80-R-3-C8-H-46-GBA-30-30-24	SERIES 90	S90-130PV
701105	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-NN-80-S-3-C8-H-46-GBA-30-30-24	SERIES 90	S90-130PV
701106	PUMP-VAR-DISPL CW 90PV100	90R100-DD-5-NN-80-S-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
701108	MOTOR-VAR-DISPL 51MD080	51D080-R-D3-N-JA-NN-B-E-K3-ADA-022-AA-NN-09-32	SERIES 51	S51-080MV
701111	PUMP-VAR-DISPL CW 90PV055	90R055-KA-5-BG-80-R-3-C6-C-03-GBA-35-35-20	SERIES 90	S90-055PV
701112	PUMP-VAR-DISPL CCW 90PV055	90L055-KA-5-CD-60-P-3-C6-D-03-GBA-23-23-22	SERIES 90	S90-055PV
701113	MOTOR-VAR-DISPL 51MV080	51V080-R-C7-N-E1-L2-A-N-A8-NNN-027-AA-F3-03-20	SERIES 51	S51-080MV
701114	PUMP-VAR-DISPL CW 90PV100	90R100-KP-5-AB-80-S-3-T6-F-03-GBA-38-14-24	SERIES 90	S90-100PV
701115	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-NN-60-R-3-C7-L-04-GBA-42-42-24	SERIES 90	S90-100PV
701116	PUMP-VAR-DISPL CW 90PV075	90R075-KA-2-BB-60-R-3-C7-D-03-GBA-38-38-28	SERIES 90	S90-075PV
701117	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-DE-80-S-7-C8-H-09-GCA-35-35-30	SERIES 90	S90-130PV
701118	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-BC-80-S-7-F1-H-09-GCA-35-35-30	SERIES 90	S90-130PV
701120	PUMP-VAR-DISPL CW 90PV250	90R250-MA-5-CD-80-T-3-C8-J-C5-NNN-30-30-24	SERIES 90	S90-250PV
701122	PUMP-VAR-DISPL CCW 90PV055	90L055-HF-5-NN-80-S-3-C6-D-03-GBA-42-42-24	SERIES 90	S90-055PV
701123	PUMP-VAR-DISPL CW 90PV100	90R100-MA-5-BC-80-S-3-F1-E-C5-GBA-17-17-20	SERIES 90	S90-100PV
701124	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-C7-N-T1-D1-N-N-X1-NNN-040-AA-F0-00-36	SERIES 51	S51-080MV-1
701129	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-CD-80-R-3-C8-H-44-GBA-30-30-30	SERIES 90	S90-130PV
701130	PUMP-VAR-DISPL CW 90PV055	90R055-KA-5-AB-60-S-3-C6-C-03-GBA-26-26-20	SERIES 90	S90-055PV
701132	PUMP-VAR-DISPL CW 90PV100	90R100-MB-5-BC-80-S-3-C7-E-C5-GBA-35-35-24	SERIES 90	S90-100PV
701133	PUMP-VAR-DISPL CW 90PV180	90R180-KN-5-NN-80-S-C-C8-H-03-NNN-29-29-24	SERIES 90	S90-180PV

701134	PUMP-VAR-DISPL CW 90PV100	90R100-HF-5-NN-60-S-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
701135	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-B-E2-A5-A-N-A6-NNN-100-AA-F3-03-00	SERIES 51	S51-250MV
701137	PUMP-VAR-DISPL CW 90PV075	90R075-MB-5-BC-80-S-3-C7-D-C5-GBA-35-35-24	SERIES 90	S90-075PV
701138	PUMP-VAR-DISPL CW 90PV130	90R130-MA-5-BC-80-S-3-C8-H-C5-GBA-42-42-24	SERIES 90	S90-130PV
701141	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-C-E2-A2-A-N-F1-NNN-122-AA-H0-03-27	SERIES 51	S51-250MV
701142	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-NN-80-R-3-C7-D-03-GBA-26-26-20	SERIES 90	S90-075PV
701143	PUMP-VAR-DISPL CW 90PV042	90R042-HF-5-AB-80-S-4-C3-C-03-GBA-20-20-20	SERIES 90	S90-042PV
701146	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-HS-A3-C-E-F7-NNN-073-AA-F0-22-16	SERIES 51	S51-160MV
701147	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-CD-80-S-3-C7-D-03-GBA-42-42-24	SERIES 90	S90-075PV
701150	PUMP-VAR-DISPL CW 90PV042	90R042-HF-5-NN-80-P-4-C3-C-00-FAD-26-26-20	SERIES 90	S90-042PV
701157	PUMP-VAR-DISPL CW 90PV075	90R075-MA-5-NN-60-S-3-C7-D-C5-GBA-42-42-24	SERIES 90	S90-075PV
701159	PUMP-VAR-DISPL CW 90PV250	90R250-HF-5-CD-80-T-4-C8-K-03-NNN-38-38-24	SERIES 90	S90-250PV
701160	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-NN-80-S-4-C8-H-03-GBA-32-32-24	SERIES 90	S90-130PV
701161	PUMP-VAR-DISPL CW 90PV075	90R075-KA-P-CD-60-S-3-C7-E-02-GBA-48-48-24	SERIES 90	S90-075PV
701162	PUMP-VAR-DISPL CW 90PV075	90R075-KA-P-BC-60-S-3-S1-E-03-GBA-48-48-24	SERIES 90	S90-075PV
701163	PUMP-VAR-DISPL CCW 90PV042	90L042-HF-5-BC-80-R-4-C3-C-03-GBA-35-35-24	SERIES 90	S90-042PV
701164	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-C8-N-T1-R5-N-N-X1-NNN-049-AA-F3-00-30	SERIES 51	S51-110MV-1
701165	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-N-T1-C2-N-N-X1-NNN-040-AA-F3-00-30	SERIES 51	S51-060MV-1
701170	PUMP-VAR DISPL, CW 90PV130	90R130-KA-5-CD-80-S-4-C8-H-03-GBA-35-35-28	SERIES 90	S90-130PV
701171	PUMP-VAR-DISPL CW 90PV130	90R130-MA-5-NN-80-S-3-C8-H-C5-GBA-42-42-24	SERIES 90	S90-130PV
701172	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-NN-80-L-4-C8-H-03-GBA-42-42-24	SERIES 90	S90-130PV
701173	PUMP-VAR-DISPL CW 90PV100	90R100-DD-5-CD-80-S-3-S1-E-02-GBA-42-42-24	SERIES 90	S90-100PV
701174	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-NN-80-S-4-C8-K-03-NNN-42-42-24	SERIES 90	S90-250PV
701175	MOTOR-VAR-DISPL 51MD110-1	51D110-1--R-D3-N-T1-L5-N-N-X1-NNN-049-AA-F3-00-20	SERIES 51	S51-110MV-1
701178	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D2-N-E1-B1-N-N-U1-ADA-020-AA-F0-00-00	SERIES 51	S51-080MV-1
701180	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-CD-80-L-3-C8-H-03-GBA-32-32-24	SERIES 90	S90-130PV
701183	PUMP-VAR-DISPL CW 90PV075	90R075-CA-5-NN-60-S-3-S1-E-00-GBA-30-35-20	SERIES 90	S90-075PV
701186	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-HS-A3-B-E-E5-NNN-086-AA-F3-05-35	SERIES 51	S51-250MV
701187	MOTOR-VAR-DISPL 51MV110	51V110-A-C8-N-D8-M1-R-JM1-ADA-039-AA-F0-C2-19	SERIES 51	S51-110MV
701188	PUMP-VAR-DISPL CW 90PV075	90R075-MA-1-NN-60-S-4-S1-D-C5-GBA-35-35-24	SERIES 90	S90-075PV
701190	PUMP-VAR-DISPL CW 90PV250	90R250-MB-5-CD-80-S-4-C8-K-C5-NNN-35-35-24	SERIES 90	S90-250PV
701191	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-NN-80-P-3-C3-C-03-GBA-42-42-24	SERIES 90	S90-042PV
701198	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-AB-80-S-3-C3-C-03-GBA-42-42-24	SERIES 90	S90-042PV
701200	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-AB-80-S-7-C7-E-09-FAC-35-35-30	SERIES 90	S90-100PV
701202	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-BB-80-L-3-C8-F-03-GBA-42-42-26	SERIES 90	S90-130PV
701203	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-E2-A5-A-N-A6-ADA-075-AA-H0-03-00	SERIES 51	S51-160MV

701204	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-BB-80-S-3-C8-F-03-GBS-42-42-24	SERIES 90	S90-130PV
701209	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-BB-80-S-3-C8-H-03-GBA-42-42-24	SERIES 90	S90-130PV
701210	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-CD-60-S-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
701212	MOTOR-VAR-DISPL 51MD160	51D160-R-D5-N-E1-R2-A-N-E3-ADA-070-BB-H0-03-17	SERIES 51	S51-160MV
701213	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-N-E1-R2-A-N-E3-ADA-095-BB-H0-03-16	SERIES 51	S51-250MV
701217	PUMP-VAR-DISPL CW 42PV41	42-R-41-D-E1A6-02-B-2-B-3-D-N-A-25-25-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
701221	PUMP-VAR-DISPL CCW 90PV075	90L075-HF-5-NN-80-S-3-C6-D-03-GBA-42-42-24	SERIES 90	S90-075PV
701224	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-BC-80-T-M-F1-H-03-EBA-38-38-24	SERIES 90	S90-180PV
701226	PUMP-VAR-DISPL CW 90PV075	90R075-KN-5-NN-60-P-3-C7-D-03-GBA-29-29-24	SERIES 90	S90-075PV
701232	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-BC-60-L-3-C7-E-03-GBA-32-32-24	SERIES 90	S90-100PV
701235	KIT RELIEF VALVE		M46	PARTS - M46
701236	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-CD-80-S-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
701237	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-NN-60-S-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-075PV
701239	PUMP-VAR-DISPL CCW 90PV130	90L130-DD-5-NN-80-P-4-C8-F-GB-GBA-38-38-24	SERIES 90	S90-130PV
701240	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-BC-60-P-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-100PV
701241	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-NN-80-T-3-C8-K-03-GLA-21-21-24	SERIES 90	S90-250PV
701244	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-S1-N-E1-B1-N-N-U1-NNN-028-AA-E4-00-00	SERIES 51	S51-080MV-1
701245	PUMP-VAR-DISPL CCW 90PV130	90L130-MA-5-NN-80-P-3-F1-F-09-GBA-42-42-20	SERIES 90	S90-130PV
701246	PUMP-VAR-DISPL CCW 90PV130	90L130-MA-5-DE-80-P-3-F1-F-09-GBA-42-42-20	SERIES 90	S90-130PV
701247	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-CD-60-L-3-C7-E-03-GBA-40-40-20	SERIES 90	S90-100PV
701248	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-AB-60-P-3-S1-D-03-GBA-21-21-20	SERIES 90	S90-075PV
701250	KIT RELIEF VALVE		M46	PARTS - M46
701251	MOTOR-VAR-DISPL 51MV110	51V110-R-F1-N-HS-A1-B-E-E2-NNN-054-AA-F3-10-25	SERIES 51	S51-110MV
701254	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-N2-NN-N-N-A0-ADA-032-AA-F0-00-00	SERIES 51	S51-160MV
701255	MOTOR-VAR-DISPL 51MD080-1	51D080-1--A-D3-N-T7-R5-N-N-X1-NNN-037-AA-F3-00-24	SERIES 51	S51-080MV-1
701257	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-CD-80-T-3-C8-H-04-NNN-42-42-24	SERIES 90	S90-180PV
701258	PUMP-VAR-DISPL CCW 90PV075	90L075-MB-P-NN-80-S-3-C7-D-C5-GBA-48-48-24	SERIES 90	S90-075PV
701259	MOTOR-VAR-DISPL 51MD080-1	51D080-1--A-D2-N-T7-D7-N-N-X1-NNN-040-AA-F0-00-26	SERIES 51	S51-080MV-1
701260	PUMP-VAR-DISPL CW 90PV075	90R075-MB-5-BC-80-S-3-C7-D-C5-GBA-40-40-24	SERIES 90	S90-075PV
701261	PUMP-VAR-DISPL CW 90PV250	90R250-MA-5-NN-80-S-4-C8-K-C5-NNN-42-42-24	SERIES 90	S90-250PV
701265	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-EG-80-S-3-C8-J-09-EBA-42-42-20	SERIES 90	S90-180PV
701266	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-EG-80-S-3-C8-J-09-EBA-42-42-20	SERIES 90	S90-180PV
701267	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-NN-80-S-3-C8-J-09-EBA-42-42-20	SERIES 90	S90-180PV
701268	KIT RELIEF VALVE		M46	PARTS - M46
701269	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-NN-80-S-3-C8-J-09-EBA-42-42-20	SERIES 90	S90-180PV
701271	PUMP-VAR-DISPL CCW 90PV055	90L055-KA-5-NN-60-S-3-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV

701272	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-CD-80-S-3-C7-E-03-GBA-32-32-24	SERIES 90	S90-075PV
701273	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-NN-80-S-3-S1-E-03-GBA-32-32-24	SERIES 90	S90-075PV
701278	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-NN-80-S-C-C8-J-03-GCA-45-45-24	SERIES 90	S90-180PV
701279	PUMP-VAR-DISPL CCW 90PV075	90L075-DD-5-NN-60-S-4-C7-D-03-GBA-42-42-24	SERIES 90	S90-075PV
701280	PUMP-VAR-DISPL CCW 90PV100	90L100-MA-5-NN-60-S-3-C7-E-21-FAB-42-42-24	SERIES 90	S90-100PV
701281	PUMP-VAR-DISPL CCW 90PV075	90L075-MA-5-NN-60-S-3-C6-D-42-GBA-42-42-24	SERIES 90	S90-075PV
701283	PUMP-VAR-DISPL CW 90PV075	90R075-DD-5-NN-80-L-3-S1-D-03-GBA-26-26-24	SERIES 90	S90-075PV
701287	PUMP-VAR-DISPL CW 90PV100	90R100-DD-5-NN-80-S-7-C7-F-G1-FAC-35-35-30	SERIES 90	S90-100PV
701288	PUMP-VAR-DISPL CW 90PV100	90R100-DD-5-AB-80-S-7-C7-F-G1-FAC-35-35-30	SERIES 90	S90-100PV
701289	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-CD-80-S-7-C8-H-09-GCA-35-35-30	SERIES 90	S90-130PV
701294	MOTOR-VAR-DISPL 51MD080	51D080-R-D2-N-L1-B1-W-B-J1-ABA-016-AA-F0-D4-00	SERIES 51	S51-080MV
701295	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-BC-80-S-3-C7-E-03-GBA-42-42-30	SERIES 90	S90-100PV
701299	PUMP-VAR-DISPL CW 90PV075	90R075-KA-2-CD-60-S-3-C7-D-03-GBA-42-42-24	SERIES 90	S90-075PV
701301	PUMP-VAR-DISPL CW 90PV075	90R075-KA-2-AB-60-S-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
701303	MOTOR-VAR-DISPL 51MV110	51V110-A-F1-N-EQ-A2-J-Y-E1-NNN-022-AA-E6-30-30	SERIES 51	S51-110MV
701304	PUMP-VAR-DISPL CCW 90PV055	90L055-KA-5-BK-80-S-3-C6-C-03-GBA-42-42-24	SERIES 90	S90-055PV
701306	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-NN-80-S-3-C8-H-03-GBA-42-42-24	SERIES 90	S90-130PV
701311	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-NN-60-R-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-100PV
701312	PUMP-VAR-DISPL CW 90PV250	90R250-MA-5-CD-80-T-3-C8-J-C5-NNN-35-35-24	SERIES 90	S90-250PV
701313	PUMP-VAR-DISPL CCW 90PV075	90L075-DC-5-NN-60-S-3-C7-D-GB-GBA-42-42-24	SERIES 90	S90-075PV
701315	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-E2-A5-A-N-A6-NNN-110-AA-G0-03-00	SERIES 51	S51-250MV
701317	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-NN-60-S-4-C7-F-04-GBA-32-32-24	SERIES 90	S90-100PV
701319	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-CD-60-P-3-S1-D-03-GBA-23-23-24	SERIES 90	S90-075PV
701320	PUMP-VAR-DISPL CW 90PV055	90R055-KA-5-NN-60-P-3-S1-C-03-EBC-23-23-24	SERIES 90	S90-055PV
701323	PUMP-VAR-DISPL CW 90PV130	90R130-FH-5-NN-80-L-7-C8-H-B1-EFI-38-38-30	SERIES 90	S90-130PV
701327	PUMP-VAR-DISPL CCW 90PV100	90L100-MA-5-AB-60-S-3-S1-E-C5-GBA-42-42-24	SERIES 90	S90-100PV
701329	PUMP-VAR-DISPL CW 90PV180	90R180-KP-5-CD-80-T-3-C8-J-03-FAC-35-35-24	SERIES 90	S90-180PV
701330	PUMP-VAR-DISPL CW 90PV130	90R130-MA-5-AB-80-S-4-C8-H-C5-GBA-30-30-24	SERIES 90	S90-130PV
701331	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-N-TA-C2-L-N-G0-NNN-050-AA-G0-00-C0	SERIES 51	S51-250MV
701332	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-NN-60-S-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-100PV
701333	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-NN-60-S-3-C7-F-03-GBA-35-35-24	SERIES 90	S90-100PV
701335	PUMP-VAR-DISPL CW 90PV075	90R075-MA-5-NN-80-S-3-C6-D-C5-GLA-21-21-24	SERIES 90	S90-075PV
701336	PUMP-VAR-DISPL CW 90PV042	90R042-EA-1-NN-80-S-3-C3-C-05-GBA-29-29-24	SERIES 90	S90-042PV
701337	PUMP-VAR-DISPL CW 90PV250	90R250-MA-5-CD-80-S-3-C8-K-C6-NNN-42-42-24	SERIES 90	S90-250PV
701338	PUMP-VAR-DISPL CW 90PV130	90R130-MA-5-BB-80-S-3-C8-H-C6-GBA-45-45-24	SERIES 90	S90-130PV
701340	PUMP-VAR-DISPL CW 90PV180	90R180-MA-5-BB-80-S-3-C8-J-C6-NNN-42-42-24	SERIES 90	S90-180PV

701343	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-HZ-B1-A-E-G0-NNN-016-AA-F0-30-00	SERIES 51	S51-080MV
701344	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-NN-60-S-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
701345	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-BC-60-S-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
701348	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-BC-60-L-3-C7-D-03-GBA-38-38-24	SERIES 90	S90-075PV
701349	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-S1-N-E2-B1-N-N-U1-NNN-029-AA-F0-00-00	SERIES 51	S51-080MV-1
701351	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-NN-80-S-3-C8-K-03-NNN-32-32-24	SERIES 90	S90-250PV
701353	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-L2-B2-V-A-H7-NNN-160-AA-H0-B2-00	SERIES 51	S51-250MV
701354	PUMP-VAR-DISPL CW 90PV042	90R042-HF-5-NN-80-S-3-C3-C-00-GBA-26-26-20	SERIES 90	S90-042PV
701355	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-BC-60-P-3-C6-D-03-GBA-32-32-20	SERIES 90	S90-075PV
701356	PUMP-VAR-DISPL CW 90PV130	90R130-HF-5-NN-80-S-3-C8-H-03-GBA-30-30-24	SERIES 90	S90-130PV
701357	PUMP-VAR-DISPL CW 90PV100	90R100-KA-2-CD-60-S-4-S1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
701358	PUMP-VAR-DISPL CW 90PV075	90R075-DD-5-NN-60-S-4-C7-D-04-GBA-32-32-20-F001	SERIES 90	S90-075PV
701360	MOTOR-VAR-DISPL 51MD160	51D160-A-D5-N-HS-A2-C-H-E1-NNN-035-AA-NN-15-27	SERIES 51	S51-160MV
701362	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-5-NN-80-S-3-C8-K-03-NNN-30-30-24	SERIES 90	S90-250PV
701364	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-E2-L2-A-N-E4-ADA-050-AA-G3-03-18	SERIES 51	S51-250MV
701365	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-E2-R2-A-N-E3-ADA-050-AA-G3-03-18	SERIES 51	S51-250MV
701366	PUMP-VAR-DISPL CCW 90PV100	90L100-HF-5-BB-60-R-3-C7-F-03-GBA-42-42-28	SERIES 90	S90-100PV
701368	PUMP-VAR-DISPL CCW 90PV100	90L100-HF-5-BC-60-R-3-C7-F-03-GBA-42-42-28	SERIES 90	S90-100PV
701370	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-CD-60-S-3-C7-E-03-FAB-32-32-20	SERIES 90	S90-100PV
701371	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-BB-60-S-3-S1-D-03-FAB-23-23-20	SERIES 90	S90-075PV
701373	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-BC-60-P-3-F1-E-03-GBA-35-35-20	SERIES 90	S90-100PV
701374	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-NN-80-S-4-C8-H-03-GBA-38-38-24	SERIES 90	S90-130PV
701376	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-NN-80-S-4-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
701377	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-NN-80-S-4-C8-K-03-NNN-32-32-24	SERIES 90	S90-250PV
701380	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-NN-80-S-3-C8-K-03-NNN-35-35-24	SERIES 90	S90-250PV
701382	PUMP-VAR-DISPL CW 90PV180	90R180-HF-5-NN-80-S-3-C8-J-03-NNN-35-35-24	SERIES 90	S90-180PV
701384	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-CD-80-S-3-C7-F-03-GBA-38-38-24	SERIES 90	S90-100PV
701385	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-CD-80-S-3-C8-H-03-GBA-38-38-26	SERIES 90	S90-130PV
701386	PUMP-VAR-DISPL CW 90PV250	90R250-HF-5-NN-80-S-4-C8-K-03-NNN-35-35-28	SERIES 90	S90-250PV
701393	MOTOR-VAR-DISPL 51MV060-1	51V060-1--R-S1-N-E2-B1-N-N-U1-ADA-012-AA-F0-00-00	SERIES 51	S51-060MV-1
701394	MOTOR-VAR-DISPL 51MV080	51V080-R-C7-N-HE-B2-C-E-E6-NNN-031-AA-E4-13-00	SERIES 51	S51-080MV
701395	PUMP-VAR-DISPL CW 90PV100	90R100-KN-5-NN-80-P-3-C7-E-03-GBA-29-29-24	SERIES 90	S90-100PV
701397	MOTOR-VAR-DISPL 51MV160	51V160-A-C8-N-T1-R5-L-N-G0-NNN-060-AA-G0-00-B7	SERIES 51	S51-160MV
701398	MOTOR-VAR-DISPL 51MD110-1	51D110-1--A-D3-N-T1-L5-N-N-X1-NNN-063-AA-F3-00-25	SERIES 51	S51-110MV-1
701399	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-BC-60-S-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
701400	PUMP-VAR-DISPL CW 90PV100	90R100-KP-5-NN-80-R-3-G1-E-00-GBA-42-42-24	SERIES 90	S90-100PV

701401	PUMP-VAR-DISPL CW 90PV100	90R100-KP-5-CK-80-R-3-F1-E-00-GBA-42-42-24	SERIES 90	S90-100PV
701402	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-NN-80-L-3-F1-F-03-GBA-42-42-28	SERIES 90	S90-130PV
701403	MOTOR-FIXED-DISPL 90MF100	90-M-100-NC-0-N-7-N-0-C7-W-00-NNN-00-00-H0	SERIES 90	S90-100MF
701404	MOTOR-FIXED-DISPL 90MF100	90-M-100-NC-0-N-U-N-0-F1-W-00-PAA-00-00-H0	SERIES 90	S90-100MF
701405	PUMP-VAR-DISPL CW 90PV042	90R042-FA-1-AB-80-S-7-C3-B-B1-FAC-48-48-26	SERIES 90	S90-042PV
701406	MOTOR-VAR-DISPL 51MV160	51V160-R-F2-N-T2-R5-L-N-G0-ADA-043-AA-F3-00-C0	SERIES 51	S51-160MV
701407	MOTOR-VAR-DISPL 51MV160	51V160-R-F2-N-T2-R5-L-N-G0-NNN-043-AA-F3-00-C0	SERIES 51	S51-160MV
701408	PUMP-VAR-DISPL CCW 90PV130	90L130-DD-5-BC-80-S-3-C8-F-GB-GBA-42-42-24	SERIES 90	S90-130PV
701410	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-AB-80-P-4-C3-C-03-GBA-35-35-24	SERIES 90	S90-042PV
701416	MOTOR-VAR-DISPL 51MD080-1	51D080-1--R-D2-N-P7-P7-N-N-X1-ADA-047-AA-F0-00-AA	SERIES 51	S51-080MV-1
701418	PUMP-VAR-DISPL CCW 90PV075	90L075-CA-1-NN-80-P-3-S1-D-00-GBA-30-30-24	SERIES 90	S90-075PV
701419	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-CD-80-P-3-C7-D-03-EFI-30-30-24	SERIES 90	S90-075PV
701421	PUMP-VAR-DISPL CW 90PV100	90R100-DD-5-AB-60-S-4-C7-F-GB-GBA-42-42-24	SERIES 90	S90-100PV
701422	PUMP-VAR-DISPL CW 90PV075	90R075-HF-5-NN-60-S-4-C6-D-03-GBA-21-21-24	SERIES 90	S90-075PV
701423	PUMP-VAR-DISPL CCW 90PV100	90L100-HF-5-NN-80-S-4-C7-E-03-GBA-21-21-24	SERIES 90	S90-100PV
701424	MOTOR-VAR-DISPL 51MD110	51D110-A-D3-N-JA-NN-B-E-K3-NNN-028-AA-F3-12-25	SERIES 51	S51-110MV
701426	PUMP-VAR-DISPL CW 90PV055	90R055-KA-5-NN-80-S-3-C6-C-03-GBA-38-38-20	SERIES 90	S90-055PV
701427	MOTOR-VAR-DISPL 51MV110	51V110-R-F1-N-HS-A2-C-H-E1-NNN-036-AA-NN-30-27	SERIES 51	S51-110MV
701428	MOTOR-VAR-DISPL 51MV060	51V060-R-S1-N-HS-A2-C-H-E1-NNN-018-AA-NN-30-25	SERIES 51	S51-060MV
701430	PUMP-VAR-DISPL CCW 90PV100	90L100-MA-5-BC-60-R-3-C7-E-C5-GBA-42-42-24	SERIES 90	S90-100PV
701432	MOTOR-VAR-DISPL 51MV080-1	51V080-1--A-C7-N-T1-D1-N-N-X1-NNN-048-AA-F0-00-29	SERIES 51	S51-080MV-1
701434	PUMP-VAR-DISPL CW 90PV130	90R130-KA-6-BC-80-S-3-C8-H-03-GBA-48-48-24	SERIES 90	S90-130PV
701437	MOTOR-VAR-DISPL 51MD110-1	51D110-1--R-D3-N-N1-NN-N-N-U1-NNN-043-AA-F0-00-00	SERIES 51	S51-110MV-1
701438	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-CD-80-S-4-C8-H-00-GBA-38-38-24	SERIES 90	S90-130PV
701442	PUMP-VAR-DISPL CW 90PV055	90R055-KA-5-CD-60-P-3-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV
701443	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-NN-80-P-4-S1-D-03-GBA-38-38-24	SERIES 90	S90-075PV
701444	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-F2-A2-A-N-E1-NNN-055-AA-G0-03-28	SERIES 51	S51-160MV
701448	PUMP-VAR-DISPL CCW 90PV055	90L055-KA-5-NN-80-S-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
701450	PUMP-VAR-DISPL CCW 90PV055	90L055-HF-5-NN-80-S-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
701452	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-CD-60-S-3-C7-D-03-GBA-42-42-24	SERIES 90	S90-075PV
701453	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-CD-60-S-3-C7-D-03-GBA-26-26-24	SERIES 90	S90-075PV
701455	PUMP-VAR-DISPL CCW 90PV055	90L055-KA-5-AB-60-S-3-S1-C-03-GBA-26-26-24	SERIES 90	S90-055PV
701456	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-AB-80-S-4-C7-E-03-GBA-42-42-24	SERIES 90	S90-075PV
701459	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-NN-80-S-4-C7-E-03-GBA-35-35-24	SERIES 90	S90-100PV
701460	PUMP-VAR-DISPL CW 90PV100	90R100-MA-5-BB-60-S-3-C7-E-C5-FAX-42-42-26	SERIES 90	S90-100PV
701462	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-5-BB-80-S-3-C8-J-03-NNN-26-26-24	SERIES 90	S90-250PV

701463	PUMP-VAR-DISPL CCW 90PV042	90L042-KA-5-AB-80-P-3-C3-C-03-GBA-42-42-24	SERIES 90	S90-042PV
701464	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-EQ-A4-K-Y-C5-NNN-137-AA-H0-70-35	SERIES 51	S51-250MV
701465	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-NN-80-S-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-100PV
701467	PUMP-VAR-DISPL CW 90PV055	90R055-KA-5-NN-60-S-3-C6-C-03-GBA-32-32-20	SERIES 90	S90-055PV
701469	PUMP-VAR-DISPL CW 90PV055	90R055-MB-5-AB-60-S-3-C6-C-C5-GBA-42-42-24	SERIES 90	S90-055PV
701470	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-AB-80-S-4-C7-E-03-GBA-26-26-24	SERIES 90	S90-100PV
701471	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-NN-80-S-3-C3-C-03-GBA-42-42-24	SERIES 90	S90-042PV
701472	PUMP-VAR-DISPL CW 90PV075	90R075-KN-5-CD-80-P-4-C7-E-03-GBA-42-42-24	SERIES 90	S90-075PV
701475	MOTOR-VAR-DISPL 51MD080-1	51D080-1--A-D2-N-TH-D2-N-N-X1-NNN-024-AA-F0-00-29	SERIES 51	S51-080MV-1
701477	PUMP-VAR-DISPL CW 90PV055	90R055-MA-5-BC-60-S-3-C6-C-C5-GBA-42-42-24	SERIES 90	S90-055PV
701478	PUMP-VAR-DISPL CW 90PV055	90R055-HF-5-CD-60-S-3-C6-C-03-GBA-42-42-24	SERIES 90	S90-055PV
701479	PUMP-VAR-DISPL MPV035	MPV-035-D-B-A-A-W-S-G-BA-A-A-BBB-DR-A-FF-A-NNN	M35/44	O35PV
701481	MOTOR-VAR-DISPL 51MV110-1	51V110-1--A-C8-N-T1-D1-N-N-X1-NNN-055-AA-E6-00-32	SERIES 51	S51-110MV-1
701483	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-AB-80-S-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
701484	MOTOR-VAR-DISPL 51MD110	51D110-A-D3-N-HS-A3-C-E-E5-NNN-050-AA-F0-13-29	SERIES 51	S51-110MV
701485	PUMP-VAR-DISPL MPV046	MPV-046-C-B-A-H-R-B-A-AA-A-A-BJJ-AB-U-ZK-A-NNN	M46	M46-046PV
701486	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-AB-80-S-3-D8-H-03-GBA-42-42-24	SERIES 90	S90-130PV
701487	MOTOR-VAR-DISPL 51MV110	51V110-R-C8-N-HS-A2-B-N-A7-NNN-074-AA-F3-10-30	SERIES 51	S51-110MV
701488	PUMP-VAR-DISPL CW 90PV180	90R180-DD-5-BB-80-S-4-C8-J-44-NNN-35-35-30	SERIES 90	S90-180PV
701489	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-EG-80-S-C-C8-J-03-NNN-42-42-24	SERIES 90	S90-180PV
701492	PUMP-VAR-DISPL CCW 90PV100	90L100-MB-5-CD-80-R-3-S1-E-C5-GBA-35-35-24	SERIES 90	S90-100PV
701493	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-HZ-B1-A-N-C2-NNN-050-BB-F3-03-00	SERIES 51	S51-250MV
701495	PUMP-VAR-DISPL CW 90PV100	90R100-MA-5-NN-60-R-3-S1-E-C5-GBA-42-42-24	SERIES 90	S90-100PV
701496	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-NN-60-R-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
701498	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-AB-80-S-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
701499	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-BB-60-R-3-C7-D-03-GBA-38-38-28	SERIES 90	S90-075PV
701500	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-HZ-B1-B-H-G5-NNN-050-AA-G3-12-00	SERIES 51	S51-250MV
701501	PUMP-VAR-DISPL CW 90PV130	90R130-DD-5-AB-80-S-4-T4-H-G8-GBA-42-42-24	SERIES 90	S90-130PV
701502	PUMP-VAR-DISPL CW 90PV250	90R250-HF-5-CD-80-T-4-F1-K-03-NNN-26-26-24	SERIES 90	S90-250PV
701505	PUMP-VAR-DISPL CW 90PV075	90R075-DD-5-AB-60-S-4-T2-D-G8-FAC-42-42-24	SERIES 90	S90-075PV
701506	PUMP-VAR-DISPL CCW 90PV130	90L130-MA-5-BC-80-S-3-F1-H-C5-GBA-38-38-24	SERIES 90	S90-130PV
701507	MOTOR-VAR-DISPL 51MC160	51C160-R-D5-N-T2-C2-L-N-G0-NNN-080-AA-H0-00-B5	SERIES 51	S51-160MV
701509	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-EF-80-S-C-C8-J-03-NNN-35-35-24	SERIES 90	S90-180PV
701510	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-NN-80-S-C-F1-J-03-NNN-35-35-24	SERIES 90	S90-180PV
701511	PUMP-VAR-DISPL CCW 90PV075	90L075-HF-5-NN-60-S-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
701513	PUMP-VAR-DISPL CW 90PV075	90R075-MA-5-CD-80-P-3-C7-D-05-GBA-29-29-24	SERIES 90	S90-075PV

701514	MOTOR-VAR-DISPL 51MV060-1	51V060-1--A-D1-N-P7-P7-N-N-X1-NNN-021-AA-E6-00-AA	SERIES 51	S51-060MV-1
701515	PUMP-VAR-DISPL CW 90PV042	90R042-FC-2-AB-80-S-7-C3-C-B4-EFI-45-45-32	SERIES 90	S90-042PV
701518	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-BC-60-S-3-T6-E-03-GBA-23-23-24	SERIES 90	S90-075PV
701519	PUMP-VAR-DISPL CW 90PV075	90R075-MN-1-BB-60-R-7-C7-C-21-FAB-42-42-28	SERIES 90	S90-075PV
701521	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-NN-80-S-C-C8-H-03-GLA-29-29-24	SERIES 90	S90-180PV
701522	PUMP-VAR-DISPL CCW 90PV042	90L042-KA-5-BB-80-S-3-C3-C-03-GBA-42-42-24	SERIES 90	S90-042PV
701523	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-NN-80-P-3-C3-C-03-GLA-23-23-24	SERIES 90	S90-042PV
701526	PUMP-VAR-DISPL CW 90PV130	90R130-MA-5-CD-80-L-4-C8-H-C7-GBA-35-35-24	SERIES 90	S90-130PV
701527	PUMP-VAR-DISPL CCW 90PV100	90L100-DD-5-BC-80-S-4-S1-F-G1-GBA-42-42-20	SERIES 90	S90-100PV
701528	PUMP-VAR-DISPL CCW 90PV055	90L055-DD-5-CD-80-S-4-S1-D-G1-GBA-42-42-20	SERIES 90	S90-055PV
701529	PUMP-VAR-DISPL CCW 90PV075	90L075-DD-5-BB-80-S-4-S1-E-G1-GBA-42-42-20	SERIES 90	S90-075PV
701530	PUMP-VAR-DISPL CW 90PV042	90R042-MA-5-BC-80-S-4-C3-B-C5-GBA-17-17-18	SERIES 90	S90-042PV
701535	PUMP-VAR-DISPL CW 90PV130	90R130-DD-5-AB-80-S-4-F1-H-G8-GBA-42-42-24	SERIES 90	S90-130PV
701536	PUMP-VAR-DISPL CW 90PV042	90R042-PB-5-NN-80-P-3-C3-C-03-GBA-20-20-24	SERIES 90	S90-042PV
701539	PUMP-VAR-DISPL CW 90PV180	90R180-PB-5-NN-80-T-3-F1-J-00-NNN-32-32-24	SERIES 90	S90-180PV
701541	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-T1-C0-L-N-K7-NNN-051-AA-F3-00-B7	SERIES 51	S51-160MV
701542	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-AB-80-P-3-T4-H-03-EFC-42-42-30	SERIES 90	S90-130PV
701544	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-NN-80-S-4-C8-H-44-GBA-35-35-20	SERIES 90	S90-130PV
701546	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-NN-60-R-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
701547	MOTOR-VAR-DISPL 51MD160	51D160-A-D5-N-HZ-B1-B-H-C2-NNN-032-AA-F0-09-00	SERIES 51	S51-160MV
701548	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-EG-80-R-3-C8-J-04-NNN-42-42-24	SERIES 90	S90-180PV
701549	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-BC-80-R-3-C8-J-04-NNN-42-42-24	SERIES 90	S90-180PV
701550	PUMP-VAR-DISPL CW 90PV250	90R250-KA-2-NN-80-T-3-C8-K-03-NNN-35-35-28	SERIES 90	S90-250PV
701552	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-BC-60-S-3-C7-F-04-GBA-35-35-24	SERIES 90	S90-100PV
701554	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-CD-80-S-3-C8-K-04-NNN-42-42-24	SERIES 90	S90-250PV
701555	PUMP-VAR-DISPL CW 90PV055	90R055-KA-5-CD-80-P-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
701559	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-CD-80-P-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
701560	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-NN-80-P-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
701562	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-5-NN-80-S-3-C8-K-01-NNN-42-42-30	SERIES 90	S90-250PV
701563	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-AB-80-S-3-C8-F-00-EFC-42-42-24	SERIES 90	S90-130PV
701564	PUMP-VAR-DISPL CW 90PV130	90R130-DD-5-NN-80-L-3-C8-H-GB-GBA-42-42-22	SERIES 90	S90-130PV
701566	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-BB-80-S-3-C3-C-03-GBA-42-42-24	SERIES 90	S90-042PV
701567	PUMP-VAR-DISPL CCW 90PV250	90L250-MB-5-NN-80-S-4-C8-K-01-NNN-42-42-30-F001	SERIES 90	S90-250PV
701568	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-EQ-A5-J-Y-A6-NNN-050-AA-H0-20-00	SERIES 51	S51-250MV
701569	PUMP-VAR-DISPL CCW 90PV055	90L055-KA-5-NN-80-S-3-S1-C-03-GBA-23-23-24	SERIES 90	S90-055PV
701570	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-C8-N-E1-B1-N-N-U1-NNN-060-AA-F3-00-00	SERIES 51	S51-110MV-1

701571	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-BC-60-S-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-100PV
701572	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-AB-80-S-3-C8-J-03-NNN-42-42-24	SERIES 90	S90-180PV
701573	PUMP-VAR-DISPL CCW 90PV055	90L055-KA-5-BC-60-S-3-S1-C-00-GBA-35-35-24	SERIES 90	S90-055PV
701575	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-E2-B1-N-N-U1-ADA-038-AA-F0-00-00	SERIES 51	S51-110MV-1
701576	PUMP-VAR-DISPL CW 42PV28	42-R-28-D-ANNB-02-B-3-G-2-C-N-A-21-21-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
701580	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-AB-80-T-3-C8-J-03-NNN-35-35-24	SERIES 90	S90-180PV
701585	PUMP-VAR-DISPL CW 90PV100	90R100-FA-1-BC-60-S-7-C7-E-B1-EAB-42-42-28	SERIES 90	S90-100PV
701586	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-AB-80-S-3-D8-H-03-GBA-23-23-20	SERIES 90	S90-130PV
701587	PUMP-VAR-DISPL CW 90PV250	90R250-MA-5-EG-80-S-4-C8-K-02-NNN-38-38-24	SERIES 90	S90-250PV
701588	PUMP-VAR-DISPL CW 90PV250	90R250-MA-5-BB-80-S-4-C8-K-02-NNN-38-38-24	SERIES 90	S90-250PV
701589	PUMP-VAR-DISPL CW 90PV042	90R042-MA-5-BC-80-S-4-C3-C-02-GBA-38-38-24-F008	SERIES 90	S90-042PV
701590	PUMP-VAR-DISPL CW 90PV180	90R180-MA-5-NN-80-S-3-C8-J-C5-NNN-35-35-24	SERIES 90	S90-180PV
701591	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-NN-60-S-3-C6-D-03-GBA-23-23-18	SERIES 90	S90-075PV
701600	PUMP-VAR-DISPL CW 90PV055	90R055-HF-5-BG-80-S-3-C6-C-03-GBA-42-42-24	SERIES 90	S90-055PV
701601	PUMP-VAR-DISPL CW 90PV042	90R042-MA-5-AB-80-P-4-C3-C-C5-GBA-26-26-24	SERIES 90	S90-042PV
701602	PUMP-VAR-DISPL CCW 90PV100	90L100-FD-5-CD-60-P-7-C7-E-B1-GCS-42-42-28	SERIES 90	S90-100PV
701604	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-NN-80-S-3-C8-F-03-GBA-32-32-24	SERIES 90	S90-130PV
701605	MOTOR-VAR-DISPL 51MD110-1	51D110-1--R-D3-N-B1-B3-N-N-U3-NNN-060-AA-F3-00-00	SERIES 51	S51-110MV-1
701606	MOTOR-VAR-DISPL 51MD110	51D110-A-D3-N-HA-B2-C-E-H7-NNN-048-AA-G0-12-00	SERIES 51	S51-110MV
701608	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-CD-80-P-3-C7-F-03-GBA-42-42-28	SERIES 90	S90-100PV
701609	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-TA-D2-N-N-X1-NNN-022-AA-F0-00-21	SERIES 51	S51-110MV-1
701610	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-NN-80-S-3-C6-D-03-GBA-42-42-24	SERIES 90	S90-075PV
701611	PUMP-VAR-DISPL CW 90PV100	90R100-MA-5-AB-80-S-4-C7-E-C5-GBA-14-14-18	SERIES 90	S90-100PV
701614	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-NN-80-L-3-C7-E-03-GBA-26-26-24	SERIES 90	S90-075PV
701616	PUMP-VAR-DISPL CW 90PV055	90R055-KA-5-NN-80-S-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
701617	PUMP-VAR-DISPL CW 90PV130	90R130-FG-5-AB-80-P-7-C8-H-B1-EFI-42-42-30	SERIES 90	S90-130PV
701618	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-C7-N-T1-L5-N-N-X1-NNN-047-AA-F3-00-25	SERIES 51	S51-080MV-1
701621	MOTOR-VAR-DISPL 51MV110	51V110-R-C8-N-J1-K3-C-E-J5-NNN-030-AA-F0-12-20	SERIES 51	S51-110MV
701624	PUMP-VAR-DISPL CCW 90PV075	90L075-PB-5-BB-80-S-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
701625	PUMP-VAR-DISPL CCW 90PV042	90L042-PB-5-BC-80-S-3-C3-B-03-GBA-42-42-24	SERIES 90	S90-042PV
701626	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-NN-80-L-4-F1-H-04-GBA-38-14-24	SERIES 90	S90-130PV
701627	PUMP-VAR-DISPL CCW 90PV042	90L042-KA-5-BB-80-P-3-C3-C-03-GBA-42-42-24	SERIES 90	S90-042PV
701629	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-CD-60-P-3-C6-D-03-GBA-14-14-20	SERIES 90	S90-075PV
701634	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-AB-60-S-3-C6-D-02-EEB-38-38-24	SERIES 90	S90-075PV
701637	PUMP-VAR-DISPL MPV046	MPV-046-C-B-A-H-S-B-B-AA-A-A-BHH-AB-U-AB-A-NNN	M46	M46-046PV
701638	MOTOR-VAR-DISPL 51MD160	51D160-A-D4-N-T4-L5-L-N-J2-ADA-055-AA-F0-00-B5	SERIES 51	S51-160MV

701639	PUMP-VAR-DISPL CCW 90PV042	90L042-KA-5-NN-80-S-3-C3-B-03-GBA-42-42-20	SERIES 90	S90-042PV
701640	PUMP-VAR-DISPL CW 90PV055	90R055-HF-5-NN-80-R-4-C6-C-03-GBA-23-23-24	SERIES 90	S90-055PV
701641	PUMP-VAR-DISPL CW 90PV180	90R180-MA-5-NN-80-T-3-C8-H-C6-NNN-17-17-20	SERIES 90	S90-180PV
701642	PUMP-VAR-DISPL CCW 90PV250	90L250-HF-5-BC-80-T-4-C8-K-03-NNN-35-35-24	SERIES 90	S90-250PV
701643	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-CD-80-P-3-C7-D-04-GBA-42-42-24	SERIES 90	S90-075PV
701645	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-JA-NN-C-E-K3-NNN-045-BB-F3-30-37	SERIES 51	S51-160MV
701648	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-CD-80-P-3-F1-H-03-GBA-35-35-24	SERIES 90	S90-130PV
701650	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-NN-80-S-4-C8-H-03-GBA-42-42-24	SERIES 90	S90-130PV
701651	PUMP-VAR-DISPL CW 90PV100	90R100-PB-5-CD-80-R-3-C7-E-00-GBA-35-14-24	SERIES 90	S90-100PV
701652	PUMP-VAR-DISPL CW 90PV100	90R100-PB-5-NN-80-R-4-S1-E-00-GBA-35-14-24	SERIES 90	S90-100PV
701654	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-NN-80-S-3-C7-F-03-GBA-30-30-24	SERIES 90	S90-100PV
701658	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-DG-80-S-4-C8-H-03-GBA-26-26-24	SERIES 90	S90-130PV
701659	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-BC-80-S-4-C8-H-03-GBA-26-26-24	SERIES 90	S90-130PV
701661	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-T2-C0-L-N-G0-ABA-100-AA-G0-00-B5	SERIES 51	S51-250MV
701662	PUMP-VAR-DISPL CW 90PV100	90R100-FD-5-CD-60-S-7-C7-F-B1-GBS-42-42-28	SERIES 90	S90-100PV
701663	PUMP-VAR-DISPL CW 90PV100	90R100-FD-5-CD-60-S-7-S1-F-B1-GBS-42-42-28	SERIES 90	S90-100PV
701667	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-AB-80-S-3-C8-K-03-EFI-42-42-24	SERIES 90	S90-250PV
701668	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-AB-80-P-3-C3-C-03-GBA-42-42-24	SERIES 90	S90-042PV
701670	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-NN-80-R-4-C7-D-05-FAL-35-35-20	SERIES 90	S90-075PV
701671	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-T2-C0-L-N-G0-NNN-100-AA-G0-00-B5	SERIES 51	S51-250MV
701673	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-N-B2-B3-N-N-U3-ADA-024-AA-E6-00-00	SERIES 51	S51-060MV-1
701674	PUMP-VAR-DISPL CW 90PV180	90R180-DD-5-NN-80-S-C-C8-J-GB-NNN-35-35-24	SERIES 90	S90-180PV
701675	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-EQ-A5-J-Y-A6-NNN-041-AA-G0-30-00	SERIES 51	S51-160MV
701676	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D2-N-T2-C2-N-N-X1-NNN-026-AA-E6-00-35	SERIES 51	S51-080MV-1
701677	PUMP-VAR-DISPL CW 90PV130	90R130-MA-5-NN-80-R-3-C8-H-C6-GBA-17-17-20	SERIES 90	S90-130PV
701679	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-BB-80-S-3-C8-J-03-EFI-42-42-24	SERIES 90	S90-180PV
701681	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-T2-C0-L-N-G0-ABA-070-AA-F3-00-B5	SERIES 51	S51-250MV
701682	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-T2-C0-L-N-G0-NNN-070-AA-F3-00-B6	SERIES 51	S51-250MV
701683	PUMP-VAR-DISPL CW 90PV180	90R180-MA-5-NN-80-S-3-C8-J-C5-NNN-42-42-24	SERIES 90	S90-180PV
701684	PUMP-VAR-DISPL CW 90PV100	90R100-MA-5-NN-80-S-3-C7-E-C5-GBA-42-42-24	SERIES 90	S90-100PV
701687	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-EQ-A5-J-Y-A6-NNN-126-AA-B3-40-00	SERIES 51	S51-250MV
701688	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-TA-C2-L-N-G0-NNN-068-AA-G3-00-A6	SERIES 51	S51-160MV
701690	PUMP-VAR-DISPL CW 90PV042	90R042-HF-5-NN-80-S-3-C3-C-03-GBA-42-42-24	SERIES 90	S90-042PV
701692	PUMP-VAR-DISPL CW 90PV100	90R100-HF-5-BC-60-S-3-C7-E-40-GBA-35-35-24	SERIES 90	S90-100PV
701693	PUMP-VAR-DISPL CW 90PV055	90R055-KA-5-AB-80-S-4-C6-C-03-GBA-20-20-24	SERIES 90	S90-055PV
701695	PUMP-VAR-DISPL CW 90PV075	90R075-DD-5-BB-60-L-3-D7-E-GB-GBA-35-35-24	SERIES 90	S90-075PV

701702	PUMP-VAR-DISPL CW 90PV042	90R042-MA-5-AB-80-P-4-C3-C-C5-GBA-20-20-24	SERIES 90	S90-042PV
701707	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-BC-80-S-3-C8-F-03-GBA-32-32-24	SERIES 90	S90-130PV
701708	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-EQ-A5-J-Y-A6-NNN-046-AA-F3-40-00	SERIES 51	S51-160MV
701711	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-NN-80-L-3-C3-C-03-GBA-29-29-24	SERIES 90	S90-042PV
701712	PUMP-VAR-DISPL CW 90PV130	90R130-DD-5-NN-80-S-3-C8-H-GB-GBA-35-35-24	SERIES 90	S90-130PV
701713	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-BC-80-S-3-C7-E-C6-GBA-45-45-24	SERIES 90	S90-100PV
701716	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-NN-80-S-3-S1-E-03-GBA-26-26-24	SERIES 90	S90-100PV
701718	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-BC-60-P-3-C7-E-03-GBA-30-30-24	SERIES 90	S90-075PV
701721	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-5-BC-80-S-3-C8-K-03-NNN-32-32-28	SERIES 90	S90-250PV
701723	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-5-NN-80-S-3-C8-K-03-NNN-32-32-28	SERIES 90	S90-250PV
701725	PUMP-VAR-DISPL CCW 90PV055	90L055-KA-5-NN-80-D-3-C6-L-03-GBG-42-42-24	SERIES 90	S90-055PV
701727	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-BC-60-L-3-C7-D-03-FAB-42-42-24	SERIES 90	S90-075PV
701728	PUMP-VAR-DISPL CW 90PV075	90R075-KA-P-NN-80-S-3-G1-E-05-FAP-48-48-42	SERIES 90	S90-075PV
701732	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-C8-N-TA-C2-N-N-X1-NNN-074-AA-F3-00-24	SERIES 51	S51-110MV-1
701733	PUMP-VAR-DISPL CW 90PV075	90R075-HF-5-NN-60-S-3-C6-E-03-GBA-42-42-24	SERIES 90	S90-075PV
701734	MOTOR-FIXED-DISPL 90MF042	90-M-042-NC-0-N-8-N-0-C3-W-00-NNN-00-00-E4	SERIES 90	S90-042MF
701737	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-BB-60-P-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
701738	PUMP-VAR-DISPL CCW 90PV042	90L042-DD-N-BC-80-P-P-C3-B-02-GBA-BP-42-24-E111	SERIES 90	S90-042PV
701740	PUMP-VAR-DISPL CCW 90PV130	90L130-HF-5-BC-80-S-7-F1-F-06-GBA-30-30-24	SERIES 90	S90-130PV
701741	PUMP-VAR-DISPL CCW 90PV055	90L055-KA-5-BB-60-P-3-C6-C-03-GBA-32-32-24	SERIES 90	S90-055PV
701742	PUMP-VAR-DISPL CW 90PV100	90R100-HF-5-AB-80-S-4-C7-E-03-GBA-26-26-24	SERIES 90	S90-100PV
701743	PUMP-VAR-DISPL CW 90PV180	90R180-MA-5-CD-80-S-C-C8-H-C5-NNN-29-29-24	SERIES 90	S90-180PV
701745	PUMP-VAR-DISPL CCW 90PV042	90L042-HF-5-AB-80-P-4-C3-C-03-GBA-32-32-24	SERIES 90	S90-042PV
701747	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-EQ-A5-J-Y-A6-NNN-060-AA-H0-40-00	SERIES 51	S51-250MV
701749	PUMP-VAR-DISPL CCW 90PV130	90L130-MA-5-BB-80-S-3-C8-H-C5-GBA-42-42-24	SERIES 90	S90-130PV
701750	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-BB-80-R-3-C3-C-02-GBA-42-42-24	SERIES 90	S90-042PV
701751	PUMP-VAR-DISPL CW 42PV41	42-R-41-D-E1A6-06-B-3-G-2-F-N-N-25-25-B-A-A-NNN-NNN	SERIES 42	S42-041PV/051PV
701754	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-NN-80-S-C-C8-J-03-NNN-42-42-28	SERIES 90	S90-180PV
701760	PUMP-VAR-DISPL CW 90PV180	90R180-KN-5-CD-80-T-C-C8-H-03-FAC-42-42-24	SERIES 90	S90-180PV
701762	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-CD-60-P-3-C7-E-03-GBA-42-42-30	SERIES 90	S90-075PV
701764	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-BC-60-S-3-C7-D-03-GBA-42-42-24	SERIES 90	S90-075PV
701765	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-AB-80-T-M-C8-J-03-NNN-35-35-24	SERIES 90	S90-180PV
701766	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-T2-C0-L-N-G0-NNN-130-AA-H0-00-C0	SERIES 51	S51-250MV
701767	PUMP-VAR-DISPL CCW 90PV042	90L042-KA-5-NN-80-P-3-C3-C-04-GBA-26-26-24	SERIES 90	S90-042PV
701770	PUMP-VAR-DISPL CW 90PV100	90R100-MA-5-CD-80-S-3-C7-F-C5-GBA-35-35-30	SERIES 90	S90-100PV
701772	PUMP-VAR-DISPL CW 90PV100	90R100-MA-5-NN-80-S-3-S1-F-C5-GBA-35-35-30	SERIES 90	S90-100PV

701773	PUMP-VAR-DISPL CW 90PV075	90R075-HF-5-BC-60-S-3-C7-D-02-GBA-42-42-24	SERIES 90	S90-075PV
701774	MOTOR-VAR-DISPL 51MV160	51V160-R-F2-N-T2-L5-L-N-G0-NNN-043-AA-F3-00-C0	SERIES 51	S51-160MV
701775	PUMP-VAR-DISPL CCW 90PV180	90L180-MA-5-AB-80-S-M-C8-J-C5-NNN-35-35-20	SERIES 90	S90-180PV
701776	PUMP-VAR-DISPL CW 90PV042	90R042-MA-5-AB-80-P-4-C3-C-C5-GBA-35-20-20	SERIES 90	S90-042PV
701777	MOTOR-VAR-DISPL 51MV160	51V160-A-C8-N-T1-C0-L-N-G0-NNN-032-AA-E4-00-A3	SERIES 51	S51-160MV
701778	MOTOR-VAR-DISPL 51MV110-1	51V110-1--A-C8-N-T1-D1-N-N-X1-ADA-022-AA-E4-00-13	SERIES 51	S51-110MV-1
701779	PUMP-VAR-DISPL MPV046	MPV-046-C-B-A-H-R-B-A-BA-A-A-BGG-AB-B-AA-A-NNN	M46	M46-046PV
701782	MOTOR-VAR-DISPL 51MC080-1	51C080-1--A-D3-N-N1-NN-N-N-U1-NNN-016-AA-F0-00-00	SERIES 51	S51-080MV-1
701783	MOTOR-VAR-DISPL 51MD110	51D110-R-D4-N-D8-M1-R-J-M1-NNN-037-AA-F0-C2-37	SERIES 51	S51-110MV
701785	PUMP-VAR-DISPL CW 90PV100	90R100-HF-P-CD-80-S-3-C7-E-03-GBA-48-48-24	SERIES 90	S90-100PV
701786	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-TA-CA-N-N-X1-NNN-036-AA-E6-00-30	SERIES 51	S51-110MV-1
701787	PUMP-VAR-DISPL CW 90PV075	90R075-DD-5-CD-60-L-3-D7-D-GB-GBA-35-35-24	SERIES 90	S90-075PV
701788	PUMP-VAR-DISPL CW 90PV055	90R055-KA-5-AB-60-L-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-055PV
701793	PUMP-VAR-DISPL CW 90PV100	90R100-PB-5-CD-80-R-3-C7-E-00-GBA-32-35-20	SERIES 90	S90-100PV
701794	PUMP-VAR-DISPL CW 90PV075	90R075-PB-5-CD-80-R-3-C7-D-00-GBA-29-32-20	SERIES 90	S90-075PV
701795	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-NN-60-P-3-C6-D-03-GBA-20-20-24	SERIES 90	S90-075PV
701798	PUMP-VAR-DISPL CW 90PV180	90R180-MA-5-NN-80-S-C-C8-H-C5-NNN-29-29-24	SERIES 90	S90-180PV
701800	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-NN-60-S-3-C7-E-03-GBA-26-26-28	SERIES 90	S90-100PV
701801	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-P-BC-80-S-3-C8-H-03-GCG-45-45-24	SERIES 90	S90-130PV
701802	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-AB-80-R-3-F1-H-00-GBA-35-35-20	SERIES 90	S90-130PV
701803	PUMP-VAR-DISPL CW 90PV250	90R250-KP-5-CD-80-T-3-F1-K-03-NNN-35-35-24	SERIES 90	S90-250PV
701807	PUMP-VAR-DISPL CW 90PV055	90R055-MA-5-AB-60-P-4-C6-C-05-GBA-32-32-24	SERIES 90	S90-055PV
701808	MOTOR-VAR-DISPL 51MD110	51D110-A-D4-N-L2-B1-V-A-J1-NNN-035-AA-NN-B2-00	SERIES 51	S51-110MV
701812	PUMP-VAR-DISPL CCW 90PV055	90L055-KA-5-AD-80-S-3-C6-C-03-GBA-42-42-28	SERIES 90	S90-055PV
701817	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-BC-80-S-3-C7-D-03-GBA-42-42-24	SERIES 90	S90-075PV
701818	MOTOR-VAR-DISPL 51MC080	51C080-R-D2-N-T2-R5-L-N-G0-ACA-020-AA-E6-00-C5	SERIES 51	S51-080MV
701820	PUMP-VAR-DISPL CCW 90PV042	90L042-FC-5-NN-80-P-7-C3-C-B1-GBA-42-42-24	SERIES 90	S90-042PV
701822	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-CD-80-T-C-F1-J-03-NNN-37-37-30	SERIES 90	S90-180PV
701827	MOTOR-VAR-DISPL 51MD080-1	51D080-1--R-D2-N-B1-B3-N-N-U3-NNN-054-AA-F3-00-00	SERIES 51	S51-080MV-1
701831	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-NN-80-S-3-C7-E-03-GBA-26-26-24	SERIES 90	S90-100PV
701832	PUMP-VAR-DISPL CW 90PV042	90R042-FC-5-NN-80-S-H-C3-C-B1-EFI-35-35-24	SERIES 90	S90-042PV
701833	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-NN-80-R-3-C7-E-03-GBA-35-35-30	SERIES 90	S90-100PV
701834	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-CD-80-R-3-T6-E-03-GBA-35-35-30	SERIES 90	S90-100PV
701836	PUMP-VAR-DISPL CW 90PV100	90R100-DD-5-NN-80-S-4-C7-E-GB-GBA-26-26-24	SERIES 90	S90-100PV
701840	MOTOR-VAR-DISPL 51MV110	51V110-R-F1-N-HS-A2-B-H-E1-NNN-068-AA-NN-10-17	SERIES 51	S51-110MV
701844	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-CD-80-P-4-C7-D-03-GBA-26-26-24	SERIES 90	S90-075PV

701845	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-CD-80-P-4-S1-D-03-GBA-26-26-24	SERIES 90	S90-075PV
701846	PUMP-VAR-DISPL CCW 90PV130	90L130-MA-5-BC-80-S-3-TK-H-C5-GBA-38-38-24	SERIES 90	S90-130PV
701849	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-CD-60-S-3-C7-E-03-GBA-30-30-24	SERIES 90	S90-100PV
701851	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-BB-60-S-3-S1-E-03-GBA-30-30-24	SERIES 90	S90-100PV
701855	PUMP-VAR-DISPL CCW 42PV41	42-L-41-D-E1A6-03-B-3-G-2-F-N-A-34-34-B-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
701856	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-HS-A2-B-E-E1-NNN-168-AA-G3-05-23	SERIES 51	S51-250MV
701857	PUMP-VAR-DISPL CW 90PV250	90R250-MA-5-EG-80-T-4-C8-J-C7-NNN-32-32-24	SERIES 90	S90-250PV
701858	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-NN-80-S-3-C8-H-03-GBA-42-42-24	SERIES 90	S90-130PV
701859	PUMP-VAR-DISPL CW 90PV130	90R130-DD-5-NN-80-S-4-C8-F-GB-GBA-32-32-24	SERIES 90	S90-130PV
701860	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-NN-60-S-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
701861	PUMP-VAR-DISPL CW 90PV075	90R075-KA-P-AB-80-S-4-C7-D-03-GBA-48-48-24	SERIES 90	S90-075PV
701863	PUMP-VAR-DISPL CW 90PV075	90R075-MA-5-AB-80-S-3-C7-D-C5-GBA-42-42-24	SERIES 90	S90-075PV
701865	PUMP-VAR-DISPL CW 90PV075	90R075-MA-5-NN-60-S-4-C6-E-C6-GBA-32-32-24	SERIES 90	S90-075PV
701867	MOTOR-VAR-DISPL 51MD160	51D160-R-D4-N-TH-C2-L-N-G0-NNN-032-AA-F3-00-A6	SERIES 51	S51-160MV
701868	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-NN-80-S-3-C7-D-03-GBA-35-35-24	SERIES 90	S90-075PV
701872	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-CD-80-S-4-T6-E-03-GBA-35-35-24	SERIES 90	S90-100PV
701873	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-BB-80-S-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
701875	PUMP-VAR-DISPL CCW 90PV075	90L075-KN-5-NN-60-S-3-C7-D-03-GBA-42-42-24	SERIES 90	S90-075PV
701880	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-NN-80-S-3-C7-F-03-GBA-38-38-24	SERIES 90	S90-100PV
701882	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-C7-N-E1-B1-N-N-U1-NNN-030-AA-B0-00-00	SERIES 51	S51-080MV-1
701883	PUMP-VAR-DISPL CCW 90PV042	90L042-KA-5-AB-80-L-3-C3-C-03-GBA-35-35-24	SERIES 90	S90-042PV
701884	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-E2-A5-A-N-A6-NNN-050-AA-F0-03-00	SERIES 51	S51-160MV
701886	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-HS-A1-B-E-E2-NNN-074-AA-E6-05-35	SERIES 51	S51-250MV
701891	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-NN-80-S-4-C8-F-01-GBA-29-29-20	SERIES 90	S90-130PV
701893	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-BB-60-S-3-C7-E-04-FAX-42-42-28	SERIES 90	S90-100PV
701897	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-BC-80-L-3-C8-H-01-GBA-42-42-24	SERIES 90	S90-130PV
701898	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-CD-80-S-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-100PV
701899	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-AB-80-S-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
701900	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-NN-60-S-3-C7-E-04-GBA-35-35-24	SERIES 90	S90-100PV
701901	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-HS-A1-C-E-E2-NNN-110-AA-F3-12-35	SERIES 51	S51-250MV
701902	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-BB-80-S-3-C8-J-03-NNN-35-35-24	SERIES 90	S90-250PV
701903	1MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-HA-B1-B-E-C2-NNN-032-AA-E6-11-00	SERIES 51	S51-080MV
701905	PUMP-VAR-DISPL MPV046	MPV-046-C-B-B-G-S-B-J-AA-G-A-BFF-CD-A-WA-C-NNN	M46	M46-046PV
701908	MOTOR-VAR-DISPL 51MC060-1	51C060-1--A-D1-N-N1-NN-N-N-U1-NNN-015-AA-NN-00-00	SERIES 51	S51-060MV-1
701911	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-CD-80-P-3-C7-E-03-GBA-42-42-20	SERIES 90	S90-100PV
701913	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-AB-80-P-3-C7-E-03-GBA-42-42-20	SERIES 90	S90-100PV

701914	PUMP-VAR-DISPL CW 90PV042	90R042-FC-5-BB-80-S-7-C3-C-B1-GLA-35-35-32	SERIES 90	S90-042PV
701915	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-AB-80-S-3-C3-B-03-GBA-20-20-18	SERIES 90	S90-042PV
701916	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-5-EG-80-S-3-C8-K-01-NNN-42-42-30	SERIES 90	S90-250PV
701918	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-E2-A2-A-N-F1-NNN-114-AA-G0-03-20	SERIES 51	S51-250MV
701924	PUMP-VAR-DISPL MPV046	MPV-046-C-B-A-W-S-B-B-AA-B-A-BFF-AB-D-JJ-A-NNN	M46	M46-046PV
701927	PUMP-VAR-DISPL CW 42PV41	42-R-41-C-E1A6-06-B-3-G-2-H-N-A-34-34-B-E-E-NNN-NNN	SERIES 42	S42-041PV/051PV
701929	PUMP-VAR-DISPL CW 42PV041	42-R-41-D-F2NN-73-J-D-G-2-H-N-A-30-30-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
701930	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-BC-80-R-3-C8-F-03-GBA-29-29-20	SERIES 90	S90-130PV
701933	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-NN-60-S-3-C6-C-03-GBA-35-35-24	SERIES 90	S90-075PV
701934	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-B-N2-NN-N-N-A0-NNN-168-AA-H0-00-00	SERIES 51	S51-250MV
701935	PUMP-VAR-DISPL CW 90PV180	90R180-DD-2-CD-80-S-C-8-J-03-NNN-32-32-24	SERIES 90	S90-180PV
701936	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-N-HS-A2-B-H-C1-NNN-070-AA-NN-10-13	SERIES 51	S51-160MV
701937	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-EQ-A5-J-Y-A6-NNN-016-AA-F3-30-00	SERIES 51	S51-080MV
701939	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-AB-80-P-4-C3-C-04-GBA-35-35-24	SERIES 90	S90-042PV
701944	PUMP-VAR-DISPL CW 90PV250	90R250-HF-5-NN-80-T-3-C8-J-03-NNN-35-35-24	SERIES 90	S90-250PV
701945	MOTOR-VAR-DISPL 51MD110-1	51D110-1--A-D4-N-T1-L5-N-N-X1-NNN-041-AA-F0-00-17	SERIES 51	S51-110MV-1
701948	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-NN-60-S-3-C7-D-03-GBA-40-40-24	SERIES 90	S90-075PV
701951	MOTOR-VAR-DISPL 51MV160	51V160-A-C8-D-N2-NN-N-N-A0-NNN-115-AA-F0-00-00	SERIES 51	S51-160MV
701952	MOTOR-FIXED-DISPL 90MF100	90-M-100-NC-0-N-8-N-0-K3-W-00-NNN-00-00-F0	SERIES 90	S90-100MF
701954	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-AB-80-P-3-C7-E-42-GBA-32-32-30	SERIES 90	S90-075PV
701955	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-CD-80-L-3-C7-D-03-GBA-40-40-24	SERIES 90	S90-075PV
701956	PUMP-VAR-DISPL CCW 90PV100	90L100-HF-5-AB-80-L-3-C7-E-03-GBA-32-32-24	SERIES 90	S90-100PV
701957	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-NN-80-T-4-C8-J-03-NNN-35-20-26	SERIES 90	S90-250PV
701958	PUMP-VAR-DISPL CW 90PV100	90R100-DD-5-BC-80-L-3-T6-E-01-GBA-29-29-24	SERIES 90	S90-100PV
701959	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-C8-N-F1-B1-N-N-U1-NNN-060-AA-F3-00-00	SERIES 51	S51-110MV-1
701962	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-NN-60-S-3-C7-D-01-GBA-42-42-24	SERIES 90	S90-075PV
701964	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-AB-80-P-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
701970	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-BC-80-R-4-C8-H-05-HCA-35-35-20	SERIES 90	S90-130PV
701971	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-CD-60-R-3-C7-E-04-FAL-35-35-20	SERIES 90	S90-100PV
701972	PUMP-VAR-DISPL CW 90PV075	90R075-MB-5-BC-60-P-3-C7-E-C5-GBA-42-42-24	SERIES 90	S90-075PV
701975	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-NN-60-S-3-C6-D-04-GBA-35-35-20	SERIES 90	S90-075PV
701976	PUMP-VAR-DISPL CW 90PV130	90R130-MA-5-NN-80-S-3-C8-H-C5-GBA-35-35-30	SERIES 90	S90-130PV
701980	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-NN-60-R-3-S1-D-05-FAL-35-35-20	SERIES 90	S90-075PV
701982	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-CD-80-T-3-C8-J-09-NNN-35-35-28	SERIES 90	S90-250PV
701984	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-NN-80-S-3-C8-H-00-GBA-42-42-24	SERIES 90	S90-130PV
701986	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-E2-A2-A-N-E1-NNN-065-AA-F3-03-20	SERIES 51	S51-160MV

701988	PUMP-VAR-DISPL CW 90PV075	90R075-FM-5-CD-60-S-7-C7-D-B6-GMD-40-40-30	SERIES 90	S90-075PV
701989	PUMP-VAR-DISPL CW 90PV075	90R075-CA-5-AB-60-S-7-S1-D-00-GLA-40-40-30	SERIES 90	S90-075PV
701992	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-NN-60-S-3-C7-E-03-GBA-29-29-24	SERIES 90	S90-075PV
701993	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-CD-80-P-4-C7-E-03-GBA-35-35-24	SERIES 90	S90-100PV
701997	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-BC-80-S-4-C8-H-03-GBA-35-35-24	SERIES 90	S90-130PV
701998	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-E2-B1-N-N-U1-NNN-036-AA-F0-00-00	SERIES 51	S51-110MV-1
701999	PUMP-VAR-DISPL CCW 90PV055	90L055-KA-5-BC-60-S-3-C6-D-03-GBA-35-35-24	SERIES 90	S90-055PV
702007	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-NN-80-S-3-C8-J-03-NNN-26-26-24	SERIES 90	S90-180PV
702008	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-NN-80-P-4-C3-B-03-GBA-23-23-24	SERIES 90	S90-042PV
702009	PUMP-VAR-DISPL CW 90PV180	90R180-HF-5-EF-80-T-3-C8-J-03-NNN-32-32-24	SERIES 90	S90-180PV
702010	PUMP-VAR-DISPL CW 90PV180	90R180-HF-5-NN-80-T-3-F1-J-03-NNN-32-32-24	SERIES 90	S90-180PV
702013	PUMP-VAR-DISPL CCW 90PV180	90L180-MA-5-AB-80-S-C-C8-J-C5-NNN-42-42-24	SERIES 90	S90-180PV
702014	MOTOR-VAR-DISPL 51MV080	51V080-R-C7-N-N2-NN-N-N-A0-NNN-024-AA-F3-00-00	SERIES 51	S51-080MV
702015	PUMP-VAR-DISPL CCW 90PV055	90L055-HF-5-BC-80-S-3-C6-C-03-GBA-42-42-24	SERIES 90	S90-055PV
702018	PUMP-VAR-DISPL CW 90PV075	90R075-MA-5-AB-60-L-4-C7-E-03-GBA-38-38-24	SERIES 90	S90-075PV
702020	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-NN-80-S-3-C7-D-03-GBA-42-42-24	SERIES 90	S90-075PV
702021	MOTOR-VAR-DISPL 51MC080	51C080-R-D2-N-N2-NN-N-N-A0-NNN-054-AA-E6-00-00	SERIES 51	S51-080MV
702022	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-NN-60-S-3-C6-D-05-GBA-32-32-24	SERIES 90	S90-075PV
702023	PUMP-VAR-DISPL CCW 90PV100	90L100-DC-5-BC-80-P-3-C7-E-GB-GBA-30-30-24	SERIES 90	S90-100PV
702024	PUMP-VAR-DISPL CW 90PV055	90R055-KA-1-AB-80-P-4-C6-C-04-GBA-35-35-24	SERIES 90	S90-055PV
702025	PUMP-VAR-DISPL MPV046	MPV-046-C-B-A-H-L-B-C-AA-A-A-BHH-CD-A-RR-A-NNN	M46	M46-046PV
702026	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-T2-L5-N-N-X1-ADA-025-AA-F3-00-30	SERIES 51	S51-110MV-1
702028	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-AB-60-R-3-C6-D-03-GBA-42-42-24	SERIES 90	S90-075PV
702029	PUMP-VAR-DISPL CCW 90PV055	90L055-KA-6-NN-80-P-3-C6-C-03-FAB-48-48-24	SERIES 90	S90-055PV
702030	PUMP-VAR-DISPL CW 90PV075	90R075-KP-5-AB-60-P-3-S1-C-03-EFC-38-14-24	SERIES 90	S90-075PV
702033	PUMP-VAR-DISPL CW 90PV100	90R100-KN-5-NN-80-S-3-S1-E-03-GBA-29-29-24	SERIES 90	S90-100PV
702036	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-NN-60-S-3-C7-D-33-GBA-38-38-24	SERIES 90	S90-075PV
702037	MOTOR-FIXED-DISPL 90MF100	90-M-100-NC-0-N-8-N-0-S1-N-00-NNN-00-00-00	SERIES 90	S90-100MF
702038	PUMP-VAR-DISPL CCW 90PV100	90L100-HF-5-AB-80-S-4-C7-F-02-GBA-30-30-20	SERIES 90	S90-100PV
702039	PUMP-VAR-DISPL CCW 90PV130	90L130-HF-5-CD-80-S-4-C8-H-02-GBA-32-32-20	SERIES 90	S90-130PV
702040	PUMP-VAR-DISPL CCW 90PV100	90L100-HF-5-BC-80-S-4-C7-F-02-GBA-30-30-20	SERIES 90	S90-100PV
702041	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-TA-C2-L-N-G0-NNN-092-AA-G0-00-B8	SERIES 51	S51-160MV
702042	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-T2-C2-L-N-K7-NNN-120-AA-NN-00-B8	SERIES 51	S51-250MV
702044	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-NN-80-S-C-C8-J-03-NNN-32-32-24	SERIES 90	S90-180PV
702045	MOTOR-VAR-DISPL 51MV110	51V110-R-F1-N-EQ-A4-J-Y-C5-NNN-055-AA-G3-15-30	SERIES 51	S51-110MV
702046	MOTOR-VAR-DISPL 51MV110	51V110-R-F1-N-EQ-A4-J-Y-C5-ADA-055-AA-G3-15-30	SERIES 51	S51-110MV

702047	PUMP-VAR-DISPL CW 90PV075	90R075-DC-5-AB-60-S-4-C7-D-GB-GBA-38-38-24	SERIES 90	S90-075PV
702048	PUMP-VAR-DISPL CW 90PV130	90R130-MA-5-CD-80-S-3-C8-H-C5-GBA-42-42-24	SERIES 90	S90-130PV
702049	PUMP-VAR-DISPL CCW 90PV180	90L180-DD-5-NN-80-S-C-C8-J-GB-NNN-42-42-24	SERIES 90	S90-180PV
702051	PUMP-VAR-DISPL CCW 90PV100	90L100-KP-5-CD-80-L-3-F1-E-03-GBA-29-29-24	SERIES 90	S90-100PV
702052	PUMP-VAR-DISPL CW 90PV180	90R180-FH-5-BC-80-S-7-C8-J-B1-NNN-45-45-30	SERIES 90	S90-180PV
702053	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-AB-80-S-4-C8-H-03-GBA-42-42-24	SERIES 90	S90-130PV
702054	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-N-D8-M1-R-J-M1-ADA-098-AA-G3-C2-16	SERIES 51	S51-250MV
702055	PUMP-VAR-DISPL MPV025	MPV-025-C-B-A-A-R-A-G-NN-A-A-BFF-DL-A-FF-A-NNN	LIGHT DUTY	025PV
702056	PUMP-VAR-DISPL CW 42PV28	42-R-28-D-E1A6-03-B-3-G-2-G-N-A-25-25-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
702060	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-BC-80-S-3-C8-H-04-GBA-35-35-24	SERIES 90	S90-130PV
702063	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-C7-N-T2-D2-N-N-X1-ADA-035-AA-E6-00-37	SERIES 51	S51-080MV-1
702064	PUMP-VAR-DISPL CW 90PV180	90R180-MA-5-NN-80-T-3-C8-J-C5-NNN-42-42-20	SERIES 90	S90-180PV
702067	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-AB-80-S-3-C8-F-03-GBS-35-35-24	SERIES 90	S90-130PV
702072	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-5-AB-80-T-3-C8-J-04-NNN-42-42-24	SERIES 90	S90-250PV
702073	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-T3-C0-L-N-K7-NNN-085-AA-H0-00-B5	SERIES 51	S51-160MV
702077	PUMP-VAR-DISPL CCW 90PV042	90L042-KA-5-BC-80-P-3-C3-C-03-GBA-45-45-24	SERIES 90	S90-042PV
702078	PUMP-VAR-DISPL CCW 90PV042	90L042-KA-5-NN-80-P-3-C3-C-03-GBA-42-42-24	SERIES 90	S90-042PV
702079	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-NN-80-S-M-C8-J-03-NNN-23-23-24	SERIES 90	S90-180PV
702085	PUMP-VAR-DISPL CCW 90PV042	90L042-MA-5-AB-80-S-3-C3-C-C5-GBA-35-35-24	SERIES 90	S90-042PV
702087	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-BC-60-P-3-T2-D-04-GBA-42-42-20	SERIES 90	S90-075PV
702088	MOTOR-FIXED-DISPL 90MF100	90-M-100-NC-0-N-8-N-0-T2-N-00-EFA-00-00-00	SERIES 90	S90-100MF
702089	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-2-AB-60-S-4-C6-D-04-GBA-38-38-24	SERIES 90	S90-075PV
702090	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-E2-A5-A-N-A6-ADA-078-AA-F0-03-00	SERIES 51	S51-160MV
702093	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-CL-80-P-3-C8-F-04-GBS-42-42-20	SERIES 90	S90-130PV
702094	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-BB-60-P-3-C7-E-03-GBA-35-35-20	SERIES 90	S90-100PV
702097	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-BB-60-P-4-C7-E-03-GBA-26-26-24	SERIES 90	S90-075PV
702099	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-CD-60-S-4-C7-D-00-GBA-38-38-24	SERIES 90	S90-075PV
702102	PUMP-VAR-DISPL CW 90PV075	90R075-MA-5-AB-60-S-3-C6-D-C5-GBA-42-42-24	SERIES 90	S90-075PV
702107	PUMP-VAR-DISPL CCW 90PV130	90L130-DC-5-BC-80-L-3-C8-H-GB-GBA-30-30-24	SERIES 90	S90-130PV
702108	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-AB-60-P-4-C7-D-28-FAP-42-35-24	SERIES 90	S90-075PV
702109	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-5-NN-80-T-3-C8-K-03-NNN-32-32-24	SERIES 90	S90-250PV
702110	PUMP-VAR-DISPL MPV035	MPV-035-D-B-A-A-R-S-G-AA-A-A-BCC-DR-A-FF-A-NNN	M35/44	035PV
702112	PUMP-VAR-DISPL CW 90PV075	90R075-MB-P-NN-80-S-3-C7-D-C5-GBA-48-48-24	SERIES 90	S90-075PV
702113	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-DE-80-S-C-C8-J-00-NNN-38-23-30	SERIES 90	S90-180PV
702114	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-BC-80-S-3-F1-H-00-GBA-38-23-30	SERIES 90	S90-130PV
702117	PUMP-VAR-DISPL CCW 90PV075	90L075-MA-5-BB-80-S-3-S1-L-C6-GBA-42-42-24	SERIES 90	S90-075PV

702119	PUMP-VAR-DISPL MPV035	MPV-035-D-B-A-A-R-S-G-AA-A-A-BFF-DR-A-FF-C-NNN	M35/44	035PV
702120	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-CD-80-R-3-S1-E-03-FAP-35-35-24	SERIES 90	S90-075PV
702122	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-CD-80-S-3-C7-E-05-GBA-42-42-20	SERIES 90	S90-075PV
702123	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-AC-80-S-3-C3-C-03-GBA-42-42-20	SERIES 90	S90-042PV
702124	PUMP-VAR-DISPL CW 90PV042	90R042-MA-5-BC-80-S-3-C3-C-C5-GBA-32-32-24	SERIES 90	S90-042PV
702125	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-NN-60-S-3-C7-F-00-GCA-32-32-28	SERIES 90	S90-100PV
702127	PUMP-VAR-DISPL CW 90PV100	90R100-MB-5-BC-60-P-4-C7-E-C5-GBA-38-38-24	SERIES 90	S90-100PV
702130	MOTOR-VAR-DISPL 51MV110	51V110-R-C8-N-HS-A1-B-E-E2-NNN-060-AA-F3-10-29	SERIES 51	S51-110MV
702131	PUMP-VAR-DISPL CW 90PV130	90R130-HF-5-NN-80-S-3-C8-H-00-GBA-42-42-24	SERIES 90	S90-130PV
702132	PUMP-VAR-DISPL CW 42PV28	42-R-28-D-E1A6-03-B-2-G-2-F-N-A-41-41-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
702135	MOTOR-VAR-DISPL 51MV080	51V080-A-S1-N-HZ-B1-C-H-C2-NNN-025-AA-NN-20-00	SERIES 51	S51-080MV
702139	PUMP-VAR-DISPL CW 90PV100	90R100-MB-5-NN-60-S-3-C7-E-C5-GBA-20-20-24	SERIES 90	S90-100PV
702140	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-CD-80-S-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-075PV
702144	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-C8-N-TA-C2-N-N-X1-NNN-040-AA-F3-00-22	SERIES 51	S51-110MV-1
702148	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-T2-C0-L-N-G0-NNN-070-AA-F0-00-B2	SERIES 51	S51-160MV
702150	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-CD-80-L-3-C7-F-03-GBA-42-42-24	SERIES 90	S90-100PV
702151	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-CD-80-L-3-C7-D-03-GBA-42-42-24	SERIES 90	S90-075PV
702152	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-BC-80-L-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
702153	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-BC-80-L-3-C7-D-03-GBA-42-42-24	SERIES 90	S90-075PV
702155	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-CD-80-R-3-C8-H-44-GLA-35-35-30	SERIES 90	S90-130PV
702157	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-CD-80-S-3-C7-D-03-GBA-35-35-24	SERIES 90	S90-075PV
702158	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-CD-80-S-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
702160	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-NN-80-S-C-C8-J-05-NNN-45-45-30	SERIES 90	S90-180PV
702161	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-BC-80-S-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
702166	PUMP-VAR-DISPL CW 90PV130	90R130-DD-5-CD-80-S-4-C8-H-GB-GBA-42-42-24	SERIES 90	S90-130PV
702169	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-NN-80-P-3-F1-H-03-GBA-38-38-24	SERIES 90	S90-130PV
702170	MOTOR-VAR-DISPL 51MV160	51V160-A-C8-N-HE-B2-B-H-E6-ACA-032-AA-F0-05-00	SERIES 51	S51-160MV
702171	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-CD-60-P-3-C7-F-00-GLS-42-42-30	SERIES 90	S90-100PV
702172	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-EG-80-S-3-C8-K-03-NNN-35-35-24	SERIES 90	S90-250PV
702173	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-CD-80-S-3-C8-K-03-NNN-35-35-24	SERIES 90	S90-250PV
702176	PUMP-VAR-DISPL CCW 90PV042	90L042-KA-5-NN-80-S-3-C3-C-04-EFC-42-42-18	SERIES 90	S90-042PV
702180	PUMP-VAR-DISPL MPV046	MPV-046-C-B-A-K-R-B-J-AA-G-A-BJJ-AB-U-DD-B-NNN	M46	M46-046PV
702181	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-NN-60-S-3-C7-F-03-GBA-35-14-24	SERIES 90	S90-100PV
702182	PUMP-VAR-DISPL CW 90PV042	90R042-FC-5-NN-80-S-7-C3-C-B4-GLA-45-45-32	SERIES 90	S90-042PV
702189	PUMP-VAR-DISPL CW 90PV130	90R130-MA-5-CS-80-P-3-C8-H-C5-GBA-42-42-24	SERIES 90	S90-130PV
702190	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-S1-N-N1-NN-N-N-U1-NNN-040-AA-NN-00-00	SERIES 51	S51-080MV-1

702192	PUMP-VAR-DISPL CW 90PV075	90R075-MA-5-NN-80-S-3-C7-D-C5-GBA-32-32-24	SERIES 90	S90-075PV
702195	PUMP-VAR-DISPL CCW 90PV055	90L055-KA-5-CD-60-S-3-C6-D-03-GBA-42-42-24	SERIES 90	S90-055PV
702198	MOTOR-VAR-DISPL 51MV110-1	51V110-1--A-C8-N-TA-C2-N-N-X1-NNN-060-AA-NN-00-15	SERIES 51	S51-110MV-1
702199	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-NN-80-S-3-C7-D-03-GBA-20-20-24	SERIES 90	S90-075PV
702201	PUMP-VAR-DISPL MPV035	MPV-035-D-B-A-G-R-S-F-AA-A-A-BJJ-DL-A-FF-A-NNN	M35/44	035PV
702202	MOTOR-VAR-DISPL 51MD160	51D160-A-D5-N-L1-B1-W-B-J1-ADA-032-AA-A3-D4-00	SERIES 51	S51-160MV
702203	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-N-TA-C2-N-N-X1-NNN-030-AA-E6-00-23	SERIES 51	S51-060MV-1
702204	PUMP-VAR-DISPL CW 90PV055	90R055-KN-5-AB-60-P-3-C6-C-04-GBA-42-42-20	SERIES 90	S90-055PV
702205	MOTOR-VAR-DISPL 51MD110	51D110-A-D4-N-L2-B1-V-A-J2-AHA-049-AA-F0-B2-00	SERIES 51	S51-110MV
702207	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-Y3-B1-S-K-J1-ADA-105-AA-F3-F4-00	SERIES 51	S51-160MV
702208	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-EG-80-S-C-C8-J-00-NNN-38-23-30	SERIES 90	S90-180PV
702210	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-BC-80-S-C-C8-J-00-NNN-38-23-30	SERIES 90	S90-180PV
702214	PUMP-VAR-DISPL CW 90PV075	90R075-MA-5-NN-80-S-3-C7-D-C5-GBA-42-42-24	SERIES 90	S90-075PV
702215	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-AB-80-P-4-C7-E-04-GBA-35-35-24	SERIES 90	S90-100PV
702216	PUMP-VAR-DISPL CW 90PV250	90R250-MA-5-NN-80-S-3-C8-K-C5-NNN-42-42-24	SERIES 90	S90-250PV
702218	PUMP-VAR-DISPL CW 90PV130	90R130-MA-5-AB-80-S-3-C8-H-C5-GBA-42-42-24	SERIES 90	S90-130PV
702222	MOTOR-VAR-DISPL 51MV110	51V110-R-C8-N-HZ-B1-A-E-C2-NNN-032-AA-NN-03-00	SERIES 51	S51-110MV
702224	PUMP-VAR-DISPL CW 90PV075	90R075-KN-5-BB-80-P-3-C7-D-03-GBA-16-16-24	SERIES 90	S90-075PV
702230	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-NN-80-S-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
702235	PUMP-VAR-DISPL CW 90PV042	90R042-MA-2-BC-80-P-4-C3-C-C5-GBA-35-35-24	SERIES 90	S90-042PV
702236	PUMP-VAR-DISPL CW 90PV100	90R100-DD-5-NN-80-L-4-C7-F-GB-GBA-23-23-30	SERIES 90	S90-100PV
702238	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-AB-80-S-4-C8-K-03-NNN-35-35-24	SERIES 90	S90-250PV
702239	PUMP-VAR-DISPL CW 90PV250	90R250-DD-5-NN-80-S-4-C8-J-GB-NNN-42-42-24	SERIES 90	S90-250PV
702240	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-NN-80-S-M-C8-J-03-NNN-35-35-24	SERIES 90	S90-180PV
702242	PUMP-VAR-DISPL CW 90PV100	90R100-DD-5-AB-60-S-4-C7-E-GB-GBA-26-26-24	SERIES 90	S90-100PV
702250	PUMP-VAR-DISPL CW 90PV055	90R055-KN-5-NN-80-S-3-C6-C-03-GBA-29-29-24	SERIES 90	S90-055PV
702251	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-N-T2-C0-L-N-L4-NNN-065-AA-E6-00-C2	SERIES 51	S51-160MV
702252	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-AB-80-S-M-C8-J-03-NNN-26-26-24	SERIES 90	S90-180PV
702254	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-NN-60-S-4-C6-C-03-GBA-42-42-24	SERIES 90	S90-075PV
702255	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-AB-80-S-3-C6-D-03-GBA-20-20-20	SERIES 90	S90-075PV
702259	PUMP-VAR-DISPL CW 90PV180	90R180-HF-5-NN-80-S-C-F1-J-03-NNN-29-29-24	SERIES 90	S90-180PV
702261	MOTOR-VAR-DISPL 51MV110	51V110-A-F1-N-HZ-B1-C-H-C2-NNN-022-AA-F0-20-00	SERIES 51	S51-110MV
702262	PUMP-VAR-DISPL CW 42PV041	42-R-41-D-F2NN-73-J-D-G-2-C-N-A-21-21-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
702263	PUMP-VAR-DISPL CW 90PV100	90R100-DD-5-NN-60-S-4-S1-E-GB-GBA-42-42-24	SERIES 90	S90-100PV
702264	MOTOR-VAR-DISPL 51MV060-1	51V060-1--R-S1-N-TA-C2-N-N-X1-NNN-035-AA-E6-00-32	SERIES 51	S51-060MV-1
702265	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-AB-80-P-4-S1-D-03-GBA-23-23-24	SERIES 90	S90-075PV

702268	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-BC-80-S-3-C7-D-03-GBA-35-35-24	SERIES 90	S90-075PV
702269	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-BC-80-S-3-C7-D-03-GBA-35-35-24	SERIES 90	S90-075PV
702270	PUMP-VAR-DISPL CCW 90PV042	90L042-MA-5-NN-80-S-3-C3-B-C5-GBA-38-38-24	SERIES 90	S90-042PV
702271	PUMP-VAR-DISPL CW 90PV130	90R130-MA-5-NN-80-L-3-C8-F-03-GDA-42-42-20	SERIES 90	S90-130PV
702272	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-BC-80-S-3-T6-D-03-GBA-42-42-24	SERIES 90	S90-075PV
702275	MOTOR-VAR-DISPL 51MD110-1	51D110-1--A-D4-N-E2-B1-N-N-U1-NNN-040-AA-F3-00-00	SERIES 51	S51-110MV-1
702276	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-AB-80-P-3-C7-F-03-GBA-38-38-30	SERIES 90	S90-100PV
702277	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-AB-80-P-3-C7-E-42-GBA-32-32-30	SERIES 90	S90-075PV
702278	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-NN-80-S-3-C7-D-05-GBA-42-42-24	SERIES 90	S90-075PV
702279	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-BC-80-R-4-C3-C-03-GBA-20-20-24	SERIES 90	S90-042PV
702286	PUMP-VAR-DISPL MPV046	MPV-046-C-B-B-G-S-B-J-AA-V-A-BHH-DB-A-TT-C-NNR	M46	M46-046PV
702287	PUMP-VAR-DISPL CCW 90PV250	90L250-MA-5-NN-80-T-3-C8-K-C5-NNN-23-23-24	SERIES 90	S90-250PV
702289	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-HS-A2-B-E-E1-NNN-032-AA-NN-05-25	SERIES 51	S51-160MV
702291	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-HS-A2-B-E-E1-NNN-050-AA-NN-05-25	SERIES 51	S51-250MV
702292	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-BC-80-S-M-C8-J-03-NNN-35-35-24	SERIES 90	S90-180PV
702294	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-AB-80-S-3-C8-H-03-GBA-35-35-24	SERIES 90	S90-130PV
702295	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-NN-80-S-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-075PV
702296	PUMP-VAR-DISPL CW 90PV075	90R075-MB-5-BC-80-S-4-C6-D-C5-GBA-42-42-24	SERIES 90	S90-075PV
702298	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-E-HZ-B1-B-H-C2-NNN-060-AA-NN-10-00	SERIES 51	S51-160MV
702301	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-CD-80-S-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
702302	PUMP-VAR-DISPL MPV035	MPV-035-D-B-A-G-W-S-G-BA-A-A-BBB-DR-A-FF-A-NNN	M35/44	035PV
702303	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-AB-80-S-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-075PV
702305	PUMP-VAR-DISPL CW 90PV130	90R130-MA-5-NN-80-S-4-C8-F-C7-GBA-32-32-24	SERIES 90	S90-130PV
702306	PUMP-VAR-DISPL MPV046	MPV-046-C-B-B-G-S-B-B-AA-V-A-BFF-DA-A-RR-C-NNN	M46	M46-046PV
702307	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-BB-80-S-3-C8-K-03-EFI-42-42-24	SERIES 90	S90-250PV
702311	PUMP-VAR-DISPL CCW 90PV075	90L075-MA-5-NN-60-S-4-D7-D-C5-GBA-42-42-24	SERIES 90	S90-075PV
702313	PUMP-VAR-DISPL CW 90PV055	90R055-KA-5-NN-60-S-3-S1-D-03-GBA-35-14-24	SERIES 90	S90-055PV
702315	PUMP-VAR-DISPL CW 90PV075	90R075-HF-1-AB-60-S-4-S1-D-00-GBA-38-38-24	SERIES 90	S90-075PV
702322	PUMP-VAR-DISPL CW 90PV100	90R100-MA-5-NN-80-S-3-C7-E-C5-GBA-38-38-24	SERIES 90	S90-100PV
702325	PUMP-VAR-DISPL CW 90PV250	90R250-DD-5-CD-80-S-4-C8-K-GB-NNN-35-35-24	SERIES 90	S90-250PV
702326	PUMP-VAR-DISPL CW 90PV130	90R130-FG-5-BC-80-L-7-C8-H-B1-EFI-30-30-32	SERIES 90	S90-130PV
702328	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-BC-80-R-3-C3-C-04-GBA-42-42-24	SERIES 90	S90-042PV
702329	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-P-CD-80-S-3-C7-E-03-GBA-48-48-24	SERIES 90	S90-100PV
702336	PUMP-VAR-DISPL CCW 90PV055	90L055-DC-5-NN-80-S-3-S1-D-52-GBA-29-29-24	SERIES 90	S90-055PV
702337	PUMP-VAR-DISPL CCW 90PV042	90L042-KA-5-NN-80-R-3-C3-B-03-GBA-42-42-24	SERIES 90	S90-042PV
702338	PUMP-VAR-DISPL CCW 90PV042	90L042-KA-5-BB-80-R-3-C3-B-03-GBA-42-42-24	SERIES 90	S90-042PV

702339	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-BB-80-R-3-F1-F-03-GBA-42-42-24	SERIES 90	S90-130PV
702342	MOTOR-VAR-DISPL 51MV160	51V160-A-C8-N-E2-L4-A-N-E8-NNN-080-AA-G3-03-35	SERIES 51	S51-160MV
702343	PUMP-VAR-DISPL CCW 90PV250	90L250-HF-5-NN-80-S-4-C8-K-03-NNN-35-35-24	SERIES 90	S90-250PV
702346	PUMP-VAR-DISPL CW 90PV100	90R100-HF-5-BC-60-S-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
702348	MOTOR-VAR-DISPL 51MV080	51V080-R-C7-N-L7-B1-W-B-J1-NNN-032-AA-F0-D4-00	SERIES 51	S51-080MV
702349	PUMP-VAR-DISPL CW 90PV075	90R075-DD-5-CD-60-S-4-C7-D-GB-GBA-40-40-24	SERIES 90	S90-075PV
702350	PUMP-VAR-DISPL CW 90PV075	90R075-DD-5-BC-60-S-4-S1-D-GB-GBA-40-40-24	SERIES 90	S90-075PV
702358	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-BB-80-S-C-C8-J-03-NNN-42-42-24	SERIES 90	S90-180PV
702360	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-NN-80-P-4-C8-F-04-GBA-38-38-20	SERIES 90	S90-130PV
702362	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-DE-80-T-4-C8-J-05-NNN-32-32-24	SERIES 90	S90-250PV
702364	MOTOR-VAR-DISPL 51MV080-1	51V080-1--A-C7-N-T2-R5-N-N-X1-NNN-050-AA-F3-00-25	SERIES 51	S51-080MV-1
702367	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-AB-80-S-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-075PV
702369	PUMP-VAR-DISPL CW 90PV180	90R180-KP-5-EF-80-T-M-C8-H-03-FAC-38-38-24	SERIES 90	S90-180PV
702370	PUMP-VAR-DISPL CW 90PV180	90R180-KP-5-NN-80-T-M-F1-H-03-FAC-38-38-24	SERIES 90	S90-180PV
702371	PUMP-VAR-DISPL CCW 90PV180	90L180-KP-5-CD-80-T-M-C8-H-03-FAC-38-38-24	SERIES 90	S90-180PV
702372	PUMP-VAR-DISPL CCW 90PV075	90L075-KP-5-NN-80-P-4-S1-D-03-GBA-17-17-18	SERIES 90	S90-075PV
702374	PUMP-VAR-DISPL CW 90PV075	90R075-DD-5-BB-60-S-3-C7-D-GB-GBA-35-35-24	SERIES 90	S90-075PV
702379	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-AB-80-S-3-S1-F-03-GBA-26-26-22	SERIES 90	S90-100PV
702383	PUMP-VAR-DISPL CCW 42PV28	42-L-28-D-E1A6-02-B-2-B-2-F-N-A-34-34-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
702384	PUMP-VAR-DISPL CW 90PV042	90R042-HF-5-AB-80-S-3-C3-C-03-GBA-17-17-20	SERIES 90	S90-042PV
702385	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-NN-80-S-3-S1-D-01-GBA-42-42-24	SERIES 90	S90-075PV
702386	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-CD-80-S-3-C7-D-01-GBA-42-42-24	SERIES 90	S90-075PV
702387	PUMP-VAR-DISPL CW 90PV042	90R042-KN-1-NN-80-R-4-C3-C-03-GBA-21-21-24	SERIES 90	S90-042PV
702389	MOTOR-VAR-DISPL 51MV060-1	51V060-1--A-S1-N-TA-C2-N-N-X1-NNN-023-AA-E6-00-18	SERIES 51	S51-060MV-1
702390	PUMP-VAR-DISPL MPV046	MPV-046-C-B-A-K-R-B-C-AA-A-A-BHH-AB-U-ED-B-NNN	M46	M46-046PV
702391	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-JA-NN-C-H-M1-NNN-045-AA-B3-12-28	SERIES 51	S51-160MV
702393	PUMP-VAR-DISPL CW 90PV130	90R130-HF-5-NN-80-P-3-C8-F-03-GBA-35-35-24	SERIES 90	S90-130PV
702395	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-NN-80-S-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
702396	PUMP-VAR-DISPL CCW 90PV075	90L075-DD-5-AB-80-S-4-S1-D-GB-GBA-35-35-24	SERIES 90	S90-075PV
702397	PUMP-VAR-DISPL MPV044	MPV-044-D-B-A-G-W-S-G-BA-A-A-BBB-DR-A-FF-A-NNN	M35/44	O44PV
702398	PUMP-VAR-DISPL CW 90PV130	90R130-MA-5-NN-80-P-3-C8-H-C5-GBA-42-42-24	SERIES 90	S90-130PV
702400	PUMP-VAR-DISPL CW 90PV075	90R075-DD-5-BC-60-S-3-C7-D-G4-GBA-35-35-24	SERIES 90	S90-075PV
702401	PUMP-VAR-DISPL CW 90PV100	90R100-FD-5-BC-60-S-7-S1-F-B1-GBA-42-42-28	SERIES 90	S90-100PV
702404	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-AB-60-R-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
702405	MOTOR-VAR-DISPL 51MV080	51V080-A-S1-N-HS-A2-B-E-E1-NNN-025-AA-F0-05-20	SERIES 51	S51-080MV
702411	MOTOR-VAR-DISPL 51MD110-1	51D110-1--A-D4-E-T7-R5-N-N-X1-NNN-037-AA-F0-00-24	SERIES 51	S51-110MV-1

702412	PUMP-VAR-DISPL CCW 90PV075	90L075-DD-5-AB-60-S-4-C7-D-G8-FAC-42-42-24	SERIES 90	S90-075PV
702416	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-EG-80-S-M-C8-J-03-NNN-42-42-24	SERIES 90	S90-180PV
702417	PUMP-VAR-DISPL CW 90PV180	90R180-HM-5-AB-80-S-M-C8-J-03-NNN-42-42-24	SERIES 90	S90-180PV
702420	PUMP-VAR-DISPL CW 90PV075	90R075-KA-P-BB-60-P-4-C7-E-03-FAB-48-48-24	SERIES 90	S90-075PV
702425	PUMP-VAR-DISPL CCW 90PV130	90L130-DD-5-AB-80-S-4-D8-H-G8-GBA-42-42-24	SERIES 90	S90-130PV
702429	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-BC-80-S-3-C7-E-03-GBA-26-26-24	SERIES 90	S90-075PV
702432	PUMP-VAR-DISPL CW 90PV055	90R055-HS-5-BK-80-P-3-S1-C-03-GBA-45-45-24	SERIES 90	S90-055PV
702434	PUMP-VAR-DISPL CW 42PV28	42-R-28-C-ANNB-02-A-N-A-2-C-N-A-34-34-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
702435	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-NN-80-S-3-C8-K-09-NNN-35-35-28	SERIES 90	S90-250PV
702437	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-T3-R5-L-N-G0-NNN-032-AA-F3-00-C0	SERIES 51	S51-160MV
702438	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-AB-60-S-3-S1-F-00-GBA-42-42-24	SERIES 90	S90-100PV
702439	MOTOR-VAR-DISPL 51MV080	51V080-R-C7-N-E1-A5-A-N-A6-NNN-027-AA-E4-03-00	SERIES 51	S51-080MV
702440	MOTOR-VAR-DISPL 51MV080-1	51V080-1--A-D2-N-P7-P7-N-N-X1-NNN-021-AA-F0-00-AA	SERIES 51	S51-080MV-1
702442	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-B-HS-A7-B-N-F1-CCA-135-AA-F0-08-16	SERIES 51	S51-250MV
702446	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-NN-60-R-4-T2-E-00-GBA-23-23-24	SERIES 90	S90-100PV
702447	MOTOR-VAR-DISPL 51MD110-1	51D110-1--R-D4-N-T2-CA-N-N-X1-NNN-043-AA-F0-00-29	SERIES 51	S51-110MV-1
702451	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-5-NN-80-S-3-C8-K-00-EFI-42-42-28	SERIES 90	S90-250PV
702453	PUMP-VAR-DISPL CCW 90PV075	90L075-HF-5-BC-80-S-3-C7-D-03-GBA-45-45-24	SERIES 90	S90-075PV
702454	MOTOR-VAR-DISPL 51MV110-1	51V110-1--A-C8-N-E2-B1-N-N-U1-NNN-055-AA-F3-00-00	SERIES 51	S51-110MV-1
702455	PUMP-VAR-DISPL CCW 90PV130	90L130-HF-5-NN-80-S-3-C8-H-03-GBA-42-42-24	SERIES 90	S90-130PV
702457	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-CD-80-P-3-C8-H-03-GBA-42-42-24	SERIES 90	S90-130PV
702458	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-BB-80-P-3-S1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
702459	MOTOR-VAR-DISPL 51MV160	51V160-A-C8-N-E2-A5-A-N-A6-NNN-032-AA-F0-03-00	SERIES 51	S51-160MV
702460	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-T1-C2-L-N-G0-NNN-070-AA-G0-00-B4	SERIES 51	S51-160MV
702461	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-T1-L5-L-N-G0-NNN-050-AA-F3-00-C2	SERIES 51	S51-160MV
702462	MOTOR-FIXED-DISPL 90MF042	90-M-042-NC-0-N-8-N-0-C3-W-00-NNN-00-00-F0	SERIES 90	S90-042MF
702463	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-NN-80-S-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
702465	PUMP-VAR-DISPL CW 90PV075	90R075-MA-5-BB-80-S-3-C7-D-C5-GBA-42-42-24	SERIES 90	S90-075PV
702466	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-AB-60-S-3-C7-D-03-GBA-17-17-20	SERIES 90	S90-075PV
702467	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-N1-NN-N-N-U1-NNN-022-AA-F0-00-00	SERIES 51	S51-110MV-1
702470	MOTOR-VAR-DISPL 51MV110	51V110-R-C8-N-EQ-A2-J-Y-H5-NNN-030-AA-G3-40-37	SERIES 51	S51-110MV
702471	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-S1-N-TA-C2-N-N-X1-NNN-040-AA-E6-00-28	SERIES 51	S51-080MV-1
702473	PUMP-VAR-DISPL CW 90PV055	90R055-KA-5-NN-60-P-3-C6-C-04-GBA-42-42-20	SERIES 90	S90-055PV
702475	PUMP-VAR-DISPL CCW 90PV130	90L130-DD-5-NN-80-S-3-C8-H-GB-GBA-42-42-24	SERIES 90	S90-130PV
702476	MOTOR-VAR-DISPL 51MV160	51V160-A-F2-N-D8-M1-R-J-M4-ANB-032-AA-F0-C2-35	SERIES 51	S51-160MV
702477	MOTOR-VAR-DISPL 51MV160	51V160-A-F2-N-D8-M1-R-J-M4-NNN-032-AA-F0-C2-35	SERIES 51	S51-160MV

702478	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-NN-80-S-4-C3-C-05-FAP-35-35-42	SERIES 90	S90-042PV
702484	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-NN-60-S-3-C7-D-03-GBA-35-35-24	SERIES 90	S90-075PV
702486	PUMP-VAR-DISPL CW 90PV250	90R250-HF-5-AB-80-T-3-C8-J-03-NNN-42-42-24	SERIES 90	S90-250PV
702487	PUMP-VAR-DISPL CW 42PV28	42-R-28-C-ANN3-02-B-D-G-2-F-N-B-28-28-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
702489	PUMP-VAR-DISPL CW 90PV100	90R100-HF-5-CD-60-S-3-C7-E-03-GBA-35-35-28	SERIES 90	S90-100PV
702491	MOTOR-VAR-DISPL 51MC160	51C160-A-D5-N-Y3-B1-S-K-J1-ABA-032-AA-H0-F4-00	SERIES 51	S51-160MV
702492	MOTOR-VAR-DISPL 51MC160	51C160-A-D5-N-Y3-B1-S-K-J1-NNN-032-AA-H0-F4-00	SERIES 51	S51-160MV
702493	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-N2-NN-N-N-A0-NNN-032-AA-NN-00-00	SERIES 51	S51-160MV
702494	PUMP-VAR-DISPL CW 90PV250	90R250-MA-5-BC-80-T-4-C8-J-C5-NNN-35-35-24	SERIES 90	S90-250PV
702495	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-L2-B1-V-A-C0-ADA-045-AA-F0-B2-00	SERIES 51	S51-160MV
702496	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-NN-60-S-3-C7-D-03-GBA-35-35-24	SERIES 90	S90-075PV
702497	PUMP-VAR-DISPL CW 90PV180	90R180-KN-5-NN-80-T-C-C8-J-03-NNN-26-26-24	SERIES 90	S90-180PV
702499	PUMP-VAR-DISPL CW 90PV130	90R130-KN-5-NN-80-P-3-C8-H-03-GBA-26-26-24	SERIES 90	S90-130PV
702500	PUMP-VAR-DISPL CW 90PV042	90R042-MA-5-NN-80-S-3-C3-C-C5-GBA-26-26-24	SERIES 90	S90-042PV
702502	PUMP-VAR-DISPL CCW 90PV130	90L130-MA-5-NN-80-S-4-F1-F-C5-GBA-35-35-24	SERIES 90	S90-130PV
702503	PUMP-VAR-DISPL CCW 90PV250	90L250-MB-5-DE-80-S-4-C8-K-C5-NNN-35-35-24	SERIES 90	S90-250PV
702507	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-BB-60-S-3-C7-D-03-GBA-45-45-24	SERIES 90	S90-075PV
702509	MOTOR-VAR-DISPL 51MV060-1	51V060-1--R-C6-N-T7-D7-N-N-X1-NNN-027-AA-F3-00-35	SERIES 51	S51-060MV-1
702512	PUMP-VAR-DISPL CW 90PV100	90R100-DD-5-BC-60-S-4-C7-E-G4-GBA-35-35-24	SERIES 90	S90-100PV
702517	PUMP-VAR-DISPL CW 90PV042	90R042-KN-5-BB-80-P-3-C3-C-03-GBA-20-20-24	SERIES 90	S90-042PV
702524	PUMP-VAR-DISPL CCW 90PV055	90L055-MA-5-NN-60-P-3-C6-C-02-GBA-35-35-24	SERIES 90	S90-055PV
702525	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-AB-80-S-3-C8-H-03-EFI-42-42-24	SERIES 90	S90-130PV
702526	MOTOR-VAR-DISPL 51MV160	51V160-R-F2-N-T2-C0-L-N-G0-NNN-050-AA-F0-00-B5	SERIES 51	S51-160MV
702527	MOTOR-VAR-DISPL 51MV160	51V160-R-F2-N-T2-C0-L-N-G0-AHA-050-AA-F0-00-B5	SERIES 51	S51-160MV
702528	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-CD-80-S-4-C8-H-03-GDA-42-42-24	SERIES 90	S90-130PV
702533	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-AB-80-S-7-C7-F-00-FAC-35-35-30	SERIES 90	S90-100PV
702534	MOTOR-VAR-DISPL 51MD060-1	51D060-1--A-D1-N-E7-B1-N-N-U1-NNN-022-AA-F3-00-00	SERIES 51	S51-060MV-1
702535	PUMP-VAR-DISPL CW 90PV042	90R042-FC-P-AB-80-S-7-C3-C-B1-EFI-48-48-28	SERIES 90	S90-042PV
702538	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-BC-60-S-4-C7-E-46-GBA-30-30-24	SERIES 90	S90-075PV
702540	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-NN-60-S-3-S1-F-04-GBA-42-42-24	SERIES 90	S90-100PV
702544	PUMP-VAR-DISPL CW 90PV130	90R130-FH-5-BB-80-S-7-C8-F-B1-GBS-36-36-28	SERIES 90	S90-130PV
702545	PUMP-VAR-DISPL CW 42PV041	42-R-41-D-F4NN-73-J-3-G-2-F-N-N-25-25-N-A-A-NNN-NNN	SERIES 42	S42-041PV/051PV
702546	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-NN-80-S-4-C8-K-03-NNN-20-20-24	SERIES 90	S90-250PV
702550	PUMP-VAR-DISPL MPV046	MPV-046-C-B-A-A-R-B-B-AA-A-A-BJF-AB-U-AB-C-NNN	M46	M46-046PV
702551	PUMP-VAR-DISPL CW 90PV100	90R100-DD-5-AB-60-S-4-S1-E-GF-GBA-42-42-24	SERIES 90	S90-100PV
702552	MOTOR-VAR-DISPL 51MD160	51D160-R-D4-N-HS-A7-B-N-F1-CCA-090-AA-F0-08-16	SERIES 51	S51-160MV

702553	MOTOR-VAR-DISPL 51MV080	51V080-R-C7-N-HZ-B1-B-H-G0-NNN-032-AA-F3-12-00	SERIES 51	S51-080MV
702556	PUMP-VAR-DISPL CW 90PV100	90R100-KP-5-NN-80-L-3-F1-E-03-GBA-42-42-28	SERIES 90	S90-100PV
702558	PUMP-VAR-DISPL CW 90PV042	90R042-MA-2-BB-80-R-4-C3-B-C5-GBA-43-43-24	SERIES 90	S90-042PV
702559	PUMP-VAR-DISPL CW 90PV042	90R042-MA-5-AB-80-R-4-C3-B-C5-GBA-43-43-24	SERIES 90	S90-042PV
702560	PUMP-VAR-DISPL CW 90PV130	90R130-FH-5-DG-80-L-7-C8-H-B1-EFI-42-42-32	SERIES 90	S90-130PV
702561	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-NN-80-S-C-F1-J-03-NNN-20-20-18	SERIES 90	S90-180PV
702567	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-C7-N-F1-B1-N-N-U1-NNN-036-AA-F0-00-00	SERIES 51	S51-080MV-1
702568	PUMP-VAR-DISPL CCW 90PV042	90L042-HF-5-BB-80-S-3-C3-C-03-GBA-35-35-24	SERIES 90	S90-042PV
702569	PUMP-VAR-DISPL CCW 90PV075	90L075-HF-5-BB-60-S-3-C6-D-03-GBA-35-35-24	SERIES 90	S90-075PV
702570	MOTOR-VAR-DISPL 51MV060-1	51V060-1--R-C6-N-F1-B1-N-N-U1-NNN-040-AA-F0-00-00	SERIES 51	S51-060MV-1
702575	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-NN-60-S-4-C7-E-06-GBA-42-42-18	SERIES 90	S90-100PV
702576	PUMP-VAR-DISPL CCW 42PV28	42-L-28-C-F6NN-53-U-2-X-N-F-1-A-32-32-N-1-1-NNN-NNN	SERIES 42	S42-028PV/032PV
702579	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-DE-80-S-4-C8-F-03-GBA-42-42-24	SERIES 90	S90-130PV
702580	PUMP-VAR-DISPL CW 90PV130	90R130-HM-5-BC-80-S-4-F1-F-03-GBA-42-42-24	SERIES 90	S90-130PV
702582	MOTOR-FIXED-DISPL 90MF100	90-M-100-NC-0-N-8-N-0-S1-W-00-EAA-00-00-E6	SERIES 90	S90-100MF
702583	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-NN-80-S-4-C3-C-03-GBA-42-42-24	SERIES 90	S90-042PV
702585	MOTOR-VAR-DISPL 51MD160	51D160-A-D4-N-TA-C2-L-N-G0-NNN-090-AA-G3-00-B2	SERIES 51	S51-160MV
702586	PUMP-VAR-DISPL CW 42PV28	42-R-28-C-ANN3-03-B-2-G-2-F-N-A-34-34-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
702588	PUMP-VAR-DISPL CCW 90PV055	90L055-HF-5-BG-80-P-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
702591	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-TH-R5-L-N-G0-NNN-032-AA-F3-00-B0	SERIES 51	S51-160MV
702592	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-NN-60-S-4-C7-D-03-GBA-30-30-24	SERIES 90	S90-075PV
702594	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-AB-80-R-3-C7-D-03-GBA-21-21-24	SERIES 90	S90-075PV
702595	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-N-B7-B3-N-N-U3-NNN-016-AA-NN-00-00	SERIES 51	S51-060MV-1
702596	PUMP-VAR-DISPL MPV046	MPV-046-C-B-A-G-R-A-B-BC-A-A-BJJ-DA-A-HH-C-NNN	M46	M46-046PV
702598	PUMP-VAR-DISPL CCW 90PV100	90L100-MA-5-NN-80-S-3-C7-E-C5-GBA-20-20-24	SERIES 90	S90-100PV
702599	PUMP-VAR-DISPL CW 90PV180	90R180-MA-5-AB-80-T-C-C8-J-C5-NNN-42-42-24	SERIES 90	S90-180PV
702601	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-HZ-B1-A-N-G0-ACA-050-AA-G0-03-00	SERIES 51	S51-250MV
702602	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-BC-80-S-C-F1-J-00-NNN-38-23-30	SERIES 90	S90-180PV
702603	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-P-CD-80-R-3-F1-F-03-GBA-35-45-24	SERIES 90	S90-130PV
702612	PUMP-VAR-DISPL CW 90PV100	90R100-DD-5-BC-60-S-4-C7-E-G1-GBA-42-42-24-F003	SERIES 90	S90-100PV
702618	PUMP-VAR-DISPL CW 90PV100	90R100-FC-5-AB-80-S-7-C7-F-B1-EFI-42-42-26	SERIES 90	S90-100PV
702619	MOTOR-VAR-DISPL 51MV110-1	51V110-1--A-C8-N-P7-P7-N-N-X1-NNN-051-AA-F3-00-AA	SERIES 51	S51-110MV-1
702623	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-NN-80-S-M-C8-J-03-NNN-42-42-24	SERIES 90	S90-180PV
702624	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-NN-80-S-M-C8-J-03-NNN-42-42-24	SERIES 90	S90-180PV
702625	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-5-NN-80-S-4-C8-K-03-NNN-42-42-24	SERIES 90	S90-250PV
702626	PUMP-VAR-DISPL CW 90PV100	90R100-PB-5-CD-80-S-3-C7-E-06-FAP-35-35-24	SERIES 90	S90-100PV

702629	PUMP-VAR-DISPL CCW 90PV042	90L042-KA-5-NN-80-R-3-C3-C-03-GBA-35-35-24	SERIES 90	S90-042PV
702630	PUMP-VAR-DISPL CW 90PV075	90R075-MA-P-BB-60-S-3-C7-D-C5-GBA-48-48-24	SERIES 90	S90-075PV
702632	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-NN-80-S-3-C8-K-03-NNN-35-35-28	SERIES 90	S90-250PV
702633	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-B-N2-NN-N-N-A0-NNN-054-AA-F3-00-00	SERIES 51	S51-160MV
702635	PUMP-VAR-DISPL CW 90PV075	90R075-HF-5-NN-60-S-3-C7-D-03-GBA-42-42-24	SERIES 90	S90-075PV
702636	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-AB-80-P-4-C8-H-03-GBA-38-38-24	SERIES 90	S90-130PV
702637	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-CD-60-P-3-C7-E-03-GBA-30-30-20	SERIES 90	S90-100PV
702638	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-NN-60-P-3-S1-E-03-GBA-30-30-20	SERIES 90	S90-100PV
702640	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-AB-80-L-3-C8-H-03-GBA-38-14-30	SERIES 90	S90-130PV
702643	PUMP-VAR-DISPL CCW 90PV130	90L130-HF-5-NN-80-R-3-F1-H-02-GBA-29-29-20	SERIES 90	S90-130PV
702644	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-BC-80-S-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
702645	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-CD-80-P-3-F1-H-03-GBA-35-35-28	SERIES 90	S90-130PV
702649	PUMP-VAR-DISPL CW 90PV130	90R130-CA-5-CD-80-L-7-C8-F-33-EEG-42-42-32	SERIES 90	S90-130PV
702650	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-S1-N-E2-B1-N-N-U1-ACB-035-AA-F0-00-00	SERIES 51	S51-080MV-1
702651	MOTOR-VAR-DISPL 51MD160	51D160-R-D4-N-T3-R5-L-N-G0-NNN-032-AA-F3-00-C0	SERIES 51	S51-160MV
702655	PUMP-VAR-DISPL CW 90PV100	90R100-MA-7-BB-80-S-3-D7-E-C5-FAX-45-45-28	SERIES 90	S90-100PV
702658	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-NN-80-R-4-T2-F-04-GBA-26-26-20	SERIES 90	S90-100PV
702663	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-NN-80-S-3-F1-H-03-GBA-35-35-24	SERIES 90	S90-130PV
702664	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-NN-80-S-4-C7-F-03-GBA-42-42-24	SERIES 90	S90-100PV
702665	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-NN-80-R-4-F1-E-03-GBA-14-14-24	SERIES 90	S90-100PV
702666	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-NN-80-L-4-F1-H-03-GBA-14-35-24	SERIES 90	S90-130PV
702667	PUMP-VAR-DISPL MPV046	MPV-046-C-B-B-K-R-B-A-AA-A-A-BDD-BA-A-GG-B-NNN	M46	M46-046PV
702668	PUMP-VAR-DISPL CCW 90PV100	90L100-HF-5-NN-80-S-3-C7-F-03-GBA-42-42-42	SERIES 90	S90-100PV
702669	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-NN-80-P-3-C7-D-03-GBA-26-26-20	SERIES 90	S90-075PV
702672	PUMP-VAR-DISPL MPV046	MPV-046-C-B-B-H-R-B-A-AA-A-A-BDD-CG-A-HH-A-NNN	M46	M46-046PV
702673	MOTOR-VAR-DISPL 51MV060	51V060-R-S1-N-E2-A1-A-N-E2-NNN-012-AA-E4-03-25	SERIES 51	S51-060MV
702675	PUMP-VAR-DISPL CCW 90PV130	90L130-MA-5-DE-80-L-3-C8-F-C5-GBA-35-35-24	SERIES 90	S90-130PV
702676	PUMP-VAR-DISPL CCW 90PV130	90L130-MA-5-NN-80-L-3-F1-F-C5-GBA-35-35-24	SERIES 90	S90-130PV
702678	MOTOR-FIXED-DISPL 90MF130	90-M-130-NC-0-N-8-N-0-C8-W-00-EEA-00-00-F0	SERIES 90	S90-130MF
702679	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-NN-60-P-3-C7-D-03-GBA-35-35-20	SERIES 90	S90-075PV
702680	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-P-CD-80-S-3-C7-E-03-GBA-48-48-24	SERIES 90	S90-075PV
702684	MOTOR-VAR-DISPL 51MV060	51V060-R-S1-N-L2-B1-V-A-C0-AHA-012-AA-NN-B2-00	SERIES 51	S51-060MV
702685	MOTOR-VAR-DISPL 51MD080	51D080-A-D2-N-HE-B2-C-E-H7-NNN-041-AA-G0-12-00	SERIES 51	S51-080MV
702686	PUMP-VAR-DISPL CCW 90PV075	90L075-DC-5-AB-80-S-4-C7-E-GB-GBA-42-42-24	SERIES 90	S90-075PV
702687	PUMP-VAR-DISPL CCW 90PV250	90L250-DD-5-NN-80-D-3-F1-N-GD-NNN-42-42-28	SERIES 90	S90-250PV
702689	MOTOR-VAR-DISPL 51MV060-1	51V060-1--R-C6-N-E1-B1-N-N-U1-NNN-012-AA-F0-00-00	SERIES 51	S51-060MV-1

702691	MOTOR-VAR-DISPL 51MV080	51D080-R-D2-N-J1-K1-D-N-H4-NNN-027-AA-F0-20-26	SERIES 51	S51-080MV
702693	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-BC-60-L-3-C7-F-03-GBA-42-42-24	SERIES 90	S90-100PV
702696	PUMP-VAR-DISPL CW 90PV042	90R042-MA-5-BC-80-S-4-C3-C-02-GBA-38-38-24	SERIES 90	S90-042PV
702699	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-BB-80-R-3-C5-C-04-GBA-42-42-24	SERIES 90	S90-042PV
702701	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-AB-80-S-3-C8-H-03-GBA-35-35-24	SERIES 90	S90-130PV
702703	PUMP-VAR-DISPL MPV046	MPV-046-C-B-A-A-R-B-A-AA-G-A-BHH-DA-A-SS-C-NNN	M46	M46-046PV
702705	PUMP-VAR-DISPL CCW 90PV075	90L075-FH-5-CD-80-P-7-C7-D-B1-GBA-35-35-28	SERIES 90	S90-075PV
702706	PUMP-VAR-DISPL CCW 90PV075	90L075-CA-5-CD-80-P-7-S1-D-00-GBA-35-35-28	SERIES 90	S90-075PV
702710	MOTOR-VAR-DISPL 51MD160	51D160-A-D4-B-D7-M1-S-K-M4-NNN-042-AA-F0-F4-27	SERIES 51	S51-160MV
702711	PUMP-VAR-DISPL CW 90PV180	90R180-DD-5-NN-80-S-C-8-J-G8-NNN-23-23-24	SERIES 90	S90-180PV
702712	PUMP-VAR-DISPL MPV046	MPV-046-C-B-B-H-R-B-C-BC-G-A-BBB-BB-A-VV-A-NNN	M46	M46-046PV
702713	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-HS-A1-B-H-E2-NNN-050-AA-NN-05-21	SERIES 51	S51-250MV
702715	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-NN-80-L-4-F1-H-03-GBA-14-35-24	SERIES 90	S90-130PV
702716	PUMP-VAR-DISPL MPV046	MPV-046-C-B-B-J-S-B-B-BA-A-A-BFD-CE-A-GG-A-NNN	M46	M46-046PV
702717	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-E2-A1-A-N-G7-NNN-070-AA-G0-03-30	SERIES 51	S51-160MV
702719	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-NN-80-P-3-C8-H-03-GBA-42-42-24	SERIES 90	S90-130PV
702721	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-NN-60-S-4-C6-D-04-GBA-16-16-32	SERIES 90	S90-075PV
702723	PUMP-VAR-DISPL CCW 90PV100	90L100-MA-5-AB-60-S-3-C7-E-C5-GBA-42-42-24	SERIES 90	S90-100PV
702726	PUMP-VAR-DISPL CCW 90PV250	90L250-MA-5-EG-80-S-4-C8-K-C3-NNN-38-38-24	SERIES 90	S90-250PV
702730	PUMP-VAR-DISPL CCW 90PV250	90L250-KP-5-NN-80-T-4-C8-K-03-NNN-32-32-28	SERIES 90	S90-250PV
702731	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-NN-80-P-4-F1-H-03-GBA-35-35-24	SERIES 90	S90-130PV
702732	PUMP-VAR-DISPL CW 90PV075	90R075-MA-5-BC-80-S-3-C6-D-C5-GBA-42-42-24	SERIES 90	S90-075PV
702733	PUMP-VAR-DISPL CW 90PV055	90R055-KA-5-BG-80-S-3-S1-D-03-GBA-26-26-24	SERIES 90	S90-055PV
702735	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-CD-80-S-3-C8-K-03-NNN-42-42-24	SERIES 90	S90-250PV
702736	MOTOR-VAR-DISPL 51MD110-1	51D110-1--R-D4-N-E1-B1-N-N-U1-NNN-045-AA-E6-00-00	SERIES 51	S51-110MV-1
702737	MOTOR-VAR-DISPL 51MD060-1	51D060-1--R-D2-N-E1-B1-N-N-U1-NNN-023-AA-E6-00-00	SERIES 51	S51-060MV-1
702739	PUMP-VAR-DISPL CW 90PV130	90R130-DD-5-CD-80-L-3-C8-H-GB-GBA-35-35-24	SERIES 90	S90-130PV
702742	PUMP-VAR-DISPL MPV025	MPV-025-C-B-A-A-R-A-G-NN-A-A-BEE-DL-A-FF-A-NNN	LIGHT DUTY	025PV
702743	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-P-NN-80-P-4-C7-D-03-GBA-48-48-24	SERIES 90	S90-075PV
702744	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-BC-60-R-4-C7-F-04-GBA-42-42-24	SERIES 90	S90-100PV
702747	PUMP-VAR-DISPL CW 90PV100	90R100-MA-5-AB-60-S-3-C7-F-C5-GBA-42-42-24	SERIES 90	S90-100PV
702748	MOTOR-VAR-DISPL 51MC080	51C080-R-D3-N-L2-B1-V-A-C0-ADA-016-AA-E6-B2-00	SERIES 51	S51-080MV
702749	PUMP-VAR-DISPL CW 90PV075	90R075-MB-5-BC-80-S-3-C7-D-C5-GBA-35-35-24	SERIES 90	S90-075PV
702754	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-C8-N-TA-C2-N-N-X1-NNN-058-AA-F3-00-30	SERIES 51	S51-110MV-1
702757	PUMP-VAR-DISPL CW 90PV130	90R130-DD-5-CD-80-L-4-C8-H-G8-GBA-26-26-20	SERIES 90	S90-130PV
702759	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-N-HS-A2-B-H-C1-NNN-080-AA-NN-10-16	SERIES 51	S51-160MV

702760	PUMP-VAR-DISPL CW 90PV075	90R075-HF-5-BC-80-S-3-C6-D-03-GBA-42-42-24	SERIES 90	S90-075PV
702762	PUMP-VAR-DISPL MPV035	MPV-035-D-B-A-A-L-S-G-AA-A-A-BEE-DR-A-FF-A-NNN	M35/44	035PV
702764	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-CD-60-S-3-C7-E-03-GBA-26-26-28	SERIES 90	S90-075PV
702768	PUMP-VAR-DISPL CW 90PV130	90R130-HF-5-BC-80-L-3-C8-H-03-GBA-23-23-24	SERIES 90	S90-130PV
702771	MOTOR-VAR-DISPL 51MC110-1	51C110-1--R-D3-N-E2-B1-N-N-U1-ABA-040-AA-E6-00-00	SERIES 51	S51-110MV-1
702772	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-NN-80-P-3-C7-D-03-GBA-42-42-24	SERIES 90	S90-075PV
702773	PUMP-VAR-DISPL MPV046	MPV-046-C-B-B-B-L-B-A-AA-A-A-BJF-CG-A-GG-A-NNN	M46	M46-046PV
702775	PUMP-VAR-DISPL CW 90PV055	90R055-KA-5-CD-80-S-3-C6-D-03-GBA-32-32-22	SERIES 90	S90-055PV
702784	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-NN-67-J-3-T2-D-03-GBJ-35-35-20	SERIES 90	S90-075PV
702789	PUMP-VAR-DISPL CW 90PV100	90R100-FD-5-CD-80-P-7-C7-F-B1-GBA-42-42-28	SERIES 90	S90-100PV
702790	PUMP-VAR-DISPL CW 90PV100	90R100-DD-5-NN-60-S-4-C7-E-GF-GBA-23-23-24	SERIES 90	S90-100PV
702792	PUMP-VAR-DISPL CW 90PV100	90R100-FD-2-CP-60-S-7-C7-F-B1-EFI-42-42-30	SERIES 90	S90-100PV
702794	PUMP-VAR-DISPL CW 90PV055	90R055-KA-5-NN-80-P-3-S1-C-03-GBA-32-32-20	SERIES 90	S90-055PV
702799	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-CD-80-P-3-C7-E-03-GBA-32-32-24	SERIES 90	S90-075PV
702802	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-E2-A1-A-N-E2-NNN-075-AA-F0-03-26	SERIES 51	S51-250MV
702805	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-AB-80-T-C-C8-J-05-NNN-35-35-24	SERIES 90	S90-180PV
702806	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-NN-80-R-3-C3-C-03-GBA-38-38-24	SERIES 90	S90-042PV
702807	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-BB-80-R-3-C3-C-03-GBA-42-42-24	SERIES 90	S90-042PV
702808	PUMP-VAR-DISPL MPV046	MPV-046-C-B-A-B-R-B-C-AA-G-A-BHH-AB-U-ED-A-NNN	M46	M46-046PV
702811	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-NN-60-S-3-C7-D-02-GBA-35-35-20	SERIES 90	S90-075PV
702815	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-DG-80-S-3-C8-H-03-GBA-42-42-24	SERIES 90	S90-130PV
702817	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-NN-80-S-3-C3-C-00-GBA-36-36-24	SERIES 90	S90-042PV
702819	PUMP-VAR-DISPL CW 42PV28	42-R-28-D-E1A6-03-B-3-G-2-H-N-N-41-41-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
702821	PUMP-VAR-DISPL CCW 90PV075	90L075-HF-5-BB-80-S-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-075PV
702822	PUMP-VAR-DISPL CCW 90PV075	90L075-HF-5-BC-80-S-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-075PV
702825	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-CD-80-S-C-F1-J-00-NNN-42-42-24	SERIES 90	S90-180PV
702828	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-BC-60-R-3-C7-D-04-GBA-42-42-20	SERIES 90	S90-075PV
702832	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-NN-80-S-3-C3-B-03-GBA-42-42-24	SERIES 90	S90-042PV
702833	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-E2-A5-A-N-G0-NNN-032-AA-G0-03-00	SERIES 51	S51-160MV
702837	PUMP-VAR-DISPL CCW 90PV055	90L055-KA-P-BK-80-P-3-C6-C-03-FAB-48-48-24	SERIES 90	S90-055PV
702839	PUMP-VAR-DISPL CW 90PV075	90R075-HF-5-NN-60-S-3-D9-D-03-GBA-35-35-18	SERIES 90	S90-075PV
702840	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-AB-80-P-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
702841	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-B-N2-NN-N-N-A0-NNN-032-AA-F3-00-00	SERIES 51	S51-160MV
702842	PUMP-VAR-DISPL CW 90PV100	90R100-MA-5-CD-60-L-4-C7-E-C7-GBA-35-35-24	SERIES 90	S90-100PV
702846	PUMP-VAR-DISPL MPV046	MPV-046-C-B-B-K-S-B-B-AA-A-A-BJJ-BA-A-HH-B-NNN	M46	M46-046PV
702847	MOTOR-FIXED-DISPL 90MF100	90-M-100-NC-0-N-8-N-0-TJ-W-00-NNN-00-00-G0	SERIES 90	S90-100MF

702848	PUMP-VAR-DISPL MPV046	MPV-046-C-B-B-H-R-B-M-AA-A-A-BFF-BA-A-GG-A-NNN	M46	M46-046PV
702849	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-BB-80-S-3-C3-C-03-GBA-35-35-24	SERIES 90	S90-042PV
702850	PUMP-VAR-DISPL CCW 90P100	90L100-MA-5-NN-60-S-3-C7-F-C5-GBA-42-42-24	SERIES 90	S90-100PV
702851	PUMP-VAR-DISPL CW 90P180	90R180-KA-5-BC-80-S-C-C8-H-04-NNN-45-45-24	SERIES 90	S90-180PV
702853	PUMP-VAR-DISPL CCW 90P100	90L100-KA-2-CD-60-S-3-S1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
702854	PUMP-VAR-DISPL CW 90P100	90R100-KA-2-CD-60-S-3-S1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
702856	MOTOR-VAR-DISPL 51MV060	51V060-R-S1-N-N2-NN-N-N-A0-NNN-039-AA-F0-00-00	SERIES 51	S51-060MV
702859	PUMP-VAR-DISPL CW 90P130	90R130-FH-5-BC-80-L-7-F1-H-B1-GBA-40-40-24	SERIES 90	S90-130PV
702861	PUMP-VAR-DISPL CW 90P130	90R130-FH-5-CD-80-L-7-F1-H-B1-GBA-40-40-24	SERIES 90	S90-130PV
702865	PUMP-VAR-DISPL CW 42PV028	42-R-28-D-ANN3-02-B-3-G-2-C-N-A-21-21-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
702867	PUMP-VAR-DISPL CW 90P075	90R075-KA-5-BB-80-S-3-C7-D-03-GBA-30-30-24	SERIES 90	S90-075PV
702868	PUMP-VAR-DISPL CW 90P075	90R075-KA-5-NN-60-R-3-C7-D-03-GBA-35-35-24	SERIES 90	S90-075PV
702873	PUMP-VAR-DISPL CW 90P130	90R130-KA-5-CF-80-L-3-F1-H-03-GBA-38-38-24	SERIES 90	S90-130PV
702876	PUMP-VAR-DISPL CW 90P100	90R100-KA-5-NN-60-S-3-S1-D-02-GBA-35-35-24	SERIES 90	S90-100PV
702877	PUMP-VAR-DISPL CW 90PV055	90R055-KA-5-CD-80-S-3-S1-C-02-GBA-35-35-24	SERIES 90	S90-055PV
702879	PUMP-VAR-DISPL CW 90P042	90R042-MB-5-BC-80-S-4-C3-B-C5-GBA-17-17-18	SERIES 90	S90-042PV
702880	PUMP-VAR-DISPL CW 90P130	90R130-HF-5-BB-80-S-3-C8-H-03-GBA-26-26-24	SERIES 90	S90-130PV
702881	PUMP-VAR-DISPL CW 90P042	90R042-HF-5-AB-80-S-3-C3-C-03-GBA-26-26-24	SERIES 90	S90-042PV
702885	PUMP-VAR-DISPL CW 90P100	90R100-KA-5-AB-60-L-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
702889	PUMP-VAR-DISPL CW 90P042	90R042-KA-5-AB-80-S-3-C3-C-03-GBA-26-26-24	SERIES 90	S90-042PV
702895	PUMP-VAR-DISPL CCW 90P075	90L075-KA-5-CD-60-L-3-C7-D-04-GBA-38-38-24	SERIES 90	S90-075PV
702896	PUMP-VAR-DISPL CCW 90PV055	90L055-KA-5-BC-60-L-3-S1-C-04-GBA-35-35-24	SERIES 90	S90-055PV
702899	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-N-HS-A2-C-H-E1-NNN-050-AA-NN-12-20	SERIES 51	S51-250MV
702901	PUMP-VAR-DISPL CW 90P130	90R130-MA-5-BC-80-S-3-C8-F-C5-GBA-32-32-24	SERIES 90	S90-130PV
702904	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-HZ-B1-C-H-C2-NNN-032-AA-F0-12-00	SERIES 51	S51-160MV
702905	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-C8-N-E1-B1-N-N-U1-NNN-074-AA-G0-00-00	SERIES 51	S51-110MV-1
702907	PUMP-VAR-DISPL CW 90P042	90R042-KA-5-NN-80-R-4-C3-C-01-GBA-32-32-24	SERIES 90	S90-042PV
702908	PUMP-VAR-DISPL CW 90P180	90R180-KA-5-NN-80-R-C-C8-J-03-NNN-32-32-24	SERIES 90	S90-180PV
704619	MOTOR-FIXED-DISPL 90MF075	90-M-075-NC-0-N-7-N-0-D4-W-00-NNN-00-00-A3	SERIES 90	S90-075MF
705319	MOTOR-FIXED-DISPL 90MF055	90-M-055-NC-0-N-7-N-0-C6-W-00-NNN-00-00-F0	SERIES 90	S90-055MF
705392	WELLE PU.4/046 KPL.KEG.1,5/SCHIEBF.SAE-B		M46	PARTS - M46
705400	FUELLP. 4/046 KPL.EXTERN		M46	PARTS - M46
705616	DRUCKB.VENTIL 280 BAR KPL.		M46	PARTS - M46
708032	PUMP-VAR-DISPL CW 20PV119	SPV2/119--R3Z-972972-PS193-384-B1	SERIES 20	S20-119PV
708040	PUMP-VAR-DISPL CCW 20PV119	SPV2/119--L3Z-972972-PS193-384-B1	SERIES 20	S20-119PV
708065	MOTOR-FIXED-DISPL 20MF119	SMF2/119--B3Z-MS35352-XCX-B1	SERIES 20	S20-119MF

708792	PUMP-VAR-DISPL CW 90PV042	90R042-MA-1-BC-80-S-3-C3-C-03-GBA-42-42-20	SERIES 90	S90-042PV
709956	PUMP-VAR-DISPL CW 90PV130	90R130-MA-1-NN-80-S-3-F1-F-03-GBA-35-35-20	SERIES 90	S90-130PV
70SA3B-LPX-50	PUMP-OPEN-CIRCUIT-VAR OPV1/070	OPV1/070--L3Z-RQN914-B1	DAIKIN	070PV - L70 - OPV 1
710376	HYD SERVO ADJ ASSY VHA1## 4/046 TPV		M46	PARTS - M46
711945	SERVO PISTON		M46	PARTS - M46
713396	MOTOR-FIXED-DISPL 90MF055	90-M-055-NC-0-N-8-N-0-T1-N-00-NNN-00-00-00	SERIES 90	S90-055MF
713628	PUMP-VAR-DISPL CW 90PV042	90R042-EA-1-BC-80-S-3-C3-C-03-GBA-42-42-24	SERIES 90	S90-042PV
714097	PUMP-VAR-DISPL MPV046	MPV-046-C-B-B-L-B-A-AA-G-A-BHH-DA-A-GG-A-NNN	M46	M46-046PV
714733	PUMP-VAR-DISPL CW 90PV130	90R130-EA-1-AB-80-P-4-C8-F-04-GBA-35-35-24-F001	SERIES 90	S90-130PV
714865	PUMP-VAR-DISPL CCW 20PV119	SPV2/119--L3Z-972972-PS333-VML132-384--B1	SERIES 20	S20-119PV
714949	PUMP-VAR-DISPL CCW 20PV119	SPV2/119--L3F-972972-PS33X-VES342-389--B1	SERIES 20	S20-119PV
715730	MOTOR-FIXED-DISPL 90MF130	90-M-130-NC-0-N-8-N-0-F1-W-00-EEA-00-00-F3	SERIES 90	S90-130MF
718254	DISPLACEMENT LIMITER		M46	PARTS - M46
719948	MOTOR-FIXED-DISPL 90MF130	90-M-130-NC-0-N-8-N-0-C8-W-00-NNN-00-00-G3	SERIES 90	S90-130MF
720151	ENDGEH.PU.1/015 F. SCR-VENTIL		LIGHT DUTY	PARTS - Low Power
722363	PUMP-VAR-DISPL CCW 90PV042	90L042-MA-1-BB-80-P-3-C3-B-03-GBA-42-42-24	SERIES 90	S90-042PV
722884	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-N2-NN-N-N-A0-NNN-050-AA-F3-00-00	SERIES 51	S51-250MV
725663	MOTOR-VAR-DISPL 51MV160	51V160-A-C8-N-E1-A1-A-N-A2-NNN-042-AA-G0-03-16	SERIES 51	S51-160MV
725978	MOTOR-VAR-DISPL 51MV110	51V110-R-F1-N-EQ-A5-J-Y-A6-NNN-058-AA-F0-30-00	SERIES 51	S51-110MV
726323	EL.HYDR.SERVOVERST. MCV104A-05-00-07-11		SERIES 20	PARTS - S20 - Unique
728790	SHAFT		LIGHT DUTY	PARTS - Low Power
728816	WELLE MO. 1/015 KPL.		LIGHT DUTY	PARTS - Low Power
729997	PUMP-VAR-DISPL CW 90PV075	90R075-KA-2-BC-60-S-3-K2-E-03-GBA-42-42-24	SERIES 90	S90-075PV
734111	PUMP-VAR-DISPL CCW 90PV042	90L042-EA-1-NN-80-L-3-C3-B-03-GBA-32-32-20	SERIES 90	S90-042PV
734327	WELLE PU.4/023 13Z. 16/32 (MPT)		M46	PARTS - M46
735951	ELEC HYD SERVO ADJUST ASSY VES1##		M46	PARTS - M46
736637	MOTOR-FIXED-DISPL 90MF100	90-M-100-NC-0-N-8-N-0-C7-N-00-NNN-00-00-00	SERIES 90	S90-100MF
741348	MOTOR-FIXED-DISPL 20MF052	SMF2/052--B6Z-MS42422-A1	SERIES 20	S20-052MF
741918	MOTOR-FIXED-DISPL 90MF075	90-M-075-NC-0-N-7-N-0-C6-W-00-NNN-00-00-F0	SERIES 90	S90-075MF
741934	PUMP-VAR-DISPL CCW 90PV055	90L055-DD-1-BC-60-S-3-C6-D-04-GBA-35-35-24	SERIES 90	S90-055PV
742650	PUMP-VAR-DISPL CCW 90PV100	90L100-MA-1-BB-60-P-3-C7-F-04-GBA-42-42-24	SERIES 90	S90-100PV
747139	MOTOR-FIXED-DISPL 90MF055	90-M-055-NC-0-N-8-N-0-T1-W-00-NNN-00-00-F0	SERIES 90	S90-055MF
747170	PUMP-VAR-DISPL CCW 90PV075	90L075-MA-2-BB-60-P-3-C7-D-03-GBA-42-42-24	SERIES 90	S90-075PV
748418	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-N-HS-A1-B-E-A2-NNN-050-AA-F3-07-35	SERIES 51	S51-250MV
748830	PUMP-VAR-DISPL CW 90PV075	90R075-MA-1-AB-80-S-3-T2-D-03-GBA-42-42-24	SERIES 90	S90-075PV
748996	PUMP-VAR-DISPL MPV046	MPV-046-C-B-B-K-L-B-A-AA-A-A-BHH-CD-A-GG-B-NNN	M46	M46-046PV

750042	PUMP-VAR-DISPL CW 90PV130	90R130-KA-1-NN-80-R-4-C8-H-05-HCA-35-35-20-F001	SERIES 90	S90-130PV
750059	PUMP-VAR-DISPL CW 90PV100	90R100-KA-1-NN-60-R-3-C7-E-04-FAL-35-35-20	SERIES 90	S90-100PV
750182	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-N2-NN-N-N-A0-NNN-016-AA-E6-00-00	SERIES 51	S51-080MV
750802	MOTOR-VAR-DISPL 51MV080	51V080-R-C7-N-EQ-A5-J-Y-A6-NNN-030-AA-F3-30-00	SERIES 51	S51-080MV
751941	MOTOR-VAR-DISPL 51MV110	51V110-R-C8-N-N2-NN-N-N-A0-NNN-055-AA-F3-00-00	SERIES 51	S51-110MV
753038	PUMP-VAR-DISPL MPV046	MPV-046-C-B-B-G-L-B-C-BA-G-A-BJJ-CD-A-TT-C-NNN	M46	M46-046PV
755165	PUMP-VAR-DISPL MPV046	MPV-046-C-B-B-D-L-B-A-AA-A-A-BBB-CD-A-GG-B-NNN	M46	M46-046PV
755827	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-BC-80-S-3-C7-E-02-GBA-42-42-24	SERIES 90	S90-100PV
762450	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-HS-A1-C-E-A2-NNN-088-AA-H0-20-30	SERIES 51	S51-250MV
762880	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-H1-A3-C-E-F7-NNN-042-AA-F0-25-20	SERIES 51	S51-160MV
763599	PUMP-VAR-DISPL CCW 90PV130	90L130-EA-1-NN-80-P-4-C8-F-04-GBA-38-38-20-F001	SERIES 90	S90-130PV
764050	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-E2-A2-A-N-A7-NNN-070-AA-G0-03-20	SERIES 51	S51-160MV
764472	MOTOR-VAR-DISPL 51MV110	51V110-R-C8-N-E2-A5-A-N-A6-NNN-046-AA-F0-03-00	SERIES 51	S51-110MV
764985	PUMP-VAR-DISPL CCW 90PV100	90L100-MH-1-NN-60-P-3-TG-D-03-FAB-42-42-20	SERIES 90	S90-100PV
765073	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-1-BB-60-R-3-C7-E-21-GBA-42-42-24	SERIES 90	S90-100PV
765511	MOTOR-VAR-DISPL 51MV110	51V110-R-C8-N-E1-A6-A-N-A9-NNN-044-AA-F0-03-00	SERIES 51	S51-110MV
765800	PUMP-VAR-DISPL CW 90PV042	90R042-DD-1-NN-80-S-4-C3-C-GF-GBA-38-38-20-F001	SERIES 90	S90-042PV
766329	PUMP-VAR-DISPL MPV046	MPV-046-C-B-A-A-L-B-A-AA-A-A-BDD-AB-U-ED-C-NNN	M46	M46-046PV
766469	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-E2-A5-A-N-A6-NNN-032-AA-F0-03-00	SERIES 51	S51-160MV
766899	WEGEVENT.4/3 NG 6 TYP J-JM-G02-4N-20		LIGHT DUTY	PARTS - Low Power
767699	PUMP-VAR-DISPL CW 90PV075	90R075-EA-1-AB-60-P-3-C7-D-03-GCA-29-29-20	SERIES 90	S90-075PV
767889	MOTOR-VAR-DISPL 51MV110	51V110-R-F1-N-E2-A5-A-N-A6-NNN-036-AA-F0-03-00	SERIES 51	S51-110MV
767897	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-E2-A5-A-N-A6-NNN-044-AA-F0-03-00	SERIES 51	S51-160MV
768713	MOTOR-FIXED-DISPL 90MF075	90-M-075-NC-0-N-7-N-0-C7-W-00-NNN-00-00-F3	SERIES 90	S90-075MF
769349	PUMP-VAR-DISPL CCW 90PV042	90L042-EA-1-AB-80-S-3-C3-C-03-GBA-26-26-20	SERIES 90	S90-042PV
770354	MOTOR-FIXED-DISPL 90MF042	90-M-042-NC-0-N-8-N-0-K4-W-00-NNN-00-00-F3	SERIES 90	S90-042MF
774638	PUMP-VAR-DISPL CW 90PV100	90R100-EA-5-CP-60-P-3-C7-F-04-FAS-38-38-28	SERIES 90	S90-100PV
779843	SERVOZYL. 2/119-166		SERIES 20	PARTS - S20 - Unique
780007	MOTOR-FIXED-DISPL 90MF130	90-M-130-NC-0-N-8-N-0-C8-N-00-NNN-00-00-00	SERIES 90	S90-130MF
780189	MOTOR-VAR-DISPL 51MV080	51V080-R-C7-N-N2-NN-N-N-A0-AAA-016-AA-F3-00-00	SERIES 51	S51-080MV
780601	PUMP-VAR-DISPL CW 90PV075	90R075-EA-1-BC-60-R-3-C7-D-04-GBA-42-42-20	SERIES 90	S90-075PV
785360	PUMP-VAR-DISPL CW 90PV130	90R130-EA-1-BC-80-R-3-C8-F-03-GBA-42-42-24	SERIES 90	S90-130PV
786640	MOTOR-VAR-DISPL 51MV080	51V080-R-C7-N-HS-A4-C-E-C5-NNN-039-AA-F3-17-24	SERIES 51	S51-080MV
788778	PUMP-VAR-DISPL CW 20PV089	SPV2/089--R6Z-PA253-430-B1	SERIES 20	S20-089PV
788877	MOTOR-VAR-DISPL 51MV080	51V080-R-C7-N-E2-A5-A-N-A6-NNN-047-AA-F0-03-00	SERIES 51	S51-080MV
788984	MOTOR-VAR-DISPL 51MV110	51V110-R-C8-N-E2-A5-A-N-A6-NNN-022-AA-F0-03-00	SERIES 51	S51-110MV

789339	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-N-E1-A2-A-N-A7-NNN-050-AA-G3-03-20	SERIES 51	S51-250MV
793109	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-B-E2-A2-A-N-E1-NNN-035-AA-F3-03-25	SERIES 51	S51-160MV
793281	MOTOR-VAR-DISPL 51MV110	51V110-R-F1-N-HS-A1-C-E-E2-NNN-022-AA-F0-22-17	SERIES 51	S51-110MV
793307	MOTOR-FIXED-DISPL 90MF100	90-M-100-NC-0-N-8-N-0-T2-W-00-NNN-00-00-F3	SERIES 90	S90-100MF
80000002	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-NN-80-P-3-C7-D-03-GBA-29-29-24	SERIES 90	S90-075PV
80000003	PUMP-VAR-DISPL CW 90PV042	90R042-FD-5-BC-80-P-7-C3-C-B1-GBA-16-16-28	SERIES 90	S90-042PV
80000004	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-AB-60-P-3-C7-D-03-GBA-40-40-24	SERIES 90	S90-075PV
80000006	MOTOR-VAR-DISPL 51MC080	51C080-A-D3-N-EQ-A2-K-Z-E1-NNN-016-AA-NN-70-22	SERIES 51	S51-080MV
80000008	PUMP-VAR-DISPL CW 90PV042	90R042-KN-5-NN-80-P-4-C3-C-03-GBA-20-20-24	SERIES 90	S90-042PV
80000009	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-BB-60-S-3-C6-D-03-GBA-26-26-24	SERIES 90	S90-075PV
80000010	PUMP-VAR-DISPL CW 90PV100	90R100-CA-5-NN-60-S-3-S1-E-00-GBA-35-35-24	SERIES 90	S90-100PV
80000011	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-CD-80-S-4-C8-K-05-NNN-35-35-28	SERIES 90	S90-250PV
80000012	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-HZ-B1-B-H-C2-NNN-115-AA-E4-12-00	SERIES 51	S51-160MV
80000013	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-AB-60-P-3-C7-D-03-GBA-29-29-20	SERIES 90	S90-075PV
80000014	MOTOR-VAR-DISPL 51MV110	51V110-R-F1-N-HZ-B1-C-H-C2-NNN-050-AA-E4-13-00	SERIES 51	S51-110MV
80000015	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-NN-80-L-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
80000016	PUMP-VAR-DISPL CW 90PV075	90R075-FM-5-BC-80-S-7-C7-E-B6-ELB-42-42-30	SERIES 90	S90-075PV
80000018	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-AB-80-D-4-C3-L-02-GBA-42-42-26	SERIES 90	S90-042PV
80000020	MOTOR-VAR-DISPL 51MV110	51V110-R-F1-N-HZ-B1-C-H-C2-NNN-022-AA-F3-15-00	SERIES 51	S51-110MV
80000021	PUMP-VAR-DISPL CCW 90PV075	90L075-MA-5-NN-80-S-3-C7-D-C5-GBA-17-17-24	SERIES 90	S90-075PV
80000022	PUMP-VAR-DISPL CW 90PV075	90R075-FK-5-NN-80-P-7-S1-D-B6-GME-40-40-24	SERIES 90	S90-075PV
80000023	MOTOR-VAR-DISPL 51MV060	51V060-R-C6-N-D8-M1-R-J-M4-ADA-020-AA-E6-C2-13	SERIES 51	S51-060MV
80000024	PUMP-VAR-DISPL CW 90PV130	90R130-PB-5-NN-80-L-3-F1-F-03-GBA-38-38-24	SERIES 90	S90-130PV
80000025	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-V-BJ-8E-L-3-F4-F-03-GB2-42-42-36	SERIES 90	S90-130PV
80000026	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-V-BJ-8E-L-3-F4-F-03-GB4-42-42-36	SERIES 90	S90-130PV
80000027	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-V-BJ-8E-L-R-F4-F-03-GB4-42-42-36	SERIES 90	S90-130PV
80000029	PUMP-VAR-DISPL CCW 90PV042	90L042-KA-5-BB-80-S-3-C5-B-02-GBA-35-35-24	SERIES 90	S90-042PV
80000030	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-AB-60-S-3-C7-D-03-GBA-14-32-24	SERIES 90	S90-075PV
80000031	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-TA-C2-L-N-G0-NNN-120-AA-F0-00-A5	SERIES 51	S51-250MV
80000032	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-CD-80-S-M-C8-J-05-NNN-35-35-28	SERIES 90	S90-180PV
80000033	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-NN-80-S-C-C8-J-06-NNN-36-36-24	SERIES 90	S90-180PV
80000034	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-AB-80-S-C-C8-J-06-NNN-36-36-24	SERIES 90	S90-180PV
80000035	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-NN-80-S-4-C8-J-03-NNN-38-38-24	SERIES 90	S90-250PV
80000042	PUMP-VAR-DISPL CW 90PV100	90R100-MA-1-BC-60-S-3-C7-F-06-GBA-42-42-24	SERIES 90	S90-100PV
80000052	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-N-E2-B1-N-N-U1-ADA-024-AA-E6-00-00	SERIES 51	S51-060MV-1
80000053	MOTOR-VAR-DISPL 51MD110	51D110-A-D3-N-HS-A2-B-E-E1-NNN-022-AA-F3-08-25	SERIES 51	S51-110MV

80000054	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-NN-80-S-C-C8-H-03-NNN-38-38-30	SERIES 90	S90-180PV
80000055	PUMP-VAR-DISPL CW 90PV075	90R075-FN-5-CD-80-P-7-C7-D-B6-GMD-42-42-32	SERIES 90	S90-075PV
80000057	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-NN-60-R-3-F1-E-03-FAB-42-42-24	SERIES 90	S90-100PV
80000058	PUMP-VAR-DISPL CW 90PV075	90R075-FN-5-BC-80-P-7-S1-D-B6-GMD-42-42-32	SERIES 90	S90-075PV
80000062	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-NN-80-S-4-C8-F-05-GBA-32-32-24	SERIES 90	S90-130PV
80000063	PUMP-VAR-DISPL CCW 90PV075	90L075-DD-5-AB-60-S-4-C7-D-GF-GBA-42-42-24	SERIES 90	S90-075PV
80000064	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-AB-80-S-C-C8-J-05-NNN-45-45-24	SERIES 90	S90-180PV
80000065	PUMP-VAR-DISPL CCW 90PV075	90L075-NA-5-AB-60-L-3-T6-D-02-FAB-42-42-24	SERIES 90	S90-075PV
80000066	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-CD-80-R-3-G1-E-03-FAP-35-35-30	SERIES 90	S90-075PV
80000068	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-NN-80-L-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
80000069	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-TA-C0-L-N-G0-NNN-072-AA-F0-00-A3	SERIES 51	S51-160MV
80000070	MOTOR-VAR-DISPL 51MD110	51D110-A-D3-N-L2-B1-V-A-G0-NNN-032-AA-F0-B2-00	SERIES 51	S51-110MV
80000071	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-E2-A5-A-N-A6-NNN-035-AA-G0-03-00	SERIES 51	S51-160MV
80000072	PUMP-VAR-DISPL CW 90PV042	90R042-MA-5-NN-80-S-3-C3-C-C5-GBA-35-35-24	SERIES 90	S90-042PV
80000073	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-BC-80-T-3-C8-K-03-NNN-35-14-24	SERIES 90	S90-250PV
80000074	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-NN-80-S-M-F1-J-05-FAC-38-38-28	SERIES 90	S90-180PV
80000075	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-EF-80-S-M-C8-J-05-FAC-38-38-28	SERIES 90	S90-180PV
80000076	MOTOR-VAR-DISPL 51MC110-1	51C110-1--R-D3-N-E2-B1-N-N-U1-ACB-033-AA-F0-00-00	SERIES 51	S51-110MV-1
80000082	PUMP-VAR-DISPL CW 90PV130	90R130-MA-5-NN-80-L-3-F1-H-C4-GBA-45-45-24	SERIES 90	S90-130PV
80000083	MOTOR-VAR-DISPL 51MD080-1	51D080-1--R-D2-N-T7-CA-N-N-X1-NNN-030-AA-F3-00-28	SERIES 51	S51-080MV-1
80000084	MOTOR-VAR-DISPL 51MC110-1	51C110-1--R-D3-E-E2-B1-N-N-U1-NNN-032-AA-E6-00-00	SERIES 51	S51-110MV-1
80000085	PUMP-VAR-DISPL CCW 90PV100	90L100-HF-5-NN-80-P-3-S1-E-03-GBA-40-40-24	SERIES 90	S90-100PV
80000086	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-AB-60-S-3-C7-D-03-EFI-35-35-22	SERIES 90	S90-075PV
80000087	PUMP-VAR-DISPL CW 90PV100	90R100-MA-5-CD-60-S-3-C7-F-C5-FAB-42-42-24	SERIES 90	S90-100PV
80000088	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-BC-80-S-3-C8-F-04-GBA-35-35-24	SERIES 90	S90-130PV
80000089	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-EG-80-S-C-C8-J-04-NNN-35-35-24	SERIES 90	S90-180PV
80000090	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-NN-80-P-3-C8-H-03-GBA-17-17-24	SERIES 90	S90-130PV
80000091	PUMP-VAR-DISPL CCW 90PV042	90L042-KA-5-BC-80-S-3-C3-C-04-GBA-35-35-24	SERIES 90	S90-042PV
80000093	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-N-TA-C2-L-N-G0-NNN-032-AA-G0-00-B0	SERIES 51	S51-160MV
80000102	MOTOR-VAR-DISPL 51MV110	51V110-R-C8-N-EQ-A6-J-Y-A9-NNN-022-AA-F3-30-00	SERIES 51	S51-110MV
80000112	MOTOR-VAR-DISPL 51MV080	51V080-A-S1-N-L2-B1-V-A-C0-AWM-016-AA-F0-B2-00	SERIES 51	S51-080MV
80000113	PUMP-VAR-DISPL CW 90PV100	90R100-FG-5-BC-60-S-7-C7-E-B1-EDI-42-42-28	SERIES 90	S90-100PV
80000114	PUMP-VAR-DISPL CW 90PV100	90R100-PB-5-CD-80-L-4-C7-E-04-GBA-26-35-24	SERIES 90	S90-100PV
80000115	PUMP-VAR-DISPL CW 90PV042	90R042-HF-5-BB-80-S-3-C5-C-03-GBA-42-42-24	SERIES 90	S90-042PV
80000116	PUMP-VAR-DISPL CW 90PV042	90R042-HF-5-AB-80-S-3-C3-C-03-GBA-42-42-24	SERIES 90	S90-042PV
80000117	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-BB-80-S-3-T8-B-03-GBA-42-42-24	SERIES 90	S90-042PV

80000122	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-AB-80-S-4-C3-C-04-GBA-35-35-30	SERIES 90	S90-042PV
80000123	MOTOR-VAR-DISPL 51MV060-1	51V060-1--A-D2-N-T1-CA-N-N-X1-NNN-021-AA-E6-00-22	SERIES 51	S51-060MV-1
80000124	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-CD-60-P-7-C7-F-00-GLS-42-42-30	SERIES 90	S90-100PV
80000125	PUMP-VAR-DISPL CW 90PV042	90R042-HF-5-NN-80-R-4-C3-C-00-GCA-42-42-20	SERIES 90	S90-042PV
80000126	PUMP-VAR-DISPL CW 90PV075	90R075-HF-5-NN-60-P-4-C7-D-00-GCA-42-42-20	SERIES 90	S90-075PV
80000127	PUMP-VAR-DISPL CCW 90PV130	90L130-KN-5-NN-80-R-3-F1-F-K2-GBA-20-20-24	SERIES 90	S90-130PV
80000128	PUMP-VAR-DISPL CCW 90PV130	90L130-KN-5-NN-80-R-3-F1-F-K2-GBA-26-26-24	SERIES 90	S90-130PV
80000129	PUMP-VAR-DISPL CCW 90PV130	90L130-KN-5-NN-80-R-3-F1-F-K2-GBA-29-29-24	SERIES 90	S90-130PV
80000130	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-N-T1-C0-L-N-K7-NNN-059-AA-G0-00-B1	SERIES 51	S51-160MV
80000131	PUMP-VAR-DISPL CCW 90PV042	90L042-KA-5-NN-80-D-3-C3-N-03-FAD-42-42-24	SERIES 90	S90-042PV
80000132	PUMP-VAR-DISPL CW 90PV075	90R075-MA-5-BB-80-S-4-C7-D-C5-GBA-35-35-24	SERIES 90	S90-075PV
80000133	PUMP-VAR-DISPL CW 90PV042	90R042-MA-5-AB-80-S-4-C3-C-C5-GBA-35-35-24	SERIES 90	S90-042PV
80000134	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-CD-80-P-4-C8-F-03-GBA-35-35-24	SERIES 90	S90-130PV
80000142	MOTOR-VAR-DISPL 51MV110	51V110-R-C8-N-HS-L2-B-E-A8-AAA-054-AA-F3-10-29	SERIES 51	S51-110MV
80000143	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-AB-60-S-4-C7-F-03-GBA-23-23-24	SERIES 90	S90-100PV
80000152	MOTOR-VAR-DISPL 51MC060	51C060-R-D1-N-L2-B1-V-A-C0-ADA-012-AA-E6-B2-00	SERIES 51	S51-060MV
80000153	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-V-BB-8E-L-3-C7-F-03-GB1-42-42-28	SERIES 90	S90-100PV
80000154	MOTOR-VAR-DISPL 51MC080	51C080-R-D3-N-HZ-B1-B-H-C2-NNN-032-AA-F0-07-00	SERIES 51	S51-080MV
80000155	PUMP-VAR-DISPL CCW 90PV100	90L100-HF-5-BC-60-S-3-C7-D-03-GBA-32-32-24	SERIES 90	S90-100PV
80000156	MOTOR-VAR-DISPL 51MV110	51V110-A-C8-N-HZ-B1-C-H-C2-NNN-032-AA-NN-20-00	SERIES 51	S51-110MV
80000157	PUMP-VAR-DISPL CW 90PV180	90R180-FH-5-CD-80-S-7-C8-J-B1-EFI-40-40-28	SERIES 90	S90-180PV
80000158	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-D8-M1-R-J-M4-NNN-049-AA-F3-C2-23	SERIES 51	S51-160MV
80000159	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-A-E2-A7-A-N-E1-CCA-125-AA-F0-03-25	SERIES 51	S51-250MV
80000162	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-BB-80-L-3-C8-H-03-GBA-35-35-24	SERIES 90	S90-130PV
80000163	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-L1-B1-W-B-C0-NNN-050-AA-F0-D4-00	SERIES 51	S51-250MV
80000164	PUMP-VAR-DISPL CW 90PV130	90R130-HF-5-NN-80-S-4-C8-H-03-GBA-35-35-24	SERIES 90	S90-130PV
80000165	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-NN-80-R-3-C7-D-03-GBA-23-07-28	SERIES 90	S90-075PV
80000166	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-NN-80-R-3-C8-H-03-GBA-30-14-28	SERIES 90	S90-130PV
80000167	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-NN-80-T-3-C8-K-04-NNN-30-14-28	SERIES 90	S90-250PV
80000168	PUMP-VAR-DISPL CCW 90PV180	90L180-KP-5-NN-80-T-M-F1-J-05-FAC-35-35-24	SERIES 90	S90-180PV
80000169	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-BC-80-R-3-C8-H-03-GBA-40-40-26	SERIES 90	S90-130PV
80000170	MOTOR-VAR-DISPL 51MV250	51V250-A-C8-N-TA-C2-L-N-G0-NNN-135-AA-H0-00-B5	SERIES 51	S51-250MV
80000171	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-DE-80-S-3-C8-K-03-EFI-42-42-24	SERIES 90	S90-250PV
80000172	PUMP-VAR-DISPL CW 90PV100	90R100-MA-2-CD-60-S-4-C7-E-04-FAX-45-45-24	SERIES 90	S90-100PV
80000173	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-CD-80-S-3-T7-H-03-GBA-38-38-24	SERIES 90	S90-130PV
80000174	MOTOR-VAR-DISPL 51MV080	51V080-A-S1-N-HS-A1-B-E-E2-NNN-054-AA-E4-05-37	SERIES 51	S51-080MV

80000192	MOTOR-VAR-DISPL 51MV060-1	51V060-1--R-S1-N-TH-C2-N-N-X1-NNN-015-AA-NN-00-28	SERIES 51	S51-060MV-1
80000212	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-BB-60-P-4-C7-F-03-FAB-45-45-24	SERIES 90	S90-100PV
80000213	PUMP-VAR-DISPL CW 90PV130	90R130-DD-5-BB-80-S-3-F1-H-GB-GBA-35-35-22	SERIES 90	S90-130PV
80000214	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-C-N2-NN-N-N-A0-NNN-115-AA-NN-00-00	SERIES 51	S51-160MV
80000215	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-BC-80-R-7-C7-E-09-FAZ-35-35-30	SERIES 90	S90-100PV
80000216	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-CD-80-L-4-F1-F-03-GBA-35-35-24	SERIES 90	S90-130PV
80000217	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-BC-80-S-C-C8-J-09-GCG-35-35-30	SERIES 90	S90-180PV
80000219	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-EG-80-S-C-C8-J-06-NNN-36-36-24	SERIES 90	S90-180PV
80000220	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-NN-80-L-4-F1-H-00-GBA-14-14-20	SERIES 90	S90-130PV
80000221	PUMP-VAR-DISPL CW 90PV100	90R100-DD-2-BC-60-S-7-C7-D-G1-GCA-30-30-30	SERIES 90	S90-100PV
80000222	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-NN-80-L-3-T6-E-03-GBA-35-35-28	SERIES 90	S90-100PV
80000224	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-BB-80-S-3-C8-H-04-GBA-45-45-24	SERIES 90	S90-130PV
80000225	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-AB-60-L-3-S1-D-03-GBA-42-42-20	SERIES 90	S90-075PV
80000226	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-V-AB-8E-P-3-C7-E-02-GB1-42-42-24	SERIES 90	S90-100PV
80000228	PUMP-VAR-DISPL CCW 90PV180	90L180-KP-5-NN-80-S-M-F1-J-03-FAC-32-32-24	SERIES 90	S90-180PV
80000229	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-E2-A5-A-N-G0-NNN-100-AA-G3-03-00	SERIES 51	S51-160MV
80000230	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-BC-80-P-3-F1-H-03-EFC-42-42-20	SERIES 90	S90-130PV
80000231	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-BC-80-P-3-F1-F-00-GBA-38-38-20	SERIES 90	S90-130PV
80000232	PUMP-VAR-DISPL CW 90PV100	90R100-DD-2-AB-60-S-7-C7-D-G1-GCA-30-30-30	SERIES 90	S90-100PV
80000233	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-DE-80-P-3-C8-H-03-EFC-42-42-20	SERIES 90	S90-130PV
80000234	MOTOR-VAR-DISPL 51MV080-1	51V080-1--A-S1-D-TA-C2-N-N-X1-NNN-045-AA-NN-00-27	SERIES 51	S51-080MV-1
80000235	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-5-EG-80-S-3-C8-K-00-EFI-42-42-28	SERIES 90	S90-250PV
80000236	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-C8-N-E2-B1-N-N-U1-ABA-045-AA-F3-00-00	SERIES 51	S51-110MV-1
80000237	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-E2-A5-A-N-A6-NNN-075-AA-F3-03-00	SERIES 51	S51-250MV
80000239	MOTOR-VAR-DISPL 51MV080-1	51V080-1--A-S1-N-N1-NN-N-N-U1-NNN-032-AA-NN-00-00	SERIES 51	S51-080MV-1
80000240	MOTOR-VAR-DISPL 51MV080-1	51V080-1--A-S1-N-N1-NN-N-N-U1-ABA-032-AA-NN-00-00	SERIES 51	S51-080MV-1
80000241	MOTOR-VAR-DISPL 51MC110	51C110-R-D3-N-L3-B1-W-B-G0-AWD-022-AA-F0-D4-00	SERIES 51	S51-110MV
80000242	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-CD-80-P-3-F1-F-00-GBA-38-38-20	SERIES 90	S90-130PV
80000243	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-CD-80-R-3-F1-F-00-GBA-38-38-20	SERIES 90	S90-130PV
80000244	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-NN-80-R-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-130PV
80000245	MOTOR-VAR-DISPL 51MC080	51C080-R-D2-N-L1-B1-W-B-M3-NNN-016-AA-E6-D4-00	SERIES 51	S51-080MV
80000246	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-BB-60-L-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-075PV
80000247	PUMP-VAR-DISPL CW 90PV180	90R180-KP-5-CD-80-T-M-C8-J-03-NNN-42-42-24	SERIES 90	S90-180PV
80000249	MOTOR-VAR-DISPL 51MD110-1	51D110-1--R-D4-N-T1-R5-N-N-X1-NNN-050-AA-F3-00-25	SERIES 51	S51-110MV-1
80000251	MOTOR-VAR-DISPL 51MV110	51V110-R-C8-N-HZ-B1-A-N-C2-NNN-080-AA-F3-03-00	SERIES 51	S51-110MV
80000252	MOTOR-VAR-DISPL 51MC080	51C080-R-D2-N-L1-B1-W-B-M3-AWA-028-AA-E6-D4-00	SERIES 51	S51-080MV

80000253	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-TH-CA-N-N-X1-NNN-071-AA-F0-00-25	SERIES 51	S51-110MV-1
80000254	MOTOR-VAR-DISPL 51MV060-1	51V060-1--R-S1-N-TA-CA-N-N-X1-ABA-015-AA-E4-00-28	SERIES 51	S51-060MV-1
80000255	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-V-NV-8E-R-3-F4-F-03-GB3-45-45-30	SERIES 90	S90-130PV
80000256	MOTOR-VAR-DISPL 51MC080-1	51C080-1--H-D3-N-N1-NN-N-N-U1-ADA-035-AA-NN-00-00	SERIES 51	S51-080MV-1
80000257	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-A-HS-A2-C-H-E1-NNN-067-AA-NN-15-32	SERIES 51	S51-250MV
80000258	MOTOR-VAR-DISPL 51MD160	51D160-A-D5-N-N2-NN-N-N-A0-NNN-107-AA-NN-00-00	SERIES 51	S51-160MV
80000259	MOTOR-VAR-DISPL 51MD160	51D160-A-D5-B-HS-A2-C-H-E1-NNN-073-AA-NN-15-27	SERIES 51	S51-160MV
80000260	MOTOR-VAR-DISPL 51MD160	51D160-A-D5-D-HS-A2-C-H-E1-NNN-080-AA-NN-15-27	SERIES 51	S51-160MV
80000261	MOTOR-VAR-DISPL 51MD160	51D160-A-D5-A-HS-A2-C-H-E1-NNN-110-AA-NN-15-27	SERIES 51	S51-160MV
80000262	MOTOR-VAR-DISPL 51MC110	51C110-R-D3-N-L3-B1-W-B-G0-ABA-022-AA-F0-D4-00	SERIES 51	S51-110MV
80000263	MOTOR-VAR-DISPL 51MC080	51C080-R-D2-N-L3-B1-W-B-G0-ABA-016-AA-F0-D4-00	SERIES 51	S51-080MV
80000264	MOTOR-VAR-DISPL 51MV080-1	51V080-1--A-S1-N-N1-NN-N-N-U1-ABA-040-AA-NN-00-00	SERIES 51	S51-080MV-1
80000265	PUMP-VAR-DISPL CW 90PV180	90R180-MA-5-NN-80-S-C-C8-J-C5-NNN-42-42-28	SERIES 90	S90-180PV
80000267	PUMP-VAR-DISPL CW 90PV180	90R180-PB-5-NN-80-T-C-F1-J-00-NNN-29-29-24	SERIES 90	S90-180PV
80000268	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-CD-80-T-7-C8-J-03-GCG-35-35-30	SERIES 90	S90-180PV
80000269	PUMP-VAR-DISPL CW 90PV130	90R130-DD-5-BC-80-L-4-C8-H-GB-GBA-42-42-28	SERIES 90	S90-130PV
80000270	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-E1-B1-N-N-U1-NNN-061-AA-NN-00-00	SERIES 51	S51-110MV-1
80000271	MOTOR-VAR-DISPL 51MD110-1	51D110-1--A-D4-N-T1-CA-N-N-X1-NNN-032-AA-F0-00-20	SERIES 51	S51-110MV-1
80000272	PUMP-VAR-DISPL CW 90PV250	90R250-MA-5-NN-80-S-4-F1-J-C7-NNN-36-36-24	SERIES 90	S90-250PV
80000273	PUMP-VAR-DISPL CW 90PV100	90R100-FA-5-BB-60-S-7-S1-F-B2-GBA-42-42-30	SERIES 90	S90-100PV
80000282	PUMP-VAR-DISPL CCW 90PV100	90L100-MA-5-CD-60-S-3-C7-E-C5-FAB-42-42-24	SERIES 90	S90-100PV
80000283	PUMP-VAR-DISPL CCW 90PV100	90L100-MA-5-NN-60-S-3-S1-E-C5-FAB-42-42-24	SERIES 90	S90-100PV
80000284	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-EG-80-T-7-C8-J-03-GCG-35-35-30	SERIES 90	S90-180PV
80000285	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-NN-80-S-3-C3-C-33-GBA-36-36-24	SERIES 90	S90-042PV
80000286	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-NN-60-P-3-C7-D-03-GBA-42-42-24	SERIES 90	S90-075PV
80000287	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-TA-C0-L-N-G0-NNN-080-AA-F0-00-A3	SERIES 51	S51-250MV
80000288	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-CD-80-P-3-C7-F-04-GBA-42-42-24	SERIES 90	S90-100PV
80000289	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-BB-80-P-3-S1-E-04-GBA-42-42-24	SERIES 90	S90-075PV
80000290	MOTOR-VAR-DISPL 51MD110-1	51D110-1--A-D3-N-T1-R5-N-N-X1-ADA-055-AA-H0-00-28	SERIES 51	S51-110MV-1
80000291	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-NN-60-S-3-C7-F-04-GBA-38-38-24	SERIES 90	S90-100PV
80000292	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-BC-80-P-3-C7-D-03-GBA-29-29-24	SERIES 90	S90-075PV
80000293	PUMP-VAR-DISPL CW 90PV250	90R250-HF-5-BC-80-T-4-F1-J-03-NNN-29-29-24	SERIES 90	S90-250PV
80000294	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-NN-80-S-3-C8-H-00-EFC-42-42-24	SERIES 90	S90-130PV
80000295	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-AB-80-P-3-C8-H-03-GBA-38-14-24	SERIES 90	S90-130PV
80000296	MOTOR-VAR-DISPL 51MV110	51V110-R-F1-N-HS-A2-B-H-C1-NNN-028-AA-NN-10-13	SERIES 51	S51-110MV
80000297	MOTOR-VAR-DISPL 51MD080-1	51D080-1--R-D3-N-E1-B1-N-N-U1-NNN-030-AA-F3-00-00	SERIES 51	S51-080MV-1

80000298	PUMP-VAR-DISPL CW 90PV075	90R075-FM-5-BC-60-P-7-C7-E-B6-EFR-42-42-30	SERIES 90	S90-075PV
80000299	PUMP-VAR-DISPL CW 90PV100	90R100-CB-5-NN-80-S-3-C7-F-00-GBA-42-42-24	SERIES 90	S90-100PV
80000300	PUMP-VAR-DISPL CW 90PV042	90R042-HF-5-BC-80-S-3-C3-C-03-GBA-29-29-24	SERIES 90	S90-042PV
80000301	MOTOR-VAR-DISPL 51MD080-1	51D080-1--A-D2-N-T2-C2-N-N-X1-NNN-036-AA-E6-00-16	SERIES 51	S51-080MV-1
80000302	MOTOR-VAR-DISPL 51MD110-1	51D110-1--A-D4-E-T7-L5-N-N-X1-NNN-055-AA-F3-00-24	SERIES 51	S51-110MV-1
80000305	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-Y3-B1-S-K-J1-ADA-110-AA-G3-F4-00	SERIES 51	S51-160MV
80000306	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-DE-80-L-4-F1-F-03-GBA-32-32-24	SERIES 90	S90-130PV
80000307	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-CD-60-S-3-C7-D-03-GBA-45-45-24	SERIES 90	S90-100PV
80000308	PUMP-VAR-DISPL CW 90PV250	90R250-MA-5-AB-80-S-3-F1-J-C6-NNN-35-35-24	SERIES 90	S90-250PV
80000309	PUMP-VAR-DISPL CW 90PV250	90R250-KP-5-CD-80-T-3-F1-K-03-NNN-35-35-24	SERIES 90	S90-250PV
80000310	PUMP-VAR-DISPL CW 90PV130	90R130-MA-5-BC-80-L-3-C8-H-C5-GBA-42-42-24	SERIES 90	S90-130PV
80000312	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-BB-60-S-3-C7-F-21-GBA-42-42-24	SERIES 90	S90-100PV
80000313	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-BC-80-L-4-F1-F-03-GBA-32-32-24	SERIES 90	S90-130PV
80000315	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-CD-80-R-3-F1-H-03-GBA-35-35-30	SERIES 90	S90-130PV
80000317	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-DE-80-L-3-F1-H-05-GBA-45-45-24	SERIES 90	S90-130PV
80000318	PUMP-VAR-DISPL CW 90PV075	90R075-FM-5-AB-60-P-7-C7-D-B6-GMD-42-42-30	SERIES 90	S90-075PV
80000319	PUMP-VAR-DISPL CW 90PV250	90R250-HF-5-AB-80-S-4-C8-K-03-NNN-42-42-24	SERIES 90	S90-250PV
80000321	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-CD-80-T-4-C8-K-01-NNN-14-38-30	SERIES 90	S90-250PV
80000322	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-BB-80-T-M-F1-J-03-EBA-38-38-24	SERIES 90	S90-180PV
80000323	MOTOR-VAR-DISPL 51MD080-1	51D080-1--A-D2-N-P7-P7-N-N-X1-NNN-019-AA-F0-00-AA	SERIES 51	S51-080MV-1
80000324	MOTOR-VAR-DISPL 51MC160	51C160-R-D5-N-L2-B1-V-A-C0-ABA-032-AA-F0-B2-00	SERIES 51	S51-160MV
80000325	MOTOR-VAR-DISPL 51MV080	51V080-A-S1-N-EQ-A5-K-Z-G5-NNN-054-AA-F0-50-00	SERIES 51	S51-080MV
80000326	PUMP-VAR-DISPL CW 90PV250	90R250-KN-5-NN-80-S-3-C8-K-03-NNN-26-26-24	SERIES 90	S90-250PV
80000328	PUMP-VAR-DISPL CCW 90PV075	90L075-FH-5-CD-80-P-7-C7-E-B1-GBA-35-35-28	SERIES 90	S90-075PV
80000329	PUMP-VAR-DISPL CCW 90PV075	90L075-CA-5-CD-80-P-7-S1-E-00-GBA-35-35-28	SERIES 90	S90-075PV
80000330	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-BB-60-S-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
80000332	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-TH-C0-L-N-G0-NNN-080-AA-F0-00-C1	SERIES 51	S51-160MV
80000334	MOTOR-VAR-DISPL 51MV160	51V160-R-D4-N-E1-A5-A-N-G0-NNN-032-AA-F0-03-00	SERIES 51	S51-160MV
80000335	PUMP-VAR-DISPL CW 90PV130	90R130-KN-5-BC-80-R-3-F1-H-03-EEB-29-29-24	SERIES 90	S90-130PV
80000336	PUMP-VAR-DISPL CW 90PV130	90R130-MA-5-NN-80-L-3-F1-F-C5-GBA-35-35-24	SERIES 90	S90-130PV
80000337	MOTOR-VAR-DISPL 51MC110-1	51C110-1--R-D3-N-E2-B1-N-N-U1-ABA-072-AA-F0-00-00	SERIES 51	S51-110MV-1
80000338	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D2-N-N1-NN-N-N-U1-ABA-038-AA-F0-00-00	SERIES 51	S51-080MV-1
80000339	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-BC-80-L-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
80000340	PUMP-VAR-DISPL CCW 90PV042	90L042-KA-5-BC-80-S-4-C3-C-03-GBA-26-26-20	SERIES 90	S90-042PV
80000341	MOTOR-VAR-DISPL 51MD080-1	51D080-1--A-D2-N-T7-L5-N-N-X1-NNN-040-AA-F0-00-26	SERIES 51	S51-080MV-1
80000342	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-N-E1-A2-A-N-A7-NNN-070-AA-G3-03-20	SERIES 51	S51-250MV

80000344	PUMP-VAR-DISPL CW 90PV130	90R130-DD-5-BC-80-R-7-C8-F-82-GCA-38-38-28	SERIES 90	S90-130PV
80000345	MOTOR-VAR-DISPL 51MD110-1	51D110-1--A-D3-N-P7-P7-N-N-X1-AWM-040-AA-F0-00-AA	SERIES 51	S51-110MV-1
80000346	MOTOR-VAR-DISPL 51MD160	51D160-A-D4-N-TW-C0-L-N-J2-AWM-048-AA-F0-00-B7	SERIES 51	S51-160MV
80000347	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-E1-A5-A-N-A6-NNN-080-AA-F0-03-00	SERIES 51	S51-160MV
80000348	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-N-TA-C2-N-N-X1-ACB-024-AA-E6-00-18	SERIES 51	S51-060MV-1
80000349	PUMP-VAR-DISPL CW 90PV180	90R180-HF-5-AB-80-S-M-C8-J-03-NNN-23-23-24	SERIES 90	S90-180PV
80000350	PUMP-VAR-DISPL CW 90PV180	90R180-KN-5-CD-80-T-M-C8-J-03-NNN-35-35-24	SERIES 90	S90-180PV
80000351	PUMP-VAR-DISPL CW 90PV075	90R075-FL-5-CD-80-P-7-C7-E-B6-GME-42-42-30	SERIES 90	S90-075PV
80000352	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-NN-80-S-3-C7-D-03-GBA-42-42-24	SERIES 90	S90-075PV
80000353	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-BC-80-S-3-F1-F-03-GBA-42-42-24	SERIES 90	S90-130PV
80000354	MOTOR-VAR-DISPL 51MV160	51V160-A-C8-N-D8-M1-R-J-M1-NNN-064-AA-E6-C2-15	SERIES 51	S51-160MV
80000355	MOTOR-VAR-DISPL 51MC160	51C160-R-D5-N-N2-NN-N-N-A0-NNN-080-AA-NN-00-00	SERIES 51	S51-160MV
80000357	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-AB-60-S-3-C7-D-04-GBA-35-35-24	SERIES 90	S90-075PV
80000358	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-TA-C2-L-N-G0-NNN-074-AA-NN-00-B0	SERIES 51	S51-250MV
80000362	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-T2-C0-L-N-G0-NNN-035-AA-F0-00-B2	SERIES 51	S51-160MV
80000363	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-AB-80-S-3-C7-F-03-GBA-42-42-24	SERIES 90	S90-100PV
80000364	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-BC-80-S-3-C8-H-03-GBA-42-42-24	SERIES 90	S90-130PV
80000365	MOTOR-VAR-DISPL 51MC110-1	51C110-1--R-D4-N-N1-NN-N-N-U1-NNN-050-AA-F0-00-00	SERIES 51	S51-110MV-1
80000366	MOTOR-VAR-DISPL 51MV080	51V080-R-C7-N-L7-B1-W-B-J1-NNN-041-AA-F0-D4-00	SERIES 51	S51-080MV
80000367	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-BC-80-S-3-C7-F-03-GBA-26-26-24	SERIES 90	S90-100PV
80000368	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-HZ-B1-B-H-G5-NNN-050-AA-F3-05-00	SERIES 51	S51-250MV
80000369	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-HZ-B1-B-H-G5-ADA-050-AA-F3-05-00	SERIES 51	S51-250MV
80000370	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-E1-A5-A-N-A6-NNN-145-AA-NN-03-00	SERIES 51	S51-250MV
80000371	PUMP-VAR-DISPL CW 90PV042	90R042-HF-5-AB-80-P-3-C3-B-03-GBA-38-38-24	SERIES 90	S90-042PV
80000372	PUMP-VAR-DISPL CW 90PV180	90R180-KN-5-NN-80-T-M-C8-J-03-NNN-35-35-24	SERIES 90	S90-180PV
80000373	MOTOR-VAR-DISPL 51MD080-1	51D080-1--A-D2-N-TH-R5-N-N-X1-NNN-024-AA-F0-00-29	SERIES 51	S51-080MV-1
80000374	MOTOR-VAR-DISPL 51MV250	51V250-A-C8-N-JS-NN-B-E-P2-ADA-050-AA-F3-10-32	SERIES 51	S51-250MV
80000375	PUMP-VAR-DISPL CW 90PV100	90R100-MA-5-AB-80-S-3-C7-E-C5-GBA-42-42-24	SERIES 90	S90-100PV
80000376	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-NN-80-S-3-C3-C-21-GBA-42-42-24	SERIES 90	S90-042PV
80000377	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-AB-60-S-3-C7-D-01-GBA-35-35-24	SERIES 90	S90-075PV
80000378	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-S1-N-TA-C2-N-N-X1-ABA-054-AA-F0-00-30	SERIES 51	S51-080MV-1
80000379	PUMP-VAR-DISPL CW 90PV100	90R100-FD-5-BC-80-P-7-S1-E-B1-GLA-42-42-32	SERIES 90	S90-100PV
80000380	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-V-NN-8E-L-3-C7-F-03-GB1-42-42-28	SERIES 90	S90-100PV
80000381	MOTOR-VAR-DISPL 51MV110-1	51V110-1--A-C8-N-E1-B1-N-N-U1-NNN-065-AA-F3-00-00	SERIES 51	S51-110MV-1
80000382	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-NN-80-P-3-C8-F-03-GBA-35-35-24	SERIES 90	S90-130PV
80000383	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-E2-A5-A-N-G0-NNN-038-AA-G0-03-00	SERIES 51	S51-160MV

80000384	PUMP-VAR-DISPL CW 90PV180	90R180-MA-5-EF-80-T-M-C8-J-C7-NNN-32-32-24	SERIES 90	S90-180PV
80000385	PUMP-VAR-DISPL CW 90PV180	90R180-MA-5-CD-80-T-C-F1-J-C7-NNN-35-35-24	SERIES 90	S90-180PV
80000386	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-EG-80-S-3-C8-K-03-NNN-42-42-24	SERIES 90	S90-250PV
80000387	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-AB-80-S-3-C8-K-03-NNN-42-42-24	SERIES 90	S90-250PV
80000388	PUMP-VAR-DISPL CW 90PV180	90R180-MB-5-AB-80-S-C-C8-J-C5-NNN-42-42-24	SERIES 90	S90-180PV
80000389	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-AB-80-S-C-C8-J-03-NNN-42-42-24	SERIES 90	S90-180PV
80000390	PUMP-VAR-DISPL CW 90PV130	90R130-MB-5-AB-80-S-3-C8-H-C5-GBA-42-42-24	SERIES 90	S90-130PV
80000391	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-AB-80-S-3-F1-H-03-GBA-42-42-24	SERIES 90	S90-130PV
80000392	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-AB-80-S-3-C8-H-03-GBA-42-42-24	SERIES 90	S90-130PV
80000393	PUMP-VAR-DISPL CW 90PV100	90R100-MB-5-AB-80-S-3-C7-E-C5-GBA-42-42-24	SERIES 90	S90-100PV
80000394	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-AB-80-S-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
80000395	PUMP-VAR-DISPL CW 90PV075	90R075-MB-5-AB-80-S-3-C7-D-C5-GBA-42-42-24	SERIES 90	S90-075PV
80000396	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-NN-80-S-C-C8-J-03-NNN-38-38-32	SERIES 90	S90-180PV
80000397	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-AB-80-S-4-C7-D-03-GBA-42-42-24	SERIES 90	S90-075PV
80000398	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-AB-80-S-3-C7-D-03-GBA-42-42-24	SERIES 90	S90-075PV
80000399	PUMP-VAR-DISPL CW 90PV042	90R042-MB-5-AB-80-S-3-C3-C-C5-GBA-42-42-24	SERIES 90	S90-042PV
80000400	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-AB-80-S-3-C3-C-03-GBA-42-42-24	SERIES 90	S90-042PV
80000401	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-2-AB-80-S-4-C8-H-04-GBA-42-42-24	SERIES 90	S90-130PV
80000403	PUMP-VAR-DISPL CW 90PV130	90R130-FG-5-BB-80-L-7-C8-F-B2-GBA-16-16-24	SERIES 90	S90-130PV
80000405	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-BC-80-S-C-C8-H-05-NNN-38-38-24	SERIES 90	S90-180PV
80000406	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-BB-80-S-C-C8-H-03-NNN-42-42-24	SERIES 90	S90-180PV
80000408	PUMP-VAR-DISPL CCW 90PV042	90L042-KA-5-AB-80-P-3-C3-B-03-GBA-26-26-20	SERIES 90	S90-042PV
80000409	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-AB-60-P-3-C7-D-03-GBA-42-42-20	SERIES 90	S90-075PV
80000410	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-NN-80-R-3-F1-F-03-GBA-42-42-24	SERIES 90	S90-130PV
80000411	PUMP-VAR-DISPL CW 90PV075	90R075-MA-5-BC-80-S-4-C7-D-C5-GBA-35-35-24	SERIES 90	S90-075PV
80000412	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-NN-80-R-7-C7-E-09-FAZ-35-35-30	SERIES 90	S90-100PV
80000413	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-AB-60-S-3-C7-E-03-GBA-23-23-24	SERIES 90	S90-075PV
80000414	PUMP-VAR-DISPL CCW 90PV075	90L075-DD-5-CD-80-S-4-S1-E-G1-GBA-42-42-20	SERIES 90	S90-075PV
80000418	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-NN-80-L-3-F1-H-03-GBA-38-38-24	SERIES 90	S90-130PV
80000419	PUMP-VAR-DISPL CW 90PV250	90R250-KP-5-CD-80-T-3-C8-J-03-NNN-32-32-24	SERIES 90	S90-250PV
80000420	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-CD-80-P-3-C7-F-03-GBA-30-30-24	SERIES 90	S90-100PV
80000422	MOTOR-VAR-DISPL 51MD110-1	51D110-1--R-D4-N-T2-R5-N-N-X1-NNN-074-AA-F3-00-30	SERIES 51	S51-110MV-1
80000423	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-BC-80-R-4-C8-H-03-GDA-32-32-24	SERIES 90	S90-130PV
80000424	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-CD-80-R-3-F1-H-03-GBA-35-35-24	SERIES 90	S90-130PV
80000425	PUMP-VAR-DISPL CW 90PV250	90R250-MB-5-BC-80-T-3-F1-K-C5-NNN-35-35-24	SERIES 90	S90-250PV
80000426	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-BB-60-S-3-T2-E-03-GBA-26-26-24	SERIES 90	S90-100PV

80000427	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-CD-80-P-3-S1-F-03-GBA-30-30-24	SERIES 90	S90-100PV
80000428	MOTOR-VAR-DISPL 51MD110-1	51D110-1--A-D3-N-T2-CA-N-N-X1-NNN-031-AA-F3-00-28	SERIES 51	S51-110MV-1
80000432	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-EQ-A5-J-Y-A6-NNN-032-AA-F0-15-00	SERIES 51	S51-160MV
80000433	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-CD-80-S-3-TJ-E-03-EFC-42-42-28	SERIES 90	S90-075PV
80000435	PUMP-VAR-DISPL CW 90PV180	90R180-MB-5-NN-80-S-C-F1-H-C5-FAC-35-35-24	SERIES 90	S90-180PV
80000436	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D2-N-TH-C2-N-N-X1-NNN-046-AA-F0-00-17	SERIES 51	S51-080MV-1
80000443	PUMP-VAR-DISPL CW 90PV075	90R075-FM-P-BC-80-S-7-C7-E-B6-EFP-48-48-30	SERIES 90	S90-075PV
80000444	PUMP-VAR-DISPL CW 90PV075	90R075-FM-5-AB-60-P-7-C7-D-B6-EFP-40-40-30	SERIES 90	S90-075PV
80000446	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-N-EQ-A6-J-Y-A9-NNN-110-AA-F3-30-00	SERIES 51	S51-250MV
80000447	MOTOR-VAR-DISPL 51MD110-1	51D110-1--A-D4-N-P7-P7-N-N-X1-NNN-031-AA-F3-00-AA	SERIES 51	S51-110MV-1
80000448	PUMP-VAR-DISPL CW 90PV100	90R100-MA-5-BC-80-S-3-C7-E-C5-GBA-16-16-24	SERIES 90	S90-100PV
80000449	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-CD-80-S-4-F1-H-03-GBA-29-29-24	SERIES 90	S90-130PV
80000450	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-CD-80-S-3-C8-J-04-NNN-42-42-24	SERIES 90	S90-250PV
80000451	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-NN-80-S-3-C8-J-03-NNN-35-35-24	SERIES 90	S90-250PV
80000452	PUMP-VAR-DISPL CW 90PV042	90R042-MB-5-AB-80-S-4-C3-C-C5-GBA-42-42-24	SERIES 90	S90-042PV
80000453	PUMP-VAR-DISPL CW 90PV075	90R075-KN-5-CD-60-S-3-C7-D-03-GBA-42-42-24	SERIES 90	S90-075PV
80000454	PUMP-VAR-DISPL CW 90PV075	90R075-KN-5-NN-60-S-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
80000455	PUMP-VAR-DISPL CW 90PV075	90R075-KN-5-CD-60-S-3-C6-D-03-GBA-42-42-24	SERIES 90	S90-075PV
80000456	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-2-CD-80-S-3-C8-K-K3-NNN-26-26-24	SERIES 90	S90-250PV
80000457	PUMP-VAR-DISPL CW 90PV180	90R180-MA-5-BC-80-T-M-C8-H-C5-NNN-35-35-24	SERIES 90	S90-180PV
80000459	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-BB-80-S-3-C8-F-04-GBA-38-38-28	SERIES 90	S90-130PV
80000460	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-BB-80-S-C-C8-H-05-NNN-38-20-24	SERIES 90	S90-180PV
80000461	MOTOR-VAR-DISPL 51MD160	51D160-R-D4-N-T4-R5-L-N-L5-NNN-045-AA-F3-00-B9	SERIES 51	S51-160MV
80000462	MOTOR-VAR-DISPL 51MV060-1	51V060-1--R-S1-N-N1-NN-N-N-U1-ABA-016-AA-E4-00-00	SERIES 51	S51-060MV-1
80000463	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-T2-L5-N-N-X1-NNN-025-AA-F3-00-30	SERIES 51	S51-110MV-1
80000464	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-BC-80-S-3-F1-H-03-GBA-40-40-30	SERIES 90	S90-130PV
80000465	PUMP-VAR-DISPL CW 90PV250	90R250-MA-5-BC-80-T-3-C8-J-C5-NNN-35-35-24	SERIES 90	S90-250PV
80000467	PUMP-VAR-DISPL CCW 90PV130	90L130-HS-5-BC-80-S-4-C8-F-03-GBA-32-32-24	SERIES 90	S90-130PV
80000468	PUMP-VAR-DISPL CCW 90PV130	90L130-HS-5-CD-80-S-4-C8-F-03-GBA-32-32-24	SERIES 90	S90-130PV
80000469	PUMP-VAR-DISPL CW 90PV100	90R100-FD-5-AB-80-L-7-C7-E-B1-EAB-42-42-32	SERIES 90	S90-100PV
80000470	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-HZ-B1-B-H-G5-NNN-054-AA-NN-07-00	SERIES 51	S51-080MV
80000471	MOTOR-VAR-DISPL 51MC080-1	51C080-1--A-D3-N-N1-NN-N-N-U1-NNN-026-AA-NN-00-00	SERIES 51	S51-080MV-1
80000472	PUMP-VAR-DISPL CCW 90PV100	90L100-KP-5-NN-80-P-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
80000473	PUMP-VAR-DISPL CW 90PV075	90R075-FN-5-BB-80-P-7-C7-D-B6-GMD-42-42-32	SERIES 90	S90-075PV
80000474	PUMP-VAR-DISPL CW 90PV130	90R130-FH-5-DE-80-S-7-F1-F-B1-GLA-45-45-30	SERIES 90	S90-130PV
80000475	MOTOR-VAR-DISPL 51MC160	51C160-R-D4-N-HZ-B1-A-E-C2-NNN-032-AA-NN-03-00	SERIES 51	S51-160MV

80000476	PUMP-VAR-DISPL CCW 90PV130	90L130-DD-5-AB-80-S-4-C8-F-GB-GBA-42-42-24	SERIES 90	S90-130PV
80000477	MOTOR-VAR-DISPL 51MV160	51V160-R-F2-N-T2-C0-L-N-G0-NNN-045-AA-F0-00-B5	SERIES 51	S51-160MV
80000478	MOTOR-VAR-DISPL 51MV160	51V160-R-F2-N-T2-C0-L-N-G0-AHA-045-AA-F0-00-B5	SERIES 51	S51-160MV
80000479	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-5-BC-80-S-3-F1-K-00-NNN-35-14-30	SERIES 90	S90-250PV
80000480	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-BB-80-T-C-C8-H-04-FAC-42-42-24	SERIES 90	S90-180PV
80000482	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-S1-N-E2-B1-N-N-U1-NNN-043-AA-NN-00-00	SERIES 51	S51-080MV-1
80000483	PUMP-VAR-DISPL CW 90PV075	90R075-FN-5-BB-80-S-7-C7-D-B6-ELB-45-45-32	SERIES 90	S90-075PV
80000484	PUMP-VAR-DISPL CCW 90PV100	90L100-HF-5-NN-80-S-4-S1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
80000485	MOTOR-VAR-DISPL 51MD160	51D160-A-D5-N-HS-A2-C-H-E1-NNN-032-AA-NN-15-30	SERIES 51	S51-160MV
80000486	PUMP-VAR-DISPL CCW 90PV130	90L130-FG-5-NN-80-L-7-C8-F-B1-GCA-42-42-24	SERIES 90	S90-130PV
80000487	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-BB-80-S-M-C8-J-05-NNN-42-42-24	SERIES 90	S90-180PV
80000488	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-NN-60-P-3-C7-E-02-GBA-14-14-24	SERIES 90	S90-100PV
80000489	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-CD-80-S-3-T2-E-03-GBA-42-42-24	SERIES 90	S90-100PV
80000490	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-C8-N-E1-B1-N-N-U1-DBA-044-AA-F3-00-00	SERIES 51	S51-110MV-1
80000491	PUMP-VAR-DISPL CCW 90PV042	90L042-PB-5-BC-80-R-4-C3-B-02-GBA-35-35-24-F008	SERIES 90	S90-042PV
80000492	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-N-N1-NN-N-N-U1-ABA-015-AA-E4-00-00	SERIES 51	S51-060MV-1
80000496	PUMP-VAR-DISPL CW 90PV075	90R075-FK-5-NN-60-S-7-C7-E-B6-EEH-42-42-30	SERIES 90	S90-075PV
80000497	PUMP-VAR-DISPL CW 90PV180	90R180-MA-5-EG-80-S-M-C8-J-C5-NNN-23-23-24	SERIES 90	S90-180PV
80000498	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-D-N2-NN-N-N-A0-NNN-050-AA-F3-00-00	SERIES 51	S51-250MV
80000499	PUMP-VAR-DISPL CW 90PV075	90R075-HF-5-NN-80-S-3-C6-D-03-GBA-20-20-24	SERIES 90	S90-075PV
80000500	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-NN-80-R-4-C3-B-03-GBA-42-42-24	SERIES 90	S90-042PV
80000501	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-BB-80-S-3-C8-H-03-EFI-42-42-24	SERIES 90	S90-130PV
80000502	PUMP-VAR-DISPL CW 90PV180	90R180-MA-5-AB-80-S-M-C8-J-C5-NNN-23-23-24	SERIES 90	S90-180PV
80000503	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-CD-80-S-3-C8-K-02-NNN-42-42-24	SERIES 90	S90-250PV
80000504	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-HS-A2-B-H-E1-NNN-080-AA-NN-10-18	SERIES 51	S51-160MV
80000505	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-HS-A2-B-H-C1-NNN-058-AA-NN-10-13	SERIES 51	S51-160MV
80000506	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-TA-C2-L-N-G0-NNN-080-AA-H0-00-B1	SERIES 51	S51-160MV
80000507	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-C7-N-E2-B1-N-N-U1-ABA-016-AA-E6-00-00	SERIES 51	S51-080MV-1
80000508	PUMP-VAR-DISPL CCW 90PV130	90L130-DD-5-AB-80-S-3-C8-F-GB-GBA-42-42-24	SERIES 90	S90-130PV
80000509	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-NN-80-S-3-C8-F-03-GBA-42-42-24	SERIES 90	S90-130PV
80000510	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-NN-80-S-3-C8-H-03-GBA-30-30-24	SERIES 90	S90-130PV
80000511	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-L2-B1-V-A-J1-NNN-067-AA-G3-B2-00	SERIES 51	S51-160MV
80000512	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-AB-60-S-4-C6-D-03-GBA-42-42-20-F052	SERIES 90	S90-075PV
80000513	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-TH-C2-L-N-G0-NNN-050-AA-F3-00-B2	SERIES 51	S51-160MV
80000514	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-BB-60-S-3-C7-F-04-GBA-35-35-24	SERIES 90	S90-100PV
80000515	PUMP-VAR-DISPL CW 90PV100	90R100-FD-5-NN-60-P-7-S1-F-B1-GLA-42-42-28	SERIES 90	S90-100PV

80000516	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-BB-80-T-3-C8-K-03-NNN-30-30-24	SERIES 90	S90-250PV
80000518	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-AB-80-R-4-C8-H-03-GBA-35-35-24	SERIES 90	S90-130PV
80000519	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-T2-C2-L-N-K7-NNN-110-AA-G0-00-B5	SERIES 51	S51-250MV
80000520	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-BC-60-S-3-C6-D-04-GBA-23-23-20	SERIES 90	S90-075PV
80000521	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-T1-C2-L-N-G0-NNN-085-AA-G0-00-A8	SERIES 51	S51-160MV
80000522	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-BB-80-R-3-S1-D-03-GBA-17-17-20	SERIES 90	S90-075PV
80000523	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-CD-80-R-3-S1-D-03-GBA-17-17-20	SERIES 90	S90-075PV
80000524	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-BC-80-L-3-F1-H-03-GBA-38-38-24	SERIES 90	S90-130PV
80000525	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-AB-60-S-3-C7-D-03-GBA-42-42-24	SERIES 90	S90-100PV
80000526	PUMP-VAR-DISPL CW 90PV075	90R075-MA-5-NN-60-S-3-C6-D-C5-GBA-35-35-24	SERIES 90	S90-075PV
80000527	PUMP-VAR-DISPL CW 90PV100	90R100-MA-5-NN-60-S-3-C7-E-C5-GBA-35-35-24	SERIES 90	S90-100PV
80000528	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-BC-80-S-3-C7-E-03-GBA-26-26-24	SERIES 90	S90-100PV
80000529	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-T1-L5-L-N-G0-NNN-064-AA-F3-00-B5	SERIES 51	S51-160MV
80000532	MOTOR-VAR-DISPL 51MC080-1	51C080-1--A-D3-N-T7-L5-N-N-X1-NNN-054-AA-F3-00-24	SERIES 51	S51-080MV-1
80000533	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-NN-80-P-3-C7-F-03-GBA-32-32-24	SERIES 90	S90-100PV
80000534	PUMP-VAR-DISPL CW 90PV100	90R100-FD-5-AB-60-L-7-C7-E-B1-EAB-42-42-32	SERIES 90	S90-100PV
80000535	PUMP-VAR-DISPL CCW 90PV250	90L250-KP-5-NN-80-T-4-F1-K-05-NNN-35-35-24	SERIES 90	S90-250PV
80000536	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-CD-80-T-3-C8-K-03-NNN-38-38-24	SERIES 90	S90-250PV
80000537	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-D7-M1-S-K-M1-ACA-118-AA-NN-F4-26	SERIES 51	S51-250MV
80000539	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-T2-C0-L-N-G0-NNN-075-AA-G0-00-C1	SERIES 51	S51-160MV
80000540	PUMP-VAR-DISPL CW 90PV130	90R130-DD-2-BC-80-S-7-C8-F-G1-GCA-29-29-30	SERIES 90	S90-130PV
80000541	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-S1-N-E1-B1-N-N-U1-ABA-032-AA-F0-00-00	SERIES 51	S51-080MV-1
80000542	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-T1-R5-L-N-G0-NNN-060-AA-F3-00-C4	SERIES 51	S51-160MV
80000544	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-HZ-B1-A-N-G0-NNN-040-AA-NN-03-00	SERIES 51	S51-160MV
80000545	PUMP-VAR-DISPL CW 90PV130	90R130-KN-5-NN-80-S-3-C8-H-03-GBA-26-26-24	SERIES 90	S90-130PV
80000546	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-NN-60-S-3-C7-E-03-GBA-26-26-24	SERIES 90	S90-100PV
80000547	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-V-BB-8E-P-3-C7-E-02-GB1-42-42-24	SERIES 90	S90-100PV
80000548	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-L2-B1-V-A-G5-ACB-079-AA-F3-B2-00	SERIES 51	S51-160MV
80000549	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-S1-N-N1-NN-N-N-U1-NNN-040-AA-F0-00-00	SERIES 51	S51-080MV-1
80000551	MOTOR-VAR-DISPL 51MD160	51D160-A-D4-N-D8-M1-R-J-M1-NNN-037-AA-F0-C2-37	SERIES 51	S51-160MV
80000552	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-HZ-B1-B-H-G5-NNN-032-AA-F3-05-00	SERIES 51	S51-160MV
80000553	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-E1-A5-A-N-G0-NNN-093-AA-F0-03-00	SERIES 51	S51-160MV
80000554	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-CD-60-S-3-C7-D-03-GBA-29-29-28	SERIES 90	S90-100PV
80000556	MOTOR-VAR-DISPL 51MD110-1	51D110-1--A-D3-N-T7-D7-N-N-X1-NNN-040-AA-E6-00-27	SERIES 51	S51-110MV-1
80000557	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-NN-80-S-3-S1-E-03-FAP-20-20-24	SERIES 90	S90-075PV
80000559	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-NN-80-S-4-C3-C-03-GBA-29-23-24	SERIES 90	S90-042PV

80000560	PUMP-VAR-DISPL CW 90PV100	90R100-FC-5-NN-80-P-7-C7-F-B1-EAB-42-42-30	SERIES 90	S90-100PV
80000561	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-NN-80-R-3-C8-H-03-GBA-30-30-24	SERIES 90	S90-130PV
80000562	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-NN-80-S-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-075PV
80000563	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-N-T1-C0-L-N-L4-NNN-065-AA-E6-00-C2	SERIES 51	S51-160MV
80000564	PUMP-VAR-DISPL CW 90PV075	90R075-DD-5-BC-80-S-4-S1-E-G8-FAD-35-35-24	SERIES 90	S90-075PV
80000565	PUMP-VAR-DISPL CW 90PV180	90R180-CA-2-NN-80-S-C-C8-H-00-FAC-38-38-24	SERIES 90	S90-180PV
80000567	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-T2-C0-L-N-L4-NNN-050-AA-E6-00-C2	SERIES 51	S51-250MV
80000573	PUMP-VAR-DISPL CW 90PV075	90R075-FK-5-BC-60-R-B-S1-D-B6-GME-29-29-24	SERIES 90	S90-075PV
80000574	PUMP-VAR-DISPL CW 90PV250	90R250-PB-5-DE-80-T-3-C8-J-04-NNN-42-42-28	SERIES 90	S90-250PV
80000576	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-BC-80-L-3-F1-H-03-GBA-42-42-24	SERIES 90	S90-130PV
80000577	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-NN-80-S-3-F1-F-03-GBA-29-29-24	SERIES 90	S90-130PV
80000583	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-NN-80-L-3-C8-H-03-GBA-29-29-24	SERIES 90	S90-130PV
80000585	PUMP-VAR-DISPL CCW 90PV075	90L075-DD-5-NN-80-S-4-S1-D-GB-GBA-35-35-24	SERIES 90	S90-075PV
80000586	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-CD-60-P-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
80000587	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-NN-60-P-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
80000588	PUMP-VAR-DISPL CCW 90PV250	90L250-HF-5-NN-80-T-4-F1-K-03-NNN-14-42-20	SERIES 90	S90-250PV
80000589	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-NN-80-S-3-F1-F-03-EBA-35-35-24	SERIES 90	S90-130PV
80000590	PUMP-VAR-DISPL CCW 90PV075	90L075-MA-5-BB-60-R-3-C7-D-C5-FAC-42-42-24	SERIES 90	S90-075PV
80000591	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-B-E2-R2-A-N-E3-NNN-035-AA-F3-03-25	SERIES 51	S51-160MV
80000592	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-2-BC-80-R-3-F1-H-00-GBA-42-42-24	SERIES 90	S90-130PV
80000593	PUMP-VAR-DISPL CW 90PV130	90R130-MA-5-BC-80-R-3-C8-H-C6-GBA-45-45-32	SERIES 90	S90-130PV
80000594	PUMP-VAR-DISPL CCW 90PV130	90L130-HF-5-NN-80-S-3-F1-F-03-GBA-45-45-24	SERIES 90	S90-130PV
80000595	PUMP-VAR-DISPL CW 90PV250	90R250-MB-5-CD-80-T-3-F1-J-C5-NNN-38-38-24	SERIES 90	S90-250PV
80000596	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-NN-80-T-C-C8-J-09-NNN-35-35-28	SERIES 90	S90-180PV
80000597	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-NN-80-S-3-C8-K-00-EFI-42-42-24	SERIES 90	S90-250PV
80000598	PUMP-VAR-DISPL CW 90PV075	90R075-HF-5-NN-60-S-4-C7-D-03-GBA-45-45-26	SERIES 90	S90-075PV
80000599	MOTOR-VAR-DISPL 51MD080-1	51D080-1--A-D3-N-T7-L5-N-N-X1-NNN-054-AA-F3-00-24	SERIES 51	S51-080MV-1
80000601	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-NN-80-S-3-S1-E-03-GBA-45-45-24	SERIES 90	S90-075PV
80000602	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-BB-80-S-4-C7-F-03-GBA-26-26-20	SERIES 90	S90-100PV
80000603	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-DE-80-L-3-F1-H-03-GBA-35-35-24	SERIES 90	S90-130PV
80000605	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-CD-80-S-3-C8-H-03-GBA-26-26-24	SERIES 90	S90-130PV
80000606	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-E2-B1-N-N-U1-NNN-055-AA-E6-00-00	SERIES 51	S51-110MV-1
80000607	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-HZ-B1-B-H-C2-NNN-080-AA-G3-05-00	SERIES 51	S51-250MV
80000608	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-5-AB-80-T-3-F1-K-03-NNN-42-42-24	SERIES 90	S90-250PV
80000609	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-EQ-A3-J-Y-E5-NNN-054-AA-F3-30-35	SERIES 51	S51-160MV
80000610	PUMP-VAR-DISPL CW 90PV075	90R075-FN-P-NN-80-D-D-S1-N-B6-GME-48-48-30	SERIES 90	S90-075PV

80000611	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-L2-B1-V-A-C0-ADA-150-AA-F0-B2-00	SERIES 51	S51-250MV
80000612	PUMP-VAR-DISPL CCW 90PV130	90L130-MA-5-BC-80-L-3-C8-H-C5-GBA-42-42-24	SERIES 90	S90-130PV
80000613	PUMP-VAR-DISPL CW 90PV250	90R250-KN-5-CD-80-S-3-C8-K-03-NNN-26-26-24	SERIES 90	S90-250PV
80000615	PUMP-VAR-DISPL CW 90PV250	90R250-KN-5-BC-80-T-3-C8-K-03-NNN-35-35-24	SERIES 90	S90-250PV
80000616	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-P-BB-60-S-3-C7-E-03-GBA-48-48-24	SERIES 90	S90-100PV
80000617	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-CD-80-R-3-F1-F-03-GBA-38-38-24	SERIES 90	S90-130PV
80000618	PUMP-VAR-DISPL CCW 90PV100	90L100-KP-5-CD-80-R-3-F1-E-03-GBA-38-38-24	SERIES 90	S90-100PV
80000620	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-EQ-A5-K-Y-G5-ACD-067-AA-F3-50-00	SERIES 51	S51-160MV
80000621	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-EQ-A5-K-Y-G5-ABA-038-AA-F3-50-00	SERIES 51	S51-080MV
80000622	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-N-E1-A5-A-N-G0-ACA-058-AA-G0-03-00	SERIES 51	S51-160MV
80000623	PUMP-VAR-DISPL CW 90PV250	90R250-MA-5-NN-80-S-4-F1-J-C6-NNN-36-36-24	SERIES 90	S90-250PV
80000632	PUMP-VAR-DISPL CW 90PV042	90R042-MA-5-BB-80-R-4-C3-C-C5-GBA-42-42-24	SERIES 90	S90-042PV
80000633	PUMP-VAR-DISPL CW 90PV042	90R042-MA-5-AB-80-R-4-C3-C-C5-GBA-42-42-24	SERIES 90	S90-042PV
80000634	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-E2-A5-A-N-G0-NNN-160-AA-H0-03-00	SERIES 51	S51-250MV
80000635	PUMP-VAR-DISPL CW 90PV250	90R250-MA-5-EG-80-S-4-C8-J-C5-NNN-36-36-24	SERIES 90	S90-250PV
80000636	PUMP-VAR-DISPL CW 90PV250	90R250-KP-5-NN-80-S-4-F1-K-05-NNN-36-36-24	SERIES 90	S90-250PV
80000642	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-BC-80-S-C-C8-J-04-NNN-42-42-24	SERIES 90	S90-180PV
80000643	MOTOR-VAR-DISPL 51MV160	51V160-R-F2-N-D8-M1-R-J-M4-NNN-050-AA-G3-C2-16	SERIES 51	S51-160MV
80000644	PUMP-VAR-DISPL CW 90PV250	90R250-KP-5-DE-80-S-3-C8-J-03-NNN-42-42-24	SERIES 90	S90-250PV
80000645	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-AB-60-S-3-C6-D-04-GBA-42-42-20	SERIES 90	S90-075PV
80000647	MOTOR-VAR-DISPL 51MD080	51D080-A-D2-N-HS-A3-C-E-E5-NNN-045-AA-F0-12-23	SERIES 51	S51-080MV
80000648	PUMP-VAR-DISPL CW 90PV075	90R075-MA-2-CD-60-S-4-C7-D-C5-GBA-38-38-24	SERIES 90	S90-075PV
80000652	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-S1-N-TA-C2-N-N-X1-NNN-034-AA-NN-00-17	SERIES 51	S51-080MV-1
80000653	PUMP-VAR-DISPL CW 90PV250	90R250-HF-5-NN-80-S-4-C8-J-03-NNN-36-36-24	SERIES 90	S90-250PV
80000654	MOTOR-VAR-DISPL 51MD110	51D110-A-D3-N-D7-M1-S-K-M4-ADA-040-AA-E6-F4-28	SERIES 51	S51-110MV
80000656	PUMP-VAR-DISPL CW 90PV250	90R250-PB-5-DE-80-T-3-F1-K-00-NNN-29-14-24	SERIES 90	S90-250PV
80000657	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-BC-80-S-3-C8-K-03-NNN-42-42-24	SERIES 90	S90-250PV
80000662	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-BC-80-S-3-C7-F-03-GBA-26-26-24	SERIES 90	S90-100PV
80000663	PUMP-VAR-DISPL CW 90PV075	90R075-KA-P-CD-80-S-3-C7-D-03-GBA-48-48-24	SERIES 90	S90-075PV
80000664	MOTOR-VAR-DISPL 51MV080	51V080-A-S1-N-HZ-B1-C-H-C2-NNN-016-AA-F0-20-00	SERIES 51	S51-080MV
80000665	PUMP-VAR-DISPL CCW 90PV100	90L100-HF-5-AB-80-S-4-S1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
80000666	PUMP-VAR-DISPL CW 90PV100	90R100-HF-5-CD-60-S-3-S1-F-03-GBA-38-38-24	SERIES 90	S90-100PV
80000667	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-NN-80-T-M-F1-H-03-FAC-23-23-24	SERIES 90	S90-180PV
80000668	MOTOR-VAR-DISPL 51MD080-1	51D080-1--A-D3-N-T1-CA-N-N-X1-NNN-028-AA-F0-00-23	SERIES 51	S51-080MV-1
80000669	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-BC-80-R-3-C8-H-06-GBA-45-45-32	SERIES 90	S90-130PV
80000670	MOTOR-VAR-DISPL 51MV110	51V110-R-F1-N-D8-M1-R-J-M4-ACA-033-AA-E6-C2-25	SERIES 51	S51-110MV

80000671	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-BC-80-S-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-100PV
80000672	PUMP-VAR-DISPL CCW 90PV250	90L250-HF-5-BC-80-T-4-F1-K-03-NNN-14-42-20	SERIES 90	S90-250PV
80000673	PUMP-VAR-DISPL CW 90PV250	90R250-KP-5-AB-80-T-4-C8-K-00-NNN-38-38-24	SERIES 90	S90-250PV
80000674	MOTOR-VAR-DISPL 51MD060-1	51D060-1--A-D2-N-P7-P7-N-N-X1-NNN-021-AA-E6-00-AA	SERIES 51	S51-060MV-1
80000675	MOTOR-VAR-DISPL 51MV110	51V110-A-C8-N-D7-M1-S-K-M4-ADA-025-AA-F3-F4-28	SERIES 51	S51-110MV
80000676	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-BC-80-L-4-C8-H-03-GBA-36-36-24	SERIES 90	S90-130PV
80000677	PUMP-VAR-DISPL CW 90PV250	90R250-CB-5-CD-80-T-4-C8-K-00-NNN-38-38-24	SERIES 90	S90-250PV
80000678	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-DE-80-L-3-F1-H-03-EBA-35-35-24	SERIES 90	S90-130PV
80000679	PUMP-VAR-DISPL CW 90PV180	90R180-KN-5-CD-80-D-M-F1-L-05-FAC-35-35-28	SERIES 90	S90-180PV
80000682	PUMP-VAR-DISPL CW 90PV180	90R180-HF-5-CD-80-T-M-F1-H-03-NNN-35-35-30	SERIES 90	S90-180PV
80000683	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-E2-A5-A-N-G0-NNN-085-AA-F0-03-00	SERIES 51	S51-160MV
80000684	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-D7-M1-S-K-M4-NNN-043-AA-F3-F4-34	SERIES 51	S51-160MV
80000685	PUMP-VAR-DISPL CW 90PV250	90R250-KP-5-DE-80-T-3-C8-J-03-NNN-42-42-24	SERIES 90	S90-250PV
80000686	MOTOR-VAR-DISPL 51MD110-1	51D110-1--A-D4-N-T1-CA-N-N-X1-NNN-032-AA-F0-00-20	SERIES 51	S51-110MV-1
80000687	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-CD-80-L-4-S1-E-04-GBA-30-30-24	SERIES 90	S90-075PV
80000688	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-CD-80-S-3-C7-D-03-GBA-42-42-24	SERIES 90	S90-100PV
80000692	PUMP-VAR-DISPL CCW 90PV130	90L130-KN-5-CD-80-R-3-F1-H-03-GBA-35-35-24	SERIES 90	S90-130PV
80000693	PUMP-VAR-DISPL CCW 90PV180	90L180-KN-5-NN-80-T-C-F1-J-03-FAC-42-42-24	SERIES 90	S90-180PV
80000694	PUMP-VAR-DISPL CCW 90PV100	90L100-DD-5-NN-80-L-4-S1-E-G4-GBA-35-35-24	SERIES 90	S90-100PV
80000695	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-D7-M1-S-K-N2-ABA-030-AA-E4-F4-31	SERIES 51	S51-080MV
80000696	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-S1-N-T2-CA-N-N-X1-NNN-032-AA-F3-00-28	SERIES 51	S51-080MV-1
80000697	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-NN-80-S-4-C7-E-03-GBA-42-42-30	SERIES 90	S90-075PV
80000698	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-HZ-B1-B-E-C2-NNN-054-AA-G0-10-00	SERIES 51	S51-080MV
80000699	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-TA-C2-L-N-K7-NNN-125-AA-G0-00-A4	SERIES 51	S51-250MV
80000700	PUMP-VAR-DISPL CW 90PV100	90R100-FA-5-NN-60-R-7-F1-E-B1-EFI-35-35-24	SERIES 90	S90-100PV
80000701	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-L1-B2-W-B-H7-ANA-032-AA-F0-D4-00	SERIES 51	S51-080MV
80000702	MOTOR-VAR-DISPL 51MV110-1	51V110-1--A-F1-N-T1-C2-N-N-X1-ADA-055-AA-F0-00-36	SERIES 51	S51-110MV-1
80000703	MOTOR-VAR-DISPL 51MV110-1	51V110-1--A-F1-N-T1-C2-N-N-X1-ADA-022-AA-F0-00-36	SERIES 51	S51-110MV-1
80000712	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-T1-D1-N-N-X1-ABA-038-AA-E6-00-18	SERIES 51	S51-110MV-1
80000713	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-NN-60-S-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
80000715	PUMP-VAR-DISPL CW 90PV075	90R075-FG-5-CD-80-S-7-C6-D-B1-GLA-38-38-30	SERIES 90	S90-075PV
80000723	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-NN-60-S-3-C6-D-03-GBA-42-42-24	SERIES 90	S90-075PV
80000732	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-BC-80-L-3-F1-H-03-EBA-35-35-24	SERIES 90	S90-130PV
80000733	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-NN-80-R-3-C7-D-03-GBA-42-42-24	SERIES 90	S90-075PV
80000734	MOTOR-VAR-DISPL 51MC080	51C080-R-D2-N-L2-B1-V-A-G5-ACB-017-AA-E6-B2-00	SERIES 51	S51-080MV
80000742	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-C8-N-T2-CA-N-N-X1-NNN-065-AA-F3-00-23	SERIES 51	S51-110MV-1

80000743	PUMP-VAR-DISPL CW 90PV075	90R075-FK-5-CD-80-P-7-S1-E-B6-GME-45-45-30	SERIES 90	S90-075PV
80000744	PUMP-VAR-DISPL CW 90PV075	90R075-FK-5-BB-80-P-7-S1-E-B6-GME-45-45-30	SERIES 90	S90-075PV
80000745	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D2-N-N1-NN-N-N-U1-NNN-040-AA-F0-00-00	SERIES 51	S51-080MV-1
80000746	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-CD-60-S-3-C7-E-03-GBA-35-35-28	SERIES 90	S90-100PV
80000747	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-AB-60-S-3-S1-E-03-GBA-35-35-28	SERIES 90	S90-100PV
80000748	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-CD-80-R-3-C8-H-00-GBA-35-14-24	SERIES 90	S90-130PV
80000749	PUMP-VAR-DISPL CW 90PV075	90R075-DD-5-NN-80-S-3-C7-E-GB-GBA-42-42-24	SERIES 90	S90-075PV
80000750	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-L2-B1-V-A-C0-ADA-150-AA-F0-B2-00	SERIES 51	S51-250MV
80000751	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-2-NN-80-T-3-F1-J-03-NNN-42-42-24	SERIES 90	S90-250PV
80000752	PUMP-VAR-DISPL CCW 90PV075	90L075-DD-5-NN-80-L-7-C7-D-82-GCB-35-35-30	SERIES 90	S90-075PV
80000754	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-AB-80-T-C-C8-J-00-NNN-32-32-24	SERIES 90	S90-180PV
80000755	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D2-N-N1-NN-N-N-U1-NNN-030-AA-F0-00-00	SERIES 51	S51-080MV-1
80000756	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-CD-80-S-4-C7-D-03-GBA-42-42-24-F003	SERIES 90	S90-075PV
80000757	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-BB-80-S-4-C3-B-03-GBA-42-42-24-F008	SERIES 90	S90-042PV
80000758	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-NN-80-S-4-C3-B-03-GBA-42-42-24-F008	SERIES 90	S90-042PV
80000759	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-EF-80-S-3-C8-K-03-GLA-35-35-30	SERIES 90	S90-250PV
80000760	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-EG-80-S-3-C8-K-03-EFI-35-35-30	SERIES 90	S90-250PV
80000762	PUMP-VAR-DISPL CCW 90PV075	90L075-FN-5-NN-60-P-7-C7-D-B6-EFP-45-45-30	SERIES 90	S90-075PV
80000763	MOTOR-VAR-DISPL 51MD160	51D160-R-D5-N-E2-A1-A-N-E2-NNN-104-AA-F3-03-26	SERIES 51	S51-160MV
80000764	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-F2-A5-A-N-G0-ACA-060-AA-F3-03-00	SERIES 51	S51-160MV
80000765	MOTOR-VAR-DISPL 51MD060	51D060-R-D2-N-HS-A7-B-N-E1-CCA-020-AA-NN-08-16	SERIES 51	S51-060MV
80000774	PUMP-VAR-DISPL CW 90PV100	90R100-MA-5-BC-60-S-3-C7-E-C6-GBA-45-45-24	SERIES 90	S90-100PV
80000775	PUMP-VAR-DISPL CCW 90PV075	90L075-HF-5-NN-80-P-3-C7-D-03-GBA-35-35-24	SERIES 90	S90-075PV
80000776	PUMP-VAR-DISPL CCW 90PV130	90L130-HF-5-CD-80-S-7-F1-F-01-GBA-30-30-24	SERIES 90	S90-130PV
80000777	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-BC-80-S-3-C7-E-03-GBA-26-26-24	SERIES 90	S90-100PV
80000778	PUMP-VAR-DISPL CW 90PV130	90R130-MA-5-AB-80-L-3-C8-H-C6-GBA-26-26-24	SERIES 90	S90-130PV
80000779	PUMP-VAR-DISPL CW 90PV180	90R180-MA-5-BC-80-S-C-C8-H-C6-NNN-42-42-24	SERIES 90	S90-180PV
80000782	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-BC-80-S-3-C8-H-04-GBA-45-45-24	SERIES 90	S90-130PV
80000792	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-T1-C2-N-N-X1-NNN-050-AA-F0-00-25	SERIES 51	S51-110MV-1
80000793	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-BC-80-L-3-F1-H-03-GBA-35-35-24	SERIES 90	S90-130PV
80000794	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-E2-A2-A-N-E1-NNN-050-AA-G3-03-26	SERIES 51	S51-250MV
80000795	MOTOR-VAR-DISPL 51MC060-1 BASE MODEL	51C060-1--A-D1-N-N1-NN-N-N-U1-ABA-012-AA-E6-00-00-P000	SERIES 51	S51-060MV-1
80000796	MOTOR-VAR-DISPL 51MC080 BASE MODEL	51C080-R-D2-N-N2-NN-N-N-A0-ABA-016-AA-F0-00-00-P000	SERIES 51	S51-080MV
80000797	MOTOR-VAR-DISPL 51MC080 BASE MODEL	51C080-R-D3-N-N2-NN-N-N-A0-ABA-016-AA-F0-00-00-P000	SERIES 51	S51-080MV
80000798	MOTOR-VAR-DISPL 51MC060-1 BASE MODEL	51C060-1--R-D1-N-N1-NN-N-N-U1-ABA-012-AA-E6-00-00-P000	SERIES 51	S51-060MV-1
80000799	MOTOR-VAR-DISPL 51MC080-1 BASE MODEL	51C080-1--R-D2-N-N1-NN-N-N-U1-ABA-016-AA-E6-00-00-P000	SERIES 51	S51-080MV-1

80000800	MOTOR-VAR-DISPL 51MC080-1 BASE MODEL	51C080-1--R-D3-N-N1-NN-N-N-U1-ABA-016-AA-E6-00-00-P000	SERIES 51	S51-080MV-1
80000801	MOTOR-VAR-DISPL 51MV060-1 BASE MODEL	51V060-1--A-S1-N-N1-NN-N-N-U1-ABA-012-AA-E4-00-00-P000	SERIES 51	S51-060MV-1
80000802	MOTOR-VAR-DISPL 51MV060-1 BASE MODEL	51V060-1--R-S1-N-N1-NN-N-N-U1-ABA-012-AA-E4-00-00-P000	SERIES 51	S51-060MV-1
80000803	MOTOR-VAR-DISPL 51MV080-1 BASE MODEL	51V080-1--A-S1-N-N1-NN-N-N-U1-ABA-016-AA-F0-00-00-P000	SERIES 51	S51-080MV-1
80000804	PUMP-VAR-DISPL CW 90PV075	90R075-FN-P-CD-80-P-7-C6-D-B6-GME-48-48-30	SERIES 90	S90-075PV
80000805	MOTOR-VAR-DISPL 51MV080-1 BASE MODEL	51V080-1--R-S1-N-N1-NN-N-N-U1-ABA-016-AA-F0-00-00-P000	SERIES 51	S51-080MV-1
80000806	MOTOR-VAR-DISPL 51MV110-1 BASE MODEL	51V110-1--A-F1-N-N1-NN-N-N-U1-ABA-022-AA-F0-00-00-P000	SERIES 51	S51-110MV-1
80000807	MOTOR-VAR-DISPL 51MV110-1 BASE MODEL	51V110-1--R-F1-N-N1-NN-N-N-U1-ABA-022-AA-F0-00-00-P000	SERIES 51	S51-110MV-1
80000808	MOTOR-VAR-DISPL 51MV080 BASE MODEL	51V080-A-S1-N-N2-NN-N-N-A0-ABA-016-AA-NN-00-00-P000	SERIES 51	S51-080MV
80000809	MOTOR-VAR-DISPL 51MV080 BASE MODEL	51V080-R-S1-N-N2-NN-N-N-A0-ABA-016-AA-NN-00-00-P000	SERIES 51	S51-080MV
80000810	MOTOR-VAR-DISPL 51MD110-1	51D110-1--A-D3-N-T1-CA-N-N-X1-ADA-039-AA-F0-00-27	SERIES 51	S51-110MV-1
80000811	MOTOR-VAR-DISPL 51MV110 BASE MODEL	51V110-A-F1-N-N2-NN-N-N-A0-ABA-022-AA-F3-00-00-P000	SERIES 51	S51-110MV
80000812	MOTOR-VAR-DISPL 51MV110 BASE MODEL	51V110-R-F1-N-N2-NN-N-N-A0-ABA-022-AA-F3-00-00-P000	SERIES 51	S51-110MV
80000813	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-N-L2-B1-V-A-C0-NNN-044-AA-G0-B2-00	SERIES 51	S51-160MV
80000814	MOTOR-VAR-DISPL 51MV160 BASE MODEL	51V160-A-F1-N-N2-NN-N-N-A0-ABA-032-AA-G0-00-00-P000	SERIES 51	S51-160MV
80000815	MOTOR-VAR-DISPL 51MV160 BASE MODEL	51V160-R-F1-N-N2-NN-N-N-A0-ABA-032-AA-G0-00-00-P000	SERIES 51	S51-160MV
80000816	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-HZ-B1-A-E-G0-NNN-060-AA-F0-03-00	SERIES 51	S51-160MV
80000817	MOTOR-VAR-DISPL 51MV250 BASE MODEL	51V250-A-F2-N-N2-NN-N-N-A0-ABA-050-AA-G3-00-00-P000	SERIES 51	S51-250MV
80000818	MOTOR-VAR-DISPL 51MV250 BASE MODEL	51V250-R-F2-N-N2-NN-N-N-A0-ABA-050-AA-G3-00-00-P000	SERIES 51	S51-250MV
80000819	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D2-N-N1-NN-N-N-U1-NNN-033-AA-E6-00-00	SERIES 51	S51-080MV-1
80000820	PUMP-VAR-DISPL CCW 90PV130	90L130-MA-5-CD-80-L-3-F1-H-C7-GBA-45-45-24	SERIES 90	S90-130PV
80000821	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-BC-80-P-3-F1-F-03-GBA-45-45-24	SERIES 90	S90-130PV
80000822	PUMP-VAR-DISPL CW 90PV250	90R250-MA-5-EF-80-S-3-C8-J-C6-NNN-38-38-24	SERIES 90	S90-250PV
80000824	PUMP-VAR-DISPL CCW 90PV250	90L250-KN-5-BC-80-S-3-F1-K-03-NNN-32-32-24	SERIES 90	S90-250PV
80000832	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-AB-60-S-3-C7-E-00-GBA-35-35-20	SERIES 90	S90-100PV
80000833	PUMP-VAR-DISPL CCW 90PV250	90L250-KN-5-EF-80-S-3-C8-K-03-NNN-32-32-24	SERIES 90	S90-250PV
80000835	PUMP-VAR-DISPL CW 90PV250	90R250-DD-2-NN-80-S-3-C8-K-GB-NNN-40-40-24	SERIES 90	S90-250PV
80000836	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-NN-80-P-3-C7-D-03-GBA-30-30-24	SERIES 90	S90-075PV
80000837	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-NN-80-T-C-C8-H-03-NNN-26-26-24	SERIES 90	S90-180PV
80000839	MOTOR-VAR-DISPL 51MV080	51V080-R-C7-N-J1-K4-B-H-J6-ADA-016-AA-E6-10-35	SERIES 51	S51-080MV
80000840	PUMP-VAR-DISPL CW 90PV100	90R100-DC-2-NN-80-R-3-C7-F-GB-GBA-26-26-24	SERIES 90	S90-100PV
80000841	PUMP-VAR-DISPL CCW 90PV180	90L180-KP-5-AB-80-T-C-C8-J-03-FAC-35-35-24	SERIES 90	S90-180PV
80000844	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-BC-80-S-3-S1-F-05-FAP-35-35-24	SERIES 90	S90-100PV
80000845	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-DE-80-P-3-F1-F-03-GBA-32-32-24	SERIES 90	S90-130PV
80000846	PUMP-VAR-DISPL CCW 90PV100	90L100-FH-V-NN-8E-R-7-F1-F-B9-GB1-45-45-30	SERIES 90	S90-100PV
80000852	PUMP-VAR-DISPL CCW 90PV100	90L100-DD-5-AB-80-S-3-C7-E-GB-GBA-42-42-24	SERIES 90	S90-100PV

80000853	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-CD-80-L-3-F1-F-03-GBA-43-43-30	SERIES 90	S90-100PV
80000862	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-NN-80-P-3-C8-F-03-GBA-35-35-24	SERIES 90	S90-130PV
80000863	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-AB-80-S-3-F1-F-04-GBA-38-38-24	SERIES 90	S90-130PV
80000864	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-DE-80-R-4-C8-H-03-GBA-35-35-24	SERIES 90	S90-130PV
80000865	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-CD-80-S-C-C8-J-03-NNN-42-42-24	SERIES 90	S90-180PV
80000867	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-S1-N-N1-NN-N-N-U1-ABA-035-AA-F0-00-00	SERIES 51	S51-080MV-1
80000868	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-BC-80-R-4-F1-H-03-GBA-35-35-24	SERIES 90	S90-130PV
80000869	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-T2-C0-L-N-K7-NNN-085-AA-H0-00-B5	SERIES 51	S51-160MV
80000870	MOTOR-VAR-DISPL 51MD110	51D110-A-D4-N-HS-A2-B-E-E1-NNN-031-AA-F3-08-25	SERIES 51	S51-110MV
80000871	MOTOR-VAR-DISPL 51MV110	51V110-A-C8-N-HS-A2-B-E-E1-NNN-022-AA-F3-08-25	SERIES 51	S51-110MV
80000872	PUMP-VAR-DISPL CW 90PV180	90R180-DD-5-BC-80-S-7-C8-H-G1-NNN-29-29-24	SERIES 90	S90-180PV
80000873	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-AB-80-R-S-F6-F-04-GBA-42-42-24	SERIES 90	S90-130PV
80000874	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-NN-60-P-3-C7-F-04-FAS-38-38-28	SERIES 90	S90-100PV
80000875	PUMP-VAR-DISPL CW 90PV075	90R075-MA-5-AB-80-S-3-C6-D-C5-GBA-42-42-24	SERIES 90	S90-075PV
80000877	PUMP-VAR-DISPL CW 90PV100	90R100-HF-5-CD-60-S-3-C7-F-03-GBA-35-35-24	SERIES 90	S90-100PV
80000879	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-EQ-A2-J-Y-E1-NNN-168-AA-H0-20-30	SERIES 51	S51-250MV
80000880	PUMP-VAR-DISPL CCW 90PV130	90L130-HF-5-NN-80-S-4-F1-H-03-GBA-38-38-24	SERIES 90	S90-130PV
80000881	MOTOR-VAR-DISPL 51MD110-1	51D110-1--A-D3-N-T1-D1-N-N-X1-NNN-054-AA-F3-00-30	SERIES 51	S51-110MV-1
80000882	PUMP-VAR-DISPL CW 90PV100	90R100-DC-5-CD-80-S-3-C7-E-GB-GBA-35-35-24	SERIES 90	S90-100PV
80000883	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-NN-80-S-3-F1-F-04-GBA-38-38-24	SERIES 90	S90-130PV
80000884	PUMP-VAR-DISPL CW 90PV250	90R250-KN-5-EF-80-S-3-C8-K-03-NNN-29-29-24	SERIES 90	S90-250PV
80000886	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-E2-B1-N-N-U1-ABA-050-AA-F3-00-00	SERIES 51	S51-110MV-1
80000887	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-NN-80-S-3-F1-F-04-GBA-38-38-24	SERIES 90	S90-130PV
80000888	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-D8-M1-R-J-M4-ADA-032-AA-H0-C2-35	SERIES 51	S51-160MV
80000889	PUMP-VAR-DISPL CW 90PV250	90R250-KN-5-EG-80-T-3-C8-K-03-NNN-35-35-24	SERIES 90	S90-250PV
80000890	PUMP-VAR-DISPL CW 90PV180	90R180-KN-5-AB-80-T-C-C8-J-03-NNN-35-35-24	SERIES 90	S90-180PV
80000891	PUMP-VAR-DISPL CW 90PV180	90R180-KN-5-NN-80-T-C-C8-J-03-NNN-35-35-24	SERIES 90	S90-180PV
80000892	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-BC-80-L-4-C8-H-05-GBA-32-32-24	SERIES 90	S90-130PV
80000893	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-BB-80-L-4-C8-H-05-GBA-32-32-24	SERIES 90	S90-130PV
80000894	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-D8-M1-R-J-N1-ADA-068-AA-F3-C2-32	SERIES 51	S51-160MV
80000895	MOTOR-VAR-DISPL 51MD160	51D160-R-D4-N-HS-A7-B-N-F1-CCA-090-AA-F0-08-16	SERIES 51	S51-160MV
80000896	MOTOR-VAR-DISPL 51MV060	51V060-R-S1-N-HS-A2-B-H-C1-NNN-030-AA-NN-10-13	SERIES 51	S51-060MV
80000898	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-C-HS-A2-B-H-C1-NNN-028-AA-NN-10-13	SERIES 51	S51-080MV
80000899	MOTOR-VAR-DISPL 51MV080	51V080-A-S1-N-HS-A2-B-H-C1-NNN-020-AA-NN-10-13	SERIES 51	S51-080MV
80000900	PUMP-VAR-DISPL CW 90PV180	90R180-MA-5-NN-80-S-C-C8-L-C5-NNN-17-17-28	SERIES 90	S90-180PV
80000901	PUMP-VAR-DISPL CCW 90PV250	90L250-KN-5-AB-80-T-4-F1-J-03-NNN-32-32-24	SERIES 90	S90-250PV

80000902	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-BB-80-L-3-F1-H-00-GBA-32-32-26	SERIES 90	S90-130PV
80000903	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-CD-80-S-3-C8-H-03-GBA-42-42-24	SERIES 90	S90-130PV
80000904	MOTOR-VAR-DISPL 51MV110	51V110-A-C8-N-HS-A2-B-E-E1-NNN-055-AA-G3-12-20	SERIES 51	S51-110MV
80000906	PUMP-VAR-DISPL CW 90PV075	90R075-CA-D-CD-6U-P-7-C7-E-00-GMA-38-38-30	SERIES 90	S90-075PV
80000907	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-T1-C0-L-N-G0-NNN-075-AA-G0-00-C1	SERIES 51	S51-160MV
80000908	MOTOR-VAR-DISPL 51MV080	51V080-A-S1-E-HS-A2-B-H-C1-NNN-050-AA-NN-10-13	SERIES 51	S51-080MV
80000909	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-N-E1-A5-A-N-G0-NNN-055-AA-F3-03-00	SERIES 51	S51-160MV
80000910	MOTOR-VAR-DISPL 51MV110	51V110-R-C8-N-D7-M1-S-K-M4-NNN-042-AA-F0-F4-17	SERIES 51	S51-110MV
80000911	MOTOR-VAR-DISPL 51MV060-1	51V060-1--A-S1-N-N1-NN-N-N-U1-NNN-040-AA-E6-00-00	SERIES 51	S51-060MV-1
80000912	PUMP-VAR-DISPL CCW 90PV180	90L180-HF-5-NN-80-S-C-C8-J-03-NNN-38-38-24	SERIES 90	S90-180PV
80000913	MOTOR-VAR-DISPL 51MV060-1	51V060-1--A-C6-N-E2-B1-N-N-U1-NNN-022-AA-NN-00-00	SERIES 51	S51-060MV-1
80000914	MOTOR-VAR-DISPL 51MV080-1	51V080-1--A-C7-N-E2-B1-N-N-U1-NNN-027-AA-NN-00-00	SERIES 51	S51-080MV-1
80000915	PUMP-VAR-DISPL CW 90PV100	90R100-MA-5-NN-80-S-4-C7-E-C5-GBA-26-26-24	SERIES 90	S90-100PV
80000917	PUMP-VAR-DISPL CW 90PV180	90R180-KN-5-NN-80-T-M-F1-J-03-FAC-20-20-24	SERIES 90	S90-180PV
80000918	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-TA-C2-L-N-G0-NNN-107-AA-F0-00-B5	SERIES 51	S51-160MV
80000919	PUMP-VAR-DISPL CW 90PV180	90R180-MA-5-AB-80-T-C-F1-H-C5-NNN-20-20-24	SERIES 90	S90-180PV
80000921	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-L2-B1-V-A-J1-ADA-035-AA-F3-B2-00	SERIES 51	S51-160MV
80000922	MOTOR-VAR-DISPL 51MV060-1	51V060-1--R-C6-N-T1-CA-N-N-X1-NNN-028-AA-NN-00-20	SERIES 51	S51-060MV-1
80000924	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-BC-80-S-3-S1-F-03-GBA-38-14-24	SERIES 90	S90-100PV
80000925	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-BC-80-T-4-C8-K-03-NNN-21-32-24	SERIES 90	S90-250PV
80000926	PUMP-VAR-DISPL CW 90PV130	90R130-DD-2-BC-80-S-7-D8-F-G1-GCA-29-29-30	SERIES 90	S90-130PV
80000928	MOTOR-VAR-DISPL 51MD160	51D160-R-D4-N-E1-A5-A-N-G0-NNN-032-AA-F0-03-00	SERIES 51	S51-160MV
80000929	MOTOR-VAR-DISPL 51MV080-1	51V080-1--A-S1-N-N1-NN-N-N-U1-ABA-040-AA-F3-00-00	SERIES 51	S51-080MV-1
80000930	PUMP-VAR-DISPL CW 90PV130	90R130-HF-5-AB-80-S-3-C8-H-03-GBA-23-23-20	SERIES 90	S90-130PV
80000931	MOTOR-VAR-DISPL 51MC060-1	51C060-1--A-S1-N-E1-B1-N-N-U1-NNN-017-AA-NN-00-00	SERIES 51	S51-060MV-1
80000932	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-CD-80-L-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-075PV
80000933	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-CD-60-L-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-100PV
80000934	PUMP-VAR-DISPL CW 90PV075	90R075-DD-5-BC-60-L-3-S1-E-GB-GBA-35-35-24	SERIES 90	S90-075PV
80000935	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-N-HZ-B1-A-N-G0-NNN-050-AA-G0-03-00	SERIES 51	S51-160MV
80000936	PUMP-VAR-DISPL CW 90PV180	90R180-HS-5-NN-80-T-C-C8-H-03-NNN-32-32-24	SERIES 90	S90-180PV
80000940	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-EQ-A2-J-Y-G0-NNN-064-AA-E6-40-27	SERIES 51	S51-160MV
80000941	MOTOR-VAR-DISPL 51MV160	51V160-R-F2-A-E2-A5-A-N-A6-NNN-055-AA-H0-03-00	SERIES 51	S51-160MV
80000942	PUMP-VAR-DISPL CW 90PV180	90R180-HS-5-NN-80-T-C-F1-H-03-NNN-32-32-24	SERIES 90	S90-180PV
80000943	PUMP-VAR-DISPL CW 90PV180	90R180-HS-5-EF-80-T-C-C8-H-03-NNN-32-32-24	SERIES 90	S90-180PV
80000944	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-CD-60-L-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
80000945	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-NN-60-L-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV

80000946	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-S1-N-E1-B1-N-N-U1-NNN-021-AA-F0-00-00	SERIES 51	S51-080MV-1
80000947	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-5-CD-80-S-3-C8-L-03-NNN-42-16-30	SERIES 90	S90-250PV
80000948	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-5-NN-80-S-3-C8-L-03-NNN-42-16-30	SERIES 90	S90-250PV
80000949	MOTOR-VAR-DISPL 51MV160	51V160-A-F2-N-EQ-A2-J-Y-E1-NNN-075-AA-F3-15-37	SERIES 51	S51-160MV
80000950	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-N-EQ-A2-J-Y-E1-NNN-095-AA-G0-15-37	SERIES 51	S51-250MV
80000951	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-L2-B1-V-A-C0-NNN-030-AA-F3-B2-00	SERIES 51	S51-080MV
80000952	MOTOR-VAR-DISPL 51MV060	51V060-R-S1-N-L2-B1-V-A-C0-NNN-030-AA-F3-B2-00	SERIES 51	S51-060MV
80000962	MOTOR-VAR-DISPL 51MV060-1	51V060-1--A-S1-N-T1-D1-N-N-X1-ABA-025-AA-E6-00-19	SERIES 51	S51-060MV-1
80000963	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-E1-B1-N-N-U2-NNN-053-AA-F3-00-00	SERIES 51	S51-110MV-1
80000964	MOTOR-VAR-DISPL 51MD110-1	51D110-1--A-D3-N-T2-CA-N-N-X1-NNN-074-AA-NN-00-37	SERIES 51	S51-110MV-1
80000972	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-EQ-A2-J-Y-G6-NNN-100-AA-F3-15-37	SERIES 51	S51-250MV
80000973	PUMP-VAR-DISPL CCW 90PV042	90L042-KA-1-NN-80-S-3-C3-B-03-GBA-42-42-24	SERIES 90	S90-042PV
80000974	MOTOR-VAR-DISPL 51MD110	51D110-A-D4-N-EQ-A2-J-Y-G6-AHA-049-AA-F0-15-37	SERIES 51	S51-110MV
80000976	MOTOR-VAR-DISPL 51MV080	51V080-R-C7-N-EQ-A5-J-Y-A6-NNN-016-AA-F3-15-00	SERIES 51	S51-080MV
80000983	PUMP-VAR-DISPL CW 90PV100	90R100-MA-5-CD-80-S-3-F1-E-C4-GBA-35-35-24	SERIES 90	S90-100PV
80000984	MOTOR-VAR-DISPL 51MV060-1	51V060-1--A-S1-N-E1-B1-N-N-U1-NNN-017-AA-NN-00-00	SERIES 51	S51-060MV-1
80000985	PUMP-VAR-DISPL CCW 90PV250	90L250-HF-5-NN-80-S-3-C8-K-03-NNN-35-35-24	SERIES 90	S90-250PV
80000986	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-5-NN-80-T-3-C8-K-03-NNN-26-26-24	SERIES 90	S90-250PV
80000987	PUMP-VAR-DISPL CW 90PV075	90R075-KA-P-BB-80-P-3-C7-E-03-FAB-48-48-24	SERIES 90	S90-075PV
80000988	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-D-HZ-B1-C-H-C2-NNN-050-AA-G3-20-00	SERIES 51	S51-250MV
80000989	PUMP-VAR-DISPL CCW 90PV130	90L130-MA-5-NN-80-S-3-C8-F-C5-GBA-35-26-24	SERIES 90	S90-130PV
80000992	MOTOR-VAR-DISPL 51MD110	51D110-R-D3-N-HZ-B1-C-H-C2-NNN-060-AA-NN-20-00	SERIES 51	S51-110MV
80000993	PUMP-VAR-DISPL CCW 90PV100	90L100-HF-5-NN-60-S-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
80000994	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-D-E2-A5-A-N-A6-NNN-072-AA-F3-03-00	SERIES 51	S51-250MV
80000995	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-5-CD-80-T-3-F1-K-03-NNN-35-35-24	SERIES 90	S90-250PV
80001003	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-L2-B1-V-A-G5-NNN-145-AA-G0-B2-00	SERIES 51	S51-250MV
80001012	PUMP-VAR-DISPL CW 90PV100	90R100-MA-5-BC-80-L-4-C7-E-C7-GBA-32-32-24	SERIES 90	S90-100PV
80001013	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-C-N1-NN-N-N-U1-AWH-020-AA-E4-00-00	SERIES 51	S51-060MV-1
80001015	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-BC-80-S-4-TK-F-04-GBA-42-42-24	SERIES 90	S90-130PV
80001016	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-HE-B2-B-E-N6-NNN-031-AA-F0-09-00	SERIES 51	S51-080MV
80001022	MOTOR-VAR-DISPL 51MD160	51D160-R-D5-N-HZ-B1-B-H-C2-NNN-N80-AA-NN-09-00	SERIES 51	S51-160MV
80001023	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-CD-60-S-3-C7-E-00-GBA-20-20-28	SERIES 90	S90-100PV
80001024	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-N-HZ-B1-A-N-G5-NNN-068-AA-F3-03-00	SERIES 51	S51-160MV
80001025	PUMP-VAR-DISPL CW 90PV180	90R180-KP-5-NN-80-T-C-F1-J-00-FAC-35-35-24	SERIES 90	S90-180PV
80001026	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-C8-N-T2-C2-N-N-X1-NNN-035-AA-F3-00-28	SERIES 51	S51-110MV-1
80001027	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-HS-A2-B-E-E1-NNN-130-AA-NN-10-18	SERIES 51	S51-250MV

80001032	PUMP-VAR-DISPL CCW 90PV100	90L100-HF-5-AB-60-P-4-C7-E-03-GBA-26-26-30	SERIES 90	S90-100PV
80001033	PUMP-VAR-DISPL CW 90PV130	90R130-MA-5-BC-80-R-3-C8-H-C6-GBA-45-45-28	SERIES 90	S90-130PV
80001034	PUMP-VAR-DISPL CW 90PV130	90R130-HS-5-NN-80-R-3-C8-H-03-GBA-42-42-24	SERIES 90	S90-130PV
80001035	MOTOR-VAR-DISPL 51MC080	51C080-R-D3-N-HZ-B1-B-E-G5-ABA-065-AA-F0-07-00	SERIES 51	S51-080MV
80001042	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-BC-80-R-3-C8-H-06-GBA-45-45-28	SERIES 90	S90-130PV
80001043	PUMP-VAR-DISPL CCW 90PV180	90L180-KN-5-NN-80-T-C-F1-J-03-FAC-35-35-24	SERIES 90	S90-180PV
80001044	PUMP-VAR-DISPL CW 90PV250	90R250-MB-5-NN-80-S-3-F1-J-C5-NNN-26-26-24	SERIES 90	S90-250PV
80001045	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-S1-N-N1-NN-N-N-U1-NNN-047-AA-E4-00-00	SERIES 51	S51-080MV-1
80001046	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-NN-80-L-4-C8-H-03-GBA-42-42-24	SERIES 90	S90-130PV
80001047	PUMP-VAR-DISPL CCW 90PV130	90L130-HS-5-NN-80-P-3-F1-H-03-GBA-35-35-24	SERIES 90	S90-130PV
80001048	PUMP-VAR-DISPL CW 90PV130	90R130-MB-5-NN-80-L-3-F1-F-C5-GBA-35-35-24	SERIES 90	S90-130PV
80001051	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-CD-80-L-4-F1-F-03-GBA-14-14-24	SERIES 90	S90-130PV
80001052	MOTOR-VAR-DISPL 51MV110-1	51V110-1--A-F1-N-TA-C2-N-N-X1-NNN-062-AA-F0-00-17	SERIES 51	S51-110MV-1
80001053	PUMP-VAR-DISPL CW 90PV075	90R075-HF-5-CD-60-S-3-C7-C-03-GBA-42-42-24	SERIES 90	S90-075PV
80001054	PUMP-VAR-DISPL CW 90PV075	90R075-HF-5-BC-60-S-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-075PV
80001055	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-EQ-A5-J-Y-J1-ADA-030-AA-G3-30-00	SERIES 51	S51-080MV
80001056	MOTOR-VAR-DISPL 51MD080-1	51D080-1--R-D2-N-T7-CA-N-N-X1-AWM-047-AA-F0-00-24	SERIES 51	S51-080MV-1
80001057	PUMP-VAR-DISPL CCW 90PV130	90L130-MA-P-AB-80-L-3-F1-H-C7-GBA-48-48-24	SERIES 90	S90-130PV
80001062	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-NN-60-P-3-C7-E-03-GBA-26-26-24	SERIES 90	S90-100PV
80001063	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-AB-80-R-3-C8-H-03-GBA-42-42-20	SERIES 90	S90-130PV
80001064	PUMP-VAR-DISPL CW 90PV100	90R100-HF-5-AB-80-S-4-C7-E-03-GBA-35-35-24	SERIES 90	S90-100PV
80001065	MOTOR-VAR-DISPL 51MV080	51V080-A-S1-N-HS-A2-B-H-A7-NNN-027-AA-NN-11-23	SERIES 51	S51-080MV
80001066	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-N-N1-NN-N-N-U1-ACB-040-AA-E4-00-00	SERIES 51	S51-060MV-1
80001067	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-NN-80-S-C-C8-H-05-NNN-38-38-24	SERIES 90	S90-180PV
80001068	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-JA-NN-B-E-K3-NNN-050-AA-F3-10-22	SERIES 51	S51-250MV
80001070	PUMP-VAR-DISPL CCW 90PV100	90L100-FD-5-NN-80-L-7-C7-E-B1-EFI-42-42-24	SERIES 90	S90-100PV
80001071	PUMP-VAR-DISPL CW 90PV180	90R180-HF-5-AB-80-S-M-C8-J-03-NNN-32-32-24	SERIES 90	S90-180PV
80001072	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-EG-80-T-C-C8-J-K4-GLA-35-35-30	SERIES 90	S90-180PV
80001073	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-NN-80-T-C-C8-J-K4-GLA-35-35-30	SERIES 90	S90-180PV
80001074	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-S1-N-E2-B1-N-N-U1-ACB-037-AA-NN-00-00	SERIES 51	S51-080MV-1
80001075	PUMP-VAR-DISPL CW 90PV100	90R100-MA-2-CD-80-S-3-C7-E-03-FAX-45-45-28	SERIES 90	S90-100PV
80001076	MOTOR-VAR-DISPL 51MC080	51C080-R-D2-N-L7-B1-W-B-G5-NNN-016-AA-E4-D4-00	SERIES 51	S51-080MV
80001077	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-BC-80-S-3-C8-H-04-GBA-38-38-24	SERIES 90	S90-130PV
80001078	PUMP-VAR-DISPL CCW 90PV100	90L100-HF-5-AB-80-S-4-S1-F-02-GBA-30-30-20	SERIES 90	S90-100PV
80001079	PUMP-VAR-DISPL CCW 90PV100	90L100-HF-5-CD-80-S-4-C7-F-02-GBA-30-30-20	SERIES 90	S90-100PV
80001080	PUMP-VAR-DISPL CCW 90PV130	90L130-KN-5-CD-80-D-4-F1-L-03-GBA-35-35-28	SERIES 90	S90-130PV

80001082	PUMP-VAR-DISPL CCW 90PV075	90L075-MB-5-CD-60-S-3-C7-E-29-GBA-32-32-20	SERIES 90	S90-075PV
80001083	MOTOR-VAR-DISPL 51MD160	51D160-A-D4-N-T4-C0-L-N-L4-NNN-055-AA-F3-00-B3	SERIES 51	S51-160MV
80001084	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-BC-80-S-3-S1-E-03-GBA-42-42-28	SERIES 90	S90-075PV
80001085	PUMP-VAR-DISPL CW 90PV100	90R100-MA-5-BC-60-S-3-C7-E-C5-GBA-42-42-24	SERIES 90	S90-100PV
80001086	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-T1-D1-N-N-X1-ABA-040-AA-E6-00-21	SERIES 51	S51-110MV-1
80001087	PUMP-VAR-DISPL CW 90PV100	90R100-MA-5-CD-60-S-4-C7-E-C7-GBA-32-32-24	SERIES 90	S90-100PV
80001088	PUMP-VAR-DISPL CW 90PV130	90R130-MA-5-BC-80-S-3-F1-F-C5-GBA-35-35-24	SERIES 90	S90-130PV
80001089	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-B-ES-A5-K-Y-G5-ACD-045-AA-F3-50-00	SERIES 51	S51-160MV
80001090	MOTOR-VAR-DISPL 51MV080-1	51V080-1--A-S1-N-TA-C2-N-N-X1-NNN-054-AA-E6-00-24	SERIES 51	S51-080MV-1
80001091	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-TA-C2-N-N-X1-NNN-064-AA-F3-00-21	SERIES 51	S51-110MV-1
80001092	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-L1-B1-W-B-J1-ANA-018-AA-F0-D4-00	SERIES 51	S51-080MV
80001093	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-NN-80-S-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-130PV
80001094	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-NN-80-P-4-C7-D-03-GBA-42-42-24	SERIES 90	S90-075PV
80001095	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-NN-60-P-3-C7-E-03-GBA-32-32-26	SERIES 90	S90-075PV
80001096	MOTOR-VAR-DISPL 51MV060	51V060-R-C6-N-JA-NN-B-E-M4-ADA-022-AA-F0-09-17	SERIES 51	S51-060MV
80001097	MOTOR-VAR-DISPL 51MV060	51V060-R-C6-N-JA-NN-B-E-M4-NNN-022-AA-F0-09-17	SERIES 51	S51-060MV
80001098	MOTOR-VAR-DISPL 51MD160	51D160-R-F1-N-EF-B1-V-A-C0-AMC-N32-AA-B3-B2-00	SERIES 51	S51-160MV
80001099	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-HS-A1-B-H-E2-NNN-110-AA-F3-09-20	SERIES 51	S51-160MV
80001100	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-T2-C2-L-N-G0-NNN-090-AA-NN-00-B5	SERIES 51	S51-160MV
80001101	PUMP-VAR-DISPL CW 90PV100	90R100-MB-5-CD-60-S-3-C7-F-03-FAB-42-42-24	SERIES 90	S90-100PV
80001102	PUMP-VAR-DISPL CCW 90PV042	90L042-MA-1-AB-80-S-4-C3-C-02-GBA-35-35-24	SERIES 90	S90-042PV
80001103	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-TA-C2-L-N-G0-NNN-100-AA-G3-00-C0	SERIES 51	S51-250MV
80001104	MOTOR-VAR-DISPL 51MV080-1	51V080-1--A-S1-N-N1-NN-N-N-U1-NNN-040-AA-F0-00-00	SERIES 51	S51-080MV-1
80001105	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-DE-80-S-3-C8-H-03-GBA-42-42-24	SERIES 90	S90-130PV
80001106	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-NN-80-S-3-F1-H-03-GBA-42-42-24	SERIES 90	S90-130PV
80001107	PUMP-VAR-DISPL CW 90PV100	90R100-HF-5-CD-80-P-3-C7-E-03-GBA-26-26-24	SERIES 90	S90-100PV
80001108	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-AB-80-S-4-C7-E-03-GBA-35-35-24	SERIES 90	S90-100PV
80001109	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-DE-80-L-4-C8-F-05-GBA-35-35-24	SERIES 90	S90-130PV
80001110	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-CD-80-L-4-F1-F-05-GBA-35-35-24	SERIES 90	S90-130PV
80001111	PUMP-VAR-DISPL CCW 90PV250	90L250-HF-5-AB-80-S-4-C8-K-03-NNN-42-42-24	SERIES 90	S90-250PV
80001112	MOTOR-VAR-DISPL 51MV160	51V160-A-C8-N-D8-M1-R-J-M1-ADA-035-AA-F3-C2-26	SERIES 51	S51-160MV
80001113	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-EQ-R4-K-Y-D5-NNN-098-AA-H0-75-28	SERIES 51	S51-250MV
80001114	PUMP-VAR-DISPL CW 90PV100	90R100-HF-5-CD-60-S-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
80001115	PUMP-VAR-DISPL CW 90PV100	90R100-HF-5-NN-60-S-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
80001116	PUMP-VAR-DISPL CW 90PV250	90R250-DD-5-CD-80-S-4-C8-K-GF-NNN-35-35-24	SERIES 90	S90-250PV
80001117	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-HS-A2-B-E-E1-NNN-032-AA-F0-05-27	SERIES 51	S51-160MV

80001118	PUMP-VAR-DISPL CW 90PV130	90R130-HF-5-BB-80-L-3-F1-H-04-GBA-32-32-28	SERIES 90	S90-130PV
80001119	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-TA-C2-N-N-X1-NNN-070-AA-F0-00-13	SERIES 51	S51-110MV-1
80001120	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-CD-80-T-3-F1-K-00-NNN-29-14-24	SERIES 90	S90-250PV
80001121	PUMP-VAR-DISPL CW 90PV100	90R100-MA-5-NN-60-L-4-C7-E-C5-GBA-26-26-24	SERIES 90	S90-100PV
80001122	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-N2-NN-N-N-A0-NNN-095-AA-G3-00-00	SERIES 51	S51-160MV
80001123	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-AB-80-S-4-C8-H-04-GBA-42-42-24	SERIES 90	S90-130PV
80001124	PUMP-VAR-DISPL CCW 90PV042	90L042-KA-5-BC-80-R-3-C3-B-03-GBA-42-42-24	SERIES 90	S90-042PV
80001132	PUMP-VAR-DISPL CW 90PV075	90R075-MB-5-CD-60-S-3-C7-D-03-FAB-42-42-24	SERIES 90	S90-075PV
80001133	MOTOR-VAR-DISPL 51MD160	51D160-R-D4-N-T2-C0-L-N-G0-ADA-053-AA-F3-00-B7	SERIES 51	S51-160MV
80001134	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-E2-R2-A-N-E3-NNN-070-AA-G0-03-20	SERIES 51	S51-160MV
80001135	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-L2-B1-V-A-G5-ACA-080-AA-F3-B2-00	SERIES 51	S51-160MV
80001136	PUMP-VAR-DISPL CCW 90PV075	90L075-MA-5-BB-80-S-3-S1-L-C6-GBS-42-42-24	SERIES 90	S90-075PV
80001137	PUMP-VAR-DISPL CCW 90PV130	90L130-MA-5-BB-80-P-3-C8-F-C6-GBS-42-42-24	SERIES 90	S90-130PV
80001138	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-NN-80-S-4-C7-E-03-GBA-20-20-20	SERIES 90	S90-075PV
80001139	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-BB-60-P-4-C7-D-03-GBS-35-14-20	SERIES 90	S90-075PV
80001140	PUMP-VAR-DISPL CCW 90PV100	90L100-MA-5-CD-80-S-3-C7-F-C6-GBA-42-42-24	SERIES 90	S90-100PV
80001141	PUMP-VAR-DISPL CW 90PV100	90R100-HF-5-NN-60-R-4-C7-E-02-GBA-26-26-20	SERIES 90	S90-100PV
80001142	MOTOR-VAR-DISPL 51MV060-1	51V060-1--R-S1-N-T1-R5-N-N-X1-ADA-022-AA-F0-00-30	SERIES 51	S51-060MV-1
80001143	MOTOR-VAR-DISPL 51MV060-1	51V060-1--R-S1-N-T1-L5-N-N-X1-ADA-022-AA-F0-00-30	SERIES 51	S51-060MV-1
80001144	PUMP-VAR-DISPL CCW 90PV130	90L130-DC-5-NN-80-S-3-F1-F-GB-GBA-14-14-24	SERIES 90	S90-130PV
80001145	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-L2-B1-V-A-G5-ACA-022-AA-F0-B2-00	SERIES 51	S51-080MV
80001146	PUMP-VAR-DISPL CW 90PV100	90R100-MA-5-NN-80-P-3-S1-F-C5-GBA-42-42-24	SERIES 90	S90-100PV
80001148	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-NN-80-S-3-C8-F-03-GBA-35-35-24	SERIES 90	S90-130PV
80001149	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-BC-80-R-3-C8-F-03-GBA-42-42-24	SERIES 90	S90-130PV
80001150	PUMP-VAR-DISPL CCW 90PV075	90L075-HF-5-NN-60-R-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
80001151	PUMP-VAR-DISPL CW 90PV180	90R180-KP-5-NN-80-S-C-F1-H-03-FAC-42-42-24	SERIES 90	S90-180PV
80001153	PUMP-VAR-DISPL CCW 90PV075	90L075-MB-5-CD-60-S-3-C7-E-29-GBA-32-32-24	SERIES 90	S90-075PV
80001154	MOTOR-VAR-DISPL 51MV080	51V080-R-C7-N-L2-B1-V-A-G0-ABA-016-AA-F0-B2-00	SERIES 51	S51-080MV
80001157	PUMP-VAR-DISPL CW 90PV075	90R075-FN-S-BC-8D-P-7-C6-D-B6-GMC-48-48-30	SERIES 90	S90-075PV
80001158	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D2-N-E1-B1-N-N-U1-NNN-030-AA-F0-00-00	SERIES 51	S51-080MV-1
80001159	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-NN-80-S-C-C8-J-03-NNN-42-42-28	SERIES 90	S90-180PV
80001160	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-5-EG-80-S-3-C8-K-03-NNN-42-42-24	SERIES 90	S90-250PV
80001161	PUMP-VAR-DISPL CW 90PV042	90R042-MA-5-BC-80-S-3-C3-C-C5-GBA-23-23-24	SERIES 90	S90-042PV
80001162	PUMP-VAR-DISPL CW 90PV250	90R250-HF-5-CD-80-T-3-F1-K-03-NNN-35-35-24	SERIES 90	S90-250PV
80001163	MOTOR-VAR-DISPL 51MD110	51D110-R-D4-N-HZ-B1-C-H-C2-NNN-060-AA-NN-20-00	SERIES 51	S51-110MV
80001164	PUMP-VAR-DISPL CW 90PV075	90R075-FG-5-CD-80-S-7-C7-D-B1-GLA-38-38-30	SERIES 90	S90-075PV

80001167	PUMP-VAR-DISPL CW 90PV100	90R100-MA-5-NN-80-S-3-C7-E-C5-GBA-35-35-24	SERIES 90	S90-100PV
80001168	PUMP-VAR-DISPL CW 90PV250	90R250-KN-5-NN-80-S-3-C8-K-03-NNN-20-20-24	SERIES 90	S90-250PV
80001169	MOTOR-VAR-DISPL 51MD110	51D110-R-D4-N-HS-A2-C-H-E1-NNN-060-AA-NN-20-16	SERIES 51	S51-110MV
80001170	MOTOR-VAR-DISPL 51MD080-1	51D080-1--A-D3-N-T1-D1-N-N-X1-NNN-054-AA-F3-00-25	SERIES 51	S51-080MV-1
80001171	PUMP-VAR-DISPL CW 90PV075	90R075-NA-1-CD-60-P-3-C7-D-03-FAB-42-42-24	SERIES 90	S90-075PV
80001172	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-NN-80-S-C-C8-J-00-NNN-42-42-28	SERIES 90	S90-180PV
80001173	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-N2-NN-N-N-A0-ADA-050-AA-F3-00-00	SERIES 51	S51-250MV
80001174	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-BC-60-P-3-TJ-D-04-GBA-42-42-20	SERIES 90	S90-075PV
80001175	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-NN-80-P-3-C8-F-03-GBA-38-38-24	SERIES 90	S90-130PV
80001176	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-BC-60-P-3-TJ-D-04-GBA-42-42-20	SERIES 90	S90-075PV
80001177	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-AB-80-L-4-C8-F-05-GBA-32-32-24	SERIES 90	S90-130PV
80001178	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-TH-C2-L-N-G0-NNN-122-AA-H0-00-C3	SERIES 51	S51-250MV
80001179	PUMP-VAR-DISPL CCW 90PV100	90L100-KP-5-CD-60-S-4-S1-E-03-GBA-29-29-24	SERIES 90	S90-100PV
80001180	MOTOR-VAR-DISPL 51MD110-1	51D110-1--R-D4-N-E2-B1-N-N-U1-NNN-025-AA-E6-00-00	SERIES 51	S51-110MV-1
80001181	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D3-N-N1-NN-N-N-U1-ABA-040-AA-F0-00-00	SERIES 51	S51-080MV-1
80001182	PUMP-VAR-DISPL CW 90PV075	90R075-NA-1-AB-60-P-3-S1-D-03-GBA-30-30-24	SERIES 90	S90-075PV
80001183	PUMP-VAR-DISPL CCW 90PV100	90L100-MB-5-CD-80-S-3-C7-E-29-GBA-45-45-24	SERIES 90	S90-100PV
80001184	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-5-BC-80-T-3-F1-K-03-NNN-38-38-24	SERIES 90	S90-250PV
80001185	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-NN-80-L-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-075PV
80001186	PUMP-VAR-DISPL CW 90PV250	90R250-KN-5-CD-80-S-3-C8-K-03-NNN-42-42-24	SERIES 90	S90-250PV
80001187	PUMP-VAR-DISPL CW 90PV100	90R100-KN-5-BC-80-S-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
80001188	PUMP-VAR-DISPL CW 90PV130	90R130-FG-5-CD-80-P-7-C8-F-B1-EFI-42-42-30	SERIES 90	S90-130PV
80001189	PUMP-VAR-DISPL CCW 90PV130	90L130-MA-5-NN-80-P-3-C8-F-C6-GBA-29-29-20	SERIES 90	S90-130PV
80001190	PUMP-VAR-DISPL CW 90PV042	90R042-FD-5-AB-80-S-7-C3-C-B1-EEG-40-40-32	SERIES 90	S90-042PV
80001192	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-N-N1-NN-N-N-U1-ABA-030-AA-F0-00-00	SERIES 51	S51-060MV-1
80001193	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-TH-C2-L-N-G0-NNN-115-AA-H0-00-C7	SERIES 51	S51-160MV
80001195	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-N-N1-NN-N-N-U1-ACG-030-AA-NN-00-00	SERIES 51	S51-060MV-1
80001196	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-E1-B1-N-N-U1-ABA-055-AA-F0-00-00	SERIES 51	S51-110MV-1
80001197	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D2-N-E1-B1-N-N-U1-NNN-054-AA-F3-00-00	SERIES 51	S51-080MV-1
80001198	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-NN-80-P-3-F1-F-04-GBA-42-42-24	SERIES 90	S90-130PV
80001199	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-DE-80-S-M-C8-H-03-FAC-42-42-24	SERIES 90	S90-180PV
80001200	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-EG-80-S-4-C8-J-03-NNN-42-42-24	SERIES 90	S90-250PV
80001201	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D2-N-E1-B1-N-N-U1-ABA-054-AA-F3-00-00	SERIES 51	S51-080MV-1
80001203	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-CD-80-P-3-C8-H-03-GBA-35-35-24	SERIES 90	S90-130PV
80001212	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-NN-80-R-4-C3-C-03-GBA-32-32-24	SERIES 90	S90-042PV
80001213	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-NN-60-L-3-C7-F-03-GBA-35-35-24	SERIES 90	S90-100PV

80001214	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-NN-80-R-3-S1-F-03-GBA-29-29-24	SERIES 90	S90-100PV
80001215	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-CD-80-R-3-C7-F-03-GBA-29-29-24	SERIES 90	S90-100PV
80001216	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-AB-60-S-3-S1-F-04-GBA-35-35-24	SERIES 90	S90-100PV
80001217	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-CD-60-S-3-S1-F-04-GBA-35-35-24	SERIES 90	S90-100PV
80001218	PUMP-VAR-DISPL CCW 90PV100	90L100-DD-5-AB-60-S-4-TG-E-G8-FAC-42-42-24	SERIES 90	S90-100PV
80001219	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-T1-CA-N-N-X1-NNN-055-AA-F3-00-31	SERIES 51	S51-110MV-1
80001220	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-TA-C2-L-N-G0-NNN-058-AA-NN-00-A8	SERIES 51	S51-160MV
80001221	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-NN-60-P-1-C6-D-03-GBA-42-07-20	SERIES 90	S90-075PV
80001222	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-C8-N-TA-C2-N-N-X1-NNN-031-AA-NN-00-22	SERIES 51	S51-110MV-1
80001223	MOTOR-VAR-DISPL 51MD110-1	51D110-1--R-D4-N-T2-CA-N-N-X1-ABA-029-AA-F0-00-20	SERIES 51	S51-110MV-1
80001232	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-TA-C2-L-N-K7-NNN-064-AA-F3-00-B8	SERIES 51	S51-160MV
80001233	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-HZ-B1-A-N-G0-NNN-115-AA-F3-03-00	SERIES 51	S51-160MV
80001235	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-C7-N-E1-B1-N-N-U1-NNN-033-AA-F0-00-00	SERIES 51	S51-080MV-1
80001236	PUMP-VAR-DISPL CCW 90PV180	90L180-KP-1-EG-80-S-C-F1-J-00-FAC-42-42-24	SERIES 90	S90-180PV
80001237	PUMP-VAR-DISPL CCW 90PV180	90L180-KP-1-EF-80-S-C-C8-J-00-FAC-42-42-24	SERIES 90	S90-180PV
80001238	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-2-NN-80-S-3-C8-K-00-NNN-38-38-28	SERIES 90	S90-250PV
80001239	PUMP-VAR-DISPL CW 90PV100	90R100-MA-5-NN-60-P-3-C7-E-C6-GBA-42-42-24	SERIES 90	S90-100PV
80001240	PUMP-VAR-DISPL CCW 90PV075	90L075-HF-5-CD-60-S-3-C7-C-03-GBA-35-35-24	SERIES 90	S90-075PV
80001241	PUMP-VAR-DISPL CW 90PV250	90R250-HS-5-NN-80-T-3-C8-K-03-NNN-42-42-24	SERIES 90	S90-250PV
80001242	PUMP-VAR-DISPL CW 90PV075	90R075-LT-5-BB-60-D-3-S1-L-C6-GBA-42-42-28	SERIES 90	S90-075PV
80001243	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-NN-80-S-3-C8-H-03-GBA-38-38-24	SERIES 90	S90-130PV
80001244	PUMP-VAR-DISPL CW 90PV075	90R075-HF-5-AB-80-R-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
80001245	PUMP-VAR-DISPL CW 90PV250	90R250-MA-5-BC-80-T-3-C8-K-C5-NNN-45-45-28	SERIES 90	S90-250PV
80001246	PUMP-VAR-DISPL CW 90PV130	90R130-MA-5-CD-80-R-3-C8-H-C5-GBA-45-45-28	SERIES 90	S90-130PV
80001247	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-CD-80-S-4-F1-K-03-NNN-38-38-28	SERIES 90	S90-250PV
80001248	MOTOR-VAR-DISPL 51MC110-1	51C110-1--R-D3-N-N1-NN-N-N-U1-NNN-039-AA-F0-00-00	SERIES 51	S51-110MV-1
80001249	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-S1-N-TH-C2-N-N-X1-NNN-050-AA-F0-00-31	SERIES 51	S51-080MV-1
80001250	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-HZ-B1-B-H-G5-NNN-060-AA-NN-07-00	SERIES 51	S51-160MV
80001251	MOTOR-VAR-DISPL 51MV060	51V060-A-S1-N-HZ-B1-A-E-G5-NNN-024-AA-F3-02-00	SERIES 51	S51-060MV
80001252	PUMP-VAR-DISPL CW 90PV075	90R075-FK-S-NN-8D-P-7-C6-D-B6-GMC-48-48-30	SERIES 90	S90-075PV
80001253	PUMP-VAR-DISPL CW 90PV130	90R130-HF-5-NN-80-S-4-F1-H-03-GBA-42-42-24	SERIES 90	S90-130PV
80001254	PUMP-VAR-DISPL CW 90PV075	90R075-MA-5-CD-60-P-4-C7-D-C7-GBA-32-32-24	SERIES 90	S90-075PV
80001255	PUMP-VAR-DISPL CW 90PV075	90R075-MA-5-BC-60-P-4-S1-D-C7-GBA-35-35-24	SERIES 90	S90-075PV
80001256	PUMP-VAR-DISPL CW 90PV100	90R100-MB-5-BC-60-R-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
80001257	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-E1-B1-N-N-U1-NNN-030-AA-G0-00-00	SERIES 51	S51-110MV-1
80001258	PUMP-VAR-DISPL CW 90PV075	90R075-FN-5-BB-80-S-7-C7-D-B6-ELB-38-38-32	SERIES 90	S90-075PV

80001259	MOTOR-VAR-DISPL 51MD160	51D160-R-D4-N-T4-R5-L-N-L5-NNN-063-AA-F3-00-B9	SERIES 51	S51-160MV
80001260	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-AB-60-R-3-C7-E-03-GBA-29-29-24	SERIES 90	S90-100PV
80001261	PUMP-VAR-DISPL CW 90PV075	90R075-DD-5-CD-80-S-4-S1-E-G1-GBA-42-42-20	SERIES 90	S90-075PV
80001262	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-AB-80-L-4-C8-H-03-GBA-35-35-24	SERIES 90	S90-130PV
80001263	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-BC-80-P-4-C3-C-03-GBA-26-26-30	SERIES 90	S90-042PV
80001264	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-E2-A5-A-N-A6-NNN-090-AA-G3-03-00	SERIES 51	S51-160MV
80001265	PUMP-VAR-DISPL CW 90PV130	90R130-FH-5-AB-80-R-7-C8-L-B1-EFI-45-45-32	SERIES 90	S90-130PV
80001266	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-B-E2-B1-N-N-U1-ACB-018-AA-E4-00-00	SERIES 51	S51-060MV-1
80001267	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-N-EQ-A2-J-Y-E1-NNN-125-AA-G0-15-37	SERIES 51	S51-250MV
80001268	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-TA-C2-N-N-X1-NNN-050-AA-F0-00-35	SERIES 51	S51-110MV-1
80001269	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-2-CD-80-R-3-F1-F-03-GBA-29-29-24	SERIES 90	S90-130PV
80001272	PUMP-VAR-DISPL CW 90PV100	90R100-FH-5-CD-80-P-7-C7-D-B1-GLA-42-42-32	SERIES 90	S90-100PV
80001273	PUMP-VAR-DISPL CW 90PV075	90R075-PB-5-CD-60-S-3-S1-D-09-GBA-26-26-24	SERIES 90	S90-075PV
80001274	MOTOR-VAR-DISPL 51MD110-1	51D110-1--R-D4-N-T1-R5-N-N-X1-NNN-034-AA-F3-00-32	SERIES 51	S51-110MV-1
80001276	PUMP-VAR-DISPL CW 90PV075	90R075-PA-2-BC-60-S-3-C6-E-03-FAX-45-45-28	SERIES 90	S90-075PV
80001277	PUMP-VAR-DISPL CW 90PV180	90R180-FG-5-BC-80-S-7-C8-H-B1-NNN-42-42-30	SERIES 90	S90-180PV
80001278	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-NN-80-P-3-S1-E-03-EFC-38-38-24	SERIES 90	S90-075PV
80001279	PUMP-VAR-DISPL CW 90PV075	90R075-KN-5-NN-80-S-3-C7-D-03-GBA-29-29-24	SERIES 90	S90-075PV
80001280	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-N-EQ-A2-J-Y-E1-NNN-050-AA-G0-15-37	SERIES 51	S51-250MV
80001281	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-5-CD-80-S-4-C8-L-03-NNN-42-16-30	SERIES 90	S90-250PV
80001282	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-CD-80-R-4-C8-L-03-GBA-35-35-34	SERIES 90	S90-130PV
80001285	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-BB-60-P-4-C6-F-03-GBA-26-26-24	SERIES 90	S90-100PV
80001286	PUMP-VAR-DISPL CCW 90PV100	90L100-FC-5-BC-80-P-7-C7-E-B1-GBA-35-35-30	SERIES 90	S90-100PV
80001292	MOTOR-VAR-DISPL 51MD080	51D080-R-D3-N-HZ-B1-C-E-G0-NNN-025-AA-E4-12-00	SERIES 51	S51-080MV
80001293	MOTOR-VAR-DISPL 51MD110	51D110-R-D3-N-HE-B2-C-E-E6-ADA-074-AA-E6-12-00	SERIES 51	S51-110MV
80001294	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-B-E2-R2-A-N-E3-ADA-035-AA-F3-03-25	SERIES 51	S51-160MV
80001295	PUMP-VAR-DISPL CW 90PV180	90R180-MA-5-NN-80-S-C-C8-J-C5-NNN-35-35-22	SERIES 90	S90-180PV
80001296	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-L2-B1-V-A-C0-NNN-030-AA-E6-B2-00	SERIES 51	S51-080MV
80001297	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-AB-80-P-3-TK-H-03-EFC-42-42-30	SERIES 90	S90-130PV
80001298	PUMP-VAR-DISPL CCW 90PV100	90L100-FD-5-NN-60-R-7-C7-E-B1-EFI-42-42-24	SERIES 90	S90-100PV
80001299	PUMP-VAR-DISPL CCW 90PV075	90L075-HF-5-AB-80-S-4-S1-E-03-GBA-42-42-24	SERIES 90	S90-075PV
80001301	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-N-TA-D7-N-N-X1-ABA-N16-AA-E6-00-28	SERIES 51	S51-060MV-1
80001302	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-AB-80-T-C-F1-H-03-FAC-38-38-24	SERIES 90	S90-180PV
80001303	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-BC-80-L-3-F1-F-00-GBA-20-20-24	SERIES 90	S90-130PV
80001304	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-C8-N-TA-C2-N-N-X1-NNN-047-AA-NN-00-13	SERIES 51	S51-110MV-1
80001305	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-TA-C2-L-N-G0-NNN-115-AA-F3-00-A4	SERIES 51	S51-160MV

80001306	PUMP-VAR-DISPL CCW 90PV180	90L180-DC-5-NN-80-S-C-C8-H-G1-NNN-42-42-24	SERIES 90	S90-180PV
80001307	PUMP-VAR-DISPL CW 90PV075	90R075-FH-5-AB-80-S-7-C7-E-B9-EFI-35-35-24	SERIES 90	S90-075PV
80001308	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-BB-80-T-C-C8-H-04-FAP-42-42-24	SERIES 90	S90-180PV
80001310	PUMP-VAR-DISPL CW 90PV075	90R075-FM-5-AB-80-P-7-C7-E-B6-EFP-45-45-30	SERIES 90	S90-075PV
80001311	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-BC-80-S-3-F1-F-03-GBA-35-35-20	SERIES 90	S90-130PV
80001312	PUMP-VAR-DISPL CW 90PV042	90R042-HF-5-NN-80-S-3-C3-C-00-GBA-42-42-28	SERIES 90	S90-042PV
80001313	MOTOR-VAR-DISPL 51MD160	51D160-R-D4-N-D8-M1-R-J-M4-ADA-064-AA-F3-C2-25	SERIES 51	S51-160MV
80001314	PUMP-VAR-DISPL CW 90PV180	90R180-KP-5-CD-80-T-C-C8-J-03-EBA-35-35-24	SERIES 90	S90-180PV
80001315	MOTOR-VAR-DISPL 51MV060-1	51V060-1--A-C6-N-N1-NN-N-N-U1-NNN-012-AA-E4-00-00	SERIES 51	S51-060MV-1
80001316	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-5-NN-80-S-3-C8-K-03-GLA-35-35-36	SERIES 90	S90-250PV
80001317	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-E2-A5-A-N-A6-ABA-080-AA-G0-03-00	SERIES 51	S51-160MV
80001318	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-D7-M1-S-K-M4-ACA-064-AA-F3-F4-28	SERIES 51	S51-160MV
80001319	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-BC-80-L-3-F1-H-03-GBA-35-35-24	SERIES 90	S90-130PV
80001320	PUMP-VAR-DISPL CW 90PV250	90R250-KP-5-DE-80-T-4-C8-J-03-NNN-42-42-24	SERIES 90	S90-250PV
80001321	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-TH-C2-L-N-G0-NNN-050-AA-G0-00-B2	SERIES 51	S51-250MV
80001322	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-AB-80-S-3-C8-H-03-GLA-35-35-30	SERIES 90	S90-130PV
80001323	PUMP-VAR-DISPL CW 90PV130	90R130-CA-5-AB-80-S-7-C8-F-00-GBA-40-40-24	SERIES 90	S90-130PV
80001324	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-BC-60-L-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-100PV
80001325	MOTOR-VAR-DISPL 51MV110	51V110-R-C8-N-L2-B1-V-A-G0-ABA-M22-AA-F0-B2-00	SERIES 51	S51-110MV
80001326	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-BC-80-R-3-C7-D-03-GBA-42-42-24	SERIES 90	S90-075PV
80001327	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-TA-C2-L-N-G0-NNN-032-AA-NN-00-B0	SERIES 51	S51-160MV
80001328	PUMP-VAR-DISPL CCW 90PV042	90L042-KA-5-BC-80-P-3-C3-C-04-GBA-35-35-24	SERIES 90	S90-042PV
80001329	PUMP-VAR-DISPL CW 90PV130	90R130-DD-5-NN-80-L-4-C8-F-GB-GBA-32-32-24	SERIES 90	S90-130PV
80001332	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-5-NN-80-T-3-C8-K-03-NNN-35-14-24	SERIES 90	S90-250PV
80001333	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-TA-C0-L-N-G0-NNN-115-AA-F3-00-B0	SERIES 51	S51-160MV
80001334	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-TA-C2-L-N-G0-NNN-050-AA-NN-00-B0	SERIES 51	S51-250MV
80001343	PUMP-VAR-DISPL CW 90PV075	90R075-FN-5-AB-60-S-7-C6-D-B6-EFP-38-38-30	SERIES 90	S90-075PV
80001346	MOTOR-VAR-DISPL 51MD080-1	51D080-1--R-D2-N-T1-CA-N-N-X1-NNN-025-AA-E6-00-25	SERIES 51	S51-080MV-1
80001347	MOTOR-VAR-DISPL 51MD160	51D160-A-D4-N-T3-C0-L-N-J1-ADA-040-AA-F0-00-B1	SERIES 51	S51-160MV
80001348	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-AB-80-S-4-F1-H-03-GBA-42-42-24	SERIES 90	S90-130PV
80001351	MOTOR-VAR-DISPL 51MC160	51C160-R-D5-N-TA-C2-L-N-G0-NNN-062-AA-G0-00-A7	SERIES 51	S51-160MV
80001352	MOTOR-VAR-DISPL 51MV080	51V080-A-S1-A-HS-A2-B-H-C1-NNN-023-AA-NN-10-14	SERIES 51	S51-080MV
80001353	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-D-HS-A2-B-H-C1-NNN-060-AA-NN-10-13	SERIES 51	S51-160MV
80001354	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-HS-A2-B-H-C1-NNN-080-AA-NN-10-13	SERIES 51	S51-160MV
80001355	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-HS-A2-B-H-C1-NNN-040-AA-NN-10-13	SERIES 51	S51-080MV
80001356	MOTOR-VAR-DISPL 51MV060	51V060-R-S1-N-HS-A2-B-H-C1-NNN-027-AA-NN-10-13	SERIES 51	S51-060MV

80001357	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-D8-M1-R-J-M1-NNN-073-AA-F0-C2-16	SERIES 51	S51-160MV
80001360	PUMP-VAR-DISPL CW 90PV180	90R180-CA-5-BC-80-S-7-C8-H-00-NNN-35-35-22	SERIES 90	S90-180PV
80001361	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-N-HS-A2-B-H-A7-NNN-032-AA-NN-11-26	SERIES 51	S51-160MV
80001362	PUMP-VAR-DISPL CW 90PV100	90R100-PA-2-BC-60-S-4-C7-E-03-FAX-45-45-28	SERIES 90	S90-100PV
80001363	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-TA-C0-L-N-G0-NNN-032-AA-G0-00-B0	SERIES 51	S51-160MV
80001364	PUMP-VAR-DISPL CCW 90PV042	90L042-HF-5-AB-80-P-4-C3-C-03-GBA-38-38-24	SERIES 90	S90-042PV
80001366	PUMP-VAR-DISPL CCW 90PV042	90L042-KA-5-BC-80-S-4-C3-B-03-GBA-26-26-24	SERIES 90	S90-042PV
80001367	PUMP-VAR-DISPL CCW 90PV130	90L130-DC-5-CD-80-L-3-C8-F-50-GBA-35-35-24	SERIES 90	S90-130PV
80001368	PUMP-VAR-DISPL CCW 90PV100	90L100-DC-5-BC-80-L-4-S1-F-50-GBA-35-35-24	SERIES 90	S90-100PV
80001372	MOTOR-VAR-DISPL 51MC060	51C060-R-D2-N-N2-NN-N-N-A0-NNN-016-AA-E6-00-00	SERIES 51	S51-060MV
80001373	MOTOR-VAR-DISPL 51MV060	51V060-R-S1-N-L7-B1-W-B-G0-ADA-030-AA-F3-D4-00	SERIES 51	S51-060MV
80001374	PUMP-VAR-DISPL CCW 90PV075	90L075-DD-5-CD-60-P-4-C7-D-G8-GBA-29-29-24	SERIES 90	S90-075PV
80001375	PUMP-VAR-DISPL CCW 90PV042	90L042-KA-5-BB-80-S-4-C3-C-03-GBA-35-35-24	SERIES 90	S90-042PV
80001376	PUMP-VAR-DISPL CCW 90PV042	90L042-KA-5-AB-80-S-4-C3-C-03-GBA-35-35-24	SERIES 90	S90-042PV
80001377	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-C8-N-E2-B1-N-N-U1-ADA-045-AA-F3-00-00	SERIES 51	S51-110MV-1
80001378	PUMP-VAR-DISPL CCW 90PV075	90L075-FN-5-CD-60-S-7-C7-D-B6-EFP-45-45-30	SERIES 90	S90-075PV
80001379	PUMP-VAR-DISPL CCW 90PV075	90L075-FN-5-AB-60-S-7-S1-D-B6-EFP-45-45-30	SERIES 90	S90-075PV
80001380	MOTOR-VAR-DISPL 51MV110	51V110-R-D3-N-L2-B1-V-A-J1-ADA-041-AA-F0-B2-00	SERIES 51	S51-110MV
80001382	PUMP-VAR-DISPL CW 90PV042	90R042-HF-5-NN-80-S-4-C3-B-00-GBA-35-35-20	SERIES 90	S90-042PV
80001383	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-S1-N-E1-B1-N-N-U1-NNN-047-AA-G0-00-00	SERIES 51	S51-080MV-1
80001384	PUMP-VAR-DISPL CW 90PV130	90R130-FH-F-DE-80-P-7-C8-F-BA-GBS-40-40-30	SERIES 90	S90-130PV
80001385	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-HZ-B1-C-N-C2-NNN-050-AA-G3-20-00	SERIES 51	S51-250MV
80001386	MOTOR-VAR-DISPL 51MD080-1	51D080-1--A-D2-N-T1-D1-N-N-X1-NNN-054-AA-F3-00-25	SERIES 51	S51-080MV-1
80001387	PUMP-VAR-DISPL CW 90PV130	90R130-KA-2-NN-80-L-3-C8-H-00-EFC-38-38-30	SERIES 90	S90-130PV
80001388	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-L2-B1-V-A-C0-ADA-050-AA-G3-B2-00	SERIES 51	S51-250MV
80001389	PUMP-VAR-DISPL CW 90PV100	90R100-HF-5-CD-60-S-3-C7-E-02-GBA-30-30-24	SERIES 90	S90-100PV
80001390	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-N-N1-NN-N-N-U1-ADA-026-AA-E4-00-00	SERIES 51	S51-060MV-1
80001391	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-D-HS-A2-B-H-C1-NNN-055-AA-NN-10-13	SERIES 51	S51-160MV
80001395	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D3-N-N1-NN-N-N-U1-ADA-026-AA-E4-00-00	SERIES 51	S51-080MV-1
80001396	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-S1-N-N1-NN-N-N-U1-AWP-N38-AA-F0-00-00-P040	SERIES 51	S51-060MV-1
80001398	MOTOR-VAR-DISPL 51MC110	51C110-A-D3-N-HE-B2-C-E-E6-NNN-043-AA-E6-12-00	SERIES 51	S51-110MV
80001399	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-NN-60-S-3-C7-D-09-GBA-30-30-30	SERIES 90	S90-075PV
80001400	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-BC-80-R-3-S1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
80001401	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-CD-80-R-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-075PV
80001402	PUMP-VAR-DISPL CW 90PV100	90R100-HM-5-BC-80-L-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
80001404	MOTOR-VAR-DISPL 51MC080	51C080-R-D2-N-HZ-B1-A-H-G5-NNN-050-AA-E6-03-00	SERIES 51	S51-080MV

80001405	PUMP-VAR-DISPL CW 90PV250	90R250-KP-5-CD-80-T-4-C8-K-00-NNN-38-38-24	SERIES 90	S90-250PV
80001406	PUMP-VAR-DISPL CCW 90PV130	90L130-KN-5-DE-80-L-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-130PV
80001407	PUMP-VAR-DISPL CCW 90PV130	90L130-KN-5-NN-80-L-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-130PV
80001408	PUMP-VAR-DISPL CW 90PV130	90R130-HS-5-DE-80-R-4-F1-H-00-GBA-17-26-24	SERIES 90	S90-130PV
80001409	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-F1-B1-N-N-U1-NNN-037-AA-E6-00-00	SERIES 51	S51-110MV-1
80001410	PUMP-VAR-DISPL CW 90PV130	90R130-KN-5-AB-80-S-4-F1-H-02-GBA-42-42-24	SERIES 90	S90-130PV
80001411	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-BC-60-S-3-C7-F-03-GBA-45-45-24	SERIES 90	S90-100PV
80001412	MOTOR-VAR-DISPL 51MV160	51V160-R-F2-N-E2-A1-A-N-E2-NNN-060-AA-F3-03-20	SERIES 51	S51-160MV
80001413	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-AB-80-L-3-S1-D-00-GBA-32-32-24	SERIES 90	S90-075PV
80001414	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-BC-80-S-4-S1-D-03-GBA-26-26-24	SERIES 90	S90-075PV
80001415	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-S1-N-E1-B1-N-N-U1-NNN-047-AA-G0-00-00	SERIES 51	S51-080MV-1
80001416	PUMP-VAR-DISPL CW 90PV075	90R075-DD-5-CD-60-L-3-C7-E-GB-GBA-35-35-24	SERIES 90	S90-075PV
80001417	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-NN-60-L-4-TG-E-03-GBA-35-35-24	SERIES 90	S90-075PV
80001419	MOTOR-VAR-DISPL 51MV060-1	51V060-1--R-S1-N-E2-B1-N-N-U1-ACB-028-AA-E6-00-00	SERIES 51	S51-060MV-1
80001420	PUMP-VAR-DISPL CW 90PV250	90R250-KP-5-DE-80-T-3-F1-K-03-NNN-42-42-24	SERIES 90	S90-250PV
80001421	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-N1-NN-N-N-U1-NNN-060-AA-E6-00-00	SERIES 51	S51-110MV-1
80001422	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-CD-60-S-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-075PV
80001423	MOTOR-VAR-DISPL 51MV060	51V060-R-S1-C-HS-A2-B-H-C1-NNN-027-AA-NN-10-13	SERIES 51	S51-060MV
80001424	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-TA-C2-L-N-G0-NNN-064-AA-F3-00-B1	SERIES 51	S51-160MV
80001426	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-D8-M1-R-J-N2-NNN-025-AA-F3-C2-20	SERIES 51	S51-080MV
80001427	PUMP-VAR-DISPL CW 90PV075	90R075-FN-P-NN-80-P-D-S1-N-B6-GME-48-48-30	SERIES 90	S90-075PV
80001428	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-CD-60-L-3-S1-D-03-GBA-26-26-24	SERIES 90	S90-075PV
80001429	PUMP-VAR-DISPL CCW 90PV180	90L180-HF-5-NN-80-T-C-F1-J-03-FAC-35-35-24	SERIES 90	S90-180PV
80001430	PUMP-VAR-DISPL CCW 90PV130	90L130-DC-5-BC-80-R-3-F1-H-G8-GBA-38-38-24	SERIES 90	S90-130PV
80001431	PUMP-VAR-DISPL CW 90PV075	90R075-FN-5-CD-60-S-7-C7-E-B6-GMD-45-45-30	SERIES 90	S90-075PV
80001432	PUMP-VAR-DISPL CW 90PV075	90R075-CA-5-AB-60-P-7-S1-D-00-GLA-40-40-28	SERIES 90	S90-075PV
80001433	PUMP-VAR-DISPL CW 90PV075	90R075-FM-5-CD-60-P-7-C7-D-B6-GMD-40-40-28	SERIES 90	S90-075PV
80001434	MOTOR-VAR-DISPL 51MV110	51V110-R-F1-N-HS-A2-B-H-E1-NNN-043-AA-NN-10-17	SERIES 51	S51-110MV
80001435	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-NN-80-R-4-F1-H-03-GBA-35-14-24	SERIES 90	S90-130PV
80001436	MOTOR-VAR-DISPL 51MV160	51V160-A-C8-N-T2-C0-L-N-G0-ADA-049-AA-F3-00-C0	SERIES 51	S51-160MV
80001437	MOTOR-VAR-DISPL 51MV250	51V250-A-C8-N-N2-NN-N-N-A0-ADA-125-AA-F3-00-00	SERIES 51	S51-250MV
80001438	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-DE-80-S-3-C8-K-03-NNN-42-42-24	SERIES 90	S90-250PV
80001439	PUMP-VAR-DISPL CCW 90PV130	90L130-MB-5-NN-80-P-3-F1-F-C6-GBA-42-42-24	SERIES 90	S90-130PV
80001440	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-EQ-A2-J-Y-M2-NNN-115-AA-G3-30-28	SERIES 51	S51-160MV
80001441	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-5-EF-80-S-3-C8-K-00-NNN-35-14-30	SERIES 90	S90-250PV
80001445	PUMP-VAR-DISPL CW 90PV250	90R250-KP-5-NN-80-T-3-F1-J-03-NNN-17-17-18	SERIES 90	S90-250PV

80001446	PUMP-VAR-DISPL CCW 90PV042	90L042-KA-5-AB-80-R-3-TL-C-03-GBA-29-29-24	SERIES 90	S90-042PV
80001448	PUMP-VAR-DISPL CW 90PV130	90R130-KN-5-NN-80-S-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-130PV
80001450	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-5-BC-80-T-3-C8-K-03-NNN-38-38-24	SERIES 90	S90-250PV
80001451	PUMP-VAR-DISPL CW 90PV250	90R250-MA-5-CD-80-T-3-C8-K-C5-NNN-26-26-24	SERIES 90	S90-250PV
80001452	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-BC-80-S-C-F1-J-00-NNN-35-14-30	SERIES 90	S90-180PV
80001453	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-NN-60-S-3-C7-D-03-GBA-38-38-20	SERIES 90	S90-075PV
80001454	PUMP-VAR-DISPL CW 90PV042	90R042-FD-5-BC-80-P-7-C3-C-B4-EFI-35-35-32	SERIES 90	S90-042PV
80001455	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-DE-80-S-3-C8-H-03-GBA-30-30-24	SERIES 90	S90-130PV
80001456	PUMP-VAR-DISPL CW 90PV075	90R075-MA-5-NN-60-S-4-S1-D-C5-GBA-35-35-24	SERIES 90	S90-075PV
80001457	PUMP-VAR-DISPL CW 90PV075	90R075-MA-5-CD-60-S-4-C6-D-C5-GBA-35-35-24	SERIES 90	S90-075PV
80001458	MOTOR-VAR-DISPL 51MC080	51C080-R-D2-N-HZ-B1-A-E-G0-NNN-040-AA-F0-03-00	SERIES 51	S51-080MV
80001459	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-DE-80-R-3-C8-H-05-GBA-30-30-30	SERIES 90	S90-130PV
80001460	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-N2-NN-N-N-A0-NNN-050-AA-NN-00-00	SERIES 51	S51-250MV
80001461	PUMP-VAR-DISPL CW 90PV075	90R075-DD-5-CD-60-S-4-C7-D-GB-GBA-40-40-24	SERIES 90	S90-075PV
80001462	PUMP-VAR-DISPL CW 90PV075	90R075-HF-5-NN-60-R-3-S1-E-03-GBA-38-38-26	SERIES 90	S90-075PV
80001463	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-NN-80-S-3-F1-H-03-GBA-30-30-24	SERIES 90	S90-130PV
80001464	PUMP-VAR-DISPL CW 90PV075	90R075-PB-5-CD-80-R-3-C7-E-06-FAP-38-41-24	SERIES 90	S90-075PV
80001465	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-NN-80-R-3-F1-F-05-GBA-30-30-30	SERIES 90	S90-100PV
80001466	MOTOR-VAR-DISPL 51MV160	51V160-A-C8-N-D7-M1-S-K-M4-ADA-032-AA-F3-F4-32	SERIES 51	S51-160MV
80001467	PUMP-VAR-DISPL CCW 90PV250	90L250-KP-5-CD-80-T-4-F1-J-03-NNN-32-32-24	SERIES 90	S90-250PV
80001468	PUMP-VAR-DISPL CW 90PV180	90R180-KP-5-CD-80-T-C-C8-J-03-EHA-35-35-24	SERIES 90	S90-180PV
80001469	PUMP-VAR-DISPL CCW 90PV075	90L075-MA-5-NN-60-S-3-S1-D-C5-GBA-42-42-24	SERIES 90	S90-075PV
80001470	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-NN-80-P-3-C7-D-03-GBA-32-32-24	SERIES 90	S90-075PV
80001471	MOTOR-VAR-DISPL 51MV080	51V080-A-S1-N-L1-B1-W-B-G5-NNN-016-AA-E4-D4-00	SERIES 51	S51-080MV
80001472	PUMP-VAR-DISPL CW 90PV075	90R075-DD-5-BC-60-S-4-S1-D-GB-GBA-40-40-24	SERIES 90	S90-075PV
80001473	PUMP-VAR-DISPL CCW 90PV075	90L075-MA-5-CD-60-S-3-S1-D-C6-GBA-21-21-24	SERIES 90	S90-075PV
80001475	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-BC-80-L-3-F1-F-03-GBA-32-32-24	SERIES 90	S90-130PV
80001476	PUMP-VAR-DISPL CW 90PV130	90R130-MA-5-CD-80-L-3-F1-F-C4-GBA-23-23-24	SERIES 90	S90-130PV
80001479	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A4-C2-N-D3-G-G3-H3-L-40-L-40-A-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
80001481	PUMP-VAR-DISPL CW 90PV100	90R100-KP-5-CD-60-L-3-C7-E-03-GBA-38-14-24	SERIES 90	S90-100PV
80001482	PUMP-VAR-DISPL CW 90PV130	90R130-HF-5-DG-80-S-3-C8-H-03-GBA-42-42-24	SERIES 90	S90-130PV
80001483	PUMP-VAR-DISPL CCW 90PV042	90L042-MA-5-NN-80-P-3-C3-B-C5-GBA-35-35-24	SERIES 90	S90-042PV
80001485	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-ES-A3-K-Y-E5-ACA-039-AA-F3-85-35	SERIES 51	S51-160MV
80001486	PUMP-VAR-DISPL CW 90PV100	90R100-DD-5-AB-80-L-3-C7-E-GB-GBA-30-30-24	SERIES 90	S90-100PV
80001487	MOTOR-VAR-DISPL 51MC080	51C080-R-D3-N-HZ-B1-B-E-C2-ANA-050-AA-F0-10-00	SERIES 51	S51-080MV
80001491	PUMP-VAR-DISPL CW 90PV250	90R250-HS-5-EF-80-T-3-C8-K-03-NNN-35-35-24	SERIES 90	S90-250PV

80001492	PUMP-VAR-DISPL CCW 90PV180	90L180-HF-2-BC-80-T-C-F1-J-03-FAC-32-32-24	SERIES 90	S90-180PV
80001493	PUMP-VAR-DISPL CW 90PV075	90R075-KP-5-AB-60-L-3-S1-D-00-EAB-38-14-24	SERIES 90	S90-075PV
80001494	PUMP-VAR-DISPL CW 90PV100	90R100-HF-5-BC-60-S-4-C7-E-01-GBA-45-45-24	SERIES 90	S90-100PV
80001495	PUMP-VAR-DISPL CCW 90PV130	90L130-MB-1-NN-80-S-3-C8-H-05-GBA-35-35-24	SERIES 90	S90-130PV
80001496	MOTOR-VAR-DISPL 51MV110	51V110-R-F1-N-HS-A2-B-E-E1-NNN-030-AA-NN-10-29	SERIES 51	S51-110MV
80001498	PUMP-VAR-DISPL CW 90PV100	90R100-DC-5-BC-60-P-4-C7-E-G8-GBA-30-30-24	SERIES 90	S90-100PV
80001499	MOTOR-VAR-DISPL 51MC080	51C080-R-D2-N-L1-B1-W-B-G5-ACA-025-AA-E6-D4-00	SERIES 51	S51-080MV
80001502	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-DE-80-T-C-C8-J-00-EEB-42-42-24	SERIES 90	S90-180PV
80001503	PUMP-VAR-DISPL CCW 90PV180	90L180-FH-5-CD-80-T-7-C8-J-B9-EFI-42-42-30	SERIES 90	S90-180PV
80001504	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-DE-80-L-3-C8-F-03-GBA-42-42-24	SERIES 90	S90-130PV
80001505	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-NN-80-L-3-F1-F-03-GBA-42-42-24	SERIES 90	S90-130PV
80001506	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-CD-80-T-3-C8-K-03-NNN-42-42-24	SERIES 90	S90-250PV
80001507	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-D8-M1-R-J-N7-ADA-085-AA-G3-C2-36	SERIES 51	S51-160MV
80001508	MOTOR-VAR-DISPL 51MV250	51V250-A-C8-N-TA-C2-L-N-G0-ADA-168-AA-H0-00-C5	SERIES 51	S51-250MV
80001511	MOTOR-VAR-DISPL 51MV080-1	51V080-1--A-S1-N-N1-NN-N-N-U1-NNN-043-AA-NN-00-00	SERIES 51	S51-080MV-1
80001512	MOTOR-VAR-DISPL 51MV080-1	51V080-1--A-S1-N-N1-NN-N-N-U1-ABA-043-AA-NN-00-00	SERIES 51	S51-080MV-1
80001513	MOTOR-VAR-DISPL 51MC080	51C080-R-D2-N-L1-B1-W-B-G5-NNN-025-AA-E6-D4-00	SERIES 51	S51-080MV
80001514	PUMP-VAR-DISPL CW 90PV075	90R075-FN-5-AB-60-P-7-C7-D-B6-GMD-42-42-30	SERIES 90	S90-075PV
80001522	MOTOR-VAR-DISPL 51MC160	51C160-R-D5-N-HZ-B1-A-N-C2-NNN-080-AA-NN-03-00	SERIES 51	S51-160MV
80001532	MOTOR-VAR-DISPL 51MV160	51V160-A-C8-N-HZ-B1-B-E-C2-NNN-032-AA-NN-05-00	SERIES 51	S51-160MV
80001533	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-T2-C0-L-N-K7-ACA-050-AA-F3-00-B7	SERIES 51	S51-250MV
80001534	MOTOR-VAR-DISPL 51MC060	51C060-R-D1-N-N2-NN-N-N-A0-NNN-028-AA-E6-00-00	SERIES 51	S51-060MV
80001535	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-5-NN-80-T-4-F1-J-04-NNN-23-23-24	SERIES 90	S90-250PV
80001536	PUMP-VAR-DISPL CCW 90PV100	90L100-HF-5-BC-80-S-4-S1-E-03-GBA-17-17-20	SERIES 90	S90-100PV
80001537	PUMP-VAR-DISPL CCW 90PV100	90L100-HF-5-CD-80-S-4-F1-E-03-GBA-17-17-20	SERIES 90	S90-100PV
80001542	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-E1-B1-N-N-U1-NNN-053-AA-F0-00-00	SERIES 51	S51-110MV-1
80001543	MOTOR-VAR-DISPL 51MV110-1	51V110-1--A-F1-N-E1-B1-N-N-U1-NNN-055-AA-G0-00-00	SERIES 51	S51-110MV-1
80001544	PUMP-VAR-DISPL CW 90PV130	90R130-HS-5-BC-80-L-4-F1-H-01-GBA-32-32-24	SERIES 90	S90-130PV
80001545	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-T1-C0-L-N-K7-NNN-055-AA-F3-00-C5	SERIES 51	S51-160MV
80001552	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-N2-NN-N-N-A0-ADA-050-AA-H0-00-00	SERIES 51	S51-250MV
80001553	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-NN-60-L-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
80001554	PUMP-VAR-DISPL CCW 90PV180	90L180-KP-5-BC-80-T-M-F1-J-03-FAC-32-32-24	SERIES 90	S90-180PV
80001555	PUMP-VAR-DISPL CW 90PV100	90R100-KA-2-BC-80-L-3-C7-E-00-GBA-35-35-24	SERIES 90	S90-100PV
80001556	PUMP-VAR-DISPL CCW 90PV075	90L075-DC-5-NN-60-S-4-S1-D-GF-GBA-40-40-24	SERIES 90	S90-075PV
80001557	MOTOR-VAR-DISPL 51MC060	51C060-A-D1-N-JA-NN-B-H-K3-ADA-031-AA-F0-05-20	SERIES 51	S51-060MV
80001558	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-NN-80-P-3-C7-E-04-GBA-45-45-24	SERIES 90	S90-075PV

80001559	MOTOR-VAR-DISPL 51MD160	51D160-R-D4-N-EQ-A5-J-Y-A6-ADA-060-AA-F3-40-00	SERIES 51	S51-160MV
80001560	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-BC-60-R-4-S1-E-03-GBA-32-32-24	SERIES 90	S90-100PV
80001562	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-T1-L5-L-N-G0-NNN-068-AA-F3-00-B5	SERIES 51	S51-160MV
80001563	PUMP-VAR-DISPL CW 90PV100	90R100-DD-5-BC-60-S-4-S1-E-GB-GBA-42-42-24	SERIES 90	S90-100PV
80001567	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-AB-80-S-4-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
80001568	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-BC-60-S-3-C7-E-03-GBA-38-38-24	SERIES 90	S90-100PV
80001569	MOTOR-VAR-DISPL 51MC110-1	51C110-1--R-D3-B-B2-B3-N-N-U3-ADA-027-AA-H0-00-00	SERIES 51	S51-110MV-1
80001570	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-B-B2-B3-N-N-U3-ADA-022-AA-NN-00-00	SERIES 51	S51-060MV-1
80001571	MOTOR-VAR-DISPL 51MD110-1	51D110-1--R-D4-N-E2-B1-N-N-U1-AWM-040-AA-F3-00-00	SERIES 51	S51-110MV-1
80001572	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-BC-60-P-3-C7-D-04-EFC-30-30-20	SERIES 90	S90-075PV
80001589	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-1-NN-80-R-4-S1-C-03-GBA-32-32-24	SERIES 90	S90-055PV
80001590	MOTOR-VARIABLE CARTRIDGE L	L-C-35E5-A-RNF-F07-S-N-N-BF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
80001591	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-D8-M1-R-J-N1-ADA-050-AA-H0-C2-35	SERIES 51	S51-250MV
80001596	PUMP-VAR DISPL MPV046C	MPV-046-C-B-A-H-S-B-AA-A-A-BJJ-AB-D-DD-A-NNN-***	M46	M46-046PV
80001597	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-5-BC-60-L-3-C6-C-03-GBA-35-35-20	SERIES 90	S90-055PV
80001598	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-5-NN-81-R-3-S1-D-C5-GBA-42-42-24	SERIES 90	S90-075PV
80001602	MOTOR-VARIABLE DISPL SAE_K	K-V-45DN-A-YNF-F09-S-N-N-AF-F16-NNN-NNN	LV / KV MOTORS	L/K-MV
80001603	MOTOR-VARIABLE DISPL SAE_L	L-V-35EN-A-YNF-F55-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
80001604	MOTOR-VARIABLE DISPL SAE_L	L-V-35EN-A-YNF-F11-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
80001605	MOTOR-VARIABLE DISPL SAE_K	K-V-45DN-A-YNF-F11-S-N-N-AF-F16-NNN-NNT	LV / KV MOTORS	L/K-MV
80001606	MOTOR-VARIABLE DISPL SAE_K	K-V-45DN-A-YNF-F55-S-N-N-AF-F16-NNN-NNT	LV / KV MOTORS	L/K-MV
80001607	MOTOR-VARIABLE DISPL SAE_L	L-V-35EN-A-YNF-F06-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
80001608	MOTOR-VARIABLE DISPL SAE_L	L-V-30DN-A-YNF-F95-S-N-N-AF-F18-NNN-NNT	LV / KV MOTORS	L/K-MV
80001609	MOTOR-VARIABLE DISPL SAE_L	L-V-30DN-A-YNF-F55-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
80001611	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-BB-60-S-4-S1-E-00-GBA-23-23-24	SERIES 90	S90-075PV
80001612	PUMP-VAR DISPL S40PV046C	MPV-046-C-B-B-G-S-B-J-AA-G-A-BDD-CD-A-GG-C-NNN-***	M46	M46-046PV
80001613	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-BC-60-S-4-S1-E-00-GBA-23-23-24	SERIES 90	S90-075PV
80001616	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-5-NN-80-P-4-S1-C-03-GBA-23-23-24	SERIES 90	S90-055PV
80001626	PUMP-VAR DISPL MPV044D	MPV-044-D-B-A-A-R-S-G-AA-A-A-BJJ-DL-A-FF-B-NNN-***	M35/44	044PV
80001627	PUMP-VAR DISPL MPV046C	MPV-046-C-B-A-K-T-B-B-AA-A-A-BHH-AB-U-ED-B-NNN-***	M46	M46-046PV
80001628	PUMP-VAR DISPL, CW 90PV055	90-R-055-MB-1-CD-80-R-3-S1-C-02-GBA-38-38-24	SERIES 90	S90-055PV
80001629	PUMP-VAR DISPL, CW 90PV055	90-R-055-MB-1-BG-80-R-3-S1-C-02-GBA-38-38-24	SERIES 90	S90-055PV
80001630	PUMP-VAR-DISPL CW 90PV100	90R100-FH-5-CD-60-S-7-C7-E-B1-EFI-40-40-30	SERIES 90	S90-100PV
80001632	PUMP-VAR-DISPL CW 90PV250	90R250-KP-5-EG-80-S-4-C8-J-03-NNN-26-26-24	SERIES 90	S90-250PV
80001633	PUMP-VAR-DISPL CW 90PV250	90R250-KP-5-NN-80-S-4-C8-J-03-NNN-26-26-24	SERIES 90	S90-250PV
80001634	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-AB-80-P-3-F1-F-00-GBA-42-42-24	SERIES 90	S90-100PV

80001640	PUMP-VAR DISPL, CW 90PV075	90-R-075-KN-1-BC-60-S-4-K2-D-02-GBA-14-32-24	SERIES 90	S90-075PV
80001642	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-NN-60-P-3-S1-D-00-GBA-42-42-24	SERIES 90	S90-075PV
80001642C	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-NN-60-P-3-S1-D-00-GBA-42-42-24	SERIES 90	S90-075PV
80001643	PUMP-VAR-DISPL CCW 90PV180	90L180-KP-5-CD-80-T-M-C8-J-03-FAC-32-32-24	SERIES 90	S90-180PV
80001644	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-AB-60-P-3-S1-D-00-GBA-42-42-24	SERIES 90	S90-075PV
80001644C	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-AB-60-P-3-S1-D-00-GBA-42-42-24	SERIES 90	S90-075PV
80001645	PUMP-VAR DISPL, CW 90PV055	90-R-055-HF-5-CD-80-R-3-S1-D-03-GBA-38-38-24	SERIES 90	S90-055PV
80001647	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-2-BC-80-P-3-F1-F-03-GBA-45-14-24	SERIES 90	S90-100PV
80001648	PUMP-VAR DISPL, CW 90PV100	90-R-100-MB-1-BC-60-P-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
80001649	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A4-C3-N-D1-F-G5-H1-25-25-25-25-N-P-22-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
80001652	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-E2-A2-A-N-E1-NNN-100-AA-F3-03-37	SERIES 51	S51-160MV
80001653	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-L2-B1-V-A-C0-NNN-050-AA-NN-B2-00	SERIES 51	S51-250MV
80001656	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-NN-60-L-3-F1-E-03-GBA-14-32-32	SERIES 90	S90-100PV
80001658	PUMP-VAR DISPL, CW S42PVR	42-R-41-D-A1N5-02-B-2-X-N-G-N-V-34-34-B-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
80001659	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HK-5-NN-60-P-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
80001660	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A2-C3-N-E7-F-G1-H3-42-42-42-42-N-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
80001661	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-2-NN-60-S-3-C7-D-03-GBA-42-42-24	SERIES 90	S90-075PV
80001661C	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-2-NN-60-S-3-C7-D-03-GBA-42-42-24	SERIES 90	S90-075PV
80001664	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-1-AD-80-P-4-S1-C-03-GBA-20-20-24	SERIES 90	S90-055PV
80001665	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-D-Z-C-S-AA-B-B-B-A-BGG-BB-A-HH-B-D-B-A-BGG-BB-A-HH-D-NNN-	M46	M46-046PT
80001666	PUMP-VAR-DISPL CW 90PV100	90R100-HF-5-BC-80-L-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-100PV
80001667	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-HS-A2-B-H-E1-NNN-032-AA-F0-12-20	SERIES 51	S51-160MV
80001668	PUMP-VAR-DISPL CW 90PV075	90R075-MA-5-NN-60-S-3-S1-D-C4-GBA-32-32-24	SERIES 90	S90-075PV
80001674	PUMP-VAR-DISPL CCW 90PV180	90L180-KP-2-NN-80-T-M-F1-H-03-FAC-35-35-24	SERIES 90	S90-180PV
80001675	PUMP-VAR-DISPL CCW 90PV180	90L180-KP-2-NN-80-T-C-F1-H-03-FAC-35-35-24	SERIES 90	S90-180PV
80001676	MOTOR-FIX DISPL S40MF044D	MMF-044-D-A-F-H-C-D-NNR-***	M35/44	044MF
80001678	MOTOR-VAR-DISPL 51MV080-1	51V080-1--A-S1-N-N1-NN-N-N-U1-ABA-040-AA-F0-00-00	SERIES 51	S51-080MV-1
80001679	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-5-NN-80-S-3-C8-K-00-EFI-30-30-24	SERIES 90	S90-250PV
80001683	MOTOR-VAR-DISPL 51MD080-1	51D080-1--R-D3-N-F1-B1-N-N-U1-NNN-030-AA-F0-00-00	SERIES 51	S51-080MV-1
80001685	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-NN-80-T-C-F1-J-05-FAC-20-20-24	SERIES 90	S90-180PV
80001686	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-BC-80-S-4-C7-E-03-GBA-35-35-24	SERIES 90	S90-075PV
80001686C	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-BC-80-S-4-C7-E-03-GBA-35-35-24	SERIES 90	S90-075PV
80001687	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-NN-80-S-4-C7-E-03-GBA-35-35-24	SERIES 90	S90-075PV
80001687C	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-NN-80-S-4-C7-E-03-GBA-35-35-24	SERIES 90	S90-075PV
80001688	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-BB-80-R-3-F1-F-00-GBA-29-29-24	SERIES 90	S90-100PV
80001688C	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-BB-80-R-3-F1-F-00-GBA-29-29-24	SERIES 90	S90-100PV

80001690	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HK-5-NN-80-R-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-075PV
80001691	PUMP-VAR DISPL S40PV046C	MPV-046-C-B-B-Z-T-B-B-AA-J-A-BGG-DA-A-WB-C-NNN-***	M46	M46-046PV
80001692	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-BC-60-P-3-C7-D-04-GBA-30-30-20	SERIES 90	S90-075PV
80001706	MOTOR-VAR-DISPL 51MV110	51V110-R-C8-N-HZ-B1-A-E-C2-NNN-038-AA-G3-03-00	SERIES 51	S51-110MV
80001707	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KN-1-CD-80-S-4-S1-C-03-GBA-20-20-24	SERIES 90	S90-055PV
80001707C	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KN-1-CD-80-S-4-S1-C-03-GBA-20-20-24	SERIES 90	S90-055PV
80001708	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KN-1-BG-80-S-4-S1-C-03-GBA-32-32-24	SERIES 90	S90-055PV
80001708C	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KN-1-BG-80-S-4-S1-C-03-GBA-32-32-24	SERIES 90	S90-055PV
80001709	PUMP-VAR DISPL, CW 90PV100	90-R-100-HS-1-CD-80-S-3-C7-E-03-GBA-29-29-24	SERIES 90	S90-100PV
80001709C	PUMP-VAR DISPL, CW 90PV100	90-R-100-HS-1-CD-80-S-3-C7-E-03-GBA-29-29-24	SERIES 90	S90-100PV
80001710	PUMP-VAR DISPL, CW 90PV055	90-R-055-HS-1-NN-80-S-3-C6-C-03-GBA-29-29-24	SERIES 90	S90-055PV
80001710C	PUMP-VAR DISPL, CW 90PV055	90-R-055-HS-1-NN-80-S-3-C6-C-03-GBA-29-29-24	SERIES 90	S90-055PV
80001711	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KN-1-NN-80-S-4-S1-D-03-GBA-23-23-24	SERIES 90	S90-075PV
80001711C	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KN-1-NN-80-S-4-S1-D-03-GBA-23-23-24	SERIES 90	S90-075PV
80001712	PUMP-VAR-DISPL CCW 90PV042	90L042-KA-5-AB-80-R-3-C3-C-03-GBA-29-29-24	SERIES 90	S90-042PV
80001713	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KN-1-NN-80-S-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
80001713C	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KN-1-NN-80-S-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
80001727	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-2-BC-60-S-3-C7-D-04-GBA-38-38-24	SERIES 90	S90-075PV
80001729	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-EG-80-S-C-C8-J-09-NNN-35-35-28	SERIES 90	S90-180PV
80001730	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-BC-80-S-C-C8-J-09-NNN-35-35-28	SERIES 90	S90-180PV
80001735	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-E-Z-C-B-AA-B-B-A-A-BJJ-CD-A-GG-B-D-A-A-BJJ-CD-A-GG-A-NNN-**	M46	M46-046PT
80001741	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-NN-80-P-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-075PV
80001744	PUMP-VAR-DISPL CCW 90PV100	90L100-FD-5-NN-80-R-7-C7-E-B1-EFI-42-42-24	SERIES 90	S90-100PV
80001745	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-N-E2-R2-A-N-E3-NNN-050-AA-F3-03-30	SERIES 51	S51-250MV
80001746	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-N-E2-A2-A-N-E1-NNN-050-AA-F3-03-30	SERIES 51	S51-250MV
80001747	PUMP-VAR-DISPL CW 90PV100	90R100-KN-5-NN-60-S-3-C7-F-03-GBA-38-38-24	SERIES 90	S90-100PV
80001748	PUMP-VAR-DISPL CCW 90PV180	90L180-HF-5-NN-80-T-C-F1-J-03-NNN-38-38-24	SERIES 90	S90-180PV
80001749	PUMP-VAR-DISPL CCW 90PV042	90L042-KA-5-BB-80-P-3-C3-B-04-GBA-32-32-20	SERIES 90	S90-042PV
80001750	PUMP-VAR-DISPL CCW 90PV042	90L042-KA-5-NN-80-P-3-C3-B-04-GBA-32-32-20	SERIES 90	S90-042PV
80001752	PUMP-VAR-DISPL, CW, S42PV041, MDC	42-R-41-C-ANN3-03-D-N-F-2-F-N-A-23-23-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
80001754	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-K-S-B-J-AA-G-A-BJJ-DA-A-ZA-B-NNR-***	M46	M46-046PV
80001757	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HK-1-BC-60-R-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
80001761	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-A-V-C-B-BA-B-B-A-A-BGG-CE-A-HH-B-D-A-A-BGG-CE-A-HH-A-NNN-	M46	M46-046PT
80001762	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-1-NN-60-L-3-C6-D-03-GBA-42-42-24	SERIES 90	S90-075PV
80001763	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-NN-80-S-3-F1-F-03-GBA-26-26-24	SERIES 90	S90-130PV
80001768	PUMP-VAR-DISPL CW 90PV130	90R130-MA-5-NN-80-P-4-F1-H-C5-GBA-42-42-24	SERIES 90	S90-130PV

80001769	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-CD-80-R-3-S1-E-06-GBA-35-35-24	SERIES 90	S90-075PV
80001771	PUMP-VAR DISPL, CW 90PV075	90-R-075-M1-1-CD-60-X-3-C7-D-04-GBA-42-42-24	SERIES 90	S90-075PV
80001783	PUMP-VAR DISPL, CW 90PV055	90-R-055-CA-2-AD-80-P-3-S1-C-00-GBA-35-35-24	SERIES 90	S90-055PV
80001784	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-TA-C2-L-N-G0-NNN-107-AA-F0-00-A8	SERIES 51	S51-160MV
80001785	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-HZ-B1-A-N-G0-NNN-055-AA-F0-03-00	SERIES 51	S51-160MV
80001788	PUMP-VAR-DISPL CW 90PV130	90R130-KN-5-CD-80-S-4-C8-H-03-GBA-23-23-24	SERIES 90	S90-130PV
80001789	PUMP-VAR-DISPL CW 90PV075	90R075-KN-5-NN-80-S-3-S1-E-03-GBA-20-20-24	SERIES 90	S90-075PV
80001791	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-D-Z-C-S-AA-B-B-V-A-BGG-BB-A-HH-B-D-V-A-BGG-BB-A-HH-D-NNN-	M46	M46-046PT
80001792	PUMP-VAR DISPL, CW 90PV075	90-R-075-M1-1-NN-60-X-3-S1-D-04-GBA-42-42-24	SERIES 90	S90-075PV
80001793	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-E-V-C-B-BA-B-B-A-A-BRR-BC-A-HH-B-D-A-A-BRR-BC-A-HH-D-NNN-*	M46	M46-046PT
80001796	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-E2-A2-A-N-E1-NNN-109-AA-G0-03-25	SERIES 51	S51-250MV
80001797	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-BB-80-S-7-C7-E-09-FAZ-35-35-28	SERIES 90	S90-100PV
80001798	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-E2-A2-A-N-E1-NNN-123-AA-G0-03-25	SERIES 51	S51-250MV
80001799	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-NN-60-P-3-S1-D-00-GBA-42-42-24	SERIES 90	S90-075PV
80001799C	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-NN-60-P-3-S1-D-00-GBA-42-42-24	SERIES 90	S90-075PV
80001800	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-AB-60-P-3-S1-D-00-GBA-42-42-24	SERIES 90	S90-075PV
80001800C	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-AB-60-P-3-S1-D-00-GBA-42-42-24	SERIES 90	S90-075PV
80001801	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-NN-60-P-3-C7-E-03-GBA-38-38-24	SERIES 90	S90-100PV
80001801C	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-NN-60-P-3-C7-E-03-GBA-38-38-24	SERIES 90	S90-100PV
80001802	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-CD-60-P-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
80001802C	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-CD-60-P-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
80001803	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-NN-80-S-4-C6-E-03-EBC-32-32-20	SERIES 90	S90-075PV
80001803C	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-NN-80-S-4-C6-E-03-EBC-32-32-20	SERIES 90	S90-075PV
80001804	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D3-N-E2-B1-N-N-U1-ADA-027-AA-E6-00-00	SERIES 51	S51-080MV-1
80001806	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D3-N-E2-B1-N-N-U1-NNN-034-AA-E6-00-00	SERIES 51	S51-080MV-1
80001808	PUMP-VAR-DISPL CCW 90PV042	90L042-KA-5-AB-80-S-3-C3-B-03-GBA-38-38-20	SERIES 90	S90-042PV
80001809	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-AB-80-S-3-C3-B-03-GBA-38-38-20	SERIES 90	S90-042PV
80001810	PUMP-VAR DISPL, CW 90PV100	90-R-100-KN-5-CD-60-D-4-F1-L-03-GBA-35-35-28	SERIES 90	S90-100PV
80001811	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KN-5-CD-60-D-4-F1-L-03-GBA-35-35-28	SERIES 90	S90-100PV
80001815	PUMP-VAR DISPL MPV046C	MPV-046-C-B-A-K-T-B-B-AA-A-A-BHH-AB-U-AA-B-NNN-***	M46	M46-046PV
80001817	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-T-B-B-AA-A-A-BGG-CE-A-GG-A-NNN-***	M46	M46-046PV
80001819	MOTOR-VARIABLE DISPL SAE_L	L-V-30DN-A-RNF-F10-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
80001823	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KN-5-CD-80-D-4-F1-L-03-GBA-35-35-28	SERIES 90	S90-100PV
80001824	PUMP-VAR DISPL, CCW 90PV075	90-L-075-LB-6-NN-60-R-3-S1-E-04-FAC-45-45-24-L001	SERIES 90	S90-075PV
80001825	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-CD-80-P-3-C6-D-03-EHA-40-40-24	SERIES 90	S90-055PV
80001825C	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-CD-80-P-3-C6-D-03-EHA-40-40-24	SERIES 90	S90-055PV

80001826	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-AD-80-P-3-C6-D-03-EBC-29-29-24	SERIES 90	S90-055PV
80001826C	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-AD-80-P-3-C6-D-03-EBC-29-29-24	SERIES 90	S90-055PV
80001827	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-NN-60-S-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-100PV
80001827C	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-NN-60-S-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-100PV
80001828	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-CD-80-P-3-C7-F-03-GBA-23-23-24	SERIES 90	S90-100PV
80001828C	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-CD-80-P-3-C7-F-03-GBA-23-23-24	SERIES 90	S90-100PV
80001829	MOTOR-VAR-DISPL 51MC080-1	51C080-1--A-D2-N-E1-B1-N-N-U1-NNN-047-AA-E6-00-00	SERIES 51	S51-080MV-1
80001830	MOTOR-VARIABLE CARTRIDGE K	K-C-38CN-A-R3F-F10-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
80001831	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-T1-R5-L-N-G0-NNN-115-AA-G0-00-B1	SERIES 51	S51-250MV
80001832	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-CD-60-R-3-S1-E-03-GBA-42-42-26	SERIES 90	S90-100PV
80001833	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-NN-80-S-4-C8-K-03-NNN-30-30-24	SERIES 90	S90-250PV
80001835	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-NN-80-S-M-C8-J-03-NNN-30-30-24	SERIES 90	S90-180PV
80001836	MOTOR-VARIABLE CARTRIDGE K	K-C-38CN-E-RNF-F55-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
80001837	MOTOR-VARIABLE CARTRIDGE K	K-C-38CN-E-RNF-F12-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
80001838	MOTOR-VAR-DISPL 51MV060-1	51V060-1--R-S1-N-E2-B1-N-N-U1-NNN-040-AA-F0-00-00	SERIES 51	S51-060MV-1
80001842	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-5-BC-80-P-3-S1-D-05-GBA-42-42-24	SERIES 90	S90-075PV
80001843	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-E2-A5-A-N-G0-NNN-032-AA-G3-03-00	SERIES 51	S51-160MV
80001844	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-NN-80-L-3-F1-F-03-EBA-35-35-20	SERIES 90	S90-130PV
80001845	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-NN-80-P-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-055PV
80001847	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-DE-80-S-4-C8-K-03-NNN-30-30-24	SERIES 90	S90-250PV
80001848	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-NN-80-S-4-F1-H-03-GBA-30-30-24	SERIES 90	S90-130PV
80001849	MOTOR-VAR-DISPL 51MV160	51V160-A-C8-N-D8-M1-R-J-M1-ADA-039-AA-F3-C2-27	SERIES 51	S51-160MV
80001850	PUMP-VAR-DISPL CCW 90PV075	90L075-DD-5-NN-60-R-3-C6-E-GB-GBA-26-26-24	SERIES 90	S90-075PV
80001851	PUMP-VAR-DISPL CCW 90PV075	90L075-FL-5-NN-60-R-7-C6-D-B6-ELA-42-42-28	SERIES 90	S90-075PV
80001852	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-W-S-B-B-AA-G-A-BDD-CD-A-HH-A-NNN-***	M46	M46-046PV
80001853	MOTOR- VARIABLE CARTRIDGE L	L-C-35EN-E-RNF-F04-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
80001855	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-5-BC-80-S-3-C8-K-03-NNN-42-42-24	SERIES 90	S90-250PV
80001862	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-NN-80-P-3-S1-D-00-GBA-42-42-24	SERIES 90	S90-075PV
80001867	PUMP-VAR-DISPL CCW 90PV075	90L075-HF-5-BC-60-S-4-C7-E-03-GBA-30-30-24	SERIES 90	S90-075PV
80001869	PUMP-VAR DISPL, CW 90PV055	90-R-055-HF-2-CD-80-S-3-S1-C-03-GBA-32-32-24	SERIES 90	S90-055PV
80001873	PUMP-VAR-DISPL CCW 90PV180	90L180-KP-5-NN-80-T-C-F5-J-03-FAC-32-32-28	SERIES 90	S90-180PV
80001874	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-NN-80-S-M-C8-H-03-NNN-26-26-24	SERIES 90	S90-180PV
80001879	PUMP-VAR DISPL, CCW 90PV055	90-L-055-DD-5-CD-60-S-4-S1-C-G8-GBA-26-26-20	SERIES 90	S90-055PV
80001880	PUMP-VAR DISPL, CW 90PV100	90-R-100-HS-1-NN-80-P-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
80001881	PUMP-VAR-DISPL CCW 90PV075	90L075-HF-5-BB-80-P-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
80001882	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-BC-80-P-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV

80001883	MOTOR-VAR-DISPL 51MC110	51C110-R-D4-N-EQ-A2-J-Z-K4-ACM-050-AA-NN-15-34	SERIES 51	S51-110MV
80001884	MOTOR-VAR-DISPL 51MC160	51C160-R-D5-N-EQ-A2-J-Z-K4-ACM-068-AA-NN-15-34	SERIES 51	S51-160MV
80001886	PUMP-VAR-DISPL, CW, S42PV041, MDC	42-R-41-D-ANNB-02-B-2-B-2-F-N-A-34-34-B-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
80001887	PUMP-VAR DISPL, CCW 90PV055	90-L-055-MA-5-AD-80-S-3-S1-C-C5-GBA-42-45-24	SERIES 90	S90-055PV
80001889	MOTOR-VAR-DISPL 51MD160	51D160-R-D4-N-T2-C0-L-N-G0-ADA-053-AA-G0-00-B7	SERIES 51	S51-160MV
80001890	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-CD-80-P-4-C6-C-03-GBA-29-29-24	SERIES 90	S90-055PV
80001890C	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-CD-80-P-4-C6-C-03-GBA-29-29-24	SERIES 90	S90-055PV
80001891	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-NN-80-P-4-S1-C-03-GBA-26-26-24	SERIES 90	S90-055PV
80001891C	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-NN-80-P-4-S1-C-03-GBA-26-26-24	SERIES 90	S90-055PV
80001892	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A2-C2-N-E7-F-G1-NN-28-28-28-28-N-P-24-PN-C04-NNN	H1-MP PUMPS	H1-045PT/053PT
80001895	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-K-S-B-J-AA-A-A-BJJ-CD-A-GG-B-NNN-***	M46	M46-046PV
80001896	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-NN-80-S-7-C3-C-09-FAZ-35-35-28	SERIES 90	S90-042PV
80001899	PUMP-VAR-DISPL CW 90PV250	90R250-KP-2-CD-80-T-3-C8-J-03-NNN-32-32-24	SERIES 90	S90-250PV
80001901	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-CD-80-L-3-S1-C-03-GBA-38-38-24	SERIES 90	S90-055PV
80001902	PUMP-VAR DISPL, CW 90PV055	90-R-055-MF-1-BB-60-D-3-S1-L-02-GBA-42-42-22	SERIES 90	S90-055PV
80001903	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A2-C2-N-E7-F-G1-NN-30-30-30-30-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
80001905	PUMP-VAR-DISPL CW 90PV075	90R075-HF-5-NN-60-R-4-C7-D-00-GCA-42-42-20	SERIES 90	S90-075PV
80001906	PUMP-VAR-DISPL CCW 90PV130	90L130-HF-5-CD-80-S-7-F1-F-06-GBA-30-30-24	SERIES 90	S90-130PV
80001907	PUMP-VAR-DISPL CW 90PV075	90R075-FH-5-NN-60-S-7-C7-D-B1-EFI-42-42-30	SERIES 90	S90-075PV
80001908	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-AB-80-S-4-C6-D-03-GBA-35-14-30	SERIES 90	S90-075PV
80001909	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-BC-80-S-4-C6-D-03-GBA-35-14-30	SERIES 90	S90-075PV
80001912	PUMP-VAR DISPL, CW 90PV100	90-R-100-DD-1-BB-80-P-3-F1-F-GB-GBA-35-35-24	SERIES 90	S90-100PV
80001912C	PUMP-VAR DISPL, CW 90PV100	90-R-100-DD-1-BB-80-P-3-F1-F-GB-GBA-35-35-24	SERIES 90	S90-100PV
80001913	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-5-NN-60-S-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
80001917	PUMP-VAR-DISPL CW 90PV130	90R130-KN-5-DE-80-L-3-F1-H-03-GBA-29-29-24	SERIES 90	S90-130PV
80001918	PUMP-VAR-DISPL CW 90PV130	90R130-KN-5-CD-80-L-3-F1-H-03-GBA-29-29-24	SERIES 90	S90-130PV
80001920	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-NN-80-L-3-F1-F-00-EEG-23-23-24	SERIES 90	S90-130PV
80001922	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-1-NN-80-P-3-S1-D-00-GCA-45-45-24	SERIES 90	S90-075PV
80001923	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-CD-60-R-3-C7-E-21-FAD-42-42-28	SERIES 90	S90-100PV
80001924	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HF-1-AB-60-R-3-S1-E-00-GBA-35-35-24	SERIES 90	S90-100PV
80001929	PUMP-VAR-DISPL, CCW, S42PV041, FNR	42-L-41-C-F4NN-73-J-D-B-2-F-5-N-21-21-N-1-1-NNN-NNN	SERIES 42	S42-041PV/051PV
80001931	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-BG-80-L-3-S1-C-03-GBA-38-38-24	SERIES 90	S90-055PV
80001933	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-NN-80-P-3-S1-C-03-EBC-35-35-24	SERIES 90	S90-055PV
80001933C	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-NN-80-P-3-S1-C-03-EBC-35-35-24	SERIES 90	S90-055PV
80001934	MOTOR-VAR-DISPL 51MV160	51V160-A-C8-N-L2-B1-V-A-J1-ADA-072-AA-G3-B2-00	SERIES 51	S51-160MV
80001935	MOTOR-VAR-DISPL 51MV110	51V110-A-C8-N-HS-A1-B-E-E2-NNN-022-AA-F3-08-25	SERIES 51	S51-110MV

80001936	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-NN-60-S-3-C7-D-03-GBA-14-14-20	SERIES 90	S90-075PV
80001937	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-L2-B1-V-A-C0-ABA-100-AA-F3-B2-00	SERIES 51	S51-250MV
80001938	PUMP-VAR-DISPL CW 90PV250	90R250-HF-5-CD-80-T-4-F1-J-03-NNN-29-29-24	SERIES 90	S90-250PV
80001939	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-T1-C2-L-N-G0-NNN-036-AA-F0-00-A8	SERIES 51	S51-160MV
80001941	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-HZ-B1-C-H-C2-NNN-050-AA-G0-20-00	SERIES 51	S51-250MV
80001943	PUMP-VAR DISPL MPV046C	MPV-046-C-B-A-B-S-B-J-BA-A-A-BGG-GB-B-AA-A-NNN-***	M46	M46-046PV
80001945	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-5-NN-80-S-3-S1-D-C5-GBA-35-35-24	SERIES 90	S90-075PV
80001946	PUMP-VAR DISPL, CCW 90PV055	90-L-055-MA-5-NN-80-S-3-S1-C-C5-GBA-35-35-24	SERIES 90	S90-055PV
80001948	PUMP-VAR-DISPL CCW 90PV130	90L130-MB-5-NN-80-R-3-F1-F-03-GBA-42-42-24	SERIES 90	S90-130PV
80001949	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-N-A2-C2-N-E7-F-G5-H3-23-23-23-23-N-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
80001950	PUMP-VAR DISPL, CW 90PV075	90-R-075-DD-1-BC-60-P-4-S1-D-G8-GBA-42-42-24	SERIES 90	S90-075PV
80001950C	PUMP-VAR DISPL, CW 90PV075	90-R-075-DD-1-BC-60-P-4-S1-D-G8-GBA-42-42-24	SERIES 90	S90-075PV
80001953	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-BC-60-P-3-S1-C-03-GBA-38-38-24	SERIES 90	S90-055PV
80001954	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-CD-80-P-3-C7-D-03-GBA-35-35-24	SERIES 90	S90-075PV
80001955	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-CD-80-P-3-C7-D-03-GBA-40-40-24	SERIES 90	S90-075PV
80001956	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-NN-60-P-3-S1-E-03-GBA-38-38-24	SERIES 90	S90-100PV
80001957	PUMP-VAR DISPL, CW 90PV100	90-R-100-HF-1-NN-80-S-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
80001958	PUMP-VAR-DISPL CCW 90PV250	90L250-KP-5-NN-80-T-4-F1-J-03-NNN-35-14-24	SERIES 90	S90-250PV
80001959	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-CD-80-T-3-C8-K-03-EHA-35-35-24	SERIES 90	S90-250PV
80001960	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-CD-80-P-4-F1-H-03-EHA-35-35-24	SERIES 90	S90-130PV
80001961	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A5-C2-N-D7-G-G2-H4-L-42-L-42-A-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
80001962	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A5-C2-N-D8-G-G3-H6-L-42-L-42-A-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
80001963	PUMP-VAR DISPL, CW 90PV055	90-R-055-DC-5-NN-80-D-N-S1-L-Z1-GBA-40-40-24	SERIES 90	S90-055PV
80001964	MOTOR-VARIABLE DISPL SAE_L	L-V-25CN-A-R1F-F06-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
80001965	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-1-NN-80-R-3-S1-D-03-GBA-29-29-24	SERIES 90	S90-075PV
80001967	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-5-BC-80-L-4-F1-E-03-GBA-38-38-24	SERIES 90	S90-100PV
80001968	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-NN-60-R-3-S1-D-04-GBA-42-42-24	SERIES 90	S90-055PV
80001969	MOTOR-VAR-DISPL 51MC160	51C160-R-D4-N-HZ-B1-A-N-G0-NNN-080-AA-F3-03-00	SERIES 51	S51-160MV
80001971	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-AB-80-L-3-F1-F-03-GBA-38-38-24	SERIES 90	S90-130PV
80001972	MOTOR-VAR-DISPL 51MC110-1	51C110-1--R-D3-N-N1-NN-N-N-U1-AWH-022-AA-F3-00-00	SERIES 51	S51-110MV-1
80001978	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A3-C2-N-D6-F-G1-H3-L-42-L-42-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
80001979	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A3-C2-N-E6-F-G1-H3-L-30-L-30-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
80001982	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-CD-80-L-4-F1-F-03-GBA-38-38-24	SERIES 90	S90-130PV
80001984	PUMP-VAR DISPL, CW 90PV055	90-R-055-M8-1-BK-80-P-3-C6-C-03-GBA-42-42-24	SERIES 90	S90-055PV
80001984C	PUMP-VAR DISPL, CW 90PV055	90-R-055-M8-1-BK-80-P-3-C6-C-03-GBA-42-42-24	SERIES 90	S90-055PV
80001985	PUMP-VAR DISPL, CCW 90PV055	90-L-055-MA-1-AB-60-D-3-C6-L-03-GBA-35-35-24	SERIES 90	S90-055PV

80001985C	PUMP-VAR DISPL, CCW 90PV055	90-L-055-MA-1-AB-60-D-3-C6-L-03-GBA-35-35-24	SERIES 90	S90-055PV
80001986	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-5-NN-60-P-3-C6-D-03-GBA-29-29-24	SERIES 90	S90-055PV
80001987	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-A-T-B-B-AA-A-A-BDD-CD-A-HH-C-NNN-***	M46	M46-046PV
80001988	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-T1-C2-L-N-G0-NNN-070-AA-NN-00-C4	SERIES 51	S51-160MV
80001989	PUMP-VAR-DISPL CW 90PV042	90R042-MB-5-BC-80-S-4-C3-C-C5-FAB-42-42-24	SERIES 90	S90-042PV
80001990	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-BG-80-R-4-S1-C-03-GBA-32-32-24	SERIES 90	S90-055PV
80001991	PUMP-VAR-DISPL CW 90PV100	90R100-KP-5-NN-80-R-3-F1-E-00-GBA-42-42-24	SERIES 90	S90-100PV
80001993	PUMP-VAR DISPL MPV046C	MPV-046-C-B-A-B-S-B-B-AA-G-A-BJB-AB-U-ED-A-NNN-***	M46	M46-046PV
80001994	PUMP-VAR DISPL MPV046C	MPV-046-C-B-A-A-S-B-B-AA-A-A-BGG-AB-U-FF-C-NNN-***	M46	M46-046PV
80001995	PUMP-VAR DISPL, CW 90PV075	90-R-075-HF-1-BB-60-L-3-S1-E-03-GBA-32-32-24	SERIES 90	S90-075PV
80001996	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-A-S-B-B-AA-G-A-BGG-CD-A-TT-C-NNN-***	M46	M46-046PV
80002002	PUMP-VAR-DISPL CCW 90PV250	90L250-KP-5-BC-80-T-3-F1-J-03-NNN-42-42-24	SERIES 90	S90-250PV
80002012	PUMP-VAR-DISPL CW 90PV130	90R130-NA-V-BJ-8J-L-3-TN-F-03-GB7-42-42-30	SERIES 90	S90-130PV
80002015	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-K-T-B-B-AA-A-A-BHH-CG-A-GG-B-NNN-***	M46	M46-046PV
80002016	PUMP-VAR-DISPL CCW 90PV130	90L130-HF-5-AB-80-P-3-C8-F-03-GBA-26-26-28	SERIES 90	S90-130PV
80002018	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-C8-N-TA-C2-N-N-X1-NNN-080-AA-NN-00-28	SERIES 51	S51-110MV-1
80002019	MOTOR-VAR-DISPL 51MC110-1	51C110-1--R-D3-N-E2-B1-N-N-U1-ABA-072-AA-G0-00-00	SERIES 51	S51-110MV-1
80002022	PUMP-VAR-DISPL CW 90PV250	90R250-KP-5-BC-80-T-3-F1-J-03-NNN-42-42-24	SERIES 90	S90-250PV
80002023	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-HZ-B1-A-N-G0-NNN-050-AA-G0-03-00	SERIES 51	S51-250MV
80002024	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-AB-60-L-3-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV
80002025	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-NN-80-P-3-S1-C-03-GBA-26-26-24	SERIES 90	S90-055PV
80002025C	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-NN-80-P-3-S1-C-03-GBA-26-26-24	SERIES 90	S90-055PV
80002026	PUMP-VAR DISPL, CCW 90PV055	90-L-055-ME-1-NN-80-P-3-S1-C-03-GBA-26-26-24	SERIES 90	S90-055PV
80002026C	PUMP-VAR DISPL, CCW 90PV055	90-L-055-ME-1-NN-80-P-3-S1-C-03-GBA-26-26-24	SERIES 90	S90-055PV
80002027	PUMP-VAR-DISPL CCW 90PV042	90L042-KA-5-NN-80-R-4-C3-B-03-GBA-42-42-24	SERIES 90	S90-042PV
80002029	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-CD-80-S-M-C8-H-03-FAC-42-42-24	SERIES 90	S90-180PV
80002030	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D2-N-E2-B1-N-N-U1-ADA-027-AA-E6-00-00	SERIES 51	S51-080MV-1
80002031	PUMP-VAR DISPL MPV035D	MPV-035-D-B-A-A-R-S-G-AA-A-A-BFF-DR-A-FF-C-NNN-***	M35/44	035PV
80002032	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-DE-80-S-3-C8-H-03-GBA-35-35-24	SERIES 90	S90-130PV
80002033	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-CD-80-S-3-F1-H-03-GBA-35-35-24	SERIES 90	S90-130PV
80002037	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-1-CD-80-P-4-S1-C-03-GBA-14-14-24	SERIES 90	S90-055PV
80002039	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HM-5-CD-80-S-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
80002040	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-CD-80-L-4-S1-D-03-GBA-14-14-24	SERIES 90	S90-075PV
80002041	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-1-AD-80-L-4-S1-C-00-GBA-14-14-24	SERIES 90	S90-055PV
80002042	PUMP-VAR DISPL, CCW 90PV055	90-L-055-DC-1-CD-80-R-3-S1-C-GB-GBA-29-29-24	SERIES 90	S90-055PV
80002043	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-BG-80-P-3-S1-D-03-GBA-32-32-24	SERIES 90	S90-055PV

80002045	PUMP-VAR-DISPL CW 90PV075	90R075-HF-5-NN-80-S-4-C7-D-03-GBA-32-32-24	SERIES 90	S90-075PV
80002046	MOTOR-VAR-DISPL 51MC080	51C080-R-D3-N-HZ-B2-B-E-H7-NNN-028-AA-F0-07-00	SERIES 51	S51-080MV
80002048	PUMP-VAR DISPL MPV046C	MPV-046-C-B-A-D-S-B-B-AA-A-A-BFF-AB-U-FF-B-NNN-***	M46	M46-046PV
80002051	PUMP-VAR-DISPL CCW 90PV075	90L075-MA-5-AB-60-L-4-C6-D-C7-GBA-32-32-24	SERIES 90	S90-075PV
80002052	MOTOR-VARIABLE DISPL SAE_K	K-V-38CS-E-Y2F-F01-S-N-N-CF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
80002053	MOTOR-VARIABLE DISPL SAE_K	K-V-38CS-E-Y2F-F65-S-N-N-CF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
80002056	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HF-1-BC-80-R-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
80002058	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-AB-60-P-4-C7-E-03-EFI-40-40-24	SERIES 90	S90-075PV
80002059	PUMP-VAR-DISPL CW 90PV250	90R250-KP-5-CD-80-T-4-C8-J-03-NNN-42-42-24	SERIES 90	S90-250PV
80002061	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-CD-80-P-4-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
80002062	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-CD-80-P-4-C8-F-03-GBA-42-42-24	SERIES 90	S90-130PV
80002065	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-1-BB-60-S-4-S1-E-00-GBA-23-23-24	SERIES 90	S90-075PV
80002066	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-1-BC-60-S-4-S1-E-00-GBA-23-23-24	SERIES 90	S90-075PV
80002072	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-C8-N-B1-B3-N-N-U3-NNN-030-AA-F3-00-00	SERIES 51	S51-110MV-1
80002082	MOTOR-FIX DISPL MMF044D	MMF-044-D-A-S-H-C-D-NNN-***	M35/44	044MF
80002083	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-BG-80-R-4-S1-D-00-GBA-35-35-24	SERIES 90	S90-055PV
80002084	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-BC-80-R-4-T2-F-00-GBA-35-35-24	SERIES 90	S90-100PV
80002085	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-CD-80-R-4-T2-F-00-GBA-35-35-24	SERIES 90	S90-100PV
80002086	PUMP-TANDEM, VAR DISPL MPT025C	MPT-025-C-S-R-A-E-NN-B-A-A-A-BDD-DL-A-FF-B-A-A-A-BDD-DR-A-FF-A-NNN-*	LIGHT DUTY	025PT
80002087	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-A-V-C-B-BA-B-A-B-A-BDD-AK-U-ED-B-C-B-A-BDD-AK-D-ED-A-NNN-	M46	M46-046PT
80002088	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-BG-80-P-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-055PV
80002090	PUMP-VAR-DISPL CW 90PV100	90R100-KA-2-BC-60-S-4-C7-E-03-GBA-45-45-24	SERIES 90	S90-100PV
80002091	PUMP-VAR-DISPL CW 90PV130	90R130-HS-5-BC-80-S-4-F1-H-00-GBA-42-42-30	SERIES 90	S90-130PV
80002092	PUMP-VAR-DISPL CW 90PV130	90R130-HS-5-DE-80-S-4-F1-H-00-GBA-42-42-30	SERIES 90	S90-130PV
80002093	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-T2-C2-L-N-G0-NNN-051-AA-F0-00-B5	SERIES 51	S51-160MV
80002094	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-CD-80-P-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-055PV
80002096	PUMP-VAR-DISPL CW 90PV180	90R180-HF-5-NN-80-T-C-C8-J-03-NNN-35-35-24	SERIES 90	S90-180PV
80002097	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-NN-80-R-3-S1-E-00-GBA-42-42-24	SERIES 90	S90-100PV
80002098	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-NN-80-R-3-S1-D-00-GBA-42-42-24	SERIES 90	S90-075PV
80002099	MOTOR-VAR-DISPL 51MV080-1	51V080-1--A-S1-N-E1-B1-N-N-U1-NNN-047-AA-E6-00-00	SERIES 51	S51-080MV-1
80002101	MOTOR-VAR-DISPL 51MV250	51V250-A-C8-N-JS-NN-B-E-P2-ADA-065-AA-G0-10-32	SERIES 51	S51-250MV
80002102	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-JA-NN-C-E-K3-NNN-052-AA-F3-12-24	SERIES 51	S51-160MV
80002103	PUMP-VAR-DISPL CW 90PV075	90R075-FN-5-CD-80-P-7-C7-E-B6-ELA-42-42-28	SERIES 90	S90-075PV
80002104	PUMP-VAR-DISPL CW 90PV075	90R075-CA-5-BC-80-P-7-S1-E-00-GCA-42-42-28	SERIES 90	S90-075PV
80002105	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HF-1-AB-80-R-3-S1-E-00-GBA-35-35-24	SERIES 90	S90-100PV
80002112	PUMP-VAR-DISPL CW 90PV042	90R042-KN-5-NN-80-P-3-C3-C-03-GBA-29-29-24	SERIES 90	S90-042PV

80002113	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-AB-60-S-3-C6-C-03-GBA-38-38-20	SERIES 90	S90-075PV
80002114	MOTOR-VAR-DISPL 51MD160	51D160-A-D5-N-D7-M1-S-K-M1-NNN-056-AA-F3-F4-13	SERIES 51	S51-160MV
80002115	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-E2-A2-A-N-E1-NNN-085-AA-G0-03-25	SERIES 51	S51-250MV
80002116	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-BC-80-R-7-C7-F-09-FAZ-35-35-30	SERIES 90	S90-100PV
80002118	PUMP-VAR-DISPL CW 90PV180	90R180-KN-5-NN-80-T-C-C8-H-03-NNN-32-32-24	SERIES 90	S90-180PV
80002119	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-B-N2-NN-N-N-A0-NNN-168-AA-F0-00-00	SERIES 51	S51-250MV
80002120	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A2-C2-N-D8-F-G5-H3-L-40-L-40-B-P-30-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
80002123	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A5-C2-N-E7-F-G1-H5-40-40-40-40-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
80002127	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-DE-80-T-M-F1-H-03-FAC-35-35-24	SERIES 90	S90-180PV
80002128	PUMP-VAR-DISPL CW 90PV180	90R180-KP-5-CD-80-T-M-F1-H-03-FAC-29-29-24	SERIES 90	S90-180PV
80002131	MOTOR-VAR-DISPL 51MV060-1	51V060-1--R-S1-N-TA-CA-N-N-X1-ABA-015-AA-F0-00-28	SERIES 51	S51-060MV-1
80002132	PUMP-VAR-DISPL CCW 90PV250	90L250-KN-5-CD-80-T-4-F1-J-03-NNN-35-35-24	SERIES 90	S90-250PV
80002133	PUMP-VAR-DISPL CCW 90PV250	90L250-KN-5-BC-80-T-4-F1-J-03-NNN-35-35-24	SERIES 90	S90-250PV
80002134	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-E1-B1-N-N-U1-NNN-041-AA-F0-00-00	SERIES 51	S51-110MV-1
80002135	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-E1-A5-A-N-G0-ABA-068-AA-G3-03-00	SERIES 51	S51-160MV
80002138	PUMP-VAR-DISPL CCW 90PV180	90L180-KP-2-CD-80-T-C-F1-H-03-FAC-35-35-24	SERIES 90	S90-180PV
80002140	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-5-NN-80-T-3-F1-K-03-NNN-35-35-24	SERIES 90	S90-250PV
80002143	PUMP-VAR DISPL, CW 90PV055	90-R-055-MB-1-BC-60-S-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
80002146	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-NN-60-R-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
80002147	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-BC-60-R-3-S1-C-03-GBA-29-29-20	SERIES 90	S90-055PV
80002149	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-A-E2-B1-N-N-U1-NNN-056-AA-F3-00-00	SERIES 51	S51-110MV-1
80002150	PUMP-VAR-DISPL CW 90PV130	90R130-HS-5-NN-80-R-4-F1-H-03-GBA-32-32-24	SERIES 90	S90-130PV
80002151	PUMP-VAR-DISPL CW 90PV180	90R180-HS-5-DE-80-T-C-C8-H-03-NNN-32-32-24	SERIES 90	S90-180PV
80002152	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A3-C3-N-D8-G-G3-NN-L-45-L-45-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
80002153	MOTOR-VAR-DISPL 51MD060-1	51D060-1--A-D1-N-TH-C2-N-N-X1-NNN-021-AA-E6-00-20	SERIES 51	S51-060MV-1
80002154	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HF-1-BG-80-R-3-S1-C-03-GBA-23-23-24	SERIES 90	S90-055PV
80002155	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-E-Z-C-J-BA-B-B-A-A-BJJ-CE-A-GG-B-D-A-A-BJJ-CE-A-GG-C-NNN-***	M46	M46-046PT
80002158	PUMP-VAR DISPL, CW 90PV055	90-R-055-CA-2-AD-80-P-3-S1-C-00-GBA-35-35-24	SERIES 90	S90-055PV
80002162	PUMP-VAR-DISPL CW 90PV075	90R075-FM-5-BC-60-P-7-C7-E-B6-EFR-42-42-30	SERIES 90	S90-075PV
80002165	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-BB-80-R-3-S1-E-03-GBA-29-29-24	SERIES 90	S90-075PV
80002168	PUMP-VAR-DISPL CW 90PV130	90R130-MB-5-NN-80-L-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-130PV
80002169	PUMP-VAR-DISPL CCW 90PV180	90L180-KP-2-BC-80-T-C-F1-J-03-FAC-42-14-24	SERIES 90	S90-180PV
80002172	PUMP-VAR DISPL MPV025C	MPV-025-C-B-A-A-W-A-C-NN-A-A-BFF-DL-A-FF-A-NNN-***	LIGHT DUTY	025PV
80002173	PUMP-VAR-DISPL CW 90PV250	90R250-KP-5-NN-80-T-3-F1-J-00-NNN-17-17-18	SERIES 90	S90-250PV
80002174	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-TA-C2-N-N-X1-NNN-065-AA-NN-00-14	SERIES 51	S51-110MV-1
80002176	MOTOR-VAR-DISPL 51MC160	51C160-R-D5-N-HZ-B1-A-N-G0-NNN-047-AA-G0-03-00	SERIES 51	S51-160MV

80002178	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-AB-80-P-3-C6-C-03-GBA-32-32-24	SERIES 90	S90-075PV
80002178C	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-AB-80-P-3-C6-C-03-GBA-32-32-24	SERIES 90	S90-075PV
80002179	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-BC-80-S-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-100PV
80002180	PUMP-VAR-DISPL, CW, S42PV041, NFPE	42-R-41-D-G1A1-70-J-2-B-2-F-5-B-34-34-B-0-0-NNN-NNN	SERIES 42	S42-041PV/051PV
80002182	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A2-C2-N-E8-G-G2-NN-L-42-L-42-L-L-24-PN-NNN-G14	H1-HP PUMPS	H1-147PV/165PV
80002184	PUMP-VAR DISPL, CCW 90PV055	90-L-055-MA-1-NN-80-S-3-S1-C-02-GBA-23-23-24	SERIES 90	S90-055PV
80002187	PUMP-VAR DISPL, CW 90PV075	90-R-075-M8-1-CD-60-P-3-C7-D-03-GBA-40-40-24	SERIES 90	S90-075PV
80002187C	PUMP-VAR DISPL, CW 90PV075	90-R-075-M8-1-CD-60-P-3-C7-D-03-GBA-40-40-24	SERIES 90	S90-075PV
80002188	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-1-NN-60-P-4-S1-D-GB-GBA-35-35-24	SERIES 90	S90-055PV
80002188C	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-1-NN-60-P-4-S1-D-GB-GBA-35-35-24	SERIES 90	S90-055PV
80002192	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HK-1-BB-60-S-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
80002193	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HK-1-BC-60-S-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
80002194	MOTOR-VARIABLE DISPL SAE_K	K-V-45DN-A-YNF-F07-S-N-N-AF-F16-NNN-NNN	LV / KV MOTORS	L/K-MV
80002195	MOTOR-VARIABLE DISPL SAE_K	K-V-45DN-A-YNF-F08-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
80002196	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-E-V-C-B-AA-B-A-A-A-BRR-AB-U-AA-B-C-A-A-BRR-AB-D-BB-B-NNN-*	M46	M46-046PT
80002197	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-NN-80-R-3-F1-D-00-GBA-14-14-18	SERIES 90	S90-100PV
80002198	PUMP-VAR-DISPL CW 90PV075	90R075-FH-5-AB-80-P-7-C6-D-B2-EFI-32-32-24	SERIES 90	S90-075PV
80002199	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-E-V-C-B-AA-B-A-A-A-BRR-AB-U-BB-B-C-A-A-BRR-AB-D-BB-B-NNN-*	M46	M46-046PT
80002200	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-5-BC-80-L-4-F1-E-00-GBA-35-35-20	SERIES 90	S90-100PV
80002202	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-1-BC-60-P-4-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
80002210	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-BC-80-S-7-C3-C-09-FAZ-35-35-28	SERIES 90	S90-042PV
80002213	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-EF-80-S-4-C8-J-03-NNN-38-38-24	SERIES 90	S90-250PV
80002215	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D3-N-N1-NN-N-N-U1-NNN-024-AA-E4-00-00	SERIES 51	S51-080MV-1
80002216	PUMP-VAR-DISPL CW 90PV130	90R130-KA-2-BB-80-R-4-C8-F-33-GCA-42-42-30	SERIES 90	S90-130PV
80002218	PUMP-VAR-DISPL CW 90PV042	90R042-KA-2-NN-80-R-4-C3-B-00-GCA-42-42-30	SERIES 90	S90-042PV
80002219	MOTOR-VAR-DISPL 51MV110	51V110-R-F1-N-EQ-A5-J-Y-G5-ACA-060-AA-F3-46-00	SERIES 51	S51-110MV
80002220	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-E-V-C-S-AA-B-A-C-A-BRR-GG-B-KF-B-C-C-A-BRR-GG-B-KF-B-NNA-*	M46	M46-046PT
80002221	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-E-V-C-S-AA-B-A-C-A-BRR-GG-B-KF-B-C-C-A-BRR-GG-B-KF-Y-GDG-*	M46	M46-046PT
80002222	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-E-V-C-S-AA-B-A-C-A-BRR-GG-B-KF-B-C-C-A-BRR-GG-B-KF-Y-GDH-*	M46	M46-046PT
80002225	PUMP-VAR DISPL, CCW 90PV055	90-L-055-DC-1-CD-80-R-3-S1-C-GB-GBA-26-26-24	SERIES 90	S90-055PV
80002243	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-CD-80-S-3-C7-E-02-GBA-35-35-24	SERIES 90	S90-100PV
80002244	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HS-5-CD-80-S-4-S1-D-03-GBA-29-29-24	SERIES 90	S90-075PV
80002244C	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HS-5-CD-80-S-4-S1-D-03-GBA-29-29-24	SERIES 90	S90-075PV
80002245	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HS-5-BC-80-S-4-S1-D-03-GBA-29-29-24	SERIES 90	S90-075PV
80002245C	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HS-5-BC-80-S-4-S1-D-03-GBA-29-29-24	SERIES 90	S90-075PV
80002247	PUMP-VAR DISPL, CW 90PV100	90-R-100-DD-1-NN-80-P-3-F1-E-GB-GBA-29-29-24	SERIES 90	S90-100PV

80002247C	PUMP-VAR DISPL, CW 90PV100	90-R-100-DD-1-NN-80-P-3-F1-E-GB-GBA-29-29-24	SERIES 90	S90-100PV
80002248	MOTOR-VAR-DISPL 51MV080-1	51V080-1--A-S1-A-E1-B1-N-N-U1-NNN-047-AA-E6-00-00	SERIES 51	S51-080MV-1
80002249	MOTOR-VAR-DISPL 51MV110-1	51V110-1--A-F1-N-TA-C2-N-N-X1-NNN-022-AA-F0-00-30	SERIES 51	S51-110MV-1
80002250	MOTOR-VAR-DISPL 51MV080-1	51V080-1--A-S1-N-TA-C2-N-N-X1-NNN-016-AA-F0-00-30	SERIES 51	S51-080MV-1
80002252	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-NN-80-R-3-F1-F-00-GBA-14-14-18	SERIES 90	S90-130PV
80002253	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-AB-60-S-4-C7-E-05-FAC-38-38-28	SERIES 90	S90-100PV
80002254	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-NN-60-S-4-C7-E-05-FAC-38-38-28	SERIES 90	S90-100PV
80002263	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-AB-80-L-4-F1-E-03-GBA-20-20-20	SERIES 90	S90-100PV
80002267	MOTOR-VAR-DISPL 51MV160	51V160-A-C8-N-T2-C0-L-N-K7-NNN-057-AA-E6-00-C6	SERIES 51	S51-160MV
80002271	PUMP-VAR-DISPL CW 90PV180	90R180-HS-5-NN-80-T-C-C8-J-03-NNN-30-30-30	SERIES 90	S90-180PV
80002273	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MB-1-BC-80-P-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
80002273C	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MB-1-BC-80-P-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
80002274	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-NN-80-R-4-C7-E-03-GBA-20-20-20	SERIES 90	S90-075PV
80002275	PUMP-VAR-DISPL CW 90PV250	90R250-PB-5-BC-80-S-3-C8-K-03-NNN-36-36-20	SERIES 90	S90-250PV
80002277	PUMP-VAR-DISPL CW 90PV180	90R180-FG-5-CD-80-T-7-C8-H-B9-EFI-42-42-32	SERIES 90	S90-180PV
80002278	MOTOR-VAR-DISPL 51MD110-1	51D110-1--R-D3-N-P7-P7-N-N-X1-NNN-049-AA-F3-00-AA	SERIES 51	S51-110MV-1
80002279	PUMP-TANDEM, VAR DISPL CCW H1T053L	H1-T-053-L-A-A-A2-C2-N-E7-F-G6-H2-35-18-35-35-N-P-22-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
80002280	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-NN-80-P-4-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
80002281	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HS-5-NN-60-R-4-S1-C-03-GBA-26-26-24	SERIES 90	S90-055PV
80002281C	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HS-5-NN-60-R-4-S1-C-03-GBA-26-26-24	SERIES 90	S90-055PV
80002282	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HS-5-NN-60-R-4-S1-D-03-GBA-26-26-28	SERIES 90	S90-075PV
80002282C	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HS-5-NN-60-R-4-S1-D-03-GBA-26-26-28	SERIES 90	S90-075PV
80002284	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-N2-NN-N-N-A0-NNN-168-AA-G3-00-00	SERIES 51	S51-250MV
80002285	PUMP-VAR-DISPL CCW 90PV100	90L100-HF-5-AB-80-S-4-C7-E-03-GBA-26-26-24	SERIES 90	S90-100PV
80002286	MOTOR-VAR-DISPL 51MV110	51V110-A-F1-N-HS-A2-B-H-C1-NNN-055-AA-NN-10-13	SERIES 51	S51-110MV
80002287	PUMP-VAR-DISPL CW 90PV180	90R180-MA-5-NN-80-S-C-F1-J-C5-NNN-42-42-24	SERIES 90	S90-180PV
80002288	PUMP-VAR-DISPL CW 90PV100	90R100-MA-5-NN-80-S-3-S1-E-C5-GBA-42-42-24	SERIES 90	S90-100PV
80002289	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-TA-C2-L-N-G0-NNN-168-AA-NN-00-B9	SERIES 51	S51-250MV
80002290	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-N-T2-C0-L-N-L4-ABA-065-AA-E6-00-C2	SERIES 51	S51-160MV
80002291	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KN-5-NN-60-D-4-S1-L-03-GBA-35-35-28	SERIES 90	S90-055PV
80002292	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-G-BC-60-R-3-S1-E-03-GBA-32-32-24	SERIES 90	S90-075PV
80002294	PUMP-VAR DISPL MPV046C	MPV-046-C-B-A-H-S-B-B-BA-A-A-BJJ-AB-U-ZX-A-NNN-***	M46	M46-046PV
80002298	PUMP-VAR DISPL, CW 90PV075	90-R-075-MV-1-CD-80-L-4-C7-E-03-GBA-42-42-28-F022	SERIES 90	S90-075PV
80002299	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-BC-80-L-4-S1-E-03-GBA-42-42-28-F022	SERIES 90	S90-075PV
80002300	PUMP-VAR DISPL, CW 90PV100	90-R-100-HS-1-BC-80-R-4-T2-E-00-GBA-35-35-24	SERIES 90	S90-100PV
80002301	PUMP-TANDEM, VAR DISPL MPT035D	MPT-035-D-A-W-R-C-BA-B-A-A-A-BHH-DR-A-FF-B-C-A-A-BHH-DL-A-FF-B-NNN-	M35/44	035PT

80002302	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-T2-CA-N-N-X1-NNN-055-AA-F3-00-31	SERIES 51	S51-110MV-1
80002307	PUMP-VAR DISPL, CCW 90PV055	90-L-055-MA-5-AB-60-P-3-C6-C-C6-GBA-42-42-24	SERIES 90	S90-055PV
80002308	MOTOR- VARIABLE CARTRIDGE L	L-C-25CN-E-RNF-F09-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
80002310	PUMP-VAR-DISPL CW 90PV100	90R100-DD-5-CD-60-S-4-TG-E-GF-GBA-42-42-24	SERIES 90	S90-100PV
80002313	PUMP-VAR DISPL, CCW 90PV055	90-L-055-MB-1-BG-80-P-3-C6-D-03-GBA-35-35-24	SERIES 90	S90-055PV
80002313C	PUMP-VAR DISPL, CCW 90PV055	90-L-055-MB-1-BG-80-P-3-C6-D-03-GBA-35-35-24	SERIES 90	S90-055PV
80002316	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-CD-80-S-3-C8-K-03-EFI-42-42-24	SERIES 90	S90-250PV
80002318	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-5-BC-80-S-3-S1-E-03-GBA-35-35-22	SERIES 90	S90-100PV
80002319	PUMP-VAR DISPL, CW 90PV055	90-R-055-MB-1-NN-60-P-3-S1-C-03-GBA-38-38-24	SERIES 90	S90-055PV
80002319C	PUMP-VAR DISPL, CW 90PV055	90-R-055-MB-1-NN-60-P-3-S1-C-03-GBA-38-38-24	SERIES 90	S90-055PV
80002320	PUMP-VAR-DISPL CCW 90PV075	90L075-HF-5-NN-60-R-3-C7-D-03-GBA-29-29-24	SERIES 90	S90-075PV
80002321	MOTOR-VAR-DISPL 51MV110	51V110-R-C8-N-HZ-B1-C-E-C2-NNN-036-AA-F0-14-00	SERIES 51	S51-110MV
80002322	MOTOR-VAR-DISPL 51MC160	51C160-A-D5-N-N2-NN-N-N-A0-NNN-107-AA-G3-00-00	SERIES 51	S51-160MV
80002323	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-5-EF-80-S-4-C8-L-03-NNN-42-16-30	SERIES 90	S90-250PV
80002325	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-5-BC-80-R-4-F1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
80002328	PUMP-VAR-DISPL CW 90PV180	90R180-KA-2-NN-80-S-C-F1-H-00-FAC-35-35-24	SERIES 90	S90-180PV
80002330	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-5-NN-80-P-4-C6-D-03-GBA-26-26-24	SERIES 90	S90-055PV
80002331	PUMP-VAR-DISPL CW 90PV130	90R130-KA-2-NN-80-R-4-C8-F-33-GCA-42-42-24	SERIES 90	S90-130PV
80002332	MOTOR-VAR-DISPL 51MV110-1	51V110-1--A-F1-N-E2-B1-N-N-U1-NNN-036-AA-NN-00-00	SERIES 51	S51-110MV-1
80002338	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-N-L7-B1-W-B-C0-ANA-050-AA-F0-D4-00	SERIES 51	S51-160MV
80002342	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-AB-80-R-3-C6-D-03-GBA-29-29-24	SERIES 90	S90-075PV
80002343	PUMP-VAR-DISPL CW 90PV100	90R100-FA-5-NN-60-S-7-C7-E-B9-GBA-42-42-30	SERIES 90	S90-100PV
80002344	PUMP-VAR-DISPL CW 90PV100	90R100-FA-5-BC-60-S-7-C7-E-B9-GBA-42-42-30	SERIES 90	S90-100PV
80002352	PUMP-VAR-DISPL CW 90PV250	90R250-HS-5-NN-80-T-3-C8-J-03-NNN-32-32-24	SERIES 90	S90-250PV
80002353	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KN-5-BC-80-D-4-F1-L-03-GBA-35-35-24	SERIES 90	S90-100PV
80002354	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-HZ-B1-A-N-G0-NNN-168-AA-G0-03-00	SERIES 51	S51-250MV
80002355	MOTOR-VAR-DISPL 51MD110-1	51D110-1--R-D3-N-T2-D2-N-N-X1-NNN-032-AA-NN-00-25	SERIES 51	S51-110MV-1
80002356	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KT-2-NN-60-R-3-S1-E-00-FAC-45-45-24	SERIES 90	S90-075PV
80002362	PUMP-VAR-DISPL CW 90PV130	90R130-MA-5-AB-80-S-4-C8-H-C6-GBA-32-32-24	SERIES 90	S90-130PV
80002363	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-NN-80-S-C-C8-J-03-NNN-45-45-24	SERIES 90	S90-180PV
80002364	PUMP-VAR-DISPL CW 90PV130	90R130-DD-5-NN-80-S-3-C8-F-GB-GBA-42-42-24	SERIES 90	S90-130PV
80002365	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-BB-60-S-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
80002367	PUMP-VAR-DISPL CW 90PV100	90R100-FD-5-AB-80-P-7-C7-F-B9-EFI-38-38-30	SERIES 90	S90-100PV
80002368	PUMP-VAR-DISPL CW 90PV100	90R100-HF-5-BC-80-P-3-S1-E-03-GBA-32-32-24	SERIES 90	S90-100PV
80002369	PUMP-VAR DISPL, CW 90PV055	90-R-055-M8-1-NN-60-P-3-C6-D-03-GBA-42-42-24	SERIES 90	S90-055PV
80002369C	PUMP-VAR DISPL, CW 90PV055	90-R-055-M8-1-NN-60-P-3-C6-D-03-GBA-42-42-24	SERIES 90	S90-055PV

80002373	PUMP-VAR-DISPL CW 90PV100	90R100-FC-5-CD-80-P-7-C7-E-B9-EFI-42-42-30	SERIES 90	S90-100PV
80002374	PUMP-VAR-DISPL CW 90PV130	90R130-MA-5-BC-80-L-4-C8-F-C7-GBA-29-29-24	SERIES 90	S90-130PV
80002378	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-BC-80-R-3-C8-H-03-GCA-35-35-24-P040	SERIES 90	S90-130PV
80002379	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-NN-60-P-4-F1-F-03-GBA-38-38-24	SERIES 90	S90-100PV
80002381	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-B-N1-NN-N-N-U1-ADA-026-AA-E4-00-00	SERIES 51	S51-060MV-1
80002383	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-BC-60-R-3-S1-E-03-GBA-32-32-24	SERIES 90	S90-100PV
80002384	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-BC-60-R-4-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
80002393	PUMP-VAR DISPL MPV035D	MPV-035-D-B-A-G-R-S-F-AA-A-A-BFF-DL-A-FF-C-NNN-***	M35/44	035PV
80002395	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HS-1-BC-80-R-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
80002396	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-NN-80-P-4-T2-D-03-GBA-29-29-24	SERIES 90	S90-075PV
80002397	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-K-S-B-B-AA-G-A-BDD-CD-A-ZG-B-NNN-***	M46	M46-046PV
80002398	PUMP-VAR DISPL MPV035D	MPV-035-D-B-A-A-L-S-G-AA-A-A-BEE-DR-A-FF-C-NNN-***	M35/44	035PV
80002405	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-2-BB-80-S-4-C8-H-03-GBA-42-42-24	SERIES 90	S90-130PV
80002406	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-2-BC-80-S-4-C8-H-03-GBA-42-42-24	SERIES 90	S90-130PV
80002407	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-BB-80-S-4-C7-D-03-GBA-35-35-24	SERIES 90	S90-075PV
80002408	PUMP-VAR DISPL MPV035D	MPV-035-D-B-A-A-R-S-F-AA-A-A-BDD-DR-A-FF-A-NNN-***	M35/44	035PV
80002409	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-NN-80-S-4-C6-C-03-GBA-20-20-24	SERIES 90	S90-055PV
80002410	PUMP-VAR-DISPL CW 90PV075	90R075-MA-5-BC-60-S-4-C6-D-C7-GBA-29-29-24	SERIES 90	S90-075PV
80002411	PUMP-VAR-DISPL CCW 90PV100	90L100-CA-5-CD-60-R-7-C7-E-00-GCA-35-35-28	SERIES 90	S90-100PV
80002412	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-AB-60-S-3-S1-C-03-GBA-26-26-24	SERIES 90	S90-055PV
80002412C	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-AB-60-S-3-S1-C-03-GBA-26-26-24	SERIES 90	S90-055PV
80002415	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-AB-80-P-3-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
80002416	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-CD-80-P-3-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
80002417	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-NN-80-P-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
80002418	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-NN-80-R-4-S1-C-03-GBA-20-20-24	SERIES 90	S90-055PV
80002420	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-CD-80-S-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-100PV
80002421	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-BC-80-S-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
80002423	PUMP-VAR-DISPL CW 90PV180	90R180-KN-5-NN-80-T-C-C8-J-03-NNN-42-42-24	SERIES 90	S90-180PV
80002424	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-HZ-B1-B-H-G5-NNN-140-AA-F3-07-00	SERIES 51	S51-250MV
80002432	PUMP-VAR-DISPL CCW 90PV100	90L100-FD-5-CD-60-R-7-C7-E-B9-GCA-35-35-28	SERIES 90	S90-100PV
80002433	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-G-S-B-B-AA-A-A-BJJ-CE-A-GG-C-NNN-***	M46	M46-046PV
80002434	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-G-T-B-B-AA-A-A-BJJ-CE-A-GG-C-NNN-***	M46	M46-046PV
80002435	PUMP-VAR-DISPL CCW 90PV180	90L180-MA-2-BB-80-S-M-C8-J-C5-NNN-35-35-24	SERIES 90	S90-180PV
80002436	PUMP-VAR-DISPL CW 90PV075	90R075-KA-2-AB-60-S-4-C6-D-04-GBA-35-35-24	SERIES 90	S90-075PV
80002437	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HS-1-AB-60-S-4-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
80002437C	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HS-1-AB-60-S-4-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV

80002438	PUMP-VAR-DISPL CW 90PV130	90R130-HF-5-BC-80-S-4-F1-H-03-GBA-30-30-24	SERIES 90	S90-130PV
80002439	PUMP-VAR-DISPL CW 90PV130	90R130-HF-5-DE-80-S-4-C8-H-03-GBA-30-30-24	SERIES 90	S90-130PV
80002441	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-HS-A2-B-E-G6-NNN-070-AA-H0-08-37	SERIES 51	S51-250MV
80002444	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-1-NN-80-S-4-S1-C-00-EBC-35-35-24	SERIES 90	S90-055PV
80002445	PUMP-VAR DISPL, CW 90PV055	90-R-055-HF-5-CD-80-R-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
80002446	PUMP-VAR DISPL, CW 90PV055	90-R-055-HF-5-AD-80-R-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
80002448	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MB-1-CD-80-P-3-C7-D-03-GBA-35-35-24	SERIES 90	S90-075PV
80002448C	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MB-1-CD-80-P-3-C7-D-03-GBA-35-35-24	SERIES 90	S90-075PV
80002450	PUMP-VAR DISPL, CW 90PV075	90-R-075-DC-1-BC-60-S-3-S1-D-GB-GBA-42-42-24	SERIES 90	S90-075PV
80002451	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-A-V-C-B-BA-B-B-G-A-BFF-CE-A-HH-B-D-G-A-BFF-DA-A-GG-A-NNN-*	M46	M46-046PT
80002452	MOTOR-VAR-DISPL 51MV080-1	51V080-1--A-C7-N-T7-D7-N-N-X1-NNN-035-AA-F0-00-27	SERIES 51	S51-080MV-1
80002463	MOTOR-VAR-DISPL 51MD110-1	51D110-1--R-D3-N-T2-C2-N-N-X1-NNN-074-AA-F3-00-28	SERIES 51	S51-110MV-1
80002465	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-NN-80-R-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
80002466	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-CD-80-R-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-100PV
80002470	PUMP-VAR-DISPL CW 90PV250	90R250-KP-5-CD-80-S-3-C8-J-03-NNN-32-32-24	SERIES 90	S90-250PV
80002471	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-NN-80-R-3-C6-C-03-GBA-29-14-28	SERIES 90	S90-055PV
80002472	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-G-T-B-B-AA-A-A-BHJ-CE-A-GG-C-NNN-***	M46	M46-046PV
80002473	MOTOR-FIX DISPL MMF044D	MMF-044-D-A-F-U-A-G-NNN-***	M35/44	044MF
80002474	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-Z-T-B-B-BA-J-A-BGG-DA-A-WA-C-NNN-***	M46	M46-046PV
80002475	PUMP-VAR DISPL, CW 90PV100	90-R-100-DC-1-BC-60-P-4-S1-E-GB-GBA-26-26-24	SERIES 90	S90-100PV
80002476	PUMP-VAR DISPL MPV035D	MPV-035-D-B-A-A-R-S-M-AA-A-A-BFF-DR-A-FF-A-NNN-***	M35/44	035PV
80002478	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-AB-80-S-4-C8-H-03-GBA-35-14-30	SERIES 90	S90-130PV
80002479	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-BC-80-S-4-C8-H-03-GBA-35-14-30	SERIES 90	S90-130PV
80002480	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-E-TA-C2-L-N-G0-NNN-040-AA-F0-00-A5	SERIES 51	S51-160MV
80002486	PUMP-VAR-DISPL CW 90PV250	90R250-HF-5-AB-80-T-4-F1-K-03-NNN-35-17-24	SERIES 90	S90-250PV
80002487	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D3-N-T2-D2-N-N-X1-ADA-036-AA-NN-00-27	SERIES 51	S51-080MV-1
80002488	PUMP-VAR-DISPL CCW 90PV250	90L250-KN-5-CD-80-D-4-F1-L-03-NNN-35-35-28	SERIES 90	S90-250PV
80002489	PUMP-VAR-DISPL CCW 90PV100	90L100-MA-5-BC-80-S-3-C7-E-C5-GBA-42-42-24	SERIES 90	S90-100PV
80002490	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-T1-C0-L-N-G0-ACA-090-AA-F0-00-C5	SERIES 51	S51-160MV
80002493	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-NN-80-S-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-075PV
80002494	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-T1-C0-L-N-G0-ACA-041-AA-F0-00-C5	SERIES 51	S51-160MV
80002496	MOTOR-VAR-DISPL 51MC080	51C080-R-D3-N-L2-B1-V-A-C2-ACA-040-AA-E6-B2-00	SERIES 51	S51-080MV
80002497	PUMP-VAR-DISPL CCW 90PV130	90L130-KN-5-BC-80-L-3-F1-F-00-GBA-38-38-24	SERIES 90	S90-130PV
80002498	PUMP-VAR-DISPL CCW 90PV130	90L130-HS-5-CD-80-R-3-F1-F-03-EEB-35-35-24	SERIES 90	S90-130PV
80002499	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-NN-80-R-3-C7-E-03-GBA-26-26-24	SERIES 90	S90-100PV
80002501	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-NN-60-R-4-S1-F-03-GBA-20-20-24	SERIES 90	S90-100PV

80002504	PUMP-VAR-DISPL CW 90PV075	90R075-HF-5-CD-80-S-3-C6-D-03-GBA-42-42-24	SERIES 90	S90-075PV
80002505	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-CD-80-T-M-C8-J-03-NNN-35-35-24	SERIES 90	S90-180PV
80002506	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-BC-80-L-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-075PV
80002507	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-N-HS-A2-B-E-E1-NNN-060-AA-F0-05-32	SERIES 51	S51-250MV
80002508	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-HS-A2-B-E-E1-NNN-050-AA-F0-05-29	SERIES 51	S51-250MV
80002509	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-1-AB-80-P-3-T1-E-03-EBC-35-14-24	SERIES 90	S90-075PV
80002510	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-AB-80-P-3-T1-E-03-EBC-35-14-24	SERIES 90	S90-075PV
80002511	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-AB-80-S-3-C3-C-03-GBA-35-35-24	SERIES 90	S90-042PV
80002512	MOTOR-VAR-DISPL 51MD110-1	51D110-1--A-D3-N-T1-R5-N-N-X1-NNN-070-AA-F3-00-23	SERIES 51	S51-110MV-1
80002513	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-BB-80-S-3-F1-E-02-GBA-45-45-24	SERIES 90	S90-100PV
80002514	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-E1-R2-A-N-E3-NNN-055-AA-F3-03-30	SERIES 51	S51-160MV
80002515	PUMP-VAR-DISPL CCW H1PV078	H1-P-078-L-A-A2-C2-N-D6-H-G9-H2-L-40-L-40-C-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
80002516	PUMP-VAR-DISPL CW 90PV075	90R075-MA-5-AB-60-L-4-C6-D-C7-GBA-32-32-24	SERIES 90	S90-075PV
80002517	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-C8-N-E1-B1-N-N-U1-NNN-045-AA-NN-00-00	SERIES 51	S51-110MV-1
80002520	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-E1-B1-N-N-U1-ABA-063-AA-F0-00-00	SERIES 51	S51-110MV-1
80002521	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-N1-NN-N-N-U1-NNN-022-AA-NN-00-00	SERIES 51	S51-110MV-1
80002524	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-AB-60-S-3-C7-E-03-GBA-38-38-24	SERIES 90	S90-100PV
80002531	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-N-L7-B1-W-B-M3-ANB-060-BB-C3-D4-00	SERIES 51	S51-160MV
80002533	PUMP-VAR DISPL, CW 90PV100	90-R-100-HS-1-CD-60-P-3-F1-E-03-GBA-32-32-24	SERIES 90	S90-100PV
80002533C	PUMP-VAR DISPL, CW 90PV100	90-R-100-HS-1-CD-60-P-3-F1-E-03-GBA-32-32-24	SERIES 90	S90-100PV
80002534	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-CD-80-R-3-C7-E-03-GBA-32-32-24	SERIES 90	S90-075PV
80002534C	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-CD-80-R-3-C7-E-03-GBA-32-32-24	SERIES 90	S90-075PV
80002535	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-CD-80-R-3-F1-F-03-GBA-32-32-24	SERIES 90	S90-100PV
80002535C	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-CD-80-R-3-F1-F-03-GBA-32-32-24	SERIES 90	S90-100PV
80002536	PUMP-VAR DISPL, CW 90PV100	90-R-100-MB-1-BC-80-S-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
80002536C	PUMP-VAR DISPL, CW 90PV100	90-R-100-MB-1-BC-80-S-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
80002537	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-5-CD-60-R-3-C6-D-04-GBA-42-42-24	SERIES 90	S90-055PV
80002538	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-5-NN-60-R-3-S1-D-04-GBA-42-42-24	SERIES 90	S90-055PV
80002539	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-BB-80-S-3-C8-F-03-GBA-45-45-24	SERIES 90	S90-130PV
80002540	PUMP-VAR DISPL, CW 90PV055	90-R-055-FC-2-NN-60-S-7-C6-C-B1-EFI-42-42-32	SERIES 90	S90-055PV
80002543	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-TA-C2-L-N-G0-NNN-074-AA-G0-00-B0	SERIES 51	S51-250MV
80002544	PUMP-VAR-DISPL CW 90PV100	90R100-KN-5-BB-80-P-4-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
80002545	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-BB-80-S-4-C3-C-03-GBA-30-30-24	SERIES 90	S90-042PV
80002546	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-K-S-B-J-AA-G-A-BJJ-DA-A-ZB-B-NNR-***	M46	M46-046PV
80002549	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-BC-80-S-7-C7-F-09-FAZ-35-35-30	SERIES 90	S90-100PV
80002550	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-F2-A2-A-N-E1-NNN-085-AA-G0-03-28	SERIES 51	S51-160MV

80002551	MOTOR-VAR-DISPL 51MV060-1	51V060-1--H-S1-N-TA-C2-N-N-X1-NNN-018-AA-NN-00-21	SERIES 51	S51-060MV-1
80002557	MOTOR-VAR-DISPL 51MD110-1	51D110-1--R-D3-N-E1-B1-N-N-U1-NNN-065-AA-F3-00-00	SERIES 51	S51-110MV-1
80002560	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-E2-A5-A-N-G0-ACA-080-AA-G0-03-00	SERIES 51	S51-160MV
80002561	PUMP-VAR-DISPL CCW 90PV180	90L180-HF-5-CD-80-T-C-F1-H-03-FAC-35-35-24	SERIES 90	S90-180PV
80002563	MOTOR-VAR-DISPL 51MV060-1	51V060-1--R-S1-N-E2-B1-N-N-U1-ABA-024-AA-NN-00-00	SERIES 51	S51-060MV-1
80002564	MOTOR-VAR-DISPL 51MV080	51V080-A-S1-N-L2-B1-V-A-C0-ABA-016-AA-G0-B2-00	SERIES 51	S51-080MV
80002566	PUMP-VAR-DISPL CCW 90PV075	90L075-FK-P-BC-80-S-7-TG-D-B6-GME-48-48-30	SERIES 90	S90-075PV
80002567	PUMP-VAR DISPL, CW 90PV055	90-R-055-KN-1-NN-80-S-4-S1-C-03-GBA-29-14-20	SERIES 90	S90-055PV
80002571	PUMP-VAR-DISPL CW 90PV130	90R130-HF-5-AB-80-R-4-C8-H-00-GBA-30-30-30	SERIES 90	S90-130PV
80002572	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-BC-80-S-3-S1-E-03-GBA-29-29-28	SERIES 90	S90-100PV
80002573	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-C-C3-B1-N-N-U1-AWK-N16-AA-E6-00-00	SERIES 51	S51-060MV-1
80002574	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-C-C3-B1-N-N-U1-DDF-N16-AA-E6-00-00	SERIES 51	S51-060MV-1
80002575	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-N-C3-B1-N-N-U1-DDF-N20-AA-NN-00-00	SERIES 51	S51-060MV-1
80002578	PUMP-VAR DISPL MPV046C	MPV-046-C-B-A-H-S-B-B-BA-A-A-BGG-AB-U-FA-A-NNN-***	M46	M46-046PV
80002580	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-5-BC-80-T-4-F1-K-03-NNN-26-26-24	SERIES 90	S90-250PV
80002581	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-HZ-B1-A-N-G0-NNN-054-AA-NN-03-00	SERIES 51	S51-080MV
80002582	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-BC-80-S-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
80002583	PUMP, VARIABLE DIRECT DISPLACMENT	LPV-B-A-A-A-E-AA-C-A-BFF-DR-A-FF-A-NNN-***	LPV	LPV
80002584	PUMP, VARIABLE DIRECT DISPLACMENT	LPV-B-A-A-F-A-E-AA-C-A-BFF-DR-A-FF-A-NNN-***	LPV	LPV
80002585	MOTOR-VAR-DISPL 51MV160	51V160-A-C8-N-HE-B2-C-H-H7-NNN-054-AA-G0-12-00	SERIES 51	S51-160MV
80002587	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-1-NN-60-P-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
80002588	MOTOR- VARIABLE CARTRIDGE L	L-C-30DN-E-RNF-F55-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
80002589	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-NN-60-L-3-C7-D-03-GBA-38-38-20	SERIES 90	S90-075PV
80002590	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-AD-80-P-3-S1-C-03-GBA-26-26-24	SERIES 90	S90-055PV
80002590C	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-AD-80-P-3-S1-C-03-GBA-26-26-24	SERIES 90	S90-055PV
80002591	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-CD-80-R-3-F1-F-03-GBA-20-20-24	SERIES 90	S90-100PV
80002591C	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-CD-80-R-3-F1-F-03-GBA-20-20-24	SERIES 90	S90-100PV
80002592	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A2-C3-N-D4-G-G2-H6-L-44-L-44-L-M-34-PN-NNN-G14	H1-HP PUMPS	H1-147PV/165PV
80002595	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-NN-80-L-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
80002602	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-AB-80-L-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
80002603	MOTOR-VAR-DISPL 51MV110	51V110-R-F1-N-EQ-A5-K-Y-G5-ABA-055-AA-F3-50-00	SERIES 51	S51-110MV
80002604	PUMP-VAR-DISPL CW 90PV250	90R250-KP-5-CD-80-S-3-C8-J-03-NNN-35-35-28	SERIES 90	S90-250PV
80002605	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-S1-N-T1-D1-N-N-X1-ABA-033-AA-E6-00-21	SERIES 51	S51-080MV-1
80002609	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-CD-80-P-4-C7-E-03-GBA-42-42-24	SERIES 90	S90-075PV
80002610	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-NN-80-L-3-F1-F-03-GBA-38-38-24	SERIES 90	S90-130PV
80002614	PUMP-VAR-DISPL CW 90PV250	90R250-HF-5-AB-80-T-4-C8-K-03-NNN-42-42-24	SERIES 90	S90-250PV

80002615	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-E1-A5-A-N-G0-NNN-085-AA-F0-03-00	SERIES 51	S51-160MV
80002616	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-K-S-B-B-AA-A-A-BJJ-BB-A-GG-B-NNN-***	M46	M46-046PV
80002619	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-DE-80-S-3-C8-K-03-NNN-35-35-30	SERIES 90	S90-250PV
80002620	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-H-T-B-B-AA-A-A-BJJ-CB-A-HH-A-NNN-***	M46	M46-046PV
80002621	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-H-L-B-A-AA-A-A-BJJ-CB-A-HH-A-NNN-***	M46	M46-046PV
80002622	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-H-T-B-J-BA-A-A-BFF-CB-A-GG-A-NNN-***	M46	M46-046PV
80002623	MOTOR-VARIABLE DISPL SAE_K	K-V-38CN-E-R1F-F10-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
80002624	PUMP-VAR-DISPL CW 90PV042	90R042-MA-5-NN-80-S-4-C3-C-C5-GBA-42-42-24	SERIES 90	S90-042PV
80002625	PUMP-VAR-DISPL CW 90PV100	90R100-MA-5-BB-60-S-4-C7-E-C5-GBA-42-42-24	SERIES 90	S90-100PV
80002630	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-2-NN-80-P-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
80002631	PUMP-VAR DISPL MPV035D	MPV-035-D-B-A-A-W-S-G-AA-A-A-BDD-DL-A-FF-A-NNN-***	M35/44	035PV
80002633	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-NN-60-P-3-C7-E-03-GBA-38-14-24	SERIES 90	S90-100PV
80002635	PUMP-VAR-DISPL CW 90PV180	90R180-DC-5-EF-80-S-C-F1-H-GB-FAC-42-42-24	SERIES 90	S90-180PV
80002637	PUMP-VAR-DISPL CW 90PV180	90R180-DC-5-NN-80-S-C-F1-H-GB-FAC-42-42-24	SERIES 90	S90-180PV
80002639	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A2-C2-N-E7-F-G1-H5-38-38-38-38-N-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
80002640	PUMP-VAR-DISPL CW 90PV100	90R100-DD-5-CD-80-S-3-C7-E-G8-GBA-42-42-24	SERIES 90	S90-100PV
80002641	MOTOR-VAR-DISPL 51MD110-1	51D110-1--A-D4-N-T1-R5-N-N-X1-ADA-072-AA-F3-00-28	SERIES 51	S51-110MV-1
80002643	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-BC-60-P-3-C7-D-00-EAB-38-38-24	SERIES 90	S90-075PV
80002644	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-CD-80-S-4-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
80002645	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-CD-80-P-4-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
80002647	PUMP, VARIABLE DIRECT DISPLACMENT	LPV-B-A-A-C-A-G-AA-C-A-BDD-DR-A-FF-A-NNN-***	LPV	LPV
80002648	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-K-S-B-J-AA-V-A-BJJ-DA-A-ZG-B-NNN-***	M46	M46-046PV
80002649	1MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-E1-B1-N-N-U1-ABA-055-AA-NN-00-00	SERIES 51	S51-110MV-1
80002650	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-HZ-B1-C-E-C2-NNN-054-AA-E6-24-00	SERIES 51	S51-080MV
80002651	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A9-C2-N-D8-F-G4-NN-L-25-L-25-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
80002652	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-AB-80-R-3-F1-H-03-GBA-29-29-24	SERIES 90	S90-130PV
80002653	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-NN-80-L-3-F1-F-06-GBA-38-38-24	SERIES 90	S90-130PV
80002656	MOTOR-VARIABLE DISPL SAE_K	K-V-38CN-C-YNF-F09-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
80002658	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-L2-B1-V-A-G0-ACA-168-AA-G0-B2-00	SERIES 51	S51-250MV
80002659	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-K-S-B-J-AA-V-A-BJJ-DA-A-ZG-B-NNN-***	M46	M46-046PV
80002662	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A5-C2-N-D5-G-G2-H4-L-35-L-35-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
80002663	MOTOR-VAR-DISPL 51MV080-1	51V080-1--A-S1-N-N1-NN-N-N-U1-ABA-024-AA-E6-00-00	SERIES 51	S51-080MV-1
80002664	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-T1-C0-L-N-G0-NNN-050-AA-G3-00-A3	SERIES 51	S51-250MV
80002665	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-HZ-B1-A-N-G0-NNN-040-AA-F3-03-00	SERIES 51	S51-160MV
80002666	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-CD-80-L-3-F1-H-05-GBA-42-42-28	SERIES 90	S90-130PV
80002667	PUMP-VAR-DISPL CCW 90PV250	90L250-KP-5-BC-80-S-3-F1-K-03-NNN-38-38-24	SERIES 90	S90-250PV

80002668	PUMP-VAR-DISPL CW 90PV130	90R130-HS-5-NN-80-L-3-F1-H-06-GBA-38-38-24	SERIES 90	S90-130PV
80002669	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-P-BK-80-P-3-C6-C-03-FAB-48-48-24	SERIES 90	S90-055PV
80002670	PUMP-VAR DISPL, CW 90PV055	90-R-055-KT-1-AB-60-P-4-S1-C-03-GBA-17-17-20	SERIES 90	S90-055PV
80002672	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-5-CD-80-S-4-C8-K-03-NNN-35-35-24	SERIES 90	S90-250PV
80002683	MOTOR-VAR-DISPL 51MC080	51C080-R-D3-N-L2-B1-V-A-C0-NNN-040-AA-E6-B2-00	SERIES 51	S51-080MV
80002692	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-5-AB-60-S-4-C6-C-C5-GBA-29-29-24	SERIES 90	S90-055PV
80002694	MOTOR-VAR-DISPL 51MD160	51D160-A-D4-N-D8-M1-R-J-M4-NNN-045-AA-F3-C2-25	SERIES 51	S51-160MV
80002695	MOTOR-VAR-DISPL 51MC060-1	51C060-1--A-D1-E-N1-NN-N-N-U1-NNN-014-AA-E4-00-00	SERIES 51	S51-060MV-1
80002698	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-TA-C2-L-N-G0-NNN-095-AA-NN-00-A5	SERIES 51	S51-160MV
80002700	PUMP, VARIABLE DIRECT DISPLACMENT	LPV-B-A-B-C-A-G-AA-C-A-BFF-DR-A-FF-B-NNN-***	LPV	LPV
80002701	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HF-1-BC-60-R-3-K3-E-00-GBA-32-32-24	SERIES 90	S90-100PV
80002703	PUMP-VAR-DISPL CCW 90PV250	90L250-MA-5-NN-80-T-3-F1-K-C7-NNN-32-32-24	SERIES 90	S90-250PV
80002704	PUMP-VAR-DISPL CW 90PV250	90R250-KP-2-CD-80-T-4-C8-J-03-NNN-32-32-24	SERIES 90	S90-250PV
80002708	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-P-BG-80-P-3-C6-C-C5-FAB-48-48-24	SERIES 90	S90-055PV
80002709	MOTOR-VAR-DISPL 51MV060-1	51V060-1--R-S1-B-E1-B1-N-N-U1-ABA-040-AA-NN-00-00	SERIES 51	S51-060MV-1
80002710	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-5-NN-80-S-4-C8-J-03-NNN-26-26-24	SERIES 90	S90-250PV
80002711	MOTOR-VARIABLE DISPL SAE_L	L-V-25CN-A-R1F-F11-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
80002716	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-N-HS-A2-B-H-E1-NNN-080-AA-NN-10-18	SERIES 51	S51-160MV
80002717	MOTOR-VAR-DISPL 51MV060	51V060-A-S1-N-HS-A2-B-H-C1-NNN-030-AA-NN-10-13	SERIES 51	S51-060MV
80002718	PUMP, VARIABLE DIRECT DISPLACMENT	LPV-A-A-A-C-A-G-AA-D-A-BFF-DR-A-FF-B-NNN-***	LPV	LPV
80002722	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-BB-80-S-7-C6-E-21-EFI-45-45-24	SERIES 90	S90-075PV
80002723	MOTOR-VAR-DISPL 51MD110-1	51D110-1--R-D3-N-T7-CA-N-N-X1-AWM-067-AA-F3-00-23	SERIES 51	S51-110MV-1
80002725	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A3-C2-N-D6-F-G1-H3-L-30-L-30-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
80002726	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KN-1-NN-80-S-4-S1-D-03-GBA-29-29-24	SERIES 90	S90-075PV
80002726C	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KN-1-NN-80-S-4-S1-D-03-GBA-29-29-24	SERIES 90	S90-075PV
80002727	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KN-1-CD-80-S-4-S1-D-03-GBA-29-29-24	SERIES 90	S90-075PV
80002727C	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KN-1-CD-80-S-4-S1-D-03-GBA-29-29-24	SERIES 90	S90-075PV
80002729	PUMP-VAR DISPL, CW 90PV055	90-R-055-CA-1-BG-80-R-3-S1-B-00-EDC-26-26-24	SERIES 90	S90-055PV
80002730	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-BC-80-S-3-C8-J-04-NNN-42-42-28	SERIES 90	S90-250PV
80002731	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-CD-80-S-3-C7-E-03-GBA-20-20-24	SERIES 90	S90-100PV
80002732	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-NN-80-S-3-C7-D-03-GBA-35-35-24	SERIES 90	S90-075PV
80002732C	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-NN-80-S-3-C7-D-03-GBA-35-35-24	SERIES 90	S90-075PV
80002733	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HF-1-NN-60-R-4-K3-E-00-GBA-32-32-24	SERIES 90	S90-100PV
80002738	PUMP-VAR DISPL, CW 90PV100	90-R-100-HF-1-BC-60-S-3-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
80002739	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-L1-B1-W-B-J1-ADA-054-AA-F3-D4-00	SERIES 51	S51-160MV
80002741	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-S1-D-N1-NN-N-N-U1-NNN-016-AA-F0-00-00	SERIES 51	S51-080MV-1

80002742	PUMP-VAR DISPL, CW 90PV055	90-R-055-KN-5-NN-60-P-3-C6-C-03-GBA-42-42-24	SERIES 90	S90-055PV
80002743	PUMP-VAR-DISPL CCW 90PV130	90L130-HF-5-NN-80-P-3-F1-F-00-GBA-35-35-24	SERIES 90	S90-130PV
80002744	PUMP-VAR-DISPL CW 90PV130	90R130-MA-5-AB-80-R-3-F1-H-C5-GBA-29-29-24	SERIES 90	S90-130PV
80002745	PUMP-VAR-DISPL CW 90PV180	90R180-MA-5-NN-80-T-C-F1-J-C5-FAC-29-29-24	SERIES 90	S90-180PV
80002747	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-1-AB-60-L-3-C6-D-03-GBA-42-42-24	SERIES 90	S90-075PV
80002749	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-BG-80-R-3-S1-D-03-GBA-29-29-24	SERIES 90	S90-055PV
80002751	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-NN-60-S-3-C6-C-04-GBA-42-42-20	SERIES 90	S90-055PV
80002752	MOTOR-VAR-DISPL 51MV160	51V160-A-C8-N-HS-A1-B-E-E2-NNN-032-AA-F3-08-25	SERIES 51	S51-160MV
80002755	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-2-BC-60-R-3-S1-E-00-GBA-42-42-24	SERIES 90	S90-075PV
80002757	PUMP-VAR-DISPL CW 90PV075	90R075-KP-5-CD-80-L-4-S1-D-03-GBA-17-17-18	SERIES 90	S90-075PV
80002758	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-DE-80-S-3-F1-H-03-GBA-42-42-24	SERIES 90	S90-130PV
80002759	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-T2-C0-L-N-K7-NNN-088-AA-G0-00-B0	SERIES 51	S51-250MV
80002761	MOTOR-VAR-DISPL 51MV060	51V060-R-C6-N-N2-NN-N-N-A0-NNN-025-AA-NN-00-00	SERIES 51	S51-060MV
80002762	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-CD-80-R-4-T2-F-03-GBA-26-26-24	SERIES 90	S90-100PV
80002764	MOTOR-VAR-DISPL 51MV110	51V110-R-F1-N-HZ-B1-B-H-G5-NNN-024-AA-F0-06-00	SERIES 51	S51-110MV
80002765	MOTOR-VAR-DISPL 51MV110	51V110-R-F1-N-HZ-B1-B-H-G5-ACA-024-AA-F0-06-00	SERIES 51	S51-110MV
80002771	PUMP-VAR DISPL, CW 90PV075	90-R-075-HS-1-NN-80-L-3-S1-D-05-GBA-26-26-24	SERIES 90	S90-075PV
80002773	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-BC-60-S-3-C7-E-03-GBA-35-35-20	SERIES 90	S90-100PV
80002776	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-CD-80-S-3-C6-C-03-GBA-32-32-24	SERIES 90	S90-055PV
80002777	MOTOR-VAR-DISPL 51MV060	51V060-R-C6-N-N2-NN-N-N-A0-ADA-025-AA-NN-00-00	SERIES 51	S51-060MV
80002778	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-HZ-B1-B-N-C2-NNN-115-AA-G3-06-00	SERIES 51	S51-160MV
80002779	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-NN-80-L-3-C8-H-03-GBA-42-14-30	SERIES 90	S90-130PV
80002781	MOTOR-VAR-DISPL 51MD160	51D160-A-D4-N-T3-C0-L-N-J1-ADA-042-AA-F3-00-B1	SERIES 51	S51-160MV
80002782	PUMP-VAR-DISPL CW 90PV130	90R130-FH-5-AB-80-S-7-TK-H-B1-EFI-20-20-32	SERIES 90	S90-130PV
80002786	PUMP-VAR DISPL, CW 90PV055	90-R-055-FC-5-AB-60-R-7-C6-C-B1-GLA-38-38-30	SERIES 90	S90-055PV
80002788	MOTOR-VAR DISPL MMV035D	MMV-035-D-A-A-D-R-R-NNR-***	M35/44	035MV
80002789	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-D-HZ-B1-A-N-G0-ABA-031-AA-NN-03-00	SERIES 51	S51-080MV
80002790	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-TA-C2-N-N-X1-NNN-022-AA-G0-00-21	SERIES 51	S51-110MV-1
80002793	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-AB-60-S-4-C7-E-03-GBA-30-30-24	SERIES 90	S90-100PV
80002794	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-BB-60-P-4-C7-D-03-GBS-07-35-20	SERIES 90	S90-075PV
80002795	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-T2-C0-L-N-K7-NNN-055-AA-G3-00-B2	SERIES 51	S51-160MV
80002796	PUMP-VAR-DISPL CW 90PV180	90R180-MA-5-AB-80-T-M-C8-H-C7-NNN-29-29-24	SERIES 90	S90-180PV
80002802	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-CD-80-L-4-C8-F-05-GBA-26-26-24	SERIES 90	S90-130PV
80002804	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-BC-80-T-C-F1-J-03-FAC-14-14-24	SERIES 90	S90-180PV
80002806	PUMP-VAR DISPL MPV046C	MPV-046-C-B-A-D-S-B-BA-A-A-BFF-AB-U-FF-B-NNN-***	M46	M46-046PV
80002808	PUMP-VAR DISPL, CW 90PV100	90-R-100-KT-5-CD-80-P-3-S1-F-03-GBA-35-35-24	SERIES 90	S90-100PV

80002812	PUMP-VAR-DISPL CCW 90PV042	90L042-KA-5-AB-80-R-3-C3-C-03-GBA-23-23-24	SERIES 90	S90-042PV
80002813	PUMP-VAR-DISPL CCW 90PV075	90L075-DD-5-NN-60-S-3-C7-D-GB-GBA-38-38-24	SERIES 90	S90-075PV
80002814	PUMP-VAR-DISPL CW 90PV075	90R075-FL-1-BC-80-S-7-C6-E-B6-GME-42-42-30	SERIES 90	S90-075PV
80002818	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-CD-80-S-3-C7-D-00-GBA-29-29-20	SERIES 90	S90-075PV
80002819	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-NN-80-S-3-S1-C-00-GBA-29-29-20	SERIES 90	S90-055PV
80002820	PUMP-TANDEM, VAR DISPL MPT025C	MPT-025-C-S-L-A-G-NN-B-A-A-A-BJJ-DL-A-FF-B-A-A-A-BJJ-DL-A-FF-A-NNN-***	LIGHT DUTY	025PT
80002821	MOTOR-VARIABLE DISPL SAE_K	K-V-45DN-E-R2F-F09-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
80002823	PUMP-VAR-DISPL CCW 90PV130	90L130-MB-5-NN-80-R-3-F1-H-C4-GBA-42-42-24	SERIES 90	S90-130PV
80002826	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-AB-80-S-3-C8-F-03-GBA-42-42-24	SERIES 90	S90-130PV
80002828	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-D-E2-A5-A-N-A6-NNN-082-AA-F3-03-00	SERIES 51	S51-250MV
80002830	PUMP-VAR-DISPL CCW 90PV130	90L130-KN-5-CD-80-R-3-F1-H-03-EEB-35-35-24	SERIES 90	S90-130PV
80002831	MOTOR-VAR-DISPL 51MD110-1	51D110-1--A-D4-N-TA-C2-N-N-X1-NNN-040-AA-NN-00-13	SERIES 51	S51-110MV-1
80002834	MOTOR-FIX DISPL MMF035D	MMF-035-D-B-C-C-C-N-NNN-***	M35/44	035MF
80002835	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-5-NN-80-T-4-C8-J-05-NNN-29-29-24	SERIES 90	S90-250PV
80002844	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KN-5-AB-80-S-4-C7-E-03-GBA-20-20-24	SERIES 90	S90-100PV
80002844C	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KN-5-AB-80-S-4-C7-E-03-GBA-20-20-24	SERIES 90	S90-100PV
80002845	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KN-1-AD-80-S-3-S1-D-03-GBA-20-20-24	SERIES 90	S90-055PV
80002845C	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KN-1-AD-80-S-3-S1-D-03-GBA-20-20-24	SERIES 90	S90-055PV
80002846	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-1-NN-80-S-3-C6-E-03-GBA-42-42-24	SERIES 90	S90-075PV
80002846C	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-1-NN-80-S-3-C6-E-03-GBA-42-42-24	SERIES 90	S90-075PV
80002847	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MA-1-AB-80-S-3-C7-E-06-GBA-32-32-24	SERIES 90	S90-100PV
80002847C	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MA-1-AB-80-S-3-C7-E-06-GBA-32-32-24	SERIES 90	S90-100PV
80002848	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-NN-80-P-3-S1-D-03-EBC-35-35-24	SERIES 90	S90-075PV
80002848C	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-NN-80-P-3-S1-D-03-EBC-35-35-24	SERIES 90	S90-075PV
80002849	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-BC-80-P-3-C7-D-03-GBA-29-29-24	SERIES 90	S90-075PV
80002849C	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-BC-80-P-3-C7-D-03-GBA-29-29-24	SERIES 90	S90-075PV
80002850	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-CD-80-P-3-C7-D-03-GBA-29-29-24	SERIES 90	S90-075PV
80002850C	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-CD-80-P-3-C7-D-03-GBA-29-29-24	SERIES 90	S90-075PV
80002851	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-NN-60-P-4-S1-C-03-GBA-26-26-24	SERIES 90	S90-055PV
80002852	PUMP-VAR-DISPL CCW 90PV130	90L130-MA-5-NN-80-L-3-C8-F-C5-GBA-35-35-24	SERIES 90	S90-130PV
80002853	PUMP-VAR-DISPL CCW 90PV130	90L130-MA-5-AB-80-L-3-C8-F-C5-GBA-35-35-24	SERIES 90	S90-130PV
80002854	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-CD-60-P-4-C6-C-03-GBA-26-26-24	SERIES 90	S90-055PV
80002855	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A4-C2-N-D3-G-G2-H3-L-42-L-42-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
80002856	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-AB-80-S-C-C8-J-03-NNN-38-38-30	SERIES 90	S90-180PV
80002857	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-BC-80-S-C-C8-J-03-NNN-38-38-30	SERIES 90	S90-180PV
80002858	PUMP-VAR-DISPL CW 90PV075	90R075-FN-5-CD-60-S-7-C7-E-B6-EFP-42-42-30	SERIES 90	S90-075PV

80002859	PUMP-VAR-DISPL CW 90PV100	90R100-HF-5-NN-60-S-4-C7-E-04-GBA-26-26-24	SERIES 90	S90-100PV
80002860	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-AD-80-S-4-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
80002861	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-AD-80-S-4-C6-C-03-GBA-42-42-24	SERIES 90	S90-055PV
80002862	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-1-BG-80-S-3-S1-C-03-GBA-35-35-20	SERIES 90	S90-055PV
80002863	PUMP-VAR-DISPL CCW 90PV100	90L100-MA-5-CD-80-P-3-C7-E-C6-GBA-42-42-24	SERIES 90	S90-100PV
80002864	MOTOR-VAR DISPL MMV046C	MMV-046-C-A-A-F-A-A1-NNN-***	M46	M46-046MV
80002865	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HK-1-BC-80-S-3-S1-E-03-GBA-40-40-24	SERIES 90	S90-075PV
80002869	PUMP-VAR DISPL, CCW 90PV055	90-L-055-MA-1-NN-80-S-3-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV
80002869C	PUMP-VAR DISPL, CCW 90PV055	90-L-055-MA-1-NN-80-S-3-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV
80002870	MOTOR-VAR-DISPL 51MV080-1	51V080-1--A-S1-N-E1-B1-N-N-U1-ABA-045-AA-G0-00-00	SERIES 51	S51-080MV-1
80002871	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-AB-80-S-4-C8-K-03-NNN-42-42-24	SERIES 90	S90-250PV
80002872	PUMP-VAR-DISPL CCW 90PV075	90L075-MA-5-AB-80-P-3-S1-D-C7-GBA-42-42-24	SERIES 90	S90-075PV
80002875	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-1-CD-80-S-3-C6-D-02-GBA-29-29-24	SERIES 90	S90-055PV
80002877	MOTOR-VAR-DISPL 51MV160	51V160-A-C8-N-TA-C2-L-N-G0-NNN-063-AA-G3-00-B1	SERIES 51	S51-160MV
80002878	PUMP-VAR-DISPL CW 90PV180	90R180-DD-5-CD-80-S-C-C8-H-GB-NNN-35-35-22	SERIES 90	S90-180PV
80002882	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-CD-80-P-4-F1-E-03-GBA-29-29-24	SERIES 90	S90-100PV
80002883	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-1-NN-80-P-4-S1-D-03-GBA-38-38-24	SERIES 90	S90-075PV
80002884	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-EQ-A5-J-Y-A6-ADA-150-AA-G0-30-00	SERIES 51	S51-250MV
80002886	MOTOR-FIX DISPL MMF044D	MMF-044-D-A-A-9-C-T-NBJ-***	M35/44	044MF
80002890	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-N-HZ-B1-C-H-G0-NNN-050-AA-NN-12-00	SERIES 51	S51-250MV
80002891	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-N-HZ-B1-C-H-G0-ABA-050-AA-NN-12-00	SERIES 51	S51-250MV
80002892	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-AB-80-S-4-C3-C-03-GBA-42-42-24	SERIES 90	S90-042PV
80002893	PUMP-VAR-DISPL CW 90PV075	90R075-MB-5-AB-80-S-4-C7-D-03-GBA-42-42-24	SERIES 90	S90-075PV
80002894	PUMP-VAR-DISPL CW 90PV100	90R100-MB-5-AB-80-S-4-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
80002895	PUMP-VAR-DISPL CW 90PV130	90R130-MB-5-AB-80-S-4-C8-H-03-GBA-42-42-24	SERIES 90	S90-130PV
80002896	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-NN-80-T-M-C8-J-03-NNN-42-42-24	SERIES 90	S90-180PV
80002897	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-AB-80-S-M-C8-J-03-NNN-42-42-24	SERIES 90	S90-180PV
80002899	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-EG-80-T-4-C8-K-03-NNN-42-42-24	SERIES 90	S90-250PV
80002900	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-5-CD-80-S-3-C6-D-02-GBA-29-29-24	SERIES 90	S90-055PV
80002902	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-CD-60-P-3-C7-F-03-GBA-32-32-24	SERIES 90	S90-100PV
80002904	PUMP-VAR-DISPL CCW 90PV075	90L075-HF-5-AB-60-S-4-C7-E-03-GBA-30-30-24	SERIES 90	S90-075PV
80002905	PUMP-VAR DISPL MPV035D	MPV-035-D-B-A-A-R-S-F-AA-A-A-BFF-DL-A-FF-C-NNN-***	M35/44	035PV
80002908	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-BC-80-T-C-C8-J-03-NNN-42-42-28	SERIES 90	S90-180PV
80002911	PUMP-VAR DISPL MPV046C	MPV-046-C-B-A-D-S-B-B-AA-A-A-BJJ-AB-D-AA-B-NNN-***	M46	M46-046PV
80002912	PUMP-VAR DISPL, CW 90PV055	90-R-055-MB-5-AD-80-S-4-C6-C-C5-GBA-42-42-24	SERIES 90	S90-055PV
80002913	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-NN-80-T-C-F1-J-03-FAC-20-20-22	SERIES 90	S90-180PV

80002915	PUMP-VAR-DISPL CCW 90PV042	90L042-MB-5-AB-80-S-4-C3-B-C5-GBA-35-35-24-F008	SERIES 90	S90-042PV
80002917	MOTOR-VAR-DISPL 51MV060-1	51V060-1--R-S1-N-T1-C2-N-N-X1-NNN-035-AA-E6-00-15	SERIES 51	S51-060MV-1
80002923	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-AB-60-P-3-S1-F-03-GBA-32-32-24	SERIES 90	S90-100PV
80002924	PUMP-VAR-DISPL CCW 90PV130	90L130-HS-5-NN-80-R-4-F1-L-03-GBA-35-35-34	SERIES 90	S90-130PV
80002925	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-NN-80-R-4-F1-F-03-GBA-35-35-24	SERIES 90	S90-130PV
80002927	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-AB-60-S-3-C7-E-04-GBA-35-35-24	SERIES 90	S90-100PV
80002930	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-EQ-A2-J-Y-E1-NNN-095-AA-F0-30-35	SERIES 51	S51-250MV
80002931	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-HS-A2-C-H-E1-NNN-050-AA-NN-12-22	SERIES 51	S51-160MV
80002932	PUMP-VAR-DISPL CCW 90PV180	90L180-HS-5-DE-80-T-M-C8-L-03-NNN-42-16-32	SERIES 90	S90-180PV
80002935	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-CD-80-T-C-C8-J-03-NNN-14-14-24	SERIES 90	S90-180PV
80002936	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-1-NN-60-R-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-055PV
80002937	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-AB-80-L-4-K3-F-03-GBA-42-42-24	SERIES 90	S90-100PV
80002938	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-1-AB-80-L-4-K2-E-03-GBA-42-42-24	SERIES 90	S90-075PV
80002939	PUMP-VAR DISPL, CW 90PV055	90-R-055-HS-1-BG-80-R-4-S1-C-00-GBA-35-35-24	SERIES 90	S90-055PV
80002940	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-AB-80-P-3-S1-D-00-GBA-42-42-24	SERIES 90	S90-075PV
80002941	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-CD-80-P-3-S1-D-00-GBA-42-42-24	SERIES 90	S90-075PV
80002943	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A2-C3-N-D4-G-G3-H5-L-44-L-44-L-M-34-PN-NNN-G14	H1-HP PUMPS	H1-147PV/165PV
80002944	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-G-T-B-B-AA-J-A-BHH-DA-A-ZD-C-NNN-***	M46	M46-046PV
80002945	PUMP-TANDEM, VAR DISPL MPT044D	MPT-044-D-A-R-R-G-AA-B-A-A-A-BDD-DL-A-FF-B-A-A-A-BDD-DR-A-FF-B-NNN-*	M35/44	044PT
80002946	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-E-V-C-S-AA-B-A-A-A-BHH-GG-B-KF-B-C-A-A-BHH-GG-B-KF-Y-NAF-*	M46	M46-046PT
80002949	PUMP-VAR DISPL, CW 90PV055	90-R-055-HS-1-NN-80-P-3-C6-C-03-GBA-38-38-24	SERIES 90	S90-055PV
80002949C	PUMP-VAR DISPL, CW 90PV055	90-R-055-HS-1-NN-80-P-3-C6-C-03-GBA-38-38-24	SERIES 90	S90-055PV
80002953	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-D-S-B-B-AA-A-A-BJJ-BB-A-RR-B-NNN-***	M46	M46-046PV
80002955	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-D-T-B-B-AA-G-A-BHH-CB-A-GG-B-NNN-***	M46	M46-046PV
80002957	MOTOR-VARIABLE DISPL SAE_L	L-V-30DS-A-R1F-F12-S-N-N-CF-F15-NNN-NNN	LV / KV MOTORS	L/K-MV
80002960	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A2-C2-N-E7-F-G5-H3-28-28-28-28-N-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
80002961	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-BB-80-S-3-C8-H-04-GBA-35-35-24	SERIES 90	S90-130PV
80002963	PUMP-VAR DISPL, CW 90PV100	90-R-100-MB-1-BC-80-S-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-100PV
80002964	MOTOR-VAR-DISPL 51MD080-1	51D080-1--A-D3-N-T1-CA-N-N-X1-NNN-026-AA-F0-00-23	SERIES 51	S51-080MV-1
80002966	MOTOR-VARIABLE CARTRIDGE K	K-C-38CS-E-RNF-F11-S-N-N-EF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
80002967	MOTOR-VAR-DISPL 51MV110	51V110-R-C8-N-HS-A3-B-E-E5-NNN-055-AA-G0-07-35	SERIES 51	S51-110MV
80002968	PUMP-VAR-DISPL CW 90PV180	90R180-HF-5-AB-80-S-M-C8-H-03-FAC-32-32-24	SERIES 90	S90-180PV
80002970	PUMP, VARIABLE DIRECT DISPLACMENT	LPV-B-A-A-A-A-E-AA-C-A-BFF-DR-A-FF-B-NNN-***	LPV	LPV
80002972	MOTOR-VAR-DISPL 51MV160	51V160-A-C8-N-HS-A2-B-E-E1-NNN-075-AA-G3-05-25	SERIES 51	S51-160MV
80002973	PUMP-VAR-DISPL CCW 90PV130	90L130-HF-5-BC-80-P-3-F1-H-03-GBA-42-42-24	SERIES 90	S90-130PV
80002974	PUMP-VAR-DISPL CW 90PV130	90R130-HF-5-NN-80-R-3-C8-H-03-GBA-23-23-20	SERIES 90	S90-130PV

80002975	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-NN-80-T-C-C8-J-03-NNN-23-23-30	SERIES 90	S90-180PV
80002976	PUMP-VAR DISPL, CW 90PV055	90-R-055-HF-1-CD-80-R-3-S1-D-03-GBA-32-32-24	SERIES 90	S90-055PV
80002980	PUMP-VAR-DISPL CCW 90PV130	90L130-HF-5-CD-80-P-7-F1-H-03-GBA-35-35-20	SERIES 90	S90-130PV
80002981	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-L2-B1-V-A-C0-NNN-050-AA-F0-B2-00	SERIES 51	S51-160MV
80002983	PUMP-VAR-DISPL CCW 90PV100	90L100-HF-5-AB-60-R-4-C7-E-03-GBA-35-35-26	SERIES 90	S90-100PV
80002984	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-BC-80-S-C-C8-H-03-NNN-21-21-24	SERIES 90	S90-180PV
80002985	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-BG-80-R-4-S1-C-03-GBA-23-23-24	SERIES 90	S90-055PV
80002987	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-NN-80-P-3-F1-H-03-GBA-42-42-24	SERIES 90	S90-130PV
80002989	MOTOR-VAR-DISPL 51MV110	51V110-R-C8-N-HS-A2-B-N-A7-NNN-034-AA-F3-07-15	SERIES 51	S51-110MV
80002990	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-AB-80-S-3-C7-F-03-GBA-42-42-24	SERIES 90	S90-100PV
80002992	PUMP-VAR DISPL, CW 90PV055	90-R-055-HS-1-NN-80-S-3-S1-C-03-GBA-29-29-24	SERIES 90	S90-055PV
80002992C	PUMP-VAR DISPL, CW 90PV055	90-R-055-HS-1-NN-80-S-3-S1-C-03-GBA-29-29-24	SERIES 90	S90-055PV
80002993	PUMP-VAR DISPL, CW 90PV055	90-R-055-MB-1-NN-80-S-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
80002993C	PUMP-VAR DISPL, CW 90PV055	90-R-055-MB-1-NN-80-S-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
80002994	PUMP-VAR DISPL, CW 90PV075	90-R-075-DD-1-CD-80-S-3-C7-D-GB-GBA-32-32-24	SERIES 90	S90-075PV
80002994C	PUMP-VAR DISPL, CW 90PV075	90-R-075-DD-1-CD-80-S-3-C7-D-GB-GBA-32-32-24	SERIES 90	S90-075PV
80002995	PUMP-VAR DISPL, CW 90PV075	90-R-075-DD-1-NN-80-S-3-S1-D-GB-GBA-32-32-24	SERIES 90	S90-075PV
80002995C	PUMP-VAR DISPL, CW 90PV075	90-R-075-DD-1-NN-80-S-3-S1-D-GB-GBA-32-32-24	SERIES 90	S90-075PV
80002997	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-5-BC-60-S-3-C6-C-GB-GBA-42-42-24	SERIES 90	S90-055PV
80002999	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-EG-80-T-4-C8-J-05-NNN-32-32-24	SERIES 90	S90-250PV
80003002	PUMP-VAR DISPL, CCW 90PV100	90-L-100-FC-5-BC-80-P-7-C7-E-B1-GCA-35-35-30	SERIES 90	S90-100PV
80003005	PUMP-VAR-DISPL CCW 90PV130	90L130-MA-V-BJ-8E-S-3-TN-F-C5-GB3-45-45-30	SERIES 90	S90-130PV
80003009	PUMP-VAR DISPL, CW 90PV100	90-R-100-CB-1-CD-80-S-3-C7-E-00-GBA-42-42-24	SERIES 90	S90-100PV
80003010	MOTOR-VARIABLE DISPL SAE_K	K-V-45DN-E-R2F-F09-S-N-N-CF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
80003011	MOTOR-VAR-DISPL 51MD060-1	51D060-1--A-D2-N-T7-D7-N-N-X1-NNN-030-AA-E4-00-27	SERIES 51	S51-060MV-1
80003012	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-NN-60-S-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
80003013	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-AB-80-S-C-F1-H-09-GCA-37-37-28	SERIES 90	S90-180PV
80003014	MOTOR-VAR-DISPL 51MD160	51D160-A-D4-N-TA-C2-L-N-G0-NNN-063-AA-G3-00-B1	SERIES 51	S51-160MV
80003015	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-AB-61-R-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-075PV
80003016	PUMP-VAR-DISPL CW 90PV075	90R075-KP-5-CD-60-P-3-S1-E-04-GBS-42-42-24	SERIES 90	S90-075PV
80003017	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-NN-80-S-C-C8-J-03-NNN-38-38-28	SERIES 90	S90-180PV
80003018	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-BC-80-P-3-C7-E-04-GBA-45-45-24	SERIES 90	S90-100PV
80003019	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-BC-80-P-3-C7-E-04-GBA-45-45-24	SERIES 90	S90-075PV
80003020	MOTOR-VAR-DISPL 51MC060-1	51C060-1--H-S1-N-TA-C2-N-N-X1-NNN-018-AA-NN-00-21	SERIES 51	S51-060MV-1
80003022	PUMP-VAR DISPL, CW 90PV075	90-R-075-DD-1-NN-60-P-4-S1-D-GB-GBA-38-38-24	SERIES 90	S90-075PV
80003022C	PUMP-VAR DISPL, CW 90PV075	90-R-075-DD-1-NN-60-P-4-S1-D-GB-GBA-38-38-24	SERIES 90	S90-075PV

80003023	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-CD-60-P-3-C7-E-03-GBA-40-40-24	SERIES 90	S90-100PV
80003023C	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-CD-60-P-3-C7-E-03-GBA-40-40-24	SERIES 90	S90-100PV
80003024	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-NN-80-P-3-C6-C-03-GBA-42-42-24	SERIES 90	S90-055PV
80003024C	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-NN-80-P-3-C6-C-03-GBA-42-42-24	SERIES 90	S90-055PV
80003025	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-AB-80-D-3-T1-L-03-GBA-42-42-24	SERIES 90	S90-075PV
80003025C	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-AB-80-D-3-T1-L-03-GBA-42-42-24	SERIES 90	S90-075PV
80003026	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-BG-80-P-3-S1-D-03-GBA-40-40-24	SERIES 90	S90-055PV
80003027	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-CD-80-P-3-S1-D-03-GBA-40-40-24	SERIES 90	S90-055PV
80003028	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-N-HZ-B1-A-N-G0-NNN-032-AA-NN-03-00	SERIES 51	S51-160MV
80003029	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-TH-C2-L-N-G0-NNN-032-AA-F0-00-B4	SERIES 51	S51-160MV
80003031	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-S1-N-E1-B1-N-N-U1-NNN-050-AA-NN-00-00	SERIES 51	S51-080MV-1
80003034	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-A-Z-C-B-AA-B-B-A-A-BJJ-CB-A-GG-B-D-A-A-BJJ-CB-A-GG-B-NNN-***	M46	M46-046PT
80003052	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-BB-80-S-3-S1-D-02-GBA-35-35-24	SERIES 90	S90-075PV
80003054	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-T1-C2-L-N-G0-NNN-060-AA-F0-00-C7	SERIES 51	S51-160MV
80003055	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-TA-C2-L-N-G0-NNN-050-AA-NN-00-A9	SERIES 51	S51-160MV
80003056	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-TA-CA-N-N-X1-NNN-050-AA-F3-00-23	SERIES 51	S51-110MV-1
80003057	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-TH-C2-L-N-G0-NNN-070-AA-NN-00-C4	SERIES 51	S51-160MV
80003058	PUMP-VAR-DISPL CCW 90PV130	90L130-HF-5-CD-80-R-4-F1-H-03-GBA-42-42-20	SERIES 90	S90-130PV
80003059	PUMP-VAR-DISPL CCW 90PV130	90L130-HF-5-BC-80-R-4-F1-H-03-GBA-42-42-20	SERIES 90	S90-130PV
80003060	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-N-N1-NN-N-N-U1-ABA-032-AA-E6-00-00	SERIES 51	S51-060MV-1
80003061	PUMP-VAR-DISPL CW 90PV250	90R250-MA-5-CD-80-T-4-C8-J-C7-NNN-26-26-24	SERIES 90	S90-250PV
80003062	MOTOR-VARIABLE CARTRIDGE K	K-C-45DN-E-R2F-F09-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
80003067	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-EF-80-T-3-C8-K-03-NNN-38-38-24	SERIES 90	S90-250PV
80003068	MOTOR-VAR-DISPL 51MV080-1	51V080-1--A-S1-N-N1-NN-N-N-U1-NNN-040-AA-E6-00-00	SERIES 51	S51-080MV-1
80003069	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-AB-80-T-3-F1-K-03-NNN-38-38-24	SERIES 90	S90-250PV
80003070	MOTOR-FIX DISPL MMF035D	MMF-035-D-A-S-A-A-S-NNR-***	M35/44	035MF
80003072	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-N2-NN-N-N-A0-NNN-095-AA-F3-00-00	SERIES 51	S51-160MV
80003073	MOTOR- VARIABLE CARTRIDGE L	L-C-35EN-A-R2F-F09-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
80003075	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-CD-80-S-3-C6-C-03-GBA-42-42-24	SERIES 90	S90-055PV
80003076	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-BK-80-S-3-C6-C-03-GBA-42-42-24	SERIES 90	S90-055PV
80003077	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-NN-80-S-3-S1-C-03-GBA-32-23-24	SERIES 90	S90-055PV
80003079	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-BB-80-S-3-S1-E-00-GBA-23-23-24	SERIES 90	S90-100PV
80003080	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-BC-80-S-3-S1-E-00-GBA-23-23-24	SERIES 90	S90-100PV
80003082	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-B-F2-A5-A-N-G0-NNN-069-AA-NN-03-00	SERIES 51	S51-160MV
80003085	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HS-1-NN-80-P-4-S1-D-02-GBA-42-42-24	SERIES 90	S90-075PV
80003086	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HS-1-CD-80-P-4-S1-F-02-GBA-42-42-24	SERIES 90	S90-100PV

80003088	PUMP-VAR-DISPL CW 90PV100	90R100-DD-5-NN-60-P-4-C7-E-GB-GBA-35-35-24	SERIES 90	S90-100PV
80003093	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-NN-60-P-3-C7-D-03-GBA-42-42-24	SERIES 90	S90-075PV
80003093C	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-NN-60-P-3-C7-D-03-GBA-42-42-24	SERIES 90	S90-075PV
80003095	PUMP-VAR DISPL, CW 90PV100	90-R-100-M8-1-BC-60-P-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
80003095C	PUMP-VAR DISPL, CW 90PV100	90-R-100-M8-1-BC-60-P-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
80003096	PUMP-VAR DISPL, CW 90PV075	90-R-075-M8-1-BC-60-P-3-C7-D-03-GBA-42-42-20	SERIES 90	S90-075PV
80003096C	PUMP-VAR DISPL, CW 90PV075	90-R-075-M8-1-BC-60-P-3-C7-D-03-GBA-42-42-20	SERIES 90	S90-075PV
80003097	PUMP-VAR DISPL, CW 90PV100	90-R-100-M8-1-CD-60-P-3-C7-E-03-GBA-42-42-20	SERIES 90	S90-100PV
80003097C	PUMP-VAR DISPL, CW 90PV100	90-R-100-M8-1-CD-60-P-3-C7-E-03-GBA-42-42-20	SERIES 90	S90-100PV
80003098	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-K-S-B-S-AA-A-A-BJJ-BB-A-GG-B-NNN-***	M46	M46-046PV
80003101	PUMP-VAR DISPL, CCW 90PV100	90-L-100-DC-1-AB-80-P-4-F1-F-GB-GBA-38-38-24	SERIES 90	S90-100PV
80003102	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-N2-NN-N-N-A0-NNN-M78-AA-G3-00-00	SERIES 51	S51-250MV
80003103	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-CD-80-S-3-C8-H-03-GBA-35-35-28	SERIES 90	S90-130PV
80003104	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-NN-80-S-C-C8-J-00-GCA-32-32-28	SERIES 90	S90-180PV
80003105	PUMP-VAR-DISPL CW 90PV100	90R100-KP-5-CD-60-L-3-TJ-E-03-GBA-38-14-24	SERIES 90	S90-100PV
80003106	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-AB-60-S-3-C6-C-04-GBA-35-35-24	SERIES 90	S90-055PV
80003109	PUMP-VAR-DISPL CCW 90PV180	90L180-MA-5-NN-80-T-C-F1-H-C5-FAC-29-29-24	SERIES 90	S90-180PV
80003111	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-TH-C2-L-N-G0-NNN-050-AA-G3-00-A9	SERIES 51	S51-250MV
80003114	MOTOR-VARIABLE DISPL SAE_K	K-V-45DS-A-RNF-F07-S-N-N-CF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
80003115	MOTOR-VARIABLE DISPL SAE_K	K-V-45DN-E-RNF-F07-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
80003117	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-D-N2-NN-N-N-A0-NNN-050-AA-G0-00-00	SERIES 51	S51-250MV
80003118	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-C7-N-TA-CA-N-N-X1-NNN-050-AA-F3-00-18	SERIES 51	S51-080MV-1
80003121	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-NN-60-S-3-C7-D-03-GBA-42-42-24	SERIES 90	S90-075PV
80003122	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-S1-N-E2-B1-N-N-U1-ADA-045-AA-F0-00-00	SERIES 51	S51-080MV-1
80003123	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-CD-80-S-3-C8-F-02-GLA-42-42-28	SERIES 90	S90-130PV
80003124	PUMP-VAR-DISPL CW 90PV100	90R100-MA-5-NN-60-P-3-C7-E-C5-GBA-32-32-26	SERIES 90	S90-100PV
80003125	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-CD-80-T-4-C8-J-05-NNN-26-26-24	SERIES 90	S90-250PV
80003126	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-BC-80-S-4-C3-C-03-GBA-42-42-24	SERIES 90	S90-042PV
80003132	PUMP-VAR-DISPL CCW 90PV130	90L130-CB-5-BC-80-S-3-F1-F-00-GBA-42-42-24	SERIES 90	S90-130PV
80003133	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HF-1-NN-80-S-3-S1-E-03-GBA-32-32-24	SERIES 90	S90-075PV
80003133C	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HF-1-NN-80-S-3-S1-E-03-GBA-32-32-24	SERIES 90	S90-075PV
80003134	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-5-CD-80-R-3-S1-E-03-EEB-42-42-24	SERIES 90	S90-075PV
80003137	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-BC-80-R-4-F1-H-03-GBA-21-32-24	SERIES 90	S90-130PV
80003138	MOTOR-FIX DISPL MMF035D	MMF-035-D-A-F-1-C-G-NNN-***	M35/44	O35MF
80003142	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A2-C3-N-D1-F-G7-H7-33-33-33-33-N-P-28-PN-C01-NNN	H1-MP PUMPS	H1-045PT/053PT
80003152	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-CD-80-P-3-C7-D-03-GBA-45-45-28	SERIES 90	S90-100PV

80003156	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-CD-80-P-4-S1-E-03-GBA-20-20-24	SERIES 90	S90-075PV
80003157	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-NN-80-P-4-S1-E-03-GBA-20-20-24	SERIES 90	S90-075PV
80003158	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-1-NN-80-S-3-S1-D-C5-GBA-23-23-24	SERIES 90	S90-055PV
80003159	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-A-T-B-B-BA-A-A-BDD-CE-A-HH-C-NNN-***	M46	M46-046PV
80003163	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-B-N1-NN-N-N-U1-NNN-020-AA-NN-00-00	SERIES 51	S51-060MV-1
80003164	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-5-CD-80-R-3-S1-C-03-GBA-20-20-20	SERIES 90	S90-055PV
80003165	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-5-NN-80-R-3-S1-C-03-GBA-20-20-20	SERIES 90	S90-055PV
80003167	PUMP-VAR-DISPL CW 90PV075	90R075-HF-5-BC-60-S-3-C6-D-03-GBA-35-35-24	SERIES 90	S90-075PV
80003168	PUMP-VAR-DISPL CCW 90PV180	90L180-FH-5-AB-80-S-7-C8-J-B1-NNN-35-35-30	SERIES 90	S90-180PV
80003169	PUMP-VAR-DISPL CCW 90PV180	90L180-CA-5-AB-80-S-7-C8-J-00-NNN-35-35-30	SERIES 90	S90-180PV
80003170	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-T2-C0-L-N-G0-ADA-115-AA-G3-00-B5	SERIES 51	S51-250MV
80003171	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-NN-80-L-3-F1-H-03-GBA-42-42-24	SERIES 90	S90-130PV
80003173	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-1-NN-80-S-4-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
80003174	PUMP-VAR DISPL, CW 90PV055	90-R-055-HF-1-BG-80-L-3-S1-C-03-GBA-29-29-24	SERIES 90	S90-055PV
80003176	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-EG-80-S-3-C8-J-03-NNN-29-29-24	SERIES 90	S90-250PV
80003177	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-CD-80-S-3-C8-J-03-NNN-29-29-24	SERIES 90	S90-250PV
80003178	PUMP-VAR DISPL, CW 90PV055	90-R-055-FD-5-BB-60-S-3-C6-C-B2-EFI-38-38-24	SERIES 90	S90-055PV
80003179	PUMP-VAR DISPL, CCW 90PV055	90-L-055-MA-1-AB-60-R-4-S1-C-03-GBA-20-20-24	SERIES 90	S90-055PV
80003179C	PUMP-VAR DISPL, CCW 90PV055	90-L-055-MA-1-AB-60-R-4-S1-C-03-GBA-20-20-24	SERIES 90	S90-055PV
80003180	PUMP-VAR DISPL, CCW 90PV055	90-L-055-MA-1-BC-60-R-4-S1-C-03-GBA-20-20-24	SERIES 90	S90-055PV
80003180C	PUMP-VAR DISPL, CCW 90PV055	90-L-055-MA-1-BC-60-R-4-S1-C-03-GBA-20-20-24	SERIES 90	S90-055PV
80003182	MOTOR-VAR-DISPL 51MD080-1	51D080-1--R-D3-N-E2-B1-N-N-U1-NNN-045-AA-F0-00-00	SERIES 51	S51-080MV-1
80003183	MOTOR-VAR-DISPL 51MD080-1	51D080-1--R-D3-N-E2-B1-N-N-U1-NNN-024-AA-NN-00-00	SERIES 51	S51-080MV-1
80003184	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-2-NN-80-R-3-C8-F-04-GBA-42-42-24	SERIES 90	S90-130PV
80003185	MOTOR-VAR-DISPL 51MC110-1	51C110-1--R-D3-N-E2-B1-N-N-U1-ADA-040-AA-E6-00-00	SERIES 51	S51-110MV-1
80003186	PUMP-VAR-DISPL CW 90PV180	90R180-KP-5-CD-80-T-M-F1-H-03-FAC-36-36-24	SERIES 90	S90-180PV
80003187	PUMP-VAR DISPL CCW H1P053L	H1-P-053-L-A-A2-C2-N-D8-F-G1-H5-L-20-L-20-B-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
80003188	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-AB-80-L-3-TG-F-02-GBA-32-32-20	SERIES 90	S90-100PV
80003189	MOTOR-VAR-DISPL 51MC080	51C080-R-D2-N-L1-B1-W-B-M3-AWA-035-AA-F0-D4-00	SERIES 51	S51-080MV
80003190	PUMP-VAR DISPL, CW 90PV100	90-R-100-MB-1-CD-60-P-3-F1-E-03-GBA-40-40-24	SERIES 90	S90-100PV
80003190C	PUMP-VAR DISPL, CW 90PV100	90-R-100-MB-1-CD-60-P-3-F1-E-03-GBA-40-40-24	SERIES 90	S90-100PV
80003191	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-NN-60-P-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
80003191C	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-NN-60-P-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
80003193	PUMP-VAR-DISPL CW 90PV100	90R100-MA-5-AB-80-P-3-S1-E-C7-GBA-35-35-24	SERIES 90	S90-100PV
80003194	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-N-L2-B1-V-A-C0-ABA-044-AA-G0-B2-00	SERIES 51	S51-160MV
80003195	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-NN-80-P-4-C3-B-00-GCA-14-14-20-F008	SERIES 90	S90-042PV

80003196	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-NN-60-S-4-C7-E-05-FAC-38-38-28-F023	SERIES 90	S90-100PV
80003197	MOTOR-VAR-DISPL 51MD110-1	51D110-1--R-D4-N-E2-B1-N-N-U1-NNN-040-AA-E6-00-00	SERIES 51	S51-110MV-1
80003198	MOTOR-VAR-DISPL 51MD110-1	51D110-1--R-D3-N-E2-B1-N-N-U1-NNN-055-AA-F0-00-00	SERIES 51	S51-110MV-1
80003200	PUMP-VAR DISPL CCW H1P053L	H1-P-053-L-A-A2-C2-N-D8-F-G5-NN-L-20-L-20-B-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
80003201	PUMP-VAR DISPL CCW H1P053L	H1-P-053-L-A-A2-C2-N-D8-F-G5-H5-L-20-L-20-B-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
80003202	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-1-BB-60-L-3-S1-E-03-GBA-45-45-24	SERIES 90	S90-075PV
80003204	MOTOR-VAR DISPL MMV046C	MMV-046-C-A-A-A-A-AV-VNB-***	M46	M46-046MV
80003205	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MA-1-NN-80-S-3-F1-E-03-GBA-32-32-20	SERIES 90	S90-100PV
80003206	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-1-NN-80-S-4-S1-C-03-GBA-38-38-24	SERIES 90	S90-055PV
80003206C	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-1-NN-80-S-4-S1-C-03-GBA-38-38-24	SERIES 90	S90-055PV
80003213	PUMP, VARIABLE DIRECT DISPLACMENT	LPV-B-A-A-A-A-G-AC-C-A-BFF-DR-A-FF-B-NNN-***	LPV	LPV
80003214	PUMP, VARIABLE DIRECT DISPLACMENT	LPV-B-A-A-A-A-E-AA-C-A-BJJ-DR-A-FF-B-NNN-***	LPV	LPV
80003215	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-NN-60-S-3-F1-E-03-GBA-20-20-24	SERIES 90	S90-100PV
80003216	PUMP-VAR DISPL, CW 90PV055	90-R-055-HF-1-BG-80-L-3-S1-C-03-GBA-38-38-24	SERIES 90	S90-055PV
80003217	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-NN-80-R-3-S1-E-03-EBC-35-35-24	SERIES 90	S90-100PV
80003222	PUMP-VAR-DISPL CW 90PV250	90R250-KN-5-AB-80-T-3-C8-K-03-NNN-35-35-24	SERIES 90	S90-250PV
80003223	MOTOR-VAR-DISPL 51MV160	51V160-U-F1-D-HZ-B1-C-N-C2-NNN-032-AA-NN-20-00	SERIES 51	S51-160MV
80003225	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-5-NN-60-S-4-C6-C-05-GBA-32-32-24	SERIES 90	S90-055PV
80003229	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-BC-80-L-4-S1-E-00-EBC-35-35-24	SERIES 90	S90-100PV
80003232	PUMP-VAR-DISPL CCW H1PV147	H1-P-147-L-C-A2-C2-N-D8-G-G2-NN-L-42-L-42-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
80003233	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-2-CD-80-P-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-075PV
80003235	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-AB-80-R-4-K3-F-03-GBA-42-42-24	SERIES 90	S90-100PV
80003236	PUMP-VAR-DISPL CW 90PV075	90R075-DC-5-NN-80-S-3-C7-E-GB-GBA-42-42-24	SERIES 90	S90-075PV
80003237	MOTOR-FIX DISPL MMF035D	MMF-035-D-A-A-G-C-D-NNN-***	M35/44	035MF
80003239	PUMP-VAR-DISPL CW 90PV100	90R100-DD-5-BC-80-L-4-C7-E-G4-GBA-30-30-24	SERIES 90	S90-100PV
80003241	MOTOR-VAR-DISPL 51MD110-1	51D110-1--A-D3-N-P8-P8-N-N-X1-NNN-049-AA-F3-00-AA	SERIES 51	S51-110MV-1
80003242	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-2-AB-80-P-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-075PV
80003243	PUMP-VAR-DISPL CCW 90PV130	90L130-DC-5-AB-80-P-4-F1-H-GB-GBA-38-38-24	SERIES 90	S90-130PV
80003244	MOTOR-FIXED DISPL MMF025C	MMF-025-C-A-E-G-A-B-NNA-***	LIGHT DUTY	025MF
80003245	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-BB-60-S-3-S1-D-00-GBA-35-35-24	SERIES 90	S90-075PV
80003246	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-BC-60-S-3-S1-D-00-GBA-35-35-24	SERIES 90	S90-075PV
80003248	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-E2-A5-A-N-A6-NNN-100-AA-NN-03-00	SERIES 51	S51-160MV
80003249	MOTOR-VARIABLE CARTRIDGE K	K-C-38CN-E-R1F-F09-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
80003250	PUMP-VAR DISPL, CW 90PV055	90-R-055-HS-1-CD-60-P-4-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
80003251	PUMP-VAR DISPL, CCW 90PV055	90-L-055-MA-1-NN-80-S-4-S1-C-03-GBA-26-26-24	SERIES 90	S90-055PV
80003253	PUMP-TANDEM, VAR DISPL MPT044D	MPT-044-D-A-R-R-F-AA-B-A-A-A-BJJ-DL-A-FF-B-A-A-A-BJJ-DR-A-FF-C-NNN-***	M35/44	044PT

80003255	PUMP-VAR-DISPL CW 90PV180	90R180-HF-5-BC-80-S-M-C8-H-03-NNN-26-26-24	SERIES 90	S90-180PV
80003256	PUMP-VAR DISPL, CW 90PV100	90-R-100-MB-1-BC-60-S-3-S1-E-02-GBA-35-35-24	SERIES 90	S90-100PV
80003256C	PUMP-VAR DISPL, CW 90PV100	90-R-100-MB-1-BC-60-S-3-S1-E-02-GBA-35-35-24	SERIES 90	S90-100PV
80003257	PUMP-VAR DISPL, CW 90PV100	90-R-100-DD-1-CD-60-S-4-C7-E-GB-GBA-35-35-24	SERIES 90	S90-100PV
80003257C	PUMP-VAR DISPL, CW 90PV100	90-R-100-DD-1-CD-60-S-4-C7-E-GB-GBA-35-35-24	SERIES 90	S90-100PV
80003258	PUMP-VAR DISPL, CW 90PV055	90-R-055-HS-1-NN-60-P-3-S1-C-03-GBA-32-32-24	SERIES 90	S90-055PV
80003258C	PUMP-VAR DISPL, CW 90PV055	90-R-055-HS-1-NN-60-P-3-S1-C-03-GBA-32-32-24	SERIES 90	S90-055PV
80003259	PUMP-VAR DISPL, CW 90PV055	90-R-055-HS-1-AD-80-S-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
80003259C	PUMP-VAR DISPL, CW 90PV055	90-R-055-HS-1-AD-80-S-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
80003260	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-1-AB-60-P-4-S1-D-G4-GBA-40-40-24	SERIES 90	S90-055PV
80003260C	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-1-AB-60-P-4-S1-D-G4-GBA-40-40-24	SERIES 90	S90-055PV
80003261	PUMP-VAR DISPL, CW 90PV055	90-R-055-DC-5-NN-60-S-3-S1-B-GF-GBA-26-26-24	SERIES 90	S90-055PV
80003263	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-NN-80-P-3-C6-C-03-GBA-29-29-24	SERIES 90	S90-055PV
80003266	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-BC-60-S-3-F1-F-03-GBA-38-38-24	SERIES 90	S90-100PV
80003267	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-NN-80-S-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-075PV
80003270	MOTOR-VARIABLE CARTRIDGE K	K-C-45DS-A-RNF-F11-S-N-N-CF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
80003272	MOTOR-VAR-DISPL 51MD160	51D160-A-D5-N-EF-B1-T-M-C0-AWM-070-AA-F3-B2-00	SERIES 51	S51-160MV
80003273	MOTOR-VAR-DISPL 51MV060	51V060-R-S1-N-L2-B1-V-A-C0-ACA-030-AA-F3-B2-00	SERIES 51	S51-060MV
80003274	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-DE-80-R-3-C8-H-03-GBA-38-38-30	SERIES 90	S90-130PV
80003275	PUMP-VAR-DISPL CW 90PV075	90R075-NA-5-NN-80-L-3-C7-D-03-GLA-42-42-26	SERIES 90	S90-075PV
80003276	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-E2-A2-A-N-E1-NNN-150-AA-H0-03-13	SERIES 51	S51-250MV
80003277	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-E2-A2-A-N-E1-NNN-090-AA-G0-03-13	SERIES 51	S51-160MV
80003278	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-DE-80-T-4-C8-K-03-NNN-29-29-28	SERIES 90	S90-250PV
80003279	PUMP-VAR-DISPL CW 90PV100	90R100-NA-5-AB-80-L-3-C7-E-76-GLA-42-42-26	SERIES 90	S90-100PV
80003280	PUMP-VAR-DISPL CW 90PV100	90R100-NA-5-NN-80-L-3-C7-E-76-GLA-42-42-26	SERIES 90	S90-100PV
80003287	MOTOR-VAR-DISPL 51MD060-1	51D060-1--A-D1-N-TA-C2-N-N-X1-NNN-040-AA-E6-00-21	SERIES 51	S51-060MV-1
80003288	MOTOR-VAR-DISPL 51MC110	51C110-R-D3-B-HZ-B1-A-E-G5-NNN-051-AA-NN-03-00	SERIES 51	S51-110MV
80003289	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-A-HS-A2-B-H-C1-NNN-075-AA-NN-10-13	SERIES 51	S51-160MV
80003291	MOTOR-VAR-DISPL 51MD110-1	51D110-1--R-D3-N-T1-CA-N-N-X1-NNN-050-AA-F3-00-25	SERIES 51	S51-110MV-1
80003295	MOTOR-VAR DISPL MMV046C	MMV-046-C-A-A-A-B-A4-NNN-***	M46	M46-046MV
80003296	MOTOR-VAR DISPL MMV046C	MMV-046-C-A-A-A-B-AU-NNN-***	M46	M46-046MV
80003297	PUMP-VAR DISPL MPV046C	MPV-046-C-B-A-D-S-B-B-BA-A-A-BJJ-AB-D-AA-B-NNN-***	M46	M46-046PV
80003298	PUMP-VAR DISPL MPV046C	MPV-046-C-B-A-B-S-B-B-BA-A-A-BJJ-AB-D-AA-A-NNN-***	M46	M46-046PV
80003300	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-D-S-B-B-BA-A-A-BJJ-BB-A-HH-B-NNN-***	M46	M46-046PV
80003305	PUMP-VAR-DISPL CW 90PV250	90R250-MA-5-NN-80-S-4-F1-J-C6-NNN-35-35-24	SERIES 90	S90-250PV
80003307	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-1-AB-61-R-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-055PV

80003308	PUMP-TANDEM, VAR DISPL MPT044D	MPT-044-D-A-W-S-J-BA-B-A-A-A-BDD-DR-A-FF-B-C-A-A-BDD-DL-A-FF-C-NNN-*	M35/44	044PT
80003309	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-A-S-B-B-AA-A-A-BDD-BA-A-HH-C-NNN-***	M46	M46-046PV
80003310	PUMP, VARIABLE DIRECT DISPLACMENT	LPV-B-A-A-A-A-E-AA-C-A-BEE-DR-A-FF-B-NNN-***	LPV	LPV
80003311	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-CD-80-L-4-S1-E-00-GBA-20-20-20	SERIES 90	S90-100PV
80003314	MOTOR-VAR-DISPL 51MV060-1	51V060-1--R-C6-N-E2-B1-N-N-U1-NNN-012-AA-F3-00-00	SERIES 51	S51-060MV-1
80003316	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-5-AB-80-R-4-S1-F-03-GBA-38-38-24	SERIES 90	S90-100PV
80003317	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-5-BC-80-R-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
80003318	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-S1-N-E2-B1-N-N-U1-NNN-026-AA-F0-00-00	SERIES 51	S51-060MV-1
80003319	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D2-N-E2-B1-N-N-U1-ADA-034-AA-E6-00-00	SERIES 51	S51-080MV-1
80003320	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-EQ-A5-J-Y-A6-NNN-041-AA-E6-30-00	SERIES 51	S51-160MV
80003321	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-CD-80-R-4-F1-F-03-GBA-42-42-24	SERIES 90	S90-130PV
80003324	PUMP-VAR-DISPL CW 90PV075	90R075-FM-D-BC-6U-S-D-C6-D-B6-GMC-48-48-30	SERIES 90	S90-075PV
80003325	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-AB-60-L-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-055PV
80003326	PUMP-VAR DISPL, CW 90PV100	90-R-100-DC-1-CD-60-L-3-F1-F-GB-GBA-42-42-24	SERIES 90	S90-100PV
80003329	PUMP-VAR-DISPL CW 90PV180	90R180-HF-5-CD-80-T-C-F1-J-03-FAC-35-35-24	SERIES 90	S90-180PV
80003332	PUMP-VAR-DISPL CW 90PV100	90R100-KP-5-AB-80-R-4-S1-F-03-GBA-38-38-24	SERIES 90	S90-100PV
80003333	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-HZ-B1-A-E-C2-NNN-070-AA-NN-03-00	SERIES 51	S51-250MV
80003335	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-1-CD-80-R-4-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
80003335C	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-1-CD-80-R-4-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
80003336	PUMP-VAR DISPL, CW 90PV075	90-R-075-M8-1-BC-60-R-3-C7-D-03-GBA-40-40-24	SERIES 90	S90-075PV
80003336C	PUMP-VAR DISPL, CW 90PV075	90-R-075-M8-1-BC-60-R-3-C7-D-03-GBA-40-40-24	SERIES 90	S90-075PV
80003337	PUMP-VAR DISPL, CW 90PV075	90-R-075-M8-1-NN-60-P-3-C6-D-03-GBA-40-40-24	SERIES 90	S90-075PV
80003337C	PUMP-VAR DISPL, CW 90PV075	90-R-075-M8-1-NN-60-P-3-C6-D-03-GBA-40-40-24	SERIES 90	S90-075PV
80003338	PUMP-VAR DISPL, CW 90PV100	90-R-100-M8-1-CD-60-R-3-C7-E-03-GBA-40-40-24	SERIES 90	S90-100PV
80003338C	PUMP-VAR DISPL, CW 90PV100	90-R-100-M8-1-CD-60-R-3-C7-E-03-GBA-40-40-24	SERIES 90	S90-100PV
80003339	PUMP-VAR DISPL, CW 90PV100	90-R-100-M8-1-BC-60-R-3-C7-E-03-GBA-40-40-24	SERIES 90	S90-100PV
80003339C	PUMP-VAR DISPL, CW 90PV100	90-R-100-M8-1-BC-60-R-3-C7-E-03-GBA-40-40-24	SERIES 90	S90-100PV
80003343	PUMP-VAR-DISPL CCW H1PV165	H1-P-165-L-C-A2-C2-N-D4-G-G3-H3-L-42-L-42-L-C-32-PN-NNN-G25	H1-HP PUMPS	H1-147PV/165PV
80003344	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-BC-60-S-3-S1-D-D3-EAB-42-42-24	SERIES 90	S90-055PV
80003345	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-CD-60-S-3-S1-D-D3-EAB-42-42-24	SERIES 90	S90-055PV
80003349	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-NN-80-S-4-S1-E-03-FAD-42-42-24	SERIES 90	S90-100PV
80003351	PUMP-VAR-DISPL CW 90PV100	90R100-MA-5-NN-80-R-4-S1-F-C5-GBA-20-20-30	SERIES 90	S90-100PV
80003352	PUMP-VAR DISPL, CW 90PV055	90-R-055-HS-1-CD-80-R-4-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
80003353	PUMP-TANDEM, VAR DISPL MPT044D	MPT-044-D-A-R-R-E-BA-B-A-A-A-BJJ-DL-A-FF-B-C-A-A-BJJ-DR-A-FF-B-NNN-***	M35/44	044PT
80003356	PUMP-VAR-DISPL CW 90PV250	90R250-KP-5-NN-80-T-3-F1-K-03-NNN-35-35-24	SERIES 90	S90-250PV
80003357	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-CD-80-T-3-F1-J-03-NNN-35-35-24	SERIES 90	S90-250PV

80003359	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-CD-60-L-3-F1-E-03-FAD-42-42-24	SERIES 90	S90-100PV
80003360	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-A-V-C-J-BA-B-B-A-A-BJJ-CE-A-GG-B-D-A-A-BJJ-CE-A-GG-B-NNN-***	M46	M46-046PT
80003362	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-BB-80-S-3-C6-D-03-GBA-42-42-24	SERIES 90	S90-075PV
80003363	PUMP-VAR-DISPL CW 90PV075	90R075-FM-5-BC-60-S-7-S1-E-B6-EFP-42-42-30	SERIES 90	S90-075PV
80003364	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-BC-80-L-3-TG-F-02-GBA-32-32-30	SERIES 90	S90-100PV
80003365	MOTOR-VAR-DISPL 51MD110-1	51D110-1--R-D4-N-E2-B1-N-N-U1-ADA-022-AA-E6-00-00	SERIES 51	S51-110MV-1
80003366	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-BC-80-L-3-TG-F-02-GBA-32-32-30	SERIES 90	S90-100PV
80003369	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-C8-N-TA-C2-N-N-X1-NNN-060-AA-NN-00-19	SERIES 51	S51-110MV-1
80003370	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-C8-N-TA-C2-N-N-X1-NNN-040-AA-NN-00-19	SERIES 51	S51-110MV-1
80003371	MOTOR-VARIABLE CARTRIDGE K	K-C-38CN-A-RNF-F12-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
80003376	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-NN-80-T-4-F1-K-03-NNN-20-20-24	SERIES 90	S90-250PV
80003378	PUMP-VAR-DISPL CCW 90PV180	90L180-MA-5-NN-80-T-C-F1-J-C5-FAC-35-35-24	SERIES 90	S90-180PV
80003379	MOTOR-VAR DISPL MMV046C	MMV-046-C-A-E-T-A-AU-NNN-***	M46	M46-046MV
80003382	PUMP-VAR-DISPL CW 90PV042	90R042-FC-5-NN-80-P-7-C3-B-B1-GLA-42-42-32	SERIES 90	S90-042PV
80003383	PUMP-VAR DISPL, CW 90PV100	90-R-100-M8-1-CD-60-P-3-C7-E-03-GBA-40-40-24	SERIES 90	S90-100PV
80003385	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-BC-60-P-3-S1-D-03-GBA-32-32-24	SERIES 90	S90-075PV
80003385C	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-BC-60-P-3-S1-D-03-GBA-32-32-24	SERIES 90	S90-075PV
80003386	MOTOR-VAR-DISPL 51MV110	51V110-R-F1-N-HZ-B1-B-H-G5-ACB-024-AA-F0-06-00	SERIES 51	S51-110MV
80003389	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-D-HS-A2-B-H-F1-NNN-090-AA-NN-10-13	SERIES 51	S51-250MV
80003392	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-2-BC-60-R-3-F1-F-00-GBA-42-42-24	SERIES 90	S90-100PV
80003393	MOTOR-VAR-DISPL 51MV160	51V160-V-F1-D-H4-B3-R-J-N2-NNN-032-AA-NN-C2-21	SERIES 51	S51-160MV
80003394	PUMP-VAR-DISPL CW 90PV130	90R130-PB-5-NN-80-R-4-C8-H-04-GBA-23-23-24	SERIES 90	S90-130PV
80003395	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-B-T-B-J-AA-A-A-BRR-BB-A-HH-A-NNN-***	M46	M46-046PV
80003396	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-K-T-B-J-AA-A-A-BRR-BB-A-HH-B-NNN-***	M46	M46-046PV
80003397	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-CE-60-S-4-S1-G-03-GBA-42-42-24	SERIES 90	S90-100PV
80003399	PUMP-VAR-DISPL CCW H1PV165	H1-P-165-L-C-A2-C3-N-D8-G-G3-NN-L-35-L-35-L-P-32-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
80003401	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-CD-80-R-4-C6-C-02-GBA-38-38-24	SERIES 90	S90-055PV
80003402	PUMP-VAR DISPL, CW 90PV055	90-R-055-MB-1-BG-80-R-3-S1-C-02-GBA-38-38-24	SERIES 90	S90-055PV
80003403	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-CD-80-P-3-F1-E-00-GBA-42-42-24	SERIES 90	S90-100PV
80003404	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-AB-80-S-C-C8-H-03-NNN-38-38-30	SERIES 90	S90-180PV
80003405	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-BG-80-R-4-S1-C-02-GBA-38-38-24	SERIES 90	S90-055PV
80003406	PUMP-VAR DISPL, CW 90PV055	90-R-055-MB-1-CD-80-R-3-C6-C-02-GBA-38-38-24	SERIES 90	S90-055PV
80003407	PUMP, VARIABLE DIRECT DISPLACMENT	LPV-B-A-A-A-A-E-AC-C-A-BGG-DR-A-FF-B-NNN-***	LPV	LPV
80003408	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-CD-80-S-7-C7-E-21-EFI-26-26-24	SERIES 90	S90-075PV
80003409	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-BC-80-S-7-C7-E-21-EFI-26-26-24	SERIES 90	S90-075PV
80003411	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-1-NN-80-P-4-S1-C-GB-GBA-35-35-24	SERIES 90	S90-055PV

80003413	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-5-BC-60-R-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
80003417	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-CD-80-P-4-C8-H-03-EHA-35-35-24	SERIES 90	S90-130PV
80003418	PUMP-VAR-DISPL CW 90PV130	90R130-MA-5-CD-80-S-4-F1-F-C5-GBA-42-42-24	SERIES 90	S90-130PV
80003419	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-DE-80-L-3-F1-H-03-GBA-35-35-24	SERIES 90	S90-130PV
80003420	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-N-E2-B1-N-N-U1-ACB-032-AA-E6-00-00	SERIES 51	S51-060MV-1
80003421	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-N-N1-NN-N-N-U1-ACB-040-AA-NN-00-00	SERIES 51	S51-060MV-1
80003422	MOTOR-VARIABLE DISPL SAE_K	K-V-38CN-A-RNF-F12-S-N-N-AF-F17-NNN-NNN	LV / KV MOTORS	L/K-MV
80003424	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-BG-80-R-4-S1-C-03-GBA-32-32-24	SERIES 90	S90-055PV
80003425	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-NN-60-P-3-S1-D-03-GBA-17-17-24	SERIES 90	S90-075PV
80003426	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-AD-80-S-4-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
80003428	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-BC-60-S-3-C7-E-03-GBA-35-35-20	SERIES 90	S90-075PV
80003428C	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-BC-60-S-3-C7-E-03-GBA-35-35-20	SERIES 90	S90-075PV
80003429	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-NN-80-P-4-C8-F-03-GBA-42-42-24	SERIES 90	S90-130PV
80003430	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-N2-NN-N-N-A0-ADA-115-AA-F3-00-00	SERIES 51	S51-160MV
80003431	PUMP-VAR-DISPL CW 90PV075	90R075-FK-5-BC-80-P-7-C7-D-B6-ELA-35-35-30	SERIES 90	S90-075PV
80003432	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-1-BG-80-L-4-S1-C-00-GBA-14-14-24	SERIES 90	S90-055PV
80003433	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-2-AD-80-S-3-C6-D-04-GBA-38-38-20	SERIES 90	S90-055PV
80003434	PUMP-VAR DISPL, CW 90PV055	90-R-055-M8-1-NN-60-P-3-C6-D-03-GBA-40-40-24	SERIES 90	S90-055PV
80003434C	PUMP-VAR DISPL, CW 90PV055	90-R-055-M8-1-NN-60-P-3-C6-D-03-GBA-40-40-24	SERIES 90	S90-055PV
80003435	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-N-E1-B1-N-N-U1-NNN-015-AA-E4-00-00	SERIES 51	S51-060MV-1
80003439	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-NN-80-S-4-C7-D-03-GBA-35-35-24	SERIES 90	S90-075PV
80003440	PUMP-VAR-DISPL CCW 90PV250	90L250-HF-5-EF-80-S-4-C8-J-03-NNN-23-23-24	SERIES 90	S90-250PV
80003441	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-2-AB-80-P-1-S1-E-03-GBA-23-42-24	SERIES 90	S90-075PV
80003443	MOTOR-VAR-DISPL 51MD160	51D160-R-D4-N-T4-C0-L-N-L4-AWM-039-AA-G0-00-B2	SERIES 51	S51-160MV
80003445	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-BC-80-R-4-S1-E-03-GBA-26-26-20	SERIES 90	S90-100PV
80003446	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-A-A2-C2-N-E7-F-G6-H2-35-18-35-35-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
80003447	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A2-C2-N-D9-G-G2-H4-L-42-L-42-L-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
80003448	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A2-C2-N-D6-G-G3-H3-L-42-L-42-L-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
80003449	PUMP-VAR-DISPL CW 90PV100	90R100-MA-5-NN-60-P-3-C7-E-C5-GBA-42-42-24	SERIES 90	S90-100PV
80003450	PUMP-VAR-DISPL CW 90PV075	90R075-HF-5-CD-80-R-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
80003451	PUMP-VAR-DISPL CW 90PV042	90R042-HF-5-AB-80-R-3-C5-B-03-GBA-35-35-24	SERIES 90	S90-042PV
80003452	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-CD-80-S-3-S1-D-03-GBA-32-32-24	SERIES 90	S90-075PV
80003453	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-N-N1-NN-N-N-U1-NNN-025-AA-F0-00-00	SERIES 51	S51-060MV-1
80003454	PUMP-VAR-DISPL CW 90PV100	90R100-FG-5-BC-60-P-7-F1-F-B1-GBA-42-42-24	SERIES 90	S90-100PV
80003455	MOTOR-VAR-DISPL 51MD160	51D160-A-D4-N-D7-M1-S-K-M4-NNN-075-AA-G0-F4-20	SERIES 51	S51-160MV
80003457	MOTOR-VAR-DISPL 51MV080	51V080-A-C7-N-L2-B1-V-A-C0-ADA-050-AA-F0-B2-00	SERIES 51	S51-080MV

80003460	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-BB-80-S-4-S1-D-02-GBA-29-29-24	SERIES 90	S90-075PV
80003461	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-E2-A5-A-N-A6-NNN-094-AA-F0-03-00	SERIES 51	S51-160MV
80003462	PUMP-VAR-DISPL CW 90PV130	90R130-MA-5-AB-80-P-3-F1-H-C5-GBA-29-29-24	SERIES 90	S90-130PV
80003464	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-CD-80-P-4-F1-F-03-GBA-35-35-24	SERIES 90	S90-130PV
80003465	PUMP-VAR-DISPL CW 90PV100	90R100-KP-5-NN-80-P-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
80003466	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-CD-80-P-4-F1-F-03-GBA-38-38-24	SERIES 90	S90-130PV
80003467	PUMP-VAR-DISPL CCW 90PV075	90L075-KP-5-BC-80-P-4-S1-D-03-GBA-17-17-18	SERIES 90	S90-075PV
80003468	PUMP-VAR-DISPL CW 90PV075	90R075-HF-5-AB-80-P-4-C6-E-03-GBA-35-35-24	SERIES 90	S90-075PV
80003470	MOTOR-VAR-DISPL 51MD110-1	51D110-1--R-D4-N-E1-B1-N-N-U2-NNN-063-AA-F3-00-00	SERIES 51	S51-110MV-1
80003471	PUMP-VAR DISPL, CW 90PV100	90-R-100-HM-1-NN-60-P-3-F1-E-04-GBA-32-32-24	SERIES 90	S90-100PV
80003475	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-NN-61-P-4-S1-E-03-GBA-29-29-24	SERIES 90	S90-100PV
80003478	PUMP-VAR-DISPL CW 90PV042	90R042-FC-P-BB-80-R-7-T8-B-B1-EEG-48-48-30	SERIES 90	S90-042PV
80003479	PUMP-VAR DISPL, CW 90PV100	90-R-100-DC-1-BC-60-P-4-S1-E-GB-GBA-26-26-24	SERIES 90	S90-100PV
80003482	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HM-1-NN-60-P-3-F1-E-04-GBA-32-32-24	SERIES 90	S90-100PV
80003484	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HF-1-NN-60-P-3-S1-E-00-GBA-26-32-24	SERIES 90	S90-075PV
80003485	PUMP-VAR DISPL, CW 90PV100	90-R-100-HF-1-BC-60-P-3-S1-F-00-GBA-17-42-24	SERIES 90	S90-100PV
80003489	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-V-S-B-B-AA-A-A-BDD-CD-A-GG-C-NNN-***	M46	M46-046PV
80003492	MOTOR-VAR-DISPL 51MV080	51V080-A-S1-N-EQ-A5-K-Z-G5-NNN-054-AA-NN-50-00	SERIES 51	S51-080MV
80003494	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-E-B4-B3-N-N-U5-NNN-022-AA-NN-00-00	SERIES 51	S51-060MV-1
80003495	MOTOR-VAR-DISPL 51MC060	51C060-R-D1-N-L2-B1-V-A-C0-ABA-012-AA-E4-B2-00	SERIES 51	S51-060MV
80003497	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-1-NN-60-P-4-S1-C-GB-GBA-35-35-20	SERIES 90	S90-055PV
80003505	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-TA-C2-N-N-X1-NNN-036-AA-NN-00-25	SERIES 51	S51-110MV-1
80003507	PUMP-VAR-DISPL CCW 90PV250	90L250-HF-5-CD-80-S-3-F1-J-03-NNN-23-23-24	SERIES 90	S90-250PV
80003510	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-E-V-C-S-AA-B-A-R-A-BHH-GG-B-KF-B-C-R-A-BHH-GG-B-KF-B-NBB-*	M46	M46-046PT
80003511	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-E-V-C-S-AA-B-A-R-A-BHH-GG-B-KF-B-C-R-A-BHH-GG-B-KF-Y-GDC-*	M46	M46-046PT
80003515	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HK-1-NN-60-R-3-S1-C-03-GBA-26-26-24	SERIES 90	S90-055PV
80003516	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HK-1-NN-60-R-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
80003518	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D3-N-F2-B1-N-N-U1-NNN-040-AA-NN-00-00	SERIES 51	S51-080MV-1
80003520	PUMP-TANDEM, VAR DISPL MPT044D	MPT-044-D-A-R-R-G-AA-B-A-A-A-BJJ-DR-A-FF-B-C-A-A-BJJ-DR-A-FF-C-NNN-***	M35/44	044PT
80003521	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-CD-80-P-3-S1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
80003521C	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-CD-80-P-3-S1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
80003522	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-E-V-C-S-AA-B-A-R-A-BHH-GG-B-KF-B-C-R-A-BHH-GG-B-KF-Y-NAF-**	M46	M46-046PT
80003527	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-NN-80-R-3-F1-F-00-GBA-17-17-18	SERIES 90	S90-130PV
80003532	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-NN-60-R-3-C7-E-03-GBA-38-38-24	SERIES 90	S90-100PV
80003532C	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-NN-60-R-3-C7-E-03-GBA-38-38-24	SERIES 90	S90-100PV
80003533	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-1-NN-60-P-4-S1-D-G8-GBA-40-40-24	SERIES 90	S90-055PV

80003533C	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-1-NN-60-P-4-S1-D-G8-GBA-40-40-24	SERIES 90	S90-055PV
80003534	PUMP, VARIABLE DIRECT DISPLACEMENT	LPV-B-A-B-C-A-E-AA-C-A-BFF-DR-A-FF-A-NNN-***	LPV	LPV
80003536	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-NN-80-R-4-C3-C-03-GBA-23-23-24	SERIES 90	S90-042PV
80003538	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-BC-80-P-3-C3-B-03-GBA-30-30-24	SERIES 90	S90-042PV
80003539	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-BB-80-P-3-C3-B-03-GBA-30-30-24	SERIES 90	S90-042PV
80003540	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A3-C2-N-D5-G-A8-H4-L-42-L-42-L-M-30-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
80003542	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HF-1-NN-81-S-3-F1-E-03-GBA-35-35-20	SERIES 90	S90-100PV
80003543	PUMP-VAR DISPL, CCW 90PV055	90-L-055-FC-1-AB-60-S-7-C6-D-B1-GCA-42-42-24	SERIES 90	S90-055PV
80003545	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-NN-80-S-3-C8-H-00-GCA-32-32-28	SERIES 90	S90-130PV
80003546	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-NN-60-L-4-C7-E-03-GBA-30-30-24	SERIES 90	S90-100PV
80003547	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-B-N1-NN-N-N-U1-NNN-030-AA-F0-00-00	SERIES 51	S51-060MV-1
80003548	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-DA-M4-R-J-N1-ADA-073-AA-G3-C2-29	SERIES 51	S51-160MV
80003549	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HS-5-NN-80-S-3-F1-F-03-GBA-42-17-20	SERIES 90	S90-100PV
80003558	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-AB-80-R-3-F1-F-04-GBA-38-38-24	SERIES 90	S90-130PV
80003559	PUMP-VAR-DISPL CCW 90PV042	90L042-KA-5-BC-80-S-3-C3-C-03-GBA-42-42-28	SERIES 90	S90-042PV
80003560	PUMP-VAR-DISPL CCW 90PV130	90L130-FH-5-CD-80-P-7-F1-H-B1-GBA-35-35-20	SERIES 90	S90-130PV
80003562	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-BC-80-S-4-F1-F-03-GBA-26-26-24	SERIES 90	S90-130PV
80003563	MOTOR-VAR-DISPL 51MV250	51V250-A-C8-C-HZ-B1-C-E-G0-NNN-110-AA-F3-12-00	SERIES 51	S51-250MV
80003564	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A3-C2-N-D3-G-G3-H5-L-42-L-42-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
80003565	PUMP-VAR DISPL, CW 90PV100	90-R-100-KT-5-CD-80-P-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
80003566	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A3-C3-N-E7-F-G1-H3-38-38-38-38-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
80003567	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-T1-C2-L-N-G0-NNN-070-AA-F3-00-C1	SERIES 51	S51-160MV
80003568	PUMP-VAR-DISPL CW 90PV180	90R180-MA-5-NN-80-S-M-F1-J-C5-NNN-35-35-24	SERIES 90	S90-180PV
80003570	PUMP-VAR-DISPL CW 90PV075	90R075-DC-5-BB-80-S-4-C7-E-50-FAD-42-42-24	SERIES 90	S90-075PV
80003571	MOTOR-VAR-DISPL 51MV110	51V110-R-F1-N-HZ-B1-A-N-G0-ABA-022-AA-F0-03-00	SERIES 51	S51-110MV
80003577	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-B-T-B-U-AA-A-A-BFF-DB-A-JJ-A-NNN-***	M46	M46-046PV
80003578	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-E2-A5-A-N-A6-ADA-045-AA-F3-03-00	SERIES 51	S51-160MV
80003579	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-NN-80-S-4-C7-D-03-GBA-42-42-24	SERIES 90	S90-075PV
80003580	MOTOR-VAR-DISPL 51MD160	51D160-A-D5-N-HZ-B1-B-H-C2-NNN-063-AA-E6-09-00	SERIES 51	S51-160MV
80003590	PUMP-VAR-DISPL CW 90PV130	90R130-LP-G-CD-80-S-4-T4-F-04-GBA-42-42-24-F054	SERIES 90	S90-130PV
80003591	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-AB-60-S-3-K3-E-03-GBA-35-35-24	SERIES 90	S90-100PV
80003592	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-BC-60-P-4-S1-D-03-GBA-23-23-24	SERIES 90	S90-100PV
80003596	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-BB-80-S-3-C7-E-03-GBA-29-29-24	SERIES 90	S90-075PV
80003597	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-L-S-B-B-BA-A-A-BJJ-CN-A-GG-A-NNN-***	M46	M46-046PV
80003598	MOTOR-VARIABLE DISPL SAE_K	K-V-38CN-A-RNF-F07-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
80003600	MOTOR-VARIABLE DISPL SAE_K	K-V-45DN-A-YNF-F65-S-N-N-AF-F16-NNN-NNN	LV / KV MOTORS	L/K-MV

80003601	MOTOR-VARIABLE DISPL SAE_K	K-V-45DN-A-YNF-F55-S-N-N-AF-F16-NNN-NNN	LV / KV MOTORS	L/K-MV
80003603	MOTOR-VAR-DISPL 51MV160	51V160-A-C8-N-L2-B1-V-A-J1-ADA-035-AA-F3-B2-00	SERIES 51	S51-160MV
80003605	PUMP-VAR-DISPL CW 90PV100	90R100-MA-5-NN-60-L-3-C7-E-C5-GBA-42-42-24-N345	SERIES 90	S90-100PV
80003607	PUMP-VAR DISPL CCW H1P053L	H1-P-053-L-A-A2-C2-N-D6-F-G1-H5-L-20-L-20-B-L-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
80003608	PUMP-VAR DISPL CCW H1P053L	H1-P-053-L-A-A2-C2-N-D6-F-G5-H5-L-20-L-20-B-L-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
80003609	PUMP-VAR DISPL CCW H1P053L	H1-P-053-L-A-A2-C2-N-D6-F-G5-NN-L-20-L-20-B-L-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
80003611	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-AB-60-L-3-S1-D-00-GBA-38-38-24	SERIES 90	S90-075PV
80003612	MOTOR-VARIABLE DISPL SAE_K	K-V-45DN-A-YNF-F75-S-N-N-AF-F16-NNN-NNN	LV / KV MOTORS	L/K-MV
80003615	PUMP-TANDEM, VAR DISPL MPT044D	MPT-044-D-V-R-A-F-NN-H-A-A-A-BHH-DA-A-FF-H-C-A-A-BHH-DB-A-FF-H-ADG-	M35/44	044PT
80003616	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-TA-C2-N-N-X1-NNN-059-AA-F0-00-17	SERIES 51	S51-110MV-1
80003617	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-CD-80-R-3-F1-H-03-GBA-35-35-24	SERIES 90	S90-130PV
80003621	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A4-C1-N-D8-H-F1-H5-L-40-L-40-N-E-26-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
80003622	PUMP-VAR-DISPL CCW 90PV180	90L180-KP-5-NN-80-T-C-F1-H-03-FAC-35-35-24	SERIES 90	S90-180PV
80003624	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KT-5-CD-80-S-3-S1-C-03-GBA-20-20-20	SERIES 90	S90-055PV
80003625	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KT-5-NN-80-S-3-S1-C-03-GBA-20-20-20	SERIES 90	S90-055PV
80003626	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-S1-N-P7-P7-N-N-X1-NNN-016-AA-F0-00-AA	SERIES 51	S51-080MV-1
80003628	PUMP-VAR-DISPL CCW 90PV100	90L100-MA-5-AB-60-S-3-C7-F-C5-GBA-42-42-24	SERIES 90	S90-100PV
80003629	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-NN-60-P-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
80003630	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-NN-60-P-3-C7-E-03-GCA-42-42-24	SERIES 90	S90-075PV
80003631	MOTOR-VAR-DISPL 51MV060-1	51V060-1--R-S1-N-B2-B3-N-N-U3-ABA-024-AA-NN-00-00	SERIES 51	S51-060MV-1
80003633	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-A-Z-C-B-AA-B-B-A-A-BGG-CG-A-GG-B-D-A-A-BGG-CG-A-GG-A-NNN	M46	M46-046PT
80003637	PUMP-VAR-DISPL CW 90PV075	90R075-MA-5-BC-80-S-3-TJ-E-C5-GBA-42-42-20	SERIES 90	S90-075PV
80003638	PUMP-VAR-DISPL CCW 90PV075	90L075-MA-5-BC-80-S-3-TJ-E-C5-GBA-42-42-20	SERIES 90	S90-075PV
80003639	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-NN-80-P-3-S1-C-03-GBA-14-20-20	SERIES 90	S90-055PV
80003640	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-CD-80-P-3-S1-C-03-GBA-42-42-20	SERIES 90	S90-055PV
80003642	PUMP-VAR-DISPL CCW 90PV100	90L100-DD-5-AB-60-S-3-C7-E-GF-GBA-42-42-24	SERIES 90	S90-100PV
80003643	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-HZ-B1-C-E-C2-NNN-054-AA-E6-24-00	SERIES 51	S51-080MV
80003647	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-1-NN-61-P-3-S1-D-03-GBA-35-35-20	SERIES 90	S90-075PV
80003650	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-1-NN-80-P-3-S1-C-03-GBA-26-26-24	SERIES 90	S90-055PV
80003651	MOTOR-VAR-DISPL 51MD110	51D110-R-D4-N-N2-NN-N-N-A0-AHA-022-AA-F0-00-00	SERIES 51	S51-110MV
80003653	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-5-CD-80-S-3-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
80003654	MOTOR-FIXED DISPL MMF025C	MMF-025-C-A-E-R-C-C-NNN-***	LIGHT DUTY	025MF
80003655	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-5-NN-80-S-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
80003656	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-5-BC-80-S-3-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
80003657	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-AB-60-S-4-S1-E-03-GBA-26-26-24	SERIES 90	S90-100PV
80003658	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-CD-80-S-3-S1-C-03-GBA-32-32-24	SERIES 90	S90-055PV

80003661	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-6-NN-80-P-3-S1-E-00-GBA-48-48-24	SERIES 90	S90-075PV
80003662	PUMP-VAR-DISPL CW 90PV075	90R075-FG-5-CD-80-R-7-C7-E-B1-EFI-45-45-30	SERIES 90	S90-075PV
80003663	MOTOR-VAR-DISPL 51MV060-1	51V060-1--R-S1-N-E2-B1-N-N-U1-NNN-026-AA-NN-00-00	SERIES 51	S51-060MV-1
80003664	PUMP-VAR-DISPL CCW 90PV100	90L100-HF-5-AB-60-P-4-C7-E-04-GBA-35-35-28	SERIES 90	S90-100PV
80003665	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-CD-80-P-3-C8-F-04-GBA-32-32-24	SERIES 90	S90-130PV
80003667	PUMP-VAR-DISPL CCW 90PV100	90L100-MA-V-AB-8E-S-3-C7-D-C6-GB1-42-42-24	SERIES 90	S90-100PV
80003668	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-A-T-B-B-AA-A-A-BDD-BA-A-HH-C-NNN-***	M46	M46-046PV
80003669	MOTOR-FIX DISPL MMF044D	MMF-044-D-A-F-E-C-D-NNN-***	M35/44	044MF
80003670	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-H-S-B-J-AA-G-A-BHH-CD-A-ZG-A-NNN-***	M46	M46-046PV
80003672	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HS-5-NN-80-S-3-F1-F-03-GBA-32-32-20	SERIES 90	S90-100PV
80003673	MOTOR- VARIABLE CARTRIDGE L	L-C-35ES-E-RNF-F04-S-N-N-BF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
80003678	PUMP-VAR-DISPL CCW 90PV180	90L180-KP-5-CD-80-S-C-F1-H-03-FAC-42-42-24	SERIES 90	S90-180PV
80003680	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-1-AB-61-S-3-S1-D-00-GBA-35-35-24	SERIES 90	S90-055PV
80003680C	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-1-AB-61-S-3-S1-D-00-GBA-35-35-24	SERIES 90	S90-055PV
80003681	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-1-CD-61-S-3-T1-D-00-GBA-35-35-24	SERIES 90	S90-055PV
80003681C	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-1-CD-61-S-3-T1-D-00-GBA-35-35-24	SERIES 90	S90-055PV
80003682	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A2-C3-N-E7-F-G5-NN-38-38-38-38-N-P-30-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
80003683	MOTOR-VAR-DISPL 51MV250	51V250-A-C8-N-L2-B1-V-A-G5-ACA-080-AA-G0-B2-00	SERIES 51	S51-250MV
80003686	PUMP-VAR-DISPL CW 90PV100	90R100-DD-5-BC-60-S-4-C7-F-G8-FAC-32-32-20	SERIES 90	S90-100PV
80003687	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MA-1-NN-60-P-4-S1-E-03-GBA-14-35-24	SERIES 90	S90-100PV
80003690	PUMP-VAR-DISPL CW 90PV042	90R042-DD-5-BC-80-D-4-C3-L-Z1-GBA-40-40-28	SERIES 90	S90-042PV
80003691	PUMP-VAR-DISPL CW 90PV075	90R075-FL-5-AB-60-P-7-S1-E-B6-ELA-42-42-28	SERIES 90	S90-075PV
80003693	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-NN-80-S-C-F1-H-03-NNN-35-35-24	SERIES 90	S90-180PV
80003694	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-EF-80-S-3-C8-J-03-NNN-35-35-24	SERIES 90	S90-250PV
80003696	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-AB-80-P-4-C3-C-03-GBA-42-42-24	SERIES 90	S90-042PV
80003697	PUMP-VAR-DISPL CW 90PV042	90R042-MB-5-AB-80-P-4-C3-C-C5-GBA-42-42-24	SERIES 90	S90-042PV
80003698	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-AB-80-P-4-C7-D-03-GBA-42-42-24	SERIES 90	S90-075PV
80003699	PUMP-VAR-DISPL CW 90PV075	90R075-MB-5-AB-80-P-4-C7-D-C5-GBA-42-42-24	SERIES 90	S90-075PV
80003700	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-AB-80-L-4-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
80003701	PUMP-VAR-DISPL CW 90PV100	90R100-MB-5-AB-80-L-4-C7-E-C5-GBA-42-42-24	SERIES 90	S90-100PV
80003702	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-AB-80-L-4-C8-H-03-GBA-42-42-24	SERIES 90	S90-130PV
80003703	PUMP-VAR-DISPL CW 90PV130	90R130-MB-5-AB-80-L-4-C8-H-C5-GBA-42-42-24	SERIES 90	S90-130PV
80003704	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-AB-80-T-M-C8-J-03-NNN-42-42-24	SERIES 90	S90-180PV
80003705	PUMP-VAR-DISPL CW 90PV180	90R180-MB-5-AB-80-T-M-C8-J-C5-NNN-42-42-24	SERIES 90	S90-180PV
80003706	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-A-T-B-J-AA-G-A-BFF-CB-A-HH-C-NNN-***	M46	M46-046PV
80003707	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-NN-80-L-4-F1-E-03-GBA-23-23-24	SERIES 90	S90-100PV

80003709	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-NN-80-S-4-S1-D-03-GBA-26-26-24	SERIES 90	S90-075PV
80003710	MOTOR-VARIABLE DISPL SAE_K	K-V-45DS-E-R2F-F09-S-N-N-CF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
80003712	MOTOR-VAR-DISPL 51MD110	51D110-R-D4-N-D8-M1-R-J-M1-NNN-040-AA-F0-C2-25	SERIES 51	S51-110MV
80003713	MOTOR-VAR-DISPL 51MC060	51C060-R-D1-N-L2-B1-V-A-C0-ADA-012-AA-E4-B2-00	SERIES 51	S51-060MV
80003714	MOTOR-VAR-DISPL 51MV110	51V110-A-F1-N-L2-B1-V-A-C0-ADA-055-AA-NN-B2-00	SERIES 51	S51-110MV
80003715	PUMP-VAR-DISPL CCW 90PV130	90L130-FG-5-BC-80-S-7-F1-F-B1-GCA-42-42-24	SERIES 90	S90-130PV
80003716	PUMP-VAR-DISPL CCW 90PV100	90L100-KP-5-NN-60-R-4-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
80003717	PUMP-VAR-DISPL CCW 90PV130	90L130-KN-5-CD-80-R-4-F1-F-03-GBA-35-35-24	SERIES 90	S90-130PV
80003718	PUMP-VAR DISPL, CCW 90PV055	90-L-055-MB-1-AD-80-P-4-C6-C-C5-GBA-42-42-24	SERIES 90	S90-055PV
80003719	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-NN-60-R-4-C7-E-02-GBA-26-26-20	SERIES 90	S90-100PV
80003720	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-DE-80-S-C-C8-H-03-NNN-32-32-24	SERIES 90	S90-180PV
80003721	PUMP-VAR-DISPL CCW 90PV075	90L075-MA-5-BB-80-S-3-C7-D-C6-GBA-42-42-24	SERIES 90	S90-075PV
80003723	PUMP-VAR DISPL, CW 90PV075	90-R-075-MV-1-AB-60-S-3-S1-D-02-GBA-42-42-24	SERIES 90	S90-075PV
80003727	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A2-C2-N-F6-H-G9-H6-L-43-L-43-C-L-20-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
80003728	MOTOR-VAR DISPL MMV046C	MMV-046-C-A-A-L-B-AV-VNA-***	M46	M46-046MV
80003730	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-ES-A5-K-Y-G5-NNN-026-AA-E6-51-00	SERIES 51	S51-080MV
80003731	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-T2-C0-L-N-L4-ABA-050-AA-E6-00-C2	SERIES 51	S51-250MV
80003733	PUMP-VAR-DISPL CW 90PV130	90R130-HF-5-BC-80-L-4-C8-H-00-GBA-32-32-24	SERIES 90	S90-130PV
80003734	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A4-C2-B-D6-G-G2-H6-L-45-L-45-L-L-30-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
80003740	PUMP-VAR-DISPL CW 90PV250	90R250-MA-5-EG-80-T-4-C8-J-C7-NNN-26-26-24	SERIES 90	S90-250PV
80003741	PUMP-VAR DISPL, CW 90PV055	90-R-055-HF-1-NN-60-P-4-C6-C-03-GBA-17-17-20	SERIES 90	S90-055PV
80003742	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-S1-N-B2-B3-N-N-U3-ABA-054-AA-NN-00-00	SERIES 51	S51-080MV-1
80003748	PUMP-VAR DISPL MPV046C	MPV-046-C-B-A-K-S-B-B-BA-A-A-BJJ-AB-U-AB-B-NNN-***	M46	M46-046PV
80003750	PUMP-VAR DISPL, CW 90PV055	90-R-055-HS-1-NN-60-P-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
80003750C	PUMP-VAR DISPL, CW 90PV055	90-R-055-HS-1-NN-60-P-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
80003751	PUMP-VAR DISPL, CW 90PV100	90-R-100-HS-1-NN-60-P-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
80003751C	PUMP-VAR DISPL, CW 90PV100	90-R-100-HS-1-NN-60-P-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
80003757	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-NN-60-L-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
80003758	PUMP-VAR DISPL, CW 90PV075	90-R-075-HS-1-BC-60-S-3-C6-E-05-GBA-23-23-24	SERIES 90	S90-075PV
80003759	PUMP-VAR-DISPL CW 90PV130	90R130-HF-5-AB-80-S-4-F1-F-03-GBA-35-35-24	SERIES 90	S90-130PV
80003760	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-HZ-B1-C-E-C2-NNN-040-AA-F3-12-00	SERIES 51	S51-080MV
80003761	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MB-1-AB-61-R-3-S1-E-03-GBA-38-38-24	SERIES 90	S90-075PV
80003762	PUMP-VAR DISPL, CW 90PV075	90-R-075-HS-1-NN-60-P-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
80003762C	PUMP-VAR DISPL, CW 90PV075	90-R-075-HS-1-NN-60-P-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
80003764	MOTOR-VAR-DISPL 51MC160	51C160-R-D5-N-L2-B2-V-A-H7-ACB-032-AA-F0-B2-00	SERIES 51	S51-160MV
80003765	PUMP-VAR-DISPL CW 90PV075	90R075-HF-P-BB-80-S-3-S1-E-03-GBA-48-48-24	SERIES 90	S90-075PV

80003766	PUMP-VAR DISPL, CW 90PV100	90-R-100-DC-1-AB-80-S-3-T2-E-GB-GBA-32-32-24	SERIES 90	S90-100PV
80003767	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-S-B-S-BA-A-A-BGG-CD-A-HH-A-NNN-***	M46	M46-046PV
80003769	PUMP-VAR-DISPL CCW 90PV042	90L042-KA-5-BB-80-R-4-C5-C-03-GBA-42-42-24	SERIES 90	S90-042PV
80003770	MOTOR-VARIABLE DISPL SAE_K	K-V-38CN-E-RNF-F12-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
80003771	PUMP-VAR DISPL, CCW 90PV100	90-L-100-LS-1-CD-80-L-3-C7-F-04-FAP-44-40-30	SERIES 90	S90-100PV
80003776	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-1-AD-80-P-4-C6-C-03-GBA-42-42-24	SERIES 90	S90-055PV
80003778	PUMP-VAR-DISPL CW 90PV130	90R130-MA-5-CD-80-S-3-C8-F-C5-GBA-35-35-24	SERIES 90	S90-130PV
80003780	MOTOR-VAR-DISPL 51MV060	51V060-A-S1-N-HZ-B1-B-N-C2-NNN-030-AA-F0-07-00	SERIES 51	S51-060MV
80003781	MOTOR-VAR-DISPL 51MD110-1	51D110-1--A-D4-N-P8-P8-N-N-X1-AWM-033-AA-E6-00-AA	SERIES 51	S51-110MV-1
80003782	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-BC-80-S-3-C6-E-03-GBA-42-42-24	SERIES 90	S90-075PV
80003782C	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-BC-80-S-3-C6-E-03-GBA-42-42-24	SERIES 90	S90-075PV
80003783	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-NN-80-S-3-C6-D-03-GBA-35-35-24	SERIES 90	S90-075PV
80003783C	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-NN-80-S-3-C6-D-03-GBA-35-35-24	SERIES 90	S90-075PV
80003784	MOTOR-VARIABLE DISPL SAE_K	K-V-45DN-A-R2F-F09-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
80003785	MOTOR-VARIABLE DISPL SAE_K	K-V-45DS-A-R2F-F09-S-N-N-CF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
80003786	MOTOR-VAR-DISPL 51MV160	51V160-A-C8-N-L2-B1-V-A-G0-ABA-032-AA-F0-B2-00	SERIES 51	S51-160MV
80003788	MOTOR-VAR-DISPL 51MC110	51C110-R-D3-N-L2-B1-V-A-G5-ADA-022-AA-E6-B2-00	SERIES 51	S51-110MV
80003789	MOTOR-VAR-DISPL 51MV060-1	51V060-1--R-S1-N-T2-CA-N-N-X1-NNN-023-AA-E6-00-28	SERIES 51	S51-060MV-1
80003790	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-BC-60-S-3-C7-D-03-GBA-42-42-24	SERIES 90	S90-100PV
80003791	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-CD-60-S-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
80003792	PUMP-VAR DISPL, CCW 90PV100	90-L-100-LS-1-BC-80-L-3-J3-F-04-FAP-44-40-30	SERIES 90	S90-100PV
80003793	PUMP, VARIABLE DIRECT DISPLACEMENT	LPV-B-A-A-A-A-G-AA-C-A-BMM-DR-A-FF-B-NNN-***	LPV	LPV
80003794	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-NN-60-S-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
80003796	MOTOR-VAR-DISPL 51MD110-1	51D110-1--A-D3-N-P7-P7-N-N-X1-NNN-048-AA-F3-00-AA	SERIES 51	S51-110MV-1
80003797	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-H-T-B-J-AA-G-A-BJJ-DA-A-ZG-A-NNN-***	M46	M46-046PV
80003798	PUMP-VAR DISPL, CW 90PV055	90-R-055-MB-1-BC-60-R-3-C6-D-03-GBA-38-38-20	SERIES 90	S90-055PV
80003800	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-NN-60-S-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
80003802	PUMP-VAR-DISPL CCW 90PV042	90L042-KA-5-NN-80-R-4-C3-N-03-GBA-42-42-24	SERIES 90	S90-042PV
80003803	PUMP-VAR-DISPL CCW 90PV075	90L075-FH-5-AB-60-S-7-C7-E-B2-EFI-42-42-30	SERIES 90	S90-075PV
80003804	PUMP-VAR-DISPL CW 90PV075	90R075-FH-5-AB-60-S-7-C7-D-B2-EFI-42-42-30	SERIES 90	S90-075PV
80003805	MOTOR-VAR-DISPL 51MD110-1	51D110-1--A-D3-N-P8-P8-N-N-X1-NNN-040-AA-E6-00-AA	SERIES 51	S51-110MV-1
80003806	MOTOR-VAR-DISPL 51MD110-1	51D110-1--A-D4-N-P8-P8-N-N-X1-NNN-024-AA-E6-00-AA	SERIES 51	S51-110MV-1
80003807	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-B2-B3-N-N-U3-NNN-044-AA-NN-00-00	SERIES 51	S51-110MV-1
80003808	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-5-NN-60-R-4-S1-C-03-GBA-29-29-20	SERIES 90	S90-055PV
80003809	MOTOR-VAR-DISPL 51MV110	51V110-A-F1-B-HS-A2-B-H-C1-NNN-042-AA-NN-10-13	SERIES 51	S51-110MV
80003810	MOTOR-VAR-DISPL 51MV060-1	51V060-1--R-S1-N-E2-B1-N-N-U1-NNN-035-AA-NN-00-00	SERIES 51	S51-060MV-1

80003811	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-5-BG-80-D-4-S1-L-Z1-FAD-40-40-28	SERIES 90	S90-055PV
80003812	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-AB-60-S-3-S1-F-03-GBA-23-23-20	SERIES 90	S90-100PV
80003813	MOTOR-VARIABLE DISPL SAE_K	K-V-45DN-A-YNF-F00-S-N-N-AF-F16-NNN-NNN	LV / KV MOTORS	L/K-MV
80003819	MOTOR-VAR DISPL MMV046C	MMV-046-C-A-A-L-B-AV-NNN-***	M46	M46-046MV
80003821	MOTOR-VARIABLE DISPL SAE_K	K-V-45DS-E-YNF-F55-S-N-N-CF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
80003824	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-5-AD-80-S-3-C6-C-03-GBA-26-26-28	SERIES 90	S90-055PV
80003825	PUMP-VAR DISPL, CW 90PV055	90-R-055-FC-5-BG-80-S-7-C6-C-B1-GBA-42-42-30	SERIES 90	S90-055PV
80003826	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-HZ-B1-B-N-C2-NNN-066-AA-F0-07-00	SERIES 51	S51-250MV
80003827	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-5-CD-80-T-3-C8-K-03-NNN-35-35-24	SERIES 90	S90-250PV
80003830	PUMP-VAR-DISPL CCW H1PV147	H1-P-147-L-C-A3-C2-N-D8-G-G2-H6-L-42-L-42-A-P-20-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
80003834	PUMP-VAR DISPL, CW 90PV055	90-R-055-FD-5-AB-60-S-3-C6-C-B2-EFI-38-38-24	SERIES 90	S90-055PV
80003835	PUMP-VAR DISPL, CW 90PV055	90-R-055-FD-2-BC-60-S-7-C6-C-B1-EFI-42-42-32	SERIES 90	S90-055PV
80003836	PUMP-VAR-DISPL CW 90PV075	90R075-CA-5-NN-60-P-4-C7-C-00-FAD-35-35-24	SERIES 90	S90-075PV
80003837	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-H-T-B-J-AA-G-A-BGG-DB-A-TT-A-NNN-***	M46	M46-046PV
80003840	PUMP-VAR-DISPL CW 90PV100	90R100-HF-5-BB-80-R-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
80003865	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-1-NN-60-P-4-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
80003866	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-N-N1-NN-N-N-U1-NNN-012-AA-NN-00-00	SERIES 51	S51-060MV-1
80003872	MOTOR-VAR-DISPL 51MV060-1	51V060-1--A-S1-N-TA-C2-N-N-X1-NNN-035-AA-NN-00-20	SERIES 51	S51-060MV-1
80003874	MOTOR-VAR-DISPL 51MD160	51D160-R-D4-N-E1-A5-A-N-G0-NNN-045-AA-F0-03-00	SERIES 51	S51-160MV
80003877	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-EF-80-T-3-C8-K-03-NNN-35-35-24	SERIES 90	S90-250PV
80003878	PUMP-VAR-DISPL CCW 90PV250	90L250-KP-5-AB-80-T-3-F1-K-03-NNN-32-32-24	SERIES 90	S90-250PV
80003879	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-NN-80-R-3-F1-F-03-GBA-35-35-30	SERIES 90	S90-130PV
80003882	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-CD-80-R-4-F1-H-03-GBA-35-35-24	SERIES 90	S90-130PV
80003883	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-N-E2-B1-N-N-U1-NNN-036-AA-E6-00-00	SERIES 51	S51-060MV-1
80003884	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-N-E2-B1-N-N-U1-ACB-036-AA-E6-00-00	SERIES 51	S51-060MV-1
80003885	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-N-E2-B1-N-N-U1-NNN-021-AA-E4-00-00	SERIES 51	S51-060MV-1
80003886	PUMP-VAR-DISPL CCW 90PV250	90L250-KP-5-NN-80-T-3-C8-K-03-NNN-35-35-24	SERIES 90	S90-250PV
80003890	MOTOR-VAR-DISPL 51MD160	51D160-A-D4-N-E1-A5-A-N-G0-NNN-045-AA-F0-03-00	SERIES 51	S51-160MV
80003891	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-NN-80-R-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
80003891C	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-NN-80-R-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
80003892	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-CD-80-R-3-C7-D-03-GBA-35-35-24	SERIES 90	S90-075PV
80003892C	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-CD-80-R-3-C7-D-03-GBA-35-35-24	SERIES 90	S90-075PV
80003893	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-BB-80-S-3-C7-D-03-GBA-42-42-24	SERIES 90	S90-075PV
80003893C	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-BB-80-S-3-C7-D-03-GBA-42-42-24	SERIES 90	S90-075PV
80003894	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-NN-60-R-3-S1-E-03-GBA-35-35-28	SERIES 90	S90-100PV
80003894C	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-NN-60-R-3-S1-E-03-GBA-35-35-28	SERIES 90	S90-100PV

80003895	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-BC-80-P-4-C6-D-03-GBA-23-23-28	SERIES 90	S90-075PV
80003895C	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-BC-80-P-4-C6-D-03-GBA-23-23-28	SERIES 90	S90-075PV
80003897	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-BG-80-P-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
80003898	PUMP, VARIABLE DIRECT DISPLACMENT	LPV-B-A-A-A-A-G-AA-C-A-BBB-DR-A-FF-B-NNN-***	LPV	LPV
80003899	PUMP-VAR-DISPL CW 90PV042	90R042-KA-2-AB-80-P-3-C3-B-03-EFC-23-23-24	SERIES 90	S90-042PV
80003900	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-BG-80-P-3-C6-D-03-EBC-32-32-24	SERIES 90	S90-055PV
80003900C	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-BG-80-P-3-C6-D-03-EBC-32-32-24	SERIES 90	S90-055PV
80003901	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-CD-60-P-3-C7-D-03-GBA-40-40-24	SERIES 90	S90-075PV
80003901C	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-CD-60-P-3-C7-D-03-GBA-40-40-24	SERIES 90	S90-075PV
80003903	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D2-N-E2-B1-N-N-U1-NNN-034-AA-E6-00-00	SERIES 51	S51-080MV-1
80003904	PUMP-VAR-DISPL CCW 90PV250	90L250-KP-5-C1-80-T-4-C8-K-03-NNN-32-32-24	SERIES 90	S90-250PV
80003905	PUMP-VAR-DISPL CCW 90PV100	90L100-MA-5-BC-60-S-3-C7-E-C5-GBA-42-42-24	SERIES 90	S90-100PV
80003906	PUMP-VAR-DISPL CCW 90PV130	90L130-MA-5-AB-80-S-3-C8-F-C5-GBA-42-42-24	SERIES 90	S90-130PV
80003907	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-AB-80-L-4-K2-E-03-GBA-42-42-24	SERIES 90	S90-075PV
80003908	MOTOR-VAR-DISPL 51MD080	51D080-A-D3-N-L2-B1-V-A-C0-NNN-016-AA-NN-B2-00	SERIES 51	S51-080MV
80003912	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HF-1-NN-80-S-4-S1-C-00-GBA-42-42-28	SERIES 90	S90-075PV
80003912C	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HF-1-NN-80-S-4-S1-C-00-GBA-42-42-28	SERIES 90	S90-075PV
80003915	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-NN-80-S-3-K2-D-00-GBA-23-23-20	SERIES 90	S90-075PV
80003916	MOTOR-VAR-DISPL 51MC080	51C080-R-D3-N-L2-B1-V-A-C0-ADA-016-AA-E4-B2-00	SERIES 51	S51-080MV
80003919	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HF-1-BC-80-R-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
80003920	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-CD-60-R-3-F1-E-03-GBA-42-42-20	SERIES 90	S90-100PV
80003925	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-AB-80-S-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
80003926	MOTOR-VAR-DISPL 51MD160	51D160-A-D4-B-TM-E7-L-N-J2-ADA-080-AA-F3-00-BB	SERIES 51	S51-160MV
80003930	PUMP-VAR DISPL MPV044D	MPV-044-D-B-A-A-R-S-E-AA-A-A-BGG-DR-A-FF-A-NNN-***	M35/44	044PV
80003931	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-1-NN-60-S-4-S1-C-03-GBA-29-29-24	SERIES 90	S90-075PV
80003935	MOTOR-VAR-DISPL 51MD060-1	51D060-1--R-D1-N-P7-P7-N-N-X1-NNN-022-AA-F0-00-AA	SERIES 51	S51-060MV-1
80003936	PUMP-VAR-DISPL CW 90PV075	90R075-HF-5-AB-80-S-3-C7-D-03-GBA-23-23-24	SERIES 90	S90-075PV
80003937	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-NN-80-S-4-C7-D-03-GBS-42-42-24	SERIES 90	S90-075PV
80003938	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-1-NN-80-S-3-D9-E-03-GBA-42-42-24	SERIES 90	S90-075PV
80003938C	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-1-NN-80-S-3-D9-E-03-GBA-42-42-24	SERIES 90	S90-075PV
80003952	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-5-CD-60-P-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
80003957	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-CD-80-L-3-C6-C-03-GBA-38-23-24	SERIES 90	S90-075PV
80003958	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-BB-80-S-3-C3-B-03-GBA-20-20-24	SERIES 90	S90-042PV
80003959	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-AB-80-S-3-C3-B-03-GBA-20-20-24	SERIES 90	S90-042PV
80003960	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-S1-N-E2-B1-N-N-U1-NNN-041-AA-F3-00-00	SERIES 51	S51-080MV-1
80003961	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-AB-80-L-3-S1-E-03-GBA-32-32-24	SERIES 90	S90-100PV

80003962	MOTOR-VAR-DISPL 51MV160	51V160-A-C8-N-T1-C2-L-N-G0-ADA-032-AA-E6-00-C6	SERIES 51	S51-160MV
80003963	MOTOR-VAR-DISPL 51MV250	51V250-A-C8-N-T1-C2-L-N-G0-ADA-050-AA-F3-00-C6	SERIES 51	S51-250MV
80003965	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-S-B-B-BA-A-A-BJJ-CN-A-GG-A-NNN-***	M46	M46-046PV
80003966	PUMP-VAR DISPL MPV044D	MPV-044-D-B-A-Y-W-S-E-AA-A-A-BGG-DL-A-FF-C-NNN-***	M35/44	044PV
80003968	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-BG-80-R-4-S1-C-01-GBA-38-38-24	SERIES 90	S90-055PV
80003969	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-NN-60-L-3-F1-E-03-FAD-42-42-24	SERIES 90	S90-100PV
80003971	PUMP-VAR DISPL MPV044D	MPV-044-D-B-A-Y-S-E-AA-A-A-BGG-DL-A-FF-C-NNN-***	M35/44	044PV
80003972	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-CD-80-L-3-C7-E-03-GBA-32-32-24	SERIES 90	S90-100PV
80003982	MOTOR-VAR-DISPL 51MV160	51V160-R-F2-N-E2-A1-A-N-E2-NNN-053-AA-F3-03-37	SERIES 51	S51-160MV
80003985	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-BC-80-L-3-S1-E-03-GBA-14-14-24	SERIES 90	S90-075PV
80003986	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HF-1-BC-80-R-4-S1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
80003990	PUMP-VAR-DISPL CW 90PV042	90R042-FA-5-AB-80-S-7-C3-C-B3-GBA-40-40-24	SERIES 90	S90-042PV
80003991	PUMP, VARIABLE DIRECT DISPLACMENT	LPV-B-A-B-B-A-E-AA-C-A-BFF-DR-A-FF-A-NNN-***	LPV	LPV
80003994	PUMP-VAR-DISPL CW 90PV042	90R042-HF-5-BC-80-P-3-C3-B-03-GBA-38-38-24	SERIES 90	S90-042PV
80003995	MOTOR-VAR-DISPL 51MV160	51V160-V-F1-N-N2-NN-N-N-A0-NNN-115-AA-NN-00-00	SERIES 51	S51-160MV
80003998	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-NN-60-P-4-K2-D-03-GBA-42-42-20	SERIES 90	S90-075PV
80004000	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-TA-C2-L-N-G0-ANB-168-AA-H0-00-B2	SERIES 51	S51-250MV
80004001	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-5-NN-80-S-4-C8-K-03-NNN-42-42-24	SERIES 90	S90-250PV
80004002	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A8-C2-C-F3-F-G5-H2-K-35-K-35-B-L-20-P1-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
80004003	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-E1-B1-N-N-U1-NNN-074-AA-G0-00-00	SERIES 51	S51-110MV-1
80004005	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-BB-60-R-3-S1-C-03-GBA-38-38-24	SERIES 90	S90-055PV
80004006	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A2-C2-N-E6-F-G5-H2-L-35-L-35-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
80004008	MOTOR-VAR-DISPL 51MV060-1	51V060-1--R-S1-N-TH-C2-N-N-X1-NNN-030-AA-F0-00-30	SERIES 51	S51-060MV-1
80004010	MOTOR-FIX DISPL MMF044D	MMF-044-D-A-F-H-A-B-NNR-***	M35/44	044MF
80004011	MOTOR-VARIABLE CARTRIDGE K	K-C-38CN-E-R1F-F12-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
80004012	PUMP, VARIABLE DIRECT DISPLACMENT	LPV-B-A-B-B-A-E-AC-C-A-BFF-DR-A-FF-A-NNN-***	LPV	LPV
80004013	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-HS-A2-C-E-E1-NNN-070-AA-G0-15-20	SERIES 51	S51-250MV
80004015	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-AB-60-P-3-C7-F-03-GBA-42-42-24	SERIES 90	S90-100PV
80004017	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-N-T1-C0-L-N-G0-NNN-062-AA-F3-00-C2	SERIES 51	S51-250MV
80004020	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A9-C1-B-D8-F-G5-NN-L-35-L-35-N-P-22-PN-NNN-E50	H1-MP PUMPS	H1-045PV/053PV
80004021	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-NN-60-S-3-C7-F-03-GBA-38-38-24	SERIES 90	S90-100PV
80004026	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-CD-80-D-3-C7-L-03-GBA-35-35-24	SERIES 90	S90-075PV
80004027	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-BC-80-D-3-S1-L-03-GBA-35-35-24	SERIES 90	S90-075PV
80004029	PUMP-VAR-DISPL CCW 90PV180	90L180-KP-5-CD-80-T-C-C8-J-03-EHA-35-35-24	SERIES 90	S90-180PV
80004030	MOTOR-VAR-DISPL 51MD160	51D160-A-D4-N-T2-C0-L-N-K7-NNN-045-AA-F0-00-B0	SERIES 51	S51-160MV
80004032	PUMP-TANDEM, VAR DISPL CCW H1T053L	H1-T-053-L-A-N-A4-C1-N-E7-F-G1-H3-28-28-28-28-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT

80004034	PUMP, VARIABLE DIRECT DISPLACMENT	LPV-B-A-A-A-E-AC-C-A-BFF-DR-A-FF-B-NNN-***	LPV	LPV
80004037	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-N-E1-A5-A-N-G0-NNN-107-AA-G0-03-00	SERIES 51	S51-160MV
80004038	PUMP-VAR-DISPL CW 90PV130	90R130-HF-5-DE-80-L-3-C8-H-03-GBA-30-30-24	SERIES 90	S90-130PV
80004039	PUMP-VAR-DISPL CW 90PV130	90R130-HF-5-CD-80-L-4-F1-H-03-GBA-30-30-24	SERIES 90	S90-130PV
80004040	PUMP-VAR-DISPL CW 90PV100	90R100-HF-5-BC-80-L-3-S1-E-03-GBA-30-30-24	SERIES 90	S90-100PV
80004042	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D2-N-E1-B1-N-N-U1-ADA-024-AA-E6-00-00	SERIES 51	S51-080MV-1
80004043	PUMP-VAR-DISPL CCW 90PV100	90L100-HF-5-BB-80-R-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
80004045	PUMP-VAR-DISPL CW 90PV042	90R042-KN-5-AB-80-S-3-C3-C-03-GBA-32-14-24	SERIES 90	S90-042PV
80004046	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-BB-80-P-3-C7-D-03-EFI-42-42-24	SERIES 90	S90-075PV
80004047	MOTOR-VAR-DISPL 51MV160	51V160-V-F1-N-L2-B1-V-A-C0-NNN-065-AA-F3-B2-00	SERIES 51	S51-160MV
80004048	MOTOR-VAR-DISPL 51MV160	51V160-A-C8-N-D7-M1-S-K-M1-NNN-062-AA-G3-F4-37	SERIES 51	S51-160MV
80004049	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-C8-N-E2-B1-N-N-U1-NNN-060-AA-F0-00-00	SERIES 51	S51-110MV-1
80004052	MOTOR-VAR-DISPL 51MV110	51V110-R-F1-N-HS-A2-A-E-C1-ACA-027-AA-NN-03-15	SERIES 51	S51-110MV
80004054	PUMP-VAR-DISPL CW 90PV180	90R180-HF-5-BC-80-T-C-F1-H-03-NNN-29-29-24	SERIES 90	S90-180PV
80004055	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-EF-80-T-C-C8-H-03-NNN-29-29-24	SERIES 90	S90-180PV
80004057	MOTOR-VAR-DISPL 51MD110-1	51D110-1--R-D3-N-TA-CA-N-N-X1-NNN-042-AA-F3-00-20	SERIES 51	S51-110MV-1
80004058	MOTOR-VAR-DISPL 51MV110	51V110-V-F1-N-L2-B1-V-A-C0-NNN-022-AA-F0-B2-00	SERIES 51	S51-110MV
80004060	PUMP, VARIABLE DIRECT DISPLACMENT	LPV-B-A-B-C-A-E-AC-C-A-BFF-DR-A-FF-B-NNN-***	LPV	LPV
80004063	PUMP-VAR-DISPL CW 90PV075	90R075-FM-5-AB-80-S-7-S1-E-B6-ELB-38-38-30	SERIES 90	S90-075PV
80004064	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-NN-80-P-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-075PV
80004065	PUMP-VAR DISPL, CW 90PV055	90-R-055-MB-1-AD-80-P-4-C6-C-C5-GBA-42-42-24	SERIES 90	S90-055PV
80004067	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-CD-80-P-4-C7-F-03-GBA-42-42-24	SERIES 90	S90-100PV
80004067C	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-CD-80-P-4-C7-F-03-GBA-42-42-24	SERIES 90	S90-100PV
80004068	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-NN-80-P-4-S1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
80004068C	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-NN-80-P-4-S1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
80004069	PUMP-VAR DISPL, CW 90PV055	90-R-055-FD-5-AB-60-S-7-C6-C-B2-EFI-38-38-24	SERIES 90	S90-055PV
80004071	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-E-V-C-S-AA-B-A-C-A-BHH-GG-B-KF-B-C-C-A-BHH-GG-B-KF-Y-NAG-*	M46	M46-046PT
80004072	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A2-C2-N-D8-F-G5-NN-L-40-L-40-B-P-24-PN-C08-NNN	H1-MP PUMPS	H1-045PV/053PV
80004073	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A2-C2-N-D8-F-G5-NN-L-40-L-40-B-P-24-PN-C08-NNN	H1-MP PUMPS	H1-045PV/053PV
80004074	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A8-C2-C-F2-F-G5-NN-J-40-J-40-B-P-24-PN-C08-NNN	H1-MP PUMPS	H1-045PV/053PV
80004075	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-N-L2-B1-V-A-C0-ANB-032-AA-NN-B2-00	SERIES 51	S51-160MV
80004077	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-1-CD-80-S-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
80004078	PUMP-VAR-DISPL CW 90PV250	90R250-PB-5-NN-80-T-3-C8-K-03-NNN-35-35-24	SERIES 90	S90-250PV
80004079	PUMP-VAR-DISPL CCW 90PV100	90L100-FD-5-NN-60-S-H-C7-D-B8-EFI-45-45-30	SERIES 90	S90-100PV
80004080	PUMP-VAR-DISPL CW 90PV100	90R100-FD-5-BC-80-P-7-C7-E-B1-EAB-42-42-28	SERIES 90	S90-100PV
80004081	PUMP-VAR-DISPL CCW 90PV100	90L100-FD-5-AB-60-S-H-S1-D-B8-EFI-45-45-30	SERIES 90	S90-100PV

80004083	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-NN-80-S-3-C3-C-03-GBA-29-29-24	SERIES 90	S90-042PV
80004084	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-DE-80-T-3-C8-K-03-NNN-32-32-24	SERIES 90	S90-250PV
80004085	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-5-DE-80-T-3-C8-K-03-NNN-32-32-24	SERIES 90	S90-250PV
80004086	MOTOR-VAR-DISPL 51MD110	51D110-A-D3-N-D7-M1-S-K-M1-NNN-037-AA-F0-F4-25	SERIES 51	S51-110MV
80004088	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A8-C2-C-D6-H-G9-H3-L-45-L-45-C-L-24-P1-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
80004091	MOTOR-VAR-DISPL 51MV110	51V110-V-F1-N-H4-B3-R-J-N2-NNN-022-AA-NN-C2-21	SERIES 51	S51-110MV
80004094	MOTOR-VAR-DISPL 51MV110-1	51V110-1--A-F1-N-TH-C2-N-N-X1-NNN-044-AA-E6-00-37	SERIES 51	S51-110MV-1
80004096	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A9-C1-B-D8-F-G5-H2-L-35-L-35-N-P-22-PN-NNN-E50	H1-MP PUMPS	H1-045PV/053PV
80004100	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-AB-60-S-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
80004101	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-AB-60-S-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
80004103	MOTOR-VAR-DISPL 51MD080	51D080-A-D2-N-D7-M1-S-K-M1-NNN-039-AA-F0-F4-25	SERIES 51	S51-080MV
80004104	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-B-T-B-J-AA-A-A-BJF-CG-A-GG-A-NNN-***	M46	M46-046PV
80004106	MOTOR-VAR-DISPL 51MD080-1	51D080-1--A-D3-N-T1-CA-N-N-X1-NNN-027-AA-F0-00-24	SERIES 51	S51-080MV-1
80004110	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-HZ-B1-B-N-C2-ACA-075-AA-H0-05-00	SERIES 51	S51-250MV
80004120	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-DE-80-R-3-C8-H-00-GBA-42-42-28	SERIES 90	S90-130PV
80004121	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-BC-80-R-3-F1-H-00-GBA-42-42-28	SERIES 90	S90-130PV
80004130	PUMP-VAR-DISPL CCW 90PV130	90L130-HF-5-CD-80-R-3-F1-F-03-EEB-35-35-24	SERIES 90	S90-130PV
80004132	MOTOR-VAR-DISPL 51MV080-1	51V080-1--H-S1-N-TA-C2-N-N-X1-NNN-018-AA-NN-00-21	SERIES 51	S51-080MV-1
80004133	MOTOR-VAR-DISPL 51MV060	51V060-R-C6-N-Y7-B1-S-L-J1-ADA-032-AA-F3-F4-00	SERIES 51	S51-060MV
80004134	MOTOR-VAR-DISPL 51MV060	51V060-R-C6-N-Y7-B1-S-L-J1-ADA-028-AA-F3-F4-00	SERIES 51	S51-060MV
80004138	PUMP-VAR-DISPL CCW 90PV250	90L250-KN-5-NN-80-S-4-F1-K-03-NNN-42-42-24	SERIES 90	S90-250PV
80004139	PUMP-VAR-DISPL CCW 90PV180	90L180-KN-5-CD-80-S-M-F1-J-05-FAC-42-42-24	SERIES 90	S90-180PV
80004140	MOTOR-VAR-DISPL 51MV110-1	51V110-1--A-F1-N-TA-C2-N-N-X1-NNN-062-AA-F0-00-22	SERIES 51	S51-110MV-1
80004141	MOTOR-VAR-DISPL 51MC160	51C160-R-D5-N-HZ-B1-A-N-G0-NNN-032-AA-F0-03-00	SERIES 51	S51-160MV
80004144	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-BC-80-S-3-C8-F-04-GBA-38-38-28	SERIES 90	S90-130PV
80004145	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-BC-80-L-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-100PV
80004146	PUMP-VAR-DISPL CW 90PV180	90R180-HF-5-BC-80-T-C-C8-J-03-NNN-42-42-24	SERIES 90	S90-180PV
80004151	MOTOR-VAR-DISPL 51MD080-1	51D080-1--R-D3-N-E2-B1-N-N-U1-NNN-021-AA-E6-00-00	SERIES 51	S51-080MV-1
80004152	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KN-5-NN-80-S-4-S1-F-03-GBA-32-32-24	SERIES 90	S90-100PV
80004153	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KN-5-CD-80-S-4-F1-F-03-GBA-32-32-24	SERIES 90	S90-100PV
80004154	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KN-5-AB-80-S-4-S1-F-03-GBA-32-32-24	SERIES 90	S90-100PV
80004155	PUMP-VAR-DISPL CW 90PV042	90R042-FA-5-AB-80-S-7-C3-C-B3-GBA-32-32-24	SERIES 90	S90-042PV
80004156	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-NN-80-S-3-C8-F-04-GBA-38-38-28	SERIES 90	S90-130PV
80004157	MOTOR-VAR-DISPL 51MC110	51C110-R-D3-N-HZ-B1-A-E-G5-NNN-037-AA-E6-05-00	SERIES 51	S51-110MV
80004160	PUMP-VAR-DISPL CCW 90PV180	90L180-HF-5-CD-80-T-M-F1-H-03-FAC-35-35-24	SERIES 90	S90-180PV
80004161	PUMP-VAR-DISPL CCW 90PV180	90L180-HF-5-EF-80-T-M-F1-H-03-EBA-38-38-24	SERIES 90	S90-180PV

80004165	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-T2-C0-L-N-G0-NNN-057-AA-F3-00-B3	SERIES 51	S51-160MV
80004166	MOTOR-VAR-DISPL 51MC160	51C160-R-D5-N-EQ-A5-J-Y-G5-ACM-032-AA-G0-15-00	SERIES 51	S51-160MV
80004174	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-NN-80-R-4-F1-F-03-EEB-23-23-24	SERIES 90	S90-130PV
80004175	MOTOR-VAR-DISPL 51MD080-1	51D080-1--A-D3-N-E1-B1-N-N-U1-NNN-032-AA-F0-00-00	SERIES 51	S51-080MV-1
80004182	PUMP-VAR-DISPL CW 90PV100	90R100-KA-P-BB-80-P-3-C7-F-03-FAB-48-48-24	SERIES 90	S90-100PV
80004183	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-5-NN-80-S-3-S1-C-05-GBA-42-42-24	SERIES 90	S90-055PV
80004210	PUMP-VAR-DISPL CCW 90PV180	90L180-HF-2-NN-80-T-C-C8-L-00-FAC-35-35-24	SERIES 90	S90-180PV
80004211	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-5-CD-60-L-3-F1-F-02-FAD-38-38-24	SERIES 90	S90-100PV
80004214	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-CD-80-S-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
80004216	MOTOR-FIX DISPL MMF044D	MMF-044-D-A-F-G-A-B-NNR.***	M35/44	044MF
80004225	PUMP-VAR-DISPL CW 90PV180	90R180-HF-2-NN-80-T-C-C8-L-00-FAC-35-35-24	SERIES 90	S90-180PV
80004228	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-1-BC-80-P-4-S1-D-03-GBA-38-38-24	SERIES 90	S90-075PV
80004229	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-5-CD-80-L-4-K2-E-03-GBA-35-42-24	SERIES 90	S90-075PV
80004230	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-E1-B1-N-N-U1-NNN-050-AA-NN-00-00	SERIES 51	S51-110MV-1
80004232	MOTOR-VAR-DISPL 51MD160	51D160-A-D4-B-L1-B1-W-B-J1-ADA-045-AA-F0-D4-00	SERIES 51	S51-160MV
80004234	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-AB-80-T-C-C8-J-03-NNN-42-42-24	SERIES 90	S90-180PV
80004235	PUMP-VAR-DISPL CW 90PV100	90R100-MA-5-NN-80-P-3-C7-D-C5-GBA-32-32-24	SERIES 90	S90-100PV
80004237	PUMP-VAR-DISPL CCW H1PV078	H1-P-078-L-A-A3-C2-N-D6-H-G1-H3-L-33-L-33-C-L-20-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
80004238	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-1-NN-60-P-3-S1-C-03-GBA-14-14-24	SERIES 90	S90-055PV
80004239	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KN-5-NN-80-R-4-S1-F-03-GBA-32-32-24	SERIES 90	S90-100PV
80004240	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KN-5-CD-80-R-4-F1-F-03-GBA-32-32-24	SERIES 90	S90-100PV
80004241	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KN-5-AB-80-R-4-S1-F-03-GBA-32-32-24	SERIES 90	S90-100PV
80004242	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-5-NN-60-L-3-S1-F-02-FAD-38-38-24	SERIES 90	S90-100PV
80004243	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-1-CD-60-S-3-C6-C-04-GBA-35-35-24	SERIES 90	S90-055PV
80004246	MOTOR-VAR DISPL MMV046C	MMV-046-C-A-E-H-A-AU-VNA.***	M46	M46-046MV
80004249	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-N-A2-C2-N-E7-F-G6-H3-28-28-25-25-N-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
80004250	PUMP-VAR-DISPL CCW H1PV165	H1-P-165-L-C-A4-C3-B-D5-G-G2-H4-L-40-L-40-L-M-20-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
80004255	MOTOR-VAR DISPL MMV046C	MMV-046-C-A-E-H-A-A4-VNA.***	M46	M46-046MV
80004257	MOTOR-VAR-DISPL 51MD110	51D110-R-D3-N-D7-M1-S-K-M1-NNN-039-AA-F0-F4-35	SERIES 51	S51-110MV
80004258	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-CD-80-S-4-C7-E-03-GBA-38-38-24	SERIES 90	S90-075PV
80004260	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A2-C2-N-F5-H-G1-H6-K-45-K-45-C-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
80004262	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-BC-80-R-4-S1-E-03-GBA-17-17-24	SERIES 90	S90-075PV
80004263	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-2-NN-80-R-4-S1-E-00-GBA-35-35-24	SERIES 90	S90-100PV
80004264	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-NN-80-R-4-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
80004267	MOTOR-VAR-DISPL 51MC080	51C080-R-D3-N-H4-B3-R-J-N2-NNN-050-AA-NN-C2-35	SERIES 51	S51-080MV
80004268	MOTOR-VAR-DISPL 51MD080-1	51D080-1--R-D3-N-E2-B1-N-N-U1-AWM-021-AA-E6-00-00	SERIES 51	S51-080MV-1

80004269	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-CD-80-D-3-C7-L-05-FAP-42-42-24	SERIES 90	S90-075PV
80004270	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-CD-60-P-4-C7-E-03-GBA-07-35-20	SERIES 90	S90-100PV
80004271	PUMP-VAR-DISPL CW 90PV075	90R075-DD-5-AB-60-L-3-S1-E-GB-GBA-35-35-24	SERIES 90	S90-075PV
80004282	PUMP-VAR-DISPL CW 90PV130	90R130-KN-5-DE-80-S-3-C8-H-03-GBA-35-35-24	SERIES 90	S90-130PV
80004283	PUMP-VAR-DISPL CW 90PV130	90R130-KN-5-DE-80-S-3-F1-H-03-GBA-35-35-24	SERIES 90	S90-130PV
80004292	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-E2-A2-A-N-E1-ABA-070-AA-F3-03-25	SERIES 51	S51-160MV
80004293	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-BB-80-D-4-S1-L-05-GBA-26-26-24-F053	SERIES 90	S90-075PV
80004295	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A2-C2-N-F5-H-F1-H6-K-45-K-45-C-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
80004296	PUMP-VAR-DISPL CCW 90PV250	90L250-KN-5-NN-80-T-4-F1-K-03-NNN-42-42-24	SERIES 90	S90-250PV
80004299	MOTOR-VAR-DISPL 51MD110-1	51D110-1--H-D4-N-T7-D7-N-N-X1-AWG-036-AA-E6-00-28	SERIES 51	S51-110MV-1
80004301	PUMP-VAR-DISPL CCW 90PV100	90L100-DC-5-CD-80-S-3-F1-E-GB-GBA-35-35-24	SERIES 90	S90-100PV
80004302	PUMP-VAR-DISPL CW 90PV100	90R100-KN-5-CD-60-S-3-C7-E-03-GBA-26-26-24	SERIES 90	S90-100PV
80004312	MOTOR-VAR-DISPL 51MD160	51D160-A-D4-N-L2-B1-V-A-C0-NNN-045-AA-F3-B2-00	SERIES 51	S51-160MV
80004313	PUMP-VAR-DISPL CCW 90PV042	90L042-KN-5-BB-80-R-4-C3-B-00-GBA-35-35-24	SERIES 90	S90-042PV
80004314	PUMP-VAR-DISPL CW 90PV130	90R130-FH-5-BC-80-S-7-C8-H-B1-EFC-42-42-30	SERIES 90	S90-130PV
80004315	PUMP-VAR-DISPL CCW 90PV180	90L180-KN-5-CD-80-T-M-F1-J-05-FAC-42-42-24	SERIES 90	S90-180PV
80004316	MOTOR-VARIABLE DISPL SAE_K	K-V-38CN-E-RNF-F07-S-N-N-AF-F18-NNN-PNN	LV / KV MOTORS	L/K-MV
80004319	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-E1-A5-A-N-G0-NNN-109-AA-F0-03-00	SERIES 51	S51-250MV
80004322	PUMP-TANDEM, VAR DISPL MPT044D	MPT-044-D-A-R-R-H-AA-B-A-A-A-BGG-DR-A-FF-B-C-A-A-BGG-DL-A-FF-D-NNN-*	M35/44	044PT
80004323	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-J-S-B-B-AA-G-A-BHH-DA-A-WA-A-NNN-***	M46	M46-046PV
80004324	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-J-S-B-B-AA-G-A-BRR-DA-A-WA-A-NNN-***	M46	M46-046PV
80004328	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HK-1-AB-60-R-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
80004330	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-1-NN-60-P-4-S1-D-GB-GBA-40-40-24	SERIES 90	S90-055PV
80004331	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-NN-80-S-4-S1-L-03-GBA-42-16-32	SERIES 90	S90-075PV
80004334	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-C8-N-TA-C2-N-N-X1-NNN-031-AA-F3-00-24	SERIES 51	S51-110MV-1
80004335	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-CD-80-S-3-TK-F-02-GLA-42-42-28	SERIES 90	S90-130PV
80004336	MOTOR-VAR-DISPL 51MD160	51D160-A-D4-N-D7-M1-S-K-M1-ACA-065-AA-F3-F4-29	SERIES 51	S51-160MV
80004338	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-BC-60-R-3-C7-F-06-EDI-43-43-30	SERIES 90	S90-100PV
80004339	PUMP-VAR-DISPL CCW H1PV165	H1-P-165-L-C-A2-C3-N-D3-G-G3-H6-L-20-L-35-L-M-20-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
80004340	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-BC-80-S-3-S1-D-03-GBA-29-29-24	SERIES 90	S90-075PV
80004342	PUMP-VAR-DISPL CCW 90PV100	90L100-DC-5-NN-80-S-3-S1-E-GB-GBA-35-35-24	SERIES 90	S90-100PV
80004344	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-1-BG-80-P-4-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV
80004355	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-D-T-B-B-BA-A-A-BMM-CE-A-GG-B-NNN-***	M46	M46-046PV
80004362	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-BK-80-P-3-C6-C-02-GBA-35-35-24	SERIES 90	S90-055PV
80004363	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-CD-80-L-3-F1-E-03-GBA-29-29-24	SERIES 90	S90-100PV
80004364	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-CD-80-P-3-C7-D-02-GBA-29-29-24	SERIES 90	S90-075PV

80004365	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-BC-80-P-3-C7-D-02-GBA-29-29-24	SERIES 90	S90-075PV
80004366	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-NN-80-L-4-F1-F-03-GBA-20-20-20	SERIES 90	S90-100PV
80004367	MOTOR-VAR-DISPL 51MD080-1	51D080-1--R-D2-N-E2-B1-N-N-U1-NNN-050-AA-E6-00-00	SERIES 51	S51-080MV-1
80004368	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-CD-80-S-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-075PV
80004369	PUMP-VAR DISPL, CW 90PV055	90-R-055-M8-1-NN-60-P-3-S1-D-03-GBA-38-38-24	SERIES 90	S90-055PV
80004374	MOTOR-VAR-DISPL 51MD110-1	51D110-1--A-D3-N-T2-D2-N-N-X1-NNN-040-AA-F0-00-20	SERIES 51	S51-110MV-1
80004375	MOTOR-VARIABLE DISPL SAE_K	K-V-45DS-A-R1F-F06-S-N-N-BF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
80004376	MOTOR-VARIABLE DISPL SAE_K	K-V-45DS-A-Y1F-F01-S-N-N-BF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
80004377	MOTOR-VARIABLE DISPL SAE_K	K-V-45DS-A-Y1F-F06-S-N-N-BF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
80004379	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-NN-80-S-3-D9-E-03-GBA-42-42-24	SERIES 90	S90-075PV
80004380	PUMP-VAR-DISPL CW 90PV130	90R130-FH-5-NN-80-S-7-C8-F-B1-GBA-42-42-30	SERIES 90	S90-130PV
80004381	PUMP-VAR-DISPL CW 90PV100	90R100-MA-5-BC-60-P-3-C7-E-C7-GBA-30-30-24	SERIES 90	S90-100PV
80004385	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-H-R-B-S-AA-A-A-BCC-CH-A-GG-A-NNN-***	M46	M46-046PV
80004386	MOTOR-VAR-DISPL 51MD160	51D160-A-D4-N-E1-A5-A-N-G0-ABA-085-AA-F0-03-00	SERIES 51	S51-160MV
80004388	MOTOR-VAR-DISPL 51MV110	51V110-R-F1-N-HZ-B1-B-E-G5-NNN-030-AA-F3-12-00	SERIES 51	S51-110MV
80004390	MOTOR-VAR-DISPL 51MD110	51D110-R-D3-N-L2-B1-V-A-C0-ADA-022-AA-E6-B2-00	SERIES 51	S51-110MV
80004391	MOTOR-VAR-DISPL 51MC080	51C080-R-D3-N-L2-B1-V-A-C0-ACB-016-AA-E4-B2-00	SERIES 51	S51-080MV
80004392	PUMP-VAR-DISPL CW 90PV075	90R075-MA-5-CD-60-S-3-C7-E-C5-GBA-26-26-20	SERIES 90	S90-075PV
80004394	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MA-1-NN-80-S-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
80004398	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-NN-80-P-3-F1-F-00-GBA-32-32-24	SERIES 90	S90-130PV
80004400	PUMP-VAR DISPL, CW 90PV075	90-R-075-DD-1-CD-60-P-4-C7-D-GB-GBA-35-35-24	SERIES 90	S90-075PV
80004403	MOTOR-VARIABLE CARTRIDGE K	K-C-45DN-A-RNF-F04-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
80004407	PUMP-VAR DISPL, CW 90PV055	90-R-055-HS-1-BC-60-P-4-S1-C-03-GBA-38-38-24	SERIES 90	S90-055PV
80004408	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HF-1-NN-80-R-3-S1-D-03-GBA-26-26-24	SERIES 90	S90-075PV
80004409	PUMP-VAR DISPL, CW 90PV055	90-R-055-DC-1-NN-80-P-3-S1-C-GB-GBA-38-38-24	SERIES 90	S90-055PV
80004410	PUMP-VAR DISPL, CW 90PV100	90-R-100-DC-1-CD-80-P-3-F1-E-GB-GBA-38-38-24	SERIES 90	S90-100PV
80004417	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A2-C2-N-D8-H-G1-NN-L-40-L-40-F-P-24-PN-C08-NNN	H1-HP PUMPS	H1-069PV/078PV
80004418	MOTOR-VAR-DISPL 51MD160	51D160-R-D4-N-TA-C2-L-N-G0-NNN-032-AA-NN-00-B5	SERIES 51	S51-160MV
80004419	PUMP-VAR-DISPL CCW 90PV130	90L130-FH-5-NN-80-S-7-C8-F-B1-GBA-42-42-30	SERIES 90	S90-130PV
80004420	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-BC-60-S-3-C7-E-02-GBA-30-30-24	SERIES 90	S90-100PV
80004421	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-T1-C0-L-N-G0-ABA-065-AA-G0-00-B0	SERIES 51	S51-160MV
80004423	PUMP-VAR-DISPL CCW H1PV147	H1-P-147-L-C-A3-C3-N-D8-G-G3-NN-L-42-L-42-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
80004426	MOTOR-VAR-DISPL 51MD060-1	51D060-1--R-D1-N-TA-CA-N-N-X1-NNN-024-AA-F0-00-18	SERIES 51	S51-060MV-1
80004428	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-CD-80-R-3-C8-H-03-GBA-29-29-30	SERIES 90	S90-130PV
80004430	PUMP-VAR DISPL, CW 90PV100	90-R-100-HS-1-CD-80-R-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
80004431	PUMP-VAR DISPL, CW 90PV100	90-R-100-HS-1-CD-80-S-3-F1-E-03-GBA-35-35-30	SERIES 90	S90-100PV

80004434	PUMP-VAR-DISPL CW 90PV250	90R250-HF-2-CD-80-T-4-C8-J-03-NNN-32-32-24	SERIES 90	S90-250PV
80004435	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-NN-80-T-C-F1-H-00-FAC-23-23-28	SERIES 90	S90-180PV
80004436	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KN-5-NN-80-R-4-S1-D-03-GBA-38-38-24	SERIES 90	S90-075PV
80004439	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-1-NN-80-S-3-S1-C-03-GBA-38-38-24	SERIES 90	S90-055PV
80004440	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-1-CD-80-S-3-S1-D-03-EBC-38-38-24	SERIES 90	S90-075PV
80004441	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-CD-80-S-3-F1-E-03-GBA-38-38-24	SERIES 90	S90-100PV
80004442	MOTOR-VAR-DISPL 51MC080	51C080-R-D3-N-L2-B1-V-A-C0-NNN-017-AA-E4-B2-00	SERIES 51	S51-080MV
80004443	MOTOR-VAR-DISPL 51MC080	51C080-R-D3-N-L2-B1-V-A-C0-ADA-017-AA-E4-B2-00	SERIES 51	S51-080MV
80004444	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-CD-80-S-3-F1-H-03-GBA-42-42-24	SERIES 90	S90-130PV
80004445	PUMP-VAR-DISPL CCW 90PV100	90L100-DD-5-NN-80-P-4-C6-E-G1-GBA-30-30-24	SERIES 90	S90-100PV
80004446	PUMP-VAR-DISPL CCW 90PV130	90L130-FH-5-BC-80-P-7-C8-H-B1-GBA-29-29-24	SERIES 90	S90-130PV
80004447	PUMP-VAR-DISPL CW 90PV100	90R100-CA-5-BC-60-P-7-S1-F-00-GBA-42-42-28	SERIES 90	S90-100PV
80004448	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-BC-80-R-3-C7-D-09-GBA-42-42-24	SERIES 90	S90-075PV
80004449	MOTOR-VAR-DISPL 51MC110	51C110-A-D3-N-HE-B2-C-E-E6-NNN-039-AA-E6-12-00	SERIES 51	S51-110MV
80004456	MOTOR-VAR-DISPL 51MV080-1	51V080-1--H-S1-N-N1-NN-N-N-U1-NNN-050-AA-NN-00-00	SERIES 51	S51-080MV-1
80004457	PUMP-VAR-DISPL CW 90PV250	90R250-KN-5-DE-80-S-3-C8-K-03-NNN-35-35-30	SERIES 90	S90-250PV
80004458	MOTOR-VAR-DISPL 51MD080	51D080-R-D2-N-HS-A2-C-E-E1-NNN-032-AA-F3-12-30	SERIES 51	S51-080MV
80004459	MOTOR-VAR-DISPL 51MD080	51D080-R-D2-N-HS-A2-C-E-E1-NNN-040-AA-NN-12-30	SERIES 51	S51-080MV
80004460	MOTOR-VAR-DISPL 51MD080-1	51D080-1--R-D3-N-E2-B1-N-N-U1-NNN-030-AA-E6-00-00	SERIES 51	S51-080MV-1
80004464	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-D-HZ-B1-A-E-G0-NNN-031-AA-NN-03-00	SERIES 51	S51-080MV
80004465	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-S1-N-TA-C2-N-N-X1-NNN-018-AA-F0-00-15	SERIES 51	S51-080MV-1
80004466	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A4-C2-N-D8-F-G4-NN-L-25-L-25-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
80004467	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A5-C2-N-D8-F-G5-NN-L-28-L-28-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
80004471	MOTOR-VAR-DISPL 51MD080-1	51D080-1--R-D3-N-F1-B1-N-N-U1-NNN-026-AA-F0-00-00	SERIES 51	S51-080MV-1
80004473	PUMP-VAR DISPL, CW 90PV075	90-R-075-KN-1-NN-60-R-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
80004479	PUMP-VAR-DISPL CW 90PV130	90R130-MA-5-NN-80-R-3-F1-F-C5-GBA-35-35-24	SERIES 90	S90-130PV
80004480	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-NN-80-L-3-S1-C-03-GBA-20-20-24	SERIES 90	S90-055PV
80004485	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-CD-80-S-3-C8-J-03-NNN-38-20-24	SERIES 90	S90-250PV
80004487	MOTOR-VAR-DISPL 51MD160	51D160-R-D5-N-T2-R5-L-N-G0-ANE-064-AA-H0-00-B0	SERIES 51	S51-160MV
80004491	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MA-1-NN-80-R-4-S1-F-03-GBA-29-29-24	SERIES 90	S90-100PV
80004498	MOTOR-VAR-DISPL 51MV080	51V080-A-S1-C-HS-A2-B-H-C1-NNN-027-AA-NN-10-13	SERIES 51	S51-080MV
80004502	PUMP-VAR DISPL, CW 90PV055	90-R-055-DC-1-NN-60-S-4-S1-C-Z1-GBA-35-35-20	SERIES 90	S90-055PV
80004512	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-NN-60-S-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
80004515	MOTOR-VAR-DISPL 51MD110	51D110-R-D3-N-L7-B1-W-B-C0-ADA-022-AA-F0-D4-00	SERIES 51	S51-110MV
80004521	PUMP-VAR DISPL, CW 90PV055	90-R-055-FA-5-AD-80-S-7-C6-D-B2-GBA-40-40-24	SERIES 90	S90-055PV
80004522	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-BK-80-S-3-S1-B-03-FAD-38-20-24	SERIES 90	S90-055PV

80004524	PUMP-VAR-DISPL CCW 90PV180	90L180-KP-5-CD-80-S-M-F1-J-03-FAC-32-32-24	SERIES 90	S90-180PV
80004525	PUMP-VAR-DISPL CCW 90PV130	90L130-MA-5-NN-80-S-3-F1-F-C5-EBA-38-38-24	SERIES 90	S90-130PV
80004526	PUMP-VAR-DISPL CCW 90PV130	90L130-MA-5-DE-80-S-3-F1-F-C5-EBA-38-38-24	SERIES 90	S90-130PV
80004527	PUMP-VAR-DISPL CW 90PV130	90R130-MA-5-BC-80-S-3-F1-F-C5-GBA-29-29-24	SERIES 90	S90-130PV
80004530	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-N-B2-B3-N-N-U3-ADA-032-AA-NN-00-00	SERIES 51	S51-060MV-1
80004532	MOTOR-VARIABLE DISPL SAE_K	K-V-45DN-A-R1F-F13-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
80004533	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-BC-80-S-4-S1-D-03-GBA-32-32-24	SERIES 90	S90-075PV
80004534	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-EG-80-S-M-C8-J-03-NNN-26-26-24	SERIES 90	S90-180PV
80004536	MOTOR-VAR-DISPL 51MC110-1	51C110-1--R-D4-N-E2-B1-N-N-U1-ADA-060-AA-G0-00-00	SERIES 51	S51-110MV-1
80004539	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-BC-80-S-4-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
80004540	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-8-N-0-S1-N-00-EEA-00-00-00	SERIES 90	#N/D!
80004541	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-BC-80-S-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
80004545	PUMP-VAR-DISPL CW 90PV180	90R180-HF-5-NN-80-S-M-C8-J-03-NNN-26-26-24	SERIES 90	S90-180PV
80004550	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D3-N-N1-NN-N-N-U1-ABA-030-AA-F0-00-00	SERIES 51	S51-080MV-1
80004553	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-CD-80-S-M-C8-J-05-NNN-32-32-28	SERIES 90	S90-180PV
80004554	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-AB-60-S-4-S1-L-04-GBA-32-32-24	SERIES 90	S90-100PV
80004557	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-2-BC-60-S-3-S1-E-03-EBC-40-40-26	SERIES 90	S90-100PV
80004558	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-T1-C0-L-N-G0-ABA-058-AA-G0-00-B7	SERIES 51	S51-160MV
80004560	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A2-C3-N-E7-F-G5-H3-38-38-38-38-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
80004561	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-T1-C0-L-N-K7-ACA-055-AA-F3-00-C5	SERIES 51	S51-160MV
80004564	PUMP-VAR-DISPL CW 90PV250	90R250-KP-5-CD-80-T-3-C8-K-03-NNN-42-42-24	SERIES 90	S90-250PV
80004565	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-EF-80-S-C-C8-H-03-NNN-20-20-24	SERIES 90	S90-180PV
80004566	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-NN-80-S-C-F1-H-03-NNN-20-20-24	SERIES 90	S90-180PV
80004567	PUMP-VAR-DISPL CCW 90PV100	90L100-DC-5-AB-80-S-3-D7-E-GB-GBA-35-35-24	SERIES 90	S90-100PV
80004568	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-BG-80-P-3-S1-D-03-GBA-38-38-24	SERIES 90	S90-055PV
80004569	MOTOR-VAR-DISPL 51MD080	51D080-A-D2-N-HS-A3-C-E-E5-NNN-030-AA-NN-12-25	SERIES 51	S51-080MV
80004570	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-1-NN-60-S-3-C6-C-GB-GBA-32-32-24	SERIES 90	S90-055PV
80004571	PUMP-VAR-DISPL CW 90PV075	90R075-HF-2-NN-60-P-4-S1-D-03-GBA-42-14-24	SERIES 90	S90-075PV
80004573	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-F1-A5-A-N-A6-NNN-060-AA-G0-03-00	SERIES 51	S51-250MV
80004574	MOTOR-VARIABLE CARTRIDGE K	K-C-38CN-E-RNF-F06-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
80004575	PUMP-VAR-DISPL CW 90PV042	90R042-FC-5-BC-80-S-7-C3-C-B1-EFI-42-42-30	SERIES 90	S90-042PV
80004576	MOTOR-VAR-DISPL 51MD060-1	51D060-1--R-D1-N-T1-D1-N-N-X1-NNN-026-AA-NN-00-17	SERIES 51	S51-060MV-1
80004577	MOTOR- VARIABLE CARTRIDGE L	L-C-25CN-E-RNF-F10-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
80004578	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-5-BC-60-D-3-F1-L-04-GBA-35-35-24	SERIES 90	S90-100PV
80004579	MOTOR-VAR-DISPL 51MD080-1	51D080-1--R-D2-N-T1-D1-N-N-X1-NNN-023-AA-NN-00-25	SERIES 51	S51-080MV-1
80004580	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-NN-80-L-3-F1-F-04-GBA-23-23-24	SERIES 90	S90-130PV

80004581	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-B1-C1-B-D8-F-G5-H3-L-35-L-35-N-P-26-PN-NNN-E50	H1-MP PUMPS	H1-045PV/053PV
80004582	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-AB-60-S-3-C6-D-01-GBA-35-35-24	SERIES 90	S90-075PV
80004583	MOTOR-VAR-DISPL 51MV060-1	51V060-1--R-S1-C-TA-C2-N-N-X1-NNN-025-AA-E6-00-30	SERIES 51	S51-060MV-1
80004586	MOTOR-VAR-DISPL 51MD110-1	51D110-1--R-D3-N-T2-L5-N-N-X1-ABA-065-AA-F3-00-28	SERIES 51	S51-110MV-1
80004588	PUMP-VAR DISPL MPV046C	MPV-046-C-B-A-R-S-B-B-AA-A-A-BJJ-AB-U-AD-A-NNN-***	M46	M46-046PV
80004590	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-CD-80-S-3-C7-F-03-GBA-42-42-24	SERIES 90	S90-100PV
80004591	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-1-CD-80-S-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-075PV
80004594	MOTOR-VAR-DISPL 51MV250	51V250-V-F2-N-HS-A2-C-H-E1-NNN-050-AA-NN-20-35	SERIES 51	S51-250MV
80004596	PUMP-VAR-DISPL CCW 90PV180	90L180-KP-5-CD-80-T-M-F1-J-03-FAC-26-26-24	SERIES 90	S90-180PV
80004597	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-CD-60-S-4-S1-D-03-EFC-29-29-24	SERIES 90	S90-075PV
80004598	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HF-5-NN-60-S-3-C6-C-00-GBA-42-42-24	SERIES 90	S90-055PV
80004599	PUMP-VAR DISPL, CW 90PV055	90-R-055-DC-5-NN-80-D-N-S1-L-Z1-GBA-29-29-24	SERIES 90	S90-055PV
80004600	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-BG-80-S-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
80004603	PUMP-VAR-DISPL CW 90PV100	90R100-NA-1-NN-80-L-3-C7-E-76-GLA-32-32-26	SERIES 90	S90-100PV
80004605	PUMP-VAR DISPL, CW 90PV055	90-R-055-KN-5-CD-60-S-3-C6-D-03-GBA-29-29-24	SERIES 90	S90-055PV
80004606	PUMP-VAR DISPL, CW 90PV055	90-R-055-KN-5-NN-60-S-3-S1-D-03-GBA-29-29-24	SERIES 90	S90-055PV
80004607	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-CD-80-P-3-C7-F-03-GBA-42-42-24	SERIES 90	S90-100PV
80004608	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-B-HS-A2-B-H-E1-NNN-032-AA-NN-10-25	SERIES 51	S51-160MV
80004609	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-AB-80-P-3-C6-C-03-GBA-42-42-24	SERIES 90	S90-075PV
80004610	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-8-N-0-F1-W-00-NNN-00-00-F0	SERIES 90	S90-100MF
80004612	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-K-T-B-J-AA-A-A-BJJ-CE-A-GG-B-NNN-***	M46	M46-046PV
80004614	MOTOR-VAR DISPL MMV046C	MMV-046-C-A-J-P-H-AA-NNN-***	M46	M46-046MV
80004617	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A9-C1-B-D8-F-G5-H3-L-35-L-35-N-P-24-PN-NNN-E50	H1-MP PUMPS	H1-045PV/053PV
80004618	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-T2-C2-L-N-G0-ADA-035-AA-E6-00-C0	SERIES 51	S51-160MV
80004619	MOTOR-VAR-DISPL 51MD080	51D080-R-D3-N-HS-A2-C-H-C1-NNN-040-AA-NN-15-15	SERIES 51	S51-080MV
80004621	PUMP-VAR-DISPL CW 90PV100	90R100-MA-5-CD-60-S-3-F1-E-C5-GBA-35-35-24	SERIES 90	S90-100PV
80004624	MOTOR-VAR-DISPL 51MD160	51D160-R-D4-N-D8-M1-R-J-M4-ADA-064-AA-F3-C2-27	SERIES 51	S51-160MV
80004625	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-HZ-B1-A-N-G0-ACA-082-AA-G3-03-00	SERIES 51	S51-160MV
80004626	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-NN-60-D-3-S1-L-03-EBC-42-42-20	SERIES 90	S90-075PV
80004627	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-8-N-0-C7-W-00-EFA-00-00-F0	SERIES 90	S90-075MF
80004631	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-BC-80-R-4-S1-E-03-GBA-26-26-20	SERIES 90	S90-100PV
80004633	PUMP-VAR-DISPL CCW H1PV130	H1-P-130-L-B-A2-C2-N-D4-G-G3-NN-L-42-L-42-A-C-34-PN-NNN-G25	H1-HP PUMPS	H1-115PV/130PV
80004634	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-CD-80-L-3-F1-H-00-GBA-32-32-34	SERIES 90	S90-130PV
80004635	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-H-S-B-T-BA-A-B-BJJ-DA-A-ZG-A-NNN-***	M46	M46-046PV
80004636	PUMP-VAR-DISPL CW 90PV075	90R075-KA-P-BC-60-P-3-C7-E-03-FAB-48-48-24	SERIES 90	S90-075PV
80004637	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-H-S-B-T-BA-A-B-BHH-DA-A-ZG-A-NNN-***	M46	M46-046PV

80004638	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-H-S-B-T-BA-A-B-BRR-DA-A-ZG-A-NNN-***	M46	M46-046PV
80004640	PUMP-VAR-DISPL CW 90PV250	90R250-HF-5-EF-80-S-3-C8-K-03-NNN-23-23-24	SERIES 90	S90-250PV
80004641	PUMP-VAR-DISPL CW 90PV250	90R250-HF-5-BC-80-S-4-F1-J-03-NNN-17-17-24	SERIES 90	S90-250PV
80004654	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-1-AB-60-S-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-055PV
80004655	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A3-C2-N-D8-G-G3-H3-L-42-L-42-A-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
80004658	MOTOR-VAR-DISPL 51MV060-1	51V060-1--R-S1-N-E1-B1-N-N-U1-NNN-020-AA-F0-00-00	SERIES 51	S51-060MV-1
80004661	PUMP-VAR DISPL, CCW 90PV055	90-L-055-MA-2-AB-60-P-3-S1-C-03-GBA-45-45-20	SERIES 90	S90-055PV
80004663	MOTOR-VAR-DISPL 51MV250	51V250-V-F2-N-H4-B3-R-J-N2-NNN-080-AA-NN-C2-35	SERIES 51	S51-250MV
80004664	MOTOR-VAR-DISPL 51MV250	51V250-V-F2-B-H4-B3-R-J-N2-NNN-090-AA-NN-C2-22	SERIES 51	S51-250MV
80004665	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-5-BC-60-S-3-C6-D-02-GBA-42-42-24	SERIES 90	S90-055PV
80004669	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-5-AB-60-P-3-C7-D-03-GBA-35-35-24	SERIES 90	S90-075PV
80004670	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-CD-80-S-3-S1-D-04-GBA-35-35-24	SERIES 90	S90-075PV
80004671	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-BC-80-S-3-S1-D-04-GBA-35-35-24	SERIES 90	S90-075PV
80004673	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-BG-80-R-3-S1-D-03-GBA-26-26-24	SERIES 90	S90-055PV
80004677	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D3-N-E2-B1-N-N-U1-NNN-032-AA-F0-00-00	SERIES 51	S51-080MV-1
80004678	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D3-N-E2-B1-N-N-U1-ACB-032-AA-F0-00-00	SERIES 51	S51-080MV-1
80004679	MOTOR-VAR-DISPL 51MC060	51C060-R-D1-N-L2-B1-V-A-C0-NNN-020-AA-E4-B2-00	SERIES 51	S51-060MV
80004682	PUMP-VAR-DISPL CW 90PV075	90R075-MA-5-CD-80-S-3-C7-D-C5-GBA-42-42-24	SERIES 90	S90-075PV
80004683	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-T1-L5-L-N-G0-NNN-100-AA-H0-00-C5	SERIES 51	S51-160MV
80004685	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D3-N-N1-NN-N-N-U1-NNN-016-AA-F0-00-00	SERIES 51	S51-080MV-1
80004686	PUMP-VAR-DISPL CW 90PV075	90R075-FG-5-AB-80-S-7-C7-E-B3-GBA-40-40-24	SERIES 90	S90-075PV
80004687	MOTOR-VAR-DISPL 51MD160	51D160-A-D4-N-L7-B1-W-B-C0-ADA-045-AA-F3-D4-00	SERIES 51	S51-160MV
80004688	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D3-N-B2-B3-N-N-U3-ADA-026-AA-NN-00-00	SERIES 51	S51-080MV-1
80004703	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-N-A4-C2-N-E7-F-G1-H3-38-25-38-38-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
80004712	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-EQ-A2-J-Y-E1-NNN-115-AA-G3-30-28	SERIES 51	S51-250MV
80004713	PUMP-VAR-DISPL CW 90PV100	90R100-FH-5-BB-60-S-7-C7-F-B1-EFI-42-42-30	SERIES 90	S90-100PV
80004714	MOTOR-VAR-DISPL 51MD160	51D160-A-D5-N-N2-NN-N-N-A0-NNN-076-AA-E6-00-00	SERIES 51	S51-160MV
80004717	MOTOR-VAR-DISPL 51MD160	51D160-R-D5-A-HS-A2-C-H-E1-NNN-076-AA-NN-15-18	SERIES 51	S51-160MV
80004722	MOTOR-VAR-DISPL 51MV250	51V250-U-F2-B-H4-B3-R-J-N2-NNN-090-AA-NN-C2-22	SERIES 51	S51-250MV
80004723	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-CD-80-S-3-C7-F-04-GBA-35-35-24	SERIES 90	S90-100PV
80004724	MOTOR-VAR-DISPL 51MV060-1	51V060-1--A-D2-N-E2-B1-N-N-U1-ACB-036-AA-F0-00-00	SERIES 51	S51-060MV-1
80004725	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-5-NN-80-D-3-S1-L-05-GBA-42-42-24	SERIES 90	S90-055PV
80004726	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-N-HZ-B1-C-H-G5-NNN-032-AA-F3-12-00	SERIES 51	S51-160MV
80004727	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-AB-61-P-3-T2-D-03-GBA-42-42-24	SERIES 90	S90-100PV
80004728	PUMP-VAR DISPL, CW 90PV055	90-R-055-KN-5-CD-80-P-3-C6-D-04-GBA-29-29-24	SERIES 90	S90-055PV
80004729	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-E1-A2-A-N-A7-NNN-050-AA-F0-03-25	SERIES 51	S51-160MV

80004730	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-5-CD-80-R-3-F1-F-29-GBA-38-38-24	SERIES 90	S90-100PV
80004731	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-5-CD-80-R-3-F1-F-29-GBA-38-38-34	SERIES 90	S90-100PV
80004732	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-AB-80-R-3-F1-H-03-GBA-32-32-24	SERIES 90	S90-130PV
80004733	PUMP-VAR-DISPL CW 90PV042	90R042-HF-5-AB-80-S-3-C3-C-03-GBA-17-17-18	SERIES 90	S90-042PV
80004734	PUMP-VAR-DISPL CCW 90PV042	90L042-KA-5-BB-80-S-4-C3-C-09-GBA-30-30-30	SERIES 90	S90-042PV
80004735	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D2-N-N1-NN-N-N-U1-ABA-050-AA-E6-00-00	SERIES 51	S51-080MV-1
80004737	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KN-1-CD-80-R-4-F1-E-03-GBA-42-14-24	SERIES 90	S90-100PV
80004738	PUMP-VAR-DISPL CCW 90PV042	90L042-KA-5-NN-80-S-4-C3-C-09-GBA-30-30-30	SERIES 90	S90-042PV
80004740	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-8-N-0-C6-W-00-NNN-00-00-F0	SERIES 90	S90-100MF
80004741	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-AB-60-R-4-C7-E-03-GBA-29-29-24	SERIES 90	S90-100PV
80004742	MOTOR-VAR-DISPL 51MV250	51V250-U-F2-E-H4-B3-R-J-N2-NNN-090-AA-NN-C2-22	SERIES 51	S51-250MV
80004743	MOTOR-VAR-DISPL 51MV250	51V250-V-F2-E-H4-B3-R-J-N2-NNN-055-AA-NN-C2-23	SERIES 51	S51-250MV
80004744	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-BC-80-L-4-S1-F-03-EBC-29-29-24	SERIES 90	S90-100PV
80004745	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-A-T-B-B-BA-G-A-BFF-CG-A-HH-C-NNN-***	M46	M46-046PV
80004746	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-G-S-B-B-AA-J-A-BFF-CD-A-RR-C-NNN-***	M46	M46-046PV
80004747	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-NN-80-S-4-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
80004749	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HS-1-CD-80-P-4-S1-D-02-GBA-42-42-24	SERIES 90	S90-075PV
80004751	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-G-S-B-B-AA-A-A-BFF-CD-A-RR-C-NNN-***	M46	M46-046PV
80004752	MOTOR-VAR-DISPL 51MD080-1	51D080-1--R-D2-N-P7-P7-N-N-X1-AWM-022-AA-E6-00-AA	SERIES 51	S51-080MV-1
80004753	MOTOR-VAR-DISPL 51MD080-1	51D080-1--R-D2-N-P7-P7-N-N-X1-NNN-022-AA-E6-00-AA	SERIES 51	S51-080MV-1
80004754	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-CD-80-S-3-F1-E-03-GBA-20-20-24	SERIES 90	S90-100PV
80004755	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-NN-80-S-3-S1-E-03-GBA-20-20-24	SERIES 90	S90-100PV
80004756	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-CD-80-P-3-C6-E-03-GBA-45-45-24	SERIES 90	S90-100PV
80004757	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-AB-60-S-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-075PV
80004758	MOTOR-VAR-DISPL 51MD110-1	51D110-1--A-D3-N-T2-D2-N-N-X1-ADA-040-AA-F0-00-20	SERIES 51	S51-110MV-1
80004759	PUMP-VAR-DISPL CW 90PV130	90R130-HF-5-NN-80-S-4-F1-H-03-GBA-35-35-24	SERIES 90	S90-130PV
80004760	PUMP-VAR-DISPL CCW 90PV130	90L130-KN-5-BC-80-R-4-F1-F-03-GBA-42-14-24	SERIES 90	S90-130PV
80004762	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-5-CD-60-R-3-C6-D-C5-GBA-35-35-24	SERIES 90	S90-055PV
80004763	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-5-CD-60-R-3-S1-D-C5-GBA-35-35-24	SERIES 90	S90-055PV
80004764	PUMP-VAR DISPL, CW 90PV055	90-R-055-HF-5-CD-80-R-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
80004765	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-NN-80-L-3-F1-F-03-GBA-26-26-24	SERIES 90	S90-130PV
80004770	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-NN-80-S-3-T2-E-03-GBA-42-42-24	SERIES 90	S90-100PV
80004771	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-C-T3-R5-L-N-C0-FCB-068-AA-F0-00-C0	SERIES 51	S51-250MV
80004772	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-D-HS-A2-B-H-G6-NNN-055-AA-NN-05-20	SERIES 51	S51-250MV
80004774	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-N-HS-A2-B-H-G6-NNN-055-AA-NN-05-20	SERIES 51	S51-160MV
80004775	PUMP-VAR-DISPL CCW H1PV165	H1-P-165-L-C-A5-C2-N-D6-G-G2-H5-L-43-L-43-L-L-30-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV

80004776	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A9-C1-N-E6-F-G5-NN-L-30-L-30-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
80004777	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-C-T3-R5-L-N-C0-FCB-068-AA-E6-00-CO	SERIES 51	S51-250MV
80004778	PUMP, VARIABLE DIRECT DISPLACMENT	LPV-C-A-A-A-A-G-AC-C-A-BDD-DL-A-FF-B-NNN-***	LPV	LPV
80004779	MOTOR-VAR-DISPL 51MD160	51D160-A-D4-N-DC-M6-S-K-M4-NNN-050-AA-G0-F4-26	SERIES 51	S51-160MV
80004780	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-AB-80-S-C-C8-H-03-NNN-35-35-28	SERIES 90	S90-180PV
80004781	MOTOR-VAR-DISPL 51MD060-1	51D060-1--R-D2-N-E2-B1-N-N-U1-NNN-030-AA-E4-00-00	SERIES 51	S51-060MV-1
80004783	MOTOR-FIX DISPL MMF035D	MMF-035-D-A-S-G-A-S-NNR-***	M35/44	035MF
80004784	MOTOR-VAR-DISPL 51MV110	51V110-R-C8-N-HS-A2-B-E-E1-NNN-022-AA-NN-05-20	SERIES 51	S51-110MV
80004785	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-NN-80-P-4-C3-C-03-GBA-26-26-24	SERIES 90	S90-042PV
80004788	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MA-1-NN-80-L-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
80004790	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-1-BC-60-S-3-S1-D-03-GBA-32-32-24	SERIES 90	S90-075PV
80004793	MOTOR-VAR-DISPL 51MV110	51V110-R-C8-N-J2-K1-D-E-H4-NNN-035-AA-E6-20-22	SERIES 51	S51-110MV
80004797	PUMP-VAR-DISPL CW 90PV130	90R130-KN-5-NN-80-R-3-C8-H-00-GBA-38-38-24	SERIES 90	S90-130PV
80004798	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-E2-A5-A-N-A6-NNN-045-AA-G3-03-00	SERIES 51	S51-160MV
80004799	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-TA-C0-L-N-G0-NNN-115-AA-NN-00-B0	SERIES 51	S51-160MV
80004801	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-E1-B1-N-N-U1-NNN-037-AA-E6-00-00	SERIES 51	S51-110MV-1
80004803	MOTOR-VAR-DISPL 51MD080	51D080-A-D3-N-J1-K1-D-E-H4-NNN-025-AA-F3-20-24	SERIES 51	S51-080MV
80004805	MOTOR-VAR-DISPL 51MD110-1	51D110-1--A-D3-N-P7-P7-N-N-X1-NNN-041-AA-F0-00-AA	SERIES 51	S51-110MV-1
80004806	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-5-NN-80-S-3-C6-C-03-GBA-23-23-24	SERIES 90	S90-055PV
80004807	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-CD-80-L-4-C8-H-03-GBA-42-42-24	SERIES 90	S90-130PV
80004809	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-HS-A2-B-H-G6-NNN-080-AA-NN-05-23	SERIES 51	S51-160MV
80004810	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-A-Z-C-B-AA-B-A-A-BJJ-AB-U-BB-B-C-A-A-BJJ-AB-U-BB-C-NNN-***	M46	M46-046PT
80004814	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KT-2-BB-80-P-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
80004816	MOTOR-VAR DISPL MMV046C	MMV-046-C-A-E-N-C-AU-NNN-***	M46	M46-046MV
80004817	PUMP-VAR DISPL CCW H1P053L	H1-P-053-L-A-A4-C2-N-E9-F-G5-NN-K-35-K-35-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
80004818	PUMP-TANDEM, VAR DISPL CCW H1T053L	H1-T-053-L-A-N-A4-C2-N-E7-F-G1-H3-35-35-35-35-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
80004819	PUMP-VAR-DISPL CCW H1PV078	H1-P-078-L-A-A2-C2-N-D6-H-G1-NN-L-40-L-40-F-L-20-PN-C08-NNN	H1-HP PUMPS	H1-069PV/078PV
80004820	MOTOR-FIX DISPL MMF044D	MMF-044-D-A-A-W-A-B-NNN-***	M35/44	044MF
80004822	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-AB-80-R-4-F1-H-03-EEB-32-32-24	SERIES 90	S90-130PV
80004823	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-TA-C2-N-N-X1-NNN-042-AA-F0-00-24	SERIES 51	S51-110MV-1
80004832	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A8-C2-C-D6-H-F1-NN-L-40-L-40-C-L-24-P1-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
80004842	PUMP-VAR-DISPL CW 90PV130	90R130-KN-5-NN-80-R-3-C8-H-00-GBA-42-42-24	SERIES 90	S90-130PV
80004863	MOTOR-VAR-DISPL 51MV110	51V110-R-F1-N-N2-NN-N-N-A0-NNN-022-AA-F0-00-00	SERIES 51	S51-110MV
80004864	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-NN-80-P-3-S1-D-03-GBA-26-26-24	SERIES 90	S90-075PV
80004865	PUMP-VAR-DISPL CW 90PV075	90R075-KA-P-BC-80-P-3-C7-E-03-FAB-48-48-24	SERIES 90	S90-075PV
80004866	MOTOR-VAR-DISPL 51MD110-1	51D110-1--R-D3-N-E2-B1-N-N-U1-NNN-050-AA-F3-00-00	SERIES 51	S51-110MV-1

80004867	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-8-N-0-C6-W-00-EFA-00-00-E6	SERIES 90	S90-055MF
80004868	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-AB-80-D-3-F1-L-03-GBA-42-42-24	SERIES 90	S90-100PV
80004869	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-A-Z-C-K-AA-B-B-A-A-BGG-BB-A-HH-B-D-A-A-BGG-BB-A-HH-D-NNN-	M46	M46-046PT
80004870	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A8-C2-C-F5-H-G9-H6-K-42-K-42-C-P-24-P1-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
80004871	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-AB-80-S-S-F6-F-04-GBA-42-42-24	SERIES 90	S90-130PV
80004874	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-B8-C2-C-D8-G-G2-H6-L-42-L-42-N-E-30-P1-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
80004875	MOTOR-FIX DISPL MMF044D	MMF-044-D-A-6-M-A-B-NNR-***	M35/44	O44MF
80004876	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A2-C2-N-D8-H-G1-H3-L-30-L-25-C-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
80004879	PUMP-VAR-DISPL CW 90PV130	90R130-FG-5-NN-80-S-7-C8-H-B1-GBA-42-42-30	SERIES 90	S90-130PV
80004880	PUMP-VAR-DISPL CW 90PV130	90R130-PB-5-AB-80-R-3-F1-H-00-GBA-35-14-24	SERIES 90	S90-130PV
80004882	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-BC-80-R-3-F1-F-03-GBA-38-38-24	SERIES 90	S90-130PV
80004883	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-EQ-A5-J-Y-G5-ACA-125-AA-G3-30-00	SERIES 51	S51-250MV
80004884	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-5-NN-80-S-3-S1-B-C5-GBA-42-42-24	SERIES 90	S90-055PV
80004885	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-NN-80-P-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
80004886	PUMP-VAR-DISPL CW 90PV250	90R250-KA-2-CD-80-T-4-C8-J-03-NNN-26-26-28	SERIES 90	S90-250PV
80004887	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-T2-C2-L-N-G0-NNN-050-AA-F0-00-C7	SERIES 51	S51-250MV
80004888	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-T2-C2-L-N-G0-NNN-050-AA-F0-00-C7	SERIES 51	S51-160MV
80004889	PUMP-VAR-DISPL CW 90PV075	90R075-FM-P-AB-80-S-7-S1-E-B6-ELA-45-45-30	SERIES 90	S90-075PV
80004899	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-D-S-B-J-BA-A-A-BJJ-BC-A-HH-B-NNN-***	M46	M46-046PV
80004900	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-8-N-0-C7-W-00-EEA-00-00-G0	SERIES 90	S90-100MF
80004901	MOTOR-VAR-DISPL 51MD060-1	51D060-1--A-D1-N-P7-P7-N-N-X1-NNN-026-AA-F0-00-AA	SERIES 51	S51-060MV-1
80004902	MOTOR-VAR DISPL MMV046C	MMV-046-C-A-E-N-C-AU-VNC-***	M46	M46-046MV
80004904	MOTOR-VAR-DISPL 51MC080	51C080-R-D3-N-N2-NN-N-N-A0-NNN-050-AA-NN-00-00	SERIES 51	S51-080MV
80004905	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-BC-80-L-4-F1-H-03-GBA-38-38-24	SERIES 90	S90-130PV
80004906	PUMP-VAR-DISPL CCW 90PV075	90L075-DD-5-NN-80-P-4-C7-D-GB-GBA-30-30-24	SERIES 90	S90-075PV
80004907	PUMP-VAR-DISPL CW 90PV180	90R180-CA-5-AB-80-S-7-C8-H-00-NNN-40-40-24	SERIES 90	S90-180PV
80004910	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-2-BC-60-S-4-C6-C-03-GBA-17-17-20-F066	SERIES 90	S90-055PV
80004913	MOTOR-VAR-DISPL 51MD060-1	51D060-1--A-D2-N-N1-NN-N-N-U1-NNN-040-AA-NN-00-00	SERIES 51	S51-060MV-1
80004916	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-2-NN-80-R-4-S1-C-03-GBA-26-26-28	SERIES 90	S90-055PV
80004918	PUMP-VAR DISPL, CW 90PV055	90-R-055-FA-5-NN-60-S-7-C6-D-B1-GBA-42-42-24	SERIES 90	S90-055PV
80004919	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-BC-60-L-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
80004920	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-5-NN-80-S-3-C8-K-03-NNN-32-32-24	SERIES 90	S90-250PV
80004921	PUMP-VAR-DISPL CCW 90PV180	90L180-FH-5-NN-80-T-7-C8-J-B9-EFI-42-42-30	SERIES 90	S90-180PV
80004922	PUMP-VAR-DISPL CCW H1PV165	H1-P-165-L-C-A5-C2-N-D3-G-G2-H3-L-35-L-35-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
80004923	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-TN-F8-L-N-J2-ADA-120-AA-F3-00-BB	SERIES 51	S51-250MV
80004924	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A2-C3-N-D9-G-G3-H4-L-45-L-45-L-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV

80004925	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A2-C3-N-D6-G-G3-H5-L-45-L-45-L-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
80004927	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-5-CD-80-P-3-S1-C-03-GBA-38-38-20	SERIES 90	S90-055PV
80004928	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-5-NN-80-P-3-S1-C-03-GBA-38-38-20	SERIES 90	S90-055PV
80004929	MOTOR-VAR-DISPL 51MD160	51D160-A-D4-N-TA-C2-L-N-G0-ACA-085-AA-F0-00-C4	SERIES 51	S51-160MV
80004931	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HS-1-CD-60-P-3-F1-E-03-GBA-32-32-24	SERIES 90	S90-100PV
80004932	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A2-C2-B-E8-G-G3-H3-L-42-L-42-L-L-24-PN-NNN-G14	H1-HP PUMPS	H1-147PV/165PV
80004933	PUMP-VAR-DISPL CW 90PV100	90R100-DD-5-NN-80-S-3-G1-F-G1-FAD-35-35-30	SERIES 90	S90-100PV
80004935	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-BB-80-L-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
80004936	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-AB-60-R-3-C7-E-00-GBA-42-42-24	SERIES 90	S90-075PV
80004938	MOTOR-VAR DISPL MMV046C	MMV-046-C-A-E-H-E-AU-VNC-***	M46	M46-046MV
80004940	MOTOR-VAR-DISPL 51MD110-1	51D110-1--R-D3-N-T2-D2-N-N-X1-NNN-032-AA-F3-00-25	SERIES 51	S51-110MV-1
80004941	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-NN-80-L-3-C8-F-03-GBA-42-42-24	SERIES 90	S90-130PV
80004946	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HS-1-CD-60-P-3-S1-C-03-GBA-32-32-24	SERIES 90	S90-055PV
80004947	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-CD-80-P-3-C7-D-02-GBA-26-26-24	SERIES 90	S90-075PV
80004949	MOTOR-VAR-DISPL 51MD160	51D160-R-D5-N-N2-NN-N-N-A0-NNN-107-AA-NN-00-00	SERIES 51	S51-160MV
80004951	PUMP-VAR-DISPL CW 90PV180	90R180-PB-5-BC-80-T-C-F1-J-06-NNN-42-42-28	SERIES 90	S90-180PV
80004953	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-HZ-B1-A-N-G0-ABA-168-AA-G0-03-00	SERIES 51	S51-250MV
80004959	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-HZ-B1-A-N-G0-ABA-107-AA-F0-03-00	SERIES 51	S51-160MV
80004960	MOTOR-VAR-DISPL 51MD080-1	51D080-1--A-D2-N-T1-D1-N-N-X1-NNN-020-AA-NN-00-23	SERIES 51	S51-080MV-1
80004961	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-N-B2-B3-N-N-U3-ADA-017-AA-F3-00-00	SERIES 51	S51-060MV-1
80004962	MOTOR-VAR-DISPL 51MV250	51V250-A-C8-N-DA-M4-R-J-N1-ADA-095-AA-H0-C2-29	SERIES 51	S51-250MV
80004963	MOTOR-VAR-DISPL 51MD080	51D080-A-D2-N-Y7-B1-S-L-J1-NNN-030-AA-F0-F4-00	SERIES 51	S51-080MV
80004964	MOTOR-VAR-DISPL 51MV250	51V250-A-C8-N-Y3-B1-S-K-J1-NNN-050-AA-G0-F4-00	SERIES 51	S51-250MV
80004968	PUMP-VAR DISPL, CW 90PV075	90-R-075-DD-1-NN-80-S-4-S1-E-GB-FAD-42-42-24	SERIES 90	S90-075PV
80004972	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-BC-80-P-3-C7-D-02-GBA-26-26-24	SERIES 90	S90-075PV
80004973	PUMP-VAR DISPL, CW 90PV055	90-R-055-MB-1-NN-80-R-3-C6-L-03-GBA-42-42-24	SERIES 90	S90-055PV
80004974	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-5-CD-80-L-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-075PV
80004977	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-DA-M4-R-J-N1-ADA-082-AA-G3-C2-29	SERIES 51	S51-250MV
80004980	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KN-1-AB-80-R-3-S1-E-03-GBA-29-29-24	SERIES 90	S90-075PV
80004981	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-N-T2-N5-N-N-X1-AWH-020-AA-E4-00-27	SERIES 51	S51-060MV-1
80004982	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-BC-80-S-3-S1-D-03-GBA-23-23-24	SERIES 90	S90-075PV
80004985	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-CD-60-S-3-T2-D-00-GBA-26-26-24	SERIES 90	S90-075PV
80004986	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-BC-60-S-3-S1-E-00-GBA-26-26-24	SERIES 90	S90-075PV
80004988	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D3-N-E2-B1-N-N-U1-ACB-032-AA-E6-00-00	SERIES 51	S51-080MV-1
80004989	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-AB-60-P-3-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV
80004991	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-HZ-B1-C-N-C2-NNN-168-AA-G0-25-00	SERIES 51	S51-250MV

80004993	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-NN-80-R-3-S1-D-03-FAP-45-45-24	SERIES 90	S90-055PV
80004995	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-NN-80-S-4-C8-H-00-GBA-37-37-24	SERIES 90	S90-130PV
80004997	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-P-BB-80-S-3-C7-E-03-GBA-48-48-24	SERIES 90	S90-100PV
80004998	PUMP-VAR-DISPL CW 90PV075	90R075-FK-P-NN-60-S-7-C7-E-B6-GME-48-48-30	SERIES 90	S90-075PV
80005002	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-HZ-B1-B-E-G5-NNN-052-AA-NN-06-00	SERIES 51	S51-160MV
80005003	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-1-NN-80-S-4-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
80005004	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-CD-80-S-3-F1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
80005005	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-1-CD-80-S-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-075PV
80005006	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-CD-80-P-3-C7-E-00-GBA-35-35-24	SERIES 90	S90-100PV
80005008	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-CD-80-P-3-F1-E-00-GBA-38-38-24	SERIES 90	S90-100PV
80005009	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-CD-80-P-3-S1-E-00-GBA-38-38-24	SERIES 90	S90-100PV
80005010	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-NN-80-P-3-S1-D-00-GBA-42-42-24	SERIES 90	S90-075PV
80005011	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A4-C3-N-E8-G-G2-H3-L-45-L-45-L-L-30-PN-NNN-G25	H1-HP PUMPS	H1-147PV/165PV
80005013	PUMP-VAR-DISPL CW 90PV075	90R075-CB-5-NN-60-S-4-C7-E-00-GBA-40-40-30	SERIES 90	S90-075PV
80005016	MOTOR-VAR-DISPL 51MD160	51D160-R-D4-N-TA-C2-L-N-G0-NNN-104-AA-F3-00-A3	SERIES 51	S51-160MV
80005018	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-1-NN-60-S-3-S1-C-03-GBA-20-20-24	SERIES 90	S90-055PV
80005019	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-NN-80-P-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
80005022	PUMP-VAR-DISPL CW 90PV180	90R180-KN-5-NN-80-S-C-C8-J-03-NNN-32-32-24	SERIES 90	S90-180PV
80005023	MOTOR-VAR-DISPL 51MD160	51D160-A-D4-N-T2-C0-L-N-G0-NNN-055-AA-F0-00-B0	SERIES 51	S51-160MV
80005024	PUMP-VAR-DISPL CW 90PV100	90R100-DD-5-NN-60-S-4-C7-E-G1-GBA-40-40-24	SERIES 90	S90-100PV
80005025	MOTOR-VAR-DISPL 51MV080	51V080-R-C7-N-L7-B1-W-B-J1-NNN-041-AA-G0-D4-00	SERIES 51	S51-080MV
80005026	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-K-S-B-T-AA-W-B-BJJ-DA-A-ZG-B-NNN-***	M46	M46-046PV
80005027	PUMP-VAR-DISPL CCW 90PV100	90L100-FD-5-NN-80-P-7-C7-E-B1-GBA-26-26-30	SERIES 90	S90-100PV
80005029	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-B-N2-NN-N-N-A0-NNN-100-AA-NN-00-00	SERIES 51	S51-250MV
80005032	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-NN-80-S-4-C8-H-03-GBA-42-42-24	SERIES 90	S90-130PV
80005037	PUMP-VAR DISPL MPV035D	MPV-035-D-B-A-A-R-S-F-AA-A-A-BHH-DR-A-FF-A-NNN-***	M35/44	035PV
80005038	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-N-L2-B1-V-A-G5-ACA-089-AA-F3-B2-00	SERIES 51	S51-160MV
80005039	MOTOR-VAR-DISPL 51MC110	51C110-R-D3-N-L2-B1-V-A-G5-ACB-028-AA-E6-B2-00	SERIES 51	S51-110MV
80005040	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-CD-80-P-4-C6-C-01-GBA-38-38-24	SERIES 90	S90-055PV
80005041	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-BG-80-P-4-S1-C-01-GBA-38-38-24	SERIES 90	S90-055PV
80005042	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-1-AD-80-L-4-S1-C-00-GBA-23-23-24	SERIES 90	S90-055PV
80005043	MOTOR-VAR-DISPL 51MD160	51D160-A-D4-N-N2-NN-N-N-A0-NNN-045-AA-F0-00-00	SERIES 51	S51-160MV
80005054	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A3-C2-N-D8-F-G5-H2-L-25-L-25-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
80005055	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A3-C2-N-D8-F-G1-H5-L-35-L-35-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
80005056	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A3-C2-N-D8-F-G5-H2-L-35-L-35-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
80005062	PUMP-VAR DISPL CCW H1P053L	H1-P-053-L-A-A3-C2-N-D8-F-G1-H5-L-35-L-35-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV

80005063	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-E1-B1-N-N-U1-ADA-052-AA-F0-00-00	SERIES 51	S51-110MV-1
80005064	PUMP-VAR-DISPL CW 90PV075	90R075-DD-5-BC-80-L-4-S1-E-GB-GBA-35-35-24	SERIES 90	S90-075PV
80005076	PUMP-VAR-DISPL CW 90PV130	90R130-KN-5-AB-80-L-4-F1-F-03-GBA-42-42-24	SERIES 90	S90-130PV
80005078	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-NN-80-S-M-F1-H-03-FAC-32-32-24	SERIES 90	S90-180PV
80005082	MOTOR-FIX DISPL MMF035D	MMF-035-D-A-A-G-C-P-NNN-***	M35/44	035MF
80005094	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-TA-CA-N-N-X1-NNN-057-AA-E6-00-13	SERIES 51	S51-110MV-1
80005095	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-BC-80-S-4-C8-K-04-NNN-38-38-24	SERIES 90	S90-250PV
80005097	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-1-BB-60-R-3-C6-D-03-GBA-26-26-24	SERIES 90	S90-055PV
80005101	MOTOR-VAR-DISPL 51MD160	51D160-A-D4-N-HZ-B1-B-H-C2-ACA-085-AA-F0-06-00	SERIES 51	S51-160MV
80005102	PUMP-VAR DISPL, CW 90PV075	90-R-075-LE-1-CD-80-L-4-C7-E-05-GBA-42-42-28-F022	SERIES 90	S90-075PV
80005103	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-BC-80-L-4-S1-E-05-GBA-42-42-28-F022	SERIES 90	S90-075PV
80005104	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-BG-80-R-4-K1-C-03-GBA-26-23-24	SERIES 90	S90-055PV
80005105	PUMP-VAR DISPL MPV046C	MPV-046-C-B-A-A-S-B-B-AA-A-A-BDD-AB-D-BF-C-NNN-***	M46	M46-046PV
80005108	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-AB-80-R-3-S1-F-03-FAX-45-45-28	SERIES 90	S90-100PV
80005109	MOTOR-VAR-DISPL 51MV250	51V250-A-C8-N-L2-B1-V-A-C0-NNN-125-AA-G0-B2-00	SERIES 51	S51-250MV
80005111	PUMP-VAR DISPL, CW 90PV055	90-R-055-FC-5-BC-60-S-7-C6-C-B1-GBA-42-42-30	SERIES 90	S90-055PV
80005114	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-CD-80-P-3-C7-E-03-EAB-42-42-24-N315	SERIES 90	S90-100PV
80005115	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-NN-80-P-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
80005116	PUMP-VAR-DISPL CW 90PV075	90R075-FL-5-CD-60-S-7-C7-D-B6-GME-42-42-30	SERIES 90	S90-075PV
80005119	MOTOR-VARIABLE CARTRIDGE K	K-C-38CN-A-R3F-F11-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
80005121	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-N-E2-A5-A-N-G0-NNN-120-AA-NN-03-00	SERIES 51	S51-250MV
80005123	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A2-C3-B-F1-F-G5-H2-K-35-K-35-B-L-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
80005125	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-NN-80-P-4-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
80005128	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A4-C1-N-E7-F-G5-H3-33-33-33-33-N-P-30-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
80005129	PUMP-VAR-DISPL CCW 90PV042	90L042-KA-5-BB-80-S-4-C5-C-03-GBA-42-42-24	SERIES 90	S90-042PV
80005130	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-1-NN-60-P-3-S1-D-03-GBA-23-23-20	SERIES 90	S90-075PV
80005131	PUMP-VAR DISPL MPV046C	MPV-046-C-B-A-J-S-B-B-AA-A-A-BJJ-AB-D-ED-A-NNN-***	M46	M46-046PV
80005132	MOTOR-VAR-DISPL 51MV080	51V080-A-S1-N-HZ-B1-B-E-C2-NNN-032-AA-E6-05-00	SERIES 51	S51-080MV
80005133	PUMP-VAR-DISPL CCW 90PV075	90L075-MA-5-BC-60-S-3-C7-E-C5-GBA-42-42-24	SERIES 90	S90-075PV
80005134	PUMP-VAR-DISPL CW 90PV075	90R075-DC-5-CD-80-P-3-C7-C-GB-GBA-42-42-24	SERIES 90	S90-075PV
80005135	PUMP-VAR DISPL, CW 90PV055	90-R-055-HS-5-NN-80-P-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
80005136	PUMP-VAR DISPL, CW 90PV055	90-R-055-HS-5-CD-80-P-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
80005137	MOTOR-VAR-DISPL 51MD060-1	51D060-1--R-D2-N-T2-C2-N-N-X1-NNN-030-AA-NN-00-24	SERIES 51	S51-060MV-1
80005138	MOTOR-VAR-DISPL 51MD080-1	51D080-1--A-D2-N-T1-CA-N-N-X1-NNN-030-AA-E6-00-30	SERIES 51	S51-080MV-1
80005139	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-CD-80-P-3-C7-F-00-GBA-35-35-24	SERIES 90	S90-100PV
80005142	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KT-2-AB-60-R-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV

80005143	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KT-2-CD-60-R-4-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
80005144	MOTOR-VAR-DISPL 51MC110-1	51C110-1--R-D3-N-N1-NN-N-N-U1-NNN-052-AA-NN-00-00	SERIES 51	S51-110MV-1
80005145	MOTOR-VAR-DISPL 51MD110	51D110-A-D3-N-D7-M1-S-K-M4-ADA-038-AA-F0-F4-31	SERIES 51	S51-110MV
80005146	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-BC-80-S-C-C8-J-09-FAC-35-35-28	SERIES 90	S90-180PV
80005147	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-EG-80-S-C-C8-J-09-FAC-35-35-28	SERIES 90	S90-180PV
80005148	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-E2-A2-A-N-E1-NNN-070-AA-F3-03-25	SERIES 51	S51-160MV
80005149	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-BB-60-R-3-C7-F-03-GBA-26-26-24	SERIES 90	S90-100PV
80005151	PUMP-VAR-DISPL CW 90PV042	90R042-FD-5-AB-80-S-7-C3-C-B1-EFC-38-38-30	SERIES 90	S90-042PV
80005152	PUMP-VAR-DISPL CCW 90PV100	90L100-DD-5-CD-60-S-3-C7-E-GB-GBA-35-35-30	SERIES 90	S90-100PV
80005153	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-NN-80-R-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-055PV
80005154	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-NN-80-S-3-S1-C-00-GBA-32-32-20	SERIES 90	S90-055PV
80005155	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A4-C2-N-E7-F-G1-H5-38-38-38-38-N-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
80005156	MOTOR-VAR-DISPL 51MD080-1	51D080-1--A-D2-N-P8-P8-N-N-X1-NNN-040-AA-F0-00-AA	SERIES 51	S51-080MV-1
80005157	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A5-C2-N-D3-G-G3-H3-L-42-L-42-L-M-30-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
80005158	PUMP-VAR-DISPL CCW H1PV165	H1-P-165-L-C-A3-C2-N-D3-G-G3-NN-L-42-L-42-L-M-30-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
80005159	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-TA-C2-L-N-G0-ACA-135-AA-G3-00-B4	SERIES 51	S51-250MV
80005160	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A2-C2-B-F1-F-G5-H2-K-35-K-35-B-L-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
80005161	MOTOR-VAR-DISPL 51MD110-1	51D110-1--R-D4-N-T2-D2-N-N-X1-NNN-022-AA-E6-00-19	SERIES 51	S51-110MV-1
80005163	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A2-C2-N-D8-F-G5-H3-L-30-L-30-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
80005165	MOTOR-VAR-DISPL 51MV250	51V250-A-C8-N-HZ-B1-C-N-C2-NNN-168-AA-F3-25-00	SERIES 51	S51-250MV
80005166	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-N-L2-B1-V-A-C0-ABA-050-AA-G0-B2-00	SERIES 51	S51-250MV
80005170	PUMP, VARIABLE DIRECT DISPLACMENT	LPV-B-A-A-B-A-G-AA-C-A-BFF-DR-A-FF-B-NNN-***	LPV	LPV
80005171	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-NN-60-P-3-S1-C-03-GBA-45-45-24	SERIES 90	S90-055PV
80005172	MOTOR-VAR DISPL MMV046C	MMV-046-C-A-E-C-F-AA-NNN-***	M46	M46-046MV
80005173	PUMP-VAR DISPL, CCW 90PV055	90-L-055-MA-1-BG-80-R-3-S1-C-02-GBA-38-38-24	SERIES 90	S90-055PV
80005174	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-2-NN-80-S-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
80005175	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-CD-80-R-3-C7-E-03-GBA-38-38-24	SERIES 90	S90-075PV
80005176	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HF-1-NN-80-R-3-S1-D-03-GBA-38-38-24	SERIES 90	S90-055PV
80005183	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-5-BC-80-L-3-S1-E-03-GBA-14-14-24	SERIES 90	S90-075PV
80005189	PUMP-VAR DISPL, CW 90PV075	90-R-075-MB-1-CD-60-S-3-C7-D-04-GBA-42-42-24	SERIES 90	S90-075PV
80005190	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-5-BC-60-R-3-S1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
80005191	MOTOR-VAR-DISPL 51MV110	51V110-R-F1-N-HZ-B1-B-E-G5-NNN-052-AA-NN-06-00	SERIES 51	S51-110MV
80005192	PUMP, VARIABLE DIRECT DISPLACMENT	LPV-B-A-A-C-A-G-AA-C-A-BFF-DR-A-FF-B-NNN-***	LPV	LPV
80005194	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-CD-80-R-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
80005195	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-CD-80-R-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-075PV
80005199	PUMP-VAR-DISPL CCW 90PV180	90L180-MB-5-NN-80-T-C-F1-J-C5-FAC-38-38-28	SERIES 90	S90-180PV

80005200	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A5-C2-N-D6-G-G3-H3-L-38-L-38-L-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
80005201	PUMP-TANDEM, VAR DISPL MPT044D	MPT-044-D-A-W-S-J-BA-B-A-A-A-BDD-DR-A-FF-B-C-A-A-BDD-DL-A-FF-D-NNN-*	M35/44	044PT
80005202	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A5-C2-B-D6-F-G1-H3-L-42-L-42-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
80005203	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A5-C2-B-D6-F-G1-H3-L-30-L-30-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
80005204	PUMP-VAR DISPL MPV025C	MPV-025-C-B-A-A-R-A-F-NN-A-A-BFF-DL-A-FF-D-NNN-***	LIGHT DUTY	025PV
80005205	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-N-T-B-B-AA-A-A-BHJ-CE-A-GG-C-NNN-***	M46	M46-046PV
80005207	PUMP-VAR DISPL, CW 90PV075	90-R-075-M8-1-BC-80-S-3-C6-E-03-GBA-42-42-24	SERIES 90	S90-075PV
80005210	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-NN-60-P-3-T2-E-00-GBA-32-32-24	SERIES 90	S90-100PV
80005211	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-5-AD-80-P-3-S1-C-04-GBA-13-35-24	SERIES 90	S90-055PV
80005212	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-2-BG-80-R-3-S1-C-03-GBA-23-23-20	SERIES 90	S90-055PV
80005214	PUMP-VAR DISPL, CW 90PV075	90-R-075-HS-1-CD-80-S-3-C7-E-03-GBA-29-29-24	SERIES 90	S90-075PV
80005215	PUMP-VAR-DISPL CW 90PV100	90R100-HF-5-BC-60-P-4-C7-E-03-GBA-38-38-24	SERIES 90	S90-100PV
80005220	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-1-AD-80-R-3-S1-C-03-GBA-29-29-24	SERIES 90	S90-055PV
80005222	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HF-5-NN-60-P-3-T1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
80005224	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MB-1-CD-60-S-3-C6-D-03-GBA-32-32-24	SERIES 90	S90-075PV
80005236	MOTOR-VAR-DISPL 51MV060	51V060-R-C6-N-JA-NN-B-E-M4-ADA-023-AA-F0-07-20	SERIES 51	S51-060MV
80005237	PUMP-VAR-DISPL CW 90PV100	90R100-MA-1-AB-60-S-7-C7-E-03-FAB-38-38-24	SERIES 90	S90-100PV
80005240	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-A-T-B-B-BA-A-A-BJJ-CB-A-JJ-C-NNN-***	M46	M46-046PV
80005243	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-BC-80-S-3-TK-H-03-GBA-42-42-24	SERIES 90	S90-130PV
80005244	PUMP-VAR-DISPL CCW 90PV130	90L130-KN-5-NN-80-S-4-C8-H-03-GBA-38-38-24	SERIES 90	S90-130PV
80005250	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-CD-80-R-7-C7-E-09-GCA-35-35-30	SERIES 90	S90-100PV
80005251	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-BC-80-R-7-S1-E-09-GCA-35-35-30	SERIES 90	S90-100PV
80005254	MOTOR-VAR-DISPL 51MC110	51C110-R-D3-N-HZ-B1-B-H-C2-NNN-022-AA-E6-07-00	SERIES 51	S51-110MV
80005257	PUMP-TANDEM, VAR DISPL MPT025C	MPT-025-C-S-R-A-E-NN-B-A-A-A-BGG-DR-A-FF-B-C-A-A-BGG-DL-A-FF-A-NNN-*	LIGHT DUTY	025PT
80005262	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-HS-A2-B-H-G6-NNN-069-AA-F3-10-22	SERIES 51	S51-160MV
80005263	PUMP-VAR DISPL, CCW 90PV055	90-L-055-MA-5-BC-60-S-3-C6-C-C5-GBA-38-38-24	SERIES 90	S90-055PV
80005265	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HF-1-NN-80-P-4-F1-E-00-GBA-35-35-24	SERIES 90	S90-100PV
80005266	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-NN-60-P-3-F1-F-03-GBA-32-32-24	SERIES 90	S90-100PV
80005267	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-N-HS-A2-C-H-G6-NNN-107-AA-NN-30-20	SERIES 51	S51-160MV
80005268	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D2-N-E1-B1-N-N-U1-ADA-032-AA-E6-00-00	SERIES 51	S51-080MV-1
80005269	MOTOR-VAR-DISPL 51MD160	51D160-A-D4-N-T2-C2-L-N-G0-NNN-082-AA-G3-00-B2	SERIES 51	S51-160MV
80005270	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-NN-80-S-3-F1-J-09-NNN-40-40-30	SERIES 90	S90-250PV
80005271	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-N2-NN-N-N-A0-AHA-032-AA-G3-00-00	SERIES 51	S51-160MV
80005272	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-BB-80-R-4-C3-C-03-GBA-23-23-24	SERIES 90	S90-042PV
80005273	MOTOR-VARIABLE DISPL SAE_K	K-V-38CN-A-R3F-F55-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
80005274	PUMP-VAR DISPL MPV046C	MPV-046-C-B-A-A-T-B-B-AA-G-A-BEE-AB-U-ED-C-NNN-***	M46	M46-046PV

80005275	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-T2-C2-L-N-G0-NNN-058-AA-F0-00-B8	SERIES 51	S51-160MV
80005277	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A3-C2-N-E5-F-G5-NN-L-35-L-35-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
80005282	MOTOR-VAR-DISPL 51MV110	51V110-A-D3-N-L2-B1-V-A-J1-ADA-041-AA-F0-B2-00	SERIES 51	S51-110MV
80005283	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-N-E2-A5-A-N-G0-NNN-133-AA-NN-03-00	SERIES 51	S51-250MV
80005284	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-TA-C2-N-N-X1-NNN-060-AA-G3-00-20	SERIES 51	S51-110MV-1
80005285	PUMP-VAR-DISPL CW 90PV075	90R075-HF-5-AB-80-S-4-S1-E-03-GBA-42-42-24	SERIES 90	S90-075PV
80005287	MOTOR-VAR-DISPL 51MD110-1	51D110-1--A-D4-N-T2-D2-N-N-X1-NNN-030-AA-E6-00-20	SERIES 51	S51-110MV-1
80005288	MOTOR-VAR-DISPL 51MV080-1	51V080-1--A-C7-N-T2-D2-N-N-X1-NNN-025-AA-E6-00-20	SERIES 51	S51-080MV-1
80005289	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-AB-60-S-3-C7-F-03-GBA-42-42-24	SERIES 90	S90-100PV
80005291	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-DE-80-L-3-C8-H-03-GBA-35-35-24	SERIES 90	S90-130PV
80005294	MOTOR-VARIABLE DISPL SAE_K	K-V-45DS-E-RNF-F55-S-N-N-CF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
80005295	MOTOR- VARIABLE CARTRIDGE L	L-C-25CN-A-RNF-F07-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
80005296	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HS-1-NN-80-R-3-S1-E-03-GBA-32-32-24	SERIES 90	S90-075PV
80005299	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-J-S-B-B-AA-A-A-BFF-BA-A-GG-A-NNN-***	M46	M46-046PV
80005300	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-N-A2-C3-B-D1-F-G1-H5-35-35-35-35-N-P-32-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
80005301	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-2-BB-60-R-3-S1-C-03-GBA-38-38-24	SERIES 90	S90-055PV
80005303	MOTOR-VAR-DISPL 51MD160	51D160-A-C8-B-L1-B1-W-B-J1-ADA-045-AA-F0-D4-00	SERIES 51	S51-160MV
80005305	PUMP-VAR DISPL, CW 90PV075	90-R-075-HS-2-CD-60-P-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-075PV
80005306	PUMP-VAR DISPL, CW 90PV075	90-R-075-DD-1-BC-80-S-3-C7-D-GB-GBA-26-26-24	SERIES 90	S90-075PV
80005307	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HS-1-CD-60-S-4-F1-E-03-GBA-38-38-24	SERIES 90	S90-100PV
80005308	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-NN-80-S-4-S1-C-03-GBA-42-42-24	SERIES 90	S90-075PV
80005309	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-A-V-C-B-BA-B-B-G-A-BFF-CD-A-GG-B-D-G-A-BFF-CD-A-GG-C-NNN-*	M46	M46-046PT
80005310	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-T1-C2-N-N-X1-ABA-038-AA-E6-00-18	SERIES 51	S51-110MV-1
80005311	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D2-N-N1-NN-N-N-U1-NNN-050-AA-NN-00-00	SERIES 51	S51-080MV-1
80005312	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-AB-80-L-3-F1-H-03-GBA-35-35-24	SERIES 90	S90-130PV
80005313	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-T2-C0-L-N-K7-NNN-095-AA-G0-00-A7	SERIES 51	S51-250MV
80005314	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-CD-80-S-3-C8-H-03-GBA-26-26-28	SERIES 90	S90-130PV
80005315	PUMP-VAR-DISPL CW 90PV075	90R075-DD-5-NN-80-S-3-S1-D-GB-GBA-35-35-24	SERIES 90	S90-075PV
80005316	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-NN-80-S-4-C8-J-03-NNN-35-35-24	SERIES 90	S90-250PV
80005317	PUMP-VAR-DISPL CW 90PV180	90R180-KP-5-DE-80-S-C-F1-H-03-FAC-32-32-24	SERIES 90	S90-180PV
80005318	PUMP-VAR DISPL, CW 90PV075	90-R-075-HS-2-BC-60-P-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-075PV
80005319	PUMP-VAR-DISPL CW 90PV075	90R075-HF-5-CD-80-S-4-S1-D-03-GBA-20-20-24	SERIES 90	S90-075PV
80005320	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A4-C2-N-D8-H-G1-H1-K-40-K-40-C-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
80005322	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A3-C2-N-D8-H-G1-NN-L-35-L-35-F-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
80005323	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-BC-80-L-3-F1-F-03-GBA-38-38-24	SERIES 90	S90-130PV
80005324	MOTOR-VAR-DISPL 51MD060	51D060-R-D2-B-HS-A2-C-H-C1-NNN-030-AA-NN-15-15	SERIES 51	S51-060MV

80005325	MOTOR-VAR-DISPL 51MV110	51V110-A-C8-N-D8-M1-R-J-M4-ACA-045-AA-G0-C2-20	SERIES 51	S51-110MV
80005326	PUMP-VAR DISPL, CW 90PV100	90-R-100-HS-1-BC-80-S-3-F1-E-03-GBA-35-35-28	SERIES 90	S90-100PV
80005328	PUMP-VAR DISPL, CW 90PV075	90-R-075-MB-1-BB-60-L-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-075PV
80005329	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MC-1-CD-80-S-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-100PV
80005330	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MC-1-NN-80-S-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-100PV
80005334	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-TA-C0-L-N-G0-NNN-080-AA-F3-00-B6	SERIES 51	S51-160MV
80005335	PUMP-VAR-DISPL CW 90PV075	90R075-CA-5-NN-60-S-7-S1-D-00-GCA-42-42-30	SERIES 90	S90-075PV
80005337	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HF-1-BC-80-S-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-100PV
80005346	MOTOR-FIX DISPL MMF044D	MMF-044-D-A-A-G-A-U-NNN-***	M35/44	044MF
80005348	MOTOR-VAR-DISPL 51MC080	51C080-R-D2-N-HZ-B1-A-N-G5-NNN-050-AA-E6-03-00	SERIES 51	S51-080MV
80005350	PUMP-VAR DISPL, CW 90PV075	90-R-075-HS-1-NN-80-S-3-S1-D-03-GBA-29-29-24	SERIES 90	S90-075PV
80005355	MOTOR-VAR-DISPL 51MC110	51C110-R-D3-N-N2-NN-N-N-A0-NNN-040-AA-F0-00-00	SERIES 51	S51-110MV
80005356	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-BC-80-P-3-S1-D-03-GBA-17-17-24	SERIES 90	S90-075PV
80005359	PUMP-VAR-DISPL CCW 90PV075	90L075-CA-5-AB-60-S-7-S1-D-00-GLA-42-42-24	SERIES 90	S90-075PV
80005362	MOTOR-VAR-DISPL 51MD160	51D160-R-D5-N-E1-A5-A-N-G0-NNN-032-AA-F0-03-00	SERIES 51	S51-160MV
80005363	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HS-1-AB-80-R-3-S1-E-03-GBA-32-32-24	SERIES 90	S90-075PV
80005365	PUMP-VAR DISPL, CCW 90PV055	90-L-055-MA-5-BC-60-S-3-C6-C-C5-GBA-35-35-24	SERIES 90	S90-055PV
80005366	PUMP-VAR DISPL, CCW 90PV055	90-L-055-MA-5-NN-60-S-3-C6-C-C5-GBA-35-35-24	SERIES 90	S90-055PV
80005368	PUMP-VAR-DISPL CCW 90PV180	90L180-KP-5-AB-80-T-C-F1-H-03-FAC-35-35-24	SERIES 90	S90-180PV
80005370	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-BC-60-S-4-C7-E-03-GBA-35-35-24	SERIES 90	S90-075PV
80005371	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-AB-60-S-4-C7-E-03-GBA-35-35-24	SERIES 90	S90-100PV
80005372	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D3-N-N1-NN-N-N-U1-NNN-025-AA-NN-00-00	SERIES 51	S51-080MV-1
80005374	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-2-NN-80-P-3-S1-F-00-GBA-45-45-24	SERIES 90	S90-100PV
80005375	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-5-AD-80-R-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-055PV
80005376	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-7-NN-80-P-3-S1-F-00-GBA-48-48-24	SERIES 90	S90-100PV
80005378	MOTOR-VAR-DISPL 51MV060-1	51V060-1--A-C6-N-P8-P8-N-N-X1-NNN-012-AA-F3-00-AA	SERIES 51	S51-060MV-1
80005382	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-BC-80-S-4-C8-H-03-GBA-35-35-24	SERIES 90	S90-130PV
80005395	MOTOR-VAR-DISPL 51MD110	51D110-R-D4-N-HS-A2-C-H-C1-NNN-055-AA-NN-15-15	SERIES 51	S51-110MV
80005396	MOTOR-VAR-DISPL 51MV060	51V060-R-S1-A-HS-A2-C-H-C1-NNN-026-AA-NN-25-15	SERIES 51	S51-060MV
80005397	MOTOR-VAR-DISPL 51MD160	51D160-R-D5-N-HS-A2-C-H-E1-NNN-080-AA-NN-15-20	SERIES 51	S51-160MV
80005402	PUMP-VAR-DISPL CW 90PV100	90R100-KP-5-CD-80-L-3-TJ-E-03-GBA-38-14-24	SERIES 90	S90-100PV
80005422	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-5-CD-60-P-4-C6-D-GB-GBA-32-32-24	SERIES 90	S90-055PV
80005432	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-HS-A2-B-N-E1-NNN-043-AA-F0-07-20	SERIES 51	S51-160MV
80005433	MOTOR-VAR-DISPL 51MD110-1	51D110-1--R-D3-N-E2-B1-N-N-U1-NNN-065-AA-NN-00-00	SERIES 51	S51-110MV-1
80005434	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-HS-A1-B-H-E2-NNN-016-AA-E6-06-15	SERIES 51	S51-080MV
80005442	PUMP-VAR-DISPL CW 90PV130	90R130-MA-5-AB-80-L-3-F1-F-C5-GBA-23-23-24	SERIES 90	S90-130PV

80005443	PUMP-VAR-DISPL CW 90PV100	90R100-MA-5-NN-80-L-3-C7-E-C5-GBA-42-42-24	SERIES 90	#N/D!
80005444	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-BC-80-D-4-K3-L-05-GBA-23-23-24	SERIES 90	S90-100PV
80005445	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-N-L1-B1-W-B-C0-ACA-100-AA-G0-D4-00	SERIES 51	S51-250MV
80005447	MOTOR-FIX DISPL MMF044D	MMF-044-D-A-F-E-A-B-NNN-***	M35/44	044MF
80005448	MOTOR-VAR-DISPL 51MC110	51C110-R-D3-N-J1-K1-D-E-H4-NNN-046-AA-NN-20-22	SERIES 51	S51-110MV
80005449	MOTOR-VAR-DISPL 51MV060-1	51V060-1--R-S1-N-TA-C2-N-N-X1-NNN-025-AA-E6-00-30	SERIES 51	S51-060MV-1
80005450	PUMP-VAR-DISPL CW 90PV100	90R100-FG-5-BC-80-P-7-C7-E-B1-GCA-42-42-30	SERIES 90	S90-100PV
80005452	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-N-DC-M6-S-K-N9-AWU-050-AA-F0-F4-26	SERIES 51	S51-160MV
80005454	PUMP-VAR DISPL, CW 90PV055	90-R-055-FA-5-AD-80-S-7-C6-D-B2-EHC-40-40-24	SERIES 90	S90-055PV
80005462	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-BC-80-L-3-F1-F-03-GBA-32-32-24	SERIES 90	S90-130PV
80005464	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-1-CD-80-P-4-S1-C-00-GBA-14-14-24	SERIES 90	S90-055PV
80005472	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-AB-80-P-3-C8-F-03-GLA-29-29-24	SERIES 90	S90-130PV
80005473	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A3-C2-N-D3-G-A8-H3-L-40-L-40-L-M-30-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
80005474	PUMP-VAR DISPL, CW 90PV075	90-R-075-HS-5-AB-80-P-3-C7-D-03-GBA-23-23-24	SERIES 90	S90-075PV
80005475	PUMP-VAR-DISPL CW 90PV042	90R042-DD-5-NN-80-R-4-C3-B-GB-GBA-26-14-24	SERIES 90	S90-042PV
80005476	PUMP-VAR DISPL, CCW 90PV075	90-L-075-DD-1-BC-80-P-4-S1-D-GB-GBA-26-26-24	SERIES 90	S90-075PV
80005477	MOTOR-VAR-DISPL 51MD110-1	51D110-1--A-D3-N-P8-P8-N-N-X1-NNN-045-AA-F0-00-AA	SERIES 51	S51-110MV-1
80005481	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-1-BG-80-D-3-S1-L-00-GBA-29-29-24	SERIES 90	S90-055PV
80005482	MOTOR-VAR-DISPL 51MD160	51D160-A-D4-N-TM-E7-L-N-J2-ADA-038-AA-F3-00-BB	SERIES 51	S51-160MV
80005483	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-BC-60-L-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-055PV
80005484	MOTOR-VAR-DISPL 51MD160	51D160-A-D4-N-HS-A2-C-H-C1-NNN-064-AA-NN-15-13	SERIES 51	S51-160MV
80005491	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-A-A2-C2-B-E7-F-G5-NN-42-42-38-38-N-P-20-PN-C04-NNN	H1-MP PUMPS	H1-045PT/053PT
80005492	MOTOR-VAR-DISPL 51MD110-1	51D110-1--A-D4-N-P7-P7-N-N-X1-ADA-022-AA-F3-00-AA	SERIES 51	S51-110MV-1
80005493	MOTOR-VARIABLE DISPL SAE_K	K-V-45DN-E-R1F-F07-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
80005495	PUMP-VAR-DISPL CCW 90PV075	90L075-FN-5-NN-60-S-7-S1-D-B6-EFP-42-42-30	SERIES 90	S90-075PV
80005496	PUMP-VAR-DISPL CW 90PV100	90R100-HF-5-BC-60-L-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-100PV
80005498	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A2-C1-N-F3-F-G5-NN-J-40-J-40-B-L-22-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
80005499	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-CD-80-T-M-F1-H-03-FAC-17-17-24	SERIES 90	S90-180PV
80005503	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-BC-60-S-3-C6-D-03-EFI-35-35-24	SERIES 90	S90-055PV
80005504	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-L2-B1-V-A-J1-ACB-016-AA-NN-B2-00	SERIES 51	S51-080MV
80005505	MOTOR-VAR-DISPL 51MV080	51V080-V-S1-N-HS-A2-C-H-E1-NNN-040-AA-NN-20-18	SERIES 51	S51-080MV
80005506	MOTOR-FIX DISPL MMF044D	MMF-044-D-A-N-E-A-B-NNN-***	M35/44	044MF
80005507	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HF-1-BC-80-R-4-S1-E-04-GBA-26-26-20	SERIES 90	S90-100PV
80005508	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-CD-80-P-3-C6-D-03-GBA-42-42-24	SERIES 90	S90-075PV
80005512	PUMP-VAR-DISPL CW 90PV180	90R180-MB-5-BB-80-T-C-F1-J-C5-NNN-38-32-28	SERIES 90	S90-180PV
80005517	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-8-N-0-S1-W-00-EBA-00-00-F0	SERIES 90	S90-100MF

80005518	MOTOR-VAR-DISPL 51MD080	51D080-R-D3-N-HS-A2-C-E-E1-NNN-047-AA-NN-15-25	SERIES 51	S51-080MV
80005519	PUMP-VAR-DISPL CCW 90PV100	90L100-HF-5-BC-80-R-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
80005522	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-BB-60-P-3-S1-C-00-GBA-45-45-32	SERIES 90	S90-055PV
80005529	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-BC-60-P-3-TJ-E-01-GBA-32-32-20	SERIES 90	S90-075PV
80005532	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-CD-80-S-3-C7-E-03-GBA-29-29-24	SERIES 90	S90-075PV
80005533	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-A-T-B-B-BA-V-A-BCC-DB-A-HH-C-NNN-***	M46	M46-046PV
80005534	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HS-1-NN-60-P-3-S1-D-03-GBA-32-14-30	SERIES 90	S90-075PV
80005535	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HS-1-NN-60-P-4-S1-E-03-GBA-32-14-30	SERIES 90	S90-100PV
80005536	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HS-1-NN-60-P-4-S1-C-03-GBA-32-14-30	SERIES 90	S90-055PV
80005538	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-TH-C2-L-N-G0-NNN-050-AA-NN-00-B0	SERIES 51	S51-250MV
80005539	PUMP-VAR-DISPL CW 90PV075	90R075-DD-5-CD-60-P-4-C7-D-GB-GBA-42-42-28	SERIES 90	S90-075PV
80005542	PUMP-VAR DISPL, CW 90PV100	90-R-100-HF-1-CD-60-P-3-F1-E-03-GBA-38-38-20	SERIES 90	S90-100PV
80005544	PUMP-VAR DISPL, CW 90PV100	90-R-100-HK-1-CD-60-S-3-F1-E-03-GBA-38-38-20	SERIES 90	S90-100PV
80005545	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-A-S-A-K-BC-B-B-A-A-BMG-CB-A-HH-B-C-A-A-BFF-AT-D-AB-S-ANN-*	M46	M46-046PT
80005548	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-HS-A2-C-H-E1-NNN-040-AA-E6-16-30	SERIES 51	S51-080MV
80005549	MOTOR-VAR-DISPL 51MV110	51V110-R-F1-N-HS-A2-C-H-E1-NNN-040-AA-F0-16-30	SERIES 51	S51-110MV
80005550	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-HS-A2-C-H-E1-NNN-040-AA-F3-16-30	SERIES 51	S51-160MV
80005551	PUMP-VAR-DISPL CCW 90PV130	90L130-HS-5-NN-80-P-4-F1-F-03-GBA-32-14-30	SERIES 90	S90-130PV
80005554	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-NN-80-P-4-F1-E-03-GBA-29-29-24	SERIES 90	S90-100PV
80005555	PUMP-VAR-DISPL CW 90PV100	90R100-FG-5-BB-60-S-7-C7-F-B1-GBA-42-42-30	SERIES 90	S90-100PV
80005556	MOTOR-VAR-DISPL 51MD160	51D160-A-D4-N-T1-C0-L-N-G0-ADA-051-AA-F3-00-B3	SERIES 51	S51-160MV
80005557	MOTOR-VAR-DISPL 51MC060	51C060-R-D1-B-HS-A2-C-H-C1-NNN-030-AA-NN-15-15	SERIES 51	S51-060MV
80005558	PUMP-TANDEM, VAR DISPL CCW H1T045L	H1-T-045-L-A-N-A3-C2-N-E7-F-G1-H3-38-38-38-38-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
80005562	MOTOR-VAR-DISPL 51MV110	51V110-R-F1-N-HZ-B1-C-H-C2-ACA-030-AA-F0-15-00	SERIES 51	S51-110MV
80005564	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A3-C2-N-D8-F-G1-H3-L-40-L-40-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
80005565	PUMP-VAR-DISPL CCW H1PV147	H1-P-147-L-C-A5-C3-N-D6-G-G3-H3-L-38-L-38-A-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
80005567	MOTOR-VAR-DISPL 51MV110-1	51V110-1--A-D3-N-N1-NN-N-N-U1-NNN-053-AA-E6-00-00	SERIES 51	S51-110MV-1
80005568	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-BK-80-L-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-055PV
80005572	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A3-C2-N-D3-G-G2-NN-L-42-L-42-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
80005573	MOTOR-VAR-DISPL 51MV080	51V080-V-S1-N-HS-A2-C-H-E1-NNN-032-AA-NN-20-20	SERIES 51	S51-080MV
80005574	PUMP-VAR-DISPL CW 90PV100	90R100-DD-5-BC-80-S-3-S1-E-G8-GBA-42-42-24	SERIES 90	S90-100PV
80005577	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-TA-C2-L-N-G0-NNN-078-AA-F0-00-A4	SERIES 51	S51-160MV
80005578	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-P-BC-80-S-3-C7-E-03-GBA-48-48-24	SERIES 90	S90-075PV
80005580	PUMP-VAR DISPL CCW H1P053L	H1-P-053-L-A-A3-C1-N-E5-F-G5-H3-L-30-L-30-B-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
80005582	MOTOR-FIX DISPL MMF044D	MMF-044-D-A-S-1-A-B-NNN-***	M35/44	044MF
80005583	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-B-HZ-B1-A-N-G0-ACB-040-AA-G0-03-00	SERIES 51	S51-160MV

80005584	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-B-E1-B1-N-N-U1-NNN-071-AA-F0-00-00	SERIES 51	S51-110MV-1
80005585	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-S1-N-T1-D1-N-N-X1-NNN-021-AA-F3-00-31	SERIES 51	S51-080MV-1
80005588	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-2-BC-80-T-C-F1-J-03-NNN-42-42-24	SERIES 90	S90-180PV
80005593	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-N-L7-B1-W-B-G5-ACA-032-AA-F0-D4-00	SERIES 51	S51-160MV
80005594	PUMP-VAR-DISPL CW 90PV250	90R250-KP-5-EG-80-T-4-C8-K-00-NNN-38-38-24	SERIES 90	S90-250PV
80005595	MOTOR-VAR-DISPL 51MC110	51C110-R-D3-N-L2-B1-V-A-C2-ACB-070-AA-NN-B2-00	SERIES 51	S51-110MV
80005596	MOTOR-VAR-DISPL 51MC110-1	51C110-1--R-D3-N-N1-NN-N-N-U1-ACB-050-AA-NN-00-00	SERIES 51	S51-110MV-1
80005597	PUMP-VAR DISPL, CW 90PV075	90-R-075-CB-1-NN-60-D-3-S1-L-00-GBA-38-38-20	SERIES 90	S90-075PV
80005598	PUMP-VAR DISPL, CW 90PV100	90-R-100-HS-1-AB-80-P-4-F1-F-03-GBA-29-29-24	SERIES 90	S90-100PV
80005604	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-N-TH-C2-N-N-X1-NNN-020-AA-E6-00-13	SERIES 51	S51-060MV-1
80005615	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A3-C3-N-D3-G-G2-NN-L-28-L-28-A-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
80005616	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-CD-80-S-3-S1-D-03-EFI-42-42-24	SERIES 90	S90-075PV
80005617	MOTOR-VAR-DISPL 51MD160	51D160-R-D4-N-D8-M1-R-J-M4-NNN-055-AA-F3-C2-20	SERIES 51	S51-160MV
80005621	MOTOR-VARIABLE DISPL SAE_K	K-V-45DN-A-YNF-F09-S-N-N-AF-F17-NNN-NNN	LV / KV MOTORS	L/K-MV
80005622	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-1-AB-60-S-3-S1-C-04-GBA-35-35-24	SERIES 90	S90-055PV
80005633	PUMP-VAR-DISPL CW 90PV042	90R042-FA-5-AB-80-S-7-C3-C-B4-EFI-40-40-26	SERIES 90	S90-042PV
80005635	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D2-N-E2-B1-N-N-U1-ADA-040-AA-E6-00-00	SERIES 51	S51-080MV-1
80005637	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-A-S-B-B-BA-A-A-BJJ-CN-A-HH-C-NNN-***	M46	M46-046PV
80005639	PUMP-VAR-DISPL CCW H1PV078	H1-P-078-L-A-A2-C2-N-D8-H-G1-H3-L-35-L-35-F-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
80005640	MOTOR-FIXED DISPL MMF025C	MMF-025-C-A-E-G-C-W-NNN-***	LIGHT DUTY	025MF
80005641	PUMP-VAR-DISPL CW 90PV100	90R100-DD-5-AB-80-S-4-C7-E-GB-GBA-42-42-24	SERIES 90	S90-100PV
80005645	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-BB-80-S-3-C6-D-03-GBA-42-42-24	SERIES 90	S90-075PV
80005646	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-N-HZ-B1-B-H-G5-NNN-080-AA-F0-05-00	SERIES 51	S51-160MV
80005647	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-N-A5-C2-N-E7-F-G1-H3-38-38-38-38-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
80005652	MOTOR-VAR-DISPL 51MD080-1	51D080-1--A-D2-N-T1-CA-N-N-X1-NNN-052-AA-F0-00-20	SERIES 51	S51-080MV-1
80005664	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-AB-60-S-4-C7-F-03-GBA-35-35-24	SERIES 90	S90-100PV
80005665	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-A-HS-A2-B-H-E1-NNN-062-AA-NN-10-25	SERIES 51	S51-250MV
80005666	PUMP-VAR-DISPL CW 90PV250	90R250-KN-5-CD-80-S-4-C8-K-03-NNN-38-38-24	SERIES 90	S90-250PV
80005667	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-CD-80-P-3-C6-D-04-GBA-42-42-24	SERIES 90	S90-055PV
80005668	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-AD-80-P-3-S1-D-04-GBA-42-42-24	SERIES 90	S90-055PV
80005671	MOTOR-VAR-DISPL 51MD060-1	51D060-1--A-D2-N-TH-C2-N-N-X1-ADA-040-AA-F3-00-37	SERIES 51	S51-060MV-1
80005673	PUMP-VAR-DISPL CW 90PV130	90R130-DD-5-AB-80-S-4-C8-F-GB-GBA-42-42-24	SERIES 90	S90-130PV
80005674	PUMP-VAR DISPL, CW 90PV075	90-R-075-DD-1-CD-80-S-3-C6-D-GB-GBA-32-32-24	SERIES 90	S90-075PV
80005675	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-1-NN-80-S-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
80005679	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-BB-80-S-3-C8-H-03-GBA-32-32-24	SERIES 90	S90-130PV
80005680	MOTOR-VAR-DISPL 51MD110	51D110-R-D3-N-D7-M1-S-K-M1-NNN-042-AA-F0-F4-35	SERIES 51	S51-110MV

80005682	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A5-C3-B-D3-G-G3-H6-L-35-L-35-A-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
80005683	PUMP-VAR DISPL, CW 90PV100	90-R-100-HS-1-NN-80-S-3-S1-E-03-GBA-23-23-24	SERIES 90	S90-100PV
80005684	MOTOR-VARIABLE DISPL SAE_K	K-V-45DN-A-YNF-F01-S-N-N-AF-F17-NNN-NNN	LV / KV MOTORS	L/K-MV
80005685	MOTOR-VARIABLE DISPL SAE_K	K-V-45DN-A-YNF-F11-S-N-N-AF-F17-NNN-NNN	LV / KV MOTORS	L/K-MV
80005686	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-NN-80-L-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
80005688	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-DA-M4-R-J-N1-ADA-150-AA-E6-C2-31	SERIES 51	S51-250MV
80005690	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-NN-80-S-4-S1-C-02-GBA-35-35-24	SERIES 90	S90-055PV
80005691	PUMP-VAR-DISPL CCW 90PV075	90L075-HF-5-CD-80-S-4-C7-D-03-GBA-35-35-24	SERIES 90	S90-075PV
80005692	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-NN-80-R-3-C7-N-03-FAD-20-20-24	SERIES 90	S90-100PV
80005695	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-BC-80-S-4-C7-C-04-GCB-26-26-18	SERIES 90	S90-075PV
80005698	PUMP-VAR-DISPL CW 90PV180	90R180-FH-5-BC-80-T-7-C8-J-B1-EFI-45-45-30	SERIES 90	S90-180PV
80005699	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-S1-N-N1-NN-N-N-U1-NNN-040-AA-E4-00-00	SERIES 51	S51-080MV-1
80005700	MOTOR-VAR-DISPL 51MV110	51V110-R-C8-N-HS-A2-C-N-A7-NNN-024-AA-NN-15-20	SERIES 51	S51-110MV
80005701	MOTOR-VARIABLE CARTRIDGE K	K-C-38CS-E-RNF-F01-S-N-N-CF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
80005703	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-N-A4-C3-N-E7-F-G5-H3-23-23-23-23-N-P-28-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
80005705	MOTOR-VAR-DISPL 51MC080	51C080-R-D3-N-HS-A2-C-H-E1-NNN-040-AA-E6-16-30	SERIES 51	S51-080MV
80005706	MOTOR-VAR-DISPL 51MC110	51C110-R-D3-N-HS-A2-C-H-E1-NNN-040-AA-F0-16-30	SERIES 51	S51-110MV
80005707	MOTOR-VAR-DISPL 51MC160	51C160-R-D5-N-HS-A2-C-H-E1-NNN-040-AA-F3-16-30	SERIES 51	S51-160MV
80005708	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-CD-80-P-3-C8-H-03-EFC-35-35-24	SERIES 90	S90-130PV
80005709	PUMP-VAR-DISPL CW 90PV075	90R075-MA-5-CD-60-D-4-C7-L-C5-GBA-35-35-18	SERIES 90	S90-075PV
80005710	PUMP-VAR-DISPL CW 90PV075	90R075-MA-5-BC-60-D-4-S1-L-C5-GBA-35-35-18	SERIES 90	S90-075PV
80005711	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MA-6-BC-80-L-3-S1-F-05-GBA-48-48-24	SERIES 90	S90-100PV
80005713	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A4-C2-B-D6-G-G3-NN-L-42-L-42-A-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
80005714	PUMP-VAR-DISPL CW 90PV100	90R100-MA-5-AB-60-S-3-C7-E-C5-FAB-38-38-24	SERIES 90	S90-100PV
80005715	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-S1-N-T2-CA-N-N-X1-NNN-022-AA-E6-00-25	SERIES 51	S51-080MV-1
80005719	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-BB-80-P-3-C3-B-04-GBA-26-26-20	SERIES 90	S90-042PV
80005720	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A2-C2-N-E6-F-G5-H3-L-28-L-28-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
80005721	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-NN-60-R-4-F1-E-00-GBA-32-32-24	SERIES 90	S90-100PV
80005722	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-N-E2-B1-N-N-U1-ACB-018-AA-E6-00-00	SERIES 51	S51-060MV-1
80005723	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-N-E2-B1-N-N-U1-NNN-018-AA-E6-00-00	SERIES 51	S51-060MV-1
80005725	MOTOR-VAR-DISPL 51MD160	51D160-A-D4-N-TA-C2-L-N-G0-NNN-080-AA-NN-00-B0	SERIES 51	S51-160MV
80005727	PUMP-VAR-DISPL CCW 90PV180	90L180-FH-5-NN-80-S-7-C8-J-B1-NNN-35-35-30	SERIES 90	S90-180PV
80005731	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-B-E2-B1-N-N-U1-NNN-027-AA-NN-00-00	SERIES 51	S51-060MV-1
80005732	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-HZ-B1-B-E-C2-NNN-082-AA-NN-10-00	SERIES 51	S51-160MV
80005733	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A2-C2-N-E5-F-G5-H3-L-30-L-30-B-P-18-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
80005736	PUMP-VAR DISPL, CW 90PV055	90-R-055-M8-1-NN-60-P-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-055PV

80005737	PUMP-VAR-DISPL CCW 90PV180	90L180-FG-5-CD-80-S-7-C8-H-B1-EFI-40-40-32	SERIES 90	S90-180PV
80005738	MOTOR-VAR-DISPL 51MV250	51V250-A-C8-N-HS-A1-B-H-E2-NNN-050-AA-G3-07-19	SERIES 51	S51-250MV
80005739	MOTOR-VAR-DISPL 51MD110-1	51D110-1--R-D3-E-F2-B1-N-N-U1-NNN-022-AA-G3-00-00	SERIES 51	S51-110MV-1
80005740	PUMP-VAR-DISPL CW 90PV250	90R250-MA-5-BC-80-S-4-C8-K-C5-NNN-38-38-24	SERIES 90	S90-250PV
80005742	MOTOR-VAR-DISPL 51MC080	51C080-A-D3-N-L1-B1-W-B-G5-ACA-016-AA-F0-D4-00	SERIES 51	S51-080MV
80005745	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HF-5-NN-60-R-4-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
80005746	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A2-C2-N-D6-G-G2-H3-L-45-L-45-A-L-28-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
80005747	MOTOR-VAR-DISPL 51MV110-1	51V110-1--A-D3-N-TH-C2-N-N-X1-NNN-053-AA-E6-00-31	SERIES 51	S51-110MV-1
80005749	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-NN-65-R-3-F3-F-00-GBA-40-35-20-N180	SERIES 90	S90-100PV
80005752	MOTOR-VAR-DISPL 51MD110-1	51D110-1--R-D3-N-N1-NN-N-N-U1-NNN-060-AA-NN-00-00	SERIES 51	S51-110MV-1
80005753	PUMP-VAR-DISPL CCW 90PV130	90L130-HF-5-BC-80-S-3-C8-F-03-GBA-35-35-24	SERIES 90	S90-130PV
80005757	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HS-1-AB-60-S-3-S1-E-06-GBA-42-42-20	SERIES 90	S90-075PV
80005758	PUMP-VAR-DISPL CW 90PV180	90R180-MA-5-CD-80-T-M-C8-J-C6-NNN-29-29-24	SERIES 90	S90-180PV
80005759	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D3-N-N1-NN-N-N-U1-ABA-025-AA-NN-00-00	SERIES 51	S51-080MV-1
80005760	PUMP-VAR DISPL CCW H1P053L	H1-P-053-L-A-A3-C1-N-E6-F-G5-H5-L-35-L-35-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
80005761	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-NN-80-R-3-F1-H-03-GBA-14-14-20	SERIES 90	S90-130PV
80005763	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-E2-A5-A-N-G0-NNN-133-AA-NN-03-00	SERIES 51	S51-250MV
80005764	MOTOR-VAR-DISPL 51MD160	51D160-A-D5-N-HS-A2-C-E-E1-NNN-110-AA-NN-18-18	SERIES 51	S51-160MV
80005765	PUMP-VAR-DISPL CW 90PV075	90R075-FK-5-BC-80-P-7-C7-D-B6-GME-36-36-22	SERIES 90	S90-075PV
80005766	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-BC-80-S-4-F1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
80005767	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-CD-60-S-4-C7-F-03-GBA-35-35-24	SERIES 90	S90-100PV
80005768	PUMP-VAR DISPL CCW H1P053L	H1-P-053-L-A-A3-C1-N-E6-F-G5-H2-L-35-L-35-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
80005769	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-HZ-B1-A-N-G0-NNN-168-AA-G0-03-00	SERIES 51	S51-250MV
80005770	MOTOR-VAR-DISPL 51MV110-1	51V110-1--A-F1-N-TA-C2-N-N-X1-NNN-074-AA-F0-00-27	SERIES 51	S51-110MV-1
80005771	PUMP-VAR-DISPL CCW 90PV130	90L130-HF-5-CD-80-L-4-F1-F-03-GBA-32-32-24	SERIES 90	S90-130PV
80005784	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-HS-A2-C-H-C1-NNN-040-AA-NN-15-15	SERIES 51	S51-080MV
80005785	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-7-N-0-C6-W-00-EFA-00-00-F3	SERIES 90	#N/D!
80005786	PUMP-VAR DISPL, CW 90PV100	90-R-100-MB-5-NN-60-S-3-C7-E-04-GBA-38-38-24	SERIES 90	S90-100PV
80005787	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-CD-80-P-3-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
80005802	MOTOR-VAR-DISPL 51MD160	51D160-A-D4-N-T4-C0-L-N-L4-NNN-040-AA-F3-00-B3	SERIES 51	S51-160MV
80005803	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A3-C2-N-D8-H-G9-NN-L-40-L-40-C-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
80005804	MOTOR-VAR-DISPL 51MD160	51D160-A-D5-N-HS-A2-C-H-C1-NNN-080-AA-NN-15-15	SERIES 51	S51-160MV
80005805	MOTOR-VAR-DISPL 51MD160	51D160-A-D5-N-HS-A2-C-H-E1-NNN-105-AA-NN-15-19	SERIES 51	S51-160MV
80005806	PUMP-VAR-DISPL CW 90PV130	90R130-FH-5-BC-80-S-7-C8-H-B1-GBA-45-45-30	SERIES 90	S90-130PV
80005807	PUMP-VAR DISPL, CW 90PV075	90-R-075-DC-5-AB-80-P-4-S1-D-GB-GBA-38-38-24	SERIES 90	S90-075PV
80005808	MOTOR-VAR-DISPL 51MV110-1	51V110-1--A-F1-N-N1-NN-N-N-U1-NNN-070-AA-F3-00-00	SERIES 51	S51-110MV-1

80005811	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-BC-80-T-4-C8-K-04-NNN-42-42-28	SERIES 90	S90-250PV
80005812	PUMP-VAR-DISPL CCW 90PV180	90L180-HF-5-CD-80-T-C-F1-J-03-EBA-42-42-24	SERIES 90	S90-180PV
80005815	MOTOR-VAR-DISPL 51MV110	51V110-R-F1-N-HS-A2-C-H-C1-NNN-055-AA-NN-15-15	SERIES 51	S51-110MV
80005816	MOTOR-VAR-DISPL 51MD110	51D110-R-D4-N-H4-B3-R-J-N2-NNN-050-AA-NN-C2-25	SERIES 51	S51-110MV
80005817	PUMP-VAR-DISPL CCW 90PV075	90L075-FN-5-NN-80-R-7-C7-D-B6-EFP-42-42-24	SERIES 90	S90-075PV
80005819	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-NN-60-R-3-S1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
80005820	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-BC-80-S-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
80005821	PUMP-VAR-DISPL CCW 90PV100	90L100-FD-5-NN-60-P-7-C7-E-B1-GBA-26-26-30	SERIES 90	S90-100PV
80005825	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-N-L3-B1-W-B-G5-ANB-032-AA-F0-D4-00	SERIES 51	S51-160MV
80005827	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-TA-C2-L-N-G0-ACA-165-AA-G3-00-B4	SERIES 51	S51-250MV
80005829	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-HS-A2-B-E-G6-ACA-070-AA-H0-08-37	SERIES 51	S51-160MV
80005831	MOTOR-VAR-DISPL 51MV080-1	51V080-1--H-S1-N-TA-C2-N-N-X1-NNN-038-AA-NN-00-20	SERIES 51	S51-080MV-1
80005832	PUMP-VAR-DISPL CW 90PV180	90R180-MA-5-NN-80-S-C-C8-J-C7-NNN-38-14-24	SERIES 90	S90-180PV
80005833	PUMP-TANDEM, VAR DISPL CCW H1T045L	H1-T-045-L-A-N-B6-C1-B-E7-F-G5-NN-25-25-40-40-N-P-20-P3-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
80005835	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A4-C1-N-E6-F-G5-NN-L-30-L-30-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
80005836	MOTOR-VAR-DISPL 51MV080-1	51V080-1--A-C7-N-E2-B1-N-N-U1-DAA-040-AA-E6-00-00	SERIES 51	S51-080MV-1
80005837	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MA-1-NN-60-S-3-K3-E-03-GBA-26-26-24	SERIES 90	S90-100PV
80005838	PUMP-VAR-DISPL CW 90PV042	90R042-FA-5-AB-80-S-7-C3-C-B4-EFI-32-32-24	SERIES 90	S90-042PV
80005843	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-TH-C2-L-N-G0-ACB-057-AA-G0-00-B9	SERIES 51	S51-160MV
80005844	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-BC-80-P-3-F1-E-03-GBA-35-35-24-G005	SERIES 90	S90-100PV
80005845	MOTOR- VARIABLE CARTRIDGE L	L-C-35EN-E-RNF-F55-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
80005852	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-NN-80-T-M-F1-J-05-NNN-38-38-24	SERIES 90	S90-180PV
80005854	MOTOR-VAR-DISPL 51MD080-1	51D080-1--R-D3-N-TA-L5-N-N-X1-NNN-040-AA-NN-00-20	SERIES 51	S51-080MV-1
80005855	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-CD-80-P-3-C8-F-03-GBA-35-35-24	SERIES 90	S90-130PV
80005856	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-BC-80-P-3-C8-F-03-GBA-35-35-24	SERIES 90	S90-130PV
80005857	MOTOR-VAR-DISPL 51MC060-1	51C060-1--A-D1-N-E2-B1-N-N-U1-NNN-022-AA-E6-00-00	SERIES 51	S51-060MV-1
80005881	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A2-C2-N-D6-F-G5-H3-L-38-L-38-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
80005891	MOTOR-VARIABLE CARTRIDGE K	K-C-45DN-E-YNF-F06-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
80005893	PUMP-VAR-DISPL CCW 90PV100	90L100-MA-5-BC-80-L-3-C7-E-C5-GBA-35-35-24	SERIES 90	S90-100PV
80005894	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-BC-80-T-4-C8-K-04-NNN-42-42-24	SERIES 90	S90-250PV
80005895	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-BB-80-L-4-C7-E-03-GBA-42-42-24	SERIES 90	S90-075PV
80005896	PUMP-VAR-DISPL CCW 90PV042	90L042-DC-5-AB-80-S-3-C3-B-Z1-GBA-45-45-20	SERIES 90	S90-042PV
80005901	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A2-C2-B-F3-F-G5-H5-J-40-J-40-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
80005912	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-BB-80-R-3-F1-F-03-GFH-35-35-20-P040	SERIES 90	S90-100PV
80005922	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-BC-80-R-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
80005923	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-NN-80-R-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV

80005924	PUMP-VAR DISPL, CCW 90PV100	90-L-100-DD-1-BC-80-R-3-C7-F-GJ-GBA-29-29-24	SERIES 90	S90-100PV
80005927	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-1-BG-80-P-4-S1-C-00-GBA-14-14-24	SERIES 90	S90-055PV
80005928	MOTOR-VAR-DISPL 51MV110	51V110-R-F1-N-HZ-B1-B-H-G5-NNN-074-AA-NN-06-00	SERIES 51	S51-110MV
80005930	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-EQ-A5-K-Y-G5-ANA-040-AA-F3-50-00	SERIES 51	S51-080MV
80005932	PUMP-VAR-DISPL CCW 90PV075	90L075-DD-5-BC-80-S-4-S1-D-Z1-GBA-26-26-24	SERIES 90	S90-075PV
80005933	PUMP-VAR DISPL, CW 90PV055	90-R-055-CB-5-BG-80-R-3-S1-B-00-GBA-38-38-24	SERIES 90	S90-055PV
80005934	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-BC-60-S-3-S1-D-D3-FAC-42-42-24	SERIES 90	S90-055PV
80005936	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-CD-60-S-3-S1-D-D3-FAC-42-42-24	SERIES 90	S90-055PV
80005939	MOTOR-VAR-DISPL 51MD110-1	51D110-1--A-D4-N-P8-P8-N-N-X1-AWM-033-AA-F0-00-AA	SERIES 51	S51-110MV-1
80005940	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-L2-B1-V-A-C0-AHA-050-AA-C3-B2-00	SERIES 51	S51-250MV
80005941	PUMP-VAR-DISPL CCW 90PV042	90L042-KA-5-AB-80-L-4-C3-C-03-GBA-42-42-24	SERIES 90	S90-042PV
80005945	MOTOR-VAR-DISPL 51MD160	51D160-R-D5-N-N2-NN-N-N-A0-NNN-060-AA-NN-00-00	SERIES 51	S51-160MV
80005946	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-BB-80-S-C-C8-H-03-GCA-29-29-24	SERIES 90	S90-180PV
80005947	PUMP-VAR-DISPL CW 90PV075	90R075-MA-5-NN-80-P-3-S1-D-C5-GBA-35-35-24	SERIES 90	S90-075PV
80005948	PUMP-VAR-DISPL CW 90PV042	90R042-MA-5-NN-80-P-3-C3-B-C5-GBA-38-38-24	SERIES 90	S90-042PV
80005949	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-BB-80-D-4-S1-L-05-GBA-23-23-24-F053	SERIES 90	S90-075PV
80005950	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-T2-C0-L-N-G0-NNN-130-AA-F3-00-A9	SERIES 51	S51-250MV
80005951	PUMP-VAR DISPL, CW 90PV055	90-R-055-CB-5-CD-80-R-3-S1-B-00-GBA-38-38-34	SERIES 90	S90-055PV
80005952	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-NN-80-R-4-S1-E-03-GBA-32-32-24	SERIES 90	S90-100PV
80005953	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-NN-80-R-4-S1-E-03-GBA-32-32-24	SERIES 90	S90-100PV
80005955	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-2-NN-80-S-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-130PV
80005962	PUMP-VAR DISPL, CW 90PV075	90-R-075-MV-1-BE-62-R-4-C7-E-03-GFK-45-45-24-F035	SERIES 90	S90-075PV
80005972	PUMP-VAR DISPL, CW 90PV055	90-R-055-HS-1-BB-60-S-3-C6-C-03-GBA-29-29-24	SERIES 90	S90-055PV
80005973	PUMP-VAR DISPL, CW 90PV075	90-R-075-M8-1-CD-60-P-3-C7-D-03-GBA-42-42-20	SERIES 90	S90-075PV
80005974	MOTOR-VAR-DISPL 51MV160	51V160-R-F2-N-E2-A5-A-N-G0-NNN-075-AA-F0-03-00	SERIES 51	S51-160MV
80005975	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A9-C2-B-D8-F-G5-NN-L-30-L-30-N-P-32-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
80005976	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-5-NN-80-S-4-S1-E-26-GBA-23-23-24	SERIES 90	S90-075PV
80005978	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A2-C2-N-D8-H-G1-H2-L-15-L-33-F-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
80005979	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MB-1-BC-60-P-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
80005980	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-DE-80-R-4-C8-L-00-GBA-35-35-34	SERIES 90	S90-130PV
80005981	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-DE-80-R-3-F1-F-03-GBA-14-14-20	SERIES 90	S90-130PV
80005982	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-CD-80-R-4-C8-L-00-GBA-42-16-34	SERIES 90	S90-130PV
80005983	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-CD-80-R-4-F1-L-00-GBA-42-16-34	SERIES 90	S90-130PV
80005984	MOTOR-VAR-DISPL 51MV080	51V080-A-C7-N-EQ-A2-J-Y-E1-NNN-030-AA-E6-15-37	SERIES 51	S51-080MV
80005985	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-5-BG-80-R-4-S1-C-C3-GBA-23-23-20	SERIES 90	S90-055PV
80005986	PUMP-VAR DISPL, CW 90PV100	90-R-100-DD-1-AB-60-P-4-S1-E-GB-GBA-35-35-24	SERIES 90	S90-100PV

80005987	MOTOR-VAR-DISPL 51MD080	51D080-A-D3-N-L2-B1-V-A-C0-NNN-030-AA-E6-B2-00	SERIES 51	S51-080MV
80005989	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-NN-60-S-3-C6-C-09-GBA-29-29-30	SERIES 90	S90-055PV
80005990	MOTOR-VAR-DISPL 51MD110	51D110-R-D4-B-HS-A2-C-H-C1-NNN-038-AA-NN-15-13	SERIES 51	S51-110MV
80005991	MOTOR-VAR-DISPL 51MV110-1	51V110-1--A-F1-N-TH-C2-N-N-X1-NNN-026-AA-E4-00-25	SERIES 51	S51-110MV-1
80005992	PUMP-VAR DISPL, CW 90PV100	90-R-100-M8-1-NN-60-P-3-C7-E-03-GBA-40-40-24	SERIES 90	S90-100PV
80005994	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-2-CD-60-L-3-C7-D-02-GBA-42-42-24	SERIES 90	S90-075PV
80005995	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-2-NN-60-L-3-S1-D-02-GBA-42-42-24	SERIES 90	S90-075PV
80005998	PUMP-VAR-DISPL CW 90PV130	90R130-NA-1-BC-80-L-3-T7-F-03-GLA-42-42-30	SERIES 90	S90-130PV
80006001	PUMP-VAR DISPL CCW H1P053L	H1-P-053-L-A-A2-C2-N-D6-F-G4-NN-L-20-L-20-B-L-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
80006002	PUMP-VAR-DISPL CW 90PV250	90R250-HF-2-EG-80-T-4-C8-K-03-NNN-32-32-24	SERIES 90	S90-250PV
80006003	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HF-5-CD-80-R-4-F1-F-03-EEB-42-42-20	SERIES 90	S90-100PV
80006004	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HF-5-BC-80-R-4-F1-F-03-EEB-42-42-20	SERIES 90	S90-100PV
80006006	PUMP-VAR-DISPL CW 90PV250	90R250-KP-2-CD-80-T-4-C8-K-03-NNN-32-32-24	SERIES 90	S90-250PV
80006007	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A4-C2-B-D8-H-G1-NN-L-23-L-23-C-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
80006008	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-E-V-C-B-AA-B-A-B-A-BRR-AB-U-BB-B-C-B-A-BRR-AB-D-BB-B-NNN-*	M46	M46-046PT
80006009	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A2-C2-N-F6-H-G9-H6-L-35-L-35-C-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
80006010	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A2-C2-N-D6-H-G1-H3-L-35-L-35-C-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
80006015	PUMP-VAR-DISPL CW 90PV250	90R250-KN-5-BC-80-T-4-F1-J-03-NNN-14-14-24	SERIES 90	S90-250PV
80006016	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-D-E2-A5-A-N-G0-ACA-065-AA-F3-03-00	SERIES 51	S51-160MV
80006017	PUMP-VAR-DISPL CCW 90PV130	90L130-KN-5-BC-80-R-4-F1-F-03-GBA-14-14-24	SERIES 90	S90-130PV
80006018	PUMP-VAR-DISPL CCW 90PV180	90L180-FG-5-CD-80-S-7-C8-H-B1-GLA-40-40-32	SERIES 90	S90-180PV
80006020	PUMP-VAR DISPL CCW H1P053L	H1-P-053-L-A-A2-C2-N-D6-F-G5-H3-L-20-L-20-B-L-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
80006022	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-N-E2-B1-N-N-U1-ACB-021-AA-E6-00-00	SERIES 51	S51-060MV-1
80006023	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-AB-80-T-4-F1-K-03-NNN-26-26-24	SERIES 90	S90-250PV
80006024	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-CD-60-P-4-C7-E-03-GBA-23-23-24	SERIES 90	S90-075PV
80006026	PUMP-VAR DISPL, CW 90PV075	90-R-075-HS-1-CD-80-R-3-C7-E-03-GBA-32-32-24	SERIES 90	S90-075PV
80006027	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D3-N-E1-B1-N-N-U1-ADA-024-AA-E6-00-00	SERIES 51	S51-080MV-1
80006033	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-5-AB-80-T-4-F1-K-03-NNN-21-21-28	SERIES 90	S90-250PV
80006034	MOTOR-VARIABLE DISPL SAE_L	L-V-25CN-A-YNF-F55-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
80006035	PUMP-VAR-DISPL CW 90PV130	90R130-PB-5-NN-80-S-3-C8-F-03-GBA-35-35-24	SERIES 90	S90-130PV
80006038	MOTOR-VAR DISPL MMV046C	MMV-046-C-A-A-L-E-AA-NNN-***	M46	M46-046MV
80006040	PUMP-VAR-DISPL CCW 90PV130	90L130-KN-5-DE-80-R-4-F1-H-03-GBA-26-26-24	SERIES 90	S90-130PV
80006041	PUMP-VAR-DISPL CW 90PV250	90R250-KP-5-BC-80-T-4-F1-J-03-NNN-29-29-24	SERIES 90	S90-250PV
80006044	MOTOR-VAR-DISPL 51MD060-1	51D060-1--A-D2-N-TA-C2-N-N-X1-NNN-030-AA-E6-00-28	SERIES 51	S51-060MV-1
80006046	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-N-B2-B3-N-N-U3-ADA-017-AA-NN-00-00	SERIES 51	S51-060MV-1
80006048	PUMP-VAR DISPL, CW 90PV055	90-R-055-HF-5-BG-80-P-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV

80006051	MOTOR-VAR-DISPL 51MV110	51V110-R-C8-N-D7-M1-S-K-M1-ANA-022-AA-E6-F4-17	SERIES 51	S51-110MV
80006055	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A9-C2-N-E6-F-G4-H3-L-35-L-35-B-L-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
80006056	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-5-BC-80-L-3-S1-E-03-GBA-32-32-24	SERIES 90	S90-100PV
80006057	MOTOR-VAR-DISPL 51MD080-1	51D080-1--R-D3-N-E1-B1-N-N-U1-NNN-035-AA-NN-00-00	SERIES 51	S51-080MV-1
80006060	PUMP-VAR-DISPL CW 90PV180	90R180-KN-5-BC-80-T-M-F1-H-03-FAC-14-14-24	SERIES 90	S90-180PV
80006062	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A8-C2-D-D6-F-G5-H2-L-40-L-40-B-L-32-P1-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
80006066	PUMP-VAR DISPL, CW 90PV100	90-R-100-M8-1-BC-60-P-3-C7-E-03-GBA-42-42-20	SERIES 90	S90-100PV
80006067	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-BB-80-P-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
80006068	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-BC-60-S-3-S1-C-03-GBA-20-20-24	SERIES 90	S90-055PV
80006069	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-NN-80-P-3-C8-F-04-GBA-32-32-22	SERIES 90	S90-130PV
80006078	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-L1-B1-W-B-G5-ACA-056-AA-F3-D4-00	SERIES 51	S51-160MV
80006079	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-L1-B1-W-B-G5-ACA-090-AA-G0-D4-00	SERIES 51	S51-250MV
80006084	MOTOR-VAR DISPL MMV046C	MMV-046-C-A-A-B-B-AV-VNC-***	M46	M46-046MV
80006085	MOTOR-VAR DISPL MMV046C	MMV-046-C-A-A-B-B-AH-NNN-***	M46	M46-046MV
80006090	MOTOR-VAR DISPL MMV046C	MMV-046-C-A-A-B-B-AM-NNN-***	M46	M46-046MV
80006091	MOTOR-VAR-DISPL 51MD060-1	51D060-1--A-D1-N-T1-D1-N-N-X1-NNN-027-AA-E6-00-28	SERIES 51	S51-060MV-1
80006092	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A2-C2-N-E7-F-G5-H3-35-35-35-35-N-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
80006093	PUMP-VAR DISPL, CW 90PV055	90-R-055-PA-5-CD-80-L-4-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
80006094	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-5-AB-60-S-3-C6-C-09-GBA-29-29-30	SERIES 90	S90-055PV
80006102	PUMP-VAR-DISPL CW 90PV075	90R075-FM-5-BC-60-P-7-C7-E-B6-EFP-42-42-30	SERIES 90	S90-075PV
80006103	MOTOR-VAR DISPL MMV046C	MMV-046-C-A-A-B-B-AF-VNC-***	M46	M46-046MV
80006104	MOTOR-VAR DISPL MMV046C	MMV-046-C-A-A-B-B-A4-VNC-***	M46	M46-046MV
80006105	MOTOR-VAR DISPL MMV046C	MMV-046-C-B-L-B-C-AD-NNN-***	M46	M46-046MV
80006106	MOTOR-VAR DISPL MMV046C	MMV-046-C-A-A-L-C-AF-VNC-***	M46	M46-046MV
80006107	MOTOR-VAR DISPL MMV046C	MMV-046-C-A-A-L-C-A4-VNC-***	M46	M46-046MV
80006110	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-CD-80-T-3-F1-J-03-NNN-14-14-24	SERIES 90	S90-250PV
80006114	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-G-T-B-B-AA-A-A-BJJ-CD-A-GG-C-NNN-***	M46	M46-046PV
80006116	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A2-C2-B-F3-F-G5-H3-J-40-J-40-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
80006119	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-TA-C0-L-N-G0-NNN-125-AA-F3-00-B0	SERIES 51	S51-160MV
80006121	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-CD-80-P-3-S1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
80006122	MOTOR-VAR-DISPL 51MD060-1	51D060-1--A-D2-N-T2-C2-N-N-X1-NNN-015-AA-E4-00-20	SERIES 51	S51-060MV-1
80006123	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A4-C2-B-D6-G-G2-H2-L-25-L-25-L-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
80006125	MOTOR-VAR DISPL MMV046C	MMV-046-C-A-A-A-B-AE-VNC-***	M46	M46-046MV
80006126	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D3-N-E2-B1-N-N-U1-ADA-017-AA-E6-00-00	SERIES 51	S51-080MV-1
80006128	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-CD-80-P-4-C7-E-03-GBA-23-23-24	SERIES 90	S90-100PV
80006129	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-NN-80-P-3-C3-B-04-EFC-26-26-20-N315	SERIES 90	S90-042PV

80006131	MOTOR-VAR-DISPL 51MD160	51D160-R-D5-N-T2-C2-L-N-G0-NNN-080-AA-F0-00-C5	SERIES 51	S51-160MV
80006132	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-AB-80-R-3-S1-D-00-GBA-26-26-24	SERIES 90	S90-075PV
80006133	PUMP-VAR-DISPL CW 90PV130	90R130-MA-5-AB-80-P-3-F1-H-C5-GBA-32-32-24	SERIES 90	S90-130PV
80006134	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-D-S-B-B-BA-A-A-BBB-CE-A-JJ-B-NNN-***	M46	M46-046PV
80006137	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-NN-60-P-4-S1-E-03-GBA-26-26-24	SERIES 90	S90-075PV
80006138	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-2-AB-80-S-4-C8-F-04-GBA-42-42-24	SERIES 90	S90-130PV
80006142	PUMP-VAR-DISPL CW 90PV100	90R100-MA-5-CD-60-L-4-C7-E-C7-GBA-29-29-24	SERIES 90	S90-100PV
80006143	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-CD-80-S-3-C8-H-03-GBA-26-26-28	SERIES 90	S90-130PV
80006144	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-A-V-C-B-BA-B-A-B-A-BDD-AK-U-ED-B-C-B-A-BDD-CB-A-GG-A-NNN-	M46	M46-046PT
80006145	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-A-V-C-B-BA-B-A-B-A-BDD-AK-U-ED-B-D-B-A-BDD-CB-A-GG-A-NNN-	M46	M46-046PT
80006146	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-BC-60-S-4-C6-D-03-GBA-42-42-24	SERIES 90	S90-075PV
80006147	MOTOR-VAR-DISPL 51MD110-1	51D110-1--R-D3-N-T1-CA-N-N-X1-NNN-050-AA-F0-00-25	SERIES 51	S51-110MV-1
80006148	PUMP-VAR DISPL CCW H1P053L	H1-P-053-L-A-A2-C2-N-E5-F-G5-H5-L-35-L-35-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
80006149	PUMP-VAR DISPL CCW H1P053L	H1-P-053-L-A-A2-C2-N-E5-F-G5-H2-L-35-L-35-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
80006152	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-NN-80-S-4-S1-E-03-GBA-38-38-24	SERIES 90	S90-100PV
80006153	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A4-C2-N-E9-F-G5-NN-K-35-K-35-B-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
80006155	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-NN-80-R-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
80006156	PUMP-VAR-DISPL CW 90PV075	90R075-FK-5-BC-80-P-7-C7-D-B6-GME-42-42-30	SERIES 90	S90-075PV
80006161	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-5-NN-80-S-3-S1-E-03-EBC-42-42-24	SERIES 90	S90-100PV
80006162	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-NN-80-P-3-C6-C-03-GBA-29-29-20	SERIES 90	S90-055PV
80006163	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-HZ-B1-A-N-G0-ACA-050-AA-G3-03-00	SERIES 51	S51-160MV
80006166	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-AB-60-S-3-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
80006167	PUMP-VAR-DISPL CCW 90PV180	90L180-KN-5-EF-80-T-M-F1-H-03-FAC-26-26-24	SERIES 90	S90-180PV
80006168	PUMP-VAR DISPL, CW 90PV055	90-R-055-CB-5-BK-80-R-3-S1-B-00-GBA-38-38-24	SERIES 90	S90-055PV
80006169	PUMP-VAR-DISPL CW 90PV130	90R130-KN-5-DE-80-R-4-F1-H-03-GBA-35-35-24	SERIES 90	S90-130PV
80006170	PUMP-VAR-DISPL CCW H1PV165	H1-P-165-L-C-A5-C3-B-D3-G-G3-NN-K-35-K-35-A-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
80006174	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-CD-80-P-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
80006175	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-CD-60-S-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
80006176	PUMP-VAR DISPL, CW 90PV100	90-R-100-HS-1-CD-60-S-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
80006180	PUMP, VARIABLE DIRECT DISPLACMENT	LPV-B-A-A-A-A-G-AC-C-A-BJJ-DR-A-FF-B-NNN-***	LPV	LPV
80006181	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-NN-80-P-4-S1-C-02-GBA-35-35-24	SERIES 90	S90-055PV
80006182	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-1-CD-80-R-3-S1-D-03-GBA-23-23-24	SERIES 90	S90-055PV
80006183	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-1-BG-80-R-3-S1-D-03-GBA-23-23-24	SERIES 90	S90-055PV
80006184	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-BC-60-S-4-C7-F-03-GBA-35-35-24	SERIES 90	S90-100PV
80006186	MOTOR-VAR-DISPL 51MD060-1	51D060-1--A-D1-N-T1-D1-N-N-X1-ADA-027-AA-E6-00-28	SERIES 51	S51-060MV-1
80006189	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-EQ-A5-J-Y-A6-ADA-035-AA-F0-30-00	SERIES 51	S51-160MV

80006191	PUMP-VAR-DISPL CW 90PV100	90R100-FG-5-BB-60-S-7-C7-F-B1-EFC-42-42-30	SERIES 90	S90-100PV
80006192	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-BC-80-L-4-C8-F-05-GBA-29-29-24	SERIES 90	S90-130PV
80006193	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A3-C2-B-F1-F-G5-H2-K-35-K-35-B-L-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
80006194	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-C8-N-E2-B1-N-N-U1-NNN-045-AA-F0-00-00	SERIES 51	S51-110MV-1
80006195	PUMP-VAR-DISPL CCW 90PV130	90L130-CA-5-NN-80-S-7-C8-F-00-GBA-42-42-30	SERIES 90	S90-130PV
80006196	MOTOR-VAR-DISPL 51MC160	51C160-A-D5-N-HZ-B1-C-H-C2-NNN-040-AA-NN-15-00	SERIES 51	S51-160MV
80006197	MOTOR-VAR-DISPL 51MD110-1	51D110-1--R-D3-N-P7-P7-N-N-X1-AWM-036-AA-F0-00-AA	SERIES 51	S51-110MV-1
80006198	MOTOR-VAR-DISPL 51MD160	51D160-A-D4-N-TM-E7-L-N-J2-ADA-045-AA-F3-00-BB	SERIES 51	S51-160MV
80006199	MOTOR-VAR-DISPL 51MV160	51V160-A-D5-N-HZ-B1-C-H-C2-NNN-040-AA-NN-15-00	SERIES 51	S51-160MV
80006201	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D3-N-E2-B1-N-N-U1-NNN-026-AA-E4-00-00	SERIES 51	S51-080MV-1
80006202	MOTOR-VAR-DISPL 51MV160	51V160-A-C8-N-DA-M4-R-J-N1-ADA-040-AA-E6-C2-20	SERIES 51	S51-160MV
80006215	MOTOR-VAR-DISPL 51MD160	51D160-A-D4-N-D8-M1-R-J-M4-ADA-060-AA-F3-C2-25	SERIES 51	S51-160MV
80006216	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-TH-C2-L-N-G0-NNN-050-AA-NN-00-B2	SERIES 51	S51-250MV
80006217	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-TA-C2-L-N-G0-NNN-070-AA-NN-00-B1	SERIES 51	S51-160MV
80006218	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-TA-C2-L-N-G0-NNN-070-AA-F0-00-B1	SERIES 51	S51-160MV
80006219	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-BC-80-S-3-C7-F-03-GBA-42-42-24	SERIES 90	S90-100PV
80006220	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MA-1-CD-60-S-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
80006221	MOTOR-VAR-DISPL 51MV250	51V250-V-F2-N-HS-A2-C-H-E1-NNN-125-AA-NN-20-17	SERIES 51	S51-250MV
80006223	MOTOR-VAR-DISPL 51MD080-1	51D080-1--A-D2-N-T1-D1-N-N-X1-NNN-020-AA-NN-00-29	SERIES 51	S51-080MV-1
80006226	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D2-N-E2-B1-N-N-U1-NNN-030-AA-F0-00-00	SERIES 51	S51-080MV-1
80006229	MOTOR-VARIABLE DISPL SAE_K	K-V-45DN-A-R1F-F09-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
80006230	PUMP-VAR DISPL MPV025C	MPV-025-C-B-A-A-L-A-E-NN-A-A-BJJ-DR-A-FF-A-NNN-***	LIGHT DUTY	025PV
80006232	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-CD-80-R-3-F1-H-03-GBA-23-23-24	SERIES 90	S90-130PV
80006233	PUMP-VAR DISPL, CW 90PV100	90-R-100-MB-1-NN-60-P-3-C7-E-04-GBA-38-38-24	SERIES 90	S90-100PV
80006235	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-BC-80-L-3-F1-H-03-GBA-42-42-24	SERIES 90	S90-130PV
80006236	MOTOR-VAR-DISPL 51MD080-1	51D080-1--R-D3-N-N1-NN-N-N-U1-NNN-035-AA-NN-00-00	SERIES 51	S51-080MV-1
80006239	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A8-C2-D-E8-G-G2-H2-L-45-L-45-L-L-24-P1-NNN-G14	H1-HP PUMPS	H1-115PV/130PV
80006240	PUMP-VAR-DISPL CCW H1PV147	H1-P-147-L-C-A5-C2-N-D6-G-G3-NN-L-35-L-35-A-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
80006248	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-1-BG-80-S-3-T1-C-03-GBA-29-29-24	SERIES 90	S90-055PV
80006249	PUMP-VAR-DISPL CCW 90PV180	90L180-KN-5-EF-80-T-M-F1-H-03-FAC-35-35-24	SERIES 90	S90-180PV
80006252	PUMP-VAR-DISPL CCW H1PV147	H1-P-147-L-C-A5-C2-N-D6-G-G3-H3-L-35-L-35-A-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
80006253	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-CD-80-S-3-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
80006254	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-1-CD-80-S-3-S1-D-03-GBA-29-29-24	SERIES 90	S90-055PV
80006255	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-A-V-C-J-BA-B-A-A-A-BJJ-AB-U-BB-B-C-A-A-BJJ-AB-U-BB-B-NNN-***	M46	M46-046PT
80006260	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A2-C2-N-D3-H-G1-H5-L-30-L-40-F-M-28-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
80006262	MOTOR-VAR-DISPL 51MV110-1	51V110-1--A-F1-N-TA-C2-N-N-X1-NNN-070-AA-NN-00-15	SERIES 51	S51-110MV-1

80006266	PUMP-VAR DISPL, CW 90PV075	90-R-075-HF-1-BC-80-R-4-S1-D-03-GBA-32-32-24	SERIES 90	S90-075PV
80006269	PUMP-VAR-DISPL CW 90PV100	90R100-MA-5-CD-80-S-4-F1-E-C4-GBA-45-45-30-F023	SERIES 90	S90-100PV
80006271	MOTOR-VAR-DISPL 51MD060-1	51D060-1--R-D1-N-TA-CA-N-N-X1-NNN-024-AA-F3-00-16	SERIES 51	S51-060MV-1
80006272	PUMP-VAR-DISPL CW 90PV130	90R130-HS-5-CD-80-P-3-F1-H-03-GBA-23-23-28	SERIES 90	S90-130PV
80006273	PUMP-VAR-DISPL CW 90PV075	90R075-DD-5-CD-80-S-3-S1-C-GB-GBA-45-35-24	SERIES 90	S90-075PV
80006275	PUMP-VAR-DISPL CW 90PV042	90R042-MA-5-BC-80-P-3-C3-C-C5-GBA-29-29-24	SERIES 90	S90-042PV
80006276	PUMP-VAR-DISPL CW 90PV042	90R042-MA-5-NN-80-P-3-C3-C-C5-GBA-29-29-24	SERIES 90	S90-042PV
80006277	PUMP-VAR-DISPL CCW 90PV180	90L180-KP-5-CD-80-T-M-C8-H-06-FAC-38-38-24	SERIES 90	S90-180PV
80006278	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-BB-80-R-3-S1-D-03-GBA-32-32-24	SERIES 90	S90-075PV
80006279	PUMP-VAR DISPL, CW 90PV075	90-R-075-HF-1-CD-80-R-4-K2-D-03-GBA-32-32-24	SERIES 90	S90-075PV
80006280	PUMP-VAR DISPL, CW 90PV075	90-R-075-HF-1-BC-80-R-4-K2-D-03-GBA-32-32-24	SERIES 90	S90-075PV
80006281	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-5-NN-80-S-3-S1-C-GB-GBA-35-35-24	SERIES 90	S90-055PV
80006282	PUMP-VAR DISPL, CW 90PV055	90-R-055-FA-5-AD-80-S-7-C6-D-B2-EFI-40-40-30	SERIES 90	S90-055PV
80006283	PUMP-VAR DISPL, CW 90PV100	90-R-100-NA-5-NN-80-L-3-C7-E-76-GLA-42-42-26	SERIES 90	S90-100PV
80006284	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-S1-N-TA-C2-N-N-X1-NNN-031-AA-NN-00-13	SERIES 51	S51-080MV-1
80006285	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-BG-80-R-3-S1-B-03-GBA-38-38-24	SERIES 90	S90-055PV
80006286	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-B-L2-B1-V-A-G5-NNN-050-AA-F0-B2-00	SERIES 51	S51-250MV
80006287	MOTOR-VAR-DISPL 51MD160	51D160-R-D5-N-E2-A5-A-N-A6-NNN-035-AA-F3-03-00	SERIES 51	S51-160MV
80006288	MOTOR-VAR-DISPL 51MC060	51C060-R-D1-A-L2-B1-V-A-C0-NNN-015-AA-F0-B2-00	SERIES 51	S51-060MV
80006289	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-AB-80-L-4-C7-F-03-GBA-42-42-24-F003	SERIES 90	S90-100PV
80006290	MOTOR-VAR-DISPL 51MD110-1	51D110-1--R-D3-N-P8-P8-N-N-X1-NNN-049-AA-F3-00-AA	SERIES 51	S51-110MV-1
80006291	PUMP-VAR-DISPL CW 90PV250	90R250-HF-5-CD-80-T-4-C8-K-03-NNN-35-35-28	SERIES 90	S90-250PV
80006292	PUMP-VAR-DISPL CW 90PV075	90R075-HF-5-CD-80-R-4-S1-D-03-GBA-35-35-28	SERIES 90	S90-075PV
80006294	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-K-S-B-J-BA-A-B-BFF-CB-A-JJ-B-NNN-***	M46	M46-046PV
80006295	PUMP-VAR-DISPL CW 90PV250	90R250-MA-5-CD-80-S-3-F1-K-C5-NNN-35-35-24	SERIES 90	S90-250PV
80006296	MOTOR-VAR-DISPL 51MV110	51V110-R-F1-N-EQ-A2-J-Z-G6-NNN-050-AA-F3-15-34	SERIES 51	S51-110MV
80006297	MOTOR-VAR-DISPL 51MD110-1	51D110-1--R-D3-N-E2-B1-N-N-U1-NNN-060-AA-F0-00-00	SERIES 51	S51-110MV-1
80006299	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A3-C2-B-F4-H-G9-H6-L-25-L-25-C-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
80006300	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-K-S-B-B-BA-G-A-BFF-BA-A-HH-B-NNN-***	M46	M46-046PV
80006301	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-NN-80-R-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
80006302	PUMP-VAR-DISPL CW 90PV075	90R075-HF-5-BB-80-R-4-S1-D-03-GBA-35-35-28	SERIES 90	S90-075PV
80006303	MOTOR-VAR-DISPL 51MD080-1	51D080-1--R-D2-N-P7-P7-N-N-X1-NNN-026-AA-F0-00-AA	SERIES 51	S51-080MV-1
80006304	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-AD-80-P-4-C6-C-03-GBA-42-42-24	SERIES 90	S90-055PV
80006305	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-CD-80-S-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-075PV
80006306	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-T2-C0-L-N-G0-ACB-100-AA-G0-00-B5	SERIES 51	S51-250MV
80006310	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-N2-NN-N-N-A0-NNN-100-AA-G0-00-00	SERIES 51	S51-250MV

80006321	PUMP-VAR DISPL, CW 90PV100	90-R-100-HS-1-BC-80-R-3-S1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
80006325	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A4-C2-N-D8-G-G3-H6-L-40-L-40-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
80006328	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A4-C2-N-D8-G-G3-H6-L-42-L-42-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
80006329	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A2-C2-N-D3-G-G3-H6-L-30-L-40-L-M-28-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
80006330	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-N-TH-C2-L-N-G0-ACA-057-AA-G0-00-B9	SERIES 51	S51-160MV
80006331	PUMP-VAR-DISPL CW 90PV180	90R180-KP-5-CD-80-T-C-F1-J-03-FAC-23-23-28	SERIES 90	S90-180PV
80006333	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-BB-80-P-3-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
80006335	PUMP-TANDEM, VAR DISPL MPT044D	MPT-044-D-A-W-S-J-AA-B-A-A-A-BDD-DR-A-FF-B-C-A-A-BDD-DL-A-FF-B-NNN-*	M35/44	044PT
80006337	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-1-BC-60-R-3-S1-B-03-GBA-38-38-24	SERIES 90	S90-055PV
80006339	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-D8-M1-R-J-N1-ANB-050-AA-G0-C2-18	SERIES 51	S51-250MV
80006340	PUMP-VAR-DISPL CW 90PV100	90R100-PB-1-BC-80-L-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
80006341	MOTOR-VAR-DISPL 51MC080	51C080-R-D3-N-HZ-B1-A-N-C2-ANA-043-AA-F0-03-00	SERIES 51	S51-080MV
80006342	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D3-N-N1-NN-N-N-U1-NNN-054-AA-E4-00-00	SERIES 51	S51-080MV-1
80006343	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-NN-80-R-4-T6-F-03-GBA-26-32-26	SERIES 90	S90-100PV
80006346	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-S1-N-B2-B3-N-N-U3-ABA-054-AA-F0-00-00	SERIES 51	S51-080MV-1
80006351	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A4-C1-N-F1-F-G4-H2-K-35-K-35-B-L-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
80006352	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-CD-80-S-3-C8-H-03-EFI-20-20-24	SERIES 90	S90-130PV
80006354	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-NN-80-S-3-F1-E-03-GBA-35-35-22	SERIES 90	S90-100PV
80006355	PUMP-VAR-DISPL CW 90PV042	90R042-DD-5-BC-80-S-4-C3-C-GB-GBA-32-32-20	SERIES 90	S90-042PV
80006357	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-NN-60-L-4-S1-C-03-GBA-42-42-24	SERIES 90	S90-075PV
80006366	PUMP-VAR DISPL, CW 90PV055	90-R-055-MV-1-NN-80-L-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-055PV
80006372	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A5-C2-N-D8-G-G2-H3-L-42-L-42-A-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
80006375	PUMP-VAR DISPL, CW 90PV075	90-R-075-NA-1-NN-80-L-3-C7-D-03-GBA-42-42-24	SERIES 90	S90-075PV
80006377	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-CD-80-S-3-C8-H-06-GBA-26-26-24	SERIES 90	S90-130PV
80006378	MOTOR-VAR-DISPL 51MD080-1	51D080-1--A-D3-N-T1-CA-N-N-X1-NNN-030-AA-F0-00-24	SERIES 51	S51-080MV-1
80006379	PUMP-VAR-DISPL CW 90PV180	90R180-DD-5-CD-80-T-M-C8-H-GB-NNN-45-45-24	SERIES 90	S90-180PV
80006381	PUMP-VAR-DISPL CCW 90PV075	90L075-FL-1-NN-80-P-7-C7-D-B6-GME-38-38-30	SERIES 90	S90-075PV
80006383	PUMP-VAR-DISPL CW 90PV130	90R130-HS-5-CD-80-P-3-F1-H-03-GBA-24-24-28	SERIES 90	S90-130PV
80006387	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-BC-80-P-3-T2-E-03-GBA-38-38-24	SERIES 90	S90-100PV
80006388	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D3-N-E2-B1-N-N-U1-ACB-024-AA-E6-00-00	SERIES 51	S51-080MV-1
80006389	PUMP-VAR-DISPL CW 90PV100	90R100-MN-1-CD-60-R-3-C7-D-04-FAD-35-35-26	SERIES 90	S90-100PV
80006390	PUMP-VAR-DISPL CW 90PV130	90R130-HS-5-BB-80-P-3-F1-H-03-GBA-24-24-28	SERIES 90	S90-130PV
80006391	PUMP-VAR-DISPL CCW 90PV130	90L130-HS-5-CD-80-R-3-F1-H-03-GBA-24-24-28	SERIES 90	S90-130PV
80006392	PUMP-VAR-DISPL CCW 90PV130	90L130-HS-5-CD-80-P-3-F1-H-03-GBA-24-24-28	SERIES 90	S90-130PV
80006412	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A2-C2-N-D3-H-G1-NN-L-30-L-40-F-M-28-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
80006414	PUMP-VAR-DISPL CW 90PV250	90R250-MA-5-NN-80-T-3-C8-K-C4-NNN-32-32-30	SERIES 90	S90-250PV

80006417	PUMP-VAR-DISPL CW 90PV130	90R130-MA-5-BC-80-L-3-F1-F-C5-GBA-42-42-24	SERIES 90	S90-130PV
80006421	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D3-N-N1-NN-N-N-U1-ADA-018-AA-F3-00-00	SERIES 51	S51-080MV-1
80006424	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A2-C2-N-D3-G-G3-H6-L-30-L-40-L-M-28-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
80006427	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-CD-80-R-3-S1-C-03-GBA-26-26-24	SERIES 90	S90-055PV
80006430	MOTOR-VAR-DISPL 51MC060	51C060-R-D2-N-L2-B1-V-A-C0-ABA-012-AA-E4-B2-00	SERIES 51	S51-060MV
80006431	MOTOR-VAR-DISPL 51MD110	51D110-R-D3-N-L2-B1-V-A-C0-AHA-022-AA-E6-B2-00	SERIES 51	S51-110MV
80006435	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-HS-A2-B-E-G6-ABA-070-AA-H0-08-37	SERIES 51	S51-160MV
80006436	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-AB-60-S-4-C6-E-03-GBA-23-23-24	SERIES 90	S90-075PV
80006437	PUMP-VAR-DISPL CW 90PV250	90R250-HF-5-EG-80-T-4-C8-K-03-NNN-35-35-28	SERIES 90	S90-250PV
80006438	PUMP-VAR-DISPL CW 90PV042	90R042-DD-5-BB-80-S-4-C3-C-GB-GBA-40-40-20	SERIES 90	S90-042PV
80006439	PUMP-VAR-DISPL CW 90PV042	90R042-DD-5-AB-80-S-4-C3-C-GB-GBA-40-40-20	SERIES 90	S90-042PV
80006441	PUMP-VAR-DISPL CW 90PV250	90R250-HF-5-BB-80-T-4-C8-K-03-NNN-35-35-28	SERIES 90	S90-250PV
80006444	PUMP, VARIABLE DIRECT DISPLACMENT	LPV-B-A-A-A-E-AC-C-A-BBB-DR-A-FF-B-NNN-***	LPV	LPV
80006445	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-BB-80-S-4-C5-C-03-GBA-40-40-20	SERIES 90	S90-042PV
80006446	PUMP-VAR-DISPL CW 90PV250	90R250-HF-5-DE-80-T-4-C8-K-03-NNN-26-26-28	SERIES 90	S90-250PV
80006447	PUMP-VAR-DISPL CW 90PV130	90R130-HF-5-DE-80-R-4-F1-F-03-GBA-26-26-28	SERIES 90	S90-130PV
80006449	PUMP-TANDEM, VAR DISPL CCW H1T045L	H1-T-045-L-A-N-A5-C1-N-E7-F-G1-H3-35-35-35-35-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
80006450	PUMP-VAR-DISPL CW 90PV042	90R042-HF-5-AB-80-P-4-C3-C-03-GBA-42-42-24	SERIES 90	S90-042PV
80006451	PUMP-VAR-DISPL CW 90PV180	90R180-KP-5-CD-80-T-C-F1-J-03-FAC-24-24-28	SERIES 90	S90-180PV
80006455	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-5-BB-60-D-3-S1-L-C5-GBA-42-42-24	SERIES 90	S90-055PV
80006457	PUMP-VAR DISPL, CW 90PV075	90-R-075-MB-1-CD-60-P-3-C7-D-03-GBA-38-38-24	SERIES 90	S90-075PV
80006458	PUMP-TANDEM, VAR DISPL MPT044D	MPT-044-D-A-Y-R-E-AA-B-A-A-A-BGG-DR-A-FF-B-A-A-A-BGG-DR-A-FF-C-NNN-*	M35/44	044PT
80006461	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-AF-80-R-4-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
80006462	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-CD-80-T-C-C8-J-03-NNN-42-42-24	SERIES 90	S90-180PV
80006465	PUMP-VAR-DISPL CW 90PV130	90R130-CB-5-CD-80-S-3-C8-F-00-GBA-42-42-24	SERIES 90	S90-130PV
80006466	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-NN-80-T-3-C8-K-03-NNN-14-14-24	SERIES 90	S90-250PV
80006470	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-N-A4-C2-N-E7-F-G5-NN-35-35-35-35-N-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
80006472	MOTOR- VARIABLE CARTRIDGE L	L-C-25CN-A-RNF-F01-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
80006476	MOTOR-VAR-DISPL 51MC110-1	51C110-1--R-D3-N-N1-NN-N-N-U1-NNN-060-AA-NN-00-00	SERIES 51	S51-110MV-1
80006481	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A2-C2-N-D1-F-G5-H3-38-38-38-38-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
80006484	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A4-C1-N-E6-F-G5-H5-L-30-L-30-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
80006485	MOTOR-VAR-DISPL 51MD160	51D160-R-D5-N-D8-M1-R-J-N7-NNN-034-AA-E6-C2-35	SERIES 51	S51-160MV
80006486	PUMP-VAR-DISPL CCW 90PV075	90L075-HF-5-NN-80-R-3-C7-D-06-GBA-42-42-24	SERIES 90	S90-075PV
80006487	PUMP-VAR-DISPL CCW 90PV075	90L075-HF-5-CD-80-R-3-C7-D-06-GBA-42-42-24	SERIES 90	S90-075PV
80006489	MOTOR-VAR-DISPL 51MC160	51C160-R-D4-N-HZ-B1-C-N-C2-NNN-080-AA-NN-15-00	SERIES 51	S51-160MV
80006492	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-N-A2-C2-B-D1-F-G5-H3-35-35-35-35-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT

80006493	MOTOR-VAR-DISPL 51MC160	51C160-R-D4-N-L2-B1-V-A-C0-NNN-065-AA-F3-B2-00	SERIES 51	S51-160MV
80006494	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-BB-80-R-3-C8-H-03-GBA-26-14-24	SERIES 90	S90-130PV
80006495	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-BB-80-R-3-C8-H-03-GBA-32-14-24	SERIES 90	S90-130PV
80006496	MOTOR-VAR-DISPL 51MC080-1	51C080-1--A-D3-N-E2-B1-N-N-U1-ACB-028-AA-E6-00-00	SERIES 51	S51-080MV-1
80006497	MOTOR-VAR-DISPL 51MC080-1	51C080-1--A-D3-N-N1-NN-N-N-U1-NNN-054-AA-F3-00-00	SERIES 51	S51-080MV-1
80006500	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-TA-C2-L-N-G0-NNN-075-AA-NN-00-A7	SERIES 51	S51-160MV
80006501	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-N1-NN-N-N-U1-NNN-055-AA-F0-00-00	SERIES 51	S51-110MV-1
80006502	PUMP-VAR-DISPL CW 90PV180	90R180-DD-5-BC-80-S-7-C8-H-G1-GLA-29-29-24	SERIES 90	S90-180PV
80006503	PUMP-VAR DISPL, CW 90PV055	90-R-055-HS-1-AB-60-S-4-S1-B-03-GBA-42-42-24	SERIES 90	S90-055PV
80006512	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A5-C2-N-D8-F-G5-H5-L-25-L-25-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
80006513	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A5-C2-N-D8-F-G5-H5-L-35-L-35-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
80006525	PUMP-VAR-DISPL CW 90PV180	90R180-HF-5-EG-80-S-C-C8-J-03-NNN-35-35-24	SERIES 90	S90-180PV
80006526	PUMP-VAR-DISPL CW 90PV180	90R180-HF-5-NN-80-S-C-C8-J-03-NNN-35-35-24	SERIES 90	S90-180PV
80006527	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-BB-80-L-4-F1-H-03-GBA-30-30-24	SERIES 90	S90-130PV
80006528	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A5-C2-B-D5-G-G2-H4-L-35-L-35-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
80006544	PUMP-VAR-DISPL CW 90PV130	90R130-KN-5-NN-80-S-4-C8-H-03-GBA-42-42-20	SERIES 90	S90-130PV
80006546	PUMP-VAR-DISPL CW 90PV180	90R180-KN-5-EF-80-T-M-F1-H-03-FAC-14-14-24	SERIES 90	S90-180PV
80006552	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A7-C2-C-F3-J-G5-H2-K-35-K-35-B-L-20-P2-NNN-D3A	H1-MP PUMPS	H1-045PV/053PV
80006557	PUMP-VAR DISPL, CW 90PV100	90-R-100-MB-1-NN-80-S-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
80006558	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-NN-80-S-3-C6-C-05-GBA-35-35-30	SERIES 90	S90-055PV
80006561	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-2-CD-60-L-4-C7-E-02-GBA-42-42-24	SERIES 90	S90-100PV
80006562	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-2-NN-60-L-4-S1-E-02-GBA-42-42-24	SERIES 90	S90-100PV
80006566	PUMP-VAR-DISPL CCW 90PV042	90L042-HK-5-NN-80-R-3-C3-B-03-GBA-32-32-24	SERIES 90	S90-042PV
80006567	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A3-C2-N-F5-H-G1-H6-L-35-L-35-F-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
80006568	PUMP-VAR DISPL, CW 90PV055	90-R-055-HF-1-BG-80-L-4-S1-C-03-GBA-29-29-24	SERIES 90	S90-055PV
80006570	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-C-E1-B1-N-N-U1-NNN-050-AA-NN-00-00	SERIES 51	S51-110MV-1
80006575	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-J-S-B-B-AA-G-A-BGG-DA-A-WA-A-NNN-***	M46	M46-046PV
80006580	PUMP-VAR DISPL, CW 90PV055	90-R-055-KN-5-CD-80-S-3-C6-C-03-GBA-32-32-24	SERIES 90	S90-055PV
80006581	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-AC-80-S-3-F1-E-04-FAD-42-42-24	SERIES 90	S90-100PV
80006583	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A4-C1-N-E7-F-G1-H3-33-33-33-33-N-P-30-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
80006584	MOTOR-VAR-DISPL 51MC080	51C080-R-D3-N-L2-B1-V-A-C0-NNN-016-AA-E6-B2-00	SERIES 51	S51-080MV
80006585	MOTOR-VARIABLE CARTRIDGE K	K-C-38CS-E-RNF-F08-S-N-N-EF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
80006586	MOTOR-VARIABLE CARTRIDGE K	K-C-45DS-E-RNF-F08-S-N-N-CF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
80006588	PUMP-VAR-DISPL CCW 90PV180	90L180-HF-5-BC-80-T-C-C8-H-03-NNN-32-32-24	SERIES 90	S90-180PV
80006590	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-NN-60-R-3-C6-C-03-GBA-32-32-20	SERIES 90	S90-055PV
80006594	MOTOR-VAR-DISPL 51MV110	51V110-R-C8-N-N2-NN-N-N-A0-NNN-040-AA-NN-00-00	SERIES 51	S51-110MV

80006595	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-HZ-B1-B-H-G5-NNN-060-AA-F0-06-00	SERIES 51	S51-160MV
80006596	MOTOR-VAR-DISPL 51MV060	51V060-R-S1-N-HZ-B1-B-N-C2-NNN-032-AA-E6-10-00	SERIES 51	S51-060MV
80006599	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HS-5-BC-60-L-3-F1-E-04-GBA-35-35-24	SERIES 90	S90-100PV
80006602	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-N-L2-B1-V-A-G5-ACA-045-AA-G0-B2-00	SERIES 51	S51-160MV
80006608	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-CD-80-S-3-F1-F-03-GBA-40-40-24	SERIES 90	S90-100PV
80006610	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-BB-80-L-3-F1-F-03-GBA-38-38-24	SERIES 90	S90-130PV
80006611	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A8-C2-C-D8-F-G5-H2-L-40-L-40-B-P-20-P1-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
80006613	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-TA-CA-N-N-X1-NNN-057-AA-E6-00-30	SERIES 51	S51-110MV-1
80006615	PUMP-VAR-DISPL CW 90PV180	90R180-KN-5-BC-80-S-C-C8-J-03-NNN-29-29-24	SERIES 90	S90-180PV
80006619	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-NN-60-S-4-T1-D-00-GBA-35-35-24	SERIES 90	S90-075PV
80006620	PUMP-VAR DISPL, CW 90PV055	90-R-055-HS-1-CD-80-R-3-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV
80006621	PUMP-VAR DISPL, CW 90PV055	90-R-055-HS-1-NN-80-R-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
80006623	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-CD-80-L-1-F1-H-04-GBA-45-45-24	SERIES 90	S90-130PV
80006624	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-5-AB-80-L-3-S1-E-04-GBA-42-42-24	SERIES 90	S90-075PV
80006627	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-NN-80-P-3-C3-C-04-GBA-26-26-22	SERIES 90	S90-042PV
80006631	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-CD-80-P-3-F1-E-00-GBA-32-32-24	SERIES 90	S90-100PV
80006632	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-CD-80-P-3-S1-E-00-GBA-35-35-24	SERIES 90	S90-100PV
80006633	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-NN-80-P-3-S1-D-00-GBA-35-35-24	SERIES 90	S90-075PV
80006634	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-TH-C0-L-N-G0-NNN-056-AA-G0-00-B5	SERIES 51	S51-160MV
80006638	PUMP-VAR-DISPL CCW 90PV075	90L075-DC-5-NN-80-S-4-S1-E-GB-GBA-35-35-24	SERIES 90	S90-075PV
80006640	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-NN-80-R-3-S1-F-00-GBA-29-29-24	SERIES 90	S90-100PV
80006643	MOTOR-VAR-DISPL 51MV080	51V080-R-C7-N-N2-NN-N-N-A0-NNN-060-AA-F3-00-00	SERIES 51	S51-080MV
80006645	PUMP-VAR-DISPL CW 90PV075	90R075-MA-5-AB-60-S-3-C6-E-C5-FAX-45-45-26	SERIES 90	S90-075PV
80006646	PUMP-VAR-DISPL CW 90PV075	90R075-MA-5-BC-60-S-3-C6-E-C5-FAX-45-45-26	SERIES 90	S90-075PV
80006647	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-AB-80-L-3-TG-F-02-GBA-32-32-30	SERIES 90	S90-100PV
80006649	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-K-S-B-J-BA-A-A-BHH-CE-A-HH-B-NNF-***	M46	M46-046PV
80006650	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-S-B-J-BA-A-A-BJJ-CE-A-HH-A-NNN-***	M46	M46-046PV
80006651	PUMP-TANDEM, VAR DISPL MPT035D	MPT-035-D-A-R-R-G-AA-B-A-A-A-BEE-DL-A-FF-B-C-A-A-BEE-DL-A-FF-B-NNN-**	M35/44	035PT
80006652	MOTOR-VAR-DISPL 51MD110-1	51D110-1--R-D3-N-T2-CA-N-N-X1-NNN-022-AA-F0-00-25	SERIES 51	S51-110MV-1
80006653	MOTOR-VAR-DISPL 51MD160	51D160-R-D5-N-D8-M1-R-J-M4-ADA-065-AA-NN-C2-20	SERIES 51	S51-160MV
80006654	PUMP-VAR-DISPL CW 90PV130	90R130-MV-5-DE-80-L-3-F1-H-C5-GBA-42-42-24	SERIES 90	S90-130PV
80006655	PUMP-VAR-DISPL CW 90PV130	90R130-MA-5-BC-80-L-3-F1-H-C5-GBA-42-42-24	SERIES 90	S90-130PV
80006656	PUMP-TANDEM, VAR DISPL CCW H1T053L	H1-T-053-L-A-N-A2-C2-N-D1-F-G1-H3-38-38-38-38-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
80006657	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-N-TA-C2-L-N-G0-NNN-050-AA-NN-00-A9	SERIES 51	S51-160MV
80006659	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A2-C2-N-D3-H-G1-H3-L-35-L-35-F-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
80006661	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A3-C2-N-D6-F-G1-H3-L-40-L-40-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV

80006665	PUMP-VAR DISPL MPV046C	MPV-046-C-B-A-G-S-B-B-AA-A-A-BJJ-AB-D-BD-C-NNN-***	M46	M46-046PV
80006668	PUMP-VAR-DISPL CW 90PV130	90R130-KN-5-BC-80-R-4-F1-F-03-GBA-14-14-24	SERIES 90	S90-130PV
80006670	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A5-C1-B-D8-F-G5-NN-L-40-L-40-B-P-30-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
80006671	PUMP-VAR-DISPL CCW H1PV147	H1-P-147-L-C-A5-C2-N-D3-G-G3-H3-L-38-L-38-A-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
80006672	PUMP-TANDEM, VAR DISPL CCW H1T045L	H1-T-045-L-A-N-A3-C2-N-E7-F-G1-H2-33-33-33-33-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
80006673	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-1-NN-80-P-3-C6-C-09-GBA-45-45-20	SERIES 90	S90-055PV
80006674	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-BC-80-P-3-C7-D-09-GBA-42-42-20	SERIES 90	S90-075PV
80006675	MOTOR-VAR-DISPL 51MV080	51V080-A-C7-N-HS-L4-B-E-E8-NNN-030-AA-F3-09-37	SERIES 51	S51-080MV
80006677	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-N-DA-M4-R-J-N1-ADA-045-AA-F3-C2-32	SERIES 51	S51-160MV
80006678	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-CD-80-L-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-075PV
80006679	MOTOR-VAR-DISPL 51MV060-1	51V060-1--R-C6-N-E2-B1-N-N-U1-ADA-036-AA-F3-00-00	SERIES 51	S51-060MV-1
80006680	PUMP-VAR-DISPL CCW 90PV075	90L075-KN-5-NN-80-R-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-075PV
80006681	PUMP-VAR-DISPL CW 90PV075	90R075-MA-5-CD-60-S-3-C6-D-C5-GBA-35-35-24	SERIES 90	S90-075PV
80006682	PUMP-VAR-DISPL CW 90PV042	90R042-HF-5-BC-80-S-3-C3-C-03-GBA-20-42-24	SERIES 90	S90-042PV
80006683	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-CD-80-P-3-C7-D-03-GBA-23-23-24	SERIES 90	S90-075PV
80006684	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-AB-80-P-3-S1-D-03-GBA-23-23-24	SERIES 90	S90-075PV
80006685	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A5-C2-B-F4-H-G9-H6-L-20-L-20-C-M-20-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
80006686	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A4-C2-B-E6-F-G5-NN-L-28-L-28-B-L-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
80006687	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A2-C1-B-D6-F-G5-NN-L-35-L-35-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
80006689	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-N-TH-CO-L-N-G0-AHA-110-AA-F0-00-C5	SERIES 51	S51-160MV
80006694	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-2-CD-60-R-F-F1-E-33-GBA-38-38-24	SERIES 90	S90-100PV
80006695	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-G-S-B-B-AA-A-A-BGG-CB-A-GG-C-NNN-***	M46	M46-046PV
80006696	PUMP-VAR DISPL MPV046C	MPV-046-C-B-A-B-S-B-B-AA-G-A-BDD-AB-D-AB-A-NNN-***	M46	M46-046PV
80006697	MOTOR- VARIABLE CARTRIDGE L	L-C-25CS-E-R2F-F55-S-N-N-CF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
80006702	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-AB-80-S-3-C8-F-03-GBA-42-42-24	SERIES 90	S90-130PV
80006703	PUMP-VAR-DISPL CW 90PV130	90R130-HS-5-CD-80-R-3-F1-H-03-GBA-35-35-24	SERIES 90	S90-130PV
80006712	MOTOR-FIXED DISPL MMF025C	MMF-025-C-A-E-R-C-C-NNW-***	LIGHT DUTY	025MF
80006752	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A3-C2-N-D3-G-A8-H6-L-40-L-40-L-M-30-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
8002M0HM	CONTROL-HDC (1.1-6.7 BAR) STANDARD 55CC		SERIES 90	PARTS - S90
8002T006	CONTROL ORIFICE-.062		SERIES 90	PARTS - S90
8100846	ADAPTER-SAE A_90P075 (SEAL)		SERIES 90	PARTS - S90
8200422	SPACER-SLIPPER HOLD DOWN		SERIES 90	PARTS - S90
83000999	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-NN-60-R-3-S1-E-03-GBA-35-35-28	SERIES 90	S90-100PV
83001006	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-8-N-0-K3-W-00-NNN-00-00-G0	SERIES 90	S90-100MF
83001007	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-NN-80-P-3-S1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
83001014	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-5-NN-80-S-3-S1-B-20-GBA-42-42-24	SERIES 90	S90-055PV

83001019	PUMP-VAR DISPL, CW 90PV075	90-R-075-LE-H-CD-60-E-3-C7-E-03-FBA-AJ-43-28	SERIES 90	S90-075PV
83001020	PUMP-VAR DISPL, CW 90PV075	90-R-075-CA-H-BC-60-E-3-S1-C-00-FBA-AJ-43-28	SERIES 90	S90-075PV
83001022	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-BB-60-L-3-F1-E-03-FAD-42-42-24	SERIES 90	S90-100PV
83001027	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HF-1-CD-80-R-4-S1-D-03-GBA-32-32-24	SERIES 90	S90-075PV
83001039	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-NN-80-S-4-F1-F-03-GBA-35-35-24	SERIES 90	S90-130PV
83001040	PUMP-TANDEM, VAR DISPL CCW H1T053L	H1-T-053-L-A-N-A5-C2-N-E7-F-G5-NN-35-35-35-35-N-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83001044	PUMP-VAR DISPL, CW 90PV075	90-R-075-MB-H-BC-60-E-3-S1-C-01-FAC-AE-42-28	SERIES 90	S90-075PV
83001048	PUMP-VAR DISPL, CW 90PV075	90-R-075-LE-1-BC-80-S-3-C6-D-02-FBA-43-43-20	SERIES 90	S90-075PV
83001051	PUMP-VAR DISPL, CW 90PV075	90-R-075-MB-1-BC-80-S-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83001053	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-CD-80-S-3-F1-E-02-GBA-42-42-24	SERIES 90	S90-100PV
83001057	PUMP-VAR-DISPL CCW 90PV180	90L180-KP-5-BC-80-S-M-F1-J-03-FAC-32-32-24	SERIES 90	S90-180PV
83001059	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-CD-80-P-3-F1-F-02-GBA-42-42-24	SERIES 90	S90-130PV
83001062	PUMP-VAR DISPL, CCW 90PV055	90-L-055-MV-1-CD-80-S-3-S1-C-01-GBA-38-38-24	SERIES 90	S90-055PV
83001063	PUMP-VAR DISPL, CCW 90PV055	90-L-055-MA-1-BG-80-S-4-S1-C-03-GBA-07-38-24	SERIES 90	S90-055PV
83001064	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MV-1-CD-80-S-3-F1-E-02-GBA-38-38-24	SERIES 90	S90-100PV
83001065	PUMP-VAR DISPL, CW 90PV100	90-R-100-HS-1-BB-80-S-3-S1-E-03-GBA-35-35-28	SERIES 90	S90-100PV
83001066	PUMP-VAR-DISPL CCW 90PV130	90L130-HS-5-NN-80-R-4-C8-F-03-GBA-32-16-34	SERIES 90	S90-130PV
83001067	PUMP-VAR-DISPL CCW 90PV130	90L130-HS-5-NN-80-R-4-C8-F-03-GBA-32-32-24	SERIES 90	S90-130PV
83001068	PUMP-VAR-DISPL CCW 90PV130	90L130-HS-5-AB-80-R-4-C8-F-03-GBA-32-16-34	SERIES 90	S90-130PV
83001069	MOTOR-VAR-DISPL 51MD110	51D110-A-D4-N-HS-A2-C-E-E1-NNN-055-AA-F3-15-27	SERIES 51	S51-110MV
83001070	MOTOR-VAR-DISPL 51MD160	51D160-A-D4-N-HS-A2-C-E-E1-NNN-080-AA-F3-15-27	SERIES 51	S51-160MV
83001071	PUMP-VAR-DISPL CW 90PV100	90R100-PB-5-CD-60-L-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83001072	MOTOR-FIX DISPL MMF035D	MMF-035-D-A-A-H-A-S-NNN-***	M35/44	035MF
83001073	PUMP-VAR-DISPL CCW 90PV042	90L042-HF-5-AB-80-S-3-C3-L-03-GBA-26-26-24	SERIES 90	S90-042PV
83001077	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-HZ-B1-A-N-C2-NNN-054-AA-F3-03-00	SERIES 51	S51-250MV
83001078	PUMP-VAR DISPL MPV046C	MPV-046-C-B-A-H-S-B-B-BA-A-A-BHM-AB-U-FA-A-NNN-***	M46	M46-046PV
83001080	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A9-C1-B-F2-F-G5-H2-J-40-J-40-B-P-30-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83001084	PUMP-TANDEM, VAR DISPL MPT035D	MPT-035-D-G-W-A-E-NN-B-A-A-A-BDD-DR-A-FF-B-C-A-A-BDD-DY-A-FF-A-NNN	M35/44	035PT
83001085	PUMP-TANDEM, VAR DISPL MPT035D	MPT-035-D-A-W-R-N-BA-B-A-A-A-BHH-DR-A-FF-B-C-A-A-BHH-DX-A-FF-D-NNN	M35/44	035PT
83001088	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-BC-80-P-3-C7-D-02-EBC-26-26-24	SERIES 90	S90-075PV
83001089	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-E-Z-C-B-AA-B-B-A-A-BHH-CD-A-GG-B-D-A-A-BJJ-CD-A-GG-A-NNN-*	M46	M46-046PT
83001092	PUMP-VAR DISPL, CW 90PV100	90-R-100-HS-1-CD-80-P-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83001100	MOTOR-VARIABLE DISPL SAE_K	K-V-38CS-A-RNF-F07-T-N-X-CF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83001103	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A3-C2-B-D3-H-G1-NN-L-35-L-35-C-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83001104	PUMP-VAR-DISPL CW 90PV100	90R100-CB-1-CD-80-P-4-F1-F-00-GBA-35-35-24	SERIES 90	S90-100PV
83001105	PUMP-VAR-DISPL CW 90PV100	90R100-CB-1-AB-80-P-4-S1-F-00-GBA-35-35-24	SERIES 90	S90-100PV

83001106	MOTOR-VAR-DISPL 51MD110-1	51D110-1--A-D4-N-E2-B1-N-N-U1-NNN-070-AA-NN-00-00	SERIES 51	S51-110MV-1
83001107	MOTOR-VAR-DISPL 51MD110-1	51D110-1--A-D4-N-T2-CA-N-N-X1-ABA-029-AA-F0-00-20	SERIES 51	S51-110MV-1
83001108	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-A-S-B-B-AA-A-A-BDD-CB-A-HH-C-NNN-***	M46	M46-046PV
83001110	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-CD-80-R-4-C6-C-04-GBA-29-29-20	SERIES 90	S90-055PV
83001111	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-CD-80-R-4-S1-C-04-GBA-29-29-20	SERIES 90	S90-055PV
83001113	PUMP-VAR DISPL, CW 90PV075	90-R-075-HS-1-CD-60-P-3-C6-D-03-GBA-23-23-24	SERIES 90	S90-075PV
83001114	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-CD-80-P-3-C6-C-03-EBC-35-35-24	SERIES 90	S90-055PV
83001117	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-T1-CA-N-N-X1-ABA-038-AA-E6-00-18	SERIES 51	S51-110MV-1
83001118	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-T1-C0-L-N-G0-ABA-036-AA-F0-00-A8	SERIES 51	S51-160MV
83001119	PUMP-VAR DISPL MPV044D	MPV-044-D-B-A-G-W-S-C-AA-A-A-BFF-DR-A-FF-A-NNN-***	M35/44	044PV
83001120	PUMP-VAR-DISPL CCW 90PV250	90L250-KP-5-NN-80-T-3-F1-J-03-NNN-35-35-24	SERIES 90	S90-250PV
83001125	MOTOR-VAR-DISPL 51MD060	51D060-R-D2-N-HS-A7-B-H-E1-CCA-020-AA-NN-05-16	SERIES 51	S51-060MV
83001126	PUMP-VAR-DISPL CW 90PV042	90R042-HF-5-NN-80-R-4-C3-C-00-GCA-29-29-20	SERIES 90	S90-042PV
83001127	PUMP-VAR-DISPL CW 90PV130	90R130-DD-2-BC-80-S-7-D8-F-G1-GLA-29-29-30	SERIES 90	S90-130PV
83001128	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-N-HZ-B1-A-N-G0-NNN-053-AA-NN-03-00	SERIES 51	S51-160MV
83001130	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-AB-60-P-3-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83001132	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-5-CD-80-T-3-C8-K-03-EHA-35-35-24	SERIES 90	S90-250PV
83001133	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-5-AB-80-T-3-C8-K-03-EHA-35-35-24	SERIES 90	S90-250PV
83001134	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-5-EG-80-S-3-C8-K-03-NNN-35-35-24	SERIES 90	S90-250PV
83001135	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HS-1-BC-60-R-4-F1-E-05-FBC-33-33-32-N180	SERIES 90	S90-100PV
83001136	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HS-1-BC-60-R-4-F1-E-05-FBC-33-33-32-N181	SERIES 90	S90-100PV
83001137	MOTOR-VARIABLE DISPL SAE_K	K-V-38CS-A-R2F-F10-S-N-N-DF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83001138	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-CD-80-S-7-TG-E-21-EFI-26-26-24	SERIES 90	S90-075PV
83001139	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-NN-80-R-3-S1-D-05-FAL-35-35-20	SERIES 90	S90-075PV
83001140	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-CD-80-R-4-C8-H-05-HCA-35-35-20	SERIES 90	S90-130PV
83001142	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-N-HZ-B1-A-N-G0-NNN-040-AA-NN-03-00	SERIES 51	S51-160MV
83001156	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-BC-60-P-3-S1-D-03-GBA-36-36-24	SERIES 90	S90-075PV
83001157	MOTOR-VAR-DISPL 51MD060	51D060-R-D1-N-HS-A2-B-H-E1-NNN-012-AA-NN-05-16	SERIES 51	S51-060MV
83001160	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-NN-80-S-4-F1-F-03-GBA-23-23-24	SERIES 90	S90-100PV
83001161	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-L2-B1-V-A-J1-NNN-110-AA-NN-B2-00	SERIES 51	S51-160MV
83001164	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-NN-80-R-4-C8-H-05-HCA-35-35-20	SERIES 90	S90-130PV
83001165	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A8-C2-C-D6-J-G5-H2-L-40-L-40-B-L-32-P2-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83001166	MOTOR-VAR-DISPL 51MD160	51D160-A-D4-N-E2-A7-A-N-E1-CCA-035-AA-F3-03-16	SERIES 51	S51-160MV
83001167	MOTOR-VAR-DISPL 51MC160	51C160-A-D5-N-HZ-B1-A-N-C2-NNN-055-AA-NN-03-00	SERIES 51	S51-160MV
83001169	MOTOR-VAR-DISPL 51MD160	51D160-R-D4-N-D7-M1-S-K-M4-NNN-100-AA-G3-F4-26	SERIES 51	S51-160MV
83001171	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-AD-80-S-3-S1-C-03-GBA-38-38-24	SERIES 90	S90-055PV

83001172	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-BG-80-S-3-S1-C-03-GBA-38-38-24	SERIES 90	S90-055PV
83001177	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-NN-60-S-3-C6-E-00-GCP-35-35-28	SERIES 90	S90-075PV
83001178	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A4-C2-N-D8-H-F1-H5-L-40-L-40-N-E-26-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83001180	PUMP-VAR-DISPL CCW 90PV075	90L075-FL-5-NN-80-S-7-C6-D-B6-GME-35-35-28	SERIES 90	S90-075PV
83001181	MOTOR-VAR-DISPL 51MV060-1	51V060-1--R-S1-N-T2-CA-N-N-X1-NNN-016-AA-F0-00-20	SERIES 51	S51-060MV-1
83001182	MOTOR-VAR-DISPL 51MV250	51V250-A-C8-N-T2-C0-L-N-G0-NNN-140-AA-G0-00-B3	SERIES 51	S51-250MV
83001206	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-L2-B1-V-A-G5-ACA-064-AA-F3-B2-00	SERIES 51	S51-160MV
83001216	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-CD-80-P-3-S1-F-02-GBA-42-42-24	SERIES 90	S90-100PV
83001218	MOTOR-VARIABLE DISPL SAE_L	L-V-35EN-A-YNF-F95-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83001219	MOTOR-VARIABLE DISPL SAE_L	L-V-35EN-A-RNF-F00-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83001221	MOTOR-VAR-DISPL 51MD160	51D160-V-D4-N-E1-A5-A-N-G0-ABA-046-AA-F3-03-00	SERIES 51	S51-160MV
83001222	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-N-HE-B2-B-H-E6-NNN-045-AA-F3-06-00	SERIES 51	S51-160MV
83001223	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-N1-NN-N-N-U1-NNN-041-AA-NN-00-00	SERIES 51	S51-110MV-1
83001225	MOTOR-VAR-DISPL 51MD110	51D110-A-D3-N-D7-M1-S-K-M1-NNN-038-AA-F0-F4-25	SERIES 51	S51-110MV
83001226	PUMP-VAR-DISPL CCW 90PV130	90L130-HF-5-NN-80-R-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-130PV
83001227	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A2-C2-N-D6-F-G5-H1-L-35-L-25-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83001228	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-CD-80-L-3-S1-D-03-GBA-26-26-20	SERIES 90	S90-055PV
83001229	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-NN-80-L-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
83001230	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HS-1-NN-60-P-4-S1-C-03-GBA-32-17-30	SERIES 90	S90-055PV
83001232	MOTOR-VAR-DISPL 51MV160	51V160-R-F2-N-E2-A1-A-N-E2-ACA-053-AA-F3-03-37	SERIES 51	S51-160MV
83001236	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-E2-A1-A-N-A2-NNN-050-AA-G0-03-37	SERIES 51	S51-250MV
83001237	MOTOR-VAR-DISPL 51MD160	51D160-R-D5-N-F2-A5-A-N-G0-NNN-080-AA-NN-03-00	SERIES 51	S51-160MV
83001238	MOTOR-VAR-DISPL 51MC160	51C160-A-D5-N-HZ-B1-A-N-G0-NNN-100-AA-NN-03-00	SERIES 51	S51-160MV
83001244	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HF-1-BC-80-R-3-S1-D-03-GBA-35-35-20	SERIES 90	S90-075PV
83001248	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-K-S-B-B-AA-V-A-BJJ-CD-A-ZG-B-NNN-***	M46	M46-046PV
83001249	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-5-NN-80-S-3-S1-B-20-GBA-38-38-24	SERIES 90	S90-055PV
83001250	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-TA-C2-N-N-X1-NNN-022-AA-G0-00-27	SERIES 51	S51-110MV-1
83001251	MOTOR-VAR-DISPL 51MV160	51V160-A-C8-N-T2-C2-L-N-G0-NNN-082-AA-G3-00-B2	SERIES 51	S51-160MV
83001253	MOTOR-VAR-DISPL 51MV110	51V110-V-F1-D-HS-A2-C-H-E1-NNN-035-AA-NN-20-13	SERIES 51	S51-110MV
83001259	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-N-TH-D2-N-N-X1-ADA-015-AA-NN-00-28	SERIES 51	S51-060MV-1
83001261	PUMP-VAR DISPL, CW 90PV075	90-R-075-DC-2-AB-80-R-4-S1-C-G4-GFK-32-32-20-F070	SERIES 90	S90-075PV
83001271	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-5-NN-80-R-4-S1-C-C3-GBA-23-23-20	SERIES 90	S90-055PV
83001272	PUMP, VARIABLE DIRECT DISPLACEMENT	LPV-B-A-A-A-A-E-AC-C-A-BGG-DR-A-FF-A-NNN-***	LPV	LPV
83001275	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-A-Z-C-B-AA-B-B-A-A-BGG-CB-A-GG-B-D-A-A-BGG-CB-A-GG-B-NNN-	M46	M46-046PT
83001288	MOTOR-VAR-DISPL 51MV110	51V110-R-F1-N-HZ-B1-B-H-G5-NNN-057-AA-NN-12-00	SERIES 51	S51-110MV
83001289	PUMP-VAR-DISPL CCW H1PV147	H1-P-147-L-C-A3-C2-N-D8-G-G2-H6-L-42-L-42-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV

83001290	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KT-5-NN-80-P-4-S1-F-00-GBA-32-32-24	SERIES 90	S90-100PV
83001294	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-NN-60-S-4-S1-D-05-GBA-26-26-24	SERIES 90	S90-075PV
83001295	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-TN-F8-L-N-J2-ADA-090-AA-F3-00-BB	SERIES 51	S51-250MV
83001299	PUMP-VAR DISPL, CW 90PV055	90-R-055-FD-5-AB-60-R-7-C6-C-B1-GLA-38-38-32	SERIES 90	S90-055PV
83001307	PUMP-VAR-DISPL CW 90PV180	90R180-KP-5-AB-80-T-M-F1-J-03-FAC-38-38-24	SERIES 90	S90-180PV
83001308	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-HZ-B1-B-H-G5-NNN-051-AA-NN-10-00	SERIES 51	S51-080MV
83001310	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-EQ-A7-J-Y-E1-CCA-140-AA-F3-15-16	SERIES 51	S51-250MV
83001311	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-N-E2-A7-A-N-E1-CCA-130-AA-F3-03-35	SERIES 51	S51-250MV
83001312	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-N-E2-A7-A-N-E1-CCA-050-AA-F3-03-35	SERIES 51	S51-250MV
83001314	MOTOR-VAR-DISPL 51MD160	51D160-A-D4-N-HS-A7-B-H-E1-CCA-N11-AA-F3-05-16	SERIES 51	S51-160MV
83001317	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KT-5-CD-80-P-4-F1-F-00-GBA-32-32-24	SERIES 90	S90-100PV
83001318	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-BC-60-L-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83001319	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-D-T-B-B-AA-A-A-BGG-CB-A-GG-B-NNN-***	M46	M46-046PV
83001320	MOTOR-VAR-DISPL 51MD080-1	51D080-1--A-D3-N-P7-P7-N-N-X1-AWM-016-AA-F0-00-AA	SERIES 51	S51-080MV-1
83001321	MOTOR-VAR-DISPL 51MC160	51C160-R-D4-N-HS-A2-C-H-E1-NNN-107-AA-NN-16-21	SERIES 51	S51-160MV
83001324	MOTOR-VAR-DISPL 51MV080-1	51V080-1--A-S1-N-T2-D2-N-N-X1-ABA-035-AA-F0-00-20	SERIES 51	S51-080MV-1
83001326	MOTOR-VAR-DISPL 51MC060-1	51C060-1--A-D1-N-T1-D1-N-N-X1-ANA-019-AA-E6-00-20	SERIES 51	S51-060MV-1
83001327	PUMP-VAR-DISPL CCW H1PV147	H1-P-147-L-C-A5-C2-N-D4-G-G2-H6-L-42-L-42-L-M-24-PN-NNN-G25	H1-HP PUMPS	H1-147PV/165PV
83001328	PUMP-VAR DISPL, CCW 90PV075	90-L-075-LL-1-BB-60-S-4-C6-C-71-GFK-35-35-24	SERIES 90	S90-075PV
83001330	PUMP-VAR DISPL, CCW 90PV075	90-L-075-EA-1-BB-60-S-3-C6-C-03-GFK-42-42-24	SERIES 90	S90-075PV
83001331	PUMP-VAR DISPL, CW 90PV075	90-R-075-MV-1-BE-62-R-3-C7-E-03-GFK-45-45-24	SERIES 90	S90-075PV
83001332	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-CD-80-T-3-F1-J-09-NNN-42-42-24	SERIES 90	S90-250PV
83001333	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A2-C2-N-E7-F-G5-H3-23-23-23-23-N-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83001334	PUMP-VAR-DISPL CW 90PV075	90R075-FN-5-CD-60-P-7-C7-D-B6-GMD-42-42-30	SERIES 90	S90-075PV
83001336	PUMP-VAR-DISPL CW 90PV075	90R075-HF-5-NN-60-P-4-C7-D-00-GCA-29-29-20	SERIES 90	S90-075PV
83001338	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HK-1-AB-80-R-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83001342	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-BB-62-R-3-C7-E-03-GBA-42-42-20	SERIES 90	S90-075PV
83001343	PUMP-VAR DISPL, CW 90PV075	90-R-075-HS-1-BC-80-S-3-S1-D-03-GBA-32-32-24	SERIES 90	S90-075PV
83001344	PUMP-VAR DISPL, CW 90PV100	90-R-100-MV-1-BE-62-R-3-C7-E-03-GFK-42-42-24	SERIES 90	S90-100PV
83001345	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-BC-60-S-3-C7-E-03-GFK-45-45-24	SERIES 90	S90-100PV
83001346	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-BC-60-S-3-C7-E-03-GFK-42-42-20	SERIES 90	S90-100PV
83001347	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-1-BC-60-S-3-C6-C-03-GFK-38-38-20	SERIES 90	S90-055PV
83001349	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A2-C2-N-D6-G-G3-H6-L-48-L-48-A-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83001352	PUMP-VAR-DISPL CW 90PV100	90R100-PB-5-CD-80-P-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83001354	PUMP-VAR-DISPL CW 90PV075	90R075-PB-5-NN-80-P-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83001359	PUMP-VAR-DISPL CCW 90PV250	90L250-KP-5-NN-80-S-4-F1-K-03-NNN-26-26-24	SERIES 90	S90-250PV

83001361	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-CD-80-S-C-C8-J-03-NNN-42-42-30	SERIES 90	S90-180PV
83001362	PUMP-VAR-DISPL CW 90PV042	90R042-DC-5-BC-80-P-3-C3-C-GB-GBA-35-35-24	SERIES 90	S90-042PV
83001368	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-H-T-B-B-AA-G-A-BGG-CD-A-JJ-A-NNN-***	M46	M46-046PV
83001369	MOTOR-VARIABLE CARTRIDGE K	K-C-45DS-E-RNF-F09-S-N-N-CF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83001371	PUMP-VAR DISPL, CW 90PV055	90-R-055-FC-2-CD-60-P-7-C6-D-B1-GLA-42-42-30	SERIES 90	S90-055PV
83001378	MOTOR-VARIABLE DISPL SAE_K	K-V-45DN-A-YNF-F08-S-N-N-AF-F16-NNN-NNN	LV / KV MOTORS	L/K-MV
83001379	PUMP-VAR-DISPL CW 90PV130	90R130-HF-5-DE-80-L-3-C8-H-03-GBA-35-35-24	SERIES 90	S90-130PV
83001380	PUMP-VAR-DISPL CW 90PV130	90R130-HF-5-AB-80-L-3-F1-H-03-GBA-35-35-24	SERIES 90	S90-130PV
83001381	MOTOR-VAR-DISPL 51MC110	51C110-R-D3-N-T9-C2-L-N-G0-ANA-055-AA-F0-00-B3	SERIES 51	S51-110MV
83001385	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-CD-60-P-3-F1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
83001387	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-BC-60-S-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83001388	PUMP-TANDEM, VAR DISPL MPT035D	MPT-035-D-A-R-A-F-NN-B-A-A-A-BEE-DR-A-FF-B-C-A-A-BEE-DL-A-FF-J-NNN-***	M35/44	O35PT
83001391	PUMP-TANDEM, VAR DISPL CCW H1T045L	H1-T-045-L-A-N-A3-C1-N-E7-F-G5-H2-20-20-20-20-N-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83001392	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-1-NN-80-R-4-S1-D-03-GBA-32-32-24	SERIES 90	S90-075PV
83001393	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-1-CD-80-R-4-K2-D-03-GBA-32-32-24	SERIES 90	S90-075PV
83001397	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-AB-81-S-3-T2-E-00-EEB-35-35-20	SERIES 90	S90-075PV
83001398	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A5-C2-N-E5-F-G4-NN-L-25-L-25-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83001400	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-L1-B1-W-B-G5-NNN-032-AA-E4-D4-00	SERIES 51	S51-160MV
83001401	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KT-1-CD-80-S-4-C6-D-03-GFK-38-38-24	SERIES 90	S90-075PV
83001404	PUMP-VAR DISPL, CW 90PV075	90-R-075-K0-1-CT-62-R-3-C7-E-03-GFK-42-42-20	SERIES 90	S90-075PV
83001405	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-CT-62-R-3-C7-E-03-GFK-42-42-20	SERIES 90	S90-075PV
83001407	MOTOR-VAR-DISPL 51MD080-1	51D080-1--R-D2-N-TA-C2-N-N-X1-NNN-030-AA-NN-00-20	SERIES 51	S51-080MV-1
83001412	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-NN-80-S-3-C8-F-03-GBA-42-42-24	SERIES 90	S90-130PV
83001414	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-CD-80-T-3-C8-J-09-NNN-42-42-24	SERIES 90	S90-250PV
83001417	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-5-CD-80-S-3-C6-B-03-GBA-42-42-24	SERIES 90	S90-055PV
83001418	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-5-AD-80-S-3-S1-B-03-GBA-42-42-24	SERIES 90	S90-055PV
83001425	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-A-V-C-J-BA-B-B-A-A-BHH-CE-A-GG-B-D-A-A-BHH-CE-A-GG-B-NNN-*	M46	M46-046PT
83001428	PUMP-VAR-DISPL CCW 90PV180	90L180-HS-5-NN-80-T-M-F1-J-05-FAC-35-35-24	SERIES 90	S90-180PV
83001430	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-NN-80-T-C-C8-H-05-HCA-35-35-20	SERIES 90	S90-180PV
83001431	MOTOR-VAR DISPL MMV046C	MMV-046-C-A-D-4-C-AV-VNB-***	M46	M46-046MV
83001442	MOTOR-VAR DISPL MMV046C	MMV-046-C-A-D-4-C-A8-VNB-***	M46	M46-046MV
83001444	MOTOR-VAR-DISPL 51MD080	51D080-R-D2-N-D7-M1-S-K-N2-ACA-016-AA-F3-F4-30	SERIES 51	S51-080MV
83001445	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-T1-L5-L-N-G0-NNN-068-AA-F3-00-C7	SERIES 51	S51-160MV
83001446	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-NN-80-S-4-F1-F-03-GBA-35-35-24	SERIES 90	S90-130PV
83001447	PUMP-VAR-DISPL CCW 90PV180	90L180-KN-5-CD-80-S-C-C8-H-03-NNN-40-40-26	SERIES 90	S90-180PV
83001457	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A5-C3-B-D3-G-G3-H6-K-35-K-35-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV

83001458	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A5-C3-N-D5-G-G3-H4-K-35-K-35-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83001462	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A4-C1-N-E6-F-G5-H2-L-30-L-30-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83001463	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HF-5-NN-60-S-4-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83001464	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-5-CD-60-S-3-S1-C-03-GBA-38-38-20	SERIES 90	S90-055PV
83001470	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-A-V-C-B-AA-B-B-G-A-BGG-CG-A-GG-B-D-G-A-BGG-CG-A-GG-B-NNN	M46	M46-046PT
83001479	PUMP-VAR-DISPL CW 90PV130	90R130-HF-5-AB-80-L-3-F1-H-03-GBA-32-32-24	SERIES 90	S90-130PV
83001493	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-NN-80-P-4-C7-F-03-GBA-42-42-24	SERIES 90	S90-100PV
83001494	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-BC-80-P-4-C7-F-03-GBA-42-42-24	SERIES 90	S90-100PV
83001495	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-NN-60-S-3-F1-E-03-GBA-32-32-24	SERIES 90	S90-100PV
83001496	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-NN-60-S-4-C7-D-01-GBA-42-42-24	SERIES 90	S90-075PV
83001497	PUMP-VAR-DISPL CCW 90PV180	90L180-KP-5-CD-80-T-C-F1-H-05-FAC-20-38-24	SERIES 90	S90-180PV
83001498	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A4-C2-N-D6-F-G5-NN-L-45-L-45-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83001499	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-5-AD-80-S-3-C6-C-03-GBA-42-42-24	SERIES 90	S90-055PV
83001500	MOTOR-VAR-DISPL 51MC060	51C060-A-D1-N-JA-NN-B-H-K3-ADA-035-AA-F0-05-25	SERIES 51	S51-060MV
83001504	PUMP-VAR-DISPL CCW 90PV130	90L130-FH-5-NN-80-R-7-C8-H-B1-EFI-42-42-24	SERIES 90	S90-130PV
83001505	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-T4-C0-L-N-L4-NNN-120-AA-F3-00-B3	SERIES 51	S51-250MV
83001506	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-AB-60-S-3-C7-F-03-GBA-42-42-24	SERIES 90	S90-100PV
83001507	MOTOR-VARIABLE DISPL SAE_K	K-V-45DN-E-Y2F-F09-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83001512	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A3-C2-B-E5-F-G4-NN-L-25-L-25-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83001515	MOTOR-FIXED DISPL MMF025C	MMF-025-C-A-T-B-A-B-NNN-***	LIGHT DUTY	O25MF
83001516	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-AB-80-S-3-C3-C-03-GBA-29-29-24	SERIES 90	S90-042PV
83001517	PUMP, VARIABLE DIRECT DISPLACMENT	LPV-C-A-B-C-A-E-AB-D-A-BGG-DL-A-FF-A-NNB-***	LPV	LPV
83001519	PUMP-VAR-DISPL CW 90PV100	90R100-KA-2-NN-80-R-4-C7-E-33-GCA-35-35-30	SERIES 90	S90-100PV
83001523	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-8-N-0-C6-W-00-NNN-00-00-N4	SERIES 90	S90-075MF
83001530	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HS-1-CD-80-S-3-C7-E-03-GBA-29-29-24	SERIES 90	S90-100PV
83001544	PUMP-VAR DISPL, CCW 90PV100	90-L-100-LS-5-CD-8P-L-3-C7-F-04-GB4-44-40-30	SERIES 90	S90-100PV
83001545	PUMP-VAR DISPL, CCW 90PV100	90-L-100-LS-5-BC-8P-L-3-J3-F-04-GB4-44-40-30	SERIES 90	S90-100PV
83001555	PUMP-VAR-DISPL CCW 90PV042	90L042-KA-5-NN-80-S-4-C3-N-03-GBA-42-42-24	SERIES 90	S90-042PV
83001565	MOTOR-VAR-DISPL 51MV160	51V160-A-C8-N-HS-A2-B-N-E1-NNN-054-AA-F3-08-20	SERIES 51	S51-160MV
83001567	PUMP-VAR-DISPL CW 90PV250	90R250-PB-5-EG-80-T-3-C8-K-00-NNN-42-42-28	SERIES 90	S90-250PV
83001568	PUMP-VAR-DISPL CW 90PV250	90R250-PB-5-NN-80-T-3-C8-K-00-NNN-42-42-28	SERIES 90	S90-250PV
83001572	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-CD-80-R-3-C6-D-00-GBA-35-35-24	SERIES 90	S90-075PV
83001582	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A5-C2-N-D8-F-G5-H2-L-30-L-30-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83001583	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-5-NN-80-P-3-S1-C-03-GBA-38-38-24	SERIES 90	S90-055PV
83001584	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-5-CD-80-P-3-S1-C-03-GBA-38-38-24	SERIES 90	S90-055PV
83001587	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A4-C2-B-D3-G-G2-H5-L-35-L-35-L-M-20-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV

83001588	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-L1-B1-W-B-G5-ACA-050-AA-F0-D4-00	SERIES 51	S51-250MV
83001590	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-N-HZ-B1-A-N-G0-NNN-107-AA-F3-03-00	SERIES 51	S51-160MV
83001591	MOTOR-VAR-DISPL 51MV060-1	51V060-1--R-S1-N-TA-CA-N-N-X1-NNN-040-AA-E4-00-25	SERIES 51	S51-060MV-1
83001592	MOTOR-VAR-DISPL 51MV160	51V160-A-C8-N-HE-B2-C-E-E6-NNN-086-AA-G0-13-00	SERIES 51	S51-160MV
83001594	PUMP-VAR-DISPL CCW 90PV130	90L130-HS-5-CD-80-S-4-C8-H-03-GBA-35-16-30	SERIES 90	S90-130PV
83001595	PUMP-VAR-DISPL CCW 90PV130	90L130-HS-5-CD-80-S-4-C8-H-03-GBA-32-32-30	SERIES 90	S90-130PV
83001596	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-TA-D1-N-N-X1-ADA-033-AA-G3-00-20	SERIES 51	S51-110MV-1
83001597	PUMP-VAR DISPL, CW 90PV075	90-R-075-HF-1-AB-80-D-4-S1-L-03-GBA-35-35-24	SERIES 90	S90-075PV
83001598	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-ANN3-03-A-N-A-2-C-N-B-28-28-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83001604	MOTOR-VAR-DISPL 51MV080-1	51V080-1--A-S1-N-N1-NN-N-N-U1-NNN-030-AA-NN-00-00	SERIES 51	S51-080MV-1
83001606	MOTOR-VAR-DISPL 51MD110-1	51D110-1--A-D4-N-N1-NN-N-N-U1-NNN-060-AA-E6-00-00	SERIES 51	S51-110MV-1
83001607	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-N-N2-NN-N-N-A0-NNN-167-AA-NN-00-00	SERIES 51	S51-250MV
83001608	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-K-S-B-B-AA-A-A-BHH-BB-A-GG-B-NNN-***	M46	M46-046PV
83001609	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-AB-81-S-3-T2-E-00-EEB-35-35-20	SERIES 90	S90-075PV
83001611	MOTOR-VARIABLE DISPL SAE_K	K-V-45DS-C-RNF-F55-S-N-N-CF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83001617	PUMP-VAR DISPL, CW 90PV100	90-R-100-FC-5-CD-80-S-7-F1-F-B1-GCA-42-42-24	SERIES 90	S90-100PV
83001618	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-BC-80-R-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83001620	MOTOR-VAR-DISPL 51MD080-1	51D080-1--A-D3-N-N1-NN-N-N-U1-NNN-040-AA-E6-00-00	SERIES 51	S51-080MV-1
83001627	PUMP-VAR-DISPL CW 90PV250	90R250-PB-5-AB-80-T-3-C8-J-00-NNN-32-14-28	SERIES 90	S90-250PV
83001628	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-2-BB-60-S-3-C6-D-03-GBA-32-32-24	SERIES 90	S90-075PV
83001629	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-B-T-B-S-BA-A-A-BGG-CD-A-HH-A-NNN-***	M46	M46-046PV
83001630	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-AB-81-S-3-T2-F-00-EEB-35-35-20	SERIES 90	S90-100PV
83001631	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-AB-81-S-3-T2-F-00-EEB-35-35-20	SERIES 90	S90-100PV
83001632	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-CD-80-R-3-C8-H-03-GBA-42-42-24	SERIES 90	S90-130PV
83001633	PUMP-VAR-DISPL CCW 90PV250	90L250-KP-5-BC-80-S-4-F1-J-03-NNN-42-42-24	SERIES 90	S90-250PV
83001634	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-AB-80-R-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-130PV
83001635	PUMP-VAR-DISPL CCW 90PV180	90L180-KP-5-BB-80-T-C-C8-H-03-FAC-35-35-24	SERIES 90	S90-180PV
83001642	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-NN-80-L-4-F1-H-00-GBA-14-14-24	SERIES 90	S90-130PV
83001647	PUMP-VAR-DISPL CW 90PV075	90R075-HF-1-BC-80-S-3-S1-D-03-GBA-40-40-24	SERIES 90	S90-075PV
83001649	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-NN-80-P-4-F1-H-03-GBA-38-38-24	SERIES 90	S90-130PV
83001650	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HS-5-CD-80-L-4-S1-C-04-GBA-35-35-24	SERIES 90	S90-055PV
83001653	MOTOR-VAR-DISPL 51MD110	51D110-R-D4-N-HS-A2-C-H-C1-NNN-036-AA-NN-15-15	SERIES 51	S51-110MV
83001665	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-AD-80-R-4-S1-C-03-GBA-32-32-24	SERIES 90	S90-055PV
83001666	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-BC-80-S-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83001667	PUMP-VAR-DISPL CW 90PV042	90R042-DD-5-BC-80-S-3-C3-C-GB-GBA-42-42-24	SERIES 90	S90-042PV
83001668	PUMP-VAR-DISPL CCW 90PV042	90L042-DD-5-BC-80-S-3-C3-C-GB-GBA-42-42-24	SERIES 90	S90-042PV

83001669	MOTOR-VAR-DISPL 51MV110	51V110-A-C8-N-L2-B1-V-A-J1-NNN-022-AA-F0-B2-00	SERIES 51	S51-110MV
83001670	PUMP-VAR-DISPL CW 90PV075	90R075-KP-5-AB-80-S-3-C7-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83001672	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-CD-80-T-M-F1-H-03-FAC-37-37-24	SERIES 90	S90-180PV
83001677	MOTOR-VARIABLE DISPL SAE_K	K-V-38CN-E-RNF-F13-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83001678	PUMP-VAR-DISPL CCW H1PV147	H1-P-147-L-C-A3-C3-N-D7-G-G3-H4-L-42-L-42-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83001679	PUMP-TANDEM, VAR DISPL CCW H1T053L	H1-T-053-L-A-N-A2-C3-B-D1-F-F2-H3-35-35-35-35-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83001681	PUMP-VAR-DISPL CCW 90PV100	90L100-HF-1-CD-60-S-4-C7-E-04-GBA-35-35-20	SERIES 90	S90-100PV
83001682	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A3-C2-N-D9-G-G2-H4-L-42-L-42-L-L-30-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83001683	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A3-C2-N-D6-G-G3-H6-L-42-L-42-L-L-30-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83001688	PUMP-VAR-DISPL CW 90PV180	90R180-FH-5-EF-80-T-7-F1-J-B1-FAC-38-38-24	SERIES 90	S90-180PV
83001689	PUMP-VAR-DISPL CW 90PV180	90R180-FH-5-NN-80-T-7-F1-J-B1-FAC-38-38-24	SERIES 90	S90-180PV
83001690	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-CD-80-S-3-C8-F-03-GBA-42-42-24	SERIES 90	S90-130PV
83001691	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A3-C2-N-D6-H-G1-H3-L-40-L-40-C-L-30-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83001693	PUMP-VAR-DISPL CW 90PV130	90R130-FH-5-NN-80-S-7-C8-H-B1-EFI-38-38-30	SERIES 90	S90-130PV
83001697	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A2-C1-B-D8-H-G1-H2-L-40-L-40-F-P-20-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83001698	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-E1-A5-A-N-A6-NNN-085-AA-NN-03-00	SERIES 51	S51-250MV
83001699	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-F1-A1-A-N-G2-NNN-078-AA-F0-03-29	SERIES 51	S51-160MV
83001703	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-BC-80-P-3-S1-D-03-EBC-35-35-24	SERIES 90	S90-075PV
83001704	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-8-N-0-S1-N-00-EBA-00-00-00	SERIES 90	S90-075MF
83001714	PUMP-VAR-DISPL CW 90PV075	90R075-HF-1-CD-80-S-3-S1-D-03-GBA-40-40-24	SERIES 90	S90-075PV
83001715	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KT-5-NN-80-P-3-S1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
83001716	PUMP-VAR DISPL, CW 90PV100	90-R-100-KT-5-NN-80-P-3-S1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
83001717	PUMP-VAR DISPL, CW 90PV100	90-R-100-KT-5-BC-80-R-3-S1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
83001718	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-5-NN-80-S-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83001719	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A3-C2-N-E6-F-G5-H2-L-28-L-28-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83001721	PUMP-VAR-DISPL CCW 90PV130	90L130-MA-5-CD-80-L-3-C8-F-C5-GBA-35-35-24	SERIES 90	S90-130PV
83001722	PUMP-VAR DISPL, CW 90PV055	90-R-055-KT-1-NN-80-P-4-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83001723	PUMP-VAR DISPL, CW 90PV055	90-R-055-KT-1-BG-80-P-4-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83001725	PUMP-VAR-DISPL CW 90PV042	90R042-MA-P-AB-80-P-4-C3-C-C5-GBA-48-48-24	SERIES 90	S90-042PV
83001729	MOTOR-VAR-DISPL 51MD060-1	51D060-1--A-D2-N-N1-NN-N-N-U1-NNN-033-AA-NN-00-00	SERIES 51	S51-060MV-1
83001731	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-S1-N-N1-NN-N-N-U1-NNN-016-AA-F0-00-00	SERIES 51	S51-080MV-1
83001732	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-L2-B1-V-A-C0-NNN-083-AA-NN-B2-00	SERIES 51	S51-250MV
83001734	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-BB-80-L-3-C7-E-03-GBA-42-42-26	SERIES 90	S90-100PV
83001735	MOTOR-VAR-DISPL 51MC110	51C110-R-D4-N-H4-B3-R-J-N2-NNN-022-AA-NN-C2-35	SERIES 51	S51-110MV
83001739	MOTOR-VARIABLE DISPL SAE_K	K-V-45DN-A-YNF-F11-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83001741	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-BB-80-L-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV

83001742	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-C8-N-TA-CA-N-N-X1-NNN-025-AA-F3-00-30	SERIES 51	S51-110MV-1
83001744	PUMP-VAR-DISPL CW 90PV100	90R100-NA-5-AB-80-S-3-C7-E-A8-GBA-42-42-24	SERIES 90	S90-100PV
83001746	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-NN-80-T-3-C8-K-03-NNN-38-38-24	SERIES 90	S90-250PV
83001748	MOTOR- VARIABLE CARTRIDGE L	L-C-30DS-A-RNF-F09-S-N-N-CF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83001750	PUMP-VAR-DISPL CW 90PV180	90R180-PB-5-BC-80-T-M-C8-J-00-NNN-32-32-28	SERIES 90	S90-180PV
83001752	PUMP-VAR DISPL MPV046C	MPV-046-C-B-A-D-T-B-B-AA-A-A-BBG-AB-U-ED-B-NNN-***	M46	M46-046PV
83001753	MOTOR-VAR-DISPL 51MD080-1	51D080-1--R-D3-N-T1-D7-N-N-X1-NNN-026-AA-F0-00-37	SERIES 51	S51-080MV-1
83001754	PUMP-TANDEM, VAR DISPL CCW H1T053L	H1-T-053-L-A-N-A4-C1-N-E7-F-G1-NN-28-28-28-28-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83001755	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-BC-80-P-3-F1-E-03-GBA-38-38-24	SERIES 90	S90-100PV
83001757	PUMP-VAR-DISPL CCW H1PV147	H1-P-147-L-C-A3-C3-B-D5-G-G3-H4-L-35-L-35-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83001764	MOTOR-VAR-DISPL 51MV060	51V060-R-S1-N-HZ-B1-A-N-C2-ACA-042-AA-F3-03-00	SERIES 51	S51-060MV
83001766	MOTOR-VAR-DISPL 51MV110	51V110-A-C8-N-HZ-B1-A-N-C2-ACA-080-AA-G3-03-00	SERIES 51	S51-110MV
83001767	PUMP-VAR-DISPL CCW 90PV130	90L130-HS-5-BB-80-S-4-C8-H-03-GBA-35-16-30	SERIES 90	S90-130PV
83001768	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-HZ-B1-A-N-C2-ACA-125-AA-G3-03-00	SERIES 51	S51-160MV
83001769	PUMP-VAR-DISPL CCW H1PV147	H1-P-147-L-C-A3-C3-B-D3-G-G3-NN-L-35-L-35-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83001771	PUMP-VAR DISPL MPV046C	MPV-046-C-B-A-G-S-B-B-BA-A-A-BJJ-AB-U-FF-C-NNN-***	M46	M46-046PV
83001772	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-BC-80-S-3-C7-D-05-GBA-42-42-24	SERIES 90	S90-075PV
83001773	MOTOR-VARIABLE DISPL SAE_K	K-V-45DN-A-RNF-F75-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83001774	MOTOR-VAR-DISPL 51MD080	51D080-R-D2-N-HS-A2-B-E-E1-NNN-045-AA-F3-11-30	SERIES 51	S51-080MV
83001775	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-NN-60-S-4-S1-C-03-GBA-38-38-24	SERIES 90	S90-055PV
83001776	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-5-NN-80-R-3-S1-D-05-FAP-26-26-24	SERIES 90	S90-055PV
83001777	MOTOR-VAR DISPL MMV046C	MMV-046-C-A-D-E-C-A4-VNB-***	M46	M46-046MV
83001782	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-N-T2-C0-L-N-L4-ABA-032-AA-E6-00-C2	SERIES 51	S51-160MV
83001783	PUMP-VAR-DISPL CCW 90PV042	90L042-KA-5-NN-80-S-3-C3-C-03-GBA-35-35-24	SERIES 90	S90-042PV
83001784	PUMP-VAR-DISPL CW 90PV130	90R130-HF-5-NN-80-R-4-C8-F-03-GBA-29-29-24	SERIES 90	S90-130PV
83001786	MOTOR-VAR-DISPL 51MV160	51V160-V-F1-N-H4-B3-R-J-N2-NNN-075-AA-NN-C2-18	SERIES 51	S51-160MV
83001787	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-CD-80-R-4-S1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
83001788	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-NN-80-R-4-S1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
83001793	MOTOR-VARIABLE DISPL SAE_L	L-V-30DS-A-RNF-F08-S-N-N-BF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83001794	PUMP-VAR-DISPL CW 90PV250	90R250-MB-5-NN-80-T-4-C8-K-C5-NNN-42-42-24	SERIES 90	S90-250PV
83001795	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-1-BG-80-L-4-S1-C-03-GBA-20-20-24	SERIES 90	S90-055PV
83001796	MOTOR-VARIABLE DISPL SAE_K	K-V-45DN-A-YNF-F13-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83001805	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KN-1-NN-80-R-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-075PV
83001806	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-CD-60-R-4-S1-C-03-GBA-29-29-24	SERIES 90	S90-075PV
83001807	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-NN-60-R-4-S1-C-03-GBA-29-29-24	SERIES 90	S90-075PV
83001820	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-NN-60-P-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV

83001821	PUMP-VAR DISPL, CCW 90PV100	90-L-100-DC-1-NN-60-P-4-S1-E-GB-GBA-35-35-24	SERIES 90	S90-100PV
83001822	PUMP-VAR DISPL, CW 90PV055	90-R-055-DC-1-BC-60-P-4-S1-C-GB-GBA-35-35-24	SERIES 90	S90-055PV
83001832	MOTOR-VAR-DISPL 51MD060-1	51D060-1--R-D1-N-E2-B1-N-N-U1-NNN-020-AA-E4-00-00	SERIES 51	S51-060MV-1
83001842	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-BC-60-L-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83001843	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-CD-80-P-4-S1-D-00-GBA-17-17-20	SERIES 90	S90-075PV
83001844	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-NN-80-P-4-S1-D-00-GBA-17-17-20	SERIES 90	S90-075PV
83001845	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-BC-80-P-4-F1-E-00-GBA-17-17-20	SERIES 90	S90-100PV
83001847	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-B-Z-C-B-AA-B-B-A-A-BFF-CB-A-HH-B-D-A-A-BFF-CB-A-HH-C-NNN-***	M46	M46-046PT
83001852	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-AB-80-S-3-C6-D-02-GBA-40-40-24	SERIES 90	S90-075PV
83001855	PUMP-VAR-DISPL CW 90PV180	90R180-HF-5-NN-80-T-C-F1-J-03-FAC-35-35-24	SERIES 90	S90-180PV
83001857	PUMP-VAR-DISPL CCW 90PV130	90L130-HS-5-BC-80-P-3-F1-H-03-GBA-24-24-28	SERIES 90	S90-130PV
83001860	PUMP-VAR-DISPL CCW 90PV130	90L130-KN-5-CD-80-R-3-F1-F-03-GBA-42-42-24	SERIES 90	S90-130PV
83001868	PUMP-VAR-DISPL CCW 90PV250	90L250-KP-5-NN-80-T-4-F1-K-03-NNN-42-42-24	SERIES 90	S90-250PV
83001869	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-HZ-B1-A-N-G0-NNN-168-AA-H0-03-00	SERIES 51	S51-250MV
83001873	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HS-1-NN-80-P-4-S1-F-02-GBA-42-42-24	SERIES 90	S90-100PV
83001874	PUMP-VAR-DISPL 42PV041 CW	42-R-51-D-G3AN-50-P-3-G-2-F-5-A-28-28-N-0-0-NNN-NNN	SERIES 42	S42-041PV/051PV
83001875	PUMP-VAR DISPL, CW 90PV055	90-R-055-HS-2-CD-80-P-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
83001876	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HS-2-CD-80-P-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
83001880	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-S1-N-E1-B1-N-N-U1-ABA-036-AA-F0-00-00	SERIES 51	S51-080MV-1
83001881	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-H-S-B-J-BA-A-A-BJJ-CE-A-HH-A-NNN-***	M46	M46-046PV
83001883	MOTOR-VAR-DISPL 51MV080	51V080-R-C7-N-L1-B1-W-B-C0-ADA-040-AA-F0-D4-00	SERIES 51	S51-080MV
83001884	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A4-C1-N-E9-F-G4-H2-K-35-K-35-B-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83001885	PUMP-VAR-DISPL CCW 90PV100	90L100-HS-5-CD-80-S-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83001886	PUMP-VAR-DISPL CCW 90PV075	90L075-HS-5-NN-80-S-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
83001889	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A4-C2-N-F2-F-G5-H2-K-35-K-35-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83001896	PUMP-VAR-DISPL CW 90PV130	90R130-KN-5-BC-80-R-4-C8-F-03-GBA-32-32-24	SERIES 90	S90-130PV
83001897	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-C2-C-C-D8-L-G2-H3-L-33-L-33-A-P-24-P2-C09-D4F	H1-HP PUMPS	H1-115PV/130PV
83001900	MOTOR-VAR-DISPL 51MV060-1	51V060-1--R-S1-N-TA-C2-N-N-X1-NNN-030-AA-NN-00-13	SERIES 51	S51-060MV-1
83001901	PUMP-TANDEM, VAR DISPL MPT025C	MPT-025-C-S-L-A-H-NN-B-A-A-A-BJJ-DL-A-FF-B-A-A-A-BJJ-DL-A-FF-A-NNN-***	LIGHT DUTY	025PT
83001903	PUMP-VAR-DISPL CW 90PV130	90R130-PB-5-DE-80-R-3-F1-H-00-GBA-29-17-24	SERIES 90	S90-130PV
83001905	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-1-BC-60-S-3-S1-E-00-GBA-23-23-24	SERIES 90	S90-100PV
83001927	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-1-AB-80-L-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83001928	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-1-NN-80-L-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83001932	PUMP-VAR-DISPL CCW 90PV100	90L100-MA-5-BC-80-S-3-C7-D-C6-GCA-42-42-24	SERIES 90	S90-100PV
83001933	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D3-N-E2-B1-N-N-U1-NNN-054-AA-NN-00-00	SERIES 51	S51-080MV-1
83001935	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-E2-A5-A-N-A6-NNN-100-AA-F0-03-00	SERIES 51	S51-160MV

83001938	PUMP-VAR-DISPL CW 90PV180	90R180-FH-5-CD-80-S-7-C8-J-B1-NNN-35-35-28	SERIES 90	S90-180PV
83001941	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-D-N2-NN-N-A0-NNN-168-AA-F3-00-00	SERIES 51	S51-250MV
83001943	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-CD-80-L-3-S1-D-03-GBA-38-38-24	SERIES 90	S90-055PV
83001949	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-HZ-B1-B-H-G5-NNN-107-AA-NN-05-00	SERIES 51	S51-160MV
83001951	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A4-C2-N-E5-F-G5-NN-L-35-L-35-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83001952	MOTOR-VAR-DISPL 51MD080	51D080-R-D3-N-L2-B1-V-A-C0-NNN-027-AA-NN-B2-00	SERIES 51	S51-080MV
83001955	PUMP-VAR-DISPL CCW 90PV100	90L100-HS-5-BC-80-S-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83001956	PUMP-VAR-DISPL CCW 90PV100	90L100-HS-5-NN-80-S-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83001957	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-NN-80-R-3-S1-D-06-GBA-42-42-24	SERIES 90	S90-075PV
83001963	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-CD-80-R-3-C7-D-03-GBA-42-42-24	SERIES 90	S90-075PV
83001964	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-BC-80-R-4-C8-H-03-GBA-32-14-24	SERIES 90	S90-130PV
83001966	PUMP-VAR-DISPL CCW 90PV130	90L130-HF-5-CD-80-R-4-F1-F-03-GBA-35-35-24	SERIES 90	S90-130PV
83001967	PUMP-VAR-DISPL CCW 90PV180	90L180-KN-5-CD-80-T-M-F1-H-03-FAC-35-35-24	SERIES 90	S90-180PV
83001968	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A4-C2-N-E5-F-G5-NN-L-33-L-33-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83001972	MOTOR-VAR-DISPL 51MD080-1	51D080-1--A-D2-N-P7-P7-N-N-X1-AWM-020-AA-E4-00-AA	SERIES 51	S51-080MV-1
83001976	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-BC-80-R-3-F1-H-03-GBA-32-32-24	SERIES 90	S90-130PV
83001977	MOTOR-VARIABLE CARTRIDGE K	K-C-38CS-E-RNF-F04-S-N-N-EF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83001978	MOTOR-VAR-DISPL 51MD080	51D080-A-D3-N-L1-B1-W-B-C0-ACA-016-AA-F0-D4-00	SERIES 51	S51-080MV
83001979	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A5-C2-N-E5-F-G5-NN-L-33-L-33-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83001984	MOTOR-VAR-DISPL 51MD060-1	51D060-1--K-D1-N-T1-D1-N-N-X1-ADA-027-AA-E6-00-21	SERIES 51	S51-060MV-1
83001985	PUMP-VAR-DISPL CCW 90PV075	90L075-MA-5-BB-80-S-3-C7-D-C6-GBA-40-40-24	SERIES 90	S90-075PV
83001986	MOTOR-VAR-DISPL 51MD060-1	51D060-1--A-D1-N-N1-NN-N-N-U1-NNN-035-AA-NN-00-00	SERIES 51	S51-060MV-1
83001992	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-CD-80-P-3-S1-D-03-GBA-40-40-24	SERIES 90	S90-055PV
83001993	MOTOR-VAR-DISPL 51MD110	51D110-R-D3-N-L2-B1-V-A-C0-NNN-040-AA-E6-B2-00	SERIES 51	S51-110MV
83001995	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A5-C2-N-F1-F-G5-NN-K-35-K-35-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83001996	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A5-C2-N-F1-F-G5-H3-K-35-K-35-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83002000	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-1-BG-80-L-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83002002	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-CD-80-L-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83002005	PUMP-VAR-DISPL CW 90PV130	90R130-KT-5-NN-80-R-3-F1-H-03-GBA-38-38-24	SERIES 90	S90-130PV
83002011	MOTOR-VAR-DISPL 51MD080-1	51D080-1--R-D2-N-E2-B1-N-N-U1-NNN-040-AA-NN-00-00	SERIES 51	S51-080MV-1
83002015	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-NN-80-R-4-C8-H-03-GBA-23-23-24	SERIES 90	S90-130PV
83002018	PUMP-VAR DISPL, CW 90PV100	90-R-100-KN-1-AB-60-R-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83002019	PUMP-VAR DISPL, CW 90PV075	90-R-075-HS-1-BC-80-S-3-S1-E-03-GBA-29-29-28	SERIES 90	S90-075PV
83002031	PUMP, VARIABLE DIRECT DISPLACMENT	LPV-B-A-B-A-A-G-AA-C-A-BDD-DR-A-FF-B-NNN-***	LPV	LPV
83002032	MOTOR-VAR-DISPL 51MD110	51D110-A-D3-N-L7-B1-W-B-G5-NNN-034-AA-F0-D4-00	SERIES 51	S51-110MV
83002033	MOTOR-VAR-DISPL 51MD160	51D160-R-D4-N-HZ-B1-B-N-C2-NNN-032-AA-NN-10-00	SERIES 51	S51-160MV

83002035	MOTOR-VAR-DISPL 51MC110-1	51C110-1--A-D3-N-E2-B1-N-N-U1-ACB-050-AA-NN-00-00	SERIES 51	S51-110MV-1
83002037	PUMP-VAR-DISPL CW 90PV180	90R180-PB-2-CD-80-S-C-C8-H-03-NNN-40-40-24	SERIES 90	S90-180PV
83002039	MOTOR-VARIABLE DISPL SAE_L	L-V-25CN-E-Y1F-F09-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83002042	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-N-HZ-B1-A-E-G5-NNN-168-AA-NN-05-00	SERIES 51	S51-250MV
83002048	PUMP-VAR DISPL, CW 90PV055	90-R-055-HF-5-NN-80-R-4-C6-C-00-GCA-29-29-20	SERIES 90	S90-055PV
83002050	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-A-N1-NN-N-N-U1-NNN-036-AA-E6-00-00	SERIES 51	S51-060MV-1
83002051	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-ES-A5-K-Y-G5-NNN-026-AA-F0-50-00	SERIES 51	S51-080MV
83002054	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-BG-80-R-3-S1-C-03-GBA-29-29-24	SERIES 90	S90-055PV
83002055	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-CD-80-R-3-S1-D-03-GBA-29-29-24	SERIES 90	S90-055PV
83002056	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-N-A2-C1-N-D1-F-G1-H2-25-25-25-25-N-P-22-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83002063	PUMP-VAR-DISPL CW 90PV100	90R100-PB-5-NN-80-R-3-F1-E-00-GBA-29-29-24	SERIES 90	S90-100PV
83002066	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-B-E2-A5-A-N-A6-NNN-130-AA-F3-03-00	SERIES 51	S51-250MV
83002067	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-E2-A5-A-N-A6-NNN-083-AA-F3-03-00	SERIES 51	S51-250MV
83002068	PUMP-VAR-DISPL CCW H1PV147	H1-P-147-L-C-A3-C2-B-D3-G-G3-H6-L-30-L-30-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83002069	PUMP-VAR-DISPL CCW 90PV042	90L042-KA-5-NN-80-S-4-C3-B-03-GBA-23-23-20	SERIES 90	S90-042PV
83002071	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-NN-80-P-3-F1-F-03-GBA-29-29-20	SERIES 90	S90-130PV
83002075	PUMP, VARIABLE DIRECT DISPLACMENT	LPV-A-A-A-A-E-AC-C-A-BDD-DR-A-FF-B-NNN-***	LPV	LPV
83002078	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-L2-B1-V-A-C0-NNN-095-AA-G3-B2-00	SERIES 51	S51-160MV
83002079	PUMP, VARIABLE DIRECT DISPLACMENT	LPV-C-A-B-B-A-E-AB-D-A-BGG-DL-A-FF-A-NNB-***	LPV	LPV
83002080	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-HZ-B1-A-E-C2-NNN-080-AA-NN-03-00	SERIES 51	S51-250MV
83002081	MOTOR-VAR-DISPL 51MV080	51V080-R-C7-N-HZ-B1-A-E-C2-NNN-026-AA-NN-03-00	SERIES 51	S51-080MV
83002083	PUMP-VAR-DISPL CW 90PV130	90R130-KT-5-NN-80-P-3-F1-H-03-GBA-38-38-24	SERIES 90	S90-130PV
83002085	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-AB-60-R-3-S1-E-03-GBA-35-35-28	SERIES 90	S90-100PV
83002091	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-G2A1-52-U-D-G-2-F-5-B-34-34-B-0-0-NNN-NNN	SERIES 42	S42-028PV/032PV
83002095	PUMP-VAR DISPL, CW 90PV100	90-R-100-KT-5-NN-80-R-3-S1-F-03-GBA-38-38-24	SERIES 90	S90-100PV
83002097	MOTOR-VAR-DISPL 51MD060-1	51D060-1--K-D2-N-T1-D1-N-N-X1-ADA-027-AA-E6-00-21	SERIES 51	S51-060MV-1
83002098	PUMP-VAR-DISPL CW 90PV130	90R130-KN-5-CD-80-R-4-F1-H-03-GBA-30-30-24	SERIES 90	S90-130PV
83002101	MOTOR-VAR-DISPL 51MC060	51C060-R-D1-N-L2-B1-V-A-C0-ACB-012-AA-E4-B2-00	SERIES 51	S51-060MV
83002102	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-TA-C2-L-N-G0-NNN-055-AA-NN-00-A9	SERIES 51	S51-160MV
83002103	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-N-A2-C1-N-D1-F-G1-H3-25-25-25-25-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83002104	PUMP-VAR DISPL CCW H1P053L	H1-P-053-L-A-A2-C3-N-E6-F-G5-H2-L-35-L-35-B-L-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83002105	PUMP-VAR-DISPL CW 90PV075	90R075-MB-5-BB-60-D-3-C7-L-C7-GBA-42-42-24	SERIES 90	S90-075PV
83002112	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-HS-A2-B-H-G6-NNN-100-AA-H0-05-20	SERIES 51	S51-250MV
83002113	PUMP-VAR-DISPL CW 90PV100	90R100-FH-5-CD-60-S-7-C7-E-B3-EFI-40-40-30	SERIES 90	S90-100PV
83002120	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-BB-80-D-3-F1-L-00-GBA-26-26-24	SERIES 90	S90-130PV
83002121	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MV-1-AB-60-S-4-S1-F-05-GBA-32-32-24	SERIES 90	S90-100PV

83002122	PUMP-VAR-DISPL CW 90PV075	90R075-CA-5-AB-80-P-7-C7-D-00-FAC-42-42-28	SERIES 90	S90-075PV
83002126	PUMP-VAR-DISPL CW 90PV100	90R100-MA-5-AB-80-P-4-C7-E-C5-GBA-26-26-24	SERIES 90	S90-100PV
83002127	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-NN-80-S-4-C8-H-03-GBA-32-32-24	SERIES 90	S90-130PV
83002128	PUMP-VAR-DISPL CW 90PV130	90R130-FG-5-AB-80-L-7-C8-H-B1-GCA-42-42-32	SERIES 90	S90-130PV
83002129	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-S1-N-N1-NN-N-N-U1-NNN-036-AA-E6-00-00	SERIES 51	S51-080MV-1
83002130	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-E-N1-NN-N-N-U1-NNN-028-AA-E6-00-00	SERIES 51	S51-060MV-1
83002131	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-S1-N-E1-B1-N-N-U1-ABA-042-AA-F0-00-00	SERIES 51	S51-080MV-1
83002133	PUMP-VAR-DISPL CW 90PV130	90R130-KT-5-CD-80-R-3-F1-H-03-GBA-38-38-24	SERIES 90	S90-130PV
83002135	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-N-E2-B1-N-N-U1-ACB-024-AA-E6-00-00	SERIES 51	S51-060MV-1
83002136	PUMP-VAR-DISPL 42PV041 CW	42-R-41-E-ANNB-02-A-N-N-N-F-N-V-B8-B8-N-A-A-NNN-ENN	SERIES 42	S42-041PV/051PV
83002137	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-ANNB-02-A-N-N-N-F-N-B-B8-B8-N-A-A-NNN-ENN	SERIES 42	S42-041PV/051PV
83002144	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-BC-80-L-3-F1-F-03-GBA-42-42-24	SERIES 90	S90-130PV
83002148	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-NN-60-P-3-C7-D-03-GBA-32-32-28	SERIES 90	S90-075PV
83002149	MOTOR-VAR-DISPL 51MV060-1	51V060-1--R-C6-N-T2-C2-N-N-X1-ADA-015-AA-E6-00-30	SERIES 51	S51-060MV-1
83002152	MOTOR-VARIABLE CARTRIDGE K	K-C-45DN-E-YNF-F12-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83002153	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-1-NN-60-P-3-S1-D-03-GBA-35-35-20	SERIES 90	S90-075PV
83002154	PUMP-VAR DISPL, CCW 90PV100	90-L-100-DC-1-NN-80-L-4-F1-E-GB-GBA-23-23-24	SERIES 90	S90-100PV
83002158	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A3-C2-N-D6-G-G3-H3-L-38-L-38-L-L-30-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83002159	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A3-C2-N-D9-G-G3-H4-L-38-L-38-L-L-30-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83002160	PUMP-VAR-DISPL CCW 90PV130	90L130-HF-5-CD-80-P-3-TK-H-03-GBA-42-42-24	SERIES 90	S90-130PV
83002161	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-EQ-A2-J-Y-E1-ADA-100-AA-G0-30-28	SERIES 51	S51-160MV
83002165	MOTOR-VAR-DISPL 51MD160	51D160-R-D5-N-D8-M1-R-J-M4-ADA-066-AA-G0-C2-18	SERIES 51	S51-160MV
83002166	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-CD-80-S-3-C7-E-03-GBA-36-36-24	SERIES 90	S90-100PV
83002170	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-H-S-B-B-BA-G-A-BJJ-DA-A-HH-A-NNN-***	M46	M46-046PV
83002171	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-TA-C2-L-N-G0-NNN-138-AA-G0-00-B0	SERIES 51	S51-250MV
83002181	PUMP-VAR DISPL, CW 90PV055	90-R-055-HS-1-BG-80-P-4-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83002182	PUMP-VAR DISPL, CW 90PV075	90-R-075-HS-1-CD-60-P-3-S1-D-03-GBA-23-23-24	SERIES 90	S90-075PV
83002183	MOTOR-VAR-DISPL 51MD110-1	51D110-1--A-D4-N-P7-P7-N-N-X1-AWM-024-AA-E6-00-AA	SERIES 51	S51-110MV-1
83002186	PUMP-VAR-DISPL CCW 90PV130	90L130-FG-5-NN-80-L-7-F1-F-B1-EBA-35-35-24	SERIES 90	S90-130PV
83002187	PUMP-VAR-DISPL CCW 90PV130	90L130-KT-5-NN-80-P-3-F1-H-03-GBA-38-38-24	SERIES 90	S90-130PV
83002188	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-E2-A5-A-N-G0-NNN-075-AA-G0-03-00	SERIES 51	S51-250MV
83002190	PUMP-VAR-DISPL CCW 90PV180	90L180-KP-5-EF-80-T-C-C8-J-03-FAC-35-35-24	SERIES 90	S90-180PV
83002194	PUMP-TANDEM, VAR DISPL MPT025C	MPT-025-C-S-R-A-E-NN-B-A-A-A-BEE-DR-A-FF-B-A-A-A-BEE-DL-A-FF-A-NNN-**	LIGHT DUTY	025PT
83002196	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-NN-60-S-4-S1-E-00-GBA-38-38-24	SERIES 90	S90-100PV
83002197	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-E2-A5-A-N-G0-ADA-042-AA-G0-03-00	SERIES 51	S51-080MV
83002201	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-EQ-A7-J-Y-E1-CCA-168-AA-F3-15-16	SERIES 51	S51-250MV

83002202	PUMP-VAR-DISPL CCW 90PV180	90L180-KP-5-BC-80-T-C-C8-J-03-FAC-35-35-24	SERIES 90	S90-180PV
83002203	PUMP-VAR-DISPL CCW 90PV180	90L180-KP-5-CD-80-T-C-C8-J-03-FAC-35-35-24	SERIES 90	S90-180PV
83002204	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-L2-B1-V-A-G5-ACA-030-AA-NN-B2-00	SERIES 51	S51-080MV
83002207	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-NN-60-S-4-S1-C-00-GBA-38-38-24	SERIES 90	S90-055PV
83002208	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-NN-80-R-4-S1-C-03-GBA-29-29-24	SERIES 90	S90-055PV
83002209	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-BK-80-S-3-C6-C-03-GBA-42-42-24	SERIES 90	S90-055PV
83002210	PUMP-VAR-DISPL CW 90PV250	90R250-KP-5-EF-80-T-4-C8-K-00-NNN-38-38-24	SERIES 90	S90-250PV
83002213	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-BC-80-R-3-F1-F-03-GBA-38-38-24	SERIES 90	S90-100PV
83002222	PUMP-VAR-DISPL CW 90PV250	90R250-KP-5-NN-80-T-4-C8-K-00-NNN-38-38-24	SERIES 90	S90-250PV
83002224	MOTOR-FIX DISPL MMF035D	MMF-035-D-A-A-U-A-S-NNN-***	M35/44	035MF
83002227	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-NN-80-L-3-C8-H-03-GBA-35-35-24	SERIES 90	S90-130PV
83002231	PUMP-VAR DISPL MPV046C	MPV-046-C-B-A-B-T-B-B-BA-A-A-BGG-AB-U-DD-A-NNN-***	M46	M46-046PV
83002232	MOTOR-VAR-DISPL 51MC110-1	51C110-1--A-D3-N-N1-NN-N-N-U1-NNN-022-AA-NN-00-00	SERIES 51	S51-110MV-1
83002233	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-E2-A5-A-N-G0-ACA-075-AA-G0-03-00	SERIES 51	S51-250MV
83002234	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-CD-80-R-3-F1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
83002235	PUMP-VAR-DISPL CW 90PV130	90R130-KN-5-BC-80-S-3-C8-H-03-GBA-32-32-24	SERIES 90	S90-130PV
83002237	PUMP-VAR DISPL, CW 90PV075	90-R-075-MV-5-AB-60-R-3-S1-D-C5-GBA-35-35-24	SERIES 90	S90-075PV
83002238	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-NN-60-L-4-K2-D-03-GBA-20-20-20	SERIES 90	S90-075PV
83002239	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-CD-80-R-3-S1-C-05-GBA-35-35-24	SERIES 90	S90-055PV
83002241	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-NN-80-R-3-S1-C-05-GBA-35-35-24	SERIES 90	S90-055PV
83002242	PUMP-VAR DISPL, CW 90PV055	90-R-055-HS-1-AD-80-R-4-S1-C-00-GBA-35-35-24	SERIES 90	S90-055PV
83002247	PUMP-VAR-DISPL CCW 90PV130	90L130-MA-5-BB-80-S-3-C8-F-C6-GBS-42-42-24	SERIES 90	S90-130PV
83002248	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KN-1-NN-80-P-4-S1-D-03-GBA-17-17-24	SERIES 90	S90-075PV
83002255	PUMP-VAR-DISPL CW 90PV100	90R100-FD-5-CD-80-S-7-C7-E-B1-GBA-42-42-28	SERIES 90	S90-100PV
83002259	PUMP-VAR DISPL, CW 90PV055	90-R-055-HF-5-NN-80-P-4-C6-C-00-GCA-29-29-20	SERIES 90	S90-055PV
83002265	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MV-5-AB-60-R-3-S1-D-C5-GBA-35-35-24	SERIES 90	S90-075PV
83002267	PUMP-VAR-DISPL 42PV041 CW	42-R-51-E-G3AN-50-P-2-G-3-G-5-V-32-32-B-0-0-NNN-NNN	SERIES 42	S42-041PV/051PV
83002268	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-E2-A5-A-N-A6-ACB-075-AA-F3-03-00	SERIES 51	S51-250MV
83002270	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-E2-A5-A-N-A6-NNN-100-AA-F3-03-00	SERIES 51	S51-250MV
83002271	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-E2-A5-A-N-A6-ACB-100-AA-F3-03-00	SERIES 51	S51-250MV
83002273	MOTOR-VAR-DISPL 51MV060-1	51V060-1--R-S1-N-T2-C2-N-N-X1-NNN-036-AA-E6-00-23	SERIES 51	S51-060MV-1
83002274	MOTOR-VAR-DISPL 51MD080-1	51D080-1--A-D3-N-N1-NN-N-N-U1-ABA-050-AA-F0-00-00	SERIES 51	S51-080MV-1
83002276	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-BC-80-S-3-C3-B-03-GBA-42-42-24	SERIES 90	S90-042PV
83002278	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-5-AB-80-T-4-C8-J-05-NNN-23-23-24	SERIES 90	S90-250PV
83002279	PUMP-VAR-DISPL CW 90PV075	90R075-DD-5-NN-60-S-4-C6-C-GF-GBA-20-20-24	SERIES 90	S90-075PV
83002280	PUMP-VAR-DISPL CW 90PV075	90R075-HS-5-NN-80-S-4-C7-D-05-GBA-38-38-24	SERIES 90	S90-075PV

83002281	PUMP-VAR-DISPL CW 90PV100	90R100-HS-5-NN-80-S-4-C7-D-05-GBA-38-38-24	SERIES 90	S90-100PV
83002283	MOTOR-FIXED DISPL MMF025C	MMF-025-C-A-N-R-C-J-NNN-***	LIGHT DUTY	025MF
83002285	MOTOR-VAR-DISPL 51MC110	51C110-R-D3-N-HZ-B1-C-H-G5-NNN-065-AA-F0-20-00	SERIES 51	S51-110MV
83002286	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-N1-NN-N-U1-NNN-055-AA-E4-00-00	SERIES 51	S51-110MV-1
83002287	MOTOR-VAR-DISPL 51MV160	51V160-A-C8-N-L1-B1-W-B-C0-ABA-100-AA-F3-D4-00	SERIES 51	S51-160MV
83002289	PUMP-VAR-DISPL 42PV041 CW	42-R-51-D-G3AN-50-P-2-G-3-G-5-B-32-32-B-0-0-NNN-NNN	SERIES 42	S42-041PV/051PV
83002290	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-CD-60-P-3-F1-E-03-GBA-23-23-24	SERIES 90	S90-100PV
83002293	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-NN-80-P-3-K3-E-00-GBA-26-26-24	SERIES 90	S90-100PV
83002294	PUMP-VAR DISPL, CW 90PV075	90-R-075-MV-1-AB-60-R-3-S1-E-C5-GBA-32-32-24	SERIES 90	S90-075PV
83002299	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-AB-60-R-3-S1-E-03-GBA-38-38-24	SERIES 90	S90-100PV
83002302	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-HZ-B1-C-H-G5-NNN-032-AA-F0-15-00	SERIES 51	S51-160MV
83002316	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-A-V-C-B-BA-B-B-A-A-BGG-BA-A-GG-B-D-A-A-BGG-BA-A-GG-A-NNN	M46	M46-046PT
83002317	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-NN-80-R-3-F1-H-00-GBA-42-42-24	SERIES 90	S90-130PV
83002318	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A3-C2-N-D8-G-G3-H5-L-43-L-43-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83002320	PUMP-VAR DISPL, CW 90PV100	90-R-100-HS-1-BC-60-P-4-C7-F-03-GBA-42-42-24	SERIES 90	S90-100PV
83002321	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MB-1-NN-60-P-3-C6-D-03-GBA-40-40-24	SERIES 90	S90-075PV
83002325	MOTOR-FIXED DISPL MMF025C	MMF-025-C-A-T-B-A-C-NNN-***	LIGHT DUTY	025MF
83002327	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-1-CD-60-R-4-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
83002329	PUMP-VAR DISPL MPV046C	MPV-046-C-B-A-B-S-B-B-AA-A-A-BJJ-AB-D-CD-A-NNN-***	M46	M46-046PV
83002330	MOTOR-FIXED DISPL MMF025C	MMF-025-C-A-S-G-C-F-NNN-***	LIGHT DUTY	025MF
83002332	PUMP-VAR DISPL, CW 90PV075	90-R-075-MV-1-BE-62-R-3-C7-E-03-GBA-45-45-24	SERIES 90	S90-075PV
83002334	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-AB-80-S-M-F1-H-03-NNN-23-23-24	SERIES 90	S90-180PV
83002335	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-CD-80-D-3-C8-L-03-GBA-42-14-34	SERIES 90	S90-130PV
83002336	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-NN-80-D-3-C8-L-03-GBA-42-14-34	SERIES 90	S90-130PV
83002337	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-E2-A5-A-N-G0-NNN-125-AA-NN-03-00	SERIES 51	S51-250MV
83002343	PUMP-VAR DISPL, CCW 90PV055	90-L-055-DD-1-NN-60-P-4-C6-D-GB-GBA-35-35-24	SERIES 90	S90-055PV
83002353	PUMP-VAR-DISPL CW 90PV075	90R075-KA-1-CD-80-S-3-C7-D-03-GBA-32-32-20	SERIES 90	S90-075PV
83002355	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-S1-N-E2-B1-N-N-U1-NNN-038-AA-F0-00-00	SERIES 51	S51-080MV-1
83002356	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-5-CD-60-S-4-S1-F-03-GBA-23-23-24	SERIES 90	S90-100PV
83002361	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HS-5-BC-60-L-4-F1-E-04-GBA-35-35-24	SERIES 90	S90-100PV
83002374	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-N-A4-C2-N-E7-F-G1-H3-30-30-20-38-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83002375	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-CD-60-S-4-C6-C-00-GBA-38-38-24	SERIES 90	S90-055PV
83002380	MOTOR-VARIABLE DISPL SAE_L	L-V-30DN-A-RNF-F12-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83002381	PUMP-VAR DISPL MPV035D	MPV-035-D-B-A-A-R-S-G-BA-A-A-BJJ-DL-A-FF-C-NNN-***	M35/44	035PV
83002384	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A5-C2-N-F6-H-G9-H6-L-38-L-38-C-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83002385	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A5-C2-N-F6-H-G1-H6-L-38-L-38-C-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV

83002389	MOTOR-VAR-DISPL 51MV080-1	51V080-1--A-S1-N-TA-C2-N-N-X1-NNN-050-AA-F3-00-16	SERIES 51	S51-080MV-1
83002392	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-NN-80-S-4-S1-D-00-GBA-35-35-24	SERIES 90	S90-075PV
83002393	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MA-1-NN-80-S-4-F1-E-00-GBA-35-35-24	SERIES 90	S90-100PV
83002404	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-C-N-0-S1-X-00-NNN-00-00-NN	SERIES 90	S90-055MF
83002406	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-S-B-J-AA-A-A-BBB-BA-A-GG-A-NNN-***	M46	M46-046PV
83002407	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A2-C3-N-E7-F-G1-H3-33-33-33-33-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83002408	PUMP-VAR-DISPL CCW 90PV130	90L130-MA-5-NN-80-S-3-F1-F-C5-GBA-23-23-24	SERIES 90	S90-130PV
83002409	PUMP-VAR-DISPL CW 90PV130	90R130-MA-5-NN-80-S-4-F1-F-C5-GBA-23-23-24	SERIES 90	S90-130PV
83002411	MOTOR-VAR-DISPL 51MV110	51V110-A-C8-N-D8-M1-R-J-M1-ADA-059-AA-F3-C2-19	SERIES 51	S51-110MV
83002413	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-1-AD-80-P-3-C6-D-03-FAD-29-29-24	SERIES 90	S90-055PV
83002414	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-AB-80-P-4-C7-E-03-FAD-32-32-24	SERIES 90	S90-100PV
83002415	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-NN-80-S-4-S1-C-03-GBA-38-38-20	SERIES 90	S90-055PV
83002421	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-BB-80-L-3-F1-F-03-GBA-45-45-24	SERIES 90	S90-130PV
83002422	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-BC-80-P-3-S1-E-05-GBA-38-38-24	SERIES 90	S90-075PV
83002425	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-HZ-B1-B-H-G5-NNN-030-AA-NN-05-00	SERIES 51	S51-080MV
83002426	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-HZ-B1-B-H-G5-ACA-030-AA-NN-05-00	SERIES 51	S51-080MV
83002428	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-BC-80-R-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83002429	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A5-C2-N-D6-F-G1-H5-L-35-L-35-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83002430	PUMP-VAR-DISPL CW 90PV042	90R042-HF-5-NN-80-P-4-C3-C-00-GCA-29-29-20	SERIES 90	S90-042PV
83002431	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-NN-80-P-3-F1-E-03-GBA-14-35-24	SERIES 90	S90-100PV
83002434	PUMP-VAR DISPL, CW 90PV075	90-R-075-MH-5-CR-62-S-3-C6-S-42-FAU-40-40-22-P020	SERIES 90	S90-075PV
83002442	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-DE-80-L-3-C8-F-03-GBA-45-45-24	SERIES 90	S90-130PV
83002443	PUMP-VAR DISPL, CW 90PV055	90-R-055-CA-1-NN-80-P-4-S1-D-00-GBA-35-35-24	SERIES 90	S90-055PV
83002444	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-CD-80-D-3-S1-L-00-GBA-29-14-24	SERIES 90	S90-075PV
83002445	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-BC-80-D-3-S1-L-00-GBA-29-14-24	SERIES 90	S90-075PV
83002446	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A5-C2-B-D3-H-G9-H5-L-35-L-35-C-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83002447	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A5-C2-N-D6-F-G5-H3-L-35-L-35-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83002449	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-CD-80-T-C-F1-J-05-NNN-42-42-24	SERIES 90	S90-180PV
83002452	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-CD-80-L-4-C8-F-05-GBA-26-26-24	SERIES 90	S90-130PV
83002453	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-NN-80-R-4-F1-F-03-GBA-29-29-24	SERIES 90	S90-130PV
83002461	MOTOR-VAR-DISPL 51MV250	51V250-A-C8-N-E2-A5-A-N-A6-NNN-160-AA-NN-03-00	SERIES 51	S51-250MV
83002462	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-AB-80-L-4-F1-F-00-EEB-35-35-24	SERIES 90	S90-130PV
83002465	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HS-1-AB-80-R-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83002466	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-AB-60-P-3-C7-E-03-GBA-38-14-24	SERIES 90	S90-100PV
83002467	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-1-NN-80-S-4-S1-D-00-GBA-35-35-24	SERIES 90	S90-075PV
83002472	MOTOR-VAR-DISPL 51MV110	51V110-R-C8-N-L2-B1-V-A-J1-ADA-030-AA-NN-B2-00	SERIES 51	S51-110MV

83002474	PUMP-TANDEM, VAR DISPL MPT044D	MPT-044-D-A-W-R-E-AA-B-A-A-A-BGG-DR-A-FF-B-A-A-A-BGG-DR-A-FF-C-NNN-	M35/44	044PT
83002475	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-NN-80-S-3-S1-B-00-GBA-20-20-24	SERIES 90	S90-055PV
83002495	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D2-N-E1-B1-N-N-U1-ADA-040-AA-F3-00-00	SERIES 51	S51-060MV-1
83002502	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MV-1-AB-60-R-3-S1-E-C5-GBA-32-32-24	SERIES 90	S90-075PV
83002523	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-DE-80-P-3-C8-F-03-GBA-35-35-24	SERIES 90	S90-130PV
83002524	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-NN-80-P-3-F1-H-03-GBA-35-35-24	SERIES 90	S90-130PV
83002525	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-C8-N-E2-B1-N-N-U1-NNN-055-AA-F0-00-00	SERIES 51	S51-110MV-1
83002526	PUMP-VAR-DISPL CW 90PV130	90R130-DD-5-NN-80-S-3-F1-F-GB-GBA-38-38-24	SERIES 90	S90-130PV
83002530	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-HS-A2-C-E-E1-NNN-054-AA-F0-16-29	SERIES 51	S51-080MV
83002531	MOTOR-VAR-DISPL 51MV110	51V110-R-F1-N-HS-A2-C-E-E1-NNN-055-AA-F0-16-29	SERIES 51	S51-110MV
83002533	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A3-C2-B-E5-F-G5-NN-L-35-L-35-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83002535	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-NN-80-P-4-S1-E-03-GBA-23-23-20	SERIES 90	S90-100PV
83002536	PUMP-VAR DISPL, CW 90PV075	90-R-075-HF-1-BC-80-R-4-S1-D-03-GBA-20-20-24	SERIES 90	S90-075PV
83002543	PUMP-VAR DISPL, CW 90PV075	90-R-075-HF-1-CD-80-R-4-K2-D-03-GBA-20-20-24	SERIES 90	S90-075PV
83002544	MOTOR- VARIABLE CARTRIDGE L	L-C-25CS-E-R4F-F07-S-N-N-FF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83002548	PUMP-VAR DISPL, CW 90PV055	90-R-055-HS-1-NN-80-R-3-S1-C-03-GBA-38-38-24	SERIES 90	S90-055PV
83002551	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-5-NN-80-P-3-T2-E-03-GBA-38-38-20	SERIES 90	S90-100PV
83002554	PUMP-VAR-DISPL CCW 90PV130	90L130-MA-5-NN-80-R-3-F1-F-C5-GBA-35-35-24	SERIES 90	S90-130PV
83002556	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-BK-80-S-3-C6-C-03-GBA-42-42-24	SERIES 90	S90-055PV
83002557	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A4-C2-B-D6-G-G2-H3-L-45-L-45-A-L-30-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83002558	PUMP-VAR-DISPL CCW H1PV115	H1-P-115-L-B-A4-C2-N-D6-G-G3-H6-L-42-L-42-L-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83002560	PUMP-VAR-DISPL CW 90PV180	90R180-FH-5-BC-80-T-7-C8-J-B1-NNN-35-35-30	SERIES 90	S90-180PV
83002562	PUMP-VAR-DISPL CCW H1PV147	H1-P-147-L-C-A3-C3-B-D3-G-G3-H6-L-35-L-35-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83002567	MOTOR-VAR-DISPL 51MD110	51D110-R-D3-N-HS-A1-C-E-A2-ADA-050-AA-E6-12-30	SERIES 51	S51-110MV
83002572	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A3-C2-N-D9-G-G3-H4-L-40-L-40-L-L-30-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83002574	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-BB-60-L-3-F1-D-03-FAD-42-42-28	SERIES 90	S90-100PV
83002575	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-BC-80-P-3-S1-D-03-GBA-40-40-24	SERIES 90	S90-100PV
83002576	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-CD-80-P-3-F1-D-03-GBA-40-40-24	SERIES 90	S90-100PV
83002580	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-N-T2-N5-N-N-X1-AWH-020-AA-E4-00-20	SERIES 51	S51-060MV-1
83002584	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-BC-80-R-4-C8-H-03-GBA-14-32-24	SERIES 90	S90-130PV
83002594	MOTOR-VARIABLE DISPL SAE_K	K-V-45DS-A-YNF-F06-S-N-N-BF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83002597	PUMP-VAR-DISPL CCW 90PV180	90L180-KP-5-CD-80-T-M-F1-J-00-EBA-42-42-24	SERIES 90	S90-180PV
83002599	MOTOR-VAR-DISPL 51MD080-1	51D080-1--R-D2-N-E2-B1-N-N-U1-NNN-025-AA-E6-00-00	SERIES 51	S51-080MV-1
83002600	MOTOR-VAR-DISPL 51MD110-1	51D110-1--R-D3-N-E2-B1-N-N-U1-NNN-030-AA-F0-00-00	SERIES 51	S51-110MV-1
83002601	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-BC-60-P-4-F1-F-03-GBA-26-26-24	SERIES 90	S90-100PV
83002603	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-NN-80-P-3-F1-F-04-GBA-40-40-24	SERIES 90	S90-130PV

83002604	PUMP-VAR-DISPL CCW 90PV180	90L180-KP-5-DE-80-T-C-C8-H-03-FAC-36-36-24	SERIES 90	S90-180PV
83002605	PUMP-VAR-DISPL CCW 90PV130	90L130-HF-5-CD-80-L-4-F1-H-03-GBA-35-35-24	SERIES 90	S90-130PV
83002606	MOTOR-VAR-DISPL 51MV250	51V250-U-F2-D-H4-B3-R-J-N2-NNN-090-AA-NN-C2-24	SERIES 51	S51-250MV
83002608	PUMP-VAR-DISPL CCW 90PV100	90L100-DC-5-NN-60-S-3-C7-E-GB-GBA-42-42-24	SERIES 90	S90-100PV
83002609	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-N-E1-B1-N-N-U1-NNN-020-AA-F0-00-00	SERIES 51	S51-060MV-1
83002611	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-2-NN-80-R-3-C8-F-06-GBA-42-42-24	SERIES 90	S90-130PV
83002612	PUMP-VAR-DISPL CW 90PV250	90R250-KP-5-CD-80-T-3-C8-J-03-NNN-40-40-24	SERIES 90	S90-250PV
83002615	PUMP-VAR-DISPL CCW 90PV130	90L130-FH-5-DE-80-S-7-F1-F-B1-GLA-45-45-30	SERIES 90	S90-130PV
83002624	MOTOR-VARIABLE DISPL SAE_K	K-V-45DS-C-RNF-F55-T-N-X-CF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83002629	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-BC-80-R-3-F1-F-03-GBA-40-40-24	SERIES 90	S90-100PV
83002633	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-G2A1-52-U-2-G-2-F-5-A-34-34-B-1-1-NNN-NNN	SERIES 42	S42-028PV/032PV
83002634	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-A1N5-02-C-2-N-N-G-N-A-30-30-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83002638	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A5-C1-N-E5-F-G5-H3-L-35-L-35-N-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83002639	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A4-C1-N-D8-F-G5-H2-L-33-L-33-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83002642	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-G3AN-52-P-3-C-2-F-1-T-30-30-N-1-1-NNN-NNN	SERIES 42	S42-028PV/032PV
83002643	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-G3AN-52-P-3-C-2-F-1-B-30-30-N-1-1-NNN-NNN	SERIES 42	S42-028PV/032PV
83002644	PUMP-VAR-DISPL CCW 90PV180	90L180-KP-5-BC-80-S-C-C8-H-03-FAC-32-32-24	SERIES 90	S90-180PV
83002645	PUMP-VAR-DISPL CCW 90PV180	90L180-KP-5-DE-80-S-C-C8-H-03-FAC-32-32-24	SERIES 90	S90-180PV
83002646	PUMP-TANDEM, VAR DISPL MPT044D	MPT-044-D-A-W-S-J-AA-B-A-A-A-BGG-DR-A-FF-B-C-A-A-BGG-DL-A-FF-C-NNN-*	M35/44	044PT
83002653	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-G-S-B-B-AA-A-A-BFF-CB-A-HH-C-NNN-***	M46	M46-046PV
83002655	PUMP-VAR DISPL CCW H1P053L	H1-P-053-L-A-A2-C1-B-E5-F-G4-NN-L-30-L-20-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83002656	PUMP-VAR-DISPL CW 90PV075	90R075-MA-5-BC-60-P-4-S1-E-C5-GBA-20-20-24	SERIES 90	S90-075PV
83002657	MOTOR-VAR-DISPL 51MD060-1	51D060-1--R-D2-N-E2-B1-N-N-U1-NNN-024-AA-NN-00-00	SERIES 51	S51-060MV-1
83002658	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-CD-60-P-3-C7-F-03-GBA-42-42-24	SERIES 90	S90-100PV
83002659	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-2-NN-60-P-3-C7-F-03-GBA-32-32-24	SERIES 90	S90-100PV
83002660	PUMP-VAR-DISPL CCW 90PV100	90L100-FB-5-CD-60-P-7-C7-E-B1-GBA-42-42-30	SERIES 90	S90-100PV
83002661	MOTOR-VAR-DISPL 51MV110	51V110-R-F1-N-L7-B1-W-B-G0-NNN-035-AA-F0-D4-00	SERIES 51	S51-110MV
83002666	MOTOR-VAR-DISPL 51MV160	51V160-V-F1-N-HS-A2-C-H-C1-NNN-100-AA-NN-15-13	SERIES 51	S51-160MV
83002667	MOTOR-VAR-DISPL 51MV250	51V250-U-F2-A-H4-B3-R-J-N2-NNN-090-AA-NN-C2-24	SERIES 51	S51-250MV
83002669	PUMP-VAR DISPL, CW 90PV055	90-R-055-FC-5-AB-60-S-7-C6-D-B1-EFI-42-42-32	SERIES 90	S90-055PV
83002671	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-HZ-B1-B-E-G5-NNN-025-AA-E6-05-00	SERIES 51	S51-080MV
83002674	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-BB-60-S-3-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83002675	MOTOR-VAR-DISPL 51MC110	51C110-R-D4-N-HS-A2-B-H-E1-ACB-030-AA-G0-06-20	SERIES 51	S51-110MV
83002684	PUMP-VAR-DISPL CW 90PV100	90R100-KN-5-CD-80-S-3-C7-F-03-GBA-30-30-24	SERIES 90	S90-100PV
83002685	PUMP-VAR-DISPL CW 90PV250	90R250-KA-2-CD-80-S-3-C8-J-03-NNN-35-35-24	SERIES 90	S90-250PV
83002686	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-B-E2-B1-N-N-U1-ACB-027-AA-NN-00-00	SERIES 51	S51-060MV-1

83002693	MOTOR-FIX DISPL MMF044D	MMF-044-D-A-F-H-A-B-NNQ-***	M35/44	044MF
83002694	PUMP-VAR-DISPL CCW 90PV250	90L250-KP-5-CD-80-T-4-F1-K-03-NNN-38-38-24	SERIES 90	S90-250PV
83002695	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-CD-60-S-4-F1-E-03-GBA-32-32-34	SERIES 90	S90-100PV
83002696	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-NN-80-D-3-S1-L-03-GBA-38-38-34	SERIES 90	S90-075PV
83002697	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-NN-80-D-3-S1-L-03-GBA-42-14-34	SERIES 90	S90-100PV
83002698	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-CD-80-D-3-C7-L-03-GBA-38-38-34	SERIES 90	S90-100PV
83002699	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-JA-NN-C-E-K3-NNN-078-AA-F3-12-30	SERIES 51	S51-160MV
83002701	MOTOR-VAR-DISPL H1B080	H1-B-080-A-P1-D1-N-B-TA-DN-JN-N-A-05-NN-040-Z-24-NNN	H1-HP MOTORS	H1-080MB1
83002702	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-2-NN-60-P-3-C6-C-03-GBA-42-42-24	SERIES 90	S90-055PV
83002703	MOTOR-VAR-DISPL 51MV060-1	51V060-1--R-S1-N-E7-B1-N-N-U1-ABA-036-AA-E4-00-00	SERIES 51	S51-060MV-1
83002704	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-2-NN-80-S-3-S1-D-02-GBA-26-26-24	SERIES 90	S90-075PV
83002706	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-BC-80-L-3-C7-F-03-GBA-42-42-24	SERIES 90	S90-100PV
83002707	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-CD-80-L-3-C7-F-03-GBA-42-42-24	SERIES 90	S90-100PV
83002708	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-AB-80-L-3-C7-F-03-GBA-42-42-24	SERIES 90	S90-100PV
83002709	PUMP-VAR-DISPL CW 90PV042	90R042-FC-5-AB-80-S-7-C3-C-B4-EFI-45-45-32	SERIES 90	S90-042PV
83002711	MOTOR-VAR-DISPL 51MD110-1	51D110-1--A-D4-N-P7-P7-N-N-X1-AWM-024-AA-F0-00-AA	SERIES 51	S51-110MV-1
83002713	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-AB-60-S-4-S1-E-03-GBA-32-32-34	SERIES 90	S90-100PV
83002716	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-S-B-B-BA-A-A-BGG-CD-A-HH-A-NNN-***	M46	M46-046PV
83002718	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-NN-80-S-3-S1-C-03-GBA-42-42-28	SERIES 90	S90-055PV
83002722	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-G-S-B-J-BA-G-A-BDD-CD-A-GG-C-NNN-***	M46	M46-046PV
83002724	PUMP-TANDEM, VAR DISPL CCW H1T045L	H1-T-045-L-A-N-A5-C2-N-E7-F-G6-H2-33-33-33-33-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83002726	PUMP-VAR-DISPL CW 90PV130	90R130-MA-5-DG-80-D-4-C8-L-C5-GBA-35-35-24	SERIES 90	S90-130PV
83002727	PUMP-VAR-DISPL CW 90PV130	90R130-MA-5-CD-80-D-4-C8-L-C5-GBA-35-35-24	SERIES 90	S90-130PV
83002728	PUMP-VAR-DISPL CW 90PV100	90R100-MB-2-CD-80-S-4-F1-E-C4-GBA-45-45-30-F023	SERIES 90	S90-100PV
83002729	PUMP-VAR-DISPL CW 90PV075	90R075-DD-2-CD-80-S-3-S1-C-GB-GBA-45-35-24	SERIES 90	S90-075PV
83002730	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-2-NN-80-S-3-S1-C-GB-GBA-35-35-24	SERIES 90	S90-055PV
83002731	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-D-S-B-S-BA-A-A-BGG-CD-A-HH-B-NNN-***	M46	M46-046PV
83002737	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-D-S-B-B-BA-A-A-BGG-CD-A-HH-B-NNN-***	M46	M46-046PV
83002739	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-H-S-B-B-AA-A-A-BDD-BB-A-ZB-A-NNN-***	M46	M46-046PV
83002740	PUMP-VAR-DISPL CCW 90PV042	90L042-KA-2-BC-80-P-3-C3-C-03-GBA-32-32-24	SERIES 90	S90-042PV
83002741	PUMP-VAR-DISPL CCW 90PV180	90L180-PB-2-CD-80-S-C-C8-H-03-NNN-40-40-24	SERIES 90	S90-180PV
83002744	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-L7-B1-W-B-G0-ADA-080-AA-G0-D4-00	SERIES 51	S51-250MV
83002752	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-NN-60-L-3-F1-D-03-FAD-42-42-24	SERIES 90	S90-100PV
83002753	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-A-S-B-J-AA-A-A-BJJ-DA-A-HH-C-NNN-***	M46	M46-046PV
83002760	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-CD-80-S-4-F1-F-03-GBA-42-42-24	SERIES 90	S90-130PV
83002766	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-ANNB-02-D-N-F-2-F-N-T-C2-C2-N-A-A-NNN-ENN	SERIES 42	S42-028PV/032PV

83002767	PUMP-VAR DISPL, CW 90PV055	90-R-055-HS-1-NN-80-R-3-S1-C-03-GBA-23-23-24	SERIES 90	S90-055PV
83002768	PUMP-VAR DISPL, CW 90PV075	90-R-075-HS-1-NN-80-R-3-S1-D-03-GBA-23-23-24	SERIES 90	S90-075PV
83002769	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HS-1-BC-80-R-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83002770	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A5-C2-B-D8-F-G5-NN-L-25-L-25-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83002773	MOTOR-VAR-DISPL 51MV250	51V250-A-C8-N-L2-B1-V-A-G0-ACA-065-AA-G0-B2-00	SERIES 51	S51-250MV
83002774	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-5-NN-80-R-4-F1-E-03-GBA-36-36-24	SERIES 90	S90-100PV
83002775	PUMP-VAR DISPL, CW 90PV100	90-R-100-EA-1-BB-80-R-3-F1-F-03-GFH-35-35-20-P040	SERIES 90	S90-100PV
83002776	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-5-NN-80-R-4-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83002777	PUMP-VAR-DISPL CCW 90PV130 BASE MODEL	90L130-CB-5-NN-80-S-4-F1-F-00-EEB-35-35-24-P000	SERIES 90	S90-130PV
83002778	PUMP-VAR-DISPL CW 90PV130 BASE MODEL	90R130-CB-5-NN-80-S-4-F1-F-00-EEB-35-35-24-P000	SERIES 90	S90-130PV
83002779	PUMP-VAR-DISPL CCW 90PV130 BASE MODEL	90L130-CB-5-NN-80-R-4-F1-F-00-GBA-35-35-24-P000	SERIES 90	S90-130PV
83002780	PUMP-VAR-DISPL CW 90PV130 BASE MODEL	90R130-CB-5-NN-80-R-4-F1-F-00-GBA-35-35-24-P000	SERIES 90	S90-130PV
83002782	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A4-C2-N-E7-F-G1-H3-38-38-38-38-N-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83002784	MOTOR-VAR DISPL MMV046C	MMV-046-C-B-L-B-C-AD-NNN-***	M46	M46-046MV
83002785	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-8-N-0-K2-W-00-EBA-00-00-F3	SERIES 90	S90-075MF
83002788	PUMP-VAR-DISPL CW 90PV180	90R180-HF-5-AB-80-T-M-C8-J-03-FAC-32-32-24	SERIES 90	S90-180PV
83002790	PUMP-VAR-DISPL CW 90PV130	90R130-HS-5-NN-80-R-4-F1-F-00-GBA-20-20-24	SERIES 90	S90-130PV
83002794	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-A-Z-C-B-BA-B-B-A-A-BJJ-CB-A-HH-B-D-A-A-BJJ-CB-A-HH-A-NNN-***	M46	M46-046PT
83002796	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-NN-80-R-3-C7-D-00-GBA-35-35-24	SERIES 90	S90-075PV
83002798	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-B-S-B-B-BA-Z-A-BJJ-DA-A-HH-H-NNN-***	M46	M46-046PV
83002800	PUMP-VAR-DISPL CCW 90PV130	90L130-MA-5-AB-80-R-4-F1-F-C6-GBA-35-35-24	SERIES 90	S90-130PV
83002801	PUMP-VAR-DISPL CW 90PV180	90R180-MA-5-EG-80-D-M-C8-L-C5-NNN-35-35-24	SERIES 90	S90-180PV
83002802	PUMP-VAR-DISPL CW 90PV075	90R075-MA-5-CD-60-L-4-C6-D-C7-GBA-29-29-24	SERIES 90	S90-075PV
83002803	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-TA-C2-N-N-X1-NNN-037-AA-F0-00-21	SERIES 51	S51-110MV-1
83002804	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D2-N-TH-C2-N-N-X1-ABA-046-AA-F0-00-33	SERIES 51	S51-080MV-1
83002806	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D3-N-B7-B3-N-N-U3-NNN-040-AA-F0-00-00	SERIES 51	S51-080MV-1
83002812	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-HZ-B1-A-N-G0-NNN-060-AA-NN-03-00	SERIES 51	S51-160MV
83002820	MOTOR-VAR-DISPL 51MV080	51V080-A-C7-N-J1-K5-B-H-L1-NNN-041-AA-F0-07-31	SERIES 51	S51-080MV
83002822	PUMP-VAR-DISPL CW 90PV180	90R180-MA-5-CD-80-D-M-C8-L-C5-NNN-35-35-24	SERIES 90	S90-180PV
83002828	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MB-2-NN-80-R-3-S1-F-00-GBA-35-35-24	SERIES 90	S90-100PV
83002832	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-BG-80-R-3-S1-C-03-GBA-26-26-24	SERIES 90	S90-055PV
83002838	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HF-1-BC-80-L-3-C7-F-03-GBA-42-42-24	SERIES 90	S90-100PV
83002839	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HF-1-CD-80-L-3-C7-F-03-GBA-42-42-24	SERIES 90	S90-100PV
83002840	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HF-1-AB-80-L-3-C7-F-03-GBA-42-42-24	SERIES 90	S90-100PV
83002841	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-CD-60-S-4-S1-D-00-GBA-35-35-24-F026	SERIES 90	S90-055PV
83002842	PUMP-VAR-DISPL CW 90PV100	90R100-DD-5-NN-80-R-4-S1-E-GB-GBA-35-35-24	SERIES 90	S90-100PV

83002843	PUMP-VAR-DISPL CW 90PV100	90R100-DD-5-CD-80-R-4-C7-E-GB-GBA-35-35-24	SERIES 90	S90-100PV
83002844	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-BC-80-S-M-C8-J-03-NNN-35-35-24	SERIES 90	S90-180PV
83002845	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-E1-A5-A-N-G0-NNN-055-AA-F3-03-00	SERIES 51	S51-160MV
83002846	MOTOR-VAR-DISPL 51MV110	51V110-A-C8-N-L2-B1-V-A-G0-ABA-022-AA-F0-B2-00	SERIES 51	S51-110MV
83002847	PUMP- VARIABLE, DIRECT DISPLACMENT	LPV-A-A-A-D-A-E-AC-C-A-BDD-DR-A-FF-B-NNN-***	LPV	LPV
83002849	PUMP-VAR-DISPL CCW 90PV180	90L180-HS-5-BC-80-T-M-F1-J-05-FAC-35-35-24	SERIES 90	S90-180PV
83002850	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-T2-C0-L-N-G0-NNN-075-AA-F0-00-B6	SERIES 51	S51-160MV
83002851	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-BB-80-R-3-F1-H-03-GBA-35-35-24	SERIES 90	S90-130PV
83002852	MOTOR-VAR-DISPL 51MD060	51D060-R-D1-N-HZ-B1-B-H-C2-NNN-025-AA-E6-11-00	SERIES 51	S51-060MV
83002853	PUMP-VAR-DISPL CW 90PV042	90R042-CB-5-NN-80-S-3-C3-C-00-GBA-40-40-20	SERIES 90	S90-042PV
83002854	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-NN-80-L-4-C8-H-00-GBA-32-32-24	SERIES 90	S90-130PV
83002857	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-AB-60-S-4-S1-D-00-GBA-35-35-24-F029	SERIES 90	S90-055PV
83002865	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-HS-A2-C-H-E1-NNN-050-AA-F3-16-30	SERIES 51	S51-250MV
83002866	PUMP- VARIABLE, DIRECT DISPLACMENT	LPV-A-A-B-A-A-I-AA-C-A-BDD-DR-A-FF-B-NNN-***	LPV	LPV
83002867	MOTOR-VARIABLE CARTRIDGE K	K-C-45DN-E-RNF-F07-S-N-N-AF-F18-NNN-NNT	LV / KV MOTORS	L/K-MV
83002869	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-BB-60-P-3-F1-E-03-GBA-38-38-24	SERIES 90	S90-100PV
83002872	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-AB-60-S-4-S1-D-00-GBA-35-35-24-F026	SERIES 90	S90-055PV
83002873	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-CD-80-T-C-C8-J-03-NNN-29-29-24	SERIES 90	S90-180PV
83002874	MOTOR-VAR-DISPL 51MC060-1	51C060-1--H-D1-N-E2-B1-N-N-U1-ADA-016-AA-E4-00-00	SERIES 51	S51-060MV-1
83002875	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-TA-C2-L-N-G0-NNN-050-AA-NN-00-A9	SERIES 51	S51-250MV
83002876	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-NN-80-R-3-C7-E-03-GBA-29-29-26	SERIES 90	S90-100PV
83002877	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-NN-80-R-3-C7-E-03-GBA-29-29-26	SERIES 90	S90-075PV
83002881	PUMP-TANDEM, VAR DISPL MPT025C	MPT-025-C-S-L-A-G-NN-B-A-A-A-BDD-DR-A-FF-B-A-A-A-BDD-DL-A-FF-A-NNN-*	LIGHT DUTY	025PT
83002882	MOTOR-VAR-DISPL 51MV110	51V110-R-F1-N-L2-B1-V-A-G5-NNN-040-AA-G0-B2-00	SERIES 51	S51-110MV
83002886	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-CD-80-R-3-C7-D-06-GBA-42-42-24	SERIES 90	S90-075PV
83002895	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-AB-80-P-3-TG-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83002896	PUMP-VAR-DISPL CW 90PV075	90R075-MA-P-BC-80-P-3-C7-E-C5-FAB-48-48-24	SERIES 90	S90-075PV
83002900	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-5-NN-60-S-3-S1-D-C5-GBA-42-42-24	SERIES 90	S90-055PV
83002901	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-5-BG-80-S-4-S1-C-C3-GBA-26-26-24	SERIES 90	S90-055PV
83002904	MOTOR-VAR-DISPL 51MV060-1	51V060-1--R-S1-N-B3-B3-N-N-U5-AWM-044-AA-E6-00-00	SERIES 51	S51-060MV-1
83002908	PUMP-TANDEM, VAR DISPL CCW H1T045L	H1-T-045-L-A-N-A3-C2-N-E7-F-G6-H2-35-35-35-35-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83002909	PUMP-VAR DISPL, CW 90PV100	90-R-100-HS-5-CD-60-L-3-F1-E-03-GBA-38-38-24	SERIES 90	S90-100PV
83002910	PUMP-VAR DISPL, CW 90PV100	90-R-100-HS-5-CD-60-L-3-S1-E-03-GBA-38-38-24	SERIES 90	S90-100PV
83002913	PUMP-VAR-DISPL CCW 90PV130	90L130-HS-5-NN-80-R-3-F1-H-03-GBA-16-32-32	SERIES 90	S90-130PV
83002914	PUMP-VAR-DISPL CCW 90PV180	90L180-HS-5-NN-80-T-C-F1-J-03-FAC-16-32-32	SERIES 90	S90-180PV
83002915	PUMP-VAR DISPL, CW 90PV075	90-R-075-DD-1-AB-60-S-3-S1-D-GB-GBA-42-42-24	SERIES 90	S90-075PV

83002916	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-7-N-0-S1-W-00-NNN-00-00-A0	SERIES 90	S90-075MF
83002918	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-1-BC-80-R-3-F1-F-03-GBA-07-23-24	SERIES 90	S90-130PV
83002920	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-1-BC-80-P-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83002921	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-1-NN-80-P-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83002922	PUMP-VAR-DISPL CW 90PV180	90R180-DD-5-EF-80-S-C-F1-H-GB-FAC-42-42-24	SERIES 90	S90-180PV
83002923	PUMP-VAR-DISPL CW 90PV180	90R180-DD-5-NN-80-S-C-F1-H-GB-FAC-42-42-24	SERIES 90	S90-180PV
83002924	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-1-CD-80-L-3-S1-B-03-GBA-35-35-24	SERIES 90	S90-055PV
83002925	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-1-NN-80-L-3-S1-B-03-GBA-35-35-24	SERIES 90	S90-055PV
83002926	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-CD-80-L-3-C7-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83002936	PUMP-VAR-DISPL CW 90PV180	90R180-KP-5-NN-80-T-C-F1-H-00-FAC-17-17-18	SERIES 90	S90-180PV
83002938	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-L2-B1-V-A-C2-NNN-105-AA-NN-B2-00	SERIES 51	S51-250MV
83002939	PUMP-VAR-DISPL CW 90PV075	90R075-FN-5-BC-60-S-7-S1-D-B6-GME-42-42-28	SERIES 90	S90-075PV
83002944	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-1-BB-60-S-3-C6-C-03-GBA-42-42-20	SERIES 90	S90-055PV
83002947	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-EF-80-S-3-C8-K-02-NNN-29-29-24	SERIES 90	S90-250PV
83002948	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-NN-80-T-M-C8-J-03-NNN-32-32-24	SERIES 90	S90-180PV
83002959	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MB-2-NN-80-R-3-F1-F-00-GBA-35-35-24	SERIES 90	S90-100PV
83002964	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-5-BC-80-P-4-S1-D-03-GBA-17-17-20	SERIES 90	S90-075PV
83002965	PUMP-TANDEM, VAR DISPL CCW H1T045L	H1-T-045-L-A-N-A3-C1-N-E7-F-G5-H2-20-20-20-20-N-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83002967	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-5-BC-60-S-3-C6-C-04-GBA-35-35-24	SERIES 90	S90-055PV
83002968	PUMP-VAR-DISPL CCW 90PV250	90L250-HF-5-BC-80-T-4-F1-K-04-NNN-42-42-24	SERIES 90	S90-250PV
83002972	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-1-AD-80-L-3-S1-B-03-GBA-35-35-24	SERIES 90	S90-055PV
83002978	PUMP-VAR-DISPL CW 90PV130	90R130-CB-2-NN-80-S-3-F1-F-00-GBA-35-35-24	SERIES 90	S90-130PV
83002982	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-HZ-B1-A-N-G0-ACA-163-AA-G0-03-00	SERIES 51	S51-250MV
83002983	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-N-E2-B1-N-N-U1-NNN-012-AA-F0-00-00	SERIES 51	S51-060MV-1
83002985	PUMP-VAR-DISPL CW 90PV075	90R075-PA-5-CD-80-L-4-C7-D-03-GBA-26-26-24	SERIES 90	S90-075PV
83002986	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-CD-80-T-3-F1-K-03-NNN-42-42-30	SERIES 90	S90-250PV
83002991	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A3-C2-B-D8-F-G5-NN-L-35-L-35-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83002992	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-CD-80-L-3-S1-C-03-GBA-29-29-24	SERIES 90	S90-055PV
83002993	PUMP-VAR DISPL, CW 90PV075	90-R-075-MV-1-AB-60-R-3-S1-E-03-GBA-38-35-24	SERIES 90	S90-075PV
83002994	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MV-1-AB-60-R-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-075PV
83003000	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-NN-80-S-4-S1-E-03-GBA-17-17-20	SERIES 90	S90-075PV
83003001	MOTOR-VARIABLE DISPL SAE_L	L-V-25CS-D-RNF-F09-S-N-N-BF-F16-NNN-NNN	LV / KV MOTORS	L/K-MV
83003003	MOTOR-VAR-DISPL 51MV080	51V080-A-C7-N-L2-B1-V-A-G5-ACB-050-AA-E6-B2-00	SERIES 51	S51-080MV
83003018	MOTOR-VAR-DISPL 51MD160	51D160-A-D4-N-EQ-A2-J-Y-E1-NNN-060-AA-F3-15-29	SERIES 51	S51-160MV
83003019	MOTOR-VAR-DISPL H1B110	H1-B-110-A-L1-BA-N-A-PA-VN-EN-N-A-15-NN-000-N-00-NNN	H1-HP MOTORS	H1-110MB1
83003020	MOTOR-VAR-DISPL H1B110	H1-B-110-A-E1-AA-N-B-TA-CS-JS-S-A-10-NN-000-Z-00-NNN	H1-HP MOTORS	H1-110MB1

83003021	MOTOR-VAR-DISPL H1B110	H1-B-110-A-K1-K1-N-B-RB-VS-ES-S-A-15-NN-000-N-24-NNN	H1-HP MOTORS	H1-110MB1
83003024	MOTOR-VAR-DISPL 51MC080	51C080-R-D3-N-L2-B1-V-A-C0-ACB-023-AA-E6-B2-00	SERIES 51	S51-080MV
83003025	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A5-C3-B-D3-G-G3-H6-K-20-K-20-L-M-32-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83003032	MOTOR-VAR-DISPL H1B110#	H1-B-110-A-T1-D1-N-B-TB-CN-JN-N-A-15-NN-022-Z-24-NNN	H1-HP MOTORS	H1-110MB1
83003037	PUMP-VAR DISPL, CW 90PV075	90-R-075-MV-1-AB-60-R-3-S1-E-C5-GBA-38-35-24	SERIES 90	S90-075PV
83003038	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MV-1-AB-60-R-3-S1-E-C5-GBA-35-35-24	SERIES 90	S90-075PV
83003041	MOTOR-VAR-DISPL 51MD080	51D080-R-D3-N-EQ-A2-J-Y-E1-NNN-054-AA-F3-15-29	SERIES 51	S51-080MV
83003042	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-BB-80-S-M-C8-L-03-NNN-35-16-34	SERIES 90	S90-180PV
83003044	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-S1-C-N1-NN-N-N-U1-ABA-016-AA-F0-00-00	SERIES 51	S51-080MV-1
83003045	MOTOR-VAR-DISPL 51MD110-1	51D110-1--A-D4-N-P7-P7-N-N-X1-AWM-035-AA-F0-00-AA	SERIES 51	S51-110MV-1
83003046	MOTOR-VAR-DISPL 51MD110-1	51D110-1--A-D4-N-N1-NN-N-N-U1-NNN-035-AA-F0-00-00	SERIES 51	S51-110MV-1
83003052	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-1-CD-80-P-3-C6-C-03-GBA-42-42-24	SERIES 90	S90-055PV
83003053	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-1-AD-80-P-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
83003059	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-NN-80-L-3-S1-F-00-EEB-38-14-24	SERIES 90	S90-100PV
83003061	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-CD-80-S-4-TK-F-00-GBA-38-38-24	SERIES 90	S90-130PV
83003062	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-5-CD-80-S-4-C8-L-03-NNN-32-32-30	SERIES 90	S90-250PV
83003064	PUMP-VAR-DISPL CW 90PV100	90R100-CB-5-AB-80-L-4-C7-E-00-GBA-42-42-24	SERIES 90	S90-100PV
83003065	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HS-5-CD-80-R-3-S1-D-03-GBA-26-26-20	SERIES 90	S90-075PV
83003067	PUMP-VAR DISPL, CW 90PV055	90-R-055-HS-2-CD-80-S-3-S1-C-00-GBA-32-32-24	SERIES 90	S90-055PV
83003070	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-BC-80-R-4-C7-F-03-GBA-29-29-24	SERIES 90	S90-100PV
83003071	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-B-TA-C2-L-N-G0-NNN-105-AA-NN-00-B0	SERIES 51	S51-160MV
83003076	MOTOR-VAR-DISPL 51MD110-1	51D110-1--R-D3-N-E1-B1-N-N-U1-NNN-053-AA-F0-00-00	SERIES 51	S51-110MV-1
83003080	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-5-NN-80-P-3-S1-E-03-GBA-38-38-24	SERIES 90	S90-075PV
83003093	PUMP-VAR-DISPL CW 90PV130	90R130-PB-5-NN-80-L-3-C8-F-00-EFC-35-35-24	SERIES 90	S90-130PV
83003094	PUMP-VAR-DISPL CW 90PV100	90R100-HS-5-NN-80-R-3-F1-F-00-GBA-29-29-24	SERIES 90	S90-100PV
83003098	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-S1-N-TA-D2-N-N-X1-NNN-052-AA-F3-00-25	SERIES 51	S51-080MV-1
83003099	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-NN-80-S-4-F1-H-02-GBA-14-35-24	SERIES 90	S90-130PV
83003100	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-CD-80-R-3-S1-E-03-GBA-38-38-24	SERIES 90	S90-075PV
83003104	MOTOR-VAR-DISPL 51MC110-1	51C110-1--R-D4-N-E2-B1-N-N-U1-NNN-045-AA-F0-00-00	SERIES 51	S51-110MV-1
83003105	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-EG-80-S-4-C8-K-04-NNN-42-42-24	SERIES 90	S90-250PV
83003106	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-CD-80-S-4-C8-K-04-NNN-42-42-24	SERIES 90	S90-250PV
83003107	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-BC-80-S-M-C8-J-04-NNN-42-42-24	SERIES 90	S90-180PV
83003108	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-BC-80-L-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-130PV
83003109	MOTOR-VAR-DISPL 51MC060	51C060-R-D1-N-L3-B1-W-B-G0-ACA-039-AA-E4-D4-00	SERIES 51	S51-060MV
83003110	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-2-CD-80-P-1-S1-E-03-GBA-23-42-24	SERIES 90	S90-075PV
83003118	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-CD-80-P-3-F1-H-03-GBA-35-35-24	SERIES 90	S90-130PV

83003122	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-E2-A5-A-N-G0-ACA-115-AA-F3-03-00	SERIES 51	S51-160MV
83003123	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A8-C2-D-E6-F-G5-NN-L-30-L-30-B-L-24-P1-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83003124	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D3-N-T2-CA-N-N-X1-ADA-017-AA-E6-00-22	SERIES 51	S51-080MV-1
83003125	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-NN-80-P-4-C7-E-03-GBA-42-42-24	SERIES 90	S90-075PV
83003128	MOTOR-VAR-DISPL 51MD060-1	51D060-1--A-D1-N-T1-D1-N-N-X1-NNN-027-AA-NN-00-28	SERIES 51	S51-060MV-1
83003129	MOTOR- VARIABLE CARTRIDGE L	L-C-25CN-E-RNF-F04-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83003131	PUMP-VAR-DISPL CCW 90PV180	90L180-HF-5-NN-80-S-M-F1-H-03-FAC-32-14-30	SERIES 90	S90-180PV
83003133	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-NN-80-L-3-C8-H-03-EEB-38-14-30	SERIES 90	S90-130PV
83003134	PUMP-VAR DISPL, CW 90PV075	90-R-075-MB-1-NN-80-P-3-C7-D-03-GBA-40-40-24	SERIES 90	S90-075PV
83003135	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-NN-80-L-3-C7-D-03-GBA-32-32-28	SERIES 90	S90-075PV
83003137	PUMP-VAR DISPL MPV035D	MPV-035-D-B-A-A-L-S-G-AA-A-A-BFF-DL-A-FF-A-NNN-***	M35/44	035PV
83003138	PUMP-VAR DISPL MPV035D	MPV-035-D-B-A-A-L-S-G-AA-A-A-BFF-DR-A-FF-C-NNN-***	M35/44	035PV
83003139	PUMP-TANDEM, VAR DISPL MPT025C	MPT-025-C-S-R-A-E-NN-B-A-A-A-BGG-DL-A-FF-B-A-A-A-BGG-DL-A-FF-A-NNN-*	LIGHT DUTY	025PT
83003140	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-G3AN-52-T-N-D-3-G-5-B-38-38-N-1-1-NNN-NNN	SERIES 42	S42-028PV/032PV
83003143	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-CD-60-S-4-S1-D-00-GBA-35-35-24-F029	SERIES 90	S90-055PV
83003144	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A5-C3-B-D3-G-G3-H6-K-33-K-20-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83003145	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-AB-80-L-3-C7-E-03-GBA-32-32-24	SERIES 90	S90-100PV
83003146	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-AB-80-L-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83003149	PUMP-VAR-DISPL CW 90PV075	90R075-MA-5-BB-80-R-3-C6-E-C5-GBA-42-42-26	SERIES 90	S90-075PV
83003150	MOTOR-VAR-DISPL 51MD110-1	51D110-1--R-D4-N-N1-NN-N-N-U1-NNN-035-AA-F3-00-00	SERIES 51	S51-110MV-1
83003152	MOTOR-VAR-DISPL 51MV060	51V060-R-C6-N-HZ-B1-A-N-C2-ACA-042-AA-F3-03-00	SERIES 51	S51-060MV
83003154	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-K-S-B-B-BA-G-A-BRR-CE-A-GG-4-NNN-***	M46	M46-046PV
83003160	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-CD-80-S-3-S1-C-02-GBA-35-35-24	SERIES 90	S90-055PV
83003161	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-NN-80-S-3-S1-C-02-GBA-35-35-24	SERIES 90	S90-055PV
83003167	MOTOR-VAR-DISPL 51MV160	51V160-A-C8-N-T2-C2-L-N-G0-ADA-032-AA-E6-00-C6	SERIES 51	S51-160MV
83003169	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-TA-C2-L-N-G0-NNN-043-AA-NN-00-A9	SERIES 51	S51-160MV
83003172	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-HS-A2-C-E-E1-NNN-041-AA-F0-16-29	SERIES 51	S51-080MV
83003174	PUMP-VAR-DISPL CW 90PV075	90R075-MA-5-NN-60-S-4-S1-D-C5-GBA-32-32-24	SERIES 90	S90-075PV
83003175	PUMP-VAR-DISPL 42PV028 CW	42-R-2A-D-G2A1-50-U-2-B-2-E-1-A-38-38-B-1-1-AAA-NNN	SERIES 42	S42-028PV/032PV
83003177	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A5-C2-B-D3-G-G2-H2-L-42-L-42-A-M-30-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83003178	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-5-BC-80-R-4-C7-F-03-GBA-29-29-24-F068	SERIES 90	S90-100PV
83003179	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-8-N-0-S1-W-00-EFS-00-00-E6	SERIES 90	S90-055MF
83003180	PUMP-VAR-DISPL CW 90PV250	90R250-KT-5-CD-80-T-3-F1-J-03-NNN-42-42-24	SERIES 90	S90-250PV
83003181	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-N-TA-D3-N-N-X1-AWS-N16-AA-E6-00-28	SERIES 51	S51-060MV-1
83003182	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-NN-80-R-3-S1-E-02-GBA-38-38-24	SERIES 90	S90-100PV
83003183	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-BC-80-R-3-F1-E-02-GBA-38-38-24	SERIES 90	S90-100PV

83003189	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-5-BB-60-R-3-C6-D-C5-GBA-40-40-24	SERIES 90	S90-055PV
83003190	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MA-1-AB-60-P-4-F1-E-01-GBA-23-23-24	SERIES 90	S90-100PV
83003191	PUMP-VAR DISPL, CW 90PV055	90-R-055-HS-2-NN-60-S-3-S1-C-00-GBA-32-32-24	SERIES 90	S90-055PV
83003192	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-L1-B1-W-B-C0-NNN-032-AA-E6-D4-00	SERIES 51	S51-160MV
83003193	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-A-Z-C-B-AA-B-A-A-BHH-AB-U-FF-B-C-A-A-BHH-AB-U-FF-C-NNN-*	M46	M46-046PT
83003196	MOTOR-VAR-DISPL 51MV080	51V080-R-C7-N-HS-A1-A-E-E2-NNN-038-AA-F0-03-28	SERIES 51	S51-080MV
83003197	PUMP-VAR-DISPL CW 90PV250	90R250-MA-5-AB-80-S-3-C8-K-C5-NNN-42-42-24	SERIES 90	S90-250PV
83003199	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D3-N-T2-CA-N-N-X1-NNN-017-AA-E6-00-22	SERIES 51	S51-080MV-1
83003200	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HS-5-NN-80-R-4-S1-D-03-GBA-38-38-24	SERIES 90	S90-075PV
83003201	MOTOR-VAR-DISPL 51MD110	51D110-R-D4-N-D8-M1-R-J-M4-NNN-049-AA-F3-C2-24	SERIES 51	S51-110MV
83003202	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-N-TA-D3-N-N-X1-AWS-N14-AA-E6-00-28-P020	SERIES 51	S51-060MV-1
83003204	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A2-C2-N-F4-H-G1-H6-L-23-L-23-C-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83003207	MOTOR-VAR-DISPL 51MV080-1	51V080-1--A-S1-N-T2-D2-N-N-X1-AWM-054-AA-E6-00-32	SERIES 51	S51-080MV-1
83003210	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-NN-80-T-C-C8-J-03-NNN-26-26-24	SERIES 90	S90-180PV
83003213	MOTOR-VAR-DISPL 51MV060-1	51V060-1--R-C6-N-B3-B3-N-N-U5-AWM-044-AA-E6-00-00	SERIES 51	S51-060MV-1
83003216	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-TA-C2-L-N-G0-NNN-085-AA-G0-00-B8	SERIES 51	S51-160MV
83003220	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-E2-B1-N-N-U1-NNN-055-AA-F3-00-00	SERIES 51	S51-110MV-1
83003221	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-1-AB-60-P-4-S1-D-GB-GBA-35-35-24	SERIES 90	S90-055PV
83003222	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-C8-N-TA-C2-N-N-X1-NNN-045-AA-NN-00-20	SERIES 51	S51-110MV-1
83003223	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A5-C2-B-D8-F-G5-H3-L-25-L-25-B-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83003225	MOTOR-VAR-DISPL 51MV110-1	51V110-1--A-C8-N-TA-C2-N-N-X1-NNN-080-AA-G0-00-25	SERIES 51	S51-110MV-1
83003227	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D2-N-N1-NN-N-N-U1-ABA-040-AA-F0-00-00	SERIES 51	S51-080MV-1
83003232	MOTOR-FIX DISPL MMF044D	MMF-044-D-A-S-G-A-B-NNR-***	M35/44	044MF
83003233	PUMP-VAR DISPL, CW 90PV075	90-R-075-DD-1-AB-60-P-4-S1-D-GB-GBA-38-38-24	SERIES 90	S90-075PV
83003236	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-CD-80-P-3-S1-E-03-GBA-40-40-24	SERIES 90	S90-075PV
83003237	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-CD-80-P-3-S1-E-03-GBA-29-29-24	SERIES 90	S90-075PV
83003238	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-BC-60-R-3-S1-D-00-GBA-38-38-24	SERIES 90	S90-075PV
83003239	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-AB-80-L-3-F1-H-03-GBA-23-23-24	SERIES 90	S90-130PV
83003240	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-NN-60-S-3-S1-D-00-GBA-38-38-24	SERIES 90	S90-075PV
83003247	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-1-CD-80-L-4-S1-D-GB-GBA-20-20-24	SERIES 90	S90-055PV
83003248	PUMP-VAR-DISPL CW 90PV130	90R130-M8-5-CD-80-P-3-C8-H-C5-GBA-38-38-24	SERIES 90	S90-130PV
83003249	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D3-N-E2-B1-N-N-U1-ACB-045-AA-F0-00-00	SERIES 51	S51-080MV-1
83003250	MOTOR-VAR-DISPL 51MD110-1	51D110-1--R-D4-N-E2-B1-N-N-U1-NNN-060-AA-F0-00-00	SERIES 51	S51-110MV-1
83003256	PUMP-VAR-DISPL CCW 90PV075	90L075-FH-5-BC-60-S-7-C7-E-B2-EFI-42-42-30	SERIES 90	S90-075PV
83003257	PUMP-VAR DISPL, CW 90PV100	90-R-100-DD-1-CD-80-L-4-K3-E-GB-GBA-20-20-24	SERIES 90	S90-100PV
83003264	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-AB-80-L-3-S1-D-00-EBC-38-14-24	SERIES 90	S90-075PV

83003265	PUMP-VAR DISPL, CW 90PV100	90-R-100-HS-1-BC-60-L-3-C7-E-05-GBA-32-32-24	SERIES 90	S90-100PV
83003266	PUMP-VAR DISPL, CW 90PV100	90-R-100-HS-1-BC-60-L-3-C6-E-05-GBA-32-32-24	SERIES 90	S90-100PV
83003269	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HS-5-AB-60-P-4-S1-B-03-GBA-42-42-24	SERIES 90	S90-055PV
83003273	MOTOR-VAR-DISPL 51MD110-1	51D110-1--R-D3-N-T2-D2-N-N-X1-NNN-068-AA-F3-00-28	SERIES 51	S51-110MV-1
83003274	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-N-E1-B1-N-N-U1-NNN-025-AA-F0-00-00	SERIES 51	S51-060MV-1
83003280	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-HZ-B1-A-N-G0-NNN-107-AA-H0-03-00	SERIES 51	S51-160MV
83003281	PUMP-VAR-DISPL CW 90PV180	90R180-CB-2-NN-80-S-C-F1-H-00-FAC-26-26-24	SERIES 90	S90-180PV
83003282	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-AB-60-S-3-F1-F-00-GBA-35-35-20	SERIES 90	S90-100PV
83003283	PUMP-VAR-DISPL CCW 90PV130	90L130-HS-5-AB-80-D-3-C8-L-03-GBA-35-35-24	SERIES 90	S90-130PV
83003284	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-5-AD-80-P-3-S1-C-03-GBA-35-14-24	SERIES 90	S90-055PV
83003286	PUMP-VAR DISPL, CW 90PV100	90-R-100-HF-5-BC-60-P-4-C7-E-03-GBA-38-38-24	SERIES 90	S90-100PV
83003287	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-G-S-A-S-BC-V-A-BRR-DA-A-HH-C-NNR-***	M46	M46-046PV
83003288	PUMP-VAR DISPL, CCW 90PV100	90-L-100-DC-1-BB-80-P-3-F1-E-G8-GBA-42-14-24	SERIES 90	S90-100PV
83003292	MOTOR-VAR DISPL MMV046C	MMV-046-C-A-A-E-B-A4-NNN-***	M46	M46-046MV
83003295	PUMP-VAR-DISPL CW 90PV075	90R075-KN-5-CD-80-S-3-C7-D-03-GBA-23-23-24	SERIES 90	S90-075PV
83003296	PUMP-VAR-DISPL CW 90PV075	90R075-KN-5-NN-80-S-3-S1-D-03-GBA-23-23-24	SERIES 90	S90-075PV
83003297	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-BB-80-L-3-F1-H-03-GBA-35-35-24	SERIES 90	S90-130PV
83003300	MOTOR-FIX DISPL MMF044D	MMF-044-D-A-6-G-A-B-NNR-***	M35/44	044MF
83003301	MOTOR-VAR DISPL MMV046C	MMV-046-C-A-A-D-B-A4-NNN-***	M46	M46-046MV
83003315	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-1-NN-80-P-3-S1-C-00-GBA-42-42-24	SERIES 90	S90-055PV
83003319	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A5-C2-B-D8-F-G5-H5-L-25-L-25-B-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83003320	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-K-T-B-J-BA-A-A-BFF-CE-A-JJ-B-NNN-***	M46	M46-046PV
83003323	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-NN-80-S-3-C8-J-00-NNN-35-35-30	SERIES 90	S90-180PV
83003324	PUMP-VAR-DISPL CW 90PV075	90R075-HS-5-BC-60-S-3-C6-D-03-GBA-30-30-24	SERIES 90	S90-075PV
83003325	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HF-1-BC-80-R-3-F1-F-03-GBA-38-38-24	SERIES 90	S90-100PV
83003331	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-HZ-B1-C-N-C2-NNN-050-AA-H0-20-00	SERIES 51	S51-250MV
83003333	PUMP-VAR-DISPL CCW H1PV147	H1-P-147-L-C-A3-C2-B-D5-G-G2-H4-K-40-K-40-A-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83003334	PUMP-VAR-DISPL CCW H1PV147	H1-P-147-L-C-A3-C2-B-D3-G-G3-H2-K-40-K-40-A-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83003338	PUMP-TANDEM, VAR DISPL MPT044D	MPT-044-D-A-W-S-J-AA-B-A-A-A-BHH-DR-A-FF-B-C-A-A-BHH-DL-A-FF-D-NNN-*	M35/44	044PT
83003340	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-H-S-B-U-BA-A-A-BFF-CE-A-HH-3-NNN-***	M46	M46-046PV
83003343	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A3-C2-N-D3-H-G1-H3-L-35-L-35-C-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83003351	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-NN-80-L-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83003355	PUMP-VAR DISPL, CCW 90PV100	90-L-100-ME-1-AB-80-L-4-F1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
83003356	PUMP-VAR-DISPL CW 90PV130	90R130-DD-5-NN-80-L-4-C8-F-GB-GBA-35-35-24	SERIES 90	S90-130PV
83003358	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-NN-80-S-3-S1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
83003361	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-N-E1-B1-N-N-U1-AWT-043-AA-E4-00-00	SERIES 51	S51-060MV-1

83003363	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HS-1-AB-60-P-4-S1-C-03-GBA-32-14-30	SERIES 90	S90-055PV
83003364	PUMP-VAR-DISPL CCW 90PV130	90L130-MA-5-BC-80-S-4-F1-F-C5-GBA-17-17-20	SERIES 90	S90-130PV
83003365	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-B1-C2-N-D6-G-G3-NN-L-40-L-40-L-L-28-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83003366	MOTOR-VARIABLE DISPL SAE_L	L-V-30DN-A-YNF-F09-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83003370	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-BC-80-S-3-C8-H-03-EFC-35-35-24	SERIES 90	S90-130PV
83003371	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-T2-C2-L-N-G0-NNN-165-AA-G3-00-B0	SERIES 51	S51-250MV
83003375	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-AB-60-R-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83003376	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-N-E2-L2-A-N-E4-NNN-050-AA-F3-03-35	SERIES 51	S51-250MV
83003378	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-S1-N-E2-B1-N-N-U1-ABA-040-AA-G0-00-00	SERIES 51	S51-080MV-1
83003382	MOTOR-VAR-DISPL 51MD160	51D160-A-D4-N-T2-C2-L-N-G0-NNN-080-AA-G3-00-B4	SERIES 51	S51-160MV
83003383	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-B1-C2-N-D6-G-G2-H4-L-40-L-40-L-L-28-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83003384	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-CD-80-P-4-F1-H-03-GBA-32-32-24	SERIES 90	S90-130PV
83003386	PUMP-VAR DISPL, CCW 90PV055	90-L-055-PB-2-NN-80-S-3-S1-B-03-GBA-40-40-32	SERIES 90	S90-055PV
83003387	PUMP-VAR DISPL, CW 90PV055	90-R-055-PB-2-BK-80-S-3-S1-B-03-GBA-40-40-24	SERIES 90	S90-055PV
83003388	PUMP-VAR-DISPL CCW 90PV130	90L130-HF-5-BC-80-S-3-C8-L-01-GBA-32-32-24	SERIES 90	S90-130PV
83003389	PUMP-VAR-DISPL CW 90PV180	90R180-HF-5-BC-80-S-M-C8-J-03-FAC-23-23-24	SERIES 90	S90-180PV
83003390	PUMP-VAR-DISPL CCW 90PV130	90L130-MA-5-BC-80-L-3-F1-H-C7-GBA-45-45-24	SERIES 90	S90-130PV
83003396	MOTOR-VAR-DISPL 51MD110-1	51D110-1--A-D3-N-E1-B1-N-N-U1-NNN-055-AA-F0-00-00	SERIES 51	S51-110MV-1
83003397	MOTOR- VARIABLE CARTRIDGE L	L-C-35ES-E-RNF-F11-S-N-N-CF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83003398	PUMP-VAR DISPL, CW 90PV075	90-R-075-MV-1-BB-80-R-3-S1-D-28-GBA-20-38-24	SERIES 90	S90-075PV
83003402	PUMP-VAR-DISPL CCW 90PV130	90L130-MA-5-DE-80-L-3-F1-H-C7-GBA-45-45-24	SERIES 90	S90-130PV
83003416	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-ANNB-03-A-N-A-2-C-N-A-B8-B8-B-A-A-NNN-ENN	SERIES 42	S42-028PV/032PV
83003417	PUMP-VAR-DISPL 42PV041 CW	42-R-41-E-ANNB-03-A-N-A-2-C-N-B-B8-B8-B-A-A-NNN-ENN	SERIES 42	S42-041PV/051PV
83003423	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HS-5-AB-60-P-4-S1-B-03-GBA-42-42-24	SERIES 90	S90-055PV
83003424	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-HS-A2-B-H-G6-NNN-080-AA-G3-10-22	SERIES 51	S51-250MV
83003429	PUMP-VAR-DISPL CCW 90PV130	90L130-FH-5-BC-80-P-7-C8-H-BA-GBA-35-35-26	SERIES 90	S90-130PV
83003430	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A2-C2-N-D6-F-G5-H3-L-23-L-23-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83003433	PUMP-VAR DISPL, CCW 90PV055	90-L-055-DC-5-BB-60-S-4-C6-C-GB-GBA-35-20-24	SERIES 90	S90-055PV
83003434	PUMP-VAR DISPL, CCW 90PV100	90-L-100-LS-5-CD-8P-L-3-C7-F-04-GB4-44-40-24	SERIES 90	S90-100PV
83003436	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-NN-60-P-4-S1-D-03-GBA-38-38-24	SERIES 90	S90-075PV
83003442	PUMP-VAR-DISPL CW 90PV130	90R130-PB-5-CD-80-R-3-C8-H-00-GBA-29-14-24	SERIES 90	S90-130PV
83003443	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A5-C2-N-D8-F-G1-H5-L-35-L-35-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83003444	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-BC-80-P-4-C7-D-03-GBA-42-42-24	SERIES 90	S90-075PV
83003445	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-N-A5-C1-B-E7-F-G5-H3-35-35-35-35-N-P-26-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83003446	MOTOR-VAR-DISPL 51MC110-1	51C110-1--R-D4-N-N1-NN-N-N-U1-ABA-050-AA-NN-00-00	SERIES 51	S51-110MV-1
83003449	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-G3AN-52-P-2-C-2-H-1-B-38-38-N-1-1-NNN-NNN	SERIES 42	S42-028PV/032PV

83003450	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-G3AN-52-P-2-C-2-H-1-B-38-38-N-1-1-NNN-NNN	SERIES 42	S42-028PV/032PV
83003451	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-G3AN-52-P-D-C-3-F-1-B-30-30-N-1-1-NNN-NNN	SERIES 42	S42-041PV/051PV
83003452	PUMP-VAR-DISPL CW 90PV100	90R100-PB-5-CD-80-R-3-S1-E-00-GBA-29-14-24	SERIES 90	S90-100PV
83003453	MOTOR-VAR-DISPL 51MD080-1	51D080-1--R-D3-N-E1-B1-N-N-U1-ACB-035-AA-NN-00-00	SERIES 51	S51-080MV-1
83003454	PUMP-VAR-DISPL CW 90PV100	90R100-MA-5-AB-60-L-4-C7-E-C5-GBA-32-32-24	SERIES 90	S90-100PV
83003457	MOTOR-VAR-DISPL 51MD080-1	51D080-1--R-D3-N-P7-P7-N-N-X1-NNN-022-AA-E6-00-AA	SERIES 51	S51-080MV-1
83003458	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-NN-80-T-C-C8-J-03-NNN-26-26-24	SERIES 90	S90-180PV
83003460	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-1-NN-81-P-3-S1-C-03-GBA-35-35-20	SERIES 90	S90-055PV
83003463	PUMP-VAR-DISPL CCW 90PV130	90L130-MA-5-NN-80-L-3-F1-F-C5-GBA-35-35-20	SERIES 90	S90-130PV
83003464	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-S1-D-B1-B3-N-N-U3-NNN-031-AA-NN-00-00	SERIES 51	S51-080MV-1
83003465	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-2-BC-80-P-1-S1-E-03-GBA-23-42-24	SERIES 90	S90-075PV
83003466	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-AB-60-P-4-F1-E-03-GBA-29-29-24	SERIES 90	S90-100PV
83003468	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-N-N2-NN-N-N-A0-NNN-032-AA-NN-00-00	SERIES 51	S51-160MV
83003469	MOTOR-VAR-DISPL 51MV250	51V250-V-F2-N-N2-NN-N-N-A0-NNN-100-AA-NN-00-00	SERIES 51	S51-250MV
83003470	PUMP-VAR-DISPL CCW 90PV130	90L130-MB-5-AB-80-S-3-F1-F-C5-GBA-38-38-24	SERIES 90	S90-130PV
83003473	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A4-C2-N-D3-G-G3-H2-L-40-L-40-A-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83003474	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-NN-80-P-4-C7-E-03-GBA-32-32-24	SERIES 90	S90-075PV
83003476	MOTOR-VAR-DISPL 51MC080	51C080-R-D3-N-HZ-B1-A-H-C2-ANA-045-AA-F0-05-00	SERIES 51	S51-080MV
83003477	MOTOR-VAR-DISPL 51MD110-1	51D110-1--R-D3-N-TA-C2-N-N-X1-NNN-031-AA-E6-00-15	SERIES 51	S51-110MV-1
83003478	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A3-C2-N-D6-F-G5-H3-L-35-L-35-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83003479	PUMP-VAR DISPL MPV046C	MPV-046-C-B-A-B-S-B-S-BA-A-A-BGG-GB-B-AA-A-NNN-***	M46	M46-046PV
83003480	PUMP-VAR DISPL MPV046C	MPV-046-C-B-A-B-S-B-S-BA-A-A-BJJ-GB-B-AA-A-NNN-***	M46	M46-046PV
83003481	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-HZ-B1-A-N-G0-ACA-032-AA-NN-03-00	SERIES 51	S51-160MV
83003483	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HS-1-NN-80-R-3-S1-C-03-GBA-38-38-24	SERIES 90	S90-055PV
83003488	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-CD-80-D-3-F1-L-03-GBA-35-35-24	SERIES 90	S90-130PV
83003489	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-L2-B1-V-A-J1-ANA-028-AA-F0-B2-00	SERIES 51	S51-080MV
83003492	PUMP-VAR-DISPL 42PV041 CW	42-R-41-C-G3AN-52-P-D-C-3-F-1-T-30-30-N-1-1-NNN-NNN	SERIES 42	S42-041PV/051PV
83003493	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-ANNB-03-A-N-A-2-C-N-N-34-34-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83003502	PUMP-VAR-DISPL CW 90PV250	90R250-KA-2-NN-80-S-4-C8-K-03-NNN-35-35-28	SERIES 90	S90-250PV
83003503	MOTOR-VAR-DISPL 51MV160	51V160-A-C8-N-DA-M4-R-J-N9-ADA-105-AA-H0-C2-20	SERIES 51	S51-160MV
83003505	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-CD-80-S-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83003507	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-NN-60-L-3-K3-F-03-GBA-35-35-24	SERIES 90	S90-100PV
83003508	PUMP-VAR DISPL MPV025C	MPV-025-C-B-A-Y-R-A-E-NN-A-A-BMM-DL-A-FF-D-NNN-***	LIGHT DUTY	025PV
83003509	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A3-C1-N-D6-F-G5-H5-L-35-L-35-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83003510	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A3-C1-N-D6-F-G5-H2-L-35-L-35-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83003511	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-CD-80-S-3-C6-D-03-GBA-35-35-24	SERIES 90	S90-075PV

83003515	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-A-V-C-B-BA-B-B-G-A-BFF-CD-A-GG-B-D-G-A-BFF-CD-A-GG-A-NNN-	M46	M46-046PT
83003516	MOTOR-VAR-DISPL H1B110	H1-B-110-A-M1-CA-N-A-RA-VS-DS-S-A-10-NN-000-N-00-NNN	H1-HP MOTORS	H1-110MB1
83003522	PUMP-VAR DISPL, CW 90PV055	90-R-055-KT-1-NN-80-P-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-055PV
83003523	PUMP-VAR DISPL, CW 90PV055	90-R-055-KT-1-BG-80-P-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-055PV
83003524	PUMP-VAR DISPL MPV046C	MPV-046-C-B-A-B-S-B-B-AA-G-A-BCC-AB-D-AB-A-NNN-***	M46	M46-046PV
83003531	MOTOR-VAR-DISPL 51MD160	51D160-R-D5-N-HS-A2-B-H-E1-NNN-035-AA-NN-06-20	SERIES 51	S51-160MV
83003536	PUMP-VAR-DISPL CW 90PV130	90R130-MA-5-NN-80-L-3-C8-H-C4-GBA-42-42-24	SERIES 90	S90-130PV
83003539	MOTOR-VAR-DISPL 51MV110	51V110-A-F1-N-L2-B1-V-A-C2-ADA-055-AA-NN-B2-00	SERIES 51	S51-110MV
83003540	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-F2-A2-A-N-E1-NNN-063-AA-G0-03-28	SERIES 51	S51-160MV
83003542	MOTOR-VAR-DISPL 51MD060	51D060-R-D2-B-HS-A2-B-H-C1-NNN-030-AA-NN-06-15	SERIES 51	S51-060MV
83003543	MOTOR-VAR-DISPL 51MD110	51D110-R-D4-N-HS-A2-B-H-C1-NNN-036-AA-NN-06-15	SERIES 51	S51-110MV
83003544	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A3-C2-B-D3-H-G1-H5-L-35-L-35-F-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83003545	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A3-C2-B-D3-H-G1-H2-L-35-L-35-F-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83003548	MOTOR-VAR-DISPL 51MV160	51V160-A-C8-N-L7-B1-W-B-G0-ADA-032-AA-F3-D4-00	SERIES 51	S51-160MV
83003549	PUMP-VAR-DISPL CCW H1PV115	H1-P-115-L-B-A4-C2-N-D3-G-G2-H4-L-42-L-42-L-M-20-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83003550	PUMP-VAR-DISPL CCW H1PV115	H1-P-115-L-B-A4-C2-N-D3-G-G3-H6-L-42-L-42-L-M-20-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83003552	MOTOR-VAR-DISPL H1B110	H1-B-110-A-E1-AA-N-A-TB-DN-KN-N-A-15-NN-035-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83003554	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-CD-80-L-3-F1-F-03-GBA-29-29-20	SERIES 90	S90-100PV
83003559	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A2-C1-N-D1-F-G5-H3-25-25-25-25-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83003562	PUMP-VAR-DISPL CCW 90PV130	90L130-HS-5-BB-80-R-4-C8-L-03-GBA-32-32-34	SERIES 90	S90-130PV
83003563	PUMP-VAR-DISPL CCW 90PV180	90L180-HS-5-CD-80-S-M-C8-L-03-NNN-32-16-34	SERIES 90	S90-180PV
83003566	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-1-AD-80-P-4-S1-C-09-GBA-35-35-24	SERIES 90	S90-055PV
83003567	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-N-HS-A2-C-H-E1-NNN-100-AA-G0-15-37	SERIES 51	S51-250MV
83003568	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-AB-80-S-4-C7-F-01-GBA-30-30-24	SERIES 90	S90-100PV
83003571	PUMP-VAR DISPL MPV046C	MPV-046-C-B-A-W-S-B-J-AA-A-A-BJJ-AB-U-FF-A-NNN-***	M46	M46-046PV
83003572	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HF-1-NN-80-P-3-S1-C-03-GBA-20-20-24	SERIES 90	S90-055PV
83003573	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-1-NN-80-P-4-S1-C-03-GBA-17-17-24	SERIES 90	S90-055PV
83003574	MOTOR-VAR-DISPL 51MD110-1	51D110-1--R-D3-N-E1-B1-N-N-U2-NNN-035-AA-F3-00-00	SERIES 51	S51-110MV-1
83003575	PUMP-VAR-DISPL CW 90PV130	90R130-MA-5-BC-80-S-4-F1-F-C5-GBA-17-17-20	SERIES 90	S90-130PV
83003576	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A2-C2-N-D8-H-G1-H5-L-40-L-40-N-E-28-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83003578	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-AB-80-S-4-C8-H-04-GBA-35-35-24	SERIES 90	S90-130PV
83003579	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A4-C2-N-D8-G-G2-H3-L-42-L-42-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83003581	PUMP-VAR DISPL, CCW 90PV055	90-L-055-MA-2-AF-80-D-3-C6-L-03-GBA-35-35-22	SERIES 90	S90-055PV
83003584	MOTOR-VAR-DISPL 51MD060-1	51D060-1--A-D1-N-P7-P7-N-N-X1-NNN-018-AA-F3-00-AA	SERIES 51	S51-060MV-1
83003593	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-NN-80-L-3-F1-H-03-GBA-26-26-24	SERIES 90	S90-130PV
83003594	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-CD-80-R-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV

83003604	PUMP-VAR DISPL, CCW 90PV100	90-L-100-DD-1-NN-80-R-4-F1-F-GB-GBA-14-14-24	SERIES 90	S90-100PV
83003605	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-CD-60-S-3-C6-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83003612	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-NN-80-S-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83003613	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-NN-60-S-4-C6-D-03-GBA-23-23-18	SERIES 90	S90-075PV
83003614	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-B8-C2-C-D3-G-G2-H2-L-38-L-38-L-M-30-P1-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83003619	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-NN-80-T-C-F1-J-03-FAC-35-35-22	SERIES 90	S90-180PV
83003620	MOTOR-VAR DISPL MMV046C	MMV-046-C-A-A-L-A-AE-VNA-***	M46	M46-046MV
83003621	MOTOR-VAR-DISPL 51MD060-1	51D060-1--H-D1-N-TA-C2-N-N-X1-NNN-012-AA-NN-00-21	SERIES 51	S51-060MV-1
83003622	MOTOR-VAR-DISPL 51MC080-1	51C080-1--A-D3-N-E2-B1-N-N-U1-NNN-028-AA-NN-00-00	SERIES 51	S51-080MV-1
83003623	MOTOR-VAR-DISPL 51MC080-1	51C080-1--A-D3-N-E2-B1-N-N-U1-ACB-028-AA-NN-00-00	SERIES 51	S51-080MV-1
83003624	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D3-N-E1-B1-N-N-U1-ACB-028-AA-NN-00-00	SERIES 51	S51-080MV-1
83003625	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A3-C2-N-D8-H-G9-H5-L-33-L-33-C-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83003626	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-N-A3-C2-N-E7-F-G5-H2-30-30-30-30-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83003631	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A3-C2-B-D3-G-G3-NN-L-28-L-28-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83003636	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-AB-80-L-4-S1-E-00-EBC-29-29-24	SERIES 90	S90-100PV
83003638	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-AB-80-P-3-F1-E-03-GBA-26-26-24	SERIES 90	S90-100PV
83003642	PUMP-VAR-DISPL CCW 90PV075	90L075-DD-5-BC-80-S-4-C7-E-GB-GBA-32-32-24	SERIES 90	S90-075PV
83003643	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-AB-80-P-3-C7-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83003650	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-1-NN-80-S-4-S1-D-03-GBA-26-26-24-F058	SERIES 90	S90-075PV
83003651	PUMP-VAR DISPL, CW 90PV100	90-R-100-HS-1-AB-80-P-4-F1-F-03-GBA-26-26-24	SERIES 90	S90-100PV
83003652	PUMP-VAR DISPL, CW 90PV055	90-R-055-HS-1-AD-80-P-3-C6-C-03-GBA-26-26-24	SERIES 90	S90-055PV
83003654	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-G-S-B-B-AA-A-A-BMM-BA-A-HH-C-NNN-***	M46	M46-046PV
83003655	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A3-C2-N-E5-F-G1-H5-L-28-L-28-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83003656	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A3-C2-N-E5-F-G5-NN-L-28-L-28-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83003660	PUMP-VAR DISPL MPV035D	MPV-035-D-B-A-A-R-S-C-AA-A-A-BJJ-DR-A-FF-A-NNN-***	M35/44	035PV
83003662	MOTOR-VAR-DISPL 51MV110	51V110-R-F1-N-L2-B1-V-A-C0-NNN-022-AA-F0-B2-00	SERIES 51	S51-110MV
83003674	PUMP-VAR-DISPL CW 90PV180	90R180-HF-5-AB-80-T-M-C8-J-03-FAC-35-35-24	SERIES 90	S90-180PV
83003682	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-A-V-C-J-AA-B-B-A-A-BJJ-CD-A-GG-B-D-A-A-BGG-CD-A-GG-C-NNN-*	M46	M46-046PT
83003683	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A4-C2-N-E7-F-G1-T1-38-38-38-38-M-P-32-PN-NNN-S01	H1-MP PUMPS	H1-045PT/053PT
83003684	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-CD-60-S-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83003686	MOTOR-VAR-DISPL 51MD080-1	51D080-1--A-D3-N-P7-P7-N-N-X1-AWM-016-AA-E6-00-AA	SERIES 51	S51-080MV-1
83003690	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-NN-80-S-4-C8-J-03-NNN-26-26-24	SERIES 90	S90-250PV
83003694	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-A-V-C-B-AA-B-A-A-A-BJJ-AB-U-CF-B-C-A-A-BJJ-AB-D-CF-B-NNN-***	M46	M46-046PT
83003701	PUMP-VAR DISPL MPV046C	MPV-046-C-B-A-G-T-B-B-BA-G-A-BGG-AB-D-FF-C-NNN-***	M46	M46-046PV
83003702	PUMP-VAR-DISPL CCW 90PV180	90L180-KP-5-CD-80-T-M-C8-J-00-EBA-42-42-24	SERIES 90	S90-180PV
83003710	PUMP-VAR-DISPL CCW 90PV100	90L100-FH-5-BC-60-S-7-C7-F-B2-EFI-42-42-30	SERIES 90	S90-100PV

83003723	MOTOR-VARIABLE CARTRIDGE K	K-C-45DN-E-RNF-F10-S-N-N-AF-F18-NNN-PNN	LV / KV MOTORS	L/K-MV
83003727	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-D-HZ-B1-C-H-G5-NNN-110-AA-H0-14-00	SERIES 51	S51-250MV
83003731	PUMP-VAR DISPL, CCW 90PV055	90-L-055-MA-1-NN-60-S-4-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83003732	PUMP-VAR DISPL, CW 90PV055	90-R-055-MB-1-NN-80-P-3-C6-C-03-GBA-42-42-24	SERIES 90	S90-055PV
83003734	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-A-V-C-B-BA-B-B-J-A-BFF-CB-A-GG-B-D-A-A-BFF-DA-A-GG-C-NNN-*	M46	M46-046PT
83003735	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A8-C2-C-D6-J-G5-H2-L-33-L-33-B-L-26-P2-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83003736	PUMP-VAR-DISPL CCW 90PV130	90L130-KT-5-BC-80-R-3-F1-H-03-GBA-38-38-24	SERIES 90	S90-130PV
83003738	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-S1-N-N1-NN-N-N-U1-NNN-040-AA-E6-00-00	SERIES 51	S51-080MV-1
83003741	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HS-1-AD-80-P-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-055PV
83003742	PUMP-VAR-DISPL CCW 90PV100	90L100-FD-5-NN-80-P-7-C7-E-BB-GBA-26-26-30	SERIES 90	S90-100PV
83003743	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-E1A6-02-C-2-A-2-F-N-A-34-34-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83003748	MOTOR-VAR-DISPL 51MD060-1	51D060-1--R-D2-N-TA-C2-N-N-X1-NNN-025-AA-F0-00-25	SERIES 51	S51-060MV-1
83003755	PUMP-VAR DISPL, CW 90PV055	90-R-055-HF-1-BB-60-P-4-S1-C-00-GBA-35-35-24	SERIES 90	S90-055PV
83003756	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HF-1-CD-60-P-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
83003758	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-BB-80-S-4-S1-D-00-GBA-23-23-24	SERIES 90	S90-075PV
83003760	PUMP-TANDEM, VAR DISPL MPT025C	MPT-025-C-S-R-A-G-NN-B-A-A-A-BJJ-DR-A-FF-B-A-A-A-BJJ-DL-A-FF-D-NNN-***	LIGHT DUTY	025PT
83003763	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HS-1-NN-80-P-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-055PV
83003765	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-1-NN-80-R-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83003768	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-TH-C2-L-N-G0-ACA-050-AA-G3-00-A9	SERIES 51	S51-250MV
83003769	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-2-CD-80-P-1-S1-E-03-GBA-23-42-24-F063	SERIES 90	S90-075PV
83003770	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A5-C2-B-D3-G-G2-H2-L-35-L-35-A-M-20-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83003773	PUMP-VAR-DISPL CW 90PV130	90R130-MA-5-NN-80-S-3-F1-F-C5-EEB-35-35-24	SERIES 90	S90-130PV
83003775	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-EQ-A5-J-Y-J1-NNN-050-AA-G3-15-00	SERIES 51	S51-250MV
83003776	MOTOR-VAR-DISPL 51MV060-1	51V060-1--A-S1-N-T1-C2-N-N-X1-ABA-015-AA-NN-00-15	SERIES 51	S51-060MV-1
83003778	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KN-1-CD-60-D-4-F1-L-03-GBA-35-35-28	SERIES 90	S90-100PV
83003779	PUMP-VAR-DISPL 42PV041 CCW	42-L-41-C-E1A5-02-B-D-B-2-H-N-N-34-34-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83003780	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-E1B6-01-A-N-N-N-H-N-B-23-23-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83003786	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-8-N-0-C7-W-00-EBA-00-00-E4	SERIES 90	S90-100MF
83003787	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-CD-80-D-4-F1-L-03-GBA-38-14-34	SERIES 90	S90-100PV
83003797	PUMP-VAR-DISPL CW 90PV075	90R075-HF-5-AB-80-P-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83003798	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-BC-80-D-C-F1-L-03-FAC-35-35-24	SERIES 90	S90-180PV
83003799	PUMP-VAR-DISPL CCW 90PV130	90L130-HF-5-CD-80-P-3-F1-F-03-GBA-38-38-24	SERIES 90	S90-130PV
83003800	PUMP-VAR-DISPL CCW 90PV250	90L250-HF-5-NN-80-T-4-F1-K-03-NNN-42-42-24	SERIES 90	S90-250PV
83003802	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-C-E1A5-03-B-2-B-2-F-N-A-21-21-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83003803	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-E1A5-03-B-5-B-2-C-N-A-30-30-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83003804	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-C-E1A5-03-B-D-G-2-H-N-N-23-23-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV

83003805	PUMP-VAR-DISPL 42PV041 CCW	42-L-41-E-E1A5-02-B-D-B-2-H-N-B-34-34-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83003806	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-E1A3-02-C-2-N-N-F-N-A-34-34-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83003807	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-E1A3-02-B-2-B-3-F-N-B-34-34-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83003809	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-E1A3-03-A-N-A-2-E-N-B-34-34-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83003810	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-D-E1A6-03-C-2-A-2-F-N-B-30-30-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83003811	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-C-E1A6-03-C-2-A-2-F-N-N-30-30-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83003812	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-C-E1A6-02-B-5-B-2-C-N-B-21-21-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83003813	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-C-E1A5-03-B-5-B-2-C-N-N-19-19-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83003814	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-C-E1B6-01-A-N-N-N-H-N-B-23-23-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83003816	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-D-E1A3-00-D-N-F-2-F-N-B-19-19-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83003818	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-E1A6-02-C-5-A-2-C-N-A-28-28-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83003819	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-E1A6-02-C-2-A-2-F-N-A-34-34-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83003820	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-E1A6-03-A-N-A-2-H-N-A-30-30-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83003822	PUMP-VAR-DISPL 42PV041 CCW	42-L-41-C-E1A3-03-B-D-G-2-E-N-A-30-30-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83003823	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-E1A4-02-B-4-B-2-D-N-A-30-30-N-A-A-NNN-NNN	SERIES 42	S42-041PV/051PV
83003824	PUMP-VAR-DISPL 42PV041 CCW	42-L-41-D-E1A6-03-B-D-B-2-F-N-A-34-34-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83003825	PUMP-VAR-DISPL 42PV041 CCW	42-L-41-D-E1A6-02-B-5-B-2-C-N-B-21-21-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83003826	PUMP-VAR-DISPL 42PV041 CCW	42-L-41-D-E1A6-03-B-D-B-2-F-N-V-30-14-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83003827	PUMP-VAR-DISPL 42PV041 CCW	42-L-41-D-E1A6-03-B-D-B-2-F-N-A-21-21-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83003828	PUMP-VAR-DISPL 42PV041 CCW	42-L-51-D-E1A5-00-B-D-G-3-F-N-A-28-28-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83003829	PUMP-VAR-DISPL 42PV041 CCW	42-L-4C-D-E1A6-02-B-3-B-2-H-N-N-28-28-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83003830	PUMP-VAR-DISPL 42PV041 CCW	42-L-41-D-E1A3-00-B-D-B-2-F-N-B-14-14-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83003831	PUMP-VAR-DISPL 42PV041 CCW	42-L-51-D-E1A5-00-B-D-G-3-F-N-A-34-34-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83003832	PUMP-VAR-DISPL 42PV041 CCW	42-L-41-E-E1A3-03-B-D-G-2-G-N-B-30-30-B-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83003833	PUMP-VAR-DISPL 42PV041 CCW	42-L-41-E-E1A3-03-B-D-G-2-G-N-B-34-34-B-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83003834	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-E1A6-02-B-5-G-2-C-N-A-28-28-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83003835	PUMP-VAR-DISPL 42PV041 CW	42-R-41-G-E1A5-03-B-3-G-2-F-N-A-28-28-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83003836	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-E1A6-02-B-D-G-2-C-N-A-28-28-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83003837	PUMP-VAR-DISPL 42PV041 CW	42-R-51-D-E1A5-00-B-D-G-3-F-N-A-28-28-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83003838	PUMP-VAR-DISPL 42PV041 CW	42-R-51-D-E1A5-00-B-D-G-3-F-N-A-34-34-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83003839	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-E1A6-02-B-3-G-2-F-N-V-41-41-N-A-A-NNN-NCN	SERIES 42	S42-041PV/051PV
83003840	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-E1A6-02-B-2-G-2-E-N-B-34-34-N-A-A-NNN-NNN	SERIES 42	S42-041PV/051PV
83003841	PUMP-VAR-DISPL 42PV041 CW	42-R-41-E-E1A7-03-B-2-X-N-E-N-B-34-34-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83003842	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-E1A6-03-B-3-B-2-F-N-B-34-34-B-A-A-NNN-NNN	SERIES 42	S42-041PV/051PV
83003843	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-E1A6-02-B-D-G-3-H-N-A-25-25-N-A-A-NNN-NNN	SERIES 42	S42-041PV/051PV
83003844	PUMP-VAR-DISPL 42PV041 CCW	42-L-41-C-E1A5-03-B-3-B-3-H-N-A-21-21-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV

83003845	PUMP-VAR-DISPL 42PV041 CCW	42-L-41-C-E1A3-03-B-D-G-2-E-N-A-34-34-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83003846	PUMP-VAR-DISPL 42PV041 CCW	42-L-41-D-E1A6-02-B-2-G-2-F-N-B-34-34-N-A-A-NNN-NNN	SERIES 42	S42-041PV/051PV
83003847	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-D-E1A3-00-A-N-A-2-F-N-B-19-19-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83003848	PUMP-VAR DISPL MPV035D	MPV-035-D-B-A-A-R-S-G-AA-A-A-BHH-DR-A-FF-C-NNN-***	M35/44	035PV
83003849	MOTOR-VARIABLE DISPL SAE_L	L-V-25CN-A-YNF-F08-S-N-N-AF-F15-NNN-NNN	LV / KV MOTORS	L/K-MV
83003850	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-C-E1A3-00-A-N-A-2-F-N-N-19-19-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83003851	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-E1A5-00-B-D-B-2-C-N-N-17-17-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83003852	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-C-E1A4-03-B-2-B-2-H-N-N-14-14-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83003853	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-C-E1A5-03-A-N-A-2-F-N-B-28-28-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83003854	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-E1A6-03-C-2-A-2-F-N-A-41-41-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83003855	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-D-E1A6-02-B-3-G-2-H-N-A-34-34-B-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83003856	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-G-E1A5-03-A-N-A-2-F-N-B-28-28-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83003857	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-E1B3-03-A-N-A-2-D-N-A-14-14-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83003858	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-E1A7-02-A-N-A-2-C-N-V-30-30-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83003859	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-E1A6-02-C-3-A-2-E-N-A-41-41-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83003860	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-E1A4-02-C-2-A-2-F-N-A-34-34-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83003861	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-E1A5-03-D-N-F-2-F-N-N-28-28-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83003862	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-D-E1A4-02-C-2-N-N-E-N-B-28-28-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83003863	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-C-E1A4-02-C-2-N-N-E-N-A-28-28-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83003864	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-D-E1A6-02-C-3-N-N-H-N-B-25-25-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83003865	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-D-E1A7-00-A-N-N-A-H-N-Z-28-28-N-N-N-NNN-BAB	SERIES 42	S42-028PV/032PV
83003867	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-C-E1A3-03-B-3-B-3-F-N-B-25-25-B-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83003868	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-C-E1A3-00-D-N-F-2-F-N-B-19-19-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83003869	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-E1A6-03-C-2-A-2-F-N-B-25-25-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83003871	PUMP-VAR-DISPL 42PV028 CW	42-R-28-G-E1A3-01-C-D-A-2-D-N-N-14-14-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83003873	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-E1B3-11-B-3-G-2-F-N-A-21-21-B-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83003874	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-E1A5-00-B-D-B-2-C-N-N-17-17-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83003875	PUMP-VAR-DISPL 42PV041 CW	42-R-41-C-E1A5-02-B-4-G-2-C-N-N-17-17-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83003876	PUMP-VAR-DISPL 42PV041 CCW	42-L-41-C-E1A3-03-B-D-G-2-G-N-N-30-30-B-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83003877	PUMP-VAR-DISPL 42PV041 CCW	42-L-41-E-E1A3-03-B-D-G-2-H-N-B-30-30-B-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83003878	PUMP-VAR-DISPL 42PV041 CW	42-R-41-C-E1A5-03-B-4-G-2-C-N-B-19-19-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83003879	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-E1A6-02-B-5-B-2-C-N-B-21-21-N-A-A-NNN-NNN	SERIES 42	S42-041PV/051PV
83003880	PUMP-VAR-DISPL 42PV041 CCW	42-L-41-C-E1A6-02-B-5-B-2-C-N-B-21-21-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83003881	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-E1B3-03-B-3-B-2-H-N-V-28-28-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83003890	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MC-1-NN-80-S-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83003891	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MC-1-CD-80-S-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV

83003892	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-E1B3-03-B-3-B-2-H-N-N-28-28-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83003893	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-E1A5-03-D-N-F-2-F-N-N-14-14-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83003894	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-C-E1A5-03-D-N-F-2-F-N-A-28-28-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83003895	PUMP-VAR-DISPL 42PV041 CCW	42-L-41-D-E1A6-02-B-3-G-2-F-N-A-28-28-B-A-A-NNN-NNN	SERIES 42	S42-041PV/051PV
83003896	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-C-E1A3-02-C-3-A-2-F-N-B-28-28-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83003897	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-E1A6-03-A-N-A-2-C-N-B-28-28-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83003898	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-E1A6-03-A-N-A-2-C-N-B-28-28-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83003899	PUMP-VAR-DISPL 42PV041 CCW	42-L-41-C-E1A5-03-B-5-B-2-C-N-N-23-23-N-A-A-NNN-NNN	SERIES 42	S42-041PV/051PV
83003900	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-E1A6-03-B-D-B-2-F-N-A-34-34-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83003901	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-E1A3-02-B-D-B-2-H-N-N-34-34-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83003902	PUMP-VAR-DISPL 42PV041 CCW	42-L-5A-D-E1A5-00-B-D-G-3-F-N-A-34-34-N-N-N-AAA-NNN	SERIES 42	S42-041PV/051PV
83003903	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-C-E1A6-02-B-2-B-2-F-N-A-34-34-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83003904	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-D-E1A6-02-B-2-B-2-F-N-B-34-34-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83003905	PUMP-VAR-DISPL 42PV041 CCW	42-L-41-C-E1A3-03-B-D-B-2-F-N-A-23-23-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83003906	PUMP-VAR-DISPL 42PV041 CW	42-R-41-C-E1A6-02-B-5-B-2-C-N-B-21-21-N-A-A-NNN-NNN	SERIES 42	S42-041PV/051PV
83003907	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-E1A3-03-B-D-B-2-F-N-A-25-25-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83003908	PUMP-VAR-DISPL 42PV041 CCW	42-L-41-C-E1A3-03-B-D-B-2-F-N-B-23-23-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83003909	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-C-E1B6-03-B-D-G-2-H-N-B-34-34-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83003910	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-E1A5-07-B-2-B-2-H-N-B-34-34-B-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83003911	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-E1A5-03-C-2-A-2-F-N-A-21-21-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83003912	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-D-E1A3-07-A-N-A-2-F-N-A-25-25-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83003913	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-E1A5-02-B-3-B-2-F-N-A-14-14-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83003914	PUMP-VAR-DISPL 42PV041 CW	42-R-41-C-E1A3-03-B-2-B-2-H-N-N-17-17-N-A-A-NNN-NNN	SERIES 42	S42-041PV/051PV
83003915	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-E1A6-06-B-3-B-2-F-N-N-30-30-B-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83003916	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-E1A6-11-B-D-G-2-F-N-B-30-30-B-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83003917	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-E1A6-02-B-5-G-2-C-N-A-34-34-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83003918	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-E1B3-11-B-3-G-2-F-N-N-25-25-B-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83003919	PUMP-VAR-DISPL 42PV041 CW	42-R-41-C-E1A5-01-B-3-B-3-H-N-N-21-21-N-A-A-NNN-NNN	SERIES 42	S42-041PV/051PV
83003920	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-E1A6-03-B-2-G-2-F-N-A-34-34-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83003921	PUMP-VAR-DISPL 42PV041 CCW	42-L-41-D-E1A5-03-B-3-G-3-G-N-V-21-21-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83003922	PUMP-VAR-DISPL 42PV041 CCW	42-L-41-D-E1A5-03-B-3-G-3-G-N-N-21-21-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83003923	PUMP-VAR-DISPL 42PV041 CCW	42-L-41-D-E1A5-03-B-2-B-3-F-N-N-34-34-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83003924	PUMP-VAR-DISPL 42PV041 CCW	42-L-41-C-E1A3-00-B-D-B-2-F-N-N-14-14-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83003925	PUMP-VAR-DISPL 42PV041 CCW	42-L-51-D-E1A6-03-B-D-G-3-F-N-N-17-17-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83003926	PUMP-VAR-DISPL 42PV041 CCW	42-L-51-D-E1A5-01-B-D-G-3-H-N-B-36-36-N-N-N-NNN-NDD	SERIES 42	S42-041PV/051PV
83003927	PUMP-VAR-DISPL 42PV041 CCW	42-L-51-K-E1A5-01-B-D-G-3-H-N-V-36-36-N-N-N-NNN-NDD	SERIES 42	S42-041PV/051PV

83003928	PUMP-VAR-DISPL 42PV041 CCW	42-L-41-C-E1A7-00-B-D-B-2-C-N-N-17-NN-N-B-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83003929	PUMP-VAR-DISPL 42PV041 CCW	42-L-41-D-E1A6-02-B-3-B-2-H-N-B-25-25-B-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83003931	PUMP-VAR-DISPL 42PV041 CCW	42-L-41-D-E1A6-01-B-D-G-2-F-N-A-28-28-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83003932	PUMP-VAR-DISPL 42PV041 CCW	42-L-41-C-E1A5-03-B-D-G-2-C-N-N-14-14-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83003933	PUMP-VAR-DISPL 42PV041 CCW	42-L-41-D-E1A6-02-B-5-G-2-C-N-A-28-28-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83003935	PUMP-VAR-DISPL 42PV041 CW	42-R-41-C-E1A3-03-B-D-C-2-E-N-B-34-34-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83003936	PUMP-VAR-DISPL 42PV041 CCW	42-L-41-D-E1A5-02-B-D-C-2-F-N-V-34-34-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83003937	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-E1A6-03-A-N-A-2-F-N-A-28-28-N-C-C-NNN-NNN	SERIES 42	S42-028PV/032PV
83003938	PUMP-VAR-DISPL 42PV041 CCW	42-L-41-C-E1A7-03-B-D-C-3-H-N-N-30-30-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83003939	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-E1A5-03-B-3-C-3-F-N-N-19-19-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83003940	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-E1A6-02-B-5-C-2-C-N-A-34-34-B-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83003942	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-E1A6-03-B-3-G-2-C-N-B-34-34-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83003943	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-E1A6-03-B-3-G-2-C-N-B-34-34-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83003944	PUMP-VAR-DISPL 42PV041 CW	42-R-51-D-E1A5-03-B-D-C-2-C-N-B-14-25-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83003945	PUMP-VAR-DISPL 42PV041 CW	42-R-41-C-E1A6-00-B-D-C-2-F-N-N-23-23-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83003947	PUMP-VAR-DISPL 42PV041 CCW	42-L-41-D-E1A5-02-B-D-C-2-F-N-V-28-28-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83003948	PUMP-VAR-DISPL 42PV041 CCW	42-L-41-D-E1A5-03-B-D-C-2-C-N-A-14-25-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83003949	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-D-E1A3-02-B-D-B-2-F-N-N-34-34-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83003950	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-D-E1A5-03-B-2-B-2-H-N-B-34-34-B-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83003951	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-E1A6-02-B-5-B-2-C-N-N-21-21-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83003952	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-E1A5-03-B-2-B-2-F-N-A-21-21-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83003953	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-E1A6-02-B-5-B-2-C-N-A-34-23-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83003954	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-E1A5-00-B-4-B-2-C-N-B-21-21-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83003955	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-E1A5-03-B-3-B-2-F-N-N-28-28-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83003956	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-E1A5-03-B-2-B-2-F-N-B-30-30-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83003957	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-E1A5-03-B-2-B-2-F-N-N-30-30-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83003958	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-D-E1A5-02-D-N-F-2-H-N-B-30-30-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83003959	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-D-E1A5-03-D-N-F-2-D-N-V-23-23-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83003961	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-C-E1A5-03-A-N-A-2-F-N-B-25-25-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83003962	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-G-E1A5-03-A-N-A-2-F-N-B-25-25-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83003963	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-C-E1A4-02-C-4-A-3-D-N-N-21-21-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83003964	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-D-E1A4-02-C-4-N-N-D-N-B-21-21-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83003965	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-E1A6-03-A-N-N-3-F-N-N-23-23-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83003973	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-E-N1-NN-N-N-U1-ABA-022-AA-E6-00-00	SERIES 51	S51-060MV-1
83003974	PUMP-VAR-DISPL CW 90PV250	90R250-MA-5-CD-80-T-3-C8-K-C5-NNN-35-35-24	SERIES 90	S90-250PV
83003980	PUMP-VAR DISPL MPV044D	MPV-044-D-B-A-G-Y-S-G-BA-A-A-BGG-DL-A-FF-C-NNN-***	M35/44	044PV

83003981	PUMP-VAR-DISPL CW 90PV130	90R130-KT-5-BC-80-R-3-F1-H-03-GBA-38-38-24	SERIES 90	S90-130PV
83003982	PUMP-VAR-DISPL 42PV041 CCW	42-L-41-D-E1A6-02-B-3-G-2-F-N-A-34-34-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83003983	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-E1A6-03-B-D-B-2-H-N-V-34-34-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83003985	PUMP-VAR-DISPL 42PV041 CW	42-R-41-C-E1A6-03-B-D-G-2-C-N-A-30-30-N-A-A-NNN-NNN	SERIES 42	S42-041PV/051PV
83003986	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-E1A3-03-B-D-G-2-F-N-N-14-14-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83003987	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-E1A3-03-B-2-G-3-F-N-B-34-34-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83003988	PUMP-VAR-DISPL 42PV041 CW	42-R-51-C-E1A5-02-B-D-C-3-D-N-N-C2-C2-N-N-N-NNN-ENN	SERIES 42	S42-041PV/051PV
83003989	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-E1A5-03-B-D-G-3-F-N-A-23-23-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83003990	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-E1A5-02-B-2-B-3-F-N-A-28-28-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83003991	PUMP-VAR-DISPL 42PV041 CW	42-R-51-C-E1A3-03-B-2-G-3-F-N-B-34-34-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83003992	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-E1A6-03-B-2-G-2-F-N-A-17-17-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83003993	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-E1A6-03-B-3-G-2-F-N-B-34-34-B-A-A-NNN-NNN	SERIES 42	S42-041PV/051PV
83003994	PUMP-VAR-DISPL 42PV041 CW	42-R-41-C-E1A6-03-B-D-G-3-C-N-N-25-25-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83003995	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-E1A3-01-B-D-G-2-C-N-B-23-23-B-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83003996	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-E1A6-06-B-3-G-2-F-N-N-34-34-B-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83003997	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-E1A6-02-B-D-B-2-F-N-B-41-41-B-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83003998	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-E1A6-03-B-2-G-2-F-N-N-34-34-B-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83003999	PUMP-VAR-DISPL 42PV041 CCW	42-L-41-D-E1A6-02-B-3-B-2-H-N-N-21-21-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83004001	PUMP-VAR-DISPL 42PV041 CCW	42-L-41-E-E1A5-03-B-D-G-2-C-N-B-14-14-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83004002	PUMP-VAR-DISPL 42PV041 CCW	42-L-41-D-E1A6-02-B-3-B-2-H-N-N-25-25-B-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83004003	PUMP-VAR-DISPL 42PV041 CCW	42-L-41-C-E1A6-02-B-2-B-2-H-N-B-25-25-B-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83004004	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-E1A3-02-A-N-N-N-F-N-A-34-34-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83004005	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-E1A6-03-A-N-A-2-C-N-N-25-25-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83004006	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-E1A4-01-A-N-A-2-C-N-B-23-23-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83004007	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-E1A6-02-C-5-A-2-C-N-A-21-21-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83004008	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-C-E1A4-03-C-2-A-2-F-N-N-25-25-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83004009	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-D-E1A4-03-C-2-A-2-F-N-B-25-25-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83004010	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-C-E1A3-03-D-N-F-2-E-N-N-34-34-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83004011	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-D-E1A6-02-A-N-A-2-C-N-A-28-28-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83004012	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-E1A6-03-C-2-A-2-F-N-N-17-17-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83004013	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-E1A6-02-B-D-B-2-H-N-A-17-17-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83004014	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-E1A3-00-B-2-B-2-F-N-B-14-14-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83004015	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-E1A5-00-A-N-N-N-C-N-A-30-30-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83004016	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-E1A5-00-A-N-N-N-C-N-B-30-30-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83004017	PUMP-VAR-DISPL 42PV041 CCW	42-L-41-D-E1A6-02-B-3-G-2-F-N-A-41-41-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83004019	PUMP-VAR-DISPL 42PV041 CW	42-R-41-E-E1A7-03-B-D-C-3-H-N-B-30-30-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV

83004020	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-E1A3-03-B-3-B-2-H-N-V-28-28-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83004021	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-E1A3-03-B-3-B-2-H-N-N-28-28-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83004022	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-D-E1A3-03-B-D-G-2-G-N-A-21-21-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83004023	PUMP-VAR-DISPL 42PV041 CCW	42-L-41-E-E1A3-03-B-D-G-2-G-N-B-30-30-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83004024	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-E2C7-03-B-3-B-3-H-N-N-28-28-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83004025	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-E2C7-03-B-3-B-3-H-N-V-28-28-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83004026	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-C-E1A5-03-A-N-A-2-F-N-A-28-28-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83004028	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-E1A6-02-B-2-G-2-F-N-B-34-34-B-N-N-AAA-NNN	SERIES 42	S42-028PV/032PV
83004029	PUMP-VAR-DISPL 42PV041 CCW	42-L-41-D-E1A5-03-B-2-X-A-E-N-Z-34-34-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83004030	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-C-E1A3-03-B-2-B-2-C-N-N-28-28-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83004031	PUMP-VAR-DISPL 42PV041 CCW	42-L-41-D-E1B6-01-B-D-G-2-F-N-A-17-17-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83004032	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-D-E1B6-03-B-D-G-2-F-N-A-17-17-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83004033	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-C-E1A6-03-C-2-A-2-F-N-N-25-25-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83004034	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-D-E1A6-03-C-2-A-2-F-N-B-25-25-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83004036	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A5-C2-N-D3-G-G3-H3-L-42-L-42-L-M-32-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83004038	MOTOR-VAR-DISPL 51MC160	51C160-R-D5-N-HZ-B1-A-N-G0-NNN-080-AA-F0-03-00	SERIES 51	S51-160MV
83004040	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-BB-80-S-4-S1-E-00-GBA-23-23-24	SERIES 90	S90-075PV
83004041	PUMP-VAR-DISPL CCW 90PV100	90L100-MA-5-BC-80-L-3-C6-E-C5-GBA-42-42-24	SERIES 90	S90-100PV
83004045	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-NN-60-S-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83004049	MOTOR-VAR-DISPL 51MV250	51V250-A-C8-N-T2-C2-L-N-G0-ADA-050-AA-F3-00-C6	SERIES 51	S51-250MV
83004050	PUMP-VAR-DISPL CW 90PV130	90R130-HF-5-AB-80-R-4-F1-H-03-GBA-42-42-24	SERIES 90	S90-130PV
83004051	PUMP-VAR-DISPL CW 90PV250	90R250-HF-5-DE-80-T-4-C8-K-03-NNN-42-42-24	SERIES 90	S90-250PV
83004052	MOTOR-VAR-DISPL 51MV160	51V160-A-C8-N-HZ-B1-A-N-C2-NNN-072-AA-F3-03-00	SERIES 51	S51-160MV
83004053	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-TA-C0-L-N-G0-NNN-080-AA-F0-00-B7	SERIES 51	S51-250MV
83004054	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-CD-80-L-3-T7-H-03-GBA-38-14-24	SERIES 90	S90-130PV
83004058	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D2-N-N1-NN-N-N-U1-ABA-030-AA-F0-00-00	SERIES 51	S51-080MV-1
83004059	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-C7-N-TA-C2-N-N-X1-NNN-016-AA-E4-00-20	SERIES 51	S51-080MV-1
83004061	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-EG-80-T-C-C8-J-03-FAC-42-42-24	SERIES 90	S90-180PV
83004062	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-B-S-B-B-BA-B-A-BJJ-DA-A-ZB-A-NNN-***	M46	M46-046PV
83004063	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-CD-80-D-3-C8-L-03-GBA-32-14-34	SERIES 90	S90-130PV
83004064	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-NN-80-D-3-C8-L-03-GBA-32-14-34	SERIES 90	S90-130PV
83004065	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-NN-80-D-4-C8-L-03-GBA-32-14-34	SERIES 90	S90-130PV
83004068	PUMP-VAR-DISPL 42PV041 CCW	42-L-41-C-E1A3-03-B-D-G-2-G-N-B-30-30-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83004069	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-CD-80-D-3-C7-L-03-GBA-26-26-34	SERIES 90	S90-100PV
83004070	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-NN-80-D-3-S1-L-03-GBA-26-26-34	SERIES 90	S90-075PV
83004072	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-2-BC-80-T-3-C8-K-00-NNN-35-35-24	SERIES 90	S90-250PV

83004079	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-NN-80-P-4-S1-D-00-GBA-42-42-24	SERIES 90	S90-075PV
83004082	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-CD-80-D-4-F1-L-03-GBA-32-14-34	SERIES 90	S90-100PV
83004083	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-NN-80-D-4-S1-L-03-GBA-32-14-34	SERIES 90	S90-100PV
83004084	MOTOR-VAR-DISPL 51MC060	51C060-R-D1-N-L1-B1-W-B-G0-ACA-039-AA-E4-D4-00	SERIES 51	S51-060MV
83004085	PUMP-TANDEM, VAR DISPL MPT035D	MPT-035-D-G-W-A-F-NN-B-A-A-A-BDD-DL-A-FF-B-C-A-A-BDD-DL-A-FF-A-NNN-	M35/44	035PT
83004090	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-NN-80-D-4-C7-L-03-GBA-32-14-34	SERIES 90	S90-100PV
83004091	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-NN-80-D-4-C7-L-03-GBA-26-26-34	SERIES 90	S90-100PV
83004094	PUMP-VAR DISPL, CW 90PV100	90-R-100-HS-1-BC-80-S-4-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83004096	MOTOR-VAR-DISPL 51MC110-1	51C110-1--R-D3-N-N1-NN-N-N-U1-NNN-058-AA-F0-00-00	SERIES 51	S51-110MV-1
83004097	PUMP-VAR DISPL CCW H1P053L	H1-P-053-L-A-A5-C2-N-E5-F-G5-NN-L-33-L-33-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83004104	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-AB-80-L-4-F1-F-03-GBA-36-14-24	SERIES 90	S90-130PV
83004108	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D3-N-E2-B1-N-N-U1-ADA-022-AA-F3-00-00	SERIES 51	S51-080MV-1
83004110	MOTOR-VAR-DISPL 51MV110-1	51V110-1--A-C8-N-T2-CA-N-N-X1-NNN-052-AA-F0-00-25	SERIES 51	S51-110MV-1
83004111	PUMP-VAR-DISPL CW 90PV075	90R075-KN-5-NN-60-S-3-C7-D-03-GBA-32-14-20	SERIES 90	S90-075PV
83004115	PUMP-VAR-DISPLPUMP-VAR-DISPL CCW 90PV100	90L100-KA-1-BC-60-P-3-C7-E-03-GBA-38-38-24	SERIES 90	S90-100PV
83004117	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-1-AB-60-P-3-C7-E-03-GBA-38-38-24	SERIES 90	S90-100PV
83004118	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-N-T2-C2-L-N-G0-ACA-078-AA-F3-00-A3	SERIES 51	S51-250MV
83004119	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-CD-80-P-4-C7-F-03-GBA-35-35-24	SERIES 90	S90-100PV
83004126	PUMP-VAR-DISPL CCW 90PV100	90L100-HF-5-CD-80-S-4-C7-E-03-GBA-26-26-24	SERIES 90	S90-100PV
83004127	PUMP-VAR-DISPL CCW 90PV100	90L100-HF-5-AB-80-S-4-S1-E-03-GBA-26-26-24	SERIES 90	S90-100PV
83004129	MOTOR-VARIABLE DISPL SAE_L	L-V-25CS-E-RNF-F01-S-N-N-CF-F16-NNN-NNN	LV / KV MOTORS	L/K-MV
83004130	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-BC-60-P-3-C6-D-04-GBA-26-26-20	SERIES 90	S90-055PV
83004133	MOTOR-VAR-DISPL 51MV060-1	51V060-1--A-S1-N-P8-P8-N-N-X1-NNN-035-AA-NN-00-AA	SERIES 51	S51-060MV-1
83004134	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-CD-80-L-3-C8-F-03-GBA-35-35-24	SERIES 90	S90-130PV
83004135	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-E1A6-03-A-N-A-2-C-N-A-28-28-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83004138	MOTOR-VAR-DISPL 51MC110-1	51C110-1--R-D3-N-N1-NN-N-N-U1-ABA-058-AA-F0-00-00	SERIES 51	S51-110MV-1
83004143	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-D-S-B-B-BA-A-A-BFF-CB-A-GG-B-NNN-***	M46	M46-046PV
83004151	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A4-C2-N-D8-F-G4-NN-L-20-L-20-B-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83004152	PUMP- VARIABLE, DIRECT DISPLACEMENT	LPV-A-A-A-A-A-G-AA-C-A-BFF-DR-A-FF-B-NNN-***	LPV	LPV
83004166	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A5-C2-N-E5-F-G5-H2-L-33-L-33-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83004171	PUMP-VAR-DISPL CW 90PV130	90R130-KN-5-AB-80-R-3-F1-H-03-GBA-29-29-24	SERIES 90	S90-130PV
83004192	PUMP-VAR-DISPL CW 90PV075	90R075-PA-5-CD-80-L-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83004193	MOTOR-VAR-DISPL 51MC080	51C080-R-D2-N-L2-B1-V-A-C0-ACA-034-AA-F0-B2-00	SERIES 51	S51-080MV
83004194	PUMP-VAR DISPL, CW 90PV055	90-R-055-HS-2-NN-60-S-3-S1-C-00-GBA-43-43-26	SERIES 90	S90-055PV
83004197	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HF-1-NN-80-S-4-S1-C-03-GBA-38-38-24	SERIES 90	S90-055PV
83004198	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-1-NN-81-R-4-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV

83004200	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-NN-80-D-4-C7-L-03-GBA-32-32-34	SERIES 90	S90-100PV
83004201	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-NN-80-D-4-C8-L-03-GBA-32-32-34	SERIES 90	S90-130PV
83004204	PUMP-VAR DISPL MPV025C	MPV-025-C-B-A-A-R-A-V-NN-A-A-BFF-DR-A-FF-A-NNN-***	LIGHT DUTY	025PV
83004205	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-C8-N-TA-C2-N-N-X1-NNN-038-AA-NN-00-20	SERIES 51	S51-110MV-1
83004206	PUMP-VAR-DISPL CCW 90PV075	90L075-HF-5-NN-60-S-4-S1-L-03-GBA-26-26-18	SERIES 90	S90-075PV
83004207	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-CD-80-S-C-C8-J-03-NNN-35-35-24	SERIES 90	S90-180PV
83004209	MOTOR-FIXED DISPL MMF025C	MMF-025-C-A-E-B-C-C-NNN-***	LIGHT DUTY	025MF
83004210	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-NN-80-D-3-S1-L-03-GBA-32-14-34	SERIES 90	S90-100PV
83004216	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-BC-80-S-3-C8-J-00-NNN-35-35-30	SERIES 90	S90-180PV
83004219	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-BC-80-P-3-F1-F-03-GBA-29-29-24	SERIES 90	S90-130PV
83004220	PUMP-VAR-DISPL CW 90PV130	90R130-DD-5-NN-80-L-4-C8-F-GF-GBA-30-30-24	SERIES 90	S90-130PV
83004222	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-D-L2-B1-V-A-C2-ACB-130-AA-NN-B2-00	SERIES 51	S51-250MV
83004223	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-N-E2-A5-A-N-A6-NNN-130-AA-NN-03-00	SERIES 51	S51-250MV
83004224	MOTOR-VAR-DISPL 51MC160	51C160-R-D5-N-L2-B1-V-A-C2-ACB-100-AA-NN-B2-00	SERIES 51	S51-160MV
83004225	MOTOR-VAR-DISPL 51MD160	51D160-R-D4-N-E2-A5-A-N-A6-NNN-035-AA-F3-03-00	SERIES 51	S51-160MV
83004228	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-5-CD-60-S-3-C6-C-04-GBA-35-35-24	SERIES 90	S90-055PV
83004229	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-5-AB-60-S-3-S1-C-04-GBA-35-35-24	SERIES 90	S90-055PV
83004232	MOTOR-FIXED DISPL MMF025C	MMF-025-C-A-U-B-A-B-NNN-***	LIGHT DUTY	025MF
83004234	PUMP-VAR-DISPL CCW 90PV075	90L075-FN-5-CD-60-P-7-C7-D-B6-ELA-42-42-24	SERIES 90	S90-075PV
83004235	PUMP-VAR-DISPL CCW 90PV075	90L075-CA-5-NN-60-P-7-S1-D-00-GBA-42-42-24	SERIES 90	S90-075PV
83004236	PUMP-VAR DISPL, CW 90PV075	90-R-075-HS-5-BC-60-P-3-S1-E-03-GBA-24-24-24	SERIES 90	S90-075PV
83004248	PUMP-VAR-DISPL CCW 90PV100	90L100-HF-1-AB-60-P-4-C7-E-03-GBA-26-26-30	SERIES 90	S90-100PV
83004249	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A4-C2-N-E7-F-G1-H1-38-38-38-38-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83004250	MOTOR-VAR-DISPL 51MV060-1	51V060-1--R-S1-N-B1-B3-N-N-U3-NNN-031-AA-NN-00-00	SERIES 51	S51-060MV-1
83004258	MOTOR-VAR-DISPL 51MV110-1	51V110-1--A-F1-N-T2-CA-N-N-X1-ABA-022-AA-E6-00-32	SERIES 51	S51-110MV-1
83004259	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KN-1-NN-80-D-4-S1-L-03-GBA-26-26-28	SERIES 90	S90-055PV
83004260	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KN-1-NN-80-D-4-F1-L-03-GBA-35-35-28	SERIES 90	S90-100PV
83004261	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-CD-80-R-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-075PV
83004262	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-1-BB-60-L-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
83004263	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-K-T-B-J-BA-V-A-BJJ-CE-A-GG-B-NNN-***	M46	M46-046PV
83004272	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-ANNA-02-C-2-A-3-F-N-A-C4-C4-N-N-N-NNN-ENN	SERIES 42	S42-041PV/051PV
83004274	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-CD-60-R-3-C7-F-03-GBA-35-35-20	SERIES 90	S90-100PV
83004275	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-NN-60-R-3-S1-F-03-GBA-35-35-20	SERIES 90	S90-100PV
83004276	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-A-HS-A2-B-H-C1-NNN-060-AA-NN-10-13	SERIES 51	S51-160MV
83004277	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-C-HS-A2-B-H-C1-NNN-065-AA-NN-10-14	SERIES 51	S51-160MV
83004279	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D3-N-TA-C2-N-N-X1-NNN-016-AA-NN-00-13	SERIES 51	S51-080MV-1

83004286	MOTOR-VAR-DISPL H1B060	H1-B-060-A-L1-BA-N-B-PA-DS-GS-S-A-10-NN-016-N-00-NNN	H1-HP MOTORS	H1-060MB1
83004287	MOTOR-VAR-DISPL H1B060	H1-B-060-A-E2-AA-N-C-TA-VS-AS-S-A-05-NN-000-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83004289	MOTOR-VAR-DISPL H1B060	H1-B-060-A-P2-D2-N-C-TB-DS-GS-S-A-10-NN-016-Z-24-NNN	H1-HP MOTORS	H1-060MB1
83004298	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-BC-80-S-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83004299	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A4-C2-N-E7-F-G1-T1-38-38-38-38-M-P-24-PN-NNN-S02	H1-MP PUMPS	H1-045PT/053PT
83004302	MOTOR-VAR-DISPL 51MV110	51V110-A-F1-N-HS-A2-C-E-G6-ABA-044-AA-E6-18-37	SERIES 51	S51-110MV
83004303	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-TA-C0-L-N-K7-NNN-090-AA-NN-00-A7	SERIES 51	S51-160MV
83004304	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-S1-N-N1-NN-N-N-U1-NNN-016-AA-E6-00-00	SERIES 51	S51-080MV-1
83004305	PUMP-VAR-DISPL CW 90PV130	90R130-KN-2-NN-80-S-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-130PV
83004306	PUMP-VAR-DISPL CCW H1PV115	H1-P-115-L-B-A2-C3-N-D8-G-G3-NN-L-35-L-35-A-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83004307	PUMP-VAR-DISPL CW 90PV180	90R180-KN-2-NN-80-S-C-F1-H-03-FAC-26-26-24	SERIES 90	S90-180PV
83004312	MOTOR-VAR-DISPL H1B080	H1-B-080-A-L2-BA-N-B-PB-VS-AS-S-A-10-NN-028-N-00-NNN	H1-HP MOTORS	H1-080MB1
83004313	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-BB-80-L-3-F1-D-03-FAD-42-42-28	SERIES 90	S90-100PV
83004314	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-NN-80-L-3-F1-D-03-FAD-42-42-24	SERIES 90	S90-100PV
83004315	MOTOR-VAR-DISPL 51MV060-1	51V060-1--A-S1-N-B3-B3-N-N-U5-AWM-044-AA-E6-00-00	SERIES 51	S51-060MV-1
83004316	MOTOR-VAR-DISPL 51MV060-1	51V060-1--A-C6-N-B3-B3-N-N-U5-AWM-044-AA-E6-00-00	SERIES 51	S51-060MV-1
83004320	PUMP-VAR-DISPL CCW H1PV147	H1-P-147-L-C-A5-C3-B-D3-G-G3-H6-K-33-K-20-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83004321	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-BC-80-S-3-F1-F-03-GBA-42-42-28	SERIES 90	S90-130PV
83004323	PUMP-VAR-DISPL CCW 90PV075	90L075-FH-5-NN-80-P-7-C7-D-B3-GBA-29-29-30	SERIES 90	S90-075PV
83004332	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-CD-80-D-3-C7-L-03-GBA-32-32-34	SERIES 90	S90-100PV
83004338	PUMP-VAR DISPL MPV046C	MPV-046-C-B-A-B-T-B-J-AA-A-A-BFF-AB-U-CD-A-NNN-***	M46	M46-046PV
83004340	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-NN-80-S-4-C3-C-09-GBA-30-30-30	SERIES 90	S90-042PV
83004341	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-BB-80-S-4-C3-C-09-GBA-30-30-30	SERIES 90	S90-042PV
83004342	PUMP-VAR-DISPL CW 90PV075	90R075-KN-5-NN-80-S-3-C7-D-03-GBA-20-20-20	SERIES 90	S90-075PV
83004351	PUMP-TANDEM, VAR DISPL MPT035D	MPT-035-D-G-W-A-E-NN-B-A-A-A-BDD-DR-A-FF-B-C-A-A-BDD-DY-A-FF-J-NNN-	M35/44	035PT
83004355	PUMP-TANDEM, VAR DISPL MPT035D	MPT-035-D-A-W-R-N-BA-B-A-A-A-BHH-DR-A-FF-B-C-A-A-BHH-DX-A-FF-K-NNN-	M35/44	035PT
83004356	PUMP-VAR-DISPL CW 90PV250	90R250-HS-5-NN-80-T-4-C8-K-03-NNN-42-42-24	SERIES 90	S90-250PV
83004357	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A3-C2-N-D6-G-G2-NN-L-25-L-25-A-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83004366	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-A-V-C-S-AA-B-A-A-A-BJJ-AA-U-CD-B-C-A-A-BJJ-AA-D-CD-D-NNN-**	M46	M46-046PT
83004367	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-A-V-C-B-AA-B-A-A-A-BRR-AB-U-DD-B-C-A-A-BRR-AB-U-DD-D-NNN-	M46	M46-046PT
83004369	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-K-S-B-S-BA-J-A-BJJ-DA-A-ZF-B-NNF-***	M46	M46-046PV
83004370	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-A-V-C-S-AA-B-A-A-A-BJJ-AK-D-CF-B-C-A-A-BJJ-AK-U-CF-D-NNN-***	M46	M46-046PT
83004371	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-B-V-C-B-AA-B-A-A-A-BFF-GG-B-FF-B-C-A-A-BFF-GG-B-FF-B-NNN-**	M46	M46-046PT
83004379	PUMP-VAR DISPL, CW 90PV055	90-R-055-MB-1-AB-60-S-4-S1-C-03-GBA-29-29-20	SERIES 90	S90-055PV
83004391	PUMP-VAR DISPL CCW H1P053L	H1-P-053-L-A-A4-C1-B-E5-F-G5-NN-L-30-L-20-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83004392	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A4-C2-N-E7-F-G5-H5-35-35-35-35-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT

83004395	MOTOR-VAR DISPL MMV046C	MMV-046-C-B-M-B-C-AD-NNN-***	M46	M46-046MV
83004396	MOTOR-VAR DISPL MMV046C	MMV-046-C-A-E-4-C-AV-VNB-***	M46	M46-046MV
83004397	MOTOR-VAR DISPL MMV046C	MMV-046-C-A-E-4-C-A8-VNB-***	M46	M46-046MV
83004398	PUMP-VAR DISPL, CW 90PV075	90-R-075-M8-1-CD-60-P-3-C7-D-02-GBA-40-40-24	SERIES 90	S90-075PV
83004401	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-CD-80-R-3-F1-F-03-GBA-38-38-24	SERIES 90	S90-100PV
83004402	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-NN-60-R-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83004406	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-NN-80-D-3-S1-L-03-GBA-32-32-34	SERIES 90	S90-075PV
83004407	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-C-E1A6-02-B-2-B-2-F-N-B-34-34-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83004412	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-A-V-C-K-AA-B-A-A-A-BHH-AK-D-CF-B-C-A-A-BHH-AK-U-CF-D-NNN-***	M46	M46-046PT
83004413	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-A-V-C-S-AA-B-A-A-A-BJJ-AK-U-CF-B-C-A-A-BJJ-AK-D-CF-D-NNN-***	M46	M46-046PT
83004414	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-A-V-C-S-AA-B-A-A-A-BJJ-GH-U-CF-B-C-A-A-BJJ-GH-D-CF-D-NNN-***	M46	M46-046PT
83004415	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-A-V-C-B-AA-B-A-A-A-BHH-GH-U-CF-B-C-A-A-BHH-GH-D-CF-D-NNN-***	M46	M46-046PT
83004416	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-A-V-C-B-AA-B-A-A-A-BHH-AK-U-CF-B-C-A-A-BHH-AK-D-CF-D-NNN-***	M46	M46-046PT
83004417	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-A-V-C-B-AA-B-A-A-A-BRR-GH-U-CF-B-C-A-A-BRR-GH-D-CF-D-NNN-***	M46	M46-046PT
83004418	PUMP-VAR-DISPL CW 90PV130	90R130-KN-5-BC-80-R-4-F1-F-03-EEB-14-14-24	SERIES 90	S90-130PV
83004420	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-1-NN-60-S-3-S1-D-03-GBA-42-42-28	SERIES 90	S90-075PV
83004422	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-N-A4-C2-N-E7-F-G1-H3-30-30-38-20-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83004429	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-HS-A3-B-E-E5-NNN-055-AA-G0-07-35	SERIES 51	S51-160MV
83004452	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-CD-80-R-3-S1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
83004453	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HF-1-CD-80-R-3-F1-F-03-GBA-38-38-24	SERIES 90	S90-100PV
83004454	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HF-1-CD-80-R-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83004458	PUMP-VARIABLE, DIRECT DISPLACEMENT	LPV-A-A-B-A-A-G-AA-C-A-BJJ-DR-A-FF-A-NNN-***	LPV	LPV
83004460	PUMP-VAR-DISPL CW 90PV075	90R075-MA-2-BC-60-S-4-C7-D-C5-GBA-38-38-24	SERIES 90	S90-075PV
83004461	PUMP-VAR-DISPL CW 90PV100	90R100-DD-5-NN-60-R-4-S1-E-GB-GBA-26-26-24	SERIES 90	S90-100PV
83004463	PUMP-TANDEM, VAR DISPL MPT035D	MPT-035-D-A-R-A-F-NN-B-A-A-A-BEE-DR-A-FF-B-C-A-A-BEE-DR-A-FF-J-NNN-***	M35/44	035PT
83004464	PUMP-TANDEM, VAR DISPL MPT035D	MPT-035-D-A-R-R-G-BA-B-A-A-A-BJJ-DR-A-FF-B-A-A-A-BJJ-DR-A-FF-A-NNN-***	M35/44	035PT
83004467	PUMP-TANDEM, VAR DISPL MPT035D	MPT-035-D-C-Y-A-E-NN-C-A-A-A-BJJ-DS-A-FF-C-C-A-A-BJJ-DS-A-FF-J-NNN-***	M35/44	035PT
83004468	PUMP-TANDEM, VAR DISPL MPT035D	MPT-035-D-G-W-A-F-NN-G-A-A-A-BFF-DL-A-FF-G-C-A-A-BFF-DL-A-FF-J-NNN-***	M35/44	035PT
83004469	PUMP-TANDEM, VAR DISPL MPT035D	MPT-035-D-G-W-A-N-NN-B-A-A-A-BDD-DR-A-FF-B-C-A-A-BDD-DY-A-FF-J-NNN-***	M35/44	035PT
83004470	PUMP-TANDEM, VAR DISPL MPT035D	MPT-035-D-G-W-A-N-NN-B-A-A-A-BHH-DL-A-FF-B-C-A-A-BHH-DL-A-FF-J-NNN-***	M35/44	035PT
83004471	PUMP-TANDEM, VAR DISPL MPT035D	MPT-035-D-G-W-R-J-BA-B-A-A-A-BFF-DR-A-FF-B-C-A-A-BFF-DL-A-FF-J-NNN-***	M35/44	035PT
83004473	PUMP-VAR DISPL, CW 90PV100	90-R-100-HS-1-BC-80-R-4-S1-E-00-GBA-35-35-24	SERIES 90	S90-100PV
83004475	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-E1A6-02-B-2-B-2-G-N-A-25-25-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83004476	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-BC-60-R-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83004479	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-NN-60-S-3-C7-E-03-GBA-42-42-20	SERIES 90	S90-100PV
83004482	PUMP-TANDEM, VAR DISPL MPT044D	MPT-044-D-A-W-A-G-NN-B-A-A-A-BGG-DR-A-FF-B-C-A-A-BGG-DR-A-FF-J-NNN-***	M35/44	044PT

83004483	PUMP-TANDEM, VAR DISPL MPT044D	MPT-044-D-A-W-A-G-NN-B-A-A-A-BJJ-DR-A-FF-B-C-A-A-BJJ-DR-A-FF-J-NNN-***	M35/44	044PT
83004487	MOTOR-VARIABLE DISPL SAE_K	K-V-45DS-A-YNF-F08-S-N-N-CF-F18-NNN-PNN	LV / KV MOTORS	L/K-MV
83004492	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-5-NN-80-S-3-S1-D-GB-GBA-42-42-24	SERIES 90	S90-055PV
83004494	PUMP-VAR-DISPL CW 90PV100	90R100-MB-5-CD-80-S-4-F1-E-C4-GBA-42-42-30-F023	SERIES 90	S90-100PV
83004495	PUMP-VAR-DISPL CW 90PV075	90R075-DD-5-CD-80-S-3-S1-E-GB-GBA-42-32-24	SERIES 90	S90-075PV
83004498	PUMP-VAR-DISPL CW 90PV100	90R100-MA-5-NN-60-S-3-S1-E-C6-GBA-42-42-24	SERIES 90	S90-100PV
83004501	PUMP-VAR-DISPL CCW H1PV115	H1-P-115-L-B-A4-C2-N-D3-G-G3-NN-L-42-L-42-L-M-20-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83004507	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-A-T-B-B-BA-G-A-BHH-CB-A-HH-5-NNN-***	M46	M46-046PV
83004508	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A4-C2-B-F3-F-G5-H3-J-40-J-40-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83004512	MOTOR-VAR-DISPL 51MD110-1	51D110-1--A-D3-N-P7-P7-N-N-X1-AWM-034-AA-F0-00-AA	SERIES 51	S51-110MV-1
83004513	MOTOR-VAR-DISPL 51MD110-1	51D110-1--A-D3-N-N1-NN-N-N-U1-AWM-034-AA-F0-00-00	SERIES 51	S51-110MV-1
83004514	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-1-AD-80-S-4-T1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83004516	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MT-1-AB-60-A-3-F1-F-02-GFK-35-35-20	SERIES 90	S90-100PV
83004519	PUMP-VAR-DISPL CW 90PV130	90R130-PA-5-CD-80-L-4-C8-F-03-GBA-35-35-24	SERIES 90	S90-130PV
83004520	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-NN-80-S-4-S1-E-26-GBA-23-23-24	SERIES 90	S90-075PV
83004521	PUMP-TANDEM, VAR DISPL MPT035D	MPT-035-D-G-W-A-F-NN-B-A-A-A-BDD-DL-A-FF-B-C-A-A-BDD-DL-A-FF-A-NNC-*	M35/44	035PT
83004522	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-NN-60-R-3-C7-E-04-FAB-35-35-20	SERIES 90	S90-100PV
83004523	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-CD-80-R-4-C7-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83004524	PUMP-VAR-DISPL CW 90PV180	90R180-FH-5-AB-80-T-7-C8-J-B2-FAC-43-43-30	SERIES 90	S90-180PV
83004525	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-D7-M1-S-K-M1-ADA-065-AA-G3-F4-17	SERIES 51	S51-250MV
83004528	PUMP-TANDEM, VAR DISPL MPT035D	MPT-035-D-A-Y-R-E-AA-B-A-A-A-BGG-DR-A-FF-B-A-A-A-BGG-DR-A-FF-C-NNN-*	M35/44	035PT
83004529	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-BC-80-P-4-C7-E-00-GBA-35-35-24	SERIES 90	S90-100PV
83004530	PUMP-VAR-DISPL CW 90PV075	90R075-MA-5-AB-60-S-4-C6-D-C7-GBA-29-29-24	SERIES 90	S90-075PV
83004534	PUMP-VAR DISPL, CW 90PV055	90-R-055-FC-1-CD-60-S-7-C6-D-B1-EFI-35-35-28	SERIES 90	S90-055PV
83004535	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-CD-80-P-3-F1-F-03-GBA-36-36-24	SERIES 90	S90-130PV
83004536	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A2-C2-N-D3-H-G1-H5-L-20-L-20-F-M-20-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83004540	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-BB-80-S-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83004546	MOTOR-VARIABLE CARTRIDGE K	K-C-45DS-E-RNF-F09-S-N-N-DF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83004550	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-5-NN-80-R-3-C6-C-03-GBA-26-26-24	SERIES 90	S90-055PV
83004555	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-1-NN-60-R-4-S1-C-03-GBA-29-29-24	SERIES 90	S90-055PV
83004557	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-NN-60-R-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83004559	PUMP-TANDEM, VAR DISPL MPT035D	MPT-035-D-G-W-A-F-NN-B-A-A-A-BDD-DL-A-FF-B-C-A-A-BDD-DL-A-FF-J-NNC-*	M35/44	035PT
83004560	PUMP-TANDEM, VAR DISPL MPT035D	MPT-035-D-G-W-A-F-NN-B-A-A-A-BFF-DL-A-FF-B-C-A-A-BFF-DL-A-FF-J-NNC-***	M35/44	035PT
83004561	PUMP-TANDEM, VAR DISPL MPT035D	MPT-035-D-G-W-A-R-NN-B-A-A-A-BHH-DL-A-FF-B-C-A-A-BFF-DL-A-FF-D-NNC-*	M35/44	035PT
83004562	PUMP-TANDEM, VAR DISPL MPT035D	MPT-035-D-G-W-A-R-NN-B-A-A-A-BHH-DL-A-FF-B-C-A-A-BHH-DL-A-FF-J-NNC-*	M35/44	035PT
83004563	PUMP-TANDEM, VAR DISPL MPT035D	MPT-035-D-G-W-A-R-NN-B-A-A-A-BNN-DL-A-FF-B-C-A-A-BNN-DL-A-FF-K-NNC-	M35/44	035PT

83004565	PUMP-TANDEM, VAR DISPL CCW H1T045L	H1-T-045-L-A-N-A3-C2-N-F7-F-G6-H3-35-35-35-35-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83004567	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D3-N-E2-B1-N-N-U1-ACB-028-AA-E6-00-00	SERIES 51	S51-080MV-1
83004568	MOTOR-VAR-DISPL 51MD060	51D060-R-D1-A-HS-A2-C-H-C1-NNN-026-AA-NN-14-13	SERIES 51	S51-060MV
83004569	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-G-S-B-B-AA-V-A-BBB-DA-A-HH-C-NNN-***	M46	M46-046PV
83004574	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-2-NN-80-L-4-F1-F-03-GBA-35-35-24	SERIES 90	S90-130PV
83004575	PUMP-VAR-DISPL CW 90PV180	90R180-KN-5-NN-80-T-C-F1-J-03-FAC-38-38-24	SERIES 90	S90-180PV
83004576	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-L2-B1-V-A-G5-NNN-095-AA-F0-B2-00	SERIES 51	S51-160MV
83004577	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-L1-B1-W-B-G0-NNN-019-AA-E4-D4-00	SERIES 51	S51-080MV
83004578	MOTOR-VAR-DISPL 51MC080-1	51C080-1--A-D2-N-P7-P7-N-N-X1-ADA-030-AA-F3-00-AA	SERIES 51	S51-080MV-1
83004579	MOTOR-VAR-DISPL H1B110	H1-B-110-A-K2-K2-N-B-RB-VS-ES-S-A-15-NN-036-N-25-NNN	H1-HP MOTORS	H1-110MB1
83004581	PUMP-VAR DISPL, CW 90PV100	90-R-100-KN-1-BC-60-S-4-K3-F-02-GBA-34-14-24-P000	SERIES 90	S90-100PV
83004587	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-5-BC-80-D-3-F1-L-03-NNN-42-42-20	SERIES 90	S90-250PV
83004588	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-P8-P8-N-N-X1-NNN-040-AA-F3-00-AA	SERIES 51	S51-110MV-1
83004590	PUMP-VAR DISPL, CW 90PV100	90-R-100-KN-1-BC-60-S-4-K3-F-02-GBA-35-14-24-P000	SERIES 90	S90-100PV
83004605	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-D3-N-P8-P8-N-N-X1-ADA-036-AA-F0-00-AA	SERIES 51	S51-080MV-1
83004606	PUMP- VARIABLE, DIRECT DISPLACMENT	LPV-A-A-B-A-A-I-AA-D-A-BDD-DR-A-FF-B-NNN-***	LPV	LPV
83004648	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-2-CD-60-D-3-S1-L-03-GBA-32-32-24	SERIES 90	S90-075PV
83004649	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-CD-60-R-3-F1-E-03-GBA-35-35-28	SERIES 90	S90-100PV
83004650	PUMP-VAR DISPL, CW 90PV075	90-R-075-HS-1-CD-80-P-3-C7-E-03-GBA-29-29-24	SERIES 90	S90-075PV
83004655	PUMP-VAR DISPL MPV046C	MPV-046-C-B-A-B-S-B-B-BA-A-A-BFF-AB-U-DD-A-NNN-***	M46	M46-046PV
83004659	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-EQ-A5-J-Y-J1-ACA-032-AA-G0-15-00	SERIES 51	S51-160MV
83004660	MOTOR-VAR-DISPL 51MV110	51V110-R-F1-N-EQ-A5-J-Y-J1-ACA-022-AA-G0-15-00	SERIES 51	S51-110MV
83004661	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-NN-80-R-3-F1-H-03-GBA-42-42-24	SERIES 90	S90-130PV
83004662	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-CD-80-R-3-F1-H-03-GBA-42-42-24	SERIES 90	S90-130PV
83004672	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HS-1-CD-80-S-3-F1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
83004673	MOTOR-VARIABLE CARTRIDGE K	K-C-38CN-A-RNF-F08-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83004675	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-HS-A3-A-H-E5-NNN-032-AA-F0-04-32	SERIES 51	S51-160MV
83004676	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-5-NN-80-T-3-C8-K-05-NNN-35-35-24	SERIES 90	S90-250PV
83004677	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-BC-80-S-3-C8-H-03-GBA-35-35-24	SERIES 90	S90-130PV
83004679	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-NN-80-R-4-C7-F-03-GBA-26-32-26	SERIES 90	S90-100PV
83004680	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-NN-80-R-4-C7-F-03-GBA-26-26-26	SERIES 90	S90-100PV
83004711	MOTOR-VAR-DISPL 51MD060-1	51D060-1--A-D2-N-P7-P7-N-N-X1-NNN-018-AA-F3-00-AA	SERIES 51	S51-060MV-1
83004716	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-N1-NN-N-N-U1-NNN-055-AA-E6-00-00	SERIES 51	S51-110MV-1
83004717	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-E1-A5-A-N-G0-NNN-125-AA-F0-03-00	SERIES 51	S51-250MV
83004721	PUMP-VAR-DISPL CCW H1PV115	H1-P-115-L-B-A5-C3-B-D3-G-G3-H6-K-35-K-20-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83004732	PUMP-VAR DISPL, CW 90PV055	90-R-055-HS-1-CD-80-R-4-S1-C-03-GBA-42-42-24-F032	SERIES 90	S90-055PV

83004733	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-BB-80-S-2-S1-D-03-GBA-35-35-20	SERIES 90	S90-075PV
83004735	PUMP-VAR-DISPL CW 90PV180	90R180-KN-5-BC-80-S-M-F1-J-03-NNN-29-14-22	SERIES 90	S90-180PV
83004739	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-D-HZ-B1-C-H-C2-NNN-110-AA-NN-14-00	SERIES 51	S51-250MV
83004747	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A2-C1-N-D6-F-G5-NN-L-40-L-40-B-L-22-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83004751	PUMP-VAR-DISPL 42PV041 CCW	42-L-51-C-E1A7-03-D-N-F-3-H-N-N-34-34-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83004754	PUMP-VAR DISPL, CW 90PV100	90-R-100-HS-1-BB-80-S-3-F1-E-03-GBA-35-35-28	SERIES 90	S90-100PV
83004755	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-BB-80-S-3-F1-F-03-GBA-35-35-20	SERIES 90	S90-130PV
83004760	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-NN-80-L-4-C7-E-03-GBA-32-32-24	SERIES 90	S90-100PV
83004763	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A4-C2-N-E7-F-G1-H1-30-30-35-20-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83004767	PUMP-VAR-DISPL CCW H1PV115	H1-P-115-L-B-A3-C2-N-D3-G-G3-H4-L-40-L-40-A-M-30-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83004769	MOTOR-VAR-DISPL 51MD160	51D160-A-D4-N-HS-A3-C-E-E5-NNN-064-AA-F0-12-24	SERIES 51	S51-160MV
83004770	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-S1-N-T5-D3-N-N-X1-NNN-035-AA-E6-00-27	SERIES 51	S51-080MV-1
83004771	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-B8-C2-C-D6-G-G2-H3-L-42-L-42-L-L-24-P1-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83004781	PUMP-VAR-DISPL CCW 90PV130	90L130-KN-5-AB-80-L-3-F1-F-00-GBA-38-38-24	SERIES 90	S90-130PV
83004782	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-D8-M1-R-J-M4-ADA-064-AA-G0-C2-30	SERIES 51	S51-160MV
83004785	PUMP-VAR DISPL CCW H1P060L	H1-P-060-L-A-A4-C2-N-D8-H-G1-NN-L-43-L-43-F-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83004786	PUMP-VAR DISPL CCW H1P060L	H1-P-060-L-A-A4-C2-N-D8-H-G1-H2-L-43-L-43-F-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83004787	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-BC-60-R-4-T2-E-03-GBA-32-32-24	SERIES 90	S90-100PV
83004788	MOTOR-VAR-DISPL 51MD110-1	51D110-1--R-D4-N-E1-B1-N-N-U1-NNN-065-AA-F3-00-00	SERIES 51	S51-110MV-1
83004789	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-C7-N-TA-C2-N-N-X1-AAA-033-AA-E4-00-16	SERIES 51	S51-080MV-1
83004792	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-E1A5-03-C-2-A-3-F-N-B-34-34-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83004793	MOTOR-VAR-DISPL 51MD160	51D160-R-D4-N-E2-A5-A-N-A6-NNN-080-AA-G3-03-00	SERIES 51	S51-160MV
83004800	PUMP-VAR DISPL CCW H1P053L	H1-P-053-L-A-A3-C1-N-D6-F-G5-H2-L-35-L-35-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83004801	PUMP-VAR DISPL CCW H1P053L	H1-P-053-L-A-A2-C1-N-E6-F-G5-H5-L-35-L-35-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83004804	MOTOR-VAR-DISPL 51MV110	51V110-A-F1-N-L2-B1-V-A-C2-ACB-055-AA-NN-B2-00	SERIES 51	S51-110MV
83004805	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-NN-60-P-3-S1-F-00-GBA-23-23-24	SERIES 90	S90-100PV
83004807	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-NN-80-P-3-S1-D-00-GBA-26-26-24	SERIES 90	S90-055PV
83004809	MOTOR-VAR-DISPL 51MV110-1	51V110-1--A-F1-N-E2-B1-N-N-U1-ADA-040-AA-NN-00-00	SERIES 51	S51-110MV-1
83004810	MOTOR-VAR-DISPL 51MD080	51D080-R-D2-N-HS-A2-C-H-C1-NNN-038-AA-NN-14-13	SERIES 51	S51-080MV
83004811	PUMP-VAR-DISPL CW 90PV250	90R250-PB-5-AB-80-T-3-C8-K-00-NNN-40-42-28	SERIES 90	S90-250PV
83004817	MOTOR-VAR-DISPL 51MD080-1	51D080-1--R-D3-N-P8-P8-N-N-X1-ADA-036-AA-F0-00-AA	SERIES 51	S51-080MV-1
83004821	MOTOR-VAR-DISPL 51MC110	51C110-R-D3-N-TH-C0-L-N-G0-ACA-032-AA-F0-00-B2	SERIES 51	S51-110MV
83004823	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-1-AB-80-R-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-075PV
83004825	PUMP-VAR DISPL MPV046C	MPV-046-C-B-A-A-S-B-B-AA-A-A-BMM-AB-D-BD-C-NNN-***	M46	M46-046PV
83004827	PUMP-VAR DISPL, CW 90PV055	90-R-055-HF-1-BB-60-P-4-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83004838	PUMP-VAR DISPL, CW 90PV055	90-R-055-HF-5-NN-80-S-4-S1-C-03-GBA-38-38-20	SERIES 90	S90-055PV

83004861	MOTOR-VAR-DISPL 51MV060-1	51V060-1--R-C6-N-E1-B1-N-N-U1-NNN-030-AA-F0-00-00	SERIES 51	S51-060MV-1
83004862	PUMP-VAR DISPL CCW H1P053L	H1-P-053-L-A-A2-C1-N-E6-F-G5-H2-L-35-L-35-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83004863	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A5-C2-B-D6-H-G9-NN-K-40-K-40-F-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83004864	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-NN-80-P-4-S1-F-04-GBA-42-42-24	SERIES 90	S90-100PV
83004870	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-AB-80-S-3-C7-E-03-GBA-23-23-24	SERIES 90	S90-100PV
83004871	MOTOR-VAR-DISPL 51MD080-1	51D080-1--R-D3-N-N1-NN-N-N-U1-NNN-040-AA-NN-00-00	SERIES 51	S51-080MV-1
83004873	MOTOR-VAR-DISPL H1B080	H1-B-080-A-E1-AA-N-A-TA-CS-HS-S-A-05-NN-016-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83004874	MOTOR-VAR-DISPL H1B080	H1-B-080-A-L2-BA-N-B-PB-VN-AN-N-A-05-NN-000-N-00-NNN	H1-HP MOTORS	H1-080MB1
83004875	MOTOR-VAR-DISPL H1B080	H1-B-080-A-M1-CA-N-A-RA-VS-AS-S-A-10-NN-016-N-00-NNN	H1-HP MOTORS	H1-080MB1
83004876	MOTOR-VAR-DISPL H1B080	H1-B-080-A-P1-D1-N-B-TB-DN-JN-N-N-NN-NN-000-Z-24-NNN	H1-HP MOTORS	H1-080MB1
83004877	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-TA-C0-L-N-K7-NNN-078-AA-F3-00-C7	SERIES 51	S51-160MV
83004878	PUMP-VAR-DISPL CCW H1PV115	H1-P-115-L-B-A4-C2-N-D6-G-G3-NN-L-42-L-42-A-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83004879	MOTOR-VAR-DISPL 51MD060-1	51D060-1--R-D2-N-T2-D2-N-N-X1-NNN-030-AA-E6-00-24	SERIES 51	S51-060MV-1
83004880	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-CD-80-L-4-F1-F-03-EHA-35-35-24	SERIES 90	S90-130PV
83004881	MOTOR-VAR-DISPL 51MD160	51D160-R-D5-N-T2-C0-L-N-G0-NNN-068-AA-F3-00-B8	SERIES 51	S51-160MV
83004882	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A2-C1-N-D6-F-G5-H3-L-35-L-35-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83004884	PUMP-VAR DISPL MPV046C	MPV-046-C-B-A-B-S-B-B-AA-V-A-BFF-AB-U-ZK-A-NNN-***	M46	M46-046PV
83004892	PUMP-TANDEM, VAR DISPL MPT035D	MPT-035-D-G-W-A-R-NN-B-A-A-A-BHH-DL-A-FF-B-C-A-A-BHH-DL-A-FF-D-NNC-	M35/44	035PT
83004895	MOTOR-VAR-DISPL 51MV110	51V110-A-F1-N-HS-A2-C-H-G6-NNN-061-AA-NN-13-32	SERIES 51	S51-110MV
83004898	MOTOR-VAR-DISPL 51MV060-1	51V060-1--R-S1-N-N1-NN-N-N-U1-NNN-026-AA-E4-00-00	SERIES 51	S51-060MV-1
83004899	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-1-AB-80-R-3-T1-E-03-EBC-38-14-24	SERIES 90	S90-075PV
83004900	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-AB-80-R-3-T1-E-03-EBC-38-14-24	SERIES 90	S90-075PV
83004901	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-CD-60-L-3-C7-F-03-GBA-42-42-24	SERIES 90	S90-100PV
83004902	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-NN-60-L-3-S1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
83004903	PUMP-VAR-DISPL CCW 90PV100	90L100-MA-1-NN-60-S-4-C7-E-04-GBA-35-35-24	SERIES 90	S90-100PV
83004904	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-B-V-C-B-AA-B-A-A-A-BGG-AW-U-FF-B-C-A-A-BGG-AW-D-FF-B-NNN	M46	M46-046PT
83004905	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A8-C1-C-E5-J-G5-NN-L-35-L-35-B-P-20-P2-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83004906	PUMP-VAR DISPL, CW 90PV055	90-R-055-FA-5-NN-80-P-7-S1-D-B1-GCA-40-40-24	SERIES 90	S90-055PV
83004907	PUMP-VAR-DISPL CCW 90PV100	90L100-DD-5-BB-80-S-4-C7-E-GB-GBA-42-42-24	SERIES 90	S90-100PV
83004909	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-1-NN-80-R-3-S1-C-05-GBA-35-35-20	SERIES 90	S90-055PV
83004911	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A4-C3-N-E7-F-G1-H3-33-33-33-33-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83004912	PUMP-VAR-DISPL CW 90PV130	90R130-KA-1-AB-80-L-4-F1-F-03-GBA-36-14-24	SERIES 90	S90-130PV
83004915	PUMP-VAR-DISPL CCW 90PV075	90L075-MA-1-NN-60-L-4-C6-D-04-GBA-35-35-24	SERIES 90	S90-075PV
83004917	Motor-var DIPSL 50MV250	51V250-R-F2-N-E2-A5-A-N-A6-NNN-168-AA-F3-03-00	SERIES 51	S51-250MV
83004918	MOTOR-VARIABLE DISPL SAE_K	K-V-38CS-E-YNF-F09-S-N-N-BF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83004923	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HF-1-NN-60-R-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV

83004928	PUMP-VAR DISPL, CW 90PV100	90-R-100-MB-2-CD-60-L-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83004929	PUMP-VAR DISPL, CW 90PV100	90-R-100-MB-2-AB-60-L-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83004945	MOTOR-VAR-DISPL H1B110	H1-B-110-A-L2-BA-N-B-PA-DS-KS-S-A-10-NN-044-N-00-NNN	H1-HP MOTORS	H1-110MB1
83004949	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A3-C2-N-D8-F-G5-H3-L-40-L-40-B-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83004972	MOTOR-VAR-DISPL 51MV060-1	51V060-1--A-C6-N-B3-B3-N-N-U5-AWM-038-AA-E6-00-00	SERIES 51	S51-060MV-1
83004975	PUMP-VAR-DISPL CCW H1PV147	H1-P-147-L-C-A4-C3-N-D6-G-G3-H6-K-38-K-38-A-L-20-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83004980	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A2-C2-N-F1-F-G5-NN-K-35-K-35-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83004981	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-T1-L5-L-N-G0-NNN-068-AA-F3-00-C2	SERIES 51	S51-160MV
83004989	MOTOR-VAR-DISPL 51MV080	51V080-R-C7-N-L2-B1-V-A-C0-NNN-040-AA-F0-B2-00	SERIES 51	S51-080MV
83004990	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-L2-B1-V-A-J2-AHA-084-AA-F3-B2-00	SERIES 51	S51-250MV
83004991	PUMP-VAR-DISPL CCW H1PV115	H1-P-115-L-B-A5-C2-N-D6-G-G2-H6-L-35-L-35-A-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83004992	PUMP-VAR-DISPL CW 90PV130	90R130-MA-5-BC-80-L-4-C8-F-C7-GBA-35-35-24	SERIES 90	S90-130PV
83004998	PUMP-VAR DISPL, CW 90PV075	90-R-075-KT-1-NN-80-R-3-S1-D-00-GBA-35-35-24	SERIES 90	S90-075PV
83005001	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HS-1-NN-80-R-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83005002	PUMP-VAR-DISPL CCW H1PV115	H1-P-115-L-B-A5-C2-N-D6-G-G2-H3-L-35-L-35-A-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83005003	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A5-C2-N-D6-H-G1-NN-L-35-L-35-C-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83005005	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-L1-B1-W-B-C0-NNN-050-AA-E6-D4-00	SERIES 51	S51-250MV
83005007	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-B8-C3-C-D3-H-F1-H2-L-38-L-38-F-M-30-P1-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83005009	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-A1N3-02-C-2-A-2-F-N-T-34-34-B-A-A-NNN-NNN	SERIES 42	S42-041PV/051PV
83005012	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HS-1-CD-80-R-3-C7-E-03-GBA-32-32-24	SERIES 90	S90-075PV
83005016	MOTOR-FIX DISPL MMF035D	MMF-035-D-A-S-G-C-G-NNN-***	M35/44	035MF
83005020	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-L1-B1-W-B-G5-NNN-048-AA-F3-D4-00	SERIES 51	S51-160MV
83005024	PUMP-VAR-DISPL CW 90PV042	90R042-FA-1-AB-80-S-7-C3-C-B1-EEG-36-36-26	SERIES 90	S90-042PV
83005025	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A5-C2-B-D6-F-G4-NN-L-35-L-35-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83005026	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A3-C2-N-D9-G-G2-H4-L-45-L-45-L-L-30-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83005027	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A3-C2-N-D6-G-G3-H6-L-45-L-45-L-L-30-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83005030	MOTOR-VAR-DISPL H1B080	H1-B-080-A-M1-CA-N-A-RA-DS-JS-S-A-15-NN-000-N-00-NNN	H1-HP MOTORS	H1-080MB1
83005031	MOTOR-VAR-DISPL 51MD110-1	51D110-1--R-D4-N-TA-C2-N-N-X1-NNN-022-AA-F0-00-25	SERIES 51	S51-110MV-1
83005033	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-8-N-0-C6-W-00-EFT-00-00-F0	SERIES 90	S90-075MF
83005034	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-CD-80-R-C-C8-H-05-HCA-35-35-20	SERIES 90	S90-180PV
83005036	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-1-NN-80-D-4-S1-L-05-FAD-35-35-20	SERIES 90	S90-055PV
83005037	MOTOR-VAR-DISPL H1B060#	H1-B-060-A-P1-D1-N-A-TA-DN-GN-N-A-20-NN-000-Z-24-NNN	H1-HP MOTORS	H1-060MB1
83005038	PUMP-VAR-DISPL CCW 90PV250	90L250-HS-5-CD-80-S-4-C8-L-03-NNN-32-32-30	SERIES 90	S90-250PV
83005045	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-BC-60-R-4-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83005046	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-NN-60-R-4-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83005047	MOTOR-VAR-DISPL 51MC060	51C060-R-D1-N-L2-B1-V-A-C0-ACB-020-AA-E4-B2-00	SERIES 51	S51-060MV

83005048	PUMP-VAR DISPL MPV044D	MPV-044-D-B-A-A-R-S-G-AA-A-A-BJJ-DL-A-FF-C-NNN-***	M35/44	044PV
83005051	MOTOR-VAR-DISPL 51MD080-1	51D080-1--A-D2-N-P7-P7-N-N-X1-ADA-030-AA-F3-00-AA	SERIES 51	S51-080MV-1
83005052	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-N-HS-A2-C-H-E1-NNN-125-AA-G0-15-37	SERIES 51	S51-250MV
83005064	PUMP-VAR-DISPL CW 90PV100	90R100-KA-2-BC-60-S-3-C6-E-02-GBA-42-42-24	SERIES 90	S90-100PV
83005067	PUMP-VAR-DISPL CW 90PV180	90R180-HF-5-BC-80-T-M-C8-H-03-NNN-24-24-24	SERIES 90	S90-180PV
83005070	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A9-C2-N-D6-G-G3-NN-L-40-L-40-L-L-28-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83005075	PUMP-VAR-DISPL CW 90PV180	90R180-KN-5-BC-80-T-M-F1-H-03-EEB-14-14-24	SERIES 90	S90-180PV
83005077	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A3-C2-N-D3-G-G3-H3-L-40-L-40-L-M-30-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83005079	PUMP-VAR DISPL, CW 90PV055	90-R-055-HS-5-NN-80-S-1-S1-C-03-GBA-38-38-20	SERIES 90	S90-055PV
83005087	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-NN-80-L-3-C8-H-03-GBA-23-23-24	SERIES 90	S90-130PV
83005088	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-NN-80-L-3-C8-H-03-GBA-23-23-24	SERIES 90	S90-130PV
83005092	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-AB-80-S-3-F1-E-03-GBA-29-29-24	SERIES 90	S90-100PV
83005096	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-1-CD-80-R-4-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83005097	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-BB-80-R-4-F1-E-03-GBA-42-14-24	SERIES 90	S90-100PV
83005098	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-CD-80-L-4-S1-E-03-GBA-20-20-24	SERIES 90	S90-100PV
83005101	MOTOR-VAR-DISPL 51MV110	51V110-A-F1-N-HS-A2-C-E-G6-NNN-044-AA-E6-18-37	SERIES 51	S51-110MV
83005105	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HF-1-BC-60-R-3-S1-C-03-GBA-32-32-24	SERIES 90	S90-055PV
83005106	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HF-1-BC-60-R-3-S1-D-03-GBA-32-32-24	SERIES 90	S90-075PV
83005107	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KN-1-BC-60-R-3-S1-D-03-GBA-32-32-24	SERIES 90	S90-075PV
83005108	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KN-1-BC-60-R-3-F1-E-03-GBA-32-32-24	SERIES 90	S90-100PV
83005116	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MA-1-NN-80-L-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83005124	PUMP-VAR-DISPL 42PV041 CW	42-R-51-E-ANNB-02-A-N-N-N-F-N-V-C0-C0-N-A-A-NNN-ENN	SERIES 42	S42-041PV/051PV
83005125	PUMP-VAR-DISPL 42PV041 CW	42-R-51-D-ANNB-02-A-N-N-N-F-N-B-C0-C0-N-A-A-NNN-ENN	SERIES 42	S42-041PV/051PV
83005133	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-V-T-B-J-BA-A-A-BJJ-DA-A-ZA-C-NNN-***	M46	M46-046PV
83005134	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A4-C1-B-D3-G-G2-H6-L-28-L-28-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83005135	PUMP-VAR-DISPL CCW 90PV130	90L130-HF-5-BC-80-R-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-130PV
83005136	PUMP-VAR-DISPL CCW 90PV130	90L130-KN-5-BC-80-R-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-130PV
83005137	PUMP-VAR-DISPL CCW 90PV180	90L180-KN-5-NN-80-T-C-F1-J-03-FAC-38-38-24	SERIES 90	S90-180PV
83005138	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-8-N-0-C6-W-00-EEA-00-00-F3	SERIES 90	S90-075MF
83005139	MOTOR-VAR-DISPL 51MV060	51V060-R-C6-N-HZ-B1-B-H-C2-NNN-036-AA-NN-10-00	SERIES 51	S51-060MV
83005142	MOTOR-VAR-DISPL 51MC080	51C080-R-D2-N-HZ-B1-A-E-G0-NNN-035-AA-F0-03-00	SERIES 51	S51-080MV
83005143	MOTOR-VARIABLE DISPL SAE_L	L-V-25CN-A-RNF-F45-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83005145	PUMP-TANDEM, VAR DISPL CCW H1T053L	H1-T-053-L-A-N-A5-C2-N-E7-F-G1-H2-30-30-30-30-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83005147	MOTOR-VAR-DISPL 51MV080-1	51V080-1--A-S1-N-T2-C2-N-N-X1-NNN-024-AA-F0-00-20	SERIES 51	S51-080MV-1
83005149	PUMP-VAR-DISPL CW 90PV075	90R075-CA-5-BC-80-P-7-C7-D-00-FAC-42-42-24	SERIES 90	S90-075PV
83005150	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-5-BC-80-L-3-S1-D-03-GBA-26-26-24	SERIES 90	S90-075PV

83005152	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-NN-80-P-4-C7-D-03-GBA-32-32-24	SERIES 90	S90-100PV
83005153	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-BC-80-P-4-S1-D-03-GBA-32-32-24	SERIES 90	S90-075PV
83005155	PUMP-VAR DISPL, CW 90PV075	90-R-075-HF-1-NN-60-P-3-S1-E-03-EBC-32-32-24	SERIES 90	S90-075PV
83005156	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-1-AB-60-S-3-C6-C-03-GBA-35-35-20	SERIES 90	S90-055PV
83005158	PUMP-VAR-DISPL CW 90PV180	90R180-KP-5-BC-80-T-C-F1-J-03-FAC-35-35-24	SERIES 90	S90-180PV
83005159	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-HS-A4-C-H-C5-NNN-050-AA-NN-25-24	SERIES 51	S51-250MV
83005160	MOTOR-VAR-DISPL 51MD080-1	51D080-1--R-D2-N-TA-D2-N-N-X1-NNN-016-AA-F3-00-20	SERIES 51	S51-080MV-1
83005161	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-EG-80-S-M-C8-J-03-EFI-42-42-24	SERIES 90	S90-180PV
83005163	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-NN-80-R-3-S1-E-03-GBA-32-32-24	SERIES 90	S90-100PV
83005168	MOTOR-VAR-DISPL 51MD110-1	51D110-1--R-D3-N-T1-CA-N-N-X1-NNN-042-AA-F3-00-20	SERIES 51	S51-110MV-1
83005169	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HS-1-CD-80-R-3-C7-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83005170	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-5-AD-80-R-4-S1-C-02-GBA-42-42-24	SERIES 90	S90-055PV
83005171	MOTOR-VARIABLE DISPL SAE_L	L-V-35EN-A-RNF-F00-S-N-N-AF-F15-NNN-NNN	LV / KV MOTORS	L/K-MV
83005172	MOTOR-VAR-DISPL 51MC060-1	51C060-1--A-D1-N-E1-B1-N-N-U1-NNN-020-AA-E4-00-00	SERIES 51	S51-060MV-1
83005174	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-5-CD-80-S-3-S1-D-03-GBA-45-45-24	SERIES 90	S90-075PV
83005175	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-5-NN-80-S-3-S1-D-03-GBA-45-45-24	SERIES 90	S90-075PV
83005176	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-5-BB-80-S-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83005177	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A2-C2-N-D3-H-G1-NN-L-20-L-20-F-M-20-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83005180	PUMP-VAR DISPL, CW 90PV055	90-R-055-KN-1-BG-80-S-4-S1-C-03-GBA-29-29-24	SERIES 90	S90-055PV
83005181	PUMP-VAR DISPL, CCW 90PV055	90-L-055-CA-1-NN-80-S-4-S1-C-00-GBA-42-42-24	SERIES 90	S90-055PV
83005182	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-T2-C0-L-N-G0-NNN-070-AA-F3-00-B5	SERIES 51	S51-250MV
83005184	MOTOR-VARIABLE DISPL SAE_K	K-V-38CN-E-RNF-F10-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83005185	MOTOR-VARIABLE DISPL SAE_L	L-V-30DN-E-RNF-F08-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83005186	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-CD-80-L-3-F1-H-03-GBA-32-32-24	SERIES 90	S90-130PV
83005187	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-BC-80-L-3-F1-H-03-GBA-32-32-24	SERIES 90	S90-130PV
83005188	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-HZ-B1-A-N-G0-NNN-168-AA-NN-03-00	SERIES 51	S51-250MV
83005189	PUMP-VAR-DISPL CW 90PV250	90R250-HF-2-CD-80-T-3-C8-K-00-NNN-32-32-24	SERIES 90	S90-250PV
83005190	PUMP-VAR-DISPL CW 90PV250	90R250-KP-2-CD-80-T-3-C8-K-00-NNN-32-32-24	SERIES 90	S90-250PV
83005191	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D2-N-N1-NN-N-N-U1-ACB-030-AA-E6-00-00	SERIES 51	S51-080MV-1
83005194	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-AB-80-S-3-C8-F-03-GBA-38-38-30	SERIES 90	S90-130PV
83005196	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A5-C2-N-E7-F-G5-H3-25-25-25-25-N-P-30-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83005197	PUMP-VAR DISPL, CW 90PV055	90-R-055-CA-1-BC-60-S-7-S1-D-00-GLA-35-35-24	SERIES 90	S90-055PV
83005198	PUMP-VAR-DISPL CW 90PV130	90R130-HF-5-BC-80-R-4-F1-F-03-GBA-35-35-24	SERIES 90	S90-130PV
83005210	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-BB-60-S-3-S1-D-D3-EAB-42-42-24	SERIES 90	S90-055PV
83005212	PUMP-VAR-DISPL CW 90PV130	90R130-MA-5-DE-80-S-4-C8-F-C5-GBA-42-42-24	SERIES 90	S90-130PV
83005213	PUMP-VAR-DISPL CW 90PV130	90R130-MA-5-BC-80-S-4-F1-F-C5-GBA-42-42-24	SERIES 90	S90-130PV

83005214	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-NN-80-P-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83005215	PUMP- VARIABLE, DIRECT DISPLACEMENT	LPV-A-A-A-A-A-G-AA-C-A-BDD-DR-A-FF-B-NNN-***	LPV	LPV
83005219	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-CD-80-S-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83005226	MOTOR-VARIABLE DISPL SAE_K	K-V-45DN-A-R1F-F11-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83005231	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-NU-60-L-3-C7-3-03-GBA-42-42-24	SERIES 90	S90-100PV
83005238	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HK-1-CD-80-S-4-S1-C-03-GBA-38-38-20	SERIES 90	S90-055PV
83005239	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-AB-60-P-3-C6-C-03-GBA-35-35-28	SERIES 90	S90-055PV
83005242	MOTOR-VAR-DISPL 51MV160	51V160-A-C8-N-DA-M4-R-J-N1-ACA-040-AA-F3-C2-24	SERIES 51	S51-160MV
83005244	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-NN-80-R-4-C8-F-03-GBA-42-42-24	SERIES 90	S90-130PV
83005245	MOTOR-VAR-DISPL 51MD160	51D160-A-D4-N-L7-B1-W-B-M3-ABA-032-BB-H0-D4-00	SERIES 51	S51-160MV
83005247	PUMP-VAR DISPL, CW 90PV075	90-R-075-KN-1-BC-80-R-3-S1-E-03-GBA-29-29-24	SERIES 90	S90-075PV
83005252	PUMP-VAR-DISPL CW 90PV075	90R075-KA-2-BB-60-S-3-C6-D-02-GBA-42-42-24	SERIES 90	S90-075PV
83005253	PUMP-VAR-DISPL CCW 90PV075	90L075-KN-1-BC-60-R-3-C7-E-03-GBA-32-14-32	SERIES 90	S90-075PV
83005254	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-TA-C2-L-N-G0-ACA-115-AA-G3-00-B4	SERIES 51	S51-160MV
83005257	PUMP-VAR-DISPL CCW H1PV115	H1-P-115-L-A-A3-C2-N-D8-G-G2-H6-L-25-L-25-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83005261	PUMP-TANDEM, VAR DISPL CCW H1T045L	H1-T-045-L-A-N-A2-C2-N-D1-F-G5-H2-40-40-40-40-N-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83005262	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A9-C2-N-D8-F-G1-NN-L-35-L-35-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83005266	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-CD-60-R-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
83005267	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-NN-60-R-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
83005269	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A4-C2-B-F3-F-G5-H5-J-40-J-40-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83005271	MOTOR-VAR-DISPL 51MC110-1	51C110-1--R-D3-N-N1-NN-N-N-U1-NNN-037-AA-F0-00-00	SERIES 51	S51-110MV-1
83005289	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A3-C1-N-F5-H-G1-H6-L-23-L-23-C-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83005290	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-5-BC-80-D-3-C8-L-03-NNN-35-35-24	SERIES 90	S90-250PV
83005292	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-5-BB-80-S-3-S1-D-03-GBA-35-35-34	SERIES 90	S90-075PV
83005293	PUMP-VAR DISPL, CCW 90PV055	90-L-055-CB-1-NN-80-R-3-S1-C-00-GBA-38-38-24	SERIES 90	S90-055PV
83005300	MOTOR-VAR-DISPL 51MD160	51D160-A-D4-N-T1-C0-L-N-G0-NNN-038-AA-G0-00-B7	SERIES 51	S51-160MV
83005301	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-AB-80-P-3-C3-B-03-GBA-30-30-24	SERIES 90	S90-042PV
83005302	MOTOR-VAR-DISPL 51MV080	51V080-A-C7-N-D8-M1-R-J-M1-ACA-032-AA-F3-C2-20	SERIES 51	S51-080MV
83005303	MOTOR-VAR-DISPL 51MV250	51V250-A-C8-N-L2-B1-V-A-C0-ANB-168-AA-G0-B2-00	SERIES 51	S51-250MV
83005304	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-5-CD-80-S-3-C8-K-02-NNN-32-32-24	SERIES 90	S90-250PV
83005306	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-E2-A5-A-N-K7-AHA-032-AA-NN-03-00	SERIES 51	S51-160MV
83005308	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A4-C2-N-E5-F-G5-H3-L-23-L-23-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83005309	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D3-N-E2-B1-N-N-U1-ABA-027-AA-E6-00-00	SERIES 51	S51-080MV-1
83005310	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-E2-A5-A-N-K7-NNN-032-AA-NN-03-00	SERIES 51	S51-160MV
83005319	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-N-L7-B1-W-B-M3-ABA-050-BB-H0-D4-00	SERIES 51	S51-250MV
83005322	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-E1A5-03-C-2-A-2-F-N-A-23-23-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV

83005332	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HF-1-CD-80-R-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-075PV
83005333	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HF-1-NN-80-R-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83005334	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MB-1-CD-80-P-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83005336	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-NN-60-S-3-C7-D-03-FAX-45-45-24	SERIES 90	S90-075PV
83005337	MOTOR-VAR-DISPL H1B080#	H1-B-080-A-E2-AA-N-B-TB-VN-AN-N-A-10-NN-035-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83005342	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HS-1-BC-60-R-4-S1-E-03-GBA-26-26-24	SERIES 90	S90-075PV
83005343	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-AB-60-R-3-F1-E-03-GBA-35-35-28	SERIES 90	S90-100PV
83005344	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-D8-M1-R-J-N1-ACB-130-AA-NN-C2-24	SERIES 51	S51-250MV
83005345	PUMP-VAR-DISPL CW 90PV250	90R250-MA-5-NN-80-T-4-C8-K-C5-NNN-35-35-24	SERIES 90	S90-250PV
83005346	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-CD-80-P-3-C8-H-03-GBA-32-35-24	SERIES 90	S90-130PV
83005350	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A3-C2-N-E5-F-G4-NN-L-23-L-23-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83005351	PUMP-VAR-DISPL 42PV041 CW	42-R-41-C-E1A5-03-B-D-G-3-H-N-B-25-25-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83005352	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HS-1-BC-60-R-4-S1-D-03-GBA-26-26-24	SERIES 90	S90-055PV
83005353	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-F6NN-50-U-D-X-A-G-N-Z-32-32-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83005354	PUMP-VAR-DISPL CCW H1PV147	H1-P-147-L-C-A5-C2-N-D8-G-G2-H3-L-42-L-42-A-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83005358	MOTOR-VAR-DISPL 51MV060	51V060-A-C6-N-HZ-B1-B-H-C2-NNN-036-AA-NN-10-00	SERIES 51	S51-060MV
83005362	PUMP-VAR-DISPL 42PV041 CW	42-R-41-E-E1A3-03-A-N-A-2-G-N-B-25-25-B-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83005363	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A3-C1-N-D8-H-G1-NN-L-23-L-23-C-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83005365	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-1-NN-80-L-4-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
83005366	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-1-NN-80-L-4-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
83005372	PUMP-VAR DISPL, CCW 90PV055	90-L-055-MA-1-NN-61-R-3-T1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83005373	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HS-1-BC-60-R-4-S1-D-03-GBA-26-26-24	SERIES 90	S90-055PV
83005374	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HS-1-BC-60-R-4-S1-E-03-GBA-26-26-24	SERIES 90	S90-075PV
83005382	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-BB-60-S-3-S1-D-D3-FAC-42-42-24	SERIES 90	S90-055PV
83005383	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-T2-C0-L-N-G0-ABA-115-AA-G0-00-B9	SERIES 51	S51-250MV
83005384	PUMP-VAR-DISPL 42PV041 CCW	42-L-41-D-ANA3-03-B-3-B-3-F-N-V-28-28-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83005385	PUMP-VAR-DISPL CW 90PV130	90R130-KN-5-AB-80-P-3-C8-H-03-GBA-42-42-20	SERIES 90	S90-130PV
83005387	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-CD-60-S-4-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83005388	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-BC-60-S-4-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83005389	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-AB-60-S-4-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
83005398	PUMP-VAR DISPL, CCW 90PV055	90-L-055-MA-1-BG-80-S-3-C6-D-03-GBA-26-26-24	SERIES 90	S90-055PV
83005399	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-1-NN-80-R-3-S1-C-03-GBA-17-17-24	SERIES 90	S90-055PV
83005400	MOTOR-VAR-DISPL 51MD080-1	51D080-1--R-D3-N-E2-B1-N-N-U1-NNN-032-AA-NN-00-00	SERIES 51	S51-080MV-1
83005404	MOTOR-VAR-DISPL 51MC110-1	51C110-1--R-D3-N-T2-N5-N-N-X1-ACG-055-AA-F3-00-35	SERIES 51	S51-110MV-1
83005405	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-BC-60-R-3-S1-B-03-GBA-38-38-24	SERIES 90	S90-055PV
83005406	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A5-C2-N-E5-F-G1-NN-L-33-L-33-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV

83005407	MOTOR-VAR DISPL MMV046C	MMV-046-C-B-M-M-C-AD-NNN-***	M46	M46-046MV
83005408	MOTOR-VAR DISPL MMV046C	MMV-046-C-B-M-N-C-AD-NNN-***	M46	M46-046MV
83005409	MOTOR-VAR DISPL MMV046C	MMV-046-C-A-E-D-C-AV-VNB-***	M46	M46-046MV
83005410	MOTOR-VAR DISPL MMV046C	MMV-046-C-A-E-D-C-A8-VNB-***	M46	M46-046MV
83005413	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-NN-61-R-3-F1-F-00-GBA-40-35-20	SERIES 90	S90-100PV
83005415	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-BB-60-S-3-C7-D-03-GBA-42-42-24	SERIES 90	S90-075PV
83005423	PUMP-VAR-DISPL 42PV041 CW	42-R-51-D-ANN3-03-D-N-F-2-H-N-A-30-30-B-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83005424	PUMP-VAR-DISPL CCW 90PV180	90L180-HS-5-DE-80-S-M-C8-L-03-NNN-42-16-34	SERIES 90	S90-180PV
83005440	PUMP-VAR-DISPL CW 90PV250	90R250-KP-5-CD-80-T-3-C8-K-03-NNN-35-35-24	SERIES 90	S90-250PV
83005441	MOTOR-VAR-DISPL 51MV060-1	51V060-1--A-S1-N-E2-B1-N-N-U1-ACB-020-AA-E4-00-00	SERIES 51	S51-060MV-1
83005442	PUMP-VAR-DISPL CCW 90PV180	90L180-HF-5-AB-80-T-C-C8-H-03-FAC-35-35-24	SERIES 90	S90-180PV
83005449	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-NN-80-R-4-F1-F-03-GBA-38-38-24	SERIES 90	S90-130PV
83005454	PUMP-TANDEM, VAR DISPL MPT044D	MPT-044-D-V-R-A-R-NN-H-A-A-A-BEE-DA-A-FF-H-C-A-A-BEE-DB-A-FF-A-NGE-*	M35/44	044PT
83005458	PUMP-TANDEM, VAR DISPL MPT044D	MPT-044-D-A-W-A-Z-NN-B-A-A-A-BHH-DL-A-FF-B-C-A-A-BHH-DL-A-FF-Z-NNN-*	M35/44	044PT
83005462	PUMP-VAR-DISPL CCW 90PV130	90L130-KE-4-DF-8W-8-3-J5-R-33-GBW-42-42-JD	SERIES 90	S90-130PV
83005466	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-2-CD-80-D-4-S1-L-03-GFD-38-38-34-F070	SERIES 90	S90-075PV
83005467	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-2-BC-80-D-4-S1-L-03-GFD-38-38-34-F070	SERIES 90	S90-075PV
83005468	MOTOR-VARIABLE DISPL SAE_K	K-V-45DS-E-R1F-F07-S-N-N-BF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83005469	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-BC-80-L-4-F1-H-03-GBA-32-32-20	SERIES 90	S90-130PV
83005470	PUMP-VAR-DISPL CW 90PV130	90R130-MA-5-AB-80-S-4-C8-H-C5-GBA-23-23-24	SERIES 90	S90-130PV
83005471	PUMP-VAR-DISPL 42PV041 CW	42-R-41-C-E1A5-02-B-D-B-2-H-N-N-23-23-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83005472	MOTOR-VAR-DISPL 51MV060-1	51V060-1--A-S1-N-E2-B1-N-N-U1-NNN-020-AA-E4-00-00	SERIES 51	S51-060MV-1
83005473	MOTOR-VAR DISPL MMV046C	MMV-046-C-A-E-F-A-AE-VNB-***	M46	M46-046MV
83005474	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A2-C2-N-D8-H-G9-H5-L-42-L-42-N-E-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83005475	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-CD-80-T-C-F1-J-03-NNN-30-30-24	SERIES 90	S90-180PV
83005477	PUMP-VAR DISPL, CCW 90PV055	90-L-055-CA-5-NN-80-P-7-S1-D-00-GBA-40-40-28	SERIES 90	S90-055PV
83005478	PUMP-VAR DISPL, CCW 90PV055	90-L-055-FD-5-CD-80-P-7-C6-D-B1-GBA-40-40-28	SERIES 90	S90-055PV
83005482	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D2-N-E2-B1-N-N-U1-NNN-050-AA-G0-00-00	SERIES 51	S51-080MV-1
83005484	MOTOR-VAR DISPL MMV046C	MMV-046-C-A-A-L-A-AX-NNN-***	M46	M46-046MV
83005486	PUMP-VAR DISPL MPV046C	MPV-046-C-B-A-A-T-B-B-BA-V-A-BFF-AB-D-AA-C-NNN-***	M46	M46-046PV
83005487	PUMP-TANDEM, VAR DISPL MPT044D	MPT-044-D-A-W-A-Z-NN-B-A-A-A-BRR-DL-A-FF-B-C-A-A-BRR-DL-A-FF-Z-NNN-*	M35/44	044PT
83005489	PUMP-TANDEM, VAR DISPL MPT044D	MPT-044-D-G-W-A-Z-NN-B-A-A-A-BHH-DL-A-FF-B-C-A-A-BHH-DL-A-FF-Z-NNN-*	M35/44	044PT
83005491	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A5-C2-N-E5-F-G1-H3-L-33-L-33-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83005495	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-CD-80-T-M-C8-J-03-EBA-42-42-24	SERIES 90	S90-180PV
83005496	MOTOR-VAR-DISPL 51MC160	51C160-R-D5-N-T2-C0-L-N-G0-NNN-040-AA-F3-00-C0	SERIES 51	S51-160MV
83005497	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-T2-C0-L-N-G0-ADA-040-AA-F3-00-C0	SERIES 51	S51-160MV

83005498	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-NN-80-S-M-C8-J-03-NNN-26-26-24	SERIES 90	S90-180PV
83005500	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-BG-80-P-3-S1-C-03-GBA-42-42-28	SERIES 90	S90-055PV
83005501	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-NN-80-P-3-S1-E-02-GBA-42-42-24	SERIES 90	S90-100PV
83005503	MOTOR-FIX DISPL MMF044D	MMF-044-D-A-S-H-C-G-NNN-***	M35/44	044MF
83005505	PUMP-VAR-DISPL CCW 90PV180	90L180-HS-5-CD-80-S-M-C8-L-03-NNN-42-16-34	SERIES 90	S90-180PV
83005506	PUMP-VAR-DISPL CCW 90PV180	90L180-HS-5-EG-80-S-M-C8-L-03-NNN-42-16-34	SERIES 90	S90-180PV
83005511	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-K-S-A-J-BC-4-A-BFF-DA-A-TT-B-NNN-***	M46	M46-046PV
83005515	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-CD-80-S-4-S1-D-02-GBA-29-29-24	SERIES 90	S90-075PV
83005516	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A9-C1-B-E9-F-G5-NN-K-35-K-35-B-P-32-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83005518	MOTOR-VAR-DISPL H1B110#	H1-B-110-A-E2-AA-N-B-TB-DN-JN-N-A-10-NN-050-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83005519	PUMP-VAR-DISPL CW 90PV250	90R250-HF-5-NN-80-T-4-C8-K-03-NNN-14-14-20	SERIES 90	S90-250PV
83005520	MOTOR-VAR-DISPL H1B110#	H1-B-110-A-E2-AA-N-B-TB-DN-JN-N-A-10-NN-040-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83005523	PUMP-TANDEM, VAR DISPL MPT035D	MPT-035-D-G-W-R-C-BA-B-A-A-A-BFF-DR-A-FF-B-C-A-A-BFF-DL-A-FF-B-NNN-***	M35/44	035PT
83005527	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-2-CD-80-D-4-C6-L-03-GFD-38-38-34-F070	SERIES 90	S90-075PV
83005528	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-A-T-B-B-AA-V-A-BHH-DB-A-HH-C-NNN-***	M46	M46-046PV
83005529	MOTOR-VAR-DISPL 51MV060-1	51V060-1--A-C6-N-T7-C2-N-N-X1-NNN-017-AA-NN-00-30	SERIES 51	S51-060MV-1
83005531	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KK-6-CD-82-U-3-S1-E-64-FBA-48-48-24-N315	SERIES 90	S90-100PV
83005533	PUMP-VAR-DISPL CW 90PV100	90R100-HS-1-CD-80-R-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
83005539	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-N-HZ-B1-A-N-G0-NNN-088-AA-NN-03-00	SERIES 51	S51-160MV
83005546	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-AB-60-S-3-S1-C-03-GBA-45-45-24	SERIES 90	S90-075PV
83005548	MOTOR-FIX DISPL MMF044D	MMF-044-D-A-F-W-C-D-NNN-***	M35/44	044MF
83005562	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A8-C2-C-D8-H-G9-H3-L-40-L-40-C-P-24-P1-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83005563	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A5-C2-N-D8-J-G5-H2-L-33-L-33-B-P-26-P4-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83005575	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-2-NN-60-S-4-F1-E-02-GBA-42-42-24	SERIES 90	S90-100PV
83005578	PUMP-VAR DISPL, CW 90PV100	90-R-100-HF-1-BC-80-S-4-F1-E-03-GBA-17-17-20	SERIES 90	S90-100PV
83005584	PUMP-VAR DISPL, CCW 90PV100	90-L-100-CB-1-NN-80-S-3-K3-E-00-GBA-35-35-24	SERIES 90	S90-100PV
83005585	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-NN-80-S-3-K3-E-04-GBA-35-35-24	SERIES 90	S90-100PV
83005586	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-1-BG-80-S-3-K1-C-04-GBA-35-35-24	SERIES 90	S90-055PV
83005587	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-1-BK-80-S-3-K1-C-06-GBA-35-35-24	SERIES 90	S90-055PV
83005602	MOTOR-VAR-DISPL 51MV160	51V160-R-F2-N-HZ-B1-B-H-C2-NNN-080-AA-NN-10-00	SERIES 51	S51-160MV
83005606	MOTOR-VAR-DISPL 51MV250	51V250-A-C8-N-JS-NN-B-E-P2-ADA-085-AA-G0-10-28	SERIES 51	S51-250MV
83005607	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-BB-80-S-3-C5-C-03-GBA-30-30-24	SERIES 90	S90-042PV
83005608	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-HZ-B1-A-N-C2-NNN-050-AA-F3-05-00	SERIES 51	S51-080MV
83005612	PUMP-VAR DISPL, CW 90PV100	90-R-100-HS-1-CD-60-P-4-S1-E-03-GBA-38-38-24	SERIES 90	S90-100PV
83005613	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MA-1-NN-60-S-3-S1-E-03-GBA-17-17-24	SERIES 90	S90-100PV
83005614	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A2-C1-N-D8-F-G1-H5-L-35-L-35-N-P-26-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV

83005617	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A9-C2-N-D8-F-G5-NN-L-35-L-35-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83005620	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A5-C2-B-D3-G-G2-H2-L-38-L-38-A-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83005623	PUMP-VAR-DISPL CCW H1PV115	H1-P-115-L-B-A3-C2-N-D8-G-G3-H6-L-25-L-25-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83005626	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-BC-80-T-C-C8-J-03-NNN-42-42-24	SERIES 90	S90-180PV
83005635	PUMP- VARIABLE, DIRECT DISPLACEMENT	LPV-A-A-A-C-A-G-DA-D-A-BFF-DR-A-FF-B-NNN-***	LPV	LPV
83005639	MOTOR-VAR-DISPL 51MV160	51V160-A-C8-N-D8-M1-R-J-M4-ACA-045-AA-G0-C2-20	SERIES 51	S51-160MV
83005651	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-BC-80-T-M-F1-J-03-EBA-42-42-24	SERIES 90	S90-180PV
83005652	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A4-C2-N-D8-J-G5-NN-L-25-L-25-B-P-24-P4-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83005653	MOTOR-VAR-DISPL 51MV110	51V110-A-F1-N-HS-A2-C-E-G6-NNN-033-AA-E6-18-24	SERIES 51	S51-110MV
83005657	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A9-C2-N-D8-H-G1-H2-K-40-K-40-F-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83005662	MOTOR-VAR-DISPL 51MV250	51V250-A-C8-N-JS-NN-B-E-P2-ADA-050-AA-G3-10-28	SERIES 51	S51-250MV
83005672	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-C-ANNB-03-C-3-A-2-F-N-B-34-34-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83005684	MOTOR-VAR DISPL MMV046C	MMV-046-C-A-E-A-B-AV-VNC-***	M46	M46-046MV
83005686	PUMP-VAR-DISPL CW 90PV180	90R180-PB-5-EG-80-S-C-C8-H-05-NNN-45-45-28	SERIES 90	S90-180PV
83005687	PUMP-VAR-DISPL CW 90PV180	90R180-PB-5-CD-80-S-C-C8-H-05-NNN-45-45-28	SERIES 90	S90-180PV
83005693	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-BC-80-L-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
83005694	PUMP-VAR DISPL, CW 90PV055	90-R-055-HS-1-BC-60-R-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
83005699	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-NN-80-R-3-F1-H-03-EBA-42-42-24	SERIES 90	S90-130PV
83005700	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-AB-60-P-3-TG-D-29-FAB-42-42-20	SERIES 90	S90-100PV
83005701	PUMP-VAR-DISPL CCW 90PV100	90L100-MH-1-AB-60-P-3-TG-D-03-FAB-42-42-20	SERIES 90	S90-100PV
83005721	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-CD-80-D-4-F1-L-03-GBA-29-14-34	SERIES 90	S90-100PV
83005722	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-NN-80-D-4-S1-L-03-GBA-29-14-34	SERIES 90	S90-100PV
83005723	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-NN-80-D-4-C7-L-03-GBA-29-14-34	SERIES 90	S90-100PV
83005724	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-NN-80-D-4-C7-L-03-GBA-29-29-34	SERIES 90	S90-100PV
83005725	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-NN-80-D-4-C8-L-03-GBA-29-14-34	SERIES 90	S90-130PV
83005726	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-NN-80-D-4-C8-L-03-GBA-29-29-34	SERIES 90	S90-130PV
83005728	PUMP-VAR-DISPL CW 90PV075	90R075-KA-1-BB-60-S-4-S1-D-09-GBA-35-35-24	SERIES 90	S90-075PV
83005729	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-B-V-C-B-AA-B-A-G-A-BFF-GG-B-FF-B-C-G-A-BFF-GG-B-FF-B-NNN-**	M46	M46-046PT
83005735	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-CD-80-S-C-C8-J-09-FAC-35-35-28	SERIES 90	S90-180PV
83005736	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-E2-A2-A-N-E1-ABA-109-AA-G0-03-25	SERIES 51	S51-250MV
83005737	MOTOR-VAR-DISPL 51MC110	51C110-R-D3-N-HZ-B1-A-N-G0-NNN-037-AA-F0-03-00	SERIES 51	S51-110MV
83005738	MOTOR-VAR-DISPL H1B080	H1-B-080-A-E2-AA-N-A-TB-CS-JS-S-A-10-NN-017-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83005743	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-AB-60-R-3-C7-E-00-GBA-36-36-24	SERIES 90	S90-075PV
83005744	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A3-C2-N-D3-H-F1-NN-L-35-L-35-C-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83005746	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A4-C2-N-D1-F-G6-H3-35-35-35-35-N-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83005747	MOTOR-VAR DISPL MMV046C	MMV-046-C-B-M-5-C-AD-NNN-***	M46	M46-046MV

83005748	MOTOR-VAR DISPL MMV046C	MMV-046-C-A-E-6-C-AV-VNB-***	M46	M46-046MV
83005749	MOTOR-VAR DISPL MMV046C	MMV-046-C-A-E-6-C-A8-VNB-***	M46	M46-046MV
83005753	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-D8-M1-R-J-N1-NNN-140-AA-NN-C2-24	SERIES 51	S51-250MV
83005754	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-CD-80-P-3-S1-E-00-GBA-17-17-20	SERIES 90	S90-100PV
83005755	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-CD-80-P-3-S1-E-00-GBA-17-17-20	SERIES 90	S90-100PV
83005760	MOTOR-VAR-DISPL 51MV060-1	51V060-1--R-S1-N-TA-D7-N-N-X1-ABA-014-AA-E6-00-28	SERIES 51	S51-060MV-1
83005764	PUMP-VAR-DISPL CW 90PV250	90R250-KP-5-EG-80-S-3-C8-J-03-NNN-32-32-24	SERIES 90	S90-250PV
83005765	PUMP-VAR-DISPL CW 90PV250	90R250-KP-5-DE-80-S-3-C8-J-03-NNN-32-32-24	SERIES 90	S90-250PV
83005766	MOTOR-VAR-DISPL H1B060#	H1-B-060-A-T1-D1-N-A-TA-DN-GN-N-A-15-NN-000-Z-30-NNN	H1-HP MOTORS	H1-060MB1
83005770	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-CD-80-T-C-C8-J-03-NNN-42-42-24	SERIES 90	S90-180PV
83005771	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A8-C1-C-E9-F-G5-H2-K-35-K-35-B-P-24-P1-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83005775	MOTOR-VAR-DISPL H1B080	H1-B-080-A-P1-D1-N-A-TB-VS-AS-S-A-10-NN-016-Z-24-NNN	H1-HP MOTORS	H1-080MB1
83005784	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HS-1-NN-60-S-4-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83005786	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-CD-80-T-3-C8-K-03-NNN-35-35-28	SERIES 90	S90-250PV
83005787	MOTOR-VAR-DISPL 51MC160	51C160-R-D5-N-HZ-B1-B-H-C2-ANF-060-AA-F3-07-00	SERIES 51	S51-160MV
83005788	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-N-T2-C2-L-N-G0-ACA-080-AA-F0-00-B0	SERIES 51	S51-160MV
83005789	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-AB-80-L-4-C7-D-03-GBA-30-30-24	SERIES 90	S90-075PV
83005796	MOTOR-VAR-DISPL 51MC080	51C080-R-D3-N-L2-B1-V-A-G5-NNN-035-AA-E4-B2-00	SERIES 51	S51-080MV
83005797	MOTOR-VAR-DISPL 51MC080	51C080-R-D3-N-L2-B1-V-A-G5-ACA-035-AA-E4-B2-00	SERIES 51	S51-080MV
83005799	PUMP-VAR-DISPL CW 90PV075	90R075-SA-2-NN-80-S-3-S1-D-33-PGA-42-42-28	SERIES 90	S90-075PV
83005805	MOTOR-VAR-DISPL H1B080	H1-B-080-A-L2-BA-N-B-PB-DS-JS-S-A-05-NN-035-N-00-NNN	H1-HP MOTORS	H1-080MB1
83005806	MOTOR-VAR-DISPL H1B080	H1-B-080-A-L2-BA-N-B-PB-DN-JN-N-A-05-NN-035-N-00-NNN	H1-HP MOTORS	H1-080MB1
83005807	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-AB-60-P-3-S1-E-03-GBA-23-23-20	SERIES 90	S90-075PV
83005808	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-NN-80-R-3-S1-E-03-EBC-32-32-24	SERIES 90	S90-100PV
83005809	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-CD-80-R-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-075PV
83005810	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A2-C2-N-D8-F-G1-H2-L-35-L-33-B-P-28-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83005811	PUMP-VAR-DISPL CW 90PV100	90R100-SA-2-CD-80-S-3-C7-D-33-PGA-42-42-28	SERIES 90	S90-100PV
83005812	MOTOR-VAR-DISPL 51MD060-1	51D060-1--A-D1-N-E2-B1-N-N-U1-ADA-022-AA-F3-00-00	SERIES 51	S51-060MV-1
83005813	MOTOR-VAR-DISPL 51MC110-1	51C110-1--R-D3-N-TA-C2-N-N-X1-NNN-055-AA-F0-00-20	SERIES 51	S51-110MV-1
83005814	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-K-S-B-B-AA-A-A-BGG-BA-A-HH-B-NNN-***	M46	M46-046PV
83005822	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KK-1-CD-82-U-3-S1-F-64-FBA-35-35-24-N315	SERIES 90	S90-100PV
83005826	PUMP-VAR-DISPL CW 90PV130	90R130-HF-5-BB-80-L-4-F1-H-00-GBA-38-38-20	SERIES 90	S90-130PV
83005827	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-G3AN-52-T-N-D-3-E-5-A-21-21-B-0-0-NNN-NNN	SERIES 42	S42-028PV/032PV
83005828	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D3-N-E0-B1-N-N-U1-NNN-040-AA-F0-00-00	SERIES 51	S51-080MV-1
83005837	PUMP-VAR-DISPL CW 90PV075	90R075-MA-5-CD-60-S-3-C6-D-C5-FAX-35-35-24	SERIES 90	S90-075PV
83005838	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-EQ-A5-J-Y-A6-ADA-035-AA-F3-30-00	SERIES 51	S51-160MV

83005882	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-ANKB-01-A-N-A-2-F-N-V-32-32-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83005883	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-F7NN-50-U-D-G-2-F-N-A-32-32-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83005885	MOTOR-VAR-DISPL 51MV250	51V250-A-C8-N-L2-B1-V-A-C0-NNN-050-AA-NN-B2-00	SERIES 51	S51-250MV
83005888	PUMP-VAR-DISPL CCW 90PV075	90L075-CB-5-NN-60-S-3-C6-D-00-GBA-32-32-24	SERIES 90	S90-075PV
83005889	PUMP-VAR-DISPL CW 90PV075	90R075-HF-5-AB-80-P-4-C7-D-00-GBA-26-26-28	SERIES 90	S90-075PV
83005891	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-E1A6-02-B-5-B-2-C-N-N-17-17-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83005897	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KT-1-CD-60-D-3-C7-L-00-GBA-45-45-24	SERIES 90	S90-075PV
83005898	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-NN-60-D-3-S1-L-00-GBA-45-45-24	SERIES 90	S90-075PV
83005899	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HF-1-AB-80-R-4-F1-E-03-GBA-38-38-24	SERIES 90	S90-100PV
83005900	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-NN-80-R-4-S1-D-03-GBA-38-38-24	SERIES 90	S90-075PV
83005901	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A5-C2-N-D6-G-G3-NN-L-42-L-42-L-L-30-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83005903	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-2-CD-80-D-4-C6-L-00-GFD-38-38-34-F070	SERIES 90	S90-075PV
83005904	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-2-BC-80-D-4-S1-L-00-GFD-38-38-34-F070	SERIES 90	S90-075PV
83005905	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-L2-B1-V-A-G5-AWU-041-AA-F3-B2-00	SERIES 51	S51-160MV
83005908	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-2-CD-80-D-4-S1-L-00-GFD-38-38-34-F070	SERIES 90	S90-075PV
83005909	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-D7-M1-S-K-N2-NNN-021-AA-F3-F4-26	SERIES 51	S51-080MV
83005910	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-B-HZ-B2-A-N-H7-NNN-040-AA-G0-03-00	SERIES 51	S51-160MV
83005911	PUMP-VAR-DISPL CW 90PV130	90R130-MA-5-CD-80-R-4-F1-F-C5-GBA-35-35-24	SERIES 90	S90-130PV
83005912	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-T1-C2-N-N-X1-ANA-080-AA-F0-00-16	SERIES 51	S51-110MV-1
83005913	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-1-NN-80-R-4-T2-F-03-GBA-26-26-24	SERIES 90	S90-100PV
83005914	MOTOR-VAR-DISPL H1B080	H1-B-080-A-M1-CA-N-A-RB-VS-AS-S-A-10-NN-054-N-00-NNN	H1-HP MOTORS	H1-080MB1
83005916	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-BC-80-S-3-C7-F-03-GBA-38-38-24	SERIES 90	S90-100PV
83005917	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-S1-N-T2-CA-N-N-X1-ABA-016-AA-E6-00-32	SERIES 51	S51-080MV-1
83005919	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A4-C2-N-D6-F-G5-H2-L-35-L-35-B-L-26-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83005930	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-NN-80-R-4-S1-D-03-GBA-26-26-24	SERIES 90	S90-055PV
83005931	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-NN-80-R-4-S1-C-03-GBA-38-38-24	SERIES 90	S90-055PV
83005932	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-T1-C0-L-N-G0-NNN-155-AA-F0-00-B5	SERIES 51	S51-250MV
83005933	MOTOR-VAR-DISPL H1B080	H1-B-080-A-E2-AA-N-B-TB-VS-AS-P-A-10-NN-049-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83005934	MOTOR-VARIABLE CARTRIDGE K	K-C-45DN-E-RNF-F04-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83005935	MOTOR-VARIABLE CARTRIDGE K	K-C-45DN-E-RNF-F10-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83005936	MOTOR-VARIABLE CARTRIDGE K	K-C-45DS-E-RNF-F10-S-N-N-DF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83005937	PUMP-VAR DISPL, CCW 90PV055	90-L-055-FD-2-CD-80-P-7-C6-C-B1-GLA-42-42-28	SERIES 90	S90-055PV
83005938	PUMP-VAR DISPL, CCW 90PV055	90-L-055-CA-2-BG-80-P-7-S1-C-00-GLA-45-45-28	SERIES 90	S90-055PV
83005948	PUMP-VAR-DISPL CW 90PV180	90R180-KN-5-BC-80-T-M-C8-J-03-NNN-32-32-24	SERIES 90	S90-180PV
83005949	PUMP-VAR-DISPL CW 90PV100	90R100-MB-5-BC-80-S-3-C7-E-C7-GBA-35-35-24	SERIES 90	S90-100PV
83005951	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-DE-80-T-C-C8-J-03-NNN-42-42-24	SERIES 90	S90-180PV

83005953	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-EG-80-T-C-C8-J-03-NNN-42-42-24	SERIES 90	S90-180PV
83005954	PUMP-VAR-DISPL CW 90PV075	90R075-HF-5-BC-60-S-4-C7-D-03-GBA-45-45-26	SERIES 90	S90-075PV
83005955	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-NN-80-S-C-C8-J-03-NNN-42-42-24	SERIES 90	S90-180PV
83005956	MOTOR-VAR-DISPL 51MV160	51V160-A-C8-N-HZ-B2-C-E-H7-NNN-046-AA-E6-12-00	SERIES 51	S51-160MV
83005963	PUMP-VAR DISPL MPV035D	MPV-035-D-B-A-Y-R-S-G-AA-A-A-BEE-DR-A-FF-A-NNN-***	M35/44	035PV
83005964	PUMP-VAR DISPL MPV035D	MPV-035-D-B-A-A-L-S-E-BA-A-A-BFF-DL-A-FF-C-NNN-***	M35/44	035PV
83005966	PUMP-VAR DISPL MPV035D	MPV-035-D-B-A-A-R-S-E-BA-A-A-BFF-DR-A-FF-C-NNN-***	M35/44	035PV
83005967	MOTOR-VARIABLE DISPL SAE_K	K-V-38CN-A-R1F-F10-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83005968	PUMP-VAR-DISPL CCW 90PV250	90L250-KP-5-AB-80-T-3-F1-J-00-NNN-35-35-20	SERIES 90	S90-250PV
83005969	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-G1A1-72-J-2-B-2-F-5-A-30-30-B-1-1-NNN-NNN	SERIES 42	S42-041PV/051PV
83005973	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-G3AN-50-P-2-G-2-H-1-A-32-32-B-4-4-NNN-NNN	SERIES 42	S42-041PV/051PV
83005977	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A4-C2-N-D6-H-G9-H3-L-40-L-40-F-L-26-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83005995	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-A-S-B-B-AA-G-A-BHH-DA-A-HH-C-NNN-***	M46	M46-046PV
83006001	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-HZ-B1-A-N-G0-ABA-168-AA-G3-03-00	SERIES 51	S51-250MV
83006008	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-CD-80-S-4-S1-C-03-GBA-29-29-24	SERIES 90	S90-055PV
83006009	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-CD-80-P-4-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83006010	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-NN-80-P-4-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83006011	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-AB-80-P-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83006015	PUMP-VAR-DISPL CCW 90PV100	90L100-KP-5-BC-80-P-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83006016	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D3-N-N1-NN-N-N-U1-ADA-016-AA-NN-00-00	SERIES 51	S51-080MV-1
83006021	MOTOR-VAR-DISPL H1B110#	H1-B-110-A-E2-AA-N-A-TB-DN-KN-N-A-15-NN-035-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83006022	MOTOR-VAR-DISPL H1B110#	H1-B-110-A-P1-D1-N-B-TL-DS-JS-S-A-15-NN-030-Z-24-NNN	H1-HP MOTORS	H1-110MB1
83006023	MOTOR-VAR-DISPL H1B080	H1-B-080-A-P1-D1-N-B-TL-DS-JS-S-A-10-NN-021-Z-24-NNN	H1-HP MOTORS	H1-080MB1
83006027	MOTOR-VARIABLE DISPL SAE_K	K-V-45DS-E-RNF-F09-S-N-N-BF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83006028	MOTOR-VARIABLE DISPL SAE_L	L-V-25CS-A-RNF-F07-S-N-N-BF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83006032	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A8-C2-C-D8-H-G1-H3-K-38-K-38-N-E-24-P1-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83006033	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-5-NN-80-T-4-F1-J-00-NNN-17-17-24	SERIES 90	S90-250PV
83006037	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-2-NN-80-R-4-S1-C-GB-GBA-40-40-24	SERIES 90	S90-055PV
83006041	PUMP-VAR-DISPL CCW 90PV250	90L250-KP-2-EG-80-T-4-C8-K-00-NNN-32-32-24	SERIES 90	S90-250PV
83006042	MOTOR-VAR-DISPL H1B080	H1-B-080-A-E2-AA-N-B-TB-CN-JN-N-A-10-NN-032-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83006045	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-BC-80-S-3-F1-D-03-EBC-29-29-24	SERIES 90	S90-100PV
83006046	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-AB-80-S-7-C8-H-04-GCA-35-35-30	SERIES 90	S90-130PV
83006047	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-N2-NN-N-N-A0-NNN-168-AA-F0-00-00	SERIES 51	S51-250MV
83006048	PUMP-VAR-DISPL CCW 90PV042	90L042-KA-5-AB-80-S-4-C3-C-04-GCA-35-35-30	SERIES 90	S90-042PV
83006049	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-EF-80-T-M-C8-J-03-NNN-35-35-24	SERIES 90	S90-180PV
83006050	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-AB-80-T-M-F1-J-03-NNN-35-35-24	SERIES 90	S90-180PV

83006053	PUMP- VARIABLE, DIRECT DISPLACMENT	LPV-A-A-B-A-A-I-AA-D-A-BDD-DR-A-FF-N-NNN-***	LPV	LPV
83006055	PUMP-VAR-DISPL CW 90PV130	90R130-MB-5-BB-80-R-3-F1-H-C5-GBA-42-42-24	SERIES 90	S90-130PV
83006059	PUMP-VAR-DISPL CCW 90PV180	90L180-HF-5-BC-80-T-C-C8-J-03-NNN-32-32-24	SERIES 90	S90-180PV
83006060	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-5-CD-80-S-4-C6-C-03-GBA-35-35-24	SERIES 90	S90-075PV
83006061	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-5-BC-80-S-4-C6-C-03-GBA-35-35-24	SERIES 90	S90-075PV
83006062	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-DE-80-R-3-F1-H-03-GBA-35-35-24	SERIES 90	S90-130PV
83006063	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-BC-80-R-3-F1-H-03-GBA-35-35-24	SERIES 90	S90-130PV
83006064	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-NN-60-R-3-T2-E-03-GBA-29-29-24	SERIES 90	S90-100PV
83006068	MOTOR-VAR-DISPL 51MC110	51C110-R-D3-N-TH-C2-L-N-G0-NNN-033-AA-F0-00-A7	SERIES 51	S51-110MV
83006070	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-N-T2-C2-L-N-G0-ACA-200-AA-G0-00-B2	SERIES 51	S51-250MV
83006072	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-2-BC-80-D-4-S1-L-00-GFD-35-35-34-F070	SERIES 90	S90-075PV
83006073	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-2-CD-80-D-4-C6-L-00-GFD-35-35-34	SERIES 90	S90-075PV
83006075	PUMP-VAR-DISPL CW 90PV100	90R100-PB-5-CD-80-S-3-C7-E-06-FAP-30-35-30	SERIES 90	S90-100PV
83006079	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-5-BC-80-S-4-S1-C-03-GBA-35-35-24	SERIES 90	S90-075PV
83006081	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-2-NN-80-R-4-S1-C-GB-GBA-40-40-24	SERIES 90	S90-055PV
83006084	PUMP-VAR DISPL MPV044D	MPV-044-D-B-A-G-R-S-G-BA-A-A-BEE-DL-A-FF-C-NNN-***	M35/44	O44PV
83006085	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-N-A5-C2-N-E7-F-G1-H5-38-38-38-38-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83006086	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-N-A4-C2-N-E7-F-G1-H5-38-38-38-38-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83006087	PUMP- VARIABLE, DIRECT DISPLACMENT	LPV-A-A-A-A-A-G-AC-C-A-BJJ-DR-A-FF-A-NNN-***	LPV	LPV
83006092	MOTOR-VAR-DISPL H1B080	H1-B-080-A-P1-D1-N-C-TA-DS-JS-S-A-10-NN-030-Z-24-NNN	H1-HP MOTORS	H1-080MB1
83006093	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-BB-60-P-3-S1-D-03-GBA-42-42-28	SERIES 90	S90-075PV
83006097	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-BG-80-P-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-055PV
83006098	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-B1-C2-B-E6-F-G5-H3-L-40-L-40-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83006099	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-5-EG-80-S-3-C8-K-00-NNN-35-14-30-G005	SERIES 90	S90-250PV
83006100	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-5-BC-80-S-3-C8-K-00-NNN-35-14-30-G005	SERIES 90	S90-250PV
83006101	MOTOR-VAR-DISPL 51MD110-1	51D110-1--A-D3-N-P8-P8-N-N-X1-AWM-033-AA-F0-00-AA	SERIES 51	S51-110MV-1
83006103	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-2-NN-80-S-3-D7-F-03-GBA-38-38-20	SERIES 90	S90-100PV
83006104	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HS-1-BB-60-D-4-S1-L-03-GBA-29-29-34	SERIES 90	S90-075PV
83006105	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-G2A1-52-U-2-G-2-F-5-A-34-34-B-0-0-NNN-NNN	SERIES 42	S42-028PV/032PV
83006106	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A5-C2-N-D8-F-G4-NN-L-20-L-20-B-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83006111	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-BB-80-P-3-C8-F-03-GBA-42-42-24	SERIES 90	S90-130PV
83006115	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-CD-60-S-4-C7-E-03-GBA-32-32-24	SERIES 90	S90-075PV
83006117	PUMP-VAR DISPL MPV044D	MPV-044-D-B-A-Y-Y-S-C-BA-A-A-BBB-DR-A-FF-A-NNN-***	M35/44	O44PV
83006118	PUMP-VAR-DISPL CW 90PV100	90R100-MB-5-CD-60-D-3-C7-L-C5-GBA-42-42-24	SERIES 90	S90-100PV
83006121	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-G-S-B-B-BA-A-A-BGG-CN-A-HH-5-NNN-***	M46	M46-046PV
83006122	PUMP-VAR-DISPL CCW 90PV042	90L042-HF-5-BC-80-S-3-C5-C-00-GBA-35-14-30-G005	SERIES 90	S90-042PV

83006124	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-BG-80-P-3-S1-D-03-GBA-42-42-28	SERIES 90	S90-055PV
83006136	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-HZ-B1-B-E-C2-NNN-063-AA-NN-07-00	SERIES 51	S51-160MV
83006138	PUMP-VAR-DISPL CW 90PV100	90R100-FD-5-BC-60-S-7-C7-E-B1-GBA-42-42-30	SERIES 90	S90-100PV
83006139	PUMP-VAR-DISPL CCW 90PV075	90L075-DD-1-AB-60-S-4-C7-D-GB-GBA-42-42-24	SERIES 90	S90-075PV
83006140	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-CD-80-S-C-C8-H-05-NNN-38-20-24	SERIES 90	S90-180PV
83006144	PUMP-VAR-DISPL CW 90PV075	90R075-PB-5-NN-80-R-3-C7-D-03-GBA-21-21-24	SERIES 90	S90-075PV
83006145	MOTOR-VAR-DISPL 51MV250	51V250-A-C8-N-N2-NN-N-N-A0-NNN-085-AA-F3-00-00	SERIES 51	S51-250MV
83006146	PUMP-VAR-DISPL 42PV041 CW	42-R-51-D-E1A5-00-B-D-G-3-F-N-A-21-21-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83006147	PUMP-VAR-DISPL 42PV041 CCW	42-L-51-D-E1A5-00-B-D-G-3-F-N-A-21-21-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83006148	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-E1A5-03-B-2-B-3-F-N-B-34-34-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83006154	PUMP-VAR-DISPL CCW 90PV250	90L250-MA-5-CD-80-S-3-C8-K-C6-NNN-42-42-24	SERIES 90	S90-250PV
83006155	MOTOR-FIXED DISPL MMF025C	MMF-025-C-A-S-R-C-B-NNN-***	LIGHT DUTY	025MF
83006156	PUMP-VAR-DISPL CW 90PV130	90R130-FH-5-DG-80-S-7-C8-F-B1-GBS-38-38-32	SERIES 90	S90-130PV
83006157	PUMP-VAR DISPL CCW H1P053L	H1-P-053-L-A-A2-C2-N-D8-F-G5-H1-L-35-L-35-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83006158	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-CD-80-P-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83006159	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-BC-80-T-4-C8-K-03-NNN-32-32-24	SERIES 90	S90-250PV
83006165	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-BC-80-D-C-C8-L-03-NNN-20-20-24	SERIES 90	S90-180PV
83006166	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-AB-80-S-3-F1-F-04-GBA-35-35-24	SERIES 90	S90-130PV
83006167	PUMP-VAR-DISPL CW 90PV130	90R130-HF-5-DE-80-P-3-C8-H-03-GBA-26-26-24	SERIES 90	S90-130PV
83006168	PUMP-VAR-DISPL CW 90PV130	90R130-HF-5-AB-80-P-3-F1-H-03-GBA-26-26-24	SERIES 90	S90-130PV
83006169	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-NN-80-R-3-C7-F-03-GBA-35-35-24-G005	SERIES 90	S90-100PV
83006174	PUMP-VAR-DISPL CW 90PV042	90R042-FC-5-BB-80-D-7-C3-L-B1-GBA-42-14-30	SERIES 90	S90-042PV
83006175	PUMP-VAR-DISPL CW 90PV075	90R075-FM-5-BB-80-D-7-C7-L-B6-GME-42-14-30	SERIES 90	S90-075PV
83006176	MOTOR-VAR-DISPL 51MD060-1	51D060-1--A-D1-N-TA-C2-N-N-X1-NNN-012-AA-F3-00-32	SERIES 51	S51-060MV-1
83006179	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-NN-80-L-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83006180	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-BC-80-P-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-075PV
83006181	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D2-N-E0-B1-N-N-U1-NNN-040-AA-F0-00-00	SERIES 51	S51-080MV-1
83006183	MOTOR-VAR-DISPL 51MV250	51V250-V-F2-N-L2-B1-V-A-C0-NNN-050-AA-F3-B2-00	SERIES 51	S51-250MV
83006184	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A3-C2-B-D6-G-G2-H3-L-28-L-28-L-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83006192	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-C7-N-E2-B1-N-N-U1-NNN-020-AA-E6-00-00	SERIES 51	S51-080MV-1
83006196	PUMP-VAR-DISPL 42PV041 CW	42-R-51-D-ANN3-03-B-3-B-3-H-N-A-23-23-B-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83006197	PUMP-VAR-DISPL 42PV041 CW	42-R-51-D-ANN3-03-B-3-B-3-H-N-A-34-34-B-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83006222	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-AB-80-L-4-C8-H-03-GBA-42-42-30	SERIES 90	S90-130PV
83006224	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-2-CD-80-D-4-C6-L-00-GFD-32-32-34-F070	SERIES 90	S90-075PV
83006225	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-2-BC-80-D-4-S1-L-00-GFD-32-32-34-F070	SERIES 90	S90-075PV
83006227	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KT-1-CD-60-S-4-C7-D-03-GBA-43-43-24-F060	SERIES 90	S90-075PV

83006228	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KT-1-BC-60-S-4-S1-D-03-GBA-43-43-24-F060	SERIES 90	S90-075PV
83006229	MOTOR-VAR DISPL MMV046C	MMV-046-C-A-A-N-A-AH-NNN-***	M46	M46-046MV
83006244	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-G-S-A-S-BC-J-A-BRR-DA-A-WA-C-NNR-***	M46	M46-046PV
83006246	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-NN-80-P-3-F1-F-05-GBA-40-40-24	SERIES 90	S90-130PV
83006247	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-BC-80-P-3-S1-D-04-GBA-40-40-24	SERIES 90	S90-100PV
83006248	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-CD-80-P-3-F1-D-04-GBA-40-40-24	SERIES 90	S90-100PV
83006305	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-C7-N-F2-B1-N-N-U1-NNN-016-AA-F0-00-00	SERIES 51	S51-080MV-1
83006313	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-E1A6-02-B-2-G-2-F-N-A-34-34-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83006316	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-BB-80-T-M-F1-J-03-NNN-38-38-24	SERIES 90	S90-180PV
83006318	MOTOR-VAR-DISPL 51MV060-1	51V060-1--R-S1-N-E2-B1-N-N-U1-ADA-012-AA-NN-00-00	SERIES 51	S51-060MV-1
83006319	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-B8-C2-C-D3-K-F1-H2-L-40-L-40-C-M-20-P2-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83006324	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A5-C1-N-D6-F-G4-H3-L-35-L-35-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83006325	PUMP-VAR DISPL CCW H1P053L	H1-P-053-L-A-A3-C2-N-D8-F-G5-H1-L-35-L-35-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83006328	PUMP-VAR-DISPL CCW 90PV100	90L100-HF-5-BC-60-R-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83006329	PUMP-VAR-DISPL CW 90PV250	90R250-HF-5-CD-80-S-4-C8-K-03-NNN-42-42-24	SERIES 90	S90-250PV
83006330	PUMP-VAR-DISPL CW 90PV075	90R075-HF-5-CD-80-S-4-S1-E-03-GBA-42-42-24	SERIES 90	S90-075PV
83006336	MOTOR-VARIABLE CARTRIDGE K	K-C-45DN-A-YNF-F55-S-N-N-AF-F16-NNN-NNN	LV / KV MOTORS	L/K-MV
83006337	MOTOR-VARIABLE CARTRIDGE K	K-C-45DN-A-YNF-F11-S-N-N-AF-F16-NNN-NNN	LV / KV MOTORS	L/K-MV
83006339	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-HS-A2-B-E-E1-NNN-016-AA-E6-06-35	SERIES 51	S51-080MV
83006340	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-CD-60-P-3-C7-D-02-GBA-40-40-24	SERIES 90	S90-075PV
83006341	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-D8-M1-R-J-M4-ADA-082-AA-G3-C2-28	SERIES 51	S51-250MV
83006342	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-CD-80-P-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83006343	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-NN-80-P-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83006347	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-N-A5-C2-N-E7-F-G5-NN-35-35-35-35-N-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83006350	PUMP-VAR DISPL, CCW 90PV055	90-L-055-CA-5-NN-60-P-7-S1-D-00-GBA-42-42-24	SERIES 90	S90-055PV
83006353	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-A3NB-03-B-5-B-2-D-N-A-34-34-B-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83006354	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-E1-A5-A-N-A6-NNN-020-AA-E6-03-00	SERIES 51	S51-080MV
83006357	PUMP-VAR-DISPL CW 90PV180	90R180-MA-5-DE-80-T-M-C8-H-C6-NNN-29-29-24	SERIES 90	S90-180PV
83006358	PUMP-VAR-DISPL CW 90PV130	90R130-MA-5-CD-80-L-3-F1-F-C6-GBA-35-35-24	SERIES 90	S90-130PV
83006359	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-BC-80-P-3-S1-D-03-EHA-35-35-24	SERIES 90	S90-075PV
83006360	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A4-C2-B-E7-F-G5-H2-35-35-35-35-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83006361	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-AB-60-L-3-C7-L-03-GBA-42-42-24	SERIES 90	S90-100PV
83006362	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D3-N-E2-B1-N-N-U1-NNN-040-AA-E6-00-00	SERIES 51	S51-080MV-1
83006364	PUMP-VAR DISPL, CW 90PV055	90-R-055-FD-5-CD-60-S-7-C6-D-B1-EFI-35-35-28	SERIES 90	S90-055PV
83006365	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-NN-80-S-4-C7-E-00-GBA-42-42-24	SERIES 90	S90-100PV
83006367	PUMP-VAR-DISPL CW 90PV130	90R130-FH-2-BB-80-S-7-C8-F-B1-GBA-42-42-26	SERIES 90	S90-130PV

83006370	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-CD-80-S-4-C7-F-03-GBA-35-35-24	SERIES 90	S90-100PV
83006371	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-HZ-B1-A-N-G0-NNN-107-AA-NN-03-00	SERIES 51	S51-160MV
83006373	PUMP-VAR DISPL, CCW 90PV055	90-L-055-FD-5-CD-60-P-7-C6-D-B2-EBC-42-42-24	SERIES 90	S90-055PV
83006374	MOTOR-VAR DISPL MMV046C	MMV-046-C-B-M-N-C-AD-NNC-***	M46	M46-046MV
83006375	PUMP-VAR DISPL MPV025C	MPV-025-C-B-A-Y-L-A-G-NN-A-A-BBB-DR-A-FF-A-NNN-***	LIGHT DUTY	025PV
83006378	PUMP-VAR-DISPL CW 90PV042	90R042-KA-1-BC-80-S-3-C3-C-03-GBA-35-35-24	SERIES 90	S90-042PV
83006379	PUMP-VAR-DISPL CW 90PV100	90R100-KA-2-BC-80-L-3-C7-E-03-GBA-30-30-24	SERIES 90	S90-100PV
83006380	PUMP-VAR-DISPL CCW 90PV042	90L042-KA-5-NN-80-S-1-C3-C-04-GBA-35-35-30	SERIES 90	S90-042PV
83006381	PUMP-VAR-DISPL CW 90PV075	90R075-MA-5-CD-60-S-4-S1-D-C4-GBA-17-17-24	SERIES 90	S90-075PV
83006382	MOTOR-VAR-DISPL H1B080	H1-B-080-A-L2-BA-N-A-PA-VS-AS-S-A-10-NN-045-N-00-NNN	H1-HP MOTORS	H1-080MB1
83006383	PUMP-VAR DISPL, CW 90PV075	90-R-075-CA-H-BC-60-E-3-S1-C-00-FBA-AJ-43-28-B010	SERIES 90	S90-075PV
83006385	PUMP-VAR DISPL, CW 90PV075	90-R-075-CA-H-BC-60-E-3-S1-E-00-FBA-AJ-43-28-B010	SERIES 90	S90-075PV
83006386	PUMP-VAR DISPL, CW 90PV075	90-R-075-CA-5-CD-80-E-3-C6-D-00-GFD-38-38-24-B010	SERIES 90	S90-075PV
83006387	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D3-N-E2-B1-N-N-U1-ACG-017-AA-E6-00-00	SERIES 51	S51-080MV-1
83006389	PUMP-TANDEM, VAR DISPL MPT035D	MPT-035-D-C-Y-A-E-NN-B-A-A-A-BJJ-DS-A-FF-B-C-A-A-BJJ-DN-A-FF-J-NGV-***	M35/44	035PT
83006390	PUMP-VAR DISPL, CW 90PV100	90-R-100-KN-1-NN-60-R-4-F1-E-03-GBA-32-32-24	SERIES 90	S90-100PV
83006392	PUMP-VAR DISPL, CW 90PV075	90-R-075-CA-H-BC-60-E-3-S1-C-00-FBA-AK-45-28-B010	SERIES 90	S90-075PV
83006393	PUMP-VAR DISPL, CW 90PV075	90-R-075-LE-5-BC-80-E-3-S1-D-03-GFD-38-38-24	SERIES 90	S90-075PV
83006394	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-E1-A5-A-N-G0-ACA-107-AA-G3-03-00	SERIES 51	S51-160MV
83006395	MOTOR-VAR-DISPL H1B080	H1-B-080-A-L1-BA-N-A-PB-CS-HS-S-A-05-NN-000-N-00-NNN	H1-HP MOTORS	H1-080MB1
83006396	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-NN-80-P-4-F1-H-03-GBA-26-26-24	SERIES 90	S90-130PV
83006397	PUMP-VAR-DISPL CCW 90PV250	90L250-KP-5-NN-80-T-4-C8-K-03-NNN-26-26-28	SERIES 90	S90-250PV
83006398	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-NN-80-P-4-C6-D-03-GBA-26-26-28	SERIES 90	S90-075PV
83006400	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-BC-60-S-3-S1-D-03-GBA-42-42-20	SERIES 90	S90-075PV
83006401	PUMP-VAR-DISPL CCW 90PV075	90L075-DC-5-CD-60-S-3-S1-D-GB-GBA-35-35-24	SERIES 90	S90-075PV
83006402	PUMP-VAR-DISPL CW 90PV075	90R075-MA-5-BC-60-S-4-S1-D-C4-GBA-17-17-24	SERIES 90	S90-075PV
83006403	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-CD-80-S-4-C8-K-03-NNN-23-23-24	SERIES 90	S90-250PV
83006406	PUMP-VAR DISPL, CW 90PV075	90-R-075-MB-1-NN-60-S-3-S1-D-03-GBA-23-23-20	SERIES 90	S90-075PV
83006407	PUMP-VAR DISPL, CW 90PV075	90-R-075-CA-2-CD-80-E-3-C6-D-00-GFD-38-38-24-B010	SERIES 90	S90-075PV
83006408	PUMP-VAR DISPL, CW 90PV075	90-R-075-LE-2-BC-80-E-3-S1-D-03-GFD-38-38-24	SERIES 90	S90-075PV
83006416	PUMP-VAR DISPL MPV046C	MPV-046-C-B-A-B-S-B-B-BA-G-A-BCC-AB-D-AB-A-NNN-***	M46	M46-046PV
83006418	MOTOR-VAR-DISPL H1B080	H1-B-080-A-M1-CA-N-A-RA-VS-AS-S-A-05-NN-000-N-00-NNN	H1-HP MOTORS	H1-080MB1
83006421	MOTOR-VAR-DISPL 51MC160	51C160-A-D5-N-HZ-B1-C-H-C2-ACM-032-AA-NN-20-00	SERIES 51	S51-160MV
83006423	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-NN-80-S-3-C7-E-03-GBA-26-26-20	SERIES 90	S90-100PV
83006424	MOTOR-VAR-DISPL H1B080	H1-B-080-A-E2-AA-N-B-TA-DN-JN-N-N-NN-NN-037-Q-00-NNN	H1-HP MOTORS	H1-080MB1
83006430	PUMP-VAR-DISPL CCW 90PV100	90L100-DD-5-BC-80-S-4-C7-E-GB-GBA-38-38-24	SERIES 90	S90-100PV

83006435	MOTOR-VAR-DISPL 51MV110	51V110-R-C8-N-D7-M1-S-K-M1-NNN-048-AA-F0-F4-30	SERIES 51	S51-110MV
83006437	PUMP-VAR-DISPL CW 90PV075	90R075-FK-5-AB-80-S-7-S1-D-B6-EFR-42-42-30	SERIES 90	S90-075PV
83006438	MOTOR-VAR-DISPL 51MV160	51V160-R-D5-N-L2-B1-V-A-J1-NNN-032-AA-F0-B2-00	SERIES 51	S51-160MV
83006439	PUMP-VAR-DISPL CW 90PV100	90R100-MA-5-BC-60-L-3-C7-E-C6-GBA-29-29-24	SERIES 90	S90-100PV
83006440	PUMP-VAR-DISPL CW 90PV075	90R075-MA-5-AB-60-L-4-C6-C-C6-GBA-29-29-24	SERIES 90	S90-075PV
83006441	PUMP-VAR-DISPL CCW 90PV075	90L075-MA-5-AB-60-S-3-C6-D-C6-GBA-29-29-24	SERIES 90	S90-075PV
83006445	PUMP-VAR DISPL, CW 90PV055	90-R-055-CA-1-BC-60-S-7-S1-D-00-GLA-35-35-28	SERIES 90	S90-055PV
83006446	MOTOR-VAR-DISPL 51MV060-1	51V060-1--A-S1-N-N1-NN-N-N-U1-NNN-030-AA-E4-00-00	SERIES 51	S51-060MV-1
83006454	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-1-BC-60-P-3-S1-D-03-GBA-26-26-24	SERIES 90	S90-055PV
83006455	MOTOR-VAR-DISPL 51MD160	51D160-A-D4-N-D8-M1-R-J-M4-ADA-065-AA-F3-C2-26	SERIES 51	S51-160MV
83006456	PUMP-VAR-DISPL CCW 90PV130	90L130-FG-5-NN-80-L-7-F1-F-B1-EDD-35-35-24	SERIES 90	S90-130PV
83006459	PUMP-VAR DISPL, CW 90PV100	90-R-100-ME-1-AB-80-L-4-F1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
83006462	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A5-C2-N-D5-G-G2-H4-L-33-L-33-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83006463	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-N-HS-A2-B-E-E1-NNN-032-AA-F0-05-24	SERIES 51	S51-160MV
83006465	PUMP-VAR DISPL, CW 90PV075	90-R-075-CA-5-CD-60-E-3-C6-D-00-GFD-38-38-24-B010	SERIES 90	S90-075PV
83006466	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A5-C2-N-E5-F-G1-H5-L-28-L-28-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83006467	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A5-C2-N-E5-F-G5-NN-L-28-L-28-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83006468	MOTOR-VARIABLE DISPL SAE_L	L-V-35EN-E-RNF-F07-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83006469	MOTOR-VAR-DISPL 51MV110	51V110-R-C8-N-HS-A2-B-H-E1-NNN-070-AA-NN-08-25	SERIES 51	S51-110MV
83006470	MOTOR-VAR-DISPL 51MV110	51V110-R-C8-N-HS-A2-B-H-E1-NNN-027-AA-NN-08-25	SERIES 51	S51-110MV
83006471	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-HS-A2-B-H-E1-NNN-168-AA-NN-08-25	SERIES 51	S51-250MV
83006472	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-HS-A2-B-H-E1-NNN-085-AA-NN-08-25	SERIES 51	S51-250MV
83006474	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-1-AD-80-P-3-S1-D-03-FAD-29-29-24	SERIES 90	S90-055PV
83006476	MOTOR-VARIABLE DISPL SAE_L	L-V-25CS-A-RNF-F07-S-N-N-CF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83006477	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A2-C3-N-E5-F-G1-H5-L-45-L-45-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83006478	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A2-C3-N-E5-F-G5-H3-L-45-L-45-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83006490	MOTOR-VAR-DISPL 51MD110-1	51D110-1--R-D4-N-T1-D7-N-N-X1-NNN-033-AA-F0-00-37	SERIES 51	S51-110MV-1
83006491	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-BC-80-R-3-F1-F-00-GBA-14-14-20	SERIES 90	S90-130PV
83006493	MOTOR-VAR-DISPL 51MC060	51C060-R-D1-N-L2-B1-V-A-C0-ACB-027-AA-NN-B2-00	SERIES 51	S51-060MV
83006494	PUMP-VAR DISPL, CCW 90PV055	90-L-055-FD-2-BG-80-S-7-S1-C-B1-GLA-45-45-28	SERIES 90	S90-055PV
83006495	PUMP-VAR DISPL, CCW 90PV055	90-L-055-CA-2-CD-80-S-7-C6-C-00-GLA-42-42-28	SERIES 90	S90-055PV
83006498	MOTOR-VAR-DISPL 51MD080	51D080-R-D3-N-L2-B1-V-A-C0-ADA-040-AA-E6-B2-00	SERIES 51	S51-080MV
83006499	PUMP-VAR-DISPL CCW 90PV042	90L042-PA-5-NN-80-P-4-C3-C-03-GBA-26-26-24	SERIES 90	S90-042PV
83006500	PUMP-VAR-DISPL CCW H1PV147	H1-P-147-L-C-A5-C3-B-D3-G-G3-H6-K-35-K-20-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83006502	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A9-C1-N-E6-F-G5-H3-L-35-L-35-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83006505	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-B-C3-B1-N-N-U1-AWK-N16-AA-E6-00-00	SERIES 51	S51-060MV-1

83006506	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-B-C3-B1-N-N-U1-DDF-N16-AA-E6-00-00	SERIES 51	S51-060MV-1
83006509	MOTOR-VAR-DISPL H1B110#	H1-B-110-A-E2-AA-N-B-TA-CS-JS-S-N-NN-NN-050-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83006512	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HS-1-BC-80-P-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83006518	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A8-C2-C-D6-J-G5-H3-L-40-L-40-B-L-30-P2-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83006526	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-DE-80-P-3-C8-F-05-GBA-42-42-24	SERIES 90	S90-130PV
83006527	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-BC-80-P-3-F1-F-05-GBA-42-42-24	SERIES 90	S90-130PV
83006528	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-5-BC-80-T-4-C8-K-03-NNN-35-35-30	SERIES 90	S90-250PV
83006529	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-DE-80-T-M-C8-J-03-NNN-35-16-34	SERIES 90	S90-180PV
83006530	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-EG-80-T-M-C8-J-03-NNN-35-16-34	SERIES 90	S90-180PV
83006531	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-CD-80-T-M-C8-J-03-NNN-35-16-34	SERIES 90	S90-180PV
83006533	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A9-C2-B-D8-H-G1-H2-K-40-K-18-F-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83006534	PUMP-VAR-DISPL CW 90PV075	90R075-MA-5-CD-80-S-4-C7-D-C6-GBA-45-45-24	SERIES 90	S90-075PV
83006537	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-BG-80-S-3-S1-D-03-EBC-32-32-24	SERIES 90	S90-055PV
83006538	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-1-NN-80-S-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-075PV
83006542	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-CD-80-L-3-F1-H-03-GBA-38-38-24	SERIES 90	S90-130PV
83006543	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-NN-60-L-3-S1-E-02-GBA-38-38-24	SERIES 90	S90-100PV
83006546	PUMP-TANDEM, VAR DISPL CCW H1T053L	H1-T-053-L-A-N-A5-C2-N-E7-F-G1-H3-30-30-30-30-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83006547	MOTOR-VARIABLE CARTRIDGE K	K-C-38CS-E-RNF-F55-S-N-N-CF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83006549	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-E1A5-03-C-2-A-2-F-N-N-17-17-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83006556	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-BC-80-S-3-C6-D-03-GBA-38-38-28	SERIES 90	S90-075PV
83006558	MOTOR-VAR-DISPL H1B080	H1-B-080-A-E1-AA-N-A-TB-CS-JS-S-A-05-NN-016-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83006559	MOTOR-VAR-DISPL 51MV060-1	51V060-1--A-C6-N-T1-D1-N-N-X1-NNN-026-AA-E4-00-23	SERIES 51	S51-060MV-1
83006561	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A4-C3-N-E7-F-G1-H3-30-30-35-35-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83006562	PUMP-VAR DISPL MPV035D	MPV-035-D-B-A-A-R-S-G-AA-A-A-BBB-DR-A-FF-B-NNN-***	M35/44	035PV
83006563	MOTOR-VAR-DISPL 51MD110-1	51D110-1--A-D4-N-T1-CA-N-N-X1-NNN-028-AA-F3-00-27	SERIES 51	S51-110MV-1
83006566	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-NN-60-R-4-S1-F-06-GBA-38-38-20	SERIES 90	S90-100PV
83006567	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KT-1-NN-60-D-3-S1-L-00-GBA-45-45-24	SERIES 90	S90-075PV
83006573	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-5-AB-60-S-3-C6-C-03-GBA-44-44-24	SERIES 90	S90-055PV
83006574	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-1-NN-80-P-4-S1-C-GB-GBA-38-38-20	SERIES 90	S90-055PV
83006575	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-1-NN-80-P-4-S1-C-GB-GBA-42-42-20	SERIES 90	S90-055PV
83006577	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A8-C2-C-D8-H-G1-H3-K-38-K-38-N-E-24-P1-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83006581	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-H-S-B-U-AA-A-A-BFF-BB-A-ZB-A-NNN-***	M46	M46-046PV
83006582	PUMP-VAR-DISPL CW 90PV100	90R100-MA-5-BC-80-S-4-C7-E-C5-GBA-42-42-24-F003	SERIES 90	S90-100PV
83006583	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-HS-A2-B-H-E1-NNN-032-AA-F0-12-25	SERIES 51	S51-160MV
83006588	MOTOR-VARIABLE DISPL SAE_K	K-V-38CS-A-RNF-F07-S-N-N-BF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83006589	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-A-S-B-J-AA-A-A-BHH-CE-A-HH-5-NNN-***	M46	M46-046PV

83006592	PUMP-VAR-DISPL CCW 90PV250	90L250-HS-5-NN-80-T-4-F1-J-03-NNN-42-42-24	SERIES 90	S90-250PV
83006593	PUMP-VAR-DISPL CCW 90PV250	90L250-HS-5-AB-80-T-4-F1-J-03-NNN-45-42-24	SERIES 90	S90-250PV
83006594	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-CD-60-S-3-S1-D-03-GBA-42-42-20	SERIES 90	S90-075PV
83006596	PUMP-VAR-DISPL CCW 90PV075	90L075-DC-5-BC-60-S-3-S1-D-GB-GBA-35-35-24	SERIES 90	S90-075PV
83006597	PUMP-VAR-DISPL CW 90PV075	90R075-HF-5-NN-60-R-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83006598	MOTOR-VAR DISPL MMV046C	MMV-046-C-A-E-D-D-AV-VNB-***	M46	M46-046MV
83006599	MOTOR-VAR DISPL MMV046C	MMV-046-C-A-E-D-D-A8-VNB-***	M46	M46-046MV
83006601	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A3-C2-N-E6-F-G4-H3-L-28-L-28-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83006604	MOTOR-VAR-DISPL H1B110	H1-B-110-A-M2-CA-N-N-RA-DN-KN-N-A-15-NN-000-N-00-NNN	H1-HP MOTORS	H1-110MB1
83006605	MOTOR-FIX DISPL MMF044D	MMF-044-D-A-A-Y-A-B-NNN-***	M35/44	044MF
83006606	MOTOR-FIX DISPL MMF035D	MMF-035-D-A-N-M-A-B-NNR-***	M35/44	035MF
83006607	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A8-C2-C-D6-G-G2-H3-L-40-L-40-L-L-24-P1-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83006608	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-AG-60-L-3-C7-S-03-GBA-42-42-18	SERIES 90	S90-100PV
83006620	MOTOR-VAR-DISPL H1B110#	H1-B-110-A-P2-D2-N-B-TA-DN-JN-N-A-15-NN-040-Z-24-NNN	H1-HP MOTORS	H1-110MB1
83006622	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HS-1-AB-80-S-4-S1-D-03-GBA-29-29-24	SERIES 90	S90-075PV
83006623	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KN-1-BC-80-R-4-S1-D-03-GBA-29-29-24	SERIES 90	S90-075PV
83006624	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-1-CD-60-S-4-C6-C-G4-GBA-35-35-20	SERIES 90	S90-055PV
83006625	PUMP-VAR DISPL, CW 90PV075	90-R-075-KN-1-NN-80-S-4-S1-D-03-GBA-29-29-24	SERIES 90	S90-075PV
83006629	MOTOR-VAR DISPL MMV046C	MMV-046-C-A-E-D-C-AQ-VND-***	M46	M46-046MV
83006630	MOTOR-VAR DISPL MMV046C	MMV-046-C-A-E-D-C-AV-VND-***	M46	M46-046MV
83006631	MOTOR-VAR DISPL MMV046C	MMV-046-C-A-E-D-D-AQ-VND-***	M46	M46-046MV
83006632	MOTOR-VAR DISPL MMV046C	MMV-046-C-A-E-D-D-AV-VND-***	M46	M46-046MV
83006634	PUMP-VAR DISPL, CW 90PV075	90-R-075-CA-B-CD-60-E-3-C6-D-00-GFD-38-34-24-B010	SERIES 90	S90-075PV
83006635	PUMP-VAR DISPL, CW 90PV075	90-R-075-LE-B-BC-60-E-3-S1-D-03-GFD-38-34-24	SERIES 90	S90-075PV
83006637	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-BC-60-P-3-C6-E-04-GBA-38-38-28	SERIES 90	S90-075PV
83006640	MOTOR-VAR-DISPL 51MV060-1	51V060-1--R-S1-N-N1-NN-N-N-U1-NNN-019-AA-NN-00-00	SERIES 51	S51-060MV-1
83006643	PUMP-TANDEM, VAR DISPL CCW H1T045L	H1-T-045-L-A-A2-C2-N-E7-F-G5-NN-42-42-42-42-N-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83006648	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-N-A2-C2-N-E7-F-G1-H3-35-35-35-35-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83006649	PUMP-VAR DISPL, CW 90PV100	90-R-100-HF-1-BC-80-R-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83006650	PUMP-VAR DISPL, CW 90PV075	90-R-075-HF-1-CD-80-P-4-S1-E-03-GBA-42-42-24	SERIES 90	S90-075PV
83006651	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-2-BC-80-R-3-F1-F-00-GBA-35-35-24	SERIES 90	S90-100PV
83006653	MOTOR-VAR-DISPL H1B080	H1-B-080-A-M2-CA-N-N-RA-DN-HN-N-N-NN-000-N-00-NNN	H1-HP MOTORS	H1-080MB1
83006654	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-BB-60-L-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
83006659	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A9-C1-N-E6-F-G4-NN-L-30-L-30-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83006662	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A5-C3-B-D6-G-G3-NN-K-25-K-25-A-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83006665	PUMP-VAR DISPL, CW 90PV075	90-R-075-KN-1-BC-60-S-4-K2-E-02-GBA-14-35-24-P000	SERIES 90	S90-075PV

83006666	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A5-C3-B-D9-G-G3-H4-K-25-K-25-A-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83006667	PUMP-TANDEM, VAR DISPL CCW H1T045L	H1-T-045-L-A-N-A4-C1-N-E7-F-G5-T3-35-35-35-35-M-P-24-PN-NNN-S01	H1-MP PUMPS	H1-045PT/053PT
83006668	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A5-C2-N-E5-F-G1-H5-L-35-L-35-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83006669	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A5-C2-N-E5-F-G5-NN-L-35-L-35-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83006670	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-BC-60-D-3-C7-L-03-GBA-20-20-28	SERIES 90	S90-100PV
83006671	PUMP-VAR-DISPL CW 90PV075	90R075-DD-5-BC-80-P-4-S1-E-GB-GBA-35-35-24	SERIES 90	S90-075PV
83006672	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-CD-60-S-3-C7-F-21-GBA-42-42-24	SERIES 90	S90-100PV
83006686	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-E2-A5-A-N-A6-NNN-050-AA-G3-03-00	SERIES 51	S51-250MV
83006687	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A2-C2-N-E7-F-G1-H3-35-35-35-35-N-P-30-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83006688	MOTOR-VAR-DISPL 51MD160	51D160-A-D4-N-EQ-A2-J-Y-E1-NNN-080-AA-F3-15-29	SERIES 51	S51-160MV
83006695	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A5-C2-N-D6-F-G5-H5-L-30-L-30-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83006696	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A5-C2-N-D6-F-G5-H2-L-30-L-30-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83006702	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-NN-80-D-C-F1-N-03-NNN-42-42-22	SERIES 90	S90-180PV
83006703	MOTOR-VAR-DISPL H1B110	H1-B-110-A-L1-BA-N-B-PB-VS-DS-S-A-15-NN-030-N-00-NNN	H1-HP MOTORS	H1-110MB1
83006710	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-BC-80-P-4-S1-D-03-GBA-26-26-24	SERIES 90	S90-075PV
83006711	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-CD-80-P-4-S1-D-03-GBA-26-26-24	SERIES 90	S90-075PV
83006714	PUMP-TANDEM, VAR DISPL CCW H1T045L	H1-T-045-L-A-N-A2-C2-N-D1-F-G5-T2-40-40-40-40-M-P-20-PN-NNN-S01	H1-MP PUMPS	H1-045PT/053PT
83006726	PUMP-VAR DISPL, CW 90PV075	90-R-075-HS-1-CD-80-P-4-S1-E-03-GBA-42-42-24	SERIES 90	S90-075PV
83006727	MOTOR-VAR-DISPL 51MD160	51D160-A-D4-N-L2-B1-V-A-C0-ADA-042-AA-NN-B2-00	SERIES 51	S51-160MV
83006728	PUMP-TANDEM, VAR DISPL MPT035D	MPT-035-D-G-W-A-N-NN-B-A-A-A-BNN-DL-A-FF-B-C-A-A-BNN-DL-A-FF-J-NNN-	M35/44	035PT
83006729	PUMP-VAR DISPL, CW 90PV075	90-R-075-K2-1-CT-60-P-3-C7-E-64-GFS-35-35-24	SERIES 90	S90-075PV
83006730	MOTOR-FIX DISPL MMF044D	MMF-044-D-A-6-U-C-D-NNN-***	M35/44	044MF
83006734	PUMP-VAR DISPL, CW 90PV055	90-R-055-HM-1-NN-60-S-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83006739	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-D7-M1-S-K-M4-NNN-032-AA-F0-F4-13	SERIES 51	S51-160MV
83006743	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-5-CD-60-S-3-C6-C-01-GBA-42-42-24	SERIES 90	S90-055PV
83006746	PUMP-VAR DISPL CCW H1P053L	H1-P-053-L-A-A4-C1-N-D6-F-G5-H5-L-35-L-35-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83006747	PUMP-VAR DISPL, CW 90PV055	90-R-055-HS-1-CD-80-S-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83006750	PUMP-VAR DISPL, CW 90PV055	90-R-055-HS-1-BG-80-S-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83006751	PUMP-VAR DISPL, CW 90PV055	90-R-055-HK-1-NN-60-P-3-S1-L-03-GBA-42-42-28	SERIES 90	S90-055PV
83006752	PUMP-VAR DISPL CCW H1P053L	H1-P-053-L-A-A4-C1-N-F3-F-G5-H5-K-35-K-35-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83006753	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-D-E1A6-03-B-D-B-2-H-N-V-34-34-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83006756	MOTOR-VAR-DISPL H1B110#	H1-B-110-A-T1-D1-N-B-TA-DS-KS-S-A-15-NN-032-Z-19-NNN	H1-HP MOTORS	H1-110MB1
83006765	MOTOR-VAR-DISPL 51MV060-1	51V060-1--A-D1-N-TA-C2-N-N-X1-NNN-021-AA-E6-00-35	SERIES 51	S51-060MV-1
83006766	MOTOR-VAR-DISPL 51MV160	51V160-R-F2-N-E2-A5-A-N-G0-NNN-085-AA-F3-03-00	SERIES 51	S51-160MV
83006768	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-B8-C2-C-D8-H-G1-H3-L-40-L-40-C-P-28-P1-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83006770	PUMP-VAR-DISPL 42PV041 CW	42-R-41-C-E1A5-03-B-2-B-3-F-N-N-34-34-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV

83006774	MOTOR-VAR-DISPL 51MC080	51C080-R-D3-N-L2-B1-V-A-C0-ACB-016-AA-NN-B2-00	SERIES 51	S51-080MV
83006782	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-G1A1-72-J-3-C-3-F-5-V-34-34-N-0-0-NNN-NNN	SERIES 42	S42-041PV/051PV
83006785	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A3-C2-N-E6-F-G4-H3-L-28-L-28-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83006786	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-HS-A2-B-H-G6-NNN-100-AA-NN-05-20	SERIES 51	S51-250MV
83006787	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-5-NN-80-P-3-S1-D-03-EBC-35-14-24	SERIES 90	S90-075PV
83006788	PUMP-VAR DISPL CCW H1P053L	H1-P-053-L-A-A4-C2-N-E6-F-G5-H5-L-30-L-30-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83006792	PUMP-VAR-DISPL 42PV041 CCW	42-L-51-C-E1A7-03-D-N-F-3-H-N-N-28-28-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83006802	MOTOR-VAR-DISPL 51MD160	51D160-R-D4-N-T2-C2-L-N-G0-NNN-080-AA-G3-00-B4	SERIES 51	S51-160MV
83006807	MOTOR-VAR-DISPL 51MD160	51D160-R-D5-N-L2-B1-V-A-G5-NNN-060-AA-E4-B2-00	SERIES 51	S51-160MV
83006808	MOTOR-VAR-DISPL 51MD160	51D160-R-D5-N-L2-B1-V-A-G5-ACA-060-AA-E4-B2-00	SERIES 51	S51-160MV
83006809	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A3-C2-N-E6-F-G4-H3-L-28-L-28-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83006810	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-CD-80-P-3-C6-D-03-GBA-35-35-24	SERIES 90	S90-055PV
83006811	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-BG-80-P-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-055PV
83006812	PUMP-VAR-DISPL CW 90PV250	90R250-MA-5-AB-80-T-4-C8-J-05-NNN-26-26-24	SERIES 90	S90-250PV
83006814	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-NN-60-S-3-C7-F-00-FAC-23-23-28	SERIES 90	S90-100PV
83006815	MOTOR-VAR-DISPL 51MD110-1	51D110-1--R-D3-N-T2-R5-N-N-X1-NNN-040-AA-F0-00-28	SERIES 51	S51-110MV-1
83006816	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-HZ-B1-A-N-G0-NNN-168-AA-F0-03-00	SERIES 51	S51-250MV
83006818	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-C-T1-L5-L-N-G0-NNN-092-AA-G0-00-B8	SERIES 51	S51-160MV
83006820	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A2-C3-N-E5-F-G1-H5-L-45-L-45-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83006821	PUMP-VAR DISPL MPV044D	MPV-044-D-B-A-Y-S-C-BA-A-A-BEE-DR-A-FF-A-NNN-***	M35/44	044PV
83006825	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-CD-60-P-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-075PV
83006826	MOTOR-VAR-DISPL 51MV080	51V080-A-S1-N-N2-NN-N-N-A0-NNN-040-AA-E6-00-00	SERIES 51	S51-080MV
83006832	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MA-1-AB-80-S-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83006833	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-NN-80-S-3-S1-D-03-GBA-26-29-24	SERIES 90	S90-075PV
83006837	MOTOR-VAR-DISPL 51MD160	51D160-A-D5-N-TM-E7-L-N-J2-AWM-038-AA-F0-00-BB	SERIES 51	S51-160MV
83006838	PUMP-VAR DISPL CCW H1P053L	H1-P-053-L-A-A4-C2-N-D8-J-G4-H3-L-30-L-30-B-P-24-P4-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83006839	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-HS-A1-C-E-A2-ADA-125-AA-G0-12-30	SERIES 51	S51-250MV
83006840	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-EF-80-T-C-C8-J-05-NNN-38-38-24	SERIES 90	S90-180PV
83006841	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-CD-80-P-3-C7-E-05-GBA-38-38-24	SERIES 90	S90-075PV
83006845	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-CD-60-S-4-C7-E-03-GBA-35-35-24	SERIES 90	S90-075PV
83006848	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A4-C1-B-D6-H-G1-NN-L-20-L-20-C-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83006849	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-S1-N-E2-B1-N-N-U1-NNN-033-AA-E6-00-00	SERIES 51	S51-080MV-1
83006850	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-S1-N-E2-B1-N-N-U1-NNN-020-AA-E6-00-00	SERIES 51	S51-080MV-1
83006851	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-CD-80-T-C-C8-J-03-NNN-35-35-24	SERIES 90	S90-180PV
83006858	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-5-NN-80-S-3-F1-K-03-NNN-35-35-24	SERIES 90	S90-250PV
83006859	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-NN-80-R-4-C7-E-03-GBA-35-35-24	SERIES 90	S90-100PV

83006860	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-E1A7-00-B-D-B-2-H-N-A-28-28-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83006862	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HF-1-NN-80-R-3-S1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
83006863	PUMP-VAR-DISPL CCW 90PV042	90L042-KA-5-AB-80-S-3-T3-B-03-GBA-35-35-24	SERIES 90	S90-042PV
83006864	PUMP-VAR-DISPL CW 90PV180	90R180-MA-5-EG-80-D-M-C8-L-C7-FAC-35-35-24-F075	SERIES 90	S90-180PV
83006865	PUMP-VAR-DISPL CW 90PV180	90R180-MA-5-CD-80-D-M-C8-L-C7-FAC-35-35-24-F075	SERIES 90	S90-180PV
83006866	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-D-N-0-C6-W-00-MIX-00-00-F0	SERIES 90	T90-075MF
83006868	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-G3AN-52-T-N-M-N-F-1-A-28-28-N-1-1-NNN-NNN	SERIES 42	S42-028PV/032PV
83006869	MOTOR-VAR-DISPL H1B060	H1-B-060-A-T1-D1-N-B-TB-VS-AS-P-A-10-NN-014-Z-28-NNN	H1-HP MOTORS	H1-060MB1
83006872	PUMP-VAR DISPL, CCW 90PV055	90-L-055-MA-5-BB-60-S-4-C6-D-C5-GBA-32-32-24	SERIES 90	S90-055PV
83006873	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-5-AB-80-P-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83006874	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-1-AB-60-P-4-S1-E-03-GBA-26-26-24	SERIES 90	S90-075PV
83006875	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A3-C2-N-D8-H-G1-H3-L-40-L-40-N-E-26-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83006876	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-B1-C2-N-D6-G-G3-H4-L-40-L-40-L-L-28-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83006878	PUMP-VAR-DISPL CCW 90PV180	90L180-MA-5-AB-80-T-M-F1-J-C5-FAC-35-35-24	SERIES 90	S90-180PV
83006881	PUMP-VAR DISPL MPV044D	MPV-044-D-B-A-Y-Y-S-S-BA-A-A-BEE-DR-A-FF-A-NNN-***	M35/44	O44PV
83006883	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-HZ-B1-A-N-G0-ACA-115-AA-F3-03-00	SERIES 51	S51-160MV
83006887	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-5-NN-80-R-3-S1-C-01-GBA-35-35-24	SERIES 90	S90-055PV
83006890	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A5-C2-N-D6-F-G1-H5-L-35-L-35-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83006891	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A5-C2-N-D8-F-G5-H2-L-23-L-23-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83006895	PUMP-VAR DISPL, CW 90PV075	90-R-075-HF-1-BC-80-P-3-S1-D-00-GBA-20-20-24	SERIES 90	S90-075PV
83006896	MOTOR-VAR-DISPL 51MV060	51V060-R-S1-N-L2-B1-V-A-C0-ACA-025-AA-E4-B2-00	SERIES 51	S51-060MV
83006897	PUMP-VAR DISPL CCW H1P053L	H1-P-053-L-A-A5-C2-B-D6-F-G4-NN-L-35-L-35-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83006898	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-EQ-A5-J-Y-J1-ACA-050-AA-G3-15-00	SERIES 51	S51-250MV
83006902	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-D-N-0-C6-W-00-MIX-00-00-F0	SERIES 90	T90-100MF
83006923	PUMP-VAR-DISPL CW 90PV100	90R100-KP-5-BC-80-R-3-S1-F-03-GBA-26-26-24	SERIES 90	S90-100PV
83006924	PUMP-VAR-DISPL CW 90PV100	90R100-KP-5-NN-80-R-3-S1-F-03-GBA-38-38-24	SERIES 90	S90-100PV
83006927	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-BC-80-P-4-S1-E-05-GBA-38-38-24	SERIES 90	S90-075PV
83006934	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-1-NN-60-S-3-C6-C-03-GBA-35-35-20	SERIES 90	S90-075PV
83006935	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-BC-80-R-3-C3-B-03-GBA-23-23-24	SERIES 90	S90-042PV
83006936	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-E1A3-03-D-N-F-2-H-N-B-34-34-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83006938	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-CD-80-P-4-C8-H-03-EHA-35-35-24	SERIES 90	S90-130PV
83006946	PUMP-VAR DISPL CCW H1P053L	H1-P-053-L-A-A9-C2-N-D8-J-G4-H3-L-30-L-30-B-P-24-P4-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83006950	MOTOR-VAR DISPL MMV046C	MMV-046-C-A-E-D-D-AV-VNF-***	M46	M46-046MV
83006951	MOTOR-VAR DISPL MMV046C	MMV-046-C-A-E-D-D-AQ-VNF-***	M46	M46-046MV
83006952	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-J-S-A-J-BC-A-A-BFF-CB-A-RR-3-NNG-***	M46	M46-046PV
83006954	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A2-C3-N-E5-F-G5-H3-L-45-L-45-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV

83006955	PUMP-VAR-DISPL CW 90PV180	90R180-KP-5-BC-80-T-C-F1-H-03-FAC-45-45-24	SERIES 90	S90-180PV
83006957	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-NN-80-S-4-F1-F-04-GBA-42-42-24	SERIES 90	S90-130PV
83006958	PUMP-VAR DISPL, CW 90PV100	90-R-100-RS-1-NN-60-S-3-C7-F-03-GBA-42-42-24	SERIES 90	S90-100PV
83006959	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A5-C2-N-D6-G-G3-NN-L-45-L-45-L-L-30-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83006963	MOTOR-VARIABLE DISPL SAE_L	L-V-35EN-E-RNF-F09-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83006964	MOTOR- VARIABLE CARTRIDGE L	L-C-35EN-E-RNF-F09-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83006965	PUMP- VARIABLE, DIRECT DISPLACMENT	LPV-A-A-B-C-A-G-DA-C-A-BHH-DR-A-FF-B-NNN-***	LPV	LPV
83006966	PUMP- VARIABLE, DIRECT DISPLACMENT	LPV-A-A-B-A-A-G-DA-C-A-BHH-DR-A-FF-B-NNN-***	LPV	LPV
83006983	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A2-C2-N-D8-H-G1-H1-K-42-K-42-N-E-22-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83006990	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A2-C2-N-D8-F-G5-H2-L-25-L-25-B-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83006996	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-L2-B1-V-A-J2-AHA-050-AA-F3-B2-00	SERIES 51	S51-250MV
83006997	MOTOR-VAR-DISPL 51MC160	51C160-R-D5-N-L2-B1-V-A-J2-NNN-050-AA-F0-B2-00	SERIES 51	S51-160MV
83006998	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A5-C2-N-F6-H-G9-H6-L-40-L-40-C-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83006999	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A5-C2-N-D6-H-G1-NN-L-40-L-40-C-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83007000	PUMP-VAR-DISPL CCW H1PV147	H1-P-147-L-C-A5-C2-N-D6-G-G2-H3-L-45-L-45-A-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83007001	PUMP-VAR-DISPL CW 90PV100	90R100-DD-5-BC-80-S-4-C7-E-GB-GBA-32-32-24	SERIES 90	S90-100PV
83007006	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-NN-60-S-4-C7-D-03-GBA-32-42-24	SERIES 90	S90-075PV
83007007	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A2-C2-N-D8-H-F4-H1-K-42-K-42-N-E-22-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83007011	MOTOR-VAR-DISPL 51MD160	51D160-R-D4-N-HS-A2-C-H-E1-NNN-095-AA-NN-16-22	SERIES 51	S51-160MV
83007012	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A2-C2-N-D3-H-G9-H5-L-40-L-40-C-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83007013	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-NN-80-T-4-C8-K-04-NNN-42-42-24-F001	SERIES 90	S90-250PV
83007021	PUMP-VAR DISPL, 42PV041 CW	42-R-41-D-ANB5-02-C-2-A-3-H-N-N-34-34-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83007023	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A3-C2-N-D6-H-G1-NN-L-35-L-35-F-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83007024	PUMP-VAR DISPL, 42PV028 CW	42-R-28-D-G3AN-50-T-N-D-3-F-1-G-28-28-B-1-1-NNN-NNN	SERIES 42	S42-028PV/032PV
83007027	MOTOR-VAR-DISPL H1B080	H1-B-080-A-E2-AA-N-B-TB-DN-HN-N-A-15-NN-040-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83007030	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-AB-80-L-4-S1-E-00-EBC-29-29-24	SERIES 90	S90-075PV
83007032	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-AB-80-L-4-S1-E-00-EBC-26-26-24	SERIES 90	S90-075PV
83007033	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-BC-80-L-3-S1-F-03-GBA-32-32-24	SERIES 90	S90-100PV
83007034	MOTOR-VAR-DISPL 51MC160	51C160-A-D5-N-HZ-B1-A-N-G0-NNN-080-AA-NN-03-00	SERIES 51	S51-160MV
83007035	PUMP-VAR-DISPL CCW 90PV180	90L180-MA-5-BB-80-S-M-C8-J-C5-NNN-35-35-24	SERIES 90	S90-180PV
83007042	PUMP-VAR DISPL, 42PV028 CW	42-R-28-D-ANB5-02-C-2-A-2-H-N-N-34-34-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83007044	MOTOR-VAR-DISPL 51MV060	51V060-R-C6-N-L2-B1-V-A-J1-NNN-036-AA-F3-B2-00	SERIES 51	S51-060MV
83007045	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-NN-80-P-4-C7-D-00-GBA-29-29-24-F003	SERIES 90	S90-075PV
83007050	PUMP-VAR-DISPL CW 90PV100	90R100-KN-5-NN-60-P-3-C7-F-03-GBA-29-29-24	SERIES 90	S90-100PV
83007051	PUMP-VAR DISPL, CCW 90PV075	90-L-075-ME-1-NN-80-P-3-S1-C-03-GBA-26-26-24	SERIES 90	S90-075PV
83007052	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HS-1-NN-80-S-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV

83007053	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KN-1-BC-80-R-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83007054	MOTOR-VAR-DISPL 51MD110-1	51D110-1--R-D3-N-E1-B1-N-N-U1-NNN-043-AA-F0-00-00	SERIES 51	S51-110MV-1
83007055	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-NN-80-S-3-C7-D-03-GBA-26-26-24	SERIES 90	S90-075PV
83007056	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KN-1-BG-80-R-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
83007059	MOTOR-VAR-DISPL H1B060	H1-B-060-A-E2-AA-N-A-TB-VN-AN-N-A-10-NN-016-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83007062	MOTOR-VAR-DISPL 51MV080	51V080-A-C7-N-HS-A1-B-E-E2-NNN-022-AA-F3-08-25	SERIES 51	S51-080MV
83007063	MOTOR-VAR-DISPL H1B080	H1-B-080-A-E2-AA-N-B-TB-DN-HN-N-N-NN-040-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83007065	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A3-C2-N-D3-G-G3-H6-L-38-L-38-L-M-20-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83007067	PUMP-VAR DISPL, CW 90PV075	90-R-075-KN-1-AB-60-R-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83007073	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-BC-80-S-4-S1-F-00-GBA-23-23-20	SERIES 90	S90-100PV
83007075	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-N-A2-C2-N-E7-F-G6-T3-35-35-35-35-M-P-24-PN-NNN-S03	H1-MP PUMPS	H1-045PT/053PT
83007076	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-NN-80-R-4-S1-E-03-GBA-26-26-24	SERIES 90	S90-100PV
83007078	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-1-AD-80-P-4-S1-C-00-GBA-14-14-24	SERIES 90	S90-055PV
83007085	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A2-C1-N-D8-F-G4-NN-L-23-L-23-B-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83007086	PUMP-VAR DISPL MPV046C	MPV-046-C-B-A-B-T-B-B-BA-V-A-BFF-AB-D-AA-A-NNN-***	M46	M46-046PV
83007090	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-AB-80-P-3-F1-F-05-GBA-42-42-24	SERIES 90	S90-130PV
83007095	PUMP-VAR DISPL, CW 90PV075	90-R-075-CA-2-CD-80-E-3-C6-D-00-GFD-40-38-24-B010	SERIES 90	S90-075PV
83007096	PUMP-VAR DISPL, CW 90PV075	90-R-075-LE-2-BC-80-E-3-S1-D-03-GFD-40-38-24	SERIES 90	S90-075PV
83007097	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-C8-N-T2-CA-N-N-X1-NNN-055-AA-F3-00-23	SERIES 51	S51-110MV-1
83007098	PUMP-VAR DISPL, CCW 90PV075	90-L-075-ME-1-NN-80-S-3-S1-C-03-GBA-35-35-20	SERIES 90	S90-075PV
83007105	PUMP-VAR-DISPL CCW 90PV130	90L130-HS-1-AB-80-L-4-F1-F-03-GBA-35-35-24	SERIES 90	S90-130PV
83007106	PUMP-VAR-DISPL CCW 90PV180	90L180-HS-1-BC-80-T-C-F1-H-03-FAC-35-35-24	SERIES 90	S90-180PV
83007107	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KT-5-AB-80-P-4-S1-F-00-GBA-32-32-24	SERIES 90	S90-100PV
83007108	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A4-C1-N-D8-H-G1-NN-L-23-L-23-F-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83007109	PUMP-VAR-DISPL CCW H1PV130	H1-P-130-L-B-A4-C1-N-D8-G-G3-NN-L-23-L-23-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83007110	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-AB-60-S-4-C6-C-03-GBA-32-32-24	SERIES 90	S90-055PV
83007112	MOTOR-VAR-DISPL 51MC060-1	51C060-1--H-D1-N-B7-B3-N-N-U3-ABA-032-AA-E6-00-00	SERIES 51	S51-060MV-1
83007114	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-NN-80-T-M-C8-J-03-NNN-35-35-30	SERIES 90	S90-180PV
83007125	MOTOR-VAR-DISPL H1B080	H1-B-080-A-E1-AA-N-A-TA-VS-AS-S-A-10-NN-046-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83007128	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HF-1-AB-80-R-3-S1-D-00-GBA-35-35-24	SERIES 90	S90-075PV
83007133	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-BC-80-P-3-F1-E-03-GBA-14-35-24	SERIES 90	S90-100PV
83007140	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-K-S-B-J-BA-A-A-BGG-CE-A-HH-B-NNN-***	M46	M46-046PV
83007142	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-NN-60-P-3-S1-D-03-EBC-38-38-24	SERIES 90	S90-075PV
83007148	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-CD-80-P-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-075PV
83007149	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-CD-80-S-3-C7-E-03-GBA-38-38-24	SERIES 90	S90-075PV
83007150	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-H-S-B-B-AA-A-A-BJJ-BA-A-GA-A-NNN-***	M46	M46-046PV

83007151	PUMP-VAR DISPL, CW 90PV055	90-R-055-FC-2-NN-60-R-3-S1-C-B1-GBA-26-26-20	SERIES 90	S90-055PV
83007157	MOTOR-VAR-DISPL 51MV060-1	51V060-1--A-S1-N-TA-CA-N-N-X1-ABA-018-AA-E6-00-13	SERIES 51	S51-060MV-1
83007158	PUMP-VAR DISPL, CW 90PV075	90-R-075-CA-2-CD-80-E-3-C6-D-00-GFD-40-34-24	SERIES 90	S90-075PV
83007159	PUMP-VAR DISPL, CW 90PV075	90-R-075-LE-2-BC-80-E-3-S1-D-03-GFD-40-34-24	SERIES 90	S90-075PV
83007161	PUMP-VAR DISPL, CW 90PV075	90-R-075-CA-2-CD-80-E-3-C6-D-00-GFD-40-34-24-B010	SERIES 90	S90-075PV
83007163	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MA-1-NN-80-S-3-F1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
83007164	PUMP-VAR DISPL, CW 90PV075	90-R-075-HS-1-AB-80-S-3-S1-E-03-GBA-29-29-24	SERIES 90	S90-075PV
83007166	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-N-A2-C2-N-E7-F-G1-NN-33-33-33-33-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83007168	PUMP-VAR-DISPL CW 90PV180	90R180-PB-5-BC-80-T-C-F1-J-00-NNN-42-42-28	SERIES 90	S90-180PV
83007171	PUMP-VAR DISPL, CW 90PV055	90-R-055-KN-1-AD-80-P-3-S1-D-03-GBA-32-32-24	SERIES 90	S90-055PV
83007172	PUMP-VAR DISPL, CW 90PV055	90-R-055-KN-1-CD-80-P-3-C6-D-03-GBA-32-32-24	SERIES 90	S90-055PV
83007184	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-B-S-B-J-BA-G-A-BFF-CD-A-GG-3-NNN-***	M46	M46-046PV
83007188	MOTOR-VAR-DISPL 51MD160	51D160-A-D4-N-D7-M1-S-K-M4-NNN-032-AA-F3-F4-26	SERIES 51	S51-160MV
83007189	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-5-AB-60-S-4-C6-D-C6-GBA-45-45-24	SERIES 90	S90-055PV
83007191	MOTOR-FIX DISPL MMF044D	MMF-044-D-A-N-H-C-D-NNN-***	M35/44	044MF
83007192	MOTOR-FIXED DISPL MMF025C	MMF-025-C-A-N-R-C-D-NNN-***	LIGHT DUTY	025MF
83007197	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A5-C2-B-F7-F-G5-T3-42-42-42-42-M-P-24-PN-NNN-S02	H1-MP PUMPS	H1-045PT/053PT
83007198	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KN-1-CD-60-S-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83007200	PUMP-TANDEM, VAR DISPL CCW H1T053L	H1-T-053-L-A-N-A5-C2-N-F7-F-G5-H3-23-23-23-23-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83007201	PUMP-VAR DISPL, CCW 90PV055	90-L-055-CA-1-NN-80-R-3-S1-C-00-GBA-38-38-24	SERIES 90	S90-055PV
83007202	MOTOR-VAR-DISPL 51MD110	51D110-A-D3-N-J2-K1-C-E-H4-NNN-027-AA-E6-20-16	SERIES 51	S51-110MV
83007221	MOTOR-VAR-DISPL H1B110	H1-B-110-A-L2-BA-N-B-PB-VN-EN-N-A-10-NN-030-N-00-NNN	H1-HP MOTORS	H1-110MB1
83007224	PUMP-VAR-DISPL CCW 90PV042	90L042-HF-5-NN-80-P-4-C3-C-03-GBA-32-32-24	SERIES 90	S90-042PV
83007225	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A3-C2-B-E6-F-G1-H3-L-40-L-40-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83007227	PUMP-VAR DISPL, CW 90PV100	90-R-100-FC-1-CD-80-P-7-S1-E-B1-GBA-29-29-28	SERIES 90	S90-100PV
83007228	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-A-V-C-J-AA-B-B-G-A-BHH-DB-A-SS-B-D-G-A-BHH-DB-A-SS-C-NNN-*	M46	M46-046PT
83007229	MOTOR-VAR-DISPL H1B060	H1-B-060-A-L1-BA-N-B-PA-VS-AS-S-A-10-NN-000-N-00-NNN	H1-HP MOTORS	H1-060MB1
83007230	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-T2-C0-L-N-G0-ADA-070-AA-H0-00-C2	SERIES 51	S51-250MV
83007232	PUMP-VAR-DISPL CCW H1PV115	H1-P-115-L-B-A4-C2-N-D6-G-G3-NN-L-40-L-40-A-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83007233	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A2-C2-N-F6-H-G1-H6-L-40-L-40-C-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83007234	MOTOR-VAR-DISPL 51MV110	51V110-R-F1-N-L2-B2-V-A-H7-NNN-022-AA-NN-B2-00	SERIES 51	S51-110MV
83007237	PUMP-VAR-DISPL CW 90PV042	90R042-MA-5-BB-80-P-3-C3-C-C5-GBA-45-45-24	SERIES 90	S90-042PV
83007238	PUMP-VAR-DISPL CW 90PV042	90R042-MA-5-AB-80-P-3-C3-C-C5-GBA-45-45-24	SERIES 90	S90-042PV
83007239	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-1-NN-80-R-3-S1-C-03-GBA-14-14-24	SERIES 90	S90-055PV
83007240	PUMP-VAR DISPL, CW 90PV075	90-R-075-MB-1-BB-60-P-3-C7-D-03-GBA-40-40-24	SERIES 90	S90-075PV
83007243	PUMP-VAR DISPL, CW 90PV075	90-R-075-HS-1-AB-80-S-3-S1-E-03-GBA-38-38-24	SERIES 90	S90-075PV

83007245	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A8-C2-C-E6-F-G5-NN-L-25-L-25-B-L-24-P1-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83007246	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-K-S-B-J-BA-A-A-BGG-CE-A-GG-B-NNN-***	M46	M46-046PV
83007249	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-CD-80-S-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83007252	MOTOR-VAR-DISPL H1B080	H1-B-080-A-E2-AA-N-B-TB-VN-AN-N-A-10-NN-022-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83007256	PUMP-VAR-DISPL CW 90PV180	90R180-KN-5-EF-80-S-C-F1-J-03-NNN-42-42-24	SERIES 90	S90-180PV
83007257	PUMP-VAR-DISPL CW 90PV180	90R180-KN-5-AB-80-S-C-F1-J-03-NNN-42-42-24	SERIES 90	S90-180PV
83007259	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-5-CD-80-S-3-S1-D-03-GBA-45-45-24	SERIES 90	S90-055PV
83007260	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-5-NN-80-S-3-S1-D-03-GBA-45-45-24	SERIES 90	S90-055PV
83007262	PUMP-VAR-DISPL CW 90PV130	90R130-FH-5-BC-80-P-7-F1-F-B1-GCA-40-40-28	SERIES 90	S90-130PV
83007263	PUMP-VAR-DISPL CW 90PV042	90R042-DC-5-NN-80-S-3-C3-C-GB-GBA-42-42-24	SERIES 90	S90-042PV
83007264	PUMP-VAR DISPL, 42PV028 CW	42-R-28-G-E1A6-02-B-2-G-2-F-N-N-17-14-B-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83007268	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-S1-N-E1-B1-N-N-U1-NNN-050-AA-F3-00-00	SERIES 51	S51-080MV-1
83007269	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-NN-80-L-3-C8-F-03-GBA-38-14-30	SERIES 90	S90-130PV
83007273	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-N-A2-C2-N-D1-F-G1-NN-33-33-33-33-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83007277	MOTOR-VAR-DISPL H1B110	H1-B-110-A-K1-K1-N-B-RB-VS-ES-S-A-10-NN-000-N-23-NNN	H1-HP MOTORS	H1-110MB1
83007278	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-HZ-B1-B-E-G5-NNN-020-AA-E6-07-00	SERIES 51	S51-080MV
83007280	PUMP-VAR-DISPL CW 90PV075	90R075-NA-5-NN-80-P-3-C7-D-03-GBA-32-32-24	SERIES 90	S90-075PV
83007284	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-N-A4-C2-B-E7-F-G1-T3-35-35-35-35-M-P-20-PN-NNN-S01	H1-MP PUMPS	H1-045PT/053PT
83007289	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-B8-C2-C-D3-G-G2-H6-L-42-L-42-A-M-30-P1-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83007290	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A5-C2-B-D8-F-G5-NN-L-33-L-33-B-P-28-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83007291	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A5-C2-B-D8-F-G5-H5-L-33-L-33-B-P-28-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83007292	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-TA-C2-L-N-G0-NNN-065-AA-F0-00-A3	SERIES 51	S51-160MV
83007293	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MA-1-NN-60-R-3-S1-E-03-GBA-17-17-24	SERIES 90	S90-100PV
83007294	PUMP- VARIABLE, DIRECT DISPLACMENT	LPV-C-A-A-A-A-E-AA-C-A-BDD-DL-A-FF-B-NNN-***	LPV	LPV
83007300	PUMP-TANDEM, VAR DISPL CCW H1T053L	H1-T-053-L-A-N-A5-C2-N-E7-F-G1-H2-28-28-28-28-N-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83007303	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-CD-60-L-3-F1-E-02-GBA-38-38-24	SERIES 90	S90-100PV
83007305	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-CD-80-P-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83007310	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KN-5-NN-60-S-4-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83007311	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A2-C1-N-D1-F-G1-T1-25-25-25-25-M-P-20-PN-NNN-S01	H1-MP PUMPS	H1-045PT/053PT
83007314	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-BC-80-P-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83007315	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-8-N-0-C7-W-00-EBA-00-00-F0	SERIES 90	S90-100MF
83007316	PUMP-VAR-DISPL CW 90PV075	90R075-HS-5-CD-80-R-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83007317	PUMP-VAR-DISPL CW 90PV075	90R075-HS-5-BC-80-R-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83007318	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-CD-80-L-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83007319	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A8-C1-C-E9-F-G5-H1-K-35-K-35-B-P-24-P1-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83007321	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-C8-N-T7-D7-N-N-X1-ADA-064-AA-F0-00-13	SERIES 51	S51-110MV-1

83007324	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A4-C2-B-F1-F-G4-NN-K-35-K-35-B-L-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83007326	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A3-C2-N-E7-F-G5-H3-30-30-30-30-N-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83007327	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-T2-C0-L-N-G0-AHA-110-AA-G0-00-C6	SERIES 51	S51-250MV
83007328	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-T2-C0-L-N-G0-NNN-110-AA-G0-00-C6	SERIES 51	S51-250MV
83007331	MOTOR-VAR-DISPL H1B080	H1-B-080-A-M1-CA-N-B-RA-VS-AS-S-N-NN-NN-049-N-00-NNN	H1-HP MOTORS	H1-080MB1
83007336	PUMP-TANDEM, VAR DISPL CCW H1T053L	H1-T-053-L-A-N-A5-C2-B-E7-F-G1-H2-30-30-30-30-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83007342	MOTOR-VAR-DISPL 51MD110-1	51D110-1--R-D3-N-E2-B1-N-N-U1-NNN-060-AA-F3-00-00	SERIES 51	S51-110MV-1
83007348	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A4-C3-N-D8-F-G5-H3-L-33-L-33-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83007349	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A4-C2-N-E7-F-G5-H1-35-35-35-35-N-P-32-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83007350	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-A-A2-C1-N-D1-F-G5-NN-40-40-20-20-N-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83007351	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-A-A2-C1-N-E7-F-G1-NN-35-35-35-35-N-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83007352	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A2-C1-N-D1-F-G5-NN-42-42-42-42-N-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83007353	PUMP-TANDEM, VAR DISPL CCW H1T045L	H1-T-045-L-A-N-A4-C2-N-D1-F-G1-H2-42-42-42-42-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83007354	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-CD-60-P-3-F1-F-03-GBA-32-32-24	SERIES 90	S90-100PV
83007355	MOTOR-VAR-DISPL H1B060	H1-B-060-A-E1-AA-N-A-TB-CS-GS-S-A-05-NN-012-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83007356	MOTOR-VAR-DISPL H1B060	H1-B-060-A-K2-K2-N-B-RB-VS-AS-S-A-10-NN-012-N-21-NNN	H1-HP MOTORS	H1-060MB1
83007357	MOTOR-VAR-DISPL H1B060	H1-B-060-A-T1-D1-N-B-TA-CS-GS-S-A-05-NN-012-Z-21-NNN	H1-HP MOTORS	H1-060MB1
83007360	PUMP-VAR-DISPL CCW 90PV100	90L100-HF-5-NN-80-S-3-C6-E-03-GBA-42-42-28	SERIES 90	S90-100PV
83007361	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-AB-80-S-3-C7-F-03-GBA-38-38-24	SERIES 90	S90-100PV
83007363	PUMP-VAR-DISPL CCW 90PV075	90L075-MA-5-BB-80-S-3-C7-D-C6-GBA-34-34-24	SERIES 90	S90-075PV
83007365	MOTOR-VAR-DISPL 51MV060-1	51V060-1--A-S1-N-TA-D1-N-N-X1-NNN-040-AA-E4-00-13	SERIES 51	S51-060MV-1
83007370	PUMP-VAR DISPL, CW 90PV100	90-R-100-KT-5-BB-80-P-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
83007373	PUMP-VAR-DISPL CCW 90PV250	90L250-KN-5-EF-80-S-3-C8-J-03-NNN-29-29-24	SERIES 90	S90-250PV
83007374	PUMP-VAR-DISPL CCW 90PV250	90L250-KN-5-BC-80-S-3-F1-J-03-NNN-29-29-24	SERIES 90	S90-250PV
83007375	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A8-C3-C-D3-H-G9-H3-L-38-L-38-C-M-30-P1-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83007377	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-BC-80-S-4-S1-E-21-FAD-35-26-30	SERIES 90	S90-075PV
83007378	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-CD-80-P-3-S1-D-00-GBA-42-42-24	SERIES 90	S90-055PV
83007380	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-A-V-C-B-AA-B-A-G-A-BJJ-AB-D-BA-B-C-G-A-BJJ-AB-D-BA-A-NNN-**	M46	M46-046PT
83007381	MOTOR-VAR-DISPL 51MV060-1	51V060-1--R-S1-N-TA-C2-N-N-X1-NNN-035-AA-E4-00-21	SERIES 51	S51-060MV-1
83007383	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-CD-80-P-3-C7-F-03-EHA-35-35-24	SERIES 90	S90-100PV
83007392	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A4-C2-N-D6-F-G4-H3-L-35-L-35-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83007393	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-BC-80-L-3-C7-E-03-GBA-30-30-24	SERIES 90	S90-075PV
83007394	PUMP-VAR-DISPL CW 90PV100	90R100-MA-5-AB-80-L-4-C7-E-C7-GBA-29-29-24	SERIES 90	S90-100PV
83007398	PUMP-VAR-DISPL CCW 90PV042	90L042-HF-5-AB-80-S-3-C3-C-03-GBA-17-17-18	SERIES 90	S90-042PV
83007403	PUMP-VAR-DISPL CW 90PV130	90R130-KA-1-NN-80-L-3-F1-H-03-GBA-35-35-24	SERIES 90	S90-130PV
83007404	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-1-BC-80-L-4-F1-F-03-GBA-32-32-20	SERIES 90	S90-130PV

83007405	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A4-C2-B-D3-H-F1-H5-L-42-L-42-C-M-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83007406	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A4-C2-B-D8-J-G5-NN-L-42-L-42-B-P-24-P4-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83007410	MOTOR-VAR-DISPL H1B080	H1-B-080-A-L1-BA-N-A-PA-VS-AS-S-A-10-NN-045-N-00-NNN	H1-HP MOTORS	H1-080MB1
83007411	PUMP-VAR-DISPL CCW 90PV250	90L250-MA-5-NN-80-S-4-F1-J-C5-NNN-42-42-24	SERIES 90	S90-250PV
83007412	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-AB-80-R-3-F1-F-03-GBA-32-32-24	SERIES 90	S90-100PV
83007416	MOTOR-VAR-DISPL H1B110#	H1-B-110-A-T1-D1-N-B-TB-VS-ES-S-A-10-NN-022-Z-23-NNN	H1-HP MOTORS	H1-110MB1
83007417	MOTOR-VARIABLE CARTRIDGE K	K-C-38CN-A-YNF-F45-S-N-N-AF-F15-NNN-NNN	LV / KV MOTORS	L/K-MV
83007419	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-AB-80-S-M-F1-H-03-FAC-26-26-24	SERIES 90	S90-180PV
83007420	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-BC-80-S-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83007421	PUMP-VAR-DISPL CW 90PV100	90R100-MA-5-AB-60-L-3-C7-E-C5-GBA-42-42-24-N345	SERIES 90	S90-100PV
83007423	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-NN-80-R-3-S1-D-03-EEB-38-38-20	SERIES 90	S90-075PV
83007427	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-T1-C0-L-N-G0-NNN-090-AA-F3-00-B0	SERIES 51	S51-160MV
83007428	MOTOR-VAR-DISPL 51MC060-1	51C060-1--A-D1-N-E2-B1-N-N-U1-NNN-022-AA-NN-00-00	SERIES 51	S51-060MV-1
83007430	MOTOR-VAR-DISPL H1B080	H1-B-080-A-HE-HE-N-A-TB-CN-JN-N-N-NN-NN-016-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83007432	PUMP-VAR DISPL, CW 90PV100	90-R-100-FC-5-CD-80-P-7-F1-F-B1-GCA-38-38-24	SERIES 90	S90-100PV
83007433	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-BC-60-S-4-K2-D-03-GBA-23-23-24-F058	SERIES 90	S90-075PV
83007441	MOTOR-VAR-DISPL H1B110#	H1-B-110-A-E2-AA-N-B-TB-DN-KN-N-N-NN-NN-065-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83007447	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-NN-80-S-C-F1-J-03-FAC-29-29-22	SERIES 90	S90-180PV
83007448	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-K-S-B-B-AA-G-A-BFF-CD-A-ZG-B-NNN-***	M46	M46-046PV
83007450	PUMP-VAR DISPL, CW 90PV075	90-R-075-DD-1-AB-80-S-4-S1-D-GB-GBA-32-32-24	SERIES 90	S90-075PV
83007451	PUMP-VAR DISPL, CW 90PV075	90-R-075-HS-2-CD-60-P-3-C7-E-00-GBA-38-38-24	SERIES 90	S90-075PV
83007452	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-BC-80-L-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
83007453	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-T2-C0-L-N-K7-NNN-072-AA-G0-00-A7	SERIES 51	S51-250MV
83007454	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-NN-60-R-3-S1-C-03-GBA-45-45-24	SERIES 90	S90-055PV
83007456	PUMP-VAR DISPL, 42PV041 CCW	42-L-41-D-E1A3-03-A-N-A-2-G-N-B-23-23-B-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83007458	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-N2-NN-N-N-A0-NNN-168-AA-H0-00-00	SERIES 51	S51-250MV
83007464	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A2-C1-B-D6-F-G5-NN-L-35-L-35-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83007473	PUMP-VAR DISPL, CCW 90PV055	90-L-055-DD-5-BC-60-S-4-S1-C-G8-GBA-26-26-20	SERIES 90	S90-055PV
83007474	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-5-BC-60-S-4-S1-C-G8-GBA-26-26-20	SERIES 90	S90-055PV
83007475	MOTOR-FIX DISPL MMF035D	MMF-035-D-A-F-H-C-V-NNR-***	M35/44	035MF
83007476	PUMP-TANDEM, VAR DISPL MPT035D	MPT-035-D-A-R-R-F-AA-B-A-A-A-BDD-DR-A-FF-B-C-A-A-BDD-DR-A-FF-B-NNN-*	M35/44	035PT
83007484	PUMP-VAR DISPL, CW 90PV075	90-R-075-HS-2-BC-60-P-3-S1-E-00-GBA-38-38-24	SERIES 90	S90-075PV
83007485	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MA-1-NN-60-S-3-S1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
83007486	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-NN-80-S-3-C8-H-00-GBA-35-35-28	SERIES 90	S90-130PV
83007487	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-C8-N-T2-C2-N-N-X1-NNN-024-AA-F3-00-26	SERIES 51	S51-110MV-1
83007492	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-B-T-B-B-AA-A-A-BGG-CH-A-GG-3-NNN-***	M46	M46-046PV

83007493	PUMP-VAR-DISPL CW 90PV180	90R180-HF-5-EF-80-T-C-F1-J-03-FAC-26-26-24	SERIES 90	S90-180PV
83007494	PUMP-VAR-DISPL CW 90PV180	90R180-HF-5-NN-80-T-C-F1-J-03-FAC-26-26-24	SERIES 90	S90-180PV
83007499	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A4-C2-B-D8-J-G5-NN-L-42-L-42-B-P-24-P4-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83007500	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-A-A2-C2-N-D6-H-F1-NN-L-42-L-42-D-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83007503	MOTOR-VAR-DISPL H1B060	H1-B-060-A-HE-HE-N-C-TB-CN-GN-N-N-NN-NN-028-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83007505	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-5-CD-80-S-3-F1-F-03-GBA-32-32-24	SERIES 90	S90-100PV
83007509	PUMP- VARIABLE, DIRECT DISPLACMENT	LPV-A-A-A-A-A-G-AC-C-A-BGG-DR-A-A-FF-B-NNN-***	LPV	LPV
83007510	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-1-BG-80-L-3-C6-C-GB-GBA-23-23-24	SERIES 90	S90-055PV
83007512	PUMP-VAR-DISPL CW 90PV130	90R130-DD-5-NN-80-L-3-C8-H-GB-GBA-35-35-24	SERIES 90	S90-130PV
83007516	PUMP-VAR DISPL, 42PV028 CW	42-R-28-C-ANNB-03-C-3-A-2-H-N-N-32-32-B-H-H-NNN-NNN	SERIES 42	S42-028PV/032PV
83007518	PUMP-VAR DISPL, 42PV028 CW	42-R-2A-D-E2C7-02-B-D-X-N-F-N-A-38-38-N-N-N-AAA-NNN	SERIES 42	S42-028PV/032PV
83007519	MOTOR-VARIABLE CARTRIDGE K	K-C-38CS-E-R1F-F07-S-N-N-EF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83007542	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HF-1-BG-80-P-3-S1-C-03-GBA-38-38-24	SERIES 90	S90-055PV
83007550	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-NN-60-S-3-C6-C-03-GBA-42-42-24	SERIES 90	S90-055PV
83007552	PUMP-VAR DISPL, CW 90PV055	90-R-055-HS-1-CD-80-S-3-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83007554	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-NN-60-S-4-S1-E-00-GBA-42-42-24	SERIES 90	S90-100PV
83007556	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-N-T2-C2-L-N-K7-NNN-060-AA-F3-00-B5	SERIES 51	S51-160MV
83007557	MOTOR-VAR-DISPL 51MV110-1	51V110-1--A-F1-N-F2-B1-N-N-U1-ADA-074-AA-F3-00-00	SERIES 51	S51-110MV-1
83007559	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-NN-80-R-3-K2-D-03-GBA-20-20-24	SERIES 90	S90-075PV
83007560	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-NN-80-R-3-K2-D-03-GBA-23-23-24	SERIES 90	S90-075PV
83007562	MOTOR-VAR-DISPL 51MD060-1	51D060-1--R-D2-N-B2-B3-N-N-U3-NNN-024-AA-NN-00-00	SERIES 51	S51-060MV-1
83007564	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-BC-80-P-3-F1-H-03-GBA-42-42-24	SERIES 90	S90-130PV
83007565	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-N-TH-C0-L-N-G0-NNN-062-AA-G3-00-C2	SERIES 51	S51-250MV
83007566	MOTOR-VAR-DISPL 51MV110-1	51V110-1--A-F1-E-N1-NN-N-N-U1-NNN-030-AA-NN-00-00	SERIES 51	S51-110MV-1
83007567	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A2-C2-N-D6-F-G5-H2-L-40-L-40-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83007568	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A2-C2-N-D6-F-G5-H5-L-40-L-40-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83007578	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-Z-Z-C-S-BA-B-A-A-A-BJJ-AB-U-DD-B-C-A-A-BJJ-AB-U-DD-C-NNN-***	M46	M46-046PT
83007584	MOTOR-VAR-DISPL 51MV250	51V250-A-C8-N-HS-A1-B-H-E2-NNN-110-AA-G3-07-19	SERIES 51	S51-250MV
83007586	PUMP-VAR DISPL, CW 90PV075	90-R-075-KT-1-NN-80-R-3-S1-D-00-GBA-35-35-28	SERIES 90	S90-075PV
83007590	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-K-S-B-J-BA-A-A-BDD-CE-A-HH-B-NNN-***	M46	M46-046PV
83007598	PUMP-VAR DISPL, CW 90PV075	90-R-075-HF-1-CD-80-L-3-C6-E-02-GBA-29-29-24	SERIES 90	S90-075PV
83007606	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-BC-60-P-3-S1-E-03-GBA-17-17-24	SERIES 90	S90-100PV
83007609	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HF-1-BC-80-R-3-F1-E-05-GBA-38-38-24	SERIES 90	S90-100PV
83007610	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-BC-80-P-3-F1-E-03-GBA-23-26-24	SERIES 90	S90-100PV
83007611	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-C7-N-E1-B1-N-N-U1-NNN-030-AA-F3-00-00	SERIES 51	S51-080MV-1
83007618	PUMP-VAR-DISPL CW 90PV075	90R075-HF-5-NN-80-S-4-S1-D-03-GBA-26-26-24	SERIES 90	S90-075PV

83007619	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-AB-60-S-4-C7-F-04-GBA-35-35-24	SERIES 90	S90-100PV
83007621	PUMP-VAR DISPL, CW 90PV055	90-R-055-MB-1-BG-80-P-3-C6-D-03-GBA-35-35-24	SERIES 90	S90-055PV
83007622	PUMP-TANDEM, VAR DISPL CCW H1T053L	H1-T-053-L-A-N-A2-C2-N-E7-F-G1-H3-38-38-38-38-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83007623	MOTOR-VAR-DISPL H1B080	H1-B-080-A-E2-AA-N-B-TB-VS-AS-S-A-10-NN-049-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83007628	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-1-NN-80-S-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83007629	PUMP-VAR-DISPL CCW 90PV100	90L100-KN-5-NN-60-S-3-C7-E-04-GCA-32-32-24	SERIES 90	S90-100PV
83007635	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-BC-80-L-3-F1-E-02-GBA-35-35-24	SERIES 90	S90-100PV
83007637	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A2-C2-N-E5-F-G4-H3-L-23-L-23-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83007643	PUMP-VAR DISPL, 42PV028 CW	42-R-2A-C-G2A1-53-U-3-B-2-H-1-A-30-30-B-0-0-AAA-NNN	SERIES 42	S42-028PV/032PV
83007644	PUMP-VAR DISPL, 42PV028 CW	42-R-28-C-G3AN-52-P-3-G-2-F-5-A-25-25-B-1-1-NNN-NNN	SERIES 42	S42-028PV/032PV
83007645	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-BC-80-S-4-F1-E-00-GBA-42-42-24	SERIES 90	S90-100PV
83007646	PUMP-VAR DISPL, 42PV028 CW	42-R-28-C-ANN3-02-B-4-B-2-C-N-B-21-21-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83007649	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-N-A2-C1-N-E7-F-G1-H2-25-25-25-25-N-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83007650	PUMP-VAR DISPL, 42PV041 CW	42-R-41-D-F2NN-72-J-3-X-N-G-N-A-34-34-N-A-A-NNN-NNN	SERIES 42	S42-041PV/051PV
83007651	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-L2-B1-V-A-C0-NNN-080-AA-E6-B2-00	SERIES 51	S51-160MV
83007655	PUMP-VAR-DISPL CCW 90PV100	90L100-FB-5-CD-60-P-7-C7-F-B1-GCA-40-40-28	SERIES 90	S90-100PV
83007660	PUMP-VAR DISPL CCW H1P053L	H1-P-053-L-A-A2-C2-N-E5-F-G4-H3-L-23-L-23-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83007666	PUMP-VAR-DISPL CW 90PV130	90R130-HF-5-CD-80-L-3-C8-H-02-GBA-42-42-24	SERIES 90	S90-130PV
83007667	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-AB-80-S-4-C7-F-04-GBA-35-35-24	SERIES 90	S90-100PV
83007671	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-NN-80-P-3-C7-D-00-GBA-35-35-24	SERIES 90	S90-075PV
83007672	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-L2-B1-V-A-C0-NNN-080-AA-F0-B2-00	SERIES 51	S51-160MV
83007673	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-A-T-B-B-AA-J-A-BHH-CB-A-HH-5-NNN-***	M46	M46-046PV
83007676	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-V-S-B-B-BA-A-A-BDD-CB-A-HH-5-NNN-***	M46	M46-046PV
83007677	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A3-C3-N-D8-G-G2-H4-K-38-K-38-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83007678	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A3-C3-N-D8-G-G3-H2-K-38-K-38-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83007679	PUMP-VAR-DISPL CCW H1PV130	H1-P-130-L-B-A3-C3-N-D8-G-G2-H4-K-38-K-38-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83007680	PUMP-VAR-DISPL CCW H1PV130	H1-P-130-L-B-A3-C3-N-D8-G-G3-H2-K-38-K-38-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83007684	PUMP-VAR DISPL, 42PV041 CW	42-R-41-D-E1A6-03-B-5-B-2-C-N-B-21-21-N-A-A-NNN-NNN	SERIES 42	S42-041PV/051PV
83007685	PUMP-VAR DISPL, 42PV041 CW	42-R-41-C-E1A6-03-B-5-B-2-C-N-B-21-21-N-A-A-NNN-NNN	SERIES 42	S42-041PV/051PV
83007687	MOTOR-VAR-DISPL 51MC160	51C160-R-D5-N-HZ-B1-B-N-C2-NNN-065-AA-F0-10-00	SERIES 51	S51-160MV
83007688	MOTOR-VAR-DISPL 51MC160	51C160-R-D5-N-HZ-B1-B-N-C2-NNN-080-AA-F0-10-00	SERIES 51	S51-160MV
83007691	PUMP-VAR-DISPL CW 90PV130	90R130-MA-5-BC-80-L-4-C8-H-C5-GBA-35-35-24	SERIES 90	S90-130PV
83007697	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A4-C2-N-E7-F-G5-NN-28-28-23-23-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83007698	PUMP-VAR-DISPL CCW 90PV130	90L130-HF-5-AB-80-R-3-F1-F-00-GBA-35-35-24	SERIES 90	S90-130PV
83007700	MOTOR-VAR-DISPL 51MC160	51C160-A-D4-N-HZ-B1-A-N-G0-NNN-040-AA-NN-03-00	SERIES 51	S51-160MV
83007701	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A5-C1-N-D8-F-G4-NN-L-38-L-38-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV

83007702	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A2-C2-N-E7-F-G1-TN-35-35-35-35-M-P-30-PN-NNN-S02	H1-MP PUMPS	H1-045PT/053PT
83007704	PUMP-VAR DISPL, 42PV028 CW	42-R-28-D-E1A3-00-B-3-G-3-G-N-B-34-34-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83007705	PUMP-VAR DISPL, 42PV028 CW	42-R-28-C-E1A3-00-B-3-G-3-G-N-A-34-34-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83007706	PUMP-VAR DISPL, 42PV028 CW	42-R-28-C-E1B6-03-B-2-B-2-E-N-B-17-17-B-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83007707	PUMP-VAR DISPL, 42PV028 CW	42-R-28-C-E1A4-02-B-3-G-2-F-N-B-21-21-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83007726	MOTOR-VAR-DISPL H1B080	H1-B-080-A-T1-DA-N-B-TB-VN-AN-N-N-NN-NN-040-Z-21-NNN	H1-HP MOTORS	H1-080MB1
83007729	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-5-CD-80-S-3-S1-D-03-GBA-41-41-24	SERIES 90	S90-075PV
83007730	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-5-NN-80-S-3-S1-D-03-GBA-41-41-24	SERIES 90	S90-075PV
83007731	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-HZ-B1-A-H-C2-NNN-029-AA-F0-03-00	SERIES 51	S51-080MV
83007732	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-TA-C2-L-N-G0-ABA-107-AA-G3-00-C5	SERIES 51	S51-250MV
83007737	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-E-N2-NN-N-N-A0-NNN-094-AA-F3-00-00	SERIES 51	S51-160MV
83007739	PUMP-VAR DISPL CCW H1P053L	H1-P-053-L-A-A5-C2-N-D6-F-G1-H3-L-35-L-35-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83007740	PUMP-VAR DISPL CCW H1P053L	H1-P-053-L-A-A5-C2-N-D6-F-G1-H5-L-35-L-35-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83007741	PUMP-VAR DISPL CCW H1P053L	H1-P-053-L-A-A5-C2-N-D8-F-G5-H3-L-35-L-35-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83007743	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-CD-60-L-4-F1-E-00-GBA-26-26-24	SERIES 90	S90-100PV
83007744	PUMP-VAR-DISPL CW 90PV130	90R130-DD-5-CD-80-L-3-C8-H-GB-GBA-23-23-24	SERIES 90	S90-130PV
83007745	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-HZ-B1-A-N-G0-NNN-090-AA-H0-03-00	SERIES 51	S51-250MV
83007746	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-NN-80-L-3-K3-E-02-GBA-23-23-24	SERIES 90	S90-100PV
83007748	MOTOR-VARIABLE DISPL SAE_L	L-V-25CN-A-RNF-F00-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83007762	PUMP-VAR DISPL CCW H1P053L	H1-P-053-L-A-A5-C2-N-D6-F-G5-H3-L-35-L-35-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83007763	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-D-TA-C2-L-N-G0-NNN-138-AA-G0-00-B0	SERIES 51	S51-250MV
83007764	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HF-2-CD-80-S-3-S1-D-00-GBA-38-38-20	SERIES 90	S90-055PV
83007765	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HF-2-AD-80-S-3-S1-D-00-GBA-38-38-20	SERIES 90	S90-055PV
83007767	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-5-CD-80-S-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
83007768	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-5-CD-80-S-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
83007769	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-5-NN-80-S-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
83007770	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-5-CD-80-S-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-055PV
83007771	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-5-NN-80-S-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-055PV
83007773	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-CD-80-S-3-C8-K-01-NNN-42-42-24	SERIES 90	S90-250PV
83007774	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-E-HS-A2-C-H-E1-NNN-140-AA-NN-12-17	SERIES 51	S51-250MV
83007775	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-B5-C3-C-D1-F-G8-H7-35-35-35-35-N-P-24-P1-C07-NNN	H1-MP PUMPS	H1-045PT/053PT
83007777	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-NN-80-P-4-S1-C-03-GBA-29-29-24	SERIES 90	S90-055PV
83007778	MOTOR-VAR-DISPL 51MC160	51C160-R-D5-N-L2-B1-V-A-C2-ACB-032-AA-G0-B2-00	SERIES 51	S51-160MV
83007787	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-5-CD-80-S-3-F1-F-03-GBA-45-45-28	SERIES 90	S90-100PV
83007788	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-5-AB-80-S-3-S1-F-03-GBA-45-45-28	SERIES 90	S90-100PV
83007789	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-1-AD-80-P-3-S1-C-03-GBA-32-32-24	SERIES 90	S90-055PV

83007793	PUMP-VAR DISPL, CW 90PV075	90-R-075-KN-1-AB-60-R-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83007794	PUMP-VAR-DISPL CCW 90PV180	90L180-PB-5-NN-80-T-M-F1-H-03-NNN-35-35-24	SERIES 90	S90-180PV
83007795	PUMP-VAR DISPL MPV046C	MPV-046-C-B-A-B-T-B-B-AA-A-A-BEE-AB-U-ED-A-NNN-***	M46	M46-046PV
83007798	PUMP-VAR-DISPL CW 90PV100	90R100-MA-5-NN-80-S-4-S1-E-C5-GBA-21-21-24	SERIES 90	S90-100PV
83007799	PUMP-VAR DISPL, 42PV028 CW	42-R-28-C-E1A5-00-A-N-A-2-E-N-A-B1-B1-N-A-A-NNN-ENN	SERIES 42	S42-028PV/032PV
83007800	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-L2-B1-V-A-C0-NNN-115-AA-G0-B2-00	SERIES 51	S51-160MV
83007802	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-NN-61-S-3-K3-E-03-GBA-23-23-24	SERIES 90	S90-100PV
83007810	MOTOR-VAR-DISPL H1B110	H1-B-110-A-L2-BA-N-B-PA-VS-DS-S-A-15-NN-074-N-00-NNN	H1-HP MOTORS	H1-110MB1
83007811	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-BC-80-P-3-F1-F-03-EBC-29-29-24	SERIES 90	S90-100PV
83007814	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A8-C2-C-E6-F-G5-NN-L-25-L-25-B-L-24-P1-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83007817	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-N2-NN-N-N-A0-NNN-140-AA-H0-00-00	SERIES 51	S51-250MV
83007818	PUMP-VAR DISPL, CCW 90PV075	90-L-075-DD-5-BC-80-S-4-S1-D-GB-GBA-26-26-24	SERIES 90	S90-075PV
83007819	MOTOR-VAR-DISPL H1B060	H1-B-060-A-M1-CA-N-B-RB-CS-GS-S-A-10-NN-000-N-00-NNN	H1-HP MOTORS	H1-060MB1
83007831	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-CD-80-L-4-C8-F-05-GBA-29-29-24	SERIES 90	S90-130PV
83007832	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-NN-60-S-3-C6-D-00-GBA-20-20-28	SERIES 90	S90-055PV
83007837	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-T2-C0-L-N-G0-NNN-098-AA-G0-00-B8	SERIES 51	S51-160MV
83007838	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A2-C2-N-D6-G-G3-H2-L-35-L-35-L-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83007839	PUMP-VAR-DISPL CCW 90PV130	90L130-MA-5-NN-80-R-3-F1-F-C5-GBA-42-42-24	SERIES 90	S90-130PV
83007840	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-TA-C0-L-N-G0-NNN-060-AA-F3-00-C2	SERIES 51	S51-160MV
83007856	PUMP-VAR DISPL, CCW 90PV055	90-L-055-MA-5-CD-60-S-3-C6-C-C5-GBA-42-42-24	SERIES 90	S90-055PV
83007858	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-NN-60-S-3-C6-C-04-GBA-32-32-24	SERIES 90	S90-055PV
83007859	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-B-S-B-J-BA-A-A-BJJ-BA-A-HH-A-NNN-***	M46	M46-046PV
83007869	PUMP-VAR DISPL, CW 90PV075 + SAE AUX KIT	90-R-075-MA-1-AB-80-S-3-C6-E-03-GBA-42-42-24	SERIES 90	S90-075PV
83007870	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-AB-80-P-3-F1-E-03-GBA-38-38-24	SERIES 90	S90-100PV
83007871	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-BC-80-S-4-C3-C-01-EFI-35-35-24	SERIES 90	S90-042PV
83007873	PUMP-VAR-DISPL CW 90PV180	90R180-HF-5-CD-80-T-C-F1-H-03-FAC-35-35-24	SERIES 90	S90-180PV
83007874	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-B5-C3-C-D1-F-G8-T8-35-35-35-35-M-P-24-P1-C07-S01	H1-MP PUMPS	H1-045PT/053PT
83007879	PUMP-VAR DISPL, CW 90PV100	90-R-100-HM-5-BC-60-P-3-F1-E-04-GBA-32-32-24	SERIES 90	S90-100PV
83007883	PUMP-VAR-DISPL CW 90PV180	90R180-MA-5-EG-80-T-M-C8-J-C7-NNN-29-29-24	SERIES 90	S90-180PV
83007884	PUMP-VAR-DISPL CW 90PV180	90R180-MA-5-CD-80-T-M-C8-J-C7-NNN-35-35-24	SERIES 90	S90-180PV
83007885	MOTOR-VAR-DISPL 51MV160	51V160-A-C8-N-HS-A2-B-E-E1-NNN-032-AA-F0-05-20	SERIES 51	S51-160MV
83007886	MOTOR-VAR-DISPL 51MV080	51V080-A-S1-N-N2-NN-N-N-A0-NNN-065-AA-E6-00-00	SERIES 51	S51-080MV
83007887	PUMP-TANDEM, VAR DISPL CCW H1T045L	H1-T-045-L-A-N-A5-C2-N-E7-F-G6-T3-35-35-30-30-M-P-24-PN-NNN-S01	H1-MP PUMPS	H1-045PT/053PT
83007889	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-DE-80-P-3-C8-F-03-GBA-35-35-24	SERIES 90	S90-130PV
83007890	PUMP-VAR DISPL, CW 90PV075	90-R-075-HS-1-AB-80-R-3-S1-E-03-GBA-20-20-24	SERIES 90	S90-075PV
83007893	MOTOR-VAR-DISPL 51MV060-1	51V060-1--A-S1-N-TA-D1-N-N-X1-NNN-040-AA-E4-00-24	SERIES 51	S51-060MV-1

83007894	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-NN-80-S-3-C7-E-03-GBA-45-45-24	SERIES 90	S90-100PV
83007900	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-1-AB-60-S-4-S1-D-G4-GBA-35-35-20	SERIES 90	S90-055PV
83007901	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-1-NN-60-S-4-S1-D-G4-GBA-35-35-20	SERIES 90	S90-055PV
83007906	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A2-C3-N-E7-F-G5-H3-38-38-38-38-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83007907	PUMP- VARIABLE, DIRECT DISPLACMENT	LPV-A-A-A-C-A-G-AB-C-A-BFF-DR-A-FF-B-NNN-***	LPV	LPV
83007911	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-CD-80-R-4-C6-C-03-GBA-32-32-28	SERIES 90	S90-055PV
83007917	PUMP-VAR-DISPL CCW 90PV130	90L130-KT-5-BC-80-P-3-F1-H-04-GBA-38-38-24	SERIES 90	S90-130PV
83007918	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-G-S-B-B-BA-A-A-BJJ-CN-A-HH-5-NNN-***	M46	M46-046PV
83007919	PUMP-VAR DISPL, CW 90PV075	90-R-075-DC-1-NN-80-R-4-T2-D-G4-GBA-45-45-24	SERIES 90	S90-075PV
83007920	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-BC-80-P-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-075PV
83007924	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-N-TH-C2-L-N-G0-NNN-088-AA-NN-00-B7	SERIES 51	S51-160MV
83007925	PUMP-VAR-DISPL CW 90PV100	90R100-KN-5-NN-80-S-4-C7-E-03-GBA-32-32-24	SERIES 90	S90-100PV
83007933	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A2-C3-N-D1-F-G7-H7-38-38-38-38-N-P-28-PN-C01-NNN	H1-MP PUMPS	H1-045PT/053PT
83007934	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-N-A2-C3-N-D1-F-G7-H7-35-35-35-35-N-P-28-PN-C01-NNN	H1-MP PUMPS	H1-045PT/053PT
83007938	PUMP-VAR-DISPL, 42PV028 CW	42-R-28-C-G3AN-53-T-N-D-2-F-1-B-21-21-B-1-1-NNN-NNN	SERIES 42	S42-028PV/032PV
83007944	PUMP-VAR-DISPL CCW 90PV042	90L042-KA-1-AB-80-S-4-C3-C-03-GBA-42-42-24	SERIES 90	S90-042PV
83007946	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-BG-80-R-4-S1-C-03-GBA-32-32-28	SERIES 90	S90-055PV
83007947	PUMP-VAR DISPL, CW 90PV055	90-R-055-HF-1-CD-80-P-3-S1-C-02-GBA-42-42-24	SERIES 90	S90-055PV
83007949	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-CD-80-P-4-C7-F-03-GBA-20-20-24	SERIES 90	S90-100PV
83007950	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-NN-80-P-4-S1-D-03-GBA-20-20-24	SERIES 90	S90-055PV
83007972	PUMP-VAR DISPL CCW H1P053L	H1-P-053-L-A-A5-C1-N-D8-F-G4-NN-L-35-L-35-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83007982	PUMP-VAR-DISPL CW 90PV042	90R042-DD-5-NN-80-P-4-C3-C-GB-GBA-42-42-24	SERIES 90	S90-042PV
83007987	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A4-C2-N-F2-F-G5-H2-K-35-K-35-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83007989	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KN-5-NN-60-P-3-C6-D-03-GBA-29-29-24	SERIES 90	S90-055PV
83007990	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A2-C3-D-E6-F-G1-NN-L-48-L-48-B-L-32-P1-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83007992	PUMP-VAR-DISPL CW 90PV075	90R075-MA-5-AB-60-R-4-S1-E-C5-GBA-21-21-24	SERIES 90	S90-075PV
83007994	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-CD-80-L-3-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83007995	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-CD-80-L-4-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83007996	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-CD-60-P-3-F1-E-03-GBA-32-32-24	SERIES 90	S90-100PV
83007997	PUMP-VAR DISPL, CW 90PV055	90-R-055-KN-1-CD-80-S-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
83007998	MOTOR-VAR-DISPL 51MV080	51V080-R-C7-N-HS-A2-B-E-E1-NNN-016-AA-F0-06-20	SERIES 51	S51-080MV
83008001	PUMP-VAR DISPL, CCW 90PV075	90-L-075-DC-1-NN-80-R-4-T2-D-G4-GBA-45-45-24	SERIES 90	S90-075PV
83008004	MOTOR-VAR-DISPL H1B080	H1-B-080-A-M2-CA-N-B-RB-DS-JS-S-A-15-NN-000-N-00-NNN	H1-HP MOTORS	H1-080MB1
83008005	PUMP-VAR-DISPL CW 90PV075	90R075-FN-5-BC-80-R-7-C7-D-B6-EFP-42-42-24	SERIES 90	S90-075PV
83008006	PUMP-VAR-DISPL CW 90PV075	90R075-DD-2-BC-80-S-4-C7-D-GB-GBA-26-26-24	SERIES 90	S90-075PV
83008007	PUMP-VAR DISPL, CW 90PV055	90-R-055-KN-1-CD-80-S-4-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV

83008008	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-BB-80-P-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83008009	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-BC-60-S-4-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83008010	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-AB-60-S-4-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83008014	PUMP-VAR DISPL, CW 90PV100	90-R-100-LV-1-BC-60-P-3-C7-E-03-GBA-40-40-24	SERIES 90	S90-100PV
83008016	PUMP-VAR DISPL CCW H1P053L	H1-P-053-L-A-A4-C1-N-E5-F-G5-H2-L-35-L-35-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83008017	PUMP-VAR DISPL CCW H1P053L	H1-P-053-L-A-A4-C1-N-E5-F-G5-H5-L-35-L-35-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83008018	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A3-C1-N-D3-H-F1-H3-L-42-L-42-C-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83008024	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-1-NN-80-T-M-F1-H-03-FAC-26-26-24	SERIES 90	S90-180PV
83008027	MOTOR-VAR-DISPL H1B080	H1-B-080-A-K2-K2-N-A-RA-DS-JS-S-A-10-NN-016-N-23-NNN	H1-HP MOTORS	H1-080MB1
83008030	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-TA-C2-L-N-G0-NNN-074-AA-G0-00-A8	SERIES 51	S51-250MV
83008031	PUMP-VAR DISPL, CW 90PV100	90-R-100-KN-1-NN-60-S-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83008039	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-NN-80-P-3-S1-E-02-GBA-26-26-24	SERIES 90	S90-075PV
83008041	PUMP-VAR-DISPL CW 90PV042	90R042-PA-5-BB-80-S-3-C3-C-03-GBA-42-42-24	SERIES 90	S90-042PV
83008042	PUMP-VAR DISPL, 42PV028 CCW	42-L-28-C-E2C7-03-D-N-F-2-F-N-A-28-28-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83008046	PUMP-VAR DISPL, 42PV028 CW	42-R-28-D-A1NB-02-C-2-N-N-F-N-A-28-28-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83008047	MOTOR-VAR-DISPL 51MD080	51D080-A-D2-N-HZ-B1-B-H-C2-ACA-019-AA-NN-08-00	SERIES 51	S51-080MV
83008048	PUMP-VAR DISPL MPV046C	MPV-046-C-B-A-H-S-B-B-AA-A-A-BGG-AB-U-ZY-A-NNN-***	M46	M46-046PV
83008050	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-1-AD-80-P-4-C6-B-03-GBA-14-14-24	SERIES 90	S90-055PV
83008051	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A2-C2-N-F2-F-G5-H1-J-40-J-40-N-E-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83008057	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-G-T-B-J-AA-A-A-BJJ-CD-A-GG-5-NNN-***	M46	M46-046PV
83008058	PUMP-VAR-DISPL CW 90PV250	90R250-KN-5-BC-80-S-3-C8-J-03-NNN-38-38-24	SERIES 90	S90-250PV
83008059	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-CD-80-S-3-T6-E-03-GBA-38-38-24	SERIES 90	S90-100PV
83008060	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-AB-80-S-3-T6-E-03-GBA-38-38-24	SERIES 90	S90-100PV
83008061	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-CD-80-S-3-C8-H-03-GCG-45-45-24	SERIES 90	S90-130PV
83008064	MOTOR-VAR-DISPL 51MD160	51D160-A-D4-N-T3-C0-L-N-J1-ANA-042-AA-F3-00-B1	SERIES 51	S51-160MV
83008065	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-L2-B1-V-A-C0-NNN-081-AA-H0-B2-00	SERIES 51	S51-160MV
83008070	MOTOR-VAR-DISPL H1B060	H1-B-060-A-HE-HE-N-C-TB-CN-GN-N-N-NN-NN-022-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83008072	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-BB-80-S-C-C8-J-03-GCG-45-45-24	SERIES 90	S90-180PV
83008075	PUMP-VAR-DISPL CW 90PV075	90R075-HF-5-CD-60-S-4-C7-E-03-GBA-32-32-24	SERIES 90	S90-075PV
83008076	PUMP-VAR-DISPL CW 90PV100	90R100-HF-5-AB-60-S-4-C7-F-03-GBA-35-35-24	SERIES 90	S90-100PV
83008077	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-NN-60-P-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-055PV
83008078	MOTOR-VAR-DISPL H1B080	H1-B-080-A-E2-AA-N-B-TB-DN-JN-N-N-NN-NN-040-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83008080	PUMP-VAR-DISPL CW 90PV250	90R250-PB-5-CD-80-T-4-F1-K-00-NNN-35-14-20	SERIES 90	S90-250PV
83008081	PUMP-VAR DISPL, CW 90PV055	90-R-055-KN-5-NN-80-S-4-K1-C-03-GBA-32-32-24	SERIES 90	S90-055PV
83008082	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-C-E1A3-03-B-4-G-2-D-N-N-34-34-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83008083	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-D-E1A3-03-B-4-G-2-D-N-B-34-34-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV

83008085	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-NN-60-P-3-S1-C-03-GBA-26-26-24	SERIES 90	S90-055PV
83008087	PUMP-VAR DISPL, 42PV041 CW	42-R-41-D-E1A3-00-A-N-N-N-G-N-B-23-23-B-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83008088	PUMP-VAR DISPL, 42PV041 CW	42-R-41-C-E1A3-00-A-N-N-N-G-N-A-23-23-B-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83008094	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-N-E2-B1-N-N-U4-NNN-032-AA-E6-00-00	SERIES 51	S51-060MV-1
83008099	PUMP-VAR DISPL, CW 90PV100	90-R-100-KT-2-AC-60-R-4-S1-E-03-GBA-32-32-24	SERIES 90	S90-100PV
83008108	MOTOR-VAR-DISPL 51MV160	51V160-A-C8-C-E1-A5-A-N-A6-NNN-100-AA-F3-03-00	SERIES 51	S51-160MV
83008109	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-1-BK-80-S-3-C6-C-03-GBA-20-20-20	SERIES 90	S90-055PV
83008110	PUMP-VAR-DISPL CW 90PV100	90R100-HF-5-NN-80-R-4-S1-E-03-GBA-32-32-28	SERIES 90	S90-100PV
83008112	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-1-BC-80-S-3-F1-F-09-GBA-26-26-24	SERIES 90	S90-130PV
83008118	PUMP-VAR-DISPL CW 90PV130	90R130-MA-1-NN-80-L-3-C8-H-09-GBA-45-45-24	SERIES 90	S90-130PV
83008119	PUMP-VAR-DISPL CCW H1PV147	H1-P-147-L-C-A5-C2-N-D6-G-G3-NN-L-33-L-33-L-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83008121	MOTOR-VAR-DISPL H1B110#	H1-B-110-A-T2-D2-N-A-TB-DS-KS-S-A-20-NN-000-Z-24-NNN	H1-HP MOTORS	H1-110MB1
83008122	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-ANNB-02-A-N-A-3-F-N-N-30-30-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83008124	PUMP-VAR DISPL, CCW 90PV055	90-L-055-MA-5-BC-60-S-4-C6-C-C5-GBA-32-32-24	SERIES 90	S90-055PV
83008127	MOTOR-VARIABLE DISPL SAE_L	L-V-30DS-A-RNF-F01-S-N-N-BF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83008129	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-CD-80-R-3-S1-E-03-GBA-29-29-24	SERIES 90	S90-075PV
83008130	PUMP-VAR-DISPL CW 90PV075	90R075-RS-1-CD-80-S-3-C7-E-A7-FAD-42-42-24	SERIES 90	S90-075PV
83008131	PUMP-VAR DISPL, CW 90PV075	90-R-075-KN-1-BC-60-S-4-K2-E-02-GBA-14-32-24-P000	SERIES 90	S90-075PV
83008132	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-AB-80-S-4-C7-E-03-GBA-32-32-24	SERIES 90	S90-100PV
83008136	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A2-C3-N-E6-F-G5-H3-L-25-L-25-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83008139	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-AD-80-P-4-S1-D-03-GBA-20-20-24	SERIES 90	S90-055PV
83008152	PUMP-VAR-DISPL CCW H1PV115	H1-P-115-L-B-A2-C3-N-D6-G-G2-NN-L-38-L-38-A-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83008157	PUMP-VAR DISPL, CW 90PV055	90-R-055-KN-5-NN-60-S-3-C6-C-00-GBA-35-35-24	SERIES 90	S90-055PV
83008158	MOTOR-VAR-DISPL 51MV080	51V080-A-S1-N-HZ-B1-A-N-G0-NNN-016-AA-E4-03-00	SERIES 51	S51-080MV
83008159	MOTOR-VAR-DISPL 51MD080-1	51D080-1--R-D3-N-T1-D1-N-N-X1-NNN-020-AA-E6-00-20	SERIES 51	S51-080MV-1
83008161	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-NN-60-S-4-C7-D-03-GBA-42-42-24	SERIES 90	S90-075PV
83008164	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-A-S-B-AA-J-A-BJJ-DA-A-HH-C-NNN-***	M46	M46-046PV
83008166	PUMP-VAR DISPL, CCW 90PV075	90-L-075-NA-1-NN-80-L-3-D7-D-03-GBA-42-42-24	SERIES 90	S90-075PV
83008170	PUMP-VAR DISPL, CW 90PV100	90-R-100-DC-1-NN-80-L-4-S1-E-GB-GBA-35-35-24	SERIES 90	S90-100PV
83008171	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-NN-80-P-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-075PV
83008173	MOTOR-VAR-DISPL 51MD160	51D160-R-D4-N-T3-C0-L-N-L4-ADA-060-AA-G0-00-B5	SERIES 51	S51-160MV
83008190	MOTOR- VARIABLE CARTRIDGE L	L-C-25CN-A-RNF-F09-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83008194	PUMP-VAR-DISPL CW 90PV180	90R180-FH-5-CD-80-S-7-C8-J-B1-EFI-40-40-32	SERIES 90	S90-180PV
83008195	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-D8-M1-R-J-N1-ANB-117-AA-H0-C2-30	SERIES 51	S51-250MV
83008197	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HS-1-NN-80-S-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-075PV
83008198	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-B8-C2-C-D6-H-F1-H3-L-38-L-38-C-L-30-P1-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV

83008199	MOTOR-VAR-DISPL H1B080	H1-B-080-A-M2-CA-N-B-RA-DS-JS-S-A-10-NN-016-N-00-NNN	H1-HP MOTORS	H1-080MB1
83008207	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A5-C2-N-D3-H-G1-H3-L-35-L-35-C-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83008209	MOTOR-VAR-DISPL 51MD060-1	51D060-1--A-D2-N-TA-R5-N-N-X1-NNN-036-AA-NN-00-21	SERIES 51	S51-060MV-1
83008210	MOTOR-VAR-DISPL 51MD060-1	51D060-1--A-D2-N-TA-L5-N-N-X1-NNN-036-AA-NN-00-21	SERIES 51	S51-060MV-1
83008216	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-BC-80-R-3-S1-E-03-GBA-38-38-24	SERIES 90	S90-075PV
83008218	MOTOR-VAR-DISPL H1B110#	H1-B-110-A-E2-AA-N-B-TB-VN-DN-N-N-NN-NN-055-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83008219	PUMP-VAR-DISPL CCW H1PV130	H1-P-130-L-B-A3-C2-N-D3-G-G3-NN-L-42-L-42-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83008220	MOTOR-VAR-DISPL 51MC160	51C160-R-D5-N-L2-B1-V-A-C0-ACB-055-AA-G0-B2-00	SERIES 51	S51-160MV
83008223	MOTOR-VAR-DISPL 51MD080-1	51D080-1--A-D3-N-T1-D1-N-N-X1-NNN-020-AA-E6-00-20	SERIES 51	S51-080MV-1
83008227	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-NN-80-R-3-T2-D-09-GBA-40-40-24	SERIES 90	S90-075PV
83008247	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-D-TA-C2-L-N-G0-NNN-107-AA-G3-00-C1	SERIES 51	S51-160MV
83008253	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-T2-C0-L-N-G0-ACA-107-AA-F0-00-C5	SERIES 51	S51-160MV
83008254	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-1-AB-80-L-3-F1-F-03-GBA-42-42-24	SERIES 90	S90-130PV
83008255	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-C-E1A6-02-D-N-F-3-F-N-N-30-30-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83008256	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A4-C3-N-D3-H-G9-NN-L-40-L-40-C-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83008258	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-NN-80-L-4-S1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
83008259	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-NN-60-L-4-S1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
83008260	PUMP-VAR DISPL, CCW 90PV075	90-L-075-NA-1-NN-80-L-3-D7-E-03-GBA-42-42-24	SERIES 90	S90-075PV
83008263	MOTOR-VAR-DISPL 51MV110	51V110-R-C8-N-L7-B1-W-B-G0-AHA-035-AA-F0-D4-00	SERIES 51	S51-110MV
83008264	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-TA-C2-L-N-G0-NNN-120-AA-G3-00-A5	SERIES 51	S51-250MV
83008265	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-CD-80-T-3-C8-J-03-NNN-42-42-24	SERIES 90	S90-250PV
83008266	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-BC-80-S-3-C7-E-21-GBA-35-35-24	SERIES 90	S90-075PV
83008274	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-1-CD-80-R-4-S1-D-03-GBA-26-26-24	SERIES 90	S90-075PV
83008275	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-1-NN-80-R-4-S1-D-03-GBA-26-26-24	SERIES 90	S90-075PV
83008276	MP-VAR DISPL, 42PV028 CW	42-R-28-D-E1A5-03-B-5-C-2-C-N-A-28-28-N-N-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83008277	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-1-BC-60-L-4-S1-C-00-GBA-26-26-24	SERIES 90	S90-055PV
83008279	PUMP-VAR DISPL, CW 90PV100	90-R-100-DD-1-BC-80-L-4-S1-E-GB-GBA-35-35-24	SERIES 90	S90-100PV
83008281	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-5-NN-80-S-4-C8-K-00-NNN-35-35-20	SERIES 90	S90-250PV
83008284	MOTOR-VAR-DISPL 51MV080-1	51V080-1--A-C7-N-T1-D1-N-N-X1-NNN-054-AA-F0-00-25	SERIES 51	S51-080MV-1
83008287	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-TH-C2-L-N-G0-NNN-070-AA-NN-00-B0	SERIES 51	S51-250MV
83008289	PUMP-VAR-DISPL CW 90PV250	90R250-HS-5-AB-80-T-3-F1-J-03-NNN-35-35-24	SERIES 90	S90-250PV
83008290	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-DE-80-T-M-F1-J-03-FAC-32-32-28	SERIES 90	S90-180PV
83008291	PUMP-VAR DISPL, 42PV028 CW	42-R-28-D-ANNB-02-B-3-G-2-H-N-B-21-21-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83008292	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-NN-80-S-4-C7-E-00-GBA-35-35-20	SERIES 90	S90-100PV
83008298	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-1-AB-60-S-3-S1-D-03-GBA-23-23-24	SERIES 90	S90-075PV
83008312	PUMP-VAR DISPL, 42PV028 CW	42-R-28-D-ANNB-02-B-3-G-2-H-N-A-21-21-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV

83008317	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-A-S-B-B-AA-A-A-BFF-CE-A-JJ-5-NNN-***	M46	M46-046PV
83008318	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-S1-N-E2-B1-N-N-U1-ABA-049-AA-F0-00-00	SERIES 51	S51-080MV-1
83008319	PUMP-VAR-DISPL CW 90PV042	90R042-KP-1-BC-80-P-3-C3-C-02-GBA-42-42-24	SERIES 90	S90-042PV
83008320	PUMP-VAR-DISPL CCW 90PV100	90L100-KP-1-CD-80-L-3-F1-E-03-GBA-29-29-24	SERIES 90	S90-100PV
83008325	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-CD-80-S-3-C7-D-03-GBA-23-23-24	SERIES 90	S90-075PV
83008326	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-NN-80-S-3-S1-D-03-GBA-23-23-24	SERIES 90	S90-075PV
83008327	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-1-BG-80-P-4-S1-D-00-GBA-17-17-28	SERIES 90	S90-055PV
83008328	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-T2-C0-L-N-G0-ADA-070-AA-F3-00-C2	SERIES 51	S51-250MV
83008330	MOTOR-VAR-DISPL 51MV110	51V110-R-F1-N-HS-A2-B-E-E1-NNN-034-AA-E6-10-23	SERIES 51	S51-110MV
83008352	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MA-1-NN-60-R-3-S1-F-03-GBA-32-32-24	SERIES 90	S90-100PV
83008354	PUMP-TANDEM, VAR DISPL MPT035D	MPT-035-D-A-R-R-G-AA-B-A-A-A-BDD-DL-A-FF-B-C-A-A-BDD-DR-A-FF-B-NNN-*	M35/44	035PT
83008359	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-C8-N-TA-C2-N-N-X1-NNN-060-AA-F0-00-28	SERIES 51	S51-110MV-1
83008362	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-7-N-0-K5-W-00-NNN-00-00-F3	SERIES 90	S90-055MF
83008364	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-BC-80-P-3-F1-F-03-EBC-29-29-24	SERIES 90	S90-100PV
83008370	PUMP-VAR-DISPL CW 90PV075	90R075-FN-1-AB-80-R-7-S1-D-B6-ELA-35-35-24	SERIES 90	S90-075PV
83008371	PUMP-VAR DISPL, 42PV041 CW	42-R-41-K-E2D8-01-C-2-A-3-H-N-A-B5-B5-N-N-N-NNN-ENN	SERIES 42	S42-041PV/051PV
83008376	PUMP-VAR-DISPL CW 90PV100	90R100-DD-5-CD-60-L-4-C7-E-G1-GBA-35-35-24	SERIES 90	S90-100PV
83008377	MOTOR-VAR-DISPL 51MD160	51D160-R-D5-N-E2-A5-A-N-G0-ABA-070-AA-F3-03-00	SERIES 51	S51-160MV
83008378	PUMP-VAR-DISPL CW 90PV130	90R130-M8-5-AB-80-P-3-C8-H-C5-GBA-38-38-20	SERIES 90	S90-130PV
83008379	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-AB-80-P-3-F1-H-03-GBA-35-35-24	SERIES 90	S90-130PV
83008382	PUMP-VAR DISPL, 42PV028 CW	42-R-28-C-ANNB-03-C-3-A-3-E-N-N-36-36-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83008384	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-CD-80-P-3-F1-F-04-GBA-35-35-20-G005	SERIES 90	S90-130PV
83008386	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-TA-C2-L-N-G0-NNN-115-AA-NN-00-B0	SERIES 51	S51-160MV
83008387	MOTOR-VAR-DISPL 51MV060	51V060-A-S1-N-HZ-B1-C-H-C2-NNN-012-AA-NN-20-00	SERIES 51	S51-060MV
83008393	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A5-C2-N-D8-F-G5-H2-L-35-L-35-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83008394	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A5-C2-N-D8-F-G5-H2-L-35-L-35-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83008396	PUMP-VAR-DISPL CCW H1PV165	H1-P-165-L-C-A4-C2-N-D5-G-G3-H4-L-40-L-40-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83008397	PUMP-VAR-DISPL CCW H1PV165	H1-P-165-L-C-A4-C2-N-D3-G-G3-H3-L-40-L-40-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83008400	MOTOR-VAR-DISPL H1B080	H1-B-080-A-E1-AA-N-B-TB-VN-AN-N-A-10-NN-036-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83008401	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-L1-B1-W-B-G0-ACA-032-AA-F0-D4-00	SERIES 51	S51-160MV
83008402	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-1-CD-60-P-4-C6-C-03-GBA-26-26-24	SERIES 90	S90-055PV
83008406	PUMP-VAR-DISPL CW 90PV130	90R130-MA-5-NN-80-S-3-C8-F-C6-GBA-35-35-24	SERIES 90	S90-130PV
83008411	PUMP-VAR-DISPL CW 90PV250	90R250-KN-5-NN-80-T-4-C8-K-03-NNN-35-35-24	SERIES 90	S90-250PV
83008414	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-G-ANNB-03-C-3-A-2-F-N-B-34-34-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83008415	PUMP-TANDEM, VAR DISPL CCW H1T045L	H1-T-045-L-A-N-A4-C1-N-E7-F-G5-TN-23-23-23-23-M-P-24-PN-NNN-S01	H1-MP PUMPS	H1-045PT/053PT
83008416	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-CD-60-S-4-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV

83008418	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-N-N1-NN-N-N-U1-ACG-030-AA-F0-00-00	SERIES 51	S51-060MV-1
83008419	MOTOR-FIX DISPL MMF035D	MMF-035-D-A-S-1-C-D-NNN-***	M35/44	O35MF
83008425	MOTOR-VAR-DISPL 51MD160	51D160-A-D4-N-DC-M6-S-K-M4-NNN-037-AA-F3-F4-22	SERIES 51	S51-160MV
83008426	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-C7-N-E2-B1-N-N-U1-NNN-053-AA-E6-00-00	SERIES 51	S51-080MV-1
83008427	MOTOR-VAR-DISPL H1B060	H1-B-060-A-E2-AA-N-B-TB-CS-GS-S-N-NN-NN-017-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83008428	MOTOR-VAR-DISPL H1B080	H1-B-080-A-E2-AA-N-B-TB-CS-JS-S-N-NN-NN-026-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83008452	MOTOR-VAR-DISPL 51MV250	51V250-A-C8-N-HZ-B1-C-N-C2-NNN-050-AA-G3-20-00	SERIES 51	S51-250MV
83008455	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-A1NB-03-B-D-C-2-H-N-V-34-34-N-A-A-NNN-NNN	SERIES 42	S42-041PV/051PV
83008460	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-B8-C2-D-D3-L-G2-H3-L-38-L-38-L-N-32-P2-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83008477	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-NN-80-S-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-075PV
83008494	MOTOR-VAR-DISPL 51MD160	51D160-A-D4-N-T2-C2-L-N-G0-NNN-068-AA-G3-00-A9	SERIES 51	S51-160MV
83008495	PUMP-VAR-DISPL CCW H1PV115	H1-P-115-L-B-A5-C3-N-D6-G-G2-H4-L-35-L-35-A-L-28-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83008496	PUMP-VAR-DISPL CCW H1PV115	H1-P-115-L-B-A5-C3-N-D6-G-G3-NN-L-35-L-35-A-L-28-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83008501	PUMP-VAR-DISPL CCW H1PV130	H1-P-130-L-B-B8-C2-C-D3-G-G2-NN-L-40-L-40-L-M-30-P1-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83008502	MOTOR-VAR-DISPL H1B160	H1-B-160-A-L1-BA-N-B-PB-VN-FN-N-A-30-NN-055-N-00-NNN	H1-HP MOTORS	H1-160MB1
83008503	MOTOR-VAR-DISPL H1B160	H1-B-160-A-L1-BA-N-B-PA-DS-KS-S-A-30-NN-100-N-00-NNN	H1-HP MOTORS	H1-160MB1
83008504	MOTOR-VAR-DISPL H1B160	H1-B-160-A-M1-CA-N-C-RB-VS-ES-S-A-20-NN-090-N-00-NNN	H1-HP MOTORS	H1-160MB1
83008508	PUMP-VAR-DISPL CW 90PV100	90R100-FD-5-CD-60-P-7-F1-F-B1-GBA-38-38-28	SERIES 90	S90-100PV
83008509	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-G3AN-53-T-N-D-3-F-5-T-38-38-N-0-0-NNN-NNN	SERIES 42	S42-028PV/032PV
83008513	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MB-1-CD-80-S-3-C6-E-03-GBA-42-42-24	SERIES 90	S90-075PV
83008514	MOTOR-VARIABLE CARTRIDGE K	K-C-45DN-E-YNF-F55-S-N-N-AF-F16-NNN-NNN	LV / KV MOTORS	L/K-MV
83008515	PUMP-VAR-DISPL CW 90PV075	90R075-HF-5-BC-60-S-4-S1-D-02-GBA-38-38-30	SERIES 90	S90-075PV
83008518	MOTOR-VAR-DISPL 51MV080	51V080-A-S1-N-L2-B1-V-A-C0-NNN-050-AA-F0-B2-00	SERIES 51	S51-080MV
83008521	MOTOR-VARIABLE DISPL SAE_L	L-V-25CS-A-RNF-F75-S-N-N-CF-F13-NNN-NNN	LV / KV MOTORS	L/K-MV
83008525	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-NN-80-R-4-F1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
83008526	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-8-N-0-F1-W-00-EBA-00-00-F0	SERIES 90	S90-100MF
83008531	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-T2-C2-L-N-G0-NNN-065-AA-F3-00-B7	SERIES 51	S51-160MV
83008532	PUMP-VAR DISPL MPV035D	MPV-035-D-B-A-G-R-S-G-AA-A-A-BJJ-DR-A-FF-C-NNN-***	M35/44	O35PV
83008543	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A3-C3-B-D8-G-G3-H4-L-45-L-45-N-E-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83008549	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-B-V-C-J-BA-B-B-G-A-BRR-DA-A-GG-B-D-G-A-BRR-DA-A-GG-C-NNN-	M46	M46-046PT
83008550	PUMP-VAR DISPL, CCW 90PV100	90-L-100-DD-5-BC-80-R-4-F1-E-GB-GBA-23-38-24	SERIES 90	S90-100PV
83008551	MOTOR-VAR-DISPL H1B080	H1-B-080-A-L1-BA-N-A-PA-VS-AS-P-A-05-NN-040-N-00-NNN	H1-HP MOTORS	H1-080MB1
83008555	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-D-E2D8-03-C-2-A-2-F-N-B-30-30-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83008556	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-D-E2D8-02-A-N-A-2-H-N-A-28-28-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83008557	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-C-E2D8-03-C-2-A-2-F-N-N-30-30-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83008564	MOTOR-VAR-DISPL 51MV110	51V110-R-F1-N-N2-NN-N-N-A0-NNN-022-AA-NN-00-00	SERIES 51	S51-110MV

83008572	PUMP-VAR-DISPL 42PV041 CCW	42-L-51-K-E1A5-01-A-N-A-3-H-N-V-36-36-N-N-N-NNN-NDD	SERIES 42	S42-041PV/051PV
83008573	PUMP-VAR-DISPL 42PV041 CCW	42-L-51-D-E1A5-01-A-N-A-3-H-N-B-36-36-N-N-N-NNN-NDD	SERIES 42	S42-041PV/051PV
83008577	PUMP-VAR DISPL MPV046C	MPV-046-C-B-A-B-S-B-J-BA-A-A-BEE-AB-D-AA-A-NNN-***	M46	M46-046PV
83008582	PUMP-VAR DISPL, CW 90PV100	90-R-100-HF-1-CD-60-P-3-F1-F-03-GBA-38-38-24	SERIES 90	S90-100PV
83008583	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-NN-80-R-4-C7-F-03-GBA-29-29-30-F068	SERIES 90	S90-100PV
83008587	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-1-BC-60-S-3-C6-D-03-GBA-35-35-24	SERIES 90	S90-055PV
83008588	MOTOR-VAR-DISPL 51MD060-1	51D060-1--A-D1-N-TH-C2-N-N-X1-NNN-021-AA-NN-00-23	SERIES 51	S51-060MV-1
83008597	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-E2D8-02-B-D-B-2-H-N-A-38-38-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83008600	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-CD-80-D-4-F1-L-05-GBA-35-35-24	SERIES 90	S90-130PV
83008604	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-8-N-0-K2-W-00-NNN-00-00-F0	SERIES 90	S90-075MF
83008605	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KN-1-CD-80-R-4-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
83008606	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-CD-60-L-3-C7-F-03-GBA-42-42-24	SERIES 90	S90-100PV
83008607	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-1-NN-80-R-3-S1-D-03-GBA-29-29-24	SERIES 90	S90-075PV
83008608	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-BC-80-T-4-C8-K-03-NNN-42-42-24	SERIES 90	S90-250PV
83008610	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A5-C3-N-D6-G-G2-H4-L-35-L-35-L-L-28-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83008611	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A5-C3-N-D6-G-G3-NN-L-35-L-35-L-L-28-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83008621	MOTOR-VAR-DISPL 51MD160	51D160-A-D5-B-L1-B1-W-B-J1-ADA-045-AA-F0-D4-00	SERIES 51	S51-160MV
83008628	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-NN-60-R-3-K2-E-03-GBA-38-38-24	SERIES 90	S90-075PV
83008629	MOTOR-VARIABLE CARTRIDGE K	K-C-45DS-E-RNF-F08-S-N-N-DF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83008631	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A5-C2-N-D6-F-G5-H3-L-25-L-25-B-L-26-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83008634	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-BG-80-L-3-S1-D-03-GBA-38-38-24	SERIES 90	S90-055PV
83008635	MOTOR-VAR-DISPL 51MV060-1	51V060-1--R-S1-N-E1-B1-N-N-U1-NNN-030-AA-NN-00-00	SERIES 51	S51-060MV-1
83008639	MOTOR-VAR-DISPL 51MV080	51V080-R-C7-N-HZ-B1-A-E-C2-NNN-035-AA-E6-03-00	SERIES 51	S51-080MV
83008640	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-BK-80-P-3-S1-D-03-GBA-23-23-24	SERIES 90	S90-055PV
83008643	PUMP-VAR DISPL MPV044D	MPV-044-D-B-A-A-Y-S-G-AA-A-A-BEE-DL-A-FF-C-NNN-***	M35/44	O44PV
83008644	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-NN-80-R-3-T2-D-09-GBA-40-40-24	SERIES 90	S90-075PV
83008646	PUMP-VAR DISPL CCW H1P053L	H1-P-053-L-A-A4-C1-B-E5-F-G5-NN-L-33-L-33-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83008649	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A4-C1-N-D1-F-G1-H1-40-40-40-40-N-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83008651	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D3-N-E1-B1-N-N-U1-ADA-032-AA-E6-00-00	SERIES 51	S51-080MV-1
83008652	PUMP-VAR DISPL, CW 90PV055	90-R-055-FC-5-BG-80-S-7-C6-D-B1-EFI-42-42-30	SERIES 90	S90-055PV
83008653	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A8-C2-C-E6-F-G5-H2-L-25-L-25-B-L-24-P1-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83008654	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HS-1-BC-60-P-4-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83008667	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-L-S-B-B-AA-A-A-BDD-BA-A-HH-A-NNN-***	M46	M46-046PV
83008670	MOTOR-VAR-DISPL 51MC060-1	51C060-1--A-D1-N-E2-B1-N-N-U1-ACB-020-AA-NN-00-00	SERIES 51	S51-060MV-1
83008671	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-CD-80-P-3-F1-H-03-GBA-32-32-28	SERIES 90	S90-130PV
83008672	MOTOR-VAR-DISPL 51MC080-1	51C080-1--A-D3-N-E2-B1-N-N-U1-NNN-050-AA-E6-00-00	SERIES 51	S51-080MV-1

83008678	MOTOR-VAR-DISPL H1B110	H1-B-110-A-L1-BA-N-A-PB-CS-JS-S-A-15-NN-000-N-00-NNN	H1-HP MOTORS	H1-110MB1
83008687	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-D-E2D8-02-B-3-G-2-H-N-V-25-25-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83008688	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-D-E2D8-02-B-3-G-2-H-N-A-25-25-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83008691	PUMP-VAR-DISPL CCW 90PV075	90L075-DC-5-AB-80-S-3-S1-E-GB-GBA-35-35-24	SERIES 90	S90-075PV
83008693	PUMP-VAR-DISPL CCW 90PV100	90L100-FG-5-BC-80-S-7-F1-F-B1-GCA-42-42-24	SERIES 90	S90-100PV
83008700	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-CD-80-R-3-F1-F-03-GBA-29-29-24	SERIES 90	S90-100PV
83008701	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-AB-80-R-4-S1-E-03-GBA-20-20-24	SERIES 90	S90-075PV
83008704	PUMP-TANDEM, VAR DISPL CCW H1T045L	H1-T-045-L-A-N-A5-C3-N-F7-F-G6-H1-25-25-25-25-N-P-22-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83008705	PUMP-TANDEM, VAR DISPL CCW H1T045L	H1-T-045-L-A-N-A3-C1-N-E7-F-G6-H2-42-42-42-42-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83008706	PUMP-TANDEM, VAR DISPL CCW H1T053L	H1-T-053-L-A-N-A4-C1-N-E7-F-G1-H3-33-33-33-33-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83008707	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-NN-80-R-3-F1-D-03-FAD-42-42-24	SERIES 90	S90-100PV
83008720	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-BC-80-S-3-C7-E-03-GBA-29-29-24	SERIES 90	S90-075PV
83008724	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-N2-NN-N-N-A0-ACA-032-AA-F0-00-00	SERIES 51	S51-160MV
83008727	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-BC-60-S-3-S1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
83008728	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-CD-80-S-4-C6-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83008729	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A4-C2-N-D6-F-G4-NN-L-35-L-35-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83008735	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-E2C8-02-A-N-A-3-H-N-A-25-25-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83008736	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-1-CD-80-S-3-C6-D-03-GBA-42-42-24	SERIES 90	S90-075PV
83008737	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-ANNB-02-B-3-G-2-H-N-A-21-21-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83008747	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-5-CD-80-S-4-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83008748	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-5-NN-80-S-4-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83008752	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-1-BC-80-S-3-C6-D-03-GBA-42-42-24	SERIES 90	S90-075PV
83008759	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-G3AN-52-T-N-D-3-H-1-A-25-25-B-0-0-NNN-NNN	SERIES 42	S42-028PV/032PV
83008760	PUMP-VAR-DISPL 42PV028 CW	42-R-32-D-G3AN-52-T-N-D-3-H-5-A-30-30-B-0-0-NNN-NNN	SERIES 42	S42-028PV/032PV
83008774	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-A-V-C-J-BA-B-B-G-B-BDD-BC-A-GG-B-D-G-B-BDD-BC-A-GG-B-NNN-	M46	M46-046PT
83008775	MOTOR-VAR-DISPL 51MD060-1	51D060-1--A-D2-N-TA-C2-N-N-X1-NNN-030-AA-NN-00-21	SERIES 51	S51-060MV-1
83008776	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A3-C3-N-D3-G-G3-H6-L-30-L-30-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83008777	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A3-C3-N-D5-G-G2-H4-L-30-L-30-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83008778	MOTOR-VAR-DISPL 51MD160	51D160-R-D5-N-E2-A5-A-N-G0-NNN-076-AA-G0-03-00	SERIES 51	S51-160MV
83008781	PUMP-VAR DISPL, CW 90PV055	90-R-055-HF-1-AB-60-P-4-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83008782	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-G3AN-52-P-D-G-3-H-5-A-30-30-B-0-0-NNN-NNN	SERIES 42	S42-041PV/051PV
83008783	PUMP-VAR-DISPL CCW 90PV130	90L130-HF-1-AB-80-L-4-F1-H-00-GBA-38-38-24	SERIES 90	S90-130PV
83008784	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-T2-C0-L-N-G0-ACA-113-AA-G0-00-B0	SERIES 51	S51-250MV
83008785	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-1-NN-80-L-3-F1-H-03-GBA-29-29-24	SERIES 90	S90-130PV
83008789	MOTOR-VARIABLE CARTRIDGE K	K-C-45DN-E-R1F-F04-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83008798	PUMP-VAR-DISPL CW 90PV100	90R100-HF-5-CD-80-R-4-C7-E-04-GBA-35-35-24	SERIES 90	S90-100PV

83008799	PUMP-VAR-DISPL CW 90PV075	90R075-HF-5-AB-80-R-4-S1-D-04-GBA-35-35-24	SERIES 90	S90-075PV
83008806	PUMP-VAR DISPL, CW 90PV075	90-R-075-LV-1-BB-60-P-3-C7-D-03-GBA-40-40-24	SERIES 90	S90-075PV
83008807	PUMP-VAR-DISPL CW 90PV075	90R075-MB-5-BC-80-L-3-S1-D-C5-GBA-35-35-24	SERIES 90	S90-075PV
83008808	PUMP-VAR-DISPL CW 90PV075	90R075-MB-5-CD-80-L-3-S1-D-C5-GBA-35-35-24	SERIES 90	S90-075PV
83008809	MOTOR-VARIABLE DISPL SAE_K	K-V-45DS-A-YNF-F09-S-N-N-BF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83008810	MOTOR-VARIABLE DISPL SAE_K	K-V-45DS-A-YNF-F01-S-N-N-BF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83008811	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-CD-80-L-3-F1-E-03-GBA-26-26-24	SERIES 90	S90-100PV
83008812	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-ANNB-02-C-D-A-2-E-N-A-34-34-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83008814	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-2-CD-80-D-4-C6-L-00-GFD-35-35-34-F070	SERIES 90	S90-075PV
83008816	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-NN-60-P-3-F1-F-02-GBA-42-42-24	SERIES 90	S90-100PV
83008817	PUMP-VAR-DISPL CW 90PV100	90R100-HF-5-NN-80-R-3-F1-F-03-GBA-30-30-24	SERIES 90	S90-100PV
83008818	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D3-N-N1-NN-N-N-U1-NNN-040-AA-F0-00-00	SERIES 51	S51-080MV-1
83008820	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HS-1-BC-60-R-4-F1-E-05-FBC-35-35-36-N181	SERIES 90	S90-100PV
83008821	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HS-1-BC-60-R-4-F1-E-05-FBC-35-35-36-N180	SERIES 90	S90-100PV
83008850	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-5-NN-60-P-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
83008851	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-5-CD-60-P-3-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83008852	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-BC-80-R-3-S1-C-03-GBA-26-26-24	SERIES 90	S90-075PV
83008854	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-AB-60-P-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83008857	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-NN-80-R-3-C6-C-03-GBA-32-14-28	SERIES 90	S90-055PV
83008913	PUMP-VAR-DISPL CCW H1PV165	H1-P-165-L-C-A5-C2-N-D6-G-G2-H3-L-45-L-45-A-L-30-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83008916	PUMP-VAR-DISPL CCW H1PV130	H1-P-130-L-B-A4-C1-N-D3-G-G2-H2-L-42-L-42-A-M-20-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83008919	PUMP-TANDEM, VAR DISPL MPT044D	MPT-044-D-H-L-R-A-AA-B-A-A-A-BJJ-DR-A-FF-B-C-A-A-BJJ-DR-A-FF-H-GNS-***	M35/44	044PT
83008931	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-BC-80-R-4-S1-D-03-GBA-38-38-24	SERIES 90	S90-075PV
83008942	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-NN-80-R-4-S1-E-03-GBA-23-23-24	SERIES 90	S90-100PV
83008950	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A2-C2-N-E7-F-G5-TN-40-40-40-40-M-P-24-PN-NNN-S01	H1-MP PUMPS	H1-045PT/053PT
83008951	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-NN-80-R-3-F1-D-03-FAD-42-42-28	SERIES 90	S90-100PV
83008957	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-G3AN-50-P-3-G-2-F-1-T-34-34-B-0-0-NNN-NNN	SERIES 42	S42-041PV/051PV
83008958	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-G3AN-50-P-3-G-3-F-1-T-41-41-B-0-0-NNN-NNN	SERIES 42	S42-041PV/051PV
83008959	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-D-E2D8-02-A-N-A-2-H-N-B-30-30-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83008960	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-CD-80-R-3-C8-F-03-GBA-35-35-24	SERIES 90	S90-130PV
83008961	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-BC-80-R-3-C8-F-03-GBA-35-35-24	SERIES 90	S90-130PV
83008966	PUMP-VAR-DISPL CW 90PV130	90R130-CB-5-NN-80-S-4-F1-F-00-GBA-35-35-24	SERIES 90	S90-130PV
83008967	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KN-1-CD-80-R-4-F1-E-01-GBA-29-29-24	SERIES 90	S90-100PV
83008968	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KN-1-NN-80-R-4-S1-E-01-GBA-29-29-24	SERIES 90	S90-100PV
83008969	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KN-1-BC-80-R-4-S1-E-01-GBA-29-29-24	SERIES 90	S90-100PV
83008970	MOTOR-VAR-DISPL H1B060	H1-B-060-A-L1-BA-N-A-PB-VN-AN-N-A-05-NN-012-N-00-NNN	H1-HP MOTORS	H1-060MB1

83008972	PUMP-VAR-DISPL CW 90PV130	90R130-HF-5-CD-80-L-4-F1-H-03-GBA-23-23-24	SERIES 90	S90-130PV
83008977	MOTOR-VARIABLE DISPL SAE_K	K-V-45DN-E-RNF-F13-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83008980	PUMP-VAR DISPL, CW 90PV100	90-R-100-CB-1-CD-80-S-3-F1-E-00-GBA-42-42-24	SERIES 90	S90-100PV
83008981	PUMP-VAR-DISPL CW 90PV250	90R250-KA-1-NN-80-T-4-F1-J-72-NNN-17-17-24	SERIES 90	S90-250PV
83008982	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-AB-60-L-4-C7-E-05-GBA-26-26-24	SERIES 90	S90-100PV
83008983	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A4-C2-N-D6-G-G2-H4-L-45-L-45-L-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83008984	PUMP-VAR DISPL, CW 90PV075	90-R-075-CA-W-CD-60-E-3-C6-D-00-GFD-40-36-24-B010	SERIES 90	S90-075PV
83008985	PUMP-VAR DISPL, CW 90PV075	90-R-075-LE-W-BC-60-E-3-S1-D-03-GFD-40-32-24	SERIES 90	S90-075PV
83008986	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-8-N-0-C7-W-00-EAJ-00-00-F3	SERIES 90	S90-075MF
83008987	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-TA-C2-N-N-X1-NNN-050-AA-F3-00-25	SERIES 51	S51-110MV-1
83008988	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A3-C2-N-D8-G-G2-H6-L-28-L-28-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83008992	PUMP-VAR DISPL, CW 90PV075	90-R-075-HF-1-AB-60-P-4-C7-E-01-GBA-29-29-24	SERIES 90	S90-075PV
83008994	MOTOR-VAR-DISPL 51MV160	51V160-A-C8-N-D8-M1-R-J-M4-ACA-045-AA-H0-C2-32	SERIES 51	S51-160MV
83008997	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-S-B-S-AA-A-A-BJJ-BB-A-YC-A-NNN-***	M46	M46-046PV
83009000	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-L2-B1-V-A-G5-ACA-089-AA-F3-B2-00	SERIES 51	S51-160MV
83009006	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-1-BC-80-P-4-S1-E-03-GBA-14-14-24	SERIES 90	S90-075PV
83009009	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-CD-80-R-4-S1-D-03-GBA-38-38-24	SERIES 90	S90-075PV
83009010	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-AB-80-S-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83009011	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-AB-80-T-4-F1-J-03-NNN-35-35-24	SERIES 90	S90-250PV
83009012	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-K-S-B-S-AA-V-A-BRR-DA-A-WA-B-NNN-***	M46	M46-046PV
83009016	MOTOR-VAR-DISPL 51MD160	51D160-A-D4-C-HS-A2-C-E-E1-NNN-080-AA-F3-15-27	SERIES 51	S51-160MV
83009023	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-N-A4-C1-N-E7-F-G5-NN-35-35-35-35-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83009024	PUMP-VAR DISPL, CW 90PV055	90-R-055-HS-1-BG-80-P-4-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83009032	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A5-C2-N-E5-F-G4-NN-L-23-L-23-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83009033	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-CD-60-L-3-S1-E-03-GBA-32-32-24	SERIES 90	S90-075PV
83009037	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-AB-60-S-4-F1-E-03-GBA-29-29-24	SERIES 90	S90-100PV
83009038	PUMP-VAR DISPL, CCW 90PV055	90-L-055-EP-1-AB-60-S-4-S1-C-03-GBA-29-14-30	SERIES 90	S90-055PV
83009039	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-B-Z-C-B-AA-B-B-A-A-BBB-CB-A-GG-B-D-A-A-BCC-CB-A-GG-B-NNN-*	M46	M46-046PT
83009042	PUMP-VAR DISPL, CCW 90PV075	90-L-075-DD-1-BC-80-L-3-D9-E-G8-GBA-35-35-24	SERIES 90	S90-075PV
83009043	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-2-CD-60-P-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83009048	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-NN-80-D-3-C8-L-04-GBA-35-35-20	SERIES 90	S90-130PV
83009053	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-NN-80-R-3-S1-E-03-GBA-32-32-20	SERIES 90	S90-075PV
83009055	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-2-AB-60-P-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83009058	PUMP-VAR DISPL, CW 90PV075	90-R-075-HS-1-BC-60-P-3-C6-E-03-GBA-35-35-24	SERIES 90	S90-075PV
83009061	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-T1-C2-L-N-G0-ACA-168-AA-G0-00-C7	SERIES 51	S51-250MV
83009062	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-D-S-B-J-BA-A-A-BJJ-BA-A-RR-B-NNN-***	M46	M46-046PV

83009063	MOTOR-VAR DISPL MMV046C	MMV-046-C-A-A-B-A-A8-VNB-***	M46	M46-046MV
83009066	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-L2-B1-V-A-C0-NNN-032-AA-F0-B2-00	SERIES 51	S51-160MV
83009067	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-L2-B1-V-A-C0-ACB-032-AA-F0-B2-00	SERIES 51	S51-160MV
83009070	MOTOR-VAR-DISPL H1B060	H1-B-060-A-TA-D1-N-B-TB-VS-AS-P-A-10-NN-014-Z-28-NNN	H1-HP MOTORS	H1-060MB1
83009071	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-F2NN-75-J-D-G-2-H-N-A-28-28-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83009072	PUMP-VAR DISPL, CW 90PV075	90-R-075-FN-1-AB-80-R-7-S1-D-B6-ELA-35-35-24	SERIES 90	S90-075PV
83009073	PUMP-VAR DISPL, CCW 90PV075	90-L-075-DD-1-NN-80-S-3-C7-D-GB-GBA-35-35-24	SERIES 90	S90-075PV
83009074	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KN-1-CD-80-S-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83009075	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KN-1-CD-80-S-4-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
83009076	PUMP-VAR-DISPL CW 90PV130	90R130-MB-5-BC-80-L-4-C8-H-C5-GBA-42-42-24	SERIES 90	S90-130PV
83009077	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-EG-80-S-3-C8-K-03-EFI-42-42-24	SERIES 90	S90-250PV
83009081	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-HZ-B1-A-N-G0-ACA-125-AA-F3-03-00	SERIES 51	S51-160MV
83009082	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A5-C3-B-D3-G-G3-H6-K-35-K-20-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83009083	MOTOR-VAR-DISPL 51MV060-1	51V060-1--A-S1-N-TA-C2-N-N-X1-NNN-040-AA-E4-00-24	SERIES 51	S51-060MV-1
83009086	PUMP-VAR DISPL, CCW 90PV055	90-L-055-MA-1-NN-80-R-3-S1-C-03-GBA-14-14-24	SERIES 90	S90-055PV
83009087	MOTOR-VAR-DISPL H1B110	H1-B-110-A-L2-BA-N-B-PA-CS-JS-S-N-NN-NN-055-N-00-NNN	H1-HP MOTORS	H1-110MB1
83009088	PUMP-VAR-DISPL CCW 90PV075	90L075-FH-5-CD-80-R-7-S1-E-B1-EFC-32-32-28	SERIES 90	S90-075PV
83009089	PUMP-VAR-DISPL CCW 90PV130	90L130-FH-5-CD-80-R-7-F1-H-B1-EFC-32-32-28	SERIES 90	S90-130PV
83009090	PUMP-VAR-DISPL CW 90PV250	90R250-KP-5-CD-80-T-4-C8-K-03-NNN-32-32-28	SERIES 90	S90-250PV
83009091	PUMP-VAR-DISPL CW 90PV130	90R130-ME-1-AB-80-L-3-F1-F-03-GBA-42-42-24	SERIES 90	S90-130PV
83009102	MOTOR-VAR-DISPL H1B080	H1-B-080-A-L2-BA-N-B-PB-CS-JS-S-A-05-NN-000-N-00-NNN	H1-HP MOTORS	H1-080MB1
83009103	MOTOR-VARIABLE CARTRIDGE K	K-C-38CS-E-R4F-F55-S-N-N-EF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83009106	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A8-C2-C-D6-H-F1-H2-L-42-L-42-C-L-28-P1-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83009107	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MA-1-BC-60-S-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83009110	MOTOR-VAR-DISPL 51MD160	51D160-R-D4-N-E1-A5-A-N-G0-NNN-062-AA-F0-03-00	SERIES 51	S51-160MV
83009115	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-2-DE-80-R-3-F1-F-03-GBA-42-14-24	SERIES 90	S90-130PV
83009116	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-2-NN-80-R-3-F1-F-03-GBA-42-14-24	SERIES 90	S90-130PV
83009117	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-D-E2D8-02-A-N-A-2-H-N-A-32-32-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83009120	MOTOR-VAR-DISPL H1B060	H1-B-060-A-L1-BA-N-B-PA-VN-AN-N-A-10-NN-000-N-00-NNN	H1-HP MOTORS	H1-060MB1
83009121	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-E2-A5-A-N-A6-ACA-053-AA-F0-03-00	SERIES 51	S51-160MV
83009124	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-CD-80-R-3-S1-D-05-GBA-35-35-24	SERIES 90	S90-075PV
83009125	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-NN-80-R-3-S1-D-05-GBA-35-35-24	SERIES 90	S90-075PV
83009126	PUMP-VAR DISPL MPV035D	MPV-035-D-B-A-A-W-S-G-BA-A-A-BFF-DL-A-FF-C-NNN-***	M35/44	035PV
83009128	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A4-C2-N-D6-G-G3-H2-L-28-L-28-L-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83009129	PUMP-VAR-DISPL CCW 90PV250	90L250-KP-5-NN-80-T-3-C8-K-03-NNN-29-29-24	SERIES 90	S90-250PV
83009131	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-5-CD-80-P-4-S1-D-05-GBA-42-42-24	SERIES 90	S90-075PV

83009135	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-N-T2-C2-L-N-K7-ACA-060-AA-F3-00-B5	SERIES 51	S51-160MV
83009136	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A5-C2-B-D3-G-G2-NN-L-42-L-42-L-M-28-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83009137	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-N-L2-B1-V-A-C0-NNN-080-AA-G3-B2-00	SERIES 51	S51-250MV
83009138	PUMP-VAR-DISPL CW 90PV042	90R042-MA-P-BC-80-P-4-C3-C-C5-GBA-48-48-24	SERIES 90	S90-042PV
83009139	MOTOR-VAR-DISPL 51MV110-1	51V110-1--A-F1-N-N1-NN-N-N-U1-ABA-047-AA-NN-00-00	SERIES 51	S51-110MV-1
83009140	PUMP-VAR-DISPL CW 90PV130	90R130-KA-1-DE-80-L-4-F1-F-03-GBA-14-14-24	SERIES 90	S90-130PV
83009141	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-2-CD-60-R-3-T2-E-03-FBA-45-45-30	SERIES 90	S90-100PV
83009142	PUMP-VAR DISPL, CW 90PV100	90-R-100-LE-2-BC-60-R-3-S1-E-03-FBA-45-45-30	SERIES 90	S90-100PV
83009145	PUMP-VAR DISPL MPV046C	MPV-046-C-B-A-J-S-B-B-AA-A-A-BFF-AB-U-DF-A-NNN-***	M46	M46-046PV
83009147	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-2-NN-80-S-3-C7-L-00-EFC-45-45-28	SERIES 90	S90-075PV
83009148	PUMP-VAR-DISPL CCW 90PV042	90L042-KA-2-NN-80-S-3-C3-B-00-EFC-45-45-28	SERIES 90	S90-042PV
83009149	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-T2-C0-L-N-G0-AHA-100-AA-G0-00-B5	SERIES 51	S51-250MV
83009150	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-T2-C0-L-N-G0-NNN-100-AA-G0-00-B5	SERIES 51	S51-250MV
83009151	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-E2-A5-A-N-A6-ACA-032-AA-F0-03-00	SERIES 51	S51-160MV
83009153	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-NN-80-S-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83009154	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-NN-80-S-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-075PV
83009157	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-BC-60-S-3-S1-E-04-GBA-42-42-24	SERIES 90	S90-075PV
83009161	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-8-N-0-S1-W-00-NNN-00-00-E6	SERIES 90	S90-100MF
83009162	PUMP-TANDEM, VAR DISPL MPT035D	MPT-035-D-H-L-R-A-AA-B-A-A-A-BJJ-DR-A-FF-B-C-A-A-BJJ-DR-A-FF-H-GNS-***	M35/44	035PT
83009171	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-E1-A5-A-N-G0-NNN-032-AA-F3-03-00	SERIES 51	S51-160MV
83009172	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-T2-C0-L-N-K7-NNN-079-AA-H0-00-C0	SERIES 51	S51-160MV
83009173	PUMP-VAR-DISPL CW 90PV180	90R180-MA-5-NN-80-S-C-F1-H-C5-FAC-35-35-24	SERIES 90	S90-180PV
83009177	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-BC-80-P-4-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83009183	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-CD-80-S-3-C7-D-03-GBA-42-42-24	SERIES 90	S90-075PV
83009184	PUMP-VAR-DISPL CCW 90PV075	90L075-CA-5-NN-80-S-3-S1-D-00-GBA-42-42-24	SERIES 90	S90-075PV
83009185	PUMP-VAR-DISPL CW 90PV130	90R130-CB-1-NN-80-S-3-F1-F-00-EEB-35-35-24-G005	SERIES 90	S90-130PV
83009188	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A3-C2-N-E6-F-G4-H3-L-20-L-20-B-L-26-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83009190	MOTOR-VAR-DISPL 51MV110-1	51V110-1--A-F1-N-E2-B1-N-N-U1-NNN-054-AA-NN-00-00	SERIES 51	S51-110MV-1
83009191	MOTOR-VAR-DISPL H1B080	H1-B-080-A-HE-HE-N-B-TB-VS-AS-S-A-10-NN-054-Z-00-N05	H1-HP MOTORS	H1-080MB1
83009193	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-NN-80-S-M-C8-H-03-NNN-42-42-24	SERIES 90	S90-180PV
83009196	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-1-NN-80-T-4-F1-K-03-NNN-20-20-24	SERIES 90	S90-250PV
83009197	MOTOR-VAR-DISPL H1B110	H1-B-110-A-M2-CA-N-B-RA-DS-KS-S-A-10-NN-022-N-00-NNN	H1-HP MOTORS	H1-110MB1
83009198	MOTOR-VAR-DISPL H1B110	H1-B-110-A-M1-CA-N-B-RA-DS-KS-S-A-10-NN-022-N-00-NNN	H1-HP MOTORS	H1-110MB1
83009200	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-DE-80-L-4-C8-H-04-GBA-42-42-24	SERIES 90	S90-130PV
83009201	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-NN-80-L-4-F1-H-04-GBA-42-42-24	SERIES 90	S90-130PV
83009203	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HS-1-NN-80-D-4-S1-L-03-GBA-35-35-28	SERIES 90	S90-075PV

83009205	PUMP-VAR DISPL MPV044D	MPV-044-D-B-A-G-Y-S-E-AA-A-A-BEE-DR-A-FF-A-NNN-***	M35/44	044PV
83009208	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A4-C1-B-E5-F-G5-NN-L-40-L-40-B-P-32-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83009210	PUMP-VAR-DISPL CCW 90PV130	90L130-HF-1-AB-80-P-4-C8-F-03-GBA-26-26-30	SERIES 90	S90-130PV
83009212	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HF-5-AB-60-S-4-S1-C-03-GBA-23-23-24	SERIES 90	S90-055PV
83009213	PUMP-VAR DISPL, CW 90PV100	90-R-100-HS-1-BC-60-S-3-C7-F-02-GBA-35-35-24	SERIES 90	S90-100PV
83009214	PUMP-VAR DISPL, CW 90PV100	90-R-100-HS-1-CD-80-P-3-F1-F-03-GBA-35-29-24	SERIES 90	S90-100PV
83009215	PUMP-VAR-DISPL CCW 90PV100	90L100-KP-5-CD-80-S-3-F1-E-03-FAD-42-42-24	SERIES 90	S90-100PV
83009216	PUMP-VAR-DISPL CCW 90PV100	90L100-KP-5-AB-80-S-3-F1-E-03-FAD-42-42-24	SERIES 90	S90-100PV
83009218	MOTOR-VAR-DISPL H1B080	H1-B-080-A-L1-BA-N-A-PA-VS-AS-S-A-10-NN-050-N-00-NNN	H1-HP MOTORS	H1-080MB1
83009220	MOTOR-VAR-DISPL 51MV110	51V110-R-F1-N-HZ-B1-B-H-G5-NNN-022-AA-F0-07-00	SERIES 51	S51-110MV
83009221	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-2-BC-80-D-3-S1-L-00-GFD-45-45-34	SERIES 90	S90-075PV
83009222	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A4-C2-B-D8-H-G1-NN-L-40-L-40-C-P-32-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83009223	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-B-E2-B1-N-N-U1-NNN-016-AA-NN-00-00	SERIES 51	S51-060MV-1
83009224	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-TA-C0-L-N-G0-NNN-075-AA-G0-00-C1	SERIES 51	S51-160MV
83009234	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-BC-80-R-4-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
83009235	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-1-BC-80-R-4-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
83009237	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MA-1-NN-80-S-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83009239	PUMP-TANDEM, VAR DISPL CCW H1T053L	H1-T-053-L-A-A-A5-C2-N-E7-F-G1-NN-28-28-28-28-N-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83009242	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-2-CD-80-D-3-C6-L-00-GFD-45-45-34	SERIES 90	S90-075PV
83009243	PUMP-VAR DISPL, CW 90PV055	90-R-055-MK-1-AB-80-P-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
83009247	MOTOR-FIXED DISPL MMF025C	MMF-025-C-A-S-B-C-B-NNN-***	LIGHT DUTY	025MF
83009265	PUMP-VAR-DISPL CW 90PV100	90R100-DD-5-CD-80-S-4-C7-E-GB-GBA-35-35-30	SERIES 90	S90-100PV
83009267	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-A-T-A-J-BC-A-A-BBB-CB-A-GG-5-NNN-***	M46	M46-046PV
83009269	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-J-S-B-S-AA-V-A-BHH-DA-A-WA-A-NNN-***	M46	M46-046PV
83009270	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-J-S-B-S-AA-V-A-BRR-DA-A-WA-A-NNN-***	M46	M46-046PV
83009274	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-T2-C2-L-N-G0-NNN-082-AA-G3-00-B4	SERIES 51	S51-160MV
83009275	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-CD-80-S-3-F1-J-09-NNN-40-40-30	SERIES 90	S90-250PV
83009276	PUMP-VAR-DISPL CCW 90PV250	90L250-HF-2-NN-80-S-3-C8-K-00-NNN-38-38-28	SERIES 90	S90-250PV
83009282	PUMP-VAR-DISPL CW 90PV100	90R100-MA-5-AB-60-S-3-C7-E-C5-GBA-42-42-24	SERIES 90	S90-100PV
83009283	PUMP-VAR-DISPL CCW 90PV075	90L075-MA-5-BC-60-P-3-S1-D-C5-GBA-42-42-24	SERIES 90	S90-075PV
83009293	PUMP-VAR-DISPL CW 90PV100	90R100-DD-5-NN-60-S-4-S1-E-GB-GBA-26-26-24	SERIES 90	S90-100PV
83009294	MOTOR-VAR-DISPL 51MD160	51D160-A-D4-N-T4-C0-L-N-L4-ACA-040-AA-F3-00-B3	SERIES 51	S51-160MV
83009295	MOTOR-VAR-DISPL H1B110	H1-B-110-A-K2-K2-N-B-RB-VS-ES-S-A-10-NN-022-N-25-NNN	H1-HP MOTORS	H1-110MB1
83009296	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A4-C2-N-E7-F-G5-T3-30-30-30-M-P-20-PN-NNN-S01	H1-MP PUMPS	H1-045PT/053PT
83009302	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-B-Z-C-J-BA-B-B-G-A-BRR-DB-A-GG-B-D-G-A-BRR-DB-A-GG-C-NNN-*	M46	M46-046PT
83009303	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-C2-C3-C-D8-K-G9-NN-L-42-L-42-D-P-24-P2-NNN-D4F	H1-HP PUMPS	H1-089PV/100PV

83009304	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-E1A6-02-C-3-A-2-F-N-B-34-34-B-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83009305	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-N2-NN-N-N-A0-NNN-070-AA-E6-00-00	SERIES 51	S51-250MV
83009306	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-N1-NN-N-N-U1-NNN-050-AA-E4-00-00	SERIES 51	S51-110MV-1
83009307	PUMP-VAR DISPL, CW 90PV075	90-R-075-DD-1-BC-60-S-4-C7-D-G1-GBA-42-42-18	SERIES 90	S90-075PV
83009308	PUMP-VAR DISPL, CW 90PV100	90-R-100-DD-1-CD-60-S-4-C7-E-G1-GBA-42-42-18	SERIES 90	S90-100PV
83009311	PUMP-VAR-DISPL CCW 90PV100	90L100-HF-5-CD-60-S-4-C7-F-03-GBA-35-35-24	SERIES 90	S90-100PV
83009312	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A4-C2-B-F1-F-G4-H3-K-35-K-35-B-L-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83009317	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-1-NN-60-S-4-T1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83009319	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-C-E1A3-03-A-N-A-3-F-N-B-28-28-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83009320	MOTOR-VAR DISPL MMV046C	MMV-046-C-A-E-K-D-AV-VNC-***	M46	M46-046MV
83009322	MOTOR-VAR-DISPL H1B110#	H1-B-110-A-P1-D1-N-B-TL-DS-JS-S-A-15-NN-040-Z-24-NNN	H1-HP MOTORS	H1-110MB1
83009323	MOTOR-VAR-DISPL H1B110#	H1-B-110-A-P1-D1-N-B-TL-DS-JS-S-A-15-NN-024-Z-24-NNN	H1-HP MOTORS	H1-110MB1
83009324	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-5-CD-60-R-3-C7-E-21-FAD-42-42-28	SERIES 90	S90-100PV
83009325	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-H-S-B-U-BA-A-B-BHH-DA-A-HH-A-NNN-***	M46	M46-046PV
83009326	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-K-S-B-T-AA-W-B-BJJ-DA-A-HH-B-NNN-***	M46	M46-046PV
83009327	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-H-S-B-U-BA-A-B-BJJ-DA-A-HH-A-NNN-***	M46	M46-046PV
83009328	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-K-S-B-U-BA-W-B-BJJ-DA-A-HH-B-NNN-***	M46	M46-046PV
83009329	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-H-S-B-U-BA-W-B-BJJ-DA-A-HH-A-NNN-***	M46	M46-046PV
83009330	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-H-S-B-U-BA-A-B-BRR-DA-A-HH-A-NNN-***	M46	M46-046PV
83009332	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-NN-60-S-4-K2-D-03-GBA-23-23-24	SERIES 90	S90-075PV
83009333	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A5-C2-N-D8-F-G5-H3-L-35-L-35-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83009334	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A5-C2-N-D8-F-G5-H5-L-35-L-35-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83009337	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-V-CD-8E-R-3-C7-F-03-GB1-42-42-28	SERIES 90	S90-100PV
83009344	PUMP-VAR-DISPL CW 90PV250	90R250-KP-1-DE-80-T-4-C8-J-03-GLA-42-42-24	SERIES 90	S90-250PV
83009346	MOTOR-VAR-DISPL 51MD160	51D160-A-D4-N-T4-C0-L-N-L4-ACA-055-AA-F3-00-B3	SERIES 51	S51-160MV
83009353	MOTOR-VAR-DISPL H1B110	H1-B-110-A-L2-BA-N-A-PB-VS-DS-S-A-10-NN-000-N-00-NNN	H1-HP MOTORS	H1-110MB1
83009358	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A4-C1-N-E6-F-G5-H3-L-35-L-35-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83009364	MOTOR-VAR-DISPL 51MC080	51C080-R-S1-N-L2-B1-V-A-C2-ADA-022-AA-F3-B2-00	SERIES 51	S51-080MV
83009368	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-BC-60-S-4-S1-F-04-GBA-42-42-24	SERIES 90	S90-100PV
83009369	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-BC-60-P-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83009370	PUMP-VAR DISPL, CW 90PV100	90-R-100-MP-1-BC-60-P-3-C7-E-03-GBA-40-40-24	SERIES 90	S90-100PV
83009373	PUMP-VAR-DISPL CCW 90PV130	90L130-KN-5-DG-80-S-3-C8-H-03-GBA-26-26-22	SERIES 90	S90-130PV
83009374	PUMP-VAR-DISPL CCW 90PV130	90L130-KN-5-AB-80-S-3-C8-H-03-GBA-26-26-22	SERIES 90	S90-130PV
83009378	PUMP-VAR DISPL, CW 90PV055	90-R-055-DC-5-NN-80-D-N-S1-L-Z1-GBA-29-29-24	SERIES 90	S90-055PV
83009380	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-C-E1A3-03-A-N-N-N-P-N-B-28-28-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83009382	PUMP-TANDEM, VAR DISPL CCW H1T045L	H1-T-045-L-A-N-A5-C2-N-E7-F-G6-T2-35-35-35-35-M-P-24-PN-NNN-S01	H1-MP PUMPS	H1-045PT/053PT

83009385	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-N-N1-NN-N-N-U1-NNN-044-AA-E6-00-00	SERIES 51	S51-060MV-1
83009390	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-L1-B1-W-B-J1-NNN-062-AA-G3-D4-00	SERIES 51	S51-160MV
83009392	PUMP-VAR-DISPL CCW 90PV250	90L250-MA-5-NN-80-T-3-C8-K-C5-NNN-32-32-24	SERIES 90	S90-250PV
83009393	MOTOR-VAR-DISPL 51MV060-1	51V060-1--R-D1-N-E2-B1-N-N-U1-ACB-020-AA-NN-00-00	SERIES 51	S51-060MV-1
83009397	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-BC-80-P-4-S1-D-03-GBA-38-38-24	SERIES 90	S90-075PV
83009398	PUMP-VAR-DISPL CCW 90PV130	90L130-MA-5-AB-80-L-3-F1-H-C5-GBA-38-38-24	SERIES 90	S90-130PV
83009400	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-T2-C2-L-N-G0-NNN-090-AA-G0-00-B3	SERIES 51	S51-250MV
83009401	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-5-NN-80-S-3-S1-B-20-GLA-38-38-24	SERIES 90	S90-055PV
83009409	MOTOR-VAR-DISPL H1B110	H1-B-110-A-L2-BA-N-B-PB-VS-DS-S-A-10-NN-000-N-00-NNN	H1-HP MOTORS	H1-110MB1
83009410	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-T2-C0-L-N-G0-ADA-035-AA-NN-00-C0	SERIES 51	S51-160MV
83009415	PUMP-VAR DISPL, CW 90PV055	90-R-055-HS-1-CD-80-R-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83009416	PUMP-VAR-DISPL CCW 90PV130	90L130-HF-5-BC-80-S-3-C8-H-02-GBA-45-45-30	SERIES 90	S90-130PV
83009418	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-D-ANNB-02-A-N-A-2-F-N-A-28-28-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83009420	MOTOR-VAR-DISPL 51MC060	51C060-R-D1-N-L2-B1-V-A-C0-ACB-036-AA-E6-B2-00	SERIES 51	S51-060MV
83009421	MOTOR-VAR-DISPL 51MD080	51D080-R-D3-N-L2-B1-V-A-C0-ABA-040-AA-E6-B2-00	SERIES 51	S51-080MV
83009424	PUMP-VAR-DISPL CCW H1PV130	H1-P-130-L-B-A3-C3-N-D3-G-G2-H3-L-35-L-35-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83009425	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A3-C3-N-F4-H-G9-H6-L-35-L-35-M-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83009426	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A3-C3-N-D3-H-G1-NN-L-35-L-35-M-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83009427	MOTOR-VAR-DISPL H1B110#	H1-B-110-A-E2-AA-N-A-TB-DN-JN-N-A-10-NN-060-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83009428	MOTOR-VAR-DISPL H1B110#	H1-B-110-A-E2-AA-N-A-TB-DN-JN-N-N-NN-NN-060-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83009429	MOTOR-VAR-DISPL H1B110#	H1-B-110-A-E2-AA-N-A-TB-DN-JN-N-N-NN-NN-040-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83009430	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-C7-N-TA-C2-N-N-X1-NNN-024-AA-NN-00-21	SERIES 51	S51-080MV-1
83009432	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-BC-80-L-3-C8-F-04-GBA-42-42-24	SERIES 90	S90-130PV
83009437	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-1-NN-60-S-4-C7-D-03-GBA-35-35-28	SERIES 90	S90-100PV
83009443	PUMP-VAR-DISPL CW 90PV075	90R075-CB-5-BC-60-L-3-S1-E-00-GBA-35-35-24	SERIES 90	S90-075PV
83009444	PUMP-VAR-DISPL CW 90PV100	90R100-CB-5-CD-60-L-3-C7-E-00-GBA-35-35-24	SERIES 90	S90-100PV
83009445	PUMP-VAR-DISPL CW 90PV130	90R130-CB-5-CD-80-L-3-C8-H-00-GBA-35-35-24	SERIES 90	S90-130PV
83009447	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KT-1-BC-80-R-3-F1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
83009449	PUMP-VAR-DISPL CCW H1PV147	H1-P-147-L-C-A5-C3-B-D8-G-G3-H6-L-38-L-38-L-P-30-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83009450	PUMP-VAR-DISPL CCW H1PV147	H1-P-147-L-C-A5-C3-B-D8-G-G3-NN-L-38-L-38-L-P-30-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83009455	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-A-A5-C3-N-D6-H-G1-H3-L-38-L-38-M-L-28-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83009456	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-A-A5-C3-N-F6-H-G9-H6-L-38-L-38-M-L-28-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83009458	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A8-C2-D-D3-H-F1-H3-L-35-L-35-C-M-24-P1-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83009460	PUMP-TANDEM, VAR DISPL MPT035D	MPT-035-D-A-Y-R-J-BA-B-A-A-A-BJJ-DR-A-FF-B-A-A-A-BJJ-DR-A-FF-A-NNN-***	M35/44	035PT
83009468	PUMP-VAR DISPL, CCW 90PV100	90-L-100-DD-1-CD-80-R-3-C7-F-G1-GBA-35-35-24	SERIES 90	S90-100PV
83009470	PUMP-VAR DISPL, CCW 90PV100	90-L-100-DD-1-NN-80-R-3-S1-F-G1-GBA-35-35-24	SERIES 90	S90-100PV

83009471	PUMP-VAR-DISPL CW 90PV075	90R075-HF-5-CD-80-S-3-C6-E-03-GBA-42-42-24	SERIES 90	S90-075PV
83009472	MOTOR-VAR-DISPL 51MD160	51D160-A-D4-N-TA-C2-L-N-G0-NNN-058-AA-G3-00-B2	SERIES 51	S51-160MV
83009473	MOTOR-VAR-DISPL 51MD160	51D160-A-D4-N-TA-C2-L-N-G0-NNN-058-AA-G3-00-B1	SERIES 51	S51-160MV
83009478	PUMP-VAR DISPL, CW 90PV075	90-R-075-FN-1-BC-60-P-7-C6-D-B6-ELA-38-38-28	SERIES 90	S90-075PV
83009479	MOTOR-VAR-DISPL H1B080	H1-B-080-A-M1-CA-N-A-RB-CS-HS-S-A-10-NN-016-N-00-NNN	H1-HP MOTORS	H1-080MB1
83009480	PUMP-VAR-DISPL CCW H1PV147	H1-P-147-L-C-A5-C2-N-D6-G-G2-H3-L-45-L-45-L-L-30-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83009482	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-AB-80-R-3-S1-E-03-GBA-32-32-24	SERIES 90	S90-075PV
83009501	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-K-T-B-B-BA-A-A-BJJ-CB-A-SS-4-NNN-***	M46	M46-046PV
83009503	PUMP-VAR DISPL, CW 90PV055	90-R-055-KT-1-CD-80-P-4-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83009508	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-BC-80-L-3-F1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
83009509	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-T2-C0-L-N-G0-NNN-048-AA-F0-00-A7	SERIES 51	S51-160MV
83009511	PUMP-VAR DISPL, CW 90PV055	90-R-055-KN-1-NN-80-S-4-K1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
83009512	PUMP-VAR-DISPL CCW 90PV130	90L130-HF-5-BC-80-S-3-C8-H-04-GBA-26-26-24	SERIES 90	S90-130PV
83009519	PUMP-VAR-DISPL CCW 90PV100	90L100-HF-5-BC-80-S-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83009521	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-BB-60-S-3-C7-D-03-GBA-14-32-24	SERIES 90	S90-075PV
83009524	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-1-AB-60-R-3-S1-C-03-GBA-17-17-24	SERIES 90	S90-055PV
83009526	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-L2-B2-V-A-H7-NNN-032-AA-F0-B2-00	SERIES 51	S51-160MV
83009527	PUMP-VAR DISPL, CCW 90PV100	90-L-100-DC-1-NN-80-S-3-F1-E-G8-GBA-42-42-24	SERIES 90	S90-100PV
83009528	PUMP-VAR-DISPL CCW 90PV130	90L130-KT-5-BC-80-S-3-F1-F-03-GBA-26-26-22	SERIES 90	S90-130PV
83009532	MOTOR-VAR-DISPL 51MV110-1	51V110-1--A-C8-N-T2-C2-N-N-X1-NNN-036-AA-F0-00-20	SERIES 51	S51-110MV-1
83009536	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-K-S-B-B-BA-A-A-BJJ-CB-A-SS-4-NNN-***	M46	M46-046PV
83009543	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A8-C2-C-D6-H-G9-NN-L-42-L-42-C-L-28-P1-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83009544	MOTOR-VAR-DISPL H1B110#	H1-B-110-A-P1-D1-N-A-TA-DS-KS-S-A-15-NN-040-Z-24-NNN	H1-HP MOTORS	H1-110MB1
83009545	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-1-NN-80-P-3-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83009546	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-AB-60-P-3-S1-C-03-GBA-32-14-30	SERIES 90	S90-075PV
83009550	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-1-AB-80-L-3-C7-E-03-GBA-45-36-30	SERIES 90	S90-075PV
83009551	MOTOR-VAR-DISPL H1B160	H1-B-160-A-L1-BA-N-B-PA-VS-ES-S-A-15-NN-100-N-00-NNN	H1-HP MOTORS	H1-160MB1
83009552	PUMP-VAR-DISPL CW 90PV042	90R042-HF-5-AB-80-S-4-C3-C-03-GBA-32-32-24	SERIES 90	S90-042PV
83009553	PUMP-VAR DISPL, CW 90PV100	90-R-100-KT-1-CD-80-R-2-C7-F-03-GBA-38-17-28-F061	SERIES 90	S90-100PV
83009554	PUMP-VAR DISPL, CW 90PV055	90-R-055-KT-1-NN-80-D-4-S1-L-03-GBA-42-42-20-F062	SERIES 90	S90-055PV
83009556	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A5-C2-N-D3-G-F3-H6-L-28-L-28-A-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83009558	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A4-C2-N-E7-F-G1-H3-30-30-38-20-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83009562	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A4-C2-N-D6-F-G5-H2-L-30-L-30-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83009563	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-1-BB-60-L-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83009568	PUMP-VAR-DISPL CW 90PV042	90R042-DD-5-BB-80-S-4-C3-C-GB-GBA-42-42-24	SERIES 90	S90-042PV
83009581	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-NN-80-L-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-075PV

83009583	PUMP-VAR-DISPL CW 90PV075	90R075-MA-5-NN-60-S-3-S1-C-C5-GBA-26-26-24	SERIES 90	S90-075PV
83009589	PUMP-VAR DISPL, CW 90PV055	90-R-055-DC-2-NN-60-D-4-S1-L-GB-GBA-32-32-22	SERIES 90	S90-055PV
83009592	PUMP- VARIABLE, DIRECT DISPLACMENT	LPV-A-A-B-A-A-G-AB-C-A-BDD-DR-A-FF-B-NNN-***	LPV	LPV
83009593	PUMP-VAR-DISPL CCW 90PV130	90L130-KT-5-BB-80-S-3-F1-F-03-GBA-26-26-22	SERIES 90	S90-130PV
83009594	PUMP-TANDEM, VAR DISPL MPT035D	MPT-035-D-G-W-R-C-BA-C-A-A-A-BFF-DR-A-FF-C-C-A-A-BFF-DL-A-FF-B-NNN-***	M35/44	035PT
83009608	PUMP-VAR-DISPL CW 90PV180	90R180-MA-5-BC-80-S-C-C8-H-C6-NNN-45-45-28	SERIES 90	S90-180PV
83009609	PUMP-VAR DISPL, CW 90PV055	90-R-055-KN-1-NN-80-P-4-S1-C-03-GBA-24-24-20	SERIES 90	S90-055PV
83009610	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-BC-80-P-4-S1-D-04-GBA-30-30-24-F065	SERIES 90	S90-075PV
83009612	PUMP-VAR-DISPL CW 90PV130	90R130-MA-5-CD-80-L-4-C8-F-C6-GBA-26-26-24	SERIES 90	S90-130PV
83009626	PUMP-VAR-DISPL CCW 90PV075	90L075-HF-5-NN-80-S-3-C7-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83009627	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-HZ-B1-B-H-C2-NNN-059-AA-F0-05-00	SERIES 51	S51-160MV
83009628	MOTOR-VAR-DISPL 51MV110	51V110-R-C8-N-HZ-B1-B-H-C2-NNN-040-AA-F0-05-00	SERIES 51	S51-110MV
83009629	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-BC-60-S-3-C7-E-02-GBA-42-42-30	SERIES 90	S90-100PV
83009635	PUMP-VAR-DISPL CCW 90PV100	90L100-FD-5-NN-60-P-7-S1-F-B1-GCA-42-42-28	SERIES 90	S90-100PV
83009636	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A4-C1-B-D6-H-G1-NN-L-30-L-30-C-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83009639	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-8-N-0-C6-W-00-EAA-00-00-G0	SERIES 90	S90-075MF
83009640	PUMP-VAR DISPL, CW 90PV055	90-R-055-HS-1-NN-60-P-3-S1-C-03-GBA-29-29-24	SERIES 90	S90-055PV
83009641	PUMP-VAR DISPL, CW 90PV055	90-R-055-HS-1-CD-80-P-3-S1-C-03-GBA-29-29-24	SERIES 90	S90-055PV
83009642	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-BB-80-S-4-C8-K-04-NNN-38-38-24	SERIES 90	S90-250PV
83009646	PUMP-VAR-DISPL CW 90PV075	90R075-DC-2-BC-80-S-4-C7-D-GB-GBA-26-26-24	SERIES 90	S90-075PV
83009647	PUMP-VAR DISPL, CW 90PV100	90-R-100-CB-1-NN-80-S-4-S1-E-00-GBA-20-38-24	SERIES 90	S90-100PV
83009648	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-CD-80-S-4-F1-E-03-GBA-20-38-24	SERIES 90	S90-100PV
83009659	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-NN-80-S-4-K2-D-03-GBA-21-21-24-F065	SERIES 90	S90-075PV
83009660	MOTOR-VAR-DISPL 51MC110-1	51C110-1--R-D3-N-N1-NN-N-N-U1-NNN-045-AA-F0-00-00	SERIES 51	S51-110MV-1
83009661	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KN-1-NN-80-R-4-S1-D-03-GBA-42-42-24	SERIES 90	S90-055PV
83009668	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HS-1-BC-80-S-4-S1-C-03-GBA-26-26-24	SERIES 90	S90-055PV
83009669	PUMP-VAR-DISPL CCW 90PV130	90L130-CB-5-NN-80-R-4-T4-F-00-GBA-32-32-24	SERIES 90	S90-130PV
83009670	PUMP-VAR-DISPL CW 90PV250	90R250-MA-5-NN-80-T-4-C8-K-C5-NNN-32-32-24	SERIES 90	S90-250PV
83009673	PUMP-VAR DISPL, CW 90PV075	90-R-075-HS-1-NN-80-S-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-075PV
83009674	PUMP-VAR-DISPL CW 90PV130	90R130-MA-5-DG-80-D-4-C8-L-C5-GBA-35-35-24-F076	SERIES 90	S90-130PV
83009675	PUMP-VAR-DISPL CW 90PV130	90R130-MA-5-CD-80-D-4-C8-L-C5-GBA-35-35-24-F076	SERIES 90	S90-130PV
83009676	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-BC-80-P-4-S1-D-04-GBA-29-29-24-F065	SERIES 90	S90-075PV
83009682	MOTOR-VAR-DISPL 51MV060-1	51V060-1--R-S1-N-B3-B3-N-N-U3-ABA-018-AA-E4-00-00	SERIES 51	S51-060MV-1
83009683	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A8-C2-D-D8-H-G1-H3-L-23-L-23-N-E-24-P1-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83009687	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-G-T-B-J-AA-A-A-BBB-CE-A-JJ-5-NNN-***	M46	M46-046PV
83009694	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A7-C2-C-D8-K-G9-NN-L-42-L-42-N-E-28-P2-NNN-D3F	H1-HP PUMPS	H1-089PV/100PV

83009695	MOTOR-VAR-DISPL 51MV080-1	51V080-1--A-S1-N-F1-B1-N-N-U1-NNN-016-AA-E4-00-00	SERIES 51	S51-080MV-1
83009696	MOTOR-VAR-DISPL 51MV060-1	51V060-1--R-S1-N-N1-NN-N-N-U1-NNN-030-AA-F0-00-00	SERIES 51	S51-060MV-1
83009697	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-5-AB-60-S-3-S1-C-02-GBA-32-32-24	SERIES 90	S90-055PV
83009699	PUMP-VAR-DISPL CW 90PV180	90R180-MA-5-BC-80-T-M-C8-H-C5-NNN-26-26-24	SERIES 90	S90-180PV
83009701	PUMP-VAR-DISPL CW 90PV180	90R180-MA-1-BC-80-T-M-F1-J-03-FAC-35-35-24	SERIES 90	S90-180PV
83009703	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-BC-80-R-3-S1-E-00-GBA-14-14-24	SERIES 90	S90-100PV
83009704	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A5-C3-B-D6-G-G3-H4-L-40-L-40-L-L-28-PN-NNN-E02	H1-HP PUMPS	H1-115PV/130PV
83009705	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A5-C3-B-D6-G-G3-H3-L-40-L-40-L-L-28-PN-NNN-E02	H1-HP PUMPS	H1-115PV/130PV
83009707	PUMP-VAR-DISPL CW 90PV180	90R180-MA-5-BC-80-T-C-C8-J-C6-NNN-45-45-28	SERIES 90	S90-180PV
83009708	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-C-E1-A5-A-N-G0-ABA-060-AA-NN-03-00	SERIES 51	S51-160MV
83009709	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-E1-A5-A-N-G0-NNN-168-AA-G0-03-00	SERIES 51	S51-250MV
83009712	PUMP-VAR-DISPL CCW 90PV100	90L100-KP-1-AB-80-S-3-F1-D-03-FAD-42-42-24	SERIES 90	S90-100PV
83009717	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-BC-80-S-C-C8-J-06-NNN-36-36-24	SERIES 90	S90-180PV
83009719	PUMP-VAR DISPL, CW 90PV100	90-R-100-KN-1-NN-80-R-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83009720	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-E1A4-02-A-N-A-2-F-N-N-21-21-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83009721	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-1-CD-80-P-4-S1-C-03-GBA-29-29-24	SERIES 90	S90-055PV
83009726	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-NN-80-L-4-S1-F-03-GBA-20-20-20	SERIES 90	S90-100PV
83009739	PUMP-VAR-DISPL CW 90PV250	90R250-KN-5-CD-80-T-3-F1-K-03-NNN-35-35-24	SERIES 90	S90-250PV
83009752	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MA-1-NN-60-L-3-C7-E-03-GBA-32-32-24	SERIES 90	S90-100PV
83009757	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-CD-80-R-3-C8-H-03-GBA-32-35-24	SERIES 90	S90-130PV
83009758	PUMP-VAR-DISPL CW 90PV042	90R042-FB-6-BC-80-S-7-C3-B-B1-FAC-48-48-26	SERIES 90	S90-042PV
83009761	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-N-HZ-B1-A-N-G0-NNN-160-AA-G0-03-00	SERIES 51	S51-250MV
83009763	PUMP-VAR-DISPL CW 90PV130	90R130-HF-5-AB-80-L-3-F1-H-03-GBA-42-42-24	SERIES 90	S90-130PV
83009764	PUMP-VAR-DISPL CW 90PV130	90R130-FH-2-AB-80-S-7-C8-F-B1-GBA-42-42-26	SERIES 90	S90-130PV
83009770	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A8-C2-C-F3-J-G5-H3-J-40-J-40-B-L-24-P2-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83009772	MOTOR-VAR-DISPL H1B060	H1-B-060-A-T2-D2-N-B-TB-VN-AN-N-A-15-NN-035-Z-35-NNN	H1-HP MOTORS	H1-060MB1
83009773	MOTOR-VAR-DISPL H1B160	H1-B-160-A-L1-BA-N-B-PA-VS-ES-S-A-30-NN-090-N-00-NNN	H1-HP MOTORS	H1-160MB1
83009774	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-CD-80-R-4-C6-D-03-GBA-32-32-28	SERIES 90	S90-055PV
83009775	PUMP-VAR-DISPL CCW 90PV130	90L130-KN-1-CD-80-R-4-F1-H-03-GBA-42-42-24	SERIES 90	S90-130PV
83009776	MOTOR-VAR-DISPL H1B060	H1-B-060-A-E2-AA-N-B-TB-DN-GN-N-N-NN-NN-015-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83009777	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-NN-80-S-C-C8-J-03-NNN-42-42-24	SERIES 90	S90-180PV
83009781	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MA-1-CD-80-P-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83009790	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-N-A2-C2-N-E7-F-G1-H5-38-38-38-38-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83009792	PUMP- VARIABLE, DIRECT DISPLACMENT	LPV-A-A-C-C-A-G-AB-C-A-BFF-DR-A-FF-A-NNN-***	LPV	LPV
83009793	PUMP-VAR DISPL, CW 90PV075	90-R-075-MV-1-AB-60-R-3-S1-E-C5-FAD-38-35-24	SERIES 90	S90-075PV
83009794	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-8-N-0-C7-W-00-NNN-00-00-E4	SERIES 90	S90-100MF

83009795	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-AB-80-S-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83009800	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A8-C2-C-D6-K-F1-H3-K-40-K-40-F-L-24-P2-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83009801	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A8-C2-C-D6-K-F1-H3-K-45-K-45-F-L-24-P2-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83009803	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-HZ-B1-B-N-C2-NNN-050-AA-H0-12-00	SERIES 51	S51-160MV
83009804	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-8-N-0-C6-W-00-EAJ-00-00-G0	SERIES 90	S90-075MF
83009812	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MA-1-NN-80-P-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83009814	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-NN-80-S-3-C8-K-03-NNN-23-23-28	SERIES 90	S90-250PV
83009816	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-TA-C2-L-N-J8-NNN-032-AA-NN-00-B0	SERIES 51	S51-160MV
83009829	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-BC-80-R-4-S1-D-03-GBA-32-32-28	SERIES 90	S90-055PV
83009830	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-CD-60-P-3-C7-F-03-GBA-45-45-24	SERIES 90	S90-100PV
83009831	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-L2-B1-V-A-G0-AHA-080-AA-G0-B2-00	SERIES 51	S51-250MV
83009832	MOTOR-VARIABLE CARTRIDGE K	K-C-38CN-E-RNF-F45-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83009835	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-L2-B1-V-A-G5-NNN-125-AA-G0-B2-00	SERIES 51	S51-250MV
83009836	MOTOR-VAR-DISPL H1B060	H1-B-060-A-E2-AA-N-B-TA-CN-GN-N-N-NN-NN-036-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83009837	PUMP-VAR DISPL, CW 90PV100	90-R-100-KT-5-NN-80-P-3-T2-E-03-GBA-38-38-20	SERIES 90	S90-100PV
83009842	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-NN-60-P-3-S1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
83009843	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-2-CD-60-P-3-C7-F-03-GBA-32-32-24	SERIES 90	S90-100PV
83009844	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-2-NN-60-P-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-075PV
83009845	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-1-AB-80-P-4-S1-C-03-GBA-29-29-24	SERIES 90	S90-055PV
83009857	PUMP-VAR-DISPL CW 90PV180	90R180-HF-5-CD-80-T-C-C8-J-04-NNN-35-35-24	SERIES 90	S90-180PV
83009858	PUMP-VAR DISPL, CW 90PV100	90-R-100-MV-1-BC-60-R-4-C7-E-05-GBA-35-35-24	SERIES 90	S90-100PV
83009866	PUMP-VAR-DISPL 42PV041 CCW	42-L-41-E-E2D8-03-A-N-A-2-G-N-B-30-30-B-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83009867	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A3-C2-N-D6-H-G9-H3-L-38-L-38-M-L-30-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83009870	MOTOR-VAR DISPL MMV046C	MMV-046-C-A-E-L-D-AV-VNC-***	M46	M46-046MV
83009871	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-HS-A1-B-E-G7-ABA-050-AA-G0-05-25	SERIES 51	S51-250MV
83009874	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A4-C2-N-D8-H-G9-H5-L-33-L-33-F-P-20-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83009882	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A4-C1-N-E6-F-F2-H3-L-25-L-25-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83009884	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A2-C3-N-D8-G-G3-NN-L-23-L-23-A-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83009885	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A4-C2-N-E5-F-G5-H2-L-35-L-35-B-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83009886	PUMP-VAR-DISPL CW 90PV100	90R100-HF-5-BC-80-R-3-S1-E-04-GBA-35-35-24	SERIES 90	S90-100PV
83009896	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-C7-N-E1-B1-N-N-U1-NNN-053-AA-E6-00-00	SERIES 51	S51-080MV-1
83009897	PUMP-VAR-DISPL CW 90PV130	90R130-MA-1-AB-80-L-3-C8-F-03-GBA-26-26-26	SERIES 90	S90-130PV
83009903	PUMP-VAR-DISPL CCW H1PV165	H1-P-165-L-C-A5-C2-N-D6-G-G2-H6-L-40-L-40-L-L-20-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83009913	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-NN-80-P-4-T2-E-03-GBA-30-30-24	SERIES 90	S90-100PV
83009916	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-NN-80-P-4-S1-E-03-FAC-20-20-24	SERIES 90	S90-100PV
83009920	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-BB-80-S-C-C8-J-03-NNN-42-42-24	SERIES 90	S90-180PV

83009921	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-BB-80-S-C-C8-J-04-NNN-42-42-24	SERIES 90	S90-180PV
83009922	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-C-ANNB-03-A-N-A-2-F-N-N-34-34-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83009925	PUMP-VAR-DISPL CCW H1PV115	H1-P-115-L-B-A5-C1-N-D3-G-G3-NN-K-45-K-45-A-M-20-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83009926	PUMP-VAR-DISPL CCW H1PV115	H1-P-115-L-B-A5-C1-N-D3-G-G3-H4-K-45-K-45-A-M-20-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83009931	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-NN-80-P-3-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83009935	MOTOR-VAR-DISPL H1B160	H1-B-160-A-L2-BA-N-A-PB-VS-ES-S-A-10-NN-000-N-00-NNN	H1-HP MOTORS	H1-160MB1
83009938	MOTOR-VAR-DISPL H1B080	H1-B-080-A-M2-CA-N-C-RB-DS-HS-S-A-05-NN-025-N-00-NNN	H1-HP MOTORS	H1-080MB1
83009942	MOTOR-VAR-DISPL 51MV080	51V080-R-C7-B-N2-NN-N-N-A0-NNN-035-AA-NN-00-00	SERIES 51	S51-080MV
83009943	PUMP-VAR-DISPL 42PV041 CCW	42-L-41-E-E1A3-03-A-N-A-2-G-N-B-30-30-B-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83009949	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-1-NN-60-D-3-S1-L-03-GBA-38-38-24	SERIES 90	S90-075PV
83009951	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-CD-60-P-3-S1-D-03-GBA-38-38-24	SERIES 90	S90-075PV
83009956	MOTOR-VAR-DISPL H1B110	H1-B-110-A-L2-BA-N-A-PA-DS-KS-S-N-NN-NN-042-N-00-NNN	H1-HP MOTORS	H1-110MB1
83009958	MOTOR-VAR-DISPL H1B080	H1-B-080-A-M1-CA-N-B-RB-CS-JS-S-A-10-NN-000-N-00-NNN	H1-HP MOTORS	H1-080MB1
83009960	MOTOR-VAR-DISPL H1B110	H1-B-110-A-K2-K2-N-A-RA-DS-JS-S-N-NN-NN-030-N-26-NNN	H1-HP MOTORS	H1-110MB1
83009961	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-B-TA-C2-L-N-G0-NNN-162-AA-G0-00-B5	SERIES 51	S51-250MV
83009967	PUMP-VAR DISPL, CW 90PV055	90-R-055-HS-1-AB-80-R-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83009969	PUMP-VAR DISPL, CW 90PV100	90-R-100-MB-1-BC-60-P-4-F1-E-03-GBA-32-32-24	SERIES 90	S90-100PV
83009970	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-W-CD-60-E-3-C6-D-03-GFD-40-32-24	SERIES 90	S90-075PV
83009971	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-BC-80-S-4-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83009972	PUMP-VAR-DISPL CW 90PV180	90R180-MA-5-CD-80-T-M-C8-H-C6-NNN-29-29-24	SERIES 90	S90-180PV
83009978	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-AB-60-P-4-S1-E-03-GBA-32-14-30	SERIES 90	S90-100PV
83009979	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-NN-60-P-4-S1-E-03-GBA-32-14-30	SERIES 90	S90-100PV
83009980	PUMP-VAR-DISPL CW 90PV075	90R075-FN-5-NN-60-P-7-C7-D-B6-GMD-42-42-30	SERIES 90	S90-075PV
83009981	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-T2-C0-L-N-K7-NNN-051-AA-F3-00-C5	SERIES 51	S51-160MV
83009983	PUMP-VAR-DISPL CW 90PV042	90R042-FC-5-BC-80-S-7-C3-C-B4-EFI-42-42-32	SERIES 90	S90-042PV
83009984	MOTOR-VAR-DISPL 51MD110-1	51D110-1--A-D3-N-P7-P7-N-N-X1-NNN-023-AA-F3-00-AA	SERIES 51	S51-110MV-1
83009985	MOTOR-VAR-DISPL H1B080	H1-B-080-A-L2-BA-N-B-PB-CN-JN-N-N-NN-NN-016-N-00-NNN	H1-HP MOTORS	H1-080MB1
83009986	MOTOR-VAR-DISPL H1B080	H1-B-080-A-E2-AA-N-B-TB-CN-JN-N-N-NN-NN-030-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83009987	MOTOR-VAR-DISPL H1B080	H1-B-080-A-E2-AA-N-B-TB-CN-JN-N-N-NN-NN-026-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83009988	MOTOR-VAR-DISPL H1B060	H1-B-060-A-L2-BA-N-B-PB-CN-GN-N-N-NN-NN-016-N-00-NNN	H1-HP MOTORS	H1-060MB1
83009989	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-BC-80-L-3-C8-H-03-GBA-42-42-24	SERIES 90	S90-130PV
83009990	MOTOR-VAR-DISPL 51MD110	51D110-R-D4-N-D8-M1-R-J-M1-NNN-061-AA-G3-C2-25	SERIES 51	S51-110MV
83009992	MOTOR-VAR-DISPL 51MD110	51D110-A-D3-N-HS-A2-B-E-E1-AHA-030-AA-NN-10-25	SERIES 51	S51-110MV
83009993	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-AB-60-S-3-F1-E-03-GBA-29-29-24	SERIES 90	S90-100PV
83009998	PUMP-VAR-DISPL CCW H1PV165	H1-P-165-L-C-A4-C2-N-D3-G-G3-H3-L-25-L-40-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83009999	PUMP-VAR-DISPL CCW H1PV165	H1-P-165-L-C-A4-C2-N-D5-G-G3-H4-L-25-L-40-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV

83010003	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-NN-80-S-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83010004	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-D4-C2-N-D4-G-G3-NN-L-42-L-42-A-D-32-PN-NNN-G34	H1-HP PUMPS	H1-147PV/165PV
83010005	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-C7-N-E1-B1-N-N-U1-NNN-038-AA-F0-00-00	SERIES 51	S51-080MV-1
83010007	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-L1-B1-W-B-G5-ADR-090-AA-G0-D4-00	SERIES 51	S51-250MV
83010008	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-AB-80-S-4-C7-E-03-GBA-42-42-24	SERIES 90	S90-075PV
83010009	MOTOR-VAR-DISPL 51MV160	51V160-A-C8-N-N2-NN-N-N-A0-NNN-050-AA-G0-00-00	SERIES 51	S51-160MV
83010010	MOTOR-VAR-DISPL 51MV250	51V250-A-C8-N-N2-NN-N-N-A0-NNN-080-AA-H0-00-00	SERIES 51	S51-250MV
83010013	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-N2-NN-N-N-A0-NNN-050-AA-G0-00-00	SERIES 51	S51-160MV
83010014	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-N2-NN-N-N-A0-NNN-080-AA-H0-00-00	SERIES 51	S51-250MV
83010015	MOTOR-FIXED DISPL MMF025C	MMF-025-C-A-E-B-C-J-NNN-***	LIGHT DUTY	025MF
83010016	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-A-V-C-J-AA-B-B-A-A-BEE-CE-A-JJ-B-D-A-A-BEE-CE-A-JJ-C-NNN-***	M46	M46-046PT
83010017	PUMP-VAR-DISPL CCW 90PV075	90L075-NA-5-BB-60-L-3-T6-D-02-FAB-42-42-24	SERIES 90	S90-075PV
83010018	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-AB-80-R-3-S1-F-00-GBA-26-26-24	SERIES 90	S90-100PV
83010023	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A3-C1-N-D6-G-G3-NN-L-30-L-30-A-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83010024	PUMP-TANDEM, VAR DISPL MPT025C	MPT-025-C-S-R-A-E-NN-B-A-A-A-BBB-DR-A-FF-B-A-A-A-BBB-DL-A-FF-A-NNN-**	LIGHT DUTY	025PT
83010025	PUMP-VAR DISPL, CW 90PV055	90-R-055-KN-1-BC-60-P-4-K1-D-03-GBA-32-32-24	SERIES 90	S90-055PV
83010026	PUMP-VAR-DISPL CCW 90PV075	90L075-MA-5-AB-60-S-4-S1-D-C6-GBA-42-42-24	SERIES 90	S90-075PV
83010027	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-AB-60-S-4-C6-D-03-GBA-35-35-24	SERIES 90	S90-055PV
83010034	PUMP-VAR-DISPL CCW H1PV165	H1-P-165-L-C-A3-C2-N-D6-G-G2-H5-L-45-L-45-A-L-30-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83010042	PUMP-VAR DISPL, CCW 90PV055	90-L-055-M8-1-NN-80-P-3-S1-D-03-GBA-26-26-24	SERIES 90	S90-055PV
83010043	PUMP-VAR DISPL, CCW 90PV055	90-L-055-ME-1-NN-80-P-3-S1-D-03-GBA-26-26-24	SERIES 90	S90-055PV
83010047	PUMP-VAR-DISPL CCW 90PV075	90L075-HS-5-NN-60-L-4-K2-D-03-GBA-17-17-24	SERIES 90	S90-075PV
83010049	PUMP-VAR-DISPL CCW H1PV115	H1-P-115-L-B-A5-C1-N-D8-G-G2-H3-L-28-L-28-N-E-20-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83010051	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-NN-80-R-4-C7-F-03-GBA-26-26-30-F068	SERIES 90	S90-100PV
83010052	MOTOR-VAR-DISPL 51MD080-1	51D080-1--A-D3-N-T7-R5-N-N-X1-NNN-054-AA-F3-00-24	SERIES 51	S51-080MV-1
83010054	MOTOR-VAR-DISPL 51MD080	51D080-R-D2-N-Y7-B1-S-K-J1-ACA-022-AA-F3-F4-00	SERIES 51	S51-080MV
83010061	PUMP-TANDEM, VAR DISPL MPT025C	MPT-025-C-S-W-A-G-NN-B-A-A-A-BGG-DL-A-FF-B-C-A-A-BGG-DL-A-FF-A-NNN-	LIGHT DUTY	025PT
83010065	PUMP-VAR-DISPL CW 90PV130	90R130-M8-5-AB-80-P-3-C8-H-C5-GBA-38-38-24	SERIES 90	S90-130PV
83010081	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-TA-C2-L-N-G0-ACA-105-AA-F3-00-C2	SERIES 51	S51-160MV
83010085	MOTOR-VAR-DISPL 51MD060-1	51D060-1--K-D2-N-T1-D1-N-N-X1-ACJ-027-AA-E6-00-21	SERIES 51	S51-060MV-1
83010087	PUMP-VAR-DISPL CW 90PV130	90R130-HF-1-BC-80-S-4-F1-H-03-GBA-17-17-24	SERIES 90	S90-130PV
83010089	PUMP-VAR-DISPL CCW H1PV165	H1-P-165-L-C-A2-C3-N-D8-G-G3-NN-L-23-L-23-A-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83010093	PUMP-VAR DISPL, CW 90PV075	90-R-075-HS-5-NN-80-S-4-S1-D-02-GBA-35-35-20	SERIES 90	S90-075PV
83010096	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-NN-60-R-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83010097	PUMP-VAR-DISPL CCW 90PV130	90L130-KK-1-NN-82-U-3-F1-F-64-FBH-35-35-24	SERIES 90	S90-130PV
83010100	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-TM-E7-L-N-J2-ADA-050-AA-G0-00-BB	SERIES 51	S51-250MV

83010103	PUMP-VAR-DISPL CCW 90PV180	90L180-HF-5-BC-80-S-C-C8-J-03-NNN-32-32-24	SERIES 90	S90-180PV
83010107	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-BB-80-S-3-S1-E-03-GBA-42-42-28	SERIES 90	S90-075PV
83010108	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-BC-80-S-3-C8-H-03-GBA-42-42-28	SERIES 90	S90-130PV
83010109	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-BC-80-S-3-C7-F-03-GBA-42-42-28	SERIES 90	S90-100PV
83010110	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-L2-B1-V-A-J2-AHA-060-AA-F3-B2-00	SERIES 51	S51-250MV
83010111	MOTOR-VAR-DISPL 51MC160	51C160-R-D5-N-L2-B1-V-A-J2-NNN-055-AA-F0-B2-00	SERIES 51	S51-160MV
83010115	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-5-CD-80-R-4-K2-D-03-GBA-14-14-24	SERIES 90	S90-075PV
83010116	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-5-CD-80-R-4-S1-D-03-GBA-14-14-24	SERIES 90	S90-075PV
83010118	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-S-B-B-BA-J-A-BJJ-DB-A-HH-H-NNA-***	M46	M46-046PV
83010126	PUMP-VAR-DISPL CW 90PV075	90R075-MA-5-BC-80-P-3-C6-D-C6-GBA-35-35-24	SERIES 90	S90-075PV
83010127	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A3-C2-N-D3-H-G1-NN-L-28-L-28-C-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83010129	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A3-C2-N-D3-H-G1-H2-L-28-L-28-C-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83010132	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-NN-80-P-4-C6-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83010133	PUMP-VAR-DISPL CW 90PV130	90R130-HF-5-DE-80-L-3-C8-H-03-GBA-32-32-24	SERIES 90	S90-130PV
83010137	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-D-N-0-C6-W-00-EBA-00-00-F0	SERIES 90	S90-075MF
83010138	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-D-N-0-C6-W-00-EBA-00-00-F0	SERIES 90	S90-100MF
83010139	PUMP-VAR DISPL, CW 90PV100	90-R-100-HS-1-CD-80-R-3-F1-F-03-GBA-35-29-24	SERIES 90	S90-100PV
83010140	MOTOR-FIXED DISPL MMF025C	MMF-025-C-A-N-R-A-C-NNN-***	LIGHT DUTY	025MF
83010141	PUMP-VAR DISPL MPV046C	MPV-046-C-B-A-V-T-A-J-BC-A-A-BGG-AB-D-AA-C-NNN-***	M46	M46-046PV
83010143	PUMP-VAR-DISPL CCW 90PV130	90L130-HF-5-BC-80-S-3-C8-H-04-GBA-42-42-30	SERIES 90	S90-130PV
83010144	PUMP-VAR-DISPL CCW 90PV130	90L130-HF-5-AB-80-S-3-C8-H-04-GBA-42-42-30	SERIES 90	S90-130PV
83010145	MOTOR-VAR-DISPL 51MV060-1	51V060-1--R-C6-N-T2-CA-N-N-X1-NNN-023-AA-E4-00-21	SERIES 51	S51-060MV-1
83010146	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-BC-60-L-3-S1-D-04-GBA-42-42-24	SERIES 90	S90-055PV
83010157	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HF-1-BC-80-R-3-F1-E-05-GBA-38-38-24-P040	SERIES 90	S90-100PV
83010172	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A8-C2-C-D6-F-G5-H3-L-35-L-35-B-L-24-P1-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83010174	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-C8-N-E1-B1-N-N-U1-NNN-034-AA-F3-00-00	SERIES 51	S51-110MV-1
83010176	PUMP-VAR-DISPL CW 90PV130	90R130-KA-1-DE-80-R-3-F1-H-09-GBA-38-38-24	SERIES 90	S90-130PV
83010179	PUMP-VAR-DISPL CW 90PV130	90R130-MA-5-DE-80-L-3-F1-F-C5-GBA-26-26-24	SERIES 90	S90-130PV
83010180	PUMP-VAR-DISPL CW 90PV130	90R130-MA-5-NN-80-L-4-F1-F-C5-GBA-26-26-24	SERIES 90	S90-130PV
83010181	PUMP-VAR-DISPL 42PV051 CW	42-R-51-D-E1A3-03-C-3-A-3-G-N-B-34-34-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83010182	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-E-V-C-B-BA-B-A-G-A-BJJ-AB-U-YJ-B-C-G-A-BJJ-AB-D-YJ-A-ANN-***	M46	M46-046PT
83010184	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-CD-80-L-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83010185	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-CD-80-L-3-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83010186	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-CD-80-L-4-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83010187	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-1-CD-80-L-3-S1-D-03-GBA-23-23-24	SERIES 90	S90-075PV
83010188	PUMP-VAR DISPL, CCW 90PV100	90-L-100-CB-1-BC-80-R-4-S1-E-00-GBA-35-35-24	SERIES 90	S90-100PV

83010189	PUMP-VAR DISPL, CCW 90PV100	90-L-100-CB-1-NN-80-R-3-F1-E-00-GBA-35-35-24	SERIES 90	S90-100PV
83010191	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-C8-N-F2-B1-N-N-U1-NNN-032-AA-F0-00-00	SERIES 51	S51-110MV-1
83010194	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-CD-80-S-M-C8-H-04-NNN-42-42-24	SERIES 90	S90-180PV
83010196	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-1-CD-80-P-4-F1-H-03-GBA-35-35-24	SERIES 90	S90-130PV
83010197	PUMP-VAR DISPL, CW 90PV055	90-R-055-HF-1-NN-60-S-3-C6-C-00-GBA-35-35-24	SERIES 90	S90-055PV
83010200	MOTOR-VAR-DISPL 51MV060	51V060-R-S1-N-L1-B1-W-B-G0-ACA-018-AA-E4-D4-00	SERIES 51	S51-060MV
83010209	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-BC-80-P-4-S1-E-04-GBA-42-42-24	SERIES 90	S90-100PV
83010210	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A7-C2-C-D3-K-G9-H3-L-42-L-42-M-M-24-P2-NNN-D3F	H1-HP PUMPS	H1-089PV/100PV
83010217	PUMP-TANDEM, VAR DISPL MPT044D	MPT-044-D-A-W-S-J-BA-B-A-A-A-BJJ-DR-A-FF-B-C-A-A-BJJ-DL-A-FF-B-NNN-***	M35/44	044PT
83010229	PUMP-VAR DISPL, CW 90PV075	90-R-075-LE-H-CD-60-E-3-J8-D-01-FBA-AJ-43-28	SERIES 90	S90-075PV
83010230	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-H-BC-60-E-3-S1-D-01-FBA-AJ-43-28	SERIES 90	S90-075PV
83010233	PUMP-VAR DISPL, CCW 90PV075	90-L-075-DC-1-NN-80-P-4-S1-D-GB-GBA-42-42-24	SERIES 90	S90-075PV
83010234	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-1-BC-60-P-4-S1-D-03-GBA-38-38-24	SERIES 90	S90-055PV
83010235	PUMP-VAR-DISPL CCW 90PV130	90L130-MA-5-AB-80-L-3-F1-F-C5-GBA-23-23-24	SERIES 90	S90-130PV
83010239	PUMP-VAR-DISPL CCW 90PV075	90L075-FM-5-NN-80-S-7-C7-D-B6-GME-45-45-30	SERIES 90	S90-075PV
83010243	MOTOR-VAR-DISPL 51MD060	51D060-R-D1-A-HS-A2-C-H-C1-NNN-026-AA-NN-26-13	SERIES 51	S51-060MV
83010244	MOTOR-VAR-DISPL 51MD080	51D080-R-D2-N-HS-A2-C-H-C1-NNN-038-AA-NN-26-13	SERIES 51	S51-080MV
83010246	PUMP-VAR-DISPL CW 90PV250	90R250-SB-2-BC-80-S-3-C8-J-33-PEA-32-32-30	SERIES 90	S90-250PV
83010247	PUMP-VAR-DISPL CW 90PV250	90R250-SB-2-BC-80-S-3-F1-J-33-PEA-32-32-30	SERIES 90	S90-250PV
83010248	PUMP-VAR-DISPL CW 90PV250	90R250-SB-2-EF-80-S-3-C8-J-33-PGA-32-32-30	SERIES 90	S90-250PV
83010250	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-C8-N-TA-C2-N-N-X1-NNN-050-AA-NN-00-20	SERIES 51	S51-110MV-1
83010254	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-NN-80-P-3-S1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
83010257	PUMP-VAR DISPL MPV046C	MPV-046-C-B-A-K-S-B-J-AA-D-A-BDD-AB-U-BF-B-NNN-***	M46	M46-046PV
83010260	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-AB-80-L-3-S1-E-03-GBA-26-26-24	SERIES 90	S90-100PV
83010262	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-1-BC-60-L-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83010263	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-2-BC-60-L-4-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83010264	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-2-CD-80-L-4-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83010266	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-CD-80-R-3-F1-F-00-GBA-42-42-24	SERIES 90	S90-100PV
83010267	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-BC-80-R-3-S1-F-00-GBA-38-38-24	SERIES 90	S90-100PV
83010268	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-HZ-B1-A-N-G0-ACA-062-AA-G0-03-00	SERIES 51	S51-160MV
83010269	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-5-NN-80-L-4-S1-E-03-GBA-26-26-24	SERIES 90	S90-100PV
83010270	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-5-CD-80-L-4-S1-E-03-GBA-26-26-24	SERIES 90	S90-100PV
83010272	MOTOR-VAR-DISPL 51MD160	51D160-R-D4-N-E2-A5-A-N-A6-NNN-050-AA-NN-03-00	SERIES 51	S51-160MV
83010273	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-E2D8-00-B-3-G-2-F-N-A-17-17-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83010274	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-DE-80-T-C-C8-J-03-NNN-35-35-24	SERIES 90	S90-180PV
83010275	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-BC-80-S-3-C8-H-03-GBA-42-42-30	SERIES 90	S90-130PV

83010276	PUMP-VAR-DISPL CCW 90PV250	90L250-KN-5-BC-80-T-4-F1-J-03-NNN-42-14-24	SERIES 90	S90-250PV
83010277	PUMP-VAR-DISPL 42PV028 CCW BASE MODEL	42-L-28-C-NDNB-NN-B-D-B-2-F-N-N-34-34-N-A-A-NNN-CNN	SERIES 42	S42-028PV/032PV
83010278	PUMP-VAR-DISPL 42PV028 CW BASE MODEL	42-R-28-D-NDNB-NN-B-D-B-2-F-N-N-34-34-N-A-A-NNN-CNN	SERIES 42	S42-028PV/032PV
83010281	PUMP-VAR-DISPL 42PV041 CCW BASE MODEL	42-L-41-C-NDNB-NN-B-D-B-3-F-N-N-34-34-N-A-A-NNN-CNN	SERIES 42	S42-041PV/051PV
83010282	PUMP-VAR-DISPL 42PV041 CW BASE MODEL	42-R-41-D-NDNB-NN-B-D-B-3-F-N-N-34-34-N-A-A-NNN-CNN	SERIES 42	S42-041PV/051PV
83010294	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-2-BC-80-L-4-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83010295	MOTOR-VAR-DISPL H1B110	H1-B-110-A-K1-K1-N-A-RA-DN-JN-N-A-15-NN-035-N-25-NNN	H1-HP MOTORS	H1-110MB1
83010298	31.07VAR DISPL, CCW 90PV100	90-L-100-HM-5-CD-80-S-4-S1-E-03-GBA-23-23-24	SERIES 90	S90-100PV
83010300	PUMP-VAR-DISPL CCW 90PV100	90L100-MA-5-NN-80-P-3-C7-E-C5-GBA-42-42-24	SERIES 90	S90-100PV
83010301	PUMP-VAR-DISPL CCW 90PV100	90L100-MA-5-AB-80-S-4-C7-D-C5-GBA-35-35-24	SERIES 90	S90-100PV
83010302	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-CD-80-R-4-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
83010312	PUMP-VAR-DISPL CW 90PV180	90R180-KA-6-CD-80-T-C-C8-J-00-FAC-48-48-24	SERIES 90	S90-180PV
83010320	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-NN-80-S-4-F1-E-03-EBC-35-35-24	SERIES 90	S90-100PV
83010322	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A4-C2-N-D3-G-G3-H2-L-40-L-40-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83010323	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-B8-C3-C-F6-H-G1-H6-K-40-K-40-F-L-24-P1-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83010324	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-B8-C3-C-D6-H-G1-H3-K-40-K-40-F-L-24-P1-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83010326	MOTOR-VAR-DISPL 51MV110	51V110-R-C8-N-EQ-A5-J-Y-J1-ACA-022-AA-NN-30-00	SERIES 51	S51-110MV
83010328	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A7-C2-C-D3-L-G3-H3-L-42-L-42-L-M-24-P2-NNN-D16	H1-HP PUMPS	H1-147PV/165PV
83010330	PUMP-VAR-DISPL CW 90PV100	90R100-MA-5-AB-80-S-4-C7-D-C5-GBA-35-35-24	SERIES 90	S90-100PV
83010332	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-E1-A5-A-N-G0-ACA-107-AA-H0-03-00	SERIES 51	S51-160MV
83010333	MOTOR-VAR-DISPL 51MV080	51V080-A-S1-N-L3-B1-W-B-G0-ANA-050-AA-F0-D4-00	SERIES 51	S51-080MV
83010334	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A5-C2-B-D8-F-G5-NN-L-20-L-20-B-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83010335	MOTOR-VAR-DISPL 51MD160	51D160-A-D4-N-TA-C2-L-N-G0-NNN-064-AA-G0-00-B9	SERIES 51	S51-160MV
83010337	PUMP-VAR-DISPL CCW 90PV250	90L250-MB-5-BC-80-T-3-F1-K-C5-NNN-35-35-24	SERIES 90	S90-250PV
83010339	PUMP-VAR DISPL MPV046C	MPV-046-C-B-A-A-S-B-S-BA-A-A-BJJ-GB-B-AA-C-NNN-***	M46	M46-046PV
83010354	PUMP-VAR DISPL MPV046C	MPV-046-C-B-A-A-S-B-S-BA-A-A-BGG-GB-B-AA-C-NNN-***	M46	M46-046PV
83010356	MOTOR-VAR-DISPL 51MV250	51V250-A-C8-N-T1-C0-L-N-K7-NNN-050-AA-G0-00-B5	SERIES 51	S51-250MV
83010359	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-B-V-C-B-BA-B-B-A-A-BHH-CE-A-GG-B-D-A-A-BHH-CE-A-GG-B-NNN	M46	M46-046PT
83010360	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-1-NN-60-S-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-075PV
83010361	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-BC-80-L-4-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83010362	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-HS-A2-C-E-G6-NNN-080-AA-F0-16-30	SERIES 51	S51-160MV
83010363	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-NN-80-S-M-F1-H-03-FAC-32-14-30	SERIES 90	S90-180PV
83010364	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A8-C2-C-E6-J-G5-H3-L-35-L-35-B-L-24-P2-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83010368	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-NN-80-R-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-075PV
83010369	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-NN-80-R-3-S1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
83010370	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-5-CD-80-R-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-100PV

83010371	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-B7-C2-C-D8-L-G2-H3-L-42-L-42-N-E-24-P2-NNN-D5F	H1-HP PUMPS	H1-147PV/165PV
83010372	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A7-C2-C-D8-K-G9-H3-L-45-L-45-C-P-28-P2-NNN-D3F	H1-HP PUMPS	H1-069PV/078PV
83010373	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-1-BC-80-R-3-F1-H-00-GBA-42-42-24	SERIES 90	S90-130PV
83010374	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-2-BB-80-D-3-S1-L-00-EBC-45-45-28	SERIES 90	S90-055PV
83010376	PUMP-VAR DISPL, CW H1PV250	H1-P-250-R-A-A2-C2-N-D6-C-G2-NN-L-45-L-45-R-L-28-PN-NNN-NNN	H1-HP PUMPS	H1-210PV/250PV
83010379	MOTOR-VAR-DISPL H1B080	H1-B-080-A-M1-CA-N-A-RA-DS-JS-P-A-10-NN-020-N-00-NNN	H1-HP MOTORS	H1-080MB1
83010382	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-BB-80-P-4-C6-D-03-GBA-42-42-24	SERIES 90	S90-075PV
83010384	MOTOR-VAR-DISPL 51MD160	51D160-R-D4-N-L2-B1-V-A-G5-ACA-060-AA-E4-B2-00	SERIES 51	S51-160MV
83010385	MOTOR-VAR-DISPL 51MD160	51D160-R-D4-N-L2-B1-V-A-G5-NNN-060-AA-E4-B2-00	SERIES 51	S51-160MV
83010388	PUMP-VAR-DISPL 42PV041 CW	42-R-41-C-F4NN-73-J-D-B-2-F-N-N-21-21-N-A-A-NNN-NNN	SERIES 42	S42-041PV/051PV
83010389	PUMP-VAR-DISPL CCW 90PV250	90L250-KP-5-AB-80-T-3-C8-K-03-NNN-35-35-24	SERIES 90	S90-250PV
83010390	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-NN-80-P-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
83010393	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A4-C2-N-D6-H-G1-NN-L-42-L-42-C-L-28-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83010400	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-E2C8-03-B-2-G-3-F-N-N-28-28-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83010401	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-E2C8-03-B-2-X-N-F-N-V-28-28-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83010421	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HF-G-CD-80-P-4-S1-D-01-GBA-32-32-24	SERIES 90	S90-075PV
83010423	PUMP-VAR-DISPL CCW 90PV130	90L130-CB-1-BC-80-S-4-F1-F-00-GBA-35-35-24	SERIES 90	S90-130PV
83010432	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A3-C2-N-F5-H-G9-H6-L-23-L-23-M-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83010434	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-N-HZ-B1-A-N-G0-NNN-060-AA-NN-03-00	SERIES 51	S51-160MV
83010435	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-5-NN-80-R-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83010437	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A5-C2-B-D3-H-G1-H2-L-35-L-35-C-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83010439	MOTOR-VAR-DISPL 51MV080	51V080-A-S1-N-HZ-B1-B-E-C2-NNN-016-AA-NN-05-00	SERIES 51	S51-080MV
83010441	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-HZ-B1-A-N-J8-NNN-056-AA-F0-03-00	SERIES 51	S51-160MV
83010442	PUMP-VAR-DISPL CCW 90PV130	90L130-HS-5-BC-80-R-3-F1-H-03-GBA-20-20-32	SERIES 90	S90-130PV
83010448	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-B7-C2-C-F6-K-G9-H6-L-42-L-42-C-L-20-P2-NNN-D5F	H1-HP PUMPS	H1-069PV/078PV
83010451	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-NN-60-S-3-C7-D-00-GBA-35-35-24	SERIES 90	S90-075PV
83010452	PUMP-VAR-DISPL CW 90PV130	90R130-MA-5-NN-80-R-3-F1-F-C5-GBA-26-26-24-P000	SERIES 90	S90-130PV
83010456	MOTOR-VAR-DISPL H1B110#	H1-B-110-A-E2-AA-N-A-TB-CS-JS-S-A-10-NN-040-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83010457	MOTOR-VAR-DISPL H1B110#	H1-B-110-A-E2-AA-N-A-TB-CS-JS-S-A-10-NN-050-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83010458	MOTOR-VAR-DISPL H1B110#	H1-B-110-A-E2-AA-N-A-TB-CN-JN-N-A-10-NN-040-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83010459	MOTOR-VAR-DISPL H1B110#	H1-B-110-A-E2-AA-N-A-TB-CN-JN-N-A-10-NN-050-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83010461	PUMP-VAR-DISPL CW 90PV075	90R075-MA-5-AB-80-P-4-C7-D-C5-GBA-26-26-24	SERIES 90	S90-075PV
83010465	PUMP-VAR-DISPL CW 90PV075	90R075-MA-5-BC-60-S-3-T2-E-C5-FAB-42-42-24	SERIES 90	S90-075PV
83010466	MOTOR-VAR DISPL MMV046C	MMV-046-C-A-A-W-X-AA-NNN-***	M46	M46-046MV
83010467	MOTOR-VAR DISPL MMV046C	MMV-046-C-A-A-W-X-A1-NNN-***	M46	M46-046MV
83010468	MOTOR-VAR DISPL MMV046C	MMV-046-C-A-A-W-X-AH-NNN-***	M46	M46-046MV

83010469	MOTOR-VAR DISPL MMV046C	MMV-046-C-A-A-4-C-AA-NNN-***	M46	M46-046MV
83010474	PUMP-VAR-DISPL CW 90PV180	90R180-KP-5-NN-80-T-C-F1-J-03-FAC-23-42-24	SERIES 90	S90-180PV
83010475	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-C-E1A6-02-B-2-G-2-F-N-A-34-34-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83010476	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-CD-80-S-3-C8-H-03-EFC-35-35-24	SERIES 90	S90-130PV
83010477	PUMP-VAR DISPL MPV046C	MPV-046-C-B-A-B-S-B-B-BA-A-A-BDD-AB-U-BB-A-NNN-***	M46	M46-046PV
83010478	PUMP-VAR DISPL MPV046C	MPV-046-C-B-A-K-S-B-B-BA-A-A-BDD-AB-U-BB-B-NNN-***	M46	M46-046PV
83010479	PUMP-VAR-DISPL CCW 90PV130	90L130-DC-5-CD-80-L-4-T4-F-GB-GBA-42-42-20	SERIES 90	S90-130PV
83010480	PUMP-VAR-DISPL CCW 90PV075	90L075-DC-5-AB-80-P-4-S1-D-GB-GBA-20-20-20	SERIES 90	S90-075PV
83010482	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-BC-80-P-3-F1-D-03-GBA-29-29-24	SERIES 90	S90-100PV
83010484	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-N-TA-C0-L-N-G0-NNN-062-AA-G3-00-C2	SERIES 51	S51-250MV
83010485	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-BC-80-S-C-C8-H-03-GLA-29-29-24	SERIES 90	S90-180PV
83010491	PUMP-VAR DISPL CW H1P068R	H1-P-068-R-A-A4-C2-N-D6-H-G1-NN-L-30-L-30-C-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83010494	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-N-A4-C2-N-E7-F-G1-T1-28-28-35-35-M-P-24-PN-NNN-S02	H1-MP PUMPS	H1-045PT/053PT
83010495	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-1-BC-80-R-4-S1-D-03-GBA-38-38-24	SERIES 90	S90-075PV
83010496	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-CD-80-R-4-F1-E-00-GBA-38-38-24	SERIES 90	S90-100PV
83010499	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-N-TA-C2-L-N-G0-NNN-100-AA-G0-00-B9	SERIES 51	S51-160MV
83010500	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-8-N-0-C7-W-00-EBA-00-00-F3	SERIES 90	S90-100MF
83010503	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-A-C2-C2-C-D6-K-G9-NN-L-44-L-44-M-L-24-P2-NNN-D4A	H1-HP PUMPS	H1-089PV/100PV
83010504	PUMP-VAR-DISPL CW 90PV130	90R130-MA-1-NN-80-R-3-C8-H-03-GBA-35-35-24	SERIES 90	S90-130PV
83010506	PUMP-VAR DISPL, CW 90PV055	90-R-055-M8-1-NN-60-P-3-S1-D-02-GBA-42-42-24	SERIES 90	S90-055PV
83010515	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-8-N-0-C6-W-00-EBA-00-00-F0	SERIES 90	S90-075MF
83010516	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A5-C3-N-D3-G-G3-NN-L-35-L-35-A-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83010524	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A5-C3-N-D3-G-G3-NN-L-35-L-35-A-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83010525	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D3-N-T2-D2-N-N-X1-ADA-023-AA-F3-00-35	SERIES 51	S51-080MV-1
83010526	MOTOR-VAR-DISPL 51MC110-1	51C110-1--R-D3-N-T2-D2-N-N-X1-ADA-042-AA-G0-00-35	SERIES 51	S51-110MV-1
83010528	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-E2D8-02-D-N-F-3-H-N-B-34-34-B-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83010530	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HS-1-NN-80-R-3-S1-D-00-GBA-32-32-24	SERIES 90	S90-075PV
83010531	PUMP-VAR-DISPL CW 90PV180	90R180-KP-5-CD-80-T-M-C8-H-03-NNN-42-42-24	SERIES 90	S90-180PV
83010533	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-A-V-C-J-AA-B-B-G-A-BDD-DB-A-SS-B-D-G-A-BDD-DB-A-SS-C-NNN-*	M46	M46-046PT
83010535	MOTOR-VAR-DISPL 51MV060-1	51V060-1--R-S1-N-TA-C2-N-N-X1-NNN-012-AA-E6-00-20	SERIES 51	S51-060MV-1
83010540	PUMP-TANDEM, VAR DISPL CCW H1T045L	H1-T-045-L-A-N-A5-C2-B-E7-F-G5-H2-30-30-30-30-N-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83010547	PUMP-VAR-DISPL CW 90PV100	90R100-HS-5-NN-80-R-3-C7-F-03-GBA-35-35-24-G005	SERIES 90	S90-100PV
83010550	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-BB-80-P-3-C6-C-03-GBA-42-42-24	SERIES 90	S90-075PV
83010551	PUMP-VAR-DISPL CW 90PV075	90R075-KA-2-AB-80-P-4-C6-C-03-GBA-42-42-24	SERIES 90	S90-075PV
83010552	PUMP-TANDEM, VAR DISPL CCW H1T045L	H1-T-045-L-A-N-A5-C2-B-E7-F-G5-T2-30-30-30-30-M-P-20-PN-NNN-S03	H1-MP PUMPS	H1-045PT/053PT
83010553	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-NN-80-P-3-C7-D-03-GBA-35-35-24	SERIES 90	S90-075PV

83010556	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-CD-60-S-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
83010558	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A2-C2-N-D8-F-G5-H3-L-25-L-25-B-P-30-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83010566	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A5-C2-N-E6-F-G5-NN-L-28-L-28-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83010567	PUMP-TANDEM, VAR DISPL CCW H1T053L	H1-T-053-L-A-N-A5-C2-N-E7-F-G5-T3-28-28-28-28-M-P-24-PN-NNN-S01	H1-MP PUMPS	H1-045PT/053PT
83010568	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A5-C2-N-F4-H-G9-H6-L-15-L-35-D-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83010569	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A5-C2-N-F4-H-G1-H6-L-15-L-35-C-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83010570	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A5-C2-N-F4-H-G1-H6-L-28-L-28-C-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83010572	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-CD-80-P-4-C6-C-03-GBA-42-42-24	SERIES 90	S90-075PV
83010573	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-BC-80-P-4-S1-C-03-GBA-42-42-24	SERIES 90	S90-075PV
83010580	PUMP-VAR-DISPL CW 90PV075	90R075-KA-2-BB-80-P-4-C6-C-03-GBA-42-42-24	SERIES 90	S90-075PV
83010583	MOTOR-VAR-DISPL H1B080	H1-B-080-A-E2-AA-N-A-TA-VN-AN-N-N-NN-NN-040-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83010584	MOTOR-VAR-DISPL H1B080	H1-B-080-A-M1-CA-N-B-RB-VS-AS-S-A-10-NN-000-N-00-NNN	H1-HP MOTORS	H1-080MB1
83010585	MOTOR-VAR-DISPL H1B110	H1-B-110-A-M1-CA-N-B-RB-VS-DS-S-A-10-NN-000-N-00-NNN	H1-HP MOTORS	H1-110MB1
83010590	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-D-S-B-B-AA-A-A-BEE-DA-A-HH-B-NNN-***	M46	M46-046PV
83010596	MOTOR-VAR-DISPL 51MC160	51C160-R-D4-N-E2-A1-A-N-A2-ACM-043-AA-F3-03-35	SERIES 51	S51-160MV
83010603	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-D8-M1-R-J-N1-NNN-087-AA-G3-C2-36	SERIES 51	S51-250MV
83010605	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KN-1-AB-60-L-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83010615	MOTOR-VAR DISPL MMV046C	MMV-046-C-A-A-B-X-AH-NNN-***	M46	M46-046MV
83010617	MOTOR-VAR DISPL MMV046C	MMV-046-C-A-A-4-C-AF-NNN-***	M46	M46-046MV
83010618	PUMP-VAR DISPL, CW 90PV100	90-R-100-HF-5-NN-60-P-3-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83010620	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-CD-80-L-3-F1-H-03-GBA-42-42-28	SERIES 90	S90-130PV
83010626	PUMP- VARIABLE, DIRECT DISPLACMENT	LPV-A-A-A-D-A-G-AC-C-A-BFF-DR-A-FF-B-NNN-***	LPV	LPV
83010627	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-E2C8-03-D-N-F-2-F-N-N-32-32-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83010628	PUMP-VAR-DISPL 42PV041 CW	42-R-51-E-G3AN-53-P-D-X-N-H-5-V-23-NN-N-1-0-NNN-NNN	SERIES 42	S42-041PV/051PV
83010629	PUMP-VAR DISPL, CCW 90PV075	90-L-075-DC-1-NN-80-S-3-C7-D-GB-GBA-35-35-24	SERIES 90	S90-075PV
83010630	PUMP-VAR-DISPL CCW 90PV100	90L100-MA-5-NN-80-P-4-C7-F-C5-GBA-29-29-24	SERIES 90	S90-100PV
83010632	PUMP-VAR-DISPL CW 90PV075	90R075-RS-1-CD-80-S-3-C7-E-A7-FAC-42-42-24	SERIES 90	S90-075PV
83010634	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-V-S-B-B-BA-A-A-BDD-CE-A-JJ-5-NNN-***	M46	M46-046PV
83010635	PUMP-VAR DISPL, CW 90PV100	90-R-100-M8-1-AB-80-P-3-C7-E-03-GBA-40-40-24	SERIES 90	S90-100PV
83010636	PUMP-VAR-DISPL CW 90PV100	90R100-KN-5-AB-80-L-4-T2-E-03-GBA-32-32-24	SERIES 90	S90-100PV
83010637	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-N-L1-B1-W-B-G5-ACA-050-AA-F0-D4-00	SERIES 51	S51-250MV
83010638	PUMP-VAR DISPL MPV035D	MPV-035-D-B-A-A-R-A-G-NN-A-A-BEE-DL-A-FF-A-NNN-***	M35/44	035PV
83010639	PUMP-VAR-DISPL 42PV041 CW	42-R-51-D-G3AN-53-P-D-X-N-H-5-B-21-NN-N-1-0-NNN-NNN	SERIES 42	S42-041PV/051PV
83010640	PUMP-VAR-DISPL 42PV041 CW	42-R-41-C-G3AN-53-P-D-X-N-H-5-B-17-NN-N-1-0-NNN-NNN	SERIES 42	S42-041PV/051PV
83010641	PUMP-VAR DISPL, CW 90PV075	90-R-075-KN-1-NN-60-R-4-S1-D-03-GBA-38-38-24	SERIES 90	S90-075PV
83010644	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A2-C2-N-D3-G-G2-H6-L-45-L-45-L-M-30-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV

83010646	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-Y3-B1-S-K-J1-ACA-055-AA-G0-F4-00	SERIES 51	S51-250MV
83010648	MOTOR-VAR-DISPL H1B060	H1-B-060-A-L1-BA-N-B-PB-CS-GS-S-A-10-NN-000-N-00-NNN	H1-HP MOTORS	H1-060MB1
83010649	PUMP-VAR DISPL C CW H1PV078	H1-P-078-L-A-A5-C2-N-F6-H-G1-H6-L-35-L-35-F-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83010650	PUMP-VAR DISPL C CW H1PV078	H1-P-078-L-A-A5-C2-N-D6-H-G1-H3-L-35-L-35-F-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83010653	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-TA-C2-L-N-G0-NNN-125-AA-F0-00-B8	SERIES 51	S51-160MV
83010654	PUMP-VAR DISPL, C CW 90PV075	90-L-075-HF-1-NN-80-S-4-S1-D-03-GBA-32-32-24	SERIES 90	S90-075PV
83010656	MOTOR-VAR-DISPL 51MD110-1	51D110-1--R-D4-N-E2-B1-N-N-U1-ABA-056-AA-F0-00-00	SERIES 51	S51-110MV-1
83010657	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-N-L2-B1-V-A-C0-ADA-040-AA-NN-B2-00	SERIES 51	S51-160MV
83010658	MOTOR-VAR-DISPL 51MV160	51V160-A-F2-N-L2-B1-V-A-C0-ADA-040-AA-NN-B2-00	SERIES 51	S51-160MV
83010659	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A9-C2-B-D8-F-G5-NN-L-38-L-38-N-P-26-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83010661	MOTOR-VAR-DISPL 51MC160	51C160-R-D5-N-EF-B1-V-A-C2-ACB-032-AA-G0-B2-00	SERIES 51	S51-160MV
83010663	PUMP-VAR DISPL, C CW 90PV055	90-L-055-KP-5-NN-80-P-4-S1-C-03-GBA-29-29-24	SERIES 90	S90-055PV
83010664	PUMP-VAR DISPL, C CW 90PV100	90-L-100-KP-1-AB-80-P-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83010665	PUMP-VAR DISPL, C CW 90PV100	90-L-100-KP-5-AB-80-P-4-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83010666	PUMP-VAR DISPL, C CW 90PV100	90-L-100-KP-5-CD-80-P-4-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83010667	PUMP-VAR-DISPL C CW 90PV180	90L180-KP-5-CD-80-T-M-F1-H-03-FAC-35-35-24	SERIES 90	S90-180PV
83010669	PUMP-VAR-DISPL C CW 90PV075	90L075-KA-5-NN-80-S-4-S1-E-03-GBA-42-42-26	SERIES 90	S90-075PV
83010672	MOTOR-VAR-DISPL H1B080	H1-B-080-A-L1-BA-N-C-PB-CN-JN-N-A-15-NN-AA2-N-00-NNN	H1-HP MOTORS	H1-080MB1
83010673	PUMP-VAR-DISPL C CW 90PV250	90L250-KP-5-CD-80-T-4-C8-K-03-NNN-29-29-24	SERIES 90	S90-250PV
83010676	MOTOR-VAR DISPL MMV046C	MMV-046-C-A-A-B-X-A4-NNN-***	M46	M46-046MV
83010681	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-L2-B1-V-A-C0-NNN-063-AA-NN-B2-00	SERIES 51	S51-250MV
83010683	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-S1-N-T2-D2-N-N-X1-AWM-016-AA-NN-00-25	SERIES 51	S51-080MV-1
83010692	PUMP-VAR-DISPL C CW 90PV100	90L100-KA-5-AB-80-S-4-C7-F-04-GBA-32-32-24	SERIES 90	S90-100PV
83010700	PUMP-VAR DISPL C CW H1PV078	H1-P-078-L-A-A9-C1-B-D6-H-G1-NN-L-38-L-38-F-L-20-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83010701	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A9-C1-B-D6-H-G1-NN-L-38-L-38-F-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83010702	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-N-N1-NN-N-N-U1-NNN-024-AA-NN-00-00	SERIES 51	S51-060MV-1
83010703	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A4-C2-N-D3-G-G2-H5-L-42-L-42-L-M-22-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83010712	PUMP-VAR DISPL, C CW 90PV075	90-R-075-MA-1-BB-60-P-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83010713	PUMP-VAR-DISPL 42PV041 C CW	42-L-41-D-E1A3-03-B-D-B-2-H-N-T-30-30-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83010714	PUMP-VAR-DISPL 42PV041 C CW	42-L-41-E-E1A5-02-B-D-B-2-H-N-V-34-34-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83010715	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-A1N5-02-A-N-A-2-F-N-N-C4-C4-N-N-N-NNN-ENN	SERIES 42	S42-041PV/051PV
83010716	PUMP-VAR-DISPL 42PV041 C CW	42-L-41-D-A1N5-02-A-N-A-2-F-N-N-C4-C4-N-N-N-NNN-ENN	SERIES 42	S42-041PV/051PV
83010717	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-T2-C2-L-N-G0-NNN-035-AA-F3-00-C2	SERIES 51	S51-160MV
83010718	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-HZ-B1-B-H-G5-NNN-032-AA-NN-07-00	SERIES 51	S51-160MV
83010719	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-C8-N-E3-B1-N-N-U1-NNN-045-AA-F3-00-00	SERIES 51	S51-110MV-1
83010722	PUMP-VAR-DISPL CW 90PV075	90R075-KA-1-NN-80-S-7-C7-E-09-FAP-35-35-30	SERIES 90	S90-075PV

83010723	PUMP-VAR-DISPL CW 90PV075	90R075-KA-1-BC-80-S-7-C7-E-09-FAP-35-35-30	SERIES 90	S90-075PV
83010724	MOTOR-VAR-DISPL 51MD160	51D160-A-D4-N-E1-A5-A-N-G0-NNN-065-AA-F0-03-00	SERIES 51	S51-160MV
83010725	MOTOR-VAR-DISPL 51MD160	51D160-A-D5-N-EF-B1-T-M-C0-ACA-070-AA-F3-B2-00	SERIES 51	S51-160MV
83010726	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-NN-80-T-3-F1-K-03-NNN-35-35-24	SERIES 90	S90-250PV
83010727	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-NN-80-R-3-F1-H-03-GBA-35-35-24	SERIES 90	S90-130PV
83010730	MOTOR-VAR-DISPL H1B080	H1-B-080-A-L2-BA-N-B-PB-CS-JS-S-A-05-NN-030-N-00-NNN	H1-HP MOTORS	H1-080MB1
83010731	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-T2-C0-L-N-G0-NNN-086-AA-F3-00-B1	SERIES 51	S51-160MV
83010732	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-NN-80-S-4-S1-E-03-GBA-20-20-24	SERIES 90	S90-075PV
83010734	MOTOR-VAR-DISPL H1B110	H1-B-110-A-K1-K1-N-A-RA-DS-KS-S-A-10-NN-060-N-24-NNN	H1-HP MOTORS	H1-110MB1
83010736	MOTOR-VAR-DISPL H1B110	H1-B-110-A-K1-K1-N-A-RA-DS-JS-S-A-10-NN-050-N-24-NNN	H1-HP MOTORS	H1-110MB1
83010738	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-L1-B1-W-B-G5-NNN-020-AA-F3-D4-00	SERIES 51	S51-080MV
83010741	PUMP-VAR-DISPL CW 90PV180	90R180-KP-5-CD-80-T-C-F1-H-03-FAC-35-35-24	SERIES 90	S90-180PV
83010742	PUMP-VAR DISPL, CW 90PV055	90-R-055-MB-1-BB-80-D-3-C6-L-02-GBA-38-38-26	SERIES 90	S90-055PV
83010751	MOTOR-VAR-DISPL 51MV060-1	51V060-1--R-S1-N-B2-B3-N-N-U3-NNN-031-AA-NN-00-00	SERIES 51	S51-060MV-1
83010752	PUMP-VAR-DISPL CCW 90PV250	90L250-MB-5-NN-80-T-3-F1-J-C5-NNN-42-42-24	SERIES 90	S90-250PV
83010762	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-5-NN-60-S-3-C7-D-C3-GBA-42-42-24	SERIES 90	S90-075PV
83010764	PUMP-TANDEM, VAR DISPL MPT025C	MPT-025-C-S-R-A-H-NN-B-A-A-A-BJJ-DL-A-FF-B-C-A-A-BJJ-DL-A-FF-A-NNN-***	LIGHT DUTY	025PT
83010782	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-B8-C2-C-D6-F-G5-H2-L-30-L-30-B-L-20-P1-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83010790	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A8-C2-C-F3-J-G5-NN-K-35-K-35-B-L-24-P2-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83010794	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-NN-80-L-4-S1-C-03-GBA-21-21-30	SERIES 90	S90-055PV
83010798	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-AB-80-P-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-055PV
83010801	MOTOR-VAR-DISPL H1B080	H1-B-080-A-T1-D1-N-B-TA-DN-HN-N-A-10-NN-028-Z-30-NNN	H1-HP MOTORS	H1-080MB1
83010802	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-8-N-0-C7-W-00-NNN-00-00-F3-P000	SERIES 90	S90-100MF
83010804	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-C3-C2-C-D6-L-G2-H3-L-42-L-42-L-L-24-P2-NNN-D6H	H1-HP PUMPS	H1-115PV/130PV
83010805	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A3-C2-B-D8-G-G3-NN-K-45-K-45-N-E-34-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83010812	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-T1-C2-L-N-G0-NNN-115-AA-G0-00-C7	SERIES 51	S51-250MV
83010815	PUMP-VAR DISPL, CW 90PV100	90-R-100-KT-5-NN-60-L-4-K3-F-04-GBA-29-29-26	SERIES 90	S90-100PV
83010827	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-N-TA-C2-L-N-G0-NNN-160-AA-F0-00-B9	SERIES 51	S51-250MV
83010831	PUMP-VAR-DISPL CW 90PV100	90R100-DD-1-BC-80-L-4-S1-E-GB-GBA-35-35-24	SERIES 90	S90-100PV
83010832	MOTOR-VAR-DISPL 51MD160	51D160-A-D4-N-DA-M4-R-J-M4-ADA-069-AA-G0-C2-25	SERIES 51	S51-160MV
83010836	PUMP-VAR-DISPL CCW H1PV089	H1-P-089-L-A-B8-C2-C-D6-H-G9-H3-L-45-L-45-M-L-30-P1-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83010839	MOTOR-VAR-DISPL 51MC060	51C060-R-D1-N-HZ-B1-A-H-G5-NNN-016-AA-E4-03-00	SERIES 51	S51-060MV
83010840	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-EG-80-T-M-C8-H-03-FAC-35-35-24	SERIES 90	S90-180PV
83010841	PUMP-VAR-DISPL 42PV041 CCW	42-L-41-D-E1A3-03-B-D-B-2-H-N-B-30-30-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83010850	PUMP-VAR DISPL MPV044D	MPV-044-D-B-A-G-R-A-H-NN-A-A-BJJ-DR-A-FF-D-NNN-***	M35/44	044PV
83010851	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-G3AN-52-P-3-G-2-F-1-B-21-21-B-1-1-NNN-NNN	SERIES 42	S42-028PV/032PV

83010852	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-G3AN-52-P-3-G-2-F-1-A-21-21-B-1-1-NNN-NNN	SERIES 42	S42-028PV/032PV
83010853	PUMP-TANDEM, VAR DISPL MPT035D	MPT-035-D-A-L-S-A-BA-C-A-A-A-BJ-DR-A-FF-C-C-A-A-BJ-DR-A-FF-A-NNN-***	M35/44	035PT
83010855	PUMP-VAR DISPL, CW 90PV055	90-R-055-MB-5-BB-80-P-4-C6-C-C5-GBA-35-35-24	SERIES 90	S90-055PV
83010858	PUMP-VAR-DISPL CW 90PV180	90R180-KN-5-NN-80-T-C-F1-J-03-FAC-29-29-24	SERIES 90	S90-180PV
83010861	PUMP-VAR-DISPL CW 90PV075	90R075-DD-1-AB-80-S-4-S1-D-GB-GBA-32-32-24	SERIES 90	S90-075PV
83010863	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KN-1-BC-80-R-4-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83010871	PUMP-VAR-DISPL CCW 90PV130	90L130-CB-1-NN-80-S-4-F1-F-00-GBA-35-35-24	SERIES 90	S90-130PV
83010876	PUMP-VAR-DISPL CW 90PV075	90R075-MA-1-BC-60-P-3-S1-D-03-GBA-32-32-24	SERIES 90	S90-075PV
83010878	PUMP-VAR-DISPL CCW 90PV100	90L100-MA-1-NN-80-P-3-F1-E-09-GBA-45-45-20	SERIES 90	S90-100PV
83010879	PUMP-VAR-DISPL CW 90PV100	90R100-KA-1-BC-80-P-4-C7-F-03-GBA-42-42-24	SERIES 90	S90-100PV
83010880	PUMP-VAR-DISPL CW 90PV100	90R100-M8-1-BC-60-P-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83010881	PUMP-VAR-DISPL CW 90PV100	90R100-HS-1-CD-60-P-3-F1-E-03-GBA-32-32-24	SERIES 90	S90-100PV
83010882	PUMP-VAR-DISPL CW 90PV100	90R100-M8-1-CD-60-P-3-C7-E-03-GBA-42-42-20	SERIES 90	S90-100PV
83010883	PUMP-VAR-DISPL CW 90PV100	90R100-DD-1-AB-60-P-4-S1-E-GB-GBA-35-35-24	SERIES 90	S90-100PV
83010884	PUMP-VAR-DISPL CW 90PV100	90R100-M8-1-BC-60-P-3-C7-E-03-GBA-42-42-20	SERIES 90	S90-100PV
83010885	PUMP-VAR-DISPL CW 90PV100	90R100-MA-1-NN-60-S-3-C7-E-03-GBA-42-42-20	SERIES 90	S90-100PV
83010886	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-AD-80-P-3-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83010887	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-AD-80-P-3-C6-C-03-GBA-26-26-24	SERIES 90	S90-055PV
83010888	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-NN-80-P-3-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83010891	PUMP-VAR-DISPL CW 90PV130	90R130-MA-5-NN-80-S-3-F1-F-C5-GBA-42-42-24	SERIES 90	S90-130PV
83010897	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-NN-60-S-4-K3-E-00-GBA-42-42-24	SERIES 90	S90-100PV
83010898	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A8-C2-C-D3-H-G9-H3-L-42-L-42-M-M-24-P1-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83010899	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-3-N-0-C7-W-00-NNN-00-00-F0	SERIES 90	S90-100MF
83010903	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-BC-80-R-3-C8-H-03-GBA-38-38-28	SERIES 90	S90-130PV
83010906	PUMP-VAR-DISPL CW 90PV100	90R100-HF-5-NN-60-S-4-S1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
83010908	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-CD-60-P-4-C6-D-03-GBA-42-42-24	SERIES 90	S90-055PV
83010909	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-BC-60-P-4-S1-D-03-GBA-42-42-24	SERIES 90	S90-055PV
83010910	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-5-CD-60-S-4-S1-D-03-GBA-42-42-24	SERIES 90	S90-055PV
83010911	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-CD-80-S-4-F1-H-04-GBA-42-42-24	SERIES 90	S90-130PV
83010914	MOTOR-VAR-DISPL 51MV160	51V160-A-D4-N-DA-M4-R-J-N1-ADA-070-AA-NN-C2-25	SERIES 51	S51-160MV
83010918	PUMP-VAR-DISPL CCW 90PV130	90L130-HM-5-CD-80-S-4-F1-F-03-GBA-35-35-24	SERIES 90	S90-130PV
83010919	PUMP-VAR-DISPL CCW 90PV100	90L100-HF-5-NN-80-S-4-C6-E-04-GBA-45-45-28	SERIES 90	S90-100PV
83010920	MOTOR-VAR-DISPL H1B080	H1-B-080-A-E1-AA-N-B-TA-DN-HN-N-A-10-NN-022-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83010921	PUMP-VAR-DISPL CW 90PV042	90R042-MB-5-BB-80-P-3-C3-C-C5-GBA-42-42-24	SERIES 90	S90-042PV
83010926	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KN-5-NN-80-R-4-S1-D-03-GBA-42-42-24	SERIES 90	S90-055PV
83010927	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-5-BC-60-P-3-F1-E-03-GBA-35-35-20	SERIES 90	S90-100PV

83010928	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-BC-80-R-3-S1-E-03-GBA-35-35-20	SERIES 90	S90-100PV
83010929	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-N-L3-B1-W-B-C0-ABA-032-AA-F0-D4-00	SERIES 51	S51-160MV
83010930	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A8-C2-C-D3-G-G2-H6-L-42-L-42-L-M-24-P1-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83010932	PUMP-VAR-DISPL CW 90PV075	90R075-M8-1-CD-60-P-3-C7-D-03-GBA-40-40-24	SERIES 90	S90-075PV
83010933	PUMP-VAR-DISPL CW 90PV075	90R075-M8-1-CD-60-P-3-C7-D-02-GBA-40-40-24	SERIES 90	S90-075PV
83010934	PUMP-VAR-DISPL CW 90PV100	90R100-M8-1-CD-60-P-3-C7-E-03-GBA-40-40-24	SERIES 90	S90-100PV
83010942	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-N-A2-C2-N-E7-F-G6-H3-28-28-25-25-N-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83010943	PUMP-VAR DISPL, CW 90PV055	90-R-055-HS-1-CD-60-P-4-C6-C-03-GBA-32-14-30	SERIES 90	S90-055PV
83010951	PUMP-VAR-DISPL CCW 90PV130	90L130-HF-5-CD-80-S-4-F1-L-03-GBA-35-35-24	SERIES 90	S90-130PV
83010952	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-CD-80-R-3-C7-C-03-GBA-35-35-24	SERIES 90	S90-075PV
83010953	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-AB-80-R-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-075PV
83010954	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-N-E2-B1-N-N-U1-NNN-030-AA-F0-00-00	SERIES 51	S51-060MV-1
83010955	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-NN-80-S-3-C6-C-03-GBA-20-20-24	SERIES 90	S90-055PV
83010961	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-E1-B1-N-N-U1-NNN-080-AA-G0-00-00	SERIES 51	S51-110MV-1
83010963	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-N-L7-B1-W-B-C0-ABA-032-AA-F0-D4-00	SERIES 51	S51-160MV
83010964	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-5-BC-80-R-3-S1-D-03-GBA-26-26-24	SERIES 90	S90-075PV
83010965	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-CD-60-L-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83010966	PUMP-VAR DISPL, CW 90PV100	90-R-100-FD-1-NN-80-S-3-S1-E-B1-EBC-29-29-24	SERIES 90	S90-100PV
83010970	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-AB-80-T-4-C8-K-04-NNN-42-42-24	SERIES 90	S90-250PV
83010971	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-L2-B1-V-A-J1-NNN-050-AA-H0-B2-00	SERIES 51	S51-250MV
83010976	PUMP-VAR-DISPL CW 90PV130	90R130-DD-5-AB-80-S-4-C8-F-GF-GBA-17-17-20	SERIES 90	S90-130PV
83010978	PUMP-VAR DISPL, CW 90PV100	90-R-100-LS-L-CD-8S-P-3-C7-F-04-GP4-45-42-24	SERIES 90	S90-100PV
83010979	PUMP-VAR DISPL, CW 90PV100	90-R-100-LS-L-BB-8S-P-3-J3-F-04-GP4-45-42-24	SERIES 90	S90-100PV
83010980	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-BC-80-P-3-S1-D-03-GBA-32-32-24	SERIES 90	S90-055PV
83010982	PUMP-VAR-DISPL CCW 90PV100	90L100-HF-5-NN-60-S-3-C7-E-02-GBA-30-30-24	SERIES 90	S90-100PV
83010993	PUMP-VAR-DISPL 42PV041 CCW	42-L-51-D-E2D8-03-B-D-B-3-G-N-A-30-30-B-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83010994	PUMP-VAR-DISPL CW 90PV250	90R250-MA-5-CD-80-T-3-F1-K-C5-NNN-35-35-24	SERIES 90	S90-250PV
83010999	PUMP-VAR-DISPL 42PV041 CW	42-R-41-C-ANN3-03-B-3-G-3-F-N-N-34-34-N-A-A-NNN-NNN	SERIES 42	S42-041PV/051PV
83011001	MOTOR-VAR-DISPL H1B060	H1-B-060-A-L2-BA-N-A-PB-CS-GS-S-A-05-NN-000-N-00-NNN	H1-HP MOTORS	H1-060MB1
83011002	PUMP-VAR-DISPL CCW 90PV180	90L180-KN-1-NN-80-S-M-F1-L-03-FAC-35-35-24	SERIES 90	S90-180PV
83011003	PUMP-VAR-DISPL CCW 90PV130	90L130-HF-5-CD-80-S-4-F1-L-03-GBA-35-35-24	SERIES 90	S90-130PV
83011004	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-CD-80-D-4-F1-L-05-GBA-35-35-24	SERIES 90	S90-130PV
83011007	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-BC-80-P-3-T2-E-03-GBA-38-38-24	SERIES 90	S90-100PV
83011012	PUMP-VAR DISPL, CCW 90PV100	90-L-100-FD-1-NN-80-S-3-F1-E-B1-EBC-29-29-24	SERIES 90	S90-100PV
83011013	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-C8-N-N1-NN-N-N-U1-NNN-050-AA-F3-00-00	SERIES 51	S51-110MV-1
83011014	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-B8-C2-D-D3-H-F1-NN-K-40-K-40-M-M-24-P1-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV

83011015	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-B1-C1-B-D3-G-G3-H6-K-42-K-42-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83011017	PUMP-VAR-DISPL CCW H1PV089	H1-P-089-L-A-C3-C1-C-D3-K-F1-NN-L-43-L-44-M-M-24-P2-NNN-D6H	H1-HP PUMPS	H1-089PV/100PV
83011019	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-TA-C2-L-N-G0-ABA-105-AA-NN-00-A3	SERIES 51	S51-160MV
83011020	PUMP-VAR-DISPL CCW 90PV042	90L042-MA-1-NN-80-S-3-T3-B-03-GBA-17-17-20	SERIES 90	S90-042PV
83011021	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KN-5-NN-60-R-4-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83011025	PUMP- VARIABLE, DIRECT DISPLACMENT	LPV-A-A-A-L-A-G-AA-D-A-BFF-DR-A-FF-B-NNN-***	LPV	LPV
83011028	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A3-C3-N-D3-H-G1-NN-L-35-L-35-M-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83011032	PUMP-TANDEM, VAR DISPL CCW H1T045L	H1-T-045-L-A-N-A3-C2-N-E7-F-G5-TN-35-35-35-35-M-P-24-PN-NNN-S01	H1-MP PUMPS	H1-045PT/053PT
83011037	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-5-CD-80-S-4-C6-C-C5-GBA-42-42-24	SERIES 90	S90-055PV
83011044	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-1-BB-80-P-3-S1-D-00-GBA-42-42-24	SERIES 90	S90-055PV
83011054	PUMP-VAR-DISPL CW 90PV075	90R075-FH-5-AB-80-R-7-C6-D-B2-EFC-42-42-24-G005	SERIES 90	S90-075PV
83011068	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A2-C3-N-D1-F-G5-H2-20-20-30-30-N-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83011069	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-NN-80-S-3-C7-F-03-GBA-45-45-24	SERIES 90	S90-100PV
83011070	PUMP-VAR DISPL MPV025C	MPV-025-C-B-A-A-R-A-E-NN-A-A-BBB-DR-A-FF-A-NNN-***	LIGHT DUTY	025PV
83011073	MOTOR-VAR-DISPL 51MC060-1	51C060-1--A-S1-E-E2-B1-N-N-U1-NNN-020-AA-NN-00-00	SERIES 51	S51-060MV-1
83011076	MOTOR-VAR-DISPL H1B060	H1-B-060-A-L1-BA-N-B-PA-VN-AN-N-N-NN-NN-000-N-00-NNN	H1-HP MOTORS	H1-060MB1
83011079	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A5-C3-B-D6-F-G5-NN-L-38-L-38-B-L-22-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83011081	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A4-C3-N-D3-G-G3-NN-L-45-L-45-A-M-20-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83011082	MOTOR-VAR-DISPL H1B060	H1-B-060-A-L1-BA-N-B-PB-CS-GS-S-A-05-NN-000-N-00-NNN	H1-HP MOTORS	H1-060MB1
83011083	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-NN-80-T-4-F1-J-03-NNN-20-20-24	SERIES 90	S90-250PV
83011084	PUMP-TANDEM, VAR DISPL CCW H1T045L	H1-T-045-L-A-N-A3-C2-N-E7-F-G5-T2-35-35-35-35-M-P-24-PN-NNN-S01	H1-MP PUMPS	H1-045PT/053PT
83011087	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-G-S-B-B-AA-A-A-BMM-CD-A-GG-C-NNN-***	M46	M46-046PV
83011089	PUMP-VAR DISPL MPV046C	MPV-046-C-B-A-G-S-B-B-AA-G-A-BJJ-AB-D-AA-C-NNN-***	M46	M46-046PV
83011094	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-N2-NN-N-N-A0-NNN-074-AA-NN-00-00	SERIES 51	S51-160MV
83011095	PUMP-VAR-DISPL CW 90PV130	90R130-HF-5-NN-80-R-4-F1-F-02-GBA-26-14-24	SERIES 90	S90-130PV
83011097	PUMP-VAR-DISPL 42PV028 CW	42-R-28-G-E1A7-03-B-2-B-3-E-N-N-23-23-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83011101	PUMP-VAR-DISPL CW 90PV100	90R100-KA-1-AB-80-P-4-S1-D-03-GBA-36-14-24	SERIES 90	S90-100PV
83011102	MOTOR-VAR-DISPL H1B110	H1-B-110-A-K2-K2-N-A-RB-VS-ES-S-A-10-NN-055-N-21-NNN	H1-HP MOTORS	H1-110MB1
83011107	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A2-C1-N-F4-H-G9-H6-L-42-L-42-C-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83011111	PUMP-VAR DISPL, CW 90PV100	90-R-100-FC-1-BC-80-P-7-F1-E-B1-GCA-35-35-24	SERIES 90	S90-100PV
83011113	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A3-C3-B-F2-F-G5-H1-K-35-K-35-B-P-30-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83011114	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A3-C3-B-F2-F-G5-NN-K-35-K-35-B-P-30-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83011115	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-1-AC-80-S-4-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83011116	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HF-1-NN-80-R-4-S1-D-03-GBA-32-32-24	SERIES 90	S90-075PV
83011117	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-5-NN-60-S-3-C6-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83011120	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-5-NN-60-S-3-C6-D-C5-GBA-35-35-24	SERIES 90	S90-075PV

83011121	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-5-NN-60-S-3-C6-D-C3-GBA-35-35-24	SERIES 90	S90-075PV
83011132	PUMP-VAR-DISPL 42PV041 CCW	42-L-51-D-E1A6-03-A-N-A-3-H-N-N-34-34-B-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83011136	PUMP-VAR DISPL, CW 90PV100	90-R-100-EA-1-NN-60-L-3-F1-F-03-GBA-29-29-24	SERIES 90	S90-100PV
83011140	PUMP-VAR-DISPL CCW H1PV147	H1-P-147-L-C-A3-C2-N-D5-G-G2-H4-L-35-L-35-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83011141	PUMP-VAR-DISPL CCW H1PV115	H1-P-115-L-B-A3-C2-N-D3-G-G3-H6-L-30-L-30-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83011142	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-5-CD-80-R-4-S1-D-C3-GBA-23-23-20	SERIES 90	S90-075PV
83011145	PUMP-VAR-DISPL CCW H1PV165	H1-P-165-L-C-A5-C3-B-D6-G-G3-NN-L-25-L-25-L-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83011155	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A8-C2-C-D3-K-G9-H3-L-42-L-42-M-M-24-P2-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83011156	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A8-C2-C-D3-L-G2-H3-L-42-L-42-L-M-24-P2-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83011157	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A8-C2-C-D3-L-G2-H6-L-42-L-42-L-M-24-P2-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83011158	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A8-C2-C-D3-K-G9-H3-L-42-L-42-C-M-24-P2-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83011162	MOTOR-VAR-DISPL 51MD080-1	51D080-1--A-D2-N-T1-CA-N-N-X1-NNN-023-AA-E6-00-26	SERIES 51	S51-080MV-1
83011165	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-A-A5-C3-N-D6-H-G1-NN-L-38-L-38-M-L-28-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83011166	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-1-NN-80-S-3-S1-C-03-GBA-38-32-24	SERIES 90	S90-055PV
83011167	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HS-1-CD-80-S-3-C7-E-03-GBA-29-29-24	SERIES 90	S90-075PV
83011182	PUMP-VAR DISPL, CCW 90PV075	90-L-075-NA-1-NN-80-L-3-D7-E-78-GBA-42-42-24	SERIES 90	S90-075PV
83011183	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A4-C2-B-D6-H-G1-NN-L-25-L-25-F-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83011184	PUMP-VAR-DISPL CCW 90PV130	90L130-HF-5-BC-80-S-4-F1-L-03-GBA-35-35-24	SERIES 90	S90-130PV
83011193	MOTOR-VAR-DISPL H1B080	H1-B-080-A-E2-AA-N-A-TB-CS-JS-S-A-10-NN-040-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83011194	MOTOR-VAR-DISPL H1B080	H1-B-080-A-E2-AA-N-A-TB-CN-JN-N-A-10-NN-040-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83011202	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A5-C1-N-D3-H-F4-NN-L-35-L-35-C-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83011203	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A5-C1-N-D3-H-F4-NN-K-35-K-35-C-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83011205	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KN-1-CD-80-D-4-S1-L-03-GBA-35-35-24	SERIES 90	S90-075PV
83011206	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KN-1-NN-80-D-4-S1-L-03-GBA-35-35-24	SERIES 90	S90-075PV
83011210	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A7-C2-D-D6-J-G5-H3-L-40-L-40-B-L-20-P2-NNN-D3F	H1-MP PUMPS	H1-045PV/053PV
83011213	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A2-C2-N-D3-H-G9-H3-K-33-K-33-D-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83011215	PUMP-VAR DISPL, CW 90PV075	90-R-075-CB-1-NN-80-R-3-S1-D-00-GBA-23-23-24	SERIES 90	S90-075PV
83011224	PUMP-VAR DISPL, CCW 90PV055	90-L-055-FD-2-BG-80-S-7-S1-C-B1-GLA-45-45-26	SERIES 90	S90-055PV
83011230	PUMP-VAR DISPL, CW 90PV075	90-R-075-DD-5-BC-60-S-4-C7-D-GB-GBA-26-26-24	SERIES 90	S90-075PV
83011231	PUMP-VAR DISPL, CW 90PV100	90-R-100-DD-1-CD-60-S-4-C7-E-GB-GBA-26-26-24	SERIES 90	S90-100PV
83011238	MOTOR-VAR-DISPL H1B110#	H1-B-110-A-T1-D1-N-B-TA-DS-KS-S-A-15-NN-032-Z-21-NNN	H1-HP MOTORS	H1-110MB1
83011242	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-NN-80-T-C-C8-H-K4-GLA-35-35-30-G005	SERIES 90	S90-180PV
83011244	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-CD-60-S-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83011247	PUMP-VAR-DISPL CW 90PV100	90R100-HF-5-BC-60-S-4-S1-F-03-GBA-17-17-20	SERIES 90	S90-100PV
83011249	PUMP-VAR-DISPL CW 90PV180	90R180-HF-5-CD-80-S-M-F1-H-03-NNN-17-17-22	SERIES 90	S90-180PV
83011250	PUMP-VAR-DISPL CCW 90PV180	90L180-HF-5-CD-80-S-M-F1-H-03-FAC-14-14-22	SERIES 90	S90-180PV

83011252	MOTOR-VAR-DISPL 51MV080	51V080-A-C7-N-L3-B1-W-B-G0-ANA-050-AA-F0-D4-00	SERIES 51	S51-080MV
83011253	MOTOR-VAR-DISPL H1B110	H1-B-110-A-L2-BA-N-B-PA-VS-ES-S-N-NN-NN-055-N-00-NNN	H1-HP MOTORS	H1-110MB1
83011254	MOTOR-VAR-DISPL 51MV250	51V250-A-C8-N-D7-M1-S-K-M1-NNN-050-AA-G0-F4-25	SERIES 51	S51-250MV
83011255	MOTOR-VAR-DISPL H1B110	H1-B-110-A-L1-BA-N-B-PA-VN-DN-N-A-10-NN-000-N-00-NNN	H1-HP MOTORS	H1-110MB1
83011258	MOTOR-FIX DISPL MMF035D	MMF-035-D-A-A-A-C-G-NNN-***	M35/44	035MF
83011259	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A5-C3-B-D6-G-G3-NN-L-25-L-25-A-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83011261	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HF-1-CD-60-P-3-S1-E-00-GBA-17-17-24	SERIES 90	S90-075PV
83011263	PUMP-VAR-DISPL CCW H1PV115	H1-P-115-L-B-A3-C2-N-D8-G-G2-H6-L-30-L-30-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83011264	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A3-C2-N-F5-H-G1-H6-L-35-L-35-M-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83011265	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A3-C2-N-D8-H-G1-NN-L-35-L-35-M-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83011266	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A3-C2-N-D8-H-G1-H3-L-35-L-35-M-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83011267	PUMP-VAR DISPL, CW 90PV100	90-R-100-HF-2-BC-80-L-4-S1-F-00-GBA-17-17-28	SERIES 90	S90-100PV
83011277	PUMP-VAR-DISPL CW 90PV100	90R100-HF-5-NN-80-R-4-S1-F-02-GBA-20-20-30	SERIES 90	S90-100PV
83011279	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-1-AB-60-P-4-S1-D-G4-GBA-35-35-20	SERIES 90	S90-055PV
83011280	PUMP-VAR-DISPL CCW H1PV130	H1-P-130-L-B-A4-C2-N-D3-G-G2-H2-L-42-L-42-A-M-20-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83011284	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-A-E2-A5-A-N-G0-NNN-075-AA-G0-03-00	SERIES 51	S51-250MV
83011285	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-C-E2-A5-A-N-G0-NNN-075-AA-G0-03-00	SERIES 51	S51-250MV
83011286	PUMP-VAR-DISPL CW 90PV250	90R250-KA-2-AB-80-T-4-C8-K-03-NNN-30-30-24	SERIES 90	S90-250PV
83011293	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-NN-80-S-C-C8-J-03-GCG-45-45-24	SERIES 90	S90-180PV
83011298	MOTOR-VAR-DISPL H1B060	H1-B-060-A-K2-KA-N-B-RB-CN-GN-N-A-05-NN-024-N-28-NNN	H1-HP MOTORS	H1-060MB1
83011305	PUMP-VAR-DISPL CW 90PV100	90R100-KN-5-AB-80-R-3-C7-F-03-GBA-42-42-28	SERIES 90	S90-100PV
83011306	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-BC-80-T-C-C8-J-03-NNN-32-32-30	SERIES 90	S90-180PV
83011308	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-H-S-B-B-BA-A-A-BGG-CE-A-GG-A-NNN-***	M46	M46-046PV
83011310	PUMP-VAR DISPL, CW 90PV055	90-R-055-FC-5-BC-60-S-7-C6-C-B2-EBC-42-42-30	SERIES 90	S90-055PV
83011319	PUMP-VAR-DISPL CW 90PV180	90R180-MA-5-CD-80-T-M-C8-J-C5-NNN-26-26-24	SERIES 90	S90-180PV
83011320	MOTOR-VAR-DISPL 51MV160	51V160-A-C8-N-Y3-B1-S-K-J1-NNN-062-AA-H0-F4-00	SERIES 51	S51-160MV
83011323	PUMP-VAR-DISPL CW 90PV130	90R130-HF-5-BC-80-R-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-130PV
83011324	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-HZ-B1-A-N-G0-NNN-032-AA-F3-03-00	SERIES 51	S51-160MV
83011326	PUMP-VAR DISPL, CCW 90PV075	90-L-075-DD-5-NN-80-P-4-C6-D-GB-GBA-26-26-28	SERIES 90	S90-075PV
83011327	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A3-C3-N-F7-F-G5-H3-35-35-35-35-N-P-28-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83011333	PUMP-VAR-DISPL CCW 90PV042	90L042-MA-5-NN-80-P-3-C3-C-C5-GBA-26-26-24	SERIES 90	S90-042PV
83011335	MOTOR-VAR-DISPL 51MD160	51D160-R-D4-N-HS-A2-C-H-E1-NNN-080-AA-NN-13-19	SERIES 51	S51-160MV
83011336	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HS-5-AB-80-S-3-S1-C-03-GBA-42-17-20	SERIES 90	S90-055PV
83011337	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A3-C1-N-D6-G-G3-H3-L-35-L-35-L-L-30-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83011338	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A3-C2-N-D3-G-A8-H3-L-43-L-43-L-M-30-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83011341	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-5-BC-80-R-4-S1-C-C3-GBA-23-23-20	SERIES 90	S90-055PV

83011342	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-T2-C2-L-N-G0-NNN-063-AA-G0-00-C2	SERIES 51	S51-160MV
83011343	PUMP-VAR-DISPL CW 90PV180	90R180-PA-1-BB-80-S-C-F1-H-09-NNN-42-42-24	SERIES 90	S90-180PV
83011344	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A3-C1-N-D9-G-G3-H4-L-35-L-35-L-L-30-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83011345	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-AB-80-T-4-C8-K-03-NNN-26-26-24	SERIES 90	S90-250PV
83011346	PUMP-VAR DISPL, CW 90PV075	90-R-075-HS-1-AB-80-S-3-S1-E-02-GBA-21-21-20	SERIES 90	S90-075PV
83011347	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-EF-80-D-C-C8-L-03-NNN-42-42-22	SERIES 90	S90-180PV
83011348	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-DH-80-D-3-C8-L-03-EHA-42-42-20	SERIES 90	S90-130PV
83011349	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-NN-80-D-3-C8-N-03-GBA-42-42-20	SERIES 90	S90-130PV
83011350	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-5-CD-60-R-3-C6-D-C5-GBA-40-40-24	SERIES 90	S90-055PV
83011351	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-2-NN-60-D-4-S1-L-02-GBA-32-32-24	SERIES 90	S90-055PV
83011356	PUMP-VAR-DISPL CCW H1PV115	H1-P-115-L-B-A5-C3-N-D6-G-G3-H3-L-35-L-35-A-L-28-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83011360	PUMP-VAR-DISPL CCW H1PV147	H1-P-147-L-C-A5-C2-N-D8-G-G3-H6-L-38-L-38-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83011364	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-1-NN-80-P-3-S1-C-03-GBA-32-32-24	SERIES 90	S90-055PV
83011369	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A5-C2-N-D3-H-G9-NN-L-40-L-40-C-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83011373	PUMP-VAR-DISPL CW 90PV042	90R042-HF-5-BC-80-S-3-C3-C-03-GBA-42-42-24	SERIES 90	S90-042PV
83011374	MOTOR-VAR-DISPL 51MD110-1	51D110-1--A-D4-N-T2-C2-N-N-X1-NNN-074-AA-F0-00-16	SERIES 51	S51-110MV-1
83011382	MOTOR-VAR-DISPL 51MV080-1	51V080-1--A-S1-N-TH-C2-N-N-X1-NNN-016-AA-NN-00-21	SERIES 51	S51-080MV-1
83011383	PUMP-VAR-DISPL CW 90PV250	90R250-KA-1-NN-80-T-4-F1-K-03-NNN-20-20-24	SERIES 90	S90-250PV
83011389	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HF-1-BC-80-L-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83011390	PUMP-VAR-DISPL CW 90PV180	90R180-DC-5-NN-80-T-C-F1-J-GB-FAC-35-35-24	SERIES 90	S90-180PV
83011391	PUMP-VAR-DISPL CW 90PV130	90R130-KN-5-BC-80-L-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-130PV
83011393	PUMP-VAR-DISPL CCW 90PV130	90L130-KN-1-AB-80-L-3-F1-F-00-GBA-38-38-28	SERIES 90	S90-130PV
83011396	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-1-NN-60-S-4-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
83011397	PUMP-VAR DISPL MPV046C	MPV-046-C-B-A-B-S-B-B-AA-A-A-BFF-AB-U-BD-A-NNN-***	M46	M46-046PV
83011399	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-A3NB-03-B-5-B-2-C-N-B-34-34-B-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83011400	MOTOR-VAR-DISPL 51MD110	51D110-R-D4-N-HS-A2-C-H-C1-NNN-055-AA-NN-26-13	SERIES 51	S51-110MV
83011401	PUMP-VAR DISPL, CW 90PV100	90-R-100-DD-1-BB-80-R-3-F1-F-GB-GBA-35-35-24	SERIES 90	S90-100PV
83011412	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-N2-NN-N-N-A0-NNN-125-AA-NN-00-00	SERIES 51	S51-250MV
83011413	PUMP-VAR-DISPL CCW 90PV100	90L100-HF-1-AB-60-R-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83011418	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A4-C1-N-D6-H-G1-NN-L-40-L-40-C-L-28-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83011419	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-P-CD-80-S-4-S1-D-00-GBA-40-40-32	SERIES 90	S90-055PV
83011420	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-P-NN-80-S-4-S1-D-00-GBA-40-40-32	SERIES 90	S90-055PV
83011421	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-P-CD-80-S-4-S1-E-00-GBA-40-40-32	SERIES 90	S90-075PV
83011422	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-P-NN-80-S-4-S1-E-00-GBA-40-40-32	SERIES 90	S90-075PV
83011423	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-P-CD-80-S-4-F1-F-00-GBA-40-40-32	SERIES 90	S90-100PV
83011424	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-P-NN-80-S-4-S1-F-00-GBA-40-40-32	SERIES 90	S90-100PV

83011425	MOTOR-VAR-DISPL 51MV110	51V110-R-C8-N-D8-M1-R-J-M1-NNN-074-AA-NN-C2-16	SERIES 51	S51-110MV
83011426	PUMP-VAR-DISPL CCW 90PV042	90L042-KA-5-BC-80-S-3-C3-C-03-GBA-42-42-24	SERIES 90	S90-042PV
83011430	MOTOR-FIX DISPL 90MF130	90-M-130-NC-0-N-8-N-0-F1-N-00-EGL-00-00-00	SERIES 90	S90-130MF
83011436	PUMP-VAR-DISPL CCW 90PV130	90L130-CB-5-NN-80-S-3-F1-F-00-EEB-35-35-24-P000	SERIES 90	S90-130PV
83011437	PUMP-VAR-DISPL CW 90PV130	90R130-CB-5-NN-80-S-3-F1-F-00-EEB-35-35-24-P000	SERIES 90	S90-130PV
83011440	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D3-N-E2-B1-N-N-U1-NNN-034-AA-F3-00-00	SERIES 51	S51-080MV-1
83011441	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-N-E2-B1-N-N-U1-NNN-022-AA-F3-00-00	SERIES 51	S51-060MV-1
83011443	MOTOR-VAR-DISPL H1B080	H1-B-080-A-L1-BA-N-B-PB-CS-HS-S-A-10-NN-000-N-00-NNN	H1-HP MOTORS	H1-080MB1
83011447	PUMP-VAR DISPL, CW 90PV055	90-R-055-MV-1-NN-80-P-3-C6-C-03-GBA-42-42-24	SERIES 90	S90-055PV
83011450	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-NN-65-R-3-F3-F-00-GLA-40-35-20-N180	SERIES 90	S90-100PV
83011459	PUMP-VAR-DISPL CW 90PV042	90R042-HF-5-BB-80-R-3-C3-C-04-GBA-35-35-24	SERIES 90	S90-042PV
83011460	PUMP-VAR-DISPL CW 90PV042	90R042-HF-5-AB-80-R-3-C3-C-04-GBA-35-35-24	SERIES 90	S90-042PV
83011462	PUMP-VAR-DISPL CW 90PV075	90R075-FM-5-BC-60-P-7-C6-D-B6-GMD-45-45-30	SERIES 90	S90-075PV
83011463	MOTOR-VAR-DISPL H1B060	H1-B-060-A-E2-AA-N-B-TA-VS-AS-S-A-10-NN-040-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83011464	MOTOR-VAR-DISPL H1B080	H1-B-080-A-L2-BA-N-B-PA-VS-AS-S-A-10-NN-045-N-00-NNN	H1-HP MOTORS	H1-080MB1
83011467	MOTOR-VAR-DISPL 51MD160	51D160-A-D5-N-HS-A1-B-H-E2-NNN-071-AA-F3-12-24	SERIES 51	S51-160MV
83011468	PUMP-VAR-DISPL CCW 90PV100	90L100-MA-1-NN-80-S-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83011476	PUMP-VAR-DISPL 42PV041 CW	42-R-41-C-F5NN-75-J-D-C-3-F-N-N-34-34-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83011480	MOTOR-VAR-DISPL 51MV160	51V160-A-C8-N-L2-B1-V-A-G0-ABA-032-AA-F3-B2-00	SERIES 51	S51-160MV
83011483	MOTOR-VAR-DISPL H1B060	H1-B-060-A-T2-D2-N-B-TA-CS-GS-S-A-05-NN-030-Z-20-NNN	H1-HP MOTORS	H1-060MB1
83011484	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A3-C2-N-D8-J-G5-H3-L-28-L-28-B-P-22-P4-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83011486	PUMP-VAR-DISPL CW 90PV075	90R075-KA-1-AB-60-P-3-C7-D-03-GBA-38-38-30	SERIES 90	S90-075PV
83011487	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MA-1-NN-80-S-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83011492	PUMP-VAR-DISPL CW 90PV180	90R180-MA-5-NN-80-S-C-F1-H-C5-NNN-35-14-24	SERIES 90	S90-180PV
83011494	PUMP-VAR DISPL, CW 90PV100	90-R-100-M8-1-BC-80-L-4-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83011496	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HF-1-AB-80-R-4-T2-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83011497	MOTOR-VAR-DISPL H1B080	H1-B-080-A-L1-BA-N-B-PA-VS-AS-S-N-NN-NN-049-N-00-NNN	H1-HP MOTORS	H1-080MB1
83011500	PUMP-VAR DISPL, CW 90PV055	90-R-055-KT-5-CD-81-P-3-S1-D-03-GBA-40-40-24	SERIES 90	S90-055PV
83011501	PUMP-VAR DISPL, CW 90PV055	90-R-055-KT-5-NN-81-P-3-S1-D-03-GBA-40-40-24	SERIES 90	S90-055PV
83011505	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-CE-60-S-4-F1-G-03-GBA-42-42-24	SERIES 90	S90-100PV
83011507	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-E2D8-02-A-N-A-3-H-N-A-25-25-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83011508	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-1-BC-80-S-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83011510	PUMP-VAR-DISPL CCW 90PV100	90L100-MA-1-BB-60-S-3-C7-D-04-GCA-42-42-20	SERIES 90	S90-100PV
83011511	MOTOR-VARIABLE CARTRIDGE K	K-C-38CS-E-RNF-F11-S-N-N-BF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83011512	MOTOR-VAR-DISPL H1B110	H1-B-110-A-L1-BA-N-A-PA-DN-KN-N-A-15-NN-000-N-00-NNN	H1-HP MOTORS	H1-110MB1
83011518	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-1-AB-60-S-3-F1-E-K1-FAD-42-42-24	SERIES 90	S90-100PV

83011524	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-N-A2-C2-N-D1-F-G1-TN-33-33-33-33-M-P-24-PN-NNN-S01	H1-MP PUMPS	H1-045PT/053PT
83011525	MOTOR-VAR-DISPL 51MD060-1	51D060-1--R-D2-N-TA-C2-N-N-X1-NNN-026-AA-E4-00-13	SERIES 51	S51-060MV-1
83011526	PUMP-VAR-DISPL 42PV041 CW	42-R-51-D-E2D8-02-D-N-F-3-H-N-B-30-30-B-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83011531	PUMP-VAR DISPL, CW 90PV100	90-R-100-HF-1-AB-80-L-3-S1-F-03-GBA-32-32-24	SERIES 90	S90-100PV
83011537	PUMP-VAR-DISPL CCW 90PV130	90L130-MB-5-CD-80-R-3-F1-F-C5-GBA-42-42-24	SERIES 90	S90-130PV
83011544	PUMP-VAR DISPL CCW H1P053L	H1-P-053-L-A-A4-C2-N-D8-F-G5-NN-L-23-L-23-B-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83011546	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-BC-80-T-C-C8-J-03-NNN-32-32-34	SERIES 90	S90-180PV
83011562	PUMP-VAR-DISPL CW 90PV130	90R130-MA-5-DG-80-D-4-C8-L-C7-GBA-35-35-24-F076	SERIES 90	S90-130PV
83011563	PUMP-VAR-DISPL CW 90PV130	90R130-MA-5-CD-80-D-4-C8-L-C7-GBA-35-35-24-F076	SERIES 90	S90-130PV
83011564	MOTOR-VAR-DISPL H1B080	H1-B-080-A-T1-DA-N-B-TA-VN-AN-N-A-05-NN-036-Z-30-NNN	H1-HP MOTORS	H1-080MB1
83011565	MOTOR-VAR-DISPL H1B080	H1-B-080-A-T2-DA-N-B-TA-VN-AN-N-A-10-NN-036-Z-30-NNN	H1-HP MOTORS	H1-080MB1
83011566	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-BC-80-P-4-S1-E-03-GBA-14-14-24	SERIES 90	S90-075PV
83011567	MOTOR-VARIABLE CARTRIDGE K	K-C-45DN-E-RNF-F01-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83011580	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-BC-80-T-M-C8-J-03-FAC-35-17-24	SERIES 90	S90-180PV
83011581	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-BC-80-T-4-C8-K-03-NNN-35-17-24	SERIES 90	S90-250PV
83011583	PUMP-VAR-DISPL CW 90PV075	90R075-KA-1-NN-60-L-3-C7-D-03-GBA-38-38-20	SERIES 90	S90-075PV
83011584	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-1-NN-60-L-3-C7-D-03-GBA-38-38-20	SERIES 90	S90-075PV
83011591	PUMP-VAR-DISPL CW 90PV075	90R075-LT-5-BB-60-D-3-S1-L-C6-GBA-42-42-24	SERIES 90	S90-075PV
83011592	MOTOR-VAR-DISPL 51MV110	51V110-R-C8-N-ES-A6-J-Y-H7-NNN-045-AA-H0-30-00	SERIES 51	S51-110MV
83011597	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-1-AB-80-T-4-F1-K-03-NNN-20-20-24	SERIES 90	S90-250PV
83011602	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-E1A6-02-B-2-B-2-G-N-A-34-34-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83011612	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-EG-80-T-4-C8-K-03-GLA-35-17-24	SERIES 90	S90-250PV
83011614	MOTOR-VARIABLE DISPL SAE_L	L-V-25CS-A-R2F-F09-S-N-N-DF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83011617	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-5-CD-80-S-4-C8-K-04-NNN-42-42-24	SERIES 90	S90-250PV
83011618	PUMP-VAR-DISPL CW 90PV130	90R130-MA-1-AB-80-S-4-F1-F-04-GBA-42-42-24	SERIES 90	S90-130PV
83011619	MOTOR-VAR-DISPL H1B110#	H1-B-110-A-HE-HE-N-B-TA-VN-EN-N-N-NN-NN-030-U-00-NNN	H1-HP MOTORS	H1-110MB1
83011620	MOTOR-VAR-DISPL 51MV110	51V110-R-F1-N-HS-A3-C-E-E5-NNN-030-AA-F0-25-25	SERIES 51	S51-110MV
83011621	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A5-C1-N-F5-H-G9-H6-L-42-L-42-C-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83011629	MOTOR-VAR-DISPL H1B080	H1-B-080-A-TA-DA-N-C-TB-VN-AN-N-N-NN-NN-AA4-Z-16-NNN	H1-HP MOTORS	H1-080MB1
83011631	MOTOR-VAR-DISPL H1B060	H1-B-060-A-L2-BA-N-B-PB-CS-GS-S-A-05-NN-012-N-00-NNN	H1-HP MOTORS	H1-060MB1
83011632	MOTOR-VAR-DISPL H1B060	H1-B-060-A-HE-HE-N-B-TB-CS-GS-S-N-NN-NN-030-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83011637	PUMP-VAR-DISPL CCW 90PV130	90L130-MA-5-DE-80-R-3-C8-F-C5-GBA-35-35-24	SERIES 90	S90-130PV
83011638	MOTOR-VAR-DISPL 51MV060-1	51V060-1--A-S1-E-E2-B1-N-N-U1-NNN-020-AA-NN-00-00	SERIES 51	S51-060MV-1
83011640	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-E2C8-03-D-N-F-2-D-N-A-30-30-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83011641	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-NN-80-L-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-075PV
83011643	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-N-A2-C2-N-E7-F-G6-T3-35-35-35-35-M-P-24-PN-NNN-S04	H1-MP PUMPS	H1-045PT/053PT

83011652	MOTOR-VAR-DISPL H1B110	H1-B-110-A-L2-BA-N-A-PB-VN-DN-N-A-10-NN-022-N-00-NNN	H1-HP MOTORS	H1-110MB1
83011654	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A3-C2-N-D8-F-G1-H5-L-35-L-35-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83011655	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A3-C2-N-D8-F-G5-H3-L-35-L-35-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83011659	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-N-L2-B1-V-A-C0-ACA-070-AA-G0-B2-00	SERIES 51	S51-250MV
83011660	PUMP-VAR-DISPL CW 90PV100	90R100-KA-2-CD-60-P-4-C7-E-03-GBA-26-26-24	SERIES 90	S90-100PV
83011661	PUMP-VAR-DISPL CW 90PV075	90R075-KA-2-AB-60-P-3-S1-D-03-EFC-23-23-24	SERIES 90	S90-075PV
83011663	MOTOR-VAR-DISPL H1B080	H1-B-080-A-E2-AA-N-B-TA-CS-JS-S-N-NN-NN-040-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83011664	MOTOR-VAR-DISPL 51MD110-1	51D110-1--R-D3-N-T1-D1-N-N-X1-NNN-023-AA-F0-00-20	SERIES 51	S51-110MV-1
83011667	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-AB-60-R-3-C7-D-00-GBA-35-35-24	SERIES 90	S90-075PV
83011668	PUMP-TANDEM, VAR DISPL MPT044D	MPT-044-D-A-Y-S-G-BA-B-A-A-A-BJJ-DR-A-FF-B-C-A-A-BJJ-DR-A-FF-C-NNN-***	M35/44	044PT
83011674	MOTOR-VAR-DISPL H1B060	H1-B-060-A-T2-D2-N-C-TA-DN-GN-N-N-NN-NN-032-Z-28-NNN	H1-HP MOTORS	H1-060MB1
83011675	MOTOR-VAR-DISPL 51MV110-1	51V110-1--A-C8-N-TA-C2-N-N-X1-NNN-080-AA-NN-00-17	SERIES 51	S51-110MV-1
83011676	PUMP-VAR-DISPL CCW H1PV089	H1-P-089-L-A-C2-C2-C-D6-K-G9-H3-L-42-L-42-M-L-24-P2-NNN-D4F	H1-HP PUMPS	H1-089PV/100PV
83011677	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-N-L7-B1-W-B-C0-ACA-050-AA-F3-D4-00	SERIES 51	S51-250MV
83011678	MOTOR-VAR-DISPL 51MC080	51C080-R-D3-N-L2-B1-V-A-C0-ACB-028-AA-E4-B2-00	SERIES 51	S51-080MV
83011679	MOTOR-VAR-DISPL 51MC080	51C080-R-D3-N-L2-B1-V-A-C0-NNN-028-AA-E4-B2-00	SERIES 51	S51-080MV
83011683	PUMP-VAR DISPL MPV035D	MPV-035-D-B-A-A-R-S-F-AA-A-A-BJJ-DR-A-FF-A-NNN-***	M35/44	035PV
83011684	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A5-C1-N-D8-H-G9-H5-L-42-L-42-C-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83011686	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-A-T-B-B-BA-A-A-BBG-CB-A-JJ-C-NNN-***	M46	M46-046PV
83011690	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A5-C2-N-D6-F-G5-NN-L-30-L-30-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83011692	MOTOR-VAR-DISPL H1B080	H1-B-080-A-L1-BA-N-B-PB-VS-AS-S-A-05-NN-035-N-00-NNN	H1-HP MOTORS	H1-080MB1
83011693	MOTOR-VAR-DISPL H1B080	H1-B-080-A-L1-BA-N-B-PB-VN-AN-N-A-05-NN-035-N-00-NNN	H1-HP MOTORS	H1-080MB1
83011694	MOTOR-VAR-DISPL 51MD080-1	51D080-1--A-D3-N-T7-L5-N-N-X1-NNN-045-AA-F0-00-26	SERIES 51	S51-080MV-1
83011695	MOTOR-VAR-DISPL 51MD110-1	51D110-1--R-D4-N-T1-C2-N-N-X1-NNN-034-AA-F0-00-37	SERIES 51	S51-110MV-1
83011703	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-B1-B3-N-N-U3-NNN-055-AA-NN-00-00	SERIES 51	S51-110MV-1
83011706	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A5-C2-N-D6-H-G1-H3-K-33-K-25-C-L-28-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83011707	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-N-A2-C2-N-D1-F-G1-H2-33-33-33-33-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83011708	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-BC-80-L-4-F1-H-00-EEB-38-14-24	SERIES 90	S90-130PV
83011709	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-A-T-B-B-AA-A-A-BDD-CD-A-JJ-5-NNN-***	M46	M46-046PV
83011710	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-D-E1A7-00-B-D-B-2-G-N-N-28-28-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83011711	PUMP-VAR-DISPL CCW 90PV180	90L180-KN-1-NN-80-D-M-F1-L-03-FAC-35-35-24	SERIES 90	S90-180PV
83011722	PUMP-VAR-DISPL CCW 90PV130	90L130-HF-5-CD-80-D-4-F1-L-03-GBA-35-35-24	SERIES 90	S90-130PV
83011724	PUMP-VAR-DISPL CCW 90PV130	90L130-HF-5-BC-80-D-4-F1-L-03-GBA-35-35-24	SERIES 90	S90-130PV
83011727	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-BC-80-S-4-C7-E-02-GBA-35-35-24	SERIES 90	S90-100PV
83011729	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-BC-60-S-3-S1-C-04-GBA-42-42-24	SERIES 90	S90-055PV
83011730	PUMP-TANDEM, VAR DISPL CCW H1T045L	H1-T-045-L-A-N-A5-C2-N-E7-F-G5-NN-28-28-28-28-N-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT

83011736	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A5-C1-N-D8-F-G5-H5-L-33-L-33-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83011743	PUMP-VAR-DISPL CCW 90PV130	90L130-KN-5-CD-80-D-4-F1-L-03-GBA-35-35-24	SERIES 90	S90-130PV
83011746	MOTOR-VAR-DISPL 51MD110-1	51D110-1--A-D4-N-E2-B1-N-N-U1-NNN-060-AA-F3-00-00	SERIES 51	S51-110MV-1
83011747	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-D-S-B-J-AA-J-A-BBB-CG-A-JJ-B-NNN-***	M46	M46-046PV
83011748	MOTOR-FIX DISPL MMF044D	MMF-044-D-A-N-H-A-B-NNN-***	M35/44	044MF
83011752	PUMP-VAR DISPL MPV035D	MPV-035-D-B-A-G-R-S-G-AA-A-A-BEE-DL-A-FF-A-NNN-***	M35/44	035PV
83011754	MOTOR-VAR-DISPL 51MD110-1	51D110-1--A-D4-N-T2-D2-N-N-X1-ABA-029-AA-F0-00-20	SERIES 51	S51-110MV-1
83011757	MOTOR-VAR DISPL MMV046C	MMV-046-C-A-A-B-C-AY-NNN-***	M46	M46-046MV
83011763	MOTOR-VAR-DISPL H1B160#	H1-B-160-A-E2-AA-N-B-TB-VS-ES-S-A-15-NN-076-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83011778	PUMP-VAR-DISPL CCW 90PV100	90L100-KN-5-NN-80-R-4-C7-E-03-GBA-29-29-26-F023	SERIES 90	S90-100PV
83011780	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-NN-80-R-4-C7-E-03-GBA-29-29-26-F023	SERIES 90	S90-100PV
83011782	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-AB-60-S-4-S1-E-03-GBA-29-29-24	SERIES 90	S90-075PV
83011783	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A3-C2-B-E6-F-G5-NN-L-28-L-28-B-L-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83011784	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-BC-80-P-3-F1-H-04-GBA-38-38-24	SERIES 90	S90-130PV
83011786	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-AB-80-S-4-F1-F-03-EEB-29-29-24	SERIES 90	S90-130PV
83011787	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-HZ-B1-A-N-G0-NNN-050-AA-NN-03-00	SERIES 51	S51-160MV
83011788	PUMP-VAR-DISPL CW 90PV250	90R250-KP-1-CD-80-T-3-C8-J-03-NNN-40-40-24	SERIES 90	S90-250PV
83011789	PUMP-VAR-DISPL CW 90PV180	90R180-KP-1-CD-80-T-M-F1-H-03-FAC-36-36-24	SERIES 90	S90-180PV
83011795	PUMP-VAR DISPL, CW 90PV055	90-R-055-KT-1-CD-80-P-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-055PV
83011798	MOTOR- VARIABLE CARTRIDGE L	L-C-25CN-A-YNF-F01-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83011801	MOTOR-VAR-DISPL H1B110	H1-B-110-A-L1-BA-N-A-PB-VN-EN-N-N-NN-022-N-00-NNN	H1-HP MOTORS	H1-110MB1
83011812	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-5-NN-60-P-4-S1-D-G4-GBA-35-35-20	SERIES 90	S90-055PV
83011813	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-N-N1-NN-N-N-U1-ANA-030-AA-NN-00-00	SERIES 51	S51-060MV-1
83011817	PUMP-VAR DISPL, CW 90PV075	90-R-075-DD-1-CD-80-L-4-K2-E-GB-GBA-20-20-24	SERIES 90	S90-075PV
83011824	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-N-A2-C2-N-E7-F-G1-TN-35-35-35-35-M-P-20-PN-NNN-S02	H1-MP PUMPS	H1-045PT/053PT
83011825	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-BB-80-P-4-S1-E-03-GBA-20-20-24	SERIES 90	S90-100PV
83011829	PUMP-TANDEM, VAR DISPL MPT025C	MPT-025-C-S-R-A-3-NN-B-A-A-A-BHH-DR-A-FF-B-C-A-A-BHH-DR-A-FF-A-NNN-*	LIGHT DUTY	025PT
83011837	PUMP-VAR-DISPL CW 90PV180	90R180-HS-5-CD-80-S-M-F1-J-03-NNN-42-42-24	SERIES 90	S90-180PV
83011838	PUMP-VAR-DISPL CW 90PV130	90R130-KP-1-AB-80-S-4-C8-F-03-GBA-35-35-24	SERIES 90	S90-130PV
83011839	MOTOR-VAR-DISPL H1B110	H1-B-110-A-K1-KA-N-A-RB-VN-EN-N-A-10-NN-065-N-20-NNN	H1-HP MOTORS	H1-110MB1
83011850	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-BC-80-S-4-C8-H-04-GBA-42-42-24	SERIES 90	S90-130PV
83011873	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-B8-C2-C-D3-K-F1-H3-L-35-L-35-F-M-24-P2-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83011874	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A5-C2-N-D3-G-G2-H4-L-35-L-35-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83011875	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A5-C2-N-D3-G-G3-H6-L-35-L-35-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83011876	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-1-AB-80-P-4-S1-C-00-GBA-14-14-24	SERIES 90	S90-055PV
83011882	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-CD-80-R-3-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV

83011889	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-G3AN-52-P-D-G-2-F-1-A-21-21-B-1-1-NNN-NNN	SERIES 42	S42-028PV/032PV
83011890	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-ANN3-03-A-N-A-2-F-N-B-23-23-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83011892	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-A-A5-C2-N-F4-H-G9-H6-L-35-L-35-M-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83011893	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A2-C2-N-F4-H-G9-H6-K-35-K-35-C-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83011894	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A2-C2-N-D3-H-G1-H3-K-35-K-35-C-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83011895	MOTOR-VAR-DISPL H1B110	H1-B-110-A-K1-KA-N-A-RA-VS-ES-S-A-10-NN-040-N-25-NNN	H1-HP MOTORS	H1-110MB1
83011906	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A4-C2-N-E6-F-G5-H2-L-25-L-25-B-L-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83011909	MOTOR-VAR-DISPL H1B060	H1-B-060-A-E2-AA-N-B-TA-VS-AS-S-A-05-NN-030-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83011910	PUMP-VAR-DISPL CW 90PV075	90R075-MA-5-CD-80-S-3-C7-D-C6-GBA-45-45-24	SERIES 90	S90-075PV
83011911	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-TA-C2-L-N-G0-NNN-100-AA-F0-00-B8	SERIES 51	S51-160MV
83011921	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-2-CD-60-R-3-T2-E-03-FBA-45-45-36	SERIES 90	S90-100PV
83011922	PUMP-VAR DISPL, CW 90PV100	90-R-100-LE-2-BC-60-R-3-S1-E-03-FBA-45-45-36	SERIES 90	S90-100PV
83011931	PUMP-VAR-DISPL CCW 90PV100	90L100-MA-1-BB-80-L-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83011933	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-5-NN-80-S-4-K3-F-00-GBA-26-26-24	SERIES 90	S90-100PV
83011942	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-A-A4-C2-N-D3-H-F1-H3-L-30-L-30-M-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83011962	MOTOR-VAR-DISPL H1B080	H1-B-080-A-E2-AA-N-A-TA-CN-JN-N-A-10-NN-040-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83011963	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-E2-A5-A-N-G0-ANB-200-AA-G3-03-00	SERIES 51	S51-250MV
83011977	PUMP-VAR-DISPL CW 90PV180	90R180-KN-5-BC-80-D-M-F1-L-03-FAC-35-35-24	SERIES 90	S90-180PV
83011979	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A4-C2-B-D8-H-G1-H2-L-42-L-42-D-P-20-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83011983	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-2-CD-80-D-3-C6-L-00-GFD-45-45-34-P020	SERIES 90	S90-075PV
83011984	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-2-BC-80-D-3-S1-L-00-GFD-45-45-34-P020	SERIES 90	S90-075PV
83011985	PUMP-VAR DISPL, CW 90PV100	90-R-100-HS-1-CD-80-R-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83011990	PUMP-VAR-DISPL CCW H1PV130	H1-P-130-L-B-B8-C2-D-D8-L-G2-H3-L-38-L-38-L-P-32-P2-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83011992	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-CD-80-S-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83011994	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-TH-C2-L-N-G0-ADA-111-AA-H0-00-C7	SERIES 51	S51-250MV
83011997	PUMP-VAR-DISPL CW 90PV075	90R075-DD-2-NN-80-R-4-S1-C-GB-GBA-38-38-24	SERIES 90	S90-075PV
83012008	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-C7-N-T2-D2-N-N-X1-AWM-035-AA-NN-00-37	SERIES 51	S51-080MV-1
83012011	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-2-AB-80-S-3-C6-D-04-GBA-38-38-20	SERIES 90	S90-055PV
83012018	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-EQ-A5-J-Y-G5-ACA-090-AA-G0-20-00	SERIES 51	S51-160MV
83012019	PUMP-VAR-DISPL CW 90PV130	90R130-KA-1-BC-80-R-4-F1-H-03-GBA-35-35-24	SERIES 90	S90-130PV
83012032	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-CD-80-P-3-C8-H-03-EFC-35-35-24	SERIES 90	S90-130PV
83012043	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-TH-C2-L-N-G0-NNN-177-AA-NN-00-B0	SERIES 51	S51-250MV
83012050	PUMP-VAR-DISPL CCW 90PV180	90L180-HF-1-NN-80-T-M-F1-J-00-NNN-42-42-24	SERIES 90	S90-180PV
83012052	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-NN-80-T-3-C8-K-03-NNN-32-32-30	SERIES 90	S90-250PV
83012053	MOTOR-VAR-DISPL 51MD080-1	51D080-1--R-D2-N-TA-D2-N-N-X1-NNN-016-AA-G3-00-33	SERIES 51	S51-080MV-1
83012061	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-CD-80-P-3-C7-E-00-GBA-42-42-24	SERIES 90	S90-075PV

83012062	MOTOR-VAR-DISPL H1B080	H1-B-080-A-E2-AA-N-A-TB-CS-JS-S-A-10-NN-028-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83012067	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-1-NN-80-L-3-F1-H-03-GBA-35-35-24	SERIES 90	S90-130PV
83012068	PUMP-VAR-DISPL CW 90PV180	90R180-CB-5-NN-80-S-C-F1-H-00-FAC-42-42-28-P000	SERIES 90	S90-180PV
83012069	PUMP-VAR-DISPL CCW 90PV180	90L180-CB-5-NN-80-S-C-F1-H-00-FAC-42-42-28-P000	SERIES 90	S90-180PV
83012071	PUMP-VAR-DISPL CW 90PV130	90R130-HF-5-BC-80-S-4-F1-F-03-GBA-35-35-24	SERIES 90	S90-130PV
83012072	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-CD-80-P-3-S1-E-00-GBA-42-42-24	SERIES 90	S90-100PV
83012073	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-NN-80-P-3-S1-F-00-GBA-42-42-24	SERIES 90	S90-100PV
83012077	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-C-E1A3-03-B-3-B-3-F-N-N-17-17-N-N-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83012078	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-D-E1A3-03-B-3-B-3-F-N-B-17-17-N-A-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83012081	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D2-N-N1-NN-N-N-U1-ABA-026-AA-NN-00-00	SERIES 51	S51-080MV-1
83012083	MOTOR-VAR-DISPL H1B110	H1-B-110-A-L1-BA-N-A-PA-DS-JS-S-A-10-NN-026-N-00-NNN	H1-HP MOTORS	H1-110MB1
83012084	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-8-N-0-C7-W-00-EAA-00-00-G0	SERIES 90	S90-100MF
83012085	PUMP-VAR-DISPL CW 90PV130	90R130-KN-5-NN-80-D-4-F1-L-03-GBA-35-35-28	SERIES 90	S90-130PV
83012088	PUMP-VAR-DISPL CW 90PV180	90R180-KA-1-CD-80-T-M-F1-H-03-NNN-23-23-24	SERIES 90	S90-180PV
83012094	PUMP-VAR-DISPL CCW 90PV100	90L100-HS-1-CD-60-R-4-S1-E-03-GBA-38-38-24	SERIES 90	S90-100PV
83012095	PUMP-VAR-DISPL CCW 90PV075	90L075-HS-1-NN-80-R-4-S1-E-03-GBA-38-38-24	SERIES 90	S90-075PV
83012099	MOTOR-VAR DISPL MMV046C	MMV-046-C-A-A-D-A-A4-NNN-***	M46	M46-046MV
83012100	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-E2-A5-A-N-G0-NNN-055-AA-F0-03-00	SERIES 51	S51-160MV
83012102	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-1-AB-80-P-4-S1-C-G8-GBA-35-35-20	SERIES 90	S90-055PV
83012103	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-NN-80-P-4-C8-H-03-GBA-42-42-24	SERIES 90	S90-130PV
83012104	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-NN-80-T-M-C8-J-03-NNN-42-42-24	SERIES 90	S90-180PV
83012105	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-1-NN-60-P-4-S1-C-GB-GBA-42-42-24	SERIES 90	S90-055PV
83012106	PUMP-VAR DISPL, CW 90PV055	90-R-055-HS-1-CD-80-R-3-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83012107	PUMP-VAR DISPL, CW 90PV055	90-R-055-HS-1-NN-80-R-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83012108	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-1-NN-80-P-3-S1-C-03-GBA-32-32-24	SERIES 90	S90-055PV
83012109	PUMP-VAR-DISPL CW 90PV075	90R075-MA-1-NN-60-L-3-S1-D-03-GBA-32-32-24	SERIES 90	S90-075PV
83012110	PUMP-VAR-DISPL CW 90PV100	90R100-MB-1-CD-60-L-3-C7-F-03-GBA-42-42-24	SERIES 90	S90-100PV
83012111	PUMP-VAR-DISPL CW 90PV100	90R100-M8-1-NN-60-P-3-C7-E-03-GBA-40-40-24	SERIES 90	S90-100PV
83012112	PUMP-VAR-DISPL CCW 90PV100	90L100-KP-1-NN-80-P-3-S1-E-02-GBA-42-42-24	SERIES 90	S90-100PV
83012113	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-E2D8-03-D-N-F-2-F-N-B-28-28-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83012114	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-E2D8-03-D-N-F-2-F-N-A-28-28-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83012116	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A4-C2-N-D1-F-G1-H3-35-35-35-35-N-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83012118	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-AB-80-P-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
83012121	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-CD-60-L-4-C7-E-03-GBA-30-30-30	SERIES 90	S90-100PV
83012132	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-CD-60-L-4-S1-D-03-GBA-23-23-30	SERIES 90	S90-075PV
83012134	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-T4-C0-L-N-G0-NNN-079-AA-G0-00-B5	SERIES 51	S51-250MV

83012135	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-N2-NN-N-N-A0-NNN-075-AA-G3-00-00	SERIES 51	S51-160MV
83012136	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-2-CD-80-D-3-C6-L-00-GLA-45-45-34	SERIES 90	S90-075PV
83012137	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-2-BC-80-D-4-S1-L-00-GLA-35-35-34-F070	SERIES 90	S90-075PV
83012138	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-2-BC-80-D-3-S1-L-00-GLA-45-45-34	SERIES 90	S90-075PV
83012139	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-2-CD-80-D-4-C6-L-00-GLA-35-35-34-F070	SERIES 90	S90-075PV
83012141	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-1-NN-80-L-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83012144	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-NN-80-R-4-C7-F-03-GBA-32-32-30	SERIES 90	S90-100PV
83012145	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-NN-80-P-3-C7-E-03-GBA-38-38-24	SERIES 90	S90-100PV
83012146	PUMP-VAR-DISPL CW 90PV130	90R130-MA-5-BC-80-L-3-F1-F-C5-GBA-42-42-28	SERIES 90	S90-130PV
83012147	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A8-C2-C-D8-H-F1-H3-K-35-K-35-C-P-24-P1-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83012148	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-B8-C2-C-D8-H-F1-H3-K-35-K-35-C-P-24-P1-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83012149	PUMP-VAR-DISPL CW 90PV100	90R100-HS-1-CD-80-R-3-F1-F-03-GBA-35-29-24	SERIES 90	S90-100PV
83012150	PUMP-VAR-DISPL CW 90PV100	90R100-M8-1-BC-80-L-4-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83012151	PUMP-VAR-DISPL CW 90PV100	90R100-KP-1-CD-60-L-3-C7-F-03-GBA-23-23-24	SERIES 90	S90-100PV
83012159	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-CD-60-S-4-C7-D-03-GBA-30-30-24	SERIES 90	S90-075PV
83012160	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-NN-60-S-4-S1-D-03-GBA-26-26-24	SERIES 90	S90-075PV
83012172	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HF-1-AB-60-R-3-F1-E-00-GBA-29-29-24	SERIES 90	S90-100PV
83012173	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HF-1-NN-60-L-3-F1-E-03-GBA-29-29-24	SERIES 90	S90-100PV
83012175	MOTOR-VAR-DISPL H1B060	H1-B-060-A-E1-AA-N-B-TB-VN-AN-N-N-NN-NN-031-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83012177	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-1-NN-80-L-3-F1-H-03-GBA-35-35-24	SERIES 90	S90-130PV
83012178	MOTOR-VAR-DISPL 51MV110	51V110-A-F1-N-HS-A2-C-E-G6-NNN-046-AA-NN-18-21	SERIES 51	S51-110MV
83012180	MOTOR-VAR-DISPL H1B060	H1-B-060-A-L2-BA-N-B-PB-CS-GS-S-A-05-NN-025-N-00-NNN	H1-HP MOTORS	H1-060MB1
83012181	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-AB-60-P-4-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83012182	PUMP-VAR-DISPL CW 90PV100	90R100-MA-1-BC-60-L-3-S1-E-03-GBA-32-32-24	SERIES 90	S90-100PV
83012183	PUMP-VAR-DISPL CW 90PV100	90R100-KP-1-CD-80-P-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83012184	PUMP-VAR-DISPL CW 90PV100	90R100-KP-1-CD-80-P-3-S1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
83012185	PUMP-VAR-DISPL CCW 90PV100	90L100-HS-1-CD-80-S-3-C7-E-03-GBA-29-29-24	SERIES 90	S90-100PV
83012186	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-1-NN-80-P-4-S1-C-GB-GBA-38-38-20	SERIES 90	S90-055PV
83012187	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A5-C2-N-D6-H-G9-H3-L-38-L-38-C-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83012188	MOTOR-VAR-DISPL H1B080	H1-B-080-A-K2-KA-N-A-RB-VS-AS-S-A-05-NN-016-N-30-NNN	H1-HP MOTORS	H1-080MB1
83012196	MOTOR-VAR-DISPL H1B160	H1-B-160-A-L2-BA-N-B-PA-VS-DS-S-A-20-NN-000-N-00-NNN	H1-HP MOTORS	H1-160MB1
83012197	MOTOR-VAR-DISPL H1B160	H1-B-160-A-K2-K2-N-B-RA-VS-DS-S-A-15-NN-000-N-36-NNN	H1-HP MOTORS	H1-160MB1
83012205	PUMP-VAR-DISPL CCW H1PV089	H1-P-089-L-A-A5-C2-N-D8-H-G1-H1-K-33-K-33-M-P-30-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83012214	MOTOR-VAR DISPL MMV046C	MMV-046-C-A-A-4-Y-AF-NNN-***	M46	M46-046MV
83012222	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-BC-80-R-3-S1-D-03-GBA-23-23-30	SERIES 90	S90-100PV
83012224	PUMP-VAR-DISPL CW 90PV130	90R130-KA-1-NN-80-L-4-F1-H-03-GBA-26-26-24	SERIES 90	S90-130PV

83012228	MOTOR-VARIABLE DISPL SAE_L	L-V-25CS-A-YNF-F01-S-N-N-BF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83012229	MOTOR-VAR-DISPL 51MV060	51V060-R-S1-N-HZ-B1-B-E-G5-NNN-020-AA-E6-05-00	SERIES 51	S51-060MV
83012234	PUMP-VAR DISPL MPV025C	MPV-025-C-B-A-A-W-A-F-NN-A-A-BMM-DR-A-FF-A-NNN-***	LIGHT DUTY	025PV
83012236	PUMP-VAR DISPL MPV025C	MPV-025-C-B-A-Y-R-A-E-NN-A-A-BMM-DR-A-FF-A-NNN-***	LIGHT DUTY	025PV
83012237	MOTOR-VARIABLE DISPL SAE_K	K-V-38CS-A-YNF-F09-S-N-N-BF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83012247	PUMP-VAR-DISPL CW 90PV250	90R250-KP-1-DE-80-T-4-C8-J-03-NNN-42-42-24	SERIES 90	S90-250PV
83012249	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-NN-80-L-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-075PV
83012250	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-BC-80-L-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-075PV
83012252	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-C7-N-E2-B1-N-N-U1-NNN-025-AA-F0-00-00	SERIES 51	S51-080MV-1
83012253	MOTOR-VAR-DISPL 51MD110-1	51D110-1--R-D4-N-T1-C2-N-N-X1-NNN-028-AA-F0-00-37	SERIES 51	S51-110MV-1
83012255	PUMP-VAR-DISPL CW 90PV130	90R130-PB-5-DG-80-L-3-C8-H-03-GBA-35-35-24	SERIES 90	S90-130PV
83012256	PUMP-VAR-DISPL CW 90PV130	90R130-PB-5-BB-80-L-3-C8-H-03-GBA-35-35-24	SERIES 90	S90-130PV
83012258	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-HZ-B1-B-H-G5-NNN-080-AA-NN-07-00	SERIES 51	S51-250MV
83012263	PUMP-VAR DISPL, CW 90PV075	90-R-075-KT-1-BC-80-L-4-K2-D-03-GBA-34-34-24	SERIES 90	S90-075PV
83012264	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-CD-80-P-3-C7-E-03-GBA-26-26-28	SERIES 90	S90-100PV
83012278	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-E1A5-03-A-N-A-2-D-N-A-14-14-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83012295	PUMP-VAR DISPL, CW 90PV100	90-R-100-KF-1-BB-80-R-3-S1-D-00-GBA-38-38-24	SERIES 90	S90-100PV
83012297	MOTOR- VARIABLE CARTRIDGE L	L-C-25CS-E-RNF-F09-S-N-N-BF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83012299	MOTOR-VAR-DISPL H1B110#	H1-B-110-A-T2-D2-N-B-TB-VN-DN-N-A-15-NN-072-Z-28-NNN	H1-HP MOTORS	H1-110MB1
83012301	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-AC-80-L-4-F1-E-03-GBA-14-14-24	SERIES 90	S90-100PV
83012308	MOTOR-VAR-DISPL 51MC160	51C160-R-D4-N-Y8-B1-R-J-J1-ACM-045-AA-G3-C2-00	SERIES 51	S51-160MV
83012313	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-1-AB-60-P-4-S1-C-GB-GBA-35-35-20	SERIES 90	S90-055PV
83012314	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A5-C2-N-D6-F-G5-NN-L-35-L-35-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83012316	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-1-AB-80-S-4-S1-C-G8-GBA-32-32-20	SERIES 90	S90-055PV
83012317	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-1-NN-80-P-4-S1-C-GB-GBA-38-38-24	SERIES 90	S90-055PV
83012318	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-1-AB-60-P-4-S1-C-GB-GBA-35-35-20	SERIES 90	S90-055PV
83012319	PUMP-VAR-DISPL CCW 90PV075	90L075-KP-1-NN-80-P-3-C6-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83012324	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-NN-80-S-3-C8-F-05-GBA-38-38-28	SERIES 90	S90-130PV
83012325	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MA-1-NN-80-S-4-F1-E-02-GBA-35-35-24	SERIES 90	S90-100PV
83012326	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-D8-M1-R-J-N1-ANB-050-AA-F3-C2-18	SERIES 51	S51-250MV
83012332	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A3-C1-N-D8-H-F1-NN-L-40-L-40-C-P-20-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83012333	PUMP-VAR-DISPL CCW 90PV180	90L180-HF-5-BC-80-S-C-C8-J-03-NNN-32-32-28	SERIES 90	S90-180PV
83012334	PUMP-VAR-DISPL CW 90PV130	90R130-HF-5-AB-80-L-3-F1-H-03-GBA-32-32-28	SERIES 90	S90-130PV
83012335	PUMP-VAR-DISPL CW 90PV180	90R180-HF-5-DE-80-S-C-C8-J-03-NNN-42-42-28	SERIES 90	S90-180PV
83012338	PUMP-VAR-DISPL CW 90PV100	90R100-FC-5-BC-80-S-7-C7-F-B1-EFI-42-42-26	SERIES 90	S90-100PV
83012339	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-BB-80-T-4-C8-K-03-NNN-21-30-24	SERIES 90	S90-250PV

83012341	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-AB-80-R-4-T4-F-03-GBA-35-35-24	SERIES 90	S90-130PV
83012350	PUMP-VAR-DISPL CW 90PV100	90R100-MB-1-CD-60-P-3-F1-E-03-GBA-40-40-24	SERIES 90	S90-100PV
83012351	PUMP-VAR-DISPL CW 90PV075	90R075-DD-1-NN-80-P-4-S1-D-GB-GBA-35-35-24	SERIES 90	S90-075PV
83012352	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-1-NN-60-S-3-C7-E-03-GBA-23-23-24	SERIES 90	S90-100PV
83012353	PUMP-VAR-DISPL CW 90PV100	90R100-MA-1-NN-60-P-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83012354	PUMP-VAR-DISPL CCW 90PV100	90L100-KP-1-CD-80-P-3-S1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
83012355	PUMP-VAR-DISPL CCW 90PV100	90L100-KP-1-CD-80-P-3-C7-F-03-GBA-35-35-24	SERIES 90	S90-100PV
83012356	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-E1A6-11-C-2-A-2-F-N-B-25-25-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83012358	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-CD-80-T-4-F1-J-03-NNN-14-14-24	SERIES 90	S90-250PV
83012363	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-NN-80-R-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
83012364	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-NN-60-S-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
83012365	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-HZ-B1-B-H-C2-NNN-080-AA-NN-07-00	SERIES 51	S51-250MV
83012366	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-G-T-B-B-AA-A-A-BHH-DA-A-YA-C-NNN-***	M46	M46-046PV
83012367	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-AB-80-L-4-T7-H-03-GBA-35-35-24	SERIES 90	S90-130PV
83012368	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-BC-80-S-3-S1-D-00-GBA-20-20-20	SERIES 90	S90-075PV
83012369	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-CD-80-S-3-C6-D-00-GBA-29-29-20	SERIES 90	S90-075PV
83012370	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HF-1-BC-80-R-3-S1-C-00-GBA-23-23-24	SERIES 90	S90-055PV
83012371	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-CD-80-R-3-S1-C-03-GBA-41-41-24	SERIES 90	S90-075PV
83012372	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A5-C2-B-F5-H-G1-H6-K-30-K-30-D-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83012382	MOTOR-VAR-DISPL 51MV080-1	51V080-1--A-S1-N-E1-B1-N-N-U1-NNN-054-AA-E6-00-00	SERIES 51	S51-080MV-1
83012385	PUMP-VAR-DISPL CW 90PV100	90R100-HF-1-BC-60-S-4-F1-E-03-GBA-20-20-20	SERIES 90	S90-100PV
83012386	PUMP-VAR-DISPL CW 90PV075	90R075-HF-1-BC-80-S-4-S1-D-03-GBA-35-35-20	SERIES 90	S90-075PV
83012390	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-NN-80-R-3-F1-F-03-GBA-35-35-34	SERIES 90	S90-130PV
83012391	PUMP-VAR DISPL, CW 90PV055	90-R-055-HS-1-BC-80-S-3-S1-C-02-GBA-42-42-24	SERIES 90	S90-055PV
83012392	PUMP-VAR-DISPL 42PV041 CW	42-R-51-D-A1NB-03-D-N-F-3-H-N-B-34-34-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83012395	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A5-C2-N-E5-F-G1-H5-L-35-L-35-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83012396	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A5-C2-N-E5-F-G5-NN-L-35-L-35-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83012397	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-5-CD-80-L-3-K3-E-02-GBA-14-14-24	SERIES 90	S90-100PV
83012398	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-5-NN-80-L-3-S1-E-02-GBA-14-14-24	SERIES 90	S90-100PV
83012399	PUMP-VAR DISPL MPV046C	MPV-046-C-B-A-B-S-B-B-BA-A-B-BFF-AB-D-AA-A-NNN-***	M46	M46-046PV
83012401	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-1-BB-60-S-4-S1-C-03-GBA-20-20-24	SERIES 90	S90-055PV
83012404	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-5-NN-80-P-4-S1-E-26-GBA-23-23-24	SERIES 90	S90-075PV
83012409	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-N2-NN-N-N-A0-ACA-075-AA-G3-00-00	SERIES 51	S51-160MV
83012410	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-NN-60-S-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83012411	MOTOR-VAR-DISPL H1B080	H1-B-080-A-E2-AA-N-B-TA-CS-JS-S-A-10-NN-030-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83012412	PUMP-TANDEM, VAR DISPL CCW H1T053L	H1-T-053-L-A-N-A4-C1-B-E7-F-G5-TN-28-28-28-28-M-P-20-PN-NNN-S01	H1-MP PUMPS	H1-045PT/053PT

83012427	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A5-C2-N-D8-F-G4-NN-L-23-L-23-B-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83012434	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KT-P-CD-80-D-3-C7-L-03-GBA-45-45-24	SERIES 90	S90-075PV
83012435	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KT-P-NN-80-D-3-S1-L-03-GBA-45-45-24	SERIES 90	S90-075PV
83012437	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-N-L8-B1-V-A-G5-AWU-032-AA-F3-B2-00	SERIES 51	S51-160MV
83012438	PUMP-VAR-DISPL CCW 90PV130	90L130-KN-5-NN-80-R-3-F1-F-03-EEB-20-20-24	SERIES 90	S90-130PV
83012440	PUMP-VAR-DISPL CW 90PV130	90R130-MA-5-CD-80-L-4-C8-H-C5-GBA-35-35-28	SERIES 90	S90-130PV
83012441	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-A-B7-C2-C-F6-K-G9-H6-L-43-L-43-D-L-24-P2-NNN-D5F	H1-HP PUMPS	H1-089PV/100PV
83012447	PUMP-VAR-DISPL CCW 90PV100	90L100-DD-5-NN-60-P-4-S1-E-GB-GBA-30-30-24	SERIES 90	S90-100PV
83012448	PUMP-VAR DISPL MPV044D	MPV-044-D-B-A-A-Y-S-E-AA-A-A-BJJ-DL-A-FF-A-NNN-***	M35/44	044PV
83012450	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A5-C2-N-F4-H-G1-H6-L-30-L-30-C-M-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83012452	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-NN-60-S-4-C7-E-03-GBA-26-26-20-F023	SERIES 90	S90-100PV
83012454	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-BC-80-L-4-S1-D-03-GBA-29-29-24	SERIES 90	S90-055PV
83012456	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HF-1-NN-60-L-3-F1-E-00-GBA-29-29-24	SERIES 90	S90-100PV
83012459	PUMP-TANDEM, VAR DISPL MPT035D	MPT-035-D-A-W-A-A-NN-C-A-A-A-BJJ-DR-A-FF-C-C-A-A-BJJ-DL-A-FF-1-NNN-***	M35/44	035PT
83012460	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KE-1-BC-80-R-3-F1-E-26-GBA-32-32-24	SERIES 90	S90-100PV
83012464	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-NN-80-S-4-S1-C-03-GFD-42-14-24	SERIES 90	S90-055PV
83012465	PUMP-VAR DISPL, CW 90PV075	90-R-075-DC-1-NN-80-S-4-S1-D-G8-GFD-35-21-24	SERIES 90	S90-075PV
83012470	MOTOR-VAR-DISPL H1B110	H1-B-110-A-L2-BA-N-A-PA-DN-JN-N-A-10-NN-022-N-00-NNN	H1-HP MOTORS	H1-110MB1
83012472	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-1-BC-80-R-3-F1-H-03-GBA-26-26-24	SERIES 90	S90-130PV
83012473	MOTOR-VAR-DISPL H1B080	H1-B-080-A-E1-AA-N-A-TB-DN-JN-N-N-NN-040-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83012474	MOTOR-VAR-DISPL H1B080	H1-B-080-A-E1-AA-N-A-TB-DN-JN-N-A-05-NN-040-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83012475	MOTOR-VAR-DISPL H1B060	H1-B-060-A-L1-BA-N-B-PA-DS-GS-S-N-NN-030-N-00-NNN	H1-HP MOTORS	H1-060MB1
83012476	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A2-C3-N-D6-H-G1-NN-L-28-L-28-F-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83012479	PUMP-VAR-DISPL CCW 90PV130	90L130-KN-5-BC-80-L-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-130PV
83012490	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-CD-80-P-3-C7-E-03-EAB-42-42-24	SERIES 90	S90-100PV
83012491	MOTOR-VAR-DISPL 51MC080-1	51C080-1--A-D3-N-E0-B1-N-N-U1-ADA-030-AA-F3-00-00	SERIES 51	S51-080MV-1
83012492	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-HZ-B1-C-H-C2-NNN-016-AA-G0-20-00	SERIES 51	S51-080MV
83012493	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-B8-C2-C-D6-H-F1-H3-L-42-L-42-D-L-28-P1-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83012494	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-1-CD-80-P-3-S1-D-03-GBA-38-38-24	SERIES 90	S90-055PV
83012495	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-NN-80-R-3-G1-E-05-FAP-35-35-30	SERIES 90	S90-075PV
83012497	PUMP-VAR-DISPL CW 90PV130	90R130-MA-2-NN-80-D-3-F1-L-05-GBA-45-45-32	SERIES 90	S90-130PV
83012498	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-N-B1-C3-N-E7-F-G5-NN-30-30-30-30-N-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83012515	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A5-C2-N-D6-F-G1-H5-L-30-L-30-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83012517	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-5-BC-80-R-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83012518	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-5-CD-80-R-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83012519	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-BC-80-P-3-F1-F-00-GBA-32-32-24	SERIES 90	S90-130PV

83012520	PUMP-VAR-DISPL 42PV041 CCW	42-L-41-E-E2D8-03-B-D-B-3-H-N-A-32-32-B-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83012521	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D3-N-N1-NN-N-N-U1-NNN-045-AA-F3-00-00	SERIES 51	S51-080MV-1
83012522	PUMP-VAR-DISPL CW 90PV075	90R075-MA-5-BC-60-L-4-C7-D-C6-GBA-32-32-24	SERIES 90	S90-075PV
83012523	PUMP-VAR-DISPL CW 90PV130	90R130-MA-5-AB-80-L-4-C8-F-C6-GBA-29-29-24	SERIES 90	S90-130PV
83012529	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-5-NN-80-T-3-C8-K-03-NNN-35-35-24	SERIES 90	S90-250PV
83012534	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-BC-60-R-3-C7-D-03-GBA-40-40-24	SERIES 90	S90-075PV
83012535	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A5-C2-N-D3-G-F3-NN-L-25-L-25-A-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83012536	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-E-V-C-S-AA-B-A-G-A-BHH-GG-B-KF-B-C-G-A-BHH-GG-B-KF-B-NNN-3	M46	M46-046PT
83012552	PUMP-VAR-DISPL CW 90PV075	90R075-M8-1-BC-60-R-3-C7-D-03-GBA-40-40-24	SERIES 90	S90-075PV
83012553	MOTOR-VAR-DISPL 51MV080-1	51V080-1--A-C7-N-E2-B1-N-N-U1-ACB-054-AA-E6-00-00	SERIES 51	S51-080MV-1
83012558	MOTOR-VARIABLE DISPL SAE_K	K-V-38CN-A-RNF-F01-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83012559	MOTOR-VARIABLE DISPL SAE_K	K-V-38CS-A-RNF-F01-S-N-N-BF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83012574	PUMP-VAR-DISPL CW 90PV075	90R075-DD-1-BC-60-P-4-S1-D-G8-GBA-42-42-24	SERIES 90	S90-075PV
83012579	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A8-C2-C-D6-F-G1-H1-L-23-L-23-B-L-20-P1-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83012580	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A5-C2-N-F4-H-G9-H6-L-38-L-38-M-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83012586	PUMP-VAR-DISPL CW 90PV250	90R250-KP-5-CD-80-T-3-F1-K-03-NNN-32-32-24	SERIES 90	S90-250PV
83012587	PUMP-TANDEM, VAR DISPL CCW H1T053L	H1-T-053-L-A-N-A4-C2-N-E7-F-G1-H3-35-35-35-35-N-P-30-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83012588	PUMP-VAR DISPL CCW H1P053L	H1-P-053-L-A-A4-C2-N-E9-F-G5-NN-K-35-K-35-N-P-30-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83012589	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A2-C2-N-E7-F-G1-TN-35-35-35-35-M-P-32-PN-NNN-S02	H1-MP PUMPS	H1-045PT/053PT
83012598	MOTOR-VARIABLE DISPL SAE_K	K-V-38CN-A-YNF-F09-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83012601	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-BC-80-P-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83012602	PUMP-VAR-DISPL CW 90PV075	90R075-MA-5-CD-60-L-4-C7-D-C6-GBA-29-29-24	SERIES 90	S90-075PV
83012606	PUMP-VAR DISPL, CW 90PV055	90-R-055-KT-1-BB-80-P-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-055PV
83012608	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-1-AB-60-P-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-075PV
83012609	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-AB-80-S-3-S1-E-03-GBA-40-40-26	SERIES 90	S90-100PV
83012610	MOTOR-VARIABLE DISPL SAE_K	K-V-38CS-C-Y3F-F09-S-N-N-CF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83012611	PUMP-VAR DISPL, CW 90PV100	90-R-100-HF-1-AB-60-P-4-C7-F-02-GBA-26-26-28	SERIES 90	S90-100PV
83012613	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-N-E2-B1-N-N-U1-NNN-030-AA-NN-00-00	SERIES 51	S51-060MV-1
83012621	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-NN-60-R-4-T2-E-03-GBA-29-29-24-F064	SERIES 90	S90-100PV
83012628	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A4-C3-B-E6-F-G5-H3-L-28-L-28-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83012629	MOTOR-VARIABLE DISPL SAE_L	L-V-35ES-A-RNF-F11-S-N-N-CF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83012636	MOTOR-VAR-DISPL H1B060	H1-B-060-A-L2-BA-N-A-PB-DS-GS-S-A-10-NN-000-N-00-NNN	H1-HP MOTORS	H1-060MB1
83012637	MOTOR-VAR-DISPL H1B060	H1-B-060-A-E1-AA-N-A-TA-VN-AN-N-A-10-NN-035-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83012639	MOTOR-VARIABLE DISPL SAE_K	K-V-38CN-C-Y3F-F09-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83012642	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-NN-80-P-3-K3-F-00-GBA-26-26-24	SERIES 90	S90-100PV
83012647	PUMP-VAR-DISPL CCW 90PV075	90L075-DC-5-AB-80-S-4-S1-E-GB-GBA-35-35-24	SERIES 90	S90-075PV

83012652	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-G2A2-50-U-D-B-2-F-1-N-25-25-B-0-0-NNN-NNN	SERIES 42	S42-028PV/032PV
83012659	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-E2-A5-A-N-A6-NNN-032-AA-G0-03-00	SERIES 51	S51-160MV
83012660	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-A-A3-C2-N-D3-H-G9-H3-L-45-L-45-D-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83012665	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-N-TH-C2-L-N-G0-NNN-160-AA-G0-00-C2	SERIES 51	S51-250MV
83012672	PUMP-TANDEM, VAR DISPL MPT025C	MPT-025-C-S-W-A-A-NN-B-A-A-A-BGG-DR-A-FF-B-C-A-A-BGG-DL-A-FF-A-NNN-	LIGHT DUTY	025PT
83012673	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-A-B7-C3-C-D6-K-F1-H3-L-45-L-45-D-L-30-P2-NNN-D5F	H1-HP PUMPS	H1-089PV/100PV
83012674	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-CD-60-R-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-075PV
83012675	PUMP-VAR-DISPL CCW 90PV180	90L180-KP-1-CD-80-T-C-F1-H-03-FAC-29-29-24	SERIES 90	S90-180PV
83012676	MOTOR-VAR-DISPL H1B110	H1-B-110-A-E1-AA-N-B-TA-DN-JN-N-A-15-NN-057-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83012686	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-AB-80-R-4-F1-H-03-GBA-42-42-24	SERIES 90	S90-130PV
83012687	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A2-C2-N-D6-G-G3-H3-K-45-K-45-L-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83012688	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A2-C2-N-D6-G-G3-H4-K-45-K-45-L-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83012690	MOTOR-VAR-DISPL H1B060	H1-B-060-A-T2-D2-N-A-TB-CS-GS-S-A-10-NN-018-Z-23-NNN	H1-HP MOTORS	H1-060MB1
83012691	MOTOR-VAR-DISPL 51MV160	51V160-V-F1-N-HS-A2-C-H-E1-NNN-032-AA-NN-20-21	SERIES 51	S51-160MV
83012693	MOTOR-VAR-DISPL H1B160	H1-B-160-A-M1-CA-N-A-RA-DS-KS-S-A-20-NN-000-N-00-NNN	H1-HP MOTORS	H1-160MB1
83012713	MOTOR-VARIABLE CARTRIDGE K	K-C-45DN-E-R1F-F65-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83012718	PUMP-VAR-DISPL 42PV041 CW	42-R-41-C-ANNB-03-D-N-F-2-F-N-N-23-23-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83012725	PUMP-VAR-DISPL CCW 90PV250	90L250-KP-5-BC-80-T-4-F1-J-03-NNN-35-35-24	SERIES 90	S90-250PV
83012727	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-CD-80-S-3-C8-H-03-GLA-38-38-20	SERIES 90	S90-130PV
83012730	MOTOR-VAR-DISPL H1B110#	H1-B-110-A-E2-AA-N-B-TA-VS-DS-S-A-15-NN-050-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83012734	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-E1A5-03-B-D-B-2-H-N-A-25-25-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83012735	PUMP-VAR-DISPL CW 90PV075	90R075-KP-1-NN-80-P-3-S1-D-03-GBA-29-29-24	SERIES 90	S90-075PV
83012736	PUMP-VAR-DISPL CW 90PV075	90R075-HS-1-CD-80-P-3-C7-E-03-GBA-29-29-24	SERIES 90	S90-075PV
83012739	PUMP-VAR-DISPL CW 90PV250	90R250-KP-5-NN-80-T-4-F1-J-03-NNN-35-35-24	SERIES 90	S90-250PV
83012745	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KT-1-NN-80-S-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83012746	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KT-1-CD-80-S-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83012749	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-G-S-B-B-AA-G-A-BFF-CB-A-HH-C-NNN-***	M46	M46-046PV
83012751	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KT-1-CD-80-S-3-S1-C-02-GBA-42-42-24	SERIES 90	S90-055PV
83012757	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-TA-C2-L-N-G0-NNN-050-AA-E6-00-A3	SERIES 51	S51-250MV
83012759	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-N-B1-C3-B-E7-F-G5-NN-30-30-30-30-N-P-20-PN-NNN-E03	H1-MP PUMPS	H1-045PT/053PT
83012767	PUMP-VAR-DISPL CCW H1PV115	H1-P-115-L-B-A5-C2-B-D8-G-G3-H6-K-25-K-25-A-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83012768	PUMP-VAR-DISPL CCW H1PV130	H1-P-130-L-B-A5-C2-B-D8-G-G3-H3-K-25-K-25-A-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83012769	PUMP-VAR-DISPL CCW H1PV115	H1-P-115-L-B-A5-C2-B-D8-G-G3-H3-K-35-K-35-A-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83012772	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E2-AA-N-B-TB-DN-GN-N-N-NN-NN-030-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83012775	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-E-V-C-S-AA-B-A-C-A-BHH-GG-B-KF-B-C-C-A-BHH-GG-B-KF-B-NNN-*	M46	M46-046PT
83012776	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-E-V-C-S-AA-B-A-B-A-BHH-GG-B-KF-B-C-B-A-BHH-GG-B-KF-B-NNN-*	M46	M46-046PT

83012780	MOTOR- VARIABLE CARTRIDGE L	L-C-30DN-E-RNF-F01-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83012784	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-NN-80-R-3-T4-F-03-GBA-35-35-24	SERIES 90	S90-130PV
83012792	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A5-C1-N-D6-F-G5-H2-L-35-L-35-B-L-32-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83012793	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A5-C1-N-D6-F-G5-H5-L-35-L-35-B-L-32-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83012794	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KT-1-BK-80-S-3-S1-C-02-GBA-42-42-24	SERIES 90	S90-055PV
83012795	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-1-NN-60-L-3-S1-C-03-GBA-35-35-20	SERIES 90	S90-055PV
83012798	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A2-C2-B-D6-G-G2-H3-L-30-L-20-L-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83012799	PUMP-VAR-DISPL CCW H1PV130	H1-P-130-L-B-A3-C3-B-D8-G-G2-NN-L-30-L-30-A-P-20-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83012800	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-NN-80-P-3-C6-C-03-GBA-24-24-24	SERIES 90	S90-055PV
83012801	MOTOR-VARIABLE CARTRIDGE K	K-C-45DS-E-R3F-F09-S-N-N-DF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83012804	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-NN-80-L-3-F1-H-03-GBA-42-42-24	SERIES 90	S90-130PV
83012805	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-CD-80-S-C-C8-J-06-NNN-36-36-24	SERIES 90	S90-180PV
83012806	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-5-NN-80-T-4-C8-K-03-NNN-42-42-24	SERIES 90	S90-250PV
83012807	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-1-BC-80-S-4-S1-D-00-GBA-35-35-24	SERIES 90	S90-075PV
83012808	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-AB-80-S-4-F1-E-00-GBA-35-35-24	SERIES 90	S90-100PV
83012809	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-BC-80-S-4-F1-E-00-GBA-35-35-24	SERIES 90	S90-100PV
83012811	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-S1-N-E1-B1-N-N-U1-NNN-046-AA-F0-00-00	SERIES 51	S51-080MV-1
83012812	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MB-1-BC-80-P-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-075PV
83012813	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E1-AA-N-A-TB-CS-HS-S-A-05-NN-032-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83012814	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E1-AA-N-A-TB-CS-JS-S-A-05-NN-032-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83012818	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-CD-80-P-4-C7-D-04-GBA-29-29-24-F065	SERIES 90	S90-075PV
83012822	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-L2-BA-N-B-PB-VS-DS-S-A-10-NN-034-N-00-NNN	H1-HP MOTORS	H1-110MB1
83012823	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-A-A5-C2-N-F4-H-G9-H6-L-42-L-42-M-M-28-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83012824	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-A-A5-C2-N-F4-H-G1-H6-L-42-L-42-M-M-28-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83012825	PUMP-VAR DISPL, CW 90PV055	90-R-055-PA-5-CD-80-L-4-C6-C-03-GBA-26-26-24	SERIES 90	S90-055PV
83012826	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-HZ-B1-B-H-G5-ACB-032-AA-F0-06-00	SERIES 51	S51-160MV
83012827	PUMP-VAR-DISPL CCW 90PV130	90L130-MA-5-BC-80-S-3-F1-H-C5-GBA-42-42-24	SERIES 90	S90-130PV
83012831	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-C2-C2-C-D6-K-F1-H3-L-45-L-45-D-L-28-P2-NNN-D4F	H1-HP PUMPS	H1-089PV/100PV
83012832	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-E1-B1-N-N-U1-ABA-057-AA-F0-00-00	SERIES 51	S51-110MV-1
83012833	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-1-BC-80-R-4-T4-F-00-GBA-32-32-24	SERIES 90	S90-130PV
83012844	PUMP-VAR-DISPL CW 90PV130	90R130-M8-1-AB-80-L-3-F1-F-03-GBA-42-42-24	SERIES 90	S90-130PV
83012845	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-ANN3-03-B-2-G-2-C-N-B-21-21-B-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83012846	PUMP-VAR-DISPL 42PV041 CW	42-R-41-C-ANN3-03-B-2-G-2-C-N-A-21-21-B-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83012847	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-C3-C3-C-D8-K-G9-H1-L-42-L-42-C-P-24-P2-NNN-D6H	H1-HP PUMPS	H1-069PV/078PV
83012848	MOTOR-VAR-DISPL H1MB060	H1-B-060-A-L2-BA-N-B-PB-CS-GS-S-N-NN-NN-020-N-00-NNN	H1-HP MOTORS	H1-060MB1
83012850	PUMP-VAR DISPL, CW 90PV075	90-R-075-DD-1-AB-60-P-4-S1-D-GB-GBA-32-32-24	SERIES 90	S90-075PV

83012851	PUMP-VAR-DISPL CW 90PV180	90R180-HS-5-AB-80-T-C-F1-H-03-FAC-35-35-24	SERIES 90	S90-180PV
83012856	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-BC-80-P-3-S1-E-03-GBA-38-38-24	SERIES 90	S90-075PV
83012858	PUMP-VAR-DISPL CCW H1PV089	H1-P-089-L-A-A5-C2-B-D6-H-G9-NN-L-42-L-42-D-L-30-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83012863	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-T3-C0-L-N-G0-NNN-050-AA-E6-00-C3	SERIES 51	S51-250MV
83012865	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HS-1-CD-80-R-4-K3-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83012866	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-BC-80-R-3-S1-C-03-GBA-23-23-24	SERIES 90	S90-055PV
83012871	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HF-1-BC-80-R-4-S1-E-09-GBA-35-35-24	SERIES 90	S90-075PV
83012872	PUMP-VAR DISPL, CW 90PV075	90-R-075-HF-1-BC-80-R-4-K2-D-03-GBA-20-20-24	SERIES 90	S90-075PV
83012879	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-CD-80-S-3-S1-E-02-GBA-35-35-24	SERIES 90	S90-100PV
83012881	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-NN-80-S-3-S1-E-02-GBA-35-35-24	SERIES 90	S90-100PV
83012882	MOTOR-VAR-DISPL 51MD110-1	51D110-1--R-D3-N-T2-D2-N-N-X1-ADA-033-AA-E6-00-28	SERIES 51	S51-110MV-1
83012883	PUMP-VAR DISPL, CW 90PV055	90-R-055-HS-1-CD-80-P-3-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83012884	PUMP-VAR DISPL, CW 90PV055	90-R-055-HS-1-AB-80-P-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83012885	MOTOR-VAR-DISPL 51MC080	51C080-R-D3-N-HZ-B1-A-H-C2-ADA-045-AA-F0-05-00	SERIES 51	S51-080MV
83012887	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A3-C2-N-D3-H-G9-H3-K-33-K-33-D-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83012889	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E2-AA-N-B-TB-DN-GN-N-N-NN-NN-025-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83012891	MOTOR-VARIABLE DISPL SAE_K	K-V-38CN-A-RNF-F08-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83012895	PUMP-VAR-DISPL CCW 90PV180	90L180-KP-5-BC-80-T-C-F1-H-03-FAC-45-45-24	SERIES 90	S90-180PV
83012896	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-BC-80-P-1-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83012898	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-5-AB-80-P-3-S1-E-03-GBA-38-38-24	SERIES 90	S90-075PV
83012899	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A2-C2-N-D8-G-G2-H2-L-35-L-35-A-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83012901	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-L8-B1-V-A-G0-NNN-140-AA-F3-B2-00	SERIES 51	S51-250MV
83012904	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-N2-NN-N-N-A0-NNN-115-AA-H0-00-00	SERIES 51	S51-160MV
83012905	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-1-AB-60-P-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83012906	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-B8-C2-C-D8-G-G2-H6-L-40-L-40-A-P-30-P1-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83012908	PUMP- VARIABLE, DIRECT DISPLACEMENT	LPV-A-A-L-A-G-AA-D-A-BGG-DR-A-FF-B-NNN-***	LPV	LPV
83012909	PUMP- VARIABLE, DIRECT DISPLACEMENT	LPV-A-A-L-A-G-DA-D-A-BGG-DR-A-FF-B-NNN-***	LPV	LPV
83012910	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-E-V-C-B-AA-B-B-A-A-BJJ-BC-A-HH-B-D-A-A-BJJ-BC-A-HH-B-NNN-***	M46	M46-046PT
83012924	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-D-T-B-J-AA-J-A-BBB-CE-A-JJ-B-NNN-***	M46	M46-046PV
83012936	PUMP-VAR DISPL, CW 90PV100	90-R-100-HF-5-BC-80-R-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83012939	MOTOR-VAR-DISPL 51MC160	51C160-R-D5-N-EF-B1-V-A-C2-ACR-032-AA-G0-B2-00	SERIES 51	S51-160MV
83012940	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-5-CD-80-L-3-F1-F-03-GBA-29-29-20	SERIES 90	S90-100PV
83012941	MOTOR- VARIABLE CARTRIDGE L	L-C-30DS-E-R1F-F09-S-N-N-FF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83012952	MOTOR- VARIABLE CARTRIDGE L	L-C-30DN-E-RNF-F09-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83012953	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-NN-80-S-C-C8-J-03-FAC-42-42-24	SERIES 90	S90-180PV
83012958	PUMP- VARIABLE, DIRECT DISPLACEMENT	LPV-C-A-A-J-A-G-DC-C-A-BDD-DL-A-FF-B-NNN-***	LPV	LPV

83012959	PUMP- VARIABLE, DIRECT DISPLACMENT	LPV-C-A-A-J-A-G-EC-C-A-BDD-DL-A-FF-E-NNN-***	LPV	LPV
83012960	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-E1A3-02-B-2-B-2-F-N-B-28-28-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83012962	PUMP-VAR DISPL, CW 90PV100	90-R-100-LV-1-CD-60-S-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83012963	PUMP-VAR DISPL MPV046C	MPV-046-C-B-A-H-S-B-B-AA-A-A-BFF-AB-U-AA-A-NNN-***	M46	M46-046PV
83012969	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-AB-80-P-3-S1-F-00-GBA-32-32-24	SERIES 90	S90-100PV
83012970	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HF-1-AB-80-S-3-S1-E-03-GBA-42-42-32	SERIES 90	S90-075PV
83012974	PUMP-VAR DISPL, CW 90PV075	90-R-075-HS-1-CD-80-R-3-C7-E-03-GBA-35-29-24	SERIES 90	S90-075PV
83012975	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-BC-80-R-3-S1-C-03-GBA-32-32-24	SERIES 90	S90-055PV
83012976	PUMP-VAR-DISPL CW 90PV042	90R042-DD-1-NN-80-R-4-C3-C-G1-GBA-35-35-24	SERIES 90	S90-042PV
83012979	MOTOR-VAR-DISPL 51MV250	51V250-V-F2-N-L4-B1-V-A-C0-NNN-050-AA-NN-B2-00	SERIES 51	S51-250MV
83012982	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-B8-C2-C-F4-H-F1-H6-L-35-L-35-C-M-24-P1-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83012983	MOTOR-VAR-DISPL 51MD110-1	51D110-1--A-D3-N-TH-C2-N-N-X1-NNN-035-AA-F0-00-25	SERIES 51	S51-110MV-1
83012988	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-1-NN-80-R-4-C6-C-G1-GBA-35-35-24	SERIES 90	S90-055PV
83012989	PUMP-VAR-DISPL CW 90PV100	90R100-KN-5-NN-80-S-3-S1-F-03-GBA-26-26-24	SERIES 90	S90-100PV
83012991	PUMP-VAR-DISPL CW 90PV100	90R100-CA-5-AC-60-S-7-C7-F-00-GLA-42-42-32	SERIES 90	S90-100PV
83012995	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-CD-80-S-3-C6-E-03-GBA-42-42-32	SERIES 90	S90-075PV
83012996	PUMP-VAR-DISPL CCW H1PV089	H1-P-089-L-A-A3-C1-N-D3-H-F1-NN-L-45-L-45-M-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83012997	PUMP-VAR-DISPL CCW 90PV100	90L100-HF-5-NN-80-S-3-C7-F-03-GBA-42-42-24	SERIES 90	S90-100PV
83012998	PUMP-VAR-DISPL CW 90PV100	90R100-CB-5-NN-80-L-3-C7-F-00-EFI-42-42-24	SERIES 90	S90-100PV
83013016	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A5-C2-N-D8-F-G5-H3-L-30-L-30-B-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83013017	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-NN-80-P-4-C7-E-03-GBA-42-42-30	SERIES 90	S90-075PV
83013018	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-NN-80-S-4-C7-E-03-GBS-42-42-30	SERIES 90	S90-075PV
83013025	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-ANN3-02-B-2-B-2-H-N-A-25-25-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83013026	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-CD-60-D-3-C7-L-03-FAD-42-42-24	SERIES 90	S90-100PV
83013029	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-AB-80-S-4-S1-E-03-GBA-40-40-24	SERIES 90	S90-100PV
83013030	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-CD-80-S-4-C8-H-03-GBA-36-36-24	SERIES 90	S90-130PV
83013032	PUMP-VAR DISPL MPV044D	MPV-044-D-B-A-G-W-S-G-AA-A-A-BDD-DR-A-FF-A-NNN-***	M35/44	044PV
83013037	MOTOR-VAR-DISPL 51MD110-1	51D110-1--R-D3-N-N1-NN-N-N-U1-NNN-035-AA-F3-00-00	SERIES 51	S51-110MV-1
83013038	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-BC-80-P-4-T2-F-03-GBA-35-35-24	SERIES 90	S90-100PV
83013039	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-T4-C2-L-N-G0-ADA-080-AA-G0-00-B5	SERIES 51	S51-160MV
83013045	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-CD-80-D-4-F1-L-05-GBA-35-35-24-F059	SERIES 90	S90-130PV
83013054	PUMP-VAR DISPL, CCW 90PV100	90-L-100-DD-1-NN-80-R-4-F1-F-GB-GBA-07-07-24	SERIES 90	S90-100PV
83013055	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A3-C1-B-F4-H-F1-H6-L-38-L-38-M-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83013063	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-AB-80-P-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-075PV
83013067	PUMP-VAR-DISPL CCW H1PV089	H1-P-089-L-A-A5-C1-N-D3-K-F1-NN-L-43-L-44-M-M-24-P4-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83013072	PUMP-VAR-DISPL CCW H1PV089	H1-P-089-L-A-A3-C1-B-D3-H-G1-NN-L-43-L-43-M-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV

83013077	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-ANN5-02-B-D-B-2-H-N-B-34-34-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83013078	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-G3AN-52-P-D-B-2-H-1-B-34-34-B-0-0-NNN-NNN	SERIES 42	S42-028PV/032PV
83013079	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-G3AN-52-P-D-B-2-H-1-A-34-34-B-0-0-NNN-NNN	SERIES 42	S42-028PV/032PV
83013080	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-T1-D1-N-B-TA-CN-HN-N-A-10-NN-032-Z-27-NNN	H1-HP MOTORS	H1-080MB1
83013081	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-T1-D1-N-B-TA-DN-KN-N-A-15-NN-060-Z-27-NNN	H1-HP MOTORS	H1-110MB1
83013088	PUMP-VAR-DISPL CCW H1PV089	H1-P-089-L-A-A3-C1-B-D3-H-G1-H2-L-41-L-41-M-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83013089	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A3-C1-B-F4-H-F1-H6-K-40-K-40-M-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83013090	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A7-C2-C-D8-K-G1-H3-K-35-K-35-C-P-24-P2-NNN-D3F	H1-HP PUMPS	H1-069PV/078PV
83013092	PUMP-VAR-DISPL CCW 90PV075	90L075-HF-5-NN-80-S-3-C7-D-03-GBA-42-42-24	SERIES 90	S90-075PV
83013093	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HK-1-NN-60-R-4-S1-C-03-GBA-17-17-24	SERIES 90	S90-055PV
83013094	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HK-1-NN-60-R-4-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83013095	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KN-5-BC-80-S-4-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83013096	PUMP-VAR DISPL, CW 90PV075	90-R-075-HF-5-NN-60-R-4-S1-C-03-GBA-35-35-24	SERIES 90	S90-075PV
83013097	PUMP-VAR-DISPL 42PV041 CW	42-R-51-D-A1NB-03-D-N-F-3-H-N-B-17-17-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83013099	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-BC-60-L-3-C7-D-03-GBA-35-35-28	SERIES 90	S90-075PV
83013100	PUMP-VAR DISPL, CW 90PV055	90-R-055-HF-5-NN-60-R-4-C6-C-00-GCA-42-42-24	SERIES 90	S90-055PV
83013111	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-AB-80-P-3-C7-E-03-GBA-30-30-24	SERIES 90	S90-100PV
83013115	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-P1-D1-N-B-TB-DS-JS-S-A-10-NN-025-Z-24-NNN	H1-HP MOTORS	H1-110MB1
83013116	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-B7-C2-C-D8-J-G5-H2-L-42-L-42-B-P-24-P2-NNN-D3H	H1-MP PUMPS	H1-045PV/053PV
83013117	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-K-S-B-S-BA-A-A-BFF-CE-A-HH-B-NNN-***	M46	M46-046PV
83013118	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-AB-80-R-3-S1-E-09-GBA-35-35-24	SERIES 90	S90-100PV
83013119	PUMP-VAR-DISPL CW 90PV250	90R250-HF-5-BC-80-T-3-F1-J-03-NNN-23-23-24	SERIES 90	S90-250PV
83013120	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A2-C3-N-D6-H-F4-H1-L-28-L-28-M-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83013121	PUMP-TANDEM, VAR DISPL MPT035D	MPT-035-D-A-L-S-A-AA-B-A-A-A-BHH-DL-A-FF-B-C-A-A-BHH-DL-A-FF-C-NNN-**	M35/44	035PT
83013146	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-1-AB-60-S-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
83013147	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-1-CD-60-S-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
83013148	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A3-C1-N-D6-F-G4-H2-L-18-L-18-B-L-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83013150	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A5-C2-N-D8-F-G1-H2-L-35-L-35-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83013153	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-N-N1-NN-N-N-U1-NNN-016-AA-E6-00-00	SERIES 51	S51-060MV-1
83013154	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-NN-80-S-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83013156	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-K-S-A-J-BC-A-A-BJJ-CB-A-GG-4-NNN-***	M46	M46-046PV
83013160	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-B8-C2-C-F5-K-G9-H6-L-40-L-40-C-P-30-P2-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83013161	PUMP-VAR DISPL CCW H1P053L	H1-P-053-L-A-A5-C2-N-D8-F-G5-H2-L-25-L-25-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83013162	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-L3-B1-W-B-CO-AWU-070-AA-F0-D4-00	SERIES 51	S51-160MV
83013166	MOTOR-VAR-DISPL 51MD160	51D160-R-D5-N-E2-A5-A-N-G0-NNN-080-AA-F0-03-00	SERIES 51	S51-160MV
83013169	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-1-CD-80-P-3-F1-H-03-GBA-35-35-24	SERIES 90	S90-130PV

83013170	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KN-1-BC-80-S-4-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83013171	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KN-1-CD-80-S-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83013172	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A5-C2-N-D8-F-G1-H3-L-35-L-35-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83013173	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A5-C2-N-D8-F-G1-H3-L-35-L-35-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83013174	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A5-C2-N-D8-F-G5-H2-L-25-L-25-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83013175	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-AB-80-P-3-C8-F-03-GBA-30-30-24	SERIES 90	S90-130PV
83013179	MOTOR-VAR-DISPL 51MD110-1	51D110-1--A-D3-N-T7-D7-N-N-X1-ADA-040-AA-E6-00-27	SERIES 51	S51-110MV-1
83013181	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-T1-D1-N-B-TA-DN-JN-N-A-15-NN-060-Z-27-NNN	H1-HP MOTORS	H1-110MB1
83013183	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-S1-N-TA-C2-N-N-X1-NNN-051-AA-F3-00-28	SERIES 51	S51-080MV-1
83013186	PUMP- VARIABLE, DIRECT DISPLACMENT	LPV-A-A-B-C-A-E-AA-C-A-BFF-DR-A-FF-B-NNN-***	LPV	LPV
83013187	PUMP-VAR-DISPL CCW 90PV180	90L180-HF-5-BC-80-T-M-F1-H-03-FAC-23-23-24	SERIES 90	S90-180PV
83013188	PUMP-VAR-DISPL CW 90PV180	90R180-MA-5-AB-80-S-M-C8-H-C5-FAC-32-32-24	SERIES 90	S90-180PV
83013189	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-AB-80-S-4-S1-D-00-GBA-35-35-24	SERIES 90	S90-075PV
83013190	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-E2-B1-N-N-U1-ABA-041-AA-F0-00-00	SERIES 51	S51-110MV-1
83013193	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-BC-80-P-3-F1-E-03-GBA-45-45-24	SERIES 90	S90-100PV
83013197	MOTOR- VARIABLE CARTRIDGE L	L-C-30DN-E-RNF-F10-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83013198	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-1-AB-60-L-3-S1-D-GB-GBA-20-20-24	SERIES 90	S90-055PV
83013199	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-ANB5-02-B-D-B-2-H-N-B-34-34-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83013208	PUMP-VAR-DISPL CW 90PV100	90R100-FD-5-AB-60-P-7-C7-F-B1-EFI-30-30-30	SERIES 90	S90-100PV
83013209	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A5-C2-B-D3-G-G2-H6-L-40-L-40-L-M-32-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83013210	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A5-C2-B-D3-H-G1-H2-L-40-L-40-C-M-32-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83013213	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KT-H-AC-60-X-3-S1-D-03-GBA-AA-42-24	SERIES 90	S90-075PV
83013214	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HF-5-CD-80-R-4-F1-F-03-EEB-35-35-24	SERIES 90	S90-100PV
83013215	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-K2-K2-N-A-RB-VS-AS-S-A-10-NN-040-N-28-NNN	H1-HP MOTORS	H1-080MB1
83013216	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A5-C2-N-D6-F-G1-H2-L-35-L-35-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83013217	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E2-AA-N-A-TB-CS-JS-S-A-05-NN-032-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83013218	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A5-C2-N-D6-F-G1-H2-L-35-L-35-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83013219	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A5-C2-N-D8-F-G1-H2-L-25-L-25-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83013220	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A5-C2-N-D6-F-G1-H3-L-35-L-35-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83013221	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A5-C2-N-D6-F-G1-H3-L-35-L-35-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83013222	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-CD-80-P-4-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83013224	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-N-L4-B1-V-A-G5-AWU-032-AA-F3-B2-00	SERIES 51	S51-160MV
83013225	PUMP-VAR-DISPL CCW 90PV180	90L180-HF-1-CD-80-S-M-F1-H-03-NNN-26-26-22	SERIES 90	S90-180PV
83013230	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-A-A7-C2-C-D8-K-G1-H3-K-35-K-35-D-P-24-P2-NNN-D3F	H1-HP PUMPS	H1-089PV/100PV
83013231	PUMP-VAR-DISPL CCW 90PV130	90L130-HF-5-CD-80-R-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-130PV
83013232	MOTOR- VARIABLE CARTRIDGE L	L-C-25CN-E-RNF-F01-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV

83013234	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-C2-C2-C-D8-K-G9-H3-L-42-L-42-C-P-24-P2-NNN-D4F	H1-HP PUMPS	H1-069PV/078PV
83013236	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-NN-80-S-M-F1-H-03-EFI-35-35-24	SERIES 90	S90-180PV
83013243	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-1-BC-80-S-3-S1-C-03-GBA-23-23-24	SERIES 90	S90-055PV
83013244	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-AB-80-L-4-C8-H-04-GBA-42-42-24	SERIES 90	S90-130PV
83013245	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-AB-80-P-4-C7-E-04-GBA-42-42-24	SERIES 90	S90-100PV
83013246	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-AB-80-S-M-C8-J-04-NNN-42-42-24	SERIES 90	S90-180PV
83013250	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-E1A6-02-B-4-G-2-C-N-A-34-34-B-A-A-NNN-NNN	SERIES 42	S42-041PV/051PV
83013254	PUMP-VAR DISPL CCW H1P053L	H1-P-053-L-A-A5-C2-N-D8-F-G5-H5-L-35-L-35-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83013255	PUMP-VAR DISPL CCW H1P053L	H1-P-053-L-A-A5-C2-N-D8-F-G5-H3-L-35-L-35-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83013256	PUMP-VAR-DISPL CCW H1PV130	H1-P-130-L-B-A5-C2-N-D8-G-G3-H5-L-40-L-40-A-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83013257	PUMP-VAR-DISPL CCW H1PV130	H1-P-130-L-B-A5-C2-N-D8-G-G3-H6-L-40-L-40-A-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83013260	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-BC-80-R-4-S1-E-04-GBA-26-26-20	SERIES 90	S90-100PV
83013261	PUMP-VAR DISPL, CW 90PV075	90-R-075-HF-1-BC-80-R-4-S1-C-04-GBA-26-26-20	SERIES 90	S90-075PV
83013262	PUMP-VAR DISPL CCW H1P053L	H1-P-053-L-A-A5-C2-N-D8-F-G5-H3-L-25-L-25-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83013267	PUMP-VAR-DISPL CW 90PV180	90R180-FH-5-BC-80-T-7-F1-H-B1-NNN-35-35-30	SERIES 90	S90-180PV
83013268	PUMP-VAR-DISPL CW 90PV180	90R180-FH-5-EF-80-T-7-C8-H-B1-NNN-35-35-30	SERIES 90	S90-180PV
83013269	MOTOR-VAR-DISPL H1MB060	H1-B-060-A-L2-BA-N-A-PB-VS-AS-S-A-10-NN-020-N-00-NNN	H1-HP MOTORS	H1-060MB1
83013270	PUMP-VAR-DISPL CCW 90PV130	90L130-KN-5-NN-80-R-3-T4-F-03-GBA-35-35-24	SERIES 90	S90-130PV
83013271	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-NN-80-S-3-F1-F-06-GBA-38-38-24	SERIES 90	S90-130PV
83013273	PUMP-VAR-DISPL CCW H1PV115	H1-P-115-L-B-A3-C2-N-D3-G-G2-NN-L-35-L-35-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83013274	MOTOR-VAR-DISPL H1MB060	H1-B-060-A-L2-BA-N-B-PB-CS-GS-S-N-NN-NN-000-N-00-NNN	H1-HP MOTORS	H1-060MB1
83013275	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A3-C2-N-D8-F-G5-NN-L-28-L-28-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83013277	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A3-C2-N-D8-H-F1-NN-L-33-L-33-C-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83013278	PUMP-VAR DISPL, CW 90PV055	90-R-055-MB-5-BC-80-S-3-C6-D-C5-GBA-35-35-24	SERIES 90	S90-055PV
83013280	PUMP-VAR DISPL, CW 90PV100	90-R-100-KN-1-BC-80-L-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83013281	PUMP-VAR DISPL, CW 90PV075	90-R-075-KN-1-CD-60-L-3-C7-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83013283	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E2-AA-N-B-TA-VS-AS-S-A-05-NN-017-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83013286	PUMP-VAR-DISPL CW 90PV180	90R180-MA-5-NN-80-S-C-F1-J-C5-NNN-35-35-28	SERIES 90	S90-180PV
83013287	PUMP-VAR-DISPL CW 90PV100	90R100-MA-5-NN-80-S-3-S1-E-C5-GBA-26-26-28	SERIES 90	S90-100PV
83013292	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-AB-80-R-3-F1-F-06-GBA-38-38-24	SERIES 90	S90-130PV
83013293	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-K2-K2-N-A-RA-VS-DS-S-A-15-NN-022-N-20-NNN	H1-HP MOTORS	H1-110MB1
83013294	PUMP-VAR-DISPL CCW 90PV130	90L130-MB-1-NN-80-P-3-C8-H-03-GBA-42-42-24	SERIES 90	S90-130PV
83013295	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-Y8-B1-R-J1-NNN-032-AA-G0-C2-00	SERIES 51	S51-160MV
83013296	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-HZ-B1-B-HJ8-NNN-032-AA-G0-06-00	SERIES 51	S51-160MV
83013297	MOTOR-VARIABLE CARTRIDGE K	K-C-38CS-E-RNF-F09-S-N-N-DF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83013298	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-NN-80-T-C-F1-J-03-FAC-20-20-22	SERIES 90	S90-180PV

83013299	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-NN-80-S-4-T2-E-02-GBA-35-35-24	SERIES 90	S90-100PV
83013300	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-BC-80-S-4-T2-E-02-GBA-35-35-24	SERIES 90	S90-100PV
83013301	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-ANB5-02-B-D-B-2-H-N-A-34-34-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83013306	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-E-V-C-S-AA-B-B-A-A-BJJ-BC-A-HH-B-D-A-A-BJJ-BC-A-HH-B-NNN-***	M46	M46-046PT
83013307	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-A-A5-C2-N-D3-H-G9-H2-L-33-L-33-M-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83013309	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-L2-BA-N-A-PB-CS-JS-S-A-10-NN-050-N-00-NNN	H1-HP MOTORS	H1-110MB1
83013311	PUMP-VAR-DISPL CW 90PV250	90R250-KP-5-BC-80-T-4-C8-K-03-NNN-35-35-24	SERIES 90	S90-250PV
83013312	PUMP-VAR DISPL, CW 90PV075	90-R-075-KN-1-NN-60-L-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83013314	PUMP-VAR-DISPL CCW 90PV130	90L130-MB-1-DJ-80-P-3-C8-H-03-GBA-42-42-24	SERIES 90	S90-130PV
83013317	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-NN-80-R-4-F1-H-03-GBA-32-32-24	SERIES 90	S90-130PV
83013318	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-A-B7-C2-C-D3-K-F1-H1-L-42-L-42-D-N-24-P2-NNN-D5F	H1-HP PUMPS	H1-089PV/100PV
83013319	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-H-T-B-B-AA-A-A-BHH-DA-A-JJ-A-NNN-***	M46	M46-046PV
83013320	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-H-T-B-B-AA-A-A-BFF-DA-A-JJ-A-NNN-***	M46	M46-046PV
83013321	PUMP-VAR DISPL, CW 90PV055	90-R-055-KN-1-NN-60-R-4-K1-C-03-GBA-29-20-24	SERIES 90	S90-055PV
83013323	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-BC-80-P-3-C6-E-02-GBA-42-42-24	SERIES 90	S90-075PV
83013324	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HS-1-NN-80-S-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83013325	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-E2C8-02-D-N-F-3-H-N-B-34-34-B-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83013326	PUMP-VAR-DISPL 42PV028 CW	42-R-2A-C-E2C8-02-B-D-B-2-H-N-N-34-34-B-N-N-AAA-NNN	SERIES 42	S42-028PV/032PV
83013329	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A5-C2-N-D6-G-G2-H3-L-42-L-42-L-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83013330	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-N2-NN-N-N-A0-NNN-146-AA-G3-00-00	SERIES 51	S51-250MV
83013338	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-L2-BA-N-B-PB-VN-EN-N-A-20-NN-AA3-N-00-NNN	H1-HP MOTORS	H1-160MB1
83013342	PUMP-VAR-DISPL CW 90PV180	90R180-MA-1-BC-80-S-C-F1-J-00-FAC-42-42-28	SERIES 90	S90-180PV
83013344	PUMP-VAR-DISPL CW 90PV100	90R100-MA-1-AB-80-P-3-S1-E-06-GBA-35-35-24	SERIES 90	S90-100PV
83013345	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A3-C2-N-D6-H-F4-H1-L-28-L-28-M-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83013347	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KN-1-BC-80-R-4-S1-D-03-GBA-38-38-24	SERIES 90	S90-075PV
83013348	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KN-1-CD-80-R-4-F1-E-00-GBA-35-35-24	SERIES 90	S90-100PV
83013360	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-BC-80-P-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-055PV
83013364	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KN-1-NN-80-S-4-S1-C-03-GBA-32-32-24	SERIES 90	S90-075PV
83013366	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E2-AA-N-B-TB-CS-GS-S-A-05-NN-018-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83013367	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-NN-80-S-3-S1-D-03-GBA-35-35-28	SERIES 90	S90-055PV
83013371	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-K-T-B-B-BA-A-A-BFF-CB-A-GG-B-NNN-***	M46	M46-046PV
83013372	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-N-N1-NN-N-N-U1-NNN-044-AA-F0-00-00	SERIES 51	S51-060MV-1
83013373	PUMP-VAR-DISPL CW 90PV075	90R075-HF-5-BC-60-S-3-S1-D-02-GBA-42-42-30	SERIES 90	S90-075PV
83013374	PUMP-VAR-DISPL CW 90PV075	90R075-HF-5-CD-60-S-3-C7-D-02-GBA-42-42-30	SERIES 90	S90-075PV
83013375	PUMP-VAR DISPL, CW 90PV100	90-R-100-HS-2-CD-80-P-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83013378	PUMP-VAR DISPL, CW 90PV100	90-R-100-HS-2-CD-80-P-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV

83013379	PUMP-VAR DISPL, CW 90PV100	90-R-100-M8-2-AB-60-L-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83013382	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-B7-C2-C-D8-J-G5-H1-L-35-L-35-N-E-18-P2-NNN-D3F	H1-MP PUMPS	H1-045PV/053PV
83013383	PUMP-VAR DISPL, CW 90PV100	90-R-100-M8-2-CD-60-L-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83013388	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E1-AA-N-B-TA-CS-JS-S-N-NN-NN-040-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83013390	PUMP- VARIABLE, DIRECT DISPLACMENT	LPV-A-A-B-L-A-K-DA-C-A-BJJ-DR-A-FF-B-NNN-***	LPV	LPV
83013391	MOTOR-FIX DISPL 90MF130	90-M-130-NC-0-N-8-N-0-F1-W-00-NNN-00-00-B3	SERIES 90	S90-130MF
83013396	PUMP-VAR DISPL, CCW 90PV055	90-L-055-CB-1-NN-80-S-3-S1-C-00-GBA-35-35-24	SERIES 90	S90-055PV
83013403	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-D-TA-C2-L-N-G0-NNN-055-AA-NN-00-B2	SERIES 51	S51-160MV
83013404	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-L1-BA-N-B-PB-VN-AN-N-A-05-NN-016-N-00-NNN	H1-HP MOTORS	H1-080MB1
83013414	PUMP-VAR DISPL, CW 90PV100	90-R-100-KT-5-BC-80-S-3-S1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
83013415	PUMP-VAR DISPL CCW H1P053L	H1-P-053-L-A-A3-C2-N-D8-F-G1-H5-L-33-L-33-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83013416	PUMP-VAR DISPL CCW H1P053L	H1-P-053-L-A-A3-C2-N-D8-F-G5-H3-L-33-L-33-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83013417	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-G2A1-53-V-N-F-2-H-2-A-41-41-N-T-T-NNN-NNN	SERIES 42	S42-028PV/032PV
83013418	PUMP-VAR DISPL CCW H1P053L	H1-P-053-L-A-A5-C1-N-D6-F-G5-H2-L-35-L-35-B-L-32-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83013423	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-CD-80-S-3-T4-F-00-GBA-38-38-24	SERIES 90	S90-130PV
83013424	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-CD-80-S-3-T4-F-00-GBA-38-38-24	SERIES 90	S90-130PV
83013441	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E1-AA-N-B-TB-CN-GN-N-A-10-NN-028-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83013443	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-H-S-B-S-AA-A-C-BHH-CD-A-GG-A-NNN-***	M46	M46-046PV
83013444	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-7-N-0-K1-W-00-NNN-00-00-E6	SERIES 90	S90-055MF
83013445	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-C-E2D8-02-D-N-F-2-H-N-A-32-32-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83013446	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-D-E2D8-02-D-N-F-2-H-N-B-32-32-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83013447	PUMP-VAR-DISPL 42PV041 CCW	42-L-41-D-E2D8-02-D-N-F-2-H-N-B-32-32-B-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83013448	PUMP-VAR-DISPL 42PV041 CCW	42-L-41-E-E2D8-02-D-N-F-2-H-N-V-32-32-B-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83013449	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-5-NN-80-R-4-C6-C-G1-GBA-35-35-24	SERIES 90	S90-055PV
83013451	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A5-C2-N-D8-F-G1-H5-L-25-L-25-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83013453	PUMP-VAR-DISPL CW 90PV130	90R130-KN-1-NN-80-L-4-F1-H-00-GBA-29-29-24	SERIES 90	S90-130PV
83013455	PUMP-VAR-DISPL 42PV041 CW	42-R-51-D-ANN3-03-B-3-B-3-H-N-T-34-34-B-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83013456	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A2-C3-N-D3-H-G1-H3-L-35-L-35-F-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83013457	PUMP-VAR-DISPL 42PV041 CCW	42-L-41-D-E2D8-02-D-N-F-2-H-N-A-32-32-B-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83013458	PUMP- VARIABLE, DIRECT DISPLACMENT	LPV-A-A-A-C-A-G-AC-C-A-BGG-DR-A-FF-B-NNN-***	LPV	LPV
83013461	PUMP-VAR-DISPL CCW 90PV130	90L130-KN-1-BC-80-R-4-F1-F-03-GBA-42-14-24	SERIES 90	S90-130PV
83013463	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-G3AN-52-P-3-G-2-H-1-A-32-32-B-4-4-NNN-NNN	SERIES 42	S42-041PV/051PV
83013464	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D3-N-N1-NN-N-N-U1-NNN-017-AA-F0-00-00	SERIES 51	S51-080MV-1
83013468	PUMP-VAR DISPL, CCW 90PV100	90-L-100-M8-1-AB-80-P-3-C7-E-03-GBA-40-40-24	SERIES 90	S90-100PV
83013469	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A3-C2-N-F4-H-F1-H6-L-42-L-42-C-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83013470	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A3-C2-N-D3-H-G1-NN-L-42-L-42-C-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV

83013473	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-N-L2-B1-V-A-G0-ADA-050-AA-G3-B2-00	SERIES 51	S51-250MV
83013474	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-B7-C2-C-D8-K-G9-H3-K-25-K-25-C-P-30-P2-NNN-D5F	H1-HP PUMPS	H1-069PV/078PV
83013475	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-BC-80-R-4-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83013478	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A5-C1-N-D8-F-G1-H5-L-33-L-33-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83013480	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HF-1-AB-80-S-4-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83013490	MOTOR-VAR-DISPL 51MV110-1	51V110-1--A-F1-N-T7-R5-N-N-X1-ADA-042-AA-E6-00-19	SERIES 51	S51-110MV-1
83013492	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-CD-80-S-4-T4-F-00-GBA-38-38-24	SERIES 90	S90-130PV
83013495	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KT-1-NN-60-P-4-S1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
83013496	MOTOR-VAR-DISPL 51MV060-1	51V060-1--A-S1-N-T1-D1-N-N-X1-ABA-012-AA-E4-00-35	SERIES 51	S51-060MV-1
83013497	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-E1A6-02-B-2-B-2-H-N-A-25-25-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83013504	PUMP-VAR-DISPL CCW 90PV180	90L180-KN-1-NN-80-T-C-F1-H-03-FAC-35-35-24	SERIES 90	S90-180PV
83013506	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-K2-K2-N-B-RB-VS-DS-S-A-10-NN-032-N-30-NNN	H1-HP MOTORS	H1-110MB1
83013507	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D3-N-N1-NN-N-N-U1-NNN-047-AA-F0-00-00	SERIES 51	S51-080MV-1
83013510	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A2-C2-N-F4-H-G1-H6-K-30-K-30-D-M-20-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83013513	PUMP-VAR-DISPL CW 90PV130	90R130-MA-2-AB-80-L-4-C8-F-02-GBA-42-42-24	SERIES 90	S90-130PV
83013514	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-BC-80-S-4-F1-H-05-GBA-42-42-24	SERIES 90	S90-130PV
83013515	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-CD-80-S-4-C8-H-05-GBA-42-42-24	SERIES 90	S90-130PV
83013516	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-BC-80-L-4-C7-E-05-GBA-29-29-24	SERIES 90	S90-100PV
83013517	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-AB-60-S-4-S1-F-05-GBA-42-42-24	SERIES 90	S90-100PV
83013518	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-L2-BA-N-B-PB-DS-HS-S-A-10-NN-000-N-00-NNN	H1-HP MOTORS	H1-080MB1
83013519	MOTOR-VAR-DISPL 51MD160	51D160-A-D4-N-T3-C0-L-N-L4-ADA-038-AA-G0-00-B5	SERIES 51	S51-160MV
83013520	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-B7-C2-C-D6-J-G1-H5-L-40-L-40-B-L-20-P2-NNN-D3H	H1-MP PUMPS	H1-045PV/053PV
83013522	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KT-Y-BC-60-X-3-S1-D-03-GBA-42-AA-24	SERIES 90	S90-075PV
83013528	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-BC-80-S-3-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83013529	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-A-A4-C1-N-D6-H-G1-H5-L-45-L-45-M-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83013530	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-T1-DA-N-C-TA-DN-KN-N-A-10-NN-070-Z-30-NNN	H1-HP MOTORS	H1-110MB1
83013534	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-CD-60-P-3-C7-D-00-GBA-35-35-20	SERIES 90	S90-075PV
83013535	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-BC-60-P-3-S1-D-00-GBA-35-35-20	SERIES 90	S90-075PV
83013536	PUMP-VAR DISPL, CW 90PV075	90-R-075-HS-1-BC-80-S-3-S1-E-03-GFD-35-35-28	SERIES 90	S90-075PV
83013537	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HS-1-BC-80-S-3-S1-E-03-GFD-35-35-28	SERIES 90	S90-075PV
83013538	PUMP-VAR DISPL, CW 90PV100	90-R-100-MB-1-CD-80-S-4-F1-F-02-GFD-38-38-24	SERIES 90	S90-100PV
83013539	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-HZ-B1-A-N-G0-ACA-107-AA-G0-03-00	SERIES 51	S51-160MV
83013552	PUMP-VAR-DISPL CCW H1PV089	H1-P-089-L-A-A2-C3-N-F5-H-G1-H6-L-35-L-35-D-P-28-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83013554	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A4-C1-N-D6-F-G5-NN-L-38-L-38-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83013562	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-E8-A5-A-N-A6-ACB-130-AA-G0-03-00	SERIES 51	S51-250MV
83013567	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A5-C3-N-D6-H-G1-NN-L-38-L-38-F-L-28-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV

83013568	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A5-C3-N-D6-H-G1-H3-L-38-L-38-F-L-28-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83013570	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KT-2-CD-80-P-4-F1-F-00-GBA-32-32-24	SERIES 90	S90-100PV
83013571	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KT-2-AB-80-P-4-S1-F-00-GBA-32-32-24	SERIES 90	S90-100PV
83013573	PUMP-VAR DISPL, CW 90PV055	90-R-055-FD-1-NN-60-L-4-S1-D-B1-EAB-38-38-30	SERIES 90	S90-055PV
83013574	PUMP-VAR-DISPL CCW H1PV147	H1-P-147-L-C-A5-C1-N-D6-G-G2-H2-L-42-L-42-L-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83013575	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-NN-80-S-4-F1-K-03-NNN-32-32-24	SERIES 90	S90-250PV
83013580	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A4-C1-N-F6-H-G9-H6-L-45-L-45-M-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83013581	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-BC-80-S-M-C8-H-04-NNN-42-42-24	SERIES 90	S90-180PV
83013592	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-AB-60-S-3-S1-D-02-GBA-42-42-30	SERIES 90	S90-075PV
83013593	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-CD-60-S-3-C7-D-02-GBA-42-42-30	SERIES 90	S90-075PV
83013594	PUMP-VAR-DISPL CW 90PV075	90R075-KA-1-AB-80-S-P-S1-D-00-GBA-14-35-24-F024	SERIES 90	S90-075PV
83013596	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-CD-80-L-4-F1-F-00-GBA-14-14-24	SERIES 90	S90-130PV
83013597	PUMP-VAR-DISPL CW 90PV130	90R130-KP-1-NN-80-L-4-F1-F-03-GBA-35-35-24	SERIES 90	S90-130PV
83013598	PUMP-VAR-DISPL CW 90PV130	90R130-MA-1-CD-80-P-3-F1-F-02-GBA-42-42-24	SERIES 90	S90-130PV
83013599	PUMP-VAR DISPL, CW 90PV100	90-R-100-HK-1-BC-80-R-4-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83013600	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-BB-80-L-3-S1-E-00-GBA-29-29-24	SERIES 90	S90-100PV
83013605	PUMP-VAR DISPL, CW 90PV100	90-R-100-LS-L-CD-80-P-3-C7-F-04-GBA-45-42-24	SERIES 90	S90-100PV
83013606	PUMP-VAR DISPL, CW 90PV100	90-R-100-LS-L-BB-80-P-3-J3-F-04-GBA-45-42-24	SERIES 90	S90-100PV
83013612	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-L1-BA-N-B-PA-DS-HS-S-A-10-NN-022-N-00-NNN	H1-HP MOTORS	H1-080MB1
83013614	PUMP-VAR-DISPL CCW H1PV165	H1-P-165-L-C-A5-C3-N-D8-G-F3-H3-L-23-L-23-A-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83013616	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A4-C2-N-F4-K-G1-H6-L-35-L-35-F-N-24-P4-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83013617	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-L1-BA-N-B-PB-CS-JS-S-A-10-NN-016-N-00-NNN	H1-HP MOTORS	H1-080MB1
83013618	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A2-C1-N-D6-F-G5-H5-L-40-L-40-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83013619	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A2-C1-N-D6-F-G5-NN-L-40-L-40-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83013623	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KN-1-BC-80-R-4-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83013624	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KN-1-CD-80-R-4-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83013625	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KN-1-NN-80-R-4-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83013626	PUMP-VAR-DISPL CCW 90PV130	90L130-HF-1-NN-80-R-3-F1-H-03-GBA-29-29-24	SERIES 90	S90-130PV
83013629	PUMP-VAR DISPL, CW 90PV075	90-R-075-HF-1-BC-80-P-3-S1-D-00-GBA-21-21-24	SERIES 90	S90-075PV
83013631	MOTOR-VAR DISPL MMV046C	MMV-046-C-A-E-B-C-A4-NNN-***	M46	M46-046MV
83013639	PUMP-VAR DISPL, CW 90PV055	90-R-055-KN-1-NN-80-R-4-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83013640	PUMP-VAR DISPL, CW 90PV075	90-R-075-KN-1-CD-80-R-4-S1-D-03-GBA-42-14-24	SERIES 90	S90-075PV
83013645	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A8-C3-C-D6-H-G9-NN-L-38-L-38-C-L-30-P1-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83013646	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-L1-BA-N-B-PA-CN-KN-N-N-NN-032-N-00-NNN	H1-HP MOTORS	H1-160MB1
83013647	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-CD-60-S-4-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
83013648	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-CD-60-S-4-F1-D-03-GBA-42-42-24	SERIES 90	S90-100PV

83013650	PUMP-VAR DISPL, CW 90PV055	90-R-055-CA-1-NN-80-R-4-T1-C-00-GBA-42-42-24	SERIES 90	S90-055PV
83013651	PUMP-VAR-DISPL CW 90PV130	90R130-HF-5-NN-80-R-3-F1-F-04-GBA-32-32-20	SERIES 90	S90-130PV
83013653	MOTOR-VAR DISPL MMV046C	MMV-046-C-B-M-N-D-BG-NNC-***	M46	M46-046MV
83013659	PUMP-VAR-DISPL CW 90PV130	90R130-FH-2-AB-80-S-B-C8-F-B1-GBA-42-42-26	SERIES 90	S90-130PV
83013662	MOTOR-VARIABLE DISPL SAE_L	L-V-30DS-A-RNF-F10-S-N-N-BF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83013663	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-E1A6-02-D-N-F-2-H-N-A-23-17-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83013664	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A3-C2-N-F5-H-G9-H6-K-40-K-40-C-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83013665	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A3-C2-N-D8-H-G9-H2-K-40-K-40-C-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83013666	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-L2-BA-N-A-PA-CS-JS-S-A-15-NN-040-N-00-NNN	H1-HP MOTORS	H1-110MB1
83013668	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A3-C2-N-D6-H-F1-H2-L-25-L-25-D-L-30-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83013673	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-A-A3-C1-B-D3-H-G1-H2-L-41-L-41-M-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83013674	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-A-A3-C1-N-F4-H-F1-H6-L-45-L-45-D-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83013675	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A8-C3-C-F6-H-G9-H6-L-38-L-38-C-L-30-P1-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83013676	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HF-1-AB-80-S-4-S1-C-03-GBA-38-38-24	SERIES 90	S90-055PV
83013677	PUMP-VAR-DISPL CW 90PV130	90R130-HF-1-CD-80-L-4-F1-H-03-GBA-29-29-24	SERIES 90	S90-130PV
83013678	PUMP-VAR DISPL, CW 90PV100	90-R-100-HF-1-NN-80-L-4-S1-F-03-GBA-29-29-24	SERIES 90	S90-100PV
83013679	PUMP-VAR DISPL, CW 90PV075	90-R-075-HK-1-BC-80-P-4-S1-D-03-GBA-26-26-24	SERIES 90	S90-075PV
83013684	PUMP-VAR DISPL, CW 90PV100	90-R-100-DD-5-NN-60-S-4-C7-E-GB-GBA-35-35-24	SERIES 90	S90-100PV
83013685	PUMP-VAR DISPL, CW 90PV075	90-R-075-DD-5-NN-60-S-4-C7-E-GB-GBA-35-35-24	SERIES 90	S90-075PV
83013687	PUMP-VAR-DISPL CW 90PV180	90R180-KN-5-NN-80-T-C-C8-J-05-NNN-38-38-24	SERIES 90	S90-180PV
83013688	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-HZ-B1-C-E-C2-NNN-160-AA-G0-15-00	SERIES 51	S51-250MV
83013694	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A5-C2-B-D6-G-G2-H3-L-45-L-45-A-L-30-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83013700	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-B7-C2-C-D8-J-G5-H1-L-40-L-40-B-P-18-P2-NNN-D3F	H1-MP PUMPS	H1-045PV/053PV
83013701	PUMP-VAR-DISPL CW 90PV075	90R075-FH-5-BC-60-S-7-S1-E-B2-EEG-38-38-20-G005	SERIES 90	S90-075PV
83013702	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-AB-80-L-4-S1-D-05-GBA-20-20-24	SERIES 90	S90-075PV
83013703	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-B7-C2-C-D8-J-G5-H1-L-35-L-35-B-P-18-P2-NNN-D3F	H1-MP PUMPS	H1-045PV/053PV
83013709	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-BC-60-R-3-C7-E-04-GBA-42-42-28	SERIES 90	S90-075PV
83013710	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E1-AA-N-B-TB-VN-DN-N-A-15-NN-030-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83013711	PUMP-VAR DISPL, CW 90PV075	90-R-075-HF-1-NN-60-P-3-C6-D-03-GBA-35-35-18	SERIES 90	S90-075PV
83013713	PUMP-VAR-DISPL CCW 90PV130	90L130-HF-5-NN-80-D-3-C8-N-01-GBA-32-32-24	SERIES 90	S90-130PV
83013716	PUMP-VAR-DISPL CW 90PV100	90R100-MA-1-BB-80-P-3-C7-F-03-FAB-45-45-24	SERIES 90	S90-100PV
83013717	PUMP-VAR-DISPL CW 90PV100	90R100-FD-5-CD-60-L-7-C7-E-B1-FAC-38-38-30	SERIES 90	S90-100PV
83013721	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-DG-80-R-3-C8-F-04-GBA-32-32-24	SERIES 90	S90-130PV
83013724	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A2-C3-N-D3-G-G2-H6-L-35-L-35-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83013728	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A5-C1-N-D8-H-G9-S1-L-42-L-42-C-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83013729	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-A-A3-C3-B-D3-H-F1-NN-L-40-L-40-M-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV

83013732	PUMP-VAR-DISPL CW 90PV130	90R130-HF-5-NN-80-R-3-C8-F-04-GBA-32-32-24	SERIES 90	S90-130PV
83013737	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-BC-60-L-3-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83013739	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A5-C2-N-F6-H-G1-H6-L-42-L-42-C-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83013742	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-B7-C2-C-D8-J-G5-H2-L-40-L-40-B-P-24-P2-NNN-D3H	H1-MP PUMPS	H1-045PV/053PV
83013743	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-L2-BA-N-A-PB-VS-DS-S-A-15-NN-022-N-00-NNN	H1-HP MOTORS	H1-110MB1
83013748	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-F7NN-50-V-N-F-2-H-N-B-25-25-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83013749	PUMP-VAR DISPL, CW 90PV055	90-R-055-KN-5-BC-80-S-3-S1-C-03-GBA-40-40-24	SERIES 90	S90-055PV
83013750	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-F7NN-50-V-N-F-2-H-N-A-25-25-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83013751	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-F7NN-50-V-N-F-2-H-N-N-25-25-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83013754	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-CD-80-P-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
83013758	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-E1A5-03-B-3-B-3-F-N-B-34-34-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83013760	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-AB-80-R-3-F1-H-03-GBA-23-23-24	SERIES 90	S90-130PV
83013761	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-1-AB-80-P-3-S1-C-GB-GBA-26-26-24	SERIES 90	S90-055PV
83013762	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-1-CD-80-P-3-C6-C-GB-GBA-26-26-24	SERIES 90	S90-055PV
83013763	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-1-NN-80-P-3-S1-C-GB-GBA-26-26-24	SERIES 90	S90-055PV
83013764	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-BC-80-P-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-075PV
83013766	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KN-1-NN-80-R-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83013767	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KN-1-CD-80-R-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83013768	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-NN-80-R-4-S1-C-03-GBA-35-35-24	SERIES 90	S90-075PV
83013770	MOTOR-VARIABLE CARTRIDGE K	K-C-38CS-E-R2F-F11-S-N-N-CF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83013771	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-2-BC-80-R-3-C6-B-03-GBA-35-35-20	SERIES 90	S90-055PV
83013772	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-F4NN-72-J-D-B-2-H-N-B-25-25-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83013773	PUMP-VAR DISPL, CCW 90PV055	90-L-055-CB-1-NN-80-S-4-S1-C-00-GBA-35-35-24	SERIES 90	S90-055PV
83013776	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-K1-K1-N-B-RB-DN-KN-N-A-10-NN-028-N-30-NNN	H1-HP MOTORS	H1-110MB1
83013779	PUMP-VAR-DISPL CW 90PV130	90R130-MA-5-BC-80-L-4-C8-H-C6-GBA-35-35-24	SERIES 90	S90-130PV
83013780	MOTOR-VAR-DISPL H1MB060	H1-B-060-A-K1-KA-N-B-RB-VN-AN-N-A-10-NN-020-N-22-NNN	H1-HP MOTORS	H1-060MB1
83013781	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-E2C8-03-D-N-F-2-D-N-B-28-28-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83013782	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A5-C2-N-D8-H-F1-NN-L-35-L-35-C-P-22-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83013783	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-8-N-0-C6-W-00-NNN-00-00-G3	SERIES 90	S90-100MF
83013784	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A2-C2-N-D8-G-G2-H3-L-35-L-35-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83013789	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-T3-C0-L-N-G0-ABA-080-AA-F0-00-B3	SERIES 51	S51-160MV
83013790	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-NN-80-P-3-C6-D-00-GBA-42-42-24	SERIES 90	S90-075PV
83013791	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-NN-80-P-3-C7-E-00-GBA-42-42-24	SERIES 90	S90-100PV
83013792	PUMP-VAR-DISPL CCW 90PV250	90L250-DD-5-NN-80-T-4-C8-K-G8-NNN-30-30-24	SERIES 90	S90-250PV
83013793	PUMP-VAR-DISPL CW 90PV130	90R130-KA-1-BC-80-R-3-T4-H-03-GBA-35-35-24	SERIES 90	S90-130PV
83013795	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-1-NN-80-L-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV

83013800	PUMP-VAR DISPL, 42PV028	42-L-28-D-E2D8-03-C-2-A-3-H-N-B-32-32-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83013802	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-NN-80-P-3-C8-H-00-GBA-42-42-24	SERIES 90	S90-130PV
83013803	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-P2-D2-N-B-TA-DN-KN-N-A-10-NN-040-Z-24-NNN	H1-HP MOTORS	H1-110MB1
83013804	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-AB-80-P-3-S1-D-03-EBC-32-32-24	SERIES 90	S90-055PV
83013806	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E2-AA-N-B-TB-VN-DN-N-A-15-NN-050-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83013807	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E1-AA-N-B-TB-DN-KN-N-A-15-NN-063-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83013811	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-5-AB-80-P-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-075PV
83013812	PUMP-VAR-DISPL CW 90PV130	90R130-KP-1-DG-80-L-4-F1-F-03-GBA-35-35-24	SERIES 90	S90-130PV
83013814	MOTOR-VAR-DISPL 51MV110	51V110-R-F1-N-L3-B1-W-B-G5-ACA-074-AA-G3-D4-00	SERIES 51	S51-110MV
83013820	PUMP-VAR-DISPL CCW 90PV180	90L180-HF-1-BC-80-T-M-F1-J-00-NNN-42-42-24	SERIES 90	S90-180PV
83013822	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-N-HS-A2-C-H-F1-NNN-050-AA-NN-12-20	SERIES 51	S51-250MV
83013824	PUMP-VAR-DISPL CCW H1PV165	H1-P-165-L-C-A5-C3-B-D8-G-F3-H3-L-23-L-23-A-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83013826	PUMP-VAR-DISPL CW 90PV130	90R130-KN-5-NN-80-S-4-T7-H-03-GBA-35-35-24	SERIES 90	S90-130PV
83013832	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A5-C2-N-D3-G-G2-NN-L-28-L-28-L-M-20-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83013833	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-BC-80-P-3-C6-C-00-GBA-29-29-24	SERIES 90	S90-055PV
83013835	PUMP-VAR-DISPL CW 90PV100	90R100-HF-5-AB-80-L-4-C7-F-03-GBA-42-42-24	SERIES 90	S90-100PV
83013836	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-BC-80-L-4-C8-H-04-GBA-42-42-24	SERIES 90	S90-130PV
83013837	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-N-HS-A2-B-H-F1-NNN-050-AA-NN-10-20	SERIES 51	S51-250MV
83013840	PUMP-VAR-DISPL CW 90PV130	90R130-KN-5-NN-80-L-4-T7-H-03-GBA-35-35-24	SERIES 90	S90-130PV
83013841	PUMP-VAR-DISPL CW 90PV100	90R100-KN-5-NN-80-L-4-C7-E-03-GBA-32-32-24	SERIES 90	S90-100PV
83013845	PUMP-VAR-DISPL CCW 90PV250	90L250-HF-1-NN-80-T-4-F1-K-00-NNN-42-42-24	SERIES 90	S90-250PV
83013850	MOTOR-VAR-DISPL 51MV110	51V110-A-F1-N-HS-A2-C-E-G6-NNN-039-AA-NN-18-37	SERIES 51	S51-110MV
83013852	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A8-C2-C-D6-J-G5-H2-L-35-L-35-B-L-28-P2-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83013855	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-BC-80-P-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-075PV
83013856	PUMP-VAR DISPL, CW 90PV075	90-R-075-HF-1-BC-80-R-4-S1-E-09-GBA-38-38-24	SERIES 90	S90-075PV
83013862	PUMP-VAR DISPL, 42PV028	42-R-28-D-ANN3-03-B-2-G-2-F-N-B-34-34-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83013863	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-CD-80-R-3-F1-H-03-EEB-38-38-30	SERIES 90	S90-130PV
83013870	PUMP-VAR-DISPL CW 90PV100	90R100-SA-2-NN-80-R-3-S1-E-33-PEA-35-35-24	SERIES 90	S90-100PV
83013871	PUMP-VAR-DISPL CW 90PV100	90R100-SA-2-BB-60-R-3-C6-F-33-PGA-40-40-30	SERIES 90	S90-100PV
83013873	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-NN-80-S-C-C8-H-03-NNN-26-26-24	SERIES 90	S90-180PV
83013874	PUMP-VAR-DISPL CW 90PV180	90R180-MA-1-BC-80-S-M-C8-J-02-NNN-42-42-24	SERIES 90	S90-180PV
83013875	PUMP-VAR-DISPL CW 90PV180	90R180-MA-1-EG-80-S-M-C8-J-02-NNN-42-42-24	SERIES 90	S90-180PV
83013893	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KN-1-CD-80-D-4-S1-L-03-GBA-35-35-24	SERIES 90	S90-100PV
83013894	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KN-1-NN-80-D-4-S1-L-03-GBA-35-35-24	SERIES 90	S90-100PV
83013896	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-E8-A5-A-N-G0-NNN-080-AA-F3-03-00	SERIES 51	S51-160MV
83013898	PUMP-VAR-DISPL CW 90PV250	90R250-KA-2-BC-80-T-3-C8-K-00-NNN-35-35-24	SERIES 90	S90-250PV

83013904	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-AB-80-L-3-C8-H-03-GBA-42-42-22	SERIES 90	S90-130PV
83013906	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-1-AB-80-R-3-F1-F-03-GBA-38-38-24	SERIES 90	S90-130PV
83013908	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-AB-60-S-4-K3-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83013909	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MA-1-NN-60-S-4-K3-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83013910	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KT-5-CD-81-P-3-S1-D-03-GBA-40-40-24	SERIES 90	S90-055PV
83013914	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-S1-N-E3-B1-N-N-U1-NNN-025-AA-E4-00-00	SERIES 51	S51-060MV-1
83013915	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-E1A6-02-B-4-X-N-C-N-A-34-34-B-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83013917	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-N-A4-C2-N-E7-J-G5-H3-35-35-35-35-N-P-28-P4-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83013919	PUMP-VAR DISPL, CW 90PV100	90-R-100-HF-1-BC-80-S-4-F1-E-03-GBA-29-29-24	SERIES 90	S90-100PV
83013927	MOTOR-VAR-DISPL 51MV110	51V110-R-F1-N-HS-A2-A-H-G6-NNN-074-AA-G0-05-20	SERIES 51	S51-110MV
83013928	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-HS-A2-A-H-G6-NNN-100-AA-H0-05-20	SERIES 51	S51-160MV
83013929	PUMP-VAR-DISPL CW 90PV075	90R075-HF-5-NN-60-P-4-C7-D-04-GBA-32-32-20	SERIES 90	S90-075PV
83013931	MOTOR-VAR-DISPL 51MD160	51D160-A-D4-N-HZ-B1-B-H-C2-NNN-080-AA-F3-06-00	SERIES 51	S51-160MV
83013933	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-CD-80-R-3-F1-H-03-EEB-40-40-30	SERIES 90	S90-130PV
83013934	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A2-C2-N-D8-H-F4-NN-L-42-L-42-M-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83013935	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A2-C2-N-D8-H-G1-NN-L-42-L-42-M-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83013936	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A5-C1-N-D6-G-G2-NN-L-42-L-42-L-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83013937	PUMP-VAR DISPL, CW 90PV055	90-R-055-HF-5-NN-80-P-3-S1-D-03-GBA-34-34-24	SERIES 90	S90-055PV
83013941	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A2-C2-N-F5-H-F4-H6-L-42-L-42-M-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83013942	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-E-V-C-S-AA-B-A-B-A-BRR-GG-B-BF-B-C-B-A-BRR-GG-B-BF-B-NNN-*	M46	M46-046PT
83013944	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A7-C2-D-D6-J-G4-H2-L-35-L-35-B-L-24-P2-NNN-D3A	H1-MP PUMPS	H1-045PV/053PV
83013946	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-E2-B1-N-N-U1-ABA-057-AA-F0-00-00	SERIES 51	S51-110MV-1
83013947	PUMP-VAR-DISPL CW 90PV130	90R130-KA-1-NN-80-R-3-F1-H-09-GBA-38-38-34	SERIES 90	S90-130PV
83013949	PUMP-VAR-DISPL CCW H1PV115	H1-P-115-L-B-A5-C2-B-D8-G-G3-H4-L-30-L-30-A-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83013950	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-CD-80-S-4-C8-F-03-GBA-38-38-24	SERIES 90	S90-130PV
83013951	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E2-AA-N-A-TA-VN-EN-N-N-NN-NN-025-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83013953	PUMP-VAR-DISPL CCW 90PV075	90L075-HS-1-NN-60-P-3-S1-D-03-GBA-32-14-30	SERIES 90	S90-075PV
83013954	PUMP-VAR-DISPL CCW 90PV100	90L100-HS-1-NN-60-P-4-S1-E-03-GBA-32-14-30	SERIES 90	S90-100PV
83013957	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-E1A6-02-B-5-G-2-C-N-A-28-28-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83013961	MOTOR-VAR-DISPL 51MV110-1	51V110-1--A-F1-A-N1-NN-N-N-U1-NNN-074-AA-F3-00-00	SERIES 51	S51-110MV-1
83013962	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A5-C3-N-D3-G-G2-H4-L-42-L-42-L-M-22-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83013963	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-P2-D2-N-B-TA-DS-KS-S-A-10-NN-040-Z-24-NNN	H1-HP MOTORS	H1-110MB1
83013964	PUMP-VAR-DISPL CW 90PV100	90R100-FD-5-BC-60-P-7-S1-F-B1-GCA-42-42-28	SERIES 90	S90-100PV
83013965	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-NN-80-S-C-C8-J-03-NNN-32-32-24	SERIES 90	S90-180PV
83013966	PUMP-VAR-DISPL CCW 90PV075	90L075-KN-1-NN-80-R-3-S1-E-03-GBA-29-29-24	SERIES 90	S90-075PV
83013968	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-L2-BA-N-B-PB-CS-JS-S-A-15-NN-042-N-00-NNN	H1-HP MOTORS	H1-110MB1

83013969	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E1-AA-N-B-TB-VS-AS-S-N-NN-NN-038-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83013972	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-NN-80-T-7-C8-J-03-GCG-35-35-30	SERIES 90	S90-180PV
83013973	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-NN-80-T-3-C8-K-09-NNN-14-14-24	SERIES 90	S90-250PV
83013976	PUMP-VAR DISPL, CW 90PV075	90-R-075-HM-1-BC-80-P-4-S1-D-03-GBA-26-26-24	SERIES 90	S90-075PV
83013977	MOTOR-VARIABLE DISPL SAE_K	K-V-45DN-A-R2F-F10-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83013984	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-NN-80-S-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83013985	MOTOR-VAR-DISPL 51MV110	51V110-R-F1-N-HS-A2-B-H-G6-NNN-040-AA-F0-06-20	SERIES 51	S51-110MV
83013986	PUMP-VAR DISPL, CW 90PV075	90-R-075-DC-1-NN-80-D-4-S1-N-Z1-GBA-35-35-24	SERIES 90	S90-075PV
83013989	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-E2C8-03-A-N-A-2-C-N-N-28-28-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83013993	PUMP-VAR DISPL CCW H1P068L	H1-P-068-L-A-A4-C2-N-D3-H-G1-H2-L-33-L-38-C-M-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83013994	PUMP-VAR DISPL CCW H1P068L	H1-P-068-L-A-A4-C2-N-F4-H-F1-H6-L-33-L-33-C-M-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83013995	PUMP-VAR DISPL CCW H1P068L	H1-P-068-L-A-A4-C2-N-F4-H-G1-H6-L-33-L-33-C-M-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83013998	PUMP-VAR-DISPL CCW 90PV250	90L250-KN-5-NN-80-S-4-C8-J-02-NNN-36-36-24	SERIES 90	S90-250PV
83014001	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-L1-BA-N-B-PA-DN-JN-N-N-NN-NN-040-N-00-NNN	H1-HP MOTORS	H1-080MB1
83014003	PUMP-VAR-DISPL CW 90PV180	90R180-MA-1-BC-80-S-P-C8-J-02-NNN-42-42-24	SERIES 90	S90-180PV
83014004	PUMP-VAR-DISPL CW 90PV180	90R180-MA-1-EG-80-S-P-C8-J-02-NNN-42-42-24	SERIES 90	S90-180PV
83014006	MOTOR-FIX DISPL MMF044D	MMF-044-D-A-N-E-A-U-NBC-***	M35/44	044MF
83014007	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-K-S-A-B-BC-A-A-BJG-CM-A-HH-B-NNN-***	M46	M46-046PV
83014008	PUMP-VAR DISPL CCW H1P068L	H1-P-068-L-A-A5-C1-N-D6-H-G1-NN-L-30-L-30-C-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83014009	MOTOR-VAR DISPL MMV046C	MMV-046-C-A-E-2-A-A4-NNN-***	M46	M46-046MV
83014019	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A4-C1-N-F4-H-G1-H6-L-42-L-42-D-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83014022	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-L2-BA-N-A-PB-DS-JS-S-A-10-NN-022-N-00-NNN	H1-HP MOTORS	H1-110MB1
83014024	MOTOR-VAR-DISPL 51MD160	51D160-A-D5-N-HZ-B1-C-N-G0-NNN-110-AA-NN-18-00	SERIES 51	S51-160MV
83014028	PUMP-VAR-DISPL CW 90PV075	90R075-KA-2-CD-80-S-3-C7-D-00-GBA-40-40-24	SERIES 90	S90-075PV
83014034	PUMP-VAR-DISPL CCW H1PV147	H1-P-147-L-C-A5-C2-N-D6-G-G2-H3-L-42-L-42-L-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83014035	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-NN-60-S-4-S1-D-00-GBA-35-35-24-F029	SERIES 90	S90-055PV
83014036	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-5-BC-80-L-3-F1-F-00-GBA-20-20-28	SERIES 90	S90-100PV
83014037	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HF-1-BC-80-R-4-S1-E-03-GBA-32-32-24	SERIES 90	S90-100PV
83014040	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A8-C2-C-D3-H-G9-H3-L-42-L-42-C-M-34-P1-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83014044	PUMP-VAR DISPL, CW 90PV075	90-R-075-DD-1-AB-60-S-4-S1-D-G4-GBA-35-35-20	SERIES 90	S90-075PV
83014045	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-A-A5-C3-N-D8-H-G9-H3-K-42-K-42-D-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83014046	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-L2-BA-N-C-PA-CS-HS-S-A-10-NN-050-N-00-NNN	H1-HP MOTORS	H1-080MB1
83014047	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-CD-60-P-3-C7-D-03-GBA-42-42-24	SERIES 90	S90-075PV
83014048	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-AB-60-P-3-S1-D-03-GBA-30-30-24	SERIES 90	S90-075PV
83014049	PUMP-VAR-DISPL CW 90PV075	90R075-KA-2-CD-80-S-3-S1-D-00-GBA-40-40-24	SERIES 90	S90-075PV
83014050	PUMP-VAR-DISPL CCW 90PV130	90L130-MA-1-CD-80-L-4-F1-H-03-GBA-35-35-30	SERIES 90	S90-130PV

83014051	PUMP-VAR-DISPL CCW 90PV130	90L130-MA-1-BB-80-L-4-F1-H-03-GBA-35-35-30	SERIES 90	S90-130PV
83014052	PUMP-VAR DISPL CW H1P068R	H1-P-068-R-A-A5-C1-N-D6-H-G1-NN-L-30-L-30-C-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83014054	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-1-AB-80-R-4-S1-D-03-GBA-38-38-24	SERIES 90	S90-075PV
83014055	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-CD-80-R-4-F1-E-03-GBA-38-38-24	SERIES 90	S90-100PV
83014063	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HS-1-AB-60-P-4-S1-C-03-GBA-32-14-30	SERIES 90	S90-055PV
83014065	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A2-C1-N-D6-F-G5-H3-L-25-L-25-B-L-22-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83014066	PUMP-VAR DISPL CCW H1P068L	H1-P-068-L-A-A5-C3-N-D8-H-G1-NN-L-35-L-35-F-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83014067	PUMP-VAR DISPL CW H1P068R	H1-P-068-R-A-A5-C3-N-D8-H-G1-NN-L-35-L-35-F-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83014068	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-E1A5-03-B-2-B-2-F-F-N-A-23-23-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83014069	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-BC-80-R-4-T2-E-00-GBA-32-32-24	SERIES 90	S90-100PV
83014073	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E1-AA-N-B-TB-VN-DN-N-A-10-NN-055-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83014078	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-CD-80-R-3-F1-H-K2-EEB-40-40-30	SERIES 90	S90-130PV
83014088	PUMP-VAR DISPL, CW 90PV100	90-R-100-FC-5-CD-80-S-7-F1-F-B1-GCA-38-38-24	SERIES 90	S90-100PV
83014094	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-Y8-B1-R-J-J1-ACD-045-AA-G3-C2-00	SERIES 51	S51-160MV
83014097	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-5-CD-80-S-3-C8-K-03-EFI-42-42-24	SERIES 90	S90-250PV
83014099	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A5-C3-N-D3-H-G1-H3-L-33-L-33-M-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83014100	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A5-C3-N-F4-H-G9-H6-L-33-L-33-M-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83014101	PUMP-VAR-DISPL CCW H1PV115	H1-P-115-L-B-A3-C2-N-D6-G-G2-H6-L-42-L-42-L-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83014102	PUMP-VAR DISPL CCW H1P060L	H1-P-060-L-A-A3-C2-N-D6-H-F1-H3-L-42-L-42-F-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83014105	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A2-C2-N-D8-F-G5-H1-L-40-L-40-B-P-18-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83014107	PUMP-VAR-DISPL CCW 90PV075	90L075-MA-5-NN-80-S-4-C6-C-C5-GBA-42-42-24	SERIES 90	S90-075PV
83014122	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-HS-A1-C-H-E2-NNN-030-AA-F0-15-27	SERIES 51	S51-080MV
83014123	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A4-C2-N-D6-G-G2-H6-L-45-L-45-L-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83014124	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-L1-BA-N-B-PA-DS-JS-S-A-10-NN-000-N-00-NNN	H1-HP MOTORS	H1-110MB1
83014125	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-A-A4-C2-N-F6-H-G1-H6-L-45-L-45-M-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83014126	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-T1-DA-N-B-TA-DS-JS-S-A-10-NN-022-Z-25-NNN	H1-HP MOTORS	H1-110MB1
83014127	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-T1-DA-N-B-TB-CS-JS-S-A-10-NN-049-Z-30-NNN	H1-HP MOTORS	H1-080MB1
83014130	PUMP-VAR-DISPL CW 90PV075	90R075-KP-1-CD-80-R-3-S1-D-03-GBA-38-38-24	SERIES 90	S90-075PV
83014131	PUMP-VAR-DISPL CCW 90PV075	90L075-HF-2-NN-60-P-4-S1-D-03-GBA-42-14-24	SERIES 90	S90-075PV
83014132	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-CD-60-P-4-C7-E-03-GBA-32-32-24	SERIES 90	S90-075PV
83014137	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KT-Y-BC-60-X-3-S1-D-03-GBA-42-AM-24	SERIES 90	S90-075PV
83014144	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-AB-80-P-3-C7-D-03-GBA-26-26-24	SERIES 90	S90-075PV
83014145	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-B8-C2-C-D6-K-F1-H3-L-45-L-45-C-L-28-P2-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83014148	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-NN-80-L-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83014152	MOTOR-VARIABLE DISPL SAE_K	K-V-45DS-A-RNF-F01-S-N-N-CF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83014153	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-NN-80-P-4-S1-D-00-GBA-42-42-24	SERIES 90	S90-075PV

83014154	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-E1A6-00-A-N-A-2-F-N-N-30-30-N-A-A-NNN-NNN	SERIES 42	S42-041PV/051PV
83014155	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D2-N-TA-C2-N-N-X1-NNN-037-AA-E4-00-26	SERIES 51	S51-080MV-1
83014156	MOTOR-VAR-DISPL 51MC110-1	51C110-1--R-D3-N-TH-C2-N-N-X1-NNN-022-AA-E4-00-13	SERIES 51	S51-110MV-1
83014158	PUMP-VAR-DISPL CCW 90PV075	90L075-HF-5-NN-60-P-4-S1-D-03-GBA-42-14-24	SERIES 90	S90-075PV
83014159	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-N-E8-A5-A-N-G0-ACA-058-AA-F3-03-00	SERIES 51	S51-160MV
83014161	MOTOR-FIXED DISPL MMF025C	MMF-025-C-A-E-G-C-D-NNN-***	LIGHT DUTY	025MF
83014163	MOTOR-VAR-DISPL 51MD160	51D160-A-D4-N-HZ-B1-C-N-G0-NNN-110-AA-NN-18-00	SERIES 51	S51-160MV
83014172	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A7-C2-C-D3-K-F1-NN-L-42-L-42-C-M-24-P2-NNN-D3H	H1-HP PUMPS	H1-069PV/078PV
83014173	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-T2-DA-N-B-TB-VN-DN-N-A-15-NN-055-Z-24-NNN	H1-HP MOTORS	H1-110MB1
83014174	PUMP-VAR-DISPL CCW 90PV130	90L130-HF-5-AB-80-L-3-C8-H-03-EEG-42-42-24	SERIES 90	S90-130PV
83014175	PUMP-VAR DISPL, CCW 90PV100	90-L-100-EA-1-NN-80-R-3-S1-F-00-GBA-42-42-24	SERIES 90	S90-100PV
83014176	PUMP-VAR DISPL, CCW 90PV100	90-L-100-EA-1-CD-80-R-3-F1-F-00-EEB-42-42-24	SERIES 90	S90-100PV
83014177	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-S1-N-N1-NN-N-N-U1-ABA-043-AA-F0-00-00	SERIES 51	S51-080MV-1
83014178	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-E2C8-03-B-D-B-2-F-N-B-30-30-N-A-A-NNN-NNN	SERIES 42	S42-041PV/051PV
83014179	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-5-NN-80-P-3-S1-C-GB-GBA-42-42-24	SERIES 90	S90-055PV
83014180	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-E2C8-03-D-N-F-2-F-N-B-34-34-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83014181	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A5-C2-N-D8-H-G1-H3-L-38-L-38-C-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83014183	PUMP-VAR-DISPL CW 90PV130	90R130-HF-5-BB-80-L-4-F1-H-04-GBA-30-30-26	SERIES 90	S90-130PV
83014184	PUMP-VAR DISPL, CW 90PV100	90-R-100-HS-1-CD-80-L-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83014185	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-NN-80-R-4-S1-D-03-GBA-17-17-24	SERIES 90	S90-075PV
83014186	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HF-1-NN-80-R-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-075PV
83014189	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-NN-80-S-3-T2-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83014190	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-D8-M1-R-J-N1-ADA-060-AA-G3-C2-32	SERIES 51	S51-160MV
83014195	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-A-T-B-B-BA-G-A-BEE-BC-A-HH-C-NNN-***	M46	M46-046PV
83014208	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-AB-80-P-3-S1-C-03-GBA-38-38-24	SERIES 90	S90-055PV
83014209	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-BC-80-R-3-F1-H-03-GBA-35-35-24	SERIES 90	S90-130PV
83014221	MOTOR-VAR-DISPL 51MC110-1	51C110-1--R-D4-N-N1-NN-N-N-U1-NNN-060-AA-NN-00-00	SERIES 51	S51-110MV-1
83014223	PUMP-VAR DISPL, CW 90PV055	90-R-055-M8-1-BC-80-L-4-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
83014224	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E1-AA-N-C-TA-DN-JN-N-A-05-NN-035-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83014226	PUMP-VAR DISPL, CCW 90PV055	90-L-055-DC-1-BB-80-S-3-S1-C-GB-GBA-42-42-28	SERIES 90	S90-055PV
83014227	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-BB-80-P-3-S1-D-02-GBA-35-35-24	SERIES 90	S90-075PV
83014228	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-CD-60-L-3-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83014234	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A9-C2-N-D6-H-G1-NN-L-42-L-42-C-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83014235	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-B-S-A-T-BC-G-A-BHH-DA-A-HH-C-NNN-***	M46	M46-046PV
83014236	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-K-T-B-B-BA-G-A-BEE-BC-A-HH-B-NNN-***	M46	M46-046PV
83014239	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-A-S-A-T-BC-G-A-BHH-DA-A-HH-C-NNN-***	M46	M46-046PV

83014243	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-T1-DA-N-B-TA-DS-KS-S-A-10-NN-022-Z-25-NNN	H1-HP MOTORS	H1-110MB1
83014244	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-L1-BA-N-B-PA-DS-KS-S-A-10-NN-000-N-00-NNN	H1-HP MOTORS	H1-110MB1
83014245	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KN-1-NN-80-R-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83014246	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KN-1-BC-80-R-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83014252	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-1-CD-80-L-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83014254	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A5-C3-B-D3-G-G3-H6-K-35-K-20-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83014255	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E2-AA-N-B-TB-DS-KS-S-A-10-NN-061-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83014257	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-CD-80-R-3-F1-E-03-GBA-38-38-24	SERIES 90	S90-100PV
83014258	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E2-AA-N-B-TB-DN-JN-N-A-10-NN-028-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83014260	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A3-C1-N-D6-F-G5-NN-L-40-L-40-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83014262	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-K1-KA-N-A-RA-VS-ES-S-A-10-NN-042-N-19-NNN	H1-HP MOTORS	H1-110MB1
83014268	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A4-C2-N-E5-F-G4-H3-L-35-L-35-B-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83014272	MOTOR-FIX DISPL MMF035D	MMF-035-D-A-A-1-C-F-NNN-***	M35/44	035MF
83014273	MOTOR-VAR-DISPL H1MB060	H1-B-060-A-L1-BA-N-B-PA-DS-GS-S-A-05-NN-000-N-00-NNN	H1-HP MOTORS	H1-060MB1
83014274	MOTOR-VAR-DISPL H1MB060	H1-B-060-A-L1-BA-N-B-PA-DS-GS-S-N-NN-NN-000-N-00-NNN	H1-HP MOTORS	H1-060MB1
83014281	PUMP-VAR-DISPL CCW H1PV089	H1-P-089-L-A-A3-C1-N-D8-K-F1-H2-L-28-L-28-M-P-24-P4-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83014286	PUMP-VAR-DISPL CCW 90PV075	90L075-DC-1-NN-60-S-3-S1-D-GB-GBA-32-32-24	SERIES 90	S90-075PV
83014289	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-CD-80-T-4-C8-J-05-NNN-29-29-24	SERIES 90	S90-250PV
83014295	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A8-C2-C-D6-J-G5-NN-L-30-L-30-B-L-24-P2-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83014298	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-B-U3-C5-P-N-J2-NNN-057-AA-NN-00-00	SERIES 51	S51-160MV
83014299	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-BB-60-P-3-C7-D-03-GBA-38-38-24	SERIES 90	S90-075PV
83014304	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-HZ-B1-B-H-C2-NNN-125-AA-NN-10-00	SERIES 51	S51-160MV
83014306	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E1-AA-N-A-TB-VN-AN-N-N-NN-NN-030-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83014313	PUMP-VAR-DISPL CCW 90PV250	90L250-KN-5-NN-80-T-P-F1-K-03-NNN-32-32-26-F056	SERIES 90	S90-250PV
83014315	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-NN-80-R-3-F1-H-03-GBA-35-35-24	SERIES 90	S90-130PV
83014322	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-E1A6-03-C-2-A-2-F-N-B-28-28-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83014323	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-D-E1A6-03-C-2-A-2-F-N-A-30-30-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83014324	MOTOR-VAR-DISPL 51MV110	51V110-R-C8-N-HS-A2-B-N-A7-NNN-028-AA-F3-10-30	SERIES 51	S51-110MV
83014325	PUMP-VAR DISPL MPV046C	MPV-046-C-B-A-H-T-B-J-BA-A-A-BHH-AK-U-BD-A-NNN-***	M46	M46-046PV
83014326	PUMP-VAR DISPL, CW 90PV100	90-R-100-KT-5-BC-80-P-3-T2-E-03-GBA-38-38-20	SERIES 90	S90-100PV
83014328	PUMP-VAR-DISPL CW 90PV100	90R100-MA-5-CD-60-S-4-C7-E-C5-GBA-45-45-24	SERIES 90	S90-100PV
83014329	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D3-N-TA-C2-N-N-X1-NNN-037-AA-E4-00-26	SERIES 51	S51-080MV-1
83014331	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A4-C2-N-D3-G-G2-H6-L-42-L-42-L-M-22-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83014333	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-NN-80-S-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-075PV
83014334	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E2-AA-N-B-TB-VN-AN-N-A-05-NN-040-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83014335	PUMP-VAR-DISPL CW 90PV250	90R250-CB-5-AB-80-S-3-C8-K-00-NNN-42-42-24	SERIES 90	S90-250PV

83014336	PUMP-VAR-DISPL CW 90PV180	90R180-MA-2-NN-80-S-C-C8-J-03-NNN-20-20-22	SERIES 90	S90-180PV
83014337	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A8-C3-C-D8-H-G1-H5-L-42-L-42-N-E-30-P1-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83014340	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-CD-80-S-4-C7-D-00-GBA-29-29-20	SERIES 90	S90-075PV
83014341	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E1-AA-N-B-TB-CN-JN-N-A-10-NN-040-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83014345	PUMP-VAR-DISPL 42PV028 CW	42-R-32-D-G3AN-52-P-3-G-2-F-1-B-21-21-B-1-1-NNN-NNN	SERIES 42	S42-028PV/032PV
83014346	PUMP-VAR-DISPL 42PV028 CW	42-R-32-C-G3AN-52-P-3-G-2-F-1-A-21-21-B-1-1-NNN-NNN	SERIES 42	S42-028PV/032PV
83014347	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-AB-80-S-4-F1-F-06-GBA-26-26-24	SERIES 90	S90-130PV
83014352	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-L1-BA-N-C-PB-VS-ES-S-A-10-NN-022-N-00-NNN	H1-HP MOTORS	H1-110MB1
83014353	PUMP-VAR DISPL CW H1P068R	H1-P-068-R-A-A5-C1-N-D3-H-G1-NN-L-30-L-30-C-M-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83014354	PUMP-VAR DISPL CCW H1P068L	H1-P-068-L-A-A5-C1-N-D3-H-G1-NN-L-30-L-30-C-M-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83014358	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-A-A4-C2-N-D6-H-G9-H3-L-42-L-42-M-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83014362	PUMP-TANDEM, VAR DISPL CCW H1T053L	H1-T-053-L-A-N-A5-C2-N-F7-F-G1-TN-33-33-33-33-M-P-24-PN-NNN-S01	H1-MP PUMPS	H1-045PT/053PT
83014363	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E2-AA-N-A-TB-CS-GS-S-A-10-NN-019-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83014368	PUMP-VAR-DISPL CW 90PV100	90R100-KP-5-CD-80-L-4-C7-E-03-GBA-32-32-20	SERIES 90	S90-100PV
83014369	PUMP-VAR-DISPL CW 90PV075	90R075-KP-5-CD-80-L-4-S1-D-03-GBA-32-32-20	SERIES 90	S90-075PV
83014377	PUMP-VAR DISPL, CW 90PV100	90-R-100-KT-1-CD-80-L-3-S1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
83014379	PUMP-VAR-DISPL CW 90PV075	90R075-MA-1-BC-60-S-3-T2-E-42-FAB-42-42-24	SERIES 90	S90-075PV
83014380	MOTOR-VAR-DISPL 51MD080-1	51D080-1--R-C7-N-E1-B1-N-N-U1-ADA-041-AA-F0-00-00	SERIES 51	S51-080MV-1
83014386	PUMP-VAR-DISPL CCW 90PV180	90L180-DD-5-CD-80-S-C-F1-H-GB-FAC-42-42-24	SERIES 90	S90-180PV
83014389	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-D-E2D8-03-A-N-A-2-E-N-B-28-28-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83014390	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E2-AA-N-B-TB-CN-GN-N-A-10-NN-022-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83014391	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E2-AA-N-B-TB-DN-JN-N-A-10-NN-032-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83014402	PUMP-VAR-DISPL CW 90PV250	90R250-MB-5-CD-80-T-3-F1-K-C5-NNN-35-35-24	SERIES 90	S90-250PV
83014423	PUMP-VAR-DISPL CW 90PV130	90R130-PB-1-NN-80-R-4-F1-F-03-GBA-29-29-24	SERIES 90	S90-130PV
83014426	PUMP-VAR DISPL, CCW 90PV075	90-L-075-DD-1-CD-60-S-4-S1-D-GB-GBA-42-42-24	SERIES 90	S90-075PV
83014427	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KN-1-NN-80-R-3-S1-D-03-GBA-29-29-24	SERIES 90	S90-075PV
83014428	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KN-1-AB-80-R-3-S1-D-03-GBA-29-29-24	SERIES 90	S90-075PV
83014433	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-1-NN-80-R-4-T4-F-03-GBA-32-32-24	SERIES 90	S90-130PV
83014434	PUMP-VAR-DISPL CCW 90PV180	90L180-HF-1-BC-80-T-C-F1-H-03-FAC-29-29-24	SERIES 90	S90-180PV
83014435	PUMP-VAR-DISPL CCW 90PV180	90L180-KN-1-CD-80-T-C-F1-H-03-FAC-42-42-24	SERIES 90	S90-180PV
83014436	PUMP-VAR-DISPL CCW 90PV075	90L075-MA-1-AB-80-S-3-S1-D-22-GLA-38-38-24	SERIES 90	S90-075PV
83014439	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-BB-80-L-4-T2-E-03-GBA-32-32-24	SERIES 90	S90-100PV
83014440	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E2-AA-N-B-TB-CS-GS-S-A-10-NN-021-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83014441	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E1-AA-N-B-TB-CN-GN-N-A-10-NN-033-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83014442	PUMP-VAR-DISPL CW 90PV130	90R130-MA-5-CD-80-L-4-C8-F-C6-GBA-29-29-24	SERIES 90	S90-130PV
83014443	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-ANNB-03-C-3-A-3-F-N-A-34-34-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV

83014444	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-ANNB-03-C-3-A-3-F-N-B-34-34-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83014445	PUMP- VARIABLE, DIRECT DISPLACMENT	LPV-A-A-A-C-A-G-DC-C-A-BGG-DR-A-FF-B-NNN-***	LPV	LPV
83014449	MOTOR-VAR-DISPL 51MC080	51C080-R-D2-N-HZ-B1-B-E-G5-NNN-020-AA-NN-07-00	SERIES 51	S51-080MV
83014452	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E2-AA-N-B-TB-CN-JN-N-A-10-NN-040-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83014453	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E2-AA-N-B-TA-CN-GN-N-A-10-NN-022-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83014455	MOTOR-VAR-DISPL 51MC110-1	51C110-1--A-D3-N-N1-NN-N-N-U1-NNN-050-AA-NN-00-00	SERIES 51	S51-110MV-1
83014457	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-CD-80-L-3-S1-F-03-GBA-23-23-24	SERIES 90	S90-100PV
83014458	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-AB-80-S-4-T4-F-04-EEB-35-35-24	SERIES 90	S90-130PV
83014459	PUMP-VAR-DISPL 42PV028 CW	42-R-28-G-E2C8-01-C-D-A-2-D-N-N-14-14-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83014460	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-T1-D1-N-A-TA-DN-GN-N-N-NN-017-Z-28-NNN	H1-HP MOTORS	H1-060MB1
83014461	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-ANN5-02-C-2-A-2-E-N-A-34-34-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83014469	PUMP-VAR-DISPL CW 90PV180	90R180-HF-1-BC-80-S-M-C8-J-03-NNN-32-32-24	SERIES 90	S90-180PV
83014470	PUMP-VAR-DISPL CCW 90PV180	90L180-HF-1-BC-80-S-M-C8-J-03-NNN-32-32-24	SERIES 90	S90-180PV
83014473	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-BB-80-S-C-C8-J-04-NNN-45-45-24	SERIES 90	S90-180PV
83014479	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-AB-60-L-4-C7-F-05-GBA-42-42-24	SERIES 90	S90-100PV
83014480	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-E2C8-00-A-N-A-2-D-N-V-C0-C0-N-A-A-NNN-ENN	SERIES 42	S42-028PV/032PV
83014483	PUMP-VAR-DISPL CW 90PV075	90R075-HF-5-NN-80-L-3-C7-D-03-GBA-26-26-24	SERIES 90	S90-075PV
83014484	PUMP-VAR-DISPL CW 90PV075	90R075-HF-5-NN-80-L-3-C7-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83014485	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-AB-80-P-4-S1-D-05-GBA-26-26-24	SERIES 90	S90-055PV
83014491	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-CD-80-S-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-075PV
83014495	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A5-C2-N-D3-G-G2-H2-L-40-L-40-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83014496	PUMP-VAR-DISPL CW 90PV075	90R075-MA-1-CD-60-S-3-C6-D-06-GBA-42-42-20	SERIES 90	S90-075PV
83014497	PUMP-VAR-DISPL CW 90PV075	90R075-MA-1-CD-60-S-3-C6-D-06-GBA-42-42-20	SERIES 90	S90-075PV
83014498	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-BC-60-S-3-C6-D-04-GBA-35-35-24	SERIES 90	S90-075PV
83014499	PUMP-VAR-DISPL CCW 90PV100	90L100-MA-1-NN-60-S-3-T2-F-04-GBA-42-42-24	SERIES 90	S90-100PV
83014500	PUMP-VAR-DISPL CW 90PV100	90R100-KA-1-NN-60-S-3-C7-F-00-GBA-37-37-24	SERIES 90	S90-100PV
83014501	PUMP-VAR-DISPL CW 90PV100	90R100-KA-1-NN-60-S-3-C7-F-00-GBA-38-38-24	SERIES 90	S90-100PV
83014504	PUMP-VAR-DISPL CCW 90PV130	90L130-HF-1-AB-80-R-4-T4-F-03-GBA-35-35-24	SERIES 90	S90-130PV
83014506	MOTOR-VAR-DISPL 51MD080	51D080-A-D3-N-HZ-B1-B-E-G5-NNN-020-AA-E6-06-00	SERIES 51	S51-080MV
83014507	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-NN-60-R-4-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83014508	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-CD-60-R-4-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83014509	PUMP-VAR-DISPL CW 90PV042	90R042-HF-5-NN-80-P-4-C3-C-00-GCA-42-42-20	SERIES 90	S90-042PV
83014513	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-N-N1-NN-N-N-U1-NNN-017-AA-E6-00-00	SERIES 51	S51-060MV-1
83014514	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-S1-N-E1-B1-N-N-U1-NNN-040-AA-NN-00-00	SERIES 51	S51-080MV-1
83014515	PUMP-VAR-DISPL CW 90PV100	90R100-SA-2-BC-60-P-3-F1-F-33-PEA-42-42-24	SERIES 90	S90-100PV
83014516	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E1-AA-N-B-TA-VN-AN-N-A-05-NN-024-Z-00-NNN	H1-HP MOTORS	H1-060MB1

83014518	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-CD-80-S-3-S1-D-03-GBA-32-32-24	SERIES 90	S90-075PV
83014519	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-NN-80-S-3-S1-D-03-GBA-32-32-24	SERIES 90	S90-075PV
83014521	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MB-1-CD-80-S-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83014524	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A8-C2-C-D8-F-G5-NN-L-38-L-38-B-P-24-P1-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83014532	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A8-C3-C-D3-K-F1-H3-L-42-L-42-C-M-30-P2-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83014533	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-T1-D1-N-B-TB-DN-JN-N-A-10-NN-023-Z-20-NNN	H1-HP MOTORS	H1-110MB1
83014534	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-K1-K1-N-B-RB-DN-JN-N-A-10-NN-023-N-20-NNN	H1-HP MOTORS	H1-110MB1
83014536	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A8-C2-C-D8-H-G1-H5-L-40-L-40-N-E-28-P1-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83014538	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-BC-60-P-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
83014542	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-BC-80-P-3-S1-C-00-EEB-20-20-24	SERIES 90	S90-055PV
83014543	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A9-C2-N-E9-F-G4-NN-K-35-K-35-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83014552	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MB-1-BC-80-S-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83014553	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-CD-80-T-M-C8-J-03-NNN-38-38-24	SERIES 90	S90-180PV
83014558	PUMP-VAR DISPL, CW 90PV075	90-R-075-DD-1-NN-60-S-4-C7-E-GB-GBA-29-29-24	SERIES 90	S90-075PV
83014559	PUMP-VAR DISPL, CW 90PV100	90-R-100-DD-1-NN-60-S-4-C7-E-GB-GBA-29-29-24	SERIES 90	S90-100PV
83014560	PUMP-VAR-DISPL CCW H1PV089	H1-P-089-L-A-A4-C3-N-F6-H-G9-H6-L-45-L-45-D-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83014561	PUMP-VAR-DISPL CCW H1PV089	H1-P-089-L-A-A4-C3-N-D6-H-G1-NN-L-42-L-42-D-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83014568	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A4-C2-N-E7-F-G1-H3-20-20-20-20-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83014571	PUMP-VAR-DISPL CW 90PV130	90R130-MA-1-BC-80-S-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-130PV
83014582	MOTOR-VAR-DISPL 51MC110-1	51C110-1--A-D3-N-N1-NN-N-N-U1-NNN-060-AA-NN-00-00	SERIES 51	S51-110MV-1
83014588	PUMP-VAR-DISPL CW 90PV250	90R250-KA-1-EF-80-T-P-C8-K-03-NNN-42-42-30-F056	SERIES 90	S90-250PV
83014592	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-NN-60-R-3-F1-F-03-FAD-42-42-28	SERIES 90	S90-100PV
83014593	PUMP-VAR-DISPL CCW 90PV130	90L130-MA-1-NN-80-S-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-130PV
83014600	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E1-AA-N-B-TB-CN-JN-N-A-10-NN-044-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83014602	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KT-1-CD-80-S-3-S1-C-04-GBA-42-42-24	SERIES 90	S90-075PV
83014603	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-N-A2-C2-N-E7-F-G6-T3-35-35-35-35-M-P-24-PN-NNN-S02	H1-MP PUMPS	H1-045PT/053PT
83014604	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-U3-C5-P-N-J2-NNN-060-AA-E4-00-00	SERIES 51	S51-160MV
83014605	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-U3-C5-P-N-J2-NNN-090-AA-E6-00-00	SERIES 51	S51-250MV
83014606	PUMP-VAR-DISPL CW 90PV075	90R075-ME-1-BC-60-S-3-C6-D-74-FAD-35-35-20	SERIES 90	S90-075PV
83014607	PUMP-VAR-DISPL CW 90PV075	90R075-MA-1-BC-60-S-3-C6-D-04-GBA-35-35-24	SERIES 90	S90-075PV
83014608	PUMP-VAR-DISPL CW 90PV075	90R075-M8-1-CD-60-S-3-C6-D-74-FAD-35-35-20	SERIES 90	S90-075PV
83014610	PUMP-VAR DISPL CW H1P068R	H1-P-068-R-A-A4-C1-B-D6-H-F1-H2-L-35-L-35-C-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83014611	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-NN-80-P-3-C7-E-03-GBA-26-26-24	SERIES 90	S90-100PV
83014621	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-K1-K1-N-B-RA-DN-JN-N-A-10-NN-023-N-20-NNN	H1-HP MOTORS	H1-110MB1
83014622	PUMP-VAR-DISPL CCW 90PV042	90L042-KA-1-AB-80-S-3-C3-C-03-GBA-35-35-20	SERIES 90	S90-042PV
83014625	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-N-HZ-B1-C-E-G5-NNN-080-AA-NN-13-00	SERIES 51	S51-160MV

83014636	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-T1-DA-N-B-TA-VN-AN-N-N-NN-NN-030-Z-30-NNN	H1-HP MOTORS	H1-060MB1
83014637	PUMP-TANDEM, VAR DISPL CCW H1T045L	H1-T-045-L-A-N-A2-C2-N-E7-F-G1-T3-28-28-28-28-M-P-24-PN-NNN-S03	H1-MP PUMPS	H1-045PT/053PT
83014638	PUMP-TANDEM, VAR DISPL CCW H1T045L	H1-T-045-L-A-N-A2-C2-N-E7-F-G5-TN-28-28-28-28-M-P-24-PN-NNN-S03	H1-MP PUMPS	H1-045PT/053PT
83014643	MOTOR-VAR-DISPL 51MD160	51D160-A-D5-N-HS-A1-B-E-E2-NNN-070-AA-F3-08-29	SERIES 51	S51-160MV
83014645	MOTOR-VAR-DISPL 51MV250	51V250-A-C8-N-D7-M1-S-K-M1-NNN-050-AA-G0-F4-31	SERIES 51	S51-250MV
83014646	MOTOR-VAR-DISPL 51MV250	51V250-A-C8-N-D7-M1-S-K-M1-NNN-050-AA-G0-F4-35	SERIES 51	S51-250MV
83014647	PUMP-VAR DISPL CW H1P068R	H1-P-068-R-A-A4-C2-N-D6-H-G1-NN-L-25-L-25-C-L-30-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83014648	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-NN-60-S-3-S1-D-03-GBA-23-23-20	SERIES 90	S90-075PV
83014650	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-T1-D1-N-B-TA-DN-JN-N-A-10-NN-023-Z-20-NNN	H1-HP MOTORS	H1-110MB1
83014656	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-E2-A2-A-N-G1-NNN-053-AA-F3-03-27	SERIES 51	S51-160MV
83014657	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-L2-BA-N-B-PA-DS-JS-S-A-10-NN-000-N-00-NNN	H1-HP MOTORS	H1-110MB1
83014659	MOTOR-VAR-DISPL H1MB060	H1-B-060-A-L2-BA-N-B-PA-DS-GS-S-A-10-NN-000-N-00-NNN	H1-HP MOTORS	H1-060MB1
83014660	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A2-C2-N-E9-F-G4-NN-K-35-K-35-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83014661	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KN-1-BC-80-S-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83014662	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-L2-BA-N-B-PB-CS-JS-S-A-10-NN-023-N-00-NNN	H1-HP MOTORS	H1-080MB1
83014665	PUMP-VAR-DISPL CW 90PV100	90R100-FD-1-NN-60-L-7-S1-E-B1-FAC-38-38-30	SERIES 90	S90-100PV
83014673	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-5-CD-60-L-3-F1-F-02-FAD-42-42-34	SERIES 90	S90-100PV
83014674	PUMP-VAR-DISPL CW 90PV130	90R130-KP-1-NN-80-S-3-F1-F-03-GBA-38-38-24	SERIES 90	S90-130PV
83014676	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-1-AB-60-S-3-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83014678	PUMP-VAR-DISPL CW 90PV180	90R180-KN-1-NN-80-S-M-F1-H-03-FAC-35-35-24	SERIES 90	S90-180PV
83014682	PUMP-VAR-DISPL CCW 90PV180	90L180-KN-1-NN-80-S-M-F1-H-03-FAC-35-35-24	SERIES 90	S90-180PV
83014683	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MA-1-CD-60-P-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83014684	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MA-1-NN-60-P-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83014685	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-1-BC-60-P-3-C7-D-03-GBA-42-42-24	SERIES 90	S90-075PV
83014687	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-BC-80-S-3-S1-C-03-GBA-35-35-22	SERIES 90	S90-055PV
83014691	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-AB-60-S-3-S1-E-00-GBA-17-17-20	SERIES 90	S90-075PV
83014693	MOTOR-VAR-DISPL 51MD080-1	51D080-1--A-D2-N-T1-CA-N-N-X1-NNN-029-AA-E6-00-31	SERIES 51	S51-080MV-1
83014700	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-AB-80-P-3-S1-F-03-GBA-23-23-24	SERIES 90	S90-100PV
83014707	PUMP-TANDEM, VAR DISPL CCW H1T045L	H1-T-045-L-A-N-A3-C2-N-E7-F-G1-H2-40-40-40-40-N-P-32-PN-C07-NNN	H1-MP PUMPS	H1-045PT/053PT
83014708	MOTOR-VARIABLE DISPL SAE_L	L-V-35ES-G-YNF-F95-S-N-N-CF-F18-NNA-NNN	LV / KV MOTORS	L/K-MV
83014710	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E1-AA-N-C-TA-VN-AN-N-A-10-NN-029-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83014715	MOTOR-VARIABLE DISPL SAE_K	K-V-38CS-E-RNF-F07-S-N-N-CF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83014716	MOTOR-VAR-DISPL 51MV250	51V250-A-C8-N-T3-R5-L-N-G0-NNN-064-AA-G0-00-C5	SERIES 51	S51-250MV
83014717	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-H-S-B-B-AA-A-A-BFF-DA-A-GG-A-NNN-***	M46	M46-046PV
83014720	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KT-1-BB-80-S-3-S1-C-02-GBA-42-26-24	SERIES 90	S90-055PV
83014721	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E1-AA-N-B-TA-VN-AN-N-A-10-NN-029-Z-00-NNN	H1-HP MOTORS	H1-060MB1

83014723	MOTOR-VAR-DISPL 51MV250	51V250-A-C8-N-T3-R5-L-N-G0-NNN-080-AA-G0-00-C5	SERIES 51	S51-250MV
83014724	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-L2-BA-N-B-PB-VS-ES-S-A-20-NN-000-N-00-NNN	H1-HP MOTORS	H1-160MB1
83014725	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-E1-AA-N-B-TB-VS-ES-S-A-20-NN-032-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83014726	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-L1-BA-N-B-PB-CS-LS-S-A-30-NN-050-N-00-NNN	H1-HP MOTORS	H1-160MB1
83014727	MOTOR-VAR-DISPL 51MV250	51V250-A-C8-N-T3-R5-L-N-G0-NNN-064-AA-G0-00-C1	SERIES 51	S51-250MV
83014728	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-T1-D1-N-A-TA-VS-ES-S-A-20-NN-080-Z-24-NNN	H1-HP MOTORS	H1-160MB1
83014729	MOTOR-VAR-DISPL 51MV160	51V160-R-F2-N-T4-C0-L-N-G0-AHA-070-AA-G0-00-B4	SERIES 51	S51-160MV
83014730	MOTOR-VAR-DISPL 51MV160	51V160-R-F2-N-T4-C0-L-N-G0-NNN-070-AA-G0-00-B4	SERIES 51	S51-160MV
83014731	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-G3AN-53-P-3-G-2-F-1-B-21-21-B-1-1-NNN-NNN	SERIES 42	S42-028PV/032PV
83014734	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-E8-A1-A-N-A2-ADA-050-AA-G0-03-37	SERIES 51	S51-250MV
83014735	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E2-AA-N-A-TB-VN-AN-N-N-NN-NN-030-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83014736	PUMP-VAR DISPL, CW 90PV055	90-R-055-PA-1-AB-60-R-3-T1-C-00-EEB-26-26-24	SERIES 90	S90-055PV
83014737	MOTOR-VARIABLE DISPL SAE_L	L-V-25CN-A-YNF-F75-S-N-N-BF-F14-NNN-NNN	LV / KV MOTORS	L/K-MV
83014743	PUMP-VAR-DISPL CW 90PV100	90R100-HK-1-AB-60-S-4-F1-E-03-GBA-42-42-20	SERIES 90	S90-100PV
83014745	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A5-C3-N-D6-G-G2-H6-L-42-L-42-A-L-22-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83014751	PUMP-VAR-DISPL CW 90PV130	90R130-MA-1-CD-80-S-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-130PV
83014752	PUMP-VAR-DISPL CCW H1PV130	H1-P-130-L-B-B8-C2-D-D3-L-G2-H3-L-38-L-38-L-N-32-P2-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83014753	PUMP-VAR-DISPL CCW 90PV130	90L130-HF-5-CD-80-S-3-F1-F-03-GBA-42-42-24	SERIES 90	S90-130PV
83014756	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-N-T3-C0-L-N-L4-ABA-065-AA-E6-00-C2	SERIES 51	S51-160MV
83014757	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-AB-80-R-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
83014759	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-BC-80-R-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
83014763	PUMP-VAR-DISPL CCW H1PV165	H1-P-165-L-C-A2-C3-N-D3-G-G3-H6-L-20-L-35-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83014764	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KN-5-CD-60-R-4-C7-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83014765	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KN-5-CD-60-R-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83014766	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HS-5-BC-60-L-3-F1-F-04-GBA-35-35-24	SERIES 90	S90-100PV
83014767	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A4-C1-B-D6-H-G1-H2-L-30-L-30-C-L-28-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83014777	PUMP-VAR-DISPL CW 90PV100	90R100-MA-5-NN-80-L-4-F1-E-C5-GBA-23-23-24	SERIES 90	S90-100PV
83014778	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HF-1-NN-80-R-4-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83014790	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-AB-80-P-3-S1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
83014796	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-CD-80-S-4-F1-F-03-GBA-29-29-24	SERIES 90	S90-100PV
83014797	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-1-NN-80-T-C-F1-J-03-FAC-20-20-22	SERIES 90	S90-180PV
83014798	PUMP-VAR-DISPL CW 90PV130	90R130-DD-5-NN-80-S-3-C8-H-GB-GBA-42-42-24	SERIES 90	S90-130PV
83014800	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-T2-D2-N-B-TB-VS-ES-S-A-10-NN-022-Z-22-NNN	H1-HP MOTORS	H1-110MB1
83014801	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-L2-BA-N-C-PA-CS-JS-S-A-10-NN-070-N-00-NNN	H1-HP MOTORS	H1-110MB1
83014816	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-H-Z-C-S-BA-B-A-A-A-BJJ-AB-U-DD-B-C-A-A-BJJ-AB-U-DD-C-NNR-***	M46	M46-046PT
83014817	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-A-V-C-B-BA-B-B-A-A-BDD-CG-A-GG-B-D-A-A-BDD-CG-A-GG-C-NNN	M46	M46-046PT

83014819	PUMP-VAR DISPL, CW 90PV100	90-R-100-DD-1-NN-60-R-4-S1-E-GB-GBA-38-38-24	SERIES 90	S90-100PV
83014823	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-G-S-B-J-BA-J-A-BMJ-DA-A-GG-C-NNN-***	M46	M46-046PV
83014824	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-TH-CO-L-N-G0-NNN-056-AA-G3-00-B5	SERIES 51	S51-160MV
83014825	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-T2-DA-N-A-TA-VN-DN-N-A-30-NN-AA5-Z-21-NNN	H1-HP MOTORS	H1-160MB1
83014828	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-HS-A2-B-H-E1-NNN-050-AA-F3-08-25	SERIES 51	S51-250MV
83014830	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-NN-80-S-3-S1-E-05-GBA-42-42-24	SERIES 90	S90-100PV
83014831	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-ANN3-02-B-3-G-2-C-N-A-34-34-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83014832	PUMP-VAR-DISPL CCW 90PV180	90L180-KP-2-CD-80-T-C-F1-J-03-FAC-42-14-24	SERIES 90	S90-180PV
83014833	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-CD-80-P-3-C7-D-05-GBA-35-35-24	SERIES 90	S90-075PV
83014834	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-NN-80-P-3-S1-D-05-GBA-35-35-24	SERIES 90	S90-075PV
83014835	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-5-BC-80-R-3-K1-C-03-GBA-26-26-24	SERIES 90	S90-055PV
83014839	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-M2-CA-N-B-RA-VS-DS-S-N-NN-NN-000-N-00-NNN	H1-HP MOTORS	H1-110MB1
83014842	PUMP-VAR-DISPL CCW 90PV130	90L130-KN-1-NN-80-R-3-F1-F-03-GBA-42-42-24	SERIES 90	S90-130PV
83014843	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-NN-80-S-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83014848	PUMP-VAR-DISPL CW 90PV075	90R075-FL-5-AB-80-P-7-S1-E-B6-GME-40-40-28	SERIES 90	S90-075PV
83014849	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-T2-D2-N-B-TB-VN-DN-N-A-15-NN-067-Z-29-NNN	H1-HP MOTORS	H1-110MB1
83014853	PUMP-VAR-DISPL CCW H1PV147	H1-P-147-L-C-A5-C2-N-D8-G-G3-H3-L-38-L-38-A-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83014857	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HK-5-NN-60-R-3-T2-E-03-GBA-26-26-24	SERIES 90	S90-075PV
83014862	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-L1-BA-N-A-PA-DN-JN-N-A-10-NN-025-N-00-NNN	H1-HP MOTORS	H1-080MB1
83014863	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-G2A1-50-U-2-G-2-F-5-B-30-30-B-0-0-NNN-NNN	SERIES 42	S42-028PV/032PV
83014864	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-G2A1-50-U-2-G-2-F-5-A-30-30-B-0-0-NNN-NNN	SERIES 42	S42-028PV/032PV
83014870	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-L8-B1-V-A-G5-NNN-045-AA-NN-B2-00	SERIES 51	S51-160MV
83014871	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-H-S-B-J-BA-V-A-BFF-DB-A-GG-A-NNN-***	M46	M46-046PV
83014873	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-NN-60-S-3-K2-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83014874	MOTOR-VAR-DISPL 51MC080	51C080-R-D2-N-L1-B1-W-B-M3-AWA-035-AA-E6-D4-00	SERIES 51	S51-080MV
83014879	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-BC-80-R-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83014884	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-HE-HE-N-B-TA-DN-KN-N-N-NN-NN-108-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83014885	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KE-1-CE-80-R-3-F1-G-26-GFD-42-42-24	SERIES 90	S90-100PV
83014886	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-H-T-B-B-BA-A-A-BFF-CE-A-GG-A-NNN-***	M46	M46-046PV
83014889	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-K1-K1-N-B-RB-DN-KN-N-A-10-NN-034-N-30-NNN	H1-HP MOTORS	H1-110MB1
83014891	PUMP-VAR-DISPL CCW 90PV130	90L130-HF-5-BC-80-D-3-C8-L-01-GBA-32-32-24	SERIES 90	S90-130PV
83014894	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-N-N1-NN-N-N-U1-NNN-018-AA-E6-00-00	SERIES 51	S51-060MV-1
83014895	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-G-T-B-B-BA-A-A-BFF-CE-A-GG-C-NNN-***	M46	M46-046PV
83014898	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-L2-BA-N-B-PA-DS-KS-S-A-15-NN-000-N-00-NNN	H1-HP MOTORS	H1-160MB1
83014907	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-K2-K2-N-B-RB-VN-DN-N-A-15-NN-056-N-25-NNN	H1-HP MOTORS	H1-110MB1
83014909	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A2-C3-N-D3-G-G2-H3-L-35-L-35-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV

83014915	PUMP-VAR-DISPL CCW H1PV147	H1-P-147-L-C-A3-C2-N-D8-G-G3-NN-L-35-L-35-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83014916	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A2-C2-N-D6-G-G3-H3-K-45-L-42-L-L-28-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83014917	PUMP-VAR-DISPL CCW 90PV075	90L075-MA-5-CD-60-S-3-G1-D-C5-GBA-42-42-24	SERIES 90	S90-075PV
83014918	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-T4-C0-L-N-G0-ADA-032-AA-F0-00-B2	SERIES 51	S51-160MV
83014919	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-T4-C0-L-N-G0-ADA-050-AA-F0-00-B2	SERIES 51	S51-250MV
83014920	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A4-C2-N-D8-F-G5-H5-L-35-L-35-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83014925	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A3-C2-N-D3-G-G2-H4-L-33-L-33-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83014926	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A3-C2-N-D3-G-G3-H1-L-33-L-33-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83014927	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A3-C2-N-D3-G-G3-NN-L-33-L-33-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83014931	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-AB-60-S-3-S1-D-00-GBA-17-17-20	SERIES 90	S90-055PV
83014942	PUMP-VAR DISPL, CW 90PV075	90-R-075-KN-1-BC-80-R-4-S1-D-03-GBA-29-29-24	SERIES 90	S90-075PV
83014943	PUMP-VAR DISPL, CW 90PV075	90-R-075-KN-1-NN-80-R-4-S1-D-03-GBA-29-29-24	SERIES 90	S90-075PV
83014944	MOTOR-VAR-DISPL 51MC060-1	51C060-1--A-D1-N-TH-CA-N-N-X1-NNN-024-AA-E4-00-18	SERIES 51	S51-060MV-1
83014945	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A5-C2-N-D6-F-G5-H1-L-35-L-35-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83014946	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E1-AA-N-A-TB-CS-JS-S-A-05-NN-030-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83014947	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E1-AA-N-A-TB-CS-HS-S-A-05-NN-030-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83014948	PUMP-VAR-DISPL CCW 90PV180	90L180-MA-5-AB-80-S-M-F1-H-C5-FAC-32-14-30	SERIES 90	S90-180PV
83014949	PUMP-VAR DISPL, CW 90PV100	90-R-100-KN-5-CD-80-S-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83014950	PUMP-VAR DISPL, CW 90PV055	90-R-055-KN-5-AB-80-S-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83014951	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-CD-80-P-3-F1-H-04-GBA-35-35-20	SERIES 90	S90-130PV
83014955	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-NN-80-L-3-F1-H-03-GBA-42-42-24	SERIES 90	S90-130PV
83014962	MOTOR-VAR-DISPL H1B110	H1-B-110-A-TA-DA-N-C-TB-VN-EN-N-A-10-NN-074-Z-30-NNN	H1-HP MOTORS	H1-110MB1
83014963	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HS-1-BC-80-P-4-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83014966	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-BC-60-R-4-S1-E-03-GBA-32-32-24	SERIES 90	S90-100PV
83014977	PUMP-VAR-DISPL CCW H1PV147	H1-P-147-L-C-C6-C2-N-D4-G-G3-NN-L-33-L-33-L-M-32-PN-NNN-G18	H1-HP PUMPS	H1-147PV/165PV
83014978	PUMP-VAR-DISPL CCW H1PV089	H1-P-089-L-A-C6-C2-N-D3-H-G1-NN-L-28-L-28-M-M-32-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83014979	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-C6-C1-B-D4-G-G3-NN-L-33-L-33-A-M-24-PN-NNN-G18	H1-HP PUMPS	H1-115PV/130PV
83014981	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A5-C3-N-D6-G-G2-H6-L-45-L-45-A-L-22-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83014983	MOTOR-VAR-DISPL 51MV080-1	51V080-1--A-S1-N-T1-D1-N-N-X1-NNN-016-AA-NN-00-24	SERIES 51	S51-080MV-1
83014984	PUMP-VAR DISPL, CW 90PV055	90-R-055-KN-1-NN-80-L-3-S1-D-03-GBA-17-17-24	SERIES 90	S90-055PV
83014997	PUMP-VAR DISPL, CW 90PV055	90-R-055-PB-5-NN-80-R-4-S1-C-03-GBA-29-29-24	SERIES 90	S90-055PV
83015000	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-B1-C1-N-D6-G-G2-H6-L-35-L-35-L-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83015001	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-A-A3-C2-N-F6-H-G9-H6-L-35-L-35-D-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83015005	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KN-1-CD-80-R-3-S1-E-03-GBA-29-29-24	SERIES 90	S90-075PV
83015006	PUMP-VAR-DISPL CCW 90PV180	90L180-KN-1-NN-80-T-C-F1-J-03-FAC-42-42-24	SERIES 90	S90-180PV
83015010	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-T1-DA-N-B-TA-DN-GN-N-N-NN-017-Z-28-NNN	H1-HP MOTORS	H1-060MB1

83015016	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MV-1-BC-60-R-3-F1-E-03-GBA-38-38-24	SERIES 90	S90-100PV
83015017	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MA-1-NN-60-R-3-F1-E-03-GBA-38-38-24	SERIES 90	S90-100PV
83015019	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HF-1-BB-80-L-4-S1-E-01-GBA-23-23-24	SERIES 90	S90-100PV
83015020	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HF-1-BB-80-L-4-T2-E-01-GBA-23-23-24	SERIES 90	S90-100PV
83015021	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-CD-60-L-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83015022	PUMP-VAR DISPL CCW H1P060L	H1-P-060-L-A-A4-C3-N-D8-H-G1-NN-L-35-L-35-F-P-28-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83015024	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A5-C2-N-D3-H-G9-H2-L-42-L-42-D-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83015025	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A4-C2-N-D1-F-G5-H3-38-38-38-38-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83015026	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A5-C2-N-D8-H-G9-H2-L-33-L-33-D-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83015027	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-N-A4-C2-N-D1-F-G5-H3-38-38-38-38-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83015029	MOTOR-VAR-DISPL 51MC110-1	51C110-1--A-D3-N-E1-B1-N-N-U1-NNN-032-AA-F0-00-00	SERIES 51	S51-110MV-1
83015032	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-L2-BA-N-A-PB-VN-AN-N-A-10-NN-040-N-00-NNN	H1-HP MOTORS	H1-080MB1
83015033	PUMP-VAR-DISPL CCW 90PV042	90L042-KA-5-NN-80-S-3-C3-C-00-GCP-32-32-28	SERIES 90	S90-042PV
83015040	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KT-P-NN-60-D-3-S1-L-03-GBA-45-45-24	SERIES 90	S90-075PV
83015044	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-N-A4-C1-N-D1-F-G1-H3-38-38-38-38-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83015045	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A4-C1-N-D1-F-G1-H3-38-38-38-38-N-P-24-PN-C13-NNN	H1-MP PUMPS	H1-045PT/053PT
83015049	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-CD-80-S-3-C8-H-03-GBA-42-42-28	SERIES 90	S90-130PV
83015050	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-NN-80-S-3-S1-E-03-GBA-30-30-28	SERIES 90	S90-075PV
83015051	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-NN-80-S-4-S1-E-03-GBA-30-30-28	SERIES 90	S90-075PV
83015052	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-1-NN-80-R-4-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
83015053	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-T2-D2-N-B-TB-DN-KN-N-A-20-NN-047-Z-26-NNN	H1-HP MOTORS	H1-160MB1
83015054	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-T2-D2-N-B-TB-DS-KS-S-A-20-NN-047-Z-26-NNN	H1-HP MOTORS	H1-160MB1
83015055	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HS-1-NN-60-P-4-S1-E-03-GBA-32-14-30	SERIES 90	S90-100PV
83015060	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A4-C3-N-D8-F-G5-NN-L-20-L-20-B-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83015061	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A4-C3-N-D1-F-G5-H5-30-30-30-30-N-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83015062	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-1-CD-80-R-4-C6-E-02-GBA-29-29-24	SERIES 90	S90-075PV
83015063	PUMP-VAR-DISPL CCW 90PV075	90L075-DC-5-AB-80-R-4-C6-D-GB-GBA-42-42-24	SERIES 90	S90-075PV
83015064	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-AB-80-S-3-C7-F-03-GBA-30-30-24	SERIES 90	S90-100PV
83015065	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-CD-80-S-3-C7-D-03-GBA-30-30-24	SERIES 90	S90-075PV
83015068	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E2-AA-N-B-TB-CN-JN-N-A-05-NN-032-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83015073	MOTOR-VAR-DISPL 51MV160	51V160-A-C8-N-D8-M1-R-J-N7-NNN-105-AA-H0-C2-20	SERIES 51	S51-160MV
83015076	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-1-NN-60-R-4-S1-D-00-GBA-26-26-24	SERIES 90	S90-075PV
83015077	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-1-CD-60-L-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83015082	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-1-NN-80-L-4-S1-D-03-GBA-17-17-24	SERIES 90	S90-055PV
83015090	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HM-1-CD-80-R-4-K3-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83015091	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-1-CD-80-L-3-S1-D-01-GBA-35-35-24	SERIES 90	S90-075PV

83015092	PUMP-TANDEM, VAR DISPL CCW H1T045L	H1-T-045-L-A-N-A2-C2-B-E7-F-G5-TN-28-28-28-28-M-P-26-PN-NNN-S04	H1-MP PUMPS	H1-045PT/053PT
83015093	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A3-C3-B-D3-H-G1-H5-K-40-K-40-F-M-30-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83015097	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-NN-80-R-3-C6-C-03-GBA-30-14-28	SERIES 90	S90-055PV
83015098	PUMP-VAR-DISPL 42PV041 CCW	42-L-41-D-E1A6-02-B-3-G-3-F-N-A-32-32-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83015100	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-G2A1-52-U-2-G-2-F-1-A-21-21-B-1-1-NNN-NNN	SERIES 42	S42-028PV/032PV
83015103	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E2-AA-N-B-TB-VN-AN-N-A-10-NN-033-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83015104	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-E2-AA-N-B-TB-VS-ES-S-A-20-NN-080-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83015105	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-NN-60-R-4-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83015106	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A5-C2-B-D3-G-G2-NN-L-42-L-42-A-M-26-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83015107	PUMP-VAR-DISPL CCW 90PV250	90L250-KP-5-EF-80-S-4-F1-J-03-NNN-20-20-24	SERIES 90	S90-250PV
83015109	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-2-BC-80-L-3-F1-H-03-GBA-45-14-24	SERIES 90	S90-130PV
83015110	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-5-CD-60-P-3-S1-D-03-GBA-45-45-24	SERIES 90	S90-055PV
83015111	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-5-NN-60-P-3-S1-D-03-GBA-45-45-24	SERIES 90	S90-055PV
83015116	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-BC-80-P-3-S1-C-00-EEB-20-20-24	SERIES 90	S90-055PV
83015118	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MA-1-NN-60-L-3-F1-E-03-GBA-26-26-24	SERIES 90	S90-100PV
83015120	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-NN-60-S-3-S1-D-03-GBA-38-38-22	SERIES 90	S90-075PV
83015122	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-CD-60-S-3-F1-E-03-GBA-35-35-20	SERIES 90	S90-100PV
83015123	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-BC-80-R-4-S1-D-03-GBA-23-23-24	SERIES 90	S90-075PV
83015124	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-CD-80-R-4-S1-D-03-GBA-23-23-24	SERIES 90	S90-075PV
83015127	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A8-C2-C-D6-J-G5-H3-L-35-L-35-B-L-24-P2-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83015128	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-NN-80-P-3-S1-D-00-GBA-32-32-24	SERIES 90	S90-075PV
83015132	PUMP-VAR-DISPL CCW 90PV042	90L042-KA-5-BC-80-P-3-C3-C-00-GBA-35-35-24	SERIES 90	S90-042PV
83015134	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A7-C2-C-D3-L-G3-H3-L-42-L-42-A-M-24-P2-NNN-D3F	H1-HP PUMPS	H1-115PV/130PV
83015135	MOTOR-VAR-DISPL 51MV110	51V110-R-C8-N-HZ-B1-B-E-C2-NNN-025-AA-NN-09-00	SERIES 51	S51-110MV
83015136	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-BB-80-S-3-C8-H-03-GBA-42-42-24	SERIES 90	S90-130PV
83015137	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-DE-80-S-4-C8-K-03-NNN-35-35-24	SERIES 90	S90-250PV
83015138	PUMP-VAR-DISPL CCW 90PV100	90L100-DC-5-BC-60-S-3-C7-E-GB-GBA-42-42-24	SERIES 90	S90-100PV
83015139	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-BC-80-D-C-C8-L-03-NNN-30-30-24	SERIES 90	S90-180PV
83015140	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-5-NN-80-S-4-S1-C-03-GBA-30-30-20	SERIES 90	S90-055PV
83015143	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-BC-80-P-3-C3-C-00-GBA-35-35-24	SERIES 90	S90-042PV
83015144	PUMP-VAR-DISPL 42PV041 CCW	42-L-41-D-E1A6-02-A-N-A-3-F-N-A-32-32-B-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83015147	PUMP-VAR DISPL, CW 90PV100	90-R-100-HF-1-NN-80-L-4-S1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
83015150	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-N-A2-C2-N-D1-F-G1-TN-33-33-33-33-M-P-24-PN-NNN-S02	H1-MP PUMPS	H1-045PT/053PT
83015154	PUMP-VAR-DISPL CCW 90PV075	90L075-MA-5-CD-60-S-3-C6-D-C5-GBA-42-42-24	SERIES 90	S90-075PV
83015156	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-AB-60-S-3-F1-E-03-GBA-26-26-24	SERIES 90	S90-100PV
83015165	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E2-AA-N-A-TB-VS-ES-S-A-15-NN-050-Z-00-NNN	H1-HP MOTORS	H1-110MB1

83015166	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E2-AA-N-A-TB-VN-EN-N-A-15-NN-050-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83015167	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-1-NN-80-S-3-C6-C-03-GBA-42-42-24	SERIES 90	S90-055PV
83015168	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-BC-80-R-3-F1-F-03-GBA-23-23-24	SERIES 90	S90-100PV
83015171	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-L2-B1-V-A-G5-NNN-045-AA-NN-B2-00	SERIES 51	S51-160MV
83015173	PUMP-VAR-DISPL CCW 90PV180	90L180-KP-5-NN-80-S-C-F1-J-03-FAC-21-21-24	SERIES 90	S90-180PV
83015180	PUMP-VAR-DISPL CCW H1PV130	H1-P-130-L-B-A5-C2-N-D3-G-G2-H3-L-25-L-25-A-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83015181	PUMP-VAR-DISPL CCW H1PV130	H1-P-130-L-B-A5-C2-N-D3-G-G2-H3-L-42-L-42-A-M-26-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83015182	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-N2-NN-N-N-A0-NNN-032-AA-H0-00-00	SERIES 51	S51-160MV
83015186	PUMP-VAR-DISPL CW 90PV250	90R250-MB-5-BC-80-T-4-C8-K-C5-NNN-42-42-24	SERIES 90	S90-250PV
83015190	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-NN-80-P-3-S1-E-03-GBA-35-35-20	SERIES 90	S90-100PV
83015193	PUMP-VAR DISPL MPV035D	MPV-035-D-B-A-Y-R-S-G-AA-A-A-BMM-DL-A-FF-A-NNN-***	M35/44	O35PV
83015194	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A2-C2-N-F4-H-F1-H6-L-35-L-35-C-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83015195	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A2-C2-B-D3-H-G1-NN-L-23-L-23-F-M-20-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83015196	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E1-AA-N-B-TB-CN-GN-N-A-05-NN-035-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83015197	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KN-1-BC-80-S-4-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83015200	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-L8-B1-V-A-G5-ANB-145-AA-G0-B2-00	SERIES 51	S51-250MV
83015202	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-B-T-B-B-BA-V-A-BFF-BA-A-HH-A-NNN-***	M46	M46-046PV
83015212	MOTOR-VARIABLE DISPL SAE_K	K-V-45DN-E-YNF-F10-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83015214	PUMP-VAR-DISPL CCW 90PV130	90L130-HF-1-NN-80-S-4-F1-H-03-GBA-23-23-24	SERIES 90	S90-130PV
83015215	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-1-DG-80-D-4-C8-L-03-GBA-35-35-34	SERIES 90	S90-130PV
83015216	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-1-CD-80-D-4-C8-L-03-GBA-35-35-34	SERIES 90	S90-130PV
83015222	PUMP-VAR-DISPL CCW 90PV075	90L075-KP-1-CD-82-P-3-S1-D-03-GBA-35-35-20	SERIES 90	S90-075PV
83015227	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A3-C2-N-D3-G-G3-H5-L-42-L-42-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83015230	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-M2-CA-N-A-RB-DS-LS-S-A-30-NN-000-N-00-NNN	H1-HP MOTORS	H1-160MB1
83015231	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-TA-C2-N-N-X1-NNN-060-AA-F0-00-22	SERIES 51	S51-110MV-1
83015232	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-TA-C2-N-N-X1-ABA-080-AA-F0-00-22	SERIES 51	S51-110MV-1
83015239	PUMP-VAR DISPL, CW 90PV100	90-R-100-M8-1-BC-60-L-3-F1-F-03-GBA-35-35-28	SERIES 90	S90-100PV
83015241	MOTOR-VAR-DISPL 51MV080	51V080-A-S1-N-HZ-B1-B-H-C2-NNN-030-AA-NN-05-00	SERIES 51	S51-080MV
83015244	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-L2-BA-N-B-PA-DS-KS-S-A-10-NN-000-N-00-NNN	H1-HP MOTORS	H1-110MB1
83015245	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A2-C2-N-D6-G-G3-NN-L-23-L-23-L-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83015246	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-HZ-B1-B-N-C2-NNN-050-AA-G3-10-00	SERIES 51	S51-250MV
83015248	PUMP-VAR-DISPL CW 90PV100	90R100-HF-5-BC-60-S-4-F1-F-03-GBA-17-17-20	SERIES 90	S90-100PV
83015249	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-CD-80-P-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-075PV
83015250	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-P1-DA-N-B-TB-CN-GN-N-A-05-NN-030-Z-24-NNN	H1-HP MOTORS	H1-060MB1
83015251	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-P1-DA-N-B-TB-CN-HN-N-A-05-NN-040-Z-24-NNN	H1-HP MOTORS	H1-080MB1
83015252	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A5-C3-N-D3-H-G1-NN-K-42-K-42-M-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV

83015254	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-CD-80-S-M-C8-J-03-NNN-42-42-24	SERIES 90	S90-180PV
83015256	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A8-C2-C-E9-F-G5-H3-K-35-K-35-B-P-24-P1-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83015262	PUMP-VAR-DISPL CCW 90PV130	90L130-KT-1-CD-80-R-3-F1-H-03-GBA-38-38-24	SERIES 90	S90-130PV
83015263	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KT-1-NN-80-R-3-S1-C-03-GBA-32-32-24	SERIES 90	S90-055PV
83015264	PUMP-VAR-DISPL CCW H1PV130	H1-P-130-L-B-A5-C2-N-D8-G-G3-NN-L-40-L-40-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83015265	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E2-AA-N-A-TB-CN-JN-N-N-NN-NN-040-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83015274	PUMP-VAR DISPL, CW 90PV100	90-R-100-KN-5-BC-80-S-4-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83015276	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E1-AA-N-B-TB-DN-JN-N-N-NN-NN-035-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83015280	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-HZ-B1-B-N-C2-NNN-050-AA-H0-12-00	SERIES 51	S51-250MV
83015281	MOTOR-VAR DISPL MMV046C	MMV-046-C-A-D-A-E-AK-VNA-***	M46	M46-046MV
83015289	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A5-C2-N-D6-G-G2-H6-L-40-L-40-L-L-20-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83015290	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-BB-60-S-4-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83015294	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-M2-CA-N-B-RB-VN-AN-N-N-NN-NN-000-N-00-NNN	H1-HP MOTORS	H1-080MB1
83015300	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-D-T-B-B-AA-A-A-BEE-CH-A-GG-B-NNN-***	M46	M46-046PV
83015301	PUMP-VAR-DISPL CW 90PV250	90R250-KN-5-NN-80-S-4-C8-J-02-NNN-36-36-24	SERIES 90	S90-250PV
83015302	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-D-T-B-B-AA-A-A-BEE-BA-A-GG-B-NNN-***	M46	M46-046PV
83015305	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KN-1-NN-80-R-3-S1-E-03-GBA-42-14-24	SERIES 90	S90-100PV
83015306	PUMP-VAR-DISPL 42PV028 CW	42-R-28-G-E1A6-02-B-2-G-2-C-N-N-17-14-B-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83015308	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E2-AA-N-B-TB-CN-GN-N-A-10-NN-032-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83015310	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A3-C2-N-D3-G-G3-H3-L-45-L-45-L-M-30-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83015311	MOTOR-VAR-DISPL 51MV160	51V160-V-F1-N-H4-B3-R-J-N2-NNN-070-AA-NN-C2-21	SERIES 51	S51-160MV
83015312	PUMP-VAR-DISPL 42PV041 CCW	42-L-41-D-E1A6-03-A-N-A-2-F-N-A-28-28-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83015313	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-E1A6-01-B-2-G-2-C-N-B-14-14-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83015315	PUMP-VAR-DISPL 42PV041 CW	42-R-5A-D-E1A5-00-B-D-G-3-F-N-A-34-34-N-N-N-AAA-NNN	SERIES 42	S42-041PV/051PV
83015316	MOTOR-VAR-DISPL H1MB060	H1-B-060-A-L1-BA-N-B-PB-VS-AS-S-A-05-NN-000-N-00-NNN	H1-HP MOTORS	H1-060MB1
83015318	MOTOR-VARIABLE CARTRIDGE K	K-C-38CS-E-YNF-F09-S-N-N-CF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83015322	MOTOR-VAR-DISPL 51MV160	51V160-V-F1-C-H4-B3-R-J-N2-NNN-075-AA-NN-C2-18	SERIES 51	S51-160MV
83015338	PUMP-VAR DISPL, CW 90PV100	90-R-100-HS-1-CD-80-S-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83015348	PUMP-VAR-DISPL CW 90PV130	90R130-MA-1-BC-80-S-4-F1-H-03-GBA-35-35-30	SERIES 90	S90-130PV
83015352	PUMP-VAR-DISPL CW 90PV130	90R130-KA-1-NN-80-R-3-C8-H-03-GBA-35-35-20	SERIES 90	S90-130PV
83015353	MOTOR-VARIABLE DISPL SAE_K	K-V-38CS-E-YNF-F09-S-N-N-CF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83015354	PUMP-VAR DISPL, CW 90PV075	90-R-075-HF-1-NN-60-S-3-C6-D-03-GBA-42-42-24	SERIES 90	S90-075PV
83015355	PUMP-VAR DISPL, CW 90PV100	90-R-100-KN-5-NN-80-S-4-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83015357	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-D4-C2-N-D8-G-G3-NN-L-35-L-35-L-P-32-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83015362	PUMP-VAR DISPL, CW 90PV055	90-R-055-FC-1-BC-80-P-7-C6-C-B1-GBA-20-20-24	SERIES 90	S90-055PV
83015372	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-CD-80-P-3-C7-E-03-EBC-42-42-24	SERIES 90	S90-075PV

83015373	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-A-Z-C-B-AA-B-A-A-A-BDD-AB-U-CF-B-C-A-A-BDD-AB-D-CF-B-NNN-*	M46	M46-046PT
83015375	PUMP-VAR-DISPL CCW 90PV075	90L075-FM-1-NN-60-S-7-C6-D-B6-GME-38-38-24	SERIES 90	S90-075PV
83015379	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-CD-80-P-3-C8-H-03-GBA-35-35-24	SERIES 90	S90-130PV
83015380	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-1-CD-80-S-3-C8-J-04-NNN-38-38-28	SERIES 90	S90-250PV
83015381	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-BC-80-S-3-C8-J-03-NNN-42-42-24	SERIES 90	S90-250PV
83015382	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-P2-DA-N-B-TA-VN-EN-N-A-15-NN-060-Z-24-NNN	H1-HP MOTORS	H1-160MB1
83015383	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-P2-DA-N-B-TA-VS-ES-S-A-15-NN-060-Z-24-NNN	H1-HP MOTORS	H1-160MB1
83015390	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-C-E2D8-03-A-N-A-3-G-N-N-23-23-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83015393	PUMP-VAR-DISPL 42PV041 CW	42-R-41-E-E2C8-00-A-N-A-2-D-N-V-C0-C0-N-A-A-NNN-ENN	SERIES 42	S42-041PV/051PV
83015395	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-CD-60-S-3-C7-D-03-GBA-23-23-24	SERIES 90	S90-100PV
83015397	MOTOR-VAR-DISPL 51MC080	51C080-R-D3-N-HZ-B1-A-H-C2-ADC-045-AA-F0-05-00	SERIES 51	S51-080MV
83015398	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-NN-80-T-M-C8-J-03-NNN-32-32-24	SERIES 90	S90-180PV
83015399	MOTOR-VAR-DISPL 51MV250	51V250-A-C8-N-HZ-B1-C-N-C2-NNN-168-AA-G3-20-00	SERIES 51	S51-250MV
83015403	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-CD-80-P-3-S1-D-05-GBA-35-35-24	SERIES 90	S90-075PV
83015405	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-CD-80-P-3-S1-E-03-GBA-29-29-24	SERIES 90	S90-075PV
83015409	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-AB-60-S-3-S1-C-03-GBA-23-23-24	SERIES 90	S90-055PV
83015410	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-L2-BA-N-A-PA-CS-LS-S-A-20-NN-032-N-00-NNN	H1-HP MOTORS	H1-160MB1
83015411	PUMP-VAR-DISPL CW 90PV130	90R130-HF-5-CD-80-L-3-F1-H-04-GBA-32-32-34	SERIES 90	S90-130PV
83015412	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-HS-A2-B-E-E1-NNN-064-AA-E6-05-27	SERIES 51	S51-160MV
83015415	PUMP-VAR-DISPL CW 90PV100	90R100-HF-5-CD-80-R-4-C7-E-03-GBA-23-23-24	SERIES 90	S90-100PV
83015417	MOTOR-VAR-DISPL 51MV110	51V110-A-C8-N-HZ-B1-A-H-C2-NNN-022-AA-F0-05-00	SERIES 51	S51-110MV
83015418	PUMP-VAR DISPL, CW 90PV055	90-R-055-HF-1-NN-60-P-4-S1-D-03-GBA-29-29-24	SERIES 90	S90-055PV
83015421	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-N-TA-C2-L-N-G0-ABA-105-AA-NN-00-A3	SERIES 51	S51-160MV
83015423	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-E8-A2-A-N-A7-NNN-125-AA-F3-03-19	SERIES 51	S51-250MV
83015424	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-NN-80-R-3-C6-C-03-GBA-30-14-28	SERIES 90	S90-055PV
83015428	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A5-C2-N-D3-H-G9-H3-L-42-L-15-C-M-30-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83015433	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-AB-60-S-4-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83015434	PUMP-VAR DISPL, CW 90PV055	90-R-055-HS-2-NN-60-S-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83015435	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-BC-60-S-4-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83015436	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-BC-80-L-3-C8-F-00-GBA-42-42-26	SERIES 90	S90-130PV
83015437	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E2-AA-N-B-TB-VN-EN-N-A-15-NN-022-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83015442	PUMP-VAR-DISPL CW 90PV250	90R250-KN-5-CD-80-T-4-F1-K-03-NNN-14-14-24	SERIES 90	S90-250PV
83015443	PUMP-VAR-DISPL CW 90PV100	90R100-MA-1-AB-60-L-4-C7-E-05-GBA-29-29-24	SERIES 90	S90-100PV
83015446	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-BC-80-S-3-S1-D-03-GBA-35-32-24	SERIES 90	S90-075PV
83015450	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-C-ANNB-03-C-3-A-2-F-N-B-36-36-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83015456	MOTOR- VARIABLE CARTRIDGE L	L-C-30DS-E-R2F-F10-S-N-N-FF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV

83015457	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A3-C2-N-D6-H-F4-H1-L-35-L-35-M-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83015461	PUMP-VAR DISPL, CCW 90PV055	90-L-055-ME-1-NN-60-S-3-C6-D-03-GBA-38-38-24	SERIES 90	S90-055PV
83015463	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A4-C2-N-E8-G-G3-H3-L-45-L-45-L-L-24-PN-NNN-G21	H1-HP PUMPS	H1-115PV/130PV
83015469	PUMP-VAR-DISPL CCW 90PV180	90L180-KP-5-NN-80-T-M-F1-H-00-FAC-23-23-24	SERIES 90	S90-180PV
83015471	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-BC-80-R-4-T4-F-00-GBA-23-23-24	SERIES 90	S90-130PV
83015473	PUMP-VAR-DISPL CW 90PV130	90R130-FH-2-BB-80-S-B-C8-F-B1-GBA-42-42-26	SERIES 90	S90-130PV
83015476	PUMP-VAR-DISPL CW 90PV075	90R075-KA-1-AB-60-P-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83015478	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-K1-K1-N-A-RA-DN-KN-N-A-20-NN-055-N-25-NNN	H1-HP MOTORS	H1-160MB1
83015479	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-N2-NN-N-N-A0-ADA-150-AA-H0-00-00	SERIES 51	S51-250MV
83015480	MOTOR-VAR-DISPL 51MV110	51V110-R-F1-N-N2-NN-N-N-A0-NNN-070-AA-E6-00-00	SERIES 51	S51-110MV
83015482	PUMP-VAR-DISPL CW 90PV250	90R250-KP-5-NN-80-T-4-F1-K-04-NNN-32-32-24	SERIES 90	S90-250PV
83015485	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-HE-HE-N-B-TB-VS-ES-S-N-NN-NN-040-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83015488	PUMP-VAR-DISPL CW 90PV100	90R100-KN-5-NN-80-S-4-C7-F-03-GBA-32-32-24	SERIES 90	S90-100PV
83015489	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A2-C1-N-D8-F-G5-H3-L-28-L-28-B-P-22-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83015490	PUMP-VAR-DISPL CCW 90PV100	90L100-KN-5-NN-80-S-4-T2-F-03-GBA-35-35-24	SERIES 90	S90-100PV
83015494	PUMP-VAR-DISPL CCW 90PV130	90L130-MA-5-NN-80-L-3-F1-F-C5-GBA-32-35-20	SERIES 90	S90-130PV
83015497	PUMP-VAR-DISPL CCW 90PV075	90L075-FN-5-CD-80-P-7-C7-E-B6-GME-35-35-28	SERIES 90	S90-075PV
83015498	PUMP-VAR-DISPL CCW 90PV075	90L075-CA-5-CD-80-P-7-S1-E-00-GCA-35-35-28	SERIES 90	S90-075PV
83015503	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-N-HS-A2-C-E-G6-NNN-044-AA-NN-18-24	SERIES 51	S51-160MV
83015504	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-5-AB-60-P-4-S1-D-G4-GBA-35-35-20	SERIES 90	S90-055PV
83015505	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E2-AA-N-B-TB-CN-JN-N-A-05-NN-024-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83015528	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-NN-60-S-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
83015529	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-AB-60-S-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83015534	PUMP-VAR-DISPL CW 90PV180	90R180-FH-5-CD-80-T-7-C8-J-B9-EBA-42-42-30	SERIES 90	S90-180PV
83015552	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-W-S-B-B-AA-A-A-BHH-CE-A-JJ-3-NNN-***	M46	M46-046PV
83015553	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-W-T-B-B-AA-A-A-BHH-BA-A-JJ-A-NNN-***	M46	M46-046PV
83015555	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KT-5-BC-80-R-3-S1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
83015556	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A2-C2-N-D6-G-G3-H4-K-45-L-42-L-L-28-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83015557	PUMP-VAR-DISPL CCW 90PV130	90L130-FH-5-NN-80-S-7-C8-H-B1-GBA-42-42-30	SERIES 90	S90-130PV
83015558	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E2-AA-N-B-TA-CN-GN-N-N-NN-NN-014-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83015559	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-N-T3-C2-L-N-K7-NNN-050-AA-E6-00-B8	SERIES 51	S51-160MV
83015560	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-NN-80-S-3-S1-E-03-GBA-45-45-30	SERIES 90	S90-075PV
83015561	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E2-AA-N-B-TB-CN-GN-N-N-NN-NN-030-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83015562	PUMP-VAR DISPL, CW 90PV075	90-R-075-DD-5-AB-60-P-4-S1-C-G8-GBA-35-35-24	SERIES 90	S90-075PV
83015565	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A5-C2-N-D3-G-G2-H3-L-38-L-20-L-M-20-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83015567	MOTOR-VARIABLE DISPL SAE_L	L-V-30DN-A-RNF-F07-S-N-N-AF-F17-NNN-NNN	LV / KV MOTORS	L/K-MV

83015568	PUMP-VAR-DISPL CW 90PV180	90R180-KN-5-NN-80-T-C-C8-H-03-NNN-42-42-24	SERIES 90	S90-180PV
83015570	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-2-BC-80-R-3-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83015572	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-E1A4-03-C-2-A-2-H-N-B-25-25-B-H-H-NNN-NNN	SERIES 42	S42-028PV/032PV
83015573	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-BC-80-L-3-C8-F-00-GBA-26-26-24	SERIES 90	S90-130PV
83015574	MOTOR-VAR-DISPL 51MV110-1	51V110-1--A-F1-N-TA-C2-N-N-X1-NNN-060-AA-E6-00-24	SERIES 51	S51-110MV-1
83015575	PUMP-VAR-DISPL CCW 90PV130	90L130-CA-5-NN-80-S-7-C8-H-00-GBA-42-42-30	SERIES 90	S90-130PV
83015577	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-K-S-A-B-BC-A-A-BJJ-CM-A-HH-B-NNN-***	M46	M46-046PV
83015579	PUMP-VAR-DISPL CW 90PV100	90R100-KN-5-CD-80-P-4-C7-F-03-GBA-35-35-24	SERIES 90	S90-100PV
83015580	PUMP-VAR DISPL, CW 90PV055	90-R-055-HF-5-BC-60-S-3-S1-C-03-GBA-40-40-24	SERIES 90	S90-055PV
83015581	MOTOR-VAR-DISPL 51MD080	51D080-R-D3-N-HZ-B1-C-E-G0-NNN-025-AA-F0-13-00	SERIES 51	S51-080MV
83015584	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A5-C2-N-D6-H-F1-NN-L-35-L-35-C-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83015591	MOTOR-VAR-DISPL H1MB060	H1-B-060-A-L1-BA-N-A-PA-CS-GS-S-A-10-NN-020-N-00-NNN	H1-HP MOTORS	H1-060MB1
83015592	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-HE-HE-N-C-TB-CN-GN-N-A-05-NN-022-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83015594	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-ANN5-02-B-D-B-2-H-N-A-34-34-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83015599	PUMP-VAR-DISPL CCW H1PV089	H1-P-089-L-A-A3-C1-N-D3-H-F1-NN-L-40-L-40-M-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83015604	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A3-C1-N-F4-H-F1-H6-L-40-L-40-M-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83015605	MOTOR-VAR-DISPL H1MB060	H1-B-060-A-L2-BA-N-B-PA-VS-AS-S-A-10-NN-040-N-00-NNN	H1-HP MOTORS	H1-060MB1
83015606	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-2-NN-80-L-3-F1-H-00-GBA-42-42-24	SERIES 90	S90-130PV
83015607	PUMP-VAR-DISPL CW 90PV130	90R130-KP-2-NN-80-L-3-F1-H-00-GBA-42-42-24	SERIES 90	S90-130PV
83015611	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KN-1-NN-80-R-3-F1-E-03-GBA-42-14-24	SERIES 90	S90-100PV
83015612	MOTOR-VARIABLE DISPL SAE_L	L-V-30DN-A-RNF-F10-S-N-N-AF-F17-NNN-NNN	LV / KV MOTORS	L/K-MV
83015614	PUMP-VAR-DISPL CW 90PV180	90R180-MA-5-AB-80-S-M-F1-H-C5-FAC-32-14-30	SERIES 90	S90-180PV
83015620	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-5-NN-80-T-4-F1-J-03-NNN-35-35-24	SERIES 90	S90-250PV
83015621	PUMP-VAR-DISPL CW 90PV130	90R130-KA-1-NN-80-L-3-F1-F-00-GBA-23-23-28	SERIES 90	S90-130PV
83015624	PUMP-VAR-DISPL CW 90PV100	90R100-DD-5-CD-80-R-4-C7-E-GB-GBA-20-20-24	SERIES 90	S90-100PV
83015628	MOTOR-VARIABLE CARTRIDGE K	K-C-45DN-E-R1F-F55-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83015633	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-HZ-B1-A-N-G0-NNN-107-AA-G0-03-00	SERIES 51	S51-160MV
83015642	PUMP-VAR-DISPL CW 90PV100	90R100-KN-5-AB-80-L-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83015643	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A7-C2-C-D8-L-G2-H6-L-45-L-45-N-E-28-P2-NNN-D39	H1-HP PUMPS	H1-115PV/130PV
83015647	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A8-C2-C-D6-J-G5-H2-L-42-L-42-B-L-28-P2-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83015650	MOTOR-VARIABLE DISPL SAE_L	L-V-30DN-A-YNF-F09-S-N-N-BF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83015653	MOTOR-VAR-DISPL 51MV160	51V160-V-F1-A-H4-B3-R-J-N2-NNN-096-AA-NN-C2-20	SERIES 51	S51-160MV
83015654	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-HS-A2-C-H-E1-NNN-100-AA-NN-16-21	SERIES 51	S51-250MV
83015655	PUMP-VAR-DISPL CW 90PV250	90R250-HF-5-BC-80-S-4-F1-J-03-NNN-42-42-24	SERIES 90	S90-250PV
83015658	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HF-5-AB-60-D-4-S1-L-03-GBA-35-35-28	SERIES 90	S90-055PV
83015659	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HF-5-CD-60-D-4-F1-L-03-GBA-35-35-28	SERIES 90	S90-100PV

83015665	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-P2-D2-N-A-TA-DS-KS-S-A-10-NN-030-Z-24-NNN	H1-HP MOTORS	H1-110MB1
83015666	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-B8-C2-C-D6-K-F1-H3-L-33-L-33-C-L-24-P2-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83015679	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-BC-80-T-M-F1-J-03-NNN-42-42-24	SERIES 90	S90-180PV
83015681	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A5-C2-N-D3-H-G1-NN-L-35-L-35-F-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83015682	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A5-C2-N-F4-H-G1-H6-L-35-L-35-F-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83015684	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-NN-60-S-3-C7-F-00-GBA-38-38-24	SERIES 90	S90-100PV
83015685	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-BB-60-P-3-S1-E-03-GBA-37-37-24	SERIES 90	S90-075PV
83015686	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A4-C3-N-E6-F-G5-H2-L-23-L-23-B-L-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83015688	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A4-C3-N-E6-F-G5-H2-L-23-L-23-B-L-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83015690	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-G3AN-50-P-D-C-3-F-1-B-30-30-N-1-1-1-NNN-NNN	SERIES 42	S42-041PV/051PV
83015691	PUMP-VAR-DISPL 42PV041 CW	42-R-41-C-G3AN-50-P-D-C-3-F-1-A-30-30-N-1-1-1-NNN-NNN	SERIES 42	S42-041PV/051PV
83015692	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-N-TH-C2-N-N-X1-NNN-030-AA-E6-00-17	SERIES 51	S51-060MV-1
83015693	PUMP-VAR-DISPL CCW 90PV130	90L130-KT-1-CD-80-R-3-F1-H-03-GBA-35-35-24	SERIES 90	S90-130PV
83015694	MOTOR-FIX DISPL MMF035D	MMF-035-D-A-F-G-A-B-NNR-***	M35/44	035MF
83015695	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-N-TA-CO-L-N-K7-NNN-100-AA-G3-00-B4	SERIES 51	S51-160MV
83015696	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KT-1-NN-80-R-3-S1-C-03-GBA-32-32-30	SERIES 90	S90-055PV
83015698	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KT-1-AB-80-R-3-S1-C-03-GBA-32-32-30	SERIES 90	S90-055PV
83015699	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-T1-DA-N-B-TB-CN-HN-N-A-05-NN-040-Z-24-NNN	H1-HP MOTORS	H1-080MB1
83015704	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-AB-80-P-3-S1-C-03-GBA-38-38-24	SERIES 90	S90-055PV
83015705	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-BC-80-P-3-S1-C-03-GBA-38-38-24	SERIES 90	S90-055PV
83015706	PUMP-VAR-DISPL CW 90PV075	90R075-KA-1-CD-80-S-7-C7-D-09-FAP-35-35-30	SERIES 90	S90-075PV
83015707	PUMP-VAR-DISPL CW 90PV075	90R075-KA-1-BC-80-S-7-S1-D-09-FAP-35-35-30	SERIES 90	S90-075PV
83015710	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-C-HS-A2-C-H-E1-NNN-055-AA-NN-16-18	SERIES 51	S51-160MV
83015715	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MV-1-BC-60-R-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83015718	PUMP-VAR-DISPL CW 90PV250	90R250-KT-5-DE-80-T-4-C8-K-03-NNN-42-42-24	SERIES 90	S90-250PV
83015719	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A4-C3-N-D3-G-G3-H4-L-35-L-35-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83015720	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A4-C3-N-D3-G-G3-H3-L-35-L-35-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83015721	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-T2-DA-N-B-TA-VS-AS-S-A-10-NN-020-Z-21-NNN	H1-HP MOTORS	H1-060MB1
83015722	MOTOR-VAR-DISPL 51MV110	51V110-R-F1-N-N2-NN-N-N-A0-ADA-026-AA-NN-00-00	SERIES 51	S51-110MV
83015723	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-1-NN-80-L-4-F1-H-03-GBA-32-32-24	SERIES 90	S90-130PV
83015724	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-1-NN-80-T-C-C8-J-03-FAC-32-32-24	SERIES 90	S90-180PV
83015726	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-BC-80-L-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83015730	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A3-C2-N-D8-H-G9-H2-L-33-L-33-M-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83015731	PUMP-VAR-DISPL CCW H1PV089	H1-P-089-L-A-A3-C2-B-D8-H-G1-NN-L-33-L-33-M-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83015737	MOTOR- VARIABLE CARTRIDGE L	L-C-25CS-E-R1F-F08-S-N-N-BF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83015738	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E2-AA-N-B-TB-VS-AS-S-A-10-NN-029-Z-00-NNN	H1-HP MOTORS	H1-080MB1

83015740	PUMP-VAR DISPL, CW 90PV075	90-R-075-DD-5-NN-80-P-4-S1-D-GB-GBA-32-32-24	SERIES 90	S90-075PV
83015741	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-E2D8-02-B-D-B-3-H-N-B-32-32-N-A-A-NNN-NNN	SERIES 42	S42-041PV/051PV
83015742	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-E2D8-02-B-D-B-3-H-N-V-25-25-N-A-A-NNN-NNN	SERIES 42	S42-041PV/051PV
83015743	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-E2D8-02-B-D-B-2-H-N-B-32-32-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83015744	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-E2D8-02-B-D-B-3-H-N-B-32-32-N-D-D-NNN-NNN	SERIES 42	S42-041PV/051PV
83015745	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-HS-A2-C-H-E1-NNN-055-AA-F3-16-30	SERIES 51	S51-160MV
83015746	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A3-C2-N-F5-H-G9-H6-L-33-L-33-M-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83015747	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E2-AA-N-B-TB-DN-GN-N-A-10-NN-012-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83015748	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E2-AA-N-B-TB-DN-GN-N-A-10-NN-020-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83015752	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-NN-60-R-4-S1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
83015754	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-BC-60-P-3-K3-E-03-GBA-32-32-24	SERIES 90	S90-100PV
83015757	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-A-Z-C-B-BA-B-B-A-A-BHH-CE-A-HH-B-D-A-A-BHH-CE-A-HH-A-NNN-	M46	M46-046PT
83015758	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-BB-80-P-4-S1-D-03-GBA-32-32-24	SERIES 90	S90-075PV
83015759	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-NN-80-P-3-C7-F-03-GBA-38-38-24	SERIES 90	S90-100PV
83015760	MOTOR-VAR-DISPL H1MB060	H1-B-060-A-L2-BA-N-A-PB-CS-GS-S-A-10-NN-000-N-00-NNN	H1-HP MOTORS	H1-060MB1
83015761	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-G-S-B-J-BA-A-A-BJJ-CB-A-HH-C-NNN-***	M46	M46-046PV
83015762	PUMP-VAR-DISPL CCW H1PV165	H1-P-165-L-C-A3-C2-B-D8-G-G2-H6-L-33-L-33-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83015765	MOTOR-VAR-DISPL 51MV110-1	51V110-1--A-F1-N-TA-R5-N-N-X1-NNN-063-AA-NN-00-16	SERIES 51	S51-110MV-1
83015774	MOTOR-VAR-DISPL 51MV250	51V250-A-C8-N-DA-M4-R-J-N1-ADA-095-AA-H0-C2-32	SERIES 51	S51-250MV
83015775	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-C2-C2-C-D8-K-G1-NN-L-42-L-42-N-E-28-P2-NNN-D4F	H1-HP PUMPS	H1-089PV/100PV
83015776	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-A-C2-C2-C-D8-K-G1-NN-K-42-K-42-N-E-28-P2-NNN-D4F	H1-HP PUMPS	H1-089PV/100PV
83015777	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-BC-80-S-4-T6-D-03-GBA-42-42-24	SERIES 90	S90-075PV
83015778	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E2-AA-N-A-TA-DN-GN-N-N-NN-NN-026-S-00-NNN	H1-HP MOTORS	H1-060MB1
83015780	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-CD-80-P-3-C7-E-02-GBA-42-42-24	SERIES 90	S90-075PV
83015785	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-BB-80-P-3-S1-E-02-GBA-42-42-24	SERIES 90	S90-075PV
83015790	PUMP-VAR DISPL, CW 90PV075	90-R-075-KT-1-CD-80-P-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83015791	PUMP-VAR DISPL, CW 90PV075	90-R-075-KT-1-NN-80-P-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83015793	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-L1-BA-N-C-PA-VS-DS-S-A-10-NN-025-N-00-NNN	H1-HP MOTORS	H1-110MB1
83015794	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-L1-BA-N-C-PA-VS-DS-S-A-20-NN-037-N-00-NNN	H1-HP MOTORS	H1-160MB1
83015795	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-E8-A1-A-N-A2-NNN-050-AA-G0-03-26	SERIES 51	S51-250MV
83015797	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A5-C2-N-D8-G-G2-H3-L-38-L-38-L-P-26-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83015799	PUMP-VAR-DISPL 42PV041 CW	42-R-51-E-ANN3-03-B-3-B-3-F-N-B-23-23-B-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83015800	PUMP-VAR-DISPL 42PV041 CW	42-R-51-C-ANN3-03-B-3-B-3-F-N-N-23-23-B-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83015807	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-5-AB-80-R-4-F1-E-02-GBA-42-42-24	SERIES 90	S90-100PV
83015811	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-BC-80-S-3-F1-J-03-NNN-26-26-24	SERIES 90	S90-250PV
83015817	PUMP-TANDEM, VAR DISPL MPT035D	MPT-035-D-A-W-S-E-AA-B-A-A-A-BFF-DR-A-FF-B-C-A-A-BFF-DL-A-FF-C-NNN-*	M35/44	035PT

83015822	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-L2-BA-N-A-PB-CS-LS-S-N-NN-NN-040-N-00-NNN	H1-HP MOTORS	H1-160MB1
83015823	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-HE-HE-N-B-TA-CN-JN-N-N-NN-NN-050-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83015824	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-BB-80-R-3-S1-C-03-EBC-35-35-24	SERIES 90	S90-055PV
83015825	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A3-C2-B-E5-F-G5-H3-L-35-L-35-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83015826	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-5-CD-60-P-4-F1-E-03-GBA-40-40-24	SERIES 90	S90-100PV
83015827	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-5-CD-60-P-3-F1-E-03-GBA-40-40-24	SERIES 90	S90-100PV
83015828	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-5-NN-80-P-3-S1-C-03-GBA-40-40-24	SERIES 90	S90-055PV
83015829	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KN-1-CD-60-D-4-F1-L-03-GBA-35-35-28	SERIES 90	S90-100PV
83015830	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A7-C2-C-E6-J-G4-H2-L-30-L-25-B-L-20-P2-NNN-D3F	H1-MP PUMPS	H1-045PV/053PV
83015831	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-1-NN-80-R-4-S1-C-03-GBA-29-29-24	SERIES 90	S90-055PV
83015834	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E2-AA-N-B-TB-CS-KS-S-A-10-NN-065-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83015835	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E2-AA-N-B-TB-CS-GS-S-A-10-NN-036-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83015836	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A3-C2-N-D3-G-G2-H6-L-42-L-42-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83015839	PUMP-VAR DISPL, CW 90PV055	90-R-055-HS-1-BC-80-R-4-S1-C-00-GBA-35-35-24	SERIES 90	S90-055PV
83015840	PUMP-VAR DISPL, CW 90PV075	90-R-075-HS-1-BC-80-S-4-S1-E-03-GBA-23-23-24	SERIES 90	S90-075PV
83015841	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-A1N3-03-C-5-A-2-C-N-A-21-21-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83015842	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-1-NN-80-S-4-S1-C-00-GBA-35-35-24	SERIES 90	S90-055PV
83015850	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-HZ-B1-A-N-C2-NNN-054-AA-E6-03-00	SERIES 51	S51-250MV
83015851	PUMP-VAR-DISPL CCW 90PV130	90L130-HF-1-NN-80-S-3-F1-F-00-EEB-35-35-24	SERIES 90	S90-130PV
83015852	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-1-NN-60-S-4-S1-C-00-GBA-35-35-24	SERIES 90	S90-055PV
83015853	PUMP-VAR DISPL, CW 90PV075	90-R-075-HF-1-NN-80-S-4-S1-D-00-GBA-35-35-24	SERIES 90	S90-075PV
83015854	PUMP-VAR DISPL, CW 90PV100	90-R-100-HF-1-NN-60-S-4-S1-E-00-GBA-35-35-24	SERIES 90	S90-100PV
83015855	PUMP-VAR-DISPL CW 90PV130	90R130-KA-1-NN-80-S-4-F1-F-00-EEB-35-35-24	SERIES 90	S90-130PV
83015856	PUMP-VAR-DISPL CW 90PV130	90R130-MA-1-NN-80-S-4-F1-F-00-EEB-35-35-24	SERIES 90	S90-130PV
83015857	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-B-V-C-B-BA-B-B-A-A-BGG-CE-A-HH-B-D-A-A-BGG-CE-A-HH-B-NNN-	M46	M46-046PT
83015858	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A2-C2-N-D1-F-G1-T3-35-35-35-35-M-P-24-PN-NNN-S01	H1-MP PUMPS	H1-045PT/053PT
83015859	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A5-C2-N-D3-G-G2-NN-L-35-L-35-A-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83015860	MOTOR-FIX DISPL 90MF130	90-M-130-NC-0-N-8-N-0-C8-W-00-EAH-00-00-F3	SERIES 90	S90-130MF
83015861	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A3-C2-N-D8-G-G2-H6-L-40-L-40-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83015866	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-L-S-B-B-BA-6-A-BJJ-DB-A-HH-H-NNA-***	M46	M46-046PV
83015867	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-L-S-B-B-BA-9-A-BJJ-DB-A-HH-H-NNA-***	M46	M46-046PV
83015869	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HS-1-CD-80-R-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83015880	PUMP-VAR-DISPL CW 90PV130	90R130-KA-1-NN-80-R-3-C8-H-03-GBA-42-42-20	SERIES 90	S90-130PV
83015882	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-C-E1A5-03-B-3-B-2-F-N-N-28-28-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83015884	MOTOR-VAR-DISPL H1MB060	H1-B-060-A-L1-BA-N-B-PB-CS-GS-S-A-50-NN-000-N-00-NNN	H1-HP MOTORS	H1-060MB1
83015885	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-L1-BA-N-B-PB-CS-HS-S-A-50-NN-000-N-00-NNN	H1-HP MOTORS	H1-080MB1

83015886	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-A1N3-03-C-5-N-N-C-N-A-21-21-B-H-H-NNN-NNN	SERIES 42	S42-028PV/032PV
83015887	PUMP-VAR-DISPL CW 90PV042	90R042-HF-5-NN-80-R-3-C3-C-04-GBA-17-17-20	SERIES 90	S90-042PV
83015888	PUMP- VARIABLE, DIRECT DISPLACMENT	LPV-A-A-B-C-A-G-AA-C-A-BHH-DR-A-FF-B-NNN-***	LPV	LPV
83015889	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-HE-HE-N-A-TB-DS-KS-S-N-NN-NN-032-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83015890	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-B7-C2-C-D8-K-G9-H5-L-42-L-42-N-E-24-P2-NNN-D5F	H1-HP PUMPS	H1-069PV/078PV
83015891	MOTOR-VAR-DISPL 51MV060	51V060-R-S1-N-HS-A2-C-H-E1-NNN-027-AA-F0-12-23	SERIES 51	S51-060MV
83015894	PUMP-VAR-DISPL CCW 90PV180	90L180-HS-5-CD-80-T-C-F1-H-03-FAC-35-35-24	SERIES 90	S90-180PV
83015900	PUMP-VAR DISPL, CW H1PV210	H1-P-210-R-A-A2-C2-N-D6-C-G2-NN-L-45-L-45-R-L-28-PN-NNN-NNN	H1-HP PUMPS	H1-210PV/250PV
83015901	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HS-1-NN-60-P-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83015903	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-NN-80-P-3-S1-D-00-GBA-35-35-24	SERIES 90	S90-075PV
83015906	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A2-C3-N-E9-F-G1-NN-K-35-K-35-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83015907	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-NN-80-S-4-C8-H-04-GBA-42-42-24	SERIES 90	S90-130PV
83015911	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A5-C2-N-D3-G-G2-H5-L-35-L-35-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83015912	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-1-AB-60-S-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83015913	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-1-CD-60-S-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83015914	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-CD-60-S-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83015915	PUMP-VAR DISPL, CW 90PV055	90-R-055-HS-1-NN-60-S-4-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83015916	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-AB-60-S-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83015918	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E2-AA-N-B-TB-CS-GS-P-N-NN-NN-026-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83015919	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E2-AA-N-B-TB-CN-GN-N-N-NN-NN-026-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83015920	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E2-AA-N-B-TB-CN-JN-N-N-NN-NN-036-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83015933	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A4-C3-N-E5-F-G5-H2-L-23-L-23-B-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83015934	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A4-C3-N-E5-F-G5-H2-L-23-L-23-B-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83015939	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-C-E1A6-02-C-D-A-3-D-N-B-38-38-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83015945	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A5-C1-N-D8-H-G1-H3-L-35-L-35-C-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83015947	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-M1-CA-N-B-RA-DS-KS-S-A-15-NN-000-N-00-NNN	H1-HP MOTORS	H1-110MB1
83015949	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-P1-D1-N-A-TA-DS-KS-S-A-20-NN-045-Z-24-NNN	H1-HP MOTORS	H1-160MB1
83015951	PUMP-VAR-DISPL CW 90PV100	90R100-DC-5-NN-60-P-3-C7-D-GB-GBA-30-30-24	SERIES 90	S90-100PV
83015952	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A3-C2-N-E9-F-G4-H1-K-35-K-35-B-P-24-PN-C03-NNN	H1-MP PUMPS	H1-045PV/053PV
83015953	PUMP-VAR-DISPL 42PV041 CCW	42-L-51-C-E1A7-03-D-N-F-2-H-N-N-34-NN-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83015954	MOTOR-VARIABLE CARTRIDGE K	K-C-38CS-E-RNF-F07-S-N-N-CF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83015955	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-D-N-0-C6-W-00-MIX-00-00-E6	SERIES 90	T90-055MF
83015956	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A3-C2-N-D8-H-G1-H2-L-35-L-35-M-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83015957	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A3-C2-N-D8-H-G1-H2-L-35-L-35-M-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83015958	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-T2-DA-N-B-TA-CN-LN-N-N-NN-NN-088-Z-20-NNN	H1-HP MOTORS	H1-160MB1
83015961	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-D2-M2-N-B-PB-VS-DS-S-A-20-NN-032-N-30-NNN	H1-HP MOTORS	H1-160MB1

83015963	PUMP-VAR-DISPL CW 90PV250	90R250-PB-5-NN-80-T-4-F1-J-03-NNN-35-35-24	SERIES 90	S90-250PV
83015978	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A5-C2-B-D8-G-G3-H2-L-38-L-38-L-P-30-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83015979	MOTOR-VAR-DISPL 51MD160	51D160-A-D5-N-HS-A1-B-E-E2-NNN-070-AA-F3-08-26	SERIES 51	S51-160MV
83015980	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-B7-C2-C-D8-J-G5-NN-L-42-L-42-B-P-24-P2-NNN-D3H	H1-MP PUMPS	H1-045PV/053PV
83015992	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A7-C3-C-D6-K-F1-H3-L-45-L-45-C-L-24-P2-NNN-D3H	H1-HP PUMPS	H1-069PV/078PV
83015995	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E2-AA-N-B-TB-CN-GN-N-N-NN-NN-024-R-00-NNN	H1-HP MOTORS	H1-060MB1
83016003	PUMP-VAR-DISPL CW 90PV100	90R100-CB-1-CD-60-L-4-F1-E-00-GBA-26-26-24	SERIES 90	S90-100PV
83016005	PUMP-VAR-DISPL CW 90PV075	90R075-HF-5-BB-80-R-3-C7-E-03-GBA-30-30-24	SERIES 90	S90-075PV
83016013	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A2-C3-N-D8-H-G1-H2-L-35-L-35-F-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83016014	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A2-C3-N-F5-H-F1-H6-L-35-L-35-F-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83016017	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-BB-80-P-4-C3-C-03-GBA-35-35-24	SERIES 90	S90-042PV
83016018	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-NN-80-P-4-C3-C-03-GBA-35-35-24	SERIES 90	S90-042PV
83016028	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E1-AA-N-B-TB-VN-DN-N-A-10-NN-022-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83016031	MOTOR-VAR-DISPL H1B250	H1-B-250-A-L1-BA-N-B-PB-VS-FS-S-A-30-NN-080-N-00-NNN	H1-HP MOTORS	H1-250MB1
83016032	PUMP-VAR-DISPL CCW 90PV180	90L180-KP-5-CD-80-S-C-C8-J-03-FAC-42-42-24	SERIES 90	S90-180PV
83016033	PUMP-VAR-DISPL CCW 90PV250	90L250-KP-5-CD-80-S-3-C8-K-03-NNN-35-35-24	SERIES 90	S90-250PV
83016034	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-L2-BA-N-B-PB-VN-DN-N-A-20-NN-050-N-00-NNN	H1-HP MOTORS	H1-160MB1
83016035	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E2-AA-N-B-TA-VN-DN-N-N-NN-NN-040-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83016040	MOTOR-VARIABLE DISPL SAE_K	K-V-38CN-E-R2F-F10-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83016042	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-D3-N-T1-C2-N-N-X1-NNN-040-AA-E6-00-24	SERIES 51	S51-080MV-1
83016043	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KN-1-BC-80-D-3-S1-L-00-GBA-26-26-24	SERIES 90	S90-075PV
83016044	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D3-N-T1-C2-N-N-X1-NNN-040-AA-E6-00-24	SERIES 51	S51-080MV-1
83016048	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-L2-BA-N-B-PA-DS-LS-S-A-30-NN-067-N-00-NNN	H1-HP MOTORS	H1-160MB1
83016049	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-M2-CA-N-A-RA-DS-KS-S-N-NN-NN-000-N-00-NNN	H1-HP MOTORS	H1-110MB1
83016061	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A2-C1-B-D3-H-G1-NN-L-33-L-33-C-M-30-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83016062	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A2-C1-B-D6-H-G1-H5-L-23-L-23-C-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83016063	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A2-C2-B-D6-H-G1-H3-L-28-L-28-C-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83016064	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A2-C2-B-D6-H-G1-NN-L-28-L-28-C-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83016065	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A2-C1-B-D3-H-G1-NN-L-35-L-35-C-M-30-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83016067	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-C7-N-E1-B1-N-N-U1-AWM-041-AA-F0-00-00	SERIES 51	S51-080MV-1
83016076	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-NN-80-L-4-C6-F-03-GBA-48-48-24	SERIES 90	S90-100PV
83016078	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-BC-60-S-3-C7-E-03-GBA-32-32-24	SERIES 90	S90-075PV
83016081	PUMP-VAR DISPL CCW H1P068L	H1-P-068-L-A-A5-C3-N-D8-H-G1-NN-L-35-L-35-C-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83016088	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HS-1-BC-80-R-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83016089	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HS-1-NN-80-R-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83016091	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-C-E1A6-00-B-D-X-N-P-N-B-28-28-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV

83016092	PUMP-VAR DISPL CW H1P068R	H1-P-068-R-A-A5-C3-N-D8-H-G1-NN-L-35-L-35-C-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83016093	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-AB-80-R-4-C6-C-03-GBA-17-13-24	SERIES 90	S90-055PV
83016095	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D3-N-N1-NN-N-N-U1-ANA-030-AA-F0-00-00	SERIES 51	S51-080MV-1
83016096	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-NN-80-L-3-S1-F-00-GBA-38-14-24	SERIES 90	S90-100PV
83016097	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-1-NN-80-S-4-S1-E-00-GBA-42-42-24	SERIES 90	S90-100PV
83016104	PUMP-VAR-DISPL CW 90PV130	90R130-MA-1-BC-80-R-3-F1-F-03-GBA-42-42-24	SERIES 90	S90-130PV
83016105	PUMP-VAR-DISPL CW 90PV250	90R250-KN-5-CD-80-T-4-F1-J-03-NNN-14-14-24	SERIES 90	S90-250PV
83016109	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-C-E2C8-00-B-D-X-N-P-N-B-28-28-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83016111	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-C-E1A6-02-B-D-X-N-P-N-B-28-28-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83016117	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-L2-BA-N-B-PB-VS-ES-S-A-10-NN-022-N-00-NNN	H1-HP MOTORS	H1-110MB1
83016119	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A3-C2-N-E5-F-G5-NN-L-35-L-35-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83016124	MOTOR-VAR DISPL MMV046C	MMV-046-C-A-E-N-E-AY-NNN-***	M46	M46-046MV
83016125	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-T1-DA-N-B-TB-VN-EN-N-A-20-NN-065-Z-30-NNN	H1-HP MOTORS	H1-160MB1
83016128	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A5-C1-N-D3-G-G3-H3-L-42-L-42-A-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83016136	PUMP-VAR DISPL CCW H1P060L	H1-P-060-L-A-A5-C1-N-D6-H-F1-NN-L-42-L-42-C-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83016138	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-AB-80-R-4-C7-F-03-GBA-35-35-24	SERIES 90	S90-100PV
83016139	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-NN-80-R-4-F1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
83016140	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-DE-80-T-M-C8-J-03-GCA-35-35-24	SERIES 90	S90-180PV
83016141	PUMP-VAR-DISPL CW 90PV075	90R075-KA-1-NN-60-L-4-C7-E-03-GBA-42-42-24	SERIES 90	S90-075PV
83016147	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-A-V-C-B-AA-B-B-A-A-BGG-CE-A-GG-B-D-A-A-BGG-CE-A-GG-A-NNN-	M46	M46-046PT
83016149	PUMP-VAR-DISPL CCW 90PV130	90L130-KT-1-BC-80-P-3-F1-H-00-GBA-42-42-24	SERIES 90	S90-130PV
83016150	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-A-A2-C3-N-F5-H-G1-H6-L-35-L-35-D-P-28-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83016151	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A4-C3-N-D8-H-G1-NN-L-35-L-35-F-P-28-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83016157	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-N1-NN-N-N-U1-NNN-074-AA-E4-00-00	SERIES 51	S51-110MV-1
83016158	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-5-AB-80-P-3-S1-C-03-GBA-35-14-24	SERIES 90	S90-055PV
83016163	PUMP-VAR-DISPL CW 90PV100	90R100-DD-5-BC-60-S-3-C7-E-GB-GLA-42-42-24	SERIES 90	S90-100PV
83016166	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-NN-80-S-4-F1-K-06-NNN-32-32-24	SERIES 90	S90-250PV
83016167	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-AB-80-S-4-C8-J-04-NNN-42-42-24	SERIES 90	S90-250PV
83016169	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A9-C2-N-D6-H-F1-H5-L-38-L-20-C-L-20-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83016172	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-2-BC-80-D-3-C6-L-00-GFD-42-42-34	SERIES 90	S90-075PV
83016173	PUMP-VAR-DISPL 42PV041 CCW	42-L-41-C-E1A3-03-D-N-F-2-F-N-A-23-23-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83016174	PUMP-VAR-DISPL 42PV041 CCW	42-L-41-C-E1A3-03-D-N-F-2-F-N-B-23-23-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83016175	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-TA-D1-N-N-X1-ADA-060-AA-G3-00-20	SERIES 51	S51-110MV-1
83016181	PUMP-VAR-DISPL CCW 90PV180	90L180-HF-5-NN-80-S-C-C8-J-05-NNN-42-42-30	SERIES 90	S90-180PV
83016184	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-A-Z-C-B-AA-B-A-C-A-BEE-AB-D-CD-B-C-C-A-BEE-AB-D-CD-A-NNN-*	M46	M46-046PT
83016199	PUMP-VAR-DISPL CCW 90PV130	90L130-KT-1-BC-80-R-3-F1-H-03-GBA-42-42-24	SERIES 90	S90-130PV

83016201	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-A-Z-C-B-AA-B-A-C-A-BEE-AB-D-CD-B-C-C-A-BEE-AB-D-CD-C-NNN-*	M46	M46-046PT
83016202	PUMP-VAR-DISPL CCW 90PV180	90L180-KN-1-BC-80-S-M-F1-H-03-FAC-35-35-24	SERIES 90	S90-180PV
83016215	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-L1-BA-N-C-PA-VS-DS-S-A-10-NN-022-N-00-NNN	H1-HP MOTORS	H1-110MB1
83016219	PUMP-VAR-DISPL CW 90PV180	90R180-HF-5-EG-80-T-C-C8-J-03-NNN-35-35-28	SERIES 90	S90-180PV
83016220	PUMP-VAR-DISPL CW 90PV180	90R180-HF-5-DE-80-T-C-C8-J-03-NNN-35-35-28	SERIES 90	S90-180PV
83016221	PUMP-VAR-DISPL CW 90PV130	90R130-HF-5-AB-80-R-3-F1-F-03-GBA-35-35-28	SERIES 90	S90-130PV
83016222	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-A-A3-C2-N-F5-H-G9-H6-L-45-L-45-D-P-22-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83016223	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-B1-C1-N-D3-H-G9-H3-L-40-L-40-F-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83016224	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-B1-C2-N-D3-H-G1-H2-L-25-L-25-F-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83016229	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-Y-Z-C-S-BA-B-A-A-A-BJJ-AB-U-DD-B-C-A-A-BJJ-AB-U-DD-C-NNR-***	M46	M46-046PT
83016232	MOTOR-VAR-DISPL 51MC060-1	51C060-1--A-D1-N-E2-B1-N-N-U1-NNN-020-AA-E4-00-00	SERIES 51	S51-060MV-1
83016238	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E2-AA-N-C-TA-DN-KN-N-A-15-NN-053-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83016239	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-L1-BA-N-C-PA-VS-DS-S-A-15-NN-032-N-00-NNN	H1-HP MOTORS	H1-160MB1
83016240	PUMP-VAR DISPL CW H1P068R	H1-P-068-R-A-A5-C1-B-D8-H-F1-H2-L-20-L-20-F-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83016241	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A2-C2-N-E8-G-G3-H6-L-48-L-48-A-L-30-PN-NNN-G25	H1-HP PUMPS	H1-115PV/130PV
83016255	PUMP-VAR-DISPL CW 90PV180	90R180-KP-5-EG-80-T-M-C8-H-03-FAC-24-24-24	SERIES 90	S90-180PV
83016256	PUMP-VAR-DISPL CW 90PV180	90R180-KP-5-NN-80-T-M-C8-H-03-NNN-24-24-24	SERIES 90	S90-180PV
83016257	PUMP-VAR-DISPL 42PV028 CW	42-R-2A-D-G2A1-50-U-2-B-2-E-1-A-34-34-B-1-1-AAA-NNN	SERIES 42	S42-028PV/032PV
83016258	MOTOR-VAR-DISPL 51MD160	51D160-A-D4-N-E2-A5-A-N-A6-NNN-100-AA-F3-03-00	SERIES 51	S51-160MV
83016259	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-C-N2-NN-N-N-A0-NNN-055-AA-F0-00-00	SERIES 51	S51-160MV
83016269	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-CD-60-S-3-T2-E-00-GBA-23-23-24	SERIES 90	S90-100PV
83016280	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-1-BC-80-T-4-C8-K-03-NNN-35-35-30	SERIES 90	S90-250PV
83016283	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-1-DE-80-T-M-C8-J-03-NNN-35-16-34	SERIES 90	S90-180PV
83016284	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-1-CD-80-T-M-C8-J-03-NNN-35-16-34	SERIES 90	S90-180PV
83016285	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-1-EG-80-T-M-C8-J-03-NNN-35-16-34	SERIES 90	S90-180PV
83016287	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-AB-80-P-3-C7-D-03-GBA-42-42-24	SERIES 90	S90-075PV
83016288	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-BC-80-P-3-C7-D-03-GBA-42-42-24	SERIES 90	S90-075PV
83016298	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-1-AB-80-S-4-F1-E-00-GBA-42-42-24	SERIES 90	S90-100PV
83016300	PUMP-VAR-DISPL 42PV041 CCW	42-L-41-E-E2D8-03-A-N-A-2-G-N-B-34-34-B-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83016305	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-NN-80-L-4-C8-F-05-GBA-30-30-24	SERIES 90	S90-130PV
83016310	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-T2-D2-N-A-TA-DS-KS-S-A-30-NN-053-Z-25-NNN	H1-HP MOTORS	H1-160MB1
83016314	PUMP-VAR DISPL, CCW 90PV100	90-L-100-CB-1-NN-80-R-4-F1-F-00-GBA-14-14-24	SERIES 90	S90-100PV
83016316	PUMP-VAR DISPL CW H1P068R	H1-P-068-R-A-A4-C3-N-F5-H-F1-H6-L-38-L-38-C-P-30-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83016328	PUMP-TANDEM, VAR DISPL CCW H1T045L	H1-T-045-L-A-N-B1-C1-B-E7-F-G1-TN-30-30-30-30-M-P-24-PN-NNN-S01	H1-MP PUMPS	H1-045PT/053PT
83016334	PUMP-VAR DISPL, CW 90PV075	90-R-075-HF-5-BC-60-P-3-S1-E-03-GBA-32-32-24	SERIES 90	S90-075PV
83016335	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-1-BC-80-P-3-F1-H-00-GBA-42-42-24	SERIES 90	S90-130PV

83016336	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-CD-80-P-3-F1-F-00-GBA-42-42-24	SERIES 90	S90-100PV
83016337	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-BC-80-P-3-S1-F-00-GBA-38-38-24	SERIES 90	S90-100PV
83016341	PUMP-VAR DISPL, CW 90PV055	90-R-055-HS-1-CD-80-P-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
83016345	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-CD-80-D-4-F1-L-03-GBA-42-42-24	SERIES 90	S90-130PV
83016358	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-CD-60-L-4-C7-E-03-GBA-32-32-24	SERIES 90	S90-075PV
83016359	PUMP-VAR-DISPL CW 90PV130	90R130-HF-5-BB-80-R-3-C8-H-03-GBA-35-35-24	SERIES 90	S90-130PV
83016361	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-HS-A2-B-N-E1-NNN-080-AA-NN-12-24	SERIES 51	S51-160MV
83016362	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-T1-D1-N-C-TB-DS-KS-S-A-20-NN-065-Z-26-NNN	H1-HP MOTORS	H1-160MB1
83016372	MOTOR-VAR-DISPL 51MV110-1	51V110-1--A-F1-N-N1-NN-N-N-U1-NNN-055-AA-F0-00-00	SERIES 51	S51-110MV-1
83016376	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A4-C2-N-D6-H-G1-NN-L-42-L-42-C-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83016377	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-AB-60-S-3-C6-D-03-GBA-26-26-24	SERIES 90	S90-055PV
83016385	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-C-ANJ5-03-A-N-A-2-H-N-N-34-34-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83016386	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-D-A7J5-03-A-N-A-2-H-N-B-34-34-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83016391	PUMP-TANDEM, VAR DISPL CCW H1T053L	H1-T-053-L-A-N-A3-C2-N-E7-F-G5-T3-35-35-35-35-M-P-24-PN-NNN-S01	H1-MP PUMPS	H1-045PT/053PT
83016392	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-BC-80-S-4-S1-E-00-GBA-42-42-24	SERIES 90	S90-100PV
83016393	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-AB-80-L-4-C8-H-03-GLA-32-32-24	SERIES 90	S90-130PV
83016396	PUMP-VAR-DISPL CW 90PV180	90R180-MA-1-NN-80-S-C-F1-H-00-NNN-35-14-22	SERIES 90	S90-180PV
83016399	PUMP-VAR-DISPL CW 90PV180	90R180-HF-1-CD-80-T-M-C8-H-03-NNN-35-35-24	SERIES 90	S90-180PV
83016401	PUMP-VAR DISPL, CW 90PV100	90-R-100-HS-1-CD-80-P-4-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83016402	MOTOR-VARIABLE CARTRIDGE K	K-C-45DN-H-YNF-F06-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83016406	MOTOR-VARIABLE DISPL SAE_L	L-V-25CN-A-YNF-F07-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83016414	PUMP-VAR-DISPL CW 90PV250	90R250-HF-5-BB-80-T-3-C8-K-03-NNN-35-35-24	SERIES 90	S90-250PV
83016415	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-8-N-0-C7-W-00-EAA-00-00-G3	SERIES 90	S90-100MF
83016419	MOTOR-VARIABLE DISPL SAE_L	L-V-35EN-A-YNF-F55-S-N-N-AF-F18-NNN-NNT	LV / KV MOTORS	L/K-MV
83016428	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-HE-HE-N-A-TB-VN-AN-N-N-NN-NN-016-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83016434	PUMP-VAR-DISPL CCW 90PV075	90L075-HF-5-BC-60-L-4-C7-E-03-GBA-30-30-24	SERIES 90	S90-075PV
83016435	PUMP-VAR-DISPL CCW 90PV100	90L100-HF-5-AC-60-L-4-C7-F-03-GBA-35-35-24	SERIES 90	S90-100PV
83016436	PUMP-VAR-DISPL CCW 90PV130	90L130-HF-5-BC-80-L-4-C8-H-03-GBA-35-35-24	SERIES 90	S90-130PV
83016440	MOTOR-VAR-DISPL 51MC080-1	51C080-1--A-D3-N-N1-NN-N-N-U1-ANA-030-AA-F0-00-00	SERIES 51	S51-080MV-1
83016441	PUMP-VAR-DISPL CW 90PV130	90R130-KP-1-CD-80-S-3-F1-F-03-GBA-38-38-24	SERIES 90	S90-130PV
83016445	PUMP-VAR-DISPL CW 90PV180	90R180-MA-1-NN-80-S-C-F1-H-00-NNN-35-14-24	SERIES 90	S90-180PV
83016451	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A4-C3-N-D3-H-F4-NN-L-40-L-40-C-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83016452	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E2-AA-N-B-TA-DN-JN-N-A-15-NN-060-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83016455	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-E1A3-03-B-D-C-2-E-N-B-34-34-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83016456	MOTOR-VAR-DISPL 51MD160	51D160-A-D4-N-T4-C0-L-N-L4-ACA-066-AA-F3-00-B3	SERIES 51	S51-160MV
83016457	PUMP-VAR-DISPL CCW H1PV089	H1-P-089-L-A-C2-C2-C-F4-K-G9-H6-L-42-L-42-D-M-24-P2-NNN-D4F	H1-HP PUMPS	H1-089PV/100PV

83016458	PUMP-VAR-DISPL CW 90PV100	90R100-MA-5-AB-80-L-3-C7-E-C5-GBA-42-42-24	SERIES 90	S90-100PV
83016461	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-C-F7NN-50-V-N-F-2-H-N-N-25-25-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83016465	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KT-5-BC-80-P-3-T2-E-03-GBA-38-38-20	SERIES 90	S90-100PV
83016466	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-1-NN-60-L-4-C6-C-GB-GBA-29-29-20	SERIES 90	S90-055PV
83016467	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-NN-80-L-3-F1-F-03-GBA-32-32-24	SERIES 90	S90-100PV
83016469	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-E2-AA-N-B-TB-DN-LN-N-A-20-NN-076-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83016470	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-L2-BA-N-A-PB-CN-JN-N-A-10-NN-000-N-00-NNN	H1-HP MOTORS	H1-110MB1
83016471	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-CD-80-P-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
83016472	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-C-F7NN-50-V-N-F-2-H-N-A-25-25-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83016473	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-C-F7NN-50-V-N-F-2-H-N-B-25-25-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83016474	PUMP-VAR-DISPL 42PV041 CCW	42-L-41-D-F4NN-72-J-D-B-2-H-N-B-25-25-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83016476	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-C7-N-T2-C2-N-N-X1-NNN-054-AA-F0-00-28	SERIES 51	S51-080MV-1
83016477	MOTOR-VAR-DISPL 51MC080-1	51C080-1--A-D3-N-T7-R5-N-N-X1-NNN-045-AA-F0-00-26	SERIES 51	S51-080MV-1
83016480	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E2-AA-N-B-TB-VN-DN-N-A-10-NN-055-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83016484	PUMP-VAR DISPL CW H1P068R	H1-P-068-R-A-A4-C3-N-D8-H-G1-H5-L-23-L-23-C-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83016485	MOTOR-VAR-DISPL 51MV080	51V080-A-S1-N-HZ-B1-B-H-G5-NNN-016-AA-E4-05-00	SERIES 51	S51-080MV
83016486	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-HZ-B1-B-H-G5-NNN-016-AA-E4-05-00	SERIES 51	S51-080MV
83016490	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-AB-60-L-4-C7-E-03-GBA-30-30-24	SERIES 90	S90-075PV
83016495	PUMP-VAR-DISPL CW 90PV130	90R130-PB-5-NN-80-R-3-C8-H-03-GBA-42-42-24	SERIES 90	S90-130PV
83016496	MOTOR-VAR-DISPL H1B110	H1-B-110-A-TA-D1-N-B-TB-DN-JN-N-A-10-NN-030-Z-26-NNN	H1-HP MOTORS	H1-110MB1
83016497	PUMP-VAR-DISPL CW 90PV180	90R180-MA-5-AB-80-S-C-C8-J-C5-FAC-42-42-24	SERIES 90	S90-180PV
83016499	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-1-AB-80-L-3-T1-D-00-GBA-29-29-24	SERIES 90	S90-075PV
83016500	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-AB-80-L-3-T1-D-00-GBA-29-29-24	SERIES 90	S90-075PV
83016501	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KN-1-CD-80-R-4-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83016502	PUMP-VAR DISPL, CCW 90PV055	90-L-055-DD-1-AB-80-P-3-S1-C-GB-GBA-26-26-24	SERIES 90	S90-055PV
83016503	PUMP-VAR DISPL, CCW 90PV055	90-L-055-DD-1-CD-80-P-3-C6-C-GB-GBA-26-26-24	SERIES 90	S90-055PV
83016504	PUMP-VAR DISPL, CCW 90PV055	90-L-055-DD-1-NN-80-P-3-S1-C-GB-GBA-26-26-24	SERIES 90	S90-055PV
83016505	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-BC-80-P-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-075PV
83016506	MOTOR-VAR-DISPL 51MD160	51D160-A-D4-N-T4-C0-L-N-L4-ACA-066-AA-F3-00-B5	SERIES 51	S51-160MV
83016507	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A8-C2-C-D8-J-G5-H3-L-35-L-35-B-P-24-P2-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83016512	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-NN-80-P-3-S1-E-03-GBA-38-38-24	SERIES 90	S90-075PV
83016526	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E2-AA-N-A-TB-CN-GN-N-A-05-NN-020-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83016527	MOTOR-VAR-DISPL H1MB060	H1-B-060-A-L2-BA-N-A-PB-VN-AN-N-A-10-NN-020-N-00-NNN	H1-HP MOTORS	H1-060MB1
83016539	PUMP-VAR-DISPL CW 90PV180	90R180-HD-D-BC-8C-S-E-F5-J-00-GCA-35-35-32	SERIES 90	S90-180PV
83016550	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KT-5-NN-80-R-4-S1-F-00-GFD-32-32-36	SERIES 90	S90-100PV
83016551	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KT-5-CD-80-R-4-F1-F-00-GFD-32-32-36	SERIES 90	S90-100PV

83016552	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A3-C1-N-D6-H-F4-H1-L-35-L-35-M-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83016558	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A4-C2-N-D8-F-G1-H3-L-35-L-35-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83016559	MOTOR-VARIABLE CARTRIDGE K	K-C-38CS-E-RNF-F06-S-N-N-DF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83016560	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-W-CD-60-E-3-C6-D-01-GFD-40-34-24	SERIES 90	S90-075PV
83016561	PUMP-VAR DISPL, CW 90PV075	90-R-075-LE-W-BC-60-E-3-S1-D-01-GFD-40-34-24	SERIES 90	S90-075PV
83016562	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-HZ-B1-A-E-G5-NNN-150-AA-G3-02-00	SERIES 51	S51-250MV
83016563	PUMP-VAR DISPL, CCW 90PV055	90-L-055-MA-1-BC-60-S-3-C6-C-03-GBA-38-38-20	SERIES 90	S90-055PV
83016565	PUMP-VAR DISPL, CW 90PV075	90-R-075-DD-1-CD-80-L-4-S1-E-GB-GBA-20-20-24	SERIES 90	S90-075PV
83016566	PUMP-VAR-DISPL CW 90PV130	90R130-DD-5-CD-80-L-4-F1-F-GB-GBA-20-20-24	SERIES 90	S90-130PV
83016567	MOTOR-VAR-DISPL 51MC080-1	51C080-1--A-D3-N-N1-NN-N-N-U1-NNN-030-AA-F0-00-00	SERIES 51	S51-080MV-1
83016568	PUMP-VAR DISPL, CW 90PV055	90-R-055-HF-1-CD-80-R-4-S1-C-03-GBA-20-20-24	SERIES 90	S90-055PV
83016569	PUMP-VAR DISPL, CW 90PV055	90-R-055-HF-1-NN-80-R-4-S1-C-03-GBA-20-20-24	SERIES 90	S90-055PV
83016570	PUMP-VAR DISPL, CW 90PV055	90-R-055-HF-1-BC-80-R-4-S1-C-03-GBA-20-20-24	SERIES 90	S90-055PV
83016574	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E2-AA-N-B-TB-VN-AN-N-A-10-NN-029-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83016575	PUMP-TANDEM, VAR DISPL MPT035D	MPT-035-D-A-R-S-J-AA-B-A-A-A-BJJ-DL-A-FF-B-C-A-A-BJJ-DL-A-FF-C-NNN-***	M35/44	035PT
83016576	PUMP-VAR DISPL, CW 90PV100	90-R-100-FD-1-AB-80-P-3-F1-E-B1-GBA-42-42-24	SERIES 90	S90-100PV
83016578	PUMP-VAR-DISPL CCW 90PV250	90L250-HF-5-NN-80-T-4-F1-K-03-NNN-35-35-24	SERIES 90	S90-250PV
83016586	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-1-NN-80-R-4-S1-D-03-GBA-14-14-20	SERIES 90	S90-055PV
83016588	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-CD-80-S-C-C8-J-03-EFI-42-42-22	SERIES 90	S90-180PV
83016589	MOTOR-VAR-DISPL 51MD160	51D160-A-D4-N-TN-F8-L-N-J2-ACA-066-AA-F3-00-BB	SERIES 51	S51-160MV
83016590	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-DE-80-D-4-C8-L-03-GBA-42-42-24	SERIES 90	S90-130PV
83016592	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-5-CD-80-P-3-S1-D-03-EEB-42-42-24	SERIES 90	S90-075PV
83016593	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-5-NN-80-P-3-S1-D-03-EEB-42-42-24	SERIES 90	S90-075PV
83016595	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-BC-80-S-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83016596	PUMP-VAR-DISPL CCW 90PV180	90L180-KP-5-NN-80-T-C-F1-H-03-EBA-42-42-24	SERIES 90	S90-180PV
83016598	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-M2-CA-N-B-RB-DS-JS-S-A-10-NN-000-N-00-NNN	H1-HP MOTORS	H1-110MB1
83016609	MOTOR-VAR-DISPL 51MD110-1	51D110-1--A-D4-N-E0-B1-N-N-U1-NNN-050-AA-F3-00-00	SERIES 51	S51-110MV-1
83016610	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-BC-80-L-3-C7-D-03-GBA-29-29-30	SERIES 90	S90-075PV
83016611	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-NN-60-L-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83016612	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-NN-80-L-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83016616	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-A-T-B-B-BA-A-A-BEE-BA-A-GG-C-NNN-***	M46	M46-046PV
83016619	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A3-C2-N-D8-G-G3-NN-L-45-L-45-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83016620	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-1-CD-80-R-3-C7-E-03-GBA-35-35-28	SERIES 90	S90-075PV
83016621	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E2-AA-N-B-TA-DS-JS-S-A-10-NN-000-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83016623	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-L1-BA-N-C-PB-CS-JS-S-A-05-NN-016-N-00-NNN	H1-HP MOTORS	H1-080MB1
83016624	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KF-5-CD-80-R-4-F1-F-00-GFD-32-32-36	SERIES 90	S90-100PV

83016625	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KF-5-NN-80-R-4-S1-F-00-GFD-32-32-36	SERIES 90	S90-100PV
83016628	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-AB-80-S-4-F1-E-00-GBA-42-42-24	SERIES 90	S90-100PV
83016633	PUMP-VAR-DISPL CCW 90PV180	90L180-HF-1-BC-80-T-M-F1-H-03-FAC-26-26-24	SERIES 90	S90-180PV
83016634	MOTOR-VARIABLE CARTRIDGE K	K-C-38CN-E-R1F-F55-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83016635	MOTOR- VARIABLE CARTRIDGE L	L-C-25CN-E-R1F-F09-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83016638	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KT-1-NN-80-S-3-S1-C-02-GBA-42-42-24	SERIES 90	S90-055PV
83016643	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-NN-80-L-4-F1-F-03-GBA-23-23-20	SERIES 90	S90-100PV
83016649	PUMP-VAR DISPL, CCW 90PV055	90-L-055-MA-1-NN-80-R-4-S1-D-03-GBA-14-14-20	SERIES 90	S90-055PV
83016650	PUMP-VAR-DISPL CW 90PV180	90R180-FH-5-CD-80-T-7-C8-J-B2-FAC-43-43-30	SERIES 90	S90-180PV
83016651	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-D8-M1-R-J-M1-ADA-065-AA-G3-C2-17	SERIES 51	S51-250MV
83016653	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-2-BC-80-R-4-F1-D-03-GBA-35-35-24	SERIES 90	S90-100PV
83016654	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-CD-80-L-4-F1-D-03-GBA-35-35-24	SERIES 90	S90-100PV
83016655	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-2-CD-80-P-4-S1-F-00-GBA-35-35-24	SERIES 90	S90-100PV
83016656	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-1-BC-80-R-4-F1-F-03-GBA-35-35-24	SERIES 90	S90-130PV
83016657	PUMP-VAR-DISPL CW 90PV130	90R130-KA-1-NN-80-R-3-F1-F-00-GBA-35-35-24	SERIES 90	S90-130PV
83016660	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-NN-80-P-3-C6-D-03-GBA-35-35-20	SERIES 90	S90-075PV
83016662	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-K2-KA-N-B-RB-CN-JN-N-A-10-NN-030-N-25-NNN	H1-HP MOTORS	H1-110MB1
83016666	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HF-5-CD-80-D-4-S1-L-03-GBA-35-35-24	SERIES 90	S90-055PV
83016672	PUMP-VAR-DISPL CW 90PV075	90R075-FL-5-BC-80-S-7-C6-E-B6-EFP-35-35-24	SERIES 90	S90-075PV
83016675	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-D2-M2-N-B-PB-VN-EN-N-A-20-NN-057-N-25-NNN	H1-HP MOTORS	H1-160MB1
83016676	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-L2-BA-N-C-PA-CS-JS-S-A-15-NN-030-N-00-NNN	H1-HP MOTORS	H1-110MB1
83016677	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-BC-80-L-3-F1-H-04-GBA-45-45-24	SERIES 90	S90-130PV
83016678	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-CD-80-S-7-C7-E-09-FAP-35-35-30	SERIES 90	S90-100PV
83016679	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-BC-80-S-7-S1-E-09-FAP-35-35-30	SERIES 90	S90-100PV
83016680	MOTOR-VAR-DISPL 51MV160	51V160-A-C8-N-D7-M1-S-K-M4-NNN-080-AA-G3-F4-28	SERIES 51	S51-160MV
83016682	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-E1A3-03-A-N-A-2-E-N-B-34-34-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83016693	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-S1-N-N1-NN-N-N-U1-ABA-040-AA-NN-00-00	SERIES 51	S51-080MV-1
83016702	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A3-C3-N-D3-G-G2-NN-L-42-L-42-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83016705	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-CD-80-L-4-C8-H-06-GBA-40-40-30	SERIES 90	S90-130PV
83016707	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-L1-BA-N-B-PB-CN-JN-N-A-05-NN-027-N-00-NNN	H1-HP MOTORS	H1-080MB1
83016710	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-A-V-C-B-BA-B-A-A-A-BHH-AB-U-ED-B-C-A-A-BHH-AT-U-ED-B-NNN-	M46	M46-046PT
83016712	MOTOR-VAR-DISPL 51MD080-1	51D080-1--R-D2-N-E2-B1-N-N-U1-NNN-025-AA-F0-00-00	SERIES 51	S51-080MV-1
83016715	PUMP-VAR-DISPL CW 90PV075	90R075-KP-5-CD-60-L-4-S1-E-06-GBA-38-38-28	SERIES 90	S90-075PV
83016716	PUMP-VAR-DISPL CW 90PV075	90R075-KP-5-NN-60-L-4-S1-D-06-GBA-29-29-28	SERIES 90	S90-075PV
83016717	MOTOR-VAR-DISPL 51MD110	51D110-A-D3-N-HZ-B1-B-E-G5-NNN-022-AA-E6-06-00	SERIES 51	S51-110MV
83016723	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-E1-A5-A-N-G0-NNN-138-AA-G0-03-00	SERIES 51	S51-250MV

83016728	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A9-C1-B-D8-F-G5-NN-L-35-L-35-N-E-26-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83016730	PUMP-VAR DISPL, CW 90PV055	90-R-055-MB-5-BB-80-D-3-C6-L-02-GBA-38-38-26	SERIES 90	S90-055PV
83016731	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-E8-A2-A-N-E1-ABA-080-AA-F3-03-20	SERIES 51	S51-160MV
83016733	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A5-C2-B-D8-H-G9-NN-L-35-L-15-D-P-20-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83016734	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A5-C2-B-D8-G-G2-NN-L-38-L-20-A-P-20-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83016740	PUMP-VAR-DISPL 42PV041 CCW	42-L-41-D-E2D8-03-B-3-B-3-H-N-A-21-21-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83016742	MOTOR-VAR-DISPL 51MD080	51D080-A-D2-N-HZ-B1-B-H-C2-NNN-045-AA-NN-10-00	SERIES 51	S51-080MV
83016749	MOTOR-VAR-DISPL 51MV160	51V160-V-F1-A-H4-B3-R-J-N2-NNN-115-AA-NN-C2-24	SERIES 51	S51-160MV
83016751	MOTOR-VAR-DISPL 51MV160	51V160-V-F1-A-H4-B3-R-J-N2-NNN-115-AA-NN-C2-20	SERIES 51	S51-160MV
83016755	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-CD-80-P-4-C6-C-03-GBA-20-20-24	SERIES 90	S90-055PV
83016756	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-NN-80-P-4-S1-C-03-GBA-20-20-24	SERIES 90	S90-055PV
83016758	PUMP-VAR-DISPL CW 90PV180	90R180-KP-1-EG-80-T-C-C8-H-03-FAC-29-29-24	SERIES 90	S90-180PV
83016759	PUMP-VAR-DISPL CW 90PV180	90R180-KP-1-BB-80-T-C-C8-H-03-FAC-29-29-24	SERIES 90	S90-180PV
83016761	PUMP-VAR-DISPL CW 90PV250	90R250-HF-5-NN-80-T-3-C8-K-03-NNN-35-35-20	SERIES 90	S90-250PV
83016764	PUMP-VAR DISPL MPV035D	MPV-035-D-B-A-A-L-S-G-BA-A-A-BFF-DL-A-FF-D-NNN.***	M35/44	O35PV
83016768	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A5-C3-N-F7-F-G5-T3-35-35-35-35-M-P-24-PN-NNN-S01	H1-MP PUMPS	H1-045PT/053PT
83016769	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-E2-AA-N-B-TB-VS-ES-S-A-20-NN-065-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83016770	PUMP-VAR DISPL, CCW 90PV075	90-L-075-M8-5-NN-60-R-3-S1-D-02-GBA-38-38-24	SERIES 90	S90-075PV
83016771	PUMP-VAR DISPL, CCW 90PV055	90-L-055-DD-5-NN-60-R-4-S1-D-G8-GBA-35-35-24	SERIES 90	S90-055PV
83016773	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A4-C1-B-D1-F-G1-H3-38-38-38-38-N-P-24-PN-NNN-E07	H1-MP PUMPS	H1-045PT/053PT
83016776	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-L2-BA-N-B-PB-VN-EN-N-A-20-NN-000-N-00-NNN	H1-HP MOTORS	H1-160MB1
83016777	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-L2-BA-N-B-PB-VN-EN-N-N-NN-000-N-00-NNN	H1-HP MOTORS	H1-160MB1
83016796	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-S1-N-E1-B1-N-N-U1-NNN-033-AA-NN-00-00	SERIES 51	S51-080MV-1
83016797	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-D-E8-A5-A-N-G0-NNN-115-AA-G0-03-00	SERIES 51	S51-250MV
83016807	MOTOR-VARIABLE CARTRIDGE K	K-C-45DN-E-YNF-F11-S-N-N-AF-F16-NNN-NNN	LV / KV MOTORS	L/K-MV
83016809	PUMP-VAR-DISPL CW 90PV130	90R130-FG-5-CD-80-R-7-C8-H-B1-EFI-32-32-30	SERIES 90	S90-130PV
83016810	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-E1A6-03-A-N-A-2-F-N-A-30-30-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83016818	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-L3A3-10-C-3-N-N-F-N-A-38-38-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83016823	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-C2-C2-C-D3-K-G9-NN-L-42-L-42-D-M-24-P2-NNN-D4F	H1-HP PUMPS	H1-089PV/100PV
83016824	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-N-TN-F8-L-N-J2-ACA-078-AA-G0-00-BB	SERIES 51	S51-250MV
83016825	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A5-C2-N-D3-H-G9-H3-L-42-L-42-C-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83016826	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E2-AA-N-A-TA-VS-DS-S-A-10-NN-049-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83016827	PUMP-VAR DISPL, CW 90PV075	90-R-075-HS-1-BC-80-R-4-K2-D-03-GBA-26-26-24	SERIES 90	S90-075PV
83016831	PUMP-VAR-DISPL 42PV041 CW	42-R-51-D-E2C8-02-D-N-F-3-H-N-B-30-30-B-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83016832	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-B-N2-NN-N-N-A0-NNN-168-AA-H0-00-00	SERIES 51	S51-250MV
83016838	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HF-5-AB-80-L-3-S1-C-03-GBA-35-35-28	SERIES 90	S90-055PV

83016839	PUMP-VAR-DISPL CCW 90PV180	90L180-HF-5-CD-80-S-C-C8-J-03-NNN-35-35-28	SERIES 90	S90-180PV
83016841	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-1-EG-80-T-4-C8-J-02-NNN-35-35-24	SERIES 90	S90-250PV
83016843	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-2-BC-80-D-3-C6-L-00-GFD-42-42-34	SERIES 90	S90-100PV
83016844	PUMP-VAR-DISPL CCW H1PV115	H1-P-115-L-B-A4-C2-N-D6-G-G3-H5-L-40-L-40-A-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83016847	MOTOR-VAR-DISPL 51MV250	51V250-V-F2-N-HS-A2-C-H-E1-NNN-050-AA-NN-20-21	SERIES 51	S51-250MV
83016848	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-P1-D1-N-B-TB-DN-HN-N-A-10-NN-026-Z-24-NNN	H1-HP MOTORS	H1-080MB1
83016849	MOTOR-VAR-DISPL 51MV060-1	51V060-1--A-S1-N-T2-C2-N-N-X1-NNN-015-AA-E4-00-20	SERIES 51	S51-060MV-1
83016859	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-N-E3-B1-N-N-U1-NNN-012-AA-E6-00-00	SERIES 51	S51-060MV-1
83016860	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-N-E3-B1-N-N-U1-AWT-032-AA-E6-00-00	SERIES 51	S51-060MV-1
83016868	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-HS-A2-C-H-E1-NNN-125-AA-NN-16-24	SERIES 51	S51-250MV
83016872	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-CD-80-R-4-C7-E-02-GBA-32-32-24	SERIES 90	S90-100PV
83016882	PUMP-VAR DISPL, CW 90PV055	90-R-055-HS-5-AB-60-P-4-S1-B-03-GBA-42-42-24	SERIES 90	S90-055PV
83016883	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-1-BC-80-T-M-C8-J-03-NNN-35-35-30	SERIES 90	S90-180PV
83016886	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-1-EG-80-T-4-C8-K-03-NNN-35-35-30	SERIES 90	S90-250PV
83016887	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-1-DE-80-T-4-C8-K-03-NNN-35-16-30	SERIES 90	S90-250PV
83016888	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-1-CD-80-T-4-C8-K-03-NNN-35-16-30	SERIES 90	S90-250PV
83016889	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-1-CD-80-R-4-S1-F-03-GBA-35-16-30	SERIES 90	S90-100PV
83016890	MOTOR-VAR-DISPL 51MC060-1	51C060-1--R-D1-E-N1-NN-N-N-U1-NNN-020-AA-NN-00-00	SERIES 51	S51-060MV-1
83016896	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-NN-80-L-3-F1-D-03-GBA-42-42-24	SERIES 90	S90-100PV
83016900	PUMP-VAR DISPL, CW 90PV075	90-R-075-DD-5-AB-80-S-4-S1-C-GB-GBA-35-35-24	SERIES 90	S90-075PV
83016901	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-5-BC-60-P-4-S1-E-03-GBA-32-32-24	SERIES 90	S90-100PV
83016902	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-NN-80-D-C-C8-L-03-NNN-42-42-22	SERIES 90	S90-180PV
83016903	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-NN-80-D-3-C8-L-03-EHA-42-42-20	SERIES 90	S90-130PV
83016905	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-M2-CA-N-A-RA-VS-ES-S-A-10-NN-055-N-00-NNN	H1-HP MOTORS	H1-110MB1
83016906	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-T2-DA-N-B-TA-VN-AN-N-A-05-NN-015-Z-20-NNN	H1-HP MOTORS	H1-060MB1
83016915	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-NN-80-P-4-F1-F-03-GBA-35-35-24	SERIES 90	S90-130PV
83016917	PUMP-VAR-DISPL CW 90PV100	90R100-HS-1-CD-80-P-4-C7-F-00-GBA-42-42-24	SERIES 90	S90-100PV
83016924	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-5-CD-60-P-3-C6-D-03-GBA-35-35-24	SERIES 90	S90-055PV
83016926	PUMP-VAR-DISPL CCW 90PV180	90L180-HF-5-CD-80-T-M-C8-J-03-NNN-38-38-28	SERIES 90	S90-180PV
83016927	PUMP-VAR-DISPL CCW 90PV100	90L100-HF-5-BC-80-R-4-S1-F-03-GBA-38-38-28	SERIES 90	S90-100PV
83016928	PUMP-VAR-DISPL CCW 90PV250	90L250-HF-5-EG-80-T-4-C8-K-03-NNN-38-38-28	SERIES 90	S90-250PV
83016936	PUMP-VAR DISPL, CW 90PV075	90-R-075-HF-1-BC-80-P-4-S1-E-03-GBA-42-42-24	SERIES 90	S90-075PV
83016938	PUMP-VAR-DISPL 42PV028 CW	42-R-28-G-E2D8-02-B-2-B-3-H-N-B-30-30-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83016940	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-T2-D2-N-A-TB-VN-AN-N-A-10-NN-012-Z-20-NNN	H1-HP MOTORS	H1-060MB1
83016941	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A3-C2-N-E6-F-G5-NN-L-42-L-42-B-L-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83016952	MOTOR-VAR-DISPL 51MD060-1	51D060-1--A-D2-N-P7-P7-N-N-X1-NNN-022-AA-F3-00-AA	SERIES 51	S51-060MV-1

83016953	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-E2-AA-N-B-TB-CN-LN-N-A-20-NN-080-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83016954	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-AB-60-S-3-C7-E-00-GBA-36-36-24	SERIES 90	S90-100PV
83016955	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-HE-HE-N-A-TA-CN-LN-N-N-NN-032-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83016956	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A3-C2-N-D8-H-F1-H5-L-30-L-30-C-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83016957	PUMP-VAR-DISPL CCW H1PV089	H1-P-089-L-A-A2-C2-N-D8-H-F1-H3-K-45-K-45-N-E-34-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83016958	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A4-C1-N-E7-F-G1-T3-33-33-33-33-M-P-30-P3-NNN-S02	H1-MP PUMPS	H1-045PT/053PT
83016966	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-L1-BA-N-B-PB-CN-JN-N-A-05-NN-048-N-00-NNN	H1-HP MOTORS	H1-080MB1
83016967	MOTOR-VAR-DISPL 51MV080	51V080-V-S1-N-H4-B3-R-J-N2-NNN-016-AA-NN-C2-18	SERIES 51	S51-080MV
83016968	PUMP-VAR-DISPL CW 90PV075	90R075-MB-5-BC-60-S-3-C7-E-C5-GBA-42-42-24	SERIES 90	S90-075PV
83016972	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-N-N2-NN-N-N-A0-ACA-050-AA-G0-00-00-P000	SERIES 51	S51-250MV
83016973	PUMP-VAR-DISPL CCW H1PV089	H1-P-089-L-A-A2-C3-N-F5-H-G1-H6-L-35-L-35-D-P-30-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83016974	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-N-E1-A5-A-N-K7-ACA-168-AA-H0-03-00	SERIES 51	S51-250MV
83016977	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-L1-BA-N-B-PB-VN-AN-N-A-05-NN-044-N-00-NNN	H1-HP MOTORS	H1-080MB1
83016978	MOTOR-FIX DISPL MMF035D	MMF-035-D-A-6-H-C-G-NNN-***	M35/44	035MF
83016981	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A2-C3-B-D1-F-G8-T8-35-35-35-35-M-P-24-PN-C07-S01	H1-MP PUMPS	H1-045PT/053PT
83016982	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-B5-C3-D-D1-F-G8-T8-35-35-35-35-M-P-24-P1-C07-S01	H1-MP PUMPS	H1-045PT/053PT
83016984	PUMP-VAR DISPL, CW 90PV100	90-R-100-RS-1-NN-60-S-3-T2-F-03-GBA-42-42-24	SERIES 90	S90-100PV
83016985	PUMP-VAR DISPL, CW 90PV100	90-R-100-HS-1-NN-60-S-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83016986	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-L2-BA-N-B-PB-VN-EN-N-A-10-NN-050-N-00-NNN	H1-HP MOTORS	H1-110MB1
83016987	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-NN-60-S-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83016988	PUMP-VAR-DISPL CCW 90PV042	90L042-KA-5-BC-80-S-4-C3-B-03-GBA-42-42-24	SERIES 90	S90-042PV
83016991	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-E1-A5-A-N-G0-ACA-035-AA-F0-03-00	SERIES 51	S51-160MV
83016992	PUMP-VAR DISPL CCW H1P060L	H1-P-060-L-A-A2-C1-B-D3-H-G1-H3-L-28-L-28-C-M-30-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83016999	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A4-C2-N-D8-H-G1-H3-L-42-L-42-D-P-20-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83017006	PUMP-VAR-DISPL CCW 90PV100	90L100-HF-5-AB-80-L-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83017007	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-8-N-0-F1-W-00-EFA-00-00-F3	SERIES 90	S90-100MF
83017009	PUMP-VAR-DISPL CW 90PV100	90R100-HF-5-AB-80-L-3-C7-E-03-GBA-42-42-28	SERIES 90	S90-100PV
83017014	MOTOR- VARIABLE CARTRIDGE L	L-C-25CS-E-R1F-F06-S-N-N-BF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83017015	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-HZ-B1-A-N-G0-NNN-050-AA-NN-03-00	SERIES 51	S51-250MV
83017018	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-L1-BA-N-B-PB-DS-JS-S-A-10-NN-040-N-00-NNN	H1-HP MOTORS	H1-110MB1
83017022	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-A-A4-C2-B-D8-H-G1-H3-L-42-L-42-D-P-20-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83017025	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A5-C2-N-E7-F-G1-NN-40-40-40-40-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83017028	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-E-EQ-A7-J-Y-E1-CCA-105-AA-F0-15-20	SERIES 51	S51-250MV
83017029	PUMP-VAR DISPL MPV046C	MPV-046-C-B-A-B-T-B-B-AA-A-A-BJJ-AB-U-AD-A-NNN-***	M46	M46-046PV
83017033	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KT-P-CD-60-D-3-C7-L-03-GBA-45-45-24	SERIES 90	S90-100PV
83017035	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KT-P-NN-60-D-3-S1-L-03-GBA-45-45-24	SERIES 90	S90-100PV

83017036	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HF-1-BC-80-P-3-S1-C-02-GBA-35-35-24	SERIES 90	S90-055PV
83017037	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HF-1-BC-80-P-3-S1-C-02-GBA-38-38-24	SERIES 90	S90-075PV
83017038	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-HE-HE-N-B-TB-VN-AN-N-A-10-NN-024-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83017044	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-CD-80-L-4-F1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
83017046	MOTOR-VAR-DISPL H1MB060	H1-B-060-A-L1-BA-N-C-PB-CS-GS-S-A-05-NN-013-N-00-NNN	H1-HP MOTORS	H1-060MB1
83017051	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-E-Z-C-B-BA-B-B-A-A-BJJ-CB-A-GG-B-C-A-A-BJB-AB-D-FF-A-NNN-***	M46	M46-046PT
83017055	MOTOR-VAR-DISPL 51MD080-1	51D080-1--R-D2-A-E7-B1-N-N-U1-NNN-031-AA-F3-00-00	SERIES 51	S51-080MV-1
83017062	PUMP-VAR-DISPL CW 90PV100	90R100-HF-5-BC-80-R-4-C7-F-03-GBA-42-42-24	SERIES 90	S90-100PV
83017063	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-K-S-B-B-BA-A-A-BJJ-CB-A-SS-Y-NNT-***	M46	M46-046PV
83017065	PUMP-TANDEM, VAR DISPL CCW H1T045L	H1-T-045-L-A-N-B5-C3-C-F9-F-F2-H3-40-40-40-N-P-28-P1-C05-NNN	H1-MP PUMPS	H1-045PT/053PT
83017067	MOTOR-VARIABLE CARTRIDGE K	K-C-45DN-E-YNF-F11-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83017072	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-2-NN-81-S-3-S1-F-03-GBA-20-20-24	SERIES 90	S90-100PV
83017073	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-A-V-C-B-AA-B-B-A-A-BFF-CE-A-GG-B-D-A-A-BFF-CE-A-GG-A-NNN-*	M46	M46-046PT
83017078	MOTOR-VAR-DISPL 51MC060	51C060-R-D1-N-HZ-B1-B-H-G5-ABA-014-AA-E4-12-00	SERIES 51	S51-060MV
83017093	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-CD-80-T-3-C8-J-04-EFI-42-42-24	SERIES 90	S90-250PV
83017098	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-M2-CA-N-A-RB-CS-AS-S-A-10-NN-037-N-00-NNN	H1-HP MOTORS	H1-080MB1
83017099	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-L2-BA-N-A-PB-CS-AS-S-A-10-NN-026-N-00-NNN	H1-HP MOTORS	H1-080MB1
83017102	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-T1-D1-N-B-TA-DN-JN-N-A-10-NN-023-Z-24-NNN	H1-HP MOTORS	H1-110MB1
83017103	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A5-C2-N-D8-F-G5-H5-L-20-L-20-N-E-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83017106	PUMP-VAR-DISPL CW 90PV100	90R100-FH-5-CD-80-P-7-C7-E-B9-EFI-42-42-30	SERIES 90	S90-100PV
83017107	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-D2-M2-N-B-PB-VN-DN-N-A-15-NN-040-N-25-NNN	H1-HP MOTORS	H1-110MB1
83017108	PUMP-VAR-DISPL CW 90PV100	90R100-HF-5-NN-80-L-4-C7-F-03-GBA-21-21-30	SERIES 90	S90-100PV
83017109	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KN-1-AB-80-R-4-S1-D-03-GBA-38-38-24	SERIES 90	S90-075PV
83017110	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KN-1-CD-80-R-4-F1-E-03-GBA-38-38-24	SERIES 90	S90-100PV
83017117	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-E1A6-03-D-N-F-3-H-N-A-30-30-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83017122	PUMP-VAR-DISPL CW 90PV180	90R180-DD-1-CD-80-S-M-C8-J-GB-NNN-42-42-24	SERIES 90	S90-180PV
83017123	PUMP-VAR-DISPL CW 90PV100	90R100-DD-1-BC-80-S-4-S1-E-GB-GBA-29-29-24	SERIES 90	S90-100PV
83017130	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-CD-80-R-4-F1-F-03-GBA-14-14-24	SERIES 90	S90-130PV
83017131	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A3-C2-N-D8-F-G5-H3-L-30-L-30-B-P-32-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83017132	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A5-C2-N-D8-H-F1-H5-L-42-L-42-N-E-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83017134	PUMP-VAR-DISPL CW 90PV130	90R130-KA-2-CD-80-R-4-F1-H-00-GBA-38-38-24	SERIES 90	S90-130PV
83017138	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-AB-80-T-C-F1-H-03-NNN-42-42-24	SERIES 90	S90-180PV
83017139	PUMP-VAR DISPL, CW 90PV055	90-R-055-HS-2-CD-60-P-3-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83017140	PUMP-VAR DISPL, CW 90PV055	90-R-055-HS-2-NN-60-P-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83017141	PUMP-VAR DISPL CCW H1P060L	H1-P-060-L-A-A2-C1-B-F5-K-F1-H6-L-40-L-40-C-P-24-P4-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83017146	PUMP-VAR-DISPL CCW 90PV250	90L250-HF-5-NN-80-T-3-F1-K-03-NNN-35-35-20	SERIES 90	S90-250PV

83017147	MOTOR-VAR-DISPL 51MD080-1	51D080-1--A-D2-N-E7-B1-N-N-U1-NNN-031-AA-F3-00-00	SERIES 51	S51-080MV-1
83017148	MOTOR-VAR-DISPL 51MD080-1	51D080-1--R-D2-N-E7-B1-N-N-U1-NNN-031-AA-F3-00-00	SERIES 51	S51-080MV-1
83017152	PUMP-VAR DISPL CCW H1P060L	H1-P-060-L-A-A2-C1-B-D8-H-G1-NN-L-40-L-40-C-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83017153	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-8-N-0-C7-W-00-EBA-00-00-F3	SERIES 90	S90-075MF
83017155	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-NN-80-S-3-C8-H-02-GLA-35-35-20	SERIES 90	S90-130PV
83017160	MOTOR-VAR-DISPL H1B080	H1-B-080-A-TA-DA-N-B-TA-DN-JN-N-N-NN-NN-049-Z-24-NNN	H1-HP MOTORS	H1-080MB1
83017161	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-L2-BA-N-A-PB-VN-AN-N-A-05-NN-050-N-00-NNN	H1-HP MOTORS	H1-080MB1
83017162	MOTOR-VAR-DISPL 51MV110-1	51V110-1--H-F1-N-TA-C2-N-N-X1-NNN-027-AA-NN-00-21	SERIES 51	S51-110MV-1
83017163	PUMP-VAR-DISPL CW 90PV075	90R075-KA-1-AB-80-L-3-S1-D-00-GBA-42-42-24	SERIES 90	S90-075PV
83017164	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-HE-HE-N-A-TB-VN-AN-N-N-NN-NN-012-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83017165	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-HE-HE-N-A-TB-VN-EN-N-N-NN-NN-022-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83017168	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A3-C1-N-E7-F-G5-H2-33-33-33-33-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83017169	PUMP-VAR-DISPL CW 90PV100	90R100-DC-5-NN-60-P-3-C7-F-GB-GBA-32-32-24	SERIES 90	S90-100PV
83017171	MOTOR-VAR-DISPL 51MV250	51V250-A-C8-N-L3-B1-W-B-C0-ADA-050-AA-G3-D4-00	SERIES 51	S51-250MV
83017175	PUMP-VAR-DISPL CCW 90PV250	90L250-KP-5-NN-80-T-4-C8-J-04-NNN-26-26-24	SERIES 90	S90-250PV
83017176	PUMP-VAR-DISPL CW 90PV250	90R250-KP-5-EG-80-T-4-C8-J-04-NNN-26-26-24	SERIES 90	S90-250PV
83017177	PUMP-VAR-DISPL CW 90PV250	90R250-KP-5-NN-80-T-4-C8-J-04-NNN-26-26-24	SERIES 90	S90-250PV
83017181	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A3-C1-N-D8-H-F1-NN-L-40-L-40-C-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83017182	MOTOR-VAR-DISPL H1B160	H1-B-160-A-TA-DA-N-A-TA-CN-KN-N-N-NN-NN-080-Z-20-NNN	H1-HP MOTORS	H1-160MB1
83017183	MOTOR-VAR-DISPL 51MD080-1	51D080-1--A-D3-N-T7-R5-N-N-X1-NNN-045-AA-F0-00-26	SERIES 51	S51-080MV-1
83017184	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-CD-80-L-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83017194	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-BC-60-L-4-C7-E-03-GBA-35-35-24	SERIES 90	S90-075PV
83017201	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-BC-80-P-3-C3-C-00-GBA-29-29-24	SERIES 90	S90-042PV
83017212	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A3-C1-N-D8-H-F1-NN-L-40-L-40-C-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83017222	PUMP-VAR DISPL, CW 90PV100	90-R-100-HF-1-CD-80-R-4-F1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
83017224	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-5-NN-80-S-3-S1-F-04-GBA-42-42-24	SERIES 90	S90-100PV
83017225	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E1-AA-N-B-TB-VN-DN-N-A-10-NN-043-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83017227	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-BB-80-P-3-C7-E-03-GBA-45-35-22	SERIES 90	S90-075PV
83017228	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-EF-80-D-C-C8-L-03-NNN-40-40-28	SERIES 90	S90-180PV
83017229	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-NN-80-D-C-F1-N-03-NNN-40-40-28	SERIES 90	S90-180PV
83017230	PUMP-VAR-DISPL CW 90PV250	90R250-KN-5-EG-80-S-4-C8-J-03-NNN-38-38-24	SERIES 90	S90-250PV
83017231	PUMP-VAR-DISPL 42PV041 CW	42-R-41-C-A1NB-03-A-N-A-3-F-N-N-17-17-B-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83017232	PUMP-VAR-DISPL 42PV041 CW	42-R-51-E-ANNB-01-A-N-A-3-F-N-B-25-25-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83017233	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-NN-80-D-C-F1-N-03-NNN-38-38-28	SERIES 90	S90-180PV
83017234	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-EF-80-D-C-C8-L-03-NNN-20-20-28	SERIES 90	S90-180PV
83017238	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-BC-80-L-3-F1-F-03-GBA-26-26-24	SERIES 90	S90-130PV

83017240	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-5-BC-80-R-4-K2-D-03-GBA-14-14-24	SERIES 90	S90-075PV
83017242	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A2-C1-N-E5-F-G5-NN-L-35-L-35-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83017243	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-5-CD-80-S-3-F1-F-04-GBA-42-42-24	SERIES 90	S90-100PV
83017244	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-L2-BA-N-C-PA-CS-JS-S-A-15-NN-040-N-00-NNN	H1-HP MOTORS	H1-110MB1
83017246	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-NN-80-D-3-C8-N-03-GBA-29-29-28	SERIES 90	S90-130PV
83017247	MOTOR-VAR DISPL MMV046C	MMV-046-C-A-A-L-A-A5-VNC-***	M46	M46-046MV
83017248	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-NN-80-D-C-F1-N-03-NNN-20-20-28	SERIES 90	S90-180PV
83017254	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-NN-80-S-4-F1-F-03-GBA-17-17-24	SERIES 90	S90-100PV
83017255	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-G2A1-50-V-N-F-2-H-2-A-34-34-N-T-T-NNN-NNN	SERIES 42	S42-028PV/032PV
83017256	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-L1-BA-N-B-PB-VN-DN-N-A-15-NN-057-N-00-NNN	H1-HP MOTORS	H1-110MB1
83017257	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HS-1-NN-60-P-4-S1-C-03-GBA-32-14-30	SERIES 90	S90-055PV
83017259	PUMP-VAR-DISPL 42PV028 CW	42-R-28-G-ANN3-03-C-3-A-2-E-N-N-21-21-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83017262	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-Y-Z-C-S-BA-B-A-A-A-BJJ-AB-U-DD-B-C-A-A-BJJ-AB-U-DD-A-NNR-***	M46	M46-046PT
83017263	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-L8-B1-V-A-G0-NNN-107-AA-NN-B2-00	SERIES 51	S51-160MV
83017270	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-CD-80-T-C-C8-J-K4-GLA-35-35-30	SERIES 90	S90-180PV
83017272	PUMP-VAR-DISPL CW 90PV130	90R130-FH-5-CD-80-R-7-C8-H-B1-GBA-42-42-28	SERIES 90	S90-130PV
83017273	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-T2-D2-N-A-TB-VS-DS-S-A-20-NN-090-Z-30-NNN	H1-HP MOTORS	H1-160MB1
83017280	PUMP-VAR-DISPL CCW H1PV115	H1-P-115-L-B-A2-C2-N-D6-G-G2-H3-L-42-L-42-A-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83017282	PUMP-TANDEM, VAR DISPL CCW H1T045L	H1-T-045-L-A-N-A2-C2-B-E7-F-G1-TN-33-33-33-33-M-P-24-PN-NNN-S01	H1-MP PUMPS	H1-045PT/053PT
83017285	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A4-C2-N-D8-F-G1-H5-L-35-L-35-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83017288	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A2-C1-N-E5-F-G1-H1-L-35-L-35-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83017289	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-A1N5-01-A-N-A-2-F-N-N-C4-C4-N-N-N-NNN-ENN	SERIES 42	S42-041PV/051PV
83017290	PUMP-VAR-DISPL 42PV041 CCW	42-L-41-D-A1N5-01-A-N-A-2-F-N-N-C4-C4-N-N-N-NNN-ENN	SERIES 42	S42-041PV/051PV
83017297	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A2-C2-B-D6-G-G2-H3-L-20-L-25-L-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83017298	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E1-AA-N-A-TB-VS-ES-S-A-15-NN-000-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83017300	PUMP-VAR-DISPL 42PV041 CW	42-R-41-C-E1A3-03-B-D-G-2-E-N-B-34-34-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83017301	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-E1A3-03-B-D-G-2-E-N-B-34-34-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83017303	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-A7NB-03-B-4-B-2-C-N-A-34-34-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83017304	PUMP-VAR-DISPL CCW 90PV180	90L180-HF-5-CD-80-T-M-C8-J-03-NNN-42-42-28	SERIES 90	S90-180PV
83017306	PUMP-VAR DISPL CCW H1P060L	H1-P-060-L-A-A2-C2-N-F6-H-F1-H6-L-42-L-42-C-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83017307	PUMP-VAR DISPL CCW H1P060L	H1-P-060-L-A-A2-C2-N-D6-H-G1-H3-L-42-L-42-C-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83017313	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-HE-HE-N-A-TB-VN-AN-N-N-NN-NN-022-U-00-NNN	H1-HP MOTORS	H1-060MB1
83017314	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-HE-HE-N-A-TB-VN-AN-N-N-NN-NN-022-S-00-NNN	H1-HP MOTORS	H1-060MB1
83017317	PUMP-VAR-DISPL CW 90PV130	90R130-SA-2-NN-80-L-3-C8-H-33-PGA-42-42-26	SERIES 90	S90-130PV
83017321	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-BC-80-R-4-S1-C-00-EBC-35-35-24	SERIES 90	S90-055PV
83017322	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-NN-80-R-4-S1-E-00-EBC-38-38-24	SERIES 90	S90-100PV

83017332	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-BC-80-P-3-F1-F-03-GBA-45-45-24	SERIES 90	S90-130PV
83017333	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A4-C1-N-E7-F-G5-H1-35-35-35-35-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83017334	PUMP-VAR-DISPL CCW 90PV180	90L180-HF-5-AB-80-S-C-C8-J-03-NNN-35-35-28	SERIES 90	S90-180PV
83017335	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-T1-DA-N-B-TB-DN-HN-N-A-10-NN-016-Z-30-NNN	H1-HP MOTORS	H1-080MB1
83017336	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A4-C2-N-D6-F-G5-NN-L-30-L-30-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83017343	MOTOR-FIX DISPL MMF044D	MMF-044-D-A-F-U-C-G-NNN-***	M35/44	044MF
83017349	PUMP-VAR-DISPL CW 90PV180	90R180-HF-5-CD-80-T-M-C8-H-04-NNN-35-35-24	SERIES 90	S90-180PV
83017350	PUMP-VAR-DISPL CW 90PV130	90R130-HF-5-CD-80-R-3-C8-F-04-GBA-35-35-24	SERIES 90	S90-130PV
83017351	PUMP-VAR-DISPL CW 90PV100	90R100-HF-5-BC-80-R-4-S1-F-04-GBA-35-35-24	SERIES 90	S90-100PV
83017373	MOTOR-VAR-DISPL H1B060	H1-B-060-A-TA-DA-N-A-TB-VN-AN-N-N-NN-NN-022-Z-30-NNN	H1-HP MOTORS	H1-060MB1
83017377	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A4-C1-N-D6-F-G5-NN-L-30-L-30-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83017384	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-EF-80-D-C-C8-L-03-NNN-38-38-28	SERIES 90	S90-180PV
83017393	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A3-C3-N-D8-F-G1-NN-L-42-L-42-B-P-24-PN-C01-NNN	H1-MP PUMPS	H1-045PV/053PV
83017394	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-BB-80-P-3-C7-E-03-GBA-42-35-22	SERIES 90	S90-075PV
83017395	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-HE-HE-N-C-TB-CS-GS-S-N-NN-NN-028-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83017400	MOTOR-FIX DISPL MMF035D	MMF-035-D-A-S-G-C-D-NNN-***	M35/44	035MF
83017402	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-E2-AA-N-B-TB-DN-KN-N-A-20-NN-076-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83017403	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-BC-80-S-3-S1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
83017404	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E2-AA-N-A-TA-VN-EN-N-N-NN-NN-036-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83017408	MOTOR-VAR-DISPL 51MV160	51V160-A-C8-N-HS-A3-A-H-E5-NNN-037-AA-F0-04-32	SERIES 51	S51-160MV
83017410	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-8-N-0-F1-N-00-EFA-00-00-00	SERIES 90	S90-100MF
83017411	PUMP-VAR DISPL CCW H1P060L	H1-P-060-L-A-A3-C1-B-F5-K-F1-H6-L-40-L-40-C-P-24-P4-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83017412	PUMP-VAR DISPL CCW H1P060L	H1-P-060-L-A-A3-C1-B-D8-H-G1-NN-L-40-L-40-C-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83017430	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-NN-80-R-4-C7-F-03-GBA-26-26-24	SERIES 90	S90-100PV
83017431	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-C8-N-E2-B1-N-N-U1-NNN-070-AA-G0-00-00	SERIES 51	S51-110MV-1
83017433	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-2-NN-80-S-3-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83017435	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A3-C3-N-D8-F-G4-NN-L-40-L-40-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83017436	PUMP-VAR-DISPL CCW 90PV250	90L250-KP-5-BC-80-T-4-F1-K-03-NNN-35-14-24	SERIES 90	S90-250PV
83017438	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-HE-HE-N-B-TA-CN-LN-N-N-NN-NN-100-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83017440	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-NN-60-S-4-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
83017441	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-C5-C2-N-F5-H-G1-H6-L-42-L-42-D-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83017443	MOTOR-VARIABLE DISPL SAE_L	L-V-30DN-A-YNF-F08-S-N-N-AF-F14-NNN-NNN	LV / KV MOTORS	L/K-MV
83017444	MOTOR-VARIABLE DISPL SAE_L	L-V-35EN-G-Y1F-F10-S-N-N-AF-F18-NNA-NNN	LV / KV MOTORS	L/K-MV
83017447	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A2-C1-N-F6-H-F1-H6-L-35-L-35-C-L-20-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83017452	PUMP-VAR-DISPL CCW 90PV180	90L180-HS-5-CD-80-T-M-C8-H-03-NNN-42-42-24	SERIES 90	S90-180PV
83017453	PUMP-VAR-DISPL CCW 90PV180	90L180-HS-5-CD-80-T-M-C8-H-03-NNN-26-26-24	SERIES 90	S90-180PV

83017454	PUMP-VAR-DISPL CCW 90PV250	90L250-HS-5-EG-80-T-4-C8-J-03-NNN-23-23-24	SERIES 90	S90-250PV
83017455	PUMP-VAR-DISPL CCW 90PV100	90L100-HS-5-BC-80-R-4-S1-E-03-GBA-26-26-24	SERIES 90	S90-100PV
83017457	PUMP-VAR-DISPL CW 90PV100	90R100-KA-1-NN-60-P-4-C7-F-03-GBA-38-38-24	SERIES 90	S90-100PV
83017458	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A2-C3-N-E5-F-G5-H5-L-40-L-40-N-E-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83017459	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A3-C2-N-D8-H-G1-H3-L-35-L-35-M-P-24-PN-C07-NNN	H1-HP PUMPS	H1-089PV/100PV
83017460	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-J-S-A-J-BC-A-A-BHF-CB-A-RR-3-NNG-***	M46	M46-046PV
83017470	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-2-CD-60-P-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-075PV
83017471	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-2-CD-60-P-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83017474	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-Y3-B1-S-K-J1-ACA-150-AA-G3-F4-00	SERIES 51	S51-250MV
83017476	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A2-C1-N-F6-H-F1-H6-L-42-L-42-C-L-20-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83017479	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-HE-HE-N-C-TB-CN-GN-N-A-05-NN-028-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83017480	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-HE-HE-N-C-TB-CS-GS-S-A-05-NN-028-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83017481	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-T2-DA-N-B-TA-VN-AN-N-N-NN-NN-024-Z-20-NNN	H1-HP MOTORS	H1-080MB1
83017482	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A5-C2-B-D8-H-G1-NN-L-35-L-35-C-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83017483	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-CD-80-P-3-C7-D-00-GBA-29-29-24	SERIES 90	S90-075PV
83017485	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-AB-80-S-3-F1-F-03-EFI-29-29-24	SERIES 90	S90-100PV
83017488	PUMP-VAR-DISPL CW 90PV180	90R180-MA-5-CD-80-T-C-C8-J-C6-NNN-45-45-28	SERIES 90	S90-180PV
83017489	PUMP-VAR-DISPL CCW 90PV042	90L042-HF-1-NN-80-R-4-C3-C-03-GBA-35-35-28	SERIES 90	S90-042PV
83017498	MOTOR-VARIABLE CARTRIDGE K	K-C-45DN-E-R1F-F08-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83017499	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-N-A4-C1-B-D1-F-G1-H3-38-38-38-38-N-P-24-PN-NNN-E10	H1-MP PUMPS	H1-045PT/053PT
83017500	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A4-C1-B-D1-F-G1-H3-38-38-38-38-N-P-24-PN-C13-E09	H1-MP PUMPS	H1-045PT/053PT
83017501	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A4-C1-B-D1-F-G1-H3-38-38-38-38-N-P-24-PN-C13-E08	H1-MP PUMPS	H1-045PT/053PT
83017502	PUMP-VAR-DISPL CW 90PV250	90R250-HF-5-AB-80-S-4-C8-J-03-NNN-42-42-24	SERIES 90	S90-250PV
83017503	PUMP-VAR-DISPL CW 90PV130	90R130-MA-5-NN-80-R-3-F1-F-C7-GBA-26-26-24-P000	SERIES 90	S90-130PV
83017504	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-8-N-0-S1-W-00-EFT-00-00-G0	SERIES 90	S90-075MF
83017505	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-5-NN-80-D-4-C8-L-03-NNN-42-16-30	SERIES 90	S90-250PV
83017510	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-CD-80-L-3-C7-E-03-GBA-29-29-24	SERIES 90	S90-100PV
83017512	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-E1-AA-N-A-TB-CN-KN-N-A-20-NN-060-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83017513	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-HE-HE-N-A-TB-CN-LN-N-N-NN-NN-108-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83017519	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-C5-C2-N-F5-H-F1-H6-L-42-L-42-D-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83017521	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-EG-80-D-M-C8-L-03-NNN-35-35-34	SERIES 90	S90-180PV
83017522	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-DE-80-D-M-C8-L-03-NNN-35-35-34	SERIES 90	S90-180PV
83017523	PUMP-VAR DISPL CCW H1P060L	H1-P-060-L-A-A2-C2-N-D8-H-G1-NN-L-42-L-42-F-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83017525	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-CD-80-R-3-F1-H-00-GBA-35-35-24	SERIES 90	S90-130PV
83017527	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-NN-80-R-3-F1-H-00-GBA-35-35-24	SERIES 90	S90-130PV
83017528	MOTOR-VAR-DISPL 51MV080-1	51V080-1--A-S1-N-E1-B1-N-N-U1-ABA-032-AA-F0-00-00	SERIES 51	S51-080MV-1

83017541	PUMP-U STYLE HST TANDEM LDU CW	LDU-20D-R-A-R-S-AA-A-H-N-07-C-25N-25N-NNN-NNN	DDC20/LDU20	OSK-020U - DO NOT USE
83017542	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-B8-C2-C-D8-G-G2-H6-L-40-L-40-L-P-30-P1-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83017543	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-C5-C2-N-D8-H-G1-H5-L-42-L-42-D-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83017544	PUMP-VAR-DISPL CCW 90PV250	90L250-KN-5-NN-80-S-4-C8-K-03-NNN-40-40-26	SERIES 90	S90-250PV
83017545	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-C5-C2-N-D8-H-F1-H5-L-42-L-42-D-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83017547	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-N2-NN-N-N-A0-NNN-060-AA-G3-00-00	SERIES 51	S51-160MV
83017552	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A2-C2-N-E9-F-G5-NN-K-35-K-35-B-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83017553	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-K2-K2-N-B-RB-DS-KS-S-A-30-NN-032-N-30-NNN	H1-HP MOTORS	H1-160MB1
83017554	PUMP-VAR-DISPL CCW H1PV089	H1-P-089-L-A-A2-C2-N-D8-H-F1-H5-L-40-L-40-M-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83017557	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E1-AA-N-C-TB-VS-AS-S-N-NN-NN-027-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83017558	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-M1-CA-N-B-RB-CS-JS-P-A-10-NN-000-N-00-N05	H1-HP MOTORS	H1-080MB1
83017559	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-M1-CA-N-B-RB-CS-JS-P-N-NN-NN-000-N-00-N05	H1-HP MOTORS	H1-080MB1
83017560	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-M1-CA-N-B-RB-CS-JS-P-N-NN-NN-000-N-00-N05	H1-HP MOTORS	H1-110MB1
83017561	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-M1-CA-N-B-RB-CS-JS-P-A-10-NN-000-N-00-N05	H1-HP MOTORS	H1-110MB1
83017562	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-1-CD-80-R-3-F1-E-03-GBA-42-14-24	SERIES 90	S90-100PV
83017564	PUMP-VAR-DISPL 42PV028 CW	42-R-2A-G-E2C8-00-B-D-X-A-D-N-Z-41-41-N-A-A-AAA-NNN	SERIES 42	S42-028PV/032PV
83017565	PUMP-VAR-DISPL 42PV028 CW	42-R-2A-G-E2C8-00-B-4-B-3-D-N-N-41-41-N-A-A-AAA-NNN	SERIES 42	S42-028PV/032PV
83017567	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-BC-80-T-M-F1-H-03-EEB-14-14-24	SERIES 90	S90-180PV
83017572	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-TA-C2-N-N-X1-NNN-080-AA-F3-00-35	SERIES 51	S51-110MV-1
83017577	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A5-C2-N-F4-H-G9-H6-L-28-L-28-M-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83017580	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-NN-60-R-4-C7-E-00-GBA-23-23-30	SERIES 90	S90-100PV
83017588	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-M1-CA-N-A-RA-DS-JS-S-A-10-NN-016-N-00-NNN	H1-HP MOTORS	H1-080MB1
83017597	MOTOR-VAR-DISPL 51MV110	51V110-A-F1-N-HZ-B1-C-H-C2-NNN-030-AA-F0-15-00	SERIES 51	S51-110MV
83017598	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-K1-K1-N-B-RB-VS-FS-S-A-20-NN-032-N-20-NNN	H1-HP MOTORS	H1-160MB1
83017601	MOTOR-VARIABLE DISPL SAE_K	K-V-38CN-E-Y2F-F10-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83017605	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E2-AA-N-B-TB-DN-KN-N-N-NN-NN-055-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83017616	MOTOR-VAR-DISPL H1B250	H1-B-250-A-L1-BA-N-A-PA-VS-FS-S-B-50-NN-050-N-00-NNN	H1-HP MOTORS	H1-250MB1
83017617	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-G3AN-50-P-D-G-2-G-5-A-30-30-B-0-0-NNN-NNN	SERIES 42	S42-041PV/051PV
83017618	PUMP-VAR-DISPL 42PV041 CW	42-R-41-E-G3AN-50-P-D-G-2-G-5-V-30-30-B-0-0-NNN-NNN	SERIES 42	S42-041PV/051PV
83017620	PUMP-VAR DISPL, CW 90PV100	90-R-100-DD-1-CD-80-L-4-C7-E-GB-GBA-35-35-24	SERIES 90	S90-100PV
83017621	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-E-V-C-S-AA-B-A-C-A-BHH-GG-B-BF-B-C-C-A-BHH-GG-B-BF-B-NNN-*	M46	M46-046PT
83017623	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-E2-AA-N-B-TB-VN-DN-N-N-NN-NN-080-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83017627	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E2-AA-N-B-TB-CS-GS-S-A-05-NN-022-S-00-NNN	H1-HP MOTORS	H1-060MB1
83017629	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-BC-80-S-3-C6-C-03-FAB-45-45-24	SERIES 90	S90-055PV
83017635	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-K1-K1-N-A-RA-DS-KS-S-A-10-NN-050-N-24-NNN	H1-HP MOTORS	H1-110MB1
83017643	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-AB-60-S-3-S1-E-03-GBA-26-26-24	SERIES 90	S90-075PV

83017645	MOTOR-VAR-DISPL 51MV080-1	51V080-1--A-C7-N-T2-D2-N-N-X1-NNN-045-AA-E6-00-16	SERIES 51	S51-080MV-1
83017646	PUMP-VAR DISPL, CW 90PV100	90-R-100-DD-1-AB-60-P-4-S1-E-G8-GBA-35-35-24	SERIES 90	S90-100PV
83017647	PUMP-VAR DISPL, CW 90PV100	90-R-100-DD-1-CD-60-P-4-C7-E-G8-GBA-35-35-24	SERIES 90	S90-100PV
83017649	PUMP-VAR-DISPL CCW 90PV250	90L250-HF-5-NN-80-T-4-F1-K-03-NNN-21-21-24	SERIES 90	S90-250PV
83017650	MOTOR-FIX DISPL MMF044D	MMF-044-D-A-F-H-C-T-NNR-***	M35/44	044MF
83017654	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A5-C3-N-D3-K-G1-H3-L-35-L-35-C-M-24-P4-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83017655	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A4-C1-N-E6-F-G5-NN-L-30-L-30-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83017656	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-F1-C1-C-E5-F-G5-NN-L-28-L-28-B-P-24-P1-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83017657	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A2-C2-N-D6-H-G1-NN-L-40-L-40-C-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83017662	MOTOR-VAR-DISPL 51MV110-1	51V110-1--A-F1-A-N1-NN-N-N-U1-NNN-072-AA-NN-00-00	SERIES 51	S51-110MV-1
83017673	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-T2-DA-N-B-TB-VN-AN-N-A-10-NN-045-Z-28-NNN	H1-HP MOTORS	H1-080MB1
83017676	PUMP-VAR-DISPL 42PV028 CW	42-R-32-D-ANN3-02-D-N-F-2-C-N-A-21-21-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83017677	PUMP-VAR-DISPL 42PV041 CCW	42-L-41-D-ANN3-02-B-2-G-2-F-N-A-34-34-B-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83017679	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-N-A4-C3-N-E7-F-G5-H3-35-35-35-35-N-P-28-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83017680	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-BC-60-S-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83017681	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-N-TA-C2-L-N-G0-NNN-125-AA-NN-00-B8	SERIES 51	S51-160MV
83017684	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-CD-80-R-3-C6-E-03-GBA-30-30-24	SERIES 90	S90-100PV
83017685	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-5-NN-80-R-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-055PV
83017687	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-BC-80-S-4-S1-D-02-GBA-35-35-24	SERIES 90	S90-075PV
83017691	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-AB-80-R-4-K3-E-00-GBA-35-35-24	SERIES 90	S90-100PV
83017692	MOTOR-FIX DISPL MMF044D	MMF-044-D-A-D-Y-A-B-NNN-***	M35/44	044MF
83017695	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-HS-A2-B-H-E1-NNN-050-AA-E6-08-25	SERIES 51	S51-250MV
83017696	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-T1-DA-N-B-TB-VN-EN-N-A-10-NN-059-Z-17-NNN	H1-HP MOTORS	H1-110MB1
83017697	PUMP-VAR-DISPL CW 90PV130	90R130-KA-2-DE-80-R-4-F1-H-00-GBA-38-38-24	SERIES 90	S90-130PV
83017698	PUMP-VAR-DISPL CCW H1PV130	H1-P-130-L-B-A3-C2-N-D6-G-G2-H3-L-42-L-42-A-L-30-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83017699	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-1-AB-60-S-4-T2-C-35-GCA-23-23-24-F003	SERIES 90	S90-075PV
83017705	PUMP-VAR DISPL, CCW 90PV100	90-L-100-CB-5-NN-80-S-3-C7-E-00-GBA-42-42-24	SERIES 90	S90-100PV
83017708	PUMP-TANDEM, VAR DISPL CCW H1T045L	H1-T-045-L-A-N-A2-C2-B-E7-F-G1-TN-18-18-18-18-M-P-22-PN-NNN-S01	H1-MP PUMPS	H1-045PT/053PT
83017710	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-NN-60-P-4-S1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
83017711	MOTOR-VAR-DISPL 51MV110-1	51V110-1--A-F1-N-TA-C2-N-N-X1-NNN-063-AA-NN-00-14	SERIES 51	S51-110MV-1
83017712	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-S1-N-TA-C2-N-N-X1-NNN-054-AA-F0-00-24	SERIES 51	S51-080MV-1
83017718	PUMP-VAR-DISPL CCW H1PV089	H1-P-089-L-A-A5-C3-N-F6-H-G9-H6-L-45-L-45-D-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83017719	PUMP-VAR-DISPL CCW H1PV089	H1-P-089-L-A-A5-C3-N-D6-H-G1-NN-L-42-L-42-D-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83017722	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-1-AB-60-L-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-055PV
83017723	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E1-AA-N-B-TB-VN-AN-N-A-10-NN-040-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83017728	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-AB-80-S-3-C8-H-03-GBA-42-42-24	SERIES 90	S90-130PV

83017729	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-BC-80-R-4-C7-F-05-GBA-26-26-24	SERIES 90	S90-100PV
83017730	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-AB-80-R-4-C8-H-05-GBA-35-35-24	SERIES 90	S90-130PV
83017734	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-B-N2-NN-N-A0-NNN-105-AA-G3-00-00	SERIES 51	S51-160MV
83017735	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-L2-BA-N-A-PA-DS-KS-S-A-15-NN-055-N-00-NNN	H1-HP MOTORS	H1-110MB1
83017739	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A4-C3-N-D1-F-G1-T3-25-25-25-25-M-P-22-PN-NNN-S01	H1-MP PUMPS	H1-045PT/053PT
83017743	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E1-AA-N-B-TB-CS-GS-S-A-05-NN-020-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83017748	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-W-CD-60-E-3-C6-D-02-GFD-40-34-24	SERIES 90	S90-075PV
83017749	PUMP-VAR DISPL, CW 90PV075	90-R-075-LE-W-BC-60-E-3-S1-D-02-GFD-40-34-24	SERIES 90	S90-075PV
83017750	MOTOR-VAR-DISPL 51MC060	51C060-R-D1-N-HZ-B1-A-H-C2-NNN-019-AA-F0-03-00	SERIES 51	S51-060MV
83017751	MOTOR-VAR-DISPL H1B250	H1-B-250-A-L2-BA-N-B-PA-VS-DS-S-A-20-NN-055-N-00-NNN	H1-HP MOTORS	H1-250MB1
83017756	PUMP-VAR-DISPL CCW 90PV180	90L180-KN-5-CD-80-D-M-F1-L-05-FAC-35-35-28	SERIES 90	S90-180PV
83017779	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-NN-80-R-3-S1-E-03-GBA-35-35-18	SERIES 90	S90-100PV
83017781	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-NN-80-R-3-S1-D-03-GBA-29-35-18	SERIES 90	S90-075PV
83017784	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A4-C2-N-E7-F-G5-NN-42-42-42-42-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83017788	PUMP-VAR DISPL, CW 90PV075	90-R-075-M8-1-CD-80-P-3-S1-D-03-GBA-45-45-24	SERIES 90	S90-075PV
83017800	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-E1A7-02-A-N-A-3-H-N-N-23-23-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83017801	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-C-E1A4-02-C-3-A-2-F-N-A-14-14-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83017804	MOTOR-VAR-DISPL H1B110	H1-B-110-A-TA-DA-N-B-TB-VN-EN-N-A-10-NN-074-Z-25-NNN	H1-HP MOTORS	H1-110MB1
83017812	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-HE-HE-N-A-TB-CN-JN-N-A-05-NN-016-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83017813	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-L1-BA-N-A-PB-CN-JN-N-A-05-NN-016-N-00-NNN	H1-HP MOTORS	H1-080MB1
83017814	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-L1-BA-N-A-PB-CN-JN-N-A-10-NN-022-N-00-NNN	H1-HP MOTORS	H1-110MB1
83017815	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A2-C1-N-D3-G-G3-H3-L-42-L-42-L-M-32-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83017816	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A2-C1-N-D5-G-G2-H4-L-42-L-42-L-M-32-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83017817	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-1-AB-60-P-3-S1-C-03-GBA-32-14-20	SERIES 90	S90-055PV
83017818	PUMP-VAR-DISPL CW DDC20	DDC-20-A-R-RB-LSA-NN-A-N-5-AB-ACD0-E-07-21A-21N-NNN-NAN	DDC20/LDU20	OSK-020PV - DO NOT USE
83017828	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-CD-80-L-3-C7-E-03-GBA-38-38-24	SERIES 90	S90-100PV
83017829	MOTOR-VARIABLE CARTRIDGE K	K-C-45DS-E-R3F-F07-S-N-N-DF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83017832	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-N-HS-A2-C-E-G6-NNN-049-AA-NN-18-24	SERIES 51	S51-160MV
83017834	PUMP-VAR-DISPL CW 90PV250	90R250-HF-5-NN-80-S-4-C8-J-03-NNN-42-42-24	SERIES 90	S90-250PV
83017836	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-BC-60-S-3-S1-D-D3-EEB-42-42-24	SERIES 90	S90-055PV
83017837	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-L2-BA-N-A-PA-CS-JS-S-A-10-NN-070-N-00-NNN	H1-HP MOTORS	H1-110MB1
83017839	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-HZ-B1-A-N-C2-NNN-032-AA-F0-03-00	SERIES 51	S51-160MV
83017841	PUMP-VAR-DISPL CCW 90PV100	90L100-MA-5-NN-80-L-3-D7-E-C5-GBA-42-42-24	SERIES 90	S90-100PV
83017843	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-A-A5-C3-N-D8-H-G9-H3-L-42-L-42-D-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83017853	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KF-5-CD-8G-D-3-F1-L-00-GFD-32-32-36	SERIES 90	S90-100PV
83017854	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KF-5-NN-8G-D-3-S1-L-00-GFD-32-32-36	SERIES 90	S90-100PV

83017855	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-HZ-B1-C-E-G5-NNN-032-AA-NN-12-00	SERIES 51	S51-160MV
83017861	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-1-CD-80-L-4-F1-H-03-GBA-26-26-26	SERIES 90	S90-130PV
83017865	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-E2D8-02-A-N-A-3-H-N-A-35-35-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83017868	MOTOR- VARIABLE CARTRIDGE L	L-C-25CS-E-RNF-F07-S-N-N-FF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83017873	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-BC-80-S-4-S1-E-02-GBA-35-35-24	SERIES 90	S90-100PV
83017875	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-1-CD-60-S-3-T2-E-03-GBA-29-29-24	SERIES 90	S90-075PV
83017882	MOTOR-VAR-DISPL 51MD060-1	51D060-1--R-D1-N-TA-CA-N-N-X1-NNN-040-AA-F0-00-20	SERIES 51	S51-060MV-1
83017883	MOTOR-VAR-DISPL 51MD080-1	51D080-1--R-D3-N-TA-CA-N-N-X1-NNN-050-AA-F0-00-20	SERIES 51	S51-080MV-1
83017891	PUMP-VAR-DISPL CW 90PV075	90R075-HF-5-BC-80-D-3-C7-L-03-GBA-35-35-30	SERIES 90	S90-075PV
83017894	PUMP-VAR DISPL, CW 90PV100	90-R-100-HF-1-BC-80-R-4-S1-F-09-GBA-38-38-24	SERIES 90	S90-100PV
83017895	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-CD-80-L-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83017897	PUMP-VAR-DISPL CW 90PV250	90R250-KA-1-BC-80-T-3-F1-K-03-NNN-32-32-30	SERIES 90	S90-250PV
83017898	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-ANN3-03-D-N-F-2-F-N-B-23-23-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83017899	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A4-C3-N-F5-H-F1-H6-L-38-L-38-F-P-30-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83017900	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A4-C3-N-D8-H-G1-H5-L-28-L-28-F-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83017909	PUMP-VAR DISPL, CCW 90PV055	90-L-055-DD-1-NN-80-S-3-S1-D-G8-GBA-26-26-24	SERIES 90	S90-055PV
83017910	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E2-AA-N-C-TB-VN-AN-N-N-NN-NN-038-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83017911	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E2-AA-N-C-TB-VN-AN-N-N-NN-NN-031-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83017923	PUMP-VAR DISPL, CW 90PV075	90-R-075-DD-1-AB-80-P-4-S1-D-G8-GBA-35-35-24	SERIES 90	S90-075PV
83017926	MOTOR-VARIABLE CARTRIDGE K	K-C-45DS-E-R3F-F07-S-N-N-DF-F15-NNN-NNN	LV / KV MOTORS	L/K-MV
83017941	PUMP-VAR-DISPL CCW 90PV250	90L250-KN-1-NN-80-T-4-F1-J-03-NNN-44-44-30	SERIES 90	S90-250PV
83017946	PUMP-VAR-DISPL 42PV041 CCW	42-L-41-C-A7J5-03-A-N-A-3-F-N-N-NN-NN-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83017953	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-1-BC-80-S-4-C7-C-00-GCB-26-26-18	SERIES 90	S90-075PV
83017959	PUMP-VAR-DISPL 42PV041 CW	42-R-51-D-ANKB-03-A-N-A-3-F-N-N-17-17-B-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83017960	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-E2-AA-N-B-TB-CN-LN-N-N-NN-NN-108-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83017961	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-A-S-B-B-AA-J-A-BJJ-DB-A-HH-C-NNN-***	M46	M46-046PV
83017963	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A4-C3-N-F6-H-F1-H6-L-38-L-38-F-L-30-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83017964	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A4-C3-N-D6-H-G1-H5-L-28-L-28-F-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83017968	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-BC-80-S-4-S1-E-02-GBA-35-35-24	SERIES 90	S90-100PV
83017969	MOTOR-VARIABLE DISPL SAE_K	K-V-45DN-A-R1F-F01-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83017970	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KN-1-BC-80-S-4-S1-C-03-GBA-32-32-24	SERIES 90	S90-055PV
83017971	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-1-AB-80-R-4-F1-F-03-GBA-26-26-24	SERIES 90	S90-130PV
83017974	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-BC-80-S-4-F1-J-04-NNN-40-40-26	SERIES 90	S90-250PV
83017979	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-CD-60-L-3-C6-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83017980	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-E1A6-02-A-N-A-3-H-N-N-23-23-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83017981	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E2-AA-N-B-TB-CN-KN-N-N-NN-NN-060-Z-00-NNN	H1-HP MOTORS	H1-110MB1

83017982	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-D-T-B-J-BA-A-A-BDD-CE-A-HH-B-NNN-***	M46	M46-046PV
83017984	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-A-Z-C-J-BA-B-B-A-A-BDD-CE-A-HH-B-D-A-A-BDD-CE-A-HH-B-NNN-*	M46	M46-046PT
83017989	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-1-NN-60-P-3-C6-E-02-GBA-42-42-24	SERIES 90	S90-075PV
83017990	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-AB-60-R-3-C7-E-04-GBA-36-36-24	SERIES 90	S90-075PV
83017994	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A5-C3-N-E7-F-G1-TN-40-40-40-40-M-P-24-PN-NNN-S01	H1-MP PUMPS	H1-045PT/053PT
83017998	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-5-BC-60-R-4-S1-C-GF-GBA-38-38-24	SERIES 90	S90-055PV
83017999	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-T2-D2-N-C-TB-VS-DS-S-A-10-NN-070-Z-25-NNN	H1-HP MOTORS	H1-110MB1
83018000	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-C-E2D8-03-C-2-A-3-F-N-B-23-23-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83018003	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A5-C2-N-F6-H-G9-H6-L-35-L-35-M-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83018004	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A5-C2-N-D6-H-G1-H5-L-35-L-35-C-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83018005	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A5-C2-N-D6-F-G5-H3-L-35-L-35-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83018006	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A5-C2-N-F6-H-G1-H6-L-35-L-35-C-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83018009	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-M2-CA-N-B-RB-VN-EN-N-N-NN-NN-000-N-00-NNN	H1-HP MOTORS	H1-160MB1
83018012	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-E2C8-03-A-N-A-2-D-N-A-30-30-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83018014	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-5-DE-80-S-3-C8-K-03-NNN-42-42-24	SERIES 90	S90-250PV
83018015	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-5-EG-80-S-3-C8-K-03-EFI-42-42-24	SERIES 90	S90-250PV
83018020	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-NN-80-S-4-S1-E-03-GBA-17-17-24	SERIES 90	S90-075PV
83018021	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-AB-60-S-4-S1-C-03-GBA-29-14-24	SERIES 90	S90-055PV
83018022	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-CD-60-S-4-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83018025	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E2-AA-N-B-TB-CN-GN-N-A-10-NN-036-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83018027	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-G-T-B-B-AA-A-A-BDD-CB-A-JJ-C-NNN-***	M46	M46-046PV
83018028	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-L2-BA-N-B-PB-VS-ES-S-A-20-NN-064-N-00-NNN	H1-HP MOTORS	H1-160MB1
83018029	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-L2-BA-N-B-PB-VS-ES-S-A-20-NN-053-N-00-NNN	H1-HP MOTORS	H1-160MB1
83018033	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-B-TH-C2-L-N-K7-ADA-079-AA-F0-00-B1	SERIES 51	S51-250MV
83018039	MOTOR-VARIABLE DISPL SAE_L	L-V-30DN-A-YNF-F65-S-N-N-AF-F12-NNN-NNN	LV / KV MOTORS	L/K-MV
83018040	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-NN-60-S-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
83018042	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HS-1-CD-80-S-3-S1-E-03-GBA-29-29-24	SERIES 90	S90-100PV
83018043	PUMP-VAR DISPL CW H1P068R	H1-P-068-R-A-A4-C2-B-D6-K-G1-H2-L-30-L-30-C-L-20-P4-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83018050	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-BC-80-R-4-C7-E-03-GBA-26-26-24	SERIES 90	S90-100PV
83018052	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-N2-NN-N-N-A0-ACA-115-AA-G0-00-00	SERIES 51	S51-160MV
83018053	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-N2-NN-N-N-A0-ADA-115-AA-G0-00-00	SERIES 51	S51-160MV
83018062	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A8-C2-C-D6-K-G9-H2-L-42-L-42-C-L-26-P2-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83018063	PUMP-VAR DISPL, CW 90PV100	90-R-100-FD-1-AB-80-P-3-F1-E-B1-GBA-35-35-24	SERIES 90	S90-100PV
83018066	PUMP-TANDEM, VAR DISPL CCW H1T045L	H1-T-045-L-A-N-A2-C2-N-E7-F-G5-H3-42-42-42-42-N-P-30-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83018068	PUMP-VAR-DISPL CCW 90PV250	90L250-KT-5-BC-80-D-4-F1-L-03-NNN-35-35-30	SERIES 90	S90-250PV
83018070	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-CD-80-R-3-C7-F-03-GBA-35-35-24	SERIES 90	S90-100PV

83018088	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-NN-80-S-3-S1-E-03-GBA-35-35-18	SERIES 90	S90-100PV
83018089	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-C8-N-TA-C2-N-N-X1-NNN-045-AA-NN-00-23	SERIES 51	S51-110MV-1
83018090	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-C8-N-TA-C2-N-N-X1-NNN-055-AA-NN-00-23	SERIES 51	S51-110MV-1
83018094	PUMP-VAR-DISPL CW 90PV180	90R180-HF-1-NN-80-T-M-F1-J-00-NNN-42-42-24	SERIES 90	S90-180PV
83018095	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-NN-80-S-3-S1-D-03-GBA-29-35-18	SERIES 90	S90-075PV
83018096	MOTOR-VAR-DISPL H1MB060	H1-B-060-A-L2-BA-N-B-PB-VN-AN-N-A-10-NN-012-N-00-NNN	H1-HP MOTORS	H1-060MB1
83018101	PUMP-VAR-DISPL CCW 90PV250	90L250-HS-5-CD-80-T-3-C8-K-03-NNN-42-42-28	SERIES 90	S90-250PV
83018105	PUMP-VAR DISPL, CW 90PV055	90-R-055-HF-2-NN-80-R-4-S1-D-04-GBA-35-35-24	SERIES 90	S90-055PV
83018112	PUMP-VAR-DISPL CCW 90PV250	90L250-HS-5-EF-80-T-3-C8-K-03-NNN-42-42-28	SERIES 90	S90-250PV
83018113	PUMP-VAR-DISPL CCW 90PV180	90L180-HS-5-BC-80-T-C-F1-J-03-FAC-42-42-28	SERIES 90	S90-180PV
83018114	MOTOR-VAR-DISPL 51MV250	51V250-A-C8-N-HZ-B1-B-H-C2-NNN-168-AA-H0-06-00	SERIES 51	S51-250MV
83018115	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-HZ-B1-B-H-C2-NNN-112-AA-G3-06-00	SERIES 51	S51-250MV
83018116	PUMP-VAR-DISPL CW 90PV075	90R075-KA-P-BB-80-P-4-C7-E-03-GBA-48-48-24	SERIES 90	S90-075PV
83018117	MOTOR-VARIABLE DISPL SAE_K	K-V-38CS-A-R1F-F12-S-N-N-BF-F17-NNN-NNN	LV / KV MOTORS	L/K-MV
83018123	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A5-C2-N-D6-H-G1-H5-L-38-L-38-F-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83018124	PUMP-VAR DISPL MPV035D	MPV-035-D-B-A-G-R-S-G-AA-A-A-BEE-DR-A-FF-A-NNN-***	M35/44	035PV
83018130	MOTOR-FIX DISPL MMF044D	MMF-044-D-A-F-M-C-T-NNQ-***	M35/44	044MF
83018137	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A3-C2-B-D3-K-G1-NN-L-35-L-35-C-M-24-P4-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83018138	MOTOR-VAR-DISPL 51MV250	51V250-A-C8-N-T3-L5-L-N-G0-NNN-064-AA-G0-00-C5	SERIES 51	S51-250MV
83018139	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A4-C1-B-D6-H-G1-H5-L-23-L-23-C-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83018140	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A4-C1-B-D3-H-G1-NN-L-33-L-33-C-M-30-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83018142	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A4-C2-B-D6-H-G1-H3-L-28-L-28-C-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83018143	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A4-C2-B-D6-H-G1-NN-L-28-L-28-C-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83018144	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A4-C1-B-D3-H-G1-NN-L-35-L-35-C-M-30-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83018145	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-B8-C2-C-D6-H-F4-H1-L-35-L-35-M-L-24-P1-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83018148	MOTOR-VARIABLE DISPL SAE_K	K-V-38CS-A-R1F-F00-S-N-N-BF-F17-NNN-NNN	LV / KV MOTORS	L/K-MV
83018149	PUMP-VAR DISPL, CCW 90PV055	90-L-055-MA-1-NN-80-R-3-S1-C-03-GBA-17-17-24	SERIES 90	S90-055PV
83018150	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-1-BC-80-R-4-S1-F-03-GBA-35-35-30	SERIES 90	S90-100PV
83018151	PUMP-VAR-DISPL CCW 90PV130	90L130-HS-1-CD-80-S-4-C8-H-03-GBA-35-32-30	SERIES 90	S90-130PV
83018152	PUMP-VAR-DISPL CCW 90PV130	90L130-HS-1-CD-80-S-4-C8-H-03-GBA-35-16-30	SERIES 90	S90-130PV
83018153	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-1-DE-80-D-M-C8-L-03-NNN-35-35-30	SERIES 90	S90-180PV
83018154	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-1-CD-80-T-4-C8-K-03-NNN-35-35-30	SERIES 90	S90-250PV
83018155	PUMP-VAR-DISPL CW 90PV250	90R250-MB-2-AB-80-S-3-F1-K-03-NNN-32-26-26	SERIES 90	S90-250PV
83018156	PUMP-VAR-DISPL CW 90PV130	90R130-MB-2-AB-80-S-3-F1-H-03-GBA-32-26-26	SERIES 90	S90-130PV
83018158	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-NN-60-R-4-S1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
83018159	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KN-1-NN-80-R-4-T2-E-03-GBA-42-14-24	SERIES 90	S90-100PV

83018160	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A4-C1-B-D6-H-G1-NN-L-28-L-28-C-L-26-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83018161	PUMP-VAR-DISPL CW 90PV180	90R180-KA-1-BC-80-S-C-F1-H-03-FAC-42-42-24	SERIES 90	S90-180PV
83018162	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-1-NN-80-S-4-S1-C-03-GBA-35-35-24	SERIES 90	S90-075PV
83018163	MOTOR-VAR DISPL MMV046C	MMV-046-C-A-E-F-A-AX-NNN-***	M46	M46-046MV
83018171	MOTOR-VARIABLE DISPL SAE_K	K-V-38CS-A-YNF-F09-S-N-N-CF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83018174	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A2-C1-N-F5-H-F1-H6-L-42-L-42-C-P-20-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83018175	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A2-C1-N-F5-H-F1-H6-L-42-L-42-N-E-30-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83018176	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A5-C3-N-D3-H-G1-NN-L-35-L-35-D-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83018178	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-2-BC-80-S-3-S1-F-33-GFJ-42-42-24	SERIES 90	S90-100PV
83018181	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-BC-80-S-3-S1-E-03-GBA-35-35-28	SERIES 90	S90-100PV
83018182	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-1-NN-80-R-3-C7-E-03-GBA-26-26-28	SERIES 90	S90-075PV
83018183	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-1-BC-80-D-3-F1-L-03-GBA-35-35-24	SERIES 90	S90-130PV
83018184	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-1-CD-80-D-3-F1-L-03-GBA-35-35-24	SERIES 90	S90-130PV
83018185	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-D2-MA-N-A-PB-CS-KS-S-N-NN-NN-050-N-22-NNN	H1-HP MOTORS	H1-160MB1
83018186	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-D2-MA-N-A-PB-DS-KS-S-N-NN-NN-050-N-22-NNN	H1-HP MOTORS	H1-160MB1
83018192	PUMP-VAR-DISPL CCW 90PV130	90L130-MA-1-BC-80-R-3-F1-F-03-GBA-42-42-24	SERIES 90	S90-130PV
83018194	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A5-C3-N-F4-H-G9-H6-L-35-L-35-D-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83018196	PUMP-VAR-DISPL CCW 90PV130	90L130-KT-2-BC-80-L-3-F1-F-03-GBA-42-42-24	SERIES 90	S90-130PV
83018197	PUMP-VAR-DISPL CCW 90PV130	90L130-KT-2-NN-80-L-3-F1-F-03-GBA-42-42-24	SERIES 90	S90-130PV
83018205	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-CD-80-R-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-075PV
83018206	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-CD-80-R-3-S1-C-03-GBA-32-32-24	SERIES 90	S90-055PV
83018209	PUMP-VAR DISPL, CW 90PV075	90-R-075-HS-1-NN-80-P-3-C6-D-03-GBA-42-42-24	SERIES 90	S90-075PV
83018210	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-BC-80-D-3-S1-L-03-GBA-26-26-24	SERIES 90	S90-075PV
83018212	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-F8NN-53-V-N-Y-A-P-1-Z-34-34-N-8-8-NNN-BAB	SERIES 42	S42-028PV/032PV
83018217	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-BC-80-P-4-C6-D-03-EBC-32-32-24-F022	SERIES 90	S90-075PV
83018221	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-P2-D2-N-B-TB-VS-DS-S-A-20-NN-098-Z-24-NNN	H1-HP MOTORS	H1-160MB1
83018222	PUMP-VAR-DISPL CW 90PV100	90R100-KA-1-CD-60-L-4-F1-E-03-GBA-26-26-24	SERIES 90	S90-100PV
83018226	MOTOR-VAR-DISPL 51MV110	51V110-R-F1-N-HZ-B1-B-H-G5-ABA-022-AA-F3-05-00	SERIES 51	S51-110MV
83018227	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-BC-80-R-3-F1-F-03-EBC-35-35-30	SERIES 90	S90-100PV
83018229	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-NN-80-R-3-F1-H-03-EBA-35-35-30	SERIES 90	S90-130PV
83018230	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-L2-BA-N-B-PB-VS-AS-S-A-05-NN-020-N-00-NNN	H1-HP MOTORS	H1-080MB1
83018231	PUMP-VAR DISPL, CCW 90PV055	90-L-055-MA-1-NN-60-S-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
83018233	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KN-1-NN-80-R-3-S1-F-03-GBA-38-38-28	SERIES 90	S90-100PV
83018234	PUMP-VAR-DISPL CW 90PV250	90R250-KN-5-CD-80-T-3-F1-K-03-NNN-38-38-28	SERIES 90	S90-250PV
83018236	PUMP-VAR-DISPL CCW H1PV130	H1-P-130-L-B-A5-C2-N-D6-G-G2-H3-L-42-L-42-L-L-30-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83018237	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A5-C2-N-D6-H-G9-H3-L-42-L-42-D-L-30-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV

83018238	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-E2-AA-N-B-TB-CS-LS-S-A-20-NN-080-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83018239	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E2-AA-N-B-TB-CS-JS-S-A-10-NN-045-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83018240	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-CD-80-L-3-C7-E-03-GBA-38-38-24	SERIES 90	S90-100PV
83018241	PUMP-VAR-DISPL CCW 90PV075	90L075-KP-2-NN-80-L-3-C7-D-00-GBA-42-42-24	SERIES 90	S90-075PV
83018244	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A4-C1-N-D6-H-G1-H5-L-42-L-42-M-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83018253	PUMP-VAR-DISPL CW 90PV100	90R100-KP-5-CD-80-L-3-C7-F-05-GBA-32-32-20	SERIES 90	S90-100PV
83018254	PUMP-VAR-DISPL CW 90PV075	90R075-KP-5-CD-80-L-3-S1-E-05-GBA-32-32-20	SERIES 90	S90-075PV
83018260	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-NN-80-P-3-S1-C-03-GBA-26-26-20	SERIES 90	S90-055PV
83018262	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-5-NN-80-S-4-S1-E-26-GBA-23-23-28	SERIES 90	S90-075PV
83018264	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E2-AA-N-B-TA-VS-AS-S-A-05-NN-000-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83018274	PUMP-VAR DISPL, CW 90PV075	90-R-075-HS-1-CD-80-R-3-S1-E-03-GBA-42-42-28	SERIES 90	S90-075PV
83018278	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E1-AA-N-A-TB-CN-GN-N-A-05-NN-035-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83018281	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A5-C2-N-D3-H-G1-H3-L-38-L-38-C-M-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83018285	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-1-CD-80-R-4-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
83018286	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-HE-HE-N-A-TB-VN-AN-N-N-NN-NN-040-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83018292	PUMP-VAR DISPL, CW 90PV055	90-R-055-HF-2-CD-60-S-3-C6-C-03-GBA-32-32-24	SERIES 90	S90-055PV
83018298	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-K-T-B-B-AA-A-A-BCC-CD-A-GG-B-NNN-***	M46	M46-046PV
83018302	PUMP-VAR-DISPL CW 90PV180	90R180-DD-5-CD-80-T-M-C8-J-G8-NNN-35-35-24	SERIES 90	S90-180PV
83018305	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A5-C2-N-D3-G-G2-H6-L-38-L-38-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83018306	PUMP-VAR DISPL, CW 90PV075	90-R-075-LN-1-CD-60-R-2-S1-D-C8-GLA-07-20-24-F022	SERIES 90	S90-075PV
83018309	PUMP-TANDEM, VAR DISPL MPT035D	MPT-035-D-C-R-A-H-NN-B-A-A-A-BJJ-DR-A-FF-B-C-A-A-BJJ-DR-A-FF-B-NNN-***	M35/44	035PT
83018310	PUMP-VAR DISPL, CW 90PV075	90-R-075-HS-5-AB-60-D-4-C7-L-03-GBA-35-35-24	SERIES 90	S90-075PV
83018311	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-HE-HE-N-A-TB-VN-EN-N-N-NN-NN-055-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83018314	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-AB-80-S-4-C8-H-03-GBA-26-26-24	SERIES 90	S90-130PV
83018320	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KN-5-CD-80-R-4-S1-D-03-GBA-42-42-24	SERIES 90	S90-055PV
83018322	PUMP-VAR DISPL, CW 90PV100	90-R-100-HS-1-CD-80-R-3-S1-F-03-GBA-42-42-28	SERIES 90	S90-100PV
83018324	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-1-AB-80-R-3-F1-H-03-GBA-45-45-24	SERIES 90	S90-130PV
83018325	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-1-CD-80-R-3-F1-H-03-GBA-45-45-24	SERIES 90	S90-130PV
83018327	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-HZ-B1-B-H-G5-ABA-036-AA-F0-06-00	SERIES 51	S51-080MV
83018332	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-D8-M1-R-J-M4-ACA-050-AA-G0-C2-35	SERIES 51	S51-250MV
83018337	PUMP-VAR-DISPL CCW H1PV089	H1-P-089-L-A-A4-C1-B-D3-H-G1-NN-L-38-L-38-D-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83018338	MOTOR-VAR-DISPL 51MV250	51V250-U-C8-N-HZ-B1-C-N-C2-NNN-100-AA-E6-18-00	SERIES 51	S51-250MV
83018339	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-1-CD-80-D-M-C8-L-03-NNN-42-16-30	SERIES 90	S90-180PV
83018340	PUMP-VAR-DISPL CCW 90PV130	90L130-HS-1-BB-80-S-4-C8-H-03-GBA-35-16-30	SERIES 90	S90-130PV
83018342	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-C2-C2-C-D6-K-G9-H2-L-35-L-35-C-L-30-P2-NNN-D4F	H1-HP PUMPS	H1-069PV/078PV
83018343	MOTOR-VAR-DISPL 51MD110-1	51D110-1--R-D3-N-E2-B1-N-N-U1-NNN-060-AA-E6-00-00	SERIES 51	S51-110MV-1

83018347	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-HE-HE-N-A-TB-CN-JN-N-A-10-NN-074-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83018352	PUMP-TANDEM, VAR DISPL MPT025C	MPT-025-C-S-R-A-G-NN-B-A-A-A-BDD-DR-A-FF-B-C-A-A-BMM-DL-A-FF-A-NNN	LIGHT DUTY	025PT
83018360	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-NN-60-S-3-S1-E-03-GBA-23-23-24	SERIES 90	S90-100PV
83018361	MOTOR-VAR-DISPL H1MB060	H1-B-060-A-L2-BA-N-B-PA-CS-GS-S-N-NN-NN-015-N-00-NNN	H1-HP MOTORS	H1-060MB1
83018362	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-AB-80-P-3-S1-D-03-GBA-29-29-24	SERIES 90	S90-075PV
83018366	PUMP-TANDEM, VAR DISPL MPT044D	MPT-044-D-A-R-R-H-AA-B-A-A-A-BJJ-DL-A-FF-B-C-A-A-BJJ-DL-A-FF-D-NNN-***	M35/44	044PT
83018369	MOTOR-FIX DISPL MMF044D	MMF-044-D-A-D-U-C-K-NNR-***	M35/44	044MF
83018370	PUMP-VAR-DISPL CCW 90PV180	90L180-DC-5-BC-80-T-M-F1-J-GB-FAC-14-32-28	SERIES 90	S90-180PV
83018372	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E1-AA-N-B-TB-VN-EN-N-A-10-NN-034-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83018375	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HS-1-CD-80-R-3-C7-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83018376	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-AB-80-T-3-C8-K-03-NNN-42-42-24	SERIES 90	S90-250PV
83018377	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-D2-MA-N-B-PA-DN-KN-N-N-NN-NN-108-N-25-NNN	H1-HP MOTORS	H1-160MB1
83018378	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A5-C2-B-D8-G-G3-NN-L-25-L-25-A-P-20-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83018379	MOTOR-VAR-DISPL H1B250	H1-B-250-A-K1-K1-N-B-RA-VS-DS-S-A-15-NN-095-N-28-NNN	H1-HP MOTORS	H1-250MB1
83018382	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-BC-80-S-3-C8-K-03-NNN-29-29-24	SERIES 90	S90-250PV
83018387	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E2-AA-N-B-TB-DN-JN-N-N-NN-NN-032-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83018389	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A9-C1-B-D8-F-G5-H2-L-40-L-40-N-E-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83018391	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-NN-80-S-3-F1-E-03-GBA-38-38-24	SERIES 90	S90-100PV
83018407	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-P2-D2-N-B-TA-DS-KS-S-A-30-NN-053-Z-24-NNN	H1-HP MOTORS	H1-160MB1
83018410	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-1-AB-80-S-M-F1-H-03-FAC-26-26-24	SERIES 90	S90-180PV
83018411	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-1-BC-60-S-3-T1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
83018414	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-CD-80-R-3-S1-D-00-EBC-38-38-24	SERIES 90	S90-075PV
83018415	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-AB-80-R-3-S1-D-00-GBA-38-38-24	SERIES 90	S90-075PV
83018416	PUMP-VAR DISPL, CW 90PV055	90-R-055-KN-5-NN-60-D-4-S1-L-03-GBA-20-20-28	SERIES 90	S90-055PV
83018419	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-E1-A5-A-N-K7-NNN-107-AA-F0-03-00	SERIES 51	S51-160MV
83018420	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-E1-A5-A-N-K7-NNN-080-AA-F0-03-00	SERIES 51	S51-160MV
83018421	PUMP-VAR DISPL, CCW 90PV100	90-L-100-DD-5-AB-60-P-4-S1-E-G8-GBA-35-35-24	SERIES 90	S90-100PV
83018422	PUMP-VAR DISPL, CCW 90PV100	90-L-100-DD-5-CD-60-P-4-T2-E-G8-GBA-35-35-24	SERIES 90	S90-100PV
83018423	PUMP-VAR DISPL, CW 90PV100	90-R-100-DD-5-AB-60-P-4-S1-E-G8-GBA-35-35-24	SERIES 90	S90-100PV
83018424	PUMP-VAR DISPL, CW 90PV100	90-R-100-DD-5-CD-60-P-4-T2-E-G8-GBA-35-35-24	SERIES 90	S90-100PV
83018430	PUMP-VAR-DISPL CW 90PV042	90R042-HF-5-NN-80-S-4-C3-C-03-GBA-35-35-24	SERIES 90	S90-042PV
83018431	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-N2-NN-N-N-A0-NNN-070-AA-F0-00-00	SERIES 51	S51-160MV
83018438	MOTOR- VARIABLE CARTRIDGE L	L-C-25CN-A-ANF-F08-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83018441	PUMP-VAR DISPL, CW 90PV100	90-R-100-HF-1-BC-80-L-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83018444	MOTOR-VARIABLE CARTRIDGE K	K-C-38CN-E-Y2F-F01-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83018448	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HS-5-BC-80-R-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV

83018449	PUMP-VAR-DISPL CCW 90PV130	90L130-HS-5-CD-80-R-4-T4-H-03-GBA-35-35-24	SERIES 90	S90-130PV
83018450	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-CD-80-R-4-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83018451	PUMP-VAR-DISPL CW 90PV250	90R250-HF-2-EG-80-T-3-C8-K-00-NNN-32-32-24	SERIES 90	S90-250PV
83018452	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HS-1-NN-80-P-4-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83018453	PUMP-VAR DISPL, CW 90PV055	90-R-055-HS-1-BC-80-P-4-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83018454	PUMP-VAR DISPL, CW 90PV100	90-R-100-FC-1-BC-60-P-7-F1-E-B1-GBA-40-40-24	SERIES 90	S90-100PV
83018460	PUMP-VAR-DISPL CW 90PV100	90R100-HF-5-BC-80-S-4-C7-F-03-GBA-26-26-24	SERIES 90	S90-100PV
83018461	PUMP-VAR-DISPL CW 90PV250	90R250-HF-5-BC-80-S-4-C8-J-03-NNN-26-26-24	SERIES 90	S90-250PV
83018462	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-CD-80-R-4-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83018467	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-1-AB-80-S-M-F1-H-03-FAC-42-42-24	SERIES 90	S90-180PV
83018470	PUMP-VAR-DISPL CCW 90PV180	90L180-KN-1-BC-80-T-C-F1-H-03-FAC-32-32-24	SERIES 90	S90-180PV
83018472	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A4-C2-B-D6-H-G1-NN-L-25-L-25-C-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83018473	PUMP-VAR-DISPL CCW H1PV089	H1-P-089-L-A-A4-C1-B-D6-H-G1-H5-L-28-L-28-D-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83018484	MOTOR-VARIABLE DISPL SAE_L	L-V-35EN-A-R4F-F08-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83018485	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-L1-BA-N-A-PB-VS-AS-S-A-05-NN-000-N-00-NNN	H1-HP MOTORS	H1-080MB1
83018486	PUMP-VAR-DISPL CW 90PV180	90R180-MB-5-CD-80-T-M-C8-J-C5-NNN-42-42-24	SERIES 90	S90-180PV
83018487	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-BC-80-T-M-C8-J-03-NNN-42-42-24	SERIES 90	S90-180PV
83018488	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HS-1-CD-80-R-3-F1-F-03-GBA-32-38-24	SERIES 90	S90-100PV
83018489	PUMP-VAR DISPL, CW 90PV100	90-R-100-HS-1-CD-80-R-3-C7-F-03-GBA-32-32-24	SERIES 90	S90-100PV
83018491	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A2-C1-N-F6-H-F1-H6-L-35-L-35-C-L-26-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83018492	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A2-C1-B-D6-H-G1-NN-L-23-L-23-F-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83018494	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A2-C1-B-D6-H-G1-NN-L-23-L-23-F-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83018497	PUMP-VAR-DISPL CW 90PV100	90R100-MB-5-CD-80-L-4-C7-E-C5-GBA-42-42-24	SERIES 90	S90-100PV
83018500	MOTOR-VAR-DISPL 51MV110-1	51V110-1--A-F1-N-E2-B1-N-N-U1-NNN-074-AA-F0-00-00	SERIES 51	S51-110MV-1
83018502	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-BC-60-S-3-C7-D-04-GBA-42-42-24	SERIES 90	S90-075PV
83018505	PUMP-VAR DISPL MPV046C	MPV-046-C-B-A-A-S-B-B-BA-A-A-BMM-AB-U-ED-C-NNN-***	M46	M46-046PV
83018506	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-ANN3-03-A-N-A-2-F-N-B-34-34-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83018507	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A5-C2-N-D6-H-G9-H3-L-30-L-30-D-L-30-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83018508	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-T2-DA-N-B-TB-DN-JN-N-A-10-NN-050-Z-20-NNN	H1-HP MOTORS	H1-080MB1
83018509	PUMP-VAR DISPL, CW 90PV100	90-R-100-DD-1-NN-60-S-4-C7-E-GB-GBA-23-23-24	SERIES 90	S90-100PV
83018510	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-CD-80-R-3-F1-F-00-GBA-42-42-24	SERIES 90	S90-100PV
83018512	PUMP-VAR DISPL, CW 90PV075	90-R-075-KT-1-CD-60-L-3-S1-E-02-GBA-32-32-24	SERIES 90	S90-075PV
83018513	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-NN-80-L-3-F1-E-03-GBA-26-26-24	SERIES 90	S90-100PV
83018515	PUMP-VAR-DISPL CCW 90PV180	90L180-KN-1-CD-80-T-M-F1-H-03-FAC-40-40-30	SERIES 90	S90-180PV
83018516	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KN-1-CD-80-P-4-S1-D-03-GBA-40-40-30	SERIES 90	S90-075PV
83018517	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KN-1-AB-80-P-4-S1-D-03-GBA-40-40-30	SERIES 90	S90-075PV

83018518	MOTOR-VARIABLE DISPL SAE_L	L-V-35EN-A-RNF-F08-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83018520	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-CD-80-R-4-S1-E-09-GBA-38-38-24	SERIES 90	S90-075PV
83018530	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A3-C3-N-D8-F-G1-H5-L-18-L-38-B-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83018531	MOTOR-FIX DISPL MMF035D	MMF-035-D-A-S-U-C-D-NNN-***	M35/44	035MF
83018537	PUMP-VAR-DISPL CCW 90PV180	90L180-KT-1-NN-80-T-C-F1-J-04-FAC-42-20-26	SERIES 90	S90-180PV
83018540	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-G3AN-53-T-N-D-3-F-5-T-30-30-B-0-0-NNN-NNN	SERIES 42	S42-028PV/032PV
83018543	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-C8-N-TA-C2-N-N-X1-NNN-038-AA-NN-00-19	SERIES 51	S51-110MV-1
83018545	PUMP-VAR-DISPL 42PV028 CW	42-R-28-G-E1A6-02-C-3-A-2-F-N-B-34-34-B-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83018547	MOTOR-VAR-DISPL 51MV110	51V110-A-F1-N-HS-A2-B-E-E1-NNN-044-AA-F0-05-24	SERIES 51	S51-110MV
83018550	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HF-1-BC-80-P-3-S1-D-02-GBA-38-38-24	SERIES 90	S90-075PV
83018552	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-CD-80-P-3-T2-F-09-GBA-35-35-24	SERIES 90	S90-100PV
83018553	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-CD-80-L-3-S1-D-03-GBA-35-35-30	SERIES 90	S90-075PV
83018555	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-D-N2-NN-N-N-A0-NNN-105-AA-H0-00-00	SERIES 51	S51-160MV
83018562	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-HE-HE-N-A-TB-VN-EN-N-N-NN-NN-035-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83018564	MOTOR-VAR-DISPL 51MC060-1	51C060-1--A-D1-N-E0-B1-N-N-U1-ADA-030-AA-F0-00-00	SERIES 51	S51-060MV-1
83018565	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-NN-60-R-3-S1-E-04-GBA-35-35-28	SERIES 90	S90-100PV
83018569	PUMP-VAR-DISPL CW 90PV075	90R075-HS-5-AB-60-D-4-C7-L-03-GBA-35-35-24	SERIES 90	S90-075PV
83018570	PUMP-VAR DISPL CW 90PV100	90R100-HF-1-CD-80-R-4-F1-F-00-GBA-32-26-30	SERIES 90	S90-100PV
83018571	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-A-B7-C2-C-D8-K-G9-H2-L-45-L-45-M-P-28-P2-NNN-D5F	H1-HP PUMPS	H1-089PV/100PV
83018573	MOTOR-VAR-DISPL 51MV160	51V160-A-C8-N-L8-B1-V-A-C0-NNN-070-AA-NN-B2-00	SERIES 51	S51-160MV
83018576	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-N2-NN-N-N-A0-NNN-085-AA-NN-00-00	SERIES 51	S51-160MV
83018577	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A3-C2-N-D6-G-G2-H2-K-42-K-42-A-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83018584	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KN-1-CD-60-P-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83018588	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-D-HS-A2-B-H-G6-NNN-100-AA-G3-05-20	SERIES 51	S51-250MV
83018590	PUMP-VAR-DISPL CW 90PV100	90R100-HF-1-BC-60-S-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83018591	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-E2-AA-N-B-TB-VN-EN-N-N-NN-NN-100-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83018602	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-D2-MA-N-B-PA-VN-AN-N-N-NN-NN-047-N-20-NNN	H1-HP MOTORS	H1-080MB1
83018603	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-HE-HE-N-B-TA-CN-JN-N-N-NN-NN-054-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83018606	PUMP-VAR DISPL, CW 90PV075	90-R-075-HS-1-CD-60-P-3-C6-D-03-GBA-23-23-24	SERIES 90	S90-075PV
83018608	PUMP-VAR DISPL CW H1P068R	H1-P-068-R-A-A5-C2-N-F6-H-G1-H6-L-30-L-30-C-L-28-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83018609	PUMP-VAR DISPL CW H1P068R	H1-P-068-R-A-A5-C2-N-D6-H-G1-H2-L-30-L-30-C-L-28-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83018616	PUMP-VAR-DISPL CCW 90PV180	90L180-MA-5-NN-80-S-C-F1-J-C5-NNN-42-42-24	SERIES 90	S90-180PV
83018617	PUMP-VAR-DISPL CCW 90PV180	90L180-MA-5-NN-80-S-M-C8-J-C5-FAC-32-32-24	SERIES 90	S90-180PV
83018618	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-AB-80-S-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
83018622	MOTOR-VAR-DISPL H1MB060	H1-B-060-A-L1-BA-N-B-PM-CS-GS-S-A-10-NN-000-N-00-NNN	H1-HP MOTORS	H1-060MB1
83018623	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-L1-BA-N-B-PM-CS-HS-S-A-10-NN-000-N-00-NNN	H1-HP MOTORS	H1-080MB1

83018634	PUMP-VAR DISPL MPV044D	MPV-044-D-B-A-G-W-S-E-AA-A-A-BEE-DR-A-FF-A-NNN-***	M35/44	044PV
83018640	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A5-C2-N-E6-F-G5-NN-L-42-L-42-B-L-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83018644	PUMP-VAR-DISPL CW 90PV100	90R100-LW-5-AB-60-S-3-C7-E-C5-FAB-38-38-24	SERIES 90	S90-100PV
83018655	PUMP-VAR-DISPL 42PV028 CW	42-R-2A-C-G2A2-50-U-3-B-2-F-1-A-25-25-B-0-0-AAA-NNN	SERIES 42	S42-028PV/032PV
83018657	PUMP-VAR-DISPL CCW H1PV130	H1-P-130-L-B-A5-C2-N-D3-G-G2-H6-L-28-L-28-A-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83018659	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A3-C2-N-D3-G-G3-H2-L-42-L-42-A-M-20-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83018660	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A3-C2-N-D9-G-G2-H4-L-42-L-42-A-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83018661	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-L2-BA-N-B-PA-VS-DS-S-A-15-NN-000-N-00-NNN	H1-HP MOTORS	H1-110MB1
83018665	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-1-NN-80-T-M-F1-H-03-FAC-42-42-24	SERIES 90	S90-180PV
83018666	PUMP-VAR-DISPL CCW 90PV100	90L100-MB-1-AB-60-L-3-C7-F-03-GBA-42-42-24	SERIES 90	S90-100PV
83018668	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-HE-HE-N-A-TB-CN-JN-N-N-NN-NN-050-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83018669	PUMP-VAR-DISPL CW 90PV130	90R130-KA-V-BJ-8J-S-3-C4-F-04-GB3-45-45-24	SERIES 90	S90-130PV
83018676	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A5-C2-N-E5-F-G1-H5-L-23-L-23-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83018677	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A5-C2-N-E5-F-G5-H2-L-20-L-20-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83018678	PUMP-VAR-DISPL CCW 90PV130	90L130-HS-1-NN-80-S-4-T4-H-03-GBA-35-35-24	SERIES 90	S90-130PV
83018679	PUMP-VAR-DISPL CCW 90PV130	90L130-HF-5-NN-80-R-4-F1-H-03-GBA-42-42-24	SERIES 90	S90-130PV
83018681	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-BC-80-R-3-F1-F-03-GBA-35-35-30	SERIES 90	S90-100PV
83018682	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-NN-80-R-3-F1-H-03-GBA-35-35-30	SERIES 90	S90-130PV
83018683	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-L2-BA-N-B-PB-VS-AS-S-A-05-NN-016-N-00-NNN	H1-HP MOTORS	H1-080MB1
83018692	PUMP-VAR DISPL, CW 90PV075	90-R-075-CA-1-NN-60-P-4-S1-D-00-GBA-20-20-24	SERIES 90	S90-075PV
83018703	PUMP-VAR-DISPL CCW 90PV180	90L180-HF-1-BC-80-S-M-C8-J-02-NNN-40-40-22	SERIES 90	S90-180PV
83018705	PUMP-VAR-DISPL CW 90PV180	90R180-HS-5-CD-80-T-C-F1-J-03-FAC-24-24-28	SERIES 90	S90-180PV
83018709	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-L2-BA-N-A-PA-VS-ES-S-A-30-NN-067-N-00-NNN	H1-HP MOTORS	H1-160MB1
83018710	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-M2-CA-N-A-RA-VS-ES-S-N-NN-NN-000-N-00-NNN	H1-HP MOTORS	H1-160MB1
83018712	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A4-C1-B-D6-J-G5-NN-L-30-L-30-B-L-24-P4-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83018715	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-L2-BA-N-B-PB-CS-JS-S-A-10-NN-034-N-00-NNN	H1-HP MOTORS	H1-080MB1
83018716	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A3-C2-N-D3-H-G1-NN-L-42-L-42-C-M-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83018718	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-L2-BA-N-B-PA-VS-AS-S-A-10-NN-016-N-00-NNN	H1-HP MOTORS	H1-080MB1
83018719	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-C2-C2-C-F6-K-G1-H6-L-42-L-42-C-L-30-P2-NNN-D4F	H1-HP PUMPS	H1-069PV/078PV
83018720	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A5-C2-N-D6-F-G5-NN-L-42-L-42-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83018726	MOTOR-VAR-DISPL 51MV080	51V080-A-C7-N-HZ-B1-B-N-C2-NNN-050-AA-E6-05-00	SERIES 51	S51-080MV
83018731	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-E-E1-A5-A-N-A6-NNN-168-AA-G0-03-00	SERIES 51	S51-250MV
83018734	PUMP-VAR-DISPL CCW 90PV100	90L100-DD-1-NN-80-R-4-F1-F-GB-GBA-14-14-24	SERIES 90	S90-100PV
83018736	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A3-C1-N-F6-H-G9-H6-L-30-L-35-D-L-30-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83018737	MOTOR-VAR-DISPL H1MB060	H1-B-060-A-L2-BA-N-B-PA-DN-GN-N-N-NN-NN-000-N-00-NNN	H1-HP MOTORS	H1-060MB1
83018739	PUMP-VAR DISPL CCW H1P053L	H1-P-053-L-A-A8-C2-C-D6-J-G5-NN-L-30-L-30-B-L-24-P2-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV

83018740	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-CD-80-L-3-T1-D-00-GBA-29-29-24	SERIES 90	S90-075PV
83018750	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-1-NN-80-S-4-F1-F-03-GBA-35-35-24	SERIES 90	S90-130PV
83018753	MOTOR-VAR-DISPL 51MD060	51D060-A-D1-N-HZ-B1-B-E-C2-NNN-020-AA-NN-10-00	SERIES 51	S51-060MV
83018754	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-HE-HE-N-B-TB-CN-JN-N-A-10-NN-047-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83018755	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-CD-80-T-M-C8-J-00-NNN-38-38-24	SERIES 90	S90-180PV
83018760	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A2-C1-N-F4-H-G1-H6-L-35-L-35-C-M-30-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83018761	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A2-C1-N-D3-H-G1-NN-L-35-L-35-C-M-30-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83018765	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A5-C3-N-D6-G-G3-H4-L-38-L-38-L-L-28-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83018766	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A5-C3-N-D6-G-G3-H3-L-38-L-38-L-L-28-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83018767	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-HZ-B1-B-N-C2-ACA-050-AA-G3-10-00	SERIES 51	S51-250MV
83018768	PUMP-VAR-DISPL CCW 90PV100	90L100-MB-5-NN-80-R-3-S1-E-C5-GBA-35-35-24	SERIES 90	S90-100PV
83018769	PUMP-VAR-DISPL CW 90PV130	90R130-KA-2-AB-80-R-3-F1-F-33-GBA-26-26-24	SERIES 90	S90-130PV
83018772	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A5-C2-B-D6-H-G9-NN-L-35-L-35-C-L-20-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83018773	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A8-C2-C-D6-L-G2-H4-L-42-L-42-L-L-24-P2-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83018774	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A8-C2-C-D6-G-G3-NN-L-42-L-42-L-L-24-P1-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83018775	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-HZ-B1-C-N-C2-NNN-168-AA-F0-20-00	SERIES 51	S51-250MV
83018785	MOTOR-VAR-DISPL 51MD160	51D160-A-D4-N-T4-C2-L-N-G0-NNN-070-AA-G3-00-B1	SERIES 51	S51-160MV
83018798	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-A-Z-C-B-AA-B-A-A-A-BEE-AB-D-CD-B-C-A-A-BEE-AB-D-CD-C-NNN-*	M46	M46-046PT
83018806	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-A-V-C-B-BA-B-A-A-A-BEE-AB-U-AA-B-C-A-A-BEE-AB-U-AA-A-NNN-*	M46	M46-046PT
83018807	PUMP-VAR-DISPL CW 90PV130	90R130-RS-5-AB-80-P-3-C8-H-03-GBA-40-40-24	SERIES 90	S90-130PV
83018808	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-E2-AA-N-B-TB-DS-LS-S-A-20-NN-080-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83018809	PUMP-VAR-DISPL CCW 90PV180	90L180-HF-5-DE-80-S-C-C8-J-03-NNN-32-32-28	SERIES 90	S90-180PV
83018810	PUMP-VAR-DISPL CCW 90PV130	90L130-HF-5-BC-80-L-3-C8-H-03-GBA-32-32-28	SERIES 90	S90-130PV
83018811	PUMP-VAR-DISPL CW 90PV180	90R180-HF-5-EG-80-S-C-C8-H-03-NNN-42-42-28	SERIES 90	S90-180PV
83018813	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-L1-BA-N-B-PB-DS-HS-S-A-10-NN-030-N-00-NNN	H1-HP MOTORS	H1-080MB1
83018814	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A3-C1-N-D8-H-F1-NN-L-40-L-40-C-P-20-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83018815	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-D8-M1-R-J-M4-ACA-085-AA-G0-C2-35	SERIES 51	S51-250MV
83018820	PUMP-VAR-DISPL CW 90PV130	90R130-CB-5-NN-80-L-3-C8-H-03-GBA-30-30-24	SERIES 90	S90-130PV
83018821	PUMP-VAR-DISPL CW 90PV100	90R100-CB-5-NN-80-L-3-C7-F-00-GBA-30-30-24	SERIES 90	S90-100PV
83018822	PUMP-VAR-DISPL CW 90PV180	90R180-HF-5-AB-80-S-C-C8-H-03-NNN-42-42-28	SERIES 90	S90-180PV
83018824	MOTOR-VARIABLE DISPL SAE_L	L-V-30DN-E-R1F-F09-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83018825	MOTOR-VARIABLE DISPL SAE_L	L-V-35EN-G-Y3F-F10-S-N-N-BF-F18-NNA-NNN	LV / KV MOTORS	L/K-MV
83018826	MOTOR-VAR-DISPL H1MB060	H1-B-060-A-L2-BA-N-B-PA-DN-GN-N-N-NN-NN-019-N-00-NNN	H1-HP MOTORS	H1-060MB1
83018827	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-CD-60-L-3-S1-E-02-GBA-32-32-24	SERIES 90	S90-075PV
83018828	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A3-C2-N-D4-G-G2-H6-L-42-L-42-L-M-24-PN-NNN-G21	H1-HP PUMPS	H1-115PV/130PV
83018829	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A4-C2-N-E6-F-G5-NN-L-40-L-40-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV

83018830	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-L2-BA-N-B-PB-CS-KS-S-A-20-NN-090-N-00-NNN	H1-HP MOTORS	H1-160MB1
83018834	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-HF-HF-N-B-TA-CN-JN-N-N-NN-NN-025-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83018840	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-HS-A2-B-H-G6-ABA-080-AA-G0-05-26	SERIES 51	S51-160MV
83018843	MOTOR-FIX DISPL MMF044D	MMF-044-D-A-D-G-C-D-NNR-***	M35/44	044MF
83018845	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-CD-80-R-3-F1-F-00-GBA-38-38-24	SERIES 90	S90-100PV
83018846	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-NN-80-R-3-F1-F-00-GBA-38-38-24	SERIES 90	S90-100PV
83018847	PUMP-VAR-DISPL CW DDC20	DDC-20-A-R-RB-LSA-NN-A-2-N-BA-AAN9-F-07-21A-21A-NNN-NNN	DDC20/LDU20	OSK-020PV - DO NOT USE
83018850	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E1-AA-N-B-TB-VN-AN-N-N-NN-NN-046-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83018852	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-E2-AA-N-A-TA-VN-DN-N-A-30-NN-105-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83018854	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A5-C2-N-D3-H-G1-H3-L-23-L-23-D-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83018855	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-K2-K2-N-B-RA-DS-KS-S-A-10-NN-022-N-24-NNN	H1-HP MOTORS	H1-110MB1
83018856	PUMP-VAR DISPL, CW 90PV055	90-R-055-HS-1-CD-60-L-4-S1-D-03-GBA-23-23-24	SERIES 90	S90-055PV
83018858	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-1-CD-80-L-3-C8-F-03-GBA-35-35-24	SERIES 90	S90-130PV
83018859	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-1-CD-80-T-3-C8-K-03-NNN-35-35-24	SERIES 90	S90-250PV
83018860	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-1-CD-60-L-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83018861	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A5-C2-B-D8-J-G4-NN-L-38-L-38-B-P-24-P4-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83018865	MOTOR-VAR-DISPL 51MD110-1	51D110-1--R-D4-N-E2-B1-N-N-U1-NNN-050-AA-E6-00-00	SERIES 51	S51-110MV-1
83018866	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E2-AA-N-C-TB-CN-HN-N-A-10-NN-054-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83018867	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-E2-AA-N-C-TB-VN-EN-N-A-20-NN-108-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83018868	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-5-BC-80-S-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83018869	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-C2-C2-C-D6-J-G1-H1-L-38-L-38-B-L-24-P2-NNN-D4F	H1-MP PUMPS	H1-045PV/053PV
83018870	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-B1-C1-N-D6-F-G5-NN-L-42-L-42-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83018875	PUMP-VAR DISPL, CW 90PV055	90-R-055-M8-1-BC-60-S-3-C6-C-03-GBA-38-38-24	SERIES 90	S90-055PV
83018881	PUMP-VAR-DISPL CCW 90PV042	90L042-KA-5-NN-80-S-4-C3-C-03-GBA-42-42-24	SERIES 90	S90-042PV
83018882	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-1-NN-80-R-4-T4-F-00-GBA-32-32-24	SERIES 90	S90-130PV
83018884	PUMP-VAR-DISPL CCW 90PV130	90L130-MA-1-AB-80-P-3-T4-F-03-GBA-42-42-24	SERIES 90	S90-130PV
83018885	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-E1A5-01-B-D-X-N-C-N-B-23-23-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83018886	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-E1A5-01-B-D-X-A-C-N-Z-23-23-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83018891	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-D-T-B-J-BA-A-A-BEE-BC-A-GG-B-NNN-***	M46	M46-046PV
83018892	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A2-C3-B-D8-H-G1-NN-K-40-K-40-N-E-32-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83018904	MOTOR-VAR-DISPL 51MV060-1	51V060-1--R-S1-N-T1-D1-N-N-X1-ABA-034-AA-E4-00-21	SERIES 51	S51-060MV-1
83018905	PUMP-VAR-DISPL CW 90PV100	90R100-KA-1-NN-60-S-3-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83018918	MOTOR-VARIABLE DISPL SAE_L	L-V-30DN-A-R1F-F09-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83018919	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A8-C2-C-F6-H-G1-H6-L-42-L-42-M-L-30-P1-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83018921	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-CD-80-R-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83018922	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-NN-80-R-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV

83018923	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-NN-80-R-4-F1-F-03-GBA-35-35-24	SERIES 90	S90-130PV
83018924	PUMP-VAR-DISPL CCW H1PV130	H1-P-130-L-B-A5-C2-B-D8-G-G3-H4-L-35-L-35-N-E-30-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83018925	PUMP-VAR DISPL, CCW 90PV055	90-L-055-MA-5-BC-60-S-4-S1-C-C5-GBA-35-35-24	SERIES 90	S90-055PV
83018926	PUMP-VAR DISPL, CCW 90PV055	90-L-055-MA-1-BC-80-S-4-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83018927	PUMP-VAR-DISPL CW 90PV250	90R250-KA-1-NN-80-D-3-C8-N-03-EHA-42-42-24	SERIES 90	S90-250PV
83018928	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-ANN3-03-C-5-N-N-C-N-A-21-21-B-H-H-NNN-NNN	SERIES 42	S42-028PV/032PV
83018930	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-P2-D2-N-B-TB-DS-KS-S-A-20-NN-040-Z-24-NNN	H1-HP MOTORS	H1-160MB1
83018933	MOTOR- VARIABLE CARTRIDGE L	L-C-30DN-E-YNF-F08-S-N-N-AF-F17-NNN-NNN	LV / KV MOTORS	L/K-MV
83018936	MOTOR-VAR-DISPL 51MV250	51V250-U-C8-N-D8-M1-R-J-M4-ADA-095-AA-NN-C2-16	SERIES 51	S51-250MV
83018937	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-HE-HE-N-B-TA-CN-KN-N-A-20-NN-060-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83018938	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A5-C2-B-D8-H-G1-NN-L-42-L-42-M-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83018939	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A5-C2-B-D8-H-G1-NN-L-25-L-25-M-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83018941	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A5-C2-N-F6-H-G9-H6-L-38-L-38-C-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83018942	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A5-C2-N-D6-H-G1-H3-L-38-L-38-C-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83018943	PUMP-VAR-DISPL CW 90PV100	90R100-KP-5-CD-80-L-3-C7-F-00-GBA-40-40-24	SERIES 90	S90-100PV
83018944	PUMP-VAR-DISPL CW 90PV075	90R075-KP-5-CD-80-L-3-S1-E-00-GBA-40-40-24	SERIES 90	S90-075PV
83018946	PUMP-VAR-DISPL CW 90PV100	90R100-KP-5-CD-80-L-3-C7-F-00-GBA-32-32-24	SERIES 90	S90-100PV
83018947	PUMP-VAR-DISPL CW 90PV075	90R075-KP-5-CD-80-L-3-S1-E-00-GBA-32-32-24	SERIES 90	S90-075PV
83018953	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A4-C2-N-E7-F-G1-H3-33-33-33-33-N-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83018973	PUMP-VAR DISPL, CW 90PV100	90-R-100-HS-1-AB-60-P-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83018974	PUMP-VAR DISPL, CW 90PV055	90-R-055-HS-1-AB-60-P-3-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83018975	PUMP-VAR DISPL, CW 90PV075	90-R-075-HS-1-AB-60-P-3-C7-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83018978	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-NN-80-S-3-F1-E-03-EFC-38-38-24	SERIES 90	S90-100PV
83018979	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-T3-R5-L-N-G0-ADA-107-AA-G0-00-B8	SERIES 51	S51-250MV
83018981	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A5-C3-N-D3-H-G1-H3-L-35-L-35-D-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83018982	PUMP-VAR DISPL, CW 90PV100	90-R-100-M8-1-AB-80-L-4-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83018987	PUMP-VAR-DISPL CW 90PV075	90R075-FN-5-NN-80-P-7-C7-E-B6-EFP-45-45-30	SERIES 90	S90-075PV
83018988	PUMP-VAR DISPL MPV035D	MPV-035-D-B-A-A-L-S-G-AA-A-A-BGG-DL-A-FF-B-NNN-***	M35/44	035PV
83018989	PUMP-VAR-DISPL CW 90PV250	90R250-KP-1-NN-80-T-3-F1-J-03-NNN-17-17-24	SERIES 90	S90-250PV
83018990	PUMP-VAR DISPL CCW H1P068L	H1-P-068-L-A-A5-C2-N-F5-H-G1-H6-L-25-L-25-F-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83018991	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-E2C8-03-A-N-A-2-C-N-B-28-28-B-H-H-NNN-NNN	SERIES 42	S42-028PV/032PV
83018996	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-C-E1A6-03-B-D-B-2-F-N-N-34-34-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83018998	PUMP-VAR-DISPL CW 90PV100	90R100-KA-1-BC-60-S-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83019003	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D3-N-B2-B3-N-N-U3-ADA-043-AA-NN-00-00	SERIES 51	S51-080MV-1
83019007	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-CD-80-L-4-T2-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83019008	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-AB-80-P-4-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV

83019012	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E1-AA-N-B-TB-CS-GS-S-A-05-NN-030-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83019013	PUMP-VAR-DISPL CCW 90PV250	90L250-KN-5-EF-80-S-3-C8-K-05-NNN-40-40-24	SERIES 90	S90-250PV
83019019	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-M1-CA-N-A-RB-VS-AS-S-N-NN-NN-000-N-00-NNN	H1-HP MOTORS	H1-080MB1
83019024	PUMP-VAR-DISPL CW 90PV130	90R130-KN-5-NN-80-P-4-C8-F-03-GBA-42-42-24	SERIES 90	S90-130PV
83019026	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-NN-80-P-3-T2-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83019028	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-H-S-B-M-BA-A-A-BFF-CE-A-HH-3-NBN-***	M46	M46-046PV
83019032	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-G3AN-53-P-D-B-2-G-5-N-19-19-B-0-0-NNN-NNN	SERIES 42	S42-028PV/032PV
83019033	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-E2C8-03-A-N-A-2-C-N-A-28-28-B-H-H-NNN-NNN	SERIES 42	S42-028PV/032PV
83019038	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-ANJ5-02-C-2-N-N-H-N-A-B1-B1-N-N-N-NNN-ENN	SERIES 42	S42-028PV/032PV
83019041	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A3-C3-N-D8-H-G9-NN-L-41-L-41-C-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83019045	MOTOR-VAR-DISPL H1MB060	H1-B-060-A-L1-BA-N-B-PB-CS-GS-S-A-10-NN-012-N-00-NNN	H1-HP MOTORS	H1-060MB1
83019046	PUMP-VAR DISPL CCW H1P060L	H1-P-060-L-A-A4-C1-N-D6-H-G1-H5-L-42-L-42-F-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83019054	PUMP-VAR-DISPL CW 90PV250	90R250-MB-5-AB-80-T-4-C8-K-C5-NNN-42-42-24	SERIES 90	S90-250PV
83019055	PUMP-VAR-DISPL CW 90PV250	90R250-KP-1-NN-80-T-3-F1-J-03-NNN-38-38-24	SERIES 90	S90-250PV
83019057	PUMP-VAR-DISPL CCW H1PV165	H1-P-165-L-C-A5-C2-N-D9-G-G2-H4-L-33-L-33-L-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83019058	PUMP-VAR-DISPL CCW H1PV165	H1-P-165-L-C-A5-C2-N-D9-G-G3-H4-L-33-L-33-L-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83019059	PUMP-VAR-DISPL CW 90PV130	90R130-LW-5-CD-80-D-4-C8-L-C7-GBA-35-35-24-F076	SERIES 90	S90-130PV
83019060	PUMP-VAR-DISPL CW 90PV130	90R130-LW-5-DG-80-D-4-C8-L-C7-GBA-35-35-24-F076	SERIES 90	S90-130PV
83019064	PUMP-VAR-DISPL CW 90PV130	90R130-HF-5-NN-80-L-3-C8-H-03-GBA-23-23-24	SERIES 90	S90-130PV
83019065	PUMP-VAR-DISPL CW 90PV130	90R130-HF-5-NN-80-L-4-C8-H-03-GBA-35-35-24	SERIES 90	S90-130PV
83019066	PUMP-VAR DISPL, CW 90PV075	90-R-075-HF-2-BC-80-R-3-K2-D-03-GBA-32-32-20	SERIES 90	S90-075PV
83019068	PUMP-VAR-DISPL CW 90PV130	90R130-HF-1-NN-80-L-3-F1-H-00-GBA-32-32-24	SERIES 90	S90-130PV
83019084	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-S-B-B-AA-A-A-BMM-CD-A-HH-3-NNN-***	M46	M46-046PV
83019086	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E1-AA-N-B-TB-CS-GS-S-A-05-NN-024-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83019087	MOTOR-FIX DISPL MMF035D	MMF-035-D-A-A-H-A-S-NNR-***	M35/44	035MF
83019092	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-L2-BA-N-A-PA-DN-JN-N-N-NN-NN-016-N-00-NNN	H1-HP MOTORS	H1-080MB1
83019093	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A2-C1-N-E7-F-G5-NN-40-40-40-40-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83019095	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-T3-L5-L-N-G0-ADA-110-AA-G0-00-B8	SERIES 51	S51-250MV
83019097	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-HE-HE-N-B-TB-CS-JS-S-A-10-NN-034-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83019098	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-HE-HE-N-B-TB-CS-HS-S-A-10-NN-034-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83019100	PUMP-VAR DISPL, CW 90PV075	90-R-075-HS-1-CD-60-P-4-C7-D-03-GBA-23-23-24	SERIES 90	S90-075PV
83019101	PUMP-VAR DISPL, CW 90PV075	90-R-075-HS-1-BC-60-P-4-S1-D-03-GBA-23-23-24	SERIES 90	S90-075PV
83019106	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-E1A6-03-B-2-G-2-F-N-V-34-34-B-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83019108	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-E1A6-03-B-2-G-2-H-N-A-34-34-B-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83019109	PUMP-VAR-DISPL CW 90PV130	90R130-HS-1-AB-80-R-4-C8-H-03-GBA-35-35-30	SERIES 90	S90-130PV
83019110	PUMP-VAR-DISPL CCW 90PV250	90L250-HS-1-AB-80-T-4-C8-K-03-NNN-35-16-30	SERIES 90	S90-250PV

83019111	MOTOR-VAR-DISPL 51MV250	51V250-A-C8-N-HS-A2-C-H-E1-NNN-168-AA-G0-15-37	SERIES 51	S51-250MV
83019115	PUMP-VAR DISPL, CW 90PV055	90-R-055-KT-1-BC-80-P-3-S1-C-00-EBC-35-35-24	SERIES 90	S90-055PV
83019116	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-TH-CA-N-N-X1-NNN-055-AA-F0-00-31	SERIES 51	S51-110MV-1
83019117	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-N2-NN-N-N-A0-ABA-032-AA-G0-00-00	SERIES 51	S51-160MV
83019119	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-TA-C2-L-N-G0-NNN-080-AA-F0-00-B3	SERIES 51	S51-160MV
83019120	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-T1-D1-N-A-TA-DS-GS-S-N-NN-NN-015-Z-26-NNN	H1-HP MOTORS	H1-060MB1
83019121	MOTOR-VAR-DISPL 51MV250	51V250-A-C8-N-T3-L5-L-N-G0-ADA-107-AA-G0-00-B8	SERIES 51	S51-250MV
83019122	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A2-C1-B-D1-F-G1-H3-38-38-38-38-N-P-24-PN-C13-E08	H1-MP PUMPS	H1-045PT/053PT
83019126	PUMP-VAR-DISPL CCW 90PV130	90L130-HF-5-BB-80-S-4-F1-F-03-GBA-20-20-20	SERIES 90	S90-130PV
83019127	PUMP-VAR-DISPL CCW 90PV130	90L130-HF-5-BC-80-S-4-F1-F-03-GBA-20-20-20	SERIES 90	S90-130PV
83019129	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-A-A5-C1-N-D6-H-F4-H2-L-42-L-42-M-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83019141	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-BC-60-P-3-S1-C-03-GBA-32-32-24	SERIES 90	S90-055PV
83019142	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-1-BC-80-R-4-S1-E-09-GBA-38-38-24	SERIES 90	S90-075PV
83019147	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-N-TA-C2-L-N-G0-NNN-160-AA-NN-00-C1	SERIES 51	S51-250MV
83019148	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-2-NN-80-P-3-S1-D-03-GBA-38-38-24	SERIES 90	S90-075PV
83019149	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-2-AB-80-P-3-S1-D-03-GBA-38-38-24	SERIES 90	S90-075PV
83019150	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-1-BC-80-P-3-F1-F-03-EBA-29-29-24	SERIES 90	S90-130PV
83019158	PUMP-VAR-DISPL CCW 90PV180	90L180-HF-1-NN-80-T-C-F1-H-03-NNN-35-35-24	SERIES 90	S90-180PV
83019161	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-N-HS-A2-C-E-E1-NNN-090-AA-NN-12-17	SERIES 51	S51-250MV
83019162	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E1-AA-N-C-TB-DN-JN-N-A-10-NN-030-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83019163	MOTOR-VARIABLE DISPL SAE_L	L-V-25CN-C-R3F-F55-S-N-N-AF-F12-NNN-NNT	LV / KV MOTORS	L/K-MV
83019165	PUMP-VAR DISPL, CCW 90PV055	90-L-055-MD-1-NN-80-R-3-C6-C-02-GBA-35-35-20	SERIES 90	S90-055PV
83019166	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KT-1-BB-80-R-3-C6-D-02-GBA-35-35-20	SERIES 90	S90-075PV
83019167	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-S1-N-N1-NN-N-N-U1-NNN-051-AA-E4-00-00	SERIES 51	S51-080MV-1
83019172	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-CD-60-S-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-075PV
83019173	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-E1A6-03-B-2-G-2-H-N-V-34-34-B-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83019174	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-AB-60-S-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-075PV
83019175	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A2-C2-N-D8-H-G1-H3-L-15-L-35-N-E-26-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83019178	PUMP-VAR-DISPL CW 90PV100	90R100-MA-1-NN-60-P-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83019179	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-NN-80-R-3-F1-E-03-GBA-32-32-20-G005	SERIES 90	S90-100PV
83019181	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-E2C8-03-B-D-B-2-F-N-B-34-34-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83019183	PUMP-VAR-DISPL CW DDC20	DDC-20-A-R-RB-RSA-NN-A-2-N-BC-AAN9-D-07-30N-30N-NNN-NNN	DDC20/LDU20	OSK-020PV - DO NOT USE
83019194	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-B1-C1-B-D6-G-G2-H6-L-40-L-40-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83019195	MOTOR-VAR-DISPL 51MD080-1	51D080-1--A-D2-N-P8-P8-N-N-X1-NNN-020-AA-E4-00-AA	SERIES 51	S51-080MV-1
83019196	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-T2-DA-N-B-TB-DN-KN-N-N-NN-NN-080-Z-23-NNN	H1-HP MOTORS	H1-160MB1
83019197	PUMP-VAR-DISPL CCW 90PV100	90L100-MB-1-AB-80-L-3-C7-F-03-GBA-42-42-24	SERIES 90	S90-100PV

83019198	PUMP-VAR-DISPL CW DDC20	DDC-20-A-R-RB-RSA-NN-A-N-3-AC-ACA0-D-07-30N-30N-NNN-NNN	DDC20/LDU20	OSK-020PV - DO NOT USE
83019199	PUMP-VAR-DISPL CCW 90PV180	90L180-KT-1-NN-80-T-M-C8-H-03-FAC-42-42-24	SERIES 90	S90-180PV
83019203	MOTOR-VAR-DISPL H1B160	H1-B-160-A-TA-DA-N-A-TA-VN-EN-N-A-20-NN-085-Z-30-NNN	H1-HP MOTORS	H1-160MB1
83019207	PUMP-VAR DISPL, CW 90PV100	90-R-100-HS-1-NN-80-S-3-S1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
83019208	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-HZ-B1-B-E-G5-NNN-030-AA-F0-07-00	SERIES 51	S51-080MV
83019211	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A5-C3-N-D6-F-G5-H2-L-30-L-30-B-L-22-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83019221	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A7-C3-C-E6-J-G5-H3-L-42-L-42-B-L-24-P2-NNN-D3F	H1-MP PUMPS	H1-045PV/053PV
83019232	MOTOR-VAR-DISPL H1MB060	H1-B-060-A-K1-K1-N-A-RA-VS-AS-S-A-05-NN-025-N-24-NNN	H1-HP MOTORS	H1-060MB1
83019236	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-CD-80-R-4-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83019237	PUMP-VAR DISPL, CCW 90PV100	90-L-100-DD-1-NN-80-S-3-C7-E-GB-GBA-29-29-24	SERIES 90	S90-100PV
83019238	PUMP-VAR-DISPL CW 90PV075	90R075-MA-5-NN-80-L-3-C7-E-C5-GBA-42-42-24	SERIES 90	S90-075PV
83019240	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-NN-80-S-3-F1-H-03-GBA-26-26-24	SERIES 90	S90-130PV
83019241	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HS-1-NN-80-R-4-S1-C-03-GBA-38-38-24	SERIES 90	S90-055PV
83019242	PUMP-VAR-DISPL CCW 90PV075	90L075-HS-1-NN-80-R-4-S1-D-03-GBA-38-38-24	SERIES 90	S90-075PV
83019243	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-HE-HE-N-A-TB-CN-LN-N-N-NN-NN-032-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83019245	MOTOR-VAR-DISPL H1B160	H1-B-160-A-TA-DA-N-B-TA-VN-EN-N-A-20-NN-105-Z-19-NNN	H1-HP MOTORS	H1-160MB1
83019246	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A5-C2-N-F5-H-G1-H6-K-42-K-42-F-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83019249	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E1-AA-N-B-TB-VN-AN-N-N-NN-NN-030-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83019250	PUMP-VAR-DISPL CW 90PV042	90R042-FD-2-BC-80-S-7-C3-C-B4-EFI-45-45-32	SERIES 90	S90-042PV
83019251	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-HE-HE-N-C-TA-CN-KN-N-N-NN-NN-055-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83019253	PUMP-VAR-DISPL CCW H1PV130	H1-P-130-L-B-A5-C2-N-D3-G-G2-H3-L-33-L-33-A-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83019274	PUMP-VAR-DISPL 42PV041 CCW	42-L-41-C-E1A5-03-D-N-F-2-H-N-N-25-25-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83019277	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-M2-CA-N-B-RB-VS-ES-S-A-15-NN-029-N-00-NNN	H1-HP MOTORS	H1-110MB1
83019278	PUMP-VAR-DISPL CCW H1PV089	H1-P-089-L-A-A5-C2-N-F6-H-G9-H6-L-42-L-42-D-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83019279	PUMP-VAR-DISPL CCW H1PV089	H1-P-089-L-A-A5-C2-N-D6-H-G1-NN-L-42-L-42-D-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83019283	MOTOR-VAR-DISPL 51MV080	51V080-A-C7-N-HZ-B1-B-N-C2-NNN-040-AA-E6-05-00	SERIES 51	S51-080MV
83019284	PUMP-VAR-DISPL CW 90PV075	90R075-HF-5-AB-60-R-4-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
83019288	PUMP-VAR DISPL, CW 90PV055	90-R-055-HS-1-CD-80-P-3-S1-C-03-GBA-29-29-24	SERIES 90	S90-055PV
83019289	PUMP-VAR DISPL, CW 90PV055	90-R-055-HS-1-NN-60-P-3-S1-C-03-GBA-29-29-24	SERIES 90	S90-055PV
83019291	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HS-5-BC-80-S-4-S1-C-03-GBA-26-26-24	SERIES 90	S90-055PV
83019292	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A5-C3-N-D8-F-G5-H3-L-28-L-28-B-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83019293	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A5-C3-N-D8-J-G4-NN-L-28-L-28-B-P-20-P4-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83019295	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-L2-BA-N-A-PB-CS-JS-S-A-10-NN-017-N-00-NNN	H1-HP MOTORS	H1-080MB1
83019296	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-E2C8-02-B-D-G-2-C-N-V-19-19-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83019297	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-E2C8-02-B-D-G-2-C-N-A-19-19-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83019298	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-K1-K1-N-A-RB-VN-EN-N-A-15-NN-038-N-30-NNN	H1-HP MOTORS	H1-110MB1

83019299	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-E2-AA-N-B-TB-VN-DN-N-A-20-NN-100-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83019303	PUMP-VAR-DISPL CCW H1PV165	H1-P-165-L-C-A3-C3-N-D5-G-G2-H4-L-35-L-20-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83019304	PUMP-VAR-DISPL CCW H1PV165	H1-P-165-L-C-A3-C3-N-D3-G-G3-NN-L-35-L-20-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83019305	PUMP-VAR-DISPL CCW H1PV165	H1-P-165-L-C-A3-C3-N-D5-G-G2-H4-L-30-L-20-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83019306	PUMP-VAR-DISPL CCW H1PV165	H1-P-165-L-C-A3-C3-N-D3-G-G3-NN-L-30-L-20-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83019307	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A3-C2-N-D3-H-G9-NN-L-25-L-25-C-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83019315	PUMP-VAR-DISPL CW 90PV250	90R250-KA-1-NN-80-S-3-F1-J-03-NNN-42-42-24	SERIES 90	S90-250PV
83019317	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-CD-80-S-4-C7-E-03-GBA-35-35-20	SERIES 90	S90-075PV
83019318	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-NN-80-S-4-S1-E-03-GBA-26-26-24	SERIES 90	S90-075PV
83019324	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-BC-80-P-3-C7-D-00-GBA-35-35-24	SERIES 90	S90-075PV
83019329	PUMP-VAR-DISPL CW DDC20	DDC-20-A-R-RB-RSA-NN-A-D-N-BC-ABN9-D-07-30N-30N-NNN-NNN	DDC20/LDU20	OSK-020PV - DO NOT USE
83019330	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-NN-80-S-3-S1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
83019334	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-D2-MA-N-C-PB-VN-EN-N-A-10-NN-046-N-20-NNN	H1-HP MOTORS	H1-110MB1
83019336	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-BC-80-R-4-S1-F-09-GBA-38-38-24	SERIES 90	S90-100PV
83019339	PUMP-VAR-DISPL CCW 90PV075	90L075-HF-5-AB-60-R-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83019340	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-HZ-B1-A-N-C2-NNN-080-AA-F0-03-00	SERIES 51	S51-160MV
83019341	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-K1-K1-N-A-RB-VN-EN-N-A-15-NN-062-N-30-NNN	H1-HP MOTORS	H1-110MB1
83019350	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-D2-M2-N-B-PA-VN-EN-N-A-20-NN-057-N-30-NNN	H1-HP MOTORS	H1-160MB1
83019351	PUMP-VAR-DISPL CW DDC20	DDC-20-A-R-RB-RSA-NN-A-N-5-AA-ACA0-D-07-21N-21N-NNN-NNN	DDC20/LDU20	OSK-020PV - DO NOT USE
83019353	PUMP-VAR-DISPL CCW 90PV075	90L075-KP-1-CD-80-R-3-C7-E-03-GBA-38-38-24	SERIES 90	S90-075PV
83019362	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A2-C2-N-D6-G-G3-H3-K-45-K-42-L-L-28-PN-C07-NNN	H1-HP PUMPS	H1-147PV/165PV
83019363	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A2-C2-N-D6-G-G3-H3-K-45-K-42-L-L-28-PN-C07-NNN	H1-HP PUMPS	H1-147PV/165PV
83019365	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-BC-80-D-3-C8-L-04-GBA-30-30-28	SERIES 90	S90-130PV
83019366	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-1-NN-60-S-3-S1-E-03-GBA-35-35-28	SERIES 90	S90-075PV
83019367	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-E2-AA-N-B-TB-VN-EN-N-A-20-NN-080-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83019368	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-NN-80-R-3-F1-E-03-GBA-32-32-20	SERIES 90	S90-100PV
83019369	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A5-C2-N-D6-G-G3-NN-L-28-L-28-L-L-28-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83019380	PUMP-VAR-DISPL CW 90PV130	90R130-KA-1-CD-80-R-4-T4-F-03-GBA-35-35-24	SERIES 90	S90-130PV
83019382	PUMP-VAR-DISPL CW 90PV130	90R130-KA-1-BC-80-R-3-F1-H-03-GBA-38-38-24	SERIES 90	S90-130PV
83019384	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-T2-D2-N-B-TB-CN-JN-N-A-10-NN-018-Z-22-NNN	H1-HP MOTORS	H1-080MB1
83019388	PUMP-VAR-DISPL CCW H1PV089	H1-P-089-L-A-A5-C1-N-D6-H-G1-NN-L-20-L-20-M-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83019392	PUMP-VAR-DISPL CW 90PV130	90R130-CB-5-NN-80-S-3-F1-H-00-GBA-42-42-24-G005	SERIES 90	S90-130PV
83019393	MOTOR-VARIABLE DISPL SAE_L	L-V-25CN-E-R3F-F01-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83019395	PUMP-VAR DISPL CW H1P068R	H1-P-068-R-A-B1-C3-N-D3-H-F1-H3-K-28-K-28-C-M-20-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83019399	PUMP-VAR DISPL, CW 90PV100	90-R-100-M8-1-NN-60-P-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83019407	PUMP-VAR-DISPL CCW H1PV130	H1-P-130-L-B-A4-C1-N-D8-G-G3-NN-L-35-L-35-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV

83019408	PUMP-VAR DISPL CCW H1P053L	H1-P-053-L-A-A4-C1-N-E5-F-G5-NN-L-35-L-35-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83019409	PUMP-TANDEM, VAR DISPL CCW H1T053L	H1-T-053-L-A-N-A4-C1-B-E7-F-G5-TN-35-35-35-35-M-P-24-PN-NNN-S01	H1-MP PUMPS	H1-045PT/053PT
83019410	MOTOR-FIX DISPL 90MF130	90-M-130-NC-0-N-8-N-0-F1-W-00-EEA-00-00-G3	SERIES 90	S90-130MF
83019412	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-T1-D1-N-A-TA-DN-GN-N-N-NN-NN-015-Z-26-NNN	H1-HP MOTORS	H1-060MB1
83019418	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A5-C2-N-D8-H-G1-NN-L-35-L-35-F-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83019419	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A5-C2-N-F5-H-F1-H6-L-35-L-35-F-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83019422	MOTOR-VAR-DISPL 51MV080-1	51V080-1--A-C7-N-T7-CA-N-N-X1-ACB-016-AA-F0-00-26	SERIES 51	S51-080MV-1
83019423	MOTOR-VARIABLE DISPL SAE_K	K-V-38CN-A-RNF-F11-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83019424	PUMP-VAR DISPL, CW 90PV100	90-R-100-HF-2-NN-80-R-3-S1-F-03-GBA-38-38-28	SERIES 90	S90-100PV
83019428	PUMP-VAR-DISPL CCW H1PV115	H1-P-115-L-B-A5-C2-B-D8-G-G3-H6-K-35-K-35-A-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83019429	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A5-C2-B-D8-H-G1-NN-K-35-K-35-C-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83019433	PUMP-VAR-DISPL CW 90PV180	90R180-MV-1-BB-80-T-C-F1-H-03-FAC-35-35-24	SERIES 90	S90-180PV
83019434	PUMP-VAR-DISPL CW 90PV250	90R250-HF-2-CD-80-T-4-F1-K-03-NNN-38-38-28	SERIES 90	S90-250PV
83019436	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-S1-N-E2-B1-N-N-U1-ABA-016-AA-E4-00-00	SERIES 51	S51-080MV-1
83019437	MOTOR-FIX DISPL MMF044D	MMF-044-D-A-S-1-C-D-NNN-***	M35/44	O44MF
83019438	PUMP-VAR DISPL, CW 90PV055	90-R-055-FD-1-BC-80-P-7-C6-C-B2-GCA-38-38-30	SERIES 90	S90-055PV
83019447	PUMP-VAR DISPL, CW 90PV100	90-R-100-M8-1-BC-60-P-3-C7-E-03-GBA-40-40-24	SERIES 90	S90-100PV
83019449	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-E2-AA-N-B-TB-DN-KN-N-N-NN-NN-060-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83019455	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A4-C2-N-E7-F-G1-H3-15-15-15-15-N-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83019456	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-G-T-B-B-BA-G-A-BMM-CE-A-HH-C-NNN-***	M46	M46-046PV
83019462	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-NN-80-R-4-K2-E-03-GBA-23-23-28	SERIES 90	S90-075PV
83019468	MOTOR-VAR-DISPL H1MB060	H1-B-060-A-L2-BA-N-A-PA-VS-AS-S-A-05-NN-000-N-00-NNN	H1-HP MOTORS	H1-060MB1
83019469	MOTOR-VARIABLE DISPL SAE_L	L-V-25CN-A-Y3F-F01-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83019473	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-T1-D1-N-B-TA-DN-HN-N-A-10-NN-054-Z-25-NNN	H1-HP MOTORS	H1-080MB1
83019475	MOTOR-VAR-DISPL 51MC080-1	51C080-1--A-D3-N-N1-NN-N-N-U1-NNN-035-AA-F3-00-00	SERIES 51	S51-080MV-1
83019483	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-HE-HE-N-C-TB-CS-GS-S-A-05-NN-022-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83019487	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-BB-80-L-4-C7-F-03-GBA-35-35-24	SERIES 90	S90-100PV
83019489	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-CD-60-P-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-075PV
83019496	PUMP-TANDEM, VAR DISPL CCW H1T045L	H1-T-045-L-A-N-A5-C3-N-F7-F-G1-H2-35-35-35-35-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83019497	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-BB-80-S-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
83019498	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-CD-80-S-3-C7-E-02-GBA-42-42-24	SERIES 90	S90-100PV
83019502	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A5-C1-N-F7-F-G1-T2-35-35-35-35-M-P-24-PN-NNN-S01	H1-MP PUMPS	H1-045PT/053PT
83019503	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-L2-BA-N-B-PB-DS-HS-S-A-10-NN-025-N-00-NNN	H1-HP MOTORS	H1-080MB1
83019504	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-1-NN-80-R-3-S1-C-03-GBA-14-14-20	SERIES 90	S90-055PV
83019505	PUMP-VAR DISPL, CCW 90PV055	90-L-055-MA-1-NN-80-R-3-S1-C-03-GBA-14-14-20	SERIES 90	S90-055PV
83019506	MOTOR-VAR-DISPL 51MD110-1	51D110-1--R-D3-N-T2-D2-N-N-X1-ADA-044-AA-F0-00-28	SERIES 51	S51-110MV-1

83019514	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-K-S-B-J-BA-V-A-BFF-DB-A-GG-B-NNN-***	M46	M46-046PV
83019516	PUMP-VAR-DISPL CW 90PV180	90R180-HD-D-EF-8C-S-E-C8-J-00-GCA-35-35-32-G004	SERIES 90	S90-180PV
83019517	PUMP-VAR-DISPL CW 90PV180	90R180-HD-D-BC-8C-S-E-F1-J-00-GCA-35-35-32-G004	SERIES 90	S90-180PV
83019518	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KT-1-AB-80-P-3-S1-C-03-GBA-38-38-24	SERIES 90	S90-055PV
83019519	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KT-1-CD-80-P-3-S1-C-03-GBA-38-38-24	SERIES 90	S90-055PV
83019520	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KT-1-BC-80-P-3-S1-C-03-GBA-38-38-24	SERIES 90	S90-055PV
83019521	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KT-1-BC-80-P-3-F1-E-03-GBA-38-38-24	SERIES 90	S90-100PV
83019522	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-A-V-C-S-AA-B-A-A-A-BJJ-AK-D-KF-B-C-A-A-BJJ-AK-U-KF-B-NNA-***	M46	M46-046PT
83019523	PUMP-VAR-DISPL CCW 90PV130 BASE MODEL	90L130-CB-5-NN-80-S-4-C8-F-00-EEB-35-35-24-P000	SERIES 90	S90-130PV
83019524	PUMP-VAR-DISPL CW 90PV130 BASE MODEL	90R130-CB-5-NN-80-S-4-C8-F-00-EEB-35-35-24-P000	SERIES 90	S90-130PV
83019525	PUMP-VAR-DISPL CCW 90PV130 BASE MODEL	90L130-CB-5-NN-80-S-4-T4-F-00-EEB-35-35-24-P000	SERIES 90	S90-130PV
83019526	PUMP-VAR-DISPL CW 90PV130 BASE MODEL	90R130-CB-5-NN-80-S-4-T4-F-00-EEB-35-35-24-P000	SERIES 90	S90-130PV
83019538	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E1-AA-N-A-TA-CN-JN-N-A-05-NN-050-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83019546	PUMP-VAR-DISPL 42PV041 CCW	42-L-51-E-E2D8-03-B-D-G-3-F-N-B-25-25-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83019548	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-HS-A2-C-H-E1-NNN-055-AA-NN-16-24	SERIES 51	S51-160MV
83019549	PUMP-VAR-DISPL CW 90PV180	90R180-LW-5-CD-80-D-M-C8-L-C7-FAC-35-35-24-F075	SERIES 90	S90-180PV
83019551	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HF-1-CD-80-P-4-S1-C-03-GBA-20-20-24	SERIES 90	S90-055PV
83019552	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-5-NN-80-L-3-S1-D-02-GBA-35-35-24	SERIES 90	S90-075PV
83019554	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-M2-CA-N-A-RA-VS-DS-S-A-30-NN-000-N-00-NNN	H1-HP MOTORS	H1-160MB1
83019558	MOTOR-VAR-DISPL 51MV110	51V110-A-C8-N-HZ-B1-C-H-C2-NNN-022-AA-F0-12-00	SERIES 51	S51-110MV
83019562	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HF-1-NN-80-P-4-S1-C-03-GBA-20-20-24	SERIES 90	S90-055PV
83019563	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HF-1-BC-80-P-4-S1-C-03-GBA-20-20-24	SERIES 90	S90-055PV
83019564	PUMP-VAR DISPL, CW 90PV075	90-R-075-KN-1-NN-80-R-4-S1-D-03-GBA-20-20-24	SERIES 90	S90-075PV
83019571	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MA-1-NN-80-R-4-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83019575	PUMP-VAR-DISPL CW 90PV250	90R250-KN-5-BC-80-S-4-F1-K-03-NNN-42-42-24	SERIES 90	S90-250PV
83019576	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-AB-80-S-4-F1-F-06-GBA-26-26-24	SERIES 90	S90-130PV
83019580	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-D-S-B-B-AA-A-A-BJJ-DA-A-JJ-B-NNN-***	M46	M46-046PV
83019592	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-BC-80-T-M-C8-J-04-FAC-45-45-28	SERIES 90	S90-180PV
83019598	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-TA-C2-N-N-X1-NNN-074-AA-F0-00-30	SERIES 51	S51-110MV-1
83019601	PUMP-VAR-DISPL CCW 90PV130	90L130-KT-1-CD-80-L-3-F1-H-03-GBA-35-35-24	SERIES 90	S90-130PV
83019602	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KT-1-NN-80-L-3-S1-C-03-GBA-32-32-24	SERIES 90	S90-055PV
83019603	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KT-1-AB-80-L-3-S1-C-03-GBA-32-32-24	SERIES 90	S90-055PV
83019604	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-NN-80-L-4-F1-H-03-GBA-29-29-24	SERIES 90	S90-130PV
83019606	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A3-C1-N-D8-H-G1-NN-K-30-K-30-C-P-26-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83019607	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-CD-80-P-3-F1-H-03-GBA-42-42-24	SERIES 90	S90-130PV
83019620	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E2-AA-N-A-TB-CN-GN-N-A-05-NN-030-Z-00-NNN	H1-HP MOTORS	H1-060MB1

83019621	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E2-AA-N-A-TB-CS-GS-S-A-05-NN-030-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83019622	PUMP-VAR DISPL, CW 90PV075	90-R-075-KN-1-CD-80-R-4-S1-D-03-GBA-20-20-24	SERIES 90	S90-075PV
83019623	PUMP-VAR DISPL, CW 90PV075	90-R-075-KN-1-BC-80-R-4-S1-D-03-GBA-20-20-24	SERIES 90	S90-075PV
83019624	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KT-1-BC-80-P-3-F1-E-03-GBA-45-45-24	SERIES 90	S90-100PV
83019632	MOTOR-VAR-DISPL 51MC160	51C160-R-D5-N-HZ-B1-B-E-G5-ABA-060-AA-G0-10-00	SERIES 51	S51-160MV
83019635	PUMP-VAR-DISPL CW 90PV180	90R180-KP-5-DE-80-T-C-C8-J-03-FAC-35-35-26	SERIES 90	S90-180PV
83019636	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-BC-80-P-4-F1-F-02-GBA-38-38-26	SERIES 90	S90-130PV
83019637	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-D1-M1-N-A-PB-CS-JS-S-A-10-NN-017-N-27-NNN	H1-HP MOTORS	H1-080MB1
83019638	PUMP-VAR-DISPL CW 90PV180	90R180-KP-1-BC-80-T-M-F1-H-03-FAC-38-38-24	SERIES 90	S90-180PV
83019639	PUMP-VAR-DISPL CW 90PV100	90R100-LW-1-BC-60-R-3-C7-E-03-GBA-45-45-24	SERIES 90	S90-100PV
83019642	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A5-C2-N-D3-G-F3-NN-L-33-L-33-A-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83019650	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E1-AA-N-B-TB-VN-EN-N-N-NN-NN-030-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83019658	PUMP-VAR-DISPL 42PV041 CCW	42-L-51-C-E1A7-03-B-2-B-2-H-N-N-34-NN-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83019659	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-DE-80-R-3-C8-F-05-GBA-35-35-20	SERIES 90	S90-130PV
83019666	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-E1-AA-N-B-TB-VN-EN-N-A-20-NN-080-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83019667	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A2-C1-N-F1-F-G5-H5-K-35-K-35-B-L-18-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83019671	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A2-C1-N-E7-F-G5-H5-35-35-35-35-N-P-22-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83019673	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-D2-MA-N-C-PB-VN-EN-N-A-20-NN-048-N-20-NNN	H1-HP MOTORS	H1-160MB1
83019674	PUMP-VAR-DISPL 42PV041 CW	42-R-41-C-ANN5-02-A-N-N-N-F-N-A-28-28-N-B-B-NNN-NNN	SERIES 42	S42-041PV/051PV
83019677	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A2-C2-N-D6-G-G3-H5-K-45-L-42-L-L-28-PN-C07-NNN	H1-HP PUMPS	H1-147PV/165PV
83019678	PUMP-VAR-DISPL CW 90PV100	90R100-KA-1-AB-60-S-3-C7-E-04-GBA-42-42-24	SERIES 90	S90-100PV
83019688	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-2-CD-80-P-3-C7-F-03-GBA-35-35-24	SERIES 90	S90-100PV
83019689	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-2-CD-80-P-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83019690	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-HS-A2-C-H-E1-NNN-100-AA-NN-16-21	SERIES 51	S51-250MV
83019692	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A8-C2-C-D8-F-G5-H5-L-38-L-38-B-P-24-P1-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83019694	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-CD-80-P-4-F1-F-06-GBA-38-38-24	SERIES 90	S90-130PV
83019698	MOTOR-FIX DISPL MMF035D	MMF-035-D-A-A-H-C-T-NNN-***	M35/44	035MF
83019699	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A4-C2-B-D6-H-G1-H3-L-25-L-25-C-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83019700	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-H-S-B-J-BA-A-A-BGG-CE-A-HH-3-NNN-***	M46	M46-046PV
83019701	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A5-C1-B-D8-F-G1-H5-L-35-L-35-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83019702	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A5-C1-B-D8-F-G5-H3-L-35-L-35-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83019706	PUMP-VAR-DISPL CCW 90PV130	90L130-HF-5-CD-80-R-3-F1-H-03-GBA-35-35-24	SERIES 90	S90-130PV
83019707	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HK-1-NN-80-R-4-S1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
83019710	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-CD-80-R-3-F1-F-05-GBA-35-35-20	SERIES 90	S90-130PV
83019711	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A3-C2-N-F4-H-G9-H6-L-35-L-35-C-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83019712	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A3-C2-N-F4-H-G1-H6-L-35-L-35-C-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV

83019714	PUMP-VAR DISPL CCW H1P053L	H1-P-053-L-A-A5-C2-N-D8-J-G5-NN-L-20-L-20-B-P-24-P4-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83019722	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A3-C2-B-D3-H-G1-NN-L-42-L-42-C-M-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83019723	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-A-A5-C1-N-D3-H-G1-H2-L-30-L-30-M-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83019725	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-5-BC-80-R-3-S1-D-03-GBA-29-29-24	SERIES 90	S90-075PV
83019726	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-NN-80-R-4-F1-H-03-GBA-35-35-24	SERIES 90	S90-130PV
83019727	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-CD-80-R-3-F1-F-03-GBA-38-38-24	SERIES 90	S90-130PV
83019728	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-BC-80-P-3-S1-C-00-EBC-20-20-24	SERIES 90	S90-055PV
83019729	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A3-C3-N-F7-F-G7-H7-40-40-40-40-N-P-28-PN-C01-NNN	H1-MP PUMPS	H1-045PT/053PT
83019736	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-B-V-C-B-BA-B-B-G-A-BHH-BA-A-GG-B-D-G-A-BHH-BA-A-GG-B-NNN	M46	M46-046PT
83019743	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-HF-HF-N-B-TB-CN-JN-N-N-NN-NN-025-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83019748	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-2-CD-80-R-4-S1-E-00-GBA-34-34-24	SERIES 90	S90-100PV
83019766	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A2-C1-B-D1-F-G1-H3-38-38-38-38-N-P-28-PN-C13-E08	H1-MP PUMPS	H1-045PT/053PT
83019767	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A2-C1-B-D1-F-G1-H3-38-38-38-38-N-P-28-PN-C13-E09	H1-MP PUMPS	H1-045PT/053PT
83019768	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-N-A2-C1-B-D1-F-G1-H3-38-38-38-38-N-P-28-PN-NNN-E10	H1-MP PUMPS	H1-045PT/053PT
83019769	PUMP-VAR DISPL, CW 90PV100	90-R-100-FD-1-BC-60-P-7-F1-E-B1-GBA-40-40-24	SERIES 90	S90-100PV
83019771	PUMP-VAR-DISPL CCW H1PV130	H1-P-130-L-B-A5-C2-N-D3-G-G2-H6-L-35-L-35-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83019775	PUMP-VAR-DISPL CW 90PV100	90R100-HF-1-NN-80-R-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83019776	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-CD-80-S-3-C6-D-03-GBA-32-32-24	SERIES 90	S90-075PV
83019777	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-NN-80-S-3-S1-D-03-GBA-32-32-24	SERIES 90	S90-075PV
83019778	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A2-C2-N-D6-G-G3-H6-K-45-L-42-L-L-28-PN-C07-NNN	H1-HP PUMPS	H1-147PV/165PV
83019779	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-2-CD-80-P-3-S1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
83019780	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-L2-BA-N-A-PA-VS-AS-S-A-10-NN-049-N-00-NNN	H1-HP MOTORS	H1-080MB1
83019782	PUMP-VAR-DISPL CCW H1PV130	H1-P-130-L-B-A5-C2-N-D3-G-G3-H3-L-35-L-35-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83019783	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-L2-BA-N-B-PB-DN-LN-N-A-20-NN-080-N-00-NNN	H1-HP MOTORS	H1-160MB1
83019784	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-L2-BA-N-B-PB-DS-LS-S-A-20-NN-080-N-00-NNN	H1-HP MOTORS	H1-160MB1
83019787	MOTOR-VAR-DISPL 51MD160	51D160-R-D4-N-L8-B1-V-A-G5-ABA-070-AA-F3-B2-00	SERIES 51	S51-160MV
83019800	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-L2-BA-N-B-PA-VN-EN-N-A-10-NN-030-N-00-NNN	H1-HP MOTORS	H1-110MB1
83019801	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-AB-80-R-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83019805	PUMP-VAR-DISPL CW 90PV250	90R250-KA-2-CD-80-S-3-C8-K-K3-NNN-26-26-24	SERIES 90	S90-250PV
83019807	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-C-EQ-A7-J-Y-E1-CCA-110-AA-F0-15-20	SERIES 51	S51-250MV
83019813	PUMP-TANDEM, VAR DISPL MPT035D	MPT-035-D-A-W-A-H-NN-B-A-A-A-BJJ-DL-A-FF-B-C-A-A-BJJ-DL-A-FF-B-NNN-***	M35/44	O35PT
83019814	PUMP-VAR DISPL, CW 90PV075	90-R-075-M8-1-BC-60-S-3-C7-D-03-GBA-29-29-24	SERIES 90	S90-075PV
83019823	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-T1-D1-N-B-TA-DN-HN-N-A-10-NN-030-Z-30-NNN	H1-HP MOTORS	H1-080MB1
83019828	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-NN-80-P-3-C6-C-00-GBA-35-35-24	SERIES 90	S90-055PV
83019831	PUMP-VAR DISPL, CCW 90PV100	90-L-100-DC-5-AC-60-P-4-S1-E-G8-GBA-35-35-24	SERIES 90	S90-100PV
83019832	PUMP-VAR DISPL, CW 90PV100	90-R-100-DC-5-AC-60-P-4-S1-E-G8-GBA-35-35-24	SERIES 90	S90-100PV

83019837	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-N-HS-A1-A-E-G7-NNN-110-AA-G3-02-20	SERIES 51	S51-250MV
83019838	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-2-NN-80-S-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83019852	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MA-1-NN-80-P-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83019853	PUMP-VAR DISPL, CW 90PV075	90-R-075-HS-2-CD-80-P-3-C7-D-03-GBA-38-38-24	SERIES 90	S90-075PV
83019854	PUMP-VAR DISPL, CW 90PV075	90-R-075-HS-2-BC-80-P-3-S1-D-03-GBA-38-38-24	SERIES 90	S90-075PV
83019855	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-L2-BA-N-A-PA-VS-DS-S-A-30-NN-108-N-00-NNN	H1-HP MOTORS	H1-160MB1
83019856	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-2-BB-80-S-3-C6-C-03-GBA-38-38-24	SERIES 90	S90-055PV
83019860	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-K-T-B-B-AA-A-A-BBB-CD-A-GG-B-NNN-***	M46	M46-046PV
83019861	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A5-C1-B-D8-F-G1-H5-L-28-L-28-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83019862	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A5-C1-B-D8-F-G5-H3-L-28-L-28-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83019863	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-E1-AA-N-B-TA-VN-EN-N-A-20-NN-080-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83019865	MOTOR- VARIABLE CARTRIDGE L	L-C-30DN-A-ANF-F65-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83019866	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A2-C2-B-D8-G-F3-NN-L-20-L-25-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83019867	PUMP-VAR-DISPL CCW H1PV165	H1-P-165-L-C-A4-C3-B-D3-G-G3-NN-L-42-L-42-A-M-20-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83019873	PUMP-VAR-DISPL CCW DDC20	DDC-20-A-L-LB-RSA-NN-A-N-5-AA-ACA0-D-07-30N-30N-NNN-NNN	DDC20/LDU20	OSK-020PV - DO NOT USE
83019876	PUMP-VAR-DISPL CW 90PV130	90R130-KA-1-BC-80-S-3-C8-F-03-GBA-42-42-24	SERIES 90	S90-130PV
83019877	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E2-AA-N-B-TB-VS-DS-S-A-15-NN-022-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83019878	PUMP-VAR-DISPL CW 90PV180	90R180-KN-5-NN-80-T-M-C8-J-03-NNN-40-16-24	SERIES 90	S90-180PV
83019879	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-C-HZ-B1-C-N-G5-NNN-055-AA-F0-15-00	SERIES 51	S51-160MV
83019880	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-L2-BA-N-B-PA-DS-JS-S-A-10-NN-022-N-00-NNN	H1-HP MOTORS	H1-110MB1
83019884	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-AB-80-T-M-C8-H-03-NNN-26-26-24	SERIES 90	S90-180PV
83019888	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HK-1-BC-80-P-4-S1-E-04-GBA-35-35-24	SERIES 90	S90-100PV
83019895	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-1-AB-60-L-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-055PV
83019897	PUMP-VAR-DISPL CW 90PV180	90R180-KA-1-NN-80-S-M-C8-H-03-NNN-35-35-24	SERIES 90	S90-180PV
83019900	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-T2-D2-N-B-TB-CS-JS-S-A-10-NN-018-Z-22-NNN	H1-HP MOTORS	H1-080MB1
83019901	PUMP-VAR-DISPL CCW 90PV075	90L075-KN-5-NN-80-S-3-C7-D-03-GBA-42-42-24	SERIES 90	S90-075PV
83019909	PUMP-VAR-DISPL CCW H1PV130	H1-P-130-L-B-A5-C3-B-D3-G-G2-H6-L-35-L-35-A-M-24-PN-C29-E15	H1-HP PUMPS	H1-115PV/130PV
83019910	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A5-C3-B-D3-H-G1-H5-L-35-L-35-M-M-24-PN-C29-E14	H1-HP PUMPS	H1-089PV/100PV
83019919	PUMP-VAR-DISPL CW 90PV100	90R100-KA-1-AB-60-S-4-C6-D-03-GBA-35-35-24	SERIES 90	S90-100PV
83019920	MOTOR-VARIABLE DISPL SAE_K	K-V-38CN-E-Y3F-F09-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83019921	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-B-V-C-B-AA-B-A-A-A-BEE-AK-U-AA-B-C-A-A-BEE-AK-U-AA-A-NNN-*	M46	M46-046PT
83019923	PUMP-VAR DISPL, CW 90PV055	90-R-055-CB-1-BC-80-P-4-S1-D-00-GBA-32-32-24	SERIES 90	S90-055PV
83019924	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-TH-CA-N-N-X1-NNN-060-AA-F0-00-18	SERIES 51	S51-110MV-1
83019926	PUMP-VAR DISPL CCW H1P060L	H1-P-060-L-A-A4-C1-B-D3-H-G1-H3-L-28-L-28-C-M-30-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83019934	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-A-T-B-B-AA-A-A-BFF-CE-A-JJ-C-NNN-***	M46	M46-046PV
83019939	PUMP-VAR-DISPL CCW 90PV180	90L180-HF-1-BC-80-S-M-C8-J-02-GLA-38-38-22	SERIES 90	S90-180PV

83019940	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-DE-80-R-4-F1-H-03-GBA-35-35-24	SERIES 90	S90-130PV
83019941	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-5-BC-60-S-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83019942	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-5-BB-60-S-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83019943	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-T2-D2-N-B-TA-DN-JN-N-A-15-NN-022-Z-25-NNN	H1-HP MOTORS	H1-110MB1
83019949	MOTOR-VAR-DISPL 51MV080-1	51V080-1--A-C7-N-E2-B1-N-N-U1-AAA-054-AA-E6-00-00	SERIES 51	S51-080MV-1
83019950	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-BB-80-S-4-S1-D-03-GBA-26-26-24	SERIES 90	S90-055PV
83019955	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-HS-A2-C-H-E1-NNN-050-AA-NN-16-13	SERIES 51	S51-250MV
83019962	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-5-BC-80-S-3-C8-K-03-EFI-42-42-24	SERIES 90	S90-250PV
83019963	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-CD-80-S-C-C8-H-03-EFI-35-35-22	SERIES 90	S90-180PV
83019972	PUMP-VAR DISPL, CW 90PV100	90-R-100-MB-1-NN-60-P-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83019973	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-HA-B1-B-E-C2-NNN-073-AA-F3-10-00	SERIES 51	S51-160MV
83019974	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-T3-L5-L-N-G0-ADA-107-AA-G0-00-B8	SERIES 51	S51-250MV
83019978	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-G-S-B-S-AA-A-A-BJJ-CE-A-HH-C-NNN-***	M46	M46-046PV
83019980	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-5-NN-80-R-3-S1-L-03-EBC-40-40-24	SERIES 90	S90-055PV
83019981	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E2-AA-N-B-TB-CS-GS-S-A-10-NN-032-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83019982	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-BC-60-P-3-C6-C-03-GBA-42-42-24	SERIES 90	S90-055PV
83019983	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-CD-60-L-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83019984	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-5-NN-60-L-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83019985	PUMP-VAR-DISPL CCW H1PV089	H1-P-089-L-A-A8-C2-C-D3-K-F1-H2-L-42-L-42-D-M-30-P2-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83019986	PUMP-VAR-DISPL CW 90PV130	90R130-KN-5-NN-80-L-3-F1-F-03-GBA-32-32-24	SERIES 90	S90-130PV
83019988	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-K-S-B-B-AA-A-A-BFF-CE-A-JJ-B-NNN-***	M46	M46-046PV
83019997	PUMP-VAR-DISPL CCW 90PV130	90L130-KK-1-NN-82-R-3-F1-F-64-FBH-42-42-24	SERIES 90	S90-130PV
83019999	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-5-BB-80-S-3-C8-K-03-EFI-42-42-24	SERIES 90	S90-250PV
83020001	PUMP-VAR-DISPL CCW 90PV130	90L130-HF-5-BC-80-L-3-F1-H-03-GBA-32-32-28	SERIES 90	S90-130PV
83020003	PUMP-VAR DISPL, CW 90PV100	90-R-100-DD-5-NN-60-S-4-C7-E-GB-GBA-23-23-24	SERIES 90	S90-100PV
83020004	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-L2-BA-N-C-PB-VS-AS-S-A-10-NN-028-N-00-NNN	H1-HP MOTORS	H1-080MB1
83020005	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-HE-HE-N-C-TB-CS-GS-S-N-NN-NN-030-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83020007	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-P2-D2-N-B-TB-VS-DS-S-A-10-NN-040-Z-24-NNN	H1-HP MOTORS	H1-110MB1
83020008	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A3-C2-N-D3-G-G3-H2-L-42-L-41-A-M-20-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83020009	PUMP-VAR-DISPL CCW 90PV180	90L180-HF-5-DE-80-T-C-F1-J-03-FAC-23-23-28	SERIES 90	S90-180PV
83020010	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-NN-80-P-4-S1-C-03-GBA-32-32-24	SERIES 90	S90-055PV
83020012	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A3-C2-N-D3-G-G2-H3-L-42-L-42-A-M-22-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83020016	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MD-1-CD-60-S-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
83020017	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A3-C2-N-E6-F-G5-H3-L-42-L-42-B-L-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83020019	PUMP-VAR-DISPL 42PV041 CW	42-R-41-C-ANN5-02-A-N-A-2-C-N-A-28-28-N-D-D-NNN-BNN	SERIES 42	S42-041PV/051PV
83020022	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A7-C1-D-D6-L-G2-NN-L-35-L-35-A-L-24-P2-NNN-D3F	H1-HP PUMPS	H1-115PV/130PV

83020023	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-CD-60-S-3-C7-F-03-GBA-42-42-24	SERIES 90	S90-100PV
83020025	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-CD-80-S-M-C8-H-03-EFI-35-35-22	SERIES 90	S90-180PV
83020026	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-HE-HE-N-C-TB-CS-GS-P-A-05-NN-022-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83020027	PUMP-VAR-DISPL CCW H1PV130	H1-P-130-L-B-A3-C2-N-D6-G-G2-H6-L-42-L-42-L-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83020030	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-E2-AA-N-B-TA-CS-KS-S-N-NN-NN-040-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83020033	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A5-C2-N-D8-F-G1-H5-L-35-L-35-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83020034	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A5-C2-N-D8-F-G5-NN-L-35-L-35-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83020035	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-HZ-B1-B-H-G5-ACA-060-AA-NN-07-00	SERIES 51	S51-160MV
83020037	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-D-T-B-B-BA-A-A-BRJ-BA-A-JJ-B-NNN-***	M46	M46-046PV
83020039	PUMP-VAR-DISPL CW 90PV250	90R250-KT-1-NN-80-T-3-F1-K-05-NNN-32-32-28	SERIES 90	S90-250PV
83020050	PUMP-VAR-DISPL CW 90PV130	90R130-DD-5-NN-80-R-4-C8-H-GB-GBA-32-32-24	SERIES 90	S90-130PV
83020057	PUMP-VAR-DISPL CCW 90PV180	90L180-HF-5-EG-80-S-C-C8-H-03-NNN-35-35-28	SERIES 90	S90-180PV
83020058	PUMP-VAR-DISPL CCW 90PV180	90L180-HF-5-CD-80-S-C-C8-H-03-NNN-35-35-28	SERIES 90	S90-180PV
83020059	PUMP-VAR-DISPL CW 90PV100	90R100-FD-5-AB-80-P-7-C7-E-B9-EAB-45-45-28	SERIES 90	S90-100PV
83020060	PUMP-VAR-DISPL CW 90PV250	90R250-HF-5-DE-80-T-3-C8-J-03-NNN-35-35-28	SERIES 90	S90-250PV
83020061	PUMP-VAR-DISPL CW 90PV130	90R130-HF-5-AB-80-L-3-F1-F-03-GBA-35-35-28	SERIES 90	S90-130PV
83020067	PUMP-VAR-DISPL 42PV028 CW	42-R-3A-D-G2A1-50-U-2-B-2-F-1-B-30-30-B-1-1-AAA-NNN	SERIES 42	S42-028PV/032PV
83020080	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A4-C1-N-E7-F-G5-H1-30-30-30-30-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83020083	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-BC-80-P-4-S1-C-00-EHA-20-20-24	SERIES 90	S90-055PV
83020085	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-A-A4-C3-B-F4-H-G1-H6-L-35-L-35-M-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83020088	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-1-NN-80-R-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83020091	PUMP-VAR-DISPL CCW 90PV250	90L250-SB-2-NN-80-T-3-C8-K-33-PGA-42-42-26	SERIES 90	S90-250PV
83020097	PUMP-VAR-DISPL CCW 90PV075	90L075-FH-5-NN-80-P-7-C7-D-B3-GBA-35-35-30	SERIES 90	S90-075PV
83020099	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-C-ANN3-03-B-3-G-2-F-N-B-34-34-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83020101	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-A1N5-03-C-2-A-3-F-N-N-34-34-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83020104	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-NN-80-P-3-S1-D-09-GBA-35-35-24	SERIES 90	S90-055PV
83020105	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-NN-80-P-3-C7-F-09-GBA-35-35-24	SERIES 90	S90-100PV
83020106	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A4-C1-N-D6-H-F1-H5-L-35-L-35-C-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83020107	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-HE-HE-N-B-TB-DN-KN-N-N-NN-NN-074-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83020108	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A5-C2-N-D6-F-G5-NN-L-42-L-42-B-L-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83020115	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-NN-80-P-3-C7-F-03-GBA-35-35-24	SERIES 90	S90-100PV
83020118	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A8-C2-C-D6-F-G4-H2-L-28-L-28-B-L-20-P1-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83020124	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-CD-80-L-3-F1-H-09-GBA-35-35-24	SERIES 90	S90-130PV
83020125	PUMP-VAR-DISPL CCW 90PV180	90L180-KP-5-CD-80-S-C-C8-J-09-FAC-35-35-24	SERIES 90	S90-180PV
83020126	PUMP-VAR-DISPL CCW 90PV250	90L250-KP-5-CD-80-S-3-C8-K-09-NNN-35-35-24	SERIES 90	S90-250PV
83020128	PUMP-VAR DISPL, CCW 90PV055	90-L-055-M8-1-NN-60-S-3-C6-D-03-GBA-38-38-24	SERIES 90	S90-055PV

83020129	PUMP-VAR DISPL, CW 90PV055	90-R-055-HF-5-NN-60-R-4-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83020133	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-1-BB-80-S-4-S1-E-00-GBA-23-23-24	SERIES 90	S90-075PV
83020143	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-A1NB-03-A-N-A-2-F-N-A-28-NN-N-N-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83020144	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-A1NB-03-A-N-A-2-F-N-B-28-NN-N-N-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83020146	PUMP-VAR DISPL, CW 90PV055	90-R-055-HS-2-CD-80-D-3-C6-L-03-GBA-35-35-24	SERIES 90	S90-055PV
83020147	PUMP-VAR DISPL, CW 90PV055	90-R-055-HS-2-AB-80-D-3-S1-L-03-GBA-35-35-24	SERIES 90	S90-055PV
83020152	PUMP-VAR-DISPL CCW 90PV100	90L100-KN-5-NN-80-S-3-C7-E-03-GBA-38-38-24	SERIES 90	S90-100PV
83020153	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-ANN3-03-A-N-A-2-F-N-A-30-30-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83020160	MOTOR-VAR-DISPL H1MB060	H1-B-060-A-L2-BA-N-A-PB-VS-AS-S-A-05-NN-000-N-00-NNN	H1-HP MOTORS	H1-060MB1
83020161	PUMP-VAR DISPL CW H1P068R	H1-P-068-R-A-A5-C1-N-F4-H-F1-H6-L-33-L-33-C-M-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83020164	PUMP-VAR DISPL, CW 90PV075	90-R-075-M8-1-CD-80-S-3-C7-E-03-FAD-42-42-24	SERIES 90	S90-075PV
83020165	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E2-AA-N-A-TB-VN-AN-N-N-NN-NN-030-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83020169	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HK-1-NN-60-P-4-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83020172	PUMP-VAR-DISPL CW 90PV250	90R250-KN-5-DE-80-T-3-C8-K-03-NNN-29-29-24	SERIES 90	S90-250PV
83020173	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A4-C1-N-E7-F-G1-T3-30-30-30-30-M-P-30-PN-NNN-S01	H1-MP PUMPS	H1-045PT/053PT
83020179	PUMP-VAR-DISPL CW 90PV180	90R180-DD-5-NN-80-S-C-C8-H-GB-NNN-32-32-24	SERIES 90	S90-180PV
83020180	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-P1-D1-N-A-TA-DS-JS-S-A-15-NN-034-Z-24-NNN	H1-HP MOTORS	H1-110MB1
83020186	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-A3NB-03-A-N-N-N-F-N-A-19-19-N-F-F-NNN-NNN	SERIES 42	S42-028PV/032PV
83020187	PUMP-VAR-DISPL CCW H1PV089	H1-P-089-L-A-A5-C3-N-D3-H-G1-H3-L-45-L-45-M-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83020194	MOTOR-VAR-DISPL 51MV250	51V250-U-F2-D-HS-A2-C-H-E1-NNN-090-AA-NN-12-24	SERIES 51	S51-250MV
83020196	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-B-T-B-B-AA-G-A-BJJ-DB-A-HH-A-NNN-***	M46	M46-046PV
83020198	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-1-NN-80-P-3-F1-F-03-GBA-45-45-24	SERIES 90	S90-130PV
83020199	PUMP-VAR-DISPL CW DDC20	DDC-20-A-R-RB-RSA-NN-A-N-3-AC-ACA0-D-07-14N-14N-NNN-NNN	DDC20/LDU20	OSK-020PV - DO NOT USE
83020201	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A9-C3-B-D3-H-G9-H2-L-35-L-35-D-M-30-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83020202	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-HE-HE-N-A-TB-CN-GN-N-N-NN-NN-040-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83020203	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A9-C3-B-F4-H-G9-H6-L-35-L-35-D-M-30-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83020205	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A8-C2-D-D3-L-G2-H3-L-38-L-38-L-N-32-P2-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83020213	PUMP-VAR DISPL, CW 90PV055	90-R-055-HS-1-NN-80-P-4-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83020218	PUMP-VAR-DISPL CW 90PV100	90R100-HF-5-BC-80-S-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83020220	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-C2-C2-C-D6-K-G1-H5-L-42-L-42-C-L-30-P2-NNN-D4F	H1-HP PUMPS	H1-069PV/078PV
83020222	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-NN-80-S-3-S1-C-00-GBA-35-35-24	SERIES 90	S90-055PV
83020223	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-NN-80-S-3-S1-E-00-GBA-35-35-24	SERIES 90	S90-075PV
83020224	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-NN-80-S-3-S1-E-00-GBA-35-35-24	SERIES 90	S90-100PV
83020226	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A3-C2-N-D8-H-G1-H3-L-42-L-42-N-E-32-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83020227	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-L2-BA-N-A-PA-DS-HS-S-A-05-NN-000-N-00-NNN	H1-HP MOTORS	H1-080MB1
83020233	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-BC-80-L-3-F1-H-05-GBA-36-36-24	SERIES 90	S90-130PV

83020234	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-BC-80-L-3-F1-H-03-GBA-36-36-24	SERIES 90	S90-130PV
83020235	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-E1A7-03-C-5-N-N-C-N-A-21-21-B-H-H-NNN-NNN	SERIES 42	S42-028PV/032PV
83020236	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-M2-CA-N-B-RA-VS-ES-S-A-10-NN-000-N-00-NNN	H1-HP MOTORS	H1-110MB1
83020237	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-M2-CA-N-B-RA-VS-ES-S-A-20-NN-000-N-00-NNN	H1-HP MOTORS	H1-160MB1
83020238	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-A1N5-03-C-2-A-3-F-N-A-34-34-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83020239	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-HE-HE-N-A-TB-CN-JN-N-N-NN-NN-074-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83020240	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-NN-80-S-3-C6-C-02-GBA-35-35-24	SERIES 90	S90-055PV
83020243	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KT-1-NN-80-S-3-S1-E-05-GBA-42-42-24	SERIES 90	S90-100PV
83020244	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KT-1-CD-80-S-3-S1-E-05-GBA-42-42-24	SERIES 90	S90-100PV
83020245	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A4-C2-N-D3-G-G3-H2-L-28-L-23-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83020246	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-BC-80-L-3-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83020247	MOTOR-VAR-DISPL H1B160	H1-B-160-A-TA-DA-N-A-TA-VN-EN-N-A-30-NN-100-Z-22-NNN	H1-HP MOTORS	H1-160MB1
83020248	MOTOR-VAR-DISPL H1MB060	H1-B-060-A-L2-BA-N-A-PA-VN-AN-N-N-NN-NN-022-N-00-NNN	H1-HP MOTORS	H1-060MB1
83020252	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-D7-M1-S-K-M4-ACA-057-AA-F0-F4-20	SERIES 51	S51-160MV
83020254	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A9-C3-B-D3-H-G1-H2-L-35-L-35-D-M-28-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83020255	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A9-C3-B-F4-H-G9-H6-L-35-L-35-D-M-28-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83020256	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E2-AA-N-B-TA-CS-HS-S-A-10-NN-040-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83020269	PUMP-VAR DISPL, CW 90PV075	90-R-075-HF-5-BC-80-S-4-C7-E-03-GBA-32-32-24	SERIES 90	S90-075PV
83020271	PUMP-VAR-DISPL CW 90PV180	90R180-FH-5-EG-80-S-7-C8-J-B1-NNN-42-42-30	SERIES 90	S90-180PV
83020274	MOTOR-VARIABLE CARTRIDGE K	K-C-38CS-E-RNF-F07-S-N-N-CF-F16-NNN-NNN	LV / KV MOTORS	L/K-MV
83020276	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-L2-BA-N-B-PB-VN-EN-N-A-20-NN-076-N-00-NNN	H1-HP MOTORS	H1-160MB1
83020278	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-AB-80-S-4-S1-E-00-GBA-42-42-24	SERIES 90	S90-100PV
83020281	PUMP-VAR-DISPL CW 90PV130	90R130-HS-5-CD-80-S-4-F1-F-03-GBA-35-35-24	SERIES 90	S90-130PV
83020282	PUMP-VAR-DISPL CW 90PV180	90R180-CA-5-NN-80-S-7-C8-J-00-NNN-42-42-30	SERIES 90	S90-180PV
83020283	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-DE-80-R-4-F1-H-03-GBA-35-35-24	SERIES 90	S90-130PV
83020286	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-HE-HE-N-B-TB-DN-KN-N-N-NN-NN-055-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83020294	PUMP-VAR DISPL, CW 90PV075	90-R-075-HS-1-CD-80-S-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83020295	PUMP-VAR DISPL, CW 90PV055	90-R-055-HS-1-AB-80-S-4-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83020296	PUMP-VAR DISPL, CW 90PV075	90-R-075-HS-1-AB-80-S-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83020297	PUMP-VAR DISPL, CW 90PV100	90-R-100-HS-1-AB-80-S-4-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83020302	PUMP-VAR DISPL, CW 90PV075	90-R-075-HS-1-NN-80-S-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83020304	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-T2-D2-N-B-TB-VN-AN-N-A-05-NN-023-Z-21-NNN	H1-HP MOTORS	H1-060MB1
83020307	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-A-Z-C-B-AA-B-A-A-A-BEE-AB-U-CD-B-C-A-A-BEE-AB-U-CD-C-NNN-*	M46	M46-046PT
83020309	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-A-A4-C2-N-F6-H-G9-H6-L-45-L-45-M-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83020311	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-D-HZ-B1-A-N-G0-NNN-065-AA-NN-03-00	SERIES 51	S51-250MV
83020318	PUMP-VAR DISPL, CW 90PV075	90-R-075-KN-1-NN-80-R-4-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV

83020319	PUMP-VAR DISPL, CCW 90PV100	90-L-100-CA-1-NN-80-R-3-S1-E-00-GBA-35-13-24	SERIES 90	S90-100PV
83020320	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-NN-80-R-3-S1-E-03-GBA-13-35-24	SERIES 90	S90-100PV
83020325	PUMP-VAR-DISPL CW 90PV075	90R075-KA-P-BC-80-S-4-S1-D-03-GBA-45-45-24	SERIES 90	S90-075PV
83020326	PUMP-VAR-DISPL CW 90PV075	90R075-KA-P-CD-80-S-4-C7-D-03-GBA-45-45-24	SERIES 90	S90-075PV
83020333	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-A-T-B-B-AA-G-A-BJJ-DB-A-HH-C-NNN-***	M46	M46-046PV
83020334	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KT-1-BC-60-P-3-T2-E-03-GBA-32-32-24	SERIES 90	S90-100PV
83020336	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-D-T-B-B-BA-A-A-BRJ-BC-A-JJ-B-NNN-***	M46	M46-046PV
83020342	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-1-AB-80-P-4-S1-B-03-GBA-26-26-24	SERIES 90	S90-055PV
83020344	MOTOR-VAR-DISPL 51MV060	51V060-R-C6-N-HS-A2-C-H-E1-NNN-015-AA-NN-16-30	SERIES 51	S51-060MV
83020349	PUMP-VAR-DISPL CW 90PV130	90R130-DC-1-BC-80-S-3-F1-H-G1-GBA-30-35-30	SERIES 90	S90-130PV
83020351	PUMP-VAR DISPL CW H1P068R	H1-P-068-R-A-A2-C1-N-D8-H-G1-H3-K-28-K-35-N-E-20-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83020354	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-CD-60-P-3-C7-F-03-GBA-35-35-24	SERIES 90	S90-100PV
83020355	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-CD-60-P-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83020358	PUMP-VAR-DISPL CW 90PV180	90R180-MA-5-NN-80-S-C-F1-H-C4-NNN-35-14-30	SERIES 90	S90-180PV
83020359	PUMP-VAR-DISPL CW 90PV100	90R100-MA-5-NN-60-S-3-S1-E-C5-GBA-23-23-30	SERIES 90	S90-100PV
83020360	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-B-U4-C5-P-N-J2-NNN-107-AA-F3-00-00	SERIES 51	S51-250MV
83020363	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-CD-80-R-4-S1-E-03-GBA-32-32-24	SERIES 90	S90-100PV
83020364	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A5-C2-N-D8-H-F1-H5-L-40-L-40-N-E-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83020365	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-N-A3-C1-N-E7-F-G5-H2-28-28-28-28-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83020370	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-T1-D1-N-C-TB-VS-DS-S-A-20-NN-059-Z-26-NNN	H1-HP MOTORS	H1-160MB1
83020374	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-D2-M2-N-B-PB-VS-ES-S-A-20-NN-035-N-30-NNN	H1-HP MOTORS	H1-160MB1
83020375	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-HE-HE-N-B-TB-VN-EN-N-A-20-NN-035-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83020381	PUMP-VAR-DISPL CW 90PV075	90R075-MB-5-BB-80-D-3-S1-L-C6-GBA-42-42-24	SERIES 90	S90-075PV
83020383	PUMP-VAR DISPL MPV035D	MPV-035-D-B-A-A-R-S-G-BA-A-A-BFF-DL-A-AFF-D-NNN-***	M35/44	035PV
83020384	PUMP-VAR-DISPL CW 90PV250	90R250-HF-1-NN-80-T-4-F1-K-00-NNN-42-42-24	SERIES 90	S90-250PV
83020391	PUMP-VAR-DISPL CCW 90PV100	90L100-HF-5-NN-60-R-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83020395	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-CD-80-S-4-C8-K-03-NNN-42-42-24	SERIES 90	S90-250PV
83020400	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-B9-C3-C-E9-F-G5-NN-J-40-J-40-N-E-24-P1-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83020403	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-L2-BA-N-B-PB-DS-KS-S-A-20-NN-063-N-00-NNN	H1-HP MOTORS	H1-160MB1
83020408	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-HE-HE-N-A-TB-VN-AN-N-A-05-NN-016-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83020409	PUMP-VAR DISPL CCW H1P053L	H1-P-053-L-A-A3-C1-N-D8-F-G1-H3-L-35-L-35-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83020410	PUMP-VAR DISPL, CW 90PV075	90-R-075-HS-1-AB-80-P-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83020415	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A4-C3-N-E6-F-G5-H5-L-35-L-35-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83020416	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A4-C3-N-E6-F-G5-H1-L-15-L-18-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83020417	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A4-C3-N-E6-F-G5-H5-L-35-L-38-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83020418	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-NN-80-P-4-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV

83020420	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-HE-HE-N-B-TA-VN-EN-N-N-NN-NN-074-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83020421	PUMP-VAR-DISPL CCW H1PV130	H1-P-130-L-B-A2-C1-N-D8-G-G3-H6-L-42-L-42-A-P-30-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83020425	PUMP-VAR DISPL, CCW 90PV055	90-L-055-FD-2-NN-60-S-7-S1-D-B1-GBA-42-42-24	SERIES 90	S90-055PV
83020426	PUMP-VAR DISPL CCW H1P053L	H1-P-053-L-A-A5-C2-N-D6-F-G5-H3-L-38-L-38-B-L-24-PN-C10-NNN	H1-MP PUMPS	H1-045PV/053PV
83020430	PUMP-VAR-DISPL CW 90PV180	90R180-KP-5-BB-80-T-M-C8-J-03-FAC-38-38-24	SERIES 90	S90-180PV
83020431	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KN-5-AB-60-R-3-S1-C-03-GBA-26-26-24	SERIES 90	S90-055PV
83020432	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-NN-60-R-3-S1-D-03-GBA-35-35-28	SERIES 90	S90-075PV
83020434	PUMP-VAR-DISPL CCW 90PV075	90L075-FH-2-NN-60-P-7-C7-D-B1-GBA-42-42-30	SERIES 90	S90-075PV
83020435	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-L8-B1-V-A-C0-NNN-050-AA-F0-B2-00	SERIES 51	S51-250MV
83020436	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-N-HS-A2-C-H-E1-NNN-050-AA-F0-30-13	SERIES 51	S51-250MV
83020437	PUMP-VAR-DISPL CW 90PV130	90R130-MA-1-AB-80-L-4-F1-F-00-GBA-26-26-24	SERIES 90	S90-130PV
83020439	PUMP-VAR-DISPL CW 90PV130	90R130-HS-5-BC-80-R-4-F1-F-03-GBA-35-35-32	SERIES 90	S90-130PV
83020440	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-M2-CA-N-C-RB-VS-ES-S-N-NN-NN-040-N-00-NNN	H1-HP MOTORS	H1-160MB1
83020449	PUMP-VAR-DISPL CW 90PV180	90R180-KP-5-CD-80-T-M-C8-J-03-FAC-38-38-24	SERIES 90	S90-180PV
83020457	PUMP-VAR-DISPL CW 90PV075	90R075-MB-1-BB-80-L-3-C6-E-03-GBA-35-35-24	SERIES 90	S90-075PV
83020458	PUMP-VAR DISPL, CW 90PV055	90-R-055-HK-1-AB-60-P-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83020460	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-F6NN-50-U-2-B-2-H-5-N-30-30-B-0-0-NNN-NNN	SERIES 42	S42-028PV/032PV
83020461	PUMP-VAR-DISPL CCW 90PV250	90L250-HF-1-NN-80-T-4-F1-K-03-NNN-42-42-24	SERIES 90	S90-250PV
83020465	PUMP-VAR DISPL, CW 90PV075	90-R-075-HF-1-CD-80-P-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-075PV
83020466	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-BB-80-R-3-S1-E-03-GBA-26-26-24	SERIES 90	S90-100PV
83020467	PUMP-VAR DISPL, CW 90PV100	90-R-100-DD-1-NN-80-S-3-C6-D-GB-GBA-20-20-24	SERIES 90	S90-100PV
83020468	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-E1A5-03-C-2-A-2-F-N-A-25-25-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83020469	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-8-N-0-K3-W-00-NNN-00-00-F0	SERIES 90	S90-100MF
83020473	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-NN-80-P-4-C7-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83020476	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-N-HS-A2-C-H-E1-NNN-115-AA-NN-15-21	SERIES 51	S51-250MV
83020478	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A4-C2-N-D8-F-G5-NN-L-38-L-38-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83020483	PUMP-VAR-DISPL CCW H1PV089	H1-P-089-L-A-A3-C2-N-D8-K-F1-H3-L-40-L-40-N-E-20-P4-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83020487	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-CD-80-S-3-C6-D-03-GBA-38-38-24	SERIES 90	S90-055PV
83020491	MOTOR-FIXED DISPL MMF025C	MMF-025-C-A-E-R-C-T-NNN-***	LIGHT DUTY	025MF
83020495	PUMP-VAR DISPL, CW 90PV055	90-R-055-HS-1-NN-80-P-4-S1-C-03-GBA-32-32-24	SERIES 90	S90-055PV
83020496	PUMP-TANDEM, VAR DISPL CCW H1T045L	H1-T-045-L-A-N-B1-C1-B-E7-F-G1-NN-28-28-28-28-N-P-30-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83020497	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-HZ-B1-C-E-C2-NNN-027-AA-NN-16-00	SERIES 51	S51-080MV
83020503	MOTOR-VARIABLE DISPL SAE_K	K-V-45DN-E-RAF-F09-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83020504	MOTOR-VARIABLE DISPL SAE_K	K-V-45DN-E-RCF-F09-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83020507	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-P1-D1-N-A-TA-DS-JS-S-A-10-NN-022-Z-24-NNN	H1-HP MOTORS	H1-110MB1
83020508	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-L1-BA-N-A-PA-DS-JS-S-A-10-NN-022-N-00-NNN	H1-HP MOTORS	H1-110MB1

83020514	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-L2-BA-N-B-PB-VS-ES-S-A-30-NN-046-N-00-NNN	H1-HP MOTORS	H1-160MB1
83020515	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-L1-BA-N-B-PB-VS-ES-S-A-15-NN-048-N-00-NNN	H1-HP MOTORS	H1-110MB1
83020516	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-L1-BA-N-B-PB-VS-ES-S-A-15-NN-038-N-00-NNN	H1-HP MOTORS	H1-110MB1
83020517	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-L1-BA-N-B-PB-VS-AS-S-A-10-NN-038-N-00-NNN	H1-HP MOTORS	H1-080MB1
83020518	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A2-C1-N-F5-H-G1-H6-K-40-K-40-C-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83020519	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A2-C1-N-F5-H-G1-H6-K-42-K-42-C-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83020520	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A2-C1-N-F5-H-G1-H6-K-40-K-40-C-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83020521	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A2-C1-N-F5-H-G1-H6-K-42-K-42-C-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83020526	MOTOR-VARIABLE DISPL SAE_L	L-V-35EN-A-YNF-F09-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83020535	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-T2-C2-L-N-G0-NNN-065-AA-G3-00-B1	SERIES 51	S51-250MV
83020543	PUMP-VAR-DISPL 42PV041 CCW	42-L-41-C-A7J5-03-A-N-A-3-F-N-N-21-21-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83020545	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-1-AB-60-R-3-S1-C-00-GBA-26-26-24	SERIES 90	S90-055PV
83020547	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-E1A5-00-B-D-G-3-F-N-A-34-34-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83020551	PUMP-VAR-DISPL CW 90PV130	90R130-KA-1-NN-80-R-3-F1-H-03-GBA-35-35-24	SERIES 90	S90-130PV
83020557	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-A-A3-C2-N-D6-H-F1-H5-L-40-L-40-M-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83020561	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-AB-80-R-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83020564	MOTOR-VAR-DISPL H1MB060	H1-B-060-A-D1-M1-N-B-PB-VS-AS-S-A-05-NN-022-N-30-NNN	H1-HP MOTORS	H1-060MB1
83020570	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-T-B-J-AA-A-A-BJJ-BA-A-JJ-A-NNN-***	M46	M46-046PV
83020573	PUMP-VAR-DISPL 42PV041 CW	42-R-51-D-G3AN-53-P-D-B-3-F-5-B-30-30-N-0-0-NNN-NNN	SERIES 42	S42-041PV/051PV
83020576	PUMP-VAR-DISPL CCW H1PV115	H1-P-115-L-B-A3-C2-N-D8-G-G3-NN-L-33-L-33-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83020577	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A3-C2-N-D8-F-G4-H3-L-33-L-33-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83020578	PUMP-VAR DISPL, CW 90PV075	90-R-075-DD-1-BC-80-S-4-C7-C-G8-GBA-29-29-24	SERIES 90	S90-075PV
83020582	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-A-A9-C1-N-D6-H-G1-H3-L-42-L-42-M-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83020586	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-Y-Z-C-S-BA-B-A-A-A-BJJ-AB-U-DD-B-C-A-A-BJJ-AB-U-DD-C-NNQ-***	M46	M46-046PT
83020587	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-A-A2-C2-N-D6-H-G1-H5-L-40-L-40-M-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83020589	MOTOR-VAR-DISPL 51MV110	51V110-R-F1-N-ES-A5-K-Y-G5-NNN-030-AA-F0-50-00	SERIES 51	S51-110MV
83020590	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-EQ-A5-K-Y-G5-ACD-042-AA-F0-50-00	SERIES 51	S51-160MV
83020591	PUMP-VAR-DISPL CW DDC20	DDC-20-A-R-RB-LSA-NN-A-2-N-BA-AAN9-D-07-23A-23A-NNN-NNN	DDC20/LDU20	OSK-020PV - DO NOT USE
83020592	PUMP-VAR-DISPL CCW H1PV165	H1-P-165-L-C-A3-C2-N-D7-G-G2-H4-L-33-L-33-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83020593	PUMP-VAR-DISPL CCW H1PV165	H1-P-165-L-C-A3-C2-N-D8-G-G2-H3-L-33-L-33-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83020594	PUMP-VAR-DISPL CCW H1PV165	H1-P-165-L-C-A3-C2-N-D8-G-G2-NN-L-33-L-33-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83020598	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-T1-D1-N-B-TB-VN-AN-N-A-05-NN-022-Z-30-NNN	H1-HP MOTORS	H1-060MB1
83020612	PUMP-VAR DISPL, CW 90PV100	90-R-100-DC-1-NN-80-R-3-S1-E-GB-GBA-42-42-24	SERIES 90	S90-100PV
83020613	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-T2-DA-N-B-TA-CN-KN-N-N-NN-NN-088-Z-20-NNN	H1-HP MOTORS	H1-160MB1
83020614	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A2-C1-N-F6-H-F1-H6-L-42-L-42-M-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83020618	PUMP-VAR-DISPL CW 90PV075	90R075-DD-5-NN-80-P-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-075PV

83020619	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-B9-C3-C-D6-H-G9-NN-K-42-K-42-D-L-24-P1-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83020629	PUMP-VAR-DISPL CW 90PV250	90R250-KN-5-BB-80-S-3-F1-K-03-NNN-26-26-24	SERIES 90	S90-250PV
83020630	PUMP-VAR-DISPL CW 90PV250	90R250-KN-5-EF-80-S-3-C8-K-03-NNN-26-26-24	SERIES 90	S90-250PV
83020638	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-2-NN-80-S-3-F1-J-00-NNN-45-45-28	SERIES 90	S90-250PV
83020641	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-BC-80-L-4-F1-E-03-GBA-14-14-24	SERIES 90	S90-100PV
83020643	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-E2-AA-N-B-TB-DN-KN-N-N-NN-NN-080-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83020645	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A2-C2-N-E7-F-G1-H3-35-35-35-35-N-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83020649	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-HE-HE-N-A-TB-CN-KN-N-N-NN-NN-074-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83020654	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-7-N-0-F1-W-00-EFA-00-00-F0	SERIES 90	S90-100MF
83020655	PUMP-VAR DISPL, CCW 90PV055	90-L-055-FD-2-NN-60-S-3-S1-C-B1-GBA-26-26-20	SERIES 90	S90-055PV
83020656	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-CD-80-P-3-C7-D-03-GBA-29-29-24	SERIES 90	S90-075PV
83020657	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-T1-D1-N-B-TB-VS-AS-S-A-05-NN-022-Z-30-NNN	H1-HP MOTORS	H1-060MB1
83020660	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A4-C2-N-D6-G-G2-NN-L-30-L-30-L-L-28-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83020674	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-J-S-B-B-BA-A-A-BGG-CE-A-GG-3-NNN-***	M46	M46-046PV
83020681	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-HE-HE-N-A-TB-VS-DS-S-A-15-NN-074-S-00-NNN	H1-HP MOTORS	H1-110MB1
83020682	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MA-1-NN-80-S-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83020683	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A5-C1-B-D6-G-G2-H4-L-42-L-42-L-L-30-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83020684	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A5-C1-B-D6-G-G3-NN-L-42-L-42-L-L-30-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83020685	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-B8-C1-D-D6-G-G2-H4-L-42-L-42-L-L-30-P1-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83020686	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-B8-C1-D-D6-G-G3-NN-L-42-L-42-L-L-30-P1-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83020688	PUMP-VAR-DISPL CCW H1PV089	H1-P-089-L-A-B9-C2-C-D6-H-G1-NN-L-42-L-42-M-L-24-P1-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83020689	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-BC-80-L-4-F1-H-03-GBA-35-35-24	SERIES 90	S90-130PV
83020694	PUMP-VAR-DISPL CCW 90PV100	90L100-KP-5-CD-80-R-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
83020696	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-HE-HE-N-B-TB-VN-DN-N-A-15-NN-074-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83020699	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A3-C1-N-D3-H-F4-H5-L-30-L-30-M-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83020713	PUMP-VAR DISPL, CCW 90PV055	90-L-055-M8-5-AB-80-R-3-S1-L-C3-GBA-38-38-24	SERIES 90	S90-055PV
83020738	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KT-1-NN-60-S-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
83020740	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-T2-D2-N-B-TA-DN-HN-N-N-NN-NN-025-Z-16-NNN	H1-HP MOTORS	H1-080MB1
83020741	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MA-1-AC-60-L-3-F1-E-03-GBA-38-38-20	SERIES 90	S90-100PV
83020752	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-NN-80-R-4-C8-F-03-GBA-26-26-24	SERIES 90	S90-130PV
83020753	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-5-AB-80-T-4-C8-J-03-NNN-32-32-24	SERIES 90	S90-250PV
83020754	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-T2-C2-L-N-G0-NNN-060-AA-G0-00-B5	SERIES 51	S51-160MV
83020755	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-A-A3-C1-N-F4-H-G9-H6-K-30-K-30-M-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83020757	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A5-C2-N-F6-H-G1-H6-L-42-L-42-F-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83020758	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A5-C2-N-D6-H-G1-H3-L-42-L-42-F-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83020762	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A4-C2-N-F5-H-G9-H6-L-15-L-33-M-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV

83020773	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HS-1-NN-60-S-3-S1-F-03-GBA-32-32-24	SERIES 90	S90-100PV
83020774	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-BC-80-L-3-F1-E-03-EBC-29-29-24	SERIES 90	S90-100PV
83020775	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-NN-80-S-4-F1-H-03-GBA-35-35-24	SERIES 90	S90-130PV
83020777	PUMP-VAR-DISPL CCW H1PV165	H1-P-165-L-C-A3-C2-N-D3-G-G2-NN-L-42-L-42-A-M-22-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83020778	PUMP-VAR-DISPL CCW H1PV130	H1-P-130-L-B-A3-C2-N-D3-G-G2-H2-L-42-L-42-A-M-20-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83020779	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A4-C2-N-F5-H-G1-H6-L-42-L-42-C-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83020782	PUMP-VAR-DISPL CW 90PV130	90R130-KT-5-BC-80-P-3-T4-F-00-GBA-38-38-20	SERIES 90	S90-130PV
83020786	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-CD-80-L-3-F1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
83020789	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-1-CD-80-D-4-C8-L-03-NNN-42-16-30	SERIES 90	S90-250PV
83020790	PUMP-VAR-DISPL CW 90PV100	90R100-MB-1-BC-80-L-4-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83020792	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-CD-80-D-C-C8-L-03-NNN-30-30-28	SERIES 90	S90-180PV
83020793	MOTOR-VAR-DISPL H1B110	H1-B-110-A-TA-D2-N-B-TA-DN-JN-N-A-10-NN-032-Z-30-NNN	H1-HP MOTORS	H1-110MB1
83020796	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-CD-60-L-4-C7-E-03-GBA-32-32-24	SERIES 90	S90-075PV
83020798	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A4-C2-N-D3-H-G9-H2-L-15-L-18-M-M-34-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83020803	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-N-TA-C2-L-N-G0-NNN-105-AA-G0-00-C2	SERIES 51	S51-160MV
83020804	PUMP-TANDEM, VAR DISPL CCW H1T045L	H1-T-045-L-A-N-A2-C1-N-E7-F-G5-H1-28-28-28-28-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83020806	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-HZ-B1-B-E-G5-NNN-115-AA-F0-12-00	SERIES 51	S51-250MV
83020811	PUMP-VAR-DISPL CW 90PV130	90R130-KP-1-CD-80-R-3-F1-F-03-GBA-42-42-24	SERIES 90	S90-130PV
83020812	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-CD-60-R-3-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83020819	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A5-C1-N-F5-H-F1-H6-L-35-L-35-C-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83020820	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A5-C1-N-D8-H-G1-H2-L-35-L-35-C-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83020822	MOTOR-VAR-DISPL H1B160	H1-B-160-A-TA-DA-N-A-TA-DN-KN-N-A-20-NN-064-Z-29-NNN	H1-HP MOTORS	H1-160MB1
83020823	MOTOR-VARIABLE CARTRIDGE K	K-C-38CN-E-R1F-F65-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83020828	PUMP-VAR-DISPL CW 90PV100	90R100-PB-5-CD-60-R-3-F1-F-00-GBA-35-35-24	SERIES 90	S90-100PV
83020830	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-K1-K1-N-C-RB-DN-JN-N-A-10-NN-031-N-31-NNN	H1-HP MOTORS	H1-110MB1
83020835	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-B-HS-A2-C-H-E1-NNN-090-AA-NN-15-21	SERIES 51	S51-250MV
83020848	PUMP-VAR-DISPL 42PV041 CCW	42-L-41-C-E1A5-03-B-2-G-2-F-N-N-28-28-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83020849	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HS-1-CD-80-R-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83020872	PUMP-VAR DISPL, CW 90PV075	90-R-075-HS-1-BC-80-R-3-C6-D-03-GBA-42-42-24	SERIES 90	S90-075PV
83020881	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-NN-80-P-4-F1-H-00-GBA-20-20-20	SERIES 90	S90-130PV
83020888	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-HE-HE-N-B-TB-CN-GN-N-A-05-NN-013-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83020889	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-HE-HE-N-B-TB-CN-GN-N-A-05-NN-024-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83020890	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-HE-HE-N-B-TB-CS-GS-S-A-05-NN-013-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83020891	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A2-C2-B-D3-H-G1-H3-L-42-L-42-C-M-28-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83020892	MOTOR-VARIABLE DISPL SAE_L	L-V-30DN-A-YNF-F09-S-N-N-AF-F18-NNN-NNT	LV / KV MOTORS	L/K-MV
83020893	MOTOR-VARIABLE DISPL SAE_L	L-V-30DN-A-YNF-F65-S-N-N-AF-F12-NNN-NNT	LV / KV MOTORS	L/K-MV

83020894	MOTOR-VARIABLE DISPL SAE_L	L-V-30DN-A-YNF-F08-S-N-N-AF-F14-NNN-NNT	LV / KV MOTORS	L/K-MV
83020895	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-5-NN-80-D-3-K3-L-03-GBA-42-42-24	SERIES 90	S90-100PV
83020902	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A2-C2-B-F4-H-F1-H6-L-42-L-42-C-M-28-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83020903	PUMP-VAR DISPL CW H1P068R	H1-P-068-R-A-A8-C3-C-D8-H-G1-H5-K-38-K-38-N-E-28-P1-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83020907	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-L2-BA-N-B-PA-VS-ES-S-A-20-NN-044-N-00-NNN	H1-HP MOTORS	H1-160MB1
83020910	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-CD-80-P-3-C7-E-03-GBA-40-40-24	SERIES 90	S90-075PV
83020911	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-BC-80-P-3-S1-E-03-GBA-40-40-24	SERIES 90	S90-075PV
83020912	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-CD-80-T-M-C8-H-03-NNN-42-42-24	SERIES 90	S90-180PV
83020914	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-HE-HE-N-B-TB-CN-JN-N-A-05-NN-045-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83020925	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-CD-80-P-4-F1-F-03-GBA-42-42-24	SERIES 90	S90-130PV
83020926	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A2-C2-N-D8-F-G5-H3-L-40-L-40-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83020930	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-2-BC-80-D-4-S1-L-03-GBA-42-42-24	SERIES 90	S90-100PV
83020947	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-HE-HE-N-B-TB-CN-GN-N-A-05-NN-013-R-00-NNN	H1-HP MOTORS	H1-060MB1
83020948	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-HE-HE-N-B-TB-CS-GS-S-A-05-NN-013-R-00-NNN	H1-HP MOTORS	H1-060MB1
83020949	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-HE-HE-N-B-TB-CN-GN-N-A-05-NN-024-R-00-NNN	H1-HP MOTORS	H1-060MB1
83020952	PUMP-VAR DISPL CW H1P068R	H1-P-068-R-A-A2-C2-N-F6-H-F1-H6-L-38-L-38-C-L-28-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83020953	PUMP-VAR DISPL CW H1P068R	H1-P-068-R-A-A2-C2-N-D6-H-G1-H3-L-38-L-38-C-L-28-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83020974	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-HZ-B1-B-E-G5-NNN-150-AA-F0-12-00	SERIES 51	S51-250MV
83020976	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A3-C2-N-D8-H-G1-H3-L-42-L-42-N-E-26-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83020977	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-CD-80-L-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-075PV
83020978	PUMP-VAR DISPL, CCW 90PV055	90-L-055-DC-5-AB-80-P-3-S1-C-50-GBA-42-42-24	SERIES 90	S90-055PV
83020980	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-B-E8-A5-A-N-A6-NNN-032-AA-F0-03-00	SERIES 51	S51-160MV
83020981	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-E8-A5-A-N-A6-NNN-032-AA-F0-03-00	SERIES 51	S51-160MV
83020983	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-NN-80-P-3-T2-E-03-GBA-26-26-24	SERIES 90	S90-100PV
83020986	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-D-T-B-B-BA-G-A-BEE-BA-A-GG-B-NNN-***	M46	M46-046PV
83020989	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-NN-80-R-3-C6-C-03-GBA-38-38-24	SERIES 90	S90-055PV
83020990	PUMP-VAR DISPL, CW 90PV100	90-R-100-HF-1-CD-80-P-3-C7-F-03-GBA-35-35-24	SERIES 90	S90-100PV
83020991	PUMP-VAR-DISPL CCW 90PV075	90L075-CB-5-NN-80-P-4-C7-E-00-GBA-42-42-30	SERIES 90	S90-075PV
83020993	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A2-C2-N-D8-F-G4-H3-L-40-L-40-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83020994	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-EG-80-T-M-C8-J-03-NNN-42-42-24	SERIES 90	S90-180PV
83020997	PUMP-VAR-DISPL CW 90PV130	90R130-KN-5-BC-80-S-3-C8-H-03-GBA-42-42-24	SERIES 90	S90-130PV
83020998	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-2-BC-80-D-4-S1-L-03-GBA-42-42-24	SERIES 90	S90-100PV
83020999	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-NN-80-T-M-C8-J-05-FAC-35-24-24	SERIES 90	S90-180PV
83021001	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A4-C3-N-F4-H-G9-H6-L-40-L-40-M-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83021002	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-TA-C2-L-N-G0-NNN-055-AA-F0-00-C7	SERIES 51	S51-160MV
83021006	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A4-C3-N-F4-H-G9-H6-K-40-K-40-M-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV

83021008	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-T2-DA-N-A-TB-DN-KN-N-A-30-NN-070-Z-21-NNN	H1-HP MOTORS	H1-160MB1
83021009	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A4-C1-N-E7-F-G1-T3-20-20-20-20-M-P-24-PN-NNN-S01	H1-MP PUMPS	H1-045PT/053PT
83021010	PUMP-VAR-DISPL CCW H1PV130	H1-P-130-L-B-A3-C1-N-D8-G-G2-H3-L-35-L-35-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83021011	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-CD-80-T-M-C8-J-00-EFI-42-42-24	SERIES 90	S90-180PV
83021012	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-L2-BA-N-B-PB-VN-EN-N-A-20-NN-032-N-00-NNN	H1-HP MOTORS	H1-160MB1
83021015	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-HE-HE-N-B-TB-VN-DN-N-A-20-NN-032-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83021016	PUMP-VAR-DISPL CCW H1PV130	H1-P-130-L-B-A3-C1-N-D3-G-G2-H3-L-35-L-35-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83021020	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-CD-80-L-4-S1-F-02-GBA-26-26-24	SERIES 90	S90-100PV
83021021	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A5-C2-B-E5-F-G4-NN-L-25-L-25-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83021022	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HS-1-BC-80-R-4-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83021023	PUMP-VAR DISPL, CW 90PV055	90-R-055-HS-1-BC-80-R-4-S1-C-00-GBA-35-35-24	SERIES 90	S90-055PV
83021024	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A2-C1-N-D8-F-G4-H3-L-33-L-33-B-P-22-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83021028	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-CD-80-L-4-S1-C-01-GBA-23-23-24	SERIES 90	S90-055PV
83021029	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A3-C1-N-D3-H-F1-NN-L-40-L-40-M-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83021030	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-L2-BA-N-B-PA-DS-KS-S-A-20-NN-060-N-00-NNN	H1-HP MOTORS	H1-160MB1
83021032	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-NN-80-D-3-S1-L-03-GBA-30-30-28	SERIES 90	S90-100PV
83021048	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-A-T-B-B-BA-A-A-BDD-CE-A-GG-C-NNN-***	M46	M46-046PV
83021049	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-D2-M2-N-B-PB-VN-DN-N-A-15-NN-050-N-25-NNN	H1-HP MOTORS	H1-110MB1
83021050	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-L2-BA-N-A-PA-DN-JN-N-A-15-NN-022-N-00-NNN	H1-HP MOTORS	H1-110MB1
83021051	PUMP-VAR-DISPL CW 90PV130	90R130-MA-5-NN-80-S-4-C8-F-C4-GBA-29-29-24	SERIES 90	S90-130PV
83021052	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-1-N-0-S1-W-00-NNN-00-00-E6	SERIES 90	S90-100MF
83021055	PUMP-VAR-DISPL CCW H1PV130	H1-P-130-L-B-A2-C3-N-D8-G-G3-NN-L-35-L-35-A-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83021075	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HF-1-NN-80-R-3-S1-F-06-GBA-35-35-24	SERIES 90	S90-100PV
83021076	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-AB-80-P-3-F1-H-06-GBA-35-35-24	SERIES 90	S90-130PV
83021077	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-CD-80-R-3-F1-H-06-GBA-35-35-30	SERIES 90	S90-130PV
83021078	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-NN-80-R-3-F1-F-06-GBA-35-35-30	SERIES 90	S90-130PV
83021079	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-CD-80-T-C-C8-J-06-NNN-35-35-24	SERIES 90	S90-180PV
83021080	PUMP-VAR-DISPL CCW 90PV180	90L180-KP-5-CD-80-T-M-C8-J-06-FAC-32-32-24	SERIES 90	S90-180PV
83021081	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-5-CD-80-T-3-C8-K-06-NNN-35-35-24	SERIES 90	S90-250PV
83021085	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-CD-80-P-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83021086	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-D-E2D8-02-A-N-A-2-H-N-A-38-38-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83021087	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-E2D8-03-B-3-B-3-F-N-A-34-34-B-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83021088	PUMP-VAR-DISPL CCW 90PV042	90L042-KA-1-BB-80-R-4-C3-C-03-GBA-23-23-24	SERIES 90	S90-042PV
83021089	PUMP-VAR-DISPL CCW 90PV042	90L042-KA-1-BC-80-R-4-C3-C-03-GBA-23-23-24	SERIES 90	S90-042PV
83021090	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-1-CD-80-R-3-F1-F-03-GBA-42-42-24	SERIES 90	S90-130PV
83021093	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-5-BC-80-T-3-F1-K-06-NNN-38-38-24	SERIES 90	S90-250PV

83021096	PUMP-VAR-DISPL CW 90PV100	90R100-MA-1-BC-60-R-3-C7-E-03-GFK-42-42-24	SERIES 90	S90-100PV
83021107	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-A-V-C-S-AA-B-A-A-A-BJJ-AK-D-ED-B-C-A-A-BJJ-AK-U-ED-B-NNA-***	M46	M46-046PT
83021124	MOTOR-VAR-DISPL H1MB060	H1-B-060-A-L2-BA-N-B-PA-VS-AS-S-N-NN-NN-000-N-00-NNN	H1-HP MOTORS	H1-060MB1
83021127	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E1-AA-N-C-TA-VN-AN-N-A-10-NN-027-Z-00-N04	H1-HP MOTORS	H1-080MB1
83021130	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-1-BC-80-P-3-S1-C-03-GBA-32-32-24	SERIES 90	S90-055PV
83021134	PUMP-VAR-DISPL 42PV041 CCW	42-L-41-D-A7J5-03-A-N-A-3-F-N-B-21-21-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83021138	PUMP-VAR DISPL CCW H1P060L	H1-P-060-L-A-B8-C1-D-D6-H-G1-H1-L-30-L-30-F-L-24-P1-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83021143	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-CD-80-P-4-F1-F-03-EEB-38-38-24	SERIES 90	S90-130PV
83021151	MOTOR-VAR-DISPL 51MC060-1	51C060-1--A-D1-N-E2-B1-N-N-U1-NNN-025-AA-F0-00-00	SERIES 51	S51-060MV-1
83021153	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-L2-BA-N-B-PA-VS-DS-S-A-10-NN-025-N-00-NNN	H1-HP MOTORS	H1-110MB1
83021154	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-L2-BA-N-B-PA-VS-DS-S-A-10-NN-050-N-00-NNN	H1-HP MOTORS	H1-110MB1
83021160	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-2-CD-80-R-3-C7-E-00-GFJ-42-14-24	SERIES 90	S90-075PV
83021169	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A7-C2-C-D6-J-G5-H2-L-42-L-42-B-L-24-P2-NNN-D3F	H1-MP PUMPS	H1-045PV/053PV
83021171	MOTOR-FIX DISPL 90MF130	90-M-130-NC-0-N-8-N-0-C8-W-00-NNN-00-00-B3	SERIES 90	S90-130MF
83021176	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A2-C3-N-D7-G-G3-H4-L-42-L-42-L-P-32-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83021177	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-HF-HF-N-A-TB-VN-AN-N-N-NN-NN-000-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83021178	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A4-C1-N-D6-H-G9-H3-L-28-L-28-C-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83021179	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A4-C1-N-D6-H-G1-H3-L-35-L-35-C-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83021181	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-K1-K1-N-C-RA-DN-HN-N-A-10-NN-027-N-23-NNN	H1-HP MOTORS	H1-080MB1
83021182	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A2-C1-N-D5-G-G3-H4-L-42-L-42-L-M-32-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83021183	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A4-C2-N-E7-F-G1-H3-18-28-35-25-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83021194	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-1-BC-80-R-4-T4-F-00-GBA-35-35-24	SERIES 90	S90-130PV
83021202	PUMP-VAR DISPL, CCW 90PV075	90-L-075-M8-1-AB-60-P-3-D7-D-03-GBA-42-42-24	SERIES 90	S90-075PV
83021203	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-1-CD-80-S-3-C7-C-34-GCB-26-26-18	SERIES 90	S90-075PV
83021204	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-N-TA-C2-L-N-G0-NNN-055-AA-F0-00-C7	SERIES 51	S51-160MV
83021206	PUMP-VAR-DISPL CCW 90PV130	90L130-HF-5-AB-80-P-4-C8-H-03-GBA-42-42-24	SERIES 90	S90-130PV
83021207	MOTOR- VARIABLE CARTRIDGE L	L-C-30DN-E-RNF-F07-S-N-N-AF-F18-NNN-NNT	LV / KV MOTORS	L/K-MV
83021208	PUMP-VAR-DISPL CCW 90PV130 BASE MODEL	90L130-CB-1-NN-80-S-4-T4-F-00-GBA-35-35-24-P000	SERIES 90	S90-130PV
83021209	PUMP-VAR-DISPL CW 90PV130 BASE MODEL	90R130-CB-1-NN-80-S-3-F1-H-00-GBA-35-35-24-P000	SERIES 90	S90-130PV
83021210	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-G-S-B-B-AA-A-A-BDD-CB-A-JJ-C-NNN-***	M46	M46-046PV
83021222	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-C5-C3-N-D7-G-G3-H4-L-42-L-42-L-P-32-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83021224	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-NN-80-P-7-C7-E-03-GBA-36-36-30	SERIES 90	S90-075PV
83021225	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-AB-80-S-4-C8-J-03-NNN-42-42-24	SERIES 90	S90-250PV
83021226	PUMP-VAR-DISPL CW 90PV100	90R100-KA-1-CD-80-S-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83021227	PUMP-VAR-DISPL CW 90PV100	90R100-KA-1-NN-80-S-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83021228	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A5-C2-N-D6-G-G2-H4-K-42-K-42-A-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV

83021229	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A5-C2-N-D6-G-G3-H3-K-42-K-42-A-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83021230	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-L2-BA-N-B-PA-CS-LS-S-A-30-NN-060-N-00-NNN	H1-HP MOTORS	H1-160MB1
83021244	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E1-AA-N-C-TB-DN-JN-N-A-15-NN-074-Z-00-N02	H1-HP MOTORS	H1-110MB1
83021247	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-HF-HF-N-B-TA-VN-FN-N-N-NN-100-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83021248	PUMP-VAR-DISPL CW 90PV100	90R100-DD-2-NN-80-R-7-C7-E-GB-GCA-35-35-30	SERIES 90	S90-100PV
83021273	PUMP-VAR-DISPL CW 90PV075	90R075-CB-5-NN-80-P-4-C7-E-00-GBA-42-42-30	SERIES 90	S90-075PV
83021281	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-K-T-B-B-AA-A-A-BDD-CB-A-JJ-4-NNN-***	M46	M46-046PV
83021302	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-EF-80-D-C-C8-L-03-NNN-30-30-28	SERIES 90	S90-180PV
83021303	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-NN-80-D-C-F1-N-03-NNN-30-30-28	SERIES 90	S90-180PV
83021305	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-CD-60-P-3-C6-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83021307	PUMP-VAR DISPL MPV046C	MPV-046-C-B-A-K-S-B-B-BA-A-A-BJJ-AB-U-CD-B-NNN-***	M46	M46-046PV
83021313	PUMP-VAR-DISPL CW 90PV250	90R250-HF-5-DE-80-T-3-C8-J-04-NNN-35-35-24	SERIES 90	S90-250PV
83021314	PUMP-VAR-DISPL CW 90PV130	90R130-HF-5-BC-80-R-4-F1-H-04-GBA-35-35-24	SERIES 90	S90-130PV
83021320	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A4-C2-B-D6-H-G1-H3-L-23-L-23-C-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83021321	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A4-C2-B-D6-H-G1-NN-L-23-L-23-C-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83021323	PUMP-VAR-DISPL CW 90PV250	90R250-KT-2-EG-80-T-3-C8-K-03-NNN-42-42-24	SERIES 90	S90-250PV
83021325	MOTOR-VAR-DISPL 51MV250	51V250-A-C8-N-T3-C2-L-N-K7-NNN-110-AA-F3-00-C6	SERIES 51	S51-250MV
83021328	PUMP-VAR DISPL, CW H1PV250	H1-P-250-R-A-A4-C2-N-D6-C-G2-H6-L-45-L-45-W-L-30-PN-NNN-NNN	H1-HP PUMPS	H1-210PV/250PV
83021329	MOTOR-VAR-DISPL 51MD060	51D060-A-D1-N-HS-A2-B-E-E1-NNN-020-AA-NN-10-20	SERIES 51	S51-060MV
83021330	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-D-B1-B3-N-N-U3-NNN-055-AA-NN-00-00	SERIES 51	S51-110MV-1
83021331	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-D8-M1-R-J-M1-NNN-082-AA-F0-C2-25	SERIES 51	S51-250MV
83021341	PUMP-VAR-DISPL CW 90PV250	90R250-MA-5-AB-80-T-4-C8-K-C7-NNN-29-29-24	SERIES 90	S90-250PV
83021342	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-AB-60-S-3-S1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
83021343	PUMP-VAR-DISPL CW 90PV250	90R250-KA-1-NN-80-T-4-F1-K-03-NNN-35-35-24	SERIES 90	S90-250PV
83021346	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A3-C1-N-F6-H-G9-H6-L-45-L-40-D-L-30-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83021348	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-E2-A1-A-N-E2-NNN-050-AA-G0-03-26	SERIES 51	S51-250MV
83021352	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-BC-80-L-3-C8-H-03-GBA-35-35-24	SERIES 90	S90-130PV
83021361	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-N-A2-C2-N-E7-F-G1-H3-35-35-35-35-N-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83021366	PUMP-VAR-DISPL CW 90PV250	90R250-MA-5-CD-80-S-3-F1-K-C5-NNN-38-38-24	SERIES 90	S90-250PV
83021367	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-EF-80-S-M-F1-J-03-NNN-32-32-28	SERIES 90	S90-180PV
83021368	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-NN-80-S-M-F1-J-03-NNN-32-32-28	SERIES 90	S90-180PV
83021370	PUMP-VAR-DISPL CW 90PV100	90R100-MA-5-AB-80-P-3-C7-F-C4-GBA-42-42-24	SERIES 90	S90-100PV
83021371	PUMP-VAR-DISPL CW 90PV130	90R130-MA-5-AB-80-P-3-C8-F-C4-GBA-42-42-24	SERIES 90	S90-130PV
83021374	MOTOR-VAR-DISPL 51MV110	51V110-R-F1-N-HZ-B1-B-H-J1-NNN-030-AA-F3-05-00	SERIES 51	S51-110MV
83021375	MOTOR-VAR-DISPL 51MV110	51V110-A-F1-N-HZ-B1-B-H-J1-NNN-030-AA-F3-05-00	SERIES 51	S51-110MV
83021376	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-D-HZ-B1-B-H-J1-NNN-050-AA-F3-11-00	SERIES 51	S51-250MV

83021377	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-C-E1A7-00-D-N-F-3-F-N-A-38-38-N-H-H-NNN-NNN	SERIES 42	S42-028PV/032PV
83021378	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-L2-BA-N-A-PB-VN-EN-N-N-NN-NN-000-N-00-NNN	H1-HP MOTORS	H1-160MB1
83021380	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A5-C2-N-D6-G-G2-H4-L-35-L-35-A-L-28-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83021381	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A5-C2-N-D6-G-G3-NN-L-35-L-35-A-L-28-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83021384	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-P1-D1-N-B-TA-DS-KS-S-A-15-NN-024-Z-24-NNN	H1-HP MOTORS	H1-110MB1
83021394	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-5-AB-60-P-3-C6-C-04-GBA-42-42-20	SERIES 90	S90-055PV
83021405	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-N1-NN-N-N-U1-ABA-041-AA-NN-00-00	SERIES 51	S51-110MV-1
83021410	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-D1-M1-N-A-PB-VS-AS-S-A-10-NN-000-N-24-NNN	H1-HP MOTORS	H1-080MB1
83021415	PUMP-VAR DISPL, CCW 90PV075 BASE MODEL	90-L-075-CB-1-NN-80-S-4-S1-E-00-GBA-35-35-24-P000	SERIES 90	S90-075PV
83021416	PUMP-VAR DISPL, CW 90PV055 BASE MODEL	90-R-055-CB-1-NN-80-S-4-K1-C-00-GBA-35-35-24-P000	SERIES 90	S90-055PV
83021417	PUMP-VAR DISPL, CW 90PV075 BASE MODEL	90-R-075-CB-1-NN-80-S-4-S1-E-00-GBA-35-35-24-P000	SERIES 90	S90-075PV
83021418	PUMP-VAR DISPL, CW 90PV075 BASE MODEL	90-R-075-CB-1-NN-80-S-4-K2-D-00-GBA-35-35-24-P000	SERIES 90	S90-075PV
83021419	PUMP-VAR DISPL, CW 90PV100 BASE MODEL	90-R-100-CB-1-NN-80-S-4-S1-F-00-GBA-35-35-24-P000	SERIES 90	S90-100PV
83021422	PUMP-VAR-DISPL CCW 90PV100	90L100-HF-5-CD-60-L-4-C7-F-03-GBA-35-35-24	SERIES 90	S90-100PV
83021423	PUMP-VAR-DISPL CCW 90PV100	90L100-CB-1-NN-80-S-3-F1-E-00-GBA-35-35-24	SERIES 90	S90-100PV
83021424	PUMP-VAR-DISPL CCW 90PV130	90L130-MA-1-CD-80-R-3-F1-F-03-GBA-42-42-24	SERIES 90	S90-130PV
83021432	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-2-CD-80-P-4-S1-C-00-GBA-35-35-24	SERIES 90	S90-055PV
83021434	PUMP-VAR-DISPL CCW H1PV115	H1-P-115-L-B-A5-C2-B-D3-G-G3-NN-L-35-L-35-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83021441	PUMP-VAR-DISPL 42PV028 CW	42-R-2A-C-E2C8-02-B-2-B-2-G-N-A-34-34-B-N-N-AAA-NNN	SERIES 42	S42-028PV/032PV
83021442	PUMP-VAR DISPL CCW H1P068L	H1-P-068-L-A-A5-C2-N-F6-H-F1-H6-L-35-L-35-F-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83021443	PUMP-VAR-DISPL CW 90PV042	90R042-KP-5-NN-80-L-3-C3-C-00-GBA-32-32-24	SERIES 90	S90-042PV
83021444	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KT-5-BC-80-P-3-S1-F-03-GBA-38-38-24	SERIES 90	S90-100PV
83021445	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KT-5-CD-80-P-3-T2-F-03-GBA-38-38-24	SERIES 90	S90-100PV
83021449	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-EG-80-S-C-C8-H-03-GLA-29-29-24	SERIES 90	S90-180PV
83021450	PUMP-VAR DISPL, CCW 90PV055	90-L-055-MA-1-CD-80-R-3-T1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83021451	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-B1-C2-N-D6-H-G1-NN-L-25-L-25-C-L-20-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83021452	PUMP-VAR DISPL, CCW 90PV055	90-L-055-MA-1-NN-80-R-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83021459	PUMP-VAR-DISPL CW 90PV250	90R250-HF-5-EG-80-T-3-C8-K-03-NNN-40-40-28	SERIES 90	S90-250PV
83021460	PUMP-VAR-DISPL CW 90PV250	90R250-HF-5-CD-80-T-3-C8-K-03-NNN-40-40-28	SERIES 90	S90-250PV
83021461	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-N-HS-A2-C-H-E1-NNN-075-AA-G0-12-35	SERIES 51	S51-250MV
83021470	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-C-E1A7-02-D-N-F-2-F-N-B-28-28-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83021471	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-C-E1A7-02-D-N-F-2-F-N-N-28-28-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83021473	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-NN-60-S-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83021474	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KN-1-CD-80-S-4-S1-C-03-GBA-32-32-24	SERIES 90	S90-055PV
83021475	PUMP-VAR DISPL, CW 90PV075	90-R-075-KN-1-CD-80-S-4-S1-C-03-GBA-35-35-24	SERIES 90	S90-075PV
83021477	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-E2-AA-N-B-TB-VN-DN-N-A-20-NN-038-R-00-NNN	H1-HP MOTORS	H1-160MB1

83021478	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-E2-A5-A-N-A6-NNN-055-AA-G0-03-00	SERIES 51	S51-250MV
83021479	PUMP-VAR DISPL CW H1P068R	H1-P-068-R-A-A3-C1-B-D3-H-G1-NN-L-30-L-30-F-M-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83021482	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-BB-80-L-4-C8-H-03-GBA-35-35-24	SERIES 90	S90-130PV
83021486	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-BC-80-P-4-C7-D-03-EFC-42-42-24	SERIES 90	S90-075PV
83021488	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A5-C3-N-D6-H-G9-NN-K-42-K-42-D-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83021490	PUMP-TANDEM, VAR DISPL MPT035D	MPT-035-D-C-R-A-H-NN-B-A-A-A-BJJ-DL-A-FF-B-C-A-A-BJJ-DL-A-FF-1-NNN-***	M35/44	035PT
83021500	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KN-1-CD-80-R-4-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83021501	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KN-1-BC-80-R-4-F1-E-03-GBA-42-14-24	SERIES 90	S90-100PV
83021502	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KN-1-NN-60-D-4-S1-L-03-GBA-35-35-28	SERIES 90	S90-055PV
83021503	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KN-1-NN-80-R-4-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
83021504	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KN-1-CD-80-R-4-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
83021505	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-C-N2-NN-N-N-A0-ANB-165-AA-G3-00-00	SERIES 51	S51-250MV
83021506	PUMP-VAR-DISPL CW 90PV100	90R100-HF-5-CD-60-P-3-C7-E-00-GBA-42-42-24	SERIES 90	S90-100PV
83021507	PUMP-VAR-DISPL CCW 90PV100	90L100-HF-5-BC-60-P-3-S1-E-00-GBA-42-42-24	SERIES 90	S90-100PV
83021508	PUMP-VAR-DISPL CCW 90PV100	90L100-HF-5-CD-60-P-3-C7-E-00-GBA-42-42-24	SERIES 90	S90-100PV
83021509	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-NN-60-L-4-S1-E-03-GBA-35-35-26	SERIES 90	S90-100PV
83021510	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-5-BB-80-P-3-S1-E-02-GBA-42-42-24	SERIES 90	S90-075PV
83021511	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-5-CD-80-P-3-C7-E-02-GBA-42-42-24	SERIES 90	S90-075PV
83021513	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E2-AA-N-B-TB-VN-AN-N-A-10-NN-054-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83021514	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-D2-M2-N-B-PB-VN-AN-N-A-10-NN-022-N-26-NNN	H1-HP MOTORS	H1-080MB1
83021515	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E2-AA-N-B-TB-VN-EN-N-A-15-NN-064-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83021520	PUMP-VAR-DISPL CW 90PV180	90R180-MA-5-AB-80-T-M-C8-J-C7-NNN-42-42-24	SERIES 90	S90-180PV
83021522	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-NN-80-T-C-C8-J-03-NNN-42-42-26	SERIES 90	S90-180PV
83021532	MOTOR-VAR-DISPL 51MV080-1	51V080-1--A-C7-N-T2-CA-N-N-X1-ACB-016-AA-F0-00-26	SERIES 51	S51-080MV-1
83021533	PUMP-VAR-DISPL CW 90PV180	90R180-KT-1-BB-80-R-C-F1-H-03-FAC-35-35-24	SERIES 90	S90-180PV
83021536	PUMP-VAR-DISPL 42PV041 CCW	42-L-41-E-E1A5-03-A-N-A-2-F-N-B-14-14-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83021538	PUMP-VAR-DISPL 42PV028 CW	42-R-2A-D-G2A1-52-U-2-G-2-F-5-B-34-34-B-0-0-AAA-NNN	SERIES 42	S42-028PV/032PV
83021539	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-NN-80-R-4-S1-D-03-GBA-29-13-18	SERIES 90	S90-075PV
83021541	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-NN-80-S-M-C8-J-04-NNN-42-42-24	SERIES 90	S90-180PV
83021549	MOTOR-VAR-DISPL 51MV110	51V110-R-C8-N-HS-A2-A-N-A7-NNN-041-AA-F3-03-25	SERIES 51	S51-110MV
83021562	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A5-C3-B-D9-G-G2-H4-L-42-L-42-L-L-28-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83021563	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A5-C3-B-D6-G-G3-H6-L-42-L-42-L-L-28-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83021564	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A5-C3-B-D6-H-G1-H3-L-42-L-42-C-L-28-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83021565	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-BC-80-P-4-C7-D-03-EFC-35-35-24	SERIES 90	S90-075PV
83021570	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A8-C3-C-F6-H-G9-H6-L-45-L-45-C-L-30-P1-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83021575	PUMP-VAR DISPL, CW 90PV100	90-R-100-HS-1-CD-80-P-3-S1-E-03-GBA-26-26-24	SERIES 90	S90-100PV

83021578	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-1-AB-80-P-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83021585	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KN-1-NN-80-R-4-T1-D-03-GBA-21-21-24	SERIES 90	S90-075PV
83021587	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-P1-D1-N-A-TA-DS-KS-S-A-15-NN-034-Z-24-N11	H1-HP MOTORS	H1-110MB1
83021591	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-P2-D2-N-B-TA-DS-KS-S-A-20-NN-053-Z-24-NNN	H1-HP MOTORS	H1-160MB1
83021592	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A3-C2-N-D8-F-G4-NN-L-25-L-25-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83021593	MOTOR-VAR-DISPL H1MB060	H1-B-060-A-L2-BA-N-B-PA-VS-AS-S-A-10-NN-016-N-00-NNN	H1-HP MOTORS	H1-060MB1
83021594	PUMP-VAR-DISPL CW 90PV130	90R130-CA-5-CL-80-L-7-C8-H-00-GBA-14-14-24	SERIES 90	S90-130PV
83021596	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-5-NN-80-P-4-S1-C-03-GBA-42-13-24	SERIES 90	S90-055PV
83021597	PUMP-VAR-DISPL CW 90PV180	90R180-DD-5-CD-80-T-M-C8-H-GB-NNN-20-20-24	SERIES 90	S90-180PV
83021604	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HS-5-NN-80-S-4-C6-D-02-GBA-42-42-24	SERIES 90	S90-075PV
83021607	PUMP-VAR-DISPL CCW H1PV165	H1-P-165-L-C-A3-C2-N-D8-G-G3-H3-L-33-L-33-A-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83021613	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-B1-C1-N-D6-H-G1-H2-L-38-L-38-F-L-20-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83021620	PUMP-VAR-DISPL CW 90PV130	90R130-HF-1-NN-80-S-3-F1-F-03-EEB-29-29-24	SERIES 90	S90-130PV
83021621	MOTOR-VAR-DISPL H1B250	H1-B-250-A-K2-K2-N-B-RA-VS-FS-S-A-20-NN-060-N-21-NNN	H1-HP MOTORS	H1-250MB1
83021624	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MA-1-NN-80-P-3-F1-E-03-GBA-32-32-24	SERIES 90	S90-100PV
83021628	PUMP-VAR-DISPL CW 90PV100	90R100-HS-1-NN-80-R-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83021630	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-HF-HF-N-A-TB-CN-KN-N-N-NN-NN-060-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83021632	PUMP-VAR DISPL MPV035D	MPV-035-D-B-A-A-R-S-G-AA-A-A-BHH-DR-A-FF-A-NNN-***	M35/44	035PV
83021634	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-2-CD-80-S-3-S1-D-03-GBA-23-23-24	SERIES 90	S90-075PV
83021635	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-2-NN-80-S-3-S1-D-03-GBA-23-23-24	SERIES 90	S90-075PV
83021636	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-CD-80-P-3-S1-E-03-GBA-32-32-24	SERIES 90	S90-100PV
83021638	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-2-BB-80-R-3-F1-F-00-GBA-42-42-24	SERIES 90	S90-130PV
83021652	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HS-1-CD-60-P-3-S1-D-03-GBA-32-32-24	SERIES 90	S90-075PV
83021653	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-NN-80-P-3-F1-E-03-GBA-32-32-24	SERIES 90	S90-100PV
83021654	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KN-1-BC-80-S-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83021655	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-G2A1-52-U-2-G-2-F-5-B-34-34-B-0-0-NNN-NNN	SERIES 42	S42-028PV/032PV
83021656	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-N-HZ-B1-C-H-G0-ADA-120-AA-H0-20-00	SERIES 51	S51-250MV
83021658	PUMP-VAR-DISPL 42PV041 CW	42-R-4A-D-G1A1-72-J-2-B-2-F-5-A-32-32-B-0-0-AAA-NNN	SERIES 42	S42-041PV/051PV
83021659	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-E2D8-03-C-2-A-3-H-N-A-32-32-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83021662	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A5-C2-N-F6-H-G1-H6-L-42-L-42-F-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83021663	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A5-C2-N-D6-H-G1-H3-L-42-L-42-F-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83021667	MOTOR-VAR-DISPL H1B250	H1-B-250-A-L2-BA-N-B-PB-VS-FS-S-A-20-NN-085-N-00-NNN	H1-HP MOTORS	H1-250MB1
83021671	PUMP-VAR-DISPL CW 90PV130	90R130-KA-1-CD-80-S-3-C8-H-04-GBA-42-42-24	SERIES 90	S90-130PV
83021683	MOTOR-VARIABLE CARTRIDGE K	K-C-38CN-A-YNF-F09-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83021684	PUMP-VAR-DISPL CW 90PV130	90R130-RS-5-BC-80-P-3-C8-H-02-GBA-40-40-24	SERIES 90	S90-130PV
83021691	PUMP-VAR-DISPL CCW H1PV115	H1-P-115-L-B-A3-C3-N-D3-G-G2-H6-L-35-L-35-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV

83021692	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-S-B-B-AA-R-A-BFF-CB-A-HH-F-NNN-***	M46	M46-046PV
83021693	MOTOR-VAR-DISPL H1B110	H1-B-110-A-TA-DA-N-B-TB-VN-DN-N-N-NN-NN-060-Z-20-NNN	H1-HP MOTORS	H1-110MB1
83021694	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-5-CD-80-S-3-F1-F-04-GBA-38-38-24	SERIES 90	S90-100PV
83021695	1PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-5-NN-80-S-3-S1-F-04-GBA-38-38-24	SERIES 90	S90-100PV
83021703	PUMP-VAR-DISPL CW 90PV250	90R250-MA-5-NN-80-S-3-F1-K-C5-NNN-38-38-24	SERIES 90	S90-250PV
83021704	PUMP-VAR-DISPL CW 90PV250	90R250-HS-1-CD-80-D-3-F1-L-03-NNN-42-42-24	SERIES 90	S90-250PV
83021708	PUMP-VAR DISPL, CW 90PV055	90-R-055-HS-1-BC-60-R-4-S1-C-03-GBA-38-38-24	SERIES 90	S90-055PV
83021710	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-HF-HF-N-B-TA-VN-EN-N-N-NN-NN-100-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83021716	PUMP-VAR-DISPL CW 90PV130	90R130-DD-5-DE-80-R-3-F1-H-G4-GBA-42-42-28	SERIES 90	S90-130PV
83021717	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E1-AA-N-B-TB-DN-JN-N-N-NN-NN-040-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83021720	PUMP-VAR DISPL, CCW 90PV055	90-L-055-MA-1-CD-80-R-3-T1-C-03-GBA-35-35-24-N180	SERIES 90	S90-055PV
83021721	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-1-BC-80-S-4-C7-E-03-GBA-35-35-24	SERIES 90	S90-075PV
83021723	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-L1-BA-N-B-PB-CS-JS-S-A-10-NN-000-N-00-NNN	H1-HP MOTORS	H1-080MB1
83021726	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-1-BC-80-L-3-F1-H-03-GBA-38-38-24	SERIES 90	S90-130PV
83021730	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A3-C1-N-D6-H-F4-NN-L-33-L-33-M-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83021732	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A5-C3-N-F4-H-G9-H6-L-35-L-35-D-M-30-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83021733	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A5-C3-N-D3-H-G1-H3-L-35-L-35-D-M-30-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83021736	PUMP-VAR-DISPL CW 90PV130	90R130-EA-1-NN-80-S-3-C8-N-03-GBA-16-16-20	SERIES 90	S90-130PV
83021739	MOTOR-FIXED DISPL MMF025C	MMF-025-C-A-S-G-A-C-NNN-***	LIGHT DUTY	025MF
83021741	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-HE-HE-N-A-TA-VN-EN-N-A-20-NN-100-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83021748	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-CD-60-R-3-S1-D-03-GBA-38-38-24	SERIES 90	S90-055PV
83021775	PUMP-VAR-DISPL 42PV028 CW	42-R-28-G-G3AN-50-P-D-B-3-G-5-N-34-34-N-1-1-NNN-BNN	SERIES 42	S42-028PV/032PV
83021777	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A5-C1-N-D8-F-G5-NN-L-33-L-33-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83021779	PUMP-VAR-DISPL CCW 90PV250	90L250-KP-5-CD-80-T-3-C8-J-03-NNN-35-35-24	SERIES 90	S90-250PV
83021781	PUMP-VAR-DISPL CCW 90PV250	90L250-KN-5-EF-80-S-3-C8-J-06-NNN-35-35-30	SERIES 90	S90-250PV
83021782	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-L8-B1-V-A-G0-ADA-060-AA-G0-B2-00	SERIES 51	S51-250MV
83021783	MOTOR-VARIABLE CARTRIDGE K	K-C-38CN-A-YNF-F07-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83021784	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-E1A6-03-D-N-F-2-F-N-N-28-28-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83021788	PUMP-VAR-DISPL CCW 90PV075	90L075-KN-1-NN-60-R-4-S1-D-03-GBA-38-38-24	SERIES 90	S90-075PV
83021789	PUMP-VAR-DISPL CW 90PV100	90R100-HF-5-NN-60-L-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83021790	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-T1-D1-N-C-TA-DN-GN-N-N-NN-NN-017-Z-28-NNN	H1-HP MOTORS	H1-060MB1
83021791	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A4-C3-N-D6-H-G1-H2-L-35-L-35-C-L-20-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83021792	MOTOR-VAR-DISPL H1MB060	H1-B-060-A-L1-BA-N-B-PB-CN-GN-N-A-10-NN-020-N-00-NNN	H1-HP MOTORS	H1-060MB1
83021794	PUMP-VAR-DISPL CCW 90PV180	90L180-HF-5-BC-80-S-M-C8-H-03-NNN-32-14-30	SERIES 90	S90-180PV
83021795	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-1-BC-60-P-4-S1-C-00-GBA-26-26-24	SERIES 90	S90-055PV
83021796	PUMP-VAR-DISPL CCW DDC20	DDC-20-A-L-LB-RSA-NN-A-N-A-CB-ACE0-E-07-25A-25A-NNN-NNN	DDC20/LDU20	OSK-020PV - DO NOT USE

83021797	PUMP- VARIABLE, DIRECT DISPLACMENT	LPV-A-A-A-A-E-AC-C-A-BHH-DR-A-FF-B-NNN-***	LPV	LPV
83021798	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A8-C2-C-D6-F-G5-H3-L-42-L-20-B-L-24-P1-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83021822	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-L2-B1-V-A-G5-ABA-085-AA-G0-B2-00	SERIES 51	S51-250MV
83021824	PUMP-VAR-DISPL CW DDC20	DDC-20-A-R-RB-LSA-NN-A-N-3-AA-ACA0-D-07-21N-21N-NNN-NNN	DDC20/LDU20	OSK-020PV - DO NOT USE
83021826	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-1-AB-60-R-4-C6-C-28-FAP-42-35-24	SERIES 90	S90-055PV
83021827	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-BB-60-D-3-C7-L-00-GBA-42-42-24	SERIES 90	S90-075PV
83021828	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-NN-60-S-3-S1-D-03-GBA-35-35-20	SERIES 90	S90-075PV
83021829	PUMP-VAR DISPL, CW 90PV075	90-R-075-HS-1-NN-60-S-3-S1-D-03-GBA-35-35-20	SERIES 90	S90-075PV
83021830	PUMP-VAR DISPL, CW 90PV075	90-R-075-HS-1-NN-80-S-3-S1-D-03-GBA-35-35-20	SERIES 90	S90-075PV
83021831	PUMP-VAR DISPL, CW 90PV055	90-R-055-HS-1-NN-60-S-3-S1-C-03-GBA-35-35-20	SERIES 90	S90-055PV
83021832	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-1-NN-60-S-3-S1-C-03-GBA-35-35-20	SERIES 90	S90-055PV
83021841	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-1-NN-60-L-3-S1-C-03-GBA-35-35-20	SERIES 90	S90-055PV
83021847	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-CD-80-P-3-F1-F-00-GBA-42-42-24	SERIES 90	S90-100PV
83021848	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-1-BC-80-P-3-F1-H-00-GBA-42-42-24	SERIES 90	S90-130PV
83021849	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-BC-80-P-3-S1-F-00-GBA-42-42-24	SERIES 90	S90-100PV
83021852	PUMP-VAR DISPL, CCW 90PV055	90-L-055-MA-1-NN-80-R-3-S1-C-03-GBA-35-35-24-N180	SERIES 90	S90-055PV
83021854	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-L7-B1-W-B-G0-ACA-050-AA-E6-D4-00	SERIES 51	S51-250MV
83021855	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-CD-80-L-4-F1-F-06-GBA-38-38-24	SERIES 90	S90-130PV
83021856	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-CD-80-L-4-F1-F-06-GBA-35-35-24	SERIES 90	S90-130PV
83021863	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E2-AA-N-B-TB-DN-HN-N-A-10-NN-024-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83021864	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E2-AA-N-B-TB-DN-HN-N-A-10-NN-045-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83021865	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E2-AA-N-B-TB-DN-JN-N-A-15-NN-040-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83021866	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E2-AA-N-B-TB-DN-JN-N-N-NN-050-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83021871	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-1-NN-60-L-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83021877	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E1-AA-N-B-TB-VN-EN-N-N-NN-034-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83021878	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A5-C2-N-F6-H-F1-H6-L-45-L-45-C-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83021879	MOTOR-VAR-DISPL H1B080	H1-B-080-A-TA-DA-N-B-TB-VS-AS-5-A-05-NN-033-Z-16-NNN	H1-HP MOTORS	H1-080MB1
83021880	MOTOR-VAR-DISPL H1B080	H1-B-080-A-TA-DA-N-B-TB-VN-AN-N-N-NN-024-Z-21-NNN	H1-HP MOTORS	H1-080MB1
83021881	MOTOR-VAR-DISPL H1B160	H1-B-160-A-TA-DA-N-B-TB-VN-DN-N-N-NN-032-Z-20-NNN	H1-HP MOTORS	H1-160MB1
83021883	MOTOR-VAR-DISPL H1B160	H1-B-160-A-TA-DA-N-B-TB-VN-DN-N-A-20-NN-032-Z-20-NNN	H1-HP MOTORS	H1-160MB1
83021892	PUMP-VAR-DISPL CW 90PV130	90R130-KA-1-CD-80-L-3-F1-F-03-EBA-35-35-20	SERIES 90	S90-130PV
83021894	PUMP-TANDEM, VAR DISPL MPT035D	MPT-035-D-A-R-A-F-NN-B-A-A-A-BEE-DR-A-FF-B-C-A-A-BEE-DL-A-FF-A-NNN-***	M35/44	035PT
83021895	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A5-C2-B-E5-F-G1-H5-L-35-L-35-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83021896	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A5-C2-B-E5-F-G5-NN-L-35-L-35-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83021897	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-7-N-0-S1-W-00-NNN-00-00-F3	SERIES 90	S90-075MF
83021898	PUMP-VAR-DISPL CW 90PV180	90R180-KA-1-NN-80-T-C-F1-H-03-FAC-38-14-24	SERIES 90	S90-180PV

83021899	MOTOR-VAR-DISPL H1MB060	H1-B-060-A-M2-CA-N-C-RB-DS-GS-S-A-10-NN-040-N-00-NNN	H1-HP MOTORS	H1-060MB1
83021900	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KN-1-NN-80-R-4-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83021901	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KN-1-NN-80-R-3-S1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
83021902	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KN-1-NN-80-R-4-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
83021903	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KN-1-BC-80-R-4-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83021904	MOTOR-VAR DISPL MMV046C	MMV-046-C-A-E-F-D-AV-VNC-***	M46	M46-046MV
83021907	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-D2-MA-N-B-PB-CS-LS-S-N-NN-NN-068-N-34-NNN	H1-HP MOTORS	H1-160MB1
83021911	MOTOR-VARIABLE DISPL SAE_L	L-V-25CS-A-RNF-F01-T-N-X-DF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83021913	PUMP-VAR-DISPL CW 90PV180	90R180-KA-1-NN-80-T-C-F1-J-03-FAC-35-35-24	SERIES 90	S90-180PV
83021916	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-AB-80-S-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83021923	PUMP-VAR DISPL, CW 90PV100	90-R-100-KT-5-BC-60-S-3-T2-E-00-GBA-42-42-20	SERIES 90	S90-100PV
83021934	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A5-C2-N-D6-H-G9-H2-L-42-L-42-M-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83021939	PUMP-VAR DISPL, CW H1PV250	H1-P-250-R-A-A5-C3-B-D8-C-G2-NN-L-30-L-30-R-P-18-PN-NNN-NNN	H1-HP PUMPS	H1-210PV/250PV
83021941	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-HZ-B1-A-N-G0-NNN-065-AA-NN-03-00	SERIES 51	S51-160MV
83021942	PUMP-VAR DISPL, CW 90PV075	90-R-075-KN-1-NN-80-R-4-T1-D-03-GBA-21-21-24	SERIES 90	S90-075PV
83021946	PUMP-VAR-DISPL CW 90PV100	90R100-HS-1-CD-80-R-3-C7-F-06-GBA-32-32-24	SERIES 90	S90-100PV
83021947	PUMP-VAR-DISPL CCW 90PV100	90L100-HS-1-CD-80-R-3-F1-F-06-GBA-35-35-24	SERIES 90	S90-100PV
83021948	PUMP-VAR-DISPL CCW 90PV075	90L075-HS-1-CD-80-R-3-S1-E-06-GBA-35-35-24	SERIES 90	S90-075PV
83021951	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-NN-80-S-3-C8-F-03-GBA-35-35-24	SERIES 90	S90-130PV
83021955	PUMP-VAR-DISPL CW 90PV100	90R100-MS-1-CD-80-S-3-C7-E-03-GBA-35-35-30	SERIES 90	S90-100PV
83021956	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-P1-D1-N-B-TA-DS-JS-S-A-15-NN-040-Z-24-NNN	H1-HP MOTORS	H1-110MB1
83021958	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-L3-B1-W-B-G5-ACA-055-AA-G3-D4-00	SERIES 51	S51-160MV
83021959	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A4-C3-B-D3-H-G1-NN-L-42-L-42-C-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83021960	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A4-C3-B-D3-H-G1-H3-L-42-L-42-M-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83021961	PUMP-TANDEM, VAR DISPL MPT044D	MPT-044-D-A-R-R-J-AA-B-A-A-A-BHH-DR-A-FF-B-C-A-A-BHH-DR-A-FF-C-NNN-*	M35/44	O44PT
83021973	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-NN-80-S-C-C8-J-03-NNN-26-26-24	SERIES 90	S90-180PV
83021979	PUMP-VAR-DISPL CCW 90PV180	90L180-KP-1-DE-80-T-C-C8-H-03-FAC-36-36-24	SERIES 90	S90-180PV
83021985	PUMP-VAR-DISPL CCW H1PV165	H1-P-165-L-C-D4-C2-N-D4-G-G3-NN-L-42-L-42-L-C-32-PN-NNN-G14	H1-HP PUMPS	H1-147PV/165PV
83021992	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-NN-80-S-4-C6-E-03-GBA-42-42-24	SERIES 90	S90-075PV
83021994	PUMP-VAR DISPL CCW H1P060L	H1-P-060-L-A-A5-C1-N-D6-H-F1-H2-L-42-L-42-C-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83021996	PUMP-VAR-DISPL CW 90PV130	90R130-KN-5-NN-80-L-4-C8-H-03-GBA-30-30-28	SERIES 90	S90-130PV
83022006	PUMP-VAR-DISPL CCW 90PV100	90L100-MA-1-NN-60-P-4-C7-D-03-GBA-26-26-24	SERIES 90	S90-100PV
83022007	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-DA-M4-R-J-N1-ANB-075-AA-G3-C2-30	SERIES 51	S51-250MV
83022010	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-D2-MA-N-B-PA-DN-JN-N-A-15-NN-040-N-26-NNN	H1-HP MOTORS	H1-110MB1
83022013	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-C9-C3-C-D8-L-G2-H4-S-45-S-45-A-P-30-P2-C02-D6F	H1-HP PUMPS	H1-115PV/130PV
83022014	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-C9-C3-C-D8-L-G2-H4-S-45-S-45-L-P-30-P2-C02-D6F	H1-HP PUMPS	H1-115PV/130PV

83022017	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-K2-K2-N-B-RA-DS-KS-S-A-15-NN-022-N-24-NNN	H1-HP MOTORS	H1-110MB1
83022021	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A2-C1-N-F5-H-G9-H6-L-42-L-42-F-P-22-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83022024	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-S1-A-B1-B3-N-N-U3-NNN-032-AA-NN-00-00	SERIES 51	S51-080MV-1
83022026	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-AB-80-P-3-S1-D-00-GBA-26-26-24	SERIES 90	S90-055PV
83022027	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-D2-MA-N-B-PA-DN-LN-N-A-20-NN-080-N-26-NNN	H1-HP MOTORS	H1-160MB1
83022031	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-CD-60-P-3-F1-E-03-GBA-38-38-24	SERIES 90	S90-100PV
83022033	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-1-DE-80-L-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-130PV
83022034	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-CD-60-S-4-C7-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83022040	PUMP-VAR-DISPL CW 90PV180	90R180-KA-1-BC-80-T-C-C8-H-04-FAC-42-42-24	SERIES 90	S90-180PV
83022046	PUMP-VAR-DISPL CW 90PV100	90R100-MA-1-BB-80-S-3-S1-E-03-GBA-35-35-30	SERIES 90	S90-100PV
83022047	PUMP-VAR-DISPL CW 90PV042	90R042-HF-5-BC-80-R-3-C3-C-04-GBA-35-35-24	SERIES 90	S90-042PV
83022049	PUMP-VAR DISPL, CCW 90PV055	90-L-055-MA-1-CD-60-R-3-T1-C-03-GBA-35-35-24-N180	SERIES 90	S90-055PV
83022051	PUMP-VAR DISPL, CCW 90PV055	90-L-055-MA-1-NN-60-R-3-S1-C-03-GBA-35-35-24-N180	SERIES 90	S90-055PV
83022052	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HF-1-BC-80-R-4-S1-C-03-GBA-20-20-24	SERIES 90	S90-055PV
83022053	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HF-1-NN-80-R-4-S1-C-03-GBA-20-20-24	SERIES 90	S90-055PV
83022054	MOTOR-VARIABLE CARTRIDGE K	K-C-38CS-A-YNF-F08-S-N-N-CF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83022059	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-N1-NN-N-N-U1-NNN-074-AA-F3-00-00	SERIES 51	S51-110MV-1
83022064	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-M2-CA-N-A-RB-VN-EN-N-A-15-NN-000-N-00-NNN	H1-HP MOTORS	H1-110MB1
83022068	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E1-AA-N-B-TB-VN-DN-N-A-10-NN-036-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83022069	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A9-C1-B-D8-H-G1-H2-L-40-L-40-N-E-26-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83022070	PUMP-VAR-DISPL CW 90PV042	90R042-HF-5-BC-80-R-3-C3-C-04-GBA-35-35-30	SERIES 90	S90-042PV
83022074	MOTOR-VAR-DISPL H1B060	H1-B-060-A-TA-DA-N-B-TB-VN-AN-N-N-NN-NN-020-Z-16-NNN	H1-HP MOTORS	H1-060MB1
83022075	PUMP-VAR-DISPL CW 90PV130	90R130-KT-1-BC-80-R-3-F1-H-03-GBA-42-42-24	SERIES 90	S90-130PV
83022077	PUMP-VAR-DISPL CCW H1PV115	H1-P-115-L-B-A3-C2-N-D8-G-G3-H6-L-38-L-38-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83022078	MOTOR-VARIABLE DISPL SAE_K	K-V-38CS-A-YNF-F08-S-N-N-CF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83022090	PUMP-VAR-DISPL CW 90PV100	90R100-MS-5-BB-80-P-3-F1-F-C5-GBA-42-42-24	SERIES 90	S90-100PV
83022093	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-D2-M2-N-A-PA-CS-HS-S-A-05-NN-016-N-28-NNN	H1-HP MOTORS	H1-080MB1
83022094	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-T2-D2-N-A-TA-CN-JN-N-A-10-NN-033-Z-28-NNN	H1-HP MOTORS	H1-080MB1
83022096	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-K-T-B-B-BA-A-A-BDD-CE-A-GG-B-NNN-***	M46	M46-046PV
83022105	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-AB-80-S-C-C8-J-03-EFI-42-42-24	SERIES 90	S90-180PV
83022107	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-1-AB-80-R-3-F1-H-00-GBA-45-45-24	SERIES 90	S90-130PV
83022108	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-P2-D2-N-A-TA-DS-KS-S-A-10-NN-022-Z-24-NNN	H1-HP MOTORS	H1-110MB1
83022115	PUMP-VAR-DISPL CW 90PV042	90R042-FC-1-BC-80-L-7-C3-C-B1-GBA-42-16-24	SERIES 90	S90-042PV
83022116	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-1-CD-80-R-3-F1-H-00-GBA-45-45-24	SERIES 90	S90-130PV
83022118	PUMP-VAR DISPL, CW 90PV100	90-R-100-DD-1-NN-80-P-4-S1-E-GB-GBA-35-35-24	SERIES 90	S90-100PV
83022119	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HF-1-AB-80-P-3-S1-F-03-GBA-35-35-24	SERIES 90	S90-100PV

83022123	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-AB-80-P-3-F1-E-00-GBA-20-20-24	SERIES 90	S90-100PV
83022124	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-C2-C2-C-D6-J-G1-H2-L-40-L-40-B-L-24-P2-NNN-D4F	H1-MP PUMPS	H1-045PV/053PV
83022125	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-F2NN-72-J-3-G-3-F-N-N-34-34-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83022136	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E2-AA-N-B-TB-DN-JN-N-A-05-NN-032-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83022139	PUMP-VAR-DISPL CW 90PV075	90R075-DD-1-AB-80-P-3-C6-E-G4-EEG-38-38-28	SERIES 90	S90-075PV
83022140	PUMP-VAR-DISPL CW 90PV075	90R075-KP-1-AB-80-P-3-C6-E-03-EEG-38-38-28	SERIES 90	S90-075PV
83022141	PUMP-VAR-DISPL CW 90PV180	90R180-KP-1-AB-80-T-M-C8-H-03-EEB-38-38-28	SERIES 90	S90-180PV
83022142	PUMP-TANDEM, VAR DISPL MPT035D	MPT-035-D-A-W-S-G-AA-C-A-A-A-BJJ-DL-A-FF-C-C-A-A-BJJ-DR-A-FF-D-NNN-***	M35/44	035PT
83022144	PUMP-VAR-DISPL CCW H1PV115	H1-P-115-L-B-A3-C2-N-D8-G-G3-H3-L-38-L-38-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83022146	PUMP-VAR-DISPL CW 90PV075	90R075-MA-1-AB-60-S-3-C6-D-C5-GBA-35-35-24	SERIES 90	S90-075PV
83022149	PUMP-VAR-DISPL CCW 90PV130	90L130-MA-1-NN-80-L-3-F1-F-03-GBA-32-32-24	SERIES 90	S90-130PV
83022150	PUMP-VAR-DISPL CCW 90PV130	90L130-KT-1-BC-80-P-4-F1-H-00-GBA-42-42-24	SERIES 90	S90-130PV
83022154	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-C2-C2-C-D3-K-G1-NN-L-40-L-40-M-M-24-P2-NNN-D4F	H1-HP PUMPS	H1-089PV/100PV
83022155	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-5-BC-80-S-3-C8-J-05-NNN-42-42-24	SERIES 90	S90-250PV
83022158	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-E1-A5-A-N-G0-NNN-065-AA-NN-03-00	SERIES 51	S51-160MV
83022162	PUMP-VAR DISPL, CW 90PV075	90-R-075-HS-1-CD-80-P-3-C7-E-03-GBA-40-40-24	SERIES 90	S90-075PV
83022166	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-HZ-B1-B-H-C2-NNN-060-AA-NN-10-00	SERIES 51	S51-160MV
83022177	PUMP-VAR DISPL, CCW 90PV055	90-L-055-SA-2-BB-60-R-3-C6-D-33-PEA-40-40-30	SERIES 90	S90-055PV
83022184	PUMP-VAR-DISPL CW DDC20	DDC-20-A-R-RB-LSA-NN-A-N-3-AC-ACA0-D-07-30N-30N-NNN-NNN	DDC20/LDU20	OSK-020PV - DO NOT USE
83022186	PUMP-VAR-DISPL CCW DDC20	DDC-20-A-L-LB-RSA-NN-A-N-3-AC-ACA0-D-07-30N-30N-NNN-NNN	DDC20/LDU20	OSK-020PV - DO NOT USE
83022188	PUMP-TANDEM, VAR DISPL CCW H1T045L	H1-T-045-L-A-N-B5-C3-D-D1-F-F2-H3-35-35-35-35-N-P-24-P1-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83022195	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A2-C2-N-F4-K-G9-H6-L-40-L-40-M-M-24-P4-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83022210	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A3-C2-N-E7-F-G1-H2-33-33-33-33-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83022212	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-C2-C2-C-D6-J-G1-H3-L-40-L-40-B-L-24-P2-NNN-D4F	H1-MP PUMPS	H1-045PV/053PV
83022216	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-HE-HE-N-A-TB-VN-AN-N-A-10-NN-050-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83022223	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-A-V-C-B-AA-B-B-A-A-BGG-CG-A-HH-B-D-A-A-BGG-CG-A-HH-A-NNN	M46	M46-046PT
83022226	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-HE-HE-N-B-TB-VN-DN-N-A-20-NN-080-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83022227	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-BC-60-L-3-S1-E-03-GBA-32-32-24	SERIES 90	S90-075PV
83022229	PUMP-VAR-DISPL CCW 90PV100	90L100-HS-1-BC-80-S-3-S1-E-03-GBA-35-35-28	SERIES 90	S90-100PV
83022233	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-M1-CA-N-A-RB-VS-ES-S-A-20-NN-080-N-00-NNN	H1-HP MOTORS	H1-160MB1
83022234	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A3-C2-N-D3-H-G1-NN-L-42-L-42-D-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83022236	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E2-AA-N-B-TA-VN-EN-N-A-15-NN-055-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83022243	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-L1-BA-N-B-PB-VS-ES-S-A-20-NN-080-N-00-NNN	H1-HP MOTORS	H1-160MB1
83022251	PUMP-VAR-DISPL CCW H1PV147	H1-P-147-L-C-A3-C2-N-D8-G-G3-NN-L-42-L-42-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83022252	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-NN-80-L-4-F1-H-03-EBA-29-29-24	SERIES 90	S90-130PV
83022253	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-L1-BA-N-B-PA-VN-EN-N-A-20-NN-080-N-00-NNN	H1-HP MOTORS	H1-160MB1

83022256	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-BB-80-L-4-T6-C-03-GBA-32-32-24	SERIES 90	S90-075PV
83022260	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-BB-80-L-4-T4-F-03-GBA-35-35-24	SERIES 90	S90-130PV
83022261	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A3-C2-N-F4-K-G9-H6-L-40-L-40-M-M-24-P4-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83022275	PUMP-VAR-DISPL CW 90PV180	90R180-KN-1-BC-80-T-M-C8-J-03-FAC-35-35-24	SERIES 90	S90-180PV
83022276	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-T1-D1-N-A-TB-VS-ES-P-A-20-NN-058-Z-27-NNN	H1-HP MOTORS	H1-160MB1
83022280	PUMP-VAR-DISPL CW 90PV130	90R130-KT-1-BB-80-R-3-F1-H-03-GBA-35-35-24	SERIES 90	S90-130PV
83022281	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MA-1-BC-60-L-3-C7-E-03-GBA-32-32-24	SERIES 90	S90-100PV
83022282	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A8-C2-C-D8-H-G1-NN-L-40-L-40-C-P-34-P1-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83022284	PUMP-VAR-DISPL CCW 90PV180	90L180-MA-5-NN-80-T-C-C8-J-C5-FAC-32-32-24	SERIES 90	S90-180PV
83022291	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-1-BC-80-S-3-S1-C-03-FAD-35-35-24	SERIES 90	S90-055PV
83022302	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HS-1-CD-80-R-3-C7-E-03-GBA-29-29-24	SERIES 90	S90-100PV
83022303	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-T2-DA-N-A-TB-DN-KN-N-A-30-NN-080-Z-21-NNN	H1-HP MOTORS	H1-160MB1
83022304	MOTOR- VARIABLE CARTRIDGE L	L-C-30DN-E-RNF-F06-S-N-N-AF-F15-NNN-NNN	LV / KV MOTORS	L/K-MV
83022305	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KT-1-CD-80-S-3-S1-C-02-GBA-42-42-24	SERIES 90	S90-075PV
83022320	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A5-C3-B-D6-G-G3-H3-L-42-L-42-L-L-28-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83022324	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-CD-80-S-3-C8-H-03-GBA-35-35-26	SERIES 90	S90-130PV
83022325	PUMP-VAR-DISPL CCW 90PV180	90L180-HF-5-BC-80-S-C-C8-H-03-NNN-32-32-24	SERIES 90	S90-180PV
83022326	PUMP-VAR-DISPL CW 90PV130	90R130-SA-2-NN-80-S-3-C8-F-33-PEA-42-42-26	SERIES 90	S90-130PV
83022329	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A7-C2-C-D8-J-G5-NN-L-38-L-38-B-P-24-P2-NNN-D3F	H1-MP PUMPS	H1-045PV/053PV
83022332	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-A-V-C-B-AA-B-B-A-A-BGG-CG-A-HH-B-D-A-A-BGG-CG-A-HH-B-NNN	M46	M46-046PT
83022333	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-E2-AA-N-B-TB-DS-LS-S-A-20-NN-070-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83022354	PUMP-VAR-DISPL CCW H1PV115	H1-P-115-L-B-A5-C2-B-D8-G-G3-H4-L-35-L-35-A-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83022356	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-N2-NN-N-N-A0-NNN-168-AA-F3-00-00	SERIES 51	S51-250MV
83022363	PUMP-VAR-DISPL CW 90PV250	90R250-KN-5-EF-80-S-3-C8-K-06-NNN-35-35-30	SERIES 90	S90-250PV
83022364	PUMP-VAR-DISPL CW 90PV250	90R250-KN-5-BC-80-S-3-F1-K-06-NNN-35-35-30	SERIES 90	S90-250PV
83022366	PUMP-VAR-DISPL CW 90PV100	90R100-KA-2-NN-80-S-4-C7-E-03-GBA-32-32-24	SERIES 90	S90-100PV
83022369	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-8-N-0-K3-W-00-EFA-00-00-B3	SERIES 90	S90-100MF
83022371	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-DE-80-T-C-C8-J-03-NNN-42-42-30	SERIES 90	S90-180PV
83022381	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-T2-D2-N-B-TB-DN-JN-N-A-10-NN-050-Z-20-NNN	H1-HP MOTORS	H1-080MB1
83022387	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-HE-HE-N-B-TB-CN-JN-N-N-NN-040-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83022391	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-T2-C2-L-N-G0-NNN-075-AA-G0-00-C1	SERIES 51	S51-160MV
83022393	MOTOR-VAR-DISPL 51MV110	51V110-R-F1-N-L1-B1-W-B-G0-ACA-051-AA-F0-D4-00	SERIES 51	S51-110MV
83022407	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-N-L1-B1-W-B-C0-NNN-120-AA-H0-D4-00	SERIES 51	S51-250MV
83022411	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-C2-C2-C-D8-J-G5-NN-L-38-L-38-B-P-24-P2-NNN-D4F	H1-MP PUMPS	H1-045PV/053PV
83022412	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A2-C1-N-F5-H-G9-H6-L-40-L-40-M-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83022413	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A2-C1-N-F5-H-G9-H6-L-40-L-40-M-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV

83022418	PUMP-VAR-DISPL CCW 90PV180	90L180-KP-1-CD-80-T-C-C8-H-03-FAC-42-42-24	SERIES 90	S90-180PV
83022430	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-1-NN-80-L-3-F1-F-03-GBA-35-35-20	SERIES 90	S90-130PV
83022433	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-E2C8-03-B-2-C-3-F-N-B-34-34-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83022434	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-E2C8-03-B-2-C-3-F-N-N-34-34-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83022436	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A5-C2-N-D8-H-G1-H5-L-35-L-35-C-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83022448	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-D2-MA-N-B-PB-CS-KS-S-N-NN-NN-068-N-24-NNN	H1-HP MOTORS	H1-160MB1
83022449	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A5-C3-N-D3-G-G3-NN-L-35-L-35-L-M-28-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83022450	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A5-C3-N-D3-G-G3-NN-L-35-L-35-L-M-28-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83022452	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-BB-80-R-3-C7-D-03-GBA-26-26-24	SERIES 90	S90-075PV
83022453	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-E2-AA-N-B-TA-VN-DN-N-N-NN-NN-040-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83022460	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-1-BC-80-S-4-S1-E-00-GBA-23-23-24	SERIES 90	S90-075PV
83022464	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A2-C2-N-D8-H-G1-H2-L-40-L-40-N-E-26-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83022465	PUMP-VAR-DISPL CW 90PV180	90R180-KA-2-BC-80-T-M-F1-J-00-NNN-38-38-24	SERIES 90	S90-180PV
83022466	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-CD-80-L-3-C8-H-00-GBA-38-38-24	SERIES 90	S90-130PV
83022467	PUMP-VAR-DISPL CW 90PV100	90R100-KP-5-CD-80-L-3-S1-F-00-GBA-32-32-24	SERIES 90	S90-100PV
83022474	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A3-C2-N-D3-H-G1-H5-L-35-L-35-C-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83022475	PUMP-VAR-DISPL CW 90PV075	90R075-CB-5-NN-80-P-4-C7-E-00-GBA-42-42-24	SERIES 90	S90-075PV
83022484	PUMP-VAR DISPL MPV035D	MPV-035-D-B-A-G-R-A-C-NN-A-A-BCC-DL-A-FF-B-NNN-***	M35/44	035PV
83022485	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-B7-C3-C-D6-K-G9-H3-K-48-K-48-C-L-28-P2-NNN-D5F	H1-HP PUMPS	H1-069PV/078PV
83022494	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-L2-BA-N-B-PA-DS-KS-S-A-20-NN-032-N-00-NNN	H1-HP MOTORS	H1-160MB1
83022496	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-CD-60-P-3-C6-D-04-GBA-42-42-20	SERIES 90	S90-075PV
83022497	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-AB-60-P-3-S1-D-04-GBA-42-42-20	SERIES 90	S90-075PV
83022498	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-HZ-B1-C-H-C2-ACA-052-AA-NN-15-00	SERIES 51	S51-250MV
83022499	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E1-AA-N-B-TA-CN-JN-N-A-10-NN-053-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83022500	MOTOR-VAR-DISPL 51MV110	51V110-R-F1-N-HZ-B1-B-H-G5-NNN-036-AA-E4-05-00	SERIES 51	S51-110MV
83022504	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A5-C1-N-F5-H-G1-H6-L-42-L-42-F-P-18-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83022508	PUMP-VAR-DISPL CW 90PV130	90R130-MA-5-NN-80-S-3-C8-H-C5-GBA-26-26-30	SERIES 90	S90-130PV
83022510	MOTOR-FIX DISPL MMF035D	MMF-035-D-A-A-E-A-U-NNN-***	M35/44	035MF
83022516	PUMP-VAR-DISPL CCW H1PV165	H1-P-165-L-C-A4-C2-N-D3-G-G3-H6-L-42-L-42-L-M-30-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83022520	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-T1-D1-N-A-TA-DN-KN-N-A-15-NN-050-Z-24-NNN	H1-HP MOTORS	H1-110MB1
83022521	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-NN-60-P-3-C7-E-03-GBA-20-20-18	SERIES 90	S90-075PV
83022523	PUMP-VAR DISPL MPV046C	MPV-046-C-B-A-H-S-B-AA-A-A-BDD-AW-D-YB-A-NNN-***	M46	M46-046PV
83022530	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-EG-80-T-C-C8-H-03-NNN-42-42-24	SERIES 90	S90-180PV
83022531	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-NN-80-T-C-C8-H-03-NNN-42-42-24	SERIES 90	S90-180PV
83022539	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A4-C2-N-E6-F-G5-H2-L-23-L-23-B-L-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83022540	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A4-C2-N-D1-F-G6-H5-35-35-35-35-N-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT

83022541	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-BC-80-P-3-C6-E-02-GBA-42-42-24	SERIES 90	S90-075PV
83022542	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-5-NN-60-L-3-C6-D-00-GBA-30-30-24	SERIES 90	S90-055PV
83022543	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-CD-80-L-3-C8-H-09-GBA-38-35-24	SERIES 90	S90-130PV
83022544	PUMP-VAR-DISPL CW 90PV075	90R075-KP-5-NN-80-L-3-S1-D-00-GBA-30-30-24	SERIES 90	S90-075PV
83022546	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-CD-80-L-3-C7-E-03-GBA-43-43-30	SERIES 90	S90-100PV
83022547	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-B-S-B-J-BA-A-A-BJJ-CD-A-GG-3-NNN-***	M46	M46-046PV
83022553	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-L1-BA-N-B-PB-VS-AS-S-A-10-NN-028-N-00-NNN	H1-HP MOTORS	H1-080MB1
83022554	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-A-A2-C1-N-D8-H-G1-H3-K-42-K-42-D-P-22-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83022555	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-HE-HE-N-B-TB-VN-AN-N-A-10-NN-015-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83022556	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-HE-HE-N-B-TB-VS-AS-S-A-10-NN-015-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83022557	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-8-N-0-S1-W-00-EBA-00-00-F0	SERIES 90	S90-055MF
83022558	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-8-N-0-S1-W-00-EEA-00-00-E6	SERIES 90	S90-055MF
83022559	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-7-N-0-K1-W-00-NNN-00-00-F0	SERIES 90	S90-055MF
83022560	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-8-N-0-T1-W-00-NNN-00-00-E6	SERIES 90	S90-055MF
83022561	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-8-N-0-C6-W-00-NNN-00-00-E4	SERIES 90	S90-055MF
83022562	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-8-N-0-S1-W-00-EHD-00-00-F0	SERIES 90	S90-055MF
83022563	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-8-N-0-K1-W-00-EEA-00-00-F0	SERIES 90	S90-055MF
83022564	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-8-N-0-K1-W-00-EBA-00-00-F0	SERIES 90	S90-055MF
83022565	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-8-N-0-S1-W-00-EEA-00-00-F0	SERIES 90	S90-055MF
83022566	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-8-N-0-K1-W-00-EBA-00-00-F3	SERIES 90	S90-055MF
83022567	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-7-N-0-K1-W-00-EAA-00-00-F0	SERIES 90	S90-055MF
83022568	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-8-N-0-K1-W-00-EAA-00-00-F0	SERIES 90	S90-055MF
83022569	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-HF-HF-N-B-TA-VN-EN-N-A-20-NN-090-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83022570	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-8-N-0-T1-W-00-EEA-00-00-F0	SERIES 90	S90-055MF
83022571	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-7-N-0-C6-W-00-EBA-00-00-G0	SERIES 90	S90-055MF
83022572	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-8-N-0-T1-W-00-EBA-00-00-F0	SERIES 90	S90-055MF
83022573	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-8-N-0-S1-W-00-EEA-00-00-E6	SERIES 90	S90-075MF
83022574	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-8-N-0-K2-W-00-NNN-00-00-F3	SERIES 90	S90-075MF
83022575	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-8-N-0-S1-W-00-EBA-00-00-E6	SERIES 90	S90-075MF
83022577	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-7-N-0-S1-W-00-NNN-00-00-E4	SERIES 90	S90-075MF
83022578	PUMP-VAR-DISPL CW 90PV075	90R075-DD-5-NN-80-L-4-S1-D-GB-GBA-42-42-24	SERIES 90	S90-075PV
83022581	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-BC-80-S-C-C8-J-00-NNN-35-35-30	SERIES 90	S90-180PV
83022596	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A5-C2-B-D6-H-G9-H2-L-42-L-42-C-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83022597	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A5-C2-N-D6-G-G2-H3-L-33-L-33-L-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83022598	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-E2-AA-N-B-TB-VN-DN-N-A-20-NN-070-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83022602	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HK-1-CD-80-R-4-S1-C-03-GBA-20-20-24	SERIES 90	S90-055PV

83022603	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-8-N-0-K2-W-00-EEA-00-00-F0	SERIES 90	S90-075MF
83022604	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-8-N-0-C6-W-00-NNN-00-00-E4	SERIES 90	S90-075MF
83022605	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-7-N-0-S1-W-00-EEA-00-00-E4	SERIES 90	S90-075MF
83022606	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-7-N-0-S1-W-00-EBA-00-00-E6	SERIES 90	S90-075MF
83022607	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-8-N-0-S1-W-00-EBA-00-00-F3	SERIES 90	S90-075MF
83022608	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-8-N-0-K2-W-00-EFA-00-00-E6	SERIES 90	S90-075MF
83022609	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-7-N-0-S1-W-00-EEA-00-00-E6	SERIES 90	S90-075MF
83022610	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-8-N-0-K2-W-00-NNN-00-00-E6	SERIES 90	S90-075MF
83022611	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-8-N-0-K2-W-00-EAA-00-00-F3	SERIES 90	S90-075MF
83022612	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-8-N-0-K2-W-00-EBA-00-00-F0	SERIES 90	S90-075MF
83022613	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-8-N-0-F1-W-00-EEA-00-00-F0	SERIES 90	S90-100MF
83022614	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-8-N-0-S1-W-00-NNN-00-00-F0	SERIES 90	S90-100MF
83022615	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-7-N-0-F1-W-00-NNN-00-00-F3	SERIES 90	S90-100MF
83022616	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-8-N-0-F1-W-00-EBA-00-00-E6	SERIES 90	S90-100MF
83022617	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-8-N-0-S1-W-00-EBA-00-00-G0	SERIES 90	S90-100MF
83022618	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-7-N-0-S1-W-00-NNN-00-00-F0	SERIES 90	S90-100MF
83022619	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-8-N-0-S1-W-00-EEA-00-00-F0	SERIES 90	S90-100MF
83022620	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-7-N-0-S1-W-00-NNN-00-00-E6	SERIES 90	S90-100MF
83022621	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-8-N-0-S1-W-00-EBA-00-00-F3	SERIES 90	S90-100MF
83022622	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-7-N-0-S1-W-00-EBA-00-00-E6	SERIES 90	S90-100MF
83022623	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-8-N-0-S1-W-00-EEA-00-00-G0	SERIES 90	S90-100MF
83022624	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-8-N-0-K3-W-00-NNN-00-00-E6	SERIES 90	S90-100MF
83022625	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-7-N-0-S1-W-00-EBB-00-00-F0	SERIES 90	S90-100MF
83022626	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-8-N-0-K3-W-00-EBA-00-00-F0	SERIES 90	S90-100MF
83022627	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-7-N-0-C7-W-00-EEA-00-00-F0	SERIES 90	S90-100MF
83022628	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-8-N-0-S1-W-00-EBA-00-00-E6	SERIES 90	S90-100MF
83022629	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-7-N-0-K1-N-00-EEA-00-00-00	SERIES 90	S90-055MF
83022630	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-7-N-0-S1-N-00-NNN-00-00-00	SERIES 90	S90-055MF
83022631	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-7-N-0-C6-N-00-NNN-00-00-00	SERIES 90	S90-055MF
83022633	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-D-N-0-S1-N-00-EEA-00-00-00	SERIES 90	S90-075MF
83022635	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-7-N-0-K2-N-00-EBA-00-00-00	SERIES 90	S90-075MF
83022636	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-8-N-0-K2-N-00-NNN-00-00-00	SERIES 90	S90-075MF
83022637	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-N-T1-R5-L-N-G0-ACA-087-AA-G0-00-B9	SERIES 51	S51-250MV
83022642	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-EF-80-T-3-C8-K-09-NNN-32-32-24	SERIES 90	S90-250PV
83022643	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-AB-80-T-3-F1-K-09-NNN-32-32-24	SERIES 90	S90-250PV
83022644	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-8-N-0-K3-N-00-NNN-00-00-00	SERIES 90	S90-100MF

83022645	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-8-N-0-F1-N-00-EBA-00-00-00	SERIES 90	S90-100MF
83022646	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-8-N-0-S1-N-00-EEA-00-00-00	SERIES 90	S90-100MF
83022647	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-7-N-0-F1-N-00-NNN-00-00-00	SERIES 90	S90-100MF
83022648	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-7-N-0-S1-N-00-NNN-00-00-00	SERIES 90	S90-100MF
83022651	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KT-1-CD-80-S-3-S1-D-02-GBA-42-42-24	SERIES 90	S90-075PV
83022653	PUMP-VAR-DISPL CW 90PV130	90R130-MA-5-DE-80-L-4-C8-H-C7-GBA-42-42-24	SERIES 90	S90-130PV
83022654	PUMP-VAR-DISPL CW 90PV130	90R130-MA-5-CD-80-L-4-F1-H-C7-GBA-42-42-24	SERIES 90	S90-130PV
83022661	PUMP-VAR DISPL, CW 90PV075	90-R-075-DD-1-AB-80-S-4-S1-D-Z1-GBA-32-32-24	SERIES 90	S90-075PV
83022662	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KT-1-BB-80-S-3-S1-D-02-GBA-42-42-24	SERIES 90	S90-075PV
83022663	MOTOR-FIX DISPL MMF035D	MMF-035-D-A-A-G-C-G-NNR-***	M35/44	035MF
83022665	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A3-C1-B-F4-H-G9-H6-L-42-L-42-C-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83022666	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-L2-BA-N-B-PB-CS-JS-S-A-10-NN-025-N-00-NNN	H1-HP MOTORS	H1-080MB1
83022667	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-C-ANB5-03-D-N-F-2-H-N-N-21-21-B-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83022668	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-HE-HE-N-B-TA-CN-JN-N-N-NN-NN-054-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83022669	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-BB-60-D-3-C7-L-03-GBA-42-42-18	SERIES 90	S90-075PV
83022670	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-G3AN-52-P-3-G-2-H-1-A-28-28-B-4-4-NNN-NNN	SERIES 42	S42-041PV/051PV
83022672	PUMP-VAR DISPL, CW 90PV075	90-R-075-DD-1-NN-80-S-4-S1-C-Z1-GBA-32-32-24	SERIES 90	S90-075PV
83022673	MOTOR-VARIABLE DISPL SAE_K	K-V-38CN-E-R2F-F08-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83022674	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-1-CD-80-D-4-C8-L-00-NNN-42-16-30	SERIES 90	S90-250PV
83022675	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A5-C2-N-F4-H-G1-H6-L-41-L-41-C-M-22-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83022681	PUMP-VAR-DISPL CW 90PV130	90R130-MA-1-NN-80-L-4-F1-F-03-GBA-36-26-20	SERIES 90	S90-130PV
83022683	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-HE-HE-N-B-TB-CN-JN-N-A-10-NN-016-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83022691	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E1-AA-N-A-TA-CS-AS-S-A-05-NN-018-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83022694	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-AB-60-P-4-S1-E-03-GBA-32-32-24	SERIES 90	S90-100PV
83022696	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E2-AA-N-B-TB-VS-AS-S-A-10-NN-054-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83022697	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A5-C2-N-D6-F-G4-H1-L-35-L-35-B-L-24-PN-C09-NNN	H1-MP PUMPS	H1-045PV/053PV
83022699	MOTOR-FIX DISPL MMF044D	MMF-044-D-A-F-H-A-B-NNW-***	M35/44	044MF
83022700	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A5-C2-N-F3-F-G1-H3-J-40-J-40-B-L-24-PN-C09-NNN	H1-MP PUMPS	H1-045PV/053PV
83022701	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-1-CD-80-S-M-F1-H-03-NNN-35-35-22	SERIES 90	S90-180PV
83022704	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KE-2-CD-82-D-3-F1-L-33-GFD-36-36-36	SERIES 90	S90-100PV
83022705	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KE-2-NN-82-D-3-S1-L-33-GFD-36-36-36	SERIES 90	S90-100PV
83022708	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-HE-HE-N-A-TA-VN-DN-N-N-NN-NN-055-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83022711	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E2-AA-N-B-TB-VN-EN-N-N-NN-NN-044-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83022712	MOTOR-VAR-DISPL 51MC110	51C110-R-D4-N-HZ-B1-A-N-G0-ABA-022-AA-F0-03-00	SERIES 51	S51-110MV
83022719	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MA-1-AB-60-S-4-K3-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83022721	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-7-N-0-D9-W-00-NNN-00-00-A0	SERIES 90	S90-055MF

83022737	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A3-C1-B-D3-H-G1-H2-L-42-L-42-C-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83022740	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-8-N-0-C6-W-00-EHD-00-00-F0	SERIES 90	S90-055MF
83022741	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-8-N-0-C6-W-00-EEA-00-00-E6	SERIES 90	S90-055MF
83022742	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-8-N-0-S1-W-00-EBA-00-00-E6	SERIES 90	S90-055MF
83022747	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-L1-BA-N-B-PA-VN-AN-N-A-10-NN-022-N-00-NNN	H1-HP MOTORS	H1-080MB1
83022749	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-K2-K2-N-B-RB-VS-ES-S-A-20-NN-045-N-27-NNN	H1-HP MOTORS	H1-160MB1
83022750	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-HF-HF-N-B-TB-VN-EN-N-A-20-NN-045-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83022752	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-8-N-0-S1-W-00-EEA-00-00-F3	SERIES 90	S90-055MF
83022753	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-7-N-0-S1-W-00-EBA-00-00-F3	SERIES 90	S90-055MF
83022754	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-8-N-0-S1-W-00-NNN-00-00-G0	SERIES 90	S90-075MF
83022755	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-8-N-0-K2-W-00-NNN-00-00-G0	SERIES 90	S90-075MF
83022757	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-8-N-0-C6-W-00-NNN-00-00-G0	SERIES 90	S90-075MF
83022758	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-7-N-0-C7-W-00-NNN-00-00-G0	SERIES 90	S90-100MF
83022759	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-7-N-0-C7-W-00-NNN-00-00-F0	SERIES 90	S90-100MF
83022761	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-CD-80-S-4-C7-D-03-GBA-38-38-24	SERIES 90	S90-075PV
83022762	MOTOR-VAR-DISPL 51MC080-1	51C080-1--A-D3-N-N1-NN-N-N-U1-NNN-036-AA-F3-00-00	SERIES 51	S51-080MV-1
83022763	MOTOR-VAR-DISPL 51MV060-1	51V060-1--A-D2-N-N1-NN-N-N-U1-NNN-036-AA-F3-00-00	SERIES 51	S51-060MV-1
83022770	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-BC-80-P-3-S1-C-00-GBA-29-29-24	SERIES 90	S90-055PV
83022771	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-CD-80-T-M-C8-J-03-NNN-42-42-24	SERIES 90	S90-180PV
83022773	PUMP-VAR-DISPL CW 90PV100	90R100-KA-1-CD-80-S-4-C7-E-03-GBA-26-26-24	SERIES 90	S90-100PV
83022775	PUMP-VAR-DISPL CW 90PV075	90R075-KA-1-AB-80-S-4-S1-E-03-GBA-30-30-24	SERIES 90	S90-075PV
83022777	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-A-A4-C2-B-F6-H-G9-H6-L-25-L-25-D-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83022778	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-8-N-0-S1-W-00-NNN-00-00-F0	SERIES 90	S90-055MF
83022779	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-8-N-0-S1-W-00-NNN-00-00-E6	SERIES 90	S90-055MF
83022780	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-7-N-0-S1-W-00-NNN-00-00-F0	SERIES 90	S90-055MF
83022781	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-8-N-0-K1-W-00-NNN-00-00-E6	SERIES 90	S90-055MF
83022782	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A4-C2-B-D6-H-G1-H2-L-30-L-30-C-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83022784	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-ANN5-03-C-2-A-2-E-N-A-34-34-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83022785	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-B-T1-C0-L-N-G0-NNN-100-AA-G3-00-A3	SERIES 51	S51-250MV
83022786	MOTOR-VAR-DISPL 51MD060	51D060-R-D1-A-HS-A2-C-H-C1-ABA-027-AA-NN-14-13	SERIES 51	S51-060MV
83022787	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E2-AA-N-B-TB-DN-HN-N-N-NN-NN-024-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83022788	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E2-AA-N-B-TB-DN-HN-N-N-NN-NN-045-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83022789	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-T2-D2-N-B-TB-VS-DS-S-A-20-NN-050-Z-25-NNN	H1-HP MOTORS	H1-160MB1
83022792	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-7-N-0-S1-W-00-NNN-00-00-E6	SERIES 90	S90-055MF
83022793	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-7-N-0-C6-W-00-NNN-00-00-E4	SERIES 90	S90-055MF
83022794	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-8-N-0-S1-W-00-NNN-00-00-E6	SERIES 90	S90-075MF

83022795	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-8-N-0-S1-W-00-NNN-00-00-F3	SERIES 90	S90-075MF
83022796	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-7-N-0-S1-W-00-NNN-00-00-E6	SERIES 90	S90-075MF
83022797	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-8-N-0-S1-W-00-NNN-00-00-E4	SERIES 90	S90-075MF
83022798	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-7-N-0-S1-W-00-NNN-00-00-F0	SERIES 90	S90-075MF
83022799	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-8-N-0-F1-W-00-NNN-00-00-E6	SERIES 90	S90-100MF
83022800	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-8-N-0-F1-W-00-NNN-00-00-F3	SERIES 90	S90-100MF
83022801	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-8-N-0-F1-W-00-NNN-00-00-G0	SERIES 90	S90-100MF
83022802	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-8-N-0-S1-W-00-NNN-00-00-G0	SERIES 90	S90-100MF
83022804	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-8-N-0-K1-N-00-NNN-00-00-00	SERIES 90	S90-055MF
83022809	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-8-N-0-S1-N-00-NNN-00-00-00	SERIES 90	S90-075MF
83022810	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-7-N-0-C7-N-00-EBB-00-00-00	SERIES 90	S90-100MF
83022811	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-8-N-0-F1-N-00-NNN-00-00-00	SERIES 90	S90-100MF
83022812	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-G-N-0-F1-W-00-EAH-00-00-F0	SERIES 90	S90-100MF
83022813	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-7-N-0-C7-N-00-NNN-00-00-00	SERIES 90	S90-100MF
83022814	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-8-N-0-S1-N-00-NNN-00-00-00	SERIES 90	S90-100MF
83022817	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A8-C2-C-F5-K-G9-H6-K-42-K-42-C-P-24-P2-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83022821	MOTOR- VARIABLE CARTRIDGE L	L-C-25CN-F-R1F-F07-S-N-N-AF-F18-NNA-NNN	LV / KV MOTORS	L/K-MV
83022829	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-8-N-0-S1-W-00-EGJ-00-00-F0	SERIES 90	S90-055MF
83022831	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-C-ANNB-03-C-3-A-2-F-N-A-34-34-N-H-H-NNN-NNN	SERIES 42	S42-028PV/032PV
83022832	PUMP-VAR DISPL, CW 90PV055	90-R-055-FD-1-BC-60-S-3-C6-C-B1-GBA-35-35-24	SERIES 90	S90-055PV
83022833	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-E1A6-03-A-N-A-2-F-N-A-17-17-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83022834	PUMP-VAR-DISPL CCW 90PV042	90L042-DD-5-BB-80-R-4-C3-B-G8-GBA-30-30-24	SERIES 90	S90-042PV
83022835	PUMP-VAR-DISPL CCW 90PV042	90L042-DD-5-NN-80-R-4-C3-B-G8-GBA-30-30-24	SERIES 90	S90-042PV
83022838	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-P2-D2-N-B-TB-VS-ES-S-A-20-NN-042-Z-24-NNN	H1-HP MOTORS	H1-160MB1
83022860	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-A-A4-C1-N-D3-H-G1-H3-K-45-K-45-D-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83022867	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A3-C2-N-D8-F-G5-NN-L-33-L-33-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83022869	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-HE-HE-N-B-TB-CS-HS-S-A-10-NN-045-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83022875	PUMP-VAR DISPL CCW H1P068L	H1-P-068-L-A-A3-C2-N-D3-H-F1-H5-L-33-L-33-C-M-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83022880	MOTOR-VAR-DISPL H1MB060	H1-B-060-A-D1-M1-N-B-PA-VS-AS-S-A-10-NN-012-N-30-NNN	H1-HP MOTORS	H1-060MB1
83022883	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-8-N-0-S1-W-00-EGH-00-00-F0	SERIES 90	S90-055MF
83022884	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-1-NN-80-S-4-S1-C-Z1-GBA-32-32-24	SERIES 90	S90-055PV
83022885	MOTOR-VAR-DISPL H1B060	H1-B-060-A-NB-NT-N-N-TA-CS-GS-P-A-05-NN-012-Z-00-0NN	H1-HP MOTORS	H1-060MB1
83022886	MOTOR-VAR-DISPL H1B060	H1-B-060-A-NB-NT-N-N-TB-CS-GS-P-A-05-NN-012-Z-00-0NN	H1-HP MOTORS	H1-060MB1
83022887	MOTOR-VAR-DISPL H1B060	H1-B-060-A-NB-NT-N-N-TA-VS-AS-P-A-05-NN-012-Z-00-0NN	H1-HP MOTORS	H1-060MB1
83022888	MOTOR-VAR-DISPL H1B060	H1-B-060-A-NB-NT-N-N-TB-VS-AS-P-A-05-NN-012-Z-00-0NN	H1-HP MOTORS	H1-060MB1
83022889	MOTOR-VAR-DISPL H1B080	H1-B-080-A-NB-NT-N-N-TB-CS-HS-P-A-05-NN-016-Z-00-0NN	H1-HP MOTORS	H1-080MB1

83022890	MOTOR-VAR-DISPL H1B080	H1-B-080-A-NB-NT-N-N-TB-CS-JS-P-A-05-NN-016-Z-00-0NN	H1-HP MOTORS	H1-080MB1
83022891	MOTOR-VAR-DISPL H1B080	H1-B-080-A-NB-NT-N-N-TA-VS-AS-P-A-10-NN-016-Z-00-0NN	H1-HP MOTORS	H1-080MB1
83022892	MOTOR-VAR-DISPL H1B080	H1-B-080-A-NB-NT-N-N-TB-CS-AS-P-A-10-NN-016-Z-00-0NN	H1-HP MOTORS	H1-080MB1
83022893	MOTOR-VAR-DISPL H1B110	H1-B-110-A-NB-NT-N-N-TA-VS-ES-P-A-10-NN-022-Z-00-0NN	H1-HP MOTORS	H1-110MB1
83022894	MOTOR-VAR-DISPL H1B110	H1-B-110-A-NB-NT-N-N-TB-VS-JS-P-A-10-NN-022-Z-00-0NN	H1-HP MOTORS	H1-110MB1
83022895	MOTOR-VAR-DISPL H1B080	H1-B-080-A-NA-NR-N-N-PB-CS-HS-P-A-10-NN-016-N-00-0NN	H1-HP MOTORS	H1-080MB1
83022896	MOTOR-VAR-DISPL H1B080	H1-B-080-A-NA-NR-N-N-PB-CS-JS-P-A-10-NN-016-N-00-0NN	H1-HP MOTORS	H1-080MB1
83022897	MOTOR-VAR-DISPL H1B080	H1-B-080-A-NA-NR-N-N-PA-VS-AS-P-A-10-NN-016-N-00-0NN	H1-HP MOTORS	H1-080MB1
83022898	MOTOR-VAR-DISPL H1B080	H1-B-080-A-NA-NR-N-N-PB-VS-AS-P-A-10-NN-016-N-00-0NN	H1-HP MOTORS	H1-080MB1
83022899	MOTOR-VAR-DISPL H1B110	H1-B-110-A-NA-NR-N-N-PA-VS-ES-P-A-10-NN-022-N-00-0NN	H1-HP MOTORS	H1-110MB1
83022900	MOTOR-VAR-DISPL H1B110	H1-B-110-A-NA-NR-N-N-PB-VS-JS-P-A-10-NN-022-N-00-0NN	H1-HP MOTORS	H1-110MB1
83022901	MOTOR-VAR-DISPL H1B160	H1-B-160-A-NA-NR-N-N-PA-VS-FS-P-A-20-NN-032-N-00-0NN	H1-HP MOTORS	H1-160MB1
83022902	MOTOR-VAR-DISPL H1B160	H1-B-160-A-NA-NR-N-N-PB-VS-KS-P-A-20-NN-032-N-00-0NN	H1-HP MOTORS	H1-160MB1
83022905	MOTOR-VAR-DISPL H1B250	H1-B-250-A-NA-NR-N-N-PA-VS-FS-P-A-30-NN-050-N-00-0NN	H1-HP MOTORS	H1-250MB1
83022906	MOTOR-VAR-DISPL H1B250	H1-B-250-A-NA-NR-N-N-PB-VS-DS-P-A-30-NN-050-N-00-0NN	H1-HP MOTORS	H1-250MB1
83022916	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-2-AB-80-S-3-S1-D-03-GBA-32-32-24	SERIES 90	S90-055PV
83022918	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HM-5-CD-80-S-4-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83022920	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-BC-80-R-4-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83022942	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-CD-80-S-M-F1-H-03-NNN-35-35-24	SERIES 90	S90-180PV
83022944	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-8-N-0-K3-N-00-EHD-00-00-00	SERIES 90	S90-100MF
83022946	MOTOR-VAR-DISPL 51MD110-1	51D110-1--A-D3-N-TH-CA-N-N-X1-NNN-035-AA-F0-00-25	SERIES 51	S51-110MV-1
83022950	PUMP-VAR-DISPL CW 90PV100	90R100-MA-5-CD-80-S-3-G1-D-C5-EFI-38-38-20	SERIES 90	S90-100PV
83022951	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-2-BC-60-P-4-C6-C-05-GBA-38-38-30	SERIES 90	S90-075PV
83022962	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-CD-80-S-C-C8-H-04-NNN-42-42-24	SERIES 90	S90-180PV
83022975	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-2-NN-80-P-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83022976	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-CD-80-S-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83022988	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-3-N-0-S1-W-00-NNN-00-00-F3	SERIES 90	S90-100MF
83022989	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-8-N-0-S1-W-00-EFA-00-00-F0	SERIES 90	S90-100MF
83022990	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-8-N-0-T2-W-00-NNN-00-00-F0	SERIES 90	S90-100MF
83022992	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-CD-80-S-4-C7-E-03-GBA-45-45-24	SERIES 90	S90-075PV
83022993	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-BC-80-S-4-S1-E-03-GBA-45-45-24	SERIES 90	S90-075PV
83022997	PUMP-VAR-DISPL CW 90PV100	90R100-HS-5-BC-80-P-4-F1-F-03-EFC-42-42-24	SERIES 90	S90-100PV
83022998	PUMP-VAR-DISPL CW 90PV042	90R042-KA-2-AB-80-S-3-C3-C-03-GBA-38-38-24	SERIES 90	S90-042PV
83023002	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-L1-BA-N-C-PB-CN-HN-N-A-05-NN-000-N-00-NNN	H1-HP MOTORS	H1-080MB1
83023003	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-L1-BA-N-A-PB-VN-AN-N-A-05-NN-000-N-00-NNN	H1-HP MOTORS	H1-080MB1
83023007	PUMP-VAR-DISPL CW 90PV130	90R130-FH-5-DE-80-P-7-C8-F-B9-GBA-40-40-30	SERIES 90	S90-130PV

83023008	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HF-1-AB-80-R-3-T2-F-03-GBA-26-26-24	SERIES 90	S90-100PV
83023009	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-F2-C1-D-E5-F-G4-NN-L-23-L-23-B-P-24-P1-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83023010	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A4-C3-N-E5-F-G5-H5-L-35-L-38-N-E-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83023011	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A4-C3-N-E5-F-G5-H1-L-28-L-23-N-E-32-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83023014	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-8-N-0-K1-W-00-NNN-00-00-24	SERIES 90	S90-055MF
83023015	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-8-N-0-K1-W-00-EBA-00-00-20	SERIES 90	S90-055MF
83023017	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-8-N-0-K1-W-00-EEA-00-00-24	SERIES 90	S90-055MF
83023018	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-7-N-0-C6-W-00-JAK-00-00-20-P040	SERIES 90	S90-055MF
83023019	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-7-N-0-C6-W-00-NNN-00-00-24	SERIES 90	S90-055MF
83023020	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-3-N-0-C6-W-00-NNN-00-00-24	SERIES 90	S90-055MF
83023021	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-8-N-0-K1-W-00-NNN-00-00-20	SERIES 90	S90-055MF
83023026	PUMP-VAR-DISPL CCW 90PV042	90L042-MA-5-AB-80-R-3-C3-B-C5-GBA-35-35-30	SERIES 90	S90-042PV
83023027	PUMP-VAR-DISPL CW 90PV130	90R130-MA-5-CD-80-R-3-C8-H-C5-GBA-35-35-30	SERIES 90	S90-130PV
83023028	PUMP-VAR-DISPL CW 90PV250	90R250-MA-5-EF-80-T-3-F1-K-C5-NNN-35-35-30	SERIES 90	S90-250PV
83023029	PUMP-VAR-DISPL CCW 90PV180	90L180-MA-5-DE-80-D-C-F1-J-C5-NNN-35-35-30	SERIES 90	S90-180PV
83023030	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-HE-HE-N-B-TB-CN-GN-N-N-NN-NN-030-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83023034	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-B8-C2-C-D3-G-G2-H4-L-40-L-40-A-M-30-P1-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83023035	MOTOR-VAR-DISPL 51MV160	51V160-R-F2-N-T4-C0-L-N-G0-NNN-050-AA-E6-00-A6	SERIES 51	S51-160MV
83023038	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-L2-BA-N-B-PB-VS-DS-S-A-10-NN-046-N-00-NNN	H1-HP MOTORS	H1-110MB1
83023039	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-1-N-0-S1-W-00-NNN-00-00-E4	SERIES 90	S90-075MF
83023040	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-8-N-0-S1-W-00-EGH-00-00-F3	SERIES 90	S90-075MF
83023041	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-8-N-0-T2-W-00-EEA-00-00-F0	SERIES 90	S90-100MF
83023043	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-B-Z-C-B-AA-B-B-A-A-BEE-CE-A-GG-B-D-A-A-BEE-CE-A-GG-D-NNH-*	M46	M46-046PT
83023044	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-1-N-0-S1-W-00-NNN-00-00-24	SERIES 90	S90-075MF
83023045	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-8-N-0-K2-W-00-NNN-00-00-20	SERIES 90	S90-075MF
83023046	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-8-N-0-K2-W-00-EBA-00-00-24	SERIES 90	S90-075MF
83023047	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-7-N-0-K2-W-00-NNN-00-00-24	SERIES 90	S90-075MF
83023048	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-8-N-0-S1-W-00-EEA-00-00-24	SERIES 90	S90-075MF
83023049	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-8-N-0-S1-W-00-EFA-00-00-24	SERIES 90	S90-075MF
83023052	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-8-N-0-F1-W-00-NNN-00-00-G3	SERIES 90	S90-100MF
83023053	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-8-N-0-S1-W-00-NNN-00-00-N6	SERIES 90	S90-100MF
83023054	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-8-N-0-S1-W-00-EAA-00-00-N6	SERIES 90	S90-100MF
83023055	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-8-N-0-S1-W-00-EEA-00-00-G3	SERIES 90	S90-100MF
83023058	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-HF-HF-N-B-TB-VS-ES-S-A-20-NN-045-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83023059	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A3-C2-N-D6-H-F1-H5-L-42-L-42-C-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83023060	PUMP-VAR-DISPL CW 90PV180	90R180-FH-5-CD-80-S-7-C8-J-B1-NNN-35-35-30	SERIES 90	S90-180PV

83023066	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A4-C3-B-D6-H-F1-H3-L-20-L-15-D-L-26-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83023068	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-EF-80-S-4-C8-K-03-NNN-35-35-24	SERIES 90	S90-250PV
83023069	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-NN-80-S-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83023074	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-7-N-0-C6-W-00-NNN-00-00-20	SERIES 90	S90-055MF
83023075	PUMP-VAR DISPL CCW H1P060L	H1-P-060-L-A-A3-C2-N-D8-H-F1-H3-L-35-L-35-F-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83023078	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A4-C2-N-D6-H-G9-H3-L-38-L-38-C-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83023079	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A4-C2-N-D6-H-G9-H3-L-38-L-38-C-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83023080	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-H-S-B-J-AA-G-A-BJJ-BA-A-ZG-A-NNN-***	M46	M46-046PV
83023081	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-HE-HE-N-B-TB-VN-DN-N-A-30-NN-032-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83023082	PUMP-VAR-DISPL CW 90PV180	90R180-DD-5-BB-80-S-M-C8-J-GJ-NNN-35-35-30	SERIES 90	S90-180PV
83023083	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-5-BB-80-S-4-S1-C-GJ-GCA-42-42-24	SERIES 90	S90-055PV
83023084	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-L2-BA-N-B-PA-VN-AN-N-A-05-NN-040-N-00-NNN	H1-HP MOTORS	H1-080MB1
83023085	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-E2-AA-N-B-TB-VN-FN-N-A-20-NN-085-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83023089	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-8-N-0-S1-W-00-NNN-00-00-F0	SERIES 90	S90-075MF
83023091	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-8-N-0-C6-W-00-NNN-00-00-F0	SERIES 90	S90-055MF
83023092	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-8-N-0-C7-N-00-NNN-00-00-00	SERIES 90	S90-100MF
83023093	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-7-N-0-C7-W-00-NNN-00-00-F3	SERIES 90	S90-100MF
83023099	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-1-NN-60-P-4-S1-D-GB-GBA-38-38-24	SERIES 90	S90-055PV
83023100	PUMP-VAR-DISPL CCW 90PV075	90L075-DD-1-NN-80-P-4-S1-E-GB-GBA-35-35-24	SERIES 90	S90-075PV
83023101	PUMP-VAR-DISPL CCW 90PV100	90L100-DD-1-NN-80-P-4-F1-F-GB-GBA-35-35-24	SERIES 90	S90-100PV
83023102	PUMP-VAR-DISPL CCW 90PV180	90L180-PB-5-NN-80-T-C-C8-J-03-NNN-35-35-24	SERIES 90	S90-180PV
83023104	PUMP-VAR-DISPL CCW H1PV130	H1-P-130-L-B-A5-C2-N-D3-G-G2-H3-L-35-L-35-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83023105	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-L2-BA-N-B-PB-CS-LS-S-A-30-NN-092-N-00-NNN	H1-HP MOTORS	H1-160MB1
83023106	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A3-C2-N-D8-F-G5-H2-L-42-L-42-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83023112	PUMP-VAR-DISPL CW 90PV130	90R130-KA-2-NN-80-R-3-C8-H-03-GBA-26-26-24	SERIES 90	S90-130PV
83023115	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A4-C2-N-F4-H-G9-H6-L-42-L-42-M-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83023116	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A4-C2-N-D3-H-G1-H3-L-42-L-42-M-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83023117	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E2-AA-N-B-TA-VS-AS-S-A-05-NN-049-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83023118	PUMP-VAR DISPL MPV046C	MPV-046-C-B-A-K-S-B-J-AA-A-A-BJJ-AK-U-BB-B-NNN-***	M46	M46-046PV
83023119	PUMP-VAR DISPL, CW 90PV100	90-R-100-HF-1-AB-80-R-3-T2-F-03-GBA-26-26-24	SERIES 90	S90-100PV
83023121	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-1-BC-80-S-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83023125	PUMP-VAR DISPL, CW 90PV075	90-R-075-KT-1-BC-80-S-4-C7-D-05-EAB-42-42-24	SERIES 90	S90-075PV
83023131	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-B8-C1-D-F6-H-F1-H6-L-42-L-42-C-L-24-P1-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83023132	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A7-C2-C-D6-J-G5-H2-L-28-L-28-B-L-24-P2-NNN-D3F	H1-MP PUMPS	H1-045PV/053PV
83023134	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-TA-C7-L-N-G5-NNN-080-AA-F3-00-B5	SERIES 51	S51-160MV
83023135	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A4-C3-N-E5-F-G5-H1-L-28-L-28-N-E-32-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV

83023136	PUMP-VAR DISPL, CCW 90PV055	90-L-055-MA-1-NN-60-R-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83023141	PUMP-VAR-DISPL CCW 90PV130	90L130-HF-5-AB-80-R-4-T4-H-03-EEB-17-35-24	SERIES 90	S90-130PV
83023142	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-B8-C1-D-D6-H-G1-NN-L-42-L-42-C-L-24-P1-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83023148	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-G-S-B-AA-V-A-BEE-DA-A-HH-C-NNN-***	M46	M46-046PV
83023150	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-8-N-0-K3-W-00-NNN-00-00-24	SERIES 90	S90-100MF
83023153	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A4-C2-N-D8-F-G5-NN-L-33-L-33-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83023155	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-M1-CA-N-A-RA-DS-JS-S-A-15-NN-000-N-00-NNN	H1-HP MOTORS	H1-110MB1
83023159	PUMP-VAR-DISPL CW H1PV069	H1-P-069-R-A-B5-C2-C-D6-H-G1-H5-L-45-L-45-C-L-24-P1-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83023162	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-3-N-0-S1-W-00-NNN-00-00-24	SERIES 90	S90-075MF
83023163	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-8-N-0-T2-W-00-NNN-00-00-24	SERIES 90	S90-075MF
83023164	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-8-N-0-S1-W-00-NNN-00-00-28	SERIES 90	S90-075MF
83023165	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-1-N-0-S1-W-00-NNN-00-00-24	SERIES 90	S90-055MF
83023166	PUMP-VAR DISPL, CCW 90PV055	90-L-055-MA-2-CD-80-P-4-C6-B-03-GBA-32-32-24	SERIES 90	S90-055PV
83023167	PUMP-VAR DISPL, CCW 90PV055	90-L-055-MA-2-NN-80-P-4-S1-B-03-GBA-32-32-24	SERIES 90	S90-055PV
83023168	PUMP-VAR DISPL, CCW 90PV055	90-L-055-DD-1-NN-80-S-4-C6-B-GB-GBA-35-35-24	SERIES 90	S90-055PV
83023170	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-3-N-0-F1-W-00-NNN-00-00-24	SERIES 90	S90-100MF
83023171	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-7-N-0-C7-W-00-EFB-00-00-24	SERIES 90	S90-100MF
83023172	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-7-N-0-F1-W-00-EBA-00-00-24	SERIES 90	S90-100MF
83023173	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-8-N-0-F1-W-00-EBA-00-00-24	SERIES 90	S90-100MF
83023174	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-7-N-0-C6-W-00-NNN-00-00-24	SERIES 90	S90-100MF
83023175	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-7-N-0-G7-N-00-LAB-00-00-00	SERIES 90	S90-100MF
83023178	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-CD-80-L-3-C8-H-05-GBA-38-35-24	SERIES 90	S90-130PV
83023180	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-7-N-0-G7-N-00-LAC-00-00-00	SERIES 90	S90-100MF
83023181	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-7-N-0-C6-N-00-LAB-00-00-00	SERIES 90	S90-100MF
83023182	PUMP-VAR-DISPL CCW 90PV042	90L042-KP-5-NN-80-L-3-C3-C-00-GBA-29-29-24	SERIES 90	S90-042PV
83023183	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-5-NN-80-L-3-C6-D-00-GBA-38-32-24	SERIES 90	S90-055PV
83023188	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-8-N-0-C7-W-00-NNN-00-00-B3	SERIES 90	S90-100MF
83023189	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A5-C2-N-D6-H-F1-H3-L-38-L-38-C-L-30-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83023192	PUMP-VAR DISPL, CW 90PV075	90-R-075-DD-5-NN-60-P-4-S1-D-G8-GBA-35-35-24	SERIES 90	S90-075PV
83023193	PUMP-VAR DISPL, CW 90PV055	90-R-055-FD-1-BC-60-S-7-C6-C-B1-FAC-35-35-24	SERIES 90	S90-055PV
83023197	MOTOR-FIX DISPL MMF044D	MMF-044-D-A-D-G-A-B-NNN-***	M35/44	044MF
83023205	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-D1-MA-N-B-PA-VS-DS-S-A-20-NN-050-N-30-NNN	H1-HP MOTORS	H1-160MB1
83023206	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A4-C2-N-D8-G-G2-NN-L-42-L-42-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83023207	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-D1-M1-N-B-PA-VS-DS-S-A-20-NN-060-N-30-NNN	H1-HP MOTORS	H1-160MB1
83023208	PUMP-VAR DISPL, CW 90PV055	90-R-055-HS-1-AB-60-S-4-S1-C-03-GBA-21-21-20	SERIES 90	S90-055PV
83023210	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-G-N-0-S1-W-00-EAH-00-00-24	SERIES 90	S90-075MF

83023212	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-8-N-0-T1-W-00-NNN-00-00-20	SERIES 90	S90-055MF
83023214	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-8-N-0-C6-W-00-NNN-00-00-24	SERIES 90	S90-055MF
83023216	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-8-N-0-S1-W-00-NNN-00-00-24	SERIES 90	S90-055MF
83023218	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-7-N-0-S1-W-00-NNN-00-00-20	SERIES 90	S90-055MF
83023219	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-8-N-0-C6-W-00-NNN-00-00-20	SERIES 90	S90-055MF
83023221	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-8-N-0-S1-W-00-NNN-00-00-20	SERIES 90	S90-055MF
83023225	PUMP-VAR-DISPL CCW H1PV130	H1-P-130-L-B-A3-C1-N-D8-G-G2-H3-L-38-L-38-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83023226	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-B1-C3-B-F5-H-G1-H6-L-38-L-38-F-P-18-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83023227	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-B1-C3-B-D8-H-G1-H3-L-38-L-38-F-P-18-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83023228	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-G3AN-53-P-3-X-N-H-5-A-21-21-B-8-8-NNN-NNN	SERIES 42	S42-028PV/032PV
83023231	PUMP-VAR-DISPL CW 90PV130	90R130-KA-1-BC-80-S-4-C8-H-02-GBA-42-42-24	SERIES 90	S90-130PV
83023232	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-7-N-0-S1-W-00-NNN-00-00-24	SERIES 90	S90-075MF
83023233	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-8-N-0-S1-W-00-NNN-00-00-24	SERIES 90	S90-075MF
83023235	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-8-N-0-C7-W-00-NNN-00-00-24	SERIES 90	S90-075MF
83023236	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-8-N-0-T2-W-00-NNN-00-00-20	SERIES 90	S90-075MF
83023237	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-8-N-0-C7-W-00-NNN-00-00-20	SERIES 90	S90-075MF
83023239	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-5-NN-60-L-3-S1-F-02-FAD-42-42-34	SERIES 90	S90-100PV
83023241	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A2-C2-N-D3-G-G3-H6-K-45-K-42-L-M-28-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83023244	PUMP-VAR DISPL, CW 90PV075	90-R-075-KT-B-BB-80-S-3-S1-D-01-GBA-32-42-24	SERIES 90	S90-075PV
83023250	MOTOR-FIX DISPL MMF044D	MMF-044-D-A-S-U-C-D-NNR-***	M35/44	O44MF
83023251	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-B1-C1-B-F5-H-F1-H6-L-38-L-38-C-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83023256	PUMP-VAR-DISPL CW 90PV130	90R130-KN-1-NN-80-R-3-C8-F-33-GBA-38-38-24	SERIES 90	S90-130PV
83023259	MOTOR-VAR-DISPL H1B250	H1-B-250-A-D2-MA-N-A-PB-VN-FN-N-A-20-NN-050-N-16-NNN	H1-HP MOTORS	H1-250MB1
83023262	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-B1-C1-B-D8-H-G1-H3-L-38-L-38-C-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83023263	PUMP-VAR DISPL MPV046C	MPV-046-C-B-A-A-S-B-B-BA-A-A-BEE-AK-D-FF-C-NNN-***	M46	M46-046PV
83023265	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-8-N-0-F1-W-00-NNN-00-00-24	SERIES 90	S90-100MF
83023266	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-1-N-0-C7-W-00-NNN-00-00-20	SERIES 90	S90-100MF
83023267	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-8-N-0-S1-W-00-NNN-00-00-24	SERIES 90	S90-100MF
83023268	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-7-N-0-S1-W-00-NNN-00-00-20	SERIES 90	S90-100MF
83023269	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-8-N-0-K3-W-00-NNN-00-00-20	SERIES 90	S90-100MF
83023270	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-8-N-0-S1-W-00-NNN-00-00-20	SERIES 90	S90-100MF
83023271	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-1-N-0-S1-W-00-NNN-00-00-24	SERIES 90	S90-100MF
83023272	PUMP-VAR-DISPL CCW H1PV165	H1-P-165-L-C-A5-C1-B-D8-G-G2-NN-L-20-L-20-N-E-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83023278	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-HZ-B1-B-H-G5-ABA-036-AA-E6-06-00	SERIES 51	S51-080MV
83023279	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-8-N-0-C7-W-00-EHD-00-00-E6	SERIES 90	S90-075MF
83023280	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-7-N-0-K1-W-00-EBA-00-00-20	SERIES 90	S90-055MF

83023281	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-8-N-0-C6-W-00-EAJ-00-00-F3	SERIES 90	S90-055MF
83023284	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-8-N-0-S1-N-00-NNN-00-00-00	SERIES 90	S90-055MF
83023285	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-8-N-0-T1-W-00-NNN-00-00-24	SERIES 90	S90-055MF
83023287	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-8-N-0-C6-N-00-NNN-00-00-00	SERIES 90	S90-055MF
83023288	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-8-N-0-C6-W-00-EAA-00-00-24	SERIES 90	S90-055MF
83023299	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-BC-60-S-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83023300	PUMP-VAR-DISPL CW 90PV250	90R250-KP-1-CD-80-T-4-F1-J-03-NNN-35-35-24	SERIES 90	S90-250PV
83023301	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-7-N-0-C6-W-00-NNN-00-00-24	SERIES 90	S90-075MF
83023308	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-1-AB-80-L-3-S1-B-03-GBA-35-35-24	SERIES 90	S90-055PV
83023311	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-C2-C2-C-D3-K-G9-H3-L-42-L-42-D-M-30-P2-NNN-D4F	H1-HP PUMPS	H1-089PV/100PV
83023312	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-8-N-0-C7-W-00-NNN-00-00-F0	SERIES 90	S90-075MF
83023313	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-8-N-0-C6-W-00-NNN-00-00-F0	SERIES 90	S90-075MF
83023316	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-8-N-0-C6-W-00-NNN-00-00-F3	SERIES 90	S90-055MF
83023317	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-7-N-0-C6-W-00-NNN-00-00-E6	SERIES 90	S90-055MF
83023318	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-8-N-0-C6-W-00-NNN-00-00-F3	SERIES 90	S90-075MF
83023319	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-7-N-0-C6-W-00-NNN-00-00-F3	SERIES 90	S90-075MF
83023320	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-8-N-0-C6-N-00-EBA-00-00-00	SERIES 90	S90-075MF
83023321	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-7-N-0-C7-N-00-NNN-00-00-00	SERIES 90	S90-075MF
83023325	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HF-5-AB-60-S-3-S1-C-02-GBA-30-30-24	SERIES 90	S90-055PV
83023329	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-L2-BA-N-A-PB-VS-AS-S-A-05-NN-050-N-00-NNN	H1-HP MOTORS	H1-080MB1
83023330	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-8-N-0-S1-W-00-EBA-00-00-E4	SERIES 90	S90-100MF
83023338	MOTOR-VAR-DISPL H1B110	H1-B-110-A-TA-D1-N-B-TB-VS-ES-S-A-10-NN-035-Z-28-NNN	H1-HP MOTORS	H1-110MB1
83023342	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A5-C2-N-D8-G-G2-H3-L-38-L-38-A-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83023343	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A5-C2-N-D8-G-G2-H3-L-38-L-38-A-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83023344	MOTOR-VAR-DISPL H1MB060	H1-B-060-A-M2-CA-N-C-RB-VS-AS-S-A-05-NN-035-N-00-NNN	H1-HP MOTORS	H1-060MB1
83023345	PUMP-VAR DISPL CW H1P068R	H1-P-068-R-A-A5-C2-N-D8-H-F1-H3-L-38-L-38-C-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83023346	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A5-C2-N-D8-H-F1-H3-L-42-L-42-C-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83023347	MOTOR-VAR-DISPL H1MB060	H1-B-060-A-M2-CA-N-C-RB-VN-AN-N-A-05-NN-035-N-00-NNN	H1-HP MOTORS	H1-060MB1
83023349	MOTOR-VAR-DISPL H1B250	H1-B-250-A-M2-CA-N-C-RB-VS-DS-S-A-20-NN-068-N-00-NNN	H1-HP MOTORS	H1-250MB1
83023350	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-CD-80-S-4-C7-E-03-GBA-45-45-24	SERIES 90	S90-100PV
83023351	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-BC-80-S-4-S1-E-03-GBA-45-45-24	SERIES 90	S90-100PV
83023355	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-HE-HE-N-B-TA-CN-GN-N-N-NN-NN-030-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83023356	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-HE-HE-N-A-TB-VN-EN-N-N-NN-NN-045-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83023357	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A5-C2-B-D8-G-G3-NN-L-25-L-25-L-P-30-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83023361	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-NN-80-R-3-G1-F-05-FAP-35-35-30	SERIES 90	S90-100PV
83023363	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-N-A3-C2-N-E7-F-G1-H2-28-28-28-28-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT

83023366	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-7-N-0-S1-W-00-EBA-00-00-24	SERIES 90	S90-100MF
83023367	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-8-N-0-C6-W-00-NNN-00-00-20	SERIES 90	S90-100MF
83023369	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-7-N-0-C7-W-00-NNN-00-00-24	SERIES 90	S90-100MF
83023370	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-7-N-0-F1-W-00-NNN-00-00-24	SERIES 90	S90-100MF
83023371	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-8-N-0-C7-W-00-NNN-00-00-24	SERIES 90	S90-100MF
83023373	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-CD-80-L-3-C7-E-03-GBA-43-43-30	SERIES 90	S90-100PV
83023376	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A5-C3-N-D6-G-G2-H3-L-35-L-35-L-L-28-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83023377	PUMP-VAR-DISPL CW H1PV069	H1-P-069-R-A-A7-C2-C-D6-K-G9-H3-K-45-K-45-C-L-28-P2-NNN-D3F	H1-HP PUMPS	H1-069PV/078PV
83023379	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A3-C1-N-D8-H-G1-NN-K-38-K-30-C-P-26-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83023380	PUMP-VAR DISPL, CW 90PV075	90-R-075-MS-1-BC-60-L-3-S1-E-03-GBA-32-32-24	SERIES 90	S90-075PV
83023381	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-2-NN-80-P-3-F1-F-03-GBA-45-14-24	SERIES 90	S90-100PV
83023382	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-8-N-0-C7-W-00-NNN-00-00-20	SERIES 90	S90-100MF
83023386	PUMP-VAR DISPL CCW H1P060L	H1-P-060-L-A-A3-C3-B-D8-H-G1-NN-L-23-L-23-C-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83023392	PUMP-VAR-DISPL CCW 90PV250	90L250-HF-5-BC-80-T-4-F1-J-00-NNN-26-26-24	SERIES 90	S90-250PV
83023402	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-7-N-0-S1-N-00-NNN-00-00-00	SERIES 90	S90-075MF
83023403	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-8-N-0-S1-W-00-EBA-00-00-24	SERIES 90	S90-055MF
83023404	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-8-N-0-C6-W-00-EAA-00-00-E6	SERIES 90	S90-055MF
83023405	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-8-N-0-C6-W-00-EEA-00-00-24	SERIES 90	S90-055MF
83023406	MOTOR-VAR-DISPL H1B080	H1-B-080-A-TA-DA-N-B-TB-VN-AN-N-N-NN-NN-040-Z-20-NNN	H1-HP MOTORS	H1-080MB1
83023414	PUMP-VAR-DISPL CW H1PV069	H1-P-069-R-A-A7-C2-C-D8-K-F1-H5-L-42-L-42-F-P-26-P2-NNN-D3F	H1-HP PUMPS	H1-069PV/078PV
83023415	PUMP-VAR-DISPL CCW H1PV165	H1-P-165-L-C-A5-C2-N-D3-G-G3-NN-L-42-L-42-L-M-28-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83023418	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A3-C1-B-D3-G-G3-NN-L-35-L-35-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83023419	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-K2-K2-N-C-RB-VS-DS-S-A-20-NN-042-N-30-NNN	H1-HP MOTORS	H1-160MB1
83023425	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-1-NN-80-R-3-S1-C-03-GBA-14-14-20-P000	SERIES 90	S90-055PV
83023426	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-AB-80-L-3-C7-D-04-GBA-42-42-24	SERIES 90	S90-075PV
83023428	PUMP-VAR DISPL CCW H1P060L	H1-P-060-L-A-A5-C2-N-D3-H-G1-H2-L-42-L-42-C-M-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83023430	PUMP-VAR-DISPL CW 90PV130	90R130-KA-1-NN-80-L-3-T7-F-03-GBA-42-42-26	SERIES 90	S90-130PV
83023431	PUMP-VAR-DISPL CW 90PV075	90R075-KP-1-NN-80-S-3-S1-D-03-GBA-26-26-20	SERIES 90	S90-075PV
83023434	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-TA-C2-L-N-G0-NNN-062-AA-G0-00-A7	SERIES 51	S51-250MV
83023437	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-BC-61-P-3-S1-E-03-GBA-32-32-24	SERIES 90	S90-075PV
83023439	PUMP-VAR-DISPL CCW 90PV130	90L130-KN-5-CD-80-S-3-C8-H-03-GBA-35-35-26	SERIES 90	S90-130PV
83023441	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A3-C2-B-F4-H-G9-H6-L-38-L-38-F-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83023442	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A3-C2-B-D3-H-G1-NN-L-38-L-38-F-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83023443	PUMP-VAR-DISPL CCW 90PV130	90L130-HF-5-DE-80-S-4-F1-F-03-GBA-17-26-24	SERIES 90	S90-130PV
83023448	PUMP-TANDEM, VAR DISPL MPT044D	MPT-044-D-A-R-S-2-AA-B-A-A-A-BFF-DR-A-FF-B-C-A-A-BFF-DL-A-FF-C-NNN-***	M35/44	O44PT
83023459	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-E2-AA-N-B-TA-CN-LN-N-N-NN-NN-040-Z-00-NNN	H1-HP MOTORS	H1-160MB1

83023461	PUMP-VAR-DISPL CW 90PV100	90R100-KN-1-CD-80-P-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83023462	PUMP-VAR-DISPL CW 90PV130	90R130-HS-5-DE-80-S-4-C8-F-03-GBA-42-42-24	SERIES 90	S90-130PV
83023463	PUMP-VAR-DISPL CW 90PV130	90R130-HS-5-NN-80-S-4-F1-F-03-GBA-42-42-24	SERIES 90	S90-130PV
83023464	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-K2-KA-N-B-RA-VS-ES-S-A-20-NN-042-N-28-N03	H1-HP MOTORS	H1-160MB1
83023468	PUMP-VAR DISPL, CCW 90PV055	90-L-055-MA-1-NN-80-R-3-S1-C-03-GBA-14-14-20-P000	SERIES 90	S90-055PV
83023469	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-NN-80-D-3-C6-N-03-GBA-32-32-24	SERIES 90	S90-075PV
83023470	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A5-C2-B-D3-H-G1-H3-L-33-L-33-F-M-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83023471	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HS-1-NN-60-R-4-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
83023472	PUMP-VAR-DISPL CCW 90PV180	90L180-KN-1-CD-80-T-C-F1-H-03-FAC-35-35-24	SERIES 90	S90-180PV
83023478	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-M1-CA-N-B-RA-VS-DS-S-A-20-NN-000-N-00-NNN	H1-HP MOTORS	H1-160MB1
83023480	PUMP-VAR-DISPL CW 90PV100	90R100-PB-5-BB-60-R-3-S1-F-00-GBA-35-35-24	SERIES 90	S90-100PV
83023482	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HS-1-NN-60-R-4-S1-D-03-GBA-42-42-30	SERIES 90	S90-075PV
83023483	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HS-1-BC-60-R-4-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
83023486	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-7-N-0-C7-W-00-EAA-00-00-18	SERIES 90	S90-100MF
83023487	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-B1-C2-N-D3-H-G1-H3-L-42-L-42-F-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83023489	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-NN-60-S-3-C7-F-03-GBA-26-26-28	SERIES 90	S90-100PV
83023491	PUMP-VAR-DISPL CW 90PV100	90R100-LW-5-AB-60-S-3-C7-E-C5-GFK-38-38-24	SERIES 90	S90-100PV
83023492	PUMP-VAR DISPL, CW 90PV055	90-R-055-KT-1-CD-80-L-3-S1-C-03-GBA-29-29-24	SERIES 90	S90-055PV
83023493	PUMP-VAR DISPL, CW 90PV100	90-R-100-KT-5-BC-80-P-3-S1-E-03-GBA-38-38-20	SERIES 90	S90-100PV
83023494	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-N-A4-C1-N-E7-F-G5-NN-30-30-30-30-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83023498	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A5-C2-B-F6-H-G1-H6-L-38-L-38-C-L-34-PN-C17-NNN	H1-HP PUMPS	H1-069PV/078PV
83023499	PUMP-VAR-DISPL CCW H1PV147	H1-P-147-L-C-A5-C2-N-D6-G-G2-H6-L-38-L-38-L-L-34-PN-C17-NNN	H1-HP PUMPS	H1-147PV/165PV
83023505	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-S1-N-TA-C2-N-N-X1-NNN-016-AA-NN-00-15	SERIES 51	S51-080MV-1
83023508	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-C-E1A3-03-C-3-A-2-F-N-B-14-14-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83023510	PUMP-VAR-DISPL CW 90PV180	90R180-KA-2-NN-80-T-C-C8-J-K4-GLA-35-35-34	SERIES 90	S90-180PV
83023515	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A3-C2-N-F5-H-G9-H6-K-42-K-42-M-P-34-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83023516	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A3-C2-N-F5-H-G1-H6-K-42-K-42-M-P-34-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83023518	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-N-HS-A2-B-H-F1-NNN-168-AA-NN-10-13	SERIES 51	S51-250MV
83023519	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-N-HS-A2-B-H-F1-NNN-140-AA-NN-10-14	SERIES 51	S51-250MV
83023520	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-N-HS-A2-B-H-F1-NNN-110-AA-NN-10-18	SERIES 51	S51-250MV
83023527	PUMP-VAR-DISPL CCW 90PV180	90L180-MA-1-NN-80-T-M-F1-J-03-FAC-35-35-24	SERIES 90	S90-180PV
83023528	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-8-N-0-S1-N-00-EBA-00-00-00	SERIES 90	S90-055MF
83023529	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-AB-80-P-3-S1-D-03-GBA-29-29-24	SERIES 90	S90-055PV
83023530	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-CD-60-P-3-C7-D-03-GBA-42-42-24	SERIES 90	S90-075PV
83023531	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-8-N-0-C6-W-00-NNN-00-00-A0	SERIES 90	S90-055MF
83023532	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-8-N-0-S1-W-00-EBA-00-00-20	SERIES 90	S90-055MF

83023533	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-8-N-0-S1-W-00-NNN-00-00-F3	SERIES 90	S90-055MF
83023534	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-8-N-0-K1-N-00-EFA-00-00-00	SERIES 90	S90-055MF
83023535	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-7-N-0-C6-W-00-NNN-00-00-G0	SERIES 90	S90-055MF
83023536	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-7-N-0-C6-W-00-EBA-00-00-E6	SERIES 90	S90-055MF
83023539	PUMP-VAR-DISPL CW 90PV130	90R130-MA-1-NN-80-R-3-F1-F-03-GBA-23-23-24	SERIES 90	S90-130PV
83023540	MOTOR-VAR-DISPL H1B250	H1-B-250-A-L1-BA-N-B-PA-VS-FS-S-A-30-NN-070-N-00-NNN	H1-HP MOTORS	H1-250MB1
83023541	MOTOR-VAR-DISPL H1B250	H1-B-250-A-L1-BA-N-B-PA-VS-FS-S-A-20-NN-070-N-00-NNN	H1-HP MOTORS	H1-250MB1
83023542	MOTOR-VAR-DISPL H1B250	H1-B-250-A-L2-BA-N-B-PA-VS-FS-S-A-20-NN-070-N-00-NNN	H1-HP MOTORS	H1-250MB1
83023543	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-L2-BA-N-B-PB-DS-KS-S-A-20-NN-045-N-00-NNN	H1-HP MOTORS	H1-160MB1
83023545	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A3-C2-N-F5-H-G9-H6-K-42-K-42-C-P-34-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83023546	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A3-C2-N-D8-H-G1-H3-K-42-K-42-C-P-34-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83023548	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A5-C3-B-D6-G-G2-H6-L-42-L-42-L-L-28-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83023550	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A5-C3-B-F6-H-G1-H6-L-42-L-42-C-L-28-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83023555	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-HE-HE-N-A-TB-VN-EN-N-N-NN-NN-108-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83023556	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-A1N5-03-C-2-A-2-E-N-A-34-34-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83023557	PUMP-VAR-DISPL CW 90PV180	90R180-KP-5-NN-80-S-C-F1-H-03-NNN-42-42-24	SERIES 90	S90-180PV
83023558	PUMP-VAR-DISPL CW 90PV100	90R100-KA-1-AB-60-P-4-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83023560	PUMP-VAR-DISPL CCW 90PV130	90L130-MA-1-NN-80-S-3-C8-F-04-GBA-42-42-24	SERIES 90	S90-130PV
83023561	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-C2-C2-C-D6-L-G2-H3-L-42-L-42-L-L-24-P2-NNN-D4F	H1-HP PUMPS	H1-115PV/130PV
83023563	MOTOR-VAR-DISPL H1MB060	H1-B-060-A-L2-BA-N-A-PA-VS-AS-S-A-10-NN-020-N-00-NNN	H1-HP MOTORS	H1-060MB1
83023564	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-8-N-0-C6-W-00-EBA-00-00-E6	SERIES 90	S90-055MF
83023565	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-8-N-0-S1-W-00-EBA-00-00-20	SERIES 90	S90-075MF
83023566	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-8-N-0-C6-W-00-EBA-00-00-24	SERIES 90	S90-075MF
83023567	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-8-N-0-C7-W-00-EEA-00-00-24	SERIES 90	S90-075MF
83023568	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-8-N-0-C6-W-00-EEA-00-00-20	SERIES 90	S90-075MF
83023571	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-N-HS-A2-B-H-F1-NNN-168-AA-NN-10-15	SERIES 51	S51-250MV
83023573	PUMP-VAR-DISPL CW 90PV130	90R130-KN-1-NN-80-L-4-F1-F-03-GBA-36-36-20	SERIES 90	S90-130PV
83023575	PUMP-VAR-DISPL CCW 90PV130	90L130-HF-1-NN-80-R-4-F1-H-03-GBA-35-35-24	SERIES 90	S90-130PV
83023588	PUMP-VAR-DISPL CW 90PV075	90R075-ME-5-BB-80-D-3-C7-L-C6-GBA-35-35-22	SERIES 90	S90-075PV
83023591	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-1-NN-60-S-3-S1-E-33-EFC-14-35-24	SERIES 90	S90-100PV
83023592	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-D-HS-A2-B-H-F1-NNN-110-AA-NN-10-18	SERIES 51	S51-250MV
83023598	MOTOR-VAR-DISPL 51MV160	51V160-R-D5-N-L1-B1-W-B-J1-NNN-032-AA-H0-D4-00	SERIES 51	S51-160MV
83023599	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-G-S-A-S-BC-V-A-BJJ-DA-A-HH-C-NNN-***	M46	M46-046PV
83023606	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-8-N-0-S1-W-00-EAA-00-00-F3	SERIES 90	S90-075MF
83023607	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-8-N-0-C7-N-00-EBA-00-00-00	SERIES 90	S90-075MF
83023608	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-8-N-0-S1-W-00-EHD-00-00-E6	SERIES 90	S90-075MF

83023609	MOTOR-VAR-DISPL H1B250	H1-B-250-A-K1-KA-N-B-RB-VN-FN-N-A-20-NN-095-N-25-NNN	H1-HP MOTORS	H1-250MB1
83023623	PUMP-VAR-DISPL CCW 90PV180	90L180-KP-5-CD-80-T-C-F1-H-03-FAC-45-45-24	SERIES 90	S90-180PV
83023625	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-7-N-0-C7-N-00-EEA-00-00-00	SERIES 90	S90-100MF
83023626	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-G-N-0-F1-W-00-EAF-00-00-A0	SERIES 90	S90-100MF
83023627	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-1-N-0-S1-N-00-NNN-00-00-00	SERIES 90	S90-100MF
83023628	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-7-N-0-F1-W-00-NNN-00-00-G0	SERIES 90	S90-100MF
83023629	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-8-N-0-C7-W-00-NNN-00-00-G0	SERIES 90	S90-100MF
83023630	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-7-N-0-S1-W-00-NNN-00-00-F3	SERIES 90	S90-100MF
83023631	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-8-N-0-C7-W-00-EBA-00-00-E6	SERIES 90	S90-100MF
83023655	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-L2-BA-N-B-PA-DS-KS-S-A-20-NN-045-N-00-NNN	H1-HP MOTORS	H1-160MB1
83023658	PUMP-VAR-DISPL CCW 90PV180	90L180-KP-2-CD-80-T-C-C8-J-00-FAC-42-42-24	SERIES 90	S90-180PV
83023659	PUMP-VAR-DISPL CCW 90PV180	90L180-KP-2-EG-80-T-C-C8-J-00-FAC-42-42-24	SERIES 90	S90-180PV
83023668	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A5-C2-N-D3-G-G2-H6-L-35-L-35-A-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83023671	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A5-C2-N-F5-H-G1-H6-L-25-L-25-D-P-20-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83023675	PUMP-VAR-DISPL CW 90PV100	90R100-LW-5-AB-60-L-3-C7-E-C5-GBA-42-42-24	SERIES 90	S90-100PV
83023676	PUMP-VAR-DISPL CW 90PV130	90R130-LW-5-BC-80-L-3-F1-F-C5-GBA-42-42-28	SERIES 90	S90-130PV
83023686	PUMP-VAR-DISPL CW 90PV075	90R075-KA-1-BC-60-R-3-S1-E-03-GBA-26-26-24	SERIES 90	S90-075PV
83023687	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E2-AA-N-C-TB-CS-JS-S-A-10-NN-045-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83023695	PUMP-VAR-DISPL CW 90PV100	90R100-KN-1-NN-80-P-4-S1-D-03-GBA-36-14-24	SERIES 90	S90-100PV
83023697	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-T2-DA-N-A-TB-CS-JS-S-N-NN-NN-016-Z-20-NNN	H1-HP MOTORS	H1-080MB1
83023702	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A5-C2-N-D8-F-G1-H1-L-33-L-33-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83023703	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E2-AA-N-B-TB-VN-AN-N-A-05-NN-018-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83023705	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-S1-N-E1-B1-N-N-U1-ABA-032-AA-NN-00-00	SERIES 51	S51-080MV-1
83023716	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-E1-AA-N-C-TB-VN-EN-N-A-20-NN-107-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83023717	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KN-1-NN-80-S-4-S1-C-03-GBA-32-32-24	SERIES 90	S90-075PV
83023718	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-CD-60-S-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-075PV
83023719	PUMP-VAR-DISPL CCW H1PV130	H1-P-130-L-B-A3-C1-N-D8-G-G2-NN-L-38-L-38-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83023723	MOTOR-VAR-DISPL H1B250	H1-B-250-A-E1-AA-N-B-TA-VS-DS-S-A-20-NN-070-Z-00-NNN	H1-HP MOTORS	H1-250MB1
83023724	MOTOR-VAR-DISPL H1B250	H1-B-250-A-E1-AA-N-B-TB-VS-DS-S-A-20-NN-070-Z-00-NNN	H1-HP MOTORS	H1-250MB1
83023725	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-CD-80-R-4-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83023727	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KN-1-NN-60-R-4-S1-D-03-GBA-38-38-24	SERIES 90	S90-075PV
83023728	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-BC-80-R-4-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83023735	PUMP-VAR DISPL MPV035D	MPV-035-D-B-A-G-R-S-G-AA-A-A-BJJ-DL-A-FF-A-NNN-***	M35/44	035PV
83023736	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-B8-C2-C-F4-H-F1-H6-L-35-L-35-C-M-24-P1-C07-NNN	H1-HP PUMPS	H1-069PV/078PV
83023737	PUMP-VAR-DISPL CW 90PV075	90R075-ME-5-BB-80-D-3-C7-L-C6-GBA-42-42-22	SERIES 90	S90-075PV
83023739	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-CD-80-R-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV

83023740	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-BC-80-R-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83023746	PUMP-VAR-DISPL CCW 90PV100	90L100-HF-5-AB-80-R-4-S1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
83023751	PUMP- VARIABLE, DIRECT DISPLACMENT	LPV-A-A-B-L-A-K-FA-C-A-BJH-DR-A-FF-B-NNN-***	LPV	LPV
83023758	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-HZ-B1-A-N-G0-ACA-062-AA-H0-03-00	SERIES 51	S51-160MV
83023759	PUMP-VAR DISPL, CCW 90PV055	90-L-055-DC-1-NN-80-P-4-S1-D-GB-GBA-35-35-24	SERIES 90	S90-055PV
83023762	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-HE-HE-N-A-TB-CN-JN-N-A-10-NN-054-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83023776	PUMP-VAR-DISPL CW 90PV100	90R100-DD-5-NN-80-L-4-S1-D-GB-GBA-42-42-30	SERIES 90	S90-100PV
83023783	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-S1-N-TA-C2-N-N-X1-NNN-041-AA-E4-00-28	SERIES 51	S51-080MV-1
83023787	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-B8-C1-D-D8-H-F1-H3-L-35-L-35-N-E-34-P1-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83023799	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-NN-80-P-3-S1-E-00-GBA-26-26-24	SERIES 90	S90-100PV
83023802	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-N-A4-C2-B-E7-F-G1-H1-38-38-38-38-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83023803	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-BB-80-L-4-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83023804	PUMP-VAR-DISPL CW 90PV130	90R130-KP-1-NN-80-P-3-F1-F-00-GBA-42-42-24	SERIES 90	S90-130PV
83023805	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A5-C2-B-D8-F-G5-H3-L-33-L-33-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83023810	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A5-C1-N-D6-F-G1-H5-L-35-L-35-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83023811	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A5-C1-N-D6-F-G5-NN-L-35-L-35-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83023813	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-NN-80-R-3-S1-E-03-GBA-35-13-24	SERIES 90	S90-100PV
83023814	PUMP-VAR DISPL, CCW 90PV100	90-L-100-CA-1-NN-80-R-3-S1-E-00-GBA-13-35-24	SERIES 90	S90-100PV
83023815	PUMP-VAR DISPL, CCW 90PV100	90-L-100-M1-1-AB-80-S-3-TF-E-03-FAC-45-45-28	SERIES 90	S90-100PV
83023818	MOTOR-VAR-DISPL 51MV160	51V160-A-C8-N-HE-B2-C-H-E6-AHA-032-AA-G0-12-00	SERIES 51	S51-160MV
83023821	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-1-AB-60-P-3-D7-D-03-GBA-42-42-24	SERIES 90	S90-075PV
83023822	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E2-AA-N-B-TB-CN-HN-N-A-05-NN-025-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83023823	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A5-C1-N-D6-H-G1-H5-L-42-L-42-C-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83023825	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-NN-80-S-3-C6-C-00-GBA-42-42-24	SERIES 90	S90-055PV
83023828	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-2-CD-80-P-3-S1-E-05-GBA-32-32-24	SERIES 90	S90-100PV
83023829	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-2-CD-80-P-3-C7-F-05-GBA-35-35-24	SERIES 90	S90-100PV
83023830	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A4-C2-N-D8-F-G5-NN-L-38-L-38-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83023832	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-DE-80-L-3-C8-H-03-GBA-29-29-24	SERIES 90	S90-130PV
83023833	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-DE-80-L-3-C8-H-03-GBA-29-29-24	SERIES 90	S90-130PV
83023837	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-G-S-A-S-BC-B-A-BRR-DA-A-WA-C-NNR-***	M46	M46-046PV
83023839	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-NN-80-R-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83023842	PUMP-VAR-DISPL CCW 90PV130	90L130-FH-2-BB-80-L-7-F1-H-B1-GCA-42-42-32	SERIES 90	S90-130PV
83023843	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-HS-A2-C-H-E1-NNN-054-AA-G0-16-30	SERIES 51	S51-080MV
83023844	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-NN-80-L-3-F1-H-03-GBA-29-29-24	SERIES 90	S90-130PV
83023845	PUMP-VAR-DISPL CW 90PV100	90R100-MA-5-BC-60-L-3-C7-E-C5-GBA-32-32-24	SERIES 90	S90-100PV
83023846	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-HE-HE-N-A-TB-VS-DS-S-A-15-NN-054-Z-00-NNN	H1-HP MOTORS	H1-110MB1

83023847	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-HE-HE-N-A-TB-VS-DS-S-A-20-NN-054-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83023848	PUMP-VAR-DISPL CW 90PV130	90R130-CA-5-NN-80-P-4-C8-H-00-GBA-42-42-30	SERIES 90	S90-130PV
83023849	MOTOR-VAR-DISPL 51MV160	51V160-A-C8-N-HZ-B1-C-H-C2-AHA-032-AA-G0-12-00	SERIES 51	S51-160MV
83023850	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-D-TA-C2-L-N-G0-NNN-095-AA-F0-00-C7	SERIES 51	S51-250MV
83023852	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-T2-D2-N-C-TB-VS-AS-S-A-05-NN-012-Z-20-NNN	H1-HP MOTORS	H1-060MB1
83023858	MOTOR-VAR-DISPL H1MB060	H1-B-060-A-L1-BA-N-B-PB-DS-GS-S-A-05-NN-024-N-00-NNN	H1-HP MOTORS	H1-060MB1
83023873	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-ANNB-02-C-2-A-2-E-N-A-30-30-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83023874	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-B9-C2-C-F4-H-G1-H6-L-25-L-25-C-M-24-P1-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83023875	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E1-AA-N-B-TA-DS-GS-S-A-10-NN-000-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83023879	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-C2-C2-C-F4-K-G9-H6-L-42-L-42-F-M-24-P2-NNN-D4F	H1-HP PUMPS	H1-069PV/078PV
83023880	MOTOR-VAR-DISPL H1MB060	H1-B-060-A-L1-BA-N-B-PB-VN-AN-N-A-05-NN-018-N-00-NNN	H1-HP MOTORS	H1-060MB1
83023881	MOTOR-VAR-DISPL 51MD160	51D160-A-D4-N-TN-F8-L-N-J2-ACA-080-AA-F3-00-BB	SERIES 51	S51-160MV
83023892	MOTOR-VAR-DISPL H1MB060	H1-B-060-A-L1-BA-N-B-PB-VS-AS-S-A-05-NN-018-N-00-NNN	H1-HP MOTORS	H1-060MB1
83023899	PUMP-TANDEM, VAR DISPL CCW H1T045L	H1-T-045-L-A-N-B1-C1-B-E7-F-G1-NN-35-35-35-35-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83023905	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-BC-60-R-3-C7-E-04-GBA-35-35-24	SERIES 90	S90-100PV
83023906	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-CD-60-P-3-F1-E-03-GBA-32-32-20	SERIES 90	S90-100PV
83023907	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-NN-60-L-3-S1-E-03-GBA-32-32-20	SERIES 90	S90-100PV
83023910	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A9-C1-B-E9-F-G1-H2-K-35-K-18-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83023911	PUMP-VAR DISPL, CW H1PV210	H1-P-210-R-A-A3-C2-N-D6-C-G2-H5-L-30-L-30-W-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-210PV/250PV
83023913	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-5-AB-80-S-3-C8-K-03-EFI-42-42-24	SERIES 90	S90-250PV
83023914	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-DE-80-T-M-C8-J-05-NNN-29-29-24	SERIES 90	S90-180PV
83023916	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-G3AN-52-P-D-G-2-H-1-N-41-41-N-0-0-NNN-NNN	SERIES 42	S42-028PV/032PV
83023918	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-C2-C2-C-D6-K-G9-H3-L-35-L-35-M-L-30-P2-NNN-D4F	H1-HP PUMPS	H1-089PV/100PV
83023919	PUMP-VAR-DISPL CW 90PV100	90R100-HF-5-CD-60-S-3-C7-F-02-GBA-30-30-24	SERIES 90	S90-100PV
83023920	MOTOR-FIX DISPL MMF044D	MMF-044-D-A-F-W-A-B-NNN-***	M35/44	O44MF
83023929	PUMP-VAR DISPL, CW 90PV100	90-R-100-DD-5-AB-60-P-4-S1-E-G8-GBA-35-35-24	SERIES 90	S90-100PV
83023930	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-DE-80-R-3-C8-H-03-GBA-32-32-24	SERIES 90	S90-130PV
83023931	PUMP-VAR-DISPL CW 90PV180	90R180-HS-1-BC-80-R-M-F1-H-00-NNN-37-37-28	SERIES 90	S90-180PV
83023938	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-5-NN-80-P-4-S1-E-03-GBA-23-23-28	SERIES 90	S90-075PV
83023939	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-HZ-B1-C-H-C2-NNN-125-AA-NN-15-00	SERIES 51	S51-250MV
83023942	PUMP-VAR-DISPL CW 90PV130	90R130-M8-1-CD-80-P-3-C8-H-02-GBA-38-38-24	SERIES 90	S90-130PV
83023953	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-BC-80-S-3-F1-E-06-GBA-23-23-24	SERIES 90	S90-100PV
83023955	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-NN-80-S-3-C7-E-03-GBA-23-23-24	SERIES 90	S90-100PV
83023957	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-EF-80-T-C-C8-J-03-NNN-32-32-24	SERIES 90	S90-180PV
83023958	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-AB-80-T-C-F1-J-03-NNN-32-32-24	SERIES 90	S90-180PV
83023959	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-E2C8-03-A-N-A-3-F-N-B-30-30-B-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV

83023960	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-E2C8-03-A-N-N-A-P-N-Z-30-30-B-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83023962	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-NN-60-R-3-F1-D-03-GBA-29-13-18	SERIES 90	S90-100PV
83023963	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-L2-BA-N-B-PB-VN-AN-N-N-NN-NN-016-N-00-NNN	H1-HP MOTORS	H1-080MB1
83023964	PUMP-VAR DISPL, CW 90PV075	90-R-075-HF-1-BC-60-P-3-C6-D-03-GBA-35-35-18	SERIES 90	S90-075PV
83023973	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-AB-80-T-M-C8-H-03-NNN-38-38-24	SERIES 90	S90-180PV
83023974	PUMP-VAR-DISPL CW 90PV075	90R075-MA-5-BB-80-S-3-S1-D-C5-GBA-35-35-30	SERIES 90	S90-075PV
83023976	MOTOR-FIX DISPL 90MF130	90-M-130-NC-0-N-8-N-0-C8-W-00-EBA-00-00-G3	SERIES 90	S90-130MF
83023978	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-EG-80-T-C-C8-J-03-NNN-29-29-24	SERIES 90	S90-180PV
83023979	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-NN-80-T-C-C8-J-03-NNN-29-29-24	SERIES 90	S90-180PV
83023981	PUMP-VAR-DISPL CW 90PV250	90R250-HF-1-NN-80-T-4-F1-K-03-NNN-42-42-24	SERIES 90	S90-250PV
83023982	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-NN-60-R-3-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83023984	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-E1A7-03-A-N-A-2-F-N-A-28-28-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83023985	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-2-NN-80-S-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83023986	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-CD-80-L-3-C8-H-05-GBA-42-42-28	SERIES 90	S90-130PV
83023988	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E2-AA-N-B-TB-CN-JN-N-N-NN-NN-033-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83023993	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A5-C1-B-D3-G-G3-H2-L-30-L-30-A-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83023996	PUMP-VAR-DISPL CCW 90PV100	90L100-FA-5-BC-60-S-7-C7-E-B1-GBA-35-35-24	SERIES 90	S90-100PV
83023997	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-L1-BA-N-B-PB-VN-EN-N-A-10-NN-056-N-00-NNN	H1-HP MOTORS	H1-110MB1
83023998	PUMP-VAR-DISPL CW 90PV075	90R075-KA-1-NN-80-S-4-C7-E-03-GBA-35-35-24	SERIES 90	S90-075PV
83024006	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-BB-61-P-3-S1-E-03-GBA-32-32-24	SERIES 90	S90-075PV
83024007	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-BC-81-P-3-S1-E-03-GBA-32-32-24	SERIES 90	S90-075PV
83024012	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-D2-MA-N-B-PB-DN-KN-N-A-10-NN-022-N-20-NNN	H1-HP MOTORS	H1-110MB1
83024017	PUMP-VAR-DISPL 42PV041 CCW	42-L-51-C-F5NN-73-J-2-B-2-H-N-N-34-NN-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83024018	PUMP-VAR-DISPL CCW 90PV075	90L075-HF-1-BC-80-S-4-S1-D-03-GBA-26-26-20	SERIES 90	S90-075PV
83024020	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A2-C2-N-F6-H-G1-H6-L-33-L-33-C-L-22-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83024021	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E2-AA-N-B-TB-VN-EN-N-A-15-NN-070-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83024033	PUMP-VAR-DISPL CCW 90PV130	90L130-HF-1-BC-80-S-4-F1-F-03-GBA-17-17-20	SERIES 90	S90-130PV
83024034	PUMP-VAR-DISPL CCW 90PV100	90L100-KP-1-NN-80-P-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83024035	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A5-C1-B-D8-H-G1-H3-L-35-L-35-F-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83024036	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-P2-D2-N-A-TA-DS-JS-S-A-10-NN-036-Z-24-NNN	H1-HP MOTORS	H1-110MB1
83024037	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-C2-C2-C-F5-K-G9-H6-L-42-L-42-C-P-24-P2-NNN-D4F	H1-HP PUMPS	H1-069PV/078PV
83024039	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-HE-HE-N-B-TB-VN-EN-N-A-10-NN-000-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83024040	PUMP-VAR-DISPL CCW 90PV075	90L075-KP-5-BC-80-S-3-S1-D-03-GBA-38-38-26	SERIES 90	S90-075PV
83024047	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-AB-80-P-3-C7-F-06-GBA-35-35-24	SERIES 90	S90-100PV
83024048	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-B7-C2-C-D6-K-G9-H3-L-48-L-48-C-L-28-P2-NNN-D5F	H1-HP PUMPS	H1-069PV/078PV
83024056	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A7-C2-C-D6-K-G9-H3-L-45-L-45-C-L-24-P2-NNN-D3E	H1-HP PUMPS	H1-069PV/078PV

83024057	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-K1-K1-N-B-RA-VS-DS-S-A-20-NN-032-N-23-NNN	H1-HP MOTORS	H1-160MB1
83024058	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-M1-CA-N-A-RA-VS-DS-S-A-20-NN-000-N-00-NNN	H1-HP MOTORS	H1-160MB1
83024061	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-T2-DA-N-A-TB-CS-JS-P-N-NN-NN-016-Z-20-NNN	H1-HP MOTORS	H1-080MB1
83024074	PUMP-VAR-DISPL CW 90PV100	90R100-HF-1-CD-80-L-3-S1-F-00-GBA-23-23-24	SERIES 90	S90-100PV
83024085	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-G3AN-52-P-3-G-3-F-1-A-34-34-N-0-0-NNN-NNN	SERIES 42	S42-028PV/032PV
83024092	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A5-C2-N-D6-H-G1-NN-L-42-L-42-D-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83024093	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A4-C1-N-D8-F-G1-H3-L-35-L-35-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83024094	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A4-C1-N-D3-H-G1-H3-L-35-L-35-C-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83024096	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HF-5-BC-80-R-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83024099	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A3-C1-N-D8-H-G1-NN-K-35-K-35-C-P-26-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83024102	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-HE-HE-N-B-TA-VS-AS-S-N-NN-NN-032-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83024103	PUMP-VAR-DISPL CCW 90PV100	90L100-HF-5-BC-80-R-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83024110	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A4-C2-N-D8-F-G5-NN-L-33-L-33-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83024116	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A5-C2-B-D8-G-G2-NN-L-35-L-35-A-P-20-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83024120	MOTOR-VARIABLE CARTRIDGE L	L-C-35EN-A-RNF-F09-S-N-N-BF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83024121	MOTOR-VARIABLE CARTRIDGE L	L-C-35EN-A-RNF-F08-S-N-N-BF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83024122	MOTOR-VARIABLE CARTRIDGE L	L-C-35EN-A-RNF-F01-S-N-N-BF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83024123	PUMP-VAR-DISPL CW 90PV075	90R075-FK-1-NN-80-P-7-C6-D-B6-GME-45-45-30	SERIES 90	S90-075PV
83024124	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-T2-D2-N-B-TB-DS-ES-S-N-NN-NN-028-Z-22-NNN	H1-HP MOTORS	H1-110MB1
83024125	PUMP-VAR-DISPL CCW H1PV069	H1-P-069-L-A-A5-C3-N-D8-H-F1-H3-L-40-L-40-N-E-28-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83024127	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E2-AA-N-B-TA-DN-KN-N-N-NN-NN-055-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83024128	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-E2-AA-N-B-TB-DN-KN-N-N-NN-NN-064-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83024138	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A2-C3-N-D1-F-G7-H7-35-35-35-35-N-P-28-PN-C01-NNN	H1-MP PUMPS	H1-045PT/053PT
83024142	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A5-C2-B-D8-H-G9-NN-L-35-L-35-D-P-20-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83024144	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-N-A5-C2-N-E7-F-G1-H2-38-38-38-38-N-P-28-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83024147	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A4-C2-N-E7-F-G1-H3-23-23-23-23-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83024149	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-K-T-B-M-BA-A-A-BJJ-BA-A-GG-B-NNN-***	M46	M46-046PV
83024154	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-N-A5-C2-N-E7-F-G1-TN-38-38-38-38-M-P-28-PN-NNN-S01	H1-MP PUMPS	H1-045PT/053PT
83024159	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-E1A6-03-B-2-B-3-F-N-B-34-34-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83024160	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-E2C8-03-A-N-N-N-P-N-B-30-30-B-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83024162	MOTOR-VAR-DISPL 51MV160	51V160-A-C8-N-D8-M1-R-J-N7-NNN-105-AA-H0-C2-25	SERIES 51	S51-160MV
83024177	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-N-A3-C1-N-F7-F-G5-H2-38-38-38-38-N-P-22-P3-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83024182	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-D2-M2-N-A-PB-VN-DN-N-A-15-NN-047-N-21-NNN	H1-HP MOTORS	H1-110MB1
83024184	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-5-NN-80-P-3-S1-E-03-GBA-33-33-24	SERIES 90	S90-100PV
83024188	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KN-1-CD-80-R-4-S1-D-03-GBA-29-29-24	SERIES 90	S90-075PV
83024189	PUMP-VAR-DISPL CW 90PV250	90R250-KN-5-EG-80-T-4-C8-K-03-NNN-35-35-24	SERIES 90	S90-250PV

83024194	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A2-C2-B-F4-H-G1-H6-L-30-L-30-F-M-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83024195	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-T1-D1-N-B-TB-DS-GS-S-A-05-NN-035-Z-20-NNN	H1-HP MOTORS	H1-060MB1
83024196	PUMP-VAR-DISPL CCW H1PV089	H1-P-089-L-A-B8-C1-D-D8-H-F1-H3-L-35-L-35-N-E-34-P1-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83024206	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-D-E2D8-03-D-N-F-2-F-N-B-34-34-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83024207	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-C-E2D8-03-D-N-F-2-F-N-N-34-34-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83024217	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-N-L3-B1-W-B-G5-NNN-032-AA-NN-D4-00	SERIES 51	S51-160MV
83024218	PUMP-VAR-DISPL CW 90PV130	90R130-HS-5-AB-80-R-3-F1-F-03-GBA-23-23-24	SERIES 90	S90-130PV
83024219	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HS-1-NN-80-R-3-S1-D-03-GBA-38-38-24	SERIES 90	S90-075PV
83024221	MOTOR-FIX DISPL MMF044D	MMF-044-D-A-F-5-C-T-NNR-***	M35/44	044MF
83024222	PUMP-VAR-DISPL CCW 90PV250	90L250-HF-5-BC-80-D-4-F1-L-03-NNN-35-35-30	SERIES 90	S90-250PV
83024224	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-N-T1-C2-L-N-G0-NNN-032-AA-NN-00-B4	SERIES 51	S51-160MV
83024225	PUMP-VAR-DISPL CW 90PV130	90R130-KT-1-CD-80-R-4-F1-F-03-GBA-26-26-20	SERIES 90	S90-130PV
83024226	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A5-C2-N-D8-G-G3-H3-L-35-L-38-A-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83024227	MOTOR-VAR-DISPL H1MB060	H1-B-060-A-L2-BA-N-B-PB-CS-GS-S-A-05-NN-000-N-00-NNN	H1-HP MOTORS	H1-060MB1
83024228	PUMP-VAR-DISPL CW 90PV250	90R250-MA-5-EF-80-S-3-C8-J-C6-NNN-38-38-30	SERIES 90	S90-250PV
83024232	PUMP-VAR DISPL, CW 90PV100	90-R-100-KN-1-AC-80-P-4-C7-F-03-GBA-26-26-24	SERIES 90	S90-100PV
83024234	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-P1-D1-N-B-TA-DS-HS-S-A-10-NN-030-Z-24-NNN	H1-HP MOTORS	H1-080MB1
83024237	MOTOR-VARIABLE DISPL SAE_K	K-V-45DN-A-YNF-F01-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83024238	PUMP-VAR DISPL, CW 90PV075	90-R-075-LE-1-CD-80-L-3-S1-D-03-GBA-29-29-24	SERIES 90	S90-075PV
83024240	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-E2C8-02-B-D-B-2-H-N-B-32-32-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83024241	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-E2C8-02-B-D-B-3-H-N-V-25-25-N-A-A-NNN-NNN	SERIES 42	S42-041PV/051PV
83024247	PUMP-VAR DISPL CCW H1P053L	H1-P-053-L-A-A4-C2-N-E9-F-G5-NN-K-35-K-35-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83024248	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-AB-80-P-3-C7-F-09-GBA-35-35-24	SERIES 90	S90-100PV
83024249	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-HE-HE-N-A-TA-CN-GN-N-N-NN-NN-000-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83024253	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KT-1-CD-80-L-3-S1-C-03-GBA-29-29-24	SERIES 90	S90-055PV
83024256	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-A-V-C-B-BA-B-B-G-A-BJJ-CB-A-GG-B-D-G-A-BJJ-CB-A-GG-A-NNN-**	M46	M46-046PT
83024264	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-T1-D1-N-A-TA-DS-KS-S-A-20-NN-036-Z-25-NNN	H1-HP MOTORS	H1-160MB1
83024265	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-N-A4-C2-N-D1-F-G1-H5-38-38-38-38-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83024266	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-B1-C1-B-D8-H-G9-H5-L-42-L-42-N-E-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83024268	PUMP-VAR-DISPL CW 90PV180	90R180-KN-5-AB-80-S-C-F1-J-02-NNN-26-26-24	SERIES 90	S90-180PV
83024269	PUMP-VAR-DISPL CW 90PV180	90R180-KN-5-EF-80-S-C-C8-J-02-NNN-26-26-24	SERIES 90	S90-180PV
83024273	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-ANN3-03-C-3-A-2-F-N-A-30-30-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83024276	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-NN-80-L-3-C7-E-03-GBA-23-23-24	SERIES 90	S90-100PV
83024282	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-E2D8-03-D-N-F-2-F-N-N-34-34-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83024283	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-E2D8-03-D-N-F-2-F-N-B-34-34-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83024287	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-L-N-0-C6-W-00-EED-00-00-A0	SERIES 90	S90-075MF

83024288	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-8-N-0-C7-W-00-NNN-00-00-F0	SERIES 90	S90-100MF
83024289	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-8-N-0-S1-W-00-NNN-00-00-F3	SERIES 90	S90-100MF
83024290	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-8-N-0-C6-W-00-EAJ-00-00-F3	SERIES 90	S90-075MF
83024291	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-7-N-0-C6-W-00-EFE-00-00-F3	SERIES 90	S90-055MF
83024293	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-T1-D1-N-B-TB-CS-JS-S-A-10-NN-074-Z-18-NNN	H1-HP MOTORS	H1-110MB1
83024295	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-HE-HE-N-B-TA-VN-AN-N-N-NN-NN-032-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83024298	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A7-C2-C-D3-K-G9-NN-L-42-L-42-C-M-30-P2-NNN-D3F	H1-HP PUMPS	H1-069PV/078PV
83024299	PUMP-VAR-DISPL CW 90PV100	90R100-MA-1-AB-60-S-3-S1-E-03-GBA-23-23-24	SERIES 90	S90-100PV
83024300	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-L2-BA-N-B-PB-CS-KS-S-A-20-NN-043-N-00-NNN	H1-HP MOTORS	H1-160MB1
83024302	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-L2-BA-N-B-PB-DS-LS-S-A-20-NN-043-N-00-NNN	H1-HP MOTORS	H1-160MB1
83024310	PUMP-VAR-DISPL CW 90PV130	90R130-DD-5-BC-80-S-3-F1-H-GB-GBA-35-35-28	SERIES 90	S90-130PV
83024325	PUMP- VARIABLE, DIRECT DISPLACMENT	LPV-A-A-A-A-I-DC-C-A-BFF-DR-A-FF-B-NNN-***	LPV	LPV
83024331	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-D-HZ-B1-B-H-J1-ACA-050-AA-F3-11-00	SERIES 51	S51-250MV
83024332	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A2-C1-N-D8-F-G5-H1-L-38-L-38-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83024337	PUMP-VAR-DISPL 42PV041 CCW	42-L-41-E-E1A5-03-A-N-A-2-F-N-B-28-28-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83024340	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-HE-HE-N-B-TB-VN-EN-N-A-20-NN-000-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83024343	MOTOR-FIX DISPL 90MF055	90-M-055-NC-A-N-J-N-0-C6-W-00-CBD-34-34-11-P020	SERIES 90	S90-055MF
83024347	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-HZ-B1-B-H-C2-NNN-050-AA-NN-06-00	SERIES 51	S51-250MV
83024349	PUMP-VAR-DISPL CCW 90PV130	90L130-KN-1-AB-80-R-4-F1-F-03-GBA-42-42-24	SERIES 90	S90-130PV
83024350	PUMP-VAR-DISPL CCW 90PV130	90L130-KN-1-CD-80-R-4-F1-F-03-GBA-42-42-24	SERIES 90	S90-130PV
83024352	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A9-C2-N-D6-F-G5-H5-L-35-L-35-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83024358	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-1-BC-80-R-4-S1-C-03-GBA-32-32-24	SERIES 90	S90-055PV
83024359	PUMP-VAR-DISPL CW 90PV180	90R180-MA-2-BC-80-S-C-C8-H-02-FAC-38-38-24	SERIES 90	S90-180PV
83024360	PUMP-VAR DISPL, CW 90PV055	90-R-055-HS-1-NN-60-S-3-S1-C-09-GBA-35-35-24	SERIES 90	S90-055PV
83024361	PUMP-VAR DISPL MPV046C	MPV-046-C-B-A-H-S-B-B-AA-A-A-BBB-AK-D-BB-A-NNN-***	M46	M46-046PV
83024366	PUMP-VAR DISPL, CW 90PV055	90-R-055-FB-2-BC-60-P-4-C6-C-B1-GBA-35-35-24	SERIES 90	S90-055PV
83024380	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-8-N-0-S1-W-00-EGH-00-00-G0	SERIES 90	S90-075MF
83024386	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-L2-BA-N-B-PA-VS-AS-S-A-05-NN-016-N-00-NNN	H1-HP MOTORS	H1-080MB1
83024387	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-L2-BA-N-B-PA-VS-DS-S-A-10-NN-022-N-00-NNN	H1-HP MOTORS	H1-110MB1
83024388	PUMP-VAR DISPL CCW H1P060L	H1-P-060-L-A-A3-C2-N-F6-H-F1-H6-L-42-L-42-C-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83024392	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-1-NN-60-P-3-C7-D-03-GBA-42-42-24	SERIES 90	S90-075PV
83024393	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A4-C1-N-D6-H-F1-NN-L-38-L-38-C-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83024400	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-T2-D2-N-C-TA-VS-ES-S-A-10-NN-074-Z-25-NNN	H1-HP MOTORS	H1-110MB1
83024401	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-T2-D2-N-C-TA-VS-DS-S-A-20-NN-074-Z-25-NNN	H1-HP MOTORS	H1-160MB1
83024405	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-N-A5-C2-N-F7-F-G1-H5-38-38-38-38-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83024406	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-CD-80-T-M-C8-H-03-EBA-42-42-24	SERIES 90	S90-180PV

83024407	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-NN-60-R-3-F1-F-03-FAD-42-42-34	SERIES 90	S90-100PV
83024409	PUMP-VAR-DISPL CCW 90PV180	90L180-KN-1-NN-80-T-M-F1-H-03-FAC-42-42-24	SERIES 90	S90-180PV
83024411	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-HE-HE-N-B-TA-CN-JN-N-N-NN-NN-040-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83024412	PUMP-VAR DISPL MPV044D	MPV-044-D-B-A-A-R-S-G-AA-A-A-BFF-DR-A-FF-A-NNN-***	M35/44	044PV
83024414	PUMP-VAR DISPL CW H1P068R	H1-P-068-R-A-A2-C2-N-F5-H-G1-H6-L-35-L-35-C-P-30-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83024415	PUMP-VAR DISPL CW H1P068R	H1-P-068-R-A-A2-C2-N-D8-H-G1-NN-L-35-L-35-C-P-30-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83024416	PUMP-TANDEM, VAR DISPL MPT044D	MPT-044-D-A-W-S-J-AA-B-A-A-A-BDD-DR-A-FF-B-C-A-A-BDD-DL-A-FF-D-NNN-*	M35/44	044PT
83024419	PUMP-VAR-DISPL CCW H1PV165	H1-P-165-L-C-A5-C3-B-D9-G-G2-H4-L-42-L-42-L-L-28-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83024420	PUMP-VAR-DISPL CCW H1PV165	H1-P-165-L-C-A5-C3-B-D6-G-G3-H3-L-42-L-42-L-L-28-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83024425	MOTOR-VAR DISPL MMV046C	MMV-046-C-A-A-F-A-AX-NNN-***	M46	M46-046MV
83024431	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-CD-80-L-4-C8-H-21-GBA-42-42-24	SERIES 90	S90-130PV
83024432	PUMP-VAR DISPL CCW H1P053L	H1-P-053-L-A-A3-C2-N-D6-F-G1-H3-L-38-L-38-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83024444	PUMP- VARIABLE, DIRECT DISPLACMENT	LPV-A-A-A-A-E-AB-C-A-BGG-DR-A-FF-B-NNN-***	LPV	LPV
83024445	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-NN-80-P-3-C3-C-00-GBA-35-35-24	SERIES 90	S90-042PV
83024446	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A5-C2-N-F6-H-G9-H6-L-33-L-33-M-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83024447	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A5-C2-N-D6-H-G1-H3-L-30-L-30-C-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83024448	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E2-AA-N-B-TB-VN-DN-N-A-10-NN-070-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83024451	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-A-A4-C2-N-E7-F-G1-H5-28-28-35-35-N-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83024452	MOTOR-VARIABLE DISPL SAE_K	K-V-38CN-A-R2F-F07-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83024456	PUMP-VAR-DISPL CW 90PV250	90R250-KA-1-NN-80-T-3-C8-K-09-NNN-32-32-24	SERIES 90	S90-250PV
83024457	PUMP-VAR-DISPL CW 90PV250	90R250-KA-1-EG-80-T-3-C8-K-09-NNN-32-32-24	SERIES 90	S90-250PV
83024458	MOTOR-VAR-DISPL H1MB060	H1-B-060-A-M2-CA-N-A-RA-VN-AN-N-N-NN-NN-000-N-00-NNN	H1-HP MOTORS	H1-060MB1
83024463	PUMP-TANDEM, VAR DISPL CCW H1T053L	H1-T-053-L-A-N-A4-C2-N-D1-F-G1-NN-33-33-33-33-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83024466	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-AB-80-P-3-C3-B-03-GBA-42-16-24	SERIES 90	S90-042PV
83024474	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-DE-80-R-4-C8-H-03-GBA-36-36-30	SERIES 90	S90-130PV
83024475	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-1-AB-80-R-4-C8-F-00-GBA-35-35-24	SERIES 90	S90-130PV
83024476	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-AB-80-L-4-F1-H-03-EBA-29-29-24	SERIES 90	S90-130PV
83024477	PUMP-VAR DISPL, CW 90PV100	90-R-100-HS-1-NN-80-S-4-S1-E-03-GBA-32-32-24	SERIES 90	S90-100PV
83024479	PUMP-VAR-DISPL CW 90PV100	90R100-MA-1-AB-80-S-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83024485	PUMP-VAR-DISPL CW 90PV250	90R250-KN-5-CD-80-T-4-F1-K-03-NNN-30-30-24	SERIES 90	S90-250PV
83024492	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-N-HZ-B1-B-H-G5-NNN-080-AA-NN-05-00	SERIES 51	S51-160MV
83024493	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A5-C1-N-D6-H-F1-NN-L-38-L-38-C-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83024505	PUMP-VAR DISPL, CW 90PV055	90-R-055-HS-5-NN-80-P-3-C6-C-03-GBA-38-38-24	SERIES 90	S90-055PV
83024506	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-T1-DA-N-B-TB-CN-GN-N-A-10-NN-035-Z-25-NNN	H1-HP MOTORS	H1-060MB1
83024513	MOTOR-VAR-DISPL 51MV250	51V250-V-F2-B-HZ-B1-A-N-G0-NNN-050-AA-E6-05-00	SERIES 51	S51-250MV
83024514	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-G-G3AN-50-P-D-B-3-G-5-N-34-34-N-1-1-NNN-BNN	SERIES 42	S42-028PV/032PV

83024515	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-HE-HE-N-B-TB-VN-EN-N-A-15-NN-064-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83024523	PUMP-VAR DISPL, CW 90PV075	90-R-075-HF-1-AB-60-P-3-C6-D-03-GBA-35-35-18	SERIES 90	S90-075PV
83024525	PUMP-VAR-DISPL CCW H1PV089	H1-P-089-L-A-A5-C1-B-D8-H-F1-H3-L-35-L-35-N-E-34-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83024528	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-B7-C2-C-D8-L-G3-H5-L-45-L-45-L-P-24-P2-NNN-D5F	H1-HP PUMPS	H1-147PV/165PV
83024533	PUMP-VAR DISPL, CW 90PV100	90-R-100-HS-1-NN-80-S-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83024534	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-NN-80-S-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83024535	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-T2-DA-N-B-TB-DS-JS-S-A-15-NN-044-Z-28-NNN	H1-HP MOTORS	H1-110MB1
83024536	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-T2-DA-N-B-TB-VS-ES-S-A-30-NN-080-Z-25-NNN	H1-HP MOTORS	H1-160MB1
83024537	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-P2-D2-N-A-TB-DS-JS-S-A-10-NN-020-Z-24-NNN	H1-HP MOTORS	H1-080MB1
83024538	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E2-AA-N-B-TB-CS-GS-P-N-NN-NN-022-Q-00-NNN	H1-HP MOTORS	H1-060MB1
83024539	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E2-AA-N-B-TB-CS-GS-S-N-NN-NN-022-Q-00-NNN	H1-HP MOTORS	H1-060MB1
83024551	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-AB-60-P-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83024565	PUMP-VAR DISPL, CW 90PV100	90-R-100-HF-1-NN-80-S-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83024569	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-C-E1A6-01-B-3-B-3-H-N-B-34-34-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83024577	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A4-C3-N-D1-F-G1-H3-25-25-25-25-N-P-22-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83024578	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E2-AA-N-B-TB-CN-JN-N-A-10-NN-033-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83024579	PUMP-VAR-DISPL CW 90PV130	90R130-KA-1-DE-80-R-3-F1-H-09-GBA-38-38-34	SERIES 90	S90-130PV
83024580	PUMP-VAR-DISPL CW 90PV130	90R130-KA-1-BC-80-R-3-F1-H-09-GBA-38-38-34	SERIES 90	S90-130PV
83024583	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-P1-D1-N-B-TA-DS-HS-S-A-10-NN-016-Z-24-NNN	H1-HP MOTORS	H1-080MB1
83024595	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-1-CD-60-L-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83024596	PUMP-VAR DISPL CCW H1P068L	H1-P-068-L-A-A2-C2-B-F6-H-G1-H6-L-28-L-28-C-L-20-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83024597	PUMP-VAR DISPL CCW H1P068L	H1-P-068-L-A-A2-C2-B-D6-H-G1-H2-L-28-L-28-C-L-20-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83024598	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-1-NN-60-L-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83024599	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A3-C2-N-F6-H-G9-H6-L-42-L-42-M-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83024601	PUMP-VAR-DISPL CW 90PV180	90R180-KP-5-CD-80-T-M-C8-H-03-FAC-38-38-24	SERIES 90	S90-180PV
83024602	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-NN-80-L-4-F1-H-03-GBA-38-38-24	SERIES 90	S90-130PV
83024603	PUMP-VAR-DISPL CW 90PV075	90R075-KP-5-NN-80-L-4-S1-E-03-GBA-38-38-24	SERIES 90	S90-075PV
83024604	PUMP-VAR-DISPL CW 90PV180	90R180-KP-5-DE-80-T-M-C8-H-03-FAC-38-38-24	SERIES 90	S90-180PV
83024606	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-G3AN-53-P-D-B-3-G-5-T-30-30-B-0-0-NNN-NNN	SERIES 42	S42-028PV/032PV
83024622	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-CD-60-R-3-S1-D-00-GBA-42-42-32	SERIES 90	S90-075PV
83024626	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-F2-C1-D-D8-F-G1-H5-L-18-L-38-B-P-24-P1-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83024631	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-NN-80-R-3-C7-F-03-GBA-26-26-24	SERIES 90	S90-100PV
83024632	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-HE-HE-N-B-TB-CN-EN-N-A-20-NN-063-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83024633	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A2-C2-N-F4-H-G1-H6-L-35-L-35-F-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83024634	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-AB-80-L-4-F1-H-03-EBA-29-29-24	SERIES 90	S90-130PV
83024657	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-NN-80-P-3-C7-D-00-GBA-35-35-24	SERIES 90	S90-075PV

83024658	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A4-C2-B-D6-F-G5-H2-L-28-L-28-B-L-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83024659	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A4-C2-B-D6-F-G5-H3-L-28-L-28-B-L-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83024665	PUMP-VAR DISPL, CW 90PV075	90-R-075-KN-5-AB-80-S-4-S1-E-03-GBA-26-26-24	SERIES 90	S90-075PV
83024666	MOTOR-VAR-DISPL H1B060	H1-B-060-A-TA-DA-N-B-TB-VN-AN-N-A-10-NN-036-Z-23-NNN	H1-HP MOTORS	H1-060MB1
83024670	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A5-C2-B-D6-H-G9-H5-L-30-L-30-M-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83024674	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-BC-80-R-4-S1-E-09-GBA-38-38-24	SERIES 90	S90-075PV
83024687	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-BC-60-P-3-C7-E-03-GBA-40-40-20	SERIES 90	S90-100PV
83024689	PUMP-TANDEM, VAR DISPL MPT035D	MPT-035-D-C-R-A-M-NN-B-A-A-A-BJJ-DL-A-FF-B-C-A-A-BJJ-DL-A-FF-1-NNN-***	M35/44	035PT
83024691	MOTOR-VARIABLE CARTRIDGE K	K-C-45DN-E-R4F-F08-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83024692	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-H-S-B-J-BA-A-A-BJJ-CE-A-HH-3-NNN-***	M46	M46-046PV
83024693	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HF-5-NN-80-S-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83024694	PUMP-VAR DISPL CCW H1P053L	H1-P-053-L-A-A4-C1-B-E5-F-G5-H3-L-28-L-28-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83024695	PUMP-VAR-DISPL CCW H1PV130	H1-P-130-L-B-A2-C1-N-D8-G-G3-H3-L-42-L-42-A-P-30-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83024699	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-N-A8-C2-C-E7-F-G6-H3-38-38-38-38-N-P-24-P1-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83024707	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A2-C2-N-D3-H-G9-NN-L-45-L-45-C-M-20-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83024708	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-HE-HE-N-B-TA-DS-KS-S-A-15-NN-070-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83024719	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-1-NN-60-P-4-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83024721	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A5-C2-N-D3-H-G1-NN-L-35-L-35-M-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83024723	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-CD-80-S-4-S1-C-03-GBA-40-40-20	SERIES 90	S90-055PV
83024724	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-AB-80-S-4-S1-C-03-GBA-40-40-20	SERIES 90	S90-055PV
83024726	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A5-C2-N-F4-H-G1-H6-L-28-L-28-M-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83024728	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-NN-60-S-3-S1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
83024729	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-NN-60-S-4-C7-E-03-GBA-42-42-24	SERIES 90	S90-075PV
83024739	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-D2-MA-N-C-PB-DN-KN-N-N-NN-NN-091-N-22-NNN	H1-HP MOTORS	H1-160MB1
83024740	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-NN-80-S-3-C3-C-00-GLA-23-23-28	SERIES 90	S90-042PV
83024741	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-L2-BB-N-N-PA-DS-BS-S-A-15-NN-016-N-00-N05	H1-HP MOTORS	H1-080MB1
83024742	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-5-EG-80-S-4-C8-J-03-NNN-30-30-24	SERIES 90	S90-250PV
83024743	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-5-NN-80-S-4-C8-J-03-NNN-30-30-24	SERIES 90	S90-250PV
83024761	PUMP-VAR-DISPL CCW 90PV130	90L130-HF-5-AB-80-R-4-F1-H-03-GBA-17-35-24	SERIES 90	S90-130PV
83024767	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-E1A6-11-C-2-A-2-F-N-B-34-34-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83024774	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-CD-80-S-3-TF-E-03-FAC-45-45-28	SERIES 90	S90-100PV
83024775	PUMP-VAR DISPL MPV044D	MPV-044-D-B-A-Y-S-S-BA-A-A-BBB-DL-A-FF-A-NNN-***	M35/44	044PV
83024780	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-D-E1A7-00-B-D-B-2-G-N-V-28-28-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83024785	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-L1-BA-N-A-PA-VN-EN-N-N-NN-NN-078-N-00-NNN	H1-HP MOTORS	H1-160MB1
83024786	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-ANN5-03-D-N-F-2-F-N-B-34-34-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83024787	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-ANN5-03-D-N-F-2-F-N-N-34-34-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV

83024788	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-ANN5-03-D-N-F-2-F-N-B-34-34-B-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83024789	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-ANN5-03-D-N-F-2-F-N-N-34-34-B-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83024790	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-P1-D1-N-B-TA-DS-JS-S-A-15-NN-031-Z-24-NNN	H1-HP MOTORS	H1-110MB1
83024791	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-P1-D1-N-B-TA-DS-KS-S-A-20-NN-034-Z-24-NNN	H1-HP MOTORS	H1-160MB1
83024793	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A5-C1-N-D3-G-G3-H3-L-42-L-42-A-M-28-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83024796	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-AB-80-S-3-TF-E-03-FAC-45-45-28	SERIES 90	S90-100PV
83024797	MOTOR-VAR-DISPL 51MC160	51C160-R-D5-N-L2-B1-V-A-M3-NNN-092-AA-H0-B2-00	SERIES 51	S51-160MV
83024802	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-P1-D1-N-B-TA-DS-KS-S-A-20-NN-032-Z-24-NNN	H1-HP MOTORS	H1-160MB1
83024806	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-A-A7-C1-C-D3-K-G9-H5-L-45-L-45-M-M-24-P2-NNN-D3E	H1-HP PUMPS	H1-089PV/100PV
83024807	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-K1-K1-N-C-RA-DS-HS-S-A-10-NN-040-N-30-NNN	H1-HP MOTORS	H1-080MB1
83024811	MOTOR-VAR-DISPL H1MB060	H1-B-060-A-L1-BA-N-B-PA-VS-AS-S-N-NN-NN-019-N-00-NNN	H1-HP MOTORS	H1-060MB1
83024815	PUMP-VAR-DISPL CCW H1PV130	H1-P-130-L-B-A2-C3-N-D8-G-G3-H3-L-38-L-38-L-P-28-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83024819	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-HE-HE-N-B-TA-DS-KS-S-N-NN-NN-108-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83024823	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-1-CD-60-S-3-T6-E-03-GBA-26-26-26	SERIES 90	S90-100PV
83024824	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-1-NN-60-S-3-S1-E-03-GBA-26-26-26	SERIES 90	S90-100PV
83024830	PUMP-VAR-DISPL CW 90PV250	90R250-MA-5-AB-80-S-3-F1-J-C6-NNN-38-38-30	SERIES 90	S90-250PV
83024852	PUMP-VAR DISPL MPV035D	MPV-035-D-B-A-A-W-S-G-AA-A-A-BEE-DR-A-FF-C-NNN-***	M35/44	035PV
83024853	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A3-C3-N-F5-H-F1-H6-K-40-K-40-C-P-24-PN-C07-NNN	H1-MP PUMPS	H1-060PV/068PV
83024854	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A3-C3-N-D8-H-G1-NN-K-40-K-40-C-P-24-PN-C07-NNN	H1-MP PUMPS	H1-060PV/068PV
83024855	MOTOR-VAR-DISPL 51MC160	51C160-R-D5-N-L4-B1-V-A-M3-NNN-092-AA-H0-B2-00	SERIES 51	S51-160MV
83024857	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-1-NN-60-S-4-C6-C-03-GBA-32-32-24	SERIES 90	S90-055PV
83024869	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-5-AB-80-S-7-C7-E-09-FAC-35-35-30	SERIES 90	S90-100PV
83024870	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-5-NN-80-S-3-S1-E-03-GBA-32-32-24	SERIES 90	S90-075PV
83024882	MOTOR-VAR-DISPL H1B250	H1-B-250-A-D2-M2-N-B-PA-VS-FS-S-A-30-NN-050-N-25-NNN	H1-HP MOTORS	H1-250MB1
83024884	PUMP-VAR-DISPL CW 90PV180	90R180-DD-5-CD-80-S-M-C8-J-GJ-NNN-35-35-30	SERIES 90	S90-180PV
83024887	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-A-A5-C2-N-D3-H-G9-H3-L-35-L-35-M-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83024888	PUMP-VAR-DISPL CW 90PV130	90R130-SA-2-BC-80-L-3-C8-F-33-PGA-35-35-28	SERIES 90	S90-130PV
83024889	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-HE-HE-N-B-TB-VN-AN-N-A-10-NN-040-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83024893	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-L2-BA-N-B-PB-CN-JN-N-A-10-NN-030-N-00-NNN	H1-HP MOTORS	H1-110MB1
83024904	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-L1-BA-N-B-PA-DS-JS-S-A-10-NN-046-N-00-NNN	H1-HP MOTORS	H1-080MB1
83024921	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-E2-AA-N-B-TA-VS-ES-S-A-20-NN-100-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83024931	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-D2-MA-N-B-PA-DS-KS-S-N-NN-NN-108-N-25-NNN	H1-HP MOTORS	H1-160MB1
83024932	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-1-CD-80-D-4-C8-L-03-NNN-35-35-30	SERIES 90	S90-250PV
83024935	MOTOR-VAR-DISPL H1B110	H1-B-110-A-TA-DA-N-B-TA-VS-ES-S-N-NN-NN-070-Z-16-NNN	H1-HP MOTORS	H1-110MB1
83024940	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-C8-N-E1-B1-N-N-U1-NNN-055-AA-F3-00-00	SERIES 51	S51-110MV-1
83024941	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-NN-80-S-3-C3-C-00-GLA-32-32-28	SERIES 90	S90-042PV

83024943	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-2-BC-80-T-C-C8-J-03-NNN-42-42-28	SERIES 90	S90-180PV
83024952	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E1-AA-N-B-TA-CN-JN-N-A-15-NN-032-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83024959	MOTOR-VARIABLE CARTRIDGE L	L-C-25CN-F-R1F-F07-S-N-N-AF-F18-NNB-NNN	LV / KV MOTORS	L/K-MV
83024962	PUMP-VAR-DISPL CW 90PV180	90R180-HF-1-NN-80-S-M-F1-J-03-FAC-14-35-24	SERIES 90	S90-180PV
83024963	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KN-1-BC-80-S-4-S1-D-03-GBA-29-29-24	SERIES 90	S90-075PV
83024964	PUMP-VAR-DISPL CCW 90PV180	90L180-HF-1-NN-80-T-M-F1-J-03-NNN-42-42-24	SERIES 90	S90-180PV
83024965	PUMP-VAR-DISPL CCW 90PV130	90L130-HF-5-BC-80-R-4-F1-H-03-GBA-42-24-24	SERIES 90	S90-130PV
83024966	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E2-AA-N-B-TA-DN-HN-N-A-10-NN-032-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83024968	PUMP-VAR-DISPL CW 90PV075	90R075-KA-1-NN-60-S-3-C7-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83024969	PUMP-VAR-DISPL CW 90PV100	90R100-KA-1-CD-80-L-4-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83024972	MOTOR-VAR-DISPL 51MV060-1	51V060-1--A-S1-N-T1-D1-N-N-X1-ABA-012-AA-E4-00-29	SERIES 51	S51-060MV-1
83024978	MOTOR-VAR-DISPL H1MB060	H1-B-060-A-L1-BA-N-B-PB-VS-AS-S-N-NN-NN-019-N-00-NNN	H1-HP MOTORS	H1-060MB1
83024979	PUMP-VAR DISPL MPV046C	MPV-046-C-B-A-B-S-B-B-BA-A-A-BFM-AB-U-AA-A-NNN-***	M46	M46-046PV
83024984	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-G2A1-50-V-N-F-2-G-5-B-28-28-B-1-1-NNN-NNN	SERIES 42	S42-028PV/032PV
83024985	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-G2A1-50-V-N-F-2-G-5-A-28-28-B-1-1-NNN-NNN	SERIES 42	S42-028PV/032PV
83024988	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-1-AB-60-S-4-S1-D-09-GBA-35-35-24	SERIES 90	S90-055PV
83024989	MOTOR-VAR-DISPL H1MB060	H1-B-060-A-L2-BA-N-A-PB-VN-AN-N-A-10-NN-025-N-00-NNN	H1-HP MOTORS	H1-060MB1
83024993	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-HE-HE-N-B-TA-VN-EN-N-A-15-NN-064-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83024994	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E1-AA-N-B-TB-VN-AN-N-N-NN-NN-040-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83025001	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-1-NN-80-P-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-130PV
83025016	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A2-C3-N-D6-G-G3-NN-L-38-L-38-L-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83025019	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A5-C3-N-F5-H-F1-H6-L-25-L-25-F-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83025020	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-D-S-B-B-BA-G-A-BGG-BA-A-GG-B-NNN-***	M46	M46-046PV
83025024	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-NN-80-S-3-F1-J-06-NNN-29-29-24	SERIES 90	S90-250PV
83025026	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-T2-C0-L-N-G0-NNN-087-AA-G0-00-B8	SERIES 51	S51-250MV
83025028	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-BC-80-L-4-T2-E-03-GBA-32-32-24	SERIES 90	S90-100PV
83025031	PUMP-VAR DISPL MPV035D	MPV-035-D-B-A-G-W-S-G-BA-A-A-BBB-DR-A-FF-A-NNN-***	M35/44	035PV
83025032	PUMP-VAR-DISPL CCW 90PV100	90L100-MA-1-NN-60-S-3-C7-F-03-GBA-35-35-20	SERIES 90	S90-100PV
83025034	PUMP-VAR DISPL, CW 90PV055	90-R-055-KN-1-NN-80-R-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-055PV
83025035	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-E2-AA-N-B-TB-VN-DN-N-N-NN-NN-032-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83025036	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E2-AA-N-B-TB-VN-AN-N-N-NN-NN-016-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83025043	PUMP-VAR DISPL, CCW 90PV055	90-L-055-DC-5-AB-80-P-3-S1-C-GB-GBA-42-42-24	SERIES 90	S90-055PV
83025044	PUMP-VAR-DISPL CW 90PV100	90R100-HF-5-AB-80-R-4-C7-F-03-GBA-42-42-24	SERIES 90	S90-100PV
83025046	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A5-C2-B-F6-H-G9-H6-L-35-L-35-C-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83025047	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-NN-80-L-3-C7-E-00-GBA-35-35-24	SERIES 90	S90-100PV
83025048	PUMP-VAR-DISPL CCW H1PV089	H1-P-089-L-A-A5-C1-N-F6-H-G9-H6-L-15-L-42-D-L-30-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV

83025049	PUMP-VAR-DISPL CCW H1PV130	H1-P-130-L-B-A5-C1-N-D6-G-G2-NN-L-20-L-42-L-L-30-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83025050	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A5-C2-B-D6-H-G1-NN-L-35-L-35-C-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83025051	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-K-S-B-J-AA-A-A-BJJ-BA-A-HH-B-NNN-***	M46	M46-046PV
83025052	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-HE-HE-N-A-TB-VN-EN-N-A-10-NN-022-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83025053	PUMP-VAR-DISPL CCW 90PV250	90L250-HF-1-CD-80-D-4-F1-J-03-NNN-38-38-24	SERIES 90	S90-250PV
83025055	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-B1-C3-B-F5-H-F1-H6-L-38-L-38-C-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83025056	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-B1-C3-B-D8-H-G1-H3-L-38-L-38-C-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83025059	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A5-C2-N-D3-G-G3-H6-L-35-L-35-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83025061	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A5-C2-N-D6-H-G1-NN-K-42-K-42-D-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83025062	PUMP-VAR-DISPL CCW H1PV165	H1-P-165-L-C-A5-C2-N-D6-G-G3-H5-K-42-K-42-L-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83025063	PUMP-VAR-DISPL CCW H1PV165	H1-P-165-L-C-A5-C2-N-D6-G-G3-H6-K-42-K-42-L-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83025066	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-CD-80-R-4-F1-E-03-GBA-35-35-20	SERIES 90	S90-100PV
83025069	PUMP-VAR-DISPL CW 90PV100	90R100-DC-5-BC-60-P-4-C7-E-G8-GBA-40-40-20	SERIES 90	S90-100PV
83025071	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-NN-60-R-4-C7-E-03-GBA-32-32-24	SERIES 90	S90-100PV
83025082	PUMP-VAR-DISPL CCW H1PV130	H1-P-130-L-B-A2-C1-N-D8-G-G3-H3-L-20-L-35-A-P-28-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83025084	PUMP-VAR DISPL, CCW 90PV055	90-L-055-MA-1-AB-60-P-3-D9-D-03-GBA-42-42-24	SERIES 90	S90-055PV
83025085	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-NN-80-R-3-C8-F-03-GBA-35-35-24	SERIES 90	S90-130PV
83025091	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-1-CD-80-D-4-S1-L-00-GBA-42-16-30	SERIES 90	S90-100PV
83025093	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-1-CD-80-D-4-S1-L-00-GBA-35-35-30	SERIES 90	S90-100PV
83025094	PUMP-VAR-DISPL CCW 90PV130	90L130-KN-1-CD-80-R-4-F1-F-03-GBA-42-14-24	SERIES 90	S90-130PV
83025096	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-G3AN-50-T-N-D-2-H-5-B-30-30-N-0-0-NNN-NNN	SERIES 42	S42-028PV/032PV
83025097	PUMP-VAR-DISPL CCW H1PV130	H1-P-130-L-B-A5-C2-B-D8-G-G3-NN-L-28-L-28-A-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83025099	PUMP-VAR-DISPL CCW H1PV115	H1-P-115-L-B-A5-C2-B-D8-G-G3-NN-L-35-L-35-A-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83025101	PUMP-VAR DISPL CCW H1P060L	H1-P-060-L-A-A5-C1-N-D6-H-G1-NN-L-42-L-42-C-L-30-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83025102	PUMP-VAR DISPL, CW 90PV075	90-R-075-HS-1-BC-80-P-3-C6-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83025107	PUMP-VAR DISPL, CW 90PV075	90-R-075-KT-1-CD-80-S-3-S1-E-05-GBA-32-42-24	SERIES 90	S90-075PV
83025108	PUMP-VAR DISPL, CW 90PV075	90-R-075-KT-2-NN-60-S-3-S1-E-05-GBA-32-42-24	SERIES 90	S90-075PV
83025109	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A2-C2-N-D6-H-G1-H3-K-42-L-42-C-L-28-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83025110	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A2-C2-N-D6-H-G1-H3-K-45-L-42-C-L-28-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83025128	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-CD-80-P-3-F1-H-03-GBA-36-36-24	SERIES 90	S90-130PV
83025129	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-1-NN-60-S-3-C7-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83025137	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A3-C1-N-F5-H-G1-H6-L-42-L-42-N-E-22-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83025138	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A3-C1-N-D8-H-G1-H2-L-42-L-42-N-E-20-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83025139	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-B1-C1-B-F5-H-G9-H6-L-42-L-42-N-E-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83025141	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-5-CD-60-L-3-F1-E-02-FAD-42-42-34	SERIES 90	S90-100PV
83025142	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-E1A6-02-C-D-A-2-F-N-B-28-28-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV

83025143	PUMP-VAR-DISPL 42PV041 CW	42-R-41-C-E1A6-02-C-D-A-2-F-N-A-28-28-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83025149	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HF-1-NN-80-P-4-S1-D-00-GBA-17-17-24	SERIES 90	S90-075PV
83025150	PUMP-VAR-DISPL CCW 90PV180	90L180-HF-1-NN-80-T-M-F1-J-00-NNN-35-35-24	SERIES 90	S90-180PV
83025153	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A5-C2-N-D3-G-G2-H6-L-30-L-20-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83025154	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A5-C2-N-D3-H-G1-NN-L-38-L-28-M-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83025158	MOTOR-VAR-DISPL H1B160	H1-B-160-A-TA-DA-N-B-TB-CS-DS-S-A-30-NN-032-Z-30-NNN	H1-HP MOTORS	H1-160MB1
83025169	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-E2C8-03-C-5-N-N-C-N-A-21-21-B-H-H-NNN-NNN	SERIES 42	S42-028PV/032PV
83025170	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-BC-80-P-3-S1-E-03-EBC-35-35-24	SERIES 90	S90-075PV
83025171	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-ANK5-03-D-N-F-2-F-N-B-34-34-B-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83025172	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-ANK5-03-D-N-F-2-F-N-N-34-34-B-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83025173	PUMP-VAR DISPL CCW H1P053L	H1-P-053-L-A-A5-C2-N-D8-F-G5-NN-L-35-L-35-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83025174	PUMP-VAR-DISPL CCW H1PV130	H1-P-130-L-B-A5-C2-N-D6-G-G3-H5-L-35-L-20-A-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83025178	PUMP-VAR DISPL CCW H1P053L	H1-P-053-L-A-A3-C1-N-D8-F-F2-H2-L-33-L-33-N-E-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83025182	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-NN-80-S-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83025184	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-1-AB-60-P-3-C7-D-03-FAD-42-42-24	SERIES 90	S90-075PV
83025185	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A5-C3-N-F5-H-G9-H6-K-45-K-45-M-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83025186	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A5-C3-N-F5-H-G1-H6-K-45-K-45-M-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83025187	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-L2-BA-N-A-PA-DS-LS-S-A-20-NN-058-N-00-NNN	H1-HP MOTORS	H1-160MB1
83025188	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-NN-80-S-4-S1-C-03-GBA-21-21-24	SERIES 90	S90-055PV
83025189	PUMP-VAR-DISPL CCW H1PV165	H1-P-165-L-C-A5-C2-N-D6-G-G2-H3-L-33-L-20-L-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83025190	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-T1-DA-N-B-TB-VN-DN-N-A-20-NN-085-Z-18-NNN	H1-HP MOTORS	H1-160MB1
83025192	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KN-5-NN-80-S-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83025194	PUMP-VAR-DISPL CW 90PV130	90R130-DC-1-BC-80-S-3-F1-H-G1-GBA-32-35-30	SERIES 90	S90-130PV
83025195	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-BC-80-P-3-S1-C-03-GBA-29-29-24	SERIES 90	S90-055PV
83025196	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-CD-80-P-3-S1-C-03-GBA-29-29-24	SERIES 90	S90-055PV
83025197	MOTOR-VAR DISPL MMV046C	MMV-046-C-A-E-L-B-AE-VNB-***	M46	M46-046MV
83025200	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-AB-80-P-4-S1-D-03-GBA-14-35-24	SERIES 90	S90-075PV
83025201	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-1-NN-60-P-3-C6-C-03-FAD-42-42-24	SERIES 90	S90-055PV
83025207	PUMP-VAR-DISPL CW 90PV075	90R075-KA-1-CD-60-L-3-S1-D-03-GBA-26-26-24	SERIES 90	S90-075PV
83025212	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-5-NN-60-L-3-S1-E-02-FAD-42-42-34	SERIES 90	S90-100PV
83025215	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-AB-80-P-4-C6-C-03-GBA-42-42-24	SERIES 90	S90-055PV
83025217	MOTOR-VAR-DISPL H1B160	H1-B-160-A-TA-DA-N-B-TB-CS-LS-S-A-30-NN-032-Z-30-NNN	H1-HP MOTORS	H1-160MB1
83025225	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-BC-80-L-4-T6-E-03-GBA-29-29-24	SERIES 90	S90-100PV
83025226	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-3-N-0-S1-W-00-NNN-00-00-E6	SERIES 90	S90-055MF
83025227	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-BC-60-L-3-F1-E-03-GBA-38-38-20	SERIES 90	S90-100PV
83025232	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-NN-60-P-3-C6-D-03-FAD-42-42-24	SERIES 90	S90-075PV

83025244	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E1-AA-N-B-TB-VN-AN-N-A-10-NN-021-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83025255	PUMP-VAR DISPL, CW 90PV055	90-R-055-HF-5-AB-80-R-4-S1-C-04-GBA-35-35-24	SERIES 90	S90-055PV
83025258	PUMP-VAR-DISPL CW 90PV130	90R130-KT-1-DE-80-R-4-F1-H-00-GBA-38-32-30	SERIES 90	S90-130PV
83025260	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A3-C1-N-D8-F-F2-H2-L-33-L-33-N-E-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83025266	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E2-AA-N-B-TB-CS-HS-S-A-10-NN-030-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83025267	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KT-1-NN-80-R-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83025268	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A4-C2-N-E7-F-G1-H3-30-35-30-20-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83025271	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-NN-80-S-3-F1-J-06-NNN-32-32-24	SERIES 90	S90-250PV
83025272	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A5-C1-N-D6-H-G1-H2-L-28-L-28-M-L-28-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83025273	PUMP-VAR-DISPL CW 90PV180	90R180-KA-1-EG-80-S-M-C8-H-03-NNN-29-29-30	SERIES 90	S90-180PV
83025274	PUMP-VAR-DISPL CW 90PV180	90R180-KA-1-NN-80-S-M-C8-H-03-NNN-29-29-30	SERIES 90	S90-180PV
83025276	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-A-A5-C2-N-D8-H-G9-H3-L-35-L-35-M-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83025284	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-5-NN-80-P-4-S1-E-03-GBA-29-29-24	SERIES 90	S90-100PV
83025285	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-5-NN-80-P-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83025287	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A2-C2-N-F6-H-G1-H6-L-30-L-40-C-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83025289	MOTOR-VAR-DISPL H1B250	H1-B-250-A-K1-K1-N-B-RA-VS-FS-S-A-20-NN-087-N-29-NNN	H1-HP MOTORS	H1-250MB1
83025298	PUMP-VAR-DISPL CW 90PV075	90R075-KN-1-NN-60-R-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83025309	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A2-C2-N-E5-F-G4-NN-L-42-L-42-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83025311	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A3-C1-N-F5-H-G1-H6-L-42-L-42-N-E-20-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83025312	PUMP-TANDEM, VAR DISPL CCW H1T045L	H1-T-045-L-A-N-A2-C2-N-E7-F-G1-TN-40-40-40-40-M-P-24-PN-NNN-S04	H1-MP PUMPS	H1-045PT/053PT
83025317	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A2-C1-N-E5-F-G1-NN-L-40-L-40-B-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83025322	PUMP-VAR DISPL CCW H1P068L	H1-P-068-L-A-A5-C2-N-D6-H-G1-H3-L-35-L-35-C-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83025325	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-NN-80-T-M-C8-H-03-NNN-26-26-24	SERIES 90	S90-180PV
83025327	PUMP-VAR DISPL MPV046C	MPV-046-C-B-A-B-S-B-AA-L-A-BEE-AB-U-AA-A-NNN-***	M46	M46-046PV
83025333	PUMP-VAR-DISPL CCW H1PV130	H1-P-130-L-B-A8-C2-C-D3-L-G3-NN-L-35-L-35-A-M-24-P2-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83025335	PUMP-TANDEM, VAR DISPL CCW H1T045L	H1-T-045-L-A-N-A2-C2-N-E7-F-G1-TN-40-40-40-40-M-P-24-PN-NNN-S01	H1-MP PUMPS	H1-045PT/053PT
83025341	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-C-G3AN-53-P-D-G-2-H-5-B-34-34-N-1-1-NNN-NNN	SERIES 42	S42-028PV/032PV
83025342	PUMP-VAR DISPL, CW 90PV055	90-R-055-PB-1-CD-60-D-3-C6-L-03-GBA-40-40-24	SERIES 90	S90-055PV
83025356	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A9-C1-B-E9-F-G5-H2-K-35-K-18-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83025359	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A5-C3-N-F4-H-G9-H6-L-33-L-33-D-M-30-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83025360	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A5-C3-N-D3-H-G1-H3-L-33-L-33-D-M-30-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83025365	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-E2C8-03-A-N-A-3-F-N-V-30-30-B-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83025366	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-E2C8-03-A-N-N-N-P-N-V-30-30-B-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83025367	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-E2C8-03-A-N-A-2-F-N-N-36-36-B-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83025369	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-L1-BA-N-C-PA-DS-JS-S-A-15-NN-032-N-00-NNN	H1-HP MOTORS	H1-080MB1
83025370	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-M1-CA-N-A-RA-DS-JS-S-N-NN-NN-000-N-00-NNN	H1-HP MOTORS	H1-110MB1

83025372	PUMP-VAR DISPL, CW H1PV250	H1-P-250-R-A-A5-C2-N-D8-C-G2-NN-L-35-L-28-W-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-210PV/250PV
83025373	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-A-Z-C-M-AA-B-B-C-A-BDD-CD-A-GG-B-D-C-A-BDD-CD-A-GG-A-NNN	M46	M46-046PT
83025376	PUMP-VAR DISPL, CW H1PV210	H1-P-210-R-A-A5-C2-N-D8-C-G2-E2-L-33-L-20-R-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-210PV/250PV
83025389	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-NN-80-L-4-F1-H-03-GBA-26-26-24	SERIES 90	S90-130PV
83025394	MOTOR-VAR-DISPL H1B110	H1-B-110-A-TA-DA-N-B-TA-DN-JN-N-N-NN-NN-046-Z-23-NNN	H1-HP MOTORS	H1-110MB1
83025395	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-1-NN-60-P-3-D7-D-03-FAD-42-42-24	SERIES 90	S90-075PV
83025401	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E2-AA-N-B-TB-CS-HS-S-A-10-NN-035-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83025402	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-E1A7-03-B-D-B-2-H-N-N-23-23-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83025406	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-N-A4-C3-N-E7-F-G5-H3-28-28-23-23-N-P-28-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83025409	PUMP-VAR-DISPL CW 90PV250	90R250-KP-5-NN-80-S-3-F1-J-06-NNN-32-32-24	SERIES 90	S90-250PV
83025415	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A2-C2-B-E5-F-G4-NN-L-42-L-42-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83025419	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-L2-BA-N-B-PB-CS-LS-S-A-20-NN-080-N-00-NNN	H1-HP MOTORS	H1-160MB1
83025425	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-L2-BA-N-B-PB-CS-JS-S-A-10-NN-025-N-00-NNN	H1-HP MOTORS	H1-110MB1
83025427	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A5-C3-N-F6-H-G9-H6-K-42-K-42-M-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83025431	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A3-C2-N-D6-G-G2-NN-L-40-L-40-L-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83025444	PUMP-VAR DISPL, CW 90PV100	90-R-100-CB-1-AB-60-P-4-S1-E-00-GBA-14-14-20	SERIES 90	S90-100PV
83025445	PUMP-VAR-DISPL CW 90PV130	90R130-KN-1-CD-80-R-4-T4-F-03-GBA-42-42-24	SERIES 90	S90-130PV
83025447	PUMP-VAR-DISPL CW 90PV100	90R100-HF-5-CD-80-R-3-C7-E-03-GBA-26-26-24	SERIES 90	S90-100PV
83025448	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-B7-C3-C-D8-K-G9-NN-L-45-L-45-N-E-32-P2-NNN-D5F	H1-HP PUMPS	H1-089PV/100PV
83025449	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A3-C1-N-D6-F-G5-NN-L-33-L-33-B-L-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83025450	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A3-C1-N-D6-F-G5-NN-L-33-L-33-B-L-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83025456	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A4-C3-N-D8-H-G1-NN-L-40-L-40-C-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83025457	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-T2-C2-L-N-G0-NNN-075-AA-G0-00-B8	SERIES 51	S51-160MV
83025461	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-T1-D1-N-A-TA-DN-HN-N-A-10-NN-018-Z-28-NNN	H1-HP MOTORS	H1-080MB1
83025462	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-7-N-0-K1-W-00-EBA-00-00-G0	SERIES 90	S90-055MF
83025463	PUMP-VAR-DISPL 42PV028 CW	42-R-28-G-ANN3-02-C-5-A-2-C-N-B-14-14-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83025464	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-ANN3-02-C-5-A-2-C-N-N-14-14-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83025467	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A4-C2-N-D6-F-G1-H5-L-42-L-42-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83025468	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A4-C2-N-D6-F-G5-NN-L-42-L-42-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83025469	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E1-AA-N-C-TA-CN-GN-N-A-05-NN-030-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83025472	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E2-AA-N-B-TB-DN-KN-N-N-NN-NN-046-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83025478	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-T1-D1-N-C-TA-DN-JN-N-A-15-NN-055-Z-29-NNN	H1-HP MOTORS	H1-110MB1
83025483	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-N-A4-C3-N-E7-F-G5-H3-25-25-25-25-N-P-28-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83025487	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A5-C2-N-F4-H-G9-H6-L-40-L-40-M-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83025488	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A5-C2-N-D3-H-G1-H3-L-40-L-40-M-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83025494	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-8-N-0-T1-W-00-EGH-00-00-F0	SERIES 90	S90-055MF

83025497	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-A-A5-C1-N-D8-H-G9-NN-L-35-L-35-M-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83025498	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-BC-80-S-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83025499	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-BC-80-S-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-100PV
83025508	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-HE-HE-N-A-TB-VN-AN-N-N-NN-NN-036-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83025510	MOTOR-VARIABLE CARTRIDGE K	K-C-38CN-E-R1F-F10-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83025511	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HF-1-BC-80-R-4-S1-D-03-GBA-20-20-24	SERIES 90	S90-075PV
83025552	PUMP-VAR-DISPL CW 90PV180	90R180-HF-5-AB-80-S-M-C8-H-03-NNN-35-35-24	SERIES 90	S90-180PV
83025553	PUMP-VAR-DISPL CW 90PV180	90R180-HF-5-EG-80-S-M-C8-H-03-NNN-35-35-24	SERIES 90	S90-180PV
83025554	PUMP- VARIABLE, DIRECT DISPLACMENT	LPV-A-A-B-L-A-K-FA-D-A-BJH-DR-A-FF-B-NNN-***	LPV	LPV
83025556	PUMP-VAR DISPL MPV046C	MPV-046-C-B-A-N-S-B-J-AA-A-A-BGG-AW-U-FF-5-NNN-***	M46	M46-046PV
83025567	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-8-N-0-S1-W-00-EHD-00-00-F3	SERIES 90	S90-075MF
83025568	MOTOR-VAR-DISPL 51MC060-1	51C060-1--H-D1-N-N1-NN-N-N-U1-NNN-012-AA-E4-00-00	SERIES 51	S51-060MV-1
83025572	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-BC-80-S-4-S1-E-02-GBA-40-40-24	SERIES 90	S90-100PV
83025574	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-BC-80-S-4-S1-D-02-GBA-40-40-24	SERIES 90	S90-075PV
83025575	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-L2-BA-N-B-PB-VN-EN-N-N-NN-NN-060-N-00-NNN	H1-HP MOTORS	H1-160MB1
83025577	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-NN-80-S-4-S1-E-03-GBA-29-29-28	SERIES 90	S90-075PV
83025589	MOTOR-VAR-DISPL H1B160	H1-B-160-A-TA-DA-N-A-TB-VS-ES-S-A-20-NN-108-Z-26-NNN	H1-HP MOTORS	H1-160MB1
83025590	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A2-C2-B-D8-G-G3-NN-L-30-L-25-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83025592	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-B1-C1-B-D8-H-G1-H5-L-35-L-18-C-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83025593	PUMP-VAR-DISPL CW H1PV069	H1-P-069-R-A-A2-C2-N-F5-H-G9-H6-K-42-K-42-C-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83025594	PUMP-VAR-DISPL CW H1PV069	H1-P-069-R-A-A2-C2-N-F5-H-G1-H6-K-42-K-42-C-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83025597	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A5-C1-B-D3-H-G9-H5-L-33-L-33-C-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83025609	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A7-C2-C-D6-J-G1-H2-L-42-L-42-B-L-26-P2-NNN-D3F	H1-MP PUMPS	H1-045PV/053PV
83025610	PUMP-VAR DISPL, CW 90PV055	90-R-055-KN-2-AB-60-S-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-055PV
83025611	PUMP-VAR DISPL, CW 90PV055	90-R-055-HF-2-AB-60-S-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-055PV
83025612	PUMP-VAR-DISPL CW 90PV075	90R075-DD-5-NN-80-P-4-S1-E-G8-GBA-42-42-30	SERIES 90	S90-075PV
83025614	PUMP-VAR-DISPL CW 90PV130	90R130-MA-2-CD-80-S-4-F1-F-05-GBA-42-42-28	SERIES 90	S90-130PV
83025625	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-L2-BA-N-B-PB-CS-HS-S-A-05-NN-000-N-00-NNN	H1-HP MOTORS	H1-080MB1
83025626	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A5-C3-N-D8-F-G4-NN-L-15-L-15-B-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83025627	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A5-C3-N-D8-F-G5-H3-L-15-L-15-B-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83025630	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-NN-80-S-3-C7-E-03-GBA-23-23-24	SERIES 90	S90-100PV
83025631	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-NN-80-R-3-S1-E-03-GBA-32-32-20	SERIES 90	S90-075PV
83025634	PUMP-VAR-DISPL CCW 90PV130	90L130-HF-5-NN-80-S-3-C8-F-03-GBA-42-42-24	SERIES 90	S90-130PV
83025636	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A2-C1-N-D8-H-G1-NN-K-18-K-18-N-E-20-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83025637	PUMP-VAR-DISPL CCW 90PV250	90L250-KN-1-NN-80-T-4-F1-K-03-NNN-38-38-24	SERIES 90	S90-250PV
83025645	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A4-C1-N-F4-H-F1-H6-L-28-L-28-C-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV

83025646	PUMP-VAR DISPL CCW H1P060L	H1-P-060-L-A-A4-C1-N-D3-H-G1-NN-L-28-L-28-C-M-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83025647	PUMP-VAR DISPL CCW H1P060L	H1-P-060-L-A-A4-C1-N-D3-H-F1-H3-L-42-L-42-C-M-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83025766	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-N-A4-C3-N-E7-F-G1-H3-35-35-35-35-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83025767	PUMP-VAR DISPL, CW 90PV075	90-R-075-KT-2-NN-60-S-3-S1-E-05-GBA-42-32-24	SERIES 90	S90-075PV
83025773	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-L1-BA-N-C-PA-DN-JN-N-A-05-NN-022-N-00-NNN	H1-HP MOTORS	H1-080MB1
83025774	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-M1-CA-N-C-RA-DN-JN-N-A-05-NN-000-N-00-NNN	H1-HP MOTORS	H1-080MB1
83025775	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-T2-D2-N-A-TA-DS-KS-S-A-20-NN-040-Z-23-NNN	H1-HP MOTORS	H1-160MB1
83025779	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-T2-D2-N-B-TB-VN-EN-N-N-NN-NN-057-Z-25-NNN	H1-HP MOTORS	H1-110MB1
83025780	PUMP-VAR-DISPL CW H1PV069	H1-P-069-R-A-A3-C2-B-D3-H-G1-NN-L-42-L-42-C-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83025782	MOTOR-VAR DISPL MMV046C	MMV-046-C-A-A-M-C-A8-VNA-***	M46	M46-046MV
83025785	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-8-N-0-S1-W-00-EBA-00-00-F0	SERIES 90	S90-075MF
83025786	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-7-N-0-S1-W-00-NNN-00-00-E4	SERIES 90	S90-055MF
83025791	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-8-N-0-K1-W-00-NNN-00-00-G0	SERIES 90	S90-055MF
83025794	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-8-N-0-K3-N-00-EEA-00-00-00	SERIES 90	S90-100MF
83025795	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A4-C1-N-D6-H-G9-NN-L-42-L-42-M-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83025798	MOTOR-VAR-DISPL 51MD110	51D110-A-D3-N-HZ-B1-B-E-G5-ADA-022-AA-E6-06-00	SERIES 51	S51-110MV
83025799	PUMP-VAR-DISPL CCW 90PV180	90L180-KN-1-NN-80-S-M-F1-H-03-FAC-42-42-24	SERIES 90	S90-180PV
83025800	PUMP-VAR-DISPL CW 90PV180	90R180-HF-1-NN-80-T-M-F1-J-03-NNN-42-42-24	SERIES 90	S90-180PV
83025801	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-P1-D1-N-B-TL-VS-AS-S-A-10-NN-027-Z-24-NNN	H1-HP MOTORS	H1-080MB1
83025803	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-AB-80-P-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
83025806	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KT-1-BC-80-R-3-F1-E-03-GBA-45-45-24	SERIES 90	S90-100PV
83025813	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-C3-C2-C-D6-K-G9-H3-L-45-L-45-M-L-32-P2-NNN-D6F	H1-HP PUMPS	H1-089PV/100PV
83025814	PUMP-VAR-DISPL CW H1PV069	H1-P-069-R-A-C3-C2-C-D6-K-F1-H3-L-45-L-45-C-L-32-P2-NNN-D6F	H1-HP PUMPS	H1-069PV/078PV
83025830	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-BC-80-S-4-C8-J-04-NNN-42-42-24	SERIES 90	S90-250PV
83026271	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A4-C1-N-D8-H-G1-NN-L-25-L-25-M-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83026277	PUMP-VAR-DISPL CW 90PV180	90R180-KT-1-BB-80-T-C-F1-H-03-FAC-38-38-24	SERIES 90	S90-180PV
83026293	PUMP-VAR-DISPL CW 90PV100	90R100-KP-1-AB-80-R-4-F1-F-00-GBA-29-29-20	SERIES 90	S90-100PV
83026294	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-C2-C3-C-D8-L-G2-S1-L-45-L-45-L-P-30-P2-NNN-D4F	H1-HP PUMPS	H1-115PV/130PV
83026295	PUMP-VAR-DISPL CCW 90PV100	90L100-HF-2-BC-80-R-4-F1-E-03-GBA-32-32-20	SERIES 90	S90-100PV
83026304	PUMP-VAR-DISPL CW 90PV042	90R042-KA-1-AB-80-P-4-C3-B-02-GBA-17-17-18	SERIES 90	S90-042PV
83026305	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-D2-M2-N-B-PB-DS-KS-S-A-20-NN-045-N-30-NNN	H1-HP MOTORS	H1-160MB1
83026306	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-L2-BA-N-B-PB-DS-JS-S-A-10-NN-048-N-00-NNN	H1-HP MOTORS	H1-080MB1
83026308	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A5-C2-N-E7-F-G1-T3-38-38-38-38-M-P-30-PN-NNN-S01	H1-MP PUMPS	H1-045PT/053PT
83026799	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-LNN8-03-C-2-N-A-F-N-Z-38-38-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83026801	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-B8-C4-C-D8-G-G2-H6-L-40-L-40-A-P-30-P1-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83026803	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-E1A7-02-B-2-C-2-H-N-A-38-38-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV

83026805	PUMP-VAR-DISPL CW 90PV130	90R130-KT-1-BB-80-L-3-F1-H-03-GBA-35-35-24	SERIES 90	S90-130PV
83026806	PUMP-VAR DISPL, CW 90PV100	90-R-100-LE-1-BB-80-L-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
83026816	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A5-C2-B-D8-G-G3-H3-K-35-K-35-A-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83026820	PUMP-VAR-DISPL CCW H1PV089	H1-P-089-L-A-A5-C2-N-F5-H-G9-H6-L-42-L-42-D-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83027102	MOTOR-VARIABLE CARTRIDGE K	K-C-38CN-E-Y2F-F10-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83027105	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-N-B1-C1-B-E7-F-G5-NN-30-30-30-30-N-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83027106	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A5-C2-N-D8-H-G9-H5-L-40-L-40-M-P-20-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83027401	PUMP-VAR DISPL, CW 90PV055	90-R-055-MB-1-AB-80-P-3-D9-D-00-GBA-38-38-24	SERIES 90	S90-055PV
83027409	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-8-N-0-S1-W-00-EFM-00-00-F0	SERIES 90	S90-055MF
83027415	PUMP-VAR-DISPL CW 90PV075	90R075-HF-1-BC-80-R-4-S1-D-03-GBA-32-32-24	SERIES 90	S90-075PV
83027427	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E2-AA-N-B-TB-VS-AS-S-A-10-NN-032-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83027441	PUMP-VAR-DISPL CCW H1PV130	H1-P-130-L-B-A3-C2-N-D6-G-G2-NN-L-40-L-40-L-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83027491	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A3-C2-N-D8-H-G1-H3-L-40-L-30-N-E-26-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83027492	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A2-C2-N-D8-H-G1-H3-L-38-L-20-N-E-26-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83027493	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A3-C2-N-D8-H-G1-H3-L-38-L-20-N-E-26-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83027494	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-C3-C2-C-D8-L-G2-S1-L-45-L-45-L-P-30-P2-NNN-D6F	H1-HP PUMPS	H1-115PV/130PV
83027497	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-E1A7-02-B-2-C-2-H-N-B-38-38-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83027499	MOTOR-VARIABLE DISPL SAE_K	K-V-45DN-A-RNF-F07-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83027500	MOTOR-VARIABLE DISPL SAE_K	K-V-45DN-A-R1F-F07-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83027501	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A8-C2-C-D6-J-G5-NN-L-33-L-33-B-L-24-P2-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83027580	PUMP-VAR DISPL, CW 90PV100	90-R-100-HS-1-CD-80-R-3-C7-F-06-GBA-32-32-24	SERIES 90	S90-100PV
83027581	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-7-N-0-C7-N-00-EBB-00-00-00	SERIES 90	S90-075MF
83027583	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E2-AA-N-B-TA-DN-JN-N-N-NN-NN-030-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83027584	PUMP-VAR-DISPL CCW 90PV130	90L130-MB-1-NN-80-P-3-F1-H-03-GBA-42-42-24	SERIES 90	S90-130PV
83027585	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A5-C2-N-F5-H-F1-H6-L-40-L-40-C-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83027586	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A5-C2-N-D8-H-G1-NN-L-40-L-40-N-E-20-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83027587	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-G-T-B-J-AA-G-A-BFF-CD-A-GG-C-NNN-***	M46	M46-046PV
83027589	MOTOR-FIX DISPL MMF044D	MMF-044-D-A-F-Y-C-T-NNN-***	M35/44	044MF
83027598	PUMP- VARIABLE, DIRECT DISPLACEMENT	LPV-A-A-A-B-A-E-AA-C-A-BDD-DR-A-FF-B-NNN-***	LPV	LPV
83027608	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-2-NN-80-S-3-S1-D-03-GBA-26-26-24	SERIES 90	S90-075PV
83027609	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-2-CD-80-S-3-S1-D-03-GBA-26-26-24	SERIES 90	S90-075PV
83027624	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A4-C2-N-D8-G-G2-H2-L-40-L-40-L-P-22-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83027625	MOTOR-VAR-DISPL H1B250	H1-B-250-A-L1-BA-N-A-PA-VS-DS-S-A-30-NN-080-N-00-NNN	H1-HP MOTORS	H1-250MB1
83027628	PUMP-VAR-DISPL CW 90PV130	90R130-DD-1-BC-80-P-4-F1-H-G8-GBA-35-35-24	SERIES 90	S90-130PV
83027629	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-CD-80-P-3-C8-H-02-GBA-38-38-24	SERIES 90	S90-130PV
83027630	PUMP-VAR-DISPL CCW 90PV130	90L130-KN-1-NN-80-S-4-F1-H-03-GBA-35-35-24	SERIES 90	S90-130PV

83027631	PUMP-VAR-DISPL CCW 90PV100	90L100-KN-1-NN-80-S-4-S1-E-03-GBA-38-38-24	SERIES 90	S90-100PV
83027635	MOTOR-VAR-DISPL H1MB060	H1-B-060-A-L1-BA-N-B-PB-CN-GN-N-N-NN-NN-020-N-00-NNN	H1-HP MOTORS	H1-060MB1
83027638	MOTOR-FIXED DISPL MMF025C	MMF-025-C-A-5-R-E-D-NNN-***	LIGHT DUTY	025MF
83027666	PUMP-VAR-DISPL 42PV041 CCW	42-L-51-E-E2D8-03-B-D-G-3-F-N-B-34-25-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83027668	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-N-HS-A2-B-H-F1-NNN-150-AA-NN-10-18	SERIES 51	S51-250MV
83027670	PUMP-TANDEM, VAR DISPL CCW H1T053L	H1-T-053-L-A-N-A5-C3-N-F7-F-G5-TN-33-38-38-38-M-P-24-PN-NNN-S02	H1-MP PUMPS	H1-045PT/053PT
83027675	PUMP-VAR DISPL CW H1P068R	H1-P-068-R-A-A5-C2-B-D3-H-G1-H3-L-33-L-33-C-M-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83027676	PUMP-VAR DISPL, CW 90PV055	90-R-055-MB-1-BG-80-R-3-C6-D-03-GBA-35-35-24	SERIES 90	S90-055PV
83027677	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MB-1-BC-80-P-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-075PV
83027678	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-1-AB-60-P-4-S1-D-Z1-GBA-35-35-24	SERIES 90	S90-055PV
83027679	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E2-AA-N-B-TB-DN-JN-N-A-05-NN-040-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83027680	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-T2-D2-N-B-TA-VN-DN-N-A-20-NN-055-Z-30-NNN	H1-HP MOTORS	H1-160MB1
83027681	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-B8-C1-C-D3-H-F1-H3-L-38-L-38-C-M-30-P1-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83027682	PUMP-VAR-DISPL CW 90PV180	90R180-KP-5-DE-80-T-C-C8-J-03-FAC-38-38-24	SERIES 90	S90-180PV
83027694	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A3-C1-N-D3-H-F1-H1-L-40-L-40-M-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83027697	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A5-C2-N-F5-H-G9-H6-L-40-L-40-M-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83027700	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-BB-80-L-3-C7-E-03-GBA-29-29-24	SERIES 90	S90-100PV
83027701	PUMP-VAR-DISPL CCW H1PV165	H1-P-165-L-C-A5-C3-B-D6-G-G3-H6-L-42-L-42-L-L-28-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83027702	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A5-C3-B-D6-H-G1-H3-L-42-L-42-C-L-28-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83027704	MOTOR-VAR-DISPL H1B110	H1-B-110-A-TA-DA-N-A-TB-CN-JN-N-N-NN-NN-056-Z-18-NNN	H1-HP MOTORS	H1-110MB1
83027705	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-HE-HE-N-A-TB-CN-KN-N-A-20-NN-065-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83027712	PUMP-VAR-DISPL CCW 90PV250	90L250-KN-1-BC-80-S-4-F1-K-03-NNN-35-35-24	SERIES 90	S90-250PV
83027725	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-AC-60-L-3-F1-E-03-GBA-38-38-20	SERIES 90	S90-100PV
83027729	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-NN-60-S-3-S1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
83027730	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-L2-BA-N-B-PB-DN-JN-N-A-15-NN-040-N-00-NNN	H1-HP MOTORS	H1-110MB1
83027731	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-BC-80-D-4-F1-L-03-NNN-40-40-24	SERIES 90	S90-250PV
83027734	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-HE-HE-N-B-TB-VN-EN-N-N-NN-NN-082-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83027745	PUMP-VAR-DISPL CW 90PV180	90R180-MA-5-AB-80-T-C-C8-J-C5-FAC-38-38-24	SERIES 90	S90-180PV
83027749	PUMP-VAR-DISPL CW 90PV180	90R180-KT-1-NN-80-T-C-F1-J-00-FAC-32-32-28	SERIES 90	S90-180PV
83027750	PUMP-VAR-DISPL CW 90PV130	90R130-KT-1-NN-80-L-3-F1-H-00-GBA-32-32-28	SERIES 90	S90-130PV
83027753	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A2-C3-B-D6-J-G1-NN-L-42-L-42-B-L-24-P4-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83027754	MOTOR-VAR-DISPL H1MB060	H1-B-060-A-L1-BA-N-A-PB-VS-AS-S-A-05-NN-012-N-00-NNN	H1-HP MOTORS	H1-060MB1
83027755	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-M1-CA-N-A-RB-VS-ES-S-N-NN-NN-000-N-00-NNN	H1-HP MOTORS	H1-110MB1
83027772	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HS-5-NN-60-R-4-S1-D-06-GBA-42-42-24	SERIES 90	S90-055PV
83027777	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-A-S-B-B-BA-A-A-BJJ-CD-A-GG-C-NNN-***	M46	M46-046PV
83027782	PUMP-VAR DISPL, CW 90PV055	90-R-055-HF-1-AB-80-D-3-S1-L-03-GBA-20-20-24	SERIES 90	S90-055PV

83027783	PUMP-VAR DISPL, CW 90PV055	90-R-055-HF-1-BC-80-D-3-S1-L-03-GBA-20-20-24	SERIES 90	S90-055PV
83027784	PUMP-VAR DISPL, CW 90PV055	90-R-055-HF-1-CD-80-D-3-S1-L-03-GBA-20-20-24	SERIES 90	S90-055PV
83027833	PUMP-VAR-DISPL CCW 90PV250	90L250-HF-5-BC-80-S-4-C8-J-03-NNN-42-42-24	SERIES 90	S90-250PV
83027835	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-1-BC-80-S-3-C6-C-G4-GBA-32-32-24	SERIES 90	S90-055PV
83027836	PUMP-VAR-DISPL CW 90PV180	90R180-HF-1-BC-80-T-M-C8-H-03-NNN-35-35-24	SERIES 90	S90-180PV
83027855	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A3-C2-N-F5-H-G9-H6-K-42-K-42-D-P-34-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83027856	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A3-C2-N-F5-H-G1-H6-K-42-K-42-D-P-34-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83027857	PUMP-VAR-DISPL 42PV041 CW	42-R-51-D-F2NN-70-J-D-B-3-F-5-B-28-28-N-1-1-NNN-NNN	SERIES 42	S42-041PV/051PV
83027858	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-T2-D2-N-B-TB-VS-ES-S-N-NN-NN-028-Z-22-NNN	H1-HP MOTORS	H1-110MB1
83027859	PUMP-VAR-DISPL CW 90PV130	90R130-HS-5-DG-80-D-4-C8-L-05-GBA-35-35-24-F076	SERIES 90	S90-130PV
83027860	PUMP-VAR-DISPL CW 90PV130	90R130-HS-5-CD-80-D-4-C8-L-05-GBA-35-35-24-F076	SERIES 90	S90-130PV
83027861	PUMP-VAR DISPL, CW 90PV075	90-R-075-HS-5-NN-80-S-4-S1-D-03-GBA-32-32-24	SERIES 90	S90-075PV
83027878	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-HE-HE-N-A-TA-CN-GN-N-N-NN-NN-039-R-00-N04	H1-HP MOTORS	H1-060MB1
83027882	PUMP-VAR DISPL, CW 90PV075	90-R-075-HS-5-CD-80-S-4-S1-D-03-GBA-29-29-24	SERIES 90	S90-075PV
83027883	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A5-C2-N-D3-H-G9-H3-L-45-L-15-C-M-30-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83027884	PUMP-VAR-DISPL CCW 90PV042	90L042-HF-5-BC-80-S-4-C3-C-03-GBA-40-40-24	SERIES 90	S90-042PV
83027885	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E2-AA-N-B-TA-VN-DN-N-A-10-NN-022-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83027893	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-5-BC-80-P-3-C6-C-00-GBA-35-35-24	SERIES 90	S90-055PV
83027899	PUMP-VAR DISPL, CW 90PV100	90-R-100-M8-5-CD-60-P-3-C7-E-C5-GBA-38-38-24	SERIES 90	S90-100PV
83027900	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-CD-80-L-3-C7-E-00-GBA-38-38-24	SERIES 90	S90-100PV
83027901	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-CD-80-S-7-C7-E-09-FAC-35-35-30	SERIES 90	S90-100PV
83027902	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-B8-C2-C-D3-H-G1-H3-L-30-L-30-C-M-26-P1-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83027911	PUMP-VAR-DISPL CCW 90PV130	90L130-MS-1-DE-80-P-3-C8-H-03-GBA-42-42-24	SERIES 90	S90-130PV
83027912	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-D-V-C-S-AA-B-B-A-A-BDD-CH-A-JJ-B-D-A-A-BDD-CH-A-JJ-C-NNN-**	M46	M46-046PT
83027916	PUMP-VAR-DISPL CCW 90PV130	90L130-HF-1-AB-80-R-4-T4-F-03-GBA-42-42-24	SERIES 90	S90-130PV
83027919	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-1-NN-60-P-3-C6-C-03-FAD-29-29-24	SERIES 90	S90-055PV
83027920	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-8-N-0-C7-W-00-EBA-00-00-E6	SERIES 90	S90-075MF
83027922	MOTOR-VAR-DISPL H1MB060	H1-B-060-A-M2-CA-N-A-RB-VS-AS-S-A-05-NN-000-N-00-NNN	H1-HP MOTORS	H1-060MB1
83027923	PUMP-VAR-DISPL CCW 90PV180	90L180-KP-5-BC-80-T-C-F1-H-03-FAC-21-21-24	SERIES 90	S90-180PV
83027924	PUMP-TANDEM, VAR DISPL CCW H1T053L	H1-T-053-L-A-N-A5-C2-N-E7-F-G1-T2-20-20-20-20-M-P-24-PN-NNN-S02	H1-MP PUMPS	H1-045PT/053PT
83027934	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-P2-D2-N-A-TA-DS-JS-S-A-10-NN-020-Z-24-NNN	H1-HP MOTORS	H1-080MB1
83027939	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HM-1-AC-60-L-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
83027940	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A2-C2-N-E5-F-G5-H2-L-23-L-23-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83027941	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-BC-80-D-3-C7-L-03-GBA-42-42-24	SERIES 90	S90-075PV
83027942	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-BC-80-S-7-S1-E-09-FAC-35-35-30	SERIES 90	S90-100PV
83027951	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-L2-B1-V-A-C0-ABA-055-AA-F0-B2-00	SERIES 51	S51-250MV

83027952	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-CD-80-D-3-C7-L-03-GBA-42-42-24	SERIES 90	S90-075PV
83027953	PUMP-VAR-DISPL CW 90PV075	90R075-FG-1-BC-60-L-7-S1-E-B1-FAD-40-40-24	SERIES 90	S90-075PV
83027954	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-K2-K2-N-B-RB-VS-ES-S-A-05-NN-046-N-27-NNN	H1-HP MOTORS	H1-160MB1
83027958	PUMP-VAR-DISPL CW 90PV100	90R100-HS-5-NN-60-L-4-C7-D-03-GBA-20-20-24	SERIES 90	S90-100PV
83027959	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A3-C1-N-D8-H-G1-NN-K-35-K-18-C-P-26-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83027963	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E2-AA-N-C-TB-VN-AN-N-A-10-NN-023-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83027967	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-T1-D1-N-B-TA-VN-AN-N-A-10-NN-016-Z-20-NNN	H1-HP MOTORS	H1-080MB1
83027969	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A4-C2-N-D3-G-G3-H3-L-35-L-35-L-M-30-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83027972	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-L1-BA-N-B-PA-CN-JN-N-N-NN-040-N-00-NNN	H1-HP MOTORS	H1-080MB1
83027976	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-D-E2D8-03-B-3-B-2-F-N-B-28-28-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83027977	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-C-E2D8-03-B-3-B-2-F-N-N-28-28-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83027978	PUMP-VAR-DISPL CW 90PV075	90R075-MA-1-BC-80-S-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83027979	PUMP-VAR-DISPL CW 90PV100	90R100-MA-1-BC-80-S-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-100PV
83027980	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-BC-60-D-3-C6-L-42-GBA-35-35-24	SERIES 90	S90-055PV
83027981	PUMP-VAR-DISPL CW 90PV100	90R100-DD-5-CD-80-L-4-F1-F-GB-GBA-35-35-24	SERIES 90	S90-100PV
83027983	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MA-2-NN-80-S-4-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83027987	PUMP-VAR-DISPL CCW H1PV115	H1-P-115-L-B-C2-C2-C-D3-L-G3-NN-L-45-L-45-L-M-30-P2-NNN-D4F	H1-HP PUMPS	H1-115PV/130PV
83027988	PUMP-VAR-DISPL CCW H1PV147	H1-P-147-L-C-A5-C2-N-D3-G-G3-NN-L-45-L-45-L-M-30-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83027989	PUMP-VAR-DISPL CCW H1PV089	H1-P-089-L-A-A5-C2-N-D3-H-G1-NN-L-42-L-42-M-M-30-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83027990	PUMP-VAR DISPL, CCW 90PV055	90-L-055-DD-1-NN-60-R-4-S1-D-Z1-GBA-35-35-24	SERIES 90	S90-055PV
83027991	PUMP-VAR DISPL, CW 90PV075	90-R-075-M8-1-CD-60-P-3-C7-D-02-GBA-38-38-24	SERIES 90	S90-075PV
83027993	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A3-C2-N-D8-H-G1-H3-L-35-L-35-C-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83027995	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A5-C2-N-D8-K-G1-NN-L-42-L-42-C-P-24-P4-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83027996	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-TH-C2-N-N-X1-ANA-080-AA-G0-00-18	SERIES 51	S51-110MV-1
83027999	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-CD-80-S-3-F1-F-03-GBA-40-40-28	SERIES 90	S90-100PV
83028004	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A4-C2-N-D8-H-G1-H3-L-40-L-40-M-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83028005	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-L2-BA-N-A-PB-VS-ES-S-A-15-NN-070-N-00-NNN	H1-HP MOTORS	H1-110MB1
83028007	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A3-C1-N-D8-G-G2-NN-L-38-L-38-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83028008	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A2-C2-N-D8-H-G1-H3-K-38-K-38-N-E-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83028012	PUMP-VAR-DISPL CCW 90PV042	90L042-HF-5-AB-80-S-4-C3-C-03-GBA-32-32-24	SERIES 90	S90-042PV
83028014	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-T2-D2-N-B-TA-CS-GS-S-A-05-NN-012-Z-21-NNN	H1-HP MOTORS	H1-060MB1
83028016	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-E-V-C-S-AA-B-A-U-A-BGG-GG-B-BF-B-C-U-A-BGG-GG-B-BF-B-NNN-	M46	M46-046PT
83028019	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-L2-BA-N-C-PA-VS-DS-S-A-30-NN-000-N-00-NNN	H1-HP MOTORS	H1-160MB1
83028020	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-BC-80-P-4-S1-C-03-GBA-35-35-20	SERIES 90	S90-055PV
83028021	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A2-C3-N-E7-J-G1-T3-35-35-35-35-M-P-24-P4-NNN-S01	H1-MP PUMPS	H1-045PT/053PT
83028024	MOTOR-VAR-DISPL 51MV080-1	51V080-1--R-S1-N-TA-C2-N-N-X1-NNN-040-AA-NN-00-20	SERIES 51	S51-080MV-1

83028028	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-CD-80-S-3-C7-D-05-GBA-42-42-24	SERIES 90	S90-075PV
83028029	MOTOR-VAR-DISPL 51MV160	51V160-A-D4-N-T2-C2-L-N-G0-NNN-080-AA-G3-00-B4	SERIES 51	S51-160MV
83028032	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A3-C1-N-D8-G-G2-H3-L-38-L-38-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83028033	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-D-E2C8-03-A-N-A-3-F-N-V-30-30-B-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83028034	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-D-E2C8-03-A-N-N-N-P-N-V-30-30-B-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83028036	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-BC-80-S-4-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
83028038	PUMP-VAR-DISPL CW DDC20	DDC-20-A-R-RB-LSA-NN-A-N-3-AA-ACA0-D-07-14A-14N-NNN-NNN	DDC20/LDU20	OSK-020PV - DO NOT USE
83028039	MOTOR-VAR-DISPL 51MC110-1	51C110-1--R-D3-N-E1-B1-N-N-U1-NNN-055-AA-F0-00-00	SERIES 51	S51-110MV-1
83028041	PUMP-VAR DISPL, CW 90PV075	90-R-075-HF-1-AB-60-S-3-S1-E-03-GBA-38-38-24	SERIES 90	S90-075PV
83028044	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-AB-80-R-3-C7-F-03-EAB-40-40-24	SERIES 90	S90-100PV
83028045	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A4-C2-N-D3-H-F1-H3-L-42-L-42-D-M-20-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83028050	PUMP-VAR-DISPL CCW 90PV180	90L180-KT-5-BC-80-T-C-F1-J-03-FAC-35-35-24	SERIES 90	S90-180PV
83028056	PUMP-VAR-DISPL CCW H1PV089	H1-P-089-L-A-A5-C2-N-D8-H-G1-NN-L-38-L-38-M-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83028060	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-HE-HE-N-B-TB-VN-AN-N-A-05-NN-040-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83028061	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A4-C2-N-D6-H-G1-NN-L-42-L-42-C-L-18-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83028062	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-E-V-C-S-AA-B-A-U-A-BGG-GG-B-BF-B-C-U-A-BGG-GG-B-BF-B-NNN-	M46	M46-046PT
83028065	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-HE-HE-N-A-TB-CN-JN-N-N-NN-NN-032-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83028066	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-HE-HE-N-A-TB-CN-KN-N-A-20-NN-060-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83028068	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-D2-MA-N-B-PB-DN-KN-N-A-30-NN-060-N-26-NNN	H1-HP MOTORS	H1-160MB1
83028069	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-K-S-B-J-AA-A-A-BRF-CE-A-TT-B-NNR-***	M46	M46-046PV
83028070	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-K-S-B-J-AA-A-A-BJF-CE-A-TT-B-NNR-***	M46	M46-046PV
83028071	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A5-C3-N-D8-H-G1-NN-L-30-L-30-M-P-20-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83028076	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A5-C3-N-D8-L-G2-H3-K-40-K-40-L-P-24-P4-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83028077	MOTOR-VAR-DISPL 51MD110-1	51D110-1--R-D4-N-TA-C2-N-N-X1-ABA-074-AA-F0-00-35	SERIES 51	S51-110MV-1
83028082	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-L2-BA-N-A-PA-VS-ES-S-N-NN-NN-000-N-00-NNN	H1-HP MOTORS	H1-160MB1
83028083	MOTOR-VAR-DISPL H1B250	H1-B-250-A-L2-BA-N-A-PA-VS-FS-S-N-NN-NN-000-N-00-NNN	H1-HP MOTORS	H1-250MB1
83028086	PUMP-VAR-DISPL CW 90PV100	90R100-HS-2-BC-80-S-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83028090	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-8-N-0-C6-W-00-EAJ-00-00-F0	SERIES 90	S90-075MF
83028091	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-EF-80-D-M-C8-L-03-NNN-42-42-22	SERIES 90	S90-180PV
83028093	PUMP-VAR-DISPL CCW H1PV089	H1-P-089-L-A-A8-C2-C-D3-K-G9-NN-L-38-L-38-M-M-26-P2-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83028094	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A5-C2-N-D6-H-G1-H3-K-42-K-42-D-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83028099	MOTOR-VAR DISPL MMV046C	MMV-046-C-A-E-2-A-AE-VNF-***	M46	M46-046MV
83028100	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A5-C2-N-D8-G-G3-H2-L-20-L-20-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83028101	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A5-C2-N-D8-G-G3-H2-L-20-L-20-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83028103	PUMP-VAR-DISPL CW 90PV130	90R130-MA-1-NN-80-R-4-F1-F-03-GBA-23-23-24	SERIES 90	S90-130PV
83028104	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-5-AB-60-P-3-T2-D-03-GBA-38-14-24	SERIES 90	S90-075PV

83028106	MOTOR-VAR-DISPL 51MV250	51V250-R-C8-N-HZ-B1-C-N-C2-ACA-050-AA-H0-20-00	SERIES 51	S51-250MV
83028107	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-L2-BA-N-B-PA-VN-DN-N-A-15-NN-040-N-00-NNN	H1-HP MOTORS	H1-110MB1
83028108	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E2-AA-N-B-TA-VN-DN-N-A-15-NN-040-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83028109	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A5-C2-N-E5-F-G4-H3-L-23-L-23-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83028115	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A5-C2-N-D8-G-G3-H4-L-20-L-20-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83028116	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A5-C2-N-D8-G-G3-H4-L-20-L-20-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83028119	PUMP-VAR DISPL CCW H1P060L	H1-P-060-L-A-A5-C1-B-D8-H-G1-H5-L-38-L-38-C-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83028120	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-5-BC-60-S-4-T2-F-03-GBA-23-23-24	SERIES 90	S90-100PV
83028128	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-NN-80-T-3-C8-K-03-NNN-42-42-24	SERIES 90	S90-250PV
83028131	PUMP-VAR DISPL MPV046C	MPV-046-C-B-A-H-S-B-B-AA-A-A-BHH-AB-U-ED-A-NNN-***	M46	M46-046PV
83028133	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-7-N-0-K2-N-00-NNN-00-00-00	SERIES 90	S90-075MF
83028134	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-7-N-0-K1-N-00-NNN-00-00-00	SERIES 90	S90-055MF
83028139	PUMP-VAR-DISPL CCW H1PV165	H1-P-165-L-C-A5-C2-N-D3-G-G2-H5-L-42-L-42-A-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83028140	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-T2-D2-N-B-TB-VN-DN-N-A-20-NN-035-Z-30-NNN	H1-HP MOTORS	H1-160MB1
83028141	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-K-S-B-B-AA-A-A-BCC-CD-A-GG-B-NNN-***	M46	M46-046PV
83028142	PUMP-VAR-DISPL CW 90PV250	90R250-KA-2-CD-80-S-3-C8-K-03-NNN-38-38-24	SERIES 90	S90-250PV
83028143	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-L2-BA-N-B-PA-VS-DS-S-N-NN-NN-080-N-00-NNN	H1-HP MOTORS	H1-160MB1
83028149	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A4-C2-B-E5-F-G4-H2-L-35-L-35-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83028152	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-C-E2C8-03-B-3-X-A-F-N-Z-41-NN-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83028153	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-N-A2-C2-N-E7-F-G1-TN-35-35-35-35-M-P-32-PN-NNN-S02	H1-MP PUMPS	H1-045PT/053PT
83028171	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-HE-HE-N-B-TA-VN-EN-N-N-NN-NN-040-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83028172	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-L2-BA-N-A-PB-DN-JN-N-A-15-NN-040-N-00-NNN	H1-HP MOTORS	H1-110MB1
83028186	PUMP-VAR-DISPL CW 90PV075	90R075-KT-2-NN-60-S-3-S1-E-05-GBA-42-32-24	SERIES 90	S90-075PV
83028190	PUMP-VAR-DISPL CCW 90PV180	90L180-KN-5-EG-80-T-C-C8-J-03-NNN-32-32-24	SERIES 90	S90-180PV
83028191	PUMP-VAR-DISPL CCW 90PV250	90L250-KN-5-EG-80-T-3-C8-J-03-NNN-32-32-24	SERIES 90	S90-250PV
83028193	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A5-C2-N-D6-G-G3-H3-L-42-L-42-A-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83028194	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A5-C2-N-D6-G-G2-H4-L-42-L-42-A-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83028196	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-E2D8-03-B-D-B-2-H-N-T-32-32-B-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83028201	PUMP-VAR-DISPL CW 90PV130	90R130-MA-1-CD-80-S-3-F1-F-03-GBA-38-38-24	SERIES 90	S90-130PV
83028206	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MA-1-AB-60-P-3-C7-E-03-FAD-42-42-24	SERIES 90	S90-100PV
83028207	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-1-CD-80-S-3-S1-D-03-GBA-29-29-24	SERIES 90	S90-055PV
83028208	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-NN-80-S-3-S1-D-03-GBA-32-32-24	SERIES 90	S90-075PV
83028213	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E2-AA-N-B-TB-CN-JN-N-A-10-NN-050-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83028214	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-E2-AA-N-B-TB-VS-ES-B-A-20-NN-080-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83028216	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-BC-80-S-4-C7-E-03-GBA-23-23-24	SERIES 90	S90-075PV
83028217	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-NN-80-S-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV

83028218	PUMP-VAR DISPL, CW 90PV100	90-R-100-KN-1-AC-80-P-4-C7-F-03-GBA-23-23-24	SERIES 90	S90-100PV
83028223	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A5-C3-N-D3-G-G2-H4-L-35-L-35-A-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83028229	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-D2-MA-N-B-PA-VS-ES-S-A-10-NN-032-N-28-NNN	H1-HP MOTORS	H1-160MB1
83028230	MOTOR-VAR-DISPL H1B160	H1-B-160-A-TA-DA-N-B-TA-VN-EN-N-A-10-NN-032-Z-28-NNN	H1-HP MOTORS	H1-160MB1
83028231	MOTOR-VARIABLE CARTRIDGE L	L-C-35EN-E-RNF-F01-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83028232	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-NN-80-R-4-F1-H-03-GBA-42-42-24	SERIES 90	S90-130PV
83028233	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-AB-80-R-4-F1-H-03-GBA-26-26-24	SERIES 90	S90-130PV
83028234	PUMP-VAR-DISPL CCW 90PV180	90L180-KP-1-NN-80-T-C-F1-H-03-NNN-32-32-24	SERIES 90	S90-180PV
83028238	PUMP-VAR-DISPL CW 90PV180	90R180-HF-1-AB-80-T-C-F1-H-03-NNN-35-35-22	SERIES 90	S90-180PV
83028241	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E1-AA-N-C-TA-DN-HN-N-A-10-NN-052-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83028243	PUMP-TANDEM, VAR DISPL MPT044D	MPT-044-D-A-R-R-G-AA-B-A-A-A-BEE-DR-A-FF-B-C-A-A-BEE-DR-A-FF-A-NNN-*	M35/44	O44PT
83028245	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-F1-N-E1-B1-N-N-U1-ABA-050-AA-G3-00-00	SERIES 51	S51-110MV-1
83028249	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-CD-80-S-3-S1-D-03-GBA-32-32-24	SERIES 90	S90-075PV
83028250	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-K1-K1-N-C-RA-DS-JS-S-A-15-NN-037-N-30-NNN	H1-HP MOTORS	H1-110MB1
83028252	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A7-C1-C-D3-K-G9-H5-L-45-L-45-M-M-24-P2-NNN-D3E	H1-HP PUMPS	H1-089PV/100PV
83028264	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-NN-60-R-4-S1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
83028279	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-T2-D2-N-C-TA-DS-KS-S-A-20-NN-085-Z-30-NNN	H1-HP MOTORS	H1-160MB1
83028280	PUMP-VAR-DISPL CCW 90PV130	90L130-FH-5-NN-80-P-7-C8-H-BA-GBA-35-35-26	SERIES 90	S90-130PV
83028284	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E2-AA-N-B-TA-DN-GN-N-N-NN-NN-030-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83028289	PUMP-VAR DISPL MPV046C	MPV-046-C-B-A-K-S-A-J-BC-B-A-BFF-GB-B-FD-B-NGG-***	M46	M46-046PV
83028295	PUMP-VAR DISPL, CW 90PV055	90-R-055-KN-1-CD-80-S-4-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83028296	PUMP-VAR DISPL, CW 90PV055	90-R-055-KN-1-NN-80-S-4-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83028297	PUMP-VAR-DISPL CW 90PV130	90R130-HS-1-NN-80-S-4-T4-H-03-GBA-35-35-24	SERIES 90	S90-130PV
83028300	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A5-C2-N-D3-H-G1-H3-L-35-L-35-M-N-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83028301	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A5-C2-B-D3-G-G3-H6-L-23-L-23-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83028306	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-HE-HE-N-C-TB-CS-JS-S-A-10-NN-058-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83028307	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A4-C2-B-D5-G-G2-H4-L-40-L-40-L-N-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83028308	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A4-C2-B-D5-G-G3-H4-L-40-L-40-L-N-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83028309	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A4-C2-B-D3-G-G3-H4-L-40-L-40-A-N-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83028312	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-T2-DA-N-B-TB-DS-LS-S-A-20-NN-084-Z-28-NNN	H1-HP MOTORS	H1-160MB1
83028313	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-HS-A2-C-N-A7-NNN-032-AA-F0-15-20	SERIES 51	S51-160MV
83028317	PUMP-VAR DISPL MPV046C	MPV-046-C-B-A-B-S-B-AA-A-A-BFF-AK-U-BD-A-NNN-***	M46	M46-046PV
83028318	PUMP-VAR DISPL MPV046C	MPV-046-C-B-A-K-S-B-B-AA-A-A-BCC-AK-U-DB-B-NNN-***	M46	M46-046PV
83028320	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-NN-60-P-3-C6-D-03-FAD-29-29-24	SERIES 90	S90-075PV
83028321	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A7-C2-C-D6-K-F1-H3-L-42-L-42-C-L-32-P2-NNN-D3F	H1-MP PUMPS	H1-060PV/068PV
83028322	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A5-C2-N-D6-G-G2-H6-L-35-L-35-L-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV

83028323	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A5-C2-N-D6-G-G2-H3-L-35-L-35-L-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83028324	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A5-C2-N-D6-F-G4-H3-L-35-L-35-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83028328	PUMP-VAR-DISPL CW H1PV069	H1-P-069-R-A-A7-C2-C-D6-K-G1-NN-K-45-K-45-F-L-24-P2-NNN-D3E	H1-HP PUMPS	H1-069PV/078PV
83028329	PUMP-VAR-DISPL CW 90PV100	90R100-HF-5-CD-80-R-4-C7-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83028331	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-T2-D2-N-B-TB-VN-EN-N-A-10-NN-060-Z-28-NNN	H1-HP MOTORS	H1-110MB1
83028332	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-P1-D1-N-A-TA-DS-KS-S-A-10-NN-025-Z-24-NNN	H1-HP MOTORS	H1-110MB1
83028333	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A7-C2-C-D6-J-G5-H3-L-42-L-42-B-L-32-P2-NNN-D3F	H1-MP PUMPS	H1-045PV/053PV
83028334	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-P1-D1-N-A-TA-DS-HS-S-A-05-NN-018-Z-24-NNN	H1-HP MOTORS	H1-080MB1
83028336	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-P1-D1-N-C-TA-DS-KS-S-A-15-NN-030-Z-24-NNN	H1-HP MOTORS	H1-110MB1
83028338	PUMP-VAR-DISPL 42PV041 CCW	42-L-41-E-E2D8-03-B-D-B-3-H-N-T-32-32-B-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83028341	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-C3-C3-D-D6-J-G1-NN-L-35-L-35-B-L-24-P2-NNN-D6F	H1-MP PUMPS	H1-045PV/053PV
83028342	MOTOR-VAR-DISPL H1MB060	H1-B-060-A-D2-M2-N-B-PB-VS-AS-S-N-NN-NN-012-N-18-NNN	H1-HP MOTORS	H1-060MB1
83028345	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-ANN3-03-B-2-G-3-F-N-B-34-34-B-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83028347	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-8-N-0-S1-N-00-ECA-00-00-00	SERIES 90	S90-055MF
83028348	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-E1A6-01-B-5-G-2-C-N-A-34-34-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83028349	PUMP-VAR-DISPL CW 90PV100	90R100-KP-1-NN-80-L-3-S1-F-03-GBA-38-38-24	SERIES 90	S90-100PV
83028350	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-L2-BA-N-B-PB-CS-LS-S-A-20-NN-098-N-00-NNN	H1-HP MOTORS	H1-160MB1
83028359	PUMP-VAR-DISPL CCW 90PV180	90L180-KP-2-BC-80-T-C-F1-J-02-FAC-45-45-24	SERIES 90	S90-180PV
83028364	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-5-BC-80-R-3-S1-D-00-GBA-14-14-20	SERIES 90	S90-075PV
83028369	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A2-C2-N-F5-H-F1-H6-L-40-L-40-N-E-22-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83028370	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A2-C2-N-D8-H-G1-H5-L-40-L-40-N-E-22-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83028371	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-G-S-B-J-BA-V-A-BBF-DB-A-GG-C-NNN-***	M46	M46-046PV
83028373	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-HE-HE-N-B-TB-VN-AN-N-A-05-NN-019-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83028374	PUMP-VAR-DISPL CW 90PV130	90R130-HS-5-NN-80-R-4-C8-H-03-GBA-42-42-26	SERIES 90	S90-130PV
83028375	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-CD-80-D-4-C8-L-05-GBA-35-35-24-F076	SERIES 90	S90-130PV
83028376	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-DG-80-D-4-C8-L-05-GBA-35-35-24-F076	SERIES 90	S90-130PV
83028378	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A5-C3-N-D8-G-G3-H2-L-23-L-23-A-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83028396	PUMP-VAR-DISPL CCW 90PV180	90L180-KT-5-CD-80-T-C-F1-J-03-FAC-35-35-24	SERIES 90	S90-180PV
83028405	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-N-N2-NN-N-N-A0-ADA-050-AA-G0-00-00	SERIES 51	S51-250MV
83028407	PUMP-VAR-DISPL CW DDC20	DDC-20-A-R-RB-LSA-NN-A-N-3-AA-ACA0-D-07-14N-14N-NNN-NNN	DDC20/LDU20	OSK-020PV - DO NOT USE
83028411	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-L1-BA-N-A-PA-VS-AS-S-N-NN-NN-054-N-00-NNN	H1-HP MOTORS	H1-080MB1
83028414	PUMP-VAR-DISPL CW 90PV075	90R075-EA-1-NN-60-S-3-C6-E-41-GBA-36-36-24	SERIES 90	S90-075PV
83028415	PUMP-VAR-DISPL CW 90PV130	90R130-KA-1-NN-80-S-3-C8-H-05-GBA-37-37-24	SERIES 90	S90-130PV
83028422	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A3-C2-N-D3-G-G2-H5-L-30-L-30-A-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83028425	PUMP-VAR DISPL MPV035D	MPV-035-D-B-A-A-R-A-M-NN-A-A-BFF-DR-A-FF-A-NNN-***	M35/44	035PV
83028427	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-L2-BA-N-B-PB-CS-LS-S-A-30-NN-070-N-00-NNN	H1-HP MOTORS	H1-160MB1

83028428	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-HE-HE-N-B-TB-CN-GN-N-A-10-NN-020-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83028429	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-B1-C1-B-D8-H-G1-H3-L-42-L-42-N-E-28-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83028431	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A3-C1-N-D8-G-G2-H6-L-40-L-40-N-E-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83028485	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A5-C3-B-F6-H-G1-H6-L-42-L-42-C-L-28-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83028486	MOTOR-VAR-DISPL H1B160	H1-B-160-A-TA-DA-N-C-TB-DN-KN-N-N-NN-NN-080-Z-23-NNN	H1-HP MOTORS	H1-160MB1
83028487	MOTOR-VAR-DISPL H1B250	H1-B-250-A-T2-D2-N-C-TA-VS-DS-S-A-20-NN-090-Z-30-NNN	H1-HP MOTORS	H1-250MB1
83028491	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A5-C3-B-D3-G-G3-H2-L-25-L-25-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83028493	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-HZ-B1-B-E-G5-ABA-078-AA-G3-06-00	SERIES 51	S51-160MV
83028494	MOTOR-VAR-DISPL 51MV250	51V250-R-F2-N-HZ-B1-B-E-G5-ABA-085-AA-F3-06-00	SERIES 51	S51-250MV
83028495	PUMP-VAR-DISPL CW 90PV130	90R130-KP-1-CD-80-R-3-F1-H-00-GBA-42-42-24	SERIES 90	S90-130PV
83028497	PUMP-VAR-DISPL CW 90PV180	90R180-KP-1-DE-80-T-C-F1-J-00-FAC-42-42-24	SERIES 90	S90-180PV
83028498	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A5-C2-N-D3-G-G3-H6-L-42-L-42-A-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83028500	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KT-1-BC-60-P-3-T2-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83028501	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-B8-C1-C-D8-J-G1-H3-L-35-L-35-B-P-28-P2-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83028504	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-HE-HE-N-A-TB-VN-EN-N-N-NN-NN-040-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83028506	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-HE-HE-N-B-TB-CN-GN-N-A-10-NN-025-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83028507	PUMP-VAR-DISPL CCW 90PV042	90L042-HF-5-BB-80-S-3-C3-C-03-GBA-45-45-24	SERIES 90	S90-042PV
83028508	PUMP-VAR-DISPL CCW 90PV042	90L042-HF-5-AB-80-S-3-C3-C-03-GBA-45-45-24	SERIES 90	S90-042PV
83028510	PUMP-VAR-DISPL CW 90PV042	90R042-KA-1-BC-80-R-3-T3-C-02-GBA-38-38-20	SERIES 90	S90-042PV
83028582	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-L1-BA-N-B-PB-VN-EN-N-A-10-NN-074-N-00-NNN	H1-HP MOTORS	H1-110MB1
83028583	MOTOR-VAR-DISPL H1B160	H1-B-160-A-TA-DA-N-A-TB-VN-EN-N-A-20-NN-085-Z-27-NNN	H1-HP MOTORS	H1-160MB1
83028585	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-E1-AA-N-B-TA-VS-ES-S-A-20-NN-100-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83028587	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-AB-80-S-3-C3-B-03-GBA-35-35-24	SERIES 90	S90-042PV
83028590	PUMP-VAR-DISPL CCW 90PV180	90L180-HF-5-BC-80-S-C-C8-J-03-NNN-29-29-28	SERIES 90	S90-180PV
83028591	PUMP-VAR-DISPL CW 90PV180	90R180-HF-5-BC-80-S-C-C8-J-03-NNN-29-29-28	SERIES 90	S90-180PV
83028592	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-7-N-0-C6-W-00-EBA-00-00-F0	SERIES 90	S90-075MF
83028593	MOTOR-VAR-DISPL H1MB060	H1-B-060-A-M2-CA-N-A-RA-VS-AS-S-A-05-NN-000-N-00-NNN	H1-HP MOTORS	H1-060MB1
83028594	PUMP-VAR-DISPL CW 90PV130	90R130-KA-1-AB-80-L-4-F1-H-03-GBA-38-14-24	SERIES 90	S90-130PV
83028612	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A5-C3-N-D8-G-G3-NN-L-35-L-35-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83028613	MOTOR-VAR-DISPL H1MB060	H1-B-060-A-L2-BA-N-A-PB-VS-AS-S-A-10-NN-040-N-00-NNN	H1-HP MOTORS	H1-060MB1
83028614	PUMP-VAR DISPL, CW 90PV100	90-R-100-CB-1-NN-80-R-4-C7-E-00-GBA-42-32-24	SERIES 90	S90-100PV
83028615	PUMP-VAR-DISPL CW 90PV130	90R130-CB-5-NN-80-R-4-C8-H-00-GBA-42-32-24	SERIES 90	S90-130PV
83028619	MOTOR-VAR-DISPL H1B250	H1-B-250-A-L2-BA-N-B-PA-VS-FS-B-A-20-NN-070-N-00-NNN	H1-HP MOTORS	H1-250MB1
83028623	PUMP-VAR DISPL CW H1P068R	H1-P-068-R-A-A7-C1-C-D3-K-G1-H2-L-33-L-33-F-M-24-P2-NNN-D3F	H1-MP PUMPS	H1-060PV/068PV
83028624	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A4-C1-N-D6-H-G9-H3-L-35-L-35-D-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83028625	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A5-C3-N-D8-G-G3-H2-L-20-L-20-A-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV

83028627	PUMP-VAR-DISPL CCW H1PV115	H1-P-115-L-B-A3-C1-N-D3-G-G3-H6-L-35-L-35-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83028628	PUMP-VAR-DISPL CCW H1PV115	H1-P-115-L-B-A3-C1-N-D3-G-G3-NN-L-35-L-35-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83028634	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-ANN3-02-A-N-A-2-C-N-A-14-14-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83028635	PUMP-VAR-DISPL CCW H1PV069	H1-P-069-L-A-A3-C2-B-D3-H-G1-NN-L-42-L-42-C-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83028636	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A5-C2-N-D6-G-G3-H3-L-35-L-35-L-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83028644	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E2-AA-N-B-TB-VN-AN-N-A-05-NN-026-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83028646	PUMP-VAR-DISPL CW 90PV100	90R100-KA-1-AB-60-S-4-F1-F-03-GBA-14-35-20	SERIES 90	S90-100PV
83028647	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-M2-CA-N-A-RA-VS-AS-S-A-10-NN-000-N-00-NNN	H1-HP MOTORS	H1-080MB1
83028648	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-7-N-0-C6-W-00-EBA-00-00-F0	SERIES 90	S90-100MF
83028649	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A5-C2-N-D6-G-G3-H3-L-35-L-35-L-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83028651	PUMP-VAR-DISPL CW 90PV250	90R250-MA-5-AB-80-T-4-C8-J-C7-NNN-26-26-24	SERIES 90	S90-250PV
83028658	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-NN-80-S-4-F1-F-03-GBA-14-14-24	SERIES 90	S90-100PV
83028659	PUMP-VAR-DISPL CW 90PV130	90R130-KA-1-NN-80-L-3-F1-F-00-GBA-17-17-20	SERIES 90	S90-130PV
83028676	PUMP-VAR-DISPL CW 90PV130	90R130-KA-1-AB-80-L-3-F1-H-03-GBA-42-42-24	SERIES 90	S90-130PV
83028683	PUMP-VAR-DISPL CW H1PV069	H1-P-069-R-A-A2-C2-N-D6-H-G1-H3-L-42-L-42-C-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83028685	PUMP-VAR-DISPL CCW H1PV115	H1-P-115-L-B-A3-C1-N-D3-G-G3-H3-L-38-L-38-L-N-20-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83028686	PUMP-VAR-DISPL CCW H1PV115	H1-P-115-L-B-A3-C1-N-D3-G-G3-NN-L-38-L-38-L-N-20-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83028687	PUMP-VAR DISPL CCW H1P053L	H1-P-053-L-A-A3-C1-N-D8-F-G4-NN-L-35-L-35-B-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83028702	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A3-C2-N-D8-G-G2-H6-L-35-L-35-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83028749	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-E2C8-03-D-N-F-3-F-N-A-34-34-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83028778	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A9-C1-N-F4-H-G1-H6-L-35-L-35-C-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83028779	PUMP-VAR-DISPL CW 90PV180	90R180-HF-1-CD-80-D-C-C8-J-00-NNN-42-42-40	SERIES 90	S90-180PV
83028784	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-AB-80-L-4-F1-H-03-GBA-29-29-24	SERIES 90	S90-130PV
83028785	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-AB-80-L-4-F1-H-03-GBA-29-29-24	SERIES 90	S90-130PV
83028786	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-L1-BA-N-B-PA-VS-ES-S-A-20-NN-050-N-00-NNN	H1-HP MOTORS	H1-160MB1
83028787	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-HF-HF-N-A-TB-CS-KS-S-A-20-NN-060-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83028797	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-B7-C2-C-D3-K-G9-H3-L-42-L-42-M-M-24-P2-NNN-D5F	H1-HP PUMPS	H1-089PV/100PV
83028803	MOTOR-VARIABLE DISPL SAE_K	K-V-38CS-F-H1F-F55-S-N-N-EF-F18-NHC-NNN	LV / KV MOTORS	L/K-MV
83028804	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-E2-AA-N-C-TB-VS-ES-S-N-NN-NN-080-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83028811	PUMP-VAR DISPL CCW H1P053L	H1-P-053-L-A-A3-C1-N-D8-F-G5-NN-L-38-L-38-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83028816	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A2-C2-N-D8-F-G4-NN-L-25-L-25-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83028817	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-HE-HE-N-B-TA-VS-AS-S-N-NN-NN-032-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83028818	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-HE-HE-N-B-TA-VN-AN-N-N-NN-NN-032-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83028824	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-BC-80-L-3-C7-E-03-GBA-30-30-24	SERIES 90	S90-100PV
83028829	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-L1-BA-N-A-PB-VN-EN-N-N-NN-NN-000-N-00-NNN	H1-HP MOTORS	H1-110MB1
83028833	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A5-C1-B-D3-H-G9-H3-L-42-L-42-M-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV

83028849	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A7-C3-D-D8-K-G1-NN-L-30-L-30-C-P-24-P2-NNN-D3F	H1-HP PUMPS	H1-069PV/078PV
83028853	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E2-AA-N-B-TA-VN-AN-N-A-10-NN-035-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83028860	PUMP-VAR-DISPL CCW 90PV180	90L180-KN-5-NN-80-T-M-F1-H-03-FAC-35-35-24	SERIES 90	S90-180PV
83028862	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-NN-80-P-4-S1-E-03-GBA-20-20-24	SERIES 90	S90-075PV
83028864	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-1-BC-80-R-4-C6-C-03-FAD-35-35-24	SERIES 90	S90-055PV
83028865	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A2-C3-N-E7-F-G1-H2-25-25-20-20-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83028869	PUMP-VAR-DISPL CCW H1PV165	H1-P-165-L-C-A5-C1-N-D6-G-G3-NN-L-38-L-38-L-L-30-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83028870	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-T2-DA-N-B-TA-VN-EN-N-A-20-NN-085-Z-30-NNN	H1-HP MOTORS	H1-160MB1
83028871	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-NN-80-S-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83028873	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-CD-80-T-M-C8-J-03-NNN-20-20-24	SERIES 90	S90-180PV
83028878	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-NN-80-L-4-C7-E-03-GBA-23-23-24	SERIES 90	S90-100PV
83028890	PUMP-VAR DISPL MPV046C	MPV-046-C-B-A-A-T-B-B-AA-A-A-BGG-AK-U-BB-C-NNN-***	M46	M46-046PV
83028894	PUMP-VAR DISPL, CW 90PV075	90-R-075-CB-1-CD-80-P-4-S1-D-00-GBA-38-38-24	SERIES 90	S90-075PV
83028895	PUMP-VAR DISPL, CW 90PV075	90-R-075-CB-1-AB-80-P-4-S1-D-00-GBA-38-38-24	SERIES 90	S90-075PV
83028896	PUMP-VAR DISPL, CW 90PV075	90-R-075-HS-1-BC-80-R-3-C6-E-06-GBA-42-42-24	SERIES 90	S90-075PV
83028901	MOTOR-VARIABLE DISPL SAE_L	L-V-25CN-A-YNF-F10-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83028905	PUMP-VAR DISPL CW H1P068R	H1-P-068-R-A-C2-C2-C-F5-K-G1-H6-L-30-L-30-F-P-24-P2-NNN-D4F	H1-MP PUMPS	H1-060PV/068PV
83028914	PUMP-VAR DISPL MPV025C	MPV-025-C-B-A-A-R-A-U-NN-A-A-BJJ-DR-A-FF-A-NNN-***	LIGHT DUTY	025PV
83028915	PUMP-VAR DISPL MPV025C	MPV-025-C-B-A-A-R-A-U-NN-A-A-BHF-DR-A-FF-A-NNN-***	LIGHT DUTY	025PV
83028916	MOTOR-VARIABLE DISPL SAE_K	K-V-38CN-E-YAF-F09-T-N-X-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83028917	MOTOR-VARIABLE DISPL SAE_K	K-V-38CN-E-RAF-F09-T-N-X-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83028921	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-T2-D2-N-B-TA-DN-KN-N-A-20-NN-060-Z-30-NNN	H1-HP MOTORS	H1-160MB1
83028926	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-K2-K2-N-B-RA-CN-JN-N-A-05-NN-026-N-30-NNN	H1-HP MOTORS	H1-080MB1
83028927	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-T2-D2-N-B-TB-DN-HN-N-A-10-NN-030-Z-24-NNN	H1-HP MOTORS	H1-080MB1
83028928	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-AB-80-R-3-F1-F-03-GBA-23-23-24	SERIES 90	S90-100PV
83028929	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-1-BC-80-R-3-C8-H-03-GBA-26-26-24	SERIES 90	S90-130PV
83028930	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MA-1-NN-60-S-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83028931	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-K2-K2-N-B-RA-CN-CN-N-A-05-NN-026-N-26-NNN	H1-HP MOTORS	H1-080MB1
83028933	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-D2-M2-N-B-PA-VS-DS-S-A-15-NN-025-N-30-NNN	H1-HP MOTORS	H1-110MB1
83028936	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-D2-M2-N-B-PA-VS-DS-S-A-15-NN-050-N-30-NNN	H1-HP MOTORS	H1-110MB1
83028937	PUMP-TANDEM, VAR DISPL MPT035D	MPT-035-D-A-W-S-J-BA-B-A-A-A-BDD-DR-A-FF-B-C-A-A-BDD-DL-A-FF-C-NNN-*	M35/44	035PT
83028940	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-C-E2D8-03-B-3-B-2-F-N-N-17-17-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83028941	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-D-E2D8-03-B-3-B-2-F-N-B-17-17-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83028946	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-P2-D2-N-B-TB-VS-DS-S-A-20-NN-050-Z-24-NNN	H1-HP MOTORS	H1-160MB1
83028949	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A5-C2-N-D8-H-G1-H3-L-40-L-40-C-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83028950	PUMP-VAR-DISPL CCW H1PV165	H1-P-165-L-C-A5-C2-N-D7-G-G3-H4-L-35-L-35-A-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV

83028951	PUMP-VAR-DISPL CCW H1PV165	H1-P-165-L-C-A5-C2-N-D7-G-G2-H4-L-35-L-35-A-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83028952	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-A-C2-C2-C-D8-K-G9-H3-L-45-L-45-M-P-28-P2-NNN-D4E	H1-HP PUMPS	H1-089PV/100PV
83028959	MOTOR-VAR-DISPL 51MV060-1	51V060-1--R-S1-N-B3-B3-N-N-U3-NNN-031-AA-NN-00-00	SERIES 51	S51-060MV-1
83028960	PUMP-VAR DISPL MPV035D	MPV-035-D-B-A-A-L-S-G-BA-A-A-BEE-DR-A-FF-C-NNN-***	M35/44	035PV
83028966	MOTOR-VAR-DISPL H1MB060	H1-B-060-A-M1-CA-N-A-RB-VS-AS-S-A-05-NN-000-N-00-NNN	H1-HP MOTORS	H1-060MB1
83028973	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A3-C3-N-D3-H-G9-H3-L-42-L-42-M-M-30-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83028974	MOTOR-VAR-DISPL H1B250	H1-B-250-A-HF-HF-N-B-TB-VN-FN-N-A-20-NN-050-Z-00-NNN	H1-HP MOTORS	H1-250MB1
83028975	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A5-C2-B-D8-F-G1-H2-L-38-L-38-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83028976	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A5-C2-B-D3-H-F1-H2-L-42-L-42-F-M-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83028977	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A3-C1-N-D8-F-G1-H3-L-35-L-35-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83028978	PUMP-VAR DISPL, CW H1PV250	H1-P-250-R-A-A5-C3-B-D8-C-G2-H6-L-35-L-40-W-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-210PV/250PV
83028979	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A5-C3-N-D8-H-G1-H3-L-35-L-40-C-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83028981	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-1-BC-80-R-4-S1-C-03-FAD-35-35-24	SERIES 90	S90-055PV
83028983	PUMP-VAR DISPL CCW H1P060L	H1-P-060-L-A-A5-C3-B-D8-H-G1-H5-L-38-L-38-C-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83028984	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-HE-HE-N-B-TB-VS-ES-S-A-30-NN-108-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83028985	PUMP-VAR-DISPL CCW H1PV089	H1-P-089-L-A-A5-C2-N-D8-H-G1-H5-L-38-L-38-M-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83028987	PUMP-VAR-DISPL CCW H1PV089	H1-P-089-L-A-A5-C3-N-D8-H-F1-NN-L-38-L-38-M-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83028988	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-HE-HE-N-A-TB-VN-CN-N-N-NN-NN-020-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83028992	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-2-BC-80-P-4-S1-D-03-GBA-20-20-24	SERIES 90	S90-075PV
83028993	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HF-1-NN-80-P-3-S1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
83028995	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A3-C3-N-D3-H-G9-NN-L-42-L-42-M-M-28-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83028997	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-E1A3-03-D-N-F-2-H-N-A-34-34-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83029000	PUMP-VAR-DISPL CW 90PV075	90R075-HS-5-NN-60-L-4-C7-D-03-GBA-16-16-24	SERIES 90	S90-075PV
83029004	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-HE-HE-N-A-TB-CN-JN-N-A-10-NN-050-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83029005	PUMP-VAR-DISPL CCW H1PV130	H1-P-130-L-B-A5-C2-N-D8-G-G2-H3-L-25-L-25-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83029006	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-C6-C2-B-D3-G-G3-H4-L-42-L-42-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83029007	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-C6-C2-B-D6-G-G3-H6-L-42-L-42-L-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83029008	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A3-C3-N-F2-F-G5-NN-K-35-K-35-B-P-30-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83029009	PUMP-VAR-DISPL CCW H1PV069	H1-P-069-L-A-C6-C2-B-D3-H-G1-NN-L-42-L-42-C-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83029015	MOTOR-VAR-DISPL H1MB060	H1-B-060-A-L2-BA-N-B-PA-CS-GS-S-A-05-NN-012-N-00-NNN	H1-HP MOTORS	H1-060MB1
83029018	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-C2-C2-C-D3-K-G9-NN-L-42-L-42-F-M-24-P2-NNN-D4F	H1-HP PUMPS	H1-069PV/078PV
83029020	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-P2-D2-N-A-TA-DS-KS-S-A-20-NN-046-Z-24-NNN	H1-HP MOTORS	H1-160MB1
83029021	PUMP-VAR-DISPL CW 90PV180	90R180-HF-1-NN-80-T-C-F1-H-05-FAC-35-35-24	SERIES 90	S90-180PV
83029023	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-2-CD-80-P-3-S1-F-05-GBA-35-35-24	SERIES 90	S90-100PV
83029024	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-BC-80-S-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83029026	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-B8-C2-C-D3-H-G1-H2-L-30-L-30-C-M-30-P1-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV

83029029	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-T2-DA-N-B-TA-DN-JN-N-A-15-NN-039-Z-28-NNN	H1-HP MOTORS	H1-110MB1
83029031	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A8-C3-C-D6-H-G9-H5-L-42-L-42-C-L-26-P1-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83029036	PUMP-VAR DISPL CCW H1P060L	H1-P-060-L-A-A5-C2-N-D8-K-G1-NN-L-42-L-42-C-P-24-P4-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83029037	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A5-C2-N-D8-J-G1-NN-L-33-L-33-B-P-24-P4-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83029038	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E2-AA-N-A-TB-CS-AS-S-A-10-NN-029-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83029046	PUMP-VAR-DISPL CCW 90PV180	90L180-KP-5-NN-80-T-M-C8-J-03-NNN-42-42-24	SERIES 90	S90-180PV
83029052	PUMP-VAR-DISPL CW 90PV130	90R130-MA-1-BC-80-S-3-C8-H-03-GCA-35-35-24	SERIES 90	S90-130PV
83029054	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A3-C2-N-D6-H-G9-H2-L-44-L-44-C-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83029064	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-L2-BA-N-A-PB-CS-DS-S-A-15-NN-000-N-00-NNN	H1-HP MOTORS	H1-110MB1
83029065	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-A-A5-C2-N-D3-H-G1-H3-K-45-K-45-D-M-28-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83029066	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-A-A5-C2-N-F4-H-G9-H6-K-45-K-45-D-M-28-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83029067	MOTOR-VAR-DISPL 51MV110	51V110-A-F1-N-HS-A2-B-H-E1-NNN-043-AA-NN-10-25	SERIES 51	S51-110MV
83029070	PUMP-VAR DISPL CCW H1P053L	H1-P-053-L-A-A4-C1-N-E5-F-G5-H5-L-38-L-38-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83029071	PUMP-VAR DISPL CCW H1P053L	H1-P-053-L-A-A4-C1-N-E5-F-G5-H2-L-38-L-38-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83029074	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E2-AA-N-B-TB-CN-GN-N-A-10-NN-026-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83029075	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E2-AA-N-B-TB-DN-JN-N-A-10-NN-040-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83029076	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E2-AA-N-B-TA-VN-EN-N-N-NN-NN-000-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83029092	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-C2-C2-C-D6-K-F1-H3-L-42-L-42-C-L-32-P2-NNN-D4F	H1-MP PUMPS	H1-060PV/068PV
83029093	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-P2-D2-N-A-TA-DS-JS-S-A-10-NN-027-Z-24-NNN	H1-HP MOTORS	H1-110MB1
83029099	MOTOR-VAR-DISPL H1B250	H1-B-250-A-HE-HE-N-B-TB-VN-FN-N-A-20-NN-100-Z-00-NNN	H1-HP MOTORS	H1-250MB1
83029100	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-HE-HE-N-B-TB-VN-EN-N-A-20-NN-100-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83029101	PUMP-VAR-DISPL CCW H1PV115	H1-P-115-L-B-A5-C3-B-D6-G-G3-H3-L-42-L-42-L-L-28-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83029103	PUMP-VAR-DISPL CCW H1PV115	H1-P-115-L-B-A5-C3-B-D6-G-G3-H4-L-42-L-42-L-L-28-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83029106	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A5-C2-N-D3-H-F4-H2-L-38-L-15-M-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83029107	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A5-C2-N-D8-F-F2-NN-L-38-L-15-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83029116	PUMP-VAR-DISPL CCW DDC20	DDC-20-A-L-LB-LSA-NN-A-2-N-BC-AAN1-D-07-30N-30N-NNN-NNN	DDC20/LDU20	OSK-020PV - DO NOT USE
83029119	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-A-A4-C2-N-F4-H-G9-H6-L-42-L-42-D-M-20-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83029120	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-A-A4-C2-N-D3-H-G1-H3-L-42-L-42-D-M-20-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83029121	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A4-C2-N-D3-H-G9-H3-L-42-L-42-D-M-20-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83029122	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-T1-D1-N-B-TA-DN-HN-N-A-05-NN-030-Z-27-NNN	H1-HP MOTORS	H1-060MB1
83029138	PUMP-VAR-DISPL CCW 90PV180	90L180-KP-1-CD-80-T-C-F1-H-03-FAC-35-35-24	SERIES 90	S90-180PV
83029139	PUMP-VAR DISPL, CCW 90PV075	90-L-075-M2-1-NN-60-S-4-S1-D-03-GBA-42-42-28	SERIES 90	S90-075PV
83029140	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-7-N-0-C6-N-00-NNN-00-00-00	SERIES 90	S90-075MF
83029141	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E1-AA-N-B-TB-VN-AN-N-A-10-NN-030-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83029146	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A5-C2-N-D3-H-G9-H5-L-42-L-42-D-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83029147	PUMP-VAR DISPL CCW H1P060L	H1-P-060-L-A-A5-C2-N-D3-H-G1-H5-L-15-L-30-F-M-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV

83029151	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A9-C3-N-D8-H-G1-H5-K-42-K-42-M-P-30-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83029162	PUMP-VAR DISPL CCW H1P060L	H1-P-060-L-A-A3-C2-N-D8-H-G1-H3-L-35-L-35-F-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83029168	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-N-A4-C3-N-E7-F-G1-H3-30-30-30-30-N-P-28-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83029172	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-7-N-0-C7-W-00-EAA-00-00-G0	SERIES 90	S90-100MF
83029173	PUMP-VAR-DISPL CW H1PV069	H1-P-069-R-A-A4-C2-N-D6-H-G1-H5-L-45-L-45-C-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83029174	MOTOR-VAR-DISPL H1B250	H1-B-250-A-K1-K1-N-B-RA-VS-FS-S-A-20-NN-050-N-25-NNN	H1-HP MOTORS	H1-250MB1
83029177	PUMP-VAR-DISPL CW 90PV250	90R250-HF-5-BB-80-S-3-C8-J-03-NNN-38-20-24	SERIES 90	S90-250PV
83029179	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A3-C3-N-D3-G-G3-H3-L-42-L-42-A-M-28-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83029197	PUMP-VAR DISPL, CCW 90PV100	90-L-100-DC-1-NN-80-S-3-F1-E-G4-GBA-42-42-24	SERIES 90	S90-100PV
83029198	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-EF-80-T-3-F1-K-03-NNN-38-38-24	SERIES 90	S90-250PV
83029200	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A5-C1-N-D6-F-G5-H2-L-35-L-35-B-L-32-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83029201	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A5-C2-N-D6-G-G2-H3-L-42-L-42-L-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83029207	MOTOR-VAR-DISPL H1B160	H1-B-160-A-TA-DA-N-B-TA-VN-EN-N-A-20-NN-100-Z-29-NNN	H1-HP MOTORS	H1-160MB1
83029208	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-AB-60-S-3-C7-D-03-GBA-42-42-24	SERIES 90	S90-075PV
83029209	PUMP-VAR-DISPL CCW 90PV075	90L075-CB-5-AB-60-S-3-C7-D-00-GBA-42-42-24	SERIES 90	S90-075PV
83029213	PUMP-VAR DISPL CCW H1P060L	H1-P-060-L-A-A5-C2-N-D6-H-G1-NN-L-25-L-25-F-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83029218	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A5-C2-N-D8-H-G9-NN-L-35-L-35-C-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83029219	PUMP-VAR-DISPL CW 90PV130	90R130-HF-5-BC-80-L-4-C8-H-03-GBA-35-35-24	SERIES 90	S90-130PV
83029220	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-E-Z-C-B-BA-B-B-A-A-BJJ-CB-A-GG-B-C-A-A-BJB-AC-D-FF-A-NNN-***	M46	M46-046PT
83029222	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-T2-C0-L-N-G0-AHA-040-AA-F3-00-C0	SERIES 51	S51-160MV
83029223	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-A-A5-C2-N-D8-H-G9-NN-L-35-L-35-M-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83029243	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-5-AB-80-L-3-S1-D-00-EBC-38-14-24	SERIES 90	S90-075PV
83029244	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A5-C2-N-D3-G-G3-H6-L-35-L-35-L-M-26-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83029245	PUMP-VAR DISPL, CW 90PV075	90-R-075-HS-1-CD-80-P-3-C7-E-03-GBA-38-38-24	SERIES 90	S90-075PV
83029246	PUMP-VAR DISPL, CW 90PV075	90-R-075-HS-1-NN-80-P-3-S1-E-03-GBA-38-38-24	SERIES 90	S90-075PV
83029248	PUMP-VAR DISPL, CW 90PV075	90-R-075-CB-1-NN-60-S-3-S1-E-00-GBA-42-42-20	SERIES 90	S90-075PV
83029255	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-L1-BA-N-A-PA-DS-HS-S-A-10-NN-000-N-00-NNN	H1-HP MOTORS	H1-080MB1
83029259	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-C3-C2-C-D8-K-G9-H2-L-38-L-38-C-P-24-P2-NNN-D6F	H1-HP PUMPS	H1-069PV/078PV
83029260	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-A-C3-C2-C-D8-K-G9-H2-L-38-L-38-M-P-24-P2-NNN-D6F	H1-HP PUMPS	H1-089PV/100PV
83029261	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-C3-C2-C-D8-K-G9-H2-L-38-L-38-M-P-24-P2-NNN-D6F	H1-HP PUMPS	H1-089PV/100PV
83029265	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KN-5-AB-80-S-3-C7-D-03-GBA-35-35-30	SERIES 90	S90-075PV
83029272	MOTOR-VAR-DISPL H1B250	H1-B-250-A-D2-M2-N-A-PB-VS-DS-S-A-30-NN-082-N-30-NNN	H1-HP MOTORS	H1-250MB1
83029277	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A4-C2-N-D3-G-G2-H3-L-42-L-42-A-M-20-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83029288	MOTOR-VAR-DISPL 51MV080	51V080-R-S1-N-HS-A1-B-E-E2-NNN-023-AA-E6-08-20	SERIES 51	S51-080MV
83029289	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E2-AA-N-B-TB-VN-AN-N-N-NN-NN-045-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83029292	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-BB-60-S-4-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV

83029297	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HS-5-NN-80-R-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-055PV
83029298	PUMP-TANDEM, VAR DISPL MPT025C	MPT-025-C-S-R-A-R-NN-B-A-A-A-BFF-DR-A-FF-B-C-A-A-BFF-DR-A-FF-A-NNN-**	LIGHT DUTY	025PT
83029299	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-D2-MA-N-B-PB-DS-KS-P-A-30-NN-035-N-26-NNN	H1-HP MOTORS	H1-160MB1
83029300	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-L2-BA-N-A-PB-DS-JS-P-A-15-NN-030-N-00-NNN	H1-HP MOTORS	H1-110MB1
83029301	PUMP-VAR-DISPL CCW 90PV250	90L250-KP-5-NN-80-T-4-F1-J-03-NNN-35-35-24	SERIES 90	S90-250PV
83029302	PUMP-VAR-DISPL CCW 90PV180	90L180-KP-5-AB-80-T-M-C8-J-03-FAC-35-35-24	SERIES 90	S90-180PV
83029304	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-L2-BA-N-A-PA-DS-HS-S-A-10-NN-000-N-00-NNN	H1-HP MOTORS	H1-080MB1
83029312	PUMP-VAR-DISPL CCW 90PV130	90L130-MA-1-CD-80-P-4-C8-F-03-GBA-26-26-24	SERIES 90	S90-130PV
83029324	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E2-AA-N-B-TB-DN-JN-N-A-10-NN-044-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83029326	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E2-AA-N-B-TB-DN-JN-N-A-10-NN-036-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83029328	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-B1-C1-B-D6-H-G1-NN-L-33-L-33-F-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83029329	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-B1-C1-B-D6-G-G2-H6-L-35-L-35-L-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83029330	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-A-B1-C1-B-D6-H-G1-NN-L-33-L-33-M-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83029331	PUMP-VAR DISPL, CW 90PV100	90-R-100-LV-1-NN-60-S-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83029332	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A5-C2-N-D3-G-G2-E5-L-33-L-33-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83029333	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A5-C2-N-D3-G-G2-E5-L-30-L-30-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83029337	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-8-N-0-F1-W-00-EEA-00-00-F0	SERIES 90	S90-100MF
83029339	PUMP-VAR-DISPL CW H1PV069	H1-P-069-R-A-A2-C2-B-D6-H-G1-H3-L-42-L-42-C-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83029342	MOTOR-VAR-DISPL H1B160	H1-B-160-A-TA-DA-N-A-TB-VN-EN-N-A-20-NN-080-Z-21-NNN	H1-HP MOTORS	H1-160MB1
83029343	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-BC-60-R-3-C7-E-03-GFK-42-42-24	SERIES 90	S90-100PV
83029344	PUMP-VAR DISPL, CW 90PV100	90-R-100-KN-1-CD-80-S-4-T2-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83029356	MOTOR-VAR-DISPL H1B080	H1-B-080-A-TA-DA-N-B-TB-VN-AN-N-N-NN-NN-050-Z-20-NNN	H1-HP MOTORS	H1-080MB1
83029361	MOTOR-VAR-DISPL H1B250	H1-B-250-A-HE-HE-N-A-TB-VN-FN-N-N-NN-NN-050-Z-00-NNN	H1-HP MOTORS	H1-250MB1
83029387	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-NN-60-S-4-F1-F-05-GBA-35-35-24	SERIES 90	S90-100PV
83029390	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A5-C1-N-D6-H-G1-H2-L-38-L-38-F-L-20-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83029391	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-C-E1A7-03-A-N-N-A-G-N-Z-NN-NN-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83029410	PUMP-TANDEM, VAR DISPL CCW H1T045L	H1-T-045-L-A-N-A4-C2-N-E7-F-G1-H3-42-42-42-42-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83029412	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-1-BC-60-R-3-S1-C-00-GBA-35-35-24	SERIES 90	S90-055PV
83029416	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A3-C2-N-D6-K-G9-NN-L-40-L-40-M-L-24-P4-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83029420	PUMP-VAR DISPL, CW 90PV075	90-R-075-MS-1-BC-60-P-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-075PV
83029426	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-NN-60-P-3-C6-D-03-GBA-20-20-24	SERIES 90	S90-075PV
83029435	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-T1-D1-N-B-TB-CN-JN-N-A-10-NN-030-Z-20-NNN	H1-HP MOTORS	H1-110MB1
83029442	MOTOR-FIX DISPL MMF044D	MMF-044-D-A-6-U-C-D-NNR-***	M35/44	044MF
83029443	MOTOR-VAR-DISPL H1B160#	H1-B-160-A-F2-EA-N-A-TB-CN-KN-N-N-NN-NN-080-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83029449	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-CD-80-R-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83029460	PUMP-VAR-DISPL CW 90PV100	90R100-KA-1-NN-60-L-3-C7-F-00-GBA-37-37-24	SERIES 90	S90-100PV

83029461	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E2-AA-N-B-TB-VN-DN-N-A-15-NN-055-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83029467	PUMP-VAR DISPL MPV046C	MPV-046-C-B-A-K-S-B-J-AA-A-A-BJJ-GB-B-CF-B-NNN-***	M46	M46-046PV
83029474	PUMP-VAR-DISPL CCW H1PV115	H1-P-115-L-B-A5-C3-N-D3-G-G2-H4-K-42-K-42-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83029475	PUMP-VAR-DISPL CCW H1PV115	H1-P-115-L-B-A5-C3-N-D3-G-G3-H3-K-42-K-42-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83029476	MOTOR-VAR-DISPL H1B250	H1-B-250-A-L2-BA-N-A-PA-VS-DS-S-A-30-NN-050-N-00-NNN	H1-HP MOTORS	H1-250MB1
83029477	PUMP-VAR-DISPL CW 90PV075	90R075-HF-5-BC-80-S-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83029478	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-HE-HE-N-B-TB-VN-DN-N-A-10-NN-060-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83029489	PUMP-VAR DISPL CCW H1P053L	H1-P-053-L-A-A5-C2-N-D8-F-G1-H2-L-38-L-38-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83029491	PUMP-VAR DISPL CCW H1P053L	H1-P-053-L-A-A5-C2-N-D8-F-G1-H5-L-38-L-38-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83029493	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A4-C1-N-D6-F-G5-NN-L-35-L-30-B-L-30-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83029494	MOTOR-VAR-DISPL H1B250#	H1-B-250-A-T2-DA-N-A-TB-VN-DN-N-A-30-NN-080-Z-20-NNN	H1-HP MOTORS	H1-250MB1
83029498	PUMP-VAR-DISPL 42PV041 CCW	42-L-51-D-E1A5-00-A-N-A-3-F-N-A-34-34-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83029499	PUMP-VAR-DISPL 42PV041 CCW	42-L-41-C-ANN5-03-C-3-A-2-F-N-B-34-34-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83029501	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-CD-80-S-3-C8-H-06-GBA-30-30-24	SERIES 90	S90-130PV
83029502	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A5-C2-N-D8-F-G5-H2-L-38-L-38-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83029503	PUMP-VAR DISPL CCW H1P053L	H1-P-053-L-A-A5-C2-N-D8-F-G5-H2-L-38-L-38-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83029504	PUMP-TANDEM, VAR DISPL CCW H1T053L	H1-T-053-L-A-N-A5-C2-N-E7-F-G1-T2-38-28-38-28-M-P-24-PN-NNN-S01	H1-MP PUMPS	H1-045PT/053PT
83029507	PUMP-VAR DISPL, CW 90PV055	90-R-055-HF-5-AB-80-R-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-055PV
83029510	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-HE-HE-N-B-TB-DN-JN-N-A-10-NN-060-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83029521	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E1-AA-N-B-TB-VS-AS-S-A-10-NN-016-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83029526	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-HE-HE-N-B-TB-VS-AS-P-A-10-NN-016-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83029527	PUMP-VAR DISPL, CCW 90PV075	90-L-075-CB-1-NN-80-S-3-S1-D-00-GBA-35-35-24	SERIES 90	S90-075PV
83029528	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-HE-HE-N-B-TB-VS-AS-S-A-05-NN-016-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83029530	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A3-C3-B-D6-F-G5-H2-L-20-L-20-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83029531	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E1-AA-N-B-TA-VN-DN-N-A-10-NN-022-S-00-NNN	H1-HP MOTORS	H1-110MB1
83029536	PUMP-VAR DISPL, CW 90PV100	90-R-100-HD-D-BC-8C-S-E-F1-F-00-GBA-33-33-30	SERIES 90	S90-100PV
83029537	PUMP-VAR DISPL, CCW H1PV210	H1-P-210-L-A-A3-C1-N-D8-C-G2-NN-L-30-L-30-R-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-210PV/250PV
83029539	PUMP-VAR-DISPL CW 90PV042	90R042-KA-P-NN-80-D-4-C3-N-03-GBA-48-48-24	SERIES 90	S90-042PV
83029555	PUMP-VAR DISPL MPV046C	MPV-046-C-B-A-H-T-B-J-BA-A-A-BFF-AK-D-AD-A-NNN-***	M46	M46-046PV
83029557	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E2-AA-N-A-TB-CS-AS-P-A-05-NN-020-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83029561	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-K-T-B-B-AA-A-A-BHH-CB-A-HH-4-NNN-***	M46	M46-046PV
83029572	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-HE-HE-N-A-TB-CN-JN-N-A-05-NN-028-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83029573	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A4-C1-B-E6-F-G5-H2-L-20-L-20-B-L-26-PN-NNN-E01	H1-MP PUMPS	H1-045PV/053PV
83029575	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-1-NN-60-P-4-S1-C-03-GBA-35-35-20	SERIES 90	S90-055PV
83029576	PUMP-VAR DISPL CCW H1P068L	H1-P-068-L-A-A5-C1-N-F6-H-F1-H6-L-35-L-35-F-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83029580	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-NN-60-L-3-C6-E-03-GBA-35-35-24	SERIES 90	S90-075PV

83029605	PUMP-VAR DISPL, CCW 90PV055	90-L-055-CB-2-NN-80-S-3-S1-C-00-GBA-42-42-24	SERIES 90	S90-055PV
83029606	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-G-S-A-J-BC-3-A-BJJ-DA-A-HH-C-NNN-***	M46	M46-046PV
83029610	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-CD-80-T-4-F1-K-03-NNN-30-30-24	SERIES 90	S90-250PV
83029615	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-8-N-0-K1-W-00-NNN-00-00-E4	SERIES 90	S90-055MF
83029622	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A2-C3-N-D8-H-F1-NN-L-42-L-42-F-P-22-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83029623	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-D2-MA-N-B-PA-CN-JN-N-N-NN-NN-045-N-16-NNN	H1-HP MOTORS	H1-080MB1
83029624	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A4-C3-N-D3-G-G3-H3-L-42-L-42-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83029629	PUMP-VAR-DISPL CCW 90PV075	90L075-DC-5-NN-80-S-4-S1-E-GB-GBA-40-40-28	SERIES 90	S90-075PV
83029634	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-8-N-0-K3-W-00-NNN-00-00-F3	SERIES 90	S90-100MF
83029638	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-T1-DA-N-B-TA-DN-KN-N-A-15-NN-037-Z-30-NNN	H1-HP MOTORS	H1-110MB1
83029642	MOTOR-VAR-DISPL 51MD110-1	51D110-1--R-C8-A-E2-B1-N-N-U1-NNN-055-AA-NN-00-00	SERIES 51	S51-110MV-1
83029645	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MA-1-NN-60-R-4-S1-E-03-GBA-23-23-24	SERIES 90	S90-100PV
83029647	PUMP-VAR-DISPL CW 90PV130	90R130-HF-5-AB-80-R-4-F1-H-03-GBA-17-35-24	SERIES 90	S90-130PV
83029652	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-5-CD-60-P-4-C6-D-GB-GBA-35-35-20	SERIES 90	S90-055PV
83029653	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-1-NN-60-P-4-S1-D-GB-GBA-35-35-20	SERIES 90	S90-055PV
83029658	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-M1-CA-N-A-RA-DS-JS-S-A-10-NN-000-N-00-NNN	H1-HP MOTORS	H1-080MB1
83029659	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-1-N-0-T1-W-00-EFM-00-00-F0	SERIES 90	S90-055MF
83029661	PUMP-VAR-DISPL CCW H1PV147	H1-P-147-L-C-A3-C1-B-D8-G-G3-NN-L-35-L-35-A-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83029663	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-HE-HE-N-B-TB-VN-AN-N-N-NN-NN-000-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83029664	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-L2-BA-N-A-PA-VS-BS-S-A-10-NN-000-N-00-NNN	H1-HP MOTORS	H1-080MB1
83029665	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A7-C2-C-D8-K-G9-H5-L-45-L-45-N-E-28-P2-NNN-D3F	H1-HP PUMPS	H1-069PV/078PV
83029666	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-P2-D2-N-A-TB-VS-ES-S-A-20-NN-032-Z-24-NNN	H1-HP MOTORS	H1-160MB1
83029667	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A5-C2-N-D3-G-G3-H6-L-42-L-42-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83029670	MOTOR-VARIABLE DISPL SAE_K	K-V-38CN-E-RNF-F01-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83029672	PUMP-VAR DISPL, CCW 90PV055	90-L-055-MA-1-BC-80-R-4-S1-C-03-GBA-35-14-24	SERIES 90	S90-055PV
83029673	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E1-AA-N-A-TA-VN-AN-N-A-10-NN-035-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83029674	PUMP-VAR DISPL, CCW 90PV055	90-L-055-MA-1-NN-80-R-4-S1-C-03-GBA-35-14-24	SERIES 90	S90-055PV
83029687	MOTOR-VARIABLE CARTRIDGE L	L-C-25CN-A-RNF-F55-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83029693	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-T1-D1-N-B-TB-DN-JN-N-A-10-NN-030-Z-20-NNN	H1-HP MOTORS	H1-110MB1
83029702	PUMP-VAR DISPL, CW 90PV075	90-R-075-DD-1-BC-80-S-3-C6-E-GB-GBA-32-32-24	SERIES 90	S90-075PV
83029703	PUMP-VAR DISPL, CW 90PV075	90-R-075-FG-1-BC-60-L-7-S1-E-B6-FAD-40-40-24	SERIES 90	S90-075PV
83029704	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-CD-80-P-3-D7-D-03-GBA-14-35-24	SERIES 90	S90-075PV
83029705	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A5-C3-B-D6-G-G3-NN-L-25-L-25-A-L-30-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83029710	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-CD-80-T-C-C8-J-05-NNN-42-42-24	SERIES 90	S90-180PV
83029711	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-NN-80-T-C-C8-J-05-NNN-42-42-24	SERIES 90	S90-180PV
83029715	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-L2-BA-N-B-PB-DN-JN-N-N-NN-NN-050-N-00-NNN	H1-HP MOTORS	H1-110MB1

83029716	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-L2-BA-N-B-PB-DN-KN-N-N-NN-NN-050-N-00-NNN	H1-HP MOTORS	H1-160MB1
83029720	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-AB-80-R-3-C7-F-03-EAB-40-40-24	SERIES 90	S90-100PV
83029722	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-N-TH-C2-L-N-G0-ADA-111-AA-H0-00-C7	SERIES 51	S51-250MV
83029729	PUMP-VAR-DISPL CW 90PV100	90R100-KP-1-AB-80-S-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83029742	PUMP-VAR-DISPL CW 90PV130	90R130-CB-5-NN-80-P-4-C8-H-00-GBA-42-42-30	SERIES 90	S90-130PV
83029743	PUMP-VAR-DISPL CW 90PV100	90R100-CB-5-NN-80-P-4-C7-E-00-GBA-42-42-30	SERIES 90	S90-100PV
83029745	MOTOR-VAR-DISPL 51MV110-1	51V110-1--R-C8-A-E2-B1-N-N-U1-NNN-055-AA-NN-00-00	SERIES 51	S51-110MV-1
83029749	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A7-C2-C-F3-J-G5-H2-K-35-K-35-B-L-20-P2-NNN-D3F	H1-MP PUMPS	H1-045PV/053PV
83029750	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-T1-D1-N-B-TA-DN-JN-N-A-10-NN-030-Z-20-NNN	H1-HP MOTORS	H1-110MB1
83029751	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-HE-HE-N-A-TA-VN-EN-N-N-NN-NN-055-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83029755	PUMP-VAR-DISPL CW 90PV075	90R075-HF-5-BC-80-R-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83029756	PUMP-VAR-DISPL CW 90PV075	90R075-K7-5-NN-80-P-4-C7-E-03-GBA-42-42-30	SERIES 90	S90-075PV
83029757	MOTOR-VAR-DISPL 51MV160	51V160-R-C8-N-L1-B1-W-B-J1-NNN-070-AA-F0-D4-00	SERIES 51	S51-160MV
83029763	PUMP-VAR-DISPL CW 90PV075	90R075-KP-5-BB-80-L-3-S1-E-00-GBA-32-32-24	SERIES 90	S90-075PV
83029767	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E2-AA-N-A-TB-VS-ES-B-A-15-NN-050-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83029769	PUMP-VAR-DISPL CCW H1PV069	H1-P-069-L-A-A2-C2-N-D6-H-G1-H3-K-33-K-33-C-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83029770	PUMP-VAR DISPL CCW H1P060L	H1-P-060-L-A-A4-C1-N-D6-H-G1-H5-L-42-L-42-C-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83029776	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-E2-AA-N-B-TA-VN-EN-N-A-20-NN-035-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83029777	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-HE-HE-N-B-TA-DN-KN-N-A-20-NN-080-T-00-NNN	H1-HP MOTORS	H1-160MB1
83029778	PUMP-VAR DISPL, CW 90PV100	90-R-100-DD-1-AB-60-L-3-F1-E-GB-GBA-38-38-20	SERIES 90	S90-100PV
83029781	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-1-NN-60-P-3-C7-D-03-FAD-42-42-24	SERIES 90	S90-075PV
83029782	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-NN-80-P-3-C7-D-03-GBA-23-23-24	SERIES 90	S90-075PV
83029783	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-BC-80-P-3-C7-D-03-GBA-23-23-24	SERIES 90	S90-075PV
83029788	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-HE-HE-N-B-TB-CN-HN-N-A-10-NN-038-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83029789	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-C3-C2-C-D3-K-G9-NN-L-42-L-42-F-M-24-P2-NNN-D6F	H1-HP PUMPS	H1-069PV/078PV
83029801	PUMP-TANDEM, VAR DISPL CCW H1T045L	H1-T-045-L-A-N-A5-C2-N-E7-F-G1-TN-35-35-35-35-M-P-24-PN-NNN-S01	H1-MP PUMPS	H1-045PT/053PT
83029802	PUMP-VAR-DISPL CW 90PV130	90R130-HF-5-BC-80-P-4-C8-F-03-GBA-26-26-24	SERIES 90	S90-130PV
83029803	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-T2-D2-N-B-TB-VN-AN-N-A-10-NN-032-Z-17-NNN	H1-HP MOTORS	H1-080MB1
83029805	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-B8-C3-C-D3-K-F1-H3-L-33-L-33-C-M-28-P2-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83029808	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A8-C2-C-E9-F-G5-H5-K-35-K-35-B-P-24-P1-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83029815	MOTOR-VAR-DISPL 51MV160	51V160-A-F1-N-TA-C2-L-N-G0-NNN-070-AA-H0-00-C6	SERIES 51	S51-160MV
83029817	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A2-C2-N-D8-K-G9-H5-L-45-L-45-N-E-34-P4-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83029819	PUMP-VAR DISPL, CW 90PV100	90-R-100-HF-1-NN-80-R-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83029820	MOTOR-VAR-DISPL H1B250	H1-B-250-A-HE-HE-N-B-TB-VN-FN-N-A-20-NN-168-Z-00-NNN	H1-HP MOTORS	H1-250MB1
83029821	MOTOR-VAR-DISPL H1B110	H1-B-110-A-TA-DA-N-B-TB-VN-DN-N-N-NN-NN-045-Z-20-NNN	H1-HP MOTORS	H1-110MB1
83029823	MOTOR-VAR-DISPL H1B110	H1-B-110-A-TA-DA-N-B-TB-VN-DN-N-N-NN-NN-045-Z-23-NNN	H1-HP MOTORS	H1-110MB1

83029824	MOTOR-VAR-DISPL H1B110	H1-B-110-A-TA-DA-N-B-TB-VN-DN-N-N-NN-NN-055-Z-23-NNN	H1-HP MOTORS	H1-110MB1
83029828	MOTOR-VAR-DISPL H1MB060	H1-B-060-A-M2-CA-N-B-RA-VS-AS-S-A-05-NN-016-N-00-NNN	H1-HP MOTORS	H1-060MB1
83029832	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A3-C3-N-D3-G-G3-H3-L-45-L-45-L-M-28-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83029837	PUMP-VAR DISPL, CCW 90PV055	90-L-055-MA-1-NN-60-P-3-C6-C-03-FAD-42-42-24	SERIES 90	S90-055PV
83029839	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-8-N-0-C6-W-00-EAJ-00-00-E6	SERIES 90	S90-055MF
83029843	MOTOR-VARIABLE CARTRIDGE K	K-C-45DN-E-R1F-F10-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83029844	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-8-N-0-S1-W-00-EGH-00-00-F0	SERIES 90	S90-075MF
83029848	MOTOR-VAR-DISPL 51MD060-1	51D060-1--R-D2-N-E0-B1-N-N-U1-NNN-012-AA-NN-00-00	SERIES 51	S51-060MV-1
83029850	MOTOR-VAR-DISPL 51MV250	51V250-A-F2-D-TA-C2-L-N-G0-NNN-095-AA-F0-00-C7	SERIES 51	S51-250MV
83029856	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A6-C3-B-G3-G-G2-NN-L-45-L-45-L-L-32-PN-NNN-G14	H1-HP PUMPS	H1-115PV/130PV
83029872	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A7-C1-C-D6-J-G4-NN-L-40-L-40-B-L-30-P2-NNN-D3F	H1-MP PUMPS	H1-045PV/053PV
83029873	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-P1-D1-N-B-TB-DN-JN-N-A-10-NN-022-Z-24-NNN	H1-HP MOTORS	H1-080MB1
83029875	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-P1-D1-N-B-TB-DN-JN-N-A-10-NN-025-Z-24-NNN	H1-HP MOTORS	H1-080MB1
83029889	PUMP-VAR-DISPL CW 90PV130	90R130-K7-5-NN-80-P-4-C8-H-03-GBA-42-42-30	SERIES 90	S90-130PV
83029890	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A5-C2-N-D3-G-G2-NN-L-35-L-35-A-M-26-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83029894	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-K-T-B-B-BA-A-A-BGG-CB-A-DT-B-NNN-***	M46	M46-046PV
83029905	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E2-AA-N-B-TB-VN-AN-N-A-10-NN-018-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83029910	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-L2-BA-N-B-PB-VN-FN-N-N-NN-NN-080-N-00-NNN	H1-HP MOTORS	H1-160MB1
83029912	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-BC-80-L-4-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83029913	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A5-C1-N-D3-H-G9-NN-L-33-L-33-M-M-26-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83029915	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E1-AA-N-B-TB-VN-BN-N-A-10-NN-036-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83029921	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E2-AA-N-B-TB-VN-AN-N-N-NN-NN-018-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83029923	PUMP-VAR-DISPL 42PV041 CW	42-R-51-E-G3AN-52-P-D-B-3-H-5-A-28-28-B-1-1-NNN-NNN	SERIES 42	S42-041PV/051PV
83029924	PUMP-TANDEM, VAR DISPL MPT044D	MPT-044-D-G-R-S-A-AA-B-A-A-A-BDD-DR-A-FF-B-C-A-A-BDD-DL-A-FF-1-NNN-*	M35/44	044PT
83029925	MOTOR-VARIABLE DISPL SAE_K	K-V-45DN-E-R4F-F11-T-N-X-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83029926	PUMP-VAR DISPL MPV046C	MPV-046-C-B-A-A-S-B-B-AA-A-A-BJJ-AB-D-BB-C-NNN-***	M46	M46-046PV
83029927	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-H-S-B-B-AA-G-A-BJJ-CB-A-GG-3-NNN-***	M46	M46-046PV
83029932	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-L2-BA-N-B-PB-DN-JN-N-A-15-NN-050-N-00-NNN	H1-HP MOTORS	H1-110MB1
83029933	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-L2-BA-N-B-PB-DN-KN-N-A-15-NN-050-N-00-NNN	H1-HP MOTORS	H1-160MB1
83029935	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-CD-80-R-4-T2-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83029940	MOTOR-VAR-DISPL H1B250	H1-B-250-A-T1-DA-N-B-TA-VN-FN-N-A-20-NN-085-Z-30-NNN	H1-HP MOTORS	H1-250MB1
83029944	PUMP-VAR-DISPL CCW H1PV069	H1-P-069-L-A-A2-C2-B-D8-H-G1-NN-L-25-L-15-F-P-20-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83029949	PUMP-VAR-DISPL CW 90PV100	90R100-KA-1-NN-60-P-3-C7-F-00-GBA-38-38-24	SERIES 90	S90-100PV
83029950	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E1-AA-N-C-TA-DN-HN-N-A-10-NN-030-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83029954	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-AB-80-L-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-075PV
83029955	MOTOR-VAR-DISPL H1B160	H1-B-160-A-TA-DA-N-B-TB-VN-EN-N-N-NN-NN-AA7-Z-20-NNN	H1-HP MOTORS	H1-160MB1

83029958	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-BC-80-L-3-F1-F-03-EBC-29-29-24	SERIES 90	S90-100PV
83029971	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-3-N-0-S1-W-00-NNN-00-00-F0	SERIES 90	S90-055MF
83029989	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-1-NN-80-L-3-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83029990	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A7-C2-C-F5-K-G9-H6-L-45-L-45-N-E-28-P2-NNN-D3F	H1-HP PUMPS	H1-069PV/078PV
83030001	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A9-C2-N-D6-F-G5-H2-L-35-L-35-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83030004	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E1-AA-N-B-TB-CS-GS-S-A-10-NN-016-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83030008	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-8-N-0-S1-W-00-EAA-00-00-F3	SERIES 90	S90-100MF
83030010	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A4-C2-B-D3-H-G1-NN-L-30-L-30-M-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83030011	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A4-C2-B-D3-G-G3-H6-L-28-L-28-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83030012	PUMP-VAR-DISPL 42PV041 CW	42-R-51-E-ANNB-01-C-3-A-3-F-N-B-25-25-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83030013	PUMP-VAR-DISPL 42PV041 CW	42-R-41-C-A1NB-03-C-3-A-3-F-N-N-17-17-B-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83030023	PUMP-VAR DISPL, CW 90PV055	90-R-055-HS-1-AB-60-S-3-C6-C-03-GBA-32-32-20	SERIES 90	S90-055PV
83030047	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A5-C2-N-D6-F-F2-H3-L-30-L-30-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83030049	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A5-C2-N-D6-H-G1-NN-L-45-L-45-D-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83030058	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-BC-80-P-3-S1-D-03-GBA-38-38-20	SERIES 90	S90-075PV
83030059	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-1-BC-80-P-3-F1-F-03-GBA-38-38-20	SERIES 90	S90-130PV
83030062	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-HE-HE-N-B-TA-VN-EN-N-A-20-NN-055-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83030064	PUMP-VAR-DISPL CCW 90PV180	90L180-KP-1-BC-80-T-C-F1-H-03-FAC-42-42-24	SERIES 90	S90-180PV
83030066	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-1-NN-80-P-4-S1-C-Z1-GBA-32-32-24	SERIES 90	S90-055PV
83030068	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E2-AA-N-B-TB-CN-GN-N-A-05-NN-032-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83030085	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-1-NN-80-R-3-F1-H-00-GBA-42-42-24	SERIES 90	S90-130PV
83030087	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-1-CD-80-R-3-F1-H-00-GBA-42-42-24	SERIES 90	S90-130PV
83030091	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-1-CD-80-R-3-F1-H-00-GBA-38-38-24	SERIES 90	S90-130PV
83030092	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-NN-80-R-3-S1-F-00-GBA-38-38-24	SERIES 90	S90-100PV
83030097	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-8-N-0-S1-W-00-EBA-00-00-E4	SERIES 90	S90-055MF
83030103	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-HE-HE-N-B-TB-VS-AS-S-A-10-NN-054-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83030105	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A9-C2-N-D6-H-G1-NN-L-38-L-38-C-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83030112	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-7-N-0-F1-W-00-EBA-00-00-F3	SERIES 90	S90-100MF
83030151	PUMP-VAR-DISPL CCW 90PV100	90L100-KP-1-BB-80-P-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83030152	PUMP-VAR-DISPL CCW 90PV100	90L100-KP-1-CD-80-P-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
83030164	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A5-C3-N-D8-G-G2-H3-L-33-L-33-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83030169	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-L1-BA-N-B-PA-VS-AS-S-A-10-NN-020-N-00-NNN	H1-HP MOTORS	H1-080MB1
83030170	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-7-N-0-S1-W-00-EEA-00-00-E6	SERIES 90	S90-055MF
83030176	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A4-C2-N-D8-F-G5-H3-L-35-L-35-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83030177	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E1-AA-N-B-TA-DS-JS-S-A-10-NN-030-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83030197	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-L1-BA-N-B-PA-DS-AS-S-N-NN-NN-030-N-00-NNN	H1-HP MOTORS	H1-080MB1

83030198	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-C2-C2-C-D8-K-G9-NN-L-42-L-42-C-P-26-P2-NNN-D4F	H1-HP PUMPS	H1-069PV/078PV
83030201	PUMP-VAR DISPL, CW H1PV210	H1-P-210-R-A-A2-C3-N-D8-C-G3-NN-L-42-L-42-R-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-210PV/250PV
83030204	PUMP-VAR-DISPL CW H1PV069	H1-P-069-R-A-A2-C2-B-D8-H-G1-NN-L-15-L-25-F-P-20-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83030216	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-HE-HE-N-B-TA-VN-EN-N-A-15-NN-055-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83030217	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-NN-60-S-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-100PV
83030218	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-HE-HE-N-B-TA-VN-EN-N-A-20-NN-107-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83030219	PUMP-VAR-DISPL CCW H1PV165	H1-P-165-L-C-A4-C3-N-D3-G-G3-H3-L-25-L-40-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83030220	PUMP-VAR-DISPL CCW H1PV165	H1-P-165-L-C-A4-C3-N-D5-G-G3-H4-L-25-L-40-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83030221	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E1-AA-N-A-TA-DN-JN-N-A-10-NN-032-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83030230	MOTOR-VAR-DISPL 51MV110	51V110-R-C8-N-HS-A2-A-N-A7-NNN-041-AA-F3-03-18	SERIES 51	S51-110MV
83030239	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E1-AA-N-B-TB-VN-EN-N-A-15-NN-074-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83030240	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-T1-D1-N-B-TB-DN-EN-N-A-30-NN-091-Z-30-NNN	H1-HP MOTORS	H1-160MB1
83030241	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-E1-AA-N-B-TB-DN-KN-N-A-20-NN-062-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83030242	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-E1-AA-N-B-TB-DN-KN-N-A-20-NN-032-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83030243	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A3-C2-N-D8-J-G4-H2-L-35-L-35-B-P-24-P4-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83030244	PUMP-VAR-DISPL CCW 90PV130	90L130-DC-1-NN-80-L-4-F1-H-G1-GBA-35-35-20	SERIES 90	S90-130PV
83030249	PUMP-VAR-DISPL 42PV041 CW	42-R-51-C-G3AN-50-P-D-B-3-H-5-B-21-21-B-0-0-NNN-NNN	SERIES 42	S42-041PV/051PV
83030251	MOTOR-VARIABLE DISPL SAE_L	L-V-25CN-E-RNF-F10-S-N-N-AF-F12-NNN-NNN	LV / KV MOTORS	L/K-MV
83030261	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A5-C3-B-D6-H-G9-H3-L-35-L-35-D-L-28-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83030262	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A9-C2-N-D6-F-G5-H5-L-35-L-35-B-L-26-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83030263	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A9-C2-N-D6-F-G5-H2-L-35-L-35-B-L-26-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83030286	PUMP-VAR-DISPL CW H1PV069	H1-P-069-R-A-B7-C2-C-D3-K-G9-NN-L-45-L-45-C-M-28-P2-NNN-D5F	H1-HP PUMPS	H1-069PV/078PV
83030294	MOTOR-VAR-DISPL 51MV080	51V080-V-S1-N-HS-A2-C-H-E1-NNN-040-AA-NN-25-20	SERIES 51	S51-080MV
83030302	PUMP-VAR DISPL, CW H1PV250	H1-P-250-R-A-A5-C2-N-D6-C-G2-H3-L-38-L-38-W-L-30-PN-NNN-NNN	H1-HP PUMPS	H1-210PV/250PV
83030331	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-CD-80-T-M-C8-J-00-NNN-35-42-24	SERIES 90	S90-180PV
83030333	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-L2-BA-N-B-PB-VN-DN-N-A-20-NN-096-N-00-NNN	H1-HP MOTORS	H1-160MB1
83030334	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-L2-BA-N-B-PB-VS-DS-S-A-20-NN-096-N-00-NNN	H1-HP MOTORS	H1-160MB1
83030335	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-5-NN-80-S-3-F1-J-03-NNN-42-42-24	SERIES 90	S90-250PV
83030336	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-NN-80-S-3-F1-J-03-NNN-42-42-24	SERIES 90	S90-250PV
83030348	PUMP-VAR-DISPL CW 90PV100	90R100-HF-1-BC-80-S-4-S1-F-03-GBA-30-30-24	SERIES 90	S90-100PV
83030349	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-E2C8-02-A-N-A-3-H-N-B-25-25-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83030387	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A5-C2-N-D6-H-G9-H2-L-40-L-40-D-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83030388	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-L2-BA-N-B-PA-VS-ES-S-A-15-NN-050-N-00-NNN	H1-HP MOTORS	H1-110MB1
83030400	PUMP-VAR-DISPL CW 90PV130	90R130-CA-2-NN-80-R-3-C8-H-00-GBA-42-42-24	SERIES 90	S90-130PV
83030417	PUMP-VAR-DISPL CCW 90PV100	90L100-MA-1-NN-80-S-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83030426	PUMP-VAR-DISPL CW 90PV250	90R250-KN-5-NN-80-S-4-C8-K-05-NNN-35-35-20	SERIES 90	S90-250PV

83030427	MOTOR-VARIABLE CARTRIDGE K	K-C-38CS-E-RNF-F07-S-N-N-DF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83030428	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-C-ANNB-03-C-3-A-2-F-N-N-34-34-B-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83030435	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-2-NN-60-P-3-S1-D-05-GCA-32-32-30	SERIES 90	S90-055PV
83030436	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A7-C2-D-D6-J-G4-H2-L-35-L-35-B-L-26-P2-NNN-D3F	H1-MP PUMPS	H1-045PV/053PV
83030459	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E1-AA-N-C-TA-DN-GN-N-N-NN-NN-025-Q-00-NNN	H1-HP MOTORS	H1-060MB1
83030460	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-HE-HE-N-C-TA-DN-GN-N-N-NN-NN-025-Q-00-NNN	H1-HP MOTORS	H1-060MB1
83030465	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-BC-60-S-4-S1-C-03-GBA-32-14-24	SERIES 90	S90-055PV
83030466	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-AB-60-S-4-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83030467	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-BC-60-S-4-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83030470	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-HE-HE-N-B-TB-CN-JN-N-N-NN-NN-025-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83030472	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-8-N-0-K2-W-00-EFT-00-00-E4	SERIES 90	S90-075MF
83030474	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-NN-80-L-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-130PV
83030475	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A7-C2-C-D6-K-F1-S1-L-38-L-38-C-L-26-P2-NNN-D3F	H1-HP PUMPS	H1-069PV/078PV
83030477	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A9-C2-N-D8-F-G1-H3-L-42-L-42-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83030490	MOTOR-VAR-DISPL H1B250	H1-B-250-A-L2-BA-N-A-PA-VN-FN-N-N-NN-NN-100-N-00-NNN	H1-HP MOTORS	H1-250MB1
83030492	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-T2-DA-N-B-TA-VN-AN-N-A-10-NN-024-Z-16-NNN	H1-HP MOTORS	H1-060MB1
83030495	MOTOR-VAR-DISPL H1B160	H1-B-160-A-NB-NT-N-N-TB-CS-LS-S-A-30-NN-032-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83030499	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-B-V-C-B-AA-B-A-A-BHH-AW-U-DB-B-C-G-A-BHH-AB-U-AA-B-NNN	M46	M46-046PT
83030502	PUMP-VAR-DISPL CW 90PV075	90R075-FH-1-CD-80-L-7-S1-D-B1-GBA-42-42-24	SERIES 90	S90-075PV
83030503	PUMP-VAR-DISPL CW 90PV075	90R075-FH-1-AB-80-L-7-S1-D-B1-GBA-42-42-24	SERIES 90	S90-075PV
83030507	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-CD-80-P-3-T2-E-03-GBA-35-35-24	SERIES 90	S90-075PV
83030509	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A4-C1-N-D6-F-G5-H3-L-33-L-33-B-L-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83030513	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-NN-80-L-2-T2-E-00-GBA-29-29-24	SERIES 90	S90-100PV
83030514	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-B-Z-C-B-AA-B-B-A-A-BBB-CE-A-GG-B-D-A-A-BMM-CE-A-GG-B-NNN	M46	M46-046PT
83030515	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-B-Z-C-B-AA-B-B-A-A-BDD-CE-A-GG-B-D-A-A-BBB-CE-A-GG-B-NNN	M46	M46-046PT
83030518	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-C-E2D8-00-A-N-N-N-H-N-B-23-23-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83030519	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-C-E2D8-00-A-N-N-A-H-N-Z-23-23-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83030535	PUMP-VAR DISPL, CW 90PV100	90-R-100-HS-1-CD-60-P-3-S1-E-03-GBA-32-32-24	SERIES 90	S90-100PV
83030536	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A3-C2-N-D8-F-G1-H1-L-23-L-23-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83030566	PUMP-VAR DISPL, CW 90PV100	90-R-100-KT-1-BC-80-L-3-S1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
83030568	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-NN-80-P-3-F1-F-03-GBA-26-26-24	SERIES 90	S90-100PV
83030571	PUMP-VAR-DISPL CW 90PV042	90R042-HF-5-NN-80-S-4-C3-B-03-GBA-29-29-24	SERIES 90	S90-042PV
83030573	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A5-C2-B-F5-H-G1-H6-L-42-L-42-M-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83030585	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-5-AB-60-R-3-S1-D-03-GBA-26-26-28	SERIES 90	S90-075PV
83030590	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-HE-HE-N-B-TB-VN-AN-N-A-10-NN-040-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83030600	PUMP-VAR DISPL, CW 90PV100	90-R-100-HF-1-AB-80-R-4-S1-F-03-GBA-32-32-24	SERIES 90	S90-100PV

83030604	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E2-AA-N-B-TB-DS-JS-P-A-15-NN-040-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83030605	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E2-AA-N-B-TB-DS-JS-P-N-NN-NN-050-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83030606	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E2-AA-N-A-TA-CS-AS-P-A-05-NN-020-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83030607	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E2-AA-N-B-TB-DS-HS-P-A-10-NN-024-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83030608	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E2-AA-N-B-TB-DS-HS-P-A-10-NN-045-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83030609	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E2-AA-N-B-TB-DS-HS-P-N-NN-NN-024-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83030610	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E2-AA-N-B-TB-DS-HS-P-N-NN-NN-045-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83030614	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E2-AA-N-B-TB-VN-AN-N-A-05-NN-020-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83030615	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A5-C2-B-D3-H-G9-H3-L-28-L-28-C-M-20-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83030619	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-AB-60-S-3-C7-E-03-GBA-32-32-24	SERIES 90	S90-075PV
83030624	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-B8-C2-C-F6-H-G9-H6-L-42-L-42-C-L-26-P1-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83030634	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-E1A6-00-B-D-B-2-H-N-N-28-28-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83030651	MOTOR-VAR DISPL MMV046C	MMV-046-C-A-E-E-C-AY-NNN-***	M46	M46-046MV
83030666	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A2-C2-N-F6-H-G9-H6-L-42-L-42-D-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83030667	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A2-C2-N-D6-H-G1-H3-L-42-L-42-D-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83030675	PUMP-VAR-DISPL CW 90PV130	90R130-HF-5-DE-80-R-4-C8-H-04-GBA-35-35-24	SERIES 90	S90-130PV
83030676	PUMP-VAR-DISPL CW 90PV130	90R130-HF-5-CD-80-R-4-F1-H-04-GBA-35-35-24	SERIES 90	S90-130PV
83030702	PUMP-VAR-DISPL CW 90PV180	90R180-KA-1-NN-80-T-C-F1-H-03-FAC-35-35-24	SERIES 90	S90-180PV
83030703	MOTOR-VAR-DISPL 51MV160	51V160-R-F1-N-HZ-B1-A-N-G0-ANA-062-AA-H0-03-00	SERIES 51	S51-160MV
83030711	PUMP-VAR-DISPL CCW H1PV165	H1-P-165-L-C-A5-C3-B-D9-G-G3-H4-L-42-L-42-L-L-28-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83030712	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-C3-C3-C-D3-K-G1-NN-K-33-K-33-M-M-28-P2-NNN-D6F	H1-HP PUMPS	H1-089PV/100PV
83030743	PUMP-VAR DISPL CW H1P068R	H1-P-068-R-A-A3-C2-N-D3-H-G1-H3-L-38-L-38-F-M-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83030744	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A8-C2-C-D6-F-G1-H1-L-40-L-40-B-L-26-P1-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83030745	PUMP-VAR DISPL CW H1P068R	H1-P-068-R-A-A5-C2-N-D3-H-F1-H3-L-38-L-38-C-M-28-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83030746	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-5-CD-60-P-4-S1-D-GB-GBA-35-35-20	SERIES 90	S90-055PV
83030749	PUMP-VAR-DISPL CW 90PV100	90R100-KN-5-NN-60-S-4-C7-E-04-GBA-26-26-20-F023	SERIES 90	S90-100PV
83030755	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-P1-D1-N-C-TA-DS-KS-S-A-15-NN-029-Z-24-NNN	H1-HP MOTORS	H1-110MB1
83030768	MOTOR-VAR-DISPL H1B160	H1-B-160-A-TA-DA-N-B-TB-VN-EN-N-A-20-NN-108-Z-25-NNN	H1-HP MOTORS	H1-160MB1
83030769	MOTOR-VAR-DISPL H1B250	H1-B-250-A-TA-DA-N-B-TB-VN-FN-N-A-20-NN-108-Z-25-NNN	H1-HP MOTORS	H1-250MB1
83030772	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-M2-CA-N-A-RA-VS-DS-S-A-30-NN-043-N-00-NNN	H1-HP MOTORS	H1-160MB1
83030774	MOTOR-VAR-DISPL H1B250	H1-B-250-A-M2-CA-N-A-RA-VS-DS-S-A-30-NN-052-N-00-NNN	H1-HP MOTORS	H1-250MB1
83030789	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-AB-80-L-3-C7-E-03-GBA-32-32-28	SERIES 90	S90-075PV
83030791	MOTOR-VAR-DISPL H1MB060	H1-B-060-A-L2-BA-N-B-PB-DN-GN-N-A-05-NN-000-N-00-NNN	H1-HP MOTORS	H1-060MB1
83030792	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-EG-80-D-M-C8-L-05-FAC-35-35-24-F075	SERIES 90	S90-180PV
83030793	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-CD-80-D-M-C8-L-05-FAC-35-35-24-F075	SERIES 90	S90-180PV
83030796	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E2-AA-N-A-TA-VS-DS-S-A-15-NN-052-Z-00-NNN	H1-HP MOTORS	H1-110MB1

83030828	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-5-CD-80-L-4-F1-F-03-GBA-29-29-20	SERIES 90	S90-100PV
83030829	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-NN-80-T-M-F1-J-03-FAC-20-20-22	SERIES 90	S90-180PV
83030830	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-NN-80-T-M-F1-J-03-FAC-20-20-22	SERIES 90	S90-180PV
83030831	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A4-C1-N-D6-H-G9-H3-L-28-L-28-C-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83030834	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-2-NN-80-P-4-S1-D-04-GBA-23-23-22	SERIES 90	S90-075PV
83030845	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-CD-80-R-3-S1-E-06-GBA-35-35-24	SERIES 90	S90-075PV
83030848	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-AB-80-L-3-C8-H-04-GBA-26-26-24	SERIES 90	S90-130PV
83030860	PUMP-VAR DISPL, CW 90PV100	90-R-100-KN-1-CD-80-S-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83030864	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-CD-80-P-3-S1-E-00-GBA-35-35-24	SERIES 90	S90-075PV
83030865	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-A-S-B-B-AA-A-A-BGG-CE-A-HH-C-NNN-***	M46	M46-046PV
83030868	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A4-C1-N-D6-H-G1-H3-L-35-L-35-C-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83030869	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A4-C3-N-D6-G-G3-NN-K-38-K-38-L-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83030874	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-L2-BA-N-B-PB-VS-ES-S-N-NN-NN-060-N-00-NNN	H1-HP MOTORS	H1-160MB1
83030902	MOTOR-VAR-DISPL 51MV080	51V080-R-C7-N-HZ-B1-C-H-C2-NNN-016-AA-NN-13-00	SERIES 51	S51-080MV
83030905	PUMP-VAR DISPL CCW H1P060L	H1-P-060-L-A-A3-C2-N-D8-H-G1-H5-K-42-K-42-C-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83030906	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A3-C2-N-D8-H-G9-H3-L-45-L-45-M-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83030907	PUMP-VAR DISPL CCW H1P060L	H1-P-060-L-A-A3-C2-N-D8-H-F1-H3-K-42-K-42-C-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83030912	PUMP-VAR-DISPL CCW H1PV089	H1-P-089-L-A-A5-C2-N-D6-H-G9-NN-L-42-L-42-D-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83030920	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-C3-C2-C-D3-L-G2-H6-L-30-L-30-A-M-26-P2-NNN-D6F	H1-HP PUMPS	H1-115PV/130PV
83030921	PUMP-VAR-DISPL CCW 90PV100	90L100-MA-1-AB-80-S-3-S1-D-02-GLA-38-38-24	SERIES 90	S90-100PV
83030927	PUMP-VAR-DISPL CCW 90PV075	90L075-MA-1-AB-80-S-3-S1-D-02-GLA-38-38-24	SERIES 90	S90-075PV
83030933	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HF-1-BC-60-R-3-S1-D-03-GBA-26-26-24	SERIES 90	S90-075PV
83030934	MOTOR-VARIABLE CARTRIDGE K	K-C-45DS-E-RNF-F12-S-N-N-CF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83030939	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HS-1-NN-80-P-3-S1-D-03-GBA-26-26-24	SERIES 90	S90-055PV
83030949	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-M1-CA-N-B-RA-VS-JS-S-A-10-NN-022-N-00-NNN	H1-HP MOTORS	H1-110MB1
83030950	PUMP-VAR-DISPL CCW H1PV089	H1-P-089-L-A-A5-C2-N-D6-H-F1-NN-L-45-L-45-D-L-22-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83030953	PUMP-VAR DISPL, CW 90PV055	90-R-055-HS-1-NN-80-P-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83030954	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-L2-BA-N-B-PB-VS-ES-S-A-20-NN-100-N-00-NNN	H1-HP MOTORS	H1-160MB1
83030963	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-K2-K2-N-B-RB-DS-KS-S-B-20-NN-045-N-30-NNN	H1-HP MOTORS	H1-160MB1
83030966	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-HE-HE-N-B-TB-CN-GN-N-A-10-NN-036-Q-00-NNN	H1-HP MOTORS	H1-060MB1
83030971	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A9-C1-N-D3-G-F3-H3-K-38-K-20-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83030972	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A4-C1-N-D3-G-F3-H3-K-38-K-20-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83030973	MOTOR-VARIABLE DISPL SAE_K	K-V-38CS-E-R1F-F09-S-N-N-CF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83030979	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A4-C3-N-F6-H-F1-H6-L-38-L-38-C-L-30-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83030980	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A4-C3-N-D6-H-G1-H5-L-28-L-28-C-L-30-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83030981	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-T1-D1-N-A-TA-VN-EN-N-A-20-NN-048-Z-21-NNN	H1-HP MOTORS	H1-160MB1

83030982	PUMP-VAR-DISPL CW 90PV130	90R130-DD-5-AB-80-S-4-D8-H-G1-GBA-42-42-24	SERIES 90	S90-130PV
83030984	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A4-C2-N-E7-F-G1-H3-35-35-35-35-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83030985	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-ANNB-02-C-2-A-2-F-N-A-34-34-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83030996	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-D2-M2-N-B-PB-VS-DS-S-A-20-NN-050-N-30-NNN	H1-HP MOTORS	H1-160MB1
83030998	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-L2-BA-N-B-PB-CS-JS-S-A-10-NN-000-N-00-NNN	H1-HP MOTORS	H1-080MB1
83030999	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-L2-BA-N-B-PB-CS-JS-S-A-10-NN-000-N-00-NNN	H1-HP MOTORS	H1-110MB1
83031004	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-A-A5-C2-N-D6-H-F1-NN-L-45-L-45-D-L-22-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83031005	MOTOR-FIX DISPL 90MF130	90-M-130-NC-0-N-8-N-0-C8-W-00-EBA-00-00-F0	SERIES 90	S90-130MF
83031006	PUMP-VAR-DISPL CCW 90PV180	90L180-HF-5-BC-80-S-M-C8-J-03-NNN-32-32-24	SERIES 90	S90-180PV
83031011	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A5-C1-N-D8-F-G5-H3-L-42-L-42-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83031018	PUMP-VAR DISPL, CW 90PV075	90-R-075-LE-1-CD-80-L-3-S1-D-03-GBA-32-32-24	SERIES 90	S90-075PV
83031029	PUMP-VAR-DISPL CW 90PV180	90R180-KP-5-CD-80-T-M-C8-J-03-NNN-32-32-26	SERIES 90	S90-180PV
83031030	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-K2-K2-N-B-RB-DS-KS-S-N-NN-NN-072-N-26-NNN	H1-HP MOTORS	H1-160MB1
83031034	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-NN-80-S-3-C3-C-03-GLA-23-23-20	SERIES 90	S90-042PV
83031046	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-HE-HE-N-B-TB-CN-JN-N-A-10-NN-050-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83031047	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-HE-HE-N-B-TB-CN-GN-N-A-10-NN-040-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83031048	PUMP-VAR-DISPL CCW H1PV147	H1-P-147-L-C-A5-C1-B-D6-G-G2-H2-L-42-L-42-A-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83031049	PUMP-VAR-DISPL CCW H1PV069	H1-P-069-L-A-A5-C1-B-D6-H-F1-H2-L-35-L-35-C-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83031050	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-HE-HE-N-B-TB-VN-DN-N-A-30-NN-108-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83031058	PUMP-VAR-DISPL CCW 90PV180	90L180-MA-2-BC-80-S-C-C8-H-C5-NNN-26-26-24	SERIES 90	S90-180PV
83031064	PUMP-VAR DISPL, CCW 90PV055	90-L-055-M8-1-NN-80-S-3-C6-C-03-GBA-20-20-20	SERIES 90	S90-055PV
83031065	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-D2-M2-N-A-PB-VN-KN-N-N-NN-NN-060-N-29-NNN	H1-HP MOTORS	H1-160MB1
83031066	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E2-AA-N-B-TB-DN-KN-N-A-10-NN-025-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83031067	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E1-AA-N-B-TB-DN-KN-N-A-10-NN-025-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83031070	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E1-AA-N-B-TB-VN-AN-N-A-05-NN-028-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83031071	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E2-AA-N-B-TB-DN-KN-N-A-10-NN-050-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83031076	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-E2C8-02-B-D-B-3-H-N-B-30-30-N-A-A-NNN-NNN	SERIES 42	S42-041PV/051PV
83031077	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E2-AA-N-B-TB-VN-EN-N-A-15-NN-045-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83031078	PUMP-VAR DISPL, CW 90PV100	90-R-100-HS-5-CD-60-S-3-F1-E-03-GBA-26-26-24	SERIES 90	S90-100PV
83031082	PUMP-VAR DISPL, CW 90PV055	90-R-055-MB-1-NN-80-P-3-C6-D-00-FAD-38-38-24	SERIES 90	S90-055PV
83031084	PUMP-VAR DISPL, CCW H1PV250	H1-P-250-L-A-A5-C2-N-D8-C-G3-NN-L-42-L-42-N-E-24-PN-NNN-NNN	H1-HP PUMPS	H1-210PV/250PV
83031085	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A5-C2-B-D8-H-G1-H3-L-25-L-25-N-E-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83031086	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A5-C2-B-D8-H-G1-H3-L-35-L-35-N-E-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83031087	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A5-C2-B-D8-F-G4-H3-L-25-L-25-N-E-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83031089	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A5-C2-B-D8-H-G1-H3-L-42-L-42-N-E-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83031090	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-DE-80-S-4-F1-H-06-GBA-29-29-24	SERIES 90	S90-130PV

83031092	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E2-AA-N-B-TB-DN-JN-N-A-10-NN-060-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83031094	PUMP-VAR-DISPL CCW H1PV130	H1-P-130-L-B-C2-C2-C-D3-L-G2-H6-L-42-L-42-L-M-26-P2-NNN-D4E	H1-HP PUMPS	H1-115PV/130PV
83031095	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-K2-K2-N-B-RB-VS-DS-S-A-20-NN-032-N-28-NNN	H1-HP MOTORS	H1-160MB1
83031096	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-K2-K2-N-B-RB-VN-DN-N-A-20-NN-032-N-28-NNN	H1-HP MOTORS	H1-160MB1
83031097	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A5-C2-N-F4-H-G9-H6-L-33-L-33-M-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83031098	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E2-AA-N-B-TB-VN-AN-N-A-10-NN-030-U-00-NNN	H1-HP MOTORS	H1-060MB1
83031103	PUMP-VAR-DISPL CCW 90PV180	90L180-HF-5-DE-80-T-C-C8-J-03-NNN-35-35-24	SERIES 90	S90-180PV
83031104	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E2-AA-N-B-TB-CN-GN-N-A-05-NN-025-S-00-NNN	H1-HP MOTORS	H1-060MB1
83031105	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-1-BC-60-R-3-S1-C-02-GBA-35-35-24	SERIES 90	S90-055PV
83031106	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-BC-60-R-3-C7-D-02-GBA-35-35-24	SERIES 90	S90-075PV
83031109	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A5-C2-N-D3-G-G3-H6-K-20-K-20-A-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83031115	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-K2-K2-N-B-RB-DS-KS-S-A-20-NN-045-N-30-NNN	H1-HP MOTORS	H1-160MB1
83031118	PUMP-VAR-DISPL CCW 90PV130	90L130-HF-5-NN-80-R-3-F1-H-03-GBA-35-35-24	SERIES 90	S90-130PV
83031119	MOTOR-VARIABLE CARTRIDGE K	K-C-45DN-E-R3F-F08-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83031120	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-AB-80-P-3-S1-C-00-GBA-42-42-24	SERIES 90	S90-055PV
83031121	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-BC-80-R-3-S1-F-00-GBA-35-35-24	SERIES 90	S90-100PV
83031128	PUMP-VAR DISPL CCW H1P060L	H1-P-060-L-A-A2-C1-B-D8-H-G1-NN-L-35-L-35-F-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83031131	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-7-N-0-F1-W-00-NNN-00-00-F0	SERIES 90	S90-100MF
83031132	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-E2-AA-N-B-TB-VN-EN-N-A-20-NN-040-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83031143	PUMP-VAR-DISPL CCW H1PV165	H1-P-165-L-C-A3-C3-B-D7-G-G3-H4-K-28-K-28-N-E-30-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83031144	PUMP-VAR-DISPL CCW H1PV165	H1-P-165-L-C-A3-C3-B-D8-G-G3-H3-K-28-K-28-N-E-30-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83031145	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-L2-BA-N-C-PB-CS-KS-S-A-20-NN-080-N-00-NNN	H1-HP MOTORS	H1-160MB1
83031148	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-2-BC-60-P-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83031149	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HS-5-NN-60-P-4-S1-D-06-GBA-42-42-24	SERIES 90	S90-055PV
83031158	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HF-1-BC-80-R-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83031162	PUMP-VAR-DISPL 42PV041 CW	42-R-51-D-E2C8-02-B-D-B-3-H-N-V-25-25-N-A-A-NNN-NNN	SERIES 42	S42-041PV/051PV
83031163	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-E2C8-02-B-D-B-3-H-N-V-32-32-N-A-A-NNN-NNN	SERIES 42	S42-041PV/051PV
83031164	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-C-ANNB-03-C-2-A-2-F-N-N-30-30-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83031166	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-D-ANN3-03-C-3-A-2-F-N-N-34-34-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83031215	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-1-AB-80-S-3-T2-E-03-GBA-35-35-20	SERIES 90	S90-075PV
83031222	PUMP-VAR DISPL, CW 90PV100	90-R-100-HS-1-AB-80-P-3-F1-E-03-GBA-32-32-24	SERIES 90	S90-100PV
83031227	PUMP-VAR-DISPL CCW 90PV075	90L075-KN-5-CD-80-S-3-C7-D-03-GBA-38-38-24	SERIES 90	S90-075PV
83031246	PUMP-VAR DISPL CCW H1P053L	H1-P-053-L-A-A2-C1-N-D8-F-G4-H2-L-23-L-23-B-P-22-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83031247	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-L1-BA-N-B-PB-VS-AS-S-N-NN-NN-019-N-00-NNN	H1-HP MOTORS	H1-080MB1
83031249	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-C-E1B6-03-B-D-B-2-F-N-N-34-34-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83031262	PUMP-VAR-DISPL CCW 90PV130	90L130-CA-2-NN-80-L-4-T4-H-00-GBA-32-32-26	SERIES 90	S90-130PV

83031268	PUMP-VAR-DISPL CW 90PV130	90R130-HF-1-CD-80-R-4-F1-H-00-GBA-32-32-24	SERIES 90	S90-130PV
83031269	PUMP-VAR-DISPL CW 90PV130	90R130-HF-1-BC-80-R-4-F1-H-00-GBA-32-32-24	SERIES 90	S90-130PV
83031277	PUMP-VAR DISPL, CW 90PV055	90-R-055-HS-1-BC-60-S-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
83031282	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A4-C1-B-D6-G-G2-H2-L-42-L-42-L-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83031284	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-B8-C2-C-D6-G-G3-H3-L-40-L-40-L-L-28-P1-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83031290	PUMP-VAR-DISPL CW 90PV075	90R075-ME-5-BB-80-D-3-C7-L-C6-GBA-32-32-22	SERIES 90	S90-075PV
83031293	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A2-C1-N-D6-H-F1-H2-L-42-L-42-C-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83031294	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-T1-D1-N-A-TA-DS-KS-S-A-15-NN-050-Z-24-NNN	H1-HP MOTORS	H1-110MB1
83031295	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-P2-D2-N-B-TA-DN-KN-N-A-20-NN-063-Z-24-NNN	H1-HP MOTORS	H1-160MB1
83031296	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-B8-C2-C-D8-G-G3-H3-L-40-L-40-L-P-28-P1-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83031297	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-T1-D1-N-C-TA-DN-JN-N-A-15-NN-054-Z-30-NNN	H1-HP MOTORS	H1-110MB1
83031310	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-1-NN-80-S-3-S1-C-03-GBA-32-32-20	SERIES 90	S90-055PV
83031314	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-BC-80-L-4-C8-H-03-GBA-35-35-24	SERIES 90	S90-130PV
83031315	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-C3-C2-D-D6-J-G1-H2-L-30-L-30-B-L-20-P2-NNN-D6F	H1-MP PUMPS	H1-045PV/053PV
83031324	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-C2-C2-C-D6-J-G1-H3-L-40-L-40-B-L-26-P2-NNN-D4F	H1-MP PUMPS	H1-045PV/053PV
83031330	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A5-C2-N-F6-H-G9-H6-L-42-L-42-C-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83031337	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A2-C2-N-F6-H-G3-H6-L-42-L-42-D-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83031343	PUMP-TANDEM, VAR DISPL CCW H1T045L	H1-T-045-L-A-N-A4-C1-N-D1-F-G5-H3-25-25-25-25-N-P-32-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83031344	PUMP-TANDEM, VAR DISPL CCW H1T053L	H1-T-053-L-A-N-A2-C1-N-E7-F-G5-TN-23-23-23-23-M-P-22-PN-NNN-S01	H1-MP PUMPS	H1-045PT/053PT
83031347	PUMP-TANDEM, VAR DISPL CCW H1T045L	H1-T-045-L-A-N-A4-C1-N-D1-F-G5-H3-25-25-25-25-N-P-28-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83031348	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-5-NN-80-S-4-F1-J-03-NNN-38-38-24	SERIES 90	S90-250PV
83031349	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-CD-80-S-4-F1-J-03-NNN-38-38-24	SERIES 90	S90-250PV
83031350	PUMP-VAR-DISPL CW 90PV250	90R250-HF-5-NN-80-S-4-F1-J-03-NNN-38-38-24	SERIES 90	S90-250PV
83031380	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KN-1-CD-60-S-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83031382	PUMP-VAR-DISPL CCW H1PV165	H1-P-165-L-C-A2-C2-N-D8-G-G3-H3-L-33-L-33-A-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83031385	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-NN-80-S-3-C7-F-03-GBA-35-35-22	SERIES 90	S90-100PV
83031395	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A5-C2-N-D3-G-G2-H2-L-45-L-45-L-M-26-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83031402	MOTOR-FIX DISPL MMF044D	MMF-044-D-A-N-K-C-D-NCG-***	M35/44	044MF
83031410	PUMP-VAR-DISPL CW DDC20	DDC-20-A-R-RB-LSA-NN-A-N-3-AB-ACA0-D-07-14A-14N-NNN-NNN	DDC20/LDU20	OSK-020PV - DO NOT USE
83031413	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E2-AA-N-B-TB-CS-GS-P-A-05-NN-036-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83031432	PUMP-VAR-DISPL CW 90PV130	90R130-HF-2-DE-80-R-3-C8-H-03-GBA-42-42-24	SERIES 90	S90-130PV
83031467	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-NN-80-R-3-C6-C-03-GBA-42-42-24	SERIES 90	S90-055PV
83031468	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-CD-60-P-4-C7-D-04-GBA-32-32-24	SERIES 90	S90-075PV
83031469	PUMP-VAR DISPL, CW 90PV075	90-R-075-HF-1-BC-60-P-4-S1-D-04-GBA-32-32-24	SERIES 90	S90-075PV
83031482	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A5-C3-B-D9-G-G3-H4-L-42-L-42-L-L-28-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83031490	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-C6-C2-B-D3-G-G3-H6-L-42-L-42-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV

83031492	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-8-N-0-S1-W-00-NNN-00-00-A3	SERIES 90	S90-100MF
83031493	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A3-C2-N-D8-F-G5-NN-L-35-L-35-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83031500	PUMP-VAR-DISPL CW 90PV130	90R130-CB-2-DE-80-R-3-C8-H-00-GBA-42-42-24	SERIES 90	S90-130PV
83031504	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-B-Z-C-B-AA-B-A-A-A-BHH-AB-U-EF-B-C-A-A-BHH-AB-U-EF-C-NNN-*	M46	M46-046PT
83031508	MOTOR-VARIABLE DISPL SAE_K	K-V-38CS-E-R4F-F12-T-N-X-CF-F17-NNN-NNN	LV / KV MOTORS	L/K-MV
83031525	PUMP-VAR DISPL, CW H1PV210	H1-P-210-R-A-A5-C2-N-D8-C-F8-E1-L-38-L-38-R-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-210PV/250PV
83031526	PUMP-VAR DISPL, CW H1PV210	H1-P-210-R-A-A5-C2-N-D8-C-G3-H6-L-38-L-38-R-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-210PV/250PV
83031527	MOTOR-VAR-DISPL H1B160	H1-B-160-A-TA-DA-N-A-TB-CN-KN-N-A-20-NN-080-Z-22-NNN	H1-HP MOTORS	H1-160MB1
83031529	PUMP-VAR-DISPL CW 90PV075	90R075-HF-5-NN-80-P-4-C7-D-03-GBA-42-42-32	SERIES 90	S90-075PV
83031530	PUMP-VAR-DISPL CCW H1PV130	H1-P-130-L-B-A5-C2-B-D6-G-G2-H6-L-35-L-35-L-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83031531	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A5-C2-B-D6-H-G1-H2-L-40-L-40-D-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83031537	MOTOR-VARIABLE DISPL SAE_K	K-V-45DS-A-RNF-F01-T-N-X-CF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83031544	PUMP-VAR-DISPL CCW 90PV075	90L075-MA-1-NN-60-S-3-S1-D-05-GBA-42-42-24	SERIES 90	S90-075PV
83031565	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-A-C2-C2-C-F6-K-G9-H6-L-42-L-42-D-L-28-P2-NNN-D4E	H1-HP PUMPS	H1-089PV/100PV
83031567	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-2-CD-80-P-3-S1-E-03-GBA-37-37-20-N270	SERIES 90	S90-075PV
83031572	PUMP-VAR-DISPL CW H1PV069	H1-P-069-R-A-A7-C3-C-D8-K-F1-H5-L-42-L-42-F-P-26-P2-NNN-D3F	H1-HP PUMPS	H1-069PV/078PV
83031576	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A4-C2-N-D6-G-G2-H3-L-30-L-30-L-L-28-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83031585	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-1-CD-60-S-3-T1-D-05-GBA-42-42-24	SERIES 90	S90-075PV
83031606	PUMP-VAR DISPL MPV046C	MPV-046-C-B-A-K-S-B-B-AA-A-A-BCC-AB-U-EB-B-NNN-***	M46	M46-046PV
83031617	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-C3-C1-D-D8-J-G1-H3-L-40-L-40-B-P-26-P2-NNN-D6F	H1-MP PUMPS	H1-045PV/053PV
83031621	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-1-N-0-S1-W-00-NNN-00-00-A0	SERIES 90	S90-055MF
83031628	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-T2-DA-N-B-TB-VS-DS-P-A-15-NN-055-Z-28-NNN	H1-HP MOTORS	H1-110MB1
83031629	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-C2-C2-C-D8-J-G1-H3-L-40-L-40-B-P-26-P2-NNN-D4F	H1-MP PUMPS	H1-045PV/053PV
83031632	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E1-AA-N-B-TA-VN-BN-N-A-05-NN-054-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83031645	PUMP-VAR-DISPL CW 90PV180	90R180-KA-1-CD-80-T-M-F1-J-03-FAC-35-35-24	SERIES 90	S90-180PV
83031646	MOTOR-VARIABLE CARTRIDGE L	L-C-30DN-A-YNF-F01-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83031648	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-AB-60-L-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
83031649	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-NN-80-R-4-S1-C-03-EBC-35-35-24	SERIES 90	S90-055PV
83031653	PUMP-VAR-DISPL CCW DDC20	DDC-20-A-L-LB-LSA-NN-A-N-3-AB-ACA0-D-07-21N-21N-NNN-NAN	DDC20/LDU20	OSK-020PV - DO NOT USE
83031654	PUMP-VAR-DISPL CCW DDC20	DDC-20-A-L-LB-RSA-NN-A-N-3-AB-ACA0-D-07-21N-21N-NNN-NAN	DDC20/LDU20	OSK-020PV - DO NOT USE
83031656	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A5-C2-B-D6-G-G2-H6-L-35-L-35-L-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83031673	PUMP-VAR-DISPL CW 90PV100	90R100-DD-5-NN-80-L-3-S1-F-G1-FAC-35-35-30	SERIES 90	S90-100PV
83031674	PUMP-VAR-DISPL CW 90PV100	90R100-DD-5-CD-80-L-3-C7-F-G1-FAC-35-35-30	SERIES 90	S90-100PV
83031679	PUMP-VAR-DISPL CW DDC20	DDC-20-A-R-RB-LSA-NN-A-N-5-AA-ACA0-D-07-30N-30N-NNN-NNN	DDC20/LDU20	OSK-020PV - DO NOT USE
83031680	PUMP-VAR-DISPL CW DDC20	DDC-20-A-R-RB-RSA-NN-A-N-5-AA-ACA0-D-07-30N-30N-NNN-NNN	DDC20/LDU20	OSK-020PV - DO NOT USE
83031681	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A2-C3-B-D8-H-G1-H3-L-35-L-35-F-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV

83031687	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-2-AB-80-S-4-S1-C-00-GBA-21-21-24	SERIES 90	S90-055PV
83031688	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-5-BC-80-L-3-S1-E-03-GBA-38-38-24	SERIES 90	S90-100PV
83031689	MOTOR-VAR-DISPL H1B160	H1-B-160-A-TA-DA-N-B-TB-VS-DS-S-A-20-NN-100-Z-30-NNN	H1-HP MOTORS	H1-160MB1
83031690	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-DE-80-R-4-C8-H-03-EBA-42-42-30	SERIES 90	S90-130PV
83031692	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A2-C3-B-D8-H-G1-NN-L-35-L-35-F-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83031694	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A2-C3-B-F5-H-G1-H6-L-35-L-35-F-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83031702	PUMP-VAR-DISPL CW 90PV130	90R130-KN-1-NN-80-S-4-F1-F-03-GBA-35-35-24	SERIES 90	S90-130PV
83031703	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A8-C3-D-D8-J-G5-H3-L-35-L-35-B-P-30-P2-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83031704	PUMP-VAR DISPL, CW H1PV250	H1-P-250-R-A-A5-C3-N-D8-C-G2-NN-L-33-L-33-W-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-210PV/250PV
83031705	PUMP-VAR DISPL, CW H1PV250	H1-P-250-R-A-A5-C3-N-D8-C-G2-E2-L-33-L-33-W-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-210PV/250PV
83031715	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A5-C1-B-D6-H-G1-NN-L-35-L-35-C-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83031716	PUMP-VAR-DISPL CCW H1PV130	H1-P-130-L-B-A5-C1-B-D6-G-G2-H2-L-42-L-42-L-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83031717	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A4-C1-N-D6-F-G1-H5-L-35-L-35-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83031718	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A4-C1-N-D6-F-G5-H3-L-35-L-35-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83031726	PUMP-VAR-DISPL CW 90PV180	90R180-DD-5-NN-80-T-C-C8-J-GB-NNN-42-42-22	SERIES 90	S90-180PV
83031740	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-BC-80-S-3-S1-E-03-GBA-32-32-24	SERIES 90	S90-100PV
83031741	MOTOR-VARIABLE CARTRIDGE L	L-C-30DN-A-YNF-F11-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83031749	PUMP-VAR-DISPL CW 90PV130	90R130-MS-5-CD-80-L-3-C8-F-C5-GBA-42-42-24	SERIES 90	S90-130PV
83031762	PUMP-VAR-DISPL CCW 90PV075	90L075-KN-1-CD-80-R-3-S1-E-03-GBA-29-29-24	SERIES 90	S90-075PV
83031763	PUMP-VAR-DISPL CCW 90PV075	90L075-KN-1-NN-80-R-3-S1-D-03-GBA-29-29-24	SERIES 90	S90-075PV
83031775	PUMP-VAR DISPL, CW 90PV100	90-R-100-KT-5-CD-80-S-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83031776	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-5-BC-80-S-4-S1-D-C3-GBA-35-35-24	SERIES 90	S90-075PV
83031777	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-8-N-0-S1-W-00-EAA-00-00-E4	SERIES 90	S90-100MF
83031784	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A4-C3-B-E6-J-G5-H3-L-23-L-23-B-L-20-P4-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83031789	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A5-C3-N-D6-G-G3-H4-L-45-L-45-A-L-30-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83031790	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A5-C3-N-D6-G-G3-NN-L-45-L-45-A-L-30-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83031791	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A5-C1-N-D6-F-G5-H3-L-35-L-35-B-L-32-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83031792	PUMP-VAR-DISPL CW 90PV100	90R100-MA-2-BC-60-S-4-C7-F-03-FAD-45-45-28	SERIES 90	S90-100PV
83031794	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A5-C2-N-F4-H-G9-H6-L-33-L-33-M-M-26-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83031798	MOTOR-VAR-DISPL H1MB060	H1-B-060-A-M2-CA-N-B-RA-VS-AS-S-A-05-NN-000-N-00-NNN	H1-HP MOTORS	H1-060MB1
83031803	MOTOR-VAR DISPL MMV046C	MMV-046-C-A-E-F-A-A5-VNB-***	M46	M46-046MV
83031804	MOTOR-VAR DISPL MMV046C	MMV-046-C-A-E-F-A-A4-VNB-***	M46	M46-046MV
83031805	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-T2-DA-N-B-TB-VS-DS-P-A-15-NN-048-Z-30-NNN	H1-HP MOTORS	H1-110MB1
83031809	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-2-AB-80-S-4-F1-E-00-GBA-35-35-24	SERIES 90	S90-100PV
83031810	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-2-CD-80-S-4-F1-E-00-GBA-35-35-24	SERIES 90	S90-100PV
83031813	MOTOR-VAR-DISPL H1B250	H1-B-250-A-L1-BA-N-B-PA-VS-DS-S-B-40-NN-000-C-00-NNN	H1-HP MOTORS	H1-250MB1

83031822	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-1-NN-80-R-4-T4-F-03-EEB-32-32-24	SERIES 90	S90-130PV
83031831	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-P1-D1-N-B-TA-DS-JS-S-A-15-NN-034-Z-24-NNN	H1-HP MOTORS	H1-110MB1
83031842	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-P1-D1-N-B-TA-DS-JS-S-A-15-NN-033-Z-24-NNN	H1-HP MOTORS	H1-110MB1
83031843	PUMP-TANDEM, VAR DISPL CCW H1T053L	H1-T-053-L-A-N-A5-C2-N-E7-F-G5-TN-35-35-35-35-M-P-24-PN-NNN-S01	H1-MP PUMPS	H1-045PT/053PT
83031844	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A2-C3-B-E7-F-G1-H1-20-20-20-20-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83031845	MOTOR-VARIABLE CARTRIDGE K	K-C-45DS-E-RNF-F07-S-N-N-CF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83031846	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KN-1-BC-80-R-4-F1-E-03-GBA-20-20-24	SERIES 90	S90-100PV
83031847	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-N-A2-C2-N-E7-F-G6-H3-28-28-35-25-N-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83031848	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KN-1-CD-80-R-3-S1-D-03-GBA-29-29-24	SERIES 90	S90-075PV
83031849	PUMP-VAR DISPL MPV046C	MPV-046-C-B-A-N-S-B-J-AA-A-A-BGG-AW-U-FF-C-NNN-***	M46	M46-046PV
83031850	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A4-C3-N-D8-F-G5-H1-L-20-L-20-B-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83031861	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-DE-80-R-4-C8-H-03-EBA-42-42-30-F055	SERIES 90	S90-130PV
83031864	PUMP-VAR-DISPL CCW 90PV180	90L180-DC-5-BC-80-T-M-F1-J-GB-FAC-14-32-24	SERIES 90	S90-180PV
83031875	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A4-C3-N-D8-F-G5-H1-L-20-L-25-B-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83031877	PUMP-VAR DISPL, CCW H1PV210	H1-P-210-L-A-A5-C1-B-D8-C-G3-NN-L-35-L-35-R-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-210PV/250PV
83031878	PUMP-VAR DISPL, CCW H1PV250	H1-P-250-L-A-A5-C1-B-D8-C-G3-NN-L-35-L-35-R-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-210PV/250PV
83031887	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A5-C2-N-D6-G-G3-NN-L-45-L-45-A-L-30-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83031899	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-J-S-B-B-AA-A-A-BFD-CB-A-JJ-3-NNN-***	M46	M46-046PV
83031930	PUMP-VAR-DISPL CCW H1PV165	H1-P-165-L-C-A5-C1-N-D3-G-G2-NN-L-38-L-38-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83031934	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-L2-BA-N-B-PA-VN-DN-N-N-NN-NN-070-N-00-NNN	H1-HP MOTORS	H1-160MB1
83031938	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-1-NN-80-S-4-S1-C-00-GBA-42-42-24	SERIES 90	S90-055PV
83031939	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-ANNB-02-B-3-C-2-F-N-A-17-17-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83031940	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-CD-80-P-3-S1-F-00-GBA-35-35-24	SERIES 90	S90-100PV
83031941	PUMP- VARIABLE, DIRECT DISPLACMENT	LPV-A-A-B-C-A-E-AA-D-A-BFF-DR-A-FF-A-NNN-***	LPV	LPV
83031962	PUMP- VARIABLE, DIRECT DISPLACMENT	LPV-A-A-B-C-A-E-AA-C-A-BFF-DR-A-FF-A-NNN-***	LPV	LPV
83031963	PUMP-VAR DISPL, CW 90PV055	90-R-055-HS-1-BC-80-S-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83031967	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-ANNB-02-B-3-C-2-F-N-B-17-17-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83031971	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A5-C1-B-F5-H-G9-H6-L-30-L-30-M-P-22-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83031977	MOTOR-VAR-DISPL H1MB060	H1-B-060-A-L2-BA-N-B-PB-CN-GN-N-A-05-NN-000-N-00-NNN	H1-HP MOTORS	H1-060MB1
83031978	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-HE-HE-N-B-TA-CN-JN-N-A-10-NN-021-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83031979	PUMP-VAR-DISPL CCW 90PV180	90L180-KN-1-CD-80-T-C-F1-J-03-FAC-32-32-26	SERIES 90	S90-180PV
83031982	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A5-C1-B-D8-H-G1-NN-L-30-L-30-M-P-22-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83031991	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A5-C2-B-D3-H-G1-H3-L-30-L-30-C-M-22-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83031992	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A5-C2-B-F4-H-G9-H6-L-30-L-30-C-M-22-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83031999	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A4-C1-N-D6-H-G9-H3-L-38-L-38-C-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83032004	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-E2-AA-N-B-TB-VS-ES-P-A-30-NN-105-Z-00-NNN	H1-HP MOTORS	H1-160MB1

83032005	PUMP-VAR-DISPL CCW 90PV250	90L250-KT-5-BC-80-T-4-F1-J-03-NNN-32-32-24	SERIES 90	S90-250PV
83032009	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-BC-80-P-3-S1-D-00-GBA-32-32-24	SERIES 90	S90-075PV
83032010	PUMP-VAR DISPL, CW 90PV055	90-R-055-HS-1-BC-80-S-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83032011	PUMP-VAR-DISPL CCW H1PV115	H1-P-115-L-B-A3-C3-N-D3-G-G2-NN-L-35-L-20-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83032015	MOTOR-VAR-DISPL H1MB060	H1-B-060-A-D1-M1-N-A-PA-VS-AS-S-A-05-NN-015-N-30-NNN	H1-HP MOTORS	H1-060MB1
83032019	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A5-C2-N-D3-L-G2-NN-L-38-L-38-L-M-32-P4-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83032020	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A5-C2-N-D3-G-F3-H6-L-30-L-30-A-N-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83032027	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-G-S-A-J-BC-V-A-BJJ-DA-A-HH-C-NNN-***	M46	M46-046PV
83032028	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A4-C1-N-D3-G-G3-NN-L-38-L-38-A-M-30-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83032029	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A4-C1-N-D3-G-G3-H4-L-38-L-38-A-M-30-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83032030	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-BB-80-R-3-C3-C-03-GBA-35-35-24	SERIES 90	S90-042PV
83032031	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A5-C1-N-D3-G-G2-NN-L-38-L-38-L-M-34-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83032033	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A5-C2-B-D3-G-G2-H6-L-45-L-45-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83032035	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A5-C2-B-D3-G-G2-H6-L-42-L-42-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83032038	PUMP-VAR DISPL CCW H1P068L	H1-P-068-L-A-A5-C1-N-D8-H-G1-H5-L-25-L-25-C-P-28-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83032039	PUMP-VAR DISPL CCW H1P068L	H1-P-068-L-A-A5-C1-N-F5-H-G1-H6-L-25-L-25-C-P-28-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83032054	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A4-C1-N-D6-H-G9-H3-L-40-L-40-C-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83032055	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-A-A4-C2-N-D3-H-G9-H3-L-42-L-42-D-M-20-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83032058	PUMP-VAR-DISPL CCW 90PV075	90L075-HF-5-BC-80-R-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83032059	PUMP-VAR DISPL, CW H1PV210	H1-P-210-R-A-A5-C2-N-D8-C-F8-H4-L-35-L-35-W-P-26-PN-NNN-NNN	H1-HP PUMPS	H1-210PV/250PV
83032060	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A5-C2-N-D8-G-G3-NN-L-33-L-33-L-P-26-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83032062	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-W-S-B-B-BA-A-A-BRR-BA-A-HH-A-NNN-***	M46	M46-046PV
83032065	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A5-C2-N-D8-H-G1-NN-L-35-L-35-C-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83032068	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A5-C2-N-F5-H-G1-H6-L-35-L-35-C-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83032073	MOTOR-VAR-DISPL H1B080	H1-B-080-A-TA-DA-N-B-TB-VS-AS-S-N-NN-NN-034-Z-17-NNN	H1-HP MOTORS	H1-080MB1
83032074	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-M1-CA-N-A-RB-VS-AS-S-A-05-NN-000-N-00-NNN	H1-HP MOTORS	H1-080MB1
83032104	PUMP-TANDEM, VAR DISPL CCW H1T053L	H1-T-053-L-A-N-B1-C2-B-E7-F-G1-T2-23-23-23-23-M-P-24-PN-NNN-S02	H1-MP PUMPS	H1-045PT/053PT
83032105	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-G-S-A-J-BC-V-A-BRR-DA-A-HH-C-NNN-***	M46	M46-046PV
83032106	MOTOR-VAR-DISPL H1B110	H1-B-110-A-TA-DA-N-B-TA-VN-EN-N-A-10-NN-062-Z-22-NNN	H1-HP MOTORS	H1-110MB1
83032110	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-HE-HE-N-A-TB-VS-FS-P-A-20-NN-107-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83032113	PUMP-VAR-DISPL CCW 90PV075	90L075-MA-5-NN-60-S-3-D9-D-C5-GBA-35-35-24	SERIES 90	S90-075PV
83032134	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-BC-80-R-4-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83032135	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-1-CD-60-L-3-S1-D-03-GBA-35-35-20	SERIES 90	S90-055PV
83032136	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-1-NN-60-L-3-S1-D-03-GBA-35-35-20	SERIES 90	S90-055PV
83032137	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-1-CD-80-L-3-C8-H-03-GBA-35-35-20	SERIES 90	S90-130PV
83032138	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-1-EG-80-T-3-C8-K-03-NNN-35-35-20	SERIES 90	S90-250PV

83032139	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-1-NN-80-T-3-C8-K-03-NNN-35-35-20	SERIES 90	S90-250PV
83032142	MOTOR-VAR-DISPL H1B110	H1-B-110-A-TA-DA-N-C-TB-VN-DN-N-N-NN-NN-060-Z-19-NNN	H1-HP MOTORS	H1-110MB1
83032143	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E2-AA-N-B-TB-CN-GN-N-A-05-NN-036-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83032157	MOTOR-VAR-DISPL 51MC080-1	51C080-1--R-D2-N-E1-B1-N-N-U1-ACG-032-AA-E6-00-00	SERIES 51	S51-080MV-1
83032169	PUMP-VAR DISPL, CCW 90PV055	90-L-055-MB-1-NN-80-P-3-C6-C-03-FAD-35-35-24	SERIES 90	S90-055PV
83032171	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A4-C1-N-D6-F-G1-H5-L-40-L-40-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83032172	PUMP-VAR-DISPL CW 90PV075	90R075-HS-1-AB-60-P-3-S1-D-03-GBA-32-14-30	SERIES 90	S90-075PV
83032186	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-ANN3-03-C-3-A-2-F-N-A-38-38-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83032190	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-B7-C2-C-D3-K-G9-H3-L-42-L-42-C-M-30-P2-NNN-D5F	H1-HP PUMPS	H1-069PV/078PV
83032191	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-B7-C2-C-D3-L-G2-H6-L-42-L-42-L-M-30-P2-NNN-D5F	H1-HP PUMPS	H1-115PV/130PV
83032195	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-ANN3-02-B-3-G-2-C-N-B-21-21-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83032199	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A5-C2-N-D6-H-G9-H2-L-42-L-42-C-L-30-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83032200	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A5-C2-N-D6-H-G9-H3-L-42-L-42-C-L-30-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83032202	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A4-C1-N-D6-F-G5-H3-L-40-L-40-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83032203	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A4-C2-N-F3-F-G5-NN-J-40-J-40-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83032213	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A3-C1-N-D8-G-G3-H6-K-35-K-20-A-P-26-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83032214	PUMP-VAR-DISPL CCW H1PV115	H1-P-115-L-B-A3-C1-N-D8-G-G3-H6-K-35-K-20-A-P-26-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83032229	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-HE-HE-N-B-TB-CS-GS-S-A-10-NN-030-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83032230	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-NN-60-S-3-S1-D-03-GBA-32-32-24	SERIES 90	S90-075PV
83032231	MOTOR-VAR-DISPL H1B250	H1-B-250-A-TA-DA-N-B-TB-VN-FN-N-A-20-NN-168-Z-17-NNN	H1-HP MOTORS	H1-250MB1
83032233	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KN-5-BC-80-R-4-S1-D-03-GBA-20-20-24	SERIES 90	S90-075PV
83032234	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KN-5-NN-80-R-4-S1-D-03-GBA-20-20-24	SERIES 90	S90-075PV
83032242	PUMP-VAR-DISPL CW 90PV180	90R180-KN-5-AB-80-S-M-F1-J-03-NNN-26-26-24	SERIES 90	S90-180PV
83032246	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-L2-BA-N-A-PB-DS-JS-P-N-NN-NN-050-N-00-NNN	H1-HP MOTORS	H1-110MB1
83032266	PUMP-VAR-DISPL CCW H1PV115	H1-P-115-L-B-C6-C2-B-D3-G-G3-H6-L-42-L-42-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83032269	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-C6-C2-B-D3-G-G3-H6-L-42-L-42-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83032271	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-L2-BA-N-B-PA-VN-EN-N-N-NN-NN-022-N-00-NNN	H1-HP MOTORS	H1-110MB1
83032272	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A5-C1-B-D8-H-G1-H3-L-30-L-30-M-P-22-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83032276	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A5-C2-B-D3-H-G1-NN-L-35-L-15-M-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83032277	MOTOR-FIX DISPL MMF044D	MMF-044-D-A-S-U-C-D-NNN-***	M35/44	044MF
83032278	MOTOR-FIXED DISPL MMF025C	MMF-025-C-A-5-B-E-D-NNN-***	LIGHT DUTY	025MF
83032279	PUMP-VAR-DISPL CW 90PV130	90R130-MA-1-BB-80-S-4-F1-F-03-GBA-42-42-24	SERIES 90	S90-130PV
83032297	MOTOR-VARIABLE DISPL SAE_L	L-V-30DN-A-YNF-F07-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83032299	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A5-C3-N-D6-G-G3-H3-L-35-L-35-L-L-28-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83032301	MOTOR-VARIABLE DISPL SAE_L	L-V-30DN-A-HNF-F07-S-N-N-AF-F18-NHC-NNN	LV / KV MOTORS	L/K-MV
83032304	PUMP-VAR-DISPL CW 90PV075	90R075-KT-1-CD-80-S-3-C6-D-03-GBA-42-42-24	SERIES 90	S90-075PV

83032309	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-BC-80-L-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83032310	PUMP-VAR-DISPL CCW 90PV180	90L180-KN-1-NN-80-T-C-F1-H-03-NNN-35-35-24	SERIES 90	S90-180PV
83032324	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-1-NN-60-P-3-S1-D-03-GBA-35-35-20	SERIES 90	S90-075PV
83032336	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-P2-D2-N-A-TA-DS-JS-S-A-10-NN-029-Z-24-NNN	H1-HP MOTORS	H1-110MB1
83032359	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-AB-80-S-4-F1-H-06-GBA-29-29-24	SERIES 90	S90-130PV
83032360	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-BC-80-S-4-F1-H-06-GBA-29-29-24	SERIES 90	S90-130PV
83032362	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-L2-BA-N-B-PB-VS-ES-S-N-NN-NN-022-N-00-NNN	H1-HP MOTORS	H1-110MB1
83032363	MOTOR-VAR-DISPL H1MB060	H1-B-060-A-M2-CA-N-B-RB-CN-GN-N-N-NN-NN-025-N-00-NNN	H1-HP MOTORS	H1-060MB1
83032364	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A5-C2-N-D7-G-G3-H4-L-45-L-45-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83032365	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A5-C2-N-D7-G-G3-H4-L-45-L-45-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83032367	PUMP-VAR DISPL CCW H1P068L	H1-P-068-L-A-A5-C2-N-F5-H-F1-H6-L-25-L-25-F-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83032368	PUMP-VAR DISPL CCW H1P068L	H1-P-068-L-A-A5-C2-N-D8-H-F1-H3-L-25-L-25-F-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83032369	PUMP-VAR DISPL CCW H1P068L	H1-P-068-L-A-A5-C3-N-D8-H-G1-NN-L-25-L-25-F-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83032375	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-D1-M1-N-B-PA-DS-KS-S-A-15-NN-022-N-30-NNN	H1-HP MOTORS	H1-110MB1
83032397	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-5-BB-80-S-4-C7-F-03-GBA-26-26-20	SERIES 90	S90-100PV
83032401	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A5-C2-B-D8-H-F1-H3-L-35-L-35-F-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83032402	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A5-C2-B-D8-H-F1-H3-L-35-L-35-D-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83032403	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A5-C2-B-D8-H-G1-H3-L-35-L-35-D-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83032404	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A5-C2-N-D8-H-G9-H3-L-35-L-35-C-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83032405	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A5-C2-B-D8-F-G4-NN-L-25-L-25-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83032406	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-T2-DA-N-A-TB-DS-KS-S-A-20-NN-070-Z-27-NNN	H1-HP MOTORS	H1-160MB1
83032408	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A5-C2-N-D8-H-G9-H2-L-38-L-38-M-P-26-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83032409	PUMP-VAR DISPL, CCW H1PV210	H1-P-210-L-A-A5-C2-B-D8-C-G2-NN-L-35-L-35-R-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-210PV/250PV
83032416	PUMP-VAR DISPL, CW 90PV055	90-R-055-HS-1-BC-80-S-3-S1-C-02-GBA-42-42-24	SERIES 90	S90-055PV
83032428	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-ANNB-02-C-2-A-2-F-N-T-34-34-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83032430	PUMP-VAR-DISPL CCW 90PV130	90L130-KN-5-AB-80-S-3-C8-H-03-GBA-35-35-26	SERIES 90	S90-130PV
83032435	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-C-ANJ5-03-A-N-A-3-H-N-N-34-34-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83032436	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-D-A7J5-03-A-N-A-3-H-N-B-34-34-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83032437	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-HE-HE-N-B-TB-CN-JN-N-A-10-NN-017-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83032438	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-E1-AA-N-B-TA-VS-ES-S-A-20-NN-058-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83032442	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-BC-80-R-3-C7-D-03-GBA-32-32-20	SERIES 90	S90-075PV
83032450	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-AB-80-R-7-C7-E-09-GCA-35-35-30	SERIES 90	S90-100PV
83032484	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-8-N-0-K3-W-00-EAA-00-00-E4	SERIES 90	S90-100MF
83032491	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-P1-D1-N-A-TA-DS-JS-S-A-05-NN-018-Z-24-NNN	H1-HP MOTORS	H1-080MB1
83032507	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A5-C1-N-D8-L-G2-H4-L-42-L-42-L-P-24-P4-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83032508	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A5-C1-N-D8-G-G3-H3-L-42-L-42-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV

83032509	MOTOR-VAR-DISPL H1B250	H1-B-250-A-D2-MA-N-C-PB-VS-DS-S-A-20-NN-080-N-30-NNN	H1-HP MOTORS	H1-250MB1
83032517	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-W-S-B-B-BA-A-A-BRR-CD-A-HH-3-NNN-***	M46	M46-046PV
83032526	MOTOR-VAR-DISPL H1B110	H1-B-110-A-TA-DA-N-B-TB-DN-KN-N-A-10-NN-060-Z-22-NNN	H1-HP MOTORS	H1-110MB1
83032527	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-CD-80-P-4-C8-H-03-GBA-42-42-24	SERIES 90	S90-130PV
83032528	PUMP-VAR-DISPL CCW H1PV115	H1-P-115-L-B-A5-C2-N-D3-G-G2-H5-L-45-L-45-A-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83032529	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A5-C2-N-E5-F-G5-H5-L-42-L-42-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83032533	PUMP-VAR-DISPL CCW 90PV180	90L180-HF-5-NN-80-T-C-F1-J-03-NNN-42-42-24	SERIES 90	S90-180PV
83032534	PUMP-VAR-DISPL CCW 90PV130	90L130-HF-5-BC-80-R-3-F1-H-03-GBA-42-42-24	SERIES 90	S90-130PV
83032535	PUMP-VAR-DISPL CCW 90PV100	90L100-HF-5-CD-80-R-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83032536	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A5-C1-B-D6-H-G9-H2-L-42-L-42-D-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83032537	PUMP-VAR-DISPL CCW H1PV147	H1-P-147-L-C-A5-C2-N-D6-G-G2-H6-L-40-L-40-L-L-20-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83032538	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HF-5-NN-80-R-4-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83032549	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-5-AB-60-P-4-C6-D-C5-GBA-42-42-24	SERIES 90	S90-055PV
83032551	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-L2-BA-N-A-PB-DS-JS-P-N-NN-NN-040-N-00-NNN	H1-HP MOTORS	H1-110MB1
83032557	PUMP-TANDEM, VAR DISPL CCW H1T053L	H1-T-053-L-A-N-A5-C2-B-F7-F-G1-NN-38-38-38-38-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83032560	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-L1-BA-N-A-PB-VS-ES-S-A-20-NN-065-N-00-NNN	H1-HP MOTORS	H1-160MB1
83032562	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A2-C2-N-D8-H-F4-H5-L-35-L-35-D-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83032563	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A2-C2-N-D8-G-G3-NN-L-35-L-35-A-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83032564	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A5-C1-B-D3-H-G9-S1-L-33-L-33-C-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83032566	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E1-AA-N-B-TB-VN-AN-N-A-05-NN-012-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83032567	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E1-AA-N-B-TB-VS-AS-S-A-05-NN-012-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83032581	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-AB-60-P-3-C7-D-03-FAD-42-42-24	SERIES 90	S90-075PV
83032582	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MA-1-NN-60-P-3-C7-E-03-FAD-42-42-24	SERIES 90	S90-100PV
83032592	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A2-C3-N-D8-G-G3-NN-L-42-L-42-A-P-32-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83032651	PUMP-VAR-DISPL CCW 90PV130	90L130-HS-1-CD-80-S-4-C8-H-03-GBA-32-32-30	SERIES 90	S90-130PV
83032652	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-T2-D2-N-B-TB-CN-LN-N-A-20-NN-040-Z-30-NNN	H1-HP MOTORS	H1-160MB1
83032660	PUMP-TANDEM, VAR DISPL CCW H1T045L	H1-T-045-L-A-N-A4-C3-N-E7-F-G5-H3-33-33-33-33-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83032668	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A4-C1-N-D6-H-G1-H3-L-35-L-35-C-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83032670	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-K1-K1-N-C-RA-DN-KN-N-A-20-NN-033-N-24-NNN	H1-HP MOTORS	H1-160MB1
83032673	PUMP-VAR DISPL, CW 90PV075	90-R-075-KT-1-BB-80-P-3-S1-E-00-GBA-38-38-24	SERIES 90	S90-075PV
83032674	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-N-A4-C3-N-E7-F-G5-H3-38-38-38-38-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83032682	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-M1-CA-N-C-RA-DN-JN-N-N-NN-NN-000-N-00-NNN	H1-HP MOTORS	H1-080MB1
83032683	PUMP-VAR DISPL CW H1P068R	H1-P-068-R-A-A5-C2-N-F6-H-F1-H6-L-25-L-25-F-L-20-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83032684	PUMP-VAR DISPL CW H1P068R	H1-P-068-R-A-A5-C2-N-F6-H-G1-H6-L-25-L-25-F-L-20-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83032685	PUMP-TANDEM, VAR DISPL CCW H1T045L	H1-T-045-L-A-N-A5-C2-B-F7-F-G5-H2-42-42-42-42-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83032698	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-5-NN-80-P-4-S1-E-03-GBA-38-38-24	SERIES 90	S90-100PV

83032699	PUMP-VAR-DISPL CW H1PV069	H1-P-069-R-A-B8-C2-C-D6-K-G1-H5-L-40-L-40-C-L-30-P2-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83032700	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-T2-D2-N-B-TA-DS-GS-S-A-10-NN-040-Z-22-NNN	H1-HP MOTORS	H1-060MB1
83032713	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-B1-C2-B-D6-H-G1-H3-L-42-L-42-D-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83032720	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A4-C2-N-D6-G-G2-H6-L-42-L-42-L-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83032721	PUMP-VAR-DISPL CW H1PV069	H1-P-069-R-A-A4-C2-N-D6-H-G1-NN-L-42-L-42-C-L-30-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83032727	PUMP-TANDEM, VAR DISPL CCW H1T053L	H1-T-053-L-A-N-A4-C3-B-E7-F-G1-TN-30-30-30-30-M-P-28-PN-NNN-S01	H1-MP PUMPS	H1-045PT/053PT
83032729	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-H-S-B-B-BA-A-A-BHH-CB-A-JJ-3-NNN-***	M46	M46-046PV
83032732	PUMP-VAR-DISPL CCW 90PV180	90L180-KP-1-DE-80-T-C-F1-J-00-FAC-42-42-24	SERIES 90	S90-180PV
83032733	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-1-AB-80-R-3-F1-H-00-GBA-42-42-24	SERIES 90	S90-130PV
83032734	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-1-NN-80-R-3-F1-H-00-GBA-29-29-24	SERIES 90	S90-130PV
83032747	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-5-NN-80-P-4-S1-E-03-GBA-29-29-24	SERIES 90	S90-100PV
83032748	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-BC-60-S-3-C7-E-04-GBA-42-42-30	SERIES 90	S90-100PV
83032751	PUMP-VAR-DISPL 42PV028 CW	42-R-32-C-ANN3-03-A-N-A-2-C-N-A-34-34-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83032753	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A5-C2-N-D8-H-G9-H2-L-28-L-28-C-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83032754	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A5-C2-N-D8-G-G3-H2-L-42-L-42-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83032755	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A5-C2-N-D7-G-G2-H4-L-42-L-42-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83032756	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A5-C2-N-F5-H-G1-H6-L-28-L-28-M-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83032757	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A5-C2-N-D8-G-G3-H5-L-42-L-42-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83032758	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A5-C2-N-F5-H-G9-H6-L-28-L-28-M-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83032767	PUMP-VAR DISPL, CCW 90PV055	90-L-055-DD-1-CD-80-S-3-S1-C-GF-GBA-35-35-24	SERIES 90	S90-055PV
83032768	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E1-AA-N-A-TA-VN-DN-N-N-NN-NN-000-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83032774	PUMP-VAR-DISPL CW H1PV069	H1-P-069-R-A-B8-C2-C-D6-K-G1-H2-L-40-L-40-C-L-30-P2-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83032780	PUMP-TANDEM, VAR DISPL CCW H1T053L	H1-T-053-L-A-N-B1-C2-B-E7-F-G1-T2-20-20-20-20-M-P-24-PN-NNN-S02	H1-MP PUMPS	H1-045PT/053PT
83032783	PUMP-VAR DISPL, CW 90PV075	90-R-075-DD-1-CD-80-L-4-S1-E-GB-GBA-20-20-24	SERIES 90	S90-075PV
83032784	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-AB-80-P-3-S1-F-00-GBA-32-32-24	SERIES 90	S90-100PV
83032785	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-N-A4-C1-N-E7-F-G5-H2-35-35-35-35-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83032786	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-AB-80-S-M-C8-J-03-NNN-38-38-24	SERIES 90	S90-180PV
83032802	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A3-C2-N-F4-H-F4-H6-L-40-L-40-C-M-26-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83032809	PUMP-VAR-DISPL CW H1PV069	H1-P-069-R-A-A2-C2-N-D6-H-G1-H3-K-33-K-33-C-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83032813	PUMP-VAR DISPL, CW H1PV250	H1-P-250-R-A-A5-C2-N-D6-C-G2-H6-L-38-L-20-R-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-210PV/250PV
83032815	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A5-C2-N-F7-F-G5-H3-30-30-30-30-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83032822	PUMP-VAR DISPL CCW H1P060L	H1-P-060-L-A-A8-C3-C-F6-H-F1-H6-L-42-L-42-C-L-26-P1-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83032823	PUMP-VAR DISPL CCW H1P060L	H1-P-060-L-A-A8-C3-C-D6-H-G1-NN-L-42-L-42-C-L-26-P1-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83032825	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-P1-D1-N-B-TA-DN-BN-N-A-10-NN-054-Z-24-NNN	H1-HP MOTORS	H1-080MB1
83032826	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-P1-D1-N-B-TA-DS-BS-S-A-10-NN-054-Z-24-NNN	H1-HP MOTORS	H1-080MB1
83032827	PUMP-VAR-DISPL CW 90PV250	90R250-KA-2-CD-80-S-3-C8-K-03-NNN-38-38-30	SERIES 90	S90-250PV

83032828	PUMP-VAR-DISPL CW 90PV042	90R042-HF-5-NN-80-S-4-C3-C-04-GBA-35-35-18	SERIES 90	S90-042PV
83032829	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-AB-80-S-3-C7-D-00-GBA-38-38-24	SERIES 90	S90-075PV
83032839	PUMP-VAR-DISPL CW 90PV180	90R180-CA-2-AB-80-S-7-C8-H-00-NNN-36-36-30	SERIES 90	S90-180PV
83032863	PUMP-VAR DISPL, CCW 90PV055	90-L-055-MT-1-CD-60-R-3-T1-C-03-GBA-35-35-24-N180	SERIES 90	S90-055PV
83032864	PUMP-VAR DISPL, CCW 90PV055	90-L-055-MT-1-NN-60-R-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83032870	PUMP-VAR DISPL MPV025C	MPV-025-C-B-A-Y-R-A-G-NN-A-A-BGG-DR-A-FF-A-NNN-***	LIGHT DUTY	025PV
83032872	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A8-C2-C-D6-H-F1-H3-L-38-L-38-C-L-30-P1-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83032877	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A5-C1-N-D6-H-F1-S1-L-38-L-38-C-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83032878	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-B1-C1-B-D6-F-G1-H3-L-38-L-38-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83032958	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A5-C1-N-D8-F-G1-H5-L-35-L-35-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83033027	PUMP-VAR DISPL MPV046C	MPV-046-C-B-A-N-S-B-J-AA-A-A-BGG-AK-U-FF-C-NNN-***	M46	M46-046PV
83033028	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-T2-D2-N-B-TA-VS-ES-P-A-10-NN-065-Z-32-NNN	H1-HP MOTORS	H1-160MB1
83033029	MP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-NN-60-S-4-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
83033046	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A4-C2-N-D6-G-G2-H3-L-45-L-45-A-L-30-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83033063	PUMP-VAR-DISPL CW 90PV180	90R180-HD-D-DE-8C-S-E-F1-J-00-GCA-35-35-32-G004	SERIES 90	S90-180PV
83033064	PUMP-VAR-DISPL CW 90PV130	90R130-HD-D-BC-8C-S-E-F1-U-00-GBT-35-35-32-G004	SERIES 90	S90-130PV
83033073	PUMP-VAR DISPL, CW 90PV100	90-R-100-KT-5-BC-80-P-3-S1-E-03-GBA-32-32-24	SERIES 90	S90-100PV
83033075	MOTOR-VAR-DISPL H1B250	H1-B-250-A-HE-HE-N-B-TB-VS-DS-P-A-30-NN-168-Z-00-NNN	H1-HP MOTORS	H1-250MB1
83033076	PUMP-VAR DISPL, CCW H1PV210	H1-P-210-L-A-A5-C1-B-D6-C-G3-NN-K-20-K-33-R-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-210PV/250PV
83033085	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-L2-BA-N-C-PB-VS-ES-P-A-20-NN-108-N-00-NNN	H1-HP MOTORS	H1-160MB1
83033095	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-G-S-A-J-BC-V-A-BJJ-DC-A-HH-C-NNN-***	M46	M46-046PV
83033111	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A4-C2-B-E5-F-G4-H3-L-35-L-35-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83033123	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-1-CD-60-L-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83033125	MOTOR-VARIABLE DISPL SAE_K	K-V-38CN-A-Y2F-F07-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83033130	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-G3AN-52-P-3-G-3-F-1-A-34-34-N-1-1-NNN-NNN	SERIES 42	S42-028PV/032PV
83033131	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-G3AN-52-P-3-G-3-F-1-B-34-34-N-1-1-NNN-NNN	SERIES 42	S42-028PV/032PV
83033136	PUMP-VAR-DISPL CW 90PV042	90R042-KA-1-NN-80-S-4-T8-B-03-GBA-26-26-20	SERIES 90	S90-042PV
83033140	PUMP-VAR-DISPL CW 90PV130	90R130-RU-5-BB-80-D-3-C8-L-D1-GBA-40-40-22	SERIES 90	S90-130PV
83033148	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A5-C2-N-F4-H-G9-H6-L-30-L-30-M-M-26-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83033149	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A5-C2-N-F4-H-G1-H6-L-30-L-30-M-M-26-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83033150	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A5-C2-N-D3-H-G9-H2-L-44-L-44-M-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83033151	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A5-C2-N-D6-F-G5-H2-L-23-L-23-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83033157	TRANSMISSION LDU20 U-STYLE CCW	LDU-20D-L-A-L-S-JJ-J-H-N-07-C-00N-30N-NNN-NNN	DDC20/LDU20	OSK-020U - DO NOT USE
83033162	PUMP-VAR DISPL, CW 90PV075	90-R-075-DC-5-BC-80-L-3-T1-E-G1-GBA-35-35-24	SERIES 90	S90-075PV
83033172	PUMP-VAR-DISPL CCW H1PV130	H1-P-130-L-B-A5-C2-N-D6-G-G2-H4-L-33-L-33-L-L-30-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83033174	PUMP-VAR-DISPL CW 90PV042	90R042-KA-1-NN-80-S-4-T3-B-03-GBA-26-26-20-F008	SERIES 90	S90-042PV

83033181	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A5-C2-N-D6-H-G9-NN-L-42-L-42-M-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83033207	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A4-C2-N-D6-F-G5-H2-L-15-L-15-B-L-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83033210	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A5-C2-N-D3-L-G2-H3-L-38-L-38-L-M-32-P4-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83033219	PUMP-VAR DISPL, CW H1PV210	H1-P-210-R-A-A5-C2-B-D8-C-G2-H4-L-35-L-35-R-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-210PV/250PV
83033222	PUMP-VAR-DISPL CW 90PV130	90R130-K7-1-AB-80-L-4-F1-F-K2-GBA-36-14-24	SERIES 90	S90-130PV
83033227	PUMP-VAR-DISPL CCW 90PV180	90L180-MA-1-NN-80-S-C-F1-H-03-FAC-42-42-24	SERIES 90	S90-180PV
83033230	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-T1-D1-N-A-TA-VN-EN-N-B-40-NN-066-Z-21-NNN	H1-HP MOTORS	H1-160MB1
83033233	PUMP-VAR-DISPL 42PV028 CW	42-R-32-C-E2D8-00-A-N-A-2-H-N-N-25-25-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83033234	PUMP-VAR-DISPL 42PV028 CW	42-R-32-C-E2D8-00-A-N-A-2-H-N-B-25-25-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83033240	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-ANNB-03-D-N-F-2-F-N-N-25-25-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83033243	MOTOR-VAR-DISPL H1B060	H1-B-060-A-TA-DA-N-A-TB-DN-GN-N-N-NN-NN-027-Q-18-NNN	H1-HP MOTORS	H1-060MB1
83033260	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A5-C3-N-D8-G-G3-NN-L-42-L-42-A-P-28-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83033263	MOTOR-VAR-DISPL H1MB060	H1-B-060-A-L2-BA-N-B-PB-VN-AN-N-A-10-NN-028-N-00-NNN	H1-HP MOTORS	H1-060MB1
83033264	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-A-A7-C2-C-D8-K-G9-H2-L-40-L-40-M-P-30-P2-NNN-D3E	H1-HP PUMPS	H1-089PV/100PV
83033272	PUMP-VAR-DISPL CW 90PV075	90R075-KN-5-NN-80-R-4-S1-E-03-GBA-26-26-20	SERIES 90	S90-075PV
83033286	PUMP-VAR-DISPL CW H1PV069	H1-P-069-R-A-A4-C2-N-D6-H-G1-NN-L-35-L-35-C-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83033287	MOTOR-VAR-DISPL H1B110	H1-B-110-A-TA-DA-N-A-TB-CN-JN-N-N-NN-NN-070-Z-18-NNN	H1-HP MOTORS	H1-110MB1
83033292	PUMP-VAR-DISPL CCW H1PV130	H1-P-130-L-B-A5-C2-N-D6-G-G3-NN-L-33-L-33-L-L-30-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83033294	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HS-5-AB-80-S-4-S1-C-03-GBA-26-26-24	SERIES 90	S90-055PV
83033307	PUMP-VAR DISPL, CW 90PV075	90-R-075-K7-2-NN-60-L-4-S1-D-03-GBA-23-23-20	SERIES 90	S90-075PV
83033308	MOTOR-VAR-DISPL H1B160	H1-B-160-A-TA-D1-N-B-TA-CN-EN-N-A-20-NN-108-Z-24-NNN	H1-HP MOTORS	H1-160MB1
83033338	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-E1A6-03-C-2-A-2-F-N-B-34-34-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83033339	PUMP-VAR-DISPL CW 90PV250	90R250-KT-1-NN-80-T-3-F1-K-00-NNN-32-32-24	SERIES 90	S90-250PV
83033340	PUMP-VAR DISPL, CW H1PV210	H1-P-210-R-A-A3-C2-B-D6-C-G2-H6-L-35-L-35-W-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-210PV/250PV
83033341	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-L2-BA-N-A-PB-VS-DS-S-A-15-NN-000-N-00-NNN	H1-HP MOTORS	H1-110MB1
83033352	MOTOR-VAR-DISPL H1B160	H1-B-160-A-TA-DA-N-B-TB-VN-DN-N-A-20-NN-080-Z-23-NNN	H1-HP MOTORS	H1-160MB1
83033361	MOTOR-FIX DISPL MMF044D	MMF-044-D-A-F-K-C-D-NCG-***	M35/44	044MF
83033374	PUMP-VAR-DISPL CW 90PV180	90R180-KP-5-BC-80-T-C-F1-J-03-FAC-38-38-24	SERIES 90	S90-180PV
83033375	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-A-S-B-B-BA-A-A-BEE-CE-A-HH-C-NNN-***	M46	M46-046PV
83033378	PUMP-VAR-DISPL CW 90PV130	90R130-K7-1-AB-80-L-4-F1-F-03-GBA-35-13-24	SERIES 90	S90-130PV
83033381	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-BC-60-L-4-C7-F-03-GBA-35-35-24	SERIES 90	S90-100PV
83033383	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-1-CD-60-P-3-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83033401	PUMP-VAR-DISPL CCW 90PV180	90L180-HF-1-BC-80-T-C-F1-J-03-FAC-35-35-26	SERIES 90	S90-180PV
83033402	PUMP-VAR-DISPL CW 90PV180	90R180-KP-1-BC-80-T-C-C8-J-03-FAC-38-38-24	SERIES 90	S90-180PV
83033405	PUMP-VAR-DISPL CCW H1PV089	H1-P-089-L-A-A5-C3-B-F4-H-G1-H6-K-35-K-20-M-M-20-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83033410	PUMP-VAR DISPL MPV044D	MPV-044-D-B-A-G-R-S-E-AA-A-A-BJJ-DL-A-FF-A-NNN-***	M35/44	044PV

83033424	PUMP-VAR-DISPL CW 90PV100	90R100-HF-5-BC-80-L-3-S1-E-03-GBA-38-38-24	SERIES 90	S90-100PV
83033431	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A4-C2-B-D3-H-G1-NN-L-28-L-28-C-M-32-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83033439	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-CD-80-P-4-D7-D-03-GBA-14-35-24	SERIES 90	S90-075PV
83033440	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A5-C2-B-D6-G-G2-H3-L-45-L-45-L-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83033441	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E2-AA-N-B-TB-VN-DN-N-A-10-NN-035-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83033443	PUMP-VAR-DISPL CW 90PV042	90R042-HF-5-BC-80-S-4-C3-B-00-GBA-42-42-24	SERIES 90	S90-042PV
83033444	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A5-C2-N-D3-G-F3-H6-L-30-L-30-A-M-20-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83033453	PUMP-VAR-DISPL CCW 90PV250	90L250-HF-1-BC-80-D-4-F1-L-03-NNN-38-38-28	SERIES 90	S90-250PV
83033457	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MB-1-NN-80-P-3-C6-D-03-FAD-35-35-24	SERIES 90	S90-075PV
83033458	PUMP-VAR DISPL, CW H1PV250	H1-P-250-R-A-A5-C3-N-D8-C-G2-NN-L-28-L-28-W-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-210PV/250PV
83033459	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A5-C2-N-D6-H-G9-NN-L-38-L-20-M-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83033463	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E2-AA-N-B-TB-VS-DS-S-A-10-NN-035-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83033475	PUMP-VAR-DISPL CW 90PV180	90R180-HF-5-BC-80-S-M-C8-J-03-NNN-29-29-24	SERIES 90	S90-180PV
83033477	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-HE-HE-N-C-TA-VS-AS-P-A-10-NN-030-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83033482	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KT-1-NN-80-L-3-S1-C-05-GBA-32-32-24	SERIES 90	S90-055PV
83033483	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KT-1-AB-80-L-3-S1-C-05-GBA-32-32-24	SERIES 90	S90-055PV
83033484	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-5-NN-80-P-3-S1-C-00-GBA-32-32-24	SERIES 90	S90-055PV
83033487	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-E1A7-02-B-2-C-2-H-N-A-38-38-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83033488	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A2-C1-N-F4-H-G9-H6-L-33-L-33-C-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83033491	PUMP-VAR-DISPL CCW H1PV130	H1-P-130-L-B-A4-C1-N-D3-G-G3-H3-L-42-L-42-A-M-30-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83033494	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E1-AA-N-B-TB-DS-JS-S-N-NN-NN-055-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83033495	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E1-AA-N-B-TB-DS-JS-S-N-NN-NN-045-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83033509	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-NN-80-S-3-F1-F-03-GBA-40-26-24	SERIES 90	S90-100PV
83033515	MOTOR-VAR-DISPL H1B160	H1-B-160-A-TA-D2-N-A-TB-VN-EN-N-A-20-NN-080-Z-26-NNN	H1-HP MOTORS	H1-160MB1
83033516	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-H-S-B-M-HB-A-A-BFF-HA-A-HC-3-NBN-***	M46	M46-046PV
83033517	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-H-S-B-M-HB-A-A-BFF-HA-A-HC-3-NNN-***	M46	M46-046PV
83033525	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E2-AA-N-B-TA-DS-KS-S-A-10-NN-070-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83033526	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-HE-HE-N-B-TB-DN-HN-N-N-NN-NN-025-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83033527	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A5-C2-B-D6-F-G5-H2-L-28-L-28-B-L-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83033528	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A5-C2-B-D6-F-G5-H3-L-28-L-28-B-L-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83033543	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A5-C2-N-D3-G-G3-H6-L-30-L-30-L-M-26-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83033570	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-1-NN-60-R-3-S1-C-03-EBC-38-14-24	SERIES 90	S90-055PV
83033571	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E2-AA-N-A-TA-DN-JN-N-N-NN-NN-030-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83033582	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-BC-60-R-4-C7-E-05-GBA-35-35-24	SERIES 90	S90-100PV
83033583	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-AB-80-S-3-C7-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83033584	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A3-C1-N-D6-H-G9-H3-L-35-L-35-C-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV

83033585	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-BC-80-R-4-S1-E-03-GBA-23-23-24	SERIES 90	S90-075PV
83033586	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E2-AA-N-B-TA-DS-GS-B-N-NN-NN-020-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83033587	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E2-AA-N-B-TA-DN-GN-N-N-NN-NN-020-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83033589	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E2-AA-N-B-TA-CN-GN-N-N-NN-NN-020-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83033594	PUMP-VAR-DISPL CW 90PV042	90R042-FC-7-BC-80-S-7-C3-C-B4-EFI-45-45-32	SERIES 90	S90-042PV
83033595	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A3-C2-N-D8-G-G2-H3-L-38-L-38-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83033598	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E1-AA-N-A-TA-VN-AN-N-A-10-NN-019-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83033599	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E2-AA-N-B-TB-VN-CN-N-A-05-NN-053-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83033600	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-D1-M1-N-A-PB-VN-DN-N-A-30-NN-090-N-30-NNN	H1-HP MOTORS	H1-160MB1
83033601	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A4-C2-N-D6-G-G2-H3-L-45-L-45-L-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83033603	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A5-C2-N-D8-H-G9-H2-L-44-L-44-M-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83033608	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A5-C2-N-D6-H-G9-H5-L-42-L-42-C-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83033640	PUMP-VAR-DISPL CW 90PV250	90R250-KA-2-BC-80-D-3-F1-L-03-NNN-42-42-24	SERIES 90	S90-250PV
83033642	PUMP-VAR-DISPL 42PV028 CW	42-R-32-D-E2D8-00-A-N-A-2-H-N-B-19-19-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83033645	PUMP-VAR-DISPL CCW 90PV130	90L130-HF-5-CD-80-L-4-C8-H-03-GBA-35-35-24	SERIES 90	S90-130PV
83033658	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A4-C2-N-D6-H-G1-NN-L-30-L-30-F-L-22-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83033659	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E1-AA-N-B-TB-DS-JS-S-N-NN-NN-061-R-00-NNN	H1-HP MOTORS	H1-110MB1
83033668	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-1-BB-60-L-4-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83033669	PUMP-VAR-DISPL CW 90PV130	90R130-HF-2-AB-80-S-4-F1-F-38-GBA-35-35-26	SERIES 90	S90-130PV
83033670	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E1-AA-N-B-TB-VN-CN-N-A-10-NN-054-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83033682	PUMP-TANDEM, VAR DISPL MPT044D	MPT-044-D-A-W-S-J-BA-B-A-A-A-BJJ-DR-A-FF-B-C-A-A-BJJ-DR-A-FF-A-NNN-***	M35/44	O44PT
83033683	PUMP-VAR-DISPL CW 90PV100	90R100-HF-1-CD-80-S-4-C6-F-00-GBA-38-38-24	SERIES 90	S90-100PV
83033698	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KN-1-CD-80-R-4-F1-F-03-GBA-38-14-24	SERIES 90	S90-100PV
83033701	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KN-1-NN-80-R-4-F1-F-03-GBA-38-14-24	SERIES 90	S90-100PV
83033711	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A4-C3-B-D8-H-F1-H5-L-38-L-18-M-P-28-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83033712	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KN-1-BC-80-R-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-055PV
83033713	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KN-1-CD-80-R-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-055PV
83033714	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KN-1-NN-80-R-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-055PV
83033727	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A5-C1-B-F5-H-G1-H6-L-30-L-30-C-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83033728	PUMP-VAR-DISPL 42PV041 CW	42-R-51-D-E2D8-02-B-D-B-3-H-N-V-25-25-N-A-A-NNN-NNN	SERIES 42	S42-041PV/051PV
83033729	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-E2D8-02-B-D-B-3-H-N-B-30-30-N-A-A-NNN-NNN	SERIES 42	S42-041PV/051PV
83033733	MOTOR-VAR-DISPL H1B160	H1-B-160-A-TA-D2-N-B-TA-CN-EN-N-A-20-NN-108-Z-24-NNN	H1-HP MOTORS	H1-160MB1
83033735	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A5-C2-N-F4-H-G1-H6-L-33-L-33-F-M-26-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83033736	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-NN-60-D-3-C7-N-03-GBA-20-20-28	SERIES 90	S90-100PV
83033737	PUMP-VAR-DISPL CW 90PV130	90R130-KA-1-AB-80-P-3-F1-H-03-GBA-35-35-24	SERIES 90	S90-130PV
83033738	PUMP-VAR-DISPL CCW 90PV250	90L250-HF-5-NN-80-T-3-F1-J-03-NNN-42-42-24	SERIES 90	S90-250PV

83033744	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-B7-C2-C-D8-K-G9-H5-L-42-L-42-N-E-26-P2-NNN-D5J	H1-HP PUMPS	H1-069PV/078PV
83033762	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A4-C3-B-F5-H-F1-H6-L-38-L-18-M-P-28-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83033765	PUMP-VAR-DISPL CW 90PV130	90R130-HS-1-CD-80-R-3-C8-F-03-GBA-32-32-24	SERIES 90	S90-130PV
83033774	MOTOR-VARIABLE CARTRIDGE K	K-C-45DS-E-RNF-F11-S-N-N-CF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83033775	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HF-1-BC-80-R-4-S1-C-00-GBA-35-35-20	SERIES 90	S90-055PV
83033780	PUMP-VAR-DISPL CCW 90PV100	90L100-HF-5-NN-80-P-3-C7-E-03-GBA-26-26-24	SERIES 90	S90-100PV
83033802	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E1-AA-N-B-TA-VN-CN-N-A-05-NN-054-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83033806	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-K-S-B-B-HB-A-A-BGG-HA-A-HA-B-NNN-***	M46	M46-046PV
83033810	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-5-AB-80-L-4-F1-E-03-GBA-20-20-20	SERIES 90	S90-100PV
83033811	MOTOR-FIX DISPL MMF035D	MMF-035-D-A-D-K-A-S-NCH-***	M35/44	035MF
83033848	PUMP-VAR-DISPL CW 90PV100	90R100-HF-5-CD-80-L-3-C7-E-03-GBA-38-38-24	SERIES 90	S90-100PV
83033854	PUMP-VAR-DISPL CCW H1PV069	H1-P-069-L-A-A5-C2-N-D6-H-G9-H3-L-42-L-42-C-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83033855	PUMP-VAR-DISPL CCW H1PV069	H1-P-069-L-A-A5-C2-N-D6-H-G9-H2-L-42-L-42-C-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83033859	PUMP-VAR-DISPL CCW 90PV180	90L180-CB-5-CD-80-S-7-C8-H-00-EFI-40-40-32	SERIES 90	S90-180PV
83033861	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-AB-80-L-3-C3-C-03-GBA-35-35-24	SERIES 90	S90-042PV
83033871	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-CD-60-L-4-C7-F-03-GBA-35-35-24	SERIES 90	S90-100PV
83033872	PUMP-VAR-DISPL CCW 90PV075	90L075-HF-5-AB-60-L-4-C7-E-03-GBA-29-29-24	SERIES 90	S90-075PV
83033883	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-A-A7-C5-C-F5-K-G9-H6-L-4G-L-4G-N-E-28-P2-NNN-D38	H1-HP PUMPS	H1-089PV/100PV
83033885	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E1-AA-N-B-TB-CN-GN-N-A-05-NN-028-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83033886	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-5-AB-80-P-3-F1-F-03-GBA-38-38-24	SERIES 90	S90-100PV
83033887	PUMP-VAR DISPL, CW 90PV075	90-R-075-KT-1-AB-80-L-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-075PV
83033891	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-D2-MA-N-B-PA-DS-JS-S-A-10-NN-054-N-21-NNN	H1-HP MOTORS	H1-080MB1
83033897	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A4-C2-N-D8-F-G5-H5-L-30-L-30-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83033898	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A4-C2-N-D8-F-G1-H5-L-30-L-30-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83033899	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A4-C2-N-D8-F-G5-H5-L-15-L-15-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83033901	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-L1-BA-N-B-PB-DS-HS-S-A-10-NN-016-N-00-NNN	H1-HP MOTORS	H1-080MB1
83033910	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-1-CD-80-T-C-F1-H-03-FAC-32-32-24	SERIES 90	S90-180PV
83033911	PUMP-VAR-DISPL CW 90PV180	90R180-KA-1-CD-80-T-C-F1-H-03-FAC-32-32-24	SERIES 90	S90-180PV
83033912	PUMP-VAR-DISPL CW 90PV180	90R180-KA-1-CD-80-D-C-F1-L-03-FAC-32-32-24	SERIES 90	S90-180PV
83033913	PUMP-VAR-DISPL CCW 90PV130	90L130-KT-5-BC-80-L-4-F1-H-03-GBA-29-29-24	SERIES 90	S90-130PV
83033915	PUMP-VAR DISPL CCW H1P068L	H1-P-068-L-A-A4-C2-N-D8-H-G1-H3-L-35-L-35-N-E-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83033916	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A4-C2-N-E5-F-G1-H3-L-30-L-30-N-E-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83033919	PUMP-VAR-DISPL CCW H1PV130	H1-P-130-L-B-A4-C1-N-D8-G-G3-H3-L-42-L-42-A-P-30-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83033920	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A4-C2-B-D8-H-G1-NN-L-28-L-28-C-P-32-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83033933	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-HE-HE-N-B-TB-DN-HN-N-A-10-NN-042-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83033935	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A2-C1-B-D8-H-G1-H3-K-42-K-42-M-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV

83033999	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A3-C3-N-F7-F-G5-H3-30-30-30-30-N-P-28-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83034012	MOTOR-VAR-DISPL H1B250	H1-B-250-A-P1-D1-N-B-TA-VS-DS-S-A-30-NN-050-Z-24-NNN	H1-HP MOTORS	H1-250MB1
83034014	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-HE-HE-N-B-TA-DN-KN-N-A-10-NN-055-T-00-NNN	H1-HP MOTORS	H1-110MB1
83034016	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A4-C1-B-D3-H-G1-NN-L-28-L-28-C-M-30-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83034019	PUMP-VAR DISPL, CW 90PV055	90-R-055-HF-1-CD-80-R-3-S1-C-00-GBA-32-32-24	SERIES 90	S90-055PV
83034020	PUMP-VAR DISPL, CW 90PV055	90-R-055-HF-1-NN-80-R-3-S1-C-00-GBA-32-32-24	SERIES 90	S90-055PV
83034021	PUMP-VAR DISPL, CW 90PV100	90-R-100-CB-1-NN-80-L-4-S1-E-00-GBA-29-29-24	SERIES 90	S90-100PV
83034105	PUMP-VAR-DISPL CCW H1PV130	H1-P-130-L-B-A5-C3-B-D8-G-G2-H3-L-30-L-30-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83034112	PUMP-VAR-DISPL CW 90PV130	90R130-KN-5-NN-80-L-3-C8-H-03-GBA-24-24-24	SERIES 90	S90-130PV
83034143	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-C6-C2-N-D6-H-G9-H2-L-38-L-20-M-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83034161	MOTOR-VAR-DISPL H1B250	H1-B-250-A-E2-AA-N-B-TB-VN-FN-N-A-20-NN-100-R-00-NNN	H1-HP MOTORS	H1-250MB1
83034163	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-AB-80-S-4-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83034165	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A3-C1-N-D3-G-G3-H3-K-35-K-35-A-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83034166	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A5-C1-N-D3-G-G3-H4-K-35-K-35-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83034170	PUMP-VAR DISPL MPV046C	MPV-046-C-B-A-H-S-B-B-AA-A-A-BHH-AB-U-AD-A-NNN-***	M46	M46-046PV
83034172	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-BC-80-L-3-C8-F-03-GBA-35-35-24	SERIES 90	S90-130PV
83034174	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-1-AB-80-S-3-C7-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83034186	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A2-C2-B-D8-G-G3-NN-L-33-L-25-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83034202	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A3-C2-N-D8-F-G1-NN-L-25-L-25-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83034205	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-8-N-0-K1-W-00-EHD-00-00-F0	SERIES 90	S90-055MF
83034207	PUMP-VAR-DISPL CW 90PV180	90R180-KA-1-NN-80-T-C-F1-H-03-FAC-32-32-24	SERIES 90	S90-180PV
83034208	MOTOR-VAR-DISPL H1B160	H1-B-160-A-TA-DA-N-A-TB-VS-ES-S-A-30-NN-108-Z-29-NNN	H1-HP MOTORS	H1-160MB1
83034229	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A5-C2-B-D3-H-G9-H2-L-35-L-35-C-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83034231	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E2-AA-N-B-TB-VN-EN-N-A-10-NN-036-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83034233	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A5-C1-N-D6-H-G1-H3-L-35-L-35-F-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83034248	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-HE-HE-N-B-TA-DN-KN-N-N-NN-NN-030-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83034253	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-T2-DA-N-B-TA-DN-KN-N-A-10-NN-058-Z-24-NNN	H1-HP MOTORS	H1-110MB1
83034256	PUMP-VAR-DISPL CW 90PV100	90R100-KA-1-NN-80-S-3-C7-E-00-GBA-42-42-24	SERIES 90	S90-100PV
83034268	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-NN-80-P-3-C7-D-03-FAD-42-42-24	SERIES 90	S90-075PV
83034275	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A4-C1-N-D3-H-G1-H3-L-38-L-38-F-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83034276	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-HE-HE-N-A-TB-VS-AS-S-A-10-NN-040-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83034278	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A4-C1-B-D8-H-G1-NN-L-20-L-20-C-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83034279	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MA-1-NN-80-L-4-S1-F-00-GBA-35-35-24	SERIES 90	S90-100PV
83034280	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-1-NN-80-L-4-S1-D-00-GBA-35-35-24	SERIES 90	S90-055PV
83034281	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-NN-80-L-4-S1-F-00-GBA-35-35-24	SERIES 90	S90-100PV
83034282	PUMP-VAR-DISPL CCW 90PV130	90L130-MA-1-NN-80-L-4-F1-H-00-GBA-35-35-24	SERIES 90	S90-130PV

83034283	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-CD-80-P-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83034284	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-NN-80-P-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83034285	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-8-N-0-C7-W-00-EBA-00-00-G3	SERIES 90	S90-100MF
83034286	PUMP-VAR-DISPL CW 90PV130	90R130-DD-5-AB-80-P-4-C8-F-GB-GBA-42-42-24	SERIES 90	S90-130PV
83034287	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-AB-60-L-3-S1-E-03-GBA-20-20-24	SERIES 90	S90-075PV
83034289	PUMP-VAR-DISPL CW 90PV130	90R130-HF-5-NN-80-R-3-F1-H-00-GBA-35-35-20	SERIES 90	S90-130PV
83034298	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-E-V-C-B-AA-B-A-U-A-BJJ-AB-U-CF-B-C-U-A-BJJ-AB-D-CF-B-NNN-***	M46	M46-046PT
83034299	MOTOR-VARIABLE DISPL SAE_L	L-V-30DS-A-Y4F-F01-S-N-N-DF-F12-NNN-NNN	LV / KV MOTORS	L/K-MV
83034300	PUMP-VAR-DISPL CW 90PV130	90R130-DC-1-BB-80-P-3-T4-F-50-GBA-26-14-24	SERIES 90	S90-130PV
83034311	PUMP-VAR DISPL, CW H1PV250	H1-P-250-R-A-A5-C2-N-D8-C-G2-NN-L-35-L-28-R-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-210PV/250PV
83034312	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A5-C2-N-F4-H-G9-H6-L-40-L-40-D-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83034313	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A5-C2-N-D3-H-G1-NN-L-40-L-40-D-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83034314	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A5-C2-N-D3-H-G1-NN-L-40-L-40-D-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83034316	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-D-E1A6-03-C-3-A-2-G-N-A-30-30-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83034317	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-E1A6-03-C-3-A-2-G-N-A-30-30-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83034318	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-E2-AA-N-B-TB-VN-DN-N-A-20-NN-080-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83034319	MOTOR-VAR-DISPL H1B060	H1-B-060-A-TA-DA-N-B-TB-CN-GN-N-N-NN-NN-015-R-16-NNN	H1-HP MOTORS	H1-060MB1
83034321	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-B1-C1-N-D8-G-G2-H3-L-30-L-30-L-P-30-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83034322	PUMP-VAR-DISPL 42PV041 CW	42-R-41-E-ANN3-03-B-3-G-3-F-N-B-34-34-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83034354	PUMP-VAR-DISPL CCW 90PV100	90L100-MA-1-AB-60-S-4-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83034361	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A5-C3-N-D8-G-G3-NN-L-42-L-42-N-E-28-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83034375	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-A-S-B-J-BA-A-A-BBB-CN-A-GG-C-NNN-***	M46	M46-046PV
83034380	PUMP-VAR-DISPL CCW H1PV165	H1-P-165-L-C-A5-C2-B-D8-G-G3-H6-L-35-L-35-A-P-20-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83034382	PUMP-VAR-DISPL CCW H1PV115	H1-P-115-L-B-B1-C1-N-D8-G-G2-H3-L-30-L-30-L-P-30-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83034419	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-A-A4-C2-N-F6-H-F1-H6-L-45-L-45-D-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83034452	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-BC-60-L-3-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83034462	MOTOR-FIXED DISPL MMF025C	MMF-025-C-A-4-M-F-B-NNN-***	LIGHT DUTY	025MF
83034464	MOTOR-VARIABLE DISPL SAE_L	L-V-25CS-C-RNF-F01-S-N-N-CF-F16-NNN-NNN	LV / KV MOTORS	L/K-MV
83034465	PUMP-VAR DISPL MPV046C	MPV-046-C-B-A-A-S-B-S-BA-G-A-BGG-GB-B-AA-C-NNN-***	M46	M46-046PV
83034466	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A4-C2-N-D3-H-F1-NN-L-40-L-40-D-M-30-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83034482	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-BC-80-L-4-T2-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83034492	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KT-1-CD-80-S-3-C7-D-00-GBA-35-35-28	SERIES 90	S90-075PV
83034493	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KT-1-NN-80-S-3-C7-D-00-GBA-35-35-28	SERIES 90	S90-075PV
83034494	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KT-1-CD-80-S-3-C7-F-00-GBA-42-38-28	SERIES 90	S90-100PV
83034495	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KT-1-NN-80-S-3-S1-D-00-GBA-32-32-28	SERIES 90	S90-075PV
83034496	PUMP-VAR DISPL MPV046C	MPV-046-C-B-A-A-S-B-S-BA-V-A-BGG-GB-B-AA-C-NNN-***	M46	M46-046PV

83034499	PUMP-VAR DISPL MPV046C	MPV-046-C-B-A-H-S-B-J-BA-A-A-BGG-AK-U-FA-A-NNN-***	M46	M46-046PV
83034500	PUMP-VAR DISPL MPV044D	MPV-044-D-B-A-A-R-S-G-AA-A-A-BFF-DR-A-FF-C-NNN-***	M35/44	044PV
83034508	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E2-AA-N-B-TB-VS-AS-S-N-NN-NN-016-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83034509	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E2-AA-N-B-TB-VN-AN-N-A-05-NN-016-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83034511	PUMP-VAR DISPL, CW 90PV100	90-R-100-KN-1-NN-80-S-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83034517	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A5-C1-B-D8-G-G3-H4-L-35-L-35-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83034522	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-1-BC-80-S-3-C6-D-02-GBA-35-35-24	SERIES 90	S90-055PV
83034528	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-BC-80-D-4-C8-L-04-GBA-42-42-24	SERIES 90	S90-130PV
83034539	PUMP-VAR-DISPL CCW 90PV075	90L075-MA-1-AB-80-L-3-C7-E-05-GBA-42-42-26	SERIES 90	S90-075PV
83034542	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A2-C2-B-E5-F-G5-NN-L-28-L-28-B-P-24-PN-NNN-E01	H1-MP PUMPS	H1-045PV/053PV
83034543	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-A-V-C-B-BA-B-B-A-A-BHH-CE-A-GG-B-D-A-A-BHH-CE-A-GG-A-NNN-	M46	M46-046PT
83034544	PUMP-VAR DISPL MPV046C	MPV-046-C-B-A-B-S-B-B-BA-A-A-BFF-AK-D-FF-A-NNN-***	M46	M46-046PV
83034545	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MA-1-NN-80-S-3-F1-E-09-GBA-42-42-20	SERIES 90	S90-100PV
83034546	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-1-NN-80-S-3-C6-C-09-GBA-42-42-20	SERIES 90	S90-055PV
83034547	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-1-NN-80-S-3-C7-D-09-GBA-42-42-20	SERIES 90	S90-075PV
83034549	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A3-C1-N-D3-H-G9-NN-K-30-K-30-C-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83034556	MOTOR-VAR-DISPL H1B060	H1-B-060-A-NB-NT-N-N-TA-VS-AS-P-N-NN-NN-000-Z-00-0NN	H1-HP MOTORS	H1-060MB1
83034557	MOTOR-VAR-DISPL H1B060	H1-B-060-A-NB-NT-N-N-TB-VS-AS-P-N-NN-NN-000-Z-00-0NN	H1-HP MOTORS	H1-060MB1
83034558	MOTOR-VAR-DISPL H1B080	H1-B-080-A-NB-NT-N-N-TA-VS-AS-P-N-NN-NN-000-Z-00-0NN	H1-HP MOTORS	H1-080MB1
83034559	MOTOR-VAR-DISPL H1B080	H1-B-080-A-NB-NT-N-N-TB-VS-AS-P-N-NN-NN-000-Z-00-0NN	H1-HP MOTORS	H1-080MB1
83034560	MOTOR-VAR-DISPL H1B110	H1-B-110-A-NB-NT-N-N-TA-VS-ES-P-N-NN-NN-000-Z-00-0NN	H1-HP MOTORS	H1-110MB1
83034561	MOTOR-VAR-DISPL H1B110	H1-B-110-A-NB-NT-N-N-TB-VS-ES-P-N-NN-NN-000-Z-00-0NN	H1-HP MOTORS	H1-110MB1
83034569	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KN-1-AB-60-L-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-055PV
83034570	PUMP-VAR DISPL MPV046C	MPV-046-C-B-A-B-S-B-B-AA-A-A-BFF-AB-D-YH-A-NNN-***	M46	M46-046PV
83034571	PUMP-VAR DISPL, CW 90PV075	90-R-075-DC-1-BC-80-L-3-T1-E-50-GBA-29-14-24	SERIES 90	S90-075PV
83034573	PUMP-VAR DISPL, CW 90PV055	90-R-055-SB-2-BC-60-R-3-S1-C-33-PEA-42-42-24	SERIES 90	S90-055PV
83034574	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A4-C2-B-E6-F-G4-H2-L-23-L-23-B-L-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83034579	PUMP-TANDEM, VAR DISPL MPT035D	MPT-035-D-A-W-A-C-NN-C-A-A-A-BJJ-DL-A-FF-C-C-A-A-BJJ-DL-A-FF-1-NNN-***	M35/44	035PT
83034580	PUMP-TANDEM, VAR DISPL MPT044D	MPT-044-D-A-L-R-G-AA-B-A-A-A-BEE-DR-A-FF-B-C-A-A-BEE-DR-A-FF-A-NNN-*	M35/44	044PT
83034584	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-AB-80-L-4-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83034587	PUMP-VAR-DISPL CW H1PV069	H1-P-069-R-A-A5-C2-N-D8-H-G1-S1-L-20-L-20-F-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83034588	PUMP-VAR-DISPL CCW H1PV130	H1-P-130-L-B-A5-C2-N-D8-G-G3-NN-L-35-L-20-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83034589	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A5-C2-N-D8-H-G9-H3-L-42-L-42-M-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83034590	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-HE-HE-N-B-TB-CS-KS-S-A-20-NN-063-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83034592	MOTOR-VAR-DISPL H1B250	H1-B-250-A-L2-BA-N-A-PA-VS-DS-S-A-20-NN-065-N-00-NNN	H1-HP MOTORS	H1-250MB1
83034595	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-NN-80-T-M-C8-J-03-NNN-26-26-24	SERIES 90	S90-180PV

83034596	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A3-C2-N-D6-H-F1-NN-K-33-K-33-F-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83034601	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-D2-M2-N-B-PB-VS-ES-S-A-30-NN-073-N-29-NNN	H1-HP MOTORS	H1-160MB1
83034602	MOTOR-VAR-DISPL H1B160	H1-B-160-A-NB-NT-N-N-TA-VS-ES-P-N-NN-NN-000-Z-00-0NN	H1-HP MOTORS	H1-160MB1
83034603	MOTOR-VAR-DISPL H1B160	H1-B-160-A-NB-NT-N-N-TB-VS-ES-P-N-NN-NN-000-Z-00-0NN	H1-HP MOTORS	H1-160MB1
83034604	MOTOR-VAR-DISPL H1B250	H1-B-250-A-NB-NT-N-N-TA-VS-FS-P-N-NN-NN-000-Z-00-0NN	H1-HP MOTORS	H1-250MB1
83034605	MOTOR-VAR-DISPL H1B250	H1-B-250-A-NB-NT-N-N-TB-VS-FS-P-N-NN-NN-000-Z-00-0NN	H1-HP MOTORS	H1-250MB1
83034617	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-T1-DA-N-B-TB-VN-EN-N-A-20-NN-065-R-30-NNN	H1-HP MOTORS	H1-160MB1
83034620	MOTOR-VARIABLE DISPL SAE_L	L-V-30DS-A-YNF-F01-S-N-N-DF-F12-NNN-NNN	LV / KV MOTORS	L/K-MV
83034623	PUMP-VAR DISPL, CW 90PV100	90-R-100-HS-1-NN-80-S-4-T2-F-02-GBA-14-29-24	SERIES 90	S90-100PV
83034624	PUMP-VAR DISPL, CCW 90PV055	90-L-055-MA-1-NN-80-P-3-C6-C-03-FAD-42-42-24	SERIES 90	S90-055PV
83034641	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-1-NN-80-S-3-C6-C-09-GBA-42-42-20	SERIES 90	S90-055PV
83034643	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-1-NN-80-S-3-C7-D-09-GBA-42-42-20	SERIES 90	S90-075PV
83034644	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MA-1-NN-80-S-3-F1-E-09-GBA-42-42-20	SERIES 90	S90-100PV
83034649	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E2-AA-N-B-TB-DS-JS-S-N-NN-NN-054-R-00-NNN	H1-HP MOTORS	H1-110MB1
83034654	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A5-C3-B-D6-G-G3-H2-L-42-L-42-L-L-28-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83034659	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-HE-HE-N-B-TB-CN-HN-N-N-NN-NN-040-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83034676	PUMP-VAR DISPL MPV025C	MPV-025-C-B-A-A-R-A-G-NN-A-A-BEE-DL-A-FF-A-NNN-***	LIGHT DUTY	025PV
83034678	PUMP-VAR-DISPL CW 90PV075	90R075-MA-1-CD-60-S-3-C6-D-03-GBA-42-42-20	SERIES 90	S90-075PV
83034679	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-B8-C2-C-D8-L-G2-H6-K-42-K-42-L-P-30-P2-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83034680	MOTOR-VAR-DISPL H1B250	H1-B-250-A-K2-K2-N-B-RB-VN-DN-N-A-30-NN-060-N-25-NNN	H1-HP MOTORS	H1-250MB1
83034687	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A3-C1-N-D5-G-G3-H4-K-35-K-35-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83034688	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A3-C1-N-D3-G-G3-H3-K-35-K-35-A-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83034691	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KN-5-CD-80-R-3-C7-D-04-GBA-32-32-24	SERIES 90	S90-075PV
83034692	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KN-5-NN-80-R-3-S1-D-04-GBA-32-32-24	SERIES 90	S90-075PV
83034693	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KN-5-CD-80-R-3-C7-E-04-GBA-32-32-24	SERIES 90	S90-100PV
83034694	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KN-5-NN-80-R-3-S1-C-04-GBA-32-32-24	SERIES 90	S90-055PV
83034705	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-HE-HE-N-A-TB-VN-EN-N-A-20-NN-032-R-00-NNN	H1-HP MOTORS	H1-160MB1
83034721	PUMP-VAR-DISPL 42PV041 CW	42-R-51-E-E1A4-02-B-2-B-3-H-N-V-34-34-B-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83034722	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-F2NN-72-J-2-B-3-H-N-A-34-34-N-A-A-NNN-NNN	SERIES 42	S42-041PV/051PV
83034735	PUMP-VAR-DISPL CW 90PV100	90R100-MA-5-NN-80-S-3-S1-E-C5-GBA-20-20-24	SERIES 90	S90-100PV
83034743	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A5-C2-N-D6-F-G5-H2-L-42-L-42-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83034747	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A5-C2-N-D3-H-G1-H2-L-25-L-25-F-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83034754	PUMP-VAR DISPL, CW 90PV075	90-R-075-MB-2-BC-60-D-3-S1-L-05-GBA-40-40-24	SERIES 90	S90-075PV
83034755	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-T1-D1-N-B-TA-VN-AN-N-A-10-NN-021-Z-30-NNN	H1-HP MOTORS	H1-080MB1
83034756	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A3-C1-N-D5-G-G2-H4-K-35-K-35-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83034763	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-8-N-0-S1-W-00-NNN-00-00-G0	SERIES 90	S90-100MF

83034766	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-1-BC-80-D-4-F1-L-03-NNN-38-38-28	SERIES 90	S90-250PV
83034772	PUMP-VAR-DISPL CCW 90PV100	90L100-MA-1-CD-80-L-3-S1-F-05-GBA-35-35-20	SERIES 90	S90-100PV
83034777	PUMP-VAR-DISPL CW 90PV250	90R250-KN-1-BC-80-T-4-F1-K-03-NNN-42-42-24	SERIES 90	S90-250PV
83034785	PUMP-VAR-DISPL CW 90PV100	90R100-CB-5-NN-80-S-3-F1-E-00-GBA-29-29-24	SERIES 90	S90-100PV
83034786	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-1-AB-60-P-3-S1-D-03-GBA-32-32-24	SERIES 90	S90-075PV
83034787	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-1-NN-60-P-3-S1-D-03-GBA-32-32-24	SERIES 90	S90-075PV
83034793	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E1-AA-N-B-TB-VN-AN-N-A-10-NN-016-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83034794	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-HE-HE-N-B-TA-VN-AN-N-A-10-NN-024-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83034803	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MA-1-BC-80-P-3-C7-E-03-FAD-42-42-24	SERIES 90	S90-100PV
83034804	PUMP-VAR DISPL, CCW 90PV055	90-L-055-MA-1-AB-80-P-3-S1-C-03-FAD-42-42-24	SERIES 90	S90-055PV
83034849	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-AB-80-P-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-055PV
83034850	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-CD-80-P-3-C6-D-03-GBA-42-42-24	SERIES 90	S90-055PV
83034851	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A5-C2-N-F6-H-G9-H6-L-42-L-42-M-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83034852	PUMP-VAR DISPL CCW H1P060L	H1-P-060-L-A-A5-C2-N-D6-H-G1-NN-L-42-L-42-F-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83034856	MOTOR-FIX DISPL MMF044D	MMF-044-D-A-F-G-C-K-NNN-***	M35/44	044MF
83034872	PUMP-VAR-DISPL CW 90PV130	90R130-MB-1-NN-80-R-3-F1-H-C5-GBA-42-42-24	SERIES 90	S90-130PV
83034874	PUMP-VAR-DISPL CCW H1PV089	H1-P-089-L-A-A2-C1-B-D6-H-G1-NN-L-38-L-38-M-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83034882	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-B8-C2-C-D3-G-G2-H6-L-30-L-30-L-M-26-P1-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83034892	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-C5-C1-N-D6-H-G1-NN-L-42-L-42-D-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83034893	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-C5-C1-N-F6-H-G9-H6-L-42-L-42-D-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83034895	PUMP-VAR-DISPL CW 90PV100	90R100-HF-1-BC-80-S-3-C7-E-03-GBA-38-38-24	SERIES 90	S90-100PV
83034900	PUMP-VAR DISPL CCW H1P068L	H1-P-068-L-A-B1-C1-N-F6-H-G1-H6-L-35-L-35-C-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83034902	PUMP-VAR DISPL CCW H1P068L	H1-P-068-L-A-A3-C1-N-F6-H-G1-H6-L-35-L-35-C-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83034904	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-NN-60-R-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83034914	PUMP-VAR-DISPL CCW 90PV042	90L042-DD-1-BB-80-S-3-C3-B-50-GBA-35-35-24	SERIES 90	S90-042PV
83034918	PUMP-VAR DISPL CCW H1P053L	H1-P-053-L-A-A5-C2-N-D6-F-G1-H5-L-38-L-38-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83034923	PUMP-VAR DISPL CCW H1P060L	H1-P-060-L-A-A4-C1-N-D6-H-F1-H3-L-30-L-30-C-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83034925	PUMP-VAR DISPL CCW H1P060L	H1-P-060-L-A-A4-C1-N-D6-H-F1-H3-L-42-L-42-C-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83034927	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-B-Z-C-B-AA-B-B-A-A-BDD-CB-A-GG-B-D-A-A-BDD-CB-A-GG-B-NNN-	M46	M46-046PT
83034950	PUMP-VAR-DISPL CW 90PV250	90R250-KA-1-BC-80-T-4-C8-K-03-NNN-42-42-24	SERIES 90	S90-250PV
83034956	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-BC-80-R-3-F1-H-03-EBA-38-38-24	SERIES 90	S90-130PV
83034957	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-BC-80-R-3-F1-H-03-EBA-38-38-24	SERIES 90	S90-130PV
83034975	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-NN-80-R-3-C7-F-03-GBA-26-26-24	SERIES 90	S90-100PV
83034980	PUMP-VAR-DISPL 42PV041 CW	42-R-51-D-G3AN-50-P-D-B-3-H-5-A-25-25-B-0-0-NNN-NNN	SERIES 42	S42-041PV/051PV
83034981	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-K-S-B-B-HB-A-A-BJJ-HB-A-HC-B-NNN-***	M46	M46-046PV
83034982	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-L2-BA-N-B-PB-VN-DN-N-A-20-NN-062-N-00-NNN	H1-HP MOTORS	H1-160MB1

83034992	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-A-S-B-B-HB-A-A-BJJ-HB-A-HC-C-NNN-***	M46	M46-046PV
83034994	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-A-S-A-B-BC-B-A-C-A-BFF-AB-D-CD-B-C-C-A-BFF-AB-D-CD-A-NNN-*	M46	M46-046PT
83034995	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-1-BC-80-S-C-F1-J-03-NNN-23-23-24	SERIES 90	S90-180PV
83035000	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HS-1-AC-80-S-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-075PV
83035010	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A3-C2-N-D8-H-A1-H3-L-25-L-25-M-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83035035	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A5-C2-B-D8-H-G1-H3-L-35-L-35-N-E-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83035036	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A5-C2-B-D8-H-G1-H3-L-28-L-28-N-E-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83035037	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-CD-60-R-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83035046	PUMP-VAR-DISPL CW 90PV100	90R100-HK-5-NN-80-S-3-F1-E-03-GBA-29-29-24	SERIES 90	S90-100PV
83035047	PUMP-VAR-DISPL 42PV041 CCW	42-L-41-C-ANN3-03-D-N-F-2-F-N-N-23-23-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83035072	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-T1-D1-N-B-TA-CN-JN-N-A-15-NN-070-Z-24-NNN	H1-HP MOTORS	H1-110MB1
83035074	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A2-C2-N-D3-H-G1-H3-K-35-K-35-F-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83035075	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A2-C2-N-F4-H-G1-H6-K-35-K-35-F-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83035076	MOTOR-VAR-DISPL H1B110	H1-B-110-A-TA-D2-N-B-TA-CN-JN-N-A-10-NN-074-Z-24-NNN	H1-HP MOTORS	H1-110MB1
83035078	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-T2-D2-N-B-TA-DS-JS-S-A-15-NN-074-S-28-NNN	H1-HP MOTORS	H1-110MB1
83035079	PUMP-VAR DISPL, CCW 90PV075	90-L-075-DD-1-BB-80-S-3-C6-D-GB-GBA-26-26-24	SERIES 90	S90-075PV
83035080	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-1-BB-80-S-3-C6-E-03-GBA-32-32-24	SERIES 90	S90-075PV
83035091	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-HE-HE-N-A-TB-VN-AN-N-A-10-NN-023-U-00-NNN	H1-HP MOTORS	H1-060MB1
83035092	PUMP-VAR DISPL, CW H1PV210	H1-P-210-R-A-A5-C2-N-D8-C-G2-H3-L-38-L-38-R-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-210PV/250PV
83035099	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A4-C1-N-D6-H-G1-H3-L-42-L-30-C-L-30-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83035101	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-A-A7-C1-C-F6-K-G1-H6-L-42-L-42-M-L-28-P2-NNN-D3F	H1-HP PUMPS	H1-089PV/100PV
83035104	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-ANNB-03-C-3-A-3-F-N-A-34-34-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83035105	MOTOR-FIX DISPL MMF035D	MMF-035-D-A-6-G-A-B-NNR-***	M35/44	035MF
83035112	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A4-C1-N-F6-H-G9-H6-L-42-L-42-M-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83035113	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-K1-K1-N-B-RA-VS-DS-S-A-10-NN-065-N-27-NNN	H1-HP MOTORS	H1-110MB1
83035123	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E2-AA-N-B-TB-CS-AS-P-A-05-NN-036-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83035124	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A5-C1-N-D6-H-G9-H3-L-35-L-35-D-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83035129	MOTOR-VARIABLE DISPL SAE_K	K-V-38CN-E-R1F-F10-S-N-N-AF-F17-NNN-NNN	LV / KV MOTORS	L/K-MV
83035144	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-HE-HE-N-A-TB-VN-AN-N-A-10-NN-016-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83035145	PUMP-VAR-DISPL CCW 90PV250	90L250-KT-5-BC-80-T-4-F1-K-03-NNN-38-14-24	SERIES 90	S90-250PV
83035146	PUMP-VAR-DISPL 42PV028 CW	42-R-28-G-E2D8-03-D-N-F-3-F-N-A-17-17-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83035155	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-1-CD-80-P-4-S1-C-00-GBA-14-14-24	SERIES 90	S90-055PV
83035158	PUMP-VAR-DISPL CW 90PV100	90R100-HK-5-BC-80-S-3-F1-E-03-GBA-29-29-24	SERIES 90	S90-100PV
83035170	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-T1-D1-N-B-TA-DN-KN-N-A-10-NN-050-Z-24-NNN	H1-HP MOTORS	H1-110MB1
83035175	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A4-C3-N-D8-F-G5-H1-L-25-L-25-B-P-22-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83035177	PUMP-VAR DISPL, CCW H1PV250	H1-P-250-L-A-A4-C1-B-D8-C-G3-H3-L-35-L-20-W-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-210PV/250PV

83035179	PUMP-VAR-DISPL CCW 90PV100	90L100-MA-1-CD-80-S-3-C7-E-02-GBA-35-35-24	SERIES 90	S90-100PV
83035180	PUMP- VARIABLE, DIRECT DISPLACMENT	LPV-A-A-A-E-A-E-AB-C-A-BDD-DR-A-FF-B-NNN-***	LPV	LPV
83035181	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-CD-80-S-3-F1-J-03-NNN-42-42-24	SERIES 90	S90-250PV
83035182	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-CD-80-S-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
83035187	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-NN-80-L-4-F1-F-03-GBA-20-20-24	SERIES 90	S90-100PV
83035191	PUMP-VAR DISPL, CW 90PV055	90-R-055-HF-1-AB-60-P-3-S1-D-03-FAD-14-14-24	SERIES 90	S90-055PV
83035192	PUMP-VAR DISPL, CW 90PV075	90-R-075-HF-1-CD-60-P-3-C7-E-03-FAD-14-14-24	SERIES 90	S90-075PV
83035204	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-CD-80-L-4-C7-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83035205	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-5-NN-80-P-4-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83035207	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-NN-80-P-3-S1-D-00-GBA-32-32-24	SERIES 90	S90-075PV
83035209	MOTOR-VAR-DISPL H1MB060	H1-B-060-A-L2-BA-N-B-PB-CN-GN-N-N-NN-NN-028-N-00-NNN	H1-HP MOTORS	H1-060MB1
83035210	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A5-C1-N-D8-F-G1-H5-L-35-L-35-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83035211	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A5-C1-N-D8-F-G5-NN-L-35-L-35-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83035215	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-NN-80-R-4-F1-E-03-GBA-14-35-24	SERIES 90	S90-100PV
83035218	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A4-C2-B-E5-F-G5-H3-L-40-L-40-B-P-32-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83035220	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-G-ANNB-03-C-D-A-2-F-N-B-34-34-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83035221	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-C-ANNB-03-C-D-A-2-F-N-N-34-34-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83035222	MOTOR-FIX DISPL MMF044D	MMF-044-D-A-F-H-C-K-NNN-***	M35/44	044MF
83035224	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-E2-AA-N-A-TA-DN-KN-N-A-20-NN-000-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83035232	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-CD-60-S-3-S1-D-03-GBA-20-20-24	SERIES 90	S90-075PV
83035242	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A5-C1-N-D3-H-G1-H5-L-35-L-35-C-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83035245	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-E-V-C-S-AA-B-A-A-A-BGG-GG-B-BF-B-C-A-A-BGG-GG-B-BF-B-NNN-*	M46	M46-046PT
83035256	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-HE-HE-N-B-TB-CN-GN-N-A-10-NN-028-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83035261	PUMP-VAR DISPL CCW H1P060L	H1-P-060-L-A-B1-C3-B-D8-H-G1-H3-L-33-L-33-C-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83035262	PUMP-VAR DISPL, CW 90PV100	90-R-100-CA-1-CD-80-D-7-F1-L-00-GBA-35-35-24	SERIES 90	S90-100PV
83035263	PUMP-VAR DISPL, CW 90PV100	90-R-100-CA-1-BC-80-D-7-S1-L-00-GBA-35-35-24	SERIES 90	S90-100PV
83035265	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-NN-80-P-4-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83035266	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A5-C3-B-D3-G-G3-NN-L-35-L-35-A-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83035267	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A5-C2-B-D3-H-G1-NN-L-25-L-25-F-M-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83035268	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A5-C2-N-D3-H-G3-NN-L-35-L-35-D-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83035274	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-T2-DA-N-B-TB-VN-DN-N-A-20-NN-060-Z-20-NNN	H1-HP MOTORS	H1-160MB1
83035286	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E2-AA-N-B-TB-VN-AN-N-A-05-NN-020-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83035287	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-AB-80-S-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-075PV
83035290	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-B1-C1-N-D6-H-F1-H2-L-35-L-35-C-L-20-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83035291	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A5-C1-N-D6-H-F1-H2-L-35-L-35-C-L-20-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83035293	PUMP-VAR DISPL, CW 90PV100	90-R-100-HF-1-BC-80-L-3-S1-E-09-GBA-26-26-24	SERIES 90	S90-100PV

83035294	PUMP-VAR DISPL, CW 90PV100	90-R-100-KN-5-NN-80-R-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83035295	MOTOR-VARIABLE CARTRIDGE K	K-C-45DS-E-RNF-F12-S-N-N-DF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83035298	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KT-1-NN-60-R-3-S1-F-06-GBA-14-14-20	SERIES 90	S90-100PV
83035299	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-C-E1A7-00-D-N-F-3-F-N-A-21-21-N-H-H-NNN-NNN	SERIES 42	S42-028PV/032PV
83035302	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KN-1-BC-80-S-4-S1-C-03-GBA-26-26-24	SERIES 90	S90-055PV
83035303	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KN-1-NN-80-S-4-S1-E-03-GBA-26-26-24	SERIES 90	S90-100PV
83035306	PUMP-VAR DISPL, CW 90PV075	90-R-075-DD-1-BC-80-S-3-C7-D-GB-GBA-35-35-24	SERIES 90	S90-075PV
83035307	PUMP-VAR-DISPL CW 90PV180	90R180-MA-5-DE-80-T-C-C8-J-C5-FAC-35-35-24	SERIES 90	S90-180PV
83035308	PUMP-VAR-DISPL CCW 90PV075	90L075-MA-5-NN-80-P-3-C7-D-C4-GBA-45-45-20	SERIES 90	S90-075PV
83035326	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-T1-DA-N-C-TB-CN-JN-N-A-15-NN-070-Z-24-NNN	H1-HP MOTORS	H1-110MB1
83035328	PUMP-VAR-DISPL CW 90PV130	90R130-KT-5-BC-80-L-4-F1-F-00-GBA-35-35-24	SERIES 90	S90-130PV
83035329	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MS-1-BC-80-L-3-F1-E-02-GBA-35-35-24	SERIES 90	S90-100PV
83035332	MOTOR-VAR-DISPL H1B060#	H1-B-060-A-F1-EA-N-B-TB-VN-AN-N-A-05-NN-012-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83035342	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-8-N-0-T2-W-00-EFT-00-00-E6	SERIES 90	S90-075MF
83035344	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-8-N-0-C7-W-00-EEA-00-00-G0	SERIES 90	S90-075MF
83035352	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-L2-BA-N-A-PA-VS-FS-S-N-NN-NN-040-N-00-NNN	H1-HP MOTORS	H1-160MB1
83035354	MOTOR-VAR-DISPL H1B250	H1-B-250-A-HE-HE-N-B-TB-VN-DN-N-N-NN-NN-050-Z-00-NNN	H1-HP MOTORS	H1-250MB1
83035362	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A5-C1-N-D3-G-G2-H4-K-35-K-35-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83035377	PUMP-VAR-DISPL CCW H1PV147	H1-P-147-L-C-A5-C1-N-D6-G-G2-H3-K-35-K-35-L-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83035379	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-1-AB-80-S-3-C7-D-03-GBA-32-32-26	SERIES 90	S90-075PV
83035390	PUMP-VAR-DISPL CCW H1PV089	H1-P-089-L-A-A5-C3-N-F5-H-F1-H6-L-25-L-25-D-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83035399	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-NN-80-S-3-C6-D-03-GBA-42-42-24	SERIES 90	S90-075PV
83035400	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-E1A6-03-B-D-G-2-F-N-A-34-34-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83035407	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-K1-K1-N-C-RA-DN-HN-N-A-10-NN-025-N-25-NNN	H1-HP MOTORS	H1-080MB1
83035431	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-E1A6-02-B-3-G-2-F-N-B-30-30-B-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83035434	MOTOR-VARIABLE DISPL SAE_K	K-V-45DS-A-RNF-F11-S-N-N-DF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83035435	PUMP-VAR-DISPL CW DDC20	DDC-20-A-R-RB-LSA-NN-A-N-5-AC-ACA0-D-07-21N-21N-NNN-NNN	DDC20/LDU20	OSK-020PV - DO NOT USE
83035439	PUMP-VAR-DISPL 42PV041 CW	42-R-41-C-ANN5-02-A-N-A-2-C-N-A-28-28-N-A-A-NNN-NNN	SERIES 42	S42-041PV/051PV
83035442	PUMP-VAR-DISPL 42PV041 CW	42-R-41-C-E1A6-02-B-3-G-2-F-N-B-30-30-B-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83035443	MOTOR-VAR-DISPL H1B110	H1-B-110-A-TA-D1-N-B-TA-VN-DN-N-A-10-NN-055-Z-30-NNN	H1-HP MOTORS	H1-110MB1
83035444	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-BC-80-S-C-C8-J-03-EFI-42-42-24	SERIES 90	S90-180PV
83035445	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A5-C1-N-D3-G-F3-NN-L-38-L-38-L-M-34-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83035447	MOTOR-VAR-DISPL H1MB060	H1-B-060-A-L2-BA-N-B-PA-CN-GN-N-N-NN-NN-028-N-00-NNN	H1-HP MOTORS	H1-060MB1
83035449	PUMP-VAR-DISPL CCW 90PV180	90L180-DD-5-NN-80-T-C-C8-J-GB-NNN-42-42-22	SERIES 90	S90-180PV
83035461	PUMP-VAR-DISPL CW 90PV180	90R180-KA-1-BC-80-S-C-F1-J-03-NNN-23-23-24	SERIES 90	S90-180PV
83035462	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-T1-D1-N-B-TB-VN-AN-N-A-10-NN-035-Z-27-NNN	H1-HP MOTORS	H1-080MB1

83035465	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KN-5-CD-80-R-4-S1-D-03-GBA-29-29-24	SERIES 90	S90-075PV
83035469	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A2-C3-N-E7-F-G5-H3-38-38-38-38-N-P-22-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83035488	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E2-AA-N-B-TB-CS-JS-P-A-10-NN-045-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83035498	PUMP-VAR-DISPL CCW 90PV250	90L250-KT-5-AB-80-T-4-F1-J-03-NNN-32-32-24	SERIES 90	S90-250PV
83035515	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-L2-BA-N-B-PA-CN-JN-N-N-NN-NN-016-N-00-NNN	H1-HP MOTORS	H1-080MB1
83035516	MOTOR-VAR-DISPL H1MB060	H1-B-060-A-L2-BA-N-B-PA-CN-GN-N-N-NN-NN-012-N-00-NNN	H1-HP MOTORS	H1-060MB1
83035517	MOTOR-FIX DISPL MMF044D	MMF-044-D-A-F-K-C-T-NCG-***	M35/44	044MF
83035526	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-NN-80-L-4-F1-H-03-GBA-29-29-24	SERIES 90	S90-130PV
83035533	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A3-C1-N-D3-G-G2-NN-L-42-L-42-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83035536	MOTOR-FIX DISPL MMF044D	MMF-044-D-A-N-K-C-T-NCG-***	M35/44	044MF
83035546	MOTOR-VARIABLE DISPL SAE_L	L-V-30DS-E-R4F-F13-T-N-X-CF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83035549	MOTOR-VARIABLE DISPL SAE_K	K-V-38CN-A-YNF-F07-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83035550	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-7-N-0-C7-W-00-EEA-00-00-F3	SERIES 90	S90-075MF
83035552	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E2-AA-N-B-TA-DS-JS-S-N-NN-NN-054-R-00-NNN	H1-HP MOTORS	H1-110MB1
83035571	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-C5-C1-N-D6-H-G1-H3-L-42-L-42-D-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83035572	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-E2-AA-N-B-TB-CN-LN-N-N-NN-NN-080-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83035576	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-C5-C1-N-F6-H-G9-H6-L-42-L-42-D-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83035578	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-A-T-B-J-AA-A-A-BEE-CB-A-GG-C-NNN-***	M46	M46-046PV
83035581	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A5-C3-N-D3-G-G3-H6-L-35-L-35-A-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83035582	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A5-C2-B-D3-H-G1-NN-L-28-L-28-F-M-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83035590	PUMP-VAR DISPL, CW 90PV075	90-R-075-KT-5-BC-80-P-3-S1-E-03-GBA-32-32-24	SERIES 90	S90-075PV
83035591	PUMP-VAR-DISPL CCW 90PV130	90L130-KN-1-BC-80-R-4-T4-F-03-GBA-35-35-24	SERIES 90	S90-130PV
83035592	PUMP-VAR-DISPL CCW H1PV147	H1-P-147-L-C-A3-C2-B-D3-G-G3-H6-L-38-L-38-A-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83035600	PUMP-VAR-DISPL CCW 90PV180	90L180-HF-5-NN-80-S-C-F1-H-04-NNN-40-40-24	SERIES 90	S90-180PV
83035614	PUMP-VAR-DISPL CW 90PV180	90R180-KP-2-NN-80-T-M-F1-H-03-FAC-35-35-24	SERIES 90	S90-180PV
83035615	PUMP-VAR DISPL, CCW H1PV250	H1-P-250-L-A-A3-C3-B-D6-C-G3-NN-L-23-L-23-W-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-210PV/250PV
83035632	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KT-1-NN-60-L-4-S1-D-03-GBA-26-14-26	SERIES 90	S90-075PV
83035635	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-NN-80-S-3-S1-E-04-GBA-35-35-24	SERIES 90	S90-100PV
83035636	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-1-NN-80-S-3-C8-K-04-NNN-35-35-24	SERIES 90	S90-250PV
83035639	MOTOR-VARIABLE DISPL SAE_K	K-V-45DN-A-RNF-F00-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83035645	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E1-AA-N-B-TB-CN-HN-N-A-05-NN-031-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83035653	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-T2-DA-N-B-TA-VN-AN-N-N-NN-NN-025-Z-18-NNN	H1-HP MOTORS	H1-080MB1
83035677	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-A-V-C-J-AA-B-A-A-A-BJJ-AB-D-CD-B-C-A-A-BJJ-AB-D-CD-A-NNN-***	M46	M46-046PT
83035681	PUMP-VAR-DISPL CCW 90PV180	90L180-KP-5-AB-80-T-M-F1-J-03-FAC-38-38-24	SERIES 90	S90-180PV
83035691	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-NN-80-L-3-C6-C-09-GBA-42-42-20	SERIES 90	S90-055PV
83035693	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-1-NN-80-L-3-C6-C-09-GBA-42-42-22	SERIES 90	S90-055PV

83035695	MOTOR-VAR-DISPL H1B250	H1-B-250-A-D2-MA-N-A-PB-VS-DS-S-A-30-NN-105-N-28-NNN	H1-HP MOTORS	H1-250MB1
83035697	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-T2-D2-N-B-TA-DN-HN-N-A-10-NN-018-Z-30-NNN	H1-HP MOTORS	H1-080MB1
83035698	PUMP-VAR-DISPL CCW 90PV100	90L100-MA-1-NN-80-L-3-F1-E-09-GBA-42-42-22	SERIES 90	S90-100PV
83035712	PUMP-VAR-DISPL CW 90PV100	90R100-KA-1-NN-80-S-3-S1-E-03-FAD-38-38-24	SERIES 90	S90-100PV
83035713	PUMP-VAR DISPL, CW 90PV075	90-R-075-KT-5-CD-80-P-3-S1-E-03-GBA-32-32-24	SERIES 90	S90-075PV
83035718	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A5-C2-N-D8-H-G1-H5-L-38-L-38-C-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83035724	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-L2-BA-N-B-PB-VS-DS-S-A-20-NN-062-N-00-NNN	H1-HP MOTORS	H1-160MB1
83035725	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A3-C2-N-D8-G-G2-H3-L-33-L-33-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83035726	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A3-C2-N-D7-G-G2-H4-L-33-L-33-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83035727	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A3-C2-N-D8-F-G4-H3-L-33-L-33-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83035733	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-7-N-0-F1-W-00-NNN-00-00-F0	SERIES 90	S90-100MF
83035734	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-E7-C2-N-D4-L-G2-H5-L-42-L-42-L-D-24-P4-NNN-G14	H1-HP PUMPS	H1-147PV/165PV
83035735	PUMP-VAR-DISPL CCW H1PV089	H1-P-089-L-A-E8-C2-N-D3-H-G1-NN-L-28-L-28-M-M-32-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83035736	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-E7-C2-N-F5-H-G1-H6-L-42-L-42-D-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83035740	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-E7-C3-N-D7-G-G3-H4-L-42-L-42-L-P-32-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83035745	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-A-T-B-J-AA-A-A-BHH-DA-A-HH-C-NNN-***	M46	M46-046PV
83035748	PUMP-VAR DISPL, CCW 90PV055	90-L-055-MA-1-NN-60-P-4-S1-C-03-GBA-29-29-24	SERIES 90	S90-055PV
83035752	PUMP-VAR-DISPL CCW H1PV165	H1-P-165-L-C-E7-C2-N-D4-G-F3-NN-L-42-L-42-L-C-32-PN-NNN-G25	H1-HP PUMPS	H1-147PV/165PV
83035768	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-E8-C2-B-D3-G-G3-H4-L-42-L-42-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83035770	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-E8-C2-B-D6-G-G3-H6-L-42-L-42-L-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83035773	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-E7-C2-N-D8-H-G1-H5-L-42-L-42-D-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83035777	PUMP-VAR-DISPL CW 90PV130	90R130-KP-1-NN-80-P-3-F1-H-03-GBA-42-42-24	SERIES 90	S90-130PV
83035784	PUMP-VAR-DISPL CCW 90PV100	90L100-MA-1-NN-80-L-3-F1-E-09-GBA-42-42-20	SERIES 90	S90-100PV
83035785	PUMP-VAR DISPL CW H1P068R	H1-P-068-R-A-B1-C2-B-D6-H-G1-H2-L-35-L-35-C-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83035786	PUMP-VAR DISPL, CW 90PV075	90-R-075-DD-1-AB-60-S-4-S1-D-GB-GBA-35-35-20	SERIES 90	S90-075PV
83035787	PUMP-VAR DISPL, CW 90PV075	90-R-075-DD-1-AB-60-S-4-S1-D-GB-GBA-35-35-24	SERIES 90	S90-075PV
83035788	PUMP-VAR DISPL CW H1P068R	H1-P-068-R-A-A5-C2-N-D6-H-F1-H3-L-35-L-35-C-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83035793	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-B8-C2-C-D8-H-G1-H1-L-35-L-35-F-P-28-P1-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83035799	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A3-C3-N-D3-H-G1-H3-L-42-L-42-M-M-28-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83035803	PUMP-VAR-DISPL CCW H1PV115	H1-P-115-L-B-E7-C2-N-D4-G-G3-H3-L-35-L-35-A-C-32-PN-NNN-G14	H1-HP PUMPS	H1-115PV/130PV
83035808	PUMP-VAR-DISPL CCW H1PV165	H1-P-165-L-C-E7-C2-N-D4-G-G3-NN-L-38-L-38-L-C-32-PN-NNN-G14	H1-HP PUMPS	H1-147PV/165PV
83035809	PUMP-VAR-DISPL CCW H1PV165	H1-P-165-L-C-E7-C2-N-D4-G-G3-H3-L-38-L-38-L-C-32-PN-NNN-G14	H1-HP PUMPS	H1-147PV/165PV
83035811	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-E8-C2-B-D3-G-G3-H6-L-42-L-42-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83035813	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A5-C2-N-D3-G-F3-NN-L-30-L-30-A-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83035814	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A5-C2-N-D3-H-G1-NN-L-30-L-30-F-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83035815	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-ANN3-03-B-D-B-2-F-N-B-23-23-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV

83035822	PUMP-VAR-DISPL CCW H1PV115	H1-P-115-L-B-E8-C2-B-D3-G-G3-H6-L-42-L-42-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83035823	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-E8-C2-B-D3-G-G3-H6-L-42-L-42-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83035828	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-E8-C2-N-D4-G-G3-NN-L-33-L-33-A-M-24-PN-NNN-G18	H1-HP PUMPS	H1-115PV/130PV
83035835	PUMP-VAR-DISPL CW 90PV075	90R075-KA-1-NN-80-S-4-C7-E-03-GBA-38-38-24	SERIES 90	S90-075PV
83035836	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-BC-80-S-4-C8-K-03-NNN-38-38-24	SERIES 90	S90-250PV
83035837	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-NN-80-S-4-C7-E-03-GBA-38-38-24	SERIES 90	S90-075PV
83035866	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-E8-C2-N-D6-H-G9-H2-L-38-L-20-M-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83035867	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-E8-C2-N-D6-H-G9-H2-L-38-L-38-M-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83035875	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-1-NN-60-P-3-S1-C-00-GBA-23-23-20	SERIES 90	S90-055PV
83035876	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-BC-80-S-4-S1-D-02-GBA-32-32-24	SERIES 90	S90-100PV
83035882	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-BC-80-S-4-C8-H-04-GBA-32-32-28	SERIES 90	S90-130PV
83035890	PUMP-VAR DISPL, CCW H1PV250	H1-P-250-L-A-A5-C2-N-D8-C-G2-H5-L-35-L-35-R-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-210PV/250PV
83035903	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-DE-80-R-3-C8-H-K2-GBA-36-36-30	SERIES 90	S90-130PV
83035907	MOTOR-VAR-DISPL H1B060	H1-B-060-A-LH-BA-E-B-PB-VS-AS-P-N-NN-NN-016-N-00-NNN	H1-HP MOTORS	H1-060MB1
83035916	PUMP-VAR DISPL, CCW H1PV250	H1-P-250-L-A-A5-C2-N-D8-C-G2-NN-L-35-L-35-R-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-210PV/250PV
83035923	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A5-C1-N-D6-G-G2-NN-L-38-L-38-A-L-18-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83035929	PUMP-VAR-DISPL CCW 90PV130	90L130-HF-5-AB-80-P-4-C8-H-03-GBA-26-26-30	SERIES 90	S90-130PV
83035932	PUMP-VAR-DISPL CCW 90PV100	90L100-MA-1-CD-80-S-3-D7-E-02-GBA-35-35-24	SERIES 90	S90-100PV
83035947	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HF-5-BC-80-R-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83035948	MOTOR-FIX DISPL MMF044D	MMF-044-D-A-S-Y-C-D-NNN-***	M35/44	O44MF
83035953	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A5-C2-N-D8-H-G3-H3-L-35-L-35-D-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83035956	PUMP-VAR-DISPL CCW 90PV075	90L075-DD-1-AB-60-S-4-C7-D-GB-FAC-42-42-24	SERIES 90	S90-075PV
83035962	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-S6-C3-N-D3-H-G1-H3-L-42-L-42-C-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83035966	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-S6-C3-N-D3-H-G1-H1-L-42-L-42-C-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83035972	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A3-C1-B-F4-H-G1-H6-L-38-L-38-D-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83035973	PUMP-VAR-DISPL CCW H1PV130	H1-P-130-L-B-A3-C1-B-D3-G-G3-H6-L-38-L-38-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83035974	PUMP-VAR-DISPL CCW H1PV130	H1-P-130-L-B-A3-C1-B-D3-G-G3-NN-L-38-L-38-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83035975	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A3-C1-B-D3-H-G1-NN-L-38-L-38-D-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83035978	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-E1B6-00-B-2-G-3-F-N-B-30-30-N-A-A-NNN-NNN	SERIES 42	S42-041PV/051PV
83035979	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-E1B6-00-B-2-G-3-F-N-V-30-30-N-A-A-NNN-NNN	SERIES 42	S42-041PV/051PV
83035997	PUMP-VAR-DISPL CCW H1PV165	H1-P-165-L-C-E8-C2-N-D4-G-G3-NN-L-33-L-33-L-M-32-PN-NNN-G18	H1-HP PUMPS	H1-147PV/165PV
83035998	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-E7-C2-N-G4-G-G3-P6-L-42-L-42-R-L-28-P5-NNN-G14	H1-HP PUMPS	H1-147PV/165PV
83035999	PUMP-VAR DISPL, CW H1PV210	H1-P-210-R-A-E8-C2-N-D6-C-G2-H6-L-38-L-20-R-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-210PV/250PV
83036000	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-E7-C1-N-D6-H-G1-NN-L-42-L-42-D-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83036001	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-E7-C1-N-F6-H-G9-H6-L-42-L-42-D-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83036003	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-S6-C2-N-D8-H-G9-H5-L-40-L-40-N-E-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV

83036004	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-S6-C2-N-D6-H-G1-H5-L-42-L-42-D-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83036009	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-C3-C2-C-F6-K-G9-H6-L-45-L-45-M-L-26-P2-NNN-D6F	H1-HP PUMPS	H1-089PV/100PV
83036016	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-C3-C2-C-D8-L-G2-H5-L-35-L-35-L-P-30-P2-NNN-D6F	H1-HP PUMPS	H1-115PV/130PV
83036017	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-C3-C2-C-D8-L-G2-S1-L-35-L-35-L-P-30-P2-NNN-D6F	H1-HP PUMPS	H1-115PV/130PV
83036021	PUMP-VAR DISPL, CW 90PV055	90-R-055-KT-1-AC-80-D-4-S1-L-03-GBA-42-42-20	SERIES 90	S90-055PV
83036022	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-S6-C3-C-G3-G-G3-NN-L-42-L-42-L-L-32-PN-C06-G14	H1-HP PUMPS	H1-115PV/130PV
83036026	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E1-AA-N-B-TB-DN-JN-N-N-NN-NN-044-R-00-NNN	H1-HP MOTORS	H1-080MB1
83036027	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E1-AA-N-B-TB-DN-GN-N-N-NN-NN-040-R-00-NNN	H1-HP MOTORS	H1-060MB1
83036028	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E1-AA-N-B-TB-DN-GN-N-N-NN-NN-036-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83036030	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-S6-C3-B-G3-G-G2-NN-L-45-L-45-L-L-32-PN-NNN-G14	H1-HP PUMPS	H1-115PV/130PV
83036031	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-BC-80-L-4-C7-E-03-GBA-26-26-24	SERIES 90	S90-100PV
83036034	PUMP-VAR-DISPL CCW H1PV115	H1-P-115-L-B-E8-C2-N-E8-G-G2-H3-L-45-L-45-A-L-24-PN-NNN-G21	H1-HP PUMPS	H1-115PV/130PV
83036035	PUMP-VAR-DISPL CCW H1PV115	H1-P-115-L-B-E8-C2-N-E8-G-G2-H5-L-45-L-45-A-L-24-PN-NNN-G21	H1-HP PUMPS	H1-115PV/130PV
83036041	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-L2-BA-N-A-PA-CN-JN-N-N-NN-NN-074-N-00-NNN	H1-HP MOTORS	H1-110MB1
83036044	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-HE-HE-N-A-TB-VN-AN-N-A-10-NN-020-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83036045	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-M1-CA-N-A-RA-VS-DS-P-A-20-NN-080-N-00-NNN	H1-HP MOTORS	H1-160MB1
83036046	MOTOR-VAR-DISPL H1B160	H1-B-160-A-TA-DA-N-A-TA-VN-DN-N-N-NN-NN-070-Z-30-NNN	H1-HP MOTORS	H1-160MB1
83036047	PUMP-VAR DISPL, CW 90PV075	90-R-075-DD-1-AB-60-L-4-S1-D-GB-GBA-35-35-24	SERIES 90	S90-075PV
83036048	MOTOR-VARIABLE REVERSING CARTRIDGE L	L-M-25CN-K-RF1-N18-S-N-N-BF-F18-NNB-FNN	LV / KV MOTORS	L/K-RDM
83036052	PUMP-VAR DISPL, CW 90PV055	90-R-055-KT-1-AC-80-D-3-S1-L-03-GBA-42-42-20	SERIES 90	S90-055PV
83036056	PUMP-VAR-DISPL CW 90PV075	90R075-HF-5-CD-80-L-3-S1-E-00-GBA-26-26-20	SERIES 90	S90-075PV
83036062	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-AB-60-P-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-075PV
83036063	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A5-C2-B-D8-H-G1-H3-K-25-K-25-C-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83036064	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A5-C2-B-F5-H-G1-H6-K-25-K-25-C-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83036066	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-E8-C2-B-D4-G-G3-NN-L-33-L-33-A-M-24-PN-NNN-G18	H1-HP PUMPS	H1-115PV/130PV
83036067	PUMP-VAR-DISPL CW 90PV130	90R130-SB-2-BC-80-R-3-C8-H-33-PEA-42-42-30	SERIES 90	S90-130PV
83036068	PUMP-VAR-DISPL CW 90PV130	90R130-SB-2-DE-80-R-3-C8-H-33-PEA-42-42-30	SERIES 90	S90-130PV
83036069	PUMP-VAR-DISPL CCW H1PV147	H1-P-147-L-C-E8-C2-N-D4-G-G3-NN-L-33-L-33-L-M-32-PN-NNN-G18	H1-HP PUMPS	H1-147PV/165PV
83036072	PUMP-VAR-DISPL 42PV028 CW	42-R-32-D-E2C8-02-B-D-B-3-H-N-V-25-25-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83036073	PUMP-VAR-DISPL 42PV028 CW	42-R-32-D-E2D8-02-B-D-B-3-H-N-V-25-25-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83036078	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A5-C2-B-E5-F-G4-H2-L-20-L-20-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83036081	MOTOR-FIX DISPL MMF035D	MMF-035-D-A-N-H-C-D-NNN-***	M35/44	035MF
83036083	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-BB-80-S-3-S1-E-03-GBA-26-26-24	SERIES 90	S90-100PV
83036098	PUMP-VAR-DISPL CCW 90PV180	90L180-KN-1-CD-80-T-M-F1-H-03-NNN-42-42-24	SERIES 90	S90-180PV
83036099	PUMP-VAR-DISPL CCW 90PV180	90L180-KN-1-AB-80-T-M-F1-H-03-NNN-35-35-24	SERIES 90	S90-180PV
83036105	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E1-AA-N-B-TB-VN-CN-N-A-05-NN-053-Z-00-NNN	H1-HP MOTORS	H1-080MB1

83036106	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E1-AA-N-B-TB-VN-DN-N-A-15-NN-055-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83036107	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-HE-HE-N-B-TA-VN-EN-N-A-20-NN-032-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83036108	MOTOR-VARIABLE DISPL SAE_L	L-V-25CN-A-YNF-F12-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83036109	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-HE-HE-N-B-TA-CN-AN-N-A-10-NN-012-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83036114	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-BC-60-L-4-S1-E-03-GBA-35-35-26	SERIES 90	S90-100PV
83036119	PUMP-TANDEM, VAR DISPL MPT044D	MPT-044-D-G-R-S-A-AA-B-A-A-A-BDD-DR-A-FF-B-C-A-A-BDD-DR-A-FF-1-NNN-*	M35/44	044PT
83036128	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A3-C2-N-D8-H-F1-H3-L-38-L-38-D-P-20-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83036130	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A3-C2-N-D8-G-G3-H3-L-42-L-42-L-P-20-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83036142	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A3-C2-N-D8-G-G3-H3-L-42-L-42-L-P-20-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83036150	MOTOR-VARIABLE CARTRIDGE K	K-C-45DN-E-RNF-F07-S-N-N-AF-F16-NNN-NNN	LV / KV MOTORS	L/K-MV
83036151	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-T1-D1-N-B-TB-VN-AN-N-A-05-NN-017-Z-17-NNN	H1-HP MOTORS	H1-060MB1
83036152	MOTOR-VARIABLE CARTRIDGE K	K-C-45DS-E-R1F-F08-S-N-N-CF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83036153	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-T1-D1-N-B-TB-VS-AS-S-A-05-NN-017-Z-17-NNN	H1-HP MOTORS	H1-060MB1
83036180	PUMP-VAR-DISPL CW 90PV100	90R100-MA-1-CD-80-S-3-D7-E-02-GBA-35-35-24	SERIES 90	S90-100PV
83036187	PUMP-VAR DISPL, CCW 90PV055	90-L-055-MA-1-CD-80-S-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83036188	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A2-C2-N-D6-F-G5-NN-L-38-L-38-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83036189	PUMP-VAR-DISPL CCW 90PV100	90L100-MA-1-NN-60-S-3-C7-E-03-GBA-38-38-24	SERIES 90	S90-100PV
83036190	PUMP-VAR-DISPL CW 90PV100	90R100-MA-1-NN-80-S-3-C7-E-05-GBA-42-42-24	SERIES 90	S90-100PV
83036191	MOTOR-VAR-DISPL H1MB060	H1-B-060-A-D2-MA-N-B-PB-VN-AN-N-N-NN-NN-023-N-30-NNN	H1-HP MOTORS	H1-060MB1
83036192	PUMP-VAR-DISPL CCW H1PV115	H1-P-115-L-B-A4-C1-N-D8-G-G2-H4-L-38-L-38-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83036193	MOTOR-VAR-DISPL H1MB060	H1-B-060-A-L1-BA-N-B-PB-CS-AS-S-A-05-NN-000-N-00-NNN	H1-HP MOTORS	H1-060MB1
83036196	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KT-2-AB-60-P-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83036197	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KT-2-CD-60-P-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83036201	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-A-D7-C1-B-E7-F-G6-H3-30-30-35-35-N-P-24-P3-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83036205	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-BC-80-R-4-S1-C-00-GBA-35-35-30	SERIES 90	S90-055PV
83036208	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HS-5-NN-80-R-4-S1-D-06-GBA-26-26-24	SERIES 90	S90-055PV
83036209	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HS-5-NN-80-R-4-S1-D-06-GBA-26-26-24	SERIES 90	S90-075PV
83036211	PUMP-VAR-DISPL CCW H1PV130	H1-P-130-L-B-B8-C3-D-D3-G-G2-H4-L-35-L-35-L-M-30-P1-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83036212	PUMP-VAR-DISPL CCW H1PV130	H1-P-130-L-B-B8-C3-D-D3-G-G3-H2-L-35-L-35-L-M-30-P1-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83036213	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-BB-60-L-3-C6-E-03-GBA-35-35-24	SERIES 90	S90-075PV
83036215	PUMP-VAR-DISPL CW 90PV130	90R130-KA-1-NN-80-S-3-T4-F-03-GDA-42-42-26	SERIES 90	S90-130PV
83036225	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-BB-80-S-3-C8-H-04-GBA-45-45-24	SERIES 90	S90-130PV
83036249	MOTOR-VAR-DISPL H1B250	H1-B-250-A-D2-M2-N-B-PA-VS-DS-S-A-20-NN-060-N-30-NNN	H1-HP MOTORS	H1-250MB1
83036250	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-B8-C2-C-D6-L-G2-H3-L-42-L-42-L-L-30-P2-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83036253	PUMP-VAR-DISPL CW 90PV100	90R100-HF-5-NN-80-R-4-G1-F-05-GBA-35-35-30	SERIES 90	S90-100PV
83036258	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-5-EG-80-T-3-C8-K-03-NNN-26-26-24	SERIES 90	S90-250PV

83036260	PUMP-VAR-DISPL CCW 90PV075	90L075-HK-5-NN-60-R-4-T2-D-03-GBA-35-35-20	SERIES 90	S90-075PV
83036261	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-A-A5-C2-N-D6-H-G9-NN-K-35-K-35-D-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83036274	PUMP-VAR DISPL, CCW H1PV250	H1-P-250-L-A-A2-C1-B-D8-C-G3-NN-K-42-K-42-R-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-210PV/250PV
83036278	MOTOR-FIX DISPL MMF035D	MMF-035-D-A-F-1-C-D-NNN-***	M35/44	035MF
83036280	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-M1-CA-N-A-RA-CS-JS-S-A-15-NN-000-N-00-NNN	H1-HP MOTORS	H1-110MB1
83036283	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KN-5-CD-80-R-4-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83036284	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KN-5-NN-80-R-4-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
83036295	PUMP-VAR-DISPL CCW 90PV100	90L100-HF-5-CD-80-S-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83036299	PUMP-VAR-DISPL CCW 90PV130	90L130-HF-5-CD-80-S-3-F1-H-03-GBA-42-42-24	SERIES 90	S90-130PV
83036301	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A5-C2-N-D3-G-G2-H3-L-42-L-42-A-M-26-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83036302	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HF-5-BC-80-S-4-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83036303	PUMP-VAR-DISPL CCW 90PV180	90L180-HF-5-NN-80-S-C-F1-J-03-NNN-42-42-24	SERIES 90	S90-180PV
83036312	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-K2-KA-N-B-RB-VS-DS-B-N-NN-NN-032-N-25-NNN	H1-HP MOTORS	H1-160MB1
83036332	MOTOR-FIX DISPL MMF044D	MMF-044-D-A-F-2-C-T-NNN-***	M35/44	044MF
83036342	PUMP-VAR-DISPL CCW 90PV250	90L250-HF-1-NN-80-T-4-F1-J-03-NNN-42-42-24	SERIES 90	S90-250PV
83036343	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HS-5-CD-80-S-3-S1-C-02-GBA-26-26-24	SERIES 90	S90-055PV
83036344	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HS-5-BC-80-S-4-S1-D-02-GBA-29-29-24	SERIES 90	S90-075PV
83036345	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HS-1-NN-80-S-4-S1-F-02-GBA-29-29-24	SERIES 90	S90-100PV
83036346	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-NN-80-S-3-C8-H-03-GBA-29-29-24	SERIES 90	S90-130PV
83036352	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A3-C2-N-D3-H-F1-H2-L-40-L-40-C-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83036355	PUMP-VAR DISPL CCW H1P053L	H1-P-053-L-A-A5-C3-N-E5-F-G4-NN-L-20-L-20-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83036357	MOTOR-VARIABLE DISPL SAE_L	L-V-25CS-E-RNF-F01-S-N-N-CF-F15-NNN-NNN	LV / KV MOTORS	L/K-MV
83036359	PUMP-VAR DISPL, CW 90PV075	90-R-075-HS-1-AB-80-S-3-C7-E-03-GBA-38-38-24	SERIES 90	S90-075PV
83036360	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-B8-C2-C-D6-G-G2-H3-L-42-L-42-L-L-30-P1-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83036370	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-E1A3-02-C-2-N-N-F-N-T-34-34-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83036380	PUMP-VAR DISPL MPV046C	MPV-046-C-B-A-G-S-B-S-BA-V-A-BRR-GB-B-AA-C-NNN-***	M46	M46-046PV
83036391	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-D1-M1-N-B-PA-DS-JS-S-A-15-NN-024-N-23-NNN	H1-HP MOTORS	H1-110MB1
83036401	PUMP-VAR-DISPL 42PV028 CW	42-R-28-G-E2D8-03-B-3-B-3-H-N-A-25-25-B-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83036402	PUMP-VAR-DISPL CW H1PV069	H1-P-069-R-A-A2-C2-B-D8-H-G1-H3-L-15-L-25-F-P-26-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83036403	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-D-G3AN-50-P-2-B-2-F-5-A-25-25-N-1-1-NNN-NNN	SERIES 42	S42-028PV/032PV
83036405	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-BC-80-R-3-S1-E-03-GBA-26-26-24	SERIES 90	S90-075PV
83036409	PUMP-VAR DISPL, CW 90PV055	90-R-055-KN-5-NN-80-S-3-C6-C-03-GBA-23-23-24	SERIES 90	S90-055PV
83036417	PUMP-VAR-DISPL CW 90PV250	90R250-KN-5-CD-80-T-4-F1-K-03-NNN-42-14-24	SERIES 90	S90-250PV
83036418	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KN-1-CD-80-R-4-C6-D-03-GBA-42-14-24	SERIES 90	S90-075PV
83036419	PUMP-VAR-DISPL CCW 90PV180	90L180-KN-5-CD-80-T-M-F1-H-03-FAC-42-14-24	SERIES 90	S90-180PV
83036422	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HF-1-CD-80-R-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV

83036425	PUMP-TANDEM, VAR DISPL MPT044D	MPT-044-D-G-R-S-J-AA-B-A-A-A-BFF-DL-A-FF-B-C-A-A-BFF-DL-A-FF-A-NNN-***	M35/44	044PT
83036426	PUMP-VAR-DISPL CCW H1PV130	H1-P-130-L-B-A5-C2-N-D8-G-G3-H2-L-35-L-35-A-P-30-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83036427	PUMP-VAR-DISPL CW DDC20	DDC-20-A-R-RB-RSA-NN-A-N-5-AC-ACA0-D-07-14A-14N-NNN-NNN	DDC20/LDU20	OSK-020PV - DO NOT USE
83036429	PUMP-VAR-DISPL CCW 90PV180	90L180-HF-5-DE-80-S-C-F1-J-03-NNN-32-32-28	SERIES 90	S90-180PV
83036432	MOTOR-VAR-DISPL H1MB060	H1-B-060-A-L1-BA-N-B-PB-CN-GN-N-N-NN-000-N-00-NNN	H1-HP MOTORS	H1-060MB1
83036433	PUMP-VAR-DISPL CCW H1PV130	H1-P-130-L-B-A4-C1-N-D8-G-G3-NN-L-30-L-30-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83036434	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A3-C1-N-D6-F-G5-H5-L-25-L-25-B-L-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83036435	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A3-C1-N-D6-F-G5-NN-L-25-L-25-B-L-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83036443	PUMP-TANDEM, VAR DISPL MPT035D	MPT-035-D-G-L-A-J-NN-C-A-A-A-BFF-DL-A-FF-C-C-A-A-BFF-DL-A-FF-A-NNN-***	M35/44	035PT
83036451	PUMP-VAR-DISPL CCW 90PV130	90L130-MA-1-NN-80-L-3-F1-F-03-GBA-35-35-20	SERIES 90	S90-130PV
83036452	PUMP-VAR DISPL, CCW H1PV210	H1-P-210-L-A-A5-C1-N-D8-C-G3-NN-L-35-L-35-R-P-26-PN-NNN-NNN	H1-HP PUMPS	H1-210PV/250PV
83036453	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-1-NN-60-R-4-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
83036455	MOTOR-VARIABLE DISPL SAE_K	K-V-38CN-E-R1F-F09-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83036456	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-1-BC-80-P-4-S1-C-00-GBA-21-21-24	SERIES 90	S90-055PV
83036457	PUMP-VAR-DISPL CW 90PV180	90R180-KA-1-CD-80-T-M-F1-H-03-NNN-14-14-24	SERIES 90	S90-180PV
83036463	PUMP-VAR-DISPL CCW 90PV100	90L100-KP-1-NN-80-S-3-S1-E-03-GBA-29-29-24	SERIES 90	S90-100PV
83036466	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-E2-AA-N-C-TB-VN-FN-N-A-30-NN-055-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83036468	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-P2-D2-N-B-TA-DS-KS-S-A-15-NN-022-Z-24-NNN	H1-HP MOTORS	H1-110MB1
83036472	MOTOR-VARIABLE DISPL SAE_K	K-V-38CN-A-R1F-F09-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83036474	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-L1-BA-N-B-PA-CS-HS-S-A-05-NN-000-N-00-NNN	H1-HP MOTORS	H1-080MB1
83036475	MOTOR-VAR-DISPL H1B110	H1-B-110-A-TA-DA-N-B-TB-VN-EN-N-A-15-NN-063-Z-21-NNN	H1-HP MOTORS	H1-110MB1
83036476	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E1-AA-N-B-TA-VN-AN-N-A-05-NN-031-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83036478	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-M2-CA-N-B-RB-VS-DS-B-N-NN-032-N-00-NNN	H1-HP MOTORS	H1-160MB1
83036483	PUMP-VAR-DISPL CCW 90PV100	90L100-KT-1-CD-80-R-3-C6-F-03-GBA-42-42-24	SERIES 90	S90-100PV
83036484	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-K1-K1-N-B-RB-VN-DN-N-A-30-NN-040-N-25-NNN	H1-HP MOTORS	H1-160MB1
83036485	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-K1-K1-N-B-RB-VS-DS-S-N-NN-040-N-25-NNN	H1-HP MOTORS	H1-160MB1
83036487	PUMP-VAR-DISPL CCW 90PV180	90L180-FH-5-NN-80-S-7-C8-J-B2-FAC-26-26-24	SERIES 90	S90-180PV
83036499	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A7-C3-C-D8-K-F1-H3-K-42-K-42-C-P-26-P2-NNN-D3E	H1-MP PUMPS	H1-060PV/068PV
83036501	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A5-C2-N-D6-G-G2-H6-L-42-L-42-L-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83036502	PUMP-VAR-DISPL CW H1PV069	H1-P-069-R-A-A5-C2-N-D6-H-G1-NN-L-35-L-35-C-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83036503	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-B8-C2-C-F6-H-G1-H6-L-42-L-42-M-L-30-P1-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83036504	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A2-C1-B-F1-F-G5-H2-K-35-K-35-B-L-24-PN-NNN-E01	H1-MP PUMPS	H1-045PV/053PV
83036510	MOTOR-VAR-DISPL H1B160	H1-B-160-A-TA-DA-N-B-TA-VN-EN-N-B-40-NN-080-Z-21-NNN	H1-HP MOTORS	H1-160MB1
83036516	PUMP-VAR-DISPL CW 90PV075	90R075-LT-5-BB-60-D-3-S1-L-C6-GBA-42-42-22	SERIES 90	S90-075PV
83036518	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-T1-D1-N-A-TA-DS-KS-S-A-10-NN-050-Z-24-NNN	H1-HP MOTORS	H1-110MB1
83036520	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-M2-CA-N-B-RB-VS-KS-B-N-NN-032-N-00-NNN	H1-HP MOTORS	H1-160MB1

83036521	PUMP-VAR-DISPL CW H1PV069	H1-P-069-R-A-A3-C3-N-D6-H-G1-NN-K-42-K-42-C-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83036522	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-NN-80-S-4-S1-E-03-GBA-23-23-24	SERIES 90	S90-075PV
83036523	PUMP-VAR-DISPL CCW 90PV130	90L130-HF-1-BC-80-R-3-F1-H-03-GBA-42-42-24	SERIES 90	S90-130PV
83036524	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E1-AA-N-B-TA-CN-AN-N-N-NN-NN-030-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83036525	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E1-AA-N-C-TA-CS-GS-B-A-05-NN-030-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83036529	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-5-CD-80-R-4-S1-D-03-GBA-29-29-24	SERIES 90	S90-075PV
83036549	PUMP-VAR-DISPL CCW H1PV165	H1-P-165-L-C-E7-C2-N-D4-G-G3-NN-L-38-L-38-A-C-32-PN-NNN-G25	H1-HP PUMPS	H1-147PV/165PV
83036552	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-HF-HF-N-C-TB-CN-JN-N-A-05-NN-050-Q-00-NNN	H1-HP MOTORS	H1-080MB1
83036554	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-G-S-B-J-BA-J-A-BRR-DA-A-HH-C-NNR-***	M46	M46-046PV
83036556	PUMP-VAR-DISPL CW H1PV069	H1-P-069-R-A-A2-C2-B-D8-K-G1-H3-L-15-L-25-F-P-20-P4-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83036559	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-A-V-C-S-AA-B-B-V-A-BBB-BA-A-HH-B-D-V-A-BBB-CE-A-HH-A-NNN-*	M46	M46-046PT
83036560	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-H-S-B-S-HB-A-A-BFF-HA-A-HC-3-NNN-***	M46	M46-046PV
83036561	PUMP-VAR DISPL, CCW 90PV055	90-L-055-MA-1-BC-80-R-3-S1-C-03-GBA-20-20-24	SERIES 90	S90-055PV
83036562	PUMP-VAR DISPL, CW 90PV075	90-R-075-HF-1-CD-80-P-3-S1-D-03-GBA-14-14-24	SERIES 90	S90-075PV
83036567	PUMP-VAR-DISPL CCW 90PV075	90L075-MA-1-NN-80-L-3-C7-D-09-GBA-42-42-22	SERIES 90	S90-075PV
83036568	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-K2-K2-N-B-RB-DN-JN-N-A-15-NN-026-N-30-NNN	H1-HP MOTORS	H1-110MB1
83036571	MOTOR-VAR-DISPL H1MB060	H1-B-060-A-D2-M2-N-A-PA-VN-AN-N-A-05-NN-025-N-25-NNN	H1-HP MOTORS	H1-060MB1
83036572	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A5-C3-N-F3-F-G4-NN-K-35-K-35-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83036577	PUMP-VAR DISPL, CW H1PV210	H1-P-210-R-A-A2-C1-N-D8-C-G3-NN-L-40-L-40-R-P-28-PN-NNN-NNN	H1-HP PUMPS	H1-210PV/250PV
83036579	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E1-AA-N-B-TA-DN-GN-N-A-10-NN-000-R-00-NNN	H1-HP MOTORS	H1-060MB1
83036585	PUMP-VAR DISPL, CW 90PV055	90-R-055-HF-5-NN-80-S-3-C6-C-03-GBA-35-35-22	SERIES 90	S90-055PV
83036603	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-ANAB-03-C-3-A-2-H-N-N-30-30-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83036620	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A5-C3-B-D6-G-G3-H6-L-42-L-42-L-L-28-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83036639	PUMP-VAR DISPL, CW 90PV055	90-R-055-KT-1-BC-80-D-3-S1-L-03-GBA-42-42-20	SERIES 90	S90-055PV
83036641	PUMP-VAR-DISPL CW 90PV250	90R250-KA-1-NN-80-T-4-F1-J-03-NNN-26-26-24	SERIES 90	S90-250PV
83036644	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-D-E1A6-03-C-2-A-2-F-N-B-17-17-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83036649	PUMP-VAR-DISPL CCW H1PV115	H1-P-115-L-B-A5-C3-B-D6-G-G3-H6-L-42-L-42-L-L-28-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83036651	PUMP-VAR-DISPL CW 90PV130	90R130-HF-1-CD-80-R-3-C8-F-03-GBA-32-32-26	SERIES 90	S90-130PV
83036652	PUMP-VAR-DISPL CW 90PV250	90R250-KA-1-BC-80-T-4-F1-J-03-NNN-26-26-24	SERIES 90	S90-250PV
83036653	PUMP-VAR-DISPL 42PV028 CW	42-R-32-C-E2D8-00-A-N-A-2-H-N-B-19-19-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83036658	PUMP-VAR-DISPL 42PV028 CW	42-R-32-D-E2D8-00-A-N-A-2-H-N-B-19-19-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83036660	PUMP-VAR-DISPL 42PV028 CW	42-R-32-D-E2D8-00-A-N-A-2-H-N-B-19-19-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83036661	PUMP-VAR-DISPL CCW 90PV075	90L075-HF-5-NN-80-S-4-C6-E-03-GBA-42-42-24	SERIES 90	S90-075PV
83036662	PUMP-VAR-DISPL 42PV028 CW	42-R-32-D-E2D8-00-A-N-A-2-H-N-B-19-19-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83036663	PUMP-VAR-DISPL CCW 90PV100	90L100-HF-5-NN-80-S-4-C6-F-03-GBA-17-35-24	SERIES 90	S90-100PV
83036664	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E2-AA-N-A-TA-VN-DN-N-N-NN-NN-030-Z-00-NNN	H1-HP MOTORS	H1-110MB1

83036669	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E2-AA-N-B-TA-VN-DN-N-A-10-NN-030-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83036680	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-CD-80-L-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
83036681	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-H-S-A-J-BC-V-A-BRR-DA-A-HH-A-NNN-***	M46	M46-046PV
83036682	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-ANA3-03-C-3-A-2-H-N-N-30-30-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83036683	PUMP-VAR DISPL, CW 90PV100	90-R-100-KN-1-BC-80-L-3-F1-E-03-GBA-14-14-20	SERIES 90	S90-100PV
83036684	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A2-C2-B-D4-G-G2-H6-L-45-L-42-L-M-32-PN-NNN-G21	H1-HP PUMPS	H1-147PV/165PV
83036685	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-1-NN-80-R-3-S1-C-03-FAD-35-35-24	SERIES 90	S90-055PV
83036707	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-H-S-B-M-HB-A-A-BGG-HA-A-HA-3-NNN-***	M46	M46-046PV
83036710	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-G3AN-52-P-D-C-2-H-1-B-30-30-N-0-0-NNN-NNN	SERIES 42	S42-028PV/032PV
83036711	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-G3AN-52-P-D-C-2-H-1-B-30-30-N-0-0-NNN-NNN	SERIES 42	S42-028PV/032PV
83036712	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A5-C1-N-D6-H-F1-H2-L-42-L-42-C-L-20-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83036724	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HF-1-BC-80-R-4-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83036725	MOTOR-VAR-DISPL H1B080	H1-B-080-A-TA-DA-N-B-TA-DN-HN-N-N-NN-NN-032-Z-16-NNN	H1-HP MOTORS	H1-080MB1
83036734	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A3-C3-N-E6-J-G5-H3-L-40-L-40-B-L-24-P4-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83036736	PUMP-VAR-DISPL 42PV041 CW	42-R-41-C-E2C8-00-B-3-G-2-F-N-A-28-28-B-A-A-NNN-NNN	SERIES 42	S42-041PV/051PV
83036737	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-E2C8-00-B-3-G-2-F-N-B-28-28-B-A-A-NNN-NNN	SERIES 42	S42-041PV/051PV
83036738	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A7-C2-C-D8-J-G1-NN-L-38-L-38-B-P-26-P2-NNN-D3F	H1-MP PUMPS	H1-045PV/053PV
83036739	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A2-C3-B-E7-F-G5-T2-28-28-28-28-M-P-20-P3-NNN-S01	H1-MP PUMPS	H1-045PT/053PT
83036740	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A3-C3-N-D6-J-G5-H3-L-40-L-40-B-L-24-P4-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83036748	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KT-1-AB-80-R-3-S1-C-03-GBA-38-38-24	SERIES 90	S90-055PV
83036750	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MA-1-NN-60-L-4-S1-E-03-GBA-32-32-24	SERIES 90	S90-100PV
83036751	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KT-1-BC-80-R-3-S1-C-03-GBA-38-38-24	SERIES 90	S90-055PV
83036752	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KT-1-CD-80-R-3-S1-C-03-GBA-38-38-24	SERIES 90	S90-055PV
83036753	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KT-1-BC-80-R-3-F1-E-03-GBA-38-38-24	SERIES 90	S90-100PV
83036754	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-1-CD-60-P-3-S1-C-03-GBA-35-35-20	SERIES 90	S90-055PV
83036756	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-BC-60-R-3-S1-D-03-GBA-40-40-30	SERIES 90	S90-075PV
83036758	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HS-5-BC-80-S-4-S1-C-03-GBA-26-26-24	SERIES 90	S90-055PV
83036759	MOTOR-VAR-DISPL H1B080	H1-B-080-A-TA-DA-N-A-TB-DN-JN-N-A-10-NN-028-Z-18-NNN	H1-HP MOTORS	H1-080MB1
83036763	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A5-C2-B-D8-H-G9-H5-L-33-L-15-C-P-28-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83036764	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A5-C2-B-D8-F-G5-H5-L-35-L-15-B-P-28-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83036771	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-BC-80-S-4-S1-E-02-GBA-40-40-24	SERIES 90	S90-100PV
83036776	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E1-AA-N-B-TB-CN-HN-N-N-NN-NN-016-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83036777	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E1-AA-N-B-TB-CN-HN-N-A-05-NN-016-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83036778	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-L1-BA-N-B-PB-CN-HN-N-A-05-NN-016-N-00-NNN	H1-HP MOTORS	H1-080MB1
83036784	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E2-AA-N-B-TA-VS-AS-P-A-05-NN-015-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83036793	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-CD-60-S-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV

83036794	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-N-A3-C1-N-E7-F-G1-T3-35-35-35-35-M-P-24-PN-NNN-S01	H1-MP PUMPS	H1-045PT/053PT
83036795	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-K2-KA-N-A-RB-DN-KN-N-A-30-NN-080-N-21-NNN	H1-HP MOTORS	H1-160MB1
83036801	PUMP-VAR-DISPL 42PV041 CCW	42-L-41-D-E1A5-02-D-N-F-2-G-N-B-38-38-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83036804	PUMP-VAR-DISPL CCW H1PV069	H1-P-069-L-A-A8-C2-C-D8-H-G1-NN-L-38-L-38-N-E-28-P1-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83036806	PUMP-VAR-DISPL 42PV041 CW	42-R-41-C-ANNB-03-A-N-A-3-F-N-N-34-34-N-A-A-NNN-NNN	SERIES 42	S42-041PV/051PV
83036808	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-AB-80-P-3-C6-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83036814	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-CD-80-D-3-C7-L-03-GBA-35-35-24	SERIES 90	S90-075PV
83036815	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-BC-80-D-3-S1-L-03-GBA-35-35-24	SERIES 90	S90-075PV
83036823	PUMP-VAR DISPL MPV046C	MPV-046-C-B-A-B-S-B-B-AA-A-A-BJJ-AB-U-AA-A-NNN-***	M46	M46-046PV
83036855	PUMP-VAR-DISPL CCW H1PV147	H1-P-147-L-C-A4-C1-N-D3-G-G3-H2-L-28-L-28-A-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83036857	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-ANNB-02-C-3-A-3-H-N-B-21-21-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83036858	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-H-S-B-B-BA-A-A-BFF-CB-A-ZB-3-NNN-***	M46	M46-046PV
83036865	PUMP-VAR DISPL, CW 90PV075	90-R-075-KN-1-NN-80-S-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83036867	MOTOR-VAR-DISPL H1B160	H1-B-160-A-TA-DA-N-B-TB-VN-DN-N-A-20-NN-092-Z-30-NNN	H1-HP MOTORS	H1-160MB1
83036868	PUMP-VAR-DISPL 42PV041 CW	42-R-41-C-E1A4-02-A-N-A-3-H-N-A-34-34-N-A-A-NNN-NNN	SERIES 42	S42-041PV/051PV
83036882	PUMP-VAR-DISPL CW 90PV075	90R075-KP-1-BC-60-D-4-S1-C-03-GBA-38-38-24	SERIES 90	S90-075PV
83036885	PUMP-VAR-DISPL CW 90PV075	90R075-KP-1-CD-60-D-4-T2-C-03-GBA-38-38-24	SERIES 90	S90-075PV
83036890	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-G3AN-52-P-D-C-2-H-1-B-30-30-N-1-1-NNN-NNN	SERIES 42	S42-028PV/032PV
83036891	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-G3AN-52-P-D-C-2-H-1-B-30-30-N-1-1-NNN-NNN	SERIES 42	S42-028PV/032PV
83036900	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A5-C2-B-D3-G-G2-H5-L-35-L-35-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83036907	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-CD-80-L-3-C8-F-03-GBA-42-42-28	SERIES 90	S90-130PV
83036916	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-E2-AA-N-B-TB-CS-LS-S-B-20-NN-065-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83036921	MOTOR-FIX DISPL MMF044D	MMF-044-D-A-D-Y-C-D-NNN-***	M35/44	044MF
83036925	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-T2-DA-N-B-TB-VS-DS-S-A-15-NN-044-Z-28-NNN	H1-HP MOTORS	H1-110MB1
83036926	PUMP-VAR DISPL, CW 90PV055	90-R-055-MB-1-NN-80-P-3-C6-C-03-FAD-35-35-24	SERIES 90	S90-055PV
83036927	PUMP-VAR DISPL, CW 90PV075	90-R-075-DD-1-BC-80-S-4-C6-D-GB-GBA-35-35-24	SERIES 90	S90-075PV
83036928	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-AB-80-P-3-S1-C-03-GBA-20-20-24	SERIES 90	S90-055PV
83036929	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-HE-HE-N-A-TB-DN-KN-N-N-NN-NN-080-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83036932	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-B8-C2-C-F4-H-F1-H6-L-42-L-42-F-M-26-P1-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83036936	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HF-2-BC-80-S-4-S1-C-00-GBA-32-32-20	SERIES 90	S90-055PV
83036943	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KN-1-NN-60-P-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83036947	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A4-C2-N-F4-H-G9-H6-L-35-L-35-M-M-26-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83036960	MOTOR-VAR-DISPL H1B250	H1-B-250-A-NB-NT-N-N-TB-VN-DN-N-A-15-NN-050-Z-00-NNN	H1-HP MOTORS	H1-250MB1
83036967	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-2-NN-80-S-3-C6-D-03-GBA-42-42-24	SERIES 90	S90-075PV
83036968	PUMP-VAR-DISPL CW 90PV130	90R130-KT-1-CD-80-D-3-F1-L-00-GBA-38-38-24	SERIES 90	S90-130PV
83036971	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-BC-80-P-4-C7-E-03-GBA-23-23-20	SERIES 90	S90-075PV

83036972	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-E2-AA-N-B-TA-CS-LS-S-N-NN-NN-050-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83036975	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-ANNB-02-C-3-A-3-H-N-A-21-21-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83036978	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E1-AA-N-A-TB-VN-EN-N-N-NN-NN-050-R-00-NNN	H1-HP MOTORS	H1-110MB1
83036979	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MA-1-AB-80-P-3-C7-E-03-FAD-42-42-24	SERIES 90	S90-100PV
83036980	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A5-C2-N-D8-G-G3-H6-L-35-L-35-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83036981	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A5-C2-B-D8-F-G5-H2-L-20-L-20-B-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83036988	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-T2-D2-N-B-TB-VN-DN-N-A-20-NN-090-Z-27-NNN	H1-HP MOTORS	H1-160MB1
83036990	PUMP-VAR-DISPL CCW H1PV130	H1-P-130-L-B-A3-C1-N-D8-G-G3-NN-L-30-L-30-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83037009	PUMP-VAR DISPL, CW 90PV100	90-R-100-HF-1-NN-80-R-4-S1-F-03-GBA-32-32-24	SERIES 90	S90-100PV
83037012	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-1-NN-80-P-4-S1-C-GB-GBA-42-42-24	SERIES 90	S90-055PV
83037013	PUMP-VAR-DISPL CCW DDC20	DDC-20-A-L-LB-RSA-NN-A-D-N-BC-ABN9-D-07-14A-14N-NNN-NNN	DDC20/LDU20	OSK-020PV - DO NOT USE
83037029	PUMP-VAR-DISPL CW 90PV130	90R130-MB-1-BC-80-S-3-F1-H-C5-GBA-26-26-30	SERIES 90	S90-130PV
83037030	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-T2-DA-N-A-TB-VN-AN-N-N-NN-NN-022-Z-30-NNN	H1-HP MOTORS	H1-060MB1
83037031	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-T2-DA-N-A-TB-VS-AS-B-N-NN-NN-022-Z-30-NNN	H1-HP MOTORS	H1-060MB1
83037045	PUMP-VAR-DISPL CW 90PV130	90R130-KP-1-AB-80-P-3-F1-F-00-GBA-42-42-24	SERIES 90	S90-130PV
83037046	MOTOR-VAR-DISPL H1B110	H1-B-110-A-TA-D1-N-A-TB-VS-ES-S-A-10-NN-060-Z-20-NNN	H1-HP MOTORS	H1-110MB1
83037048	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E2-AA-N-B-TB-DN-JN-N-N-NN-NN-055-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83037049	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-7-N-0-F1-W-00-EAA-00-00-F0	SERIES 90	S90-100MF
83037051	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-HE-HE-N-B-TB-VN-EN-N-A-10-NN-022-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83037070	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A4-C3-B-D1-F-G5-T2-35-35-35-35-M-P-24-P3-NNN-S01	H1-MP PUMPS	H1-045PT/053PT
83037072	PUMP-VAR-DISPL CCW 90PV180	90L180-HF-1-NN-80-T-C-C8-H-03-NNN-35-35-24	SERIES 90	S90-180PV
83037074	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-HE-HE-N-A-TB-VS-AS-P-N-NN-NN-016-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83037075	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A8-C2-C-F5-H-G1-H6-L-38-L-38-M-P-26-P1-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83037078	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HS-1-BC-80-S-4-S1-E-03-GBA-26-26-24	SERIES 90	S90-100PV
83037087	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-A-V-C-S-AA-B-B-V-A-BBB-CE-A-HH-B-D-V-A-BBB-CE-A-HH-A-NNN-*	M46	M46-046PT
83037089	PUMP-VAR DISPL, CCW H1PV210	H1-P-210-L-A-A3-C2-N-D8-C-G2-NN-L-42-L-42-R-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-210PV/250PV
83037099	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A5-C2-B-D3-G-G3-NN-L-42-L-42-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83037108	PUMP-VAR-DISPL CW 90PV100	90R100-KP-1-NN-80-D-4-S1-L-03-GBA-29-14-34	SERIES 90	S90-100PV
83037109	PUMP-VAR DISPL, CW H1PV210	H1-P-210-R-A-A5-C2-N-D8-C-G2-H5-L-42-L-42-W-P-26-PN-NNN-NNN	H1-HP PUMPS	H1-210PV/250PV
83037131	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A5-C2-N-E5-F-G1-H3-L-35-L-35-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83037132	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A5-C2-N-E5-F-G4-NN-L-35-L-35-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83037133	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A3-C1-B-F6-H-G1-H6-L-33-L-33-M-L-26-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83037136	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-CD-80-R-3-F1-H-03-GBA-29-29-24	SERIES 90	S90-130PV
83037137	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-NN-80-R-3-F1-H-03-GBA-35-35-24	SERIES 90	S90-130PV
83037140	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-C-ANNA-03-B-2-B-3-F-N-N-36-36-B-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83037141	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-D-ANNA-03-B-2-B-3-F-N-B-36-36-B-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV

83037143	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A3-C1-B-F6-H-G9-H6-L-33-L-33-M-L-26-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83037148	PUMP-VAR-DISPL CW 90PV075	90R075-MA-1-CD-60-S-3-C7-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83037156	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-B-T-B-B-BA-A-A-BGG-CE-A-GG-3-NNN-***	M46	M46-046PV
83037160	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-AB-80-L-3-C7-F-03-GBA-35-35-28	SERIES 90	S90-100PV
83037161	MOTOR-VAR-DISPL H1B250	H1-B-250-A-T2-DA-N-B-TA-VS-FS-S-A-20-NN-050-Z-28-NNN	H1-HP MOTORS	H1-250MB1
83037163	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A3-C3-N-F7-F-G5-H3-20-20-20-20-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83037170	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A5-C2-B-D3-G-G3-NN-L-45-L-45-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83037201	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-NN-80-L-4-F1-F-03-GBA-20-20-20	SERIES 90	S90-130PV
83037206	MOTOR-VARIABLE CARTRIDGE K	K-C-45DN-E-R3F-F12-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83037208	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A9-C1-B-F1-F-G5-H2-K-35-K-18-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83037211	PUMP-VAR-DISPL CW 90PV100	90R100-KA-1-NN-80-R-3-C7-E-03-GBA-35-35-28	SERIES 90	S90-100PV
83037214	PUMP-VAR-DISPL CW 90PV130	90R130-HF-5-AB-80-L-3-F1-H-03-GBA-42-42-28	SERIES 90	S90-130PV
83037215	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-7-N-0-F1-W-00-EEA-00-00-F0	SERIES 90	S90-100MF
83037243	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KT-1-NN-80-L-3-S1-E-03-GBA-17-32-24	SERIES 90	S90-100PV
83037244	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A2-C1-B-E9-F-G5-H2-K-35-K-35-B-P-24-PN-NNN-E01	H1-MP PUMPS	H1-045PV/053PV
83037245	PUMP-VAR-DISPL CW DDC20	DDC-20-A-R-RB-RSA-NN-A-D-N-BC-ABN9-D-07-14N-14N-NNN-NNN	DDC20/LDU20	OSK-020PV - DO NOT USE
83037251	PUMP-VAR DISPL, CW H1PV210	H1-P-210-R-A-A5-C2-B-D8-C-G2-H2-L-38-L-38-R-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-210PV/250PV
83037255	PUMP-VAR-DISPL CW DDC20	DDC-20-A-R-RB-RSA-NN-A-D-N-BA-ABN9-D-07-21N-21N-NNN-NNN	DDC20/LDU20	OSK-020PV - DO NOT USE
83037257	PUMP-VAR-DISPL CW 90PV130	90R130-KN-1-NN-80-L-4-C8-H-03-GBA-32-32-24-F001	SERIES 90	S90-130PV
83037258	PUMP-VAR-DISPL CW 90PV100	90R100-HF-5-CD-60-P-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83037276	MOTOR-VAR-DISPL H1B110	H1-B-110-A-TA-DA-N-B-TB-DS-JS-P-A-15-NN-074-Z-25-NNN	H1-HP MOTORS	H1-110MB1
83037301	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E1-AA-N-B-TB-VS-AS-B-N-NN-NN-045-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83037302	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E1-AA-N-B-TB-VS-ES-B-N-NN-NN-050-R-00-NNN	H1-HP MOTORS	H1-110MB1
83037303	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-E1-AA-N-B-TB-VS-ES-S-N-NN-NN-060-S-00-NNN	H1-HP MOTORS	H1-160MB1
83037304	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-5-CD-80-R-3-C7-D-03-GBA-35-35-30	SERIES 90	S90-075PV
83037306	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-A-V-C-B-AA-B-B-A-A-BFF-BA-A-HH-B-D-A-A-BFF-BA-A-HH-B-NNN-*	M46	M46-046PT
83037309	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A5-C1-N-D3-H-G1-H2-L-35-L-35-D-M-28-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83037312	MOTOR-VAR-DISPL H1B060	H1-B-060-A-TA-DA-N-B-TB-VN-AN-N-A-05-NN-015-Z-18-NNN	H1-HP MOTORS	H1-060MB1
83037317	PUMP-VAR-DISPL CCW H1PV165	H1-P-165-L-C-A5-C2-N-D8-G-G3-NN-L-42-L-42-N-E-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83037318	MOTOR-VAR-DISPL H1B250	H1-B-250-A-D2-MA-N-B-PB-VS-DS-S-A-30-NN-050-N-26-NNN	H1-HP MOTORS	H1-250MB1
83037327	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-T1-D1-N-B-TB-VN-AN-N-A-10-NN-019-Z-25-NNN	H1-HP MOTORS	H1-080MB1
83037328	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-A-Z-C-B-AA-B-B-A-A-BJJ-CE-A-HH-B-D-A-A-BJJ-CE-A-JJ-C-NNN-***	M46	M46-046PT
83037329	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E2-AA-N-B-TA-VN-EN-N-N-NN-NN-050-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83037331	MOTOR-VAR-DISPL H1B080	H1-B-080-A-TA-DA-N-B-TB-VS-CS-S-N-NN-NN-024-Z-21-NNN	H1-HP MOTORS	H1-080MB1
83037339	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HF-2-BC-80-S-4-S1-C-03-GBA-32-32-20	SERIES 90	S90-055PV
83037340	PUMP-VAR DISPL CCW H1P068L	H1-P-068-L-A-B1-C2-B-D6-H-G1-NN-L-28-L-28-C-L-20-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV

83037350	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-L-S-A-M-BC-X-A-BJJ-DB-A-HH-A-NNR-***	M46	M46-046PV
83037368	PUMP-VAR DISPL, CW 90PV055	90-R-055-M8-1-AD-80-P-3-S1-C-03-GBA-32-32-24	SERIES 90	S90-055PV
83037371	PUMP-VAR-DISPL CCW 90PV100	90L100-CA-5-CD-80-P-7-S1-F-00-GCA-35-35-28	SERIES 90	S90-100PV
83037410	PUMP-VAR-DISPL CW 90PV130	90R130-HF-5-CD-80-S-4-F1-F-03-GBA-35-35-24	SERIES 90	S90-130PV
83037416	PUMP-VAR-DISPL CCW H1PV089	H1-P-089-L-A-A2-C1-N-D8-H-G1-NN-L-42-L-42-N-E-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83037418	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-D-S-B-B-HA-A-A-BFF-HB-A-HA-B-NNN-***	M46	M46-046PV
83037419	PUMP-VAR-DISPL CCW 90PV075	90L075-HF-5-CD-80-S-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-075PV
83037420	PUMP-VAR-DISPL CCW 90PV075	90L075-HF-5-BC-80-S-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-075PV
83037437	MOTOR-VARIABLE REVERSING CARTRIDGE L	L-M-25CS-F-EF2-N18-S-N-N-BF-F18-NNB-NNN	LV / KV MOTORS	L/K-RDM
83037513	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MA-1-CD-80-L-3-C6-F-03-GBA-35-35-24	SERIES 90	S90-100PV
83037592	PUMP-VAR-DISPL CCW 90PV100	90L100-FH-5-CD-80-P-7-C7-F-B1-GCA-35-35-28	SERIES 90	S90-100PV
83037593	PUMP-VAR DISPL, CW 90PV055	90-R-055-KN-5-AB-80-S-3-C6-C-03-GBA-30-30-24	SERIES 90	S90-055PV
83037600	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A2-C2-N-D8-H-G1-H3-K-45-K-45-M-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83037601	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A2-C2-N-F5-H-F1-H6-K-45-K-45-N-E-34-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83037675	PUMP-VAR DISPL, CCW H1PV250	H1-P-250-L-A-A3-C3-N-D8-C-F8-NN-L-28-L-28-W-P-30-PN-NNN-NNN	H1-HP PUMPS	H1-210PV/250PV
83037681	MOTOR-FIXED DISPL MMF025C	MMF-025-C-A-4-B-E-C-NNN-***	LIGHT DUTY	025MF
83037682	PUMP-VAR-DISPL CCW H1PV089	H1-P-089-L-A-A2-C1-N-F5-H-G1-H6-L-42-L-42-N-E-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83037779	MOTOR-VAR-DISPL H1B160	H1-B-160-A-TA-D1-N-A-TB-VS-ES-S-A-30-NN-045-Z-30-NNN	H1-HP MOTORS	H1-160MB1
83037780	PUMP-VAR-DISPL CW H1PV069	H1-P-069-R-A-A2-C2-B-D8-H-G1-H3-L-42-L-42-C-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83037781	MOTOR-VAR-DISPL H1B160	H1-B-160-A-TA-D1-N-A-TA-VS-ES-S-A-30-NN-045-Z-30-NNN	H1-HP MOTORS	H1-160MB1
83037784	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-A-S-A-B-BC-B-A-C-A-BFF-AB-U-CD-B-C-C-A-BFF-AB-U-CD-A-NNN-***	M46	M46-046PT
83037789	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-N-A3-C2-N-E7-F-G1-T2-35-35-35-35-M-P-32-PN-NNN-S02	H1-MP PUMPS	H1-045PT/053PT
83037790	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A2-C2-N-F5-H-A1-H6-K-45-K-45-M-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83037794	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-NN-80-R-4-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83037799	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-AB-80-R-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83037800	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-L2-BA-N-B-PB-VS-ES-S-A-15-NN-067-N-00-NNN	H1-HP MOTORS	H1-110MB1
83037801	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A4-C2-N-D6-H-F1-H5-L-42-L-42-C-L-26-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83037802	PUMP-VAR-DISPL CCW H1PV130	H1-P-130-L-B-A5-C2-N-D8-G-G2-H6-L-42-L-42-L-P-30-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83037803	PUMP-VAR-DISPL CCW H1PV130	H1-P-130-L-B-A5-C2-N-D8-G-G2-NN-L-42-L-42-L-P-30-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83037811	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HF-1-AB-80-P-4-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83037812	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-E1A6-03-B-3-G-2-F-N-B-34-34-B-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83037813	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-1-NN-80-P-3-F1-F-03-GBA-32-32-24	SERIES 90	S90-130PV
83037817	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-A-T-B-B-AA-A-A-BDD-CD-A-JJ-C-NNN-***	M46	M46-046PV
83037818	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A3-C1-N-D8-H-G1-NN-K-45-K-45-M-P-26-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83037819	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-L2-BA-N-A-PB-VN-EN-N-A-10-NN-047-N-00-NNN	H1-HP MOTORS	H1-110MB1
83037822	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A2-C2-N-D8-H-G1-H3-K-45-K-45-N-E-34-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV

83037846	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-5-BB-80-L-4-S1-C-03-GTA-38-38-24	SERIES 90	S90-055PV
83037850	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A2-C1-N-F5-H-G1-H6-L-42-L-42-N-E-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83037856	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A5-C2-N-D3-L-G2-H6-L-42-L-42-L-M-26-P4-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83037857	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-L2-BA-N-C-PA-VN-CN-N-A-05-NN-000-N-00-NNN	H1-HP MOTORS	H1-080MB1
83037858	PUMP-VAR-DISPL CCW 90PV100	90L100-MA-1-NN-80-P-3-F1-E-09-FAD-45-45-20	SERIES 90	S90-100PV
83037860	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-CD-80-S-4-C6-C-03-GBA-45-45-24	SERIES 90	S90-055PV
83037866	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-1-NN-80-S-4-S1-C-GB-GBA-32-32-20	SERIES 90	S90-055PV
83037867	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-A-A3-C3-N-D8-H-F1-NN-K-45-K-45-M-P-24-PN-C26-NNN	H1-HP PUMPS	H1-089PV/100PV
83037872	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-5-BC-80-S-4-S1-C-03-GBA-45-45-24	SERIES 90	S90-055PV
83037883	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E1-AA-N-B-TB-VN-AN-N-A-05-NN-020-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83037885	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E2-AA-N-C-TA-VS-AS-B-A-10-NN-018-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83037886	MOTOR-VAR-DISPL H1B060#	H1-B-060-A-F2-EA-N-C-TA-VS-AS-B-N-NN-NN-021-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83037888	MOTOR-VAR-DISPL H1B060#	H1-B-060-A-F2-EA-N-C-TA-VN-AN-N-N-NN-NN-024-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83037890	PUMP-VAR DISPL CCW H1P068L	H1-P-068-L-A-A5-C3-B-F5-H-G1-H6-L-38-L-38-C-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83037891	PUMP-VAR-DISPL CCW H1PV165	H1-P-165-L-C-A5-C3-B-D8-G-G3-H6-L-42-L-42-A-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83037896	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-BC-80-L-3-S1-D-03-FAD-38-38-24	SERIES 90	S90-075PV
83037913	PUMP-VAR-DISPL CW 90PV180	90R180-KP-2-AB-80-S-C-F1-H-00-NNN-26-26-26	SERIES 90	S90-180PV
83037922	MOTOR-VAR-DISPL H1B250	H1-B-250-A-E2-AA-N-A-TB-VN-DN-N-A-20-NN-000-Z-00-NNN	H1-HP MOTORS	H1-250MB1
83037923	MOTOR-VAR-DISPL H1B250	H1-B-250-A-F2-EA-N-A-TB-VN-DN-N-A-20-NN-000-Z-00-NNN	H1-HP MOTORS	H1-250MB1
83037924	MOTOR-VAR-DISPL H1B250	H1-B-250-A-HE-HE-N-A-TB-VN-DN-N-A-20-NN-000-Z-00-NNN	H1-HP MOTORS	H1-250MB1
83037925	MOTOR-VAR-DISPL H1B250	H1-B-250-A-HF-HF-N-A-TB-VN-DN-N-A-20-NN-000-Z-00-NNN	H1-HP MOTORS	H1-250MB1
83037927	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A5-C2-B-D3-G-G3-NN-L-45-L-45-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83037929	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A2-C2-N-D3-G-G3-H3-L-42-L-42-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83037930	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-1-EF-80-D-4-C8-L-03-NNN-42-16-30	SERIES 90	S90-250PV
83037931	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A3-C1-N-D8-H-G1-NN-L-45-L-45-M-P-26-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83037934	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-CD-60-S-3-F1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
83037940	PUMP-VAR DISPL CCW H1P053L	H1-P-053-L-A-A5-C1-N-D8-F-G4-H3-L-38-L-38-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83037941	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-T2-DA-N-A-TB-CS-GS-P-N-NN-NN-012-Z-20-NNN	H1-HP MOTORS	H1-060MB1
83037944	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A3-C3-B-D3-H-G1-NN-L-35-L-35-C-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83037955	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-K1-KA-N-B-RA-VN-DN-N-A-10-NN-022-N-30-NNN	H1-HP MOTORS	H1-110MB1
83037957	MOTOR-VAR-DISPL H1B160	H1-B-160-A-DH-MA-R-B-PA-VN-EN-N-N-NN-NN-049-N-24-NNN	H1-HP MOTORS	H1-160MB1
83037995	PUMP-VAR-DISPL 42PV028 CW	42-R-28-G-E1A6-02-C-3-A-2-G-N-N-19-19-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83038013	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-5-NN-80-S-3-F1-J-00-NNN-42-42-24	SERIES 90	S90-250PV
83038022	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-T2-D2-N-C-TA-DN-JN-N-A-15-NN-035-Z-25-NNN	H1-HP MOTORS	H1-110MB1
83038040	MOTOR-VAR-DISPL H1B060	H1-B-060-A-DH-MH-R-B-PA-DS-GS-S-N-NN-NN-000-N-20-NNN	H1-HP MOTORS	H1-060MB1
83038044	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A2-C1-N-F4-H-G1-H6-L-42-L-42-F-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV

83038045	PUMP-VAR-DISPL CCW H1PV089	H1-P-089-L-A-A2-C1-N-F4-H-G1-H6-L-42-L-42-D-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83038046	PUMP-VAR-DISPL CCW H1PV089	H1-P-089-L-A-A2-C1-N-D3-H-G1-NN-L-42-L-42-D-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83038048	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-E1A3-03-B-D-B-2-H-N-N-21-21-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83038054	PUMP-VAR-DISPL CW DDC20	DDC-20-A-R-RB-RSA-NN-A-D-N-BA-ABN9-D-07-00N-00N-NNN-NNN	DDC20/LDU20	OSK-020PV - DO NOT USE
83038055	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-HE-HE-N-A-TA-VS-AS-S-A-10-NN-040-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83038056	PUMP-TANDEM, VAR DISPL MPT044D	MPT-044-D-A-R-S-A-BA-B-A-A-A-BFF-DR-A-FF-B-C-A-A-BFF-DL-A-FF-A-NNN-***	M35/44	044PT
83038060	PUMP-VAR-DISPL CCW 90PV130	90L130-KN-1-BC-80-S-4-F1-H-03-GBA-35-35-24	SERIES 90	S90-130PV
83038061	PUMP-VAR-DISPL CW 90PV130	90R130-KN-1-CD-80-S-4-F1-H-03-GBA-35-35-24	SERIES 90	S90-130PV
83038069	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-A-A4-C3-B-E7-F-G1-NN-38-38-38-38-N-P-30-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83038071	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A5-C3-N-D8-G-G3-H6-K-42-K-42-L-P-30-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83038072	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-E1A3-02-B-2-B-3-F-N-B-28-28-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83038073	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-E1A3-02-C-2-N-N-F-N-T-28-28-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83038082	PUMP-VAR-DISPL CCW H1PV069	H1-P-069-L-A-A4-C1-N-D3-H-F4-H3-K-33-K-18-F-M-22-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83038083	MOTOR-FIX DISPL MMF035D	MMF-035-D-A-6-G-A-B-NNN-***	M35/44	035MF
83038087	PUMP-VAR-DISPL CCW H1PV130	H1-P-130-L-B-A5-C2-B-D8-G-G3-H3-L-25-L-25-A-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83038088	PUMP-VAR DISPL, CCW H1PV250	H1-P-250-L-A-A5-C2-B-D8-C-G2-NN-L-35-L-35-R-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-210PV/250PV
83038089	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A5-C2-B-D8-G-G3-NN-L-35-L-35-A-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83038106	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-P1-D1-N-B-TA-DN-JN-N-A-10-NN-041-Z-24-NNN	H1-HP MOTORS	H1-110MB1
83038108	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A5-C2-B-D6-G-G2-H5-K-38-K-38-L-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83038133	PUMP-VAR DISPL, CW H1PV250	H1-P-250-R-A-A3-C1-N-D8-C-F8-E2-L-42-L-42-W-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-210PV/250PV
83038135	MOTOR-VARIABLE DISPL SAE_L	L-V-35EN-A-YNF-F00-T-N-X-BF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83038136	MOTOR-VARIABLE DISPL SAE_L	L-V-25CN-A-YNF-F00-T-N-X-BF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83038139	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-E2C8-03-A-N-A-3-H-N-A-30-30-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83038140	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-T1-D1-N-B-TA-VN-CN-N-A-10-NN-048-Z-29-NNN	H1-HP MOTORS	H1-080MB1
83038141	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-T1-D1-N-B-TA-VN-CN-N-A-10-NN-054-Z-25-NNN	H1-HP MOTORS	H1-080MB1
83038142	MOTOR-VAR-DISPL H1B250	H1-B-250-A-T2-D2-N-B-TB-VN-DN-N-A-20-NN-080-Z-30-NNN	H1-HP MOTORS	H1-250MB1
83038144	PUMP-VAR-DISPL CCW H1PV147	H1-P-147-L-C-A5-C2-N-D8-G-G2-NN-L-42-L-42-A-P-26-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83038145	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A5-C2-N-D8-H-G9-NN-L-33-L-33-D-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83038157	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-T1-D1-N-A-TA-DS-KS-P-A-10-NN-050-Z-24-NNN	H1-HP MOTORS	H1-110MB1
83038162	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-BB-80-L-3-C7-E-00-GBA-35-35-24	SERIES 90	S90-100PV
83038163	PUMP-VAR-DISPL CCW 90PV130	90L130-FH-1-AB-80-L-4-C8-H-B1-GBA-32-32-32	SERIES 90	S90-130PV
83038166	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-E8-C2-N-D6-H-G1-H5-L-38-L-20-F-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83038167	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-1-BC-60-P-4-S1-D-03-GBA-32-32-24	SERIES 90	S90-075PV
83038169	PUMP-VAR-DISPL CW 90PV075	90R075-HF-1-AB-80-L-4-C6-E-00-GBA-32-32-32	SERIES 90	S90-075PV
83038176	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-8-N-0-D9-W-00-EAJ-00-00-E6	SERIES 90	S90-055MF
83038190	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-HE-HE-N-B-TA-VN-AN-N-A-10-NN-040-Z-00-NNN	H1-HP MOTORS	H1-080MB1

83038199	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-D-ANNB-03-A-N-A-2-F-N-B-34-34-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83038202	PUMP-VAR-DISPL CCW H1PV130	H1-P-130-L-B-A3-C3-B-D6-G-G3-NN-L-23-L-23-L-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83038203	PUMP-VAR-DISPL CCW H1PV165	H1-P-165-L-C-A3-C3-B-D6-G-G3-NN-L-23-L-23-L-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83038205	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-HE-HE-N-A-TA-VN-EN-N-A-10-NN-055-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83038216	MOTOR-VARIABLE DISPL SAE_K	K-V-38CS-E-R1F-F07-S-N-N-CF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83038221	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-T1-D1-N-B-TA-VN-DN-N-A-20-NN-062-Z-28-NNN	H1-HP MOTORS	H1-160MB1
83038244	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-L1-BA-N-A-PA-VS-DS-S-A-20-NN-108-N-00-NNN	H1-HP MOTORS	H1-160MB1
83038245	MOTOR-VAR-DISPL H1B250	H1-B-250-A-L1-BA-N-A-PA-VS-DS-S-A-30-NN-052-N-00-NNN	H1-HP MOTORS	H1-250MB1
83038246	PUMP-VAR-DISPL CCW H1PV089	H1-P-089-L-A-A4-C2-N-F6-H-G1-H6-L-45-L-45-M-L-26-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83038254	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-T2-D2-N-C-TB-VS-DS-S-A-10-NN-037-S-17-NNN	H1-HP MOTORS	H1-110MB1
83038269	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-NN-80-R-3-S1-E-00-GBA-35-13-24	SERIES 90	S90-100PV
83038270	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-NN-80-R-3-S1-E-00-GBA-13-35-24	SERIES 90	S90-100PV
83038271	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E2-AA-N-C-TB-CS-JS-P-A-05-NN-024-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83038293	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HS-5-CD-80-S-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83038307	PUMP-VAR-DISPL CCW H1PV115	H1-P-115-L-B-A4-C2-N-D6-G-G3-NN-L-45-L-45-A-L-26-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83038308	PUMP-VAR-DISPL CW 90PV130	90R130-KA-1-NN-80-S-3-C8-H-03-GBA-35-35-24	SERIES 90	S90-130PV
83038312	PUMP-VAR DISPL CCW H1P068L	H1-P-068-L-A-A4-C2-N-D6-H-G1-NN-L-30-L-30-C-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83038313	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A5-C2-B-F4-H-F1-H6-L-42-L-42-C-M-22-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83038314	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A5-C2-B-D3-H-G1-H3-K-28-K-28-C-M-22-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83038315	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-L2-BA-N-B-PB-VS-BS-B-A-10-NN-016-N-00-NNN	H1-HP MOTORS	H1-080MB1
83038323	PUMP-VAR-DISPL CCW 90PV130	90L130-CB-1-NN-80-R-4-F1-F-00-GBA-32-32-24	SERIES 90	S90-130PV
83038341	PUMP-VAR-DISPL CW 90PV130	90R130-KA-1-AB-80-S-3-F1-H-04-GBA-35-35-24	SERIES 90	S90-130PV
83038353	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-N-A5-C1-N-E7-F-G1-TN-28-28-25-25-M-P-24-P3-NNN-S01	H1-MP PUMPS	H1-045PT/053PT
83038374	PUMP-VAR-DISPL 42PV041 CW	42-R-51-C-ANNB-03-A-N-N-N-F-N-B-34-34-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83038375	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E1-AA-N-B-TB-VN-EN-N-N-NN-000-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83038385	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-CD-80-S-C-C8-J-03-NNN-23-23-28	SERIES 90	S90-180PV
83038386	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-AB-80-S-3-C7-D-03-GBA-26-26-24	SERIES 90	S90-075PV
83038387	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-CD-80-S-3-C7-D-03-GBA-26-26-24	SERIES 90	S90-075PV
83038396	PUMP-VAR-DISPL CW 90PV100	90R100-KA-2-CD-80-R-3-C7-F-03-EFI-40-40-34	SERIES 90	S90-100PV
83038397	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-2-NN-80-R-3-S1-D-03-EFI-40-40-34	SERIES 90	S90-055PV
83038398	PUMP-VAR-DISPL CW H1PV069	H1-P-069-R-A-A5-C3-B-F5-H-F4-H6-L-42-L-15-C-P-26-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83038399	PUMP-VAR-DISPL CW H1PV069	H1-P-069-R-A-A5-C3-B-F5-H-G1-H6-L-42-L-15-C-P-26-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83038402	PUMP-VAR-DISPL CCW 90PV075	90L075-HF-5-NN-60-R-4-T2-D-03-GBA-35-35-20	SERIES 90	S90-075PV
83038405	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A5-C2-B-D3-H-G9-H2-L-38-L-38-C-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83038416	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-CD-60-P-3-C6-D-04-GBA-35-35-20	SERIES 90	S90-075PV
83038417	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-AB-60-P-3-S1-D-04-GBA-35-35-20	SERIES 90	S90-075PV

83038419	PUMP-VAR-DISPL 42PV041 CW	42-R-51-D-E1A6-03-B-2-G-2-F-N-N-34-34-B-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83038421	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-CD-80-P-4-S1-C-03-GBA-23-23-24	SERIES 90	S90-055PV
83038422	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-BC-80-P-4-S1-C-03-GBA-23-23-24	SERIES 90	S90-055PV
83038429	MOTOR-VAR-DISPL H1B250	H1-B-250-A-M2-CA-N-A-RA-VN-DN-N-N-NN-NN-000-N-00-NNN	H1-HP MOTORS	H1-250MB1
83038461	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A5-C2-N-D8-H-G9-NN-L-42-L-42-D-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83038465	PUMP-VAR DISPL, CW 90PV075	90-R-075-KT-1-AB-80-P-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83038469	PUMP-VAR-DISPL CCW H1PV165	H1-P-165-L-C-A5-C3-N-D8-G-G3-H6-L-43-L-43-N-E-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83038470	PUMP-VAR DISPL, CW H1PV210	H1-P-210-R-A-A3-C2-N-D8-C-G3-H4-L-40-L-40-R-P-30-PN-NNN-NNN	H1-HP PUMPS	H1-210PV/250PV
83038479	PUMP-VAR DISPL CCW H1P060L	H1-P-060-L-A-A5-C2-B-D6-H-F1-NN-L-35-L-35-F-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83038482	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-BC-80-S-M-C8-J-00-NNN-35-35-30	SERIES 90	S90-180PV
83038494	PUMP-VAR-DISPL CCW 90PV180	90L180-MA-1-NN-80-S-C-F1-H-03-FAC-38-38-24	SERIES 90	S90-180PV
83038496	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A2-C1-N-F4-H-G1-H6-L-38-L-38-M-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83038497	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E1-AA-N-B-TB-VS-AS-B-N-NN-NN-040-R-00-NNN	H1-HP MOTORS	H1-060MB1
83038501	PUMP-VAR DISPL MPV046C	MPV-046-C-B-A-J-S-B-B-AA-A-A-BFD-GB-B-YG-A-NNN-***	M46	M46-046PV
83038503	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-AB-80-R-4-S1-D-03-GBA-26-26-24	SERIES 90	S90-055PV
83038516	PUMP-VAR DISPL, CW H1PV210	H1-P-210-R-A-A3-C3-N-D8-C-G3-H3-L-42-L-42-R-P-28-PN-NNN-NNN	H1-HP PUMPS	H1-210PV/250PV
83038522	MOTOR-VAR-DISPL H1B110	H1-B-110-A-TA-DA-N-C-TA-DN-JN-N-A-10-NN-074-Z-28-NNN	H1-HP MOTORS	H1-110MB1
83038531	PUMP-VAR-DISPL 42PV028 CW	42-R-28-G-E2D8-01-C-3-A-2-G-N-N-28-28-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83038539	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-BC-80-R-4-S1-D-03-GBA-21-21-24	SERIES 90	S90-055PV
83038540	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-T2-DA-N-B-TA-VS-AS-B-A-05-NN-015-Z-20-NNN	H1-HP MOTORS	H1-060MB1
83038541	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A3-C1-N-D8-F-G1-H3-L-23-L-23-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83038546	MOTOR-VARIABLE DISPL SAE_L	L-V-30DS-E-YNF-F01-S-N-N-CF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83038548	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E1-AA-N-B-TB-VN-AN-N-N-NN-NN-015-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83038549	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E1-AA-N-B-TB-VS-AS-S-N-NN-NN-015-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83038550	PUMP-VAR DISPL CW H1P068R	H1-P-068-R-A-A4-C1-N-D3-H-G1-H3-L-35-L-35-F-M-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83038552	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A5-C1-B-F5-K-F1-H6-L-35-L-35-D-P-24-P4-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83038557	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A5-C2-N-D8-G-G3-NN-L-42-L-42-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83038558	PUMP-VAR-DISPL CCW H1PV130	H1-P-130-L-B-A5-C2-N-D8-G-G3-H3-L-42-L-42-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83038559	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-M2-CA-N-C-RB-VS-ES-B-A-20-NN-060-N-00-NNN	H1-HP MOTORS	H1-160MB1
83038564	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A3-C2-N-D8-G-G2-H6-L-40-L-40-N-E-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83038567	PUMP-VAR-DISPL CW 90PV075	90R075-HS-1-CD-60-P-3-C6-D-03-GBA-23-23-24	SERIES 90	S90-075PV
83038592	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E2-AA-N-B-TB-CS-GS-S-N-NN-NN-022-R-00-NNN	H1-HP MOTORS	H1-060MB1
83038593	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E2-AA-N-B-TB-CS-GS-S-N-NN-NN-032-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83038595	PUMP-VAR-DISPL 42PV041 CW	42-R-41-C-E1A6-00-B-D-C-3-F-N-B-14-14-N-A-A-NNN-NNN	SERIES 42	S42-041PV/051PV
83038597	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-AB-80-R-3-F1-H-06-GBA-35-35-24	SERIES 90	S90-130PV
83038598	PUMP-VAR-DISPL CW 90PV075	90R075-HF-5-NN-60-P-3-S1-D-00-GBA-42-42-24	SERIES 90	S90-075PV

83038615	PUMP-VAR DISPL CW H1P068R	H1-P-068-R-A-A8-C2-C-D6-K-G1-H3-L-38-L-38-C-L-32-P2-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83038616	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-K1-K1-N-B-RA-DS-KS-S-A-20-NN-034-N-18-NNN	H1-HP MOTORS	H1-160MB1
83038624	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-C-E2D8-03-C-3-A-2-F-N-N-28-28-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83038625	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-C-E2D8-03-C-3-A-2-F-N-A-28-28-B-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83038627	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-L2-BA-N-A-PA-VN-KN-N-N-NN-NN-035-N-00-NNN	H1-HP MOTORS	H1-110MB1
83038628	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-L2-BA-N-B-PB-DS-KS-S-A-10-NN-000-N-00-NNN	H1-HP MOTORS	H1-110MB1
83038629	MOTOR-VAR-DISPL H1MB060	H1-B-060-A-L2-BA-N-B-PB-CS-GS-S-A-10-NN-000-N-00-NNN	H1-HP MOTORS	H1-060MB1
83038631	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-DE-80-S-4-F1-H-03-GBA-42-42-24	SERIES 90	S90-130PV
83038632	PUMP-VAR-DISPL CCW H1PV115	H1-P-115-L-B-A5-C2-N-D8-G-G3-H6-L-30-L-30-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83038672	PUMP-VAR-DISPL CCW H1PV130	H1-P-130-L-B-A5-C2-N-D8-G-G3-NN-L-35-L-35-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83038673	PUMP-VAR DISPL, CW H1PV250	H1-P-250-R-A-A5-C2-N-D8-C-G3-NN-L-35-L-35-W-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-210PV/250PV
83038679	PUMP-VAR-DISPL CCW 90PV042	90L042-MA-1-AB-80-S-4-C3-C-02-GBA-38-38-24	SERIES 90	S90-042PV
83038681	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-T1-DA-N-B-TB-VN-BN-N-A-10-NN-025-Z-20-NNN	H1-HP MOTORS	H1-060MB1
83038682	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-M2-CA-N-C-RB-VS-ES-B-A-20-NN-066-N-00-NNN	H1-HP MOTORS	H1-160MB1
83038685	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-A-C3-C3-C-F5-K-F1-H6-L-42-L-42-M-P-26-P2-NNN-D6J	H1-HP PUMPS	H1-089PV/100PV
83038695	PUMP-VAR DISPL, CW 90PV100	90-R-100-HS-1-CD-80-R-3-C7-E-03-GBA-35-29-24	SERIES 90	S90-100PV
83038697	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A8-C2-C-F4-K-G9-H6-L-42-L-42-M-M-26-P2-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83038698	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E1-AA-N-B-TB-VS-DS-B-A-10-NN-036-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83038707	MOTOR-VAR-DISPL H1B060	H1-B-060-A-DH-MA-R-B-PB-VN-AN-N-N-NN-NN-030-N-16-NNN	H1-HP MOTORS	H1-060MB1
83038709	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E1-AA-N-B-TB-DS-JS-B-N-NN-NN-045-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83038714	PUMP-VAR-DISPL CW 90PV075	90R075-KA-1-NN-80-S-4-S1-D-03-GBA-38-38-24	SERIES 90	S90-075PV
83038715	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-C3-C2-C-D8-L-G2-H5-L-45-L-45-L-P-30-P2-NNN-D6J	H1-HP PUMPS	H1-115PV/130PV
83038716	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-CD-80-P-3-T2-F-09-GBA-35-35-24	SERIES 90	S90-100PV
83038720	PUMP-VAR-DISPL CCW H1PV089	H1-P-089-L-A-A5-C2-N-D8-H-G1-H5-L-33-L-33-M-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83038723	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A5-C1-N-D3-G-G2-H2-L-33-L-33-A-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83038725	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-C2-C2-C-D8-K-G1-NN-K-45-K-45-C-P-28-P2-NNN-D4F	H1-HP PUMPS	H1-069PV/078PV
83038726	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-B8-C2-C-D8-H-G1-NN-K-45-K-45-C-P-28-P1-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83038727	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-T2-D2-N-C-TB-VS-ES-S-A-20-NN-065-Z-30-NNN	H1-HP MOTORS	H1-160MB1
83038728	PUMP-VAR-DISPL CCW 90PV042	90L042-DC-5-NN-80-S-4-C3-C-G8-GBA-35-35-24	SERIES 90	S90-042PV
83038733	PUMP-VAR-DISPL CCW H1PV147	H1-P-147-L-C-A5-C2-B-D3-G-G3-NN-K-35-K-35-A-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83038734	PUMP-VAR-DISPL CCW H1PV147	H1-P-147-L-C-A5-C2-N-D3-G-G3-NN-K-35-K-35-A-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83038748	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E1-AA-N-B-TB-DN-HN-N-A-10-NN-020-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83038750	PUMP-VAR DISPL MPV035D	MPV-035-D-B-A-Y-L-S-G-AA-A-A-BGG-DL-A-FF-A-NNN-***	M35/44	035PV
83038752	PUMP-VAR DISPL, CW 90PV100	90-R-100-HS-2-BC-80-S-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83038765	PUMP-VAR-DISPL CW 90PV180	90R180-FH-5-CD-80-S-7-F1-J-B2-FAC-38-38-24	SERIES 90	S90-180PV
83038766	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-D2-MA-N-B-PA-DS-LS-B-A-30-NN-054-N-28-NNN	H1-HP MOTORS	H1-160MB1

83038768	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-1-BC-80-S-3-C6-C-06-FAC-38-38-20	SERIES 90	S90-055PV
83038775	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A9-C2-N-D8-J-G5-NN-L-38-L-38-B-P-24-P4-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83038776	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-5-NN-60-S-3-S1-E-00-GBA-42-42-24	SERIES 90	S90-100PV
83038777	PUMP-VAR-DISPL CW 90PV130	90R130-MA-1-DG-80-L-3-C8-F-03-GBA-26-26-26	SERIES 90	S90-130PV
83038783	PUMP-VAR-DISPL CW 90PV100	90R100-KP-1-CD-80-S-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83038784	PUMP-VAR-DISPL CW 90PV100	90R100-KP-1-BC-80-S-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83038785	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A2-C2-N-D8-F-G5-H3-L-42-L-42-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83038786	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E1-AA-N-B-TA-CS-JS-P-A-05-NN-016-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83038787	PUMP-VAR-DISPL CCW 90PV180	90L180-KP-5-CD-80-T-C-F1-J-03-FAC-24-24-28	SERIES 90	S90-180PV
83038790	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-8-N-0-F1-W-00-EEA-00-00-GO	SERIES 90	S90-100MF
83038792	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-F5NN-75-J-D-B-2-P-1-N-34-34-N-8-8-NNN-NNN	SERIES 42	S42-041PV/051PV
83038793	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-E1A3-02-C-2-N-N-F-N-A-28-28-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83038794	MOTOR-VAR-DISPL H1B110	H1-B-110-A-TA-DA-N-B-TA-DN-JN-N-N-NN-046-Z-27-NNN	H1-HP MOTORS	H1-110MB1
83038797	PUMP-VAR-DISPL CCW H1PV165	H1-P-165-L-C-A5-C1-B-D8-G-G2-H6-L-40-L-40-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83038800	MOTOR-VAR-DISPL H1B250	H1-B-250-A-E2-AA-N-B-TB-VN-DN-N-B-40-NN-050-Z-00-NNN	H1-HP MOTORS	H1-250MB1
83038807	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-L2-BA-N-A-PA-DN-JN-N-A-10-NN-047-N-00-NNN	H1-HP MOTORS	H1-110MB1
83038813	PUMP-VAR DISPL, CW 90PV055	90-R-055-KN-1-AB-80-P-4-S1-C-03-GBA-29-29-24	SERIES 90	S90-055PV
83038827	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HF-1-BC-80-L-3-F1-E-03-GBA-38-38-24	SERIES 90	S90-100PV
83038828	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HF-1-NN-80-L-3-F1-E-03-GBA-38-38-24	SERIES 90	S90-100PV
83038829	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-L1-BA-N-B-PB-CS-AS-S-A-05-NN-000-N-00-NNN	H1-HP MOTORS	H1-080MB1
83038836	MOTOR-VARIABLE CARTRIDGE K	K-C-38CS-E-YNF-F07-S-N-N-DF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83038844	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A2-C3-B-D3-G-G2-NN-L-40-L-40-L-M-20-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83038850	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-B1-C1-N-D3-H-G1-NN-L-28-L-28-D-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83038858	PUMP-TANDEM, VAR DISPL MPT044D	MPT-044-D-A-W-S-J-AA-B-A-A-A-BJJ-DR-A-FF-B-C-A-A-BJJ-DL-A-FF-1-NNN-***	M35/44	044PT
83038860	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-NN-80-S-4-C7-F-02-GBA-35-35-24	SERIES 90	S90-100PV
83038861	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-8-N-0-C6-W-00-NNN-00-00-E6	SERIES 90	S90-100MF
83038869	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-BC-60-P-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-075PV
83038874	PUMP-VAR-DISPL CW 90PV130	90R130-KN-1-CD-80-P-4-F1-F-03-GBA-17-17-24	SERIES 90	S90-130PV
83038877	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-E2-AA-N-A-TA-DN-KN-N-N-NN-060-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83038879	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E2-AA-N-B-TB-CS-BS-S-A-10-NN-035-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83038881	PUMP-VAR DISPL, CW H1PV250	H1-P-250-R-A-A5-C1-N-D8-C-G3-H6-L-35-L-35-W-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-210PV/250PV
83038887	MOTOR-VAR-DISPL H1MB060	H1-B-060-A-L1-BA-N-B-PB-VS-AS-S-A-10-NN-000-N-00-NNN	H1-HP MOTORS	H1-060MB1
83038893	PUMP-VAR-DISPL CCW 90PV130	90L130-KN-5-AB-80-R-3-C8-H-03-GBA-26-23-22	SERIES 90	S90-130PV
83038916	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-A-A3-C3-N-F5-H-G9-H6-K-42-K-42-D-P-34-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83038918	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-L2-BA-N-B-PA-VS-BS-S-A-10-NN-000-N-00-NNN	H1-HP MOTORS	H1-080MB1
83038920	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-CD-80-T-C-C8-J-03-NNN-38-38-24	SERIES 90	S90-180PV

83038923	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-L2-BA-N-B-PB-VS-DS-B-A-10-NN-000-N-00-NNN	H1-HP MOTORS	H1-110MB1
83038940	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A5-C2-N-E6-F-G5-H2-L-28-L-28-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83038946	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E2-AA-N-B-TB-CS-KS-S-A-10-NN-064-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83038966	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A2-C2-B-D3-K-G9-NN-K-40-K-40-M-M-26-P4-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83038968	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A9-C1-B-E9-F-G5-NN-K-35-K-18-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83038974	PUMP-VAR DISPL, CW 90PV055	90-R-055-HF-5-CD-80-R-4-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83038975	PUMP-VAR DISPL, CW 90PV055	90-R-055-HF-5-AB-80-R-4-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83038976	PUMP-VAR DISPL, CW 90PV075	90-R-075-HF-5-AB-80-R-4-S1-C-03-GBA-35-35-24	SERIES 90	S90-075PV
83038977	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-M2-C1-N-D8-F-G5-H3-L-42-L-42-B-P-24-H1-NNN-M00	H1-MP PUMPS	H1-045PV/053PV
83038979	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E2-AA-N-B-TB-DN-KN-N-A-10-NN-040-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83038980	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-HE-HE-N-B-TB-CN-GN-N-A-05-NN-027-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83038985	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A2-C1-B-F4-H-G1-H6-K-25-K-25-C-M-28-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83038987	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A3-C1-B-F4-H-G1-H6-K-25-K-25-C-M-28-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83038988	PUMP-VAR-DISPL CCW H1PV069	H1-P-069-L-A-A5-C1-B-D6-H-F1-H2-L-35-L-35-F-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83039004	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-HE-HE-N-B-TA-CN-GN-N-A-05-NN-040-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83039005	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-A-A5-C3-N-F5-H-G3-H6-K-42-K-42-D-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83039006	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-A-A5-C3-N-D8-H-G1-H3-K-42-K-42-D-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83039007	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-L2-BA-N-A-PB-VS-ES-S-A-20-NN-032-N-00-NNN	H1-HP MOTORS	H1-160MB1
83039010	MOTOR-VAR-DISPL H1B110	H1-B-110-A-TA-DA-N-B-TA-VN-EN-N-A-15-NN-074-Z-30-NNN	H1-HP MOTORS	H1-110MB1
83039014	PUMP-VAR-DISPL CW 90PV100	90R100-HF-1-BC-80-S-4-C7-E-03-GBA-38-38-24	SERIES 90	S90-100PV
83039022	MOTOR-VARIABLE DISPL SAE_L	L-V-30DN-E-Y3F-F01-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83039023	MOTOR-VAR-DISPL H1B080	H1-B-080-A-TA-DA-N-B-TA-VN-AN-N-N-NN-NN-052-R-25-NNN	H1-HP MOTORS	H1-080MB1
83039028	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-A-B8-C3-C-F6-H-G9-H6-K-45-K-45-D-L-28-P1-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83039029	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MA-1-CD-80-S-3-C7-E-03-GBA-38-38-24	SERIES 90	S90-100PV
83039030	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-T2-DA-N-B-TA-DN-GN-N-A-10-NN-020-Z-18-NNN	H1-HP MOTORS	H1-060MB1
83039031	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-1-BC-80-S-3-S1-D-03-GBA-38-38-24	SERIES 90	S90-075PV
83039034	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-E1-AA-N-B-TB-VN-EN-N-A-20-NN-107-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83039039	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-S-B-B-AA-A-A-BFF-BC-A-HH-A-NNN-***	M46	M46-046PV
83039043	PUMP-VAR DISPL, CW 90PV100	90-R-100-KT-1-CD-80-S-4-F1-F-00-GBA-35-26-30	SERIES 90	S90-100PV
83039045	MOTOR-VAR-DISPL H1MB060	H1-B-060-A-D2-MA-N-B-PA-DS-GS-B-A-10-NN-036-N-16-NNN	H1-HP MOTORS	H1-060MB1
83039047	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-T1-D1-N-B-TA-DN-JN-N-A-15-NN-054-Z-30-NNN	H1-HP MOTORS	H1-110MB1
83039051	PUMP-VAR-DISPL CW 90PV100	90R100-HF-5-AB-80-R-3-T2-F-03-GBA-26-26-24	SERIES 90	S90-100PV
83039064	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-T1-D1-N-B-TB-DN-LN-N-A-20-NN-055-R-30-NNN	H1-HP MOTORS	H1-160MB1
83039065	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-T1-DA-N-B-TA-DN-JN-N-A-10-NN-030-Z-30-NNN	H1-HP MOTORS	H1-080MB1
83039066	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-T1-DA-N-B-TA-DN-KN-N-A-20-NN-050-R-30-NNN	H1-HP MOTORS	H1-160MB1
83039069	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-A-A9-C1-N-F6-H-G1-H6-L-45-L-45-D-L-26-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV

83039070	PUMP-VAR-DISPL CCW H1PV089	H1-P-089-L-A-A2-C2-N-D6-H-F1-H1-L-45-L-45-D-L-26-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83039071	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A2-C2-N-D6-H-F1-H1-L-45-L-45-D-L-26-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83039075	PUMP-VAR DISPL, CW 90PV055	90-R-055-HF-1-BC-80-P-4-S1-C-00-GBA-35-35-24	SERIES 90	S90-055PV
83039076	MOTOR-VARIABLE DISPL SAE_L	L-V-25CN-A-RNF-F09-T-N-X-BF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83039077	MOTOR-VARIABLE DISPL SAE_L	L-V-35EN-A-RNF-F10-T-N-X-BF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83039078	MOTOR-VARIABLE DISPL SAE_L	L-V-35EN-A-YNF-F01-T-N-X-BF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83039079	MOTOR-VARIABLE DISPL SAE_L	L-V-35EN-A-YNF-F11-T-N-X-BF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83039080	MOTOR-VARIABLE DISPL SAE_L	L-V-30DN-A-RNF-F11-T-N-X-BF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83039081	MOTOR-VARIABLE DISPL SAE_L	L-V-25CN-A-RNF-F11-T-N-X-BF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83039082	MOTOR-VARIABLE DISPL SAE_L	L-V-30DN-A-YNF-F85-S-N-3-BF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83039083	MOTOR-VARIABLE DISPL SAE_L	L-V-25CN-A-YNF-F09-S-N-2-BF-F16-NNN-NNN	LV / KV MOTORS	L/K-MV
83039084	MOTOR-VARIABLE DISPL SAE_K	K-V-38CN-A-RNF-F00-T-N-X-BF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83039085	MOTOR-VARIABLE DISPL SAE_K	K-V-38CN-E-RNF-F08-T-N-X-BF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83039086	MOTOR-VARIABLE DISPL SAE_K	K-V-38CN-E-YNF-F08-T-N-X-BF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83039087	MOTOR-VARIABLE DISPL SAE_K	K-V-38CN-E-RNF-F85-T-N-X-BF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83039088	MOTOR-VARIABLE DISPL SAE_K	K-V-45DN-E-RNF-F75-T-N-X-BF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83039089	MOTOR-VARIABLE DISPL SAE_K	K-V-38CN-E-YNF-F11-T-N-X-BF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83039090	MOTOR-VARIABLE DISPL SAE_K	K-V-38CN-E-YAF-F09-T-N-X-BF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83039091	MOTOR-VARIABLE DISPL SAE_K	K-V-38CN-E-RAF-F09-T-N-X-BF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83039092	MOTOR-VARIABLE DISPL SAE_K	K-V-45DN-E-R4F-F11-T-N-X-BF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83039098	PUMP-VAR-DISPL CW 90PV180	90R180-HF-1-CD-80-S-M-C8-J-00-NNN-42-42-24	SERIES 90	S90-180PV
83039104	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E2-AA-N-B-TB-CS-GS-P-N-NN-NN-022-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83039110	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-A-A3-C3-N-F5-H-G9-H6-K-42-K-42-D-P-28-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83039121	MOTOR-VARIABLE REVERSING CARTRIDGE L	L-M-30DS-F-RE1-N18-S-N-N-BF-F18-NNB-FNT	LV / KV MOTORS	L/K-RDM
83039123	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-T1-D1-N-B-TA-VS-AS-B-A-10-NN-030-Z-25-NNN	H1-HP MOTORS	H1-080MB1
83039126	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A5-C2-B-D5-G-G2-H4-K-38-K-38-L-M-26-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83039127	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A5-C2-B-D3-G-G3-H3-K-38-K-38-L-M-26-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83039129	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-D2-M2-N-B-PA-VS-AS-S-A-05-NN-025-N-22-NNN	H1-HP MOTORS	H1-080MB1
83039130	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A3-C1-N-D8-F-G5-H5-L-25-L-25-B-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83039131	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A3-C1-N-D8-F-G5-NN-L-25-L-25-B-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83039140	PUMP-VAR-DISPL CCW 90PV075	90L075-HS-1-AB-80-R-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83039150	PUMP-VAR-DISPL CW 90PV130	90R130-HF-1-NN-80-R-3-C8-H-01-GBA-32-32-24	SERIES 90	S90-130PV
83039151	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-K-S-B-J-BA-A-A-BFD-CB-A-JJ-4-NNN-***	M46	M46-046PV
83039152	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A2-C2-N-F3-F-G5-NN-K-35-K-35-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83039153	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A2-C2-N-D6-H-G1-NN-L-42-L-42-F-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83039154	PUMP-VAR-DISPL CW H1PV069	H1-P-069-R-A-A2-C2-N-D6-H-G1-NN-L-45-L-45-F-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV

83039155	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-A-A2-C2-N-D6-H-G1-NN-L-45-L-45-D-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83039156	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A2-C2-N-D6-G-G3-NN-L-45-L-45-L-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83039157	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A2-C2-N-D6-G-G3-NN-L-45-L-45-L-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83039158	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A5-C2-N-D3-G-G3-H3-L-42-L-42-A-M-28-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83039172	MOTOR-VARIABLE DISPL SAE_L	L-V-35EN-E-RNF-F13-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83039173	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KN-1-BC-80-R-4-F1-E-03-GBA-42-14-24	SERIES 90	S90-100PV
83039174	MOTOR-VARIABLE DISPL SAE_L	L-V-35ES-E-RNF-F13-S-N-N-CF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83039176	PUMP-VAR-DISPL CCW 90PV180	90L180-KN-1-NN-80-D-M-F1-L-00-FAC-35-35-24	SERIES 90	S90-180PV
83039195	PUMP-VAR DISPL CCW H1P060L	H1-P-060-L-A-A5-C2-B-F6-H-F1-H6-L-42-L-42-F-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83039201	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-T2-DA-N-A-TB-VS-AS-S-N-NN-NN-022-Z-30-NNN	H1-HP MOTORS	H1-060MB1
83039203	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-K-S-B-J-AA-A-A-BFD-CB-A-JJ-4-NNN-***	M46	M46-046PV
83039220	PUMP-VAR-DISPL CW 90PV250	90R250-KA-1-EF-80-S-3-F1-J-03-NNN-42-42-24	SERIES 90	S90-250PV
83039221	PUMP-VAR-DISPL CW 90PV250	90R250-KA-1-BC-80-S-3-F1-J-03-NNN-42-42-24	SERIES 90	S90-250PV
83039227	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-E1A3-03-A-N-A-2-F-N-A-34-34-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83039232	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-NN-80-P-3-S1-E-03-GBA-35-35-20	SERIES 90	S90-100PV
83039235	PUMP-VAR-DISPL CW 90PV075	90R075-HF-5-CD-60-D-4-C7-L-03-GBA-35-35-18	SERIES 90	S90-075PV
83039236	PUMP-VAR-DISPL CW 90PV075	90R075-HF-5-BC-60-D-4-S1-L-03-GBA-35-35-18	SERIES 90	S90-075PV
83039238	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-HE-HE-N-B-TA-VN-EN-N-A-20-NN-064-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83039248	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-5-CD-80-P-4-F1-E-03-GBA-29-29-24	SERIES 90	S90-100PV
83039250	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HF-1-NN-80-P-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-075PV
83039252	PUMP-VAR-DISPL CCW H1PV165	H1-P-165-L-C-A5-C2-B-D8-G-G3-H3-L-35-L-35-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83039253	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A5-C2-B-F5-H-G3-H6-L-35-L-35-D-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83039259	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A5-C2-B-F6-H-G9-H6-L-42-L-42-M-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83039260	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A5-C2-N-D9-G-G3-H4-L-45-L-45-L-L-30-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83039262	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-8-N-0-T2-W-00-NNN-00-00-F3	SERIES 90	S90-075MF
83039270	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A5-C2-N-F6-H-G1-H6-L-28-L-28-C-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83039271	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A5-C2-N-F6-H-G9-H6-L-15-L-35-D-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83039275	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A4-C2-N-E7-F-G1-T3-35-35-35-35-M-P-24-PN-NNN-S02	H1-MP PUMPS	H1-045PT/053PT
83039277	PUMP-VAR-DISPL CCW H1PV130	H1-P-130-L-B-A5-C2-B-D8-G-G3-NN-L-35-L-35-A-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83039278	PUMP-VAR DISPL CCW H1P060L	H1-P-060-L-A-A5-C2-B-D8-H-G1-NN-L-35-L-35-C-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83039279	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E2-AA-N-B-TB-DN-JN-N-A-15-NN-026-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83039281	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-D2-MA-N-B-PA-DS-LS-S-A-30-NN-054-N-28-NNN	H1-HP MOTORS	H1-160MB1
83039283	PUMP-VAR-DISPL CW H1PV069	H1-P-069-R-A-A9-C1-N-D6-H-G1-S1-L-45-L-45-F-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83039289	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A5-C1-N-D3-H-G9-H3-L-42-L-42-C-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83039290	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-NN-80-R-3-C8-H-03-GBA-35-35-32	SERIES 90	S90-130PV
83039291	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A5-C3-N-F6-H-G9-H6-L-38-L-38-M-L-30-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV

83039292	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-A-A3-C3-N-D8-H-G1-H3-K-42-K-42-D-P-28-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83039293	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A5-C2-B-D3-H-F1-H2-L-38-L-38-F-M-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83039297	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A5-C2-B-D5-G-G2-H4-L-38-L-38-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83039299	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-HE-HE-N-B-TA-VN-DN-N-A-20-NN-032-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83039301	MOTOR-VAR-DISPL H1B250	H1-B-250-A-HE-HE-N-B-TA-VN-DN-N-A-20-NN-050-Z-00-NNN	H1-HP MOTORS	H1-250MB1
83039302	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A5-C2-B-D3-G-G3-H6-L-38-L-38-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83039314	MOTOR-VAR-DISPL H1B080	H1-B-080-A-TA-DA-N-B-TA-VN-AN-N-A-10-NN-054-Z-24-NNN	H1-HP MOTORS	H1-080MB1
83039315	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-HE-HE-N-B-TB-VN-EN-N-A-10-NN-060-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83039316	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A5-C1-N-D3-G-G3-NN-L-25-L-25-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83039326	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-E2-AA-N-B-TA-DN-KN-N-N-NN-NN-080-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83039345	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E1-AA-N-B-TB-VS-AS-P-A-10-NN-032-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83039352	PUMP-VAR-DISPL 42PV041 CW	42-R-51-D-G3AN-50-P-D-G-3-G-5-B-30-30-B-0-0-NNN-NNN	SERIES 42	S42-041PV/051PV
83039358	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A2-C2-N-D8-J-G4-H2-L-35-L-35-B-P-24-P4-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83039364	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-D2-M2-N-B-PB-VS-DS-S-A-30-NN-092-N-29-NNN	H1-HP MOTORS	H1-160MB1
83039366	MOTOR-VAR-DISPL H1B250	H1-B-250-A-TA-DA-N-B-TA-VS-FS-P-A-15-NN-095-T-37-NNN	H1-HP MOTORS	H1-250MB1
83039376	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-HE-HE-N-B-TB-DN-KN-N-N-NN-NN-080-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83039382	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A5-C3-N-D6-H-G1-H3-L-38-L-38-M-L-30-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83039383	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-K2-KA-N-A-RA-DN-KN-N-A-20-NN-058-N-19-NNN	H1-HP MOTORS	H1-160MB1
83039384	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-K2-KA-N-A-RA-DS-KS-B-A-20-NN-058-N-19-NNN	H1-HP MOTORS	H1-160MB1
83039399	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A5-C1-N-D3-H-G9-H5-L-40-L-40-M-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83039404	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-N-A5-C2-N-E7-F-G1-TN-35-35-35-35-M-P-28-PN-NNN-S01	H1-MP PUMPS	H1-045PT/053PT
83039405	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-P2-DA-N-B-TA-DS-GS-B-A-05-NN-032-Z-24-NNN	H1-HP MOTORS	H1-060MB1
83039413	PUMP-VAR DISPL MPV046C	MPV-046-C-B-A-G-S-B-B-AA-A-A-BJJ-AW-U-AB-C-NNN-***	M46	M46-046PV
83039417	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-L1-BA-N-A-PB-VN-DN-N-A-15-NN-050-N-00-NNN	H1-HP MOTORS	H1-110MB1
83039421	PUMP-VAR-DISPL CCW H1PV165	H1-P-165-L-C-A3-C1-N-D8-G-G2-NN-L-38-L-38-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83039428	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-C-E1B6-01-B-3-B-3-H-N-B-23-23-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83039430	MOTOR-FIXED DISPL MMF025C	MMF-025-C-A-4-G-E-N-NNN-***	LIGHT DUTY	025MF
83039440	PUMP-VAR-DISPL CW 90PV042	90R042-HF-5-AB-80-S-3-C3-B-03-GBA-35-35-24	SERIES 90	S90-042PV
83039441	PUMP-VAR-DISPL CW 90PV042	90R042-HF-5-BB-80-S-3-C3-B-03-GBA-35-35-24	SERIES 90	S90-042PV
83039444	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A5-C2-N-D8-F-G5-NN-L-35-L-35-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83039449	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-E2C8-02-D-N-F-2-F-N-V-30-30-N-C-C-NNN-NNN	SERIES 42	S42-028PV/032PV
83039450	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-E2C8-02-D-N-F-2-F-N-A-30-30-N-C-C-NNN-NNN	SERIES 42	S42-028PV/032PV
83039453	PUMP-VAR-DISPL CCW H1PV089	H1-P-089-L-A-A5-C2-N-D6-H-G1-H3-L-35-L-35-D-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83039459	MOTOR-VAR-DISPL H1B250	H1-B-250-A-L1-BA-N-B-PB-VS-FS-S-A-20-NN-055-N-00-NNN	H1-HP MOTORS	H1-250MB1
83039461	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-1-NN-60-S-4-C6-E-03-GBA-32-32-24	SERIES 90	S90-075PV
83039462	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-T1-DA-N-B-TB-DN-KN-N-A-20-NN-050-R-30-NNN	H1-HP MOTORS	H1-160MB1

83039464	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-D-N-0-C6-W-00-NNN-00-00-N4	SERIES 90	S90-075MF
83039465	PUMP-VAR-DISPL CW 90PV075	90R075-KA-1-CD-60-S-4-S1-D-03-EFC-29-29-24	SERIES 90	S90-075PV
83039475	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A5-C2-N-D8-G-G2-H6-L-38-L-38-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83039478	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A5-C2-B-E5-F-G4-H2-L-28-L-28-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83039481	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A5-C2-B-E5-F-G1-H3-L-28-L-28-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83039490	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A5-C1-N-D6-H-F1-H2-L-35-L-35-C-L-20-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83039492	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-A-T-B-B-HB-A-A-BJJ-HB-A-HC-C-NNN-***	M46	M46-046PV
83039495	MOTOR-VAR-DISPL H1B110	H1-B-110-A-TA-D1-N-A-TB-VS-ES-S-A-15-NN-060-Z-20-NNN	H1-HP MOTORS	H1-110MB1
83039496	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-8-N-0-K2-W-00-EHD-00-00-F3	SERIES 90	S90-075MF
83039497	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A4-C3-N-D8-G-G3-H3-L-42-L-42-N-E-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83039499	PUMP-VAR-DISPL CCW H1PV165	H1-P-165-L-C-A5-C2-B-D3-G-G3-H6-L-35-L-35-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83039500	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KT-1-NN-80-S-3-C7-F-00-GBA-42-38-28	SERIES 90	S90-100PV
83039510	PUMP-VAR DISPL, CW H1PV250	H1-P-250-R-A-A5-C2-B-D8-C-G2-H2-L-38-L-38-W-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-210PV/250PV
83039522	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-P1-D1-N-A-TA-DS-JS-S-A-10-NN-020-Z-24-NNN	H1-HP MOTORS	H1-080MB1
83039528	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-1-BC-80-L-4-S1-D-GB-GBA-20-20-24	SERIES 90	S90-055PV
83039529	PUMP-VAR DISPL CW H1P068R	H1-P-068-R-A-A8-C2-C-D8-H-G1-NN-L-38-L-38-C-P-34-P1-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83039531	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-K-T-B-B-HB-A-A-BJJ-HB-A-HC-B-NNN-***	M46	M46-046PV
83039532	MOTOR-VAR-DISPL H1MB060	H1-B-060-A-M1-CA-N-B-RA-DN-GN-N-A-10-NN-035-N-00-NNN	H1-HP MOTORS	H1-060MB1
83039533	PUMP-VAR DISPL, CW H1PV210	H1-P-210-R-A-A2-C2-N-D6-C-G2-NN-L-45-L-45-R-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-210PV/250PV
83039548	PUMP-VAR DISPL, CCW 90PV100	90-L-100-CA-1-BC-80-S-3-C7-E-00-GBA-38-38-24	SERIES 90	S90-100PV
83039552	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-8-N-0-C6-W-00-NNN-00-00-F3	SERIES 90	S90-100MF
83039577	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-BC-80-R-4-S1-E-03-EBC-26-26-20	SERIES 90	S90-100PV
83039578	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-NN-80-R-4-S1-E-03-GBA-21-21-24	SERIES 90	S90-100PV
83039579	PUMP-VAR DISPL, CW 90PV055	90-R-055-HF-1-NN-80-R-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-055PV
83039580	PUMP-VAR DISPL, CW 90PV075	90-R-075-HF-1-CD-80-R-4-S1-D-03-GBA-32-32-24	SERIES 90	S90-075PV
83039581	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-T1-DA-N-B-TB-CN-JN-N-A-10-NN-040-Z-24-NNN	H1-HP MOTORS	H1-080MB1
83039584	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-D1-M1-N-C-PB-VS-AS-P-A-05-NN-030-N-30-NNN	H1-HP MOTORS	H1-080MB1
83039588	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A5-C2-B-D3-G-G3-H2-L-38-L-38-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83039591	MOTOR-VAR-DISPL H1B250	H1-B-250-A-L2-BA-N-B-PA-VS-DS-S-A-30-NN-070-N-00-NNN	H1-HP MOTORS	H1-250MB1
83039596	MOTOR-VAR-DISPL H1B250	H1-B-250-A-L2-BA-N-B-PB-VS-FS-S-A-30-NN-050-N-00-NNN	H1-HP MOTORS	H1-250MB1
83039610	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-B8-C2-C-D3-L-G2-H6-L-42-L-42-A-M-30-P2-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83039612	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A2-C3-B-D8-H-G1-NN-L-35-L-35-F-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83039613	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A2-C3-B-F5-H-G1-H6-L-35-L-35-F-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83039614	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A2-C3-B-D8-H-G1-H3-L-35-L-35-F-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83039617	PUMP-VAR-DISPL CW 90PV180	90R180-KN-1-NN-80-S-M-F1-H-03-FAC-42-42-24	SERIES 90	S90-180PV
83039619	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-A-V-C-S-BA-B-A-C-A-BFF-AB-U-CD-B-C-C-A-BFF-AB-U-CD-A-NNN-*	M46	M46-046PT

83039620	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-HF-HF-N-B-TA-CN-EN-N-A-20-NN-085-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83039624	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-E1A6-02-B-2-G-2-F-N-A-21-21-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83039635	MOTOR-FIX DISPL MMF044D	MMF-044-D-A-N-W-A-B-NNN-***	M35/44	044MF
83039636	MOTOR-VAR-DISPL H1B250	H1-B-250-A-L1-BA-N-B-PA-VS-FS-S-A-20-NN-055-N-00-NNN	H1-HP MOTORS	H1-250MB1
83039637	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A4-C1-N-D6-H-G1-H5-L-35-L-35-C-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83039641	MOTOR-VAR-DISPL H1B250	H1-B-250-A-F2-EA-N-B-TA-VN-FN-N-N-NN-NN-107-T-00-NNN	H1-HP MOTORS	H1-250MB1
83039642	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-AB-80-R-4-F1-H-03-GBA-20-20-20	SERIES 90	S90-130PV
83039643	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-ANN3-03-C-3-A-2-F-N-N-30-30-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83039656	PUMP-VAR DISPL, CW 90PV075	90-R-075-LE-1-AB-60-R-3-S1-E-C5-FAD-42-38-24	SERIES 90	S90-075PV
83039664	PUMP-VAR DISPL CCW H1P060L	H1-P-060-L-A-A5-C2-N-D8-H-G1-H5-K-42-K-42-C-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83039665	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A5-C2-N-D8-H-G9-H3-L-45-L-45-M-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83039666	PUMP-VAR DISPL CCW H1P060L	H1-P-060-L-A-A5-C2-N-D8-H-F1-H3-K-42-K-42-C-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83039667	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-L2-BA-N-B-PB-VS-ES-S-A-20-NN-065-N-00-NNN	H1-HP MOTORS	H1-160MB1
83039670	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A5-C2-N-D6-H-G9-H5-L-35-L-35-M-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83039671	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-T2-DA-N-B-TB-VN-AN-N-A-10-NN-036-Z-23-NNN	H1-HP MOTORS	H1-060MB1
83039673	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A5-C1-N-D5-G-G2-H4-L-25-L-25-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83039674	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A5-C3-N-D6-H-G1-H3-L-38-L-38-C-L-28-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83039681	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-C2-C-D8-K-G1-NN-K-45-K-45-C-P-28-P2-NNN-D4F	H1-HP PUMPS	H1-069PV/078PV
83039683	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A5-C3-N-D6-H-G1-H2-L-38-L-38-C-L-28-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83039684	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A5-C3-N-D6-H-G1-NN-L-38-L-38-C-L-28-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83039688	PUMP-VAR-DISPL CCW H1PV165	H1-P-165-L-C-A4-C2-N-D8-G-G3-NN-L-42-L-42-L-P-30-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83039689	PUMP-VAR DISPL CW H1P068R	H1-P-068-R-A-A8-C2-C-D8-H-G1-NN-L-40-L-40-C-P-34-P1-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83039692	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-1-BC-80-P-4-S1-C-03-GBA-14-14-24	SERIES 90	S90-055PV
83039693	PUMP-VAR-DISPL CCW 90PV130	90L130-MA-5-DE-80-S-3-F1-H-C5-GBA-38-38-24	SERIES 90	S90-130PV
83039694	PUMP-VAR-DISPL CCW 90PV130	90L130-MA-5-NN-80-S-3-F1-H-C5-GBA-38-38-24	SERIES 90	S90-130PV
83039695	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-5-CD-80-S-3-F1-F-03-GBA-38-38-24	SERIES 90	S90-100PV
83039696	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-5-NN-80-S-3-S1-B-03-GBA-38-38-24	SERIES 90	S90-055PV
83039698	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A5-C2-B-D3-H-A1-NN-L-15-L-15-M-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83039716	MOTOR-VAR-DISPL H1B160	H1-B-160-A-TA-D2-N-B-TA-CN-EN-N-A-20-NN-085-Z-24-NNN	H1-HP MOTORS	H1-160MB1
83039718	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A2-C2-B-D3-H-G1-NN-L-40-L-40-M-M-26-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83039720	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-L2-BA-N-B-PB-VS-DS-B-N-NN-NN-022-N-00-NNN	H1-HP MOTORS	H1-110MB1
83039728	PUMP-VAR DISPL CW H1P068R	H1-P-068-R-A-A8-C2-D-D3-H-G1-NN-L-20-L-20-F-M-30-P1-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83039729	PUMP-VAR DISPL CW H1P068R	H1-P-068-R-A-A8-C2-D-F4-H-G1-H6-L-20-L-20-F-M-30-P1-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83039730	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-M1-CA-N-B-RA-DN-HN-N-A-10-NN-024-N-00-NNN	H1-HP MOTORS	H1-080MB1
83039731	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-M1-CA-N-B-RA-DN-JN-N-A-15-NN-023-N-00-NNN	H1-HP MOTORS	H1-110MB1
83039732	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-B8-C2-C-D8-H-G1-NN-K-45-K-45-C-P-28-P1-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV

83039741	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-E8-C2-B-D6-H-G1-NN-L-33-L-33-C-L-30-PN-C23-NNN	H1-MP PUMPS	H1-060PV/068PV
83039742	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-M1-CA-N-B-RA-DN-KN-N-A-20-NN-035-N-00-NNN	H1-HP MOTORS	H1-160MB1
83039745	PUMP-VAR-DISPL CCW 90PV100	90L100-MB-1-NN-80-L-3-S1-E-02-GBA-35-35-24	SERIES 90	S90-100PV
83039746	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-N-A2-C3-N-D1-F-G5-H3-35-35-35-35-N-P-26-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83039747	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A2-C3-N-D1-F-G5-H3-35-35-35-35-N-P-26-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83039751	MOTOR-VAR-DISPL H1B160#	H1-B-160-A-F2-EA-N-A-TB-VN-DN-N-N-NN-NN-061-T-00-NNN	H1-HP MOTORS	H1-160MB1
83039753	PUMP-VAR-DISPL CCW 90PV100	90L100-KN-1-CD-80-R-4-F1-E-03-GBA-42-14-24	SERIES 90	S90-100PV
83039756	PUMP-VAR-DISPL CCW 90PV075	90L075-HS-1-BC-60-S-3-C6-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83039759	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-K-T-B-J-HB-A-A-BGG-HA-A-HB-5-NNN-***	M46	M46-046PV
83039764	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A2-C2-B-D8-G-G3-H6-L-33-L-25-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83039766	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-NN-80-L-4-S1-D-03-GBA-14-14-24	SERIES 90	S90-075PV
83039767	MOTOR-VARIABLE DISPL SAE_K	K-V-45DS-A-R1F-F07-T-N-X-CF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83039768	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-AB-60-R-4-S1-E-03-GBA-14-29-24	SERIES 90	S90-100PV
83039771	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-M1-CA-N-A-RA-DS-KS-S-A-15-NN-000-N-00-NNN	H1-HP MOTORS	H1-110MB1
83039777	PUMP-VAR-DISPL CW H1PV069	H1-P-069-R-A-A7-C2-C-D6-K-G1-H3-L-45-L-45-C-L-28-P2-NNN-D3E	H1-HP PUMPS	H1-069PV/078PV
83039788	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A3-C2-N-D3-H-G9-H3-L-42-L-42-M-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83039816	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A7-C2-C-D6-L-G2-H3-L-45-L-45-A-L-30-P2-NNN-D3E	H1-HP PUMPS	H1-115PV/130PV
83039817	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A7-C2-C-D6-L-G2-H3-L-45-L-45-A-L-30-P2-NNN-D3E	H1-HP PUMPS	H1-115PV/130PV
83039819	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A7-C2-C-D6-L-G2-H3-L-45-L-45-L-L-30-P2-NNN-D3E	H1-HP PUMPS	H1-115PV/130PV
83039841	PUMP-VAR DISPL CCW H1P068L	H1-P-068-L-A-A2-C2-N-D8-H-G1-NN-L-42-L-42-F-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83039844	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KN-1-BC-60-P-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83039845	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-BC-80-S-4-S1-D-03-GBA-42-42-24	SERIES 90	S90-100PV
83039852	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A7-C2-C-D6-K-G1-H3-L-45-L-45-C-L-28-P2-NNN-D3E	H1-HP PUMPS	H1-069PV/078PV
83039853	PUMP-VAR-DISPL 42PV041 CW	42-R-41-C-G1A1-72-J-D-G-2-F-5-N-41-41-N-0-0-NNN-NNN	SERIES 42	S42-041PV/051PV
83039870	PUMP-VAR-DISPL CW 90PV250	90R250-KA-2-BC-80-D-3-C8-L-00-NNN-35-35-30	SERIES 90	S90-250PV
83039872	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-AB-60-R-4-S1-E-03-GBA-14-29-24-F023	SERIES 90	S90-100PV
83039876	PUMP-VAR DISPL CCW H1P068L	H1-P-068-L-A-A4-C2-N-D8-H-G1-H3-L-35-L-35-F-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83039883	PUMP-VAR-DISPL CCW H1PV115	H1-P-115-L-B-A5-C2-B-D8-G-G3-H6-L-30-L-30-A-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83039886	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-T1-DA-N-B-TB-VN-DN-N-N-NN-NN-060-Z-25-NNN	H1-HP MOTORS	H1-160MB1
83039887	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-T1-DA-N-B-TB-DN-KN-N-A-15-NN-055-Z-30-NNN	H1-HP MOTORS	H1-110MB1
83039919	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A8-C2-C-D6-H-G1-H3-L-42-L-42-F-L-26-P1-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83039920	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A8-C2-C-D6-H-G1-H3-L-45-L-45-F-L-26-P1-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83039921	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-A-A8-C2-C-D6-H-G1-H3-L-45-L-45-D-L-26-P1-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83039922	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A8-C2-C-D6-H-G1-H3-L-45-L-45-D-L-26-P1-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83039924	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A8-C2-C-D6-G-G3-H3-L-45-L-45-A-L-26-P1-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83039925	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A8-C2-C-D6-G-G3-H3-L-45-L-45-A-L-26-P1-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV

83039926	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A8-C2-C-D6-F-G4-H3-L-38-L-38-B-L-26-P1-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83039927	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A8-C2-C-D6-F-G4-H3-L-42-L-42-B-L-26-P1-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83039928	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A5-C2-B-D8-H-G1-NN-L-30-L-30-C-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83039934	MOTOR-VARIABLE CARTRIDGE L	L-C-25CN-F-R1F-F11-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83039935	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-5-CD-80-R-3-F1-F-03-GBA-38-38-34	SERIES 90	S90-100PV
83039936	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-NN-80-R-3-S1-F-00-GBA-29-14-24	SERIES 90	S90-100PV
83039937	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KN-1-CD-60-S-3-S1-D-03-GBA-24-24-24	SERIES 90	S90-100PV
83039938	PUMP-VAR DISPL, CW 90PV075	90-R-075-KT-1-CD-80-P-3-C7-E-00-GBA-42-42-24	SERIES 90	S90-075PV
83039939	PUMP-VAR DISPL, CW 90PV055	90-R-055-KT-1-BB-80-P-3-S1-D-00-GBA-42-42-24	SERIES 90	S90-055PV
83039947	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E2-AA-N-B-TB-DN-BN-N-N-NN-NN-035-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83039948	PUMP-VAR-DISPL CCW H1PV165	H1-P-165-L-C-A3-C2-B-D6-G-G2-H2-L-42-L-42-L-L-26-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83039951	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-BC-80-L-3-F1-D-03-FAD-42-42-28	SERIES 90	S90-100PV
83039964	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-HE-HE-N-B-TA-VN-AN-N-N-NN-NN-045-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83039976	PUMP-VAR-DISPL CW 90PV180	90R180-KP-5-DE-80-T-C-C8-J-05-FAC-35-35-34	SERIES 90	S90-180PV
83039977	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A2-C2-N-D8-H-G9-H5-L-35-L-35-D-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83039978	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KN-1-CD-80-R-3-S1-D-03-GBA-24-24-24	SERIES 90	S90-075PV
83039979	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KN-1-CD-80-R-3-S1-E-03-GBA-24-24-24	SERIES 90	S90-100PV
83039984	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A5-C2-N-D3-G-G2-NN-L-38-L-38-L-M-32-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83039987	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-HE-HE-N-B-TB-VN-AN-N-N-NN-NN-030-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83039992	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-HE-HE-N-B-TB-VN-AN-N-N-NN-NN-040-Q-00-NNN	H1-HP MOTORS	H1-080MB1
83039993	PUMP-VAR DISPL CW H1P068R	H1-P-068-R-A-A4-C3-N-D3-H-G1-H3-L-30-L-30-C-M-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83039997	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-P1-D1-N-B-TA-DN-JN-N-A-10-NN-022-Z-24-NNN	H1-HP MOTORS	H1-080MB1
83039998	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A7-C2-C-D6-J-G4-NN-L-40-L-40-B-L-30-P2-NNN-D3F	H1-MP PUMPS	H1-045PV/053PV
83040007	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A5-C1-N-D8-F-G1-H3-L-35-L-35-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83040008	MOTOR-FIX DISPL MMF035D	MMF-035-D-A-A-M-C-F-NNR-***	M35/44	035MF
83040009	PUMP-VAR-DISPL 42PV041 CCW	42-L-41-C-E2D8-03-B-D-G-2-H-N-N-30-30-B-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83040010	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-E2D8-03-B-D-G-3-H-N-N-23-23-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83040013	PUMP-VAR-DISPL CW 90PV180	90R180-MA-5-NN-80-T-M-C8-J-C5-NNN-26-26-24	SERIES 90	S90-180PV
83040021	PUMP-VAR DISPL MPV044D	MPV-044-D-B-A-G-R-S-G-AA-A-A-BBB-DR-A-FF-C-NNN-***	M35/44	044PV
83040034	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-2-CD-80-P-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83040035	PUMP-VAR-DISPL CW 90PV130	90R130-KT-1-CD-80-R-4-F1-H-00-GBA-38-32-30	SERIES 90	S90-130PV
83040036	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A4-C3-N-F4-H-G3-H6-L-42-L-42-M-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83040038	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-2-NN-80-L-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83040040	PUMP-VAR-DISPL CW 90PV180	90R180-KP-1-CD-80-T-C-C8-J-09-FAC-42-42-24	SERIES 90	S90-180PV
83040041	MOTOR-VAR-DISPL H1B250	H1-B-250-A-HE-HE-N-B-TB-VN-DN-N-A-30-NN-100-Z-00-NNN	H1-HP MOTORS	H1-250MB1
83040051	PUMP-VAR-DISPL 42PV041 CCW	42-L-41-D-E2C8-03-D-N-F-2-H-N-N-41-41-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV

83040052	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-E1A6-03-B-2-G-2-H-N-B-34-34-B-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83040053	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-BC-80-P-4-C7-F-03-GBA-42-42-24	SERIES 90	S90-100PV
83040054	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-HE-HE-N-B-TB-VS-AS-S-A-05-NN-035-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83040059	PUMP-VAR-DISPL 42PV041 CCW	42-L-51-D-F5NN-73-J-2-B-2-H-N-N-34-NN-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83040064	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-2-NN-80-S-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
83040071	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-BC-80-P-3-C7-D-00-GBA-29-29-24	SERIES 90	S90-075PV
83040080	MOTOR-VARIABLE REVERSING CARTRIDGE K	K-M-45DN-F-RF2-N18-S-N-N-BF-F18-NNB-FNT	LV / KV MOTORS	L/K-RDM
83040083	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-HE-HE-N-C-TB-VN-DN-N-A-10-NN-055-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83040085	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-BC-80-P-3-S1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
83040086	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A5-C3-N-D3-H-G1-H3-L-42-L-42-M-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83040092	PUMP-VAR-DISPL CW 90PV130	90R130-KA-1-NN-80-S-3-C8-F-03-GBA-29-29-24	SERIES 90	S90-130PV
83040093	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A4-C1-N-D6-H-G1-H5-L-42-L-42-F-L-30-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83040111	PUMP-VAR-DISPL CCW H1PV089	H1-P-089-L-A-E8-C1-B-D3-H-G1-H2-L-42-L-42-D-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83040117	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-B-T-B-B-AA-A-A-BDD-CG-A-HH-A-NNN-***	M46	M46-046PV
83040123	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A2-C2-N-D8-H-G1-NN-L-42-L-42-M-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83040124	PUMP-TANDEM, VAR DISPL CCW H1T053L	H1-T-053-L-A-N-A5-C2-B-F7-F-G5-NN-38-38-38-38-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83040125	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A5-C1-B-D3-H-G9-H5-L-33-L-33-C-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83040126	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-BC-60-S-4-S1-C-03-FAD-38-38-24	SERIES 90	S90-075PV
83040127	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-CD-60-S-4-J1-C-03-FAD-38-38-24	SERIES 90	S90-075PV
83040133	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-BC-80-P-3-S1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
83040134	PUMP-VAR-DISPL CCW H1PV147	H1-P-147-L-C-A5-C2-N-D6-G-G2-H6-L-35-L-35-L-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83040143	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-P1-D1-N-B-TA-DN-HN-N-A-10-NN-032-Z-24-NNN	H1-HP MOTORS	H1-080MB1
83040150	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-L2-BA-N-B-PA-VS-BS-B-A-10-NN-000-N-00-NNN	H1-HP MOTORS	H1-080MB1
83040157	PUMP-VAR-DISPL CCW H1PV147	H1-P-147-L-C-A5-C3-B-D8-G-G3-H3-L-42-L-42-A-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83040158	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-1-NN-80-R-4-F1-F-03-GBA-32-32-24	SERIES 90	S90-130PV
83040174	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-HE-HE-N-B-TA-VS-ES-S-A-20-NN-045-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83040176	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A4-C2-N-D8-H-G1-H3-L-40-L-40-M-P-30-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83040182	PUMP-VAR-DISPL CW H1PV069	H1-P-069-R-A-A8-C2-C-D6-H-G1-H3-L-45-L-45-F-L-26-P1-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83040190	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A4-C1-N-D6-H-G1-H3-L-30-L-42-C-L-30-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83040193	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-HE-HE-N-B-TA-DN-KN-N-B-20-NN-070-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83040194	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E1-AA-N-A-TB-VS-ES-P-A-15-NN-074-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83040195	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-E1-AA-N-A-TB-VS-ES-P-A-30-NN-108-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83040197	MOTOR-FIX DISPL MMF044D	MMF-044-D-A-D-M-A-B-NNR-***	M35/44	044MF
83040199	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A5-C2-N-F4-H-F1-H6-L-25-L-25-C-M-26-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83040203	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-HE-HE-N-B-TB-VN-EN-N-N-NN-NN-070-R-00-NNN	H1-HP MOTORS	H1-110MB1
83040211	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A4-C2-N-D8-G-G3-H2-L-40-L-40-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV

83040216	MOTOR-VAR-DISPL H1B080	H1-B-080-A-LH-BA-F-C-PB-VN-AN-N-N-NN-NN-054-N-00-NNN	H1-HP MOTORS	H1-080MB1
83040217	MOTOR-VAR-DISPL H1B160	H1-B-160-A-LH-BA-F-C-PB-VN-EN-N-N-NN-NN-060-N-00-NNN	H1-HP MOTORS	H1-160MB1
83040223	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-E8-C2-N-D6-H-F1-NN-K-45-K-45-C-L-22-PN-C12-NNN	H1-HP PUMPS	H1-069PV/078PV
83040229	MOTOR-VARIABLE CARTRIDGE K	K-C-45DN-E-R4F-F08-S-N-N-AF-F17-NNN-NNN	LV / KV MOTORS	L/K-MV
83040230	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-BC-60-R-3-S1-F-06-GBA-20-20-20	SERIES 90	S90-100PV
83040232	MOTOR-VAR-DISPL H1B250	H1-B-250-A-M1-CA-N-B-RB-VS-DS-B-A-20-NN-000-N-00-NNN	H1-HP MOTORS	H1-250MB1
83040236	PUMP-VAR-DISPL CCW H1PV130	H1-P-130-L-B-A5-C2-N-D8-G-G3-NN-L-20-L-35-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83040260	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A4-C2-N-D1-F-G6-T3-28-28-28-28-M-P-24-PN-NNN-S02	H1-MP PUMPS	H1-045PT/053PT
83040262	PUMP-VAR-DISPL CCW H1PV089	H1-P-089-L-A-A5-C2-N-F5-H-G9-H6-L-42-L-42-N-E-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83040263	PUMP-VAR-DISPL CCW H1PV089	H1-P-089-L-A-A5-C2-N-D8-H-G1-H3-L-42-L-42-N-E-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83040281	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E1-AA-N-C-TB-DN-HN-N-A-10-NN-054-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83040304	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-A-V-C-B-BA-B-A-V-A-BDD-GG-B-FF-B-C-V-A-BDD-GG-B-FF-C-NNN-*	M46	M46-046PT
83040305	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-E2-AA-N-B-TA-CS-ES-S-A-20-NN-000-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83040307	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-NN-C2-C-F3-J-G5-NN-J-40-J-40-B-L-24-P2-C08-NNN	H1-MP PUMPS	H1-045PV/053PV
83040309	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-5-AB-80-P-3-S1-E-06-GBA-36-36-24	SERIES 90	S90-075PV
83040313	PUMP-VAR-DISPL CW 90PV250	90R250-HF-1-DE-80-T-4-C8-K-04-NNN-35-35-20	SERIES 90	S90-250PV
83040314	PUMP-VAR-DISPL CW 90PV130	90R130-HF-1-BC-80-R-4-F1-H-04-GBA-35-35-24	SERIES 90	S90-130PV
83040317	PUMP-VAR-DISPL CCW 90PV100	90L100-KT-2-CD-60-R-4-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83040318	PUMP-VAR-DISPL CCW 90PV100	90L100-KT-2-AB-60-R-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83040321	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-E1A6-03-B-3-G-2-F-N-A-34-34-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83040330	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A7-C4-C-D6-K-F1-H3-L-45-L-45-C-L-28-P2-NNN-D3E	H1-HP PUMPS	H1-069PV/078PV
83040332	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-L2-BA-N-B-PB-DS-JS-S-A-10-NN-022-N-00-NNN	H1-HP MOTORS	H1-110MB1
83040333	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-L2-BA-N-B-PB-DS-JS-S-N-NN-NN-022-N-00-NNN	H1-HP MOTORS	H1-110MB1
83040338	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-NN-80-S-M-C8-J-03-NNN-29-29-24	SERIES 90	S90-180PV
83040341	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A7-C2-C-D8-L-G2-H6-L-45-L-45-A-P-28-P2-NNN-D3E	H1-HP PUMPS	H1-115PV/130PV
83040343	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A7-C2-C-D8-L-G2-H6-L-45-L-45-L-P-28-P2-NNN-D3E	H1-HP PUMPS	H1-115PV/130PV
83040344	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-HE-HE-N-B-TA-VN-AN-N-N-NN-NN-024-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83040345	PUMP-TANDEM, VAR DISPL MPT035D	MPT-035-D-C-L-S-G-BA-C-A-A-A-BDD-DR-A-FF-C-C-A-A-BDD-DR-A-FF-A-NNN-*	M35/44	035PT
83040346	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A4-C1-B-E5-F-G1-H2-L-30-L-30-B-P-18-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83040348	MOTOR-VAR-DISPL H1B250	H1-B-250-A-T2-DA-N-B-TB-VS-FS-B-A-30-NN-058-Z-22-NNN	H1-HP MOTORS	H1-250MB1
83040350	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A3-C2-N-D3-H-F1-NN-L-42-L-38-M-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83040356	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A5-C2-B-D3-H-G9-H2-L-38-L-38-D-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83040359	PUMP-TANDEM, VAR DISPL MPT035D	MPT-035-D-A-R-S-G-AA-C-A-A-A-BEE-DR-A-FF-C-C-A-A-BEE-DR-A-FF-C-NNN-*	M35/44	035PT
83040368	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-7-N-0-T2-W-00-NNN-00-00-F3	SERIES 90	S90-075MF
83040373	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-A-V-C-B-BA-B-B-V-A-BEE-BA-A-GG-B-D-V-A-BEE-BA-A-GG-C-NNN-*	M46	M46-046PT
83040374	PUMP-VAR-DISPL CCW H1PV069	H1-P-069-L-A-A5-C3-B-D3-H-G1-NN-K-33-K-33-C-M-20-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV

83040375	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A2-C1-B-D1-F-G5-NN-33-33-33-33-N-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83040379	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-1-BC-60-D-3-S1-L-03-GBA-42-42-24	SERIES 90	S90-075PV
83040381	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-HE-HE-N-B-TA-VN-EN-N-N-NN-NN-056-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83040384	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A5-C2-B-D3-G-G2-H2-L-38-L-38-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83040388	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-B1-C2-B-D6-H-G9-H3-L-30-L-30-M-L-20-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83040389	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-B-V-C-B-AA-B-B-A-A-BBB-BA-A-GG-B-D-A-A-BBB-BA-A-GG-C-NNN-	M46	M46-046PT
83040393	MOTOR-VARIABLE REVERSING CARTRIDGE L	L-M-25CS-F-RF2-N24-S-N-N-DF-F18-NNA-FNN	LV / KV MOTORS	L/K-RDM
83040394	MOTOR-VAR-DISPL H1B110	H1-B-110-A-TA-DA-N-B-TB-VN-EN-N-N-NN-NN-036-Z-20-NNN	H1-HP MOTORS	H1-110MB1
83040398	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-2-CD-80-L-3-S1-D-00-GBA-29-29-26	SERIES 90	S90-075PV
83040400	PUMP-VAR DISPL CW H1P068R	H1-P-068-R-A-A3-C2-N-D3-H-G1-H3-L-38-L-38-F-M-24-PN-C14-NNN	H1-MP PUMPS	H1-060PV/068PV
83040404	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A4-C1-N-D6-H-G1-H5-L-42-L-42-D-L-30-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83040406	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-1-NN-60-S-3-C6-C-02-GBA-35-35-24	SERIES 90	S90-055PV
83040412	PUMP-VAR-DISPL CCW 90PV130	90L130-CB-1-NN-80-R-4-T4-F-00-EEB-32-32-24	SERIES 90	S90-130PV
83040414	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-B-V-C-B-AA-B-B-U-A-BBB-BA-A-GG-B-D-U-A-BBB-BA-A-GG-C-NNN-	M46	M46-046PT
83040419	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-M1-CA-N-A-RB-CS-JS-S-B-15-NN-000-N-00-NNN	H1-HP MOTORS	H1-110MB1
83040422	PUMP-VAR-DISPL CW H1PV069	H1-P-069-R-A-A3-C2-N-D3-H-G1-H3-L-38-L-38-F-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83040425	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A5-C2-B-D3-H-G9-H3-L-20-L-20-C-M-20-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83040436	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A3-C2-N-D3-H-G9-NN-L-42-L-42-M-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83040442	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E2-AA-N-B-TB-DN-DN-N-N-NN-NN-035-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83040447	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-A-B8-C3-C-F6-K-G9-H6-K-45-K-45-D-L-28-P2-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83040449	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E2-AA-N-B-TB-DN-JN-N-N-NN-NN-035-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83040452	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-D2-MA-N-B-PB-VN-DN-N-A-10-NN-064-N-27-NNN	H1-HP MOTORS	H1-110MB1
83040454	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-M1-C8-N-D6-H-G1-H3-L-38-L-38-F-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83040455	PUMP-VAR-DISPL CCW H1PV089	H1-P-089-L-A-M1-D1-N-D6-H-G1-H3-L-38-L-38-D-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83040456	PUMP-VAR-DISPL CCW H1PV069	H1-P-069-L-A-A4-C1-N-D6-H-G1-H2-L-35-L-35-F-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83040457	PUMP-VAR-DISPL CCW H1PV089	H1-P-089-L-A-A4-C1-N-D6-H-G1-H2-L-35-L-35-D-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83040459	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-D1-MA-N-B-PB-DS-JS-S-A-10-NN-031-N-30-NNN	H1-HP MOTORS	H1-110MB1
83040461	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-NN-80-S-4-C8-H-03-GBA-20-20-24	SERIES 90	S90-130PV
83040463	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A5-C1-N-D3-H-G9-H2-L-42-L-42-M-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83040475	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-L2-BA-N-B-PB-VN-AN-N-A-05-NN-020-N-00-NNN	H1-HP MOTORS	H1-080MB1
83040481	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E1-AA-N-B-TB-VS-ES-P-A-10-NN-041-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83040504	PUMP-VAR DISPL, CW 90PV100	90-R-100-KN-1-NN-80-S-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83040506	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A5-C3-B-D6-G-G3-H3-L-45-L-45-L-L-28-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83040508	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A5-C3-B-D6-G-G3-H3-L-45-L-45-L-L-28-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83040509	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-T2-DA-N-A-TB-DN-KN-N-A-10-NN-074-Z-21-NNN	H1-HP MOTORS	H1-110MB1
83040511	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-NN-80-S-3-C6-F-03-GBA-42-42-24	SERIES 90	S90-100PV

83040532	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-BC-80-P-3-S1-E-03-GBA-38-38-24	SERIES 90	S90-075PV
83040533	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-1-CD-80-S-3-S1-D-03-GBA-29-29-24	SERIES 90	S90-075PV
83040534	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-CD-60-S-4-C7-E-00-GBA-38-38-24	SERIES 90	S90-100PV
83040535	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-1-BC-80-R-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83040536	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-CD-80-R-4-F1-F-03-GBA-35-35-28	SERIES 90	S90-100PV
83040537	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-CD-80-R-3-C8-H-03-GBA-35-35-28	SERIES 90	S90-130PV
83040539	PUMP-VAR-DISPL CW 90PV180	90R180-MA-1-NN-80-S-C-F1-H-03-NNN-35-35-24	SERIES 90	S90-180PV
83040542	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A4-C2-N-F6-H-G1-H6-L-42-L-42-C-L-26-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83040543	PUMP-VAR-DISPL CCW H1PV089	H1-P-089-L-A-B7-C2-C-F6-K-G1-H6-L-45-L-45-M-L-26-P2-NNN-D5J	H1-HP PUMPS	H1-089PV/100PV
83040544	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-T1-D1-N-B-TA-DN-JN-N-A-10-NN-020-Z-27-NNN	H1-HP MOTORS	H1-080MB1
83040565	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E2-AA-N-B-TB-DN-HN-N-N-NN-NN-030-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83040572	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-5-CD-60-S-3-S1-F-04-GBA-35-35-24	SERIES 90	S90-100PV
83040573	MOTOR-VAR-DISPL H1MB060	H1-B-060-A-D1-MA-N-B-PA-VS-AS-P-A-10-NN-012-N-30-NNN	H1-HP MOTORS	H1-060MB1
83040574	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-D1-MA-N-B-PA-VS-AS-P-A-10-NN-016-N-30-NNN	H1-HP MOTORS	H1-080MB1
83040575	PUMP-VAR DISPL CW H1P068R	H1-P-068-R-A-A3-C3-N-F4-H-G1-H6-K-35-K-35-C-M-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83040576	PUMP-VAR DISPL CW H1P068R	H1-P-068-R-A-A3-C3-N-D3-H-G1-H3-K-35-K-35-F-M-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83040577	MOTOR-VAR-DISPL H1B060	H1-B-060-A-TA-D2-N-B-TA-CS-GS-S-A-05-NN-035-Z-24-NNN	H1-HP MOTORS	H1-060MB1
83040597	PUMP-VAR DISPL, CW 90PV075	90-R-075-HF-1-NN-60-S-3-T2-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83040620	MOTOR-VAR-DISPL H1MB060	H1-B-060-A-D2-MA-N-B-PB-VS-AS-B-N-NN-NN-012-N-19-NNN	H1-HP MOTORS	H1-060MB1
83040621	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A4-C1-N-D6-F-G5-NN-L-30-L-30-B-L-30-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83040626	PUMP-VAR-DISPL CW 90PV180	90R180-KP-5-NN-80-S-M-F1-H-03-FAC-23-23-24	SERIES 90	S90-180PV
83040627	PUMP-VAR DISPL, CW 90PV100	90-R-100-LE-1-CD-62-R-3-C7-E-05-GFK-45-45-20	SERIES 90	S90-100PV
83040628	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-BB-60-P-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
83040629	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E1-AA-N-B-TA-CS-AS-S-A-05-NN-039-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83040632	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-BC-80-R-3-F1-F-03-EBC-29-29-24	SERIES 90	S90-100PV
83040633	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-BC-80-R-3-F1-F-03-EBC-29-29-24	SERIES 90	S90-100PV
83040646	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-E1-AA-N-B-TA-VN-EN-N-A-20-NN-036-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83040647	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-8-N-0-C6-W-00-EEA-00-00-F0	SERIES 90	S90-055MF
83040648	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-A-M1-C1-N-D8-H-G1-H3-L-42-L-42-N-E-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83040649	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-A-A2-C1-N-D8-H-G1-H3-L-42-L-42-N-E-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83040668	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-HE-HE-N-C-TB-CN-JN-N-A-10-NN-017-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83040670	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-1-BC-60-P-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83040683	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A5-C2-N-D6-H-G1-NN-L-45-L-45-M-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83040684	PUMP-VAR-DISPL CW 90PV100	90R100-KA-1-BC-80-R-3-C7-F-03-GBA-42-42-24	SERIES 90	S90-100PV
83040695	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-BC-80-P-4-F1-E-00-GBA-32-32-24	SERIES 90	S90-100PV
83040699	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-5-CD-80-S-3-F1-F-C5-GBA-38-38-24	SERIES 90	S90-100PV

83040702	PUMP-VAR-DISPL CCW H1PV069	H1-P-069-L-A-A9-C1-N-D3-H-F4-H5-L-45-L-45-F-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83040703	PUMP-VAR-DISPL CW H1PV069	H1-P-069-R-A-A9-C1-N-D3-H-F4-H5-L-45-L-45-F-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83040707	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A4-C2-B-D8-H-G1-H3-L-28-L-28-C-P-32-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83040716	PUMP-TANDEM, VAR DISPL CCW H1T053L	H1-T-053-L-A-N-A4-C2-N-E7-F-G1-TN-25-25-33-33-M-P-30-PN-NNN-S01	H1-MP PUMPS	H1-045PT/053PT
83040717	MOTOR-VAR-DISPL H1B080	H1-B-080-A-TA-DA-N-B-TA-DN-HN-N-A-10-NN-027-Z-21-NNN	H1-HP MOTORS	H1-080MB1
83040723	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E2-AA-N-B-TB-CN-JN-N-A-10-NN-045-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83040724	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E2-AA-N-B-TB-DN-JN-N-A-10-NN-055-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83040730	PUMP-VAR DISPL, CW H1PV210	H1-P-210-R-A-A3-C1-B-D6-C-F8-H6-K-25-K-25-R-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-210PV/250PV
83040737	PUMP-VAR DISPL, CW 90PV075	90-R-075-DD-1-NN-60-S-3-S1-E-GB-GBA-35-35-24	SERIES 90	S90-075PV
83040739	PUMP-VAR-DISPL CW 90PV250	90R250-HF-5-EG-80-T-3-C8-K-03-NNN-42-42-28	SERIES 90	S90-250PV
83040741	PUMP-VAR-DISPL CW 90PV250	90R250-HF-5-CD-80-T-3-C8-K-03-NNN-42-42-28	SERIES 90	S90-250PV
83040747	MOTOR-VAR-DISPL H1B110	H1-B-110-A-TA-DA-N-A-TB-VN-EN-N-A-15-NN-070-Z-16-NNN	H1-HP MOTORS	H1-110MB1
83040752	MOTOR-VAR-DISPL H1B250	H1-B-250-A-T2-D2-N-B-TA-VN-FN-N-A-30-NN-100-Z-25-NNN	H1-HP MOTORS	H1-250MB1
83040753	MOTOR-VAR-DISPL H1B250	H1-B-250-A-T2-D2-N-B-TA-VS-FS-S-A-30-NN-100-Z-25-NNN	H1-HP MOTORS	H1-250MB1
83040755	MOTOR-VARIABLE DISPL SAE_K	K-V-38CN-E-R1F-F10-S-N-N-AF-F16-NNN-NNN	LV / KV MOTORS	L/K-MV
83040761	PUMP-VAR DISPL CCW H1P053L	H1-P-053-L-A-M1-C1-B-E6-F-G5-NN-L-35-L-35-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83040766	PUMP-VAR DISPL, CW H1PV250	H1-P-250-R-A-A5-C2-N-D8-C-F8-E1-L-38-L-38-R-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-210PV/250PV
83040777	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-M1-C3-N-D1-F-G5-H3-35-35-35-35-N-P-26-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83040779	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-N-A4-C3-N-E7-F-G5-H3-35-35-35-35-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83040791	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-E1A5-03-A-N-A-2-F-N-A-25-25-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83040795	PUMP-VAR DISPL, CW H1PV210	H1-P-210-R-A-A5-C3-N-D8-C-F8-E1-L-38-L-38-R-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-210PV/250PV
83040796	PUMP-VAR DISPL, CW H1PV210	H1-P-210-R-A-A5-C3-N-D8-C-G3-H6-L-38-L-38-R-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-210PV/250PV
83040814	MOTOR-VARIABLE DISPL SAE_L	L-V-35EN-F-RNF-F55-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83040816	PUMP-VAR DISPL CW H1P068R	H1-P-068-R-A-A2-C1-N-D3-H-F1-H3-K-38-K-38-F-M-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83040817	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-BC-80-S-3-T4-H-03-GBA-42-42-24	SERIES 90	S90-130PV
83040818	PUMP-VAR-DISPL CCW 90PV130	90L130-MA-5-BC-80-S-3-T4-F-C5-GBA-42-42-24	SERIES 90	S90-130PV
83040820	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-D1-MA-N-B-PA-DS-JS-S-A-10-NN-028-N-30-NNN	H1-HP MOTORS	H1-110MB1
83040821	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-D2-M2-N-B-PB-VS-ES-S-A-15-NN-065-N-30-NNN	H1-HP MOTORS	H1-110MB1
83040822	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-L2-BA-N-B-PB-VS-ES-S-A-15-NN-043-N-00-NNN	H1-HP MOTORS	H1-110MB1
83040823	PUMP-VAR-DISPL CCW H1PV130	H1-P-130-L-B-A5-C2-N-D6-G-G2-NN-L-30-L-30-A-L-28-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83040824	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A5-C2-N-D6-H-G9-NN-L-30-L-30-M-L-28-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83040825	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A5-C2-N-D6-H-G9-H3-L-42-L-42-M-L-28-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83040841	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E2-AA-N-B-TA-DS-JS-S-N-NN-NN-050-R-00-NNN	H1-HP MOTORS	H1-110MB1
83040844	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A4-C3-N-D3-H-G1-H3-L-38-L-38-F-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83040845	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-HE-HE-N-A-TB-CN-JN-N-N-NN-NN-032-R-00-NNN	H1-HP MOTORS	H1-110MB1
83040869	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A5-C2-N-F6-H-G9-H6-L-42-L-42-C-L-28-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV

83040877	PUMP-VAR-DISPL CW H1PV069	H1-P-069-R-A-B5-C1-C-F4-K-F1-H6-K-35-K-35-F-M-28-P2-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83040878	PUMP-VAR-DISPL CW H1PV069	H1-P-069-R-A-B5-C1-C-D3-K-G1-NN-K-35-K-35-F-M-28-P2-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83040879	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A2-C1-N-F5-H-G9-H6-L-45-L-44-N-E-22-PN-C27-NNN	H1-HP PUMPS	H1-069PV/078PV
83040903	PUMP-VAR DISPL, CCW H1PV210	H1-P-210-L-A-A3-C2-N-D6-C-G2-H5-L-42-L-42-R-L-30-PN-NNN-NNN	H1-HP PUMPS	H1-210PV/250PV
83040907	PUMP-VAR DISPL, CW H1PV210	H1-P-210-R-A-A5-C3-B-D8-C-G2-H6-L-35-L-40-W-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-210PV/250PV
83040908	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-HE-HE-N-A-TB-DN-JN-N-A-10-NN-032-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83040909	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-L2-BA-N-A-PB-DS-JS-P-A-15-NN-040-N-00-NNN	H1-HP MOTORS	H1-110MB1
83040954	MOTOR-VAR-DISPL H1B110	H1-B-110-A-TA-DA-N-B-TB-VS-ES-P-A-15-NN-036-Z-23-NNN	H1-HP MOTORS	H1-110MB1
83040956	PUMP-VAR-DISPL CW H1PV069	H1-P-069-R-A-A3-C2-N-D3-H-G1-H3-L-35-L-35-F-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83040961	PUMP-VAR-DISPL CW 90PV130	90R130-KN-5-BC-80-S-4-F1-F-03-GBA-42-42-24	SERIES 90	S90-130PV
83040973	PUMP-VAR-DISPL CCW H1PV089	H1-P-089-L-A-C3-C2-C-D8-K-G9-H3-L-45-L-45-M-P-28-P2-NNN-D6J	H1-HP PUMPS	H1-089PV/100PV
83040974	MOTOR-VAR-DISPL H1B250	H1-B-250-A-L1-BA-N-B-PB-VN-FN-N-A-20-NN-050-N-00-NNN	H1-HP MOTORS	H1-250MB1
83040975	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-1-CD-60-S-4-C6-C-C5-GBA-38-38-20	SERIES 90	S90-055PV
83040976	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-1-AB-60-S-4-S1-C-03-GBA-38-38-20	SERIES 90	S90-055PV
83040977	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-L2-BA-N-A-PA-DS-JS-B-N-NN-NN-016-N-00-NNN	H1-HP MOTORS	H1-080MB1
83040984	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-1-BC-80-L-3-S1-D-03-FAD-32-32-24	SERIES 90	S90-075PV
83040985	PUMP-VAR DISPL, CCW 90PV100	90-L-100-CA-1-BC-80-S-3-C7-E-00-GBA-38-38-24	SERIES 90	S90-100PV
83040988	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-NN-60-S-3-C7-F-00-GBA-38-38-32	SERIES 90	S90-100PV
83041009	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-K-T-B-S-HB-A-A-BJJ-HB-A-HA-B-NNN-***	M46	M46-046PV
83041010	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-A-T-B-S-HB-A-A-BJJ-HB-A-HA-C-NNN-***	M46	M46-046PV
83041011	PUMP-VAR-DISPL CW 90PV100	90R100-KA-1-CD-60-L-4-F1-E-03-GBA-32-32-24	SERIES 90	S90-100PV
83041012	PUMP-VAR DISPL, CW 90PV100	90-R-100-KT-5-CD-80-L-3-S1-F-03-GBA-30-30-28	SERIES 90	S90-100PV
83041013	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-HE-HE-N-B-TA-VN-AN-N-N-NN-NN-041-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83041014	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-HE-HE-N-B-TA-VS-AS-P-N-NN-NN-041-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83041020	MOTOR-VARIABLE DISPL SAE_K	K-V-45DN-A-R4F-F11-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83041026	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A5-C2-N-D8-H-G1-NN-K-40-K-40-D-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83041027	MOTOR-VAR-DISPL H1B110	H1-B-110-A-DH-MA-F-B-PB-VN-EN-N-N-NN-NN-022-N-24-0NN	H1-HP MOTORS	H1-110MB1
83041028	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A5-C2-B-D3-G-G2-H2-L-38-L-38-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83041029	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-E8-C2-N-D3-H-G9-H3-L-42-L-42-M-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83041030	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-L2-BA-N-B-PB-VS-DS-B-A-15-NN-065-N-00-NNN	H1-HP MOTORS	H1-110MB1
83041039	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A5-C2-B-D6-H-G1-NN-L-35-L-35-C-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83041063	PUMP-VAR DISPL CW H1P068R	H1-P-068-R-A-A5-C2-B-D6-H-F1-H5-L-30-L-30-C-L-26-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83041064	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A5-C2-B-D6-F-G5-H2-L-33-L-33-B-L-26-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83041067	MOTOR-VAR-DISPL H1B110	H1-B-110-A-DH-MA-D-B-PB-VN-DN-N-A-10-NN-050-N-23-NNN	H1-HP MOTORS	H1-110MB1
83041076	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-CD-80-S-M-C8-J-03-NNN-26-26-28	SERIES 90	S90-180PV
83041077	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-T2-DA-N-A-TB-DN-KN-N-A-15-NN-035-Z-30-NNN	H1-HP MOTORS	H1-110MB1

83041086	PUMP-TANDEM, VAR DISPL CCW H1T045L	H1-T-045-L-A-N-A2-C2-N-E7-F-G1-TN-38-38-38-38-M-P-24-PN-NNN-S01	H1-MP PUMPS	H1-045PT/053PT
83041087	PUMP-VAR-DISPL CCW 90PV100	90L100-KN-1-BC-80-S-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83041091	PUMP-VAR-DISPL CCW 90PV100	90L100-HS-1-NN-80-S-4-S1-F-02-GBA-29-29-24	SERIES 90	S90-100PV
83041112	MOTOR-VAR-DISPL H1B250	H1-B-250-A-L2-BA-N-A-PA-VS-FS-B-A-20-NN-070-N-00-NNN	H1-HP MOTORS	H1-250MB1
83041126	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E2-AA-N-B-TB-VN-EN-N-A-15-NN-047-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83041135	PUMP-VAR-DISPL CCW H1PV130	H1-P-130-L-B-A3-C1-N-D3-G-G2-NN-L-42-L-42-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83041139	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-M1-CA-N-B-RB-CS-JS-S-A-10-NN-037-N-00-NNN	H1-HP MOTORS	H1-110MB1
83041140	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-HE-HE-N-B-TA-CN-JN-N-N-NN-NN-026-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83041146	PUMP-VAR-DISPL CCW 90PV130	90L130-KT-1-NN-80-L-4-F1-H-02-GBA-23-23-20	SERIES 90	S90-130PV
83041148	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-BC-80-P-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-075PV
83041155	PUMP-VAR DISPL CW H1P068R	H1-P-068-R-A-A3-C1-N-D8-H-G1-H3-L-20-L-20-C-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83041156	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-E1-AA-N-B-TB-VN-FN-N-A-20-NN-032-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83041160	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A7-C2-C-D6-K-F1-H3-L-42-L-42-C-L-28-P2-NNN-D3F	H1-HP PUMPS	H1-069PV/078PV
83041166	MOTOR-VAR-DISPL H1B250	H1-B-250-A-LH-BA-D-B-PA-VN-FN-N-N-NN-NN-168-N-00-NNN	H1-HP MOTORS	H1-250MB1
83041172	MOTOR-VARIABLE DISPL SAE_L	L-V-30DN-C-RNF-F00-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83041181	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A9-C1-N-D6-F-G5-H2-L-42-L-42-B-L-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83041182	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A9-C1-N-D6-F-G5-H2-L-35-L-35-B-L-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83041187	PUMP-VAR-DISPL CW 90PV130	90R130-KN-5-CD-80-L-4-C8-H-03-GBA-42-42-24	SERIES 90	S90-130PV
83041189	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A2-C3-N-D3-H-G1-NN-L-30-L-30-F-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83041191	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A5-C2-N-D3-G-G2-H6-L-42-L-42-A-M-28-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83041192	PUMP-VAR-DISPL CCW H1PV130	H1-P-130-L-B-A5-C2-N-D3-G-G2-H6-L-42-L-42-A-M-28-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83041199	PUMP-VAR-DISPL CCW H1PV089	H1-P-089-L-A-A3-C2-N-D3-H-G9-NN-L-35-L-35-M-M-20-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83041200	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E2-AA-N-B-TB-VS-CS-B-A-10-NN-040-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83041206	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-1-BC-60-S-3-C6-D-03-GBA-35-35-20	SERIES 90	S90-055PV
83041207	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A5-C2-N-D6-H-G9-H5-L-38-L-38-M-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83041208	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-P2-DA-N-B-TA-CS-GS-B-A-10-NN-032-Z-24-NNN	H1-HP MOTORS	H1-060MB1
83041215	PUMP-VAR DISPL CCW H1P060L	H1-P-060-L-A-A2-C1-B-D8-K-G1-NN-L-30-L-30-F-P-24-P4-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83041218	PUMP-VAR DISPL, CW 90PV075	90-R-075-MS-1-BC-80-P-3-S1-E-02-GBA-42-42-24	SERIES 90	S90-075PV
83041225	PUMP-VAR-DISPL CCW H1PV130	H1-P-130-L-B-A5-C2-N-D8-G-G3-H4-L-40-L-40-A-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83041226	MOTOR-VAR-DISPL H1B160	H1-B-160-A-LH-BA-I-B-PA-DS-KS-P-N-NN-NN-032-N-00-NNN	H1-HP MOTORS	H1-160MB1
83041227	PUMP-VAR-DISPL CW 90PV075	90R075-HF-1-BC-60-S-3-C7-D-04-GBA-21-21-18	SERIES 90	S90-075PV
83041245	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-K2-K2-N-A-RB-VS-DS-S-A-20-NN-063-N-30-NNN	H1-HP MOTORS	H1-160MB1
83041246	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A2-C2-B-D6-G-G3-H6-L-45-L-45-A-L-30-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83041264	PUMP-VAR DISPL CCW H1P053L	H1-P-053-L-A-E8-C1-N-D8-J-G5-H5-L-30-L-35-B-P-24-P4-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83041265	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-E8-C1-N-D8-J-G5-H5-L-35-L-35-B-P-24-P4-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83041266	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-E8-C1-N-D8-J-G5-NN-L-35-L-35-B-P-24-P4-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV

83041268	PUMP-VAR-DISPL CW 90PV075	90R075-KA-1-CD-60-L-4-S1-D-03-GBA-26-26-24	SERIES 90	S90-075PV
83041271	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-B8-C2-C-D8-G-G2-H4-L-40-L-40-A-P-30-P1-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83041272	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E2-AA-N-B-TB-CN-DN-N-A-15-NN-023-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83041281	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-G3AN-50-P-3-X-N-H-5-A-21-21-B-8-8-NNN-NNN	SERIES 42	S42-028PV/032PV
83041284	MOTOR-VAR-DISPL H1B110	H1-B-110-A-LH-BA-O-B-PB-VN-EN-N-A-10-NN-030-N-00-NNN	H1-HP MOTORS	H1-110MB1
83041289	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-CD-80-P-3-S1-F-03-EBC-35-35-24	SERIES 90	S90-100PV
83041299	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A4-C2-N-D3-H-G9-H5-L-42-L-42-M-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83041300	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A2-C2-N-D8-F-G5-H2-L-30-L-30-B-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83041301	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A3-C3-N-D3-G-G3-H3-L-45-L-45-A-M-28-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83041310	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KT-1-BC-80-P-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83041311	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KT-1-BC-80-R-4-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83041312	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KT-1-NN-80-R-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83041314	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-7-N-0-S1-W-00-EFT-00-00-G0	SERIES 90	S90-075MF
83041326	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-C3-C2-C-D3-L-G2-H6-L-42-L-42-L-M-30-P2-NNN-D6F	H1-HP PUMPS	H1-115PV/130PV
83041346	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-N-A5-C2-N-F7-F-G5-H2-35-35-35-35-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83041365	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-J-S-B-J-BA-A-A-BGG-CE-A-GG-3-NNN-***	M46	M46-046PV
83041367	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A4-C2-B-D3-G-G3-H6-L-33-L-33-A-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83041368	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A3-C3-N-D8-G-G2-H4-K-42-K-42-A-P-28-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83041369	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A3-C3-N-D8-G-G3-H6-K-42-K-42-A-P-28-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83041371	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A5-C2-N-D8-G-G3-NN-L-42-L-42-A-P-28-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83041372	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A4-C2-N-D6-H-G9-NN-L-45-L-45-M-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83041373	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-L1-BA-N-A-PA-VN-DN-N-A-30-NN-062-N-00-NNN	H1-HP MOTORS	H1-160MB1
83041374	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-C3-C2-C-D3-K-G9-NN-L-42-L-42-C-M-26-P2-NNN-D6J	H1-HP PUMPS	H1-069PV/078PV
83041375	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-B7-C2-C-D8-J-G5-NN-L-42-L-42-B-P-28-P2-NNN-D5J	H1-MP PUMPS	H1-045PV/053PV
83041376	PUMP-VAR-DISPL CW 90PV075	90R075-KN-1-CD-80-S-4-S1-C-03-GBA-35-35-24	SERIES 90	S90-075PV
83041394	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-A-A5-C2-N-D6-H-G1-NN-L-25-L-25-M-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83041395	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-A-A5-C2-N-D6-H-G1-H2-L-25-L-25-M-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83041396	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-B7-C2-C-D8-J-G5-H2-L-42-L-42-B-P-28-P2-NNN-D5J	H1-MP PUMPS	H1-045PV/053PV
83041405	PUMP-VAR DISPL, CW 90PV055	90-R-055-KN-1-NN-80-R-4-S1-D-03-GBA-32-32-24	SERIES 90	S90-055PV
83041406	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E2-AA-N-B-TA-CS-JS-B-N-NN-NN-050-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83041409	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A4-C2-N-D3-G-G2-H3-L-42-L-42-L-M-20-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83041412	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A7-C3-C-D8-K-F1-H5-L-45-L-45-D-P-28-P2-NNN-D3E	H1-HP PUMPS	H1-089PV/100PV
83041419	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A5-C2-B-D8-H-G1-H3-L-35-L-35-C-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83041429	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-M1-C1-N-D3-G-G3-H2-L-28-L-28-L-M-34-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83041430	MOTOR-FIX DISPL MMF044D	MMF-044-D-A-A-2-C-T-NNN-***	M35/44	044MF
83041443	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-T1-DA-N-B-TB-DN-KN-N-A-20-NN-108-Z-18-NNN	H1-HP MOTORS	H1-160MB1

83041451	PUMP-VAR-DISPL CCW 90PV042	90L042-KA-1-BB-80-S-3-C3-C-03-GBA-23-23-24	SERIES 90	S90-042PV
83041455	MOTOR-VARIABLE REVERSING CARTRIDGE K	K-M-45DN-F-EF1-N18-S-N-N-BF-F18-NNB-FNN	LV / KV MOTORS	L/K-RDM
83041456	MOTOR-VAR-DISPL H1B060	H1-B-060-A-DH-MH-B-C-PA-CS-GS-S-A-05-NN-024-N-18-NNN	H1-HP MOTORS	H1-060MB1
83041457	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-A7NB-03-B-3-G-2-F-N-B-25-25-B-N-N-NNN-NBN	SERIES 42	S42-028PV/032PV
83041467	PUMP-VAR-DISPL CCW 90PV130	90L130-HF-5-DE-80-S-3-C8-H-00-GBA-42-42-24	SERIES 90	S90-130PV
83041468	PUMP-VAR-DISPL CCW 90PV130	90L130-HF-5-NN-80-S-3-F1-H-00-GBA-42-42-24	SERIES 90	S90-130PV
83041491	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-1-NN-80-R-3-S1-C-03-GBA-20-20-24	SERIES 90	S90-055PV
83041497	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A5-C2-B-D6-H-G1-H2-L-30-L-30-C-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83041498	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E2-AA-N-B-TB-VS-DS-B-A-10-NN-065-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83041506	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-BC-80-S-M-C8-J-03-NNN-29-29-24	SERIES 90	S90-180PV
83041526	PUMP-VAR DISPL, CW 90PV075	90-R-075-HF-1-NN-80-S-4-S1-E-03-GBA-17-17-26	SERIES 90	S90-075PV
83041530	MOTOR-VARIABLE DISPL SAE_K	K-V-38CN-A-R2F-F08-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83041548	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A5-C2-N-D3-H-G1-NN-L-35-L-35-C-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83041550	PUMP-VAR-DISPL CCW 90PV100	90L100-HF-5-CD-60-D-4-F1-L-03-GBA-35-35-28	SERIES 90	S90-100PV
83041551	PUMP-VAR-DISPL CCW H1PV115	H1-P-115-L-B-A5-C3-B-D8-G-G2-H6-L-25-L-25-L-P-30-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83041559	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E1-AA-N-B-TB-CS-GS-B-A-10-NN-032-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83041560	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E1-AA-N-B-TB-CN-GN-N-A-10-NN-032-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83041561	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E1-AA-N-B-TB-CS-JS-B-A-10-NN-055-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83041562	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E1-AA-N-B-TB-CN-JN-N-A-10-NN-055-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83041563	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E1-AA-N-B-TB-DS-KS-B-A-15-NN-069-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83041564	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E1-AA-N-B-TB-DN-KN-N-A-15-NN-069-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83041565	PUMP-VAR DISPL CCW H1P060L	H1-P-060-L-A-A4-C1-N-D8-H-G1-NN-L-42-L-42-F-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83041567	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-HE-HE-N-B-TA-VS-ES-S-A-10-NN-000-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83041572	MOTOR-VARIABLE DISPL SAE_K	K-V-45DN-A-R1F-F55-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83041575	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-BB-60-P-3-F1-D-C3-GBA-38-38-24	SERIES 90	S90-100PV
83041576	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-D-E2D8-03-D-N-F-3-H-N-B-23-23-B-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83041577	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-C-E2D8-03-D-N-F-3-H-N-A-23-23-B-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83041578	PUMP-VAR-DISPL CCW H1PV115	H1-P-115-L-B-A5-C3-B-D8-G-G2-H3-L-25-L-25-L-P-30-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83041580	PUMP-VAR DISPL CCW H1P068L	H1-P-068-L-A-A5-C3-B-D8-H-F1-H5-L-23-L-23-C-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83041581	MOTOR-VAR-DISPL H1B110	H1-B-110-A-DH-MA-R-B-PB-DN-KN-N-N-NN-NN-036-N-28-NNN	H1-HP MOTORS	H1-110MB1
83041582	MOTOR-VAR-DISPL H1B160	H1-B-160-A-DH-MA-R-B-PB-DN-LN-N-N-NN-NN-053-N-28-NNN	H1-HP MOTORS	H1-160MB1
83041583	MOTOR-VAR-DISPL H1B080	H1-B-080-A-DH-MA-R-B-PB-DN-JN-N-N-NN-NN-026-N-28-NNN	H1-HP MOTORS	H1-080MB1
83041584	MOTOR-VAR-DISPL H1B060	H1-B-060-A-DH-MA-R-B-PB-DN-HN-N-N-NN-NN-020-N-28-NNN	H1-HP MOTORS	H1-060MB1
83041597	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A5-C3-B-D3-G-G3-H3-L-35-L-35-A-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83041616	PUMP-TANDEM, VAR DISPL CCW H1T045L	H1-T-045-L-A-N-A5-C3-N-F7-F-G1-TN-35-35-35-35-M-P-24-PN-NNN-S01	H1-MP PUMPS	H1-045PT/053PT
83041617	MOTOR-VAR-DISPL H1B080	H1-B-080-A-LH-BA-F-B-PB-VN-AN-N-N-NN-NN-020-N-00-NNN	H1-HP MOTORS	H1-080MB1

83041618	MOTOR-VAR-DISPL H1B080	H1-B-080-A-LH-BA-F-B-PB-CS-JS-P-A-10-NN-030-N-00-NNN	H1-HP MOTORS	H1-080MB1
83041619	MOTOR-VAR-DISPL H1B080	H1-B-080-A-LH-BA-F-B-PB-CS-JS-P-A-10-NN-054-N-00-NNN	H1-HP MOTORS	H1-080MB1
83041620	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-HF-HF-N-B-TA-VN-JN-N-A-10-NN-053-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83041621	MOTOR-VAR-DISPL H1B080	H1-B-080-A-LH-BA-B-B-PB-CS-JS-P-A-10-NN-030-N-00-NNN	H1-HP MOTORS	H1-080MB1
83041630	PUMP-VAR-DISPL CW 90PV180	90R180-KA-1-NN-80-T-M-C8-H-00-NNN-26-26-24	SERIES 90	S90-180PV
83041633	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-BC-80-S-3-S1-C-03-FAD-35-35-24	SERIES 90	S90-055PV
83041634	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-A-A5-C3-B-D6-H-G1-H3-L-45-L-45-M-L-30-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83041636	PUMP-VAR-DISPL CW H1PV069	H1-P-069-R-A-A7-C2-C-D3-K-G1-H3-L-45-L-45-C-M-28-P2-NNN-D3E	H1-HP PUMPS	H1-069PV/078PV
83041637	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-M1-CA-N-A-RA-DN-KN-N-A-15-NN-000-N-00-NNN	H1-HP MOTORS	H1-110MB1
83041639	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-5-NN-80-P-3-C6-C-00-GBA-35-35-24	SERIES 90	S90-055PV
83041640	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A4-C3-N-D8-F-G5-NN-L-30-L-30-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83041649	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A5-C2-B-F6-H-G9-H6-L-38-L-38-M-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83041650	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HS-5-BC-80-R-3-S1-D-02-GBA-42-42-24	SERIES 90	S90-055PV
83041651	PUMP-VAR-DISPL CCW H1PV147	H1-P-147-L-C-A4-C2-N-D8-G-G3-H6-L-38-L-38-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83041653	MOTOR-VARIABLE CARTRIDGE K	K-C-38CN-E-R3F-F12-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83041655	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-5-BC-80-S-4-C8-J-05-NNN-42-42-24	SERIES 90	S90-250PV
83041657	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A2-C1-N-E7-F-G1-T3-30-30-30-30-M-P-24-PN-NNN-S01	H1-MP PUMPS	H1-045PT/053PT
83041662	PUMP-VAR-DISPL CCW H1PV147	H1-P-147-L-C-A4-C2-N-D8-G-G3-H2-L-38-L-38-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83041664	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A3-C1-N-D8-K-G1-NN-L-35-L-35-M-P-34-P4-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83041672	PUMP-VAR-DISPL CCW 90PV075	90L075-HS-5-BC-60-R-4-S1-E-03-GBA-26-26-28	SERIES 90	S90-075PV
83041687	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-T2-D2-N-B-TB-VS-FS-S-A-30-NN-100-Z-25-NNN	H1-HP MOTORS	H1-160MB1
83041688	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-BC-80-D-3-S1-L-00-GBA-29-17-24	SERIES 90	S90-075PV
83041694	PUMP-TANDEM, VAR DISPL CCW H1T045L	H1-T-045-L-A-N-A5-C3-N-F7-F-G1-TN-35-35-35-35-M-P-30-PN-NNN-S01	H1-MP PUMPS	H1-045PT/053PT
83041695	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A3-C2-N-D8-H-F1-NN-L-42-L-38-N-E-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83041701	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-D1-M1-N-B-PB-DS-KS-S-A-20-NN-050-N-30-NNN	H1-HP MOTORS	H1-160MB1
83041702	PUMP-VAR-DISPL CCW 90PV075	90L075-HS-5-BC-80-S-4-S1-D-02-GBA-29-29-24	SERIES 90	S90-075PV
83041703	MOTOR-VAR-DISPL H1B160	H1-B-160-A-DH-MH-A-B-PB-VN-EN-N-A-30-NN-056-N-25-NNN	H1-HP MOTORS	H1-160MB1
83041704	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E1-AA-N-B-TB-DS-JS-B-N-NN-NN-055-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83041706	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HS-1-AB-80-L-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83041707	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HS-1-BC-80-L-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83041708	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-CD-80-L-3-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83041709	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-NN-80-L-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83041711	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-HE-HE-N-B-TA-VN-AN-N-N-NN-NN-036-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83041712	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-HE-HE-N-B-TA-VS-AS-P-N-NN-NN-036-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83041715	MOTOR-VAR-DISPL H1B080	H1-B-080-A-DH-MA-A-B-PB-VN-AN-N-N-NN-NN-042-N-16-NNN	H1-HP MOTORS	H1-080MB1
83041716	PUMP-VAR-DISPL CW 90PV075	90R075-CB-1-NN-60-S-3-S1-E-00-GBA-38-38-20	SERIES 90	S90-075PV

83041740	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A2-C1-N-E5-F-G5-NN-L-42-L-42-N-E-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83041741	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A2-C1-N-E5-F-G5-H5-L-42-L-42-N-E-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83041745	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-3-N-0-S1-W-00-NNN-00-00-E4	SERIES 90	S90-075MF
83041746	PUMP-VAR DISPL, CW S45PVOC_E	ER-R-130B-LS-25-21-NN-N-3-S1NL-A1N-AAA-NNN-NNN	SERIES 45	S45-E Frame PV
83041759	MOTOR-VAR-DISPL H1B080	H1-B-080-A-TA-DA-N-B-TB-VS-CS-S-A-05-NN-033-Z-16-NNN	H1-HP MOTORS	H1-080MB1
83041763	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-E1-AA-N-B-TB-VN-EN-N-A-20-NN-085-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83041766	MOTOR-VAR-DISPL H1B080	H1-B-080-A-TA-DA-N-B-TA-VN-AN-N-N-NN-NN-016-Z-16-NNN	H1-HP MOTORS	H1-080MB1
83041771	PUMP-VAR DISPL, CCW H1PV250	H1-P-250-L-A-A4-C1-N-D8-C-G3-NN-L-35-L-35-W-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-210PV/250PV
83041772	PUMP-VAR-DISPL CW H1PV069	H1-P-069-R-A-A4-C2-N-D6-H-G1-H3-L-42-L-42-C-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83041780	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-A1N5-03-C-2-A-2-F-N-B-34-34-B-H-H-NNN-NBN	SERIES 42	S42-028PV/032PV
83041801	PUMP-VAR DISPL, CW 90PV075	90-R-075-KN-1-NN-80-R-4-T1-D-03-GBA-21-21-24	SERIES 90	S90-075PV
83041804	PUMP-VAR DISPL, CW H1PV210	H1-P-210-R-A-A3-C3-N-D8-C-G2-H3-L-45-L-45-R-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-210PV/250PV
83041805	PUMP-VAR DISPL, CW H1PV250	H1-P-250-R-A-A3-C3-N-D8-C-G2-H3-L-45-L-45-R-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-210PV/250PV
83041806	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-BC-80-L-3-F1-H-04-GBA-38-38-24	SERIES 90	S90-130PV
83041826	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-L2-BA-N-B-PB-CS-JS-S-A-10-NN-022-N-00-NNN	H1-HP MOTORS	H1-110MB1
83041831	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-P1-D1-N-B-TA-DS-KS-S-A-20-NN-045-Z-24-NNN	H1-HP MOTORS	H1-160MB1
83041832	PUMP-VAR-DISPL CCW H1PV165	H1-P-165-L-C-A4-C2-N-D8-G-G3-H3-L-42-L-42-L-P-30-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83041833	PUMP-VAR DISPL, CW 90PV075	90-R-075-HS-5-NN-80-S-3-S1-D-02-GBA-35-35-20	SERIES 90	S90-075PV
83041839	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-M1-C2-B-F5-H-G1-H6-K-30-K-30-D-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83041840	PUMP-VAR-DISPL CCW 90PV075	90L075-KA-5-AB-80-R-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83041841	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-5-AB-80-R-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83041842	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-P1-D1-N-B-TA-DS-JS-S-A-10-NN-041-Z-24-NNN	H1-HP MOTORS	H1-110MB1
83041844	PUMP-VAR-DISPL CW 90PV180	90R180-HF-2-CD-80-T-C-C8-J-03-NNN-40-40-24	SERIES 90	S90-180PV
83041847	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-HE-HE-N-B-TB-VN-CN-N-A-05-NN-040-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83041863	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-BC-80-P-3-S1-C-03-FAD-35-35-24	SERIES 90	S90-055PV
83041865	PUMP-VAR DISPL, CCW 90PV055	90-L-055-MA-1-BC-80-R-4-C6-C-03-FAD-35-35-24	SERIES 90	S90-055PV
83041866	PUMP-VAR DISPL, CW 90PV055	90-R-055-CB-1-NN-60-S-3-C6-C-00-GBA-38-38-20	SERIES 90	S90-055PV
83041885	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-E1A4-02-B-3-G-2-H-N-B-21-21-B-A-A-NNN-BNN	SERIES 42	S42-028PV/032PV
83041906	MOTOR-VAR-DISPL H1B250	H1-B-250-A-E2-AA-N-B-TB-VN-FN-N-A-20-NN-100-Z-00-NNN	H1-HP MOTORS	H1-250MB1
83041909	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-L1-BA-N-B-PA-DS-JS-S-A-10-NN-000-N-00-NNN	H1-HP MOTORS	H1-080MB1
83041910	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-L1-BA-N-B-PB-DS-JS-S-A-10-NN-000-N-00-NNN	H1-HP MOTORS	H1-080MB1
83041913	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A7-C3-C-D8-L-G2-H6-L-45-L-45-L-P-28-P2-NNN-D3E	H1-HP PUMPS	H1-115PV/130PV
83041914	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A7-C3-C-D8-L-G2-H6-L-45-L-45-L-P-28-P2-NNN-D3E	H1-HP PUMPS	H1-115PV/130PV
83041915	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A5-C2-B-D6-H-G9-H2-L-33-L-33-M-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83041920	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-A-S-B-AA-T-A-BFF-BA-A-GG-C-NNN-***	M46	M46-046PV
83041924	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-A4-C2-N-D3-G-G2-H3-L-35-L-35-L-M-26-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV

83041925	MOTOR-VAR-DISPL H1B080	H1-B-080-A-TA-DA-N-B-TA-VS-BS-S-A-10-NN-050-Z-24-NNN	H1-HP MOTORS	H1-080MB1
83041926	PUMP-VAR-DISPL CCW 90PV100	90L100-HF-5-NN-80-S-4-C6-F-00-GBA-17-35-24	SERIES 90	S90-100PV
83041937	PUMP-VAR DISPL, CW H1PV250	H1-P-250-R-A-A5-C2-N-D8-C-G2-H5-L-20-L-30-W-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-210PV/250PV
83041939	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-B1-C2-N-D8-F-G5-H3-L-30-L-30-B-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83041940	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A5-C2-N-D8-H-F1-H5-L-40-L-40-C-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83041942	PUMP-VAR-DISPL 42PV041 CW	42-R-51-D-E1A6-02-B-D-G-2-F-N-A-30-30-B-N-N-NNN-NBN	SERIES 42	S42-041PV/051PV
83041951	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-NN-80-L-4-S1-C-03-GBA-26-26-24	SERIES 90	S90-055PV
83041952	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-CD-80-L-4-S1-C-03-GBA-26-26-24	SERIES 90	S90-055PV
83041954	MOTOR-VAR-DISPL H1B060	H1-B-060-A-TA-DA-N-B-TB-CS-GS-B-N-NN-NN-015-R-16-NNN	H1-HP MOTORS	H1-060MB1
83041956	PUMP-VAR-DISPL CCW 90PV100	90L100-KP-5-CD-80-R-3-F1-F-03-GBA-38-38-24	SERIES 90	S90-100PV
83041957	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-K-T-B-B-AA-A-A-BJJ-BA-A-GG-B-NNN-***	M46	M46-046PV
83041958	PUMP-VAR DISPL, CCW H1PV250	H1-P-250-L-A-A5-C2-N-D8-C-G3-H6-L-35-L-35-W-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-210PV/250PV
83041965	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A7-C3-C-D8-L-G2-H6-L-45-L-45-N-E-28-P2-NNN-D3E	H1-HP PUMPS	H1-115PV/130PV
83041969	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-8-N-0-S1-W-00-NNN-00-00-F0	SERIES 90	S90-100MF
83041970	MOTOR-VAR-DISPL H1B080	H1-B-080-A-LH-BA-D-C-PB-CS-JS-S-A-10-NN-045-N-00-NNN	H1-HP MOTORS	H1-080MB1
83041993	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A4-C3-N-D8-H-G1-H3-L-42-L-42-N-E-20-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83041996	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E1-AA-N-B-TB-VN-EN-N-N-NN-NN-050-S-00-NNN	H1-HP MOTORS	H1-110MB1
83041999	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E2-AA-N-B-TA-DN-HN-N-N-NN-NN-020-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83042028	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A5-C2-B-D8-F-G5-H2-L-42-L-42-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83042029	PUMP-TANDEM, VAR DISPL MPT044D	MPT-044-D-A-W-R-A-BA-B-A-A-A-BHH-DR-A-FF-B-C-A-A-BHH-DR-A-FF-1-NNN-	M35/44	O44PT
83042032	PUMP-VAR-DISPL CCW H1PV130	H1-P-130-L-B-A5-C2-N-D8-G-G3-NN-L-28-L-28-A-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83042034	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-BC-60-P-3-C7-D-03-GBA-38-38-24	SERIES 90	S90-075PV
83042035	PUMP-VAR-DISPL CCW H1PV130	H1-P-130-L-B-A5-C2-N-D8-G-G3-H3-L-35-L-35-A-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83042038	MOTOR-VAR-DISPL H1B110	H1-B-110-A-LH-BA-K-B-PA-CN-JN-N-A-10-NN-039-N-00-NNN	H1-HP MOTORS	H1-110MB1
83042039	MOTOR-VAR-DISPL H1B160	H1-B-160-A-LH-BA-H-B-PB-DN-LN-N-N-NN-NN-080-N-00-NNN	H1-HP MOTORS	H1-160MB1
83042045	PUMP-VAR-DISPL CCW 90PV130	90L130-KT-5-BC-80-P-3-F1-H-04-GBA-38-38-24	SERIES 90	S90-130PV
83042046	MOTOR-FIX DISPL 90MF075	90-M-075-NC-0-N-3-N-0-C6-W-00-NNN-00-00-F3	SERIES 90	S90-075MF
83042060	PUMP-VAR-DISPL 42PV028 CCW	42-L-28-C-E1B6-01-A-N-A-2-H-N-B-23-23-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83042068	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-CD-80-P-3-F1-E-00-GBA-35-35-24	SERIES 90	S90-100PV
83042070	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-NN-80-S-3-S1-E-02-GBA-42-42-24	SERIES 90	S90-100PV
83042071	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-CD-80-S-3-F1-E-02-GBA-42-42-24	SERIES 90	S90-100PV
83042072	PUMP-VAR DISPL, CW 90PV075	90-R-075-HS-1-CD-80-P-4-C7-E-03-GBA-35-35-24	SERIES 90	S90-075PV
83042073	PUMP-VAR DISPL, CW 90PV075	90-R-075-HS-1-NN-80-P-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-075PV
83042086	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-NN-60-S-3-C7-D-03-GBA-14-14-20	SERIES 90	S90-075PV
83042093	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-M2-D1-B-D6-F-G5-H2-L-35-L-35-B-L-24-H1-NNN-M00	H1-MP PUMPS	H1-045PV/053PV
83042094	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-E1A3-02-C-2-N-N-F-N-A-25-25-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV

83042095	PUMP-VAR-DISPL CCW DDC20	DDC-20-A-L-LB-RSA-NN-A-N-5-AA-ACA0-D-07-21N-21N-NNN-NNN	DDC20/LDU20	OSK-020PV - DO NOT USE
83042096	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-E1A3-02-B-2-B-3-F-N-B-25-25-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83042097	PUMP-VAR-DISPL CCW DDC20	DDC-20-A-L-LB-LSA-NN-A-N-5-AA-ACA0-D-07-21N-21N-NNN-NNN	DDC20/LDU20	OSK-020PV - DO NOT USE
83042100	PUMP-TANDEM, VAR DISPL CCW H1T045L	H1-T-045-L-A-N-A2-C1-N-E7-F-G1-H3-40-40-40-40-N-P-30-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83042101	PUMP-TANDEM, VAR DISPL CCW H1T053L	H1-T-053-L-A-N-A4-C2-N-E7-F-G5-TN-28-28-30-30-M-P-30-PN-NNN-S01	H1-MP PUMPS	H1-045PT/053PT
83042103	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-L1-BA-N-B-PA-VS-DS-S-A-30-NN-000-N-00-NNN	H1-HP MOTORS	H1-160MB1
83042108	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-L1-BA-N-B-PA-VS-ES-S-B-40-NN-095-N-00-NNN	H1-HP MOTORS	H1-160MB1
83042109	PUMP-VAR DISPL, CW H1PV250	H1-P-250-R-A-A5-C2-N-D8-C-G2-H6-L-35-L-35-W-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-210PV/250PV
83042111	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-CD-80-S-3-C8-K-03-NNN-38-38-24	SERIES 90	S90-250PV
83042116	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A4-C2-N-D6-H-G9-H5-L-42-L-42-M-L-28-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83042120	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A5-C2-N-D8-F-G4-NN-L-35-L-35-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83042138	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-A-T-B-B-AA-T-A-BFF-BA-A-GG-C-NNN-***	M46	M46-046PV
83042139	PUMP-VAR-DISPL CCW 90PV100	90L100-KP-5-CD-80-R-3-S1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
83042147	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A2-C2-N-F5-H-G1-H6-L-33-L-33-C-P-28-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83042160	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-D-S-B-J-HA-A-A-BHH-HA-A-HA-B-NNN-***	M46	M46-046PV
83042164	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A5-C2-N-D8-F-G5-NN-L-30-L-30-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83042165	PUMP-VAR-DISPL CCW H1PV130	H1-P-130-L-B-A5-C2-N-D3-G-G2-H5-L-33-L-33-A-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83042184	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-NN-80-L-4-S1-C-03-GBA-32-32-24	SERIES 90	S90-055PV
83042185	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-NN-80-L-4-S1-C-03-GBA-32-32-24	SERIES 90	S90-055PV
83042191	PUMP-VAR-DISPL CW 90PV250	90R250-KN-5-BC-80-S-4-C8-K-06-NNN-42-42-24	SERIES 90	S90-250PV
83042192	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-K-S-B-J-BA-A-A-BHF-CB-A-RR-4-NNN-***	M46	M46-046PV
83042197	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-E2-AA-N-A-TB-VS-FS-S-B-40-NN-096-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83042198	PUMP-VAR-DISPL CCW 90PV130	90L130-KN-1-NN-80-R-4-F1-H-03-EEB-35-35-24	SERIES 90	S90-130PV
83042210	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E1-AA-N-B-TA-DS-JS-B-N-NN-NN-061-R-00-NNN	H1-HP MOTORS	H1-110MB1
83042218	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A5-C2-N-F6-H-G9-H6-L-35-L-35-C-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83042219	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A5-C2-N-D6-H-G1-H2-L-35-L-35-C-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83042225	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A4-C2-N-D6-H-F1-H5-L-45-L-45-C-L-26-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83042227	PUMP-VAR-DISPL CCW 90PV100	90L100-KN-5-NN-60-S-3-C7-E-03-GBA-36-36-24	SERIES 90	S90-100PV
83042230	PUMP-VAR-DISPL CW H1PV069	H1-P-069-R-A-A7-C2-C-F4-K-G1-H6-L-45-L-45-C-M-28-P2-NNN-D3F	H1-HP PUMPS	H1-069PV/078PV
83042231	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-F7NN-53-V-N-F-2-F-N-A-34-25-B-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
83042234	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-1-N-0-S1-W-00-EEA-00-00-F3	SERIES 90	S90-055MF
83042238	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A5-C1-N-D6-F-G5-NN-L-40-L-40-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83042240	MOTOR-VAR-DISPL H1B250	H1-B-250-A-L2-BA-N-B-PB-VS-DS-B-N-NN-NN-090-N-00-NNN	H1-HP MOTORS	H1-250MB1
83042241	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HF-1-BB-60-S-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-055PV
83042243	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-1-NN-60-S-3-C6-C-03-GBA-35-35-24	SERIES 90	S90-075PV
83042244	PUMP-VAR-DISPL CCW H1PV069	H1-P-069-L-A-A5-C2-N-D8-H-G1-H2-L-38-L-15-C-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV

83042245	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A5-C2-N-F5-H-G3-H6-L-38-L-15-M-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83042246	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A5-C2-N-F5-H-F4-H6-L-38-L-15-M-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83042265	PUMP-VAR-DISPL CCW H1PV130	H1-P-130-L-B-A5-C2-N-D3-G-G2-H5-L-42-L-42-A-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83042268	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-AB-80-R-3-S1-D-C5-GBA-38-38-24	SERIES 90	S90-075PV
83042273	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-BC-80-R-3-S1-D-03-GBA-29-29-24	SERIES 90	S90-100PV
83042275	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KN-1-NN-80-R-4-S1-F-03-GBA-24-24-24	SERIES 90	S90-100PV
83042277	MOTOR-VAR-DISPL H1B110	H1-B-110-A-TA-DA-N-B-TB-VN-KN-N-N-NN-NN-065-Z-16-NNN	H1-HP MOTORS	H1-110MB1
83042278	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-P2-DA-N-A-TB-DS-GS-S-A-10-NN-012-Z-24-NNN	H1-HP MOTORS	H1-060MB1
83042282	MOTOR-VAR-DISPL H1B110	H1-B-110-A-DH-MH-Y-B-PA-VN-DN-N-A-10-NN-050-N-25-NNN	H1-HP MOTORS	H1-110MB1
83042294	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-1-CD-80-S-3-S1-C-04-GBA-38-38-28	SERIES 90	S90-055PV
83042297	PUMP-TANDEM, VAR DISPL CCW H1T053L	H1-T-053-L-A-N-A2-C1-N-E7-F-G1-H3-38-38-38-38-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83042324	MOTOR-VARIABLE REVERSING CARTRIDGE L	L-M-25CN-F-EF2-N24-S-N-N-BF-F18-NNA-FNN	LV / KV MOTORS	L/K-RDM
83042325	MOTOR-VARIABLE REVERSING CARTRIDGE K	K-M-38CN-F-EF2-N18-S-N-N-BF-F18-NNA-FNN	LV / KV MOTORS	L/K-RDM
83042326	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-HE-HE-N-B-TB-VN-AN-N-N-NN-NN-035-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83042328	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-HF-HF-N-A-TB-VN-EN-N-A-20-NN-055-S-00-NNN	H1-HP MOTORS	H1-160MB1
83042331	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A5-C1-N-D6-F-G5-NN-L-25-L-25-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83042332	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-D-N-0-C6-W-00-EBA-00-00-E6	SERIES 90	S90-055MF
83042338	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-L1-BA-N-A-PA-VS-DS-S-A-30-NN-062-N-00-NNN	H1-HP MOTORS	H1-160MB1
83042352	PUMP-VAR DISPL, CCW H1PV210	H1-P-210-L-A-A3-C1-N-D8-C-G3-NN-L-45-L-45-R-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-210PV/250PV
83042353	PUMP-VAR DISPL, CCW H1PV250	H1-P-250-L-A-A3-C1-N-D8-C-G3-NN-L-42-L-42-R-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-210PV/250PV
83042370	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-NN-60-L-4-S1-C-03-GBA-42-42-24	SERIES 90	S90-075PV
83042371	PUMP-VAR DISPL, CCW 90PV100	90-L-100-DD-1-AB-60-R-4-S1-F-GB-GBA-35-35-24	SERIES 90	S90-100PV
83042376	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-C2-C2-C-D3-K-G9-NN-L-42-L-42-D-M-26-P2-NNN-D4F	H1-HP PUMPS	H1-089PV/100PV
83042379	PUMP-VAR-DISPL CW H1PV069	H1-P-069-R-A-A7-C2-C-F4-K-G1-H6-L-45-L-45-C-M-28-P2-NNN-D3E	H1-HP PUMPS	H1-069PV/078PV
83042381	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-T1-DA-N-B-TB-DN-KN-N-A-15-NN-074-Z-18-NNN	H1-HP MOTORS	H1-110MB1
83042406	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-HE-HE-N-A-TB-VN-EN-N-A-20-NN-050-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83042411	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A5-C3-B-F6-H-G1-H6-L-42-L-42-C-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83042412	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A5-C3-B-F6-H-F1-H6-L-42-L-42-C-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83042420	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A2-C2-N-E5-F-G1-H5-L-20-L-20-B-P-18-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83042421	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A2-C2-N-E5-F-G5-H3-L-20-L-20-B-P-18-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83042424	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-L2-BA-N-B-PA-VS-CS-B-A-10-NN-000-N-00-NNN	H1-HP MOTORS	H1-080MB1
83042425	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A5-C2-N-D6-H-G1-H2-L-42-L-42-C-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83042431	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-B-V-C-B-BA-B-B-A-A-BJJ-CB-A-JJ-B-D-A-A-BJJ-CB-A-JJ-B-NNN-***	M46	M46-046PT
83042442	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-B-V-C-B-BA-B-B-A-A-BJJ-BA-A-GG-B-D-A-A-BJJ-BA-A-GG-B-NNN-**	M46	M46-046PT
83042445	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E2-AA-N-B-TB-CS-JS-B-A-10-NN-028-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83042448	PUMP-VAR DISPL, CW 90PV055	90-R-055-HF-5-AB-60-S-3-C6-C-03-GBA-42-42-24	SERIES 90	S90-055PV

83042453	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-5-NN-80-R-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83042455	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A5-C2-B-D6-H-F1-NN-L-33-L-33-C-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83042468	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-A-A7-C2-C-F5-K-G9-H6-L-45-L-45-M-P-28-P2-NNN-D3F	H1-HP PUMPS	H1-089PV/100PV
83042469	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A7-C2-C-F5-K-G9-H6-L-45-L-45-M-P-28-P2-NNN-D3F	H1-HP PUMPS	H1-089PV/100PV
83042470	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-D1-MA-N-C-PB-VS-AS-P-A-05-NN-030-N-30-NNN	H1-HP MOTORS	H1-080MB1
83042484	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A5-C2-B-D6-H-G9-H2-L-28-L-28-C-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83042485	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A5-C2-B-F6-H-G9-H6-L-28-L-28-C-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83042486	PUMP-VAR-DISPL CW 90PV130	90R130-HS-5-AB-80-L-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-130PV
83042489	PUMP-VAR-DISPL CCW 90PV075	90L075-KN-5-CD-60-S-3-C7-D-03-GBA-30-30-24	SERIES 90	S90-075PV
83042490	PUMP-VAR-DISPL CCW 90PV075	90L075-KN-5-NN-60-S-3-S1-D-03-GBA-30-30-24	SERIES 90	S90-075PV
83042502	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A5-C2-N-D6-H-F1-H2-K-35-K-35-F-L-20-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83042503	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A5-C2-N-D6-H-F1-H3-K-35-K-35-F-L-20-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83042511	PUMP-VAR-DISPL CW 90PV100	90R100-FC-5-CD-80-P-7-F1-F-B9-GCA-38-38-24	SERIES 90	S90-100PV
83042513	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-AB-60-R-3-F1-F-00-GBA-35-35-24	SERIES 90	S90-100PV
83042514	MOTOR-VAR-DISPL H1B250	H1-B-250-A-E1-AA-N-A-TB-VN-FN-N-A-20-NN-050-R-00-NNN	H1-HP MOTORS	H1-250MB1
83042517	MOTOR-VAR-DISPL H1B160	H1-B-160-A-DH-MH-Y-B-PA-VN-DN-N-A-20-NN-040-N-25-NNN	H1-HP MOTORS	H1-160MB1
83042518	MOTOR-VAR-DISPL H1B110	H1-B-110-A-DH-MH-Y-B-PA-VN-DN-N-A-10-NN-030-N-25-NNN	H1-HP MOTORS	H1-110MB1
83042521	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A4-C2-B-D5-G-G3-H4-L-35-L-35-A-M-30-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83042522	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A4-C2-B-D5-G-G2-H4-L-35-L-35-A-M-30-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83042523	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A4-C2-B-D3-G-G3-H4-L-38-L-38-L-M-30-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83042524	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A2-C2-N-F5-H-F1-H6-L-33-L-33-C-P-28-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83042544	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A5-C3-N-D3-G-G2-H4-K-42-K-42-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83042545	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A5-C3-N-D3-G-G3-NN-K-42-K-42-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83042552	PUMP-VAR-DISPL CW 90PV180	90R180-FH-1-BC-80-S-7-C8-H-B1-NNN-35-26-24	SERIES 90	S90-180PV
83042553	PUMP-VAR-DISPL CW 90PV100	90R100-FH-1-NN-80-P-7-F1-D-B1-GBA-35-26-24	SERIES 90	S90-100PV
83042554	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-E2-AA-N-B-TB-VS-ES-S-N-NN-NN-060-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83042562	PUMP-VAR-DISPL CW 90PV075	90R075-HS-1-AB-60-P-3-C7-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83042563	PUMP-VAR-DISPL CW 90PV100	90R100-HF-1-AB-60-P-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83042564	PUMP-VAR-DISPL CW 90PV075	90R075-KP-1-AB-60-P-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-075PV
83042568	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A5-C2-B-D8-F-G1-H2-L-28-L-28-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83042574	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-BB-80-R-3-C3-C-00-GBA-20-20-24	SERIES 90	S90-042PV
83042575	PUMP-VAR-DISPL CW 90PV042	90R042-KA-5-BC-80-R-3-C3-C-00-GBA-20-20-24	SERIES 90	S90-042PV
83042576	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-T2-DA-N-B-TA-VN-KN-N-N-NN-NN-065-Z-16-NNN	H1-HP MOTORS	H1-110MB1
83042577	MOTOR-VAR-DISPL H1B110	H1-B-110-A-TA-DA-N-B-TA-VN-KN-N-N-NN-NN-065-Z-16-NNN	H1-HP MOTORS	H1-110MB1
83042578	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-E8-C2-N-D9-G-G2-H4-L-38-L-20-L-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83042579	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-E8-C2-N-D6-H-G1-NN-L-38-L-20-C-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV

83042580	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-E8-C2-N-D6-G-G3-H6-L-38-L-20-L-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83042585	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-M1-CA-N-A-RA-DS-AS-S-A-10-NN-000-N-00-NNN	H1-HP MOTORS	H1-080MB1
83042606	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-B-V-C-B-BA-B-B-A-A-BJJ-BC-A-HH-B-D-A-A-BJJ-BC-A-HH-B-NNN-***	M46	M46-046PT
83042607	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-B-V-C-B-BA-B-B-A-A-BJJ-BA-A-HH-B-D-A-A-BJJ-BA-A-HH-B-NNN-***	M46	M46-046PT
83042611	PUMP-VAR-DISPL CCW 90PV250	90L250-KT-5-CD-80-T-4-C8-K-03-NNN-29-29-24	SERIES 90	S90-250PV
83042619	MOTOR-VAR-DISPL H1B060	H1-B-060-A-TH-HA-N-B-TA-DN-GN-N-A-10-NN-017-Z-16-NNN	H1-HP MOTORS	H1-060MB1
83042630	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E2-AA-N-B-TB-DN-KN-N-N-NN-NN-024-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83042654	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-BC-80-P-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-055PV
83042660	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-CD-80-P-3-C6-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83042661	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-BC-80-P-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83042685	PUMP-VAR-DISPL 42PV028 CW	42-R-28-C-E2D8-03-C-2-A-2-H-N-A-34-34-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83042686	PUMP-VAR-DISPL 42PV028 CW	42-R-28-D-E2D8-03-C-2-A-2-H-N-B-34-34-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
83042687	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A5-C2-B-D6-H-G1-H2-L-28-L-28-C-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83042699	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-NN-80-S-C-C8-J-03-NNN-35-35-24	SERIES 90	S90-180PV
83042707	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A4-C2-B-D3-G-G3-H4-L-38-L-38-A-M-30-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83042708	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A4-C2-B-D5-G-G2-H4-L-38-L-38-A-M-30-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83042709	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A4-C2-B-D5-G-G3-H4-L-38-L-38-A-M-30-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83042714	PUMP-VAR DISPL, CW 90PV055	90-R-055-HS-1-CD-80-R-3-C6-D-04-GBA-35-29-24	SERIES 90	S90-055PV
83042716	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E2-AA-N-B-TB-DS-KS-P-A-10-NN-040-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83042729	MOTOR-VAR-DISPL H1B160	H1-B-160-A-TA-D1-N-B-TA-CS-ES-B-A-20-NN-108-Z-24-NNN	H1-HP MOTORS	H1-160MB1
83042730	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-B-S-B-B-HA-A-A-BJJ-HA-A-HD-A-NNN-***	M46	M46-046PV
83042733	PUMP-VAR-DISPL CCW H1PV165	H1-P-165-L-C-A5-C3-N-D8-G-G2-NN-L-45-L-45-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83042734	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A5-C3-N-D8-H-G1-H5-L-42-L-42-M-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83042748	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-A-A9-C2-B-D3-H-G1-NN-L-38-L-38-M-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83042756	MOTOR-VAR-DISPL H1B160#	H1-B-160-A-F2-EA-N-A-TB-DN-LN-N-N-NN-NN-064-T-00-NNN	H1-HP MOTORS	H1-160MB1
83042757	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-NN-80-R-4-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83042761	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HS-1-BC-60-R-4-S1-E-03-GBA-26-26-28	SERIES 90	S90-075PV
83042767	PUMP-VAR-DISPL CW 90PV075	90R075-HF-1-AB-60-P-3-C7-D-03-GBA-35-35-24	SERIES 90	S90-075PV
83042768	PUMP-VAR-DISPL CW 90PV250	90R250-KN-5-EG-80-T-3-C8-K-03-NNN-40-40-28	SERIES 90	S90-250PV
83042769	PUMP-VAR-DISPL CW 90PV250	90R250-KN-5-CD-80-T-3-C8-K-03-NNN-40-40-28	SERIES 90	S90-250PV
83042770	MOTOR-VAR-DISPL H1B110	H1-B-110-A-TA-DA-N-B-TA-DN-KN-N-N-NN-NN-065-Z-16-NNN	H1-HP MOTORS	H1-110MB1
83042778	PUMP-VAR-DISPL CW 90PV130	90R130-MA-5-AB-80-P-3-F1-H-C5-GBA-35-35-24	SERIES 90	S90-130PV
83042784	PUMP-VAR-DISPL CCW 90PV100	90L100-KP-1-CD-80-S-3-C7-E-02-GBA-42-42-24	SERIES 90	S90-100PV
83042787	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-E-V-C-J-AA-B-A-A-A-BRR-AB-U-EA-B-C-A-A-BRR-AB-D-EA-B-NNN-***	M46	M46-046PT
83042790	PUMP-VAR-DISPL CCW H1PV069	H1-P-069-L-A-A8-C1-C-D3-K-F1-H3-L-41-L-41-F-M-28-P2-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83042791	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-M2-CA-N-C-RA-VN-EN-N-A-30-NN-060-N-00-NNN	H1-HP MOTORS	H1-160MB1

83042792	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-B8-C2-C-D8-J-G1-H5-L-38-L-38-B-P-26-P2-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83042795	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A4-C2-N-F4-H-G9-H6-L-42-L-42-M-M-20-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83042796	PUMP-VAR-DISPL CW H1PV069	H1-P-069-R-A-A4-C2-B-D3-H-G1-H3-L-42-L-42-C-M-20-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83042797	PUMP-VAR-DISPL CW H1PV069	H1-P-069-R-A-A4-C1-B-D6-H-F1-H5-L-35-L-35-F-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83042801	PUMP-VAR DISPL CCW H1P060L	H1-P-060-L-A-A5-C1-B-D3-H-G1-H2-L-35-L-35-C-M-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83042833	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A3-C3-N-D5-G-G2-H4-K-35-K-35-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83042834	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A3-C3-N-D3-G-G3-H3-K-35-K-35-A-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83042842	PUMP-VAR DISPL, CW H1PV250	H1-P-250-R-A-A5-C3-B-D8-C-G2-H3-L-38-L-38-N-E-30-PN-NNN-NNN	H1-HP PUMPS	H1-210PV/250PV
83042846	PUMP-VAR-DISPL CCW H1PV130	H1-P-130-L-B-A4-C2-N-D6-G-G3-H3-K-30-L-42-L-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83042853	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-T2-DA-N-B-TB-VS-DS-S-A-15-NN-074-Z-18-NNN	H1-HP MOTORS	H1-110MB1
83042857	PUMP-VAR DISPL, CW H1PV250	H1-P-250-R-A-A4-C2-N-J1-C-G2-H3-L-45-L-45-Y-D-24-PN-NNN-GAG	H1-HP PUMPS	H1-210PV/250PV
83042858	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-C2-C2-C-D5-L-G2-H4-L-45-L-45-L-M-30-P2-NNN-D4E	H1-HP PUMPS	H1-147PV/165PV
83042876	PUMP-VAR DISPL, CW 90PV055	90-R-055-MS-1-NN-60-P-3-C6-C-03-FAD-35-35-24	SERIES 90	S90-055PV
83042887	MOTOR-VAR-DISPL H1B060	H1-B-060-A-LH-BA-I-B-PA-VN-AN-N-N-NN-NN-000-N-00-NNN	H1-HP MOTORS	H1-060MB1
83042892	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-AB-80-R-3-C8-H-03-GCA-35-35-24	SERIES 90	S90-130PV
83042896	PUMP-VAR DISPL, CW H1PV210	H1-P-210-R-A-A3-C3-N-D8-C-G3-H4-L-40-L-40-R-P-30-PN-NNN-NNN	H1-HP PUMPS	H1-210PV/250PV
83042901	PUMP-VAR DISPL, CW H1PV250	H1-P-250-R-A-A5-C2-B-D8-C-G2-H6-L-35-L-35-W-P-18-PN-NNN-NNN	H1-HP PUMPS	H1-210PV/250PV
83042910	PUMP-TANDEM, VAR DISPL CCW H1T053L	H1-T-053-L-A-N-A5-C2-N-E7-F-G1-T2-38-28-28-38-M-P-24-PN-NNN-S01	H1-MP PUMPS	H1-045PT/053PT
83042911	MOTOR-VAR-DISPL H1B110	H1-B-110-A-TA-DA-N-B-TB-VN-EN-N-A-15-NN-050-Z-22-NNN	H1-HP MOTORS	H1-110MB1
83042912	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-B7-C2-C-D3-K-G9-H2-L-45-L-45-M-M-26-P2-NNN-D5F	H1-HP PUMPS	H1-089PV/100PV
83042915	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-H-S-B-B-BA-A-A-BJJ-CN-A-HH-3-NNN-***	M46	M46-046PV
83042916	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-HE-HE-N-B-TB-VN-AN-N-N-NN-NN-053-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83042917	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A2-C2-B-D8-G-G3-H3-L-42-L-42-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83042929	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-HE-HE-N-B-TB-VS-AS-B-A-05-NN-019-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83042930	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A3-C1-N-D8-H-G9-NN-L-38-L-38-C-P-22-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83042931	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-K1-K1-N-C-RA-DN-JN-N-A-10-NN-027-N-25-NNN	H1-HP MOTORS	H1-110MB1
83042932	MOTOR-VAR-DISPL H1B080	H1-B-080-A-DH-MH-L-C-PA-DN-HN-N-A-10-NN-045-N-23-NNN	H1-HP MOTORS	H1-080MB1
83042933	MOTOR-VAR-DISPL H1B250	H1-B-250-A-T2-DA-N-A-TB-VS-FS-B-A-20-NN-050-Z-30-NNN	H1-HP MOTORS	H1-250MB1
83042934	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-M2-CA-N-B-RA-CS-JS-B-A-10-NN-030-N-00-NNN	H1-HP MOTORS	H1-080MB1
83042935	MOTOR-VAR-DISPL H1MB060	H1-B-060-A-M2-CA-N-B-RA-CS-HS-B-A-10-NN-030-N-00-NNN	H1-HP MOTORS	H1-060MB1
83042936	MOTOR-VAR-DISPL H1B060	H1-B-060-A-TH-HC-N-B-TA-DN-GN-N-A-10-NN-017-Z-16-NNN	H1-HP MOTORS	H1-060MB1
83042941	PUMP-VAR-DISPL CCW H1PV130	H1-P-130-L-B-E8-C3-N-D3-G-G3-H6-L-38-L-35-A-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83042942	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A3-C3-N-D6-H-G1-NN-L-28-L-28-D-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83042943	PUMP-VAR-DISPL CCW H1PV165	H1-P-165-L-C-A3-C3-N-D9-G-G3-H4-L-28-L-28-A-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83042944	PUMP-VAR-DISPL CCW H1PV130	H1-P-130-L-B-E8-C3-N-D3-G-G3-NN-L-30-L-25-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83042945	PUMP-VAR-DISPL CW 90PV180	90R180-KP-5-CD-80-T-M-F1-H-03-FAC-35-35-24	SERIES 90	S90-180PV

83042946	PUMP-VAR-DISPL CW 90PV075	90R075-KN-1-BC-80-P-4-T2-E-00-GBA-35-35-24	SERIES 90	S90-075PV
83042948	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-5-CD-80-P-4-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83042965	PUMP-VAR-DISPL CW 90PV100	90R100-HF-1-BC-60-R-4-S1-E-03-GBA-29-29-24	SERIES 90	S90-100PV
83042966	PUMP-VAR DISPL, CW H1PV210	H1-P-210-R-A-A5-C2-N-D8-C-F8-H4-L-33-L-20-R-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-210PV/250PV
83042967	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A5-C2-N-D8-G-G3-NN-L-35-L-28-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83042968	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-T2-DA-N-A-TB-VN-EN-N-N-NN-NN-040-Z-28-NNN	H1-HP MOTORS	H1-110MB1
83042969	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E1-AA-N-B-TA-DN-JN-N-A-10-NN-055-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83042981	MOTOR-VAR-DISPL H1B060	H1-B-060-A-TA-DA-N-A-TB-VN-AN-N-N-NN-NN-020-Z-20-NNN	H1-HP MOTORS	H1-060MB1
83042985	PUMP-VAR DISPL, CW 90PV075	90-R-075-KN-1-BC-80-P-4-T2-E-00-GBA-35-35-24	SERIES 90	S90-075PV
83042986	PUMP-VAR DISPL, CW 90PV100	90-R-100-KN-1-BC-80-P-4-T2-E-00-GBA-35-35-24	SERIES 90	S90-100PV
83042988	PUMP-VAR DISPL C CW H1P060L	H1-P-060-L-A-B1-C3-B-D8-H-G1-H3-L-30-L-30-C-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83042993	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-DE-80-R-3-F1-F-00-GBA-14-14-20	SERIES 90	S90-130PV
83042997	PUMP-VAR DISPL, C CW 90PV055	90-L-055-KP-1-NN-80-P-4-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV
83042998	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-L2-BA-N-B-PB-CN-LN-N-A-15-NN-000-N-00-NNN	H1-HP MOTORS	H1-160MB1
83043000	MOTOR-VAR-DISPL H1B080	H1-B-080-A-DH-MA-Q-B-PB-VN-AN-N-A-10-NN-054-N-24-NNN	H1-HP MOTORS	H1-080MB1
83043011	PUMP-VAR-DISPL CW 90PV130	90R130-KA-1-NN-80-L-3-F1-H-03-GBA-38-38-20	SERIES 90	S90-130PV
83043017	MOTOR-VAR-DISPL H1B080	H1-B-080-A-TA-DA-N-B-TA-VN-AN-N-A-05-NN-016-Z-16-NNN	H1-HP MOTORS	H1-080MB1
83043018	MOTOR-FIX DISPL 90MF055	90-M-055-NC-0-N-7-N-0-S1-W-00-EEA-00-00-E4	SERIES 90	S90-055MF
83043020	MOTOR-VAR-DISPL H1B250	H1-B-250-A-F2-EA-N-B-TB-VN-DN-N-A-30-NN-050-Z-00-NNN	H1-HP MOTORS	H1-250MB1
83043021	PUMP-VAR-DISPL C CW H1PV147	H1-P-147-L-C-A5-C2-N-D8-G-G3-H3-L-42-L-42-A-P-30-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83043022	PUMP-VAR-DISPL C CW H1PV147	H1-P-147-L-C-A5-C2-N-D8-G-G3-H2-L-42-L-42-A-P-30-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83043023	MOTOR-VAR-DISPL H1B250	H1-B-250-A-T2-DA-N-B-TA-VN-FN-N-A-30-NN-085-Z-30-NNN	H1-HP MOTORS	H1-250MB1
83043032	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-L1-BA-N-B-PA-VN-AN-N-A-10-NN-016-N-00-NNN	H1-HP MOTORS	H1-080MB1
83043039	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-AB-80-R-3-C8-H-03-GCA-35-35-24	SERIES 90	S90-130PV
83043040	PUMP-VAR-DISPL C CW H1PV147	H1-P-147-L-C-A5-C2-N-D7-G-G2-H4-L-42-L-42-A-P-30-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83043041	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-B8-C2-C-D8-J-G4-H3-L-35-L-35-B-P-30-P2-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83043042	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E2-AA-N-B-TB-DN-JN-N-A-10-NN-024-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83043043	PUMP-VAR-DISPL CW 90PV100	90R100-MA-1-NN-80-S-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
83043049	PUMP-VAR-DISPL C CW H1PV100	H1-P-100-L-A-A3-C3-N-D8-H-G1-H3-L-45-L-45-D-P-30-PN-C07-NNN	H1-HP PUMPS	H1-089PV/100PV
83043073	PUMP-VAR-DISPL CW H1PV069	H1-P-069-R-A-E7-C2-N-F6-H-F1-H6-L-42-L-42-F-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83043075	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-L2-BA-N-A-PA-VS-DS-S-A-20-NN-000-N-00-NNN	H1-HP MOTORS	H1-160MB1
83043077	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-M2-CA-N-B-RA-CS-JS-S-A-10-NN-030-N-00-NNN	H1-HP MOTORS	H1-080MB1
83043078	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A5-C2-N-D8-G-G3-H4-L-42-L-42-A-P-28-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83043080	PUMP-VAR-DISPL C CW H1PV089	H1-P-089-L-A-A5-C2-B-D6-H-G1-NN-L-35-L-35-M-L-30-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83043081	PUMP-VAR DISPL C CW H1P045L	H1-P-045-L-A-A3-C3-B-D6-F-G5-NN-L-23-L-23-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83043082	PUMP-VAR-DISPL CW DDC20	DDC-20-A-R-RB-RSA-NN-A-N-3-AA-ACA0-D-07-14N-14N-NNN-NNN	DDC20/LDU20	OSK-020PV - DO NOT USE

83043090	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-L1-BA-N-B-PB-VS-DS-B-B-40-NN-058-N-00-NNN	H1-HP MOTORS	H1-160MB1
83043096	PUMP-VAR-DISPL CW 90PV180	90R180-KA-2-CD-80-S-C-C8-J-03-NNN-42-42-24	SERIES 90	S90-180PV
83043104	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A7-C1-C-F4-K-G9-H6-L-45-L-45-D-M-26-P2-NNN-D3F	H1-HP PUMPS	H1-089PV/100PV
83043111	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A4-C1-N-F5-H-F1-H6-L-45-L-45-M-P-26-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83043113	PUMP-VAR-DISPL CCW 90PV250	90L250-HF-5-CD-80-T-3-C8-K-03-NNN-35-35-24	SERIES 90	S90-250PV
83043124	MOTOR-FIX DISPL MMF035D	MMF-035-D-A-A-U-A-G-NNN-***	M35/44	035MF
83043126	PUMP-VAR-DISPL 42PV041 CW	42-R-41-D-F5NN-72-J-D-G-2-F-N-B-30-30-N-C-C-NNN-NNN	SERIES 42	S42-041PV/051PV
83043127	PUMP-TANDEM, VAR DISPL CCW H1T045L	H1-T-045-L-A-N-A4-C2-N-E7-F-G1-H3-35-35-35-35-N-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83043128	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-HE-HE-N-B-TB-CS-GS-P-A-10-NN-030-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83043129	PUMP-VAR-DISPL 42PV041 CW	42-R-41-C-E1A5-02-C-4-A-2-C-N-A-17-17-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83043132	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-1-CD-60-D-3-C7-L-00-GBA-42-42-24	SERIES 90	S90-075PV
83043136	PUMP-VAR-DISPL CW 90PV075	90R075-KA-5-BC-80-P-3-T6-E-03-GBA-38-38-28	SERIES 90	S90-075PV
83043137	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-D-S-B-J-BA-A-A-BRR-CD-A-GG-B-NNN-***	M46	M46-046PV
83043141	PUMP-VAR-DISPL 42PV041 CW	42-R-41-C-E1A6-03-B-3-B-3-F-N-A-34-34-B-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
83043144	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A2-C3-B-E6-J-G5-H2-K-30-K-30-B-L-20-P4-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83043145	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-HE-HE-N-B-TB-DS-KS-P-N-NN-NN-055-Z-00-N13	H1-HP MOTORS	H1-110MB1
83043150	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-B7-C1-C-D8-K-G1-H3-L-42-L-42-M-P-26-P2-NNN-D5J	H1-HP PUMPS	H1-089PV/100PV
83043152	MOTOR-VAR-DISPL H1B160	H1-B-160-A-DH-MA-I-B-PB-VN-EN-N-A-10-NN-046-N-25-NNN	H1-HP MOTORS	H1-160MB1
83043161	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A5-C2-N-F4-H-F1-H6-L-35-L-35-D-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83043162	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A5-C2-N-D3-H-G1-H2-L-35-L-35-D-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83043182	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-L1-BA-N-B-PB-VS-AS-S-A-05-NN-022-N-00-NNN	H1-HP MOTORS	H1-080MB1
83043186	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-1-AB-80-P-3-S1-C-03-GBA-29-29-28	SERIES 90	S90-055PV
83043193	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-M2-CA-N-B-RB-VS-DS-P-A-20-NN-000-N-00-NNN	H1-HP MOTORS	H1-160MB1
83043194	MOTOR-VAR-DISPL H1B080	H1-B-080-A-TA-DA-N-B-TB-CN-JN-N-N-NN-NN-016-R-16-NNN	H1-HP MOTORS	H1-080MB1
83043200	MOTOR-VAR-DISPL H1B060	H1-B-060-A-LH-BA-E-B-PB-CS-GS-P-N-NN-NN-015-N-00-NNN	H1-HP MOTORS	H1-060MB1
83043201	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-A-Z-C-B-AA-B-B-V-A-BGG-CD-A-HH-B-D-V-A-BGG-CD-A-HH-A-NNN	M46	M46-046PT
83043225	PUMP-VAR-DISPL CW 90PV100	90R100-HF-5-NN-80-R-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83043234	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-BC-60-L-3-S1-E-03-GBA-38-38-20	SERIES 90	S90-100PV
83043235	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-CD-60-L-3-F1-E-03-GBA-38-38-20	SERIES 90	S90-100PV
83043266	MOTOR-VAR-DISPL H1B160	H1-B-160-A-LH-BA-D-B-PA-CS-LS-S-A-20-NN-000-N-00-NNN	H1-HP MOTORS	H1-160MB1
83043279	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A2-C2-B-D8-G-G3-H4-L-33-L-25-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83043280	MOTOR-VAR-DISPL H1B160	H1-B-160-A-TA-D1-N-A-TB-VS-ES-S-A-30-NN-085-Z-30-NNN	H1-HP MOTORS	H1-160MB1
83043281	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-T1-DA-N-B-TB-DN-KN-N-A-20-NN-060-T-30-NNN	H1-HP MOTORS	H1-160MB1
83043292	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A2-C2-N-D6-H-F1-H1-L-40-L-40-D-L-26-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83043293	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-T1-DA-N-B-TB-DN-JN-N-A-10-NN-026-Z-16-NNN	H1-HP MOTORS	H1-080MB1
83043322	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-N-A4-C2-N-E7-F-G1-T3-23-23-23-23-M-P-24-PN-NNN-S01	H1-MP PUMPS	H1-045PT/053PT

83043342	PUMP-VAR-DISPL CW H1PV069	H1-P-069-R-A-A4-C2-N-D6-H-G1-NN-L-30-L-30-C-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83043343	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-A-A5-C2-N-D3-H-G9-H3-L-45-L-15-D-M-30-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83043357	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-AB-60-L-4-C7-F-03-GBA-35-35-24	SERIES 90	S90-100PV
83043364	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A5-C2-N-D8-G-G3-H2-L-42-L-42-A-P-28-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83043369	MOTOR-VARIABLE DISPL SAE_K	K-V-45DN-A-Y2F-F13-S-N-N-AF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83043370	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-A-V-C-B-BA-B-B-V-B-BGG-BC-A-HH-B-D-V-B-BGG-BC-A-HH-B-NNN-	M46	M46-046PT
83043373	PUMP-TANDEM, VAR DISPL MPT025C	MPT-025-C-S-R-A-H-NN-B-A-A-A-BFF-DR-A-FF-B-C-A-A-BFF-DR-A-FF-A-NNN-*	LIGHT DUTY	025PT
83043380	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E2-AA-N-A-TA-CN-GN-N-A-10-NN-000-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83043381	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E2-AA-N-A-TA-CN-HN-N-A-10-NN-000-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83043401	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A5-C2-B-D3-G-G2-H2-L-38-L-38-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83043403	PUMP-VAR-DISPL CW 90PV100	90R100-KA-1-BB-60-L-3-C7-F-02-GBA-42-42-24	SERIES 90	S90-100PV
83043409	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-D1-MA-N-C-PB-VS-AS-P-A-05-NN-020-N-30-NNN	H1-HP MOTORS	H1-080MB1
83043410	PUMP-VAR-DISPL CCW H1PV165	H1-P-165-L-C-A3-C2-N-D8-G-F3-NN-L-42-L-42-A-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83043414	PUMP-VAR DISPL CCW H1P053L	H1-P-053-L-A-A4-C2-N-D8-F-G1-H5-L-38-L-38-B-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83043415	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-1-N-0-S1-W-00-NNN-00-00-F3	SERIES 90	S90-100MF
83043416	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-CD-60-L-3-F1-E-03-GBA-38-38-20	SERIES 90	S90-100PV
83043417	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A8-C3-D-D8-F-G5-H3-L-35-L-35-B-P-30-P1-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83043418	MOTOR-VAR-DISPL H1B250	H1-B-250-A-D2-M2-N-A-PA-VS-DS-S-A-30-NN-082-N-27-NNN	H1-HP MOTORS	H1-250MB1
83043420	TRANSMISSION LDU20 U-STYLE CW	LDU-20D-R-A-R-S-JJ-J-H-N-07-C-25A-30N-NNN-BNN	DDC20/LDU20	OSK-020U - DO NOT USE
83043428	PUMP-VAR-DISPL CW 90PV100	90R100-KA-5-CD-80-S-4-C7-F-03-GBA-38-38-24	SERIES 90	S90-100PV
83043449	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A5-C3-B-D8-H-G1-NN-L-33-L-33-C-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83043450	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A5-C3-N-D8-H-G1-NN-L-33-L-33-C-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83043453	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-A-V-C-B-AA-B-B-A-BJJ-CG-A-HH-B-D-A-A-BJJ-CG-A-HH-B-NNN-*	M46	M46-046PT
83043462	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A5-C2-B-D3-H-F1-H3-L-38-L-38-C-M-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83043469	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-HE-HE-N-B-TB-VS-ES-B-A-20-NN-095-Q-00-NNN	H1-HP MOTORS	H1-160MB1
83043470	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-M2-D3-N-D6-G-G3-H5-L-40-L-40-A-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83043471	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-C-M2-D3-N-D9-G-G3-H4-L-40-L-40-A-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83043487	PUMP-VAR DISPL, CCW H1PV210	H1-P-210-L-A-A5-C2-N-D8-C-G2-H3-L-38-L-38-R-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-210PV/250PV
83043488	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A5-C2-B-D3-G-G2-H3-L-40-L-33-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83043490	PUMP-VAR DISPL, CW H1PV210	H1-P-210-R-A-A3-C1-B-D6-C-F8-E1-L-35-L-20-R-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-210PV/250PV
83043491	PUMP-VAR DISPL, CW H1PV210	H1-P-210-R-A-A3-C1-B-D6-C-G3-H3-L-35-L-20-R-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-210PV/250PV
83043496	MOTOR-VAR-DISPL H1B160	H1-B-160-A-TA-DA-N-B-TB-VN-DN-N-N-NN-NN-044-Z-20-NNN	H1-HP MOTORS	H1-160MB1
83043497	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-L2-BA-N-B-PA-DS-KS-S-A-10-NN-036-N-00-NNN	H1-HP MOTORS	H1-110MB1
83043498	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A3-C1-N-D8-G-G2-H1-L-40-L-40-A-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83043501	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-M1-CA-N-B-RB-CS-KS-S-A-10-NN-037-N-00-NNN	H1-HP MOTORS	H1-110MB1
83043502	PUMP-VAR DISPL, CW H1PV210	H1-P-210-R-A-A3-C1-B-D6-C-F8-H4-L-35-L-20-R-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-210PV/250PV

83043503	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-C-A3-C1-B-D6-G-G3-H3-L-35-L-20-A-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83043517	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A5-C2-N-F4-H-F1-H6-L-28-L-28-F-M-26-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83043518	MOTOR-VAR-DISPL H1B160	H1-B-160-A-LH-BA-D-B-PA-VN-EN-N-N-NN-NN-080-N-00-NNN	H1-HP MOTORS	H1-160MB1
83043525	PUMP-VAR-DISPL CW DDC20	DDC-20-A-R-RB-RSA-NN-A-N-F-DA-BCF0-D-07-21A-21N-NNN-NNN	DDC20/LDU20	OSK-020PV - DO NOT USE
83043526	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A2-C2-N-D3-G-G3-H2-L-42-L-42-L-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83043527	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-1-AB-80-P-4-C6-C-03-GBA-17-17-20	SERIES 90	S90-055PV
83043528	PUMP-VAR-DISPL CCW H1PV147	H1-P-147-L-C-A5-C1-N-D8-G-G2-H3-L-30-L-30-L-P-30-PN-NNN-NNN	H1-HP PUMPS	H1-147PV/165PV
83043531	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-M2-C2-B-D3-G-G2-H2-L-38-L-38-L-M-24-H1-NNN-M00	H1-HP PUMPS	H1-115PV/130PV
83043542	MOTOR-VAR-DISPL H1B160	H1-B-160-A-DH-MA-I-C-PA-VN-EN-N-N-NN-NN-090-N-16-NNN	H1-HP MOTORS	H1-160MB1
83043564	MOTOR-VAR-DISPL H1B060	H1-B-060-A-LH-BA-K-C-PB-CN-GN-N-A-10-NN-025-N-00-NNN	H1-HP MOTORS	H1-060MB1
83043619	PUMP-VAR DISPL MPV035D	MPV-035-D-B-A-Y-R-A-F-NN-A-A-BBB-DL-A-FF-A-NNN-***	M35/44	035PV
83043621	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A2-C2-N-D3-H-G1-NN-L-38-L-38-M-M-26-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83043623	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-D2-M2-N-B-PB-VS-ES-P-A-20-NN-032-N-28-NNN	H1-HP MOTORS	H1-160MB1
83043624	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A3-C1-B-D8-G-F3-NN-L-33-L-33-L-P-28-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83043625	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-L2-BA-N-B-PA-VS-AS-S-A-10-NN-000-N-00-NNN	H1-HP MOTORS	H1-080MB1
83043626	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-L2-BA-N-A-PA-DS-JS-S-A-10-NN-050-N-00-NNN	H1-HP MOTORS	H1-110MB1
83043627	PUMP-VAR-DISPL CW 90PV130	90R130-DD-5-BB-80-P-4-D8-F-GB-GBA-40-40-24-F076	SERIES 90	S90-130PV
83043662	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A8-C2-C-D6-H-G1-H3-L-38-L-38-C-L-32-P1-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83043663	PUMP-VAR DISPL CW H1P068R	H1-P-068-R-A-A8-C2-C-D6-H-G1-H3-L-38-L-38-C-L-32-P1-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83043664	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A8-C2-C-D6-H-G1-H3-L-42-L-42-C-L-32-P1-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83043665	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-K-T-B-J-AA-A-A-BGG-BA-A-JJ-B-NNN-***	M46	M46-046PV
83043670	PUMP-VAR-DISPL CCW 90PV075	90L075-KN-1-CD-80-R-4-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
83043691	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A5-C2-N-D3-H-G1-H2-L-35-L-35-C-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83043704	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A5-C2-B-D3-G-G3-H6-L-42-L-42-A-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83043705	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-A-A5-C2-B-D3-H-G1-NN-L-35-L-35-D-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83043708	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-CD-80-P-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83043715	PUMP-VAR DISPL, CW 90PV075	90-R-075-M8-1-BC-60-P-3-C7-D-03-GBA-29-29-24	SERIES 90	S90-075PV
83043717	MOTOR-VAR-DISPL H1B160	H1-B-160-A-LH-BA-D-B-PB-DN-KN-N-N-NN-NN-045-N-00-NNN	H1-HP MOTORS	H1-160MB1
83043718	MOTOR-VAR-DISPL H1B160	H1-B-160-A-LH-BA-D-B-PB-DS-KS-B-N-NN-NN-045-N-00-NNN	H1-HP MOTORS	H1-160MB1
83043752	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-B7-C2-C-D8-J-G5-H3-L-35-L-35-B-P-30-P2-NNN-D5J	H1-MP PUMPS	H1-045PV/053PV
83043758	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-C3-C2-C-D6-K-G9-H3-L-45-L-45-M-L-32-P2-NNN-D6J	H1-HP PUMPS	H1-089PV/100PV
83043760	PUMP-VAR-DISPL CCW 90PV130	90L130-KN-1-NN-80-S-4-T4-F-03-GBA-35-35-24	SERIES 90	S90-130PV
83043775	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A3-C2-N-D8-H-G1-H2-L-40-L-40-C-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83043777	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-5-NN-80-T-C-C8-J-03-NNN-36-36-24	SERIES 90	S90-180PV
83043781	PUMP-VAR-DISPL CW H1PV069	H1-P-069-R-A-A4-C2-N-D6-H-G9-S1-L-45-L-45-C-L-26-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83043782	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-L1-BA-N-B-PB-CS-KS-S-A-10-NN-044-N-00-NNN	H1-HP MOTORS	H1-110MB1

83043789	PUMP-VAR-DISPL CW 90PV180	90R180-KA-1-BC-80-D-C-C8-L-03-NNN-20-20-24	SERIES 90	S90-180PV
83043792	PUMP-VAR-DISPL CCW H1PV069	H1-P-069-L-A-A4-C2-N-D6-H-G9-NN-L-45-L-45-C-L-26-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83043793	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-L1-BA-N-A-PA-VS-DS-S-A-15-NN-057-N-00-NNN	H1-HP MOTORS	H1-110MB1
83043794	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-M1-CA-N-B-RA-VS-DS-S-A-10-NN-000-N-00-NNN	H1-HP MOTORS	H1-110MB1
83043824	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-E2-AA-N-B-TA-CS-KS-S-A-20-NN-000-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83043825	MOTOR-VAR-DISPL H1B110	H1-B-110-A-TA-DA-N-B-TA-VN-EN-N-N-NN-NN-074-Z-30-NNN	H1-HP MOTORS	H1-110MB1
83043828	PUMP-VAR DISPL, CW 90PV100	90-R-100-KT-1-BC-80-P-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83043835	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-E8-C2-N-D6-H-G1-NN-L-38-L-20-F-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83043844	PUMP-VAR-DISPL CW 90PV100	90R100-KA-6-BC-60-S-3-C7-E-03-GBA-45-45-24	SERIES 90	S90-100PV
83043851	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-BC-80-R-3-S1-C-03-GBA-35-35-20	SERIES 90	S90-055PV
83043852	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A5-C2-N-D6-H-G1-H3-L-23-L-23-D-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83043853	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A5-C2-N-D6-H-G1-H5-L-23-L-23-D-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83043854	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A5-C2-N-D8-H-G1-H3-L-23-L-23-D-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83043855	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A5-C2-N-D8-H-G1-H5-L-23-L-23-D-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83043870	MOTOR-VAR-DISPL H1B060	H1-B-060-A-LH-BA-E-B-PB-CS-HS-P-N-NN-NN-016-N-00-NNN	H1-HP MOTORS	H1-060MB1
83043871	MOTOR-VAR-DISPL H1B060	H1-B-060-A-LH-BA-E-B-PA-CS-HS-P-N-NN-NN-016-N-00-NNN	H1-HP MOTORS	H1-060MB1
83043877	MOTOR-VAR-DISPL H1MB060	H1-B-060-A-L1-BA-N-A-PA-CS-GS-S-A-10-NN-012-N-00-NNN	H1-HP MOTORS	H1-060MB1
83043880	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-B-A7-C2-C-D8-L-G2-H6-L-45-L-45-A-P-30-P2-NNN-D3F	H1-HP PUMPS	H1-115PV/130PV
83043881	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A7-C2-C-D8-L-G2-H6-L-45-L-45-A-P-30-P2-NNN-D3F	H1-HP PUMPS	H1-115PV/130PV
83043889	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-5-BB-60-S-3-S1-C-00-GBA-35-35-24	SERIES 90	S90-055PV
83043891	PUMP-VAR-DISPL CW 90PV250	90R250-MA-1-NN-80-T-4-F1-J-05-NNN-20-20-24	SERIES 90	S90-250PV
83043893	PUMP-VAR-DISPL CCW H1PV130	H1-P-130-L-B-A5-C2-B-D8-G-G2-H6-L-40-L-40-A-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83043899	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-A-E8-C2-N-D6-H-G1-NN-L-42-L-42-D-L-20-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83043900	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-A-E8-C2-N-D6-H-F1-H2-L-42-L-42-D-L-20-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83043901	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-A-E8-C2-N-D6-H-F1-NN-L-42-L-42-D-L-20-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83043928	PUMP-VAR DISPL CCW H1P053L	H1-P-053-L-A-A2-C1-B-D8-J-G4-H3-L-35-L-35-B-P-24-P4-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83043929	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-A9-C1-B-D8-H-G1-H3-L-35-L-35-D-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83043932	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-D2-MA-N-B-PA-DS-LS-P-N-NN-NN-080-N-30-NNN	H1-HP MOTORS	H1-160MB1
83043933	PUMP-VAR DISPL, CW 90PV075	90-R-075-HS-1-BB-60-R-3-S1-E-03-GBA-38-38-28	SERIES 90	S90-075PV
83043939	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A3-C2-B-D6-H-F1-H3-L-35-L-35-C-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83043941	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E2-AA-N-B-TB-DN-JN-N-B-10-NN-035-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83043942	PUMP-VAR DISPL, CW 90PV055	90-R-055-HS-1-NN-80-P-3-C6-C-03-GBA-42-42-24	SERIES 90	S90-055PV
83043943	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-NN-80-L-3-C8-F-03-GBA-42-42-24	SERIES 90	S90-130PV
83043959	PUMP-VAR DISPL, CW 90PV075	90-R-075-HS-1-CD-80-P-3-S1-E-00-GBA-35-35-24	SERIES 90	S90-075PV
83043966	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-A-A7-C3-C-D8-K-F1-H3-L-45-L-45-D-P-28-P2-NNN-D3E	H1-HP PUMPS	H1-089PV/100PV
83043968	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-5-BC-61-S-3-S1-E-C3-FAD-35-35-24	SERIES 90	S90-075PV

83043969	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-5-CD-61-S-3-S1-E-C3-FAD-35-35-24	SERIES 90	S90-075PV
83043974	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-L1-BA-N-A-PB-CS-JS-B-A-05-NN-000-N-00-NNN	H1-HP MOTORS	H1-080MB1
83043977	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-HF-HF-N-A-TB-CN-HN-N-N-NN-NN-016-R-00-NNN	H1-HP MOTORS	H1-080MB1
83043993	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-A-A7-C2-C-F6-K-G1-H6-L-42-L-42-M-L-28-P2-NNN-D3E	H1-HP PUMPS	H1-089PV/100PV
83043995	PUMP-VAR-DISPL CW 90PV250	90R250-KN-1-EG-80-T-3-C8-K-03-NNN-26-26-26	SERIES 90	S90-250PV
83043996	PUMP-VAR-DISPL CW 90PV250	90R250-KN-1-BB-80-T-3-C8-K-03-NNN-26-26-26	SERIES 90	S90-250PV
83044000	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A3-C3-N-F5-H-G9-H6-K-42-K-42-C-P-34-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83044001	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A3-C3-N-D8-H-G1-H3-K-42-K-42-C-P-34-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83044011	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-N-A2-C3-N-E7-F-G5-T3-28-28-28-28-M-P-24-PN-NNN-S01	H1-MP PUMPS	H1-045PT/053PT
83044017	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A3-C3-B-D6-H-F1-NN-L-23-L-23-C-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83044018	PUMP-VAR-DISPL CW 90PV180	90R180-MA-1-NN-80-S-M-C8-J-03-NNN-38-38-24	SERIES 90	S90-180PV
83044029	PUMP-VAR-DISPL CW 90PV100	90R100-KA-1-NN-60-S-3-T2-F-03-FAC-42-42-24	SERIES 90	S90-100PV
83044030	MOTOR-VARIABLE DISPL SAE_K	K-V-45DS-E-RNF-F11-T-N-X-EF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83044045	MOTOR-VARIABLE REVERSING CARTRIDGE L	L-M-25CS-F-RG2-N18-S-N-N-DF-F18-NNB-FNN	LV / KV MOTORS	L/K-RDM
83044046	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-2-AB-80-P-3-C7-E-03-GBA-26-26-24	SERIES 90	S90-100PV
83044051	PUMP-VAR DISPL, CW 90PV075	90-R-075-HS-1-CD-80-P-3-C7-E-00-GBA-35-35-24	SERIES 90	S90-075PV
83044065	PUMP-VAR DISPL, CCW 90PV100	90-L-100-DC-5-AB-80-R-3-S1-E-G8-GBA-38-38-24	SERIES 90	S90-100PV
83044068	MOTOR-VARIABLE DISPL SAE_L	L-V-25CN-C-YNF-F13-S-N-N-AF-F16-NNN-NNN	LV / KV MOTORS	L/K-MV
83044084	MOTOR-FIX DISPL 90MF100	90-M-100-NC-0-N-8-N-0-F1-W-00-NNN-00-00-A0	SERIES 90	S90-100MF
83044099	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-P2-D2-N-B-TB-DS-JS-S-N-NN-NN-025-Z-24-NNN	H1-HP MOTORS	H1-110MB1
83044102	MOTOR-VARIABLE CARTRIDGE L	L-C-25CN-F-RNF-F12-S-N-N-AF-F15-NNN-NNN	LV / KV MOTORS	L/K-MV
83044104	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-P2-D2-N-B-TA-DN-KN-N-A-20-NN-040-Z-24-NNN	H1-HP MOTORS	H1-160MB1
83044107	MOTOR-VARIABLE REVERSING CARTRIDGE L	L-M-35EN-K-RF1-N18-S-N-N-BF-F18-NNN-FNN	LV / KV MOTORS	L/K-RDM
83044108	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A2-C3-N-E5-F-G1-NN-L-25-L-25-B-P-26-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83044111	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A4-C2-N-D8-G-G3-H6-L-45-L-45-L-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83044112	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-E8-C3-N-D8-H-G1-H5-L-30-L-35-C-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83044122	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HF-1-NN-80-R-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-075PV
83044125	PUMP-VAR DISPL, CW 90PV075	90-R-075-HF-1-NN-80-R-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-075PV
83044126	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-BC-80-P-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-055PV
83044128	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-L2-BA-N-B-PB-DS-JS-B-A-10-NN-000-N-00-NNN	H1-HP MOTORS	H1-110MB1
83044132	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-T1-D1-N-B-TB-DN-GN-N-A-10-NN-022-Z-25-NNN	H1-HP MOTORS	H1-060MB1
83044144	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-5-AC-60-P-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83044145	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-5-CD-60-P-4-T2-E-03-GBA-35-35-24	SERIES 90	S90-100PV
83044147	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A2-C2-N-E5-F-G5-H2-L-23-L-18-B-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83044149	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-D2-MA-N-B-PB-VN-EN-N-A-30-NN-035-N-26-NNN	H1-HP MOTORS	H1-160MB1
83044150	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-BC-80-R-4-C7-E-03-GBA-23-23-20	SERIES 90	S90-075PV

83044162	MOTOR-VAR-DISPL H1MB060	H1-B-060-A-K1-KA-N-B-RB-CN-GN-N-N-NN-NN-035-N-28-NNN	H1-HP MOTORS	H1-060MB1
83044166	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A4-C3-N-D6-G-G2-H4-L-45-L-45-L-L-30-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83044167	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A4-C3-N-D6-G-G3-H3-L-45-L-45-L-L-30-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83044168	PUMP-VAR-DISPL CW 90PV130	90R130-KT-1-BC-80-D-3-F1-L-00-GBA-32-32-24	SERIES 90	S90-130PV
83044169	PUMP-VAR-DISPL CW 90PV130	90R130-KT-5-CD-80-L-3-F1-H-03-GBA-29-29-28	SERIES 90	S90-130PV
83044177	MOTOR-VAR-DISPL H1B060	H1-B-060-A-LH-BA-K-B-PA-CS-GS-S-A-10-NN-030-N-00-NNN	H1-HP MOTORS	H1-060MB1
83044178	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A4-C1-N-D6-F-G4-H3-L-35-L-35-B-L-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83044188	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A2-C3-N-E5-F-G1-NN-L-25-L-25-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83044191	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-E7-C2-N-D3-G-G3-H6-L-42-L-42-L-M-26-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83044192	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-K-S-B-J-BA-A-A-BFF-CE-A-HH-B-NNN-***	M46	M46-046PV
83044193	PUMP-VAR-DISPL CW DDC20	DDC-20-A-R-RB-RSA-NN-A-N-3-AA-ACA0-D-07-25N-25N-NNN-NNN	DDC20/LDU20	OSK-020PV - DO NOT USE
83044194	MOTOR-VARIABLE REVERSING CARTRIDGE L	L-M-35ES-K-RF1-N18-S-N-N-DF-F18-NNB-FNN	LV / KV MOTORS	L/K-RDM
83044202	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E2-AA-N-B-TB-DN-KN-N-N-NN-NN-022-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83044204	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-A-A9-C2-N-D8-J-G1-NN-L-35-L-35-B-P-24-P4-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83044206	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A9-C2-N-D8-J-G1-NN-L-35-L-35-B-P-24-P4-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83044208	MOTOR-VAR-DISPL H1MB060	H1-B-060-A-L2-BA-N-B-PB-VN-AN-N-N-NN-NN-030-N-00-NNN	H1-HP MOTORS	H1-060MB1
83044209	PUMP-VAR-DISPL CCW H1PV130	H1-P-130-L-B-A4-C3-N-D3-L-G3-H3-K-28-K-28-L-M-24-P4-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83044210	MOTOR-VAR-DISPL H1MB060	H1-B-060-A-L2-BA-N-A-PB-VN-AN-N-N-NN-NN-030-N-00-NNN	H1-HP MOTORS	H1-060MB1
83044211	MOTOR-VAR-DISPL H1B080	H1-B-080-A-LH-BA-I-B-PB-VN-AN-N-N-NN-NN-051-N-00-NNN	H1-HP MOTORS	H1-080MB1
83044212	MOTOR-VAR-DISPL H1B110	H1-B-110-A-LH-BA-K-B-PB-VN-EN-N-N-NN-NN-057-N-00-NNN	H1-HP MOTORS	H1-110MB1
83044219	MOTOR-VARIABLE REVERSING CARTRIDGE L	L-M-35EN-K-RF2-N18-S-N-N-BF-F18-NNN-FNN	LV / KV MOTORS	L/K-RDM
83044238	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-B7-C2-C-D8-K-G1-H3-L-30-L-30-C-P-24-P2-NNN-D5J	H1-HP PUMPS	H1-069PV/078PV
83044248	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-B-A5-C2-N-D3-G-F3-H2-L-42-L-42-L-M-26-PN-NNN-NNN	H1-HP PUMPS	H1-115PV/130PV
83044250	PUMP-VAR DISPL, CW 90PV075	90-R-075-LE-5-BC-61-S-3-S1-E-C3-FAD-35-35-24	SERIES 90	S90-075PV
83044251	PUMP-VAR DISPL, CW 90PV075	90-R-075-LE-5-CD-61-S-3-S1-E-C3-FAD-35-35-24	SERIES 90	S90-075PV
83044252	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-A-B1-C1-N-D3-H-G1-NN-L-20-L-20-D-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-089PV/100PV
83044260	MOTOR-VAR-DISPL H1B080	H1-B-080-A-LH-BA-I-B-PB-VN-AN-N-N-NN-NN-054-N-00-NNN	H1-HP MOTORS	H1-080MB1
83044262	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-CD-80-P-3-F1-H-00-GBA-36-36-24	SERIES 90	S90-130PV
83044267	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A5-C2-N-F7-F-G5-T3-30-30-30-30-M-P-24-PN-NNN-S01	H1-MP PUMPS	H1-045PT/053PT
83044271	PUMP-VAR-DISPL CCW 90PV100	90L100-KP-1-CD-80-S-3-F1-D-03-FAD-42-42-24	SERIES 90	S90-100PV
83044272	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-M3-D4-N-D8-H-G9-H5-L-33-L-33-N-E-22-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83044290	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-P1-D1-N-A-TA-DS-GS-S-A-10-NN-022-Z-24-NNN	H1-HP MOTORS	H1-060MB1
83044291	MOTOR-VAR-DISPL H1B110	H1-B-110-A-DH-MA-O-B-PB-VN-DN-N-A-10-NN-024-N-20-NNN	H1-HP MOTORS	H1-110MB1
83044292	MOTOR-VAR-DISPL H1B110	H1-B-110-A-DH-MA-O-B-PB-VN-DN-N-A-15-NN-024-N-20-NNN	H1-HP MOTORS	H1-110MB1
83044301	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E2-AA-N-B-TB-CS-JS-B-A-10-NN-033-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83044302	MOTOR-VARIABLE REVERSING CARTRIDGE K	K-M-38CN-F-RF2-N18-S-N-N-BF-F18-NNN-NNN	LV / KV MOTORS	L/K-RDM

83044303	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-A-N-A5-C2-N-F7-F-G5-T3-30-30-30-30-M-P-24-PN-NNN-S03	H1-MP PUMPS	H1-045PT/053PT
83044307	MOTOR-VAR-DISPL H1MB060	H1-B-060-A-L2-BA-N-B-PB-VS-BS-S-A-05-NN-012-N-00-NNN	H1-HP MOTORS	H1-060MB1
83044308	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A5-C2-N-F4-H-G1-H6-L-42-L-42-C-M-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83044319	PUMP-VAR-DISPL CW 90PV075	90R075-HF-5-NN-60-P-4-C7-E-00-GBA-42-42-24	SERIES 90	S90-075PV
83044320	PUMP-VAR-DISPL CW 90PV250	90R250-KN-5-NN-80-S-4-C8-J-03-NNN-26-26-24	SERIES 90	S90-250PV
83044322	MOTOR-VAR-DISPL H1B160	H1-B-160-A-LH-BA-G-B-PB-VN-DN-N-A-20-NN-060-N-00-NNN	H1-HP MOTORS	H1-160MB1
83044323	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-A-A9-C2-N-F6-H-G1-H6-L-38-L-38-C-L-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83044324	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-T1-DA-N-B-TA-DN-LN-N-A-20-NN-040-T-30-NNN	H1-HP MOTORS	H1-160MB1
83044328	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-A-A4-C1-N-E5-F-G4-NN-L-30-L-30-B-P-20-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83044329	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-N-A4-C1-N-E7-F-G1-T3-35-35-35-35-M-P-24-PN-NNN-S01	H1-MP PUMPS	H1-045PT/053PT
83044330	MOTOR-VARIABLE DISPL SAE_K	K-V-45DS-E-R1F-F11-S-N-N-CF-F18-NNN-NNN	LV / KV MOTORS	L/K-MV
83044333	PUMP-VAR DISPL CW H1P068R	H1-P-068-R-A-A5-C2-N-F4-H-F1-H6-L-28-L-28-C-M-24-PN-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83044336	MOTOR-VAR-DISPL H1B250	H1-B-250-A-L2-BA-N-A-PB-VS-FS-S-B-20-NN-000-N-00-NNN	H1-HP MOTORS	H1-250MB1
83044344	MOTOR-VAR-DISPL H1B110	H1-B-110-A-TH-HA-N-B-TB-VS-ES-S-A-15-NN-074-Z-18-NNN	H1-HP MOTORS	H1-110MB1
83044347	PUMP-VAR DISPL MPV046C	MPV-046-C-B-B-K-S-B-S-AA-B-A-BHH-CN-A-JJ-4-NNN-***	M46	M46-046PV
83044348	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-NN-60-S-3-S1-E-03-GBA-16-16-24	SERIES 90	S90-075PV
83044350	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-HE-HE-N-A-TB-CN-KN-N-N-NN-NN-040-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83044352	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-A-N-A4-C3-N-E7-F-G5-H3-30-30-30-30-N-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PT/053PT
83044353	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-HE-HE-N-A-TB-CN-HN-N-N-NN-NN-016-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83044365	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-A-A5-C2-N-D8-H-G1-H5-L-28-L-28-C-P-24-PN-NNN-NNN	H1-HP PUMPS	H1-069PV/078PV
83044374	PUMP-VAR DISPL MPV046C	MPV-046-C-B-A-K-T-B-S-BA-A-A-BJJ-AB-U-BB-B-NNN-***	M46	M46-046PV
83044375	PUMP-VAR DISPL MPV046C	MPV-046-C-B-A-A-T-B-S-BA-A-A-BJJ-AB-U-BB-C-NNN-***	M46	M46-046PV
83044377	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-A-A5-C2-N-D6-K-E1-NN-L-35-L-35-C-L-24-P4-NNN-NNN	H1-MP PUMPS	H1-060PV/068PV
83044379	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-A-A5-C1-N-D8-F-G5-H3-L-30-L-30-B-P-24-PN-NNN-NNN	H1-MP PUMPS	H1-045PV/053PV
83044392	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-HE-HE-N-C-TB-VN-DN-N-N-NN-NN-070-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83044422	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E2-AA-N-B-TA-DN-JN-N-A-10-NN-055-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83044446	MOTOR-VAR-DISPL H1B250	H1-B-250-A-L1-BA-N-A-PA-VS-DS-S-A-30-NN-065-N-00-NNN	H1-HP MOTORS	H1-250MB1
83044463	MOTOR-VAR-DISPL H1B080	H1-B-080-A-LH-BA-E-B-PA-VN-AN-N-N-NN-NN-036-N-00-NNN	H1-HP MOTORS	H1-080MB1
83044487	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-D2-MA-N-A-PA-VS-ES-B-B-30-NN-080-N-30-NNN	H1-HP MOTORS	H1-160MB1
83044535	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-T1-DA-N-B-TA-DN-KN-N-A-20-NN-040-T-30-NNN	H1-HP MOTORS	H1-160MB1
83044548	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-T2-D2-N-B-TA-VS-CS-B-A-10-NN-040-Z-26-NNN	H1-HP MOTORS	H1-080MB1
83044550	MOTOR-VAR-DISPL H1B110	H1-B-110-A-LH-BA-T-B-PA-VS-ES-P-A-10-NN-022-N-00-NNN	H1-HP MOTORS	H1-110MB1
83044579	MOTOR-VAR-DISPL H1B080	H1-B-080-A-LH-BA-D-B-PA-CN-JN-N-A-05-NN-028-N-00-NNN	H1-HP MOTORS	H1-080MB1
83044599	MOTOR-VAR-DISPL H1B160	H1-B-160-A-TH-HB-N-B-TB-VN-EN-N-A-30-NN-056-Z-25-NNN	H1-HP MOTORS	H1-160MB1
83044646	MOTOR-VAR-DISPL H1B080#	H1-B-080-A-F1-EA-N-B-TB-DN-JN-N-A-10-NN-026-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83044656	MOTOR-VAR-DISPL H1B060	H1-B-060-A-TA-DA-N-B-TB-DN-HN-N-N-NN-NN-030-V-20-NNN	H1-HP MOTORS	H1-060MB1

83044686	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-T2-DA-N-B-TB-DN-HN-N-N-NN-NN-030-V-20-NNN	H1-HP MOTORS	H1-060MB1
83044687	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-D2-M2-N-B-PA-VS-ES-P-A-20-NN-032-N-28-NNN	H1-HP MOTORS	H1-160MB1
83044696	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-HE-HE-N-B-TA-VS-ES-P-A-10-NN-022-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83044706	MOTOR-VAR-DISPL H1MB060	H1-B-060-A-M1-CA-N-A-RB-DS-HS-S-A-05-NN-000-N-00-NNN	H1-HP MOTORS	H1-060MB1
83044707	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-M1-CA-N-A-RB-DS-HS-S-A-05-NN-000-N-00-NNN	H1-HP MOTORS	H1-080MB1
83044724	MOTOR-VAR-DISPL H1B160	H1-B-160-A-TA-DA-N-A-TA-DN-KN-N-A-20-NN-075-Z-26-NNN	H1-HP MOTORS	H1-160MB1
83044729	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-T2-DA-N-B-TB-DN-JN-N-N-NN-NN-030-R-18-NNN	H1-HP MOTORS	H1-080MB1
83044733	MOTOR-VAR-DISPL H1B110	H1-B-110-A-TA-DA-N-C-TA-VN-EN-N-N-NN-NN-074-Z-19-NNN	H1-HP MOTORS	H1-110MB1
83044745	MOTOR-VAR-DISPL H1B250	H1-B-250-A-T2-D2-N-B-TA-VN-DN-N-A-30-NN-105-Z-25-NNN	H1-HP MOTORS	H1-250MB1
83044779	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-T2-D2-N-B-TB-VN-FN-N-A-20-NN-075-Z-25-NNN	H1-HP MOTORS	H1-160MB1
83044795	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E1-AA-N-B-TA-VN-CN-N-A-10-NN-032-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83044796	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-HE-HE-N-B-TB-CN-JN-N-A-10-NN-045-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83044822	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-HE-HE-N-B-TB-CS-GS-P-A-05-NN-025-R-00-NNN	H1-HP MOTORS	H1-060MB1
83044837	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-P2-D2-N-B-TB-VS-DS-S-A-20-NN-038-Z-24-NNN	H1-HP MOTORS	H1-160MB1
83044966	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-L1-BA-N-B-PB-DN-JN-N-A-10-NN-022-N-00-NNN	H1-HP MOTORS	H1-110MB1
83044968	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-HE-HE-N-C-TA-CS-JS-P-A-05-NN-016-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83044986	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-D1-MA-N-A-PB-DS-JS-S-A-15-NN-034-N-30-NNN	H1-HP MOTORS	H1-110MB1
83044998	MOTOR-VAR-DISPL H1B110	H1-B-110-A-DH-MA-P-B-PB-VN-EN-N-A-10-NN-040-N-30-NNN	H1-HP MOTORS	H1-110MB1
83045063	MOTOR-VAR-DISPL H1MB110	H1-B-110-A-L1-BA-N-B-PB-VN-EN-N-A-15-NN-029-N-00-NNN	H1-HP MOTORS	H1-110MB1
83045077	MOTOR-VAR-DISPL H1B250	H1-B-250-A-T1-BD-N-B-TB-VT-FS-S-A-30-NN-068-Z-25-NNN	H1-HP MOTORS	H1-250MB1
83045079	MOTOR-VAR-DISPL H1B160	H1-B-160-A-DH-MA-O-B-PB-VN-DN-N-A-20-NN-032-N-20-NNN	H1-HP MOTORS	H1-160MB1
83045111	MOTOR-VAR-DISPL H1MB080	H1-B-080-A-L2-BA-N-B-PB-CS-JS-S-A-05-NN-016-N-00-NNN	H1-HP MOTORS	H1-080MB1
83045117	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-L1-BA-N-B-PA-DS-KS-S-N-NN-NN-000-N-00-NNN	H1-HP MOTORS	H1-160MB1
83045174	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-L1-BA-N-B-PB-VS-ES-S-A-20-NN-042-N-00-NNN	H1-HP MOTORS	H1-160MB1
83045181	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-L2-BA-N-A-PA-DS-KS-S-A-20-NN-000-N-00-NNN	H1-HP MOTORS	H1-160MB1
83045190	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-T1-D1-N-B-TA-DS-GS-S-A-05-NN-022-Z-30-NNN	H1-HP MOTORS	H1-060MB1
83045201	MOTOR-VAR-DISPL H1B160	H1-B-160-A-TA-D1-N-A-TA-VS-ES-S-A-30-NN-085-Z-30-NNN	H1-HP MOTORS	H1-160MB1
83045208	MOTOR-VAR-DISPL H1B060#	H1-B-060-A-F2-EA-N-B-TB-VS-AS-P-N-NN-NN-015-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83045226	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-HE-HE-N-A-TB-VN-EN-N-N-NN-NN-032-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83045234	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-E2-AA-N-B-TB-DN-KN-N-A-20-NN-050-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83045244	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-HE-HE-N-B-TA-VS-AS-P-N-NN-NN-032-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83045270	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-HE-HE-N-B-TB-CS-HS-P-A-10-NN-030-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83045271	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E2-AA-N-B-TA-CS-GS-P-A-05-NN-018-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83045272	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-HE-HE-N-B-TB-CS-KS-P-A-10-NN-022-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83045273	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-HE-HE-N-B-TB-VS-ES-P-A-20-NN-034-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83045274	MOTOR-VAR-DISPL H1B060	H1-B-060-A-LH-BA-K-B-PB-CS-GS-S-A-05-NN-014-N-00-NNN	H1-HP MOTORS	H1-060MB1

83045284	MOTOR-VAR-DISPL H1MB060	H1-B-060-A-L2-BA-N-B-PB-VS-AS-S-A-10-NN-015-N-00-NNN	H1-HP MOTORS	H1-060MB1
83045334	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-P2-D2-N-B-TA-VN-BN-N-A-10-NN-035-Z-24-NNN	H1-HP MOTORS	H1-060MB1
83045337	MOTOR-VAR-DISPL H1MB060	H1-B-060-A-D1-M1-N-B-PB-VN-BN-N-A-10-NN-033-N-30-NNN	H1-HP MOTORS	H1-060MB1
83045344	MOTOR-VAR-DISPL H1B250	H1-B-250-A-LH-BA-K-B-PA-VN-FN-N-A-30-NN-050-N-00-NNN	H1-HP MOTORS	H1-250MB1
83045347	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-T2-D2-N-C-TA-VS-ES-S-A-20-NN-065-Z-30-NNN	H1-HP MOTORS	H1-160MB1
83045353	MOTOR-VAR-DISPL H1MB060	H1-B-060-A-D1-MA-N-B-PB-VN-BN-N-A-10-NN-033-N-30-NNN	H1-HP MOTORS	H1-060MB1
83045395	MOTOR-VAR-DISPL H1B060#	H1-B-060-A-F1-EA-N-B-TB-VN-BN-N-A-10-NN-025-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83045397	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-HE-HE-N-B-TB-VN-DN-N-A-20-NN-000-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83045433	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-E1-AA-N-B-TB-VS-AS-B-A-10-NN-050-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83045443	MOTOR-VAR-DISPL H1B250	H1-B-250-A-L2-BA-N-A-PA-VS-FS-S-N-NN-NN-050-N-00-NNN	H1-HP MOTORS	H1-250MB1
83045452	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-E2-AA-N-B-TA-DN-KN-N-N-NN-NN-050-Z-00-NNN	H1-HP MOTORS	H1-160MB1
83045511	MOTOR-VAR-DISPL H1MB060#	H1-B-060-A-E2-AA-N-B-TB-CS-GS-P-A-10-NN-015-Z-00-NNN	H1-HP MOTORS	H1-060MB1
83045571	MOTOR-VAR-DISPL H1B060	H1-B-060-A-LH-BA-D-B-PB-VS-AS-P-N-NN-NN-012-N-00-NNN	H1-HP MOTORS	H1-060MB1
83045572	MOTOR-VAR-DISPL H1B110	H1-B-110-A-LH-BA-D-B-PB-VS-ES-P-N-NN-NN-030-N-00-NNN	H1-HP MOTORS	H1-110MB1
83045573	MOTOR-VAR-DISPL H1B250	H1-B-250-A-LH-BA-J-B-PB-VS-FS-P-N-NN-NN-050-N-00-NNN	H1-HP MOTORS	H1-250MB1
83045574	MOTOR-VAR-DISPL H1B080	H1-B-080-A-LH-BA-D-B-PB-VS-JS-P-N-NN-NN-016-N-00-NNN	H1-HP MOTORS	H1-080MB1
83045575	MOTOR-VAR-DISPL H1B110	H1-B-110-A-LH-BA-D-B-PA-VS-ES-P-N-NN-NN-030-N-00-NNN	H1-HP MOTORS	H1-110MB1
83045576	MOTOR-VAR-DISPL H1B080	H1-B-080-A-LH-BA-D-B-PA-VS-JS-P-N-NN-NN-016-N-00-NNN	H1-HP MOTORS	H1-080MB1
83045586	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-L2-BA-N-B-PB-DS-LS-S-A-20-NN-000-N-00-NNN	H1-HP MOTORS	H1-160MB1
83045644	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-T2-D2-N-B-TB-VS-DS-S-N-NN-NN-035-Z-30-NNN	H1-HP MOTORS	H1-160MB1
83045664	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-D2-M2-N-B-PA-DS-KS-S-B-30-NN-058-N-25-NNN	H1-HP MOTORS	H1-160MB1
83045685	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-HE-HE-N-A-TA-CN-JN-N-N-NN-NN-032-R-00-NNN	H1-HP MOTORS	H1-110MB1
83045693	MOTOR-VAR-DISPL H1MB110#	H1-B-110-A-E2-AA-N-B-TB-VN-DN-N-N-NN-NN-040-Z-00-NNN	H1-HP MOTORS	H1-110MB1
83045714	PUMP-VAR-DISPL 42PV041 CCW	42-L-41-C-E2D8-02-A-N-A-2-G-N-N-25-25-B-A-A-NNN-NNN	SERIES 42	S42-041PV/051PV
83045732	MOTOR-VAR-DISPL H1B250	H1-B-250-A-L2-BA-N-B-PB-VS-FS-S-N-NN-NN-085-N-00-NNN	H1-HP MOTORS	H1-250MB1
83045738	MOTOR-VAR-DISPL H1B080	H1-B-080-A-TA-DA-N-B-TB-VN-CN-N-N-NN-NN-024-Z-21-NNN	H1-HP MOTORS	H1-080MB1
83045766	MOTOR-VAR-DISPL H1B060	H1-B-060-A-TA-DA-N-B-TA-VN-AN-N-A-05-NN-025-Z-20-NNN	H1-HP MOTORS	H1-060MB1
83045771	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-HE-HE-N-B-TA-VN-AN-N-N-NN-NN-053-Z-00-NNN	H1-HP MOTORS	H1-080MB1
83045774	MOTOR-VAR-DISPL H1MB080#	H1-B-080-A-T1-D1-N-B-TA-DN-JN-N-A-10-NN-026-Z-23-NNN	H1-HP MOTORS	H1-080MB1
83045782	MOTOR-VAR-DISPL H1MB060	H1-B-060-A-L2-BA-N-A-PA-VS-BS-S-N-NN-NN-000-N-00-NNN	H1-HP MOTORS	H1-060MB1
83045787	MOTOR-VAR-DISPL H1MB160	H1-B-160-A-M2-CA-N-A-RB-VS-DS-S-E-10-NN-000-N-00-NNN	H1-HP MOTORS	H1-160MB1
83045793	MOTOR-VAR-DISPL H1MB160#	H1-B-160-A-E2-AA-N-B-TA-DN-KN-N-N-NN-NN-050-Q-00-NNN	H1-HP MOTORS	H1-160MB1
83045836	MOTOR-VAR-DISPL H1B250	H1-B-250-A-TA-DA-N-C-TB-VN-DN-N-N-NN-NN-075-Z-20-NNN	H1-HP MOTORS	H1-250MB1
83045872	MOTOR-VAR-DISPL H1MB060	H1-B-060-A-M1-CA-N-A-RB-DS-HS-S-A-10-NN-000-N-00-NNN	H1-HP MOTORS	H1-060MB1
83046065	PUMP-VAR DISPL, CCW H1PV210	H1-P-210-L-A-A5-C2-N-D6-C-G3-NN-L-42-L-42-W-L-20-PN-NNN-NNN	H1-HP PUMPS	H1-210PV/250PV
83046159	PUMP-VAR DISPL, CCW H1PV210	H1-P-210-L-A-A5-C2-B-D8-E-G3-H3-L-40-L-40-R-P-34-P4-NNN-NNN	H1-HP PUMPS	H1-210PV/250PV

83046473	MOTOR-VAR-DISPL H1B080	H1-B-080-A-DH-MH-Y-B-PA-VN-CN-N-A-10-NN-030-N-25-NNN	H1-HP MOTORS	H1-080MB1
8700066	RING PISTON		SERIES 90	PARTS - S90
90002	PUMP-VAR DISPL, CW 90PV055	90-R-055-DC-1-AB-80-D-4-S1-L-GB-GBA-38-38-20	SERIES 90	S90-055PV
90003	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-AB-80-S-3-C7-E-05-GBA-32-32-24	SERIES 90	S90-100PV
90004	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-1-BB-60-L-3-C6-D-03-GBA-38-38-24	SERIES 90	S90-055PV
90005	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-1-NN-80-L-3-C6-E-03-GBA-35-35-24	SERIES 90	S90-075PV
9001436-0001	BEARING CUP-4.000 X 1.0625W		SERIES 20	PARTS - S20 - Purchased Parts
9001436-0003	BEARING CUP-3.750 X .875 W (33821)		SERIES 20	PARTS - S20 - Purchased Parts
9001437-0001	BEARING CONE-2.0000 X 1.420 W		SERIES 20	PARTS - S20 - Purchased Parts
90027	MOTOR-FIXED-DISPL 90MF055	90-M-055-NC-0-N-8-N-0-D9-W-00-NNN-00-00-20	SERIES 90	S90-055MF
90028	PUMP-VAR DISPL, CW 90PV055	90-R-055-DC-1-AB-80-D-4-S1-L-GB-GBA-38-38-20-F001	SERIES 90	S90-055PV
90032	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HF-1-NN-60-R-4-S1-E-03-GBA-29-29-24	SERIES 90	S90-100PV
90033	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HF-1-NN-60-R-4-F1-E-03-GBA-20-20-24	SERIES 90	S90-100PV
9003508-0008	NUT-HEX SEAL, M8X1 CL 8		HP OTHER PARTS	HP SHARED PARTS
90041	MOTOR-FIXED-DISPL 90MF055	90-M-055-NC-0-N-8-N-0-C6-W-00-NNN-00-00-30	SERIES 90	S90-055MF
9004100-1390	O RING-.103 X 2.175 NBR/NITRILE, 70D		HP OTHER PARTS	HP SHARED PARTS
9004201-2500	O RING-.072 X .351 NBR/NITRILE, 90D		HP OTHER PARTS	HP SHARED PARTS
90046	PUMP-VAR DISPL, CW 90PV055	90-R-055-MB-1-BC-60-R-3-C6-D-03-GBA-38-38-20	SERIES 90	S90-055PV
90048	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MA-1-NN-60-S-3-S1-E-03-GBA-40-40-28	SERIES 90	S90-100PV
90049	MOTOR-FIXED-DISPL 90MF100	90-M-100-NC-0-N-7-N-0-S1-W-00-NNN-00-00-28	SERIES 90	S90-100MF
90051	PUMP-VAR DISPL, CW 90PV055	90-R-055-MB-1-BC-60-S-3-C6-D-03-GBA-35-35-20	SERIES 90	S90-055PV
90052	PUMP-VAR DISPL, CW 90PV100	90-R-100-MB-1-CD-60-L-3-C7-F-03-GBA-35-35-24	SERIES 90	S90-100PV
90053	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-1-AB-80-L-4-S1-C-GB-GBA-42-42-24	SERIES 90	S90-055PV
90054	MOTOR-FIXED-DISPL 90MF055	90-M-055-NC-0-N-8-N-0-C6-W-00-NNN-00-00-22	SERIES 90	S90-055MF
90059	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-1-AB-60-P-3-C6-D-03-GBA-35-35-20	SERIES 90	S90-075PV
90060	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-1-BC-80-P-3-C6-C-03-GBA-26-26-20	SERIES 90	S90-055PV
90061	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-1-AB-60-L-3-C6-C-03-GBA-42-42-20	SERIES 90	S90-055PV
9006110-0110	RING-BACK UP, PACKING, .327 X .054		HP OTHER PARTS	HP SHARED PARTS
9006250-0144	RING-RTNG, INT 1.437 HSG ID X .043		HP OTHER PARTS	HP SHARED PARTS
90063	PUMP-VAR DISPL, CW 90PV055	90-R-055-MB-1-BC-60-S-3-C6-C-03-GBA-35-35-20	SERIES 90	S90-055PV
90067	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HF-1-NN-60-R-4-S1-E-03-GBA-20-20-24	SERIES 90	S90-100PV
90068	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-1-NN-60-S-3-C7-D-03-GBA-42-42-24	SERIES 90	S90-075PV
90069	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-CD-80-L-3-F1-D-03-GBA-35-35-20	SERIES 90	S90-100PV
90070	MOTOR-FIXED-DISPL 90MF100	90-M-100-NC-0-N-8-N-0-C7-W-00-EBA-00-00-20	SERIES 90	S90-100MF
9007200-3122	SCREW-HEX HD, .3125-18 X 1.250 GR 5		HP OTHER PARTS	HP SHARED PARTS
9007276-0049	SCREW-HEX HD, .250 -20 X .625 SPCL		SERIES 20	PARTS - S20 - "No Name"

90073	PUMP-VAR DISPL, CCW 90PV075	90-L-075-ME-1-AB-60-S-3-C6-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9007314-0605	SCREW-SOC HD, M 6 X 20 - 12.9		HP OTHER PARTS	HP SHARED PARTS
9007314-1221	SCREW-SOC HD, M12 X 120 - 12.9		HP OTHER PARTS	HP SHARED PARTS
9007375-0036	SCREW-SHC M6x12 DIN6912 8.8		LIGHT DUTY	PARTS - Low Power
90085	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-CD-80-L-3-F1-D-03-GBA-35-35-20	SERIES 90	S90-100PV
90086	PUMP-VAR DISPL, CW 90PV075	90-R-075-MB-1-CD-60-L-3-C7-D-03-GBA-35-35-24	SERIES 90	S90-075PV
90087	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-1-NN-80-L-4-S1-C-GB-GBA-35-35-24	SERIES 90	S90-055PV
90091	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-NN-80-S-4-S1-E-03-GBA-17-17-24	SERIES 90	S90-075PV
90092	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-NN-80-S-4-C6-E-03-GBA-17-17-24	SERIES 90	S90-075PV
9009625-0132	WASHER-METRIC, 17.0 X 30.0 X 4.0 SPCL		SERIES 90	PARTS - S90
90100	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-1-NN-80-R-3-S1-D-03-GBA-23-23-24	SERIES 90	S90-075PV
90104	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MA-1-NN-60-S-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-100PV
90105	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MA-1-AB-60-S-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-100PV
90106	PUMP-VAR DISPL, CW 90PV055	90-R-055-MB-1-BC-60-P-3-C6-C-03-GBA-42-42-24	SERIES 90	S90-075PV
90107	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-CD-60-P-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-100PV
90110	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-1-AB-60-L-4-S1-D-G4-GBA-35-35-20	SERIES 90	S90-055PV
90111	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-1-NN-60-S-3-S1-D-03-GBA-32-32-24	SERIES 90	S90-075PV
90112	MOTOR-FIXED-DISPL 90MF075	90-M-075-NC-0-N-8-N-0-S1-W-00-NNN-00-00-22	SERIES 90	S90-075MF
90114	PUMP-VAR DISPL, CW 90PV100	90-R-100-MB-1-CD-60-L-3-C7-F-03-GBA-42-42-24	SERIES 90	S90-100PV
90115	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-1-AB-80-R-4-S1-C-GB-GBA-42-42-24	SERIES 90	S90-055PV
90119	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-1-NN-80-R-3-S1-D-03-GBA-23-23-24	SERIES 90	S90-075PV
90120	PUMP-VAR DISPL, CCW 90PV055	90-L-055-MA-1-NN-80-R-4-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
90121	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-1-NN-80-R-4-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
90122	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-1-NN-80-R-3-C6-D-03-GBA-23-23-24	SERIES 90	S90-075PV
90124	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-NN-60-R-3-C6-C-03-GBA-42-42-20	SERIES 90	S90-055PV
90126	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MB-1-NN-80-R-3-T2-F-03-GBA-35-35-24	SERIES 90	S90-100PV
90128	PUMP-VAR DISPL, CW 90PV100	90-R-100-ME-1-CD-60-R-3-C7-D-03-GBA-42-42-28	SERIES 90	S90-100PV
90130	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-1-BC-60-S-3-C6-D-03-GBA-35-35-24	SERIES 90	S90-075PV
90131	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-1-CD-60-S-3-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV
90132	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-1-NN-60-S-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
90134	PUMP-VAR DISPL, CW 90PV055	90-R-055-MB-1-CD-60-S-3-C6-C-03-GBA-38-38-20	SERIES 90	S90-055PV
90136	PUMP-VAR DISPL, CW 90PV055	90-R-055-MB-1-BB-80-R-3-C6-L-03-GBA-38-38-20	SERIES 90	S90-055PV
90137	MOTOR-FIXED-DISPL 90MF100	90-M-100-NC-0-N-7-N-0-K3-W-00-NNN-00-00-28	SERIES 90	S90-100MF
90139	PUMP-VAR DISPL, CW 90PV100	90-R-100-MB-1-CD-60-R-3-C7-D-03-GBA-42-42-28	SERIES 90	S90-100PV
90142	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-1-NN-60-S-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-075PV
90144	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-2-NN-80-S-3-C6-E-03-GBA-42-42-24	SERIES 90	S90-075PV

90145	PUMP-VAR DISPL, CW 90PV075	90-R-075-MB-1-CD-60-S-3-C7-D-03-GBA-38-38-24	SERIES 90	S90-075PV
90146	PUMP-VAR DISPL, CW 90PV075	90-R-075-MT-1-NN-60-S-3-C6-E-02-GBA-38-38-24	SERIES 90	S90-075PV
90147	MOTOR-FIXED-DISPL 90MF100	90-M-100-NC-0-N-7-N-0-F1-W-00-EBA-00-00-20	SERIES 90	S90-100MF
90148	PUMP-VAR DISPL, CW 90PV100	90-R-100-M8-1-CD-60-P-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
90149	PUMP-VAR DISPL, CW 90PV100	90-R-100-DD-1-NN-80-P-4-S1-E-GB-GBA-32-32-24	SERIES 90	S90-100PV
90153	PUMP-VAR DISPL, CW 90PV055	90-R-055-DC-1-NN-60-D-4-S1-L-GB-GBA-35-35-24	SERIES 90	S90-055PV
90155	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-NN-80-R-3-S1-F-03-GBA-32-32-28	SERIES 90	S90-100PV
90156	PUMP-VAR DISPL, CCW 90PV055	90-L-055-DC-1-NN-80-P-4-S1-C-GB-GBA-38-38-24	SERIES 90	S90-055PV
90157	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-1-AB-60-L-3-C7-D-03-GBA-32-32-20	SERIES 90	S90-075PV
90161	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-NN-80-P-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
90164	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-NN-60-R-3-S1-F-03-GBA-32-32-26	SERIES 90	S90-100PV
90165	PUMP-VAR DISPL, CCW 90PV075	90-L-075-DC-1-NN-80-P-4-S1-C-GB-GBA-38-38-24	SERIES 90	S90-075PV
90166	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-NN-80-S-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
90168	PUMP-VAR DISPL, CCW 90PV075	90-L-075-DC-1-NN-80-P-4-S1-D-GB-GBA-38-38-24	SERIES 90	S90-075PV
90170	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-CD-80-L-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
90172	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-NN-80-P-3-C7-D-03-GBA-35-35-24	SERIES 90	S90-075PV
90173	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-NN-80-P-3-C7-D-03-EBC-35-35-24	SERIES 90	S90-075PV
90174	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-2-AB-80-S-3-C6-E-03-GBA-42-42-24	SERIES 90	S90-075PV
90175	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-2-NN-80-S-3-C6-E-06-GBA-42-42-24	SERIES 90	S90-075PV
90177	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-AB-80-P-3-F1-E-03-GBA-29-29-24	SERIES 90	S90-100PV
90178	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-1-AB-60-L-4-S1-C-G8-GBA-32-32-20	SERIES 90	S90-055PV
90180	PUMP-VAR DISPL, CW 90PV075	90-R-075-M8-1-CD-60-L-3-C7-D-03-GBA-38-38-24	SERIES 90	S90-075PV
90182	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-NN-80-S-3-C6-D-03-GBA-35-35-24	SERIES 90	S90-075PV
90189	PUMP-VAR DISPL, CCW 90PV055	90-L-055-MA-1-NN-60-S-3-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV
90191	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MA-1-NN-80-P-3-F1-E-09-EBC-45-45-20	SERIES 90	S90-100PV
90192	PUMP-VAR DISPL, CCW 90PV055	90-L-055-MA-1-NN-80-S-3-S1-C-03-GBA-29-29-20	SERIES 90	S90-055PV
90193	PUMP-VAR DISPL, CW 90PV075	90-R-075-DD-1-NN-80-P-4-S1-D-GB-GBA-35-35-24	SERIES 90	S90-075PV
90207	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-2-CD-80-P-3-C6-D-03-GBA-42-42-24	SERIES 90	S90-075PV
90208	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-2-AB-80-P-3-C6-D-03-GBA-42-42-24	SERIES 90	S90-075PV
90214	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-NN-60-R-3-S1-F-03-GBA-32-32-26	SERIES 90	S90-100PV
90215	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-NN-60-R-3-S1-E-03-GBA-32-32-26	SERIES 90	S90-100PV
90216	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-2-NN-80-S-3-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV
90217	PUMP-VAR DISPL, CCW 90PV055	90-L-055-DD-1-NN-80-P-4-S1-C-GB-GBA-38-38-24	SERIES 90	S90-055PV
90218	PUMP-VAR DISPL, CCW 90PV075	90-L-075-DD-1-NN-80-P-4-S1-D-GB-GBA-38-38-24	SERIES 90	S90-075PV
90222	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-CD-60-P-3-C7-E-03-GBA-23-23-24	SERIES 90	S90-100PV
90223	PUMP-VAR DISPL, CW 90PV075	90-R-075-DC-1-NN-60-P-4-S1-D-GB-GBA-23-23-24	SERIES 90	S90-075PV

90224	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MB-1-NN-80-S-3-C7-D-03-GBA-35-35-24	SERIES 90	S90-075PV
90225	PUMP-VAR DISPL, CW 90PV100	90-R-100-MB-1-CD-60-P-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
90227	PUMP-VAR DISPL, CW 90PV100	90-R-100-HF-1-NN-60-P-4-S1-E-03-GBA-29-29-24	SERIES 90	S90-100PV
90228	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HF-1-NN-60-P-4-S1-E-03-GBA-29-29-24	SERIES 90	S90-100PV
90229	PUMP-VAR DISPL, CCW 90PV055	90-L-055-MA-2-NN-80-L-3-C6-D-03-GBA-42-42-24	SERIES 90	S90-055PV
90230	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-1-NN-80-R-4-C6-C-GB-GBA-42-42-24	SERIES 90	S90-055PV
90231	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-CD-60-L-3-C7-F-03-GBA-23-23-24	SERIES 90	S90-100PV
90232	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-1-NN-60-L-3-S1-D-GB-GBA-20-20-24	SERIES 90	S90-055PV
90239	PUMP-VAR DISPL, CW 90PV055	90-R-055-MB-1-BB-60-S-3-C6-C-03-GBA-38-38-24	SERIES 90	S90-055PV
90240	PUMP-VAR DISPL, CW 90PV075	90-R-075-MB-1-NN-80-S-3-C7-D-03-GBA-35-35-24	SERIES 90	S90-055PV
90241	PUMP-VAR DISPL, CW 90PV100	90-R-100-MB-1-CD-60-L-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
90242	PUMP-VAR DISPL, CW 90PV075	90-R-075-DD-1-AB-80-R-4-S1-D-GB-GBA-42-42-24	SERIES 90	S90-075PV
90245	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-BG-80-P-3-C6-C-03-GBA-32-32-24	SERIES 90	S90-055PV
90246	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-AD-80-P-3-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV
90247	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-NN-80-P-3-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV
90251	PUMP-VAR DISPL, CW 90PV055	90-R-055-MB-1-BB-80-D-3-C6-L-03-GBA-38-38-24	SERIES 90	S90-055PV
90254	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HF-1-NN-80-S-3-S1-C-03-GBA-29-29-20	SERIES 90	S90-055PV
90255	MOTOR-FIXED-DISPL 90MF075	90-M-075-NC-0-N-7-N-0-K2-W-00-NNN-00-00-20	SERIES 90	S90-075MF
90256	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-1-AB-80-P-4-C6-D-03-GBA-35-35-24	SERIES 90	S90-055PV
90258	PUMP-VAR DISPL, CCW 90PV055	90-L-055-MA-1-NN-80-S-3-S1-C-03-GBA-35-35-20	SERIES 90	S90-055PV
90259	PUMP-VAR DISPL, CCW 90PV055	90-L-055-DD-1-AB-80-R-4-C6-C-GB-GBA-35-35-24	SERIES 90	S90-055PV
90261	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MA-1-AB-60-R-3-F1-E-03-GBA-38-38-20	SERIES 90	S90-100PV
90263	PUMP-VAR DISPL, CW 90PV055	90-R-055-MB-1-BB-80-D-3-C6-L-03-GBA-38-38-20	SERIES 90	S90-055PV
90264	PUMP-VAR DISPL, CW 90PV055	90-R-055-DC-1-AB-80-D-4-S1-L-GB-GBA-38-38-24-F001	SERIES 90	S90-055PV
90265	PUMP-VAR DISPL, CW 90PV075	90-R-075-M8-1-CD-60-P-3-C7-D-03-GBA-35-35-24	SERIES 90	S90-075PV
90266	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-1-NN-80-P-4-S1-C-GB-GBA-35-35-24	SERIES 90	S90-055PV
90269	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-1-BC-60-P-3-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV
90270	PUMP-VAR DISPL, CW 90PV075	90-R-075-M8-1-BC-60-P-3-C7-D-03-GBA-35-35-24	SERIES 90	S90-075PV
90271	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MB-1-AB-60-P-3-C7-D-03-GBA-38-38-24	SERIES 90	S90-100PV
90274	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-1-AB-80-D-4-S1-L-GB-GBA-38-38-24	SERIES 90	S90-055PV
90277	PUMP-VAR DISPL, CW 90PV100	90-R-100-MB-1-NN-80-S-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
90278	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-1-NN-60-S-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
90279	PUMP-VAR DISPL, CW 90PV075	90-R-075-M8-1-BB-60-P-3-C7-D-03-GBA-35-35-24	SERIES 90	S90-075PV
90284	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-1-BB-60-P-3-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV
90285	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-NN-60-S-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
90286	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HS-1-NN-80-P-3-C6-C-03-GBA-38-38-24	SERIES 90	S90-055PV

90288	MOTOR-FIXED-DISPL 90MF055	90-M-055-NC-0-N-7-N-0-S1-W-00-NNN-00-00-24	SERIES 90	S90-055MF
90294	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-BC-80-S-4-C6-E-03-GBA-20-20-24	SERIES 90	S90-075PV
90297	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-AB-80-S-3-C7-E-06-GBA-42-42-24	SERIES 90	S90-100PV
90299	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-NN-60-L-3-C6-E-03-GBA-29-29-20	SERIES 90	S90-075PV
90301	PUMP-VAR DISPL, CCW 90PV075	90-L-075-M8-1-AB-60-L-3-K2-D-03-GBA-35-35-24	SERIES 90	S90-075PV
90302	MOTOR-FIXED-DISPL 90MF075	90-M-075-NC-0-N-8-N-0-K2-W-00-NNN-00-00-24	SERIES 90	S90-075MF
90303	PUMP-VAR DISPL, CW 90PV075	90-R-075-M8-1-BC-60-D-3-C7-L-03-GBA-38-38-20	SERIES 90	S90-075PV
90304	MOTOR-FIXED-DISPL 90MF055	90-M-055-NC-0-N-8-N-0-C6-W-00-NNN-00-00-E6	SERIES 90	S90-055MF
90305	PUMP-VAR DISPL, CW 90PV075	90-R-075-M8-1-BC-60-D-3-C7-L-03-GBA-40-40-20	SERIES 90	S90-075PV
90308	PUMP-VAR DISPL, CW 90PV055	90-R-055-DC-1-NN-60-D-4-S1-L-GB-GBA-35-35-20	SERIES 90	S90-055PV
90310	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-NN-60-S-3-S1-E-03-GBA-32-32-24	SERIES 90	S90-100PV
90313	PUMP-VAR DISPL, CW 90PV100	90-R-100-LV-1-CD-60-S-3-C7-E-03-GBA-38-38-24	SERIES 90	S90-100PV
90314	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-1-AB-80-S-4-S1-C-GB-GBA-35-35-24	SERIES 90	S90-055PV
90317	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-CD-60-L-3-C7-F-03-GBA-26-26-24	SERIES 90	S90-100PV
90318	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-1-NN-60-L-3-S1-D-GB-GBA-23-23-24	SERIES 90	S90-055PV
90320	PUMP-VAR DISPL, CCW 90PV075	90-L-075-M8-1-BC-60-P-3-C7-D-03-GBA-35-35-24	SERIES 90	S90-075PV
90321	PUMP-VAR DISPL, CW 90PV055	90-R-055-DC-1-NN-80-R-4-S1-B-GB-FAB-40-40-24	SERIES 90	S90-055PV
90322	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-NN-80-P-3-C7-E-03-GBA-26-26-24	SERIES 90	S90-100PV
90323	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MB-1-AB-60-L-3-K2-D-03-GBA-35-35-24	SERIES 90	S90-075PV
90324	PUMP-VAR DISPL, CW 90PV075	90-R-075-MB-1-CD-60-L-3-C7-D-03-GBA-38-38-24	SERIES 90	S90-075PV
90326	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-1-CD-60-S-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-075PV
90327	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MA-1-AB-60-S-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
90328	MOTOR-FIXED-DISPL 90MF100	90-M-100-NC-0-N-8-N-0-S1-W-00-NNN-00-00-E4	SERIES 90	S90-100MF
90329	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-1-NN-60-S-3-C6-E-03-GBA-38-38-20	SERIES 90	S90-075PV
90330	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KA-1-NN-80-P-3-S1-C-03-GBA-29-29-24	SERIES 90	S90-055PV
90335	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-1-NN-80-S-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
90336	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-AB-60-S-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
90337	PUMP-VAR DISPL, CCW 90PV055	90-L-055-DD-1-NN-80-L-4-S1-D-G4-GBA-35-35-20	SERIES 90	S90-055PV
90338	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-NN-80-P-3-C6-E-03-EBC-35-35-24	SERIES 90	S90-075PV
90339	PUMP-VAR DISPL, CCW 90PV075	90-L-075-M8-1-AB-80-S-3-C6-D-03-GBA-40-40-24	SERIES 90	S90-075PV
90341	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-NN-80-S-3-C6-E-03-GBA-29-29-20	SERIES 90	S90-075PV
90348	PUMP-VAR DISPL, CCW 90PV055	90-L-055-DD-1-NN-80-P-4-C6-C-GB-GBA-29-29-20	SERIES 90	S90-055PV
90349	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-CD-80-S-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
90350	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-NN-80-S-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
90352	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-1-NN-60-P-3-K2-D-03-GBA-35-35-24	SERIES 90	S90-075PV
90353	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-NN-80-S-3-C6-E-03-GBA-42-42-24	SERIES 90	S90-075PV

90354	PUMP-VAR DISPL, CCW 90PV055	90-L-055-MA-1-NN-80-L-3-C6-C-09-GBA-45-45-20	SERIES 90	S90-055PV
90355	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KN-1-NN-80-P-3-C6-E-03-EBC-35-35-24	SERIES 90	S90-075PV
90356	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-NN-80-S-3-C6-E-03-GBA-26-26-20	SERIES 90	S90-075PV
90359	PUMP-VAR DISPL, CW 90PV075	90-R-075-M8-1-CD-60-P-3-C7-D-03-GBA-35-35-20	SERIES 90	S90-075PV
90360	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-1-NN-80-P-4-S1-C-GB-GBA-35-35-20	SERIES 90	S90-055PV
90362	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MB-1-AB-80-P-3-C7-D-03-GBA-38-38-24	SERIES 90	S90-100PV
90364	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MB-1-NN-60-P-3-S1-D-03-GBA-42-42-20	SERIES 90	S90-075PV
90367	PUMP-VAR DISPL, CCW 90PV055	90-L-055-MA-1-NN-60-S-3-C6-C-03-GBA-35-35-20	SERIES 90	S90-055PV
90369	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-1-NN-80-S-3-S1-C-03-GBA-35-35-20	SERIES 90	S90-055PV
90370	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-NN-80-P-3-C6-D-03-GBA-26-26-20	SERIES 90	S90-075PV
90371	PUMP-VAR DISPL, CW 90PV100	90-R-100-M8-1-CD-60-S-3-C7-E-03-GBA-38-38-24	SERIES 90	S90-100PV
90372	PUMP-VAR DISPL, CW 90PV075	90-R-075-DD-1-AB-80-S-4-S1-C-GB-GBA-35-35-24	SERIES 90	S90-075PV
90374	MOTOR-FIXED-DISPL 90MF075	90-M-075-NC-0-N-8-N-0-C6-W-00-NNN-00-00-E6	SERIES 90	S90-075MF
90375	PUMP-VAR DISPL, CW 90PV075	90-R-075-LV-1-CD-60-S-3-C7-D-03-GBA-38-38-24	SERIES 90	S90-075PV
90377	PUMP-VAR DISPL, CW 90PV075	90-R-075-M8-1-CD-60-P-3-C7-D-03-GBA-38-38-24	SERIES 90	S90-075PV
90378	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-1-AB-60-P-4-S1-D-G4-GBA-35-35-20	SERIES 90	S90-055PV
90381	PUMP-VAR DISPL, CCW 90PV055	90-L-055-MA-1-AB-60-S-3-C6-D-03-GBA-35-35-24	SERIES 90	S90-055PV
90382	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-NN-80-P-3-C6-D-03-GBA-29-29-20	SERIES 90	S90-075PV
90383	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-CD-60-S-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
90384	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-CD-80-S-3-C7-F-03-GBA-42-42-24	SERIES 90	S90-100PV
90385	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-1-NN-80-S-4-S1-D-GB-GBA-42-42-24	SERIES 90	S90-055PV
90386	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-2-NN-80-S-3-C6-E-06-GBA-42-42-24	SERIES 90	S90-075PV
90387	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-AB-80-L-3-C7-F-03-GBA-42-42-24	SERIES 90	S90-100PV
90388	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-NN-60-P-4-S1-D-03-GBA-38-38-24-F001	SERIES 90	S90-075PV
90392	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HF-1-NN-80-S-3-C7-E-03-GBA-32-32-24	SERIES 90	S90-100PV
90393	PUMP-VAR DISPL, CW 90PV075	90-R-075-MB-1-CD-80-P-3-C6-D-03-GBA-32-32-24	SERIES 90	S90-075PV
90394	PUMP-VAR DISPL, CW 90PV075	90-R-075-MB-1-AB-80-P-3-S1-D-03-GBA-32-32-24	SERIES 90	S90-075PV
90396	MOTOR-FIXED-DISPL 90MF100	90-M-100-NC-0-N-8-N-0-C7-W-00-EBA-00-00-24	SERIES 90	S90-100MF
90399	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-AB-60-P-3-D7-D-03-GBA-35-35-24	SERIES 90	S90-075PV
90402	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-1-NN-60-S-3-C7-D-03-GBA-35-35-24	SERIES 90	S90-075PV
90403	MOTOR-FIXED-DISPL 90MF075	90-M-075-NC-0-N-7-N-0-C7-W-00-NNN-00-00-24	SERIES 90	S90-075MF
90404	PUMP-VAR DISPL, CW 90PV100	90-R-100-MB-1-CD-60-S-3-C7-F-03-GBA-42-42-24	SERIES 90	S90-100PV
90405	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-1-NN-80-R-4-S1-C-GB-GBA-42-42-24	SERIES 90	S90-055PV
90407	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-BC-80-S-3-C7-E-03-GBA-38-38-24	SERIES 90	S90-100PV
90408	PUMP-VAR DISPL, CW 90PV100	90-R-100-M8-1-CD-60-P-3-C7-E-03-GBA-40-40-24	SERIES 90	S90-100PV
90410	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-AB-80-P-3-C6-D-03-GBA-42-42-20	SERIES 90	S90-075PV

90411	PUMP-VAR DISPL, CW 90PV100	90-R-100-M8-1-CD-60-P-3-C7-E-03-GBA-38-38-20	SERIES 90	S90-100PV
90412	PUMP-VAR DISPL, CW 90PV075	90-R-075-DD-1-NN-80-P-4-S1-D-GB-GBA-35-35-20	SERIES 90	S90-075PV
90414	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-BC-80-P-3-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
90416	PUMP-VAR DISPL, CW 90PV100	90-R-100-MB-1-NN-60-S-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
90417	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-AB-60-P-4-F1-E-03-GBA-32-32-24	SERIES 90	S90-100PV
90418	PUMP-VAR DISPL, CW 90PV100	90-R-100-M8-1-CD-60-P-3-F1-E-03-GBA-40-40-24	SERIES 90	S90-100PV
90420	MOTOR-FIXED-DISPL 90MF075	90-M-075-NC-0-N-8-N-0-C7-W-00-NNN-00-00-E6	SERIES 90	S90-075MF
90421	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MA-2-NN-80-S-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
90422	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KN-1-NN-80-P-3-C6-E-03-GBA-35-35-24	SERIES 90	S90-075PV
90423	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KN-1-NN-80-P-3-C6-F-03-GBA-35-35-24	SERIES 90	S90-100PV
90424	MOTOR-FIXED-DISPL 90MF075	90-M-075-NC-0-N-8-N-0-C6-W-00-NNN-00-00-24	SERIES 90	S90-075MF
90425	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-2-AB-80-S-4-C6-E-03-GBA-42-42-24	SERIES 90	S90-075PV
90426	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-1-NN-60-S-3-C7-E-03-GBA-38-38-24	SERIES 90	S90-075PV
90427	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-1-AB-80-L-3-C6-D-03-GBA-32-32-24	SERIES 90	S90-075PV
90428	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-1-BC-60-P-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
90430	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-CD-80-L-3-C7-D-03-GBA-35-35-20	SERIES 90	S90-100PV
90432	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-NN-80-P-4-S1-E-03-GBA-26-26-24	SERIES 90	S90-075PV
90433	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-AB-80-P-3-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
90435	MOTOR-FIXED-DISPL 90MF100	90-M-100-NC-0-N-8-N-0-F1-W-00-NNN-00-00-E4	SERIES 90	S90-100MF
90436	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-1-NN-60-S-3-S1-D-03-GBA-20-20-24	SERIES 90	S90-055PV
90438	PUMP-VAR DISPL, CW 90PV055	90-R-055-M8-1-BC-60-S-3-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV
90439	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-NN-60-S-3-S1-D-03-GBA-00-00-24	SERIES 90	S90-075PV
90440	PUMP-VAR DISPL, CW 90PV055	90-R-055-ME-1-BC-60-P-3-C6-C-03-GBA-42-42-24	SERIES 90	S90-055PV
90441	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-CD-80-P-3-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
90442	MOTOR-FIXED-DISPL 90MF055	90-M-055-NC-0-N-8-N-0-S1-W-00-NNN-00-00-E4	SERIES 90	S90-055MF
90443	PUMP-VAR DISPL, CCW 90PV055	90-L-055-DD-1-NN-80-P-4-S1-D-GB-GBA-35-35-20	SERIES 90	S90-055PV
90444	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-AC-60-L-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
90445	PUMP-VAR DISPL, CCW 90PV055	90-L-055-DD-1-NN-60-P-4-C6-C-G4-GBA-42-42-20	SERIES 90	S90-055PV
90446	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-1-NN-60-P-4-C6-C-GB-GBA-35-35-20	SERIES 90	S90-055PV
90447	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-BC-80-S-3-C6-C-03-GBA-38-38-24	SERIES 90	S90-055PV
90448	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-NN-60-S-3-T1-C-03-GBA-35-35-20	SERIES 90	S90-055PV
90449	PUMP-VAR DISPL, CW 90PV075	90-R-075-DD-1-NN-80-P-3-C7-D-GB-GBA-26-26-24	SERIES 90	S90-075PV
90450	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-1-BC-60-S-3-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV
90452	PUMP-VAR DISPL, CCW 90PV055	90-L-055-MA-1-NN-80-R-3-S1-C-03-GBA-38-38-24	SERIES 90	S90-055PV
90453	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-NN-80-R-3-S1-C-03-EBC-35-35-24	SERIES 90	S90-055PV
90454	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-NN-80-R-4-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV

90455	PUMP-VAR DISPL, CCW 90PV055	90-L-055-DD-1-NN-80-P-4-C6-C-GB-GBA-29-29-24	SERIES 90	S90-055PV
90456	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-NN-80-S-3-C6-E-03-EBC-32-32-20	SERIES 90	S90-100PV
90457	PUMP-VAR DISPL, CW 90PV100	90-R-100-ME-1-CD-60-S-4-C7-L-03-GBA-42-42-24	SERIES 90	S90-100PV
90458	PUMP-VAR DISPL, CW 90PV055	90-R-055-DC-1-NN-80-R-4-S1-B-G4-GBA-42-42-24	SERIES 90	S90-055PV
90460	PUMP-VAR DISPL, CCW 90PV055	90-L-055-MA-1-NN-80-S-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
90461	PUMP-VAR DISPL, CCW 90PV100	90-L-100-ME-1-AB-60-P-3-S1-E-03-GBA-35-35-20	SERIES 90	S90-100PV
90462	MOTOR-FIXED-DISPL 90MF075	90-M-075-NC-0-N-8-N-0-S1-W-00-EBA-00-00-E4	SERIES 90	S90-075MF
90463	PUMP-VAR DISPL, CW 90PV100	90-R-100-M8-1-NN-80-P-3-C7-E-03-GBA-26-26-24	SERIES 90	S90-100PV
90464	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-NN-60-S-3-S1-C-03-GBA-32-32-18	SERIES 90	S90-055PV
90467	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-1-AB-60-S-3-S1-C-03-GBA-17-17-24	SERIES 90	S90-055PV
90468	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HF-1-BC-80-P-4-C7-E-03-GBA-26-26-18	SERIES 90	S90-100PV
90469	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-NN-80-S-4-C6-F-03-GBA-26-26-24	SERIES 90	S90-100PV
90470	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-BC-80-S-4-C6-E-03-GBA-23-23-24	SERIES 90	S90-075PV
90471	PUMP-VAR DISPL, CW 90PV075	90-R-075-DD-1-NN-80-L-3-C7-D-GD-GBA-26-26-24	SERIES 90	S90-075PV
90472	PUMP-VAR DISPL, CCW 90PV055	90-L-055-DD-1-NN-80-P-4-S1-C-GB-GBA-35-35-24	SERIES 90	S90-055PV
90473	PUMP-VAR DISPL, CW 90PV100	90-R-100-M8-1-CD-60-L-3-F1-E-03-GBA-40-40-24	SERIES 90	S90-100PV
90474	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-1-AB-60-L-4-S1-D-G4-GBA-38-38-24	SERIES 90	S90-055PV
90476	PUMP-VAR DISPL, CCW 90PV075	90-L-075-M8-1-NN-60-P-3-C7-D-03-GBA-35-35-24	SERIES 90	S90-075PV
90477	PUMP-VAR DISPL, CW 90PV055	90-R-055-MB-1-CD-80-R-3-C6-C-03-GBA-42-42-24	SERIES 90	S90-055PV
90480	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-NN-80-P-3-S1-C-03-GBA-20-20-24	SERIES 90	S90-055PV
90483	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-CD-60-L-3-F1-E-00-GBA-35-35-20	SERIES 90	S90-100PV
90484	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-CD-80-R-4-F1-F-00-GBA-32-26-30	SERIES 90	S90-100PV
90485	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-NN-80-S-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
90486	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HF-1-AD-80-R-3-S1-C-03-GBA-20-20-24	SERIES 90	S90-055PV
90488	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-1-NN-80-P-3-S1-D-03-GBA-29-29-24	SERIES 90	S90-075PV
90489	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-1-NN-60-P-4-S1-C-GB-GBA-35-35-24	SERIES 90	S90-055PV
90490	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MB-1-BC-80-P-3-C7-D-03-GBA-35-35-24	SERIES 90	S90-075PV
90492	MOTOR-FIXED-DISPL 90MF075	90-M-075-NC-0-N-8-N-0-C7-W-00-EAA-00-00-E6	SERIES 90	S90-075MF
90494	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-1-AB-80-S-4-S1-C-Z1-GBA-32-32-20	SERIES 90	S90-055PV
90496	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-NN-80-P-3-C7-D-09-GBA-45-45-20	SERIES 90	S90-075PV
90503	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-BC-60-S-3-S1-E-03-GBA-32-32-20	SERIES 90	S90-100PV
90504	PUMP-VAR DISPL, CW 90PV055	90-R-055-LU-1-AD-80-P-3-C6-C-03-GBA-32-32-24	SERIES 90	S90-055PV
90506	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-1-NN-80-P-4-S1-C-GB-GBA-38-38-24	SERIES 90	S90-055PV
90507	PUMP-VAR DISPL, CW 90PV075	90-R-075-MB-1-NN-80-S-3-S1-D-03-GBA-38-38-24	SERIES 90	S90-075PV
90509	PUMP-VAR DISPL, CW 90PV075	90-R-075-HF-1-BC-60-R-3-S1-D-00-GBA-38-38-20	SERIES 90	S90-075PV
90510	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-2-NN-80-S-3-S1-E-00-GBA-42-42-24	SERIES 90	S90-100PV

90511	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-BB-60-R-3-S1-E-03-GBA-42-42-26	SERIES 90	S90-100PV
90512	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-1-AB-80-S-4-S1-C-G4-GBA-32-32-24	SERIES 90	S90-055PV
90515	PUMP-VAR DISPL, CW 90PV075	90-R-075-DD-1-AB-80-S-4-S1-C-G4-GBA-32-32-24	SERIES 90	S90-075PV
90517	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-1-NN-60-S-3-S1-C-03-GBA-17-17-24	SERIES 90	S90-055PV
90518	PUMP-VAR DISPL, CCW 90PV100	90-L-100-CB-1-BC-60-S-3-S1-E-00-GBA-14-14-10	SERIES 90	S90-100PV
90522	PUMP-VAR DISPL, CW 90PV100	90-R-100-DD-1-NN-80-L-4-S1-E-GB-GBA-23-23-24	SERIES 90	S90-100PV
90523	PUMP-VAR DISPL, CCW 90PV055	90-L-055-M8-1-NN-60-S-3-C6-C-03-GBA-35-35-20	SERIES 90	S90-055PV
90524	PUMP-VAR DISPL, CW 90PV100	90-R-100-M8-1-NN-60-S-3-C7-E-03-GBA-38-38-20	SERIES 90	S90-100PV
90525	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-NN-60-S-3-S1-C-03-GBA-17-17-24	SERIES 90	S90-055PV
90527	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-CD-60-P-3-C7-E-03-GBA-38-38-24	SERIES 90	S90-100PV
90529	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-CD-60-P-3-C6-D-03-GBA-42-42-24	SERIES 90	S90-055PV
90530	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-CD-80-P-4-S1-D-01-GBA-26-26-24	SERIES 90	S90-075PV
90531	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-AC-60-L-3-S1-D-03-GBA-32-32-24	SERIES 90	S90-075PV
90532	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-1-NN-80-S-3-T1-E-03-GBA-42-42-24	SERIES 90	S90-075PV
90533	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-AC-60-L-3-S1-E-03-GBA-32-32-24	SERIES 90	S90-100PV
90534	MOTOR-FIXED-DISPL 90MF100	90-M-100-NC-0-N-8-N-0-C7-W-00-NNN-00-00-E6	SERIES 90	S90-100MF
90535	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-BC-80-S-3-S1-C-03-GBA-35-35-20	SERIES 90	S90-055PV
90537	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-1-NN-80-S-4-S1-C-G4-GBA-32-32-24	SERIES 90	S90-055PV
90539	PUMP-VAR DISPL, CCW 90PV055	90-L-055-ME-1-NN-60-S-3-C6-C-03-GBA-35-35-20	SERIES 90	S90-055PV
90541	PUMP-VAR DISPL, CW 90PV100	90-R-100-MB-1-NN-80-S-3-S1-E-03-GBA-32-32-24	SERIES 90	S90-100PV
90542	MOTOR-FIXED-DISPL 90MF055	90-M-055-NC-0-N-8-N-0-D9-W-00-NNN-00-00-24	SERIES 90	S90-055MF
90543	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-BF-80-P-3-C7-E-03-GBA-32-32-24	SERIES 90	S90-100PV
90544	MOTOR-FIXED-DISPL 90MF100	90-M-100-NC-0-N-7-N-0-C7-W-00-EBA-00-00-F3	SERIES 90	S90-100MF
90545	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HS-2-CD-80-P-3-C6-C-03-GBA-38-38-24	SERIES 90	S90-055PV
90546	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HS-2-NN-80-P-3-S1-C-03-GBA-38-38-24	SERIES 90	S90-055PV
90548	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MB-1-NN-60-S-3-C6-D-03-GBA-40-40-24	SERIES 90	S90-075PV
90549	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-NN-80-P-3-C6-C-03-GBA-32-32-20	SERIES 90	S90-055PV
90550	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-1-NN-60-P-4-S1-C-GB-GBA-42-42-24	SERIES 90	S90-055PV
90551	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-BC-80-P-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-100PV
90553	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-NN-80-P-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-100PV
90556	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-NN-60-L-3-S1-D-03-GBA-32-32-24	SERIES 90	S90-075PV
90557	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-1-NN-60-P-4-S1-C-GB-GBA-35-35-20	SERIES 90	S90-055PV
90558	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-BC-80-P-3-C7-D-03-GBA-38-38-24	SERIES 90	S90-075PV
90559	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-1-NN-80-P-4-C6-C-GB-GBA-29-29-24	SERIES 90	S90-055PV
90560	PUMP-VAR DISPL, CW 90PV075	90-R-075-ME-1-BC-60-S-3-C6-D-03-GBA-35-35-20	SERIES 90	S90-075PV
90561	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-1-BB-80-S-4-S1-D-00-GBA-42-42-24	SERIES 90	S90-075PV

90562	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-NN-60-L-3-S1-E-03-GBA-32-32-24	SERIES 90	S90-100PV
90564	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-NN-80-R-4-S1-C-03-EBC-35-35-24	SERIES 90	S90-055PV
90566	PUMP-VAR DISPL, CW 90PV100	90-R-100-MB-1-CD-60-P-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
90567	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-1-AB-80-P-4-S1-C-GB-GBA-38-38-24	SERIES 90	S90-055PV
90571	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-NN-80-P-3-S1-C-03-GBA-26-26-20	SERIES 90	S90-055PV
90573	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-BB-60-P-3-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV
90576	PUMP-VAR DISPL, CW 90PV075	90-R-075-DD-1-NN-80-S-4-S1-C-G4-GBA-32-32-24	SERIES 90	S90-075PV
90578	PUMP-VAR DISPL, CW 90PV100	90-R-100-MB-1-AB-60-S-3-C7-E-03-GBA-38-38-24	SERIES 90	S90-100PV
90580	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-BC-60-L-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
90581	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-NN-80-P-3-C6-C-03-GBA-40-40-24	SERIES 90	S90-075PV
90582	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-NN-80-P-3-C6-D-03-GBA-35-35-24	SERIES 90	S90-075PV
90583	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-CD-80-P-3-C7-F-03-GBA-26-26-24	SERIES 90	S90-100PV
90585	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-AD-80-P-3-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV
90586	PUMP-VAR DISPL, CW 90PV075	90-R-075-MB-1-BC-60-S-3-C7-D-03-GBA-42-42-20	SERIES 90	S90-075PV
90587	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-1-NN-80-P-4-C6-C-GB-GBA-38-38-24	SERIES 90	S90-055PV
90588	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-NN-80-P-4-C6-C-03-GBA-38-38-24	SERIES 90	S90-075PV
90589	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-1-AB-80-S-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
90590	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-AB-80-S-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-055PV
90591	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-NN-60-L-3-C6-E-03-GBA-42-42-24	SERIES 90	S90-075PV
90600	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-NN-60-S-3-S1-C-03-GBA-17-17-24	SERIES 90	S90-055PV
90603	PUMP-VAR DISPL, CW 90PV055	90-R-055-DC-1-NN-80-P-4-C6-C-G4-GBA-38-38-24-F027	SERIES 90	S90-055PV
90604	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-NN-80-P-4-C6-C-03-GBA-38-38-24-F032	SERIES 90	S90-075PV
90608	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-NN-80-P-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
90610	MOTOR-FIXED-DISPL 90MF075	90-M-075-NC-0-N-8-N-0-S1-W-00-EHD-00-00-E4	SERIES 90	S90-075MF
90611	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-CD-80-P-3-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV
90612	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-BG-80-P-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
90614	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-CD-80-P-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-100PV
90615	PUMP-VAR DISPL, CW 90PV075	90-R-075-CB-1-NN-80-P-4-S1-D-00-GBA-35-35-24	SERIES 90	S90-075PV
90617	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-AD-80-P-3-C6-C-03-GBA-26-26-24	SERIES 90	S90-055PV
90619	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-1-AB-80-D-4-S1-L-GB-GBA-35-35-20	SERIES 90	S90-055PV
90621	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-1-AB-80-P-4-S1-C-G8-GBA-35-35-20	SERIES 90	S90-055PV
90628	PUMP-VAR DISPL, CW 90PV075	90-R-075-DD-1-NN-80-L-3-S1-E-GB-GBA-32-32-24	SERIES 90	S90-075PV
90629	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-NN-80-S-4-F1-E-00-GBA-42-42-24	SERIES 90	S90-100PV
90630	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-2-NN-80-S-4-S1-E-33-GBA-42-42-24	SERIES 90	S90-100PV
90631	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-2-BB-80-S-4-S1-D-33-GBA-42-42-24	SERIES 90	S90-075PV
90632	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-CD-80-P-4-C7-E-03-GBA-32-32-24	SERIES 90	S90-100PV

90633	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-NN-80-P-3-S1-D-03-GBA-32-32-24	SERIES 90	S90-075PV
90634	MOTOR-FIXED-DISPL 90MF075	90-M-075-NC-0-N-7-N-0-C6-W-00-NNN-00-00-E6	SERIES 90	S90-075MF
90635	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-BB-60-L-3-S1-E-03-GBA-32-32-24	SERIES 90	S90-100PV
90638	PUMP-VAR DISPL, CCW 90PV055	90-L-055-ME-1-NN-80-P-3-C6-C-03-GBA-26-26-24	SERIES 90	S90-055PV
90639	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-BG-80-S-4-K1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
90640	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-1-NN-80-R-4-S1-C-GB-GBA-35-35-24	SERIES 90	S90-055PV
90641	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-CD-80-P-3-C7-F-03-GBA-35-35-28	SERIES 90	S90-100PV
90642	PUMP-VAR DISPL, CCW 90PV100	90-L-100-CB-1-NN-80-P-3-S1-F-00-GBA-35-35-28	SERIES 90	S90-100PV
90644	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KN-1-NN-80-P-3-C6-D-03-GBA-42-42-24	SERIES 90	S90-075PV
90645	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KN-1-CD-80-P-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-100PV
90650	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-BC-60-L-3-S1-E-03-GBA-32-32-24	SERIES 90	S90-100PV
90653	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-AB-60-S-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
90656	PUMP-VAR DISPL, CW 90PV100	90-R-100-M8-1-CD-60-P-3-C7-E-03-GBA-38-38-24	SERIES 90	S90-100PV
90658	MOTOR-FIXED-DISPL 90MF055	90-M-055-NC-0-N-8-N-0-C6-W-00-EHD-00-00-E6	SERIES 90	S90-055MF
90659	PUMP-VAR DISPL, CW 90PV075	90-R-075-DD-1-BC-60-P-4-S1-E-G4-GBA-32-32-24	SERIES 90	S90-075PV
90663	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-1-BC-80-L-4-S1-D-G4-GBA-35-35-20	SERIES 90	S90-055PV
90664	PUMP-VAR DISPL, CW 90PV075	90-R-075-MB-1-NN-60-P-3-C7-D-03-EBC-38-38-20	SERIES 90	S90-075PV
90665	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MB-1-BB-60-S-3-C6-C-03-GBA-35-35-24	SERIES 90	S90-075PV
90666	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MA-1-NN-80-S-3-T2-E-03-GBA-35-35-24	SERIES 90	S90-100PV
90667	MOTOR-FIXED-DISPL 90MF075	90-M-075-NC-0-N-8-N-0-C6-W-00-NNN-00-00-22	SERIES 90	S90-075MF
90668	PUMP-VAR DISPL, CW 90PV100	90-R-100-DD-1-CD-60-S-3-C7-E-GB-GBA-42-42-24	SERIES 90	S90-100PV
90669	PUMP-VAR DISPL, CW 90PV100	90-R-100-CB-1-NN-60-S-4-S1-E-00-GBA-42-42-24	SERIES 90	S90-100PV
90671	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-NN-80-P-3-C6-C-03-GBA-32-32-24	SERIES 90	S90-055PV
90672	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-BG-80-P-3-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV
90673	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-BC-60-P-3-C6-C-03-GBA-35-35-28	SERIES 90	S90-055PV
90674	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-BC-80-P-3-C7-D-03-GBA-29-29-24	SERIES 90	S90-075PV
90676	PUMP-VAR DISPL, CW 90PV100	90-R-100-MB-1-NN-60-P-3-C7-E-03-EBC-38-38-20	SERIES 90	S90-100PV
90677	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-1-AB-80-S-4-S1-C-GB-GBA-38-38-24	SERIES 90	S90-055PV
90679	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MB-1-AB-60-P-3-C7-F-03-GBA-35-35-20	SERIES 90	S90-100PV
90681	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-NN-80-P-3-C6-E-01-GBA-20-20-24	SERIES 90	S90-075PV
90682	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-NN-60-S-3-C7-E-03-GBA-38-38-24	SERIES 90	S90-100PV
90683	MOTOR-FIXED-DISPL 90MF075	90-M-075-NC-0-N-8-N-0-C7-N-00-NNN-00-00-00	SERIES 90	S90-075MF
90684	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-BG-80-S-3-C6-C-03-EBC-32-32-24	SERIES 90	S90-055PV
90686	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-BG-80-S-3-C6-C-03-GBA-32-32-24	SERIES 90	S90-055PV
90688	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-NN-80-S-3-C6-C-03-GBA-32-32-24	SERIES 90	S90-055PV
90692	PUMP-VAR DISPL, CW 90PV055	90-R-055-KP-1-NN-60-S-3-S1-C-03-GBA-32-32-24	SERIES 90	S90-055PV

90694	PUMP-VAR DISPL, CW 90PV075	90-R-075-MB-1-BC-60-R-3-C7-D-03-GBA-42-42-20	SERIES 90	S90-075PV
90701	PUMP-VAR DISPL, CW 90PV055	90-R-055-DD-1-NN-60-L-4-S1-D-G4-GBA-35-35-20	SERIES 90	S90-055PV
90703	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-AB-60-S-4-C7-E-03-GBA-32-32-24	SERIES 90	S90-100PV
90709	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-NN-80-P-3-S1-D-03-GBA-29-29-24	SERIES 90	S90-075PV
90710	PUMP-VAR DISPL, CW 90PV100	90-R-100-M8-1-CD-60-R-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
90713	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-NN-80-P-3-S1-D-03-GBA-29-29-24	SERIES 90	S90-075PV
90714	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-CD-80-P-3-C7-E-03-GBA-32-32-24	SERIES 90	S90-100PV
90715	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-NN-80-P-3-S1-D-03-GBA-38-38-24	SERIES 90	S90-075PV
90717	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-NN-80-P-3-S1-D-03-GBA-29-29-24	SERIES 90	S90-055PV
90719	PUMP-VAR DISPL, CCW 90PV100	90-L-100-CB-1-NN-80-S-3-F1-E-00-GBA-35-35-24	SERIES 90	S90-100PV
90720	PUMP-VAR DISPL, CW 90PV100	90-R-100-CB-1-NN-60-S-3-F1-E-00-GBA-35-35-24	SERIES 90	S90-100PV
90721	PUMP-VAR DISPL, CW 90PV100	90-R-100-CB-1-NN-80-S-3-F1-E-00-GBA-35-35-24	SERIES 90	S90-100PV
90722	PUMP-VAR DISPL, CW 90PV055	90-R-055-MA-1-AD-80-S-3-S1-C-03-GBA-26-26-24	SERIES 90	S90-055PV
90726	PUMP-VAR DISPL, CW 90PV075	90-R-075-MB-1-CD-60-S-3-C7-D-03-GBA-35-35-24	SERIES 90	S90-075PV
90728	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-AB-80-S-3-C6-D-03-GBA-40-40-24	SERIES 90	S90-075PV
90730	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-NN-80-P-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-075PV
90750	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-BG-80-P-3-C6-C-03-GBA-35-35-28	SERIES 90	S90-055PV
90751	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-BG-80-P-3-C6-C-03-EBC-35-35-28	SERIES 90	S90-055PV
9200343-01	SHIM		SERIES 20	PARTS - S20 - Purchased Parts
9210428	SHAFT PUMP		SERIES 20	PARTS - S20 - Unique
9210553	PV/MF21 PISTON ASSY, (STANDARD)		SERIES 20	PARTS - S20 - Unique
9221012	PISTON SERVO		SERIES 20	PARTS - S20 - Unique
9221441	SHAFT PUMP		SERIES 20	PARTS - S20 - Unique
9230129	SWASHPLATE-VARIABLE, 16 DEGREE		SERIES 20	PARTS - S20 - Unique
9230583	SPRING		SERIES 20	PARTS - S20 - Purchased Parts
9240217	PIN(BEARING PLATE)		SERIES 20	PARTS - S20 - Unique
9250275	SHIM		SERIES 20	PARTS - S20 - Purchased Parts
9250379	SHAFT MOTOR		SERIES 20	PARTS - S20 - Unique
9260333	LINK		SERIES 20	PARTS - S20 - Purchased Parts
9260442	SWASHPLATE ASSY (PV, STD)		SERIES 20	PARTS - S20 - Unique
9270574	PISTON-SERVO		SERIES 20	PARTS - S20 - Unique
9270754	SWASHPLATE ASSY (PV, STD)		SERIES 20	PARTS - S20 - Unique
9321056	PUMP-VAR-DISPL CCW 90PV042	90L042-EA-1-BB-80-R-3-C3-B-03-GBA-42-42-24	SERIES 90	S90-042PV
9321060	PUMP-VAR-DISPL CCW 90PV042	90L042-HK-1-NN-80-P-3-C3-B-03-GBA-32-32-24	SERIES 90	S90-042PV
9321063	PUMP-VAR-DISPL CCW 90PV042	90L042-KA-1-BC-80-S-3-T3-B-00-GBA-29-29-24	SERIES 90	S90-042PV
9321065	PUMP-VAR-DISPL CCW 90PV042	90L042-KP-1-NN-80-S-3-C3-B-03-GBA-42-42-24	SERIES 90	S90-042PV

9321074	PUMP-VAR-DISPL CCW 90PV042	90L042-CB-1-NN-80-S-3-C3-B-00-GBA-42-42-24	SERIES 90	S90-042PV
9321080	PUMP-VAR-DISPL CCW 90PV042	90L042-KA-1-BB-80-R-3-C3-C-02-GBA-29-20-20	SERIES 90	S90-042PV
9321081	PUMP-VAR-DISPL CCW 90PV042	90L042-KA-1-NN-80-D-4-C3-L-02-GBA-29-29-20	SERIES 90	S90-042PV
9321084	PUMP-VAR-DISPL CCW 90PV042	90L042-HF-1-BC-80-S-3-T3-B-00-GBA-29-29-24	SERIES 90	S90-042PV
9321086	PUMP-VAR-DISPL CCW 90PV042	90L042-EA-1-NN-80-S-3-C3-B-03-GBA-32-32-24	SERIES 90	S90-042PV
9321516	PUMP-VAR-DISPL CW 90PV042	90R042-MB-1-BC-80-P-3-C3-C-02-GBA-42-42-24	SERIES 90	S90-042PV
9321517	PUMP-VAR-DISPL CW 90PV042	90R042-EA-1-NN-80-L-3-C3-B-03-GBA-17-17-20	SERIES 90	S90-042PV
9321526	PUMP-VAR-DISPL CW 90PV042	90R042-KP-1-NN-80-S-3-C3-B-03-GBA-42-42-24	SERIES 90	S90-042PV
9321529	PUMP-VAR-DISPL CW 90PV042	90R042-KP-1-BC-80-R-3-C3-B-00-GBA-32-32-24	SERIES 90	S90-042PV
9321540	PUMP-VAR-DISPL CW 90PV042	90R042-CB-1-NN-80-S-3-C3-B-00-GBA-42-42-24	SERIES 90	S90-042PV
9321541	PUMP-VAR-DISPL CW 90PV042	90R042-DC-1-NN-80-R-4-C3-C-GB-GBA-38-38-24	SERIES 90	S90-042PV
9321545	PUMP-VAR-DISPL CW 90PV042	90R042-HF-1-NN-80-P-4-C3-B-01-GBA-26-26-24	SERIES 90	S90-042PV
9321552	PUMP-VAR-DISPL CW 90PV042	90R042-DC-1-AB-80-D-4-C3-L-GF-GBA-32-32-20	SERIES 90	S90-042PV
9321554	PUMP-VAR-DISPL CW 90PV042	90R042-MB-1-BC-80-L-4-C3-B-03-GBA-42-42-20	SERIES 90	S90-042PV
9321555	PUMP-VAR-DISPL CW 90PV042	90R042-KA-1-NN-80-P-4-C3-B-03-GBA-17-17-24	SERIES 90	S90-042PV
9321556	PUMP-VAR-DISPL CW 90PV042	90R042-KP-1-AB-80-S-4-C3-C-03-GBA-42-42-24	SERIES 90	S90-042PV
9321558	PUMP-VAR-DISPL CW 90PV042	90R042-KA-1-BC-80-S-3-C3-B-00-GBA-29-29-24	SERIES 90	S90-042PV
9321560	PUMP-VAR-DISPL CW 90PV042	90R042-KP-1-BB-80-S-3-C3-B-03-GBA-32-32-24	SERIES 90	S90-042PV
94-2061	PUMP-VAR DISPL, CW	90-R-055-HF-1-BG-80-R-3-S1-C-A3-GBA-38-38-28	SERIES 90	S90-055PV
94-2062	PUMP-VAR DISPL, CW	90-R-055-MA-1-BC-60-S-3-C6-C-03-GBA-42-42-20	SERIES 90	S90-055PV
94-21004	PUMP-VAR DISPL, CCW	90-L-055-EA-1-NN-60-R-3-S1-D-02-GBA-42-42-24	SERIES 90	S90-055PV
94-21005	PUMP-VAR DISPL, CCW	90-L-055-MB-1-BK-80-R-3-S1-D-03-GBA-42-42-20	SERIES 90	S90-055PV
94-21006	PUMP-VAR DISPL, CCW	90-L-055-MA-1-NN-60-S-3-C6-C-03-GBA-32-32-20	SERIES 90	S90-055PV
94-21007	PUMP-VAR DISPL, CCW	90-L-055-MD-1-BC-60-S-3-S1-C-02-GBA-42-42-24	SERIES 90	S90-055PV
94-21008	PUMP-VAR DISPL, CCW	90-L-055-MA-1-AD-80-S-3-S1-C-03-GBA-38-38-20	SERIES 90	S90-055PV
94-21009	PUMP-VAR-DISPL CCW 90PV055	90-L-055-MA-1-NN-80-S-3-C6-C-03-GBA-42-42-24	SERIES 90	S90-055PV
94-21010	PUMP-VAR DISPL, CCW	90-L-055-MK-1-AB-60-R-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-055PV
94-21012	PUMP-VAR DISPL, CCW	90-L-055-EA-1-BC-60-P-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
94-21013	PUMP-VAR DISPL, CCW	90-L-055-EA-1-NN-60-R-3-C6-C-04-GBA-26-26-28	SERIES 90	S90-055PV
94-21014	PUMP-VAR DISPL, CCW	90-L-055-EA-1-NN-60-S-3-T1-C-02-GBA-35-35-24	SERIES 90	S90-055PV
94-21015	PUMP-VAR DISPL, CCW	90-L-055-MA-1-NN-60-P-3-S1-C-03-GBA-42-42-20	SERIES 90	S90-055PV
94-21016	PUMP-VAR DISPL, CCW	90-L-055-EA-6-AB-60-P-3-C6-D-03-FAB-45-45-24	SERIES 90	S90-055PV
94-21017	PUMP-VAR DISPL, CCW	90-L-055-EA-1-CD-60-S-4-S1-C-00-GBA-42-42-24	SERIES 90	S90-055PV
94-21018	PUMP-VAR DISPL, CCW	90-L-055-EA-1-NN-60-S-4-S1-C-00-GBA-42-42-24	SERIES 90	S90-055PV
94-21019	PUMP-VAR DISPL, CCW	90-L-055-EA-1-CD-80-S-4-S1-C-00-GBA-42-42-24	SERIES 90	S90-055PV
94-21020	PUMP-VAR DISPL, CCW	90-L-055-EA-1-NN-80-S-4-S1-C-00-GBA-42-42-24	SERIES 90	S90-055PV

94-21021	PUMP-VAR DISPL, CCW	90-L-055-EA-1-CD-60-R-3-C6-L-03-GBA-35-35-24	SERIES 90	S90-055PV
94-21022	PUMP-VAR DISPL, CCW	90-L-055-EA-1-NN-60-S-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-055PV
94-21025	PUMP-VAR DISPL, CCW	90-L-055-EA-1-NN-60-S-4-S1-C-03-GBA-29-29-20	SERIES 90	S90-055PV
94-21026	PUMP-VAR DISPL, CCW	90-L-055-CA-1-AB-60-P-3-S1-C-00-GBA-42-42-24	SERIES 90	S90-055PV
94-21027	PUMP-VAR DISPL, CCW	90-L-055-EA-1-AB-60-S-3-S1-C-03-GBA-26-26-24	SERIES 90	S90-055PV
94-21028	PUMP-VAR DISPL, CCW	90-L-055-MA-1-NN-60-S-3-S1-C-03-GBA-35-35-20	SERIES 90	S90-055PV
94-21029	PUMP-VAR DISPL, CCW	90-L-055-EA-2-CD-60-S-4-S1-C-33-GBA-42-42-24	SERIES 90	S90-055PV
94-21030	PUMP-VAR DISPL, CCW	90-L-055-EA-2-NN-60-S-4-S1-C-33-GBA-42-42-24	SERIES 90	S90-055PV
94-21031	PUMP-VAR DISPL, CCW	90-L-055-EA-2-CD-80-S-4-S1-C-33-GBA-42-42-24	SERIES 90	S90-055PV
94-21032	PUMP-VAR DISPL, CCW	90-L-055-EA-2-NN-80-S-4-S1-C-33-GBA-42-42-24	SERIES 90	S90-055PV
94-21033	PUMP-VAR DISPL, CCW	90-L-055-EA-1-CD-60-P-4-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
94-21034	PUMP-VAR DISPL, CCW	90-L-055-EA-1-CD-80-S-3-S1-C-04-GFN-38-38-28-C002	SERIES 90	S90-055PV
94-21035	PUMP-VAR DISPL, CCW	90-L-055-MA-1-NN-80-S-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
94-21036	PUMP-VAR DISPL, CCW	90-L-055-KA-1-BB-60-R-3-C6-C-21-GBA-35-35-24	SERIES 90	S90-055PV
94-21037	PUMP-VAR DISPL, CCW	90-L-055-MB-2-BK-80-R-1-S1-D-03-GBA-42-23-20	SERIES 90	S90-055PV
94-21038	PUMP-VAR DISPL, CCW	90-L-055-MB-1-NN-60-S-3-S1-C-03-GBA-32-32-20	SERIES 90	S90-055PV
94-21039	PUMP-VAR DISPL, CCW	90-L-055-EA-1-CD-60-R-4-C6-L-03-FAB-26-26-24	SERIES 90	S90-055PV
94-21041	PUMP-VAR DISPL, CCW	90-L-055-MK-1-NN-60-R-3-S1-C-04-GBA-29-29-24	SERIES 90	S90-055PV
94-21042	PUMP-VAR DISPL, CCW	90-L-055-MK-1-NN-60-R-3-S1-C-04-GBA-42-42-24	SERIES 90	S90-055PV
94-21043	PUMP-VAR DISPL, CCW	90-L-055-MD-1-CD-80-S-3-S1-C-02-GBA-35-35-24	SERIES 90	S90-055PV
94-21044	PUMP-VAR DISPL, CCW	90-L-055-MD-1-BK-80-S-3-S1-C-02-GBA-35-35-24	SERIES 90	S90-055PV
94-21045	PUMP-VAR DISPL, CCW	90-L-055-EA-1-CD-60-R-4-C6-L-04-FAB-26-26-24	SERIES 90	S90-055PV
94-21046	PUMP-VAR DISPL, CCW	90-L-055-EA-1-NN-60-S-4-S1-D-04-FAB-26-26-24	SERIES 90	S90-055PV
94-21049	PUMP-VAR DISPL, CCW	90-L-055-DC-1-NN-60-D-4-C6-L-GB-GBA-42-42-18	SERIES 90	S90-055PV
94-21050	PUMP-VAR DISPL, CCW	90-L-055-EA-1-NN-80-D-3-C6-L-03-FAB-42-42-24	SERIES 90	S90-055PV
94-21051	PUMP-VAR DISPL, CCW	90-L-055-MB-1-BB-60-S-3-C6-D-03-GBA-32-32-20	SERIES 90	S90-055PV
94-21052	PUMP-VAR DISPL, CCW	90-L-055-MB-1-CD-80-S-3-S1-C-02-GBA-35-35-24	SERIES 90	S90-055PV
94-21053	PUMP-VAR DISPL, CCW	90-L-055-MB-1-BK-80-S-3-S1-C-02-GBA-35-35-24	SERIES 90	S90-055PV
94-21054	PUMP-VAR DISPL, CCW	90-L-055-MA-1-NN-61-R-3-C6-D-05-GBA-32-32-24	SERIES 90	S90-055PV
94-21055	PUMP-VAR DISPL, CCW	90-L-055-EA-1-NN-60-P-3-S1-C-02-GBA-42-42-20	SERIES 90	S90-055PV
94-21056	PUMP-VAR DISPL, CCW	90-L-055-MA-1-NN-80-S-3-T1-C-03-GBA-20-20-20	SERIES 90	S90-055PV
94-21057	PUMP-VAR-DISPL CCW 90PV055	90-L-055-EA-1-CD-60-S-3-C6-C-03-GBA-42-42-24	SERIES 90	S90-055PV
94-21058	PUMP-VAR DISPL, CCW	90-L-055-EA-1-AB-60-S-3-C6-C-02-GBA-42-42-24	SERIES 90	S90-055PV
94-21061	PUMP-VAR DISPL, CCW	90-L-055-EP-1-BC-60-S-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
94-21062	PUMP-VAR DISPL, CCW	90-L-055-EA-2-NN-60-S-3-S1-C-03-GBA-26-26-20	SERIES 90	S90-055PV
94-21065	PUMP-VAR DISPL, CCW	90-L-055-MB-1-NN-61-R-3-C6-D-05-GBA-32-32-24	SERIES 90	S90-055PV

94-21066	PUMP-VAR-DISPL CCW 90PV055	90-L-055-MA-1-BC-60-S-3-S1-C-04-GBA-32-32-24	SERIES 90	S90-055PV
94-21071	PUMP-VAR DISPL, CCW	90-L-055-MA-1-AB-60-R-3-S1-L-03-FAB-42-42-24	SERIES 90	S90-055PV
94-21072	PUMP-VAR DISPL, CCW	90-L-055-EA-1-AB-60-R-3-S1-L-03-FAB-42-42-24	SERIES 90	S90-055PV
94-21074	PUMP-VAR DISPL, CCW	90-L-055-MA-1-NN-80-S-3-T1-C-03-GBA-35-35-20	SERIES 90	S90-055PV
94-21075	PUMP-VAR DISPL, CCW	90-L-055-MA-1-NN-80-S-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
94-21076	PUMP-VAR DISPL, CCW	90-L-055-HK-1-BC-60-R-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
94-21077	PUMP-VAR DISPL, CCW	90-L-055-HK-1-BB-60-P-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
94-21078	PUMP-VAR DISPL, CCW	90-L-055-HK-1-AB-60-P-3-S1-C-02-GBA-20-20-24	SERIES 90	S90-055PV
94-21079	PUMP-VAR DISPL, CCW	90-L-055-HK-1-NN-60-R-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
94-21080	PUMP-VAR DISPL, CCW	90-L-055-HK-1-BC-60-P-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
94-21083	PUMP-VAR DISPL, CCW	90-L-055-EP-1-BG-80-R-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-055PV
94-21084	PUMP-VAR DISPL, CCW	90-L-055-EP-1-NN-80-S-3-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV
94-21085	PUMP-VAR DISPL, CCW	90-L-055-HK-1-BG-80-P-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
94-21086	PUMP-VAR DISPL, CCW	90-L-055-HF-1-NN-60-P-3-K1-C-03-GBA-20-20-24	SERIES 90	S90-055PV
94-21087	PUMP-VAR DISPL, CCW	90-L-055-EA-1-AB-60-P-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-055PV
94-21091	PUMP-VAR DISPL, CCW	90-L-055-EP-1-NN-60-P-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-055PV
94-21092	PUMP-VAR DISPL, CCW	90-L-055-EP-1-CD-80-S-3-C6-C-03-GBA-38-38-24	SERIES 90	S90-055PV
94-21093	PUMP-VAR DISPL, CCW	90-L-055-EP-1-BG-80-S-3-C6-C-03-GBA-38-38-24	SERIES 90	S90-055PV
94-21094	PUMP-VAR DISPL, CCW	90-L-055-MA-1-NN-80-S-4-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
94-21095	PUMP-VAR DISPL, CCW	90-L-055-EP-1-BC-60-R-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
94-21096	PUMP-VAR DISPL, CCW	90-L-055-MA-6-BC-60-S-3-S1-C-03-GBA-48-48-24	SERIES 90	S90-055PV
94-21097	PUMP-VAR DISPL, CCW	90-L-055-MA-1-BC-60-S-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
94-21098	PUMP-VAR DISPL, CCW	90-L-055-EA-1-NN-80-S-3-C6-C-03-GBA-42-42-24	SERIES 90	S90-055PV
94-21099	PUMP-VAR DISPL, CCW	90-L-055-DD-1-NN-80-S-3-C6-C-GF-GBA-20-20-20	SERIES 90	S90-055PV
94-21100	PUMP-VAR DISPL, CCW	90-L-055-EA-1-NN-60-S-3-T1-C-02-EAB-38-38-24	SERIES 90	S90-055PV
94-21101	PUMP-VAR DISPL, CCW	90-L-055-EA-1-AB-60-L-3-K1-D-00-GEA-38-38-24	SERIES 90	S90-055PV
94-21102	PUMP-VAR DISPL, CCW	90-L-055-MA-1-NN-60-S-3-C6-C-03-GBA-42-42-24	SERIES 90	S90-055PV
94-21103	PUMP-VAR DISPL, CCW	90-L-055-EA-1-BC-60-S-3-S1-C-03-GBA-42-42-28	SERIES 90	S90-055PV
94-21104	PUMP-VAR DISPL, CCW	90-L-055-EA-1-BC-60-S-3-C6-C-04-GBA-42-42-24	SERIES 90	S90-055PV
94-21105	PUMP-VAR DISPL, CCW	90-L-055-EA-1-BK-80-P-3-T1-C-03-GBA-42-42-28	SERIES 90	S90-055PV
94-21106	PUMP-VAR DISPL, CCW	90-L-055-EA-1-NN-60-S-3-S1-C-03-GBA-29-29-24	SERIES 90	S90-055PV
94-21107	PUMP-VAR DISPL, CCW	90-L-055-EA-1-NN-60-L-3-S1-C-05-GBA-38-38-20	SERIES 90	S90-055PV
94-21108	PUMP-VAR DISPL, CCW	90-L-055-MA-1-BB-60-S-3-C6-D-36-GBA-35-35-24	SERIES 90	S90-055PV
94-21113	PUMP-VAR DISPL, CCW	90-L-055-MA-1-NN-60-S-3-C6-D-36-GBA-35-35-24	SERIES 90	S90-055PV
94-21115	PUMP-VAR DISPL, CCW	90-L-055-DD-1-AB-60-L-4-S1-C-G8-GBA-42-42-20	SERIES 90	S90-055PV
94-21118	PUMP-VAR DISPL, CCW	90-L-055-MA-1-NN-60-S-3-S1-C-03-GBA-29-29-24	SERIES 90	S90-055PV

94-21120	PUMP-VAR DISPL, CCW	90-L-055-HP-1-BG-80-P-3-S1-C-02-GBA-35-35-24	SERIES 90	S90-055PV
94-21121	PUMP-VAR DISPL, CCW	90-L-055-MA-1-NN-60-S-3-C6-C-04-GBA-32-32-24	SERIES 90	S90-055PV
94-21124	PUMP-VAR DISPL, CCW	90-L-055-MC-1-CD-60-R-3-S1-D-02-GBA-29-29-24	SERIES 90	S90-055PV
94-21125	PUMP-VAR DISPL, CCW	90-L-055-MC-1-NN-60-R-3-S1-D-02-GBA-29-29-24	SERIES 90	S90-055PV
94-21126	PUMP-VAR DISPL, CCW	90-L-055-MA-1-NN-80-S-4-S1-C-03-GBA-26-26-24	SERIES 90	S90-055PV
94-21127	PUMP-VAR DISPL, CCW	90-L-055-MB-1-AB-60-S-3-S1-C-03-GBA-38-38-20	SERIES 90	S90-055PV
94-21128	PUMP-VAR DISPL, CCW	90-L-055-EP-1-BG-80-R-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-055PV
94-21129	PUMP-VAR DISPL, CCW	90-L-055-EX-1-AB-60-S-3-S1-C-03-GBA-17-17-24	SERIES 90	S90-055PV
94-21130	PUMP-VAR DISPL, CCW	90-L-055-MA-1-NN-60-S-3-S1-C-03-GBA-23-23-24	SERIES 90	S90-055PV
94-21131	PUMP-VAR-DISPL CCW 90PV055	90-L-055-EA-1-BC-60-S-3-C6-D-03-GBA-35-35-20	SERIES 90	S90-055PV
94-21133	PUMP-VAR DISPL, CCW	90-L-055-EA-1-NN-60-S-3-C6-D-36-GBA-35-35-24	SERIES 90	S90-055PV
94-21134	PUMP-VAR-DISPL CCW 90PV055	90-L-055-KA-2-CD-60-P-3-C6-D-21-GBA-29-29-28	SERIES 90	S90-055PV
94-21135	PUMP-VAR DISPL, CCW	90-L-055-KA-2-BC-60-P-4-S1-D-21-GBA-29-29-28	SERIES 90	S90-055PV
94-21136	PUMP-VAR DISPL, CCW	90-L-055-EX-1-CD-80-S-3-C6-C-03-GBA-32-32-24	SERIES 90	S90-055PV
94-21137	PUMP-VAR DISPL, CCW	90-L-055-EX-1-BG-80-S-1-C6-C-03-GBA-32-32-24	SERIES 90	S90-055PV
94-21138	PUMP-VAR DISPL, CCW	90-L-055-MA-1-BC-60-R-3-S1-C-03-GBA-29-29-24	SERIES 90	S90-055PV
94-21139	PUMP-VAR DISPL, CCW	90-L-055-MA-1-BC-60-P-3-S1-C-03-GBA-29-29-24	SERIES 90	S90-055PV
94-21140	PUMP-VAR DISPL, CCW	90-L-055-MA-1-BG-80-R-3-S1-C-03-GBA-29-29-24	SERIES 90	S90-055PV
94-21141	PUMP-VAR DISPL, CCW	90-L-055-DD-1-CD-60-S-3-T1-C-GB-GBA-42-42-20	SERIES 90	S90-055PV
94-21142	PUMP-VAR DISPL, CCW	90-L-055-EX-1-BG-80-S-3-S1-C-03-GBA-32-32-24	SERIES 90	S90-055PV
94-21143	PUMP-VAR DISPL, CCW	90-L-055-EA-1-NN-60-S-3-T1-C-02-GBA-42-42-24	SERIES 90	S90-055PV
94-2386	PUMP-VAR DISPL, CCW	90-L-055-MA-1-NN-60-S-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-055PV
94-2387	PUMP-VAR DISPL, CCW	90-L-055-EA-1-AB-60-S-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
94-2388	PUMP-VAR DISPL, CCW	90-L-055-MB-1-AB-60-P-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
94-2389	PUMP-VAR DISPL, CCW	90-L-055-EA-1-NN-60-P-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
94-2390	PUMP-VAR DISPL, CW	90-R-055-MA-1-AB-60-S-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
94-2391	PUMP-VAR-DISPL CCW 90PV055	90-L-055-EA-1-NN-60-S-3-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV
94-2392	PUMP-VAR DISPL, CCW	90-L-055-EA-1-BC-60-S-3-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV
94-2393	PUMP-VAR DISPL, CW	90-R-055-MA-1-BC-60-S-3-C6-C-06-GBA-38-38-24	SERIES 90	S90-055PV
94-2394	PUMP-VAR DISPL, CCW	90-L-055-EA-1-NN-60-S-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
94-2396	PUMP-VAR DISPL, CCW	90-L-055-EA-1-AB-60-P-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
94-2397	PUMP-VAR DISPL, CCW	90-L-055-MA-1-NN-61-S-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
94-2399	PUMP-VAR DISPL, CW	90-R-055-MB-1-BC-60-S-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
94-2400	PUMP-VAR DISPL, CCW	90-L-055-EA-1-NN-61-P-3-S1-C-00-GBA-35-35-24	SERIES 90	S90-055PV
94-2401	PUMP-VAR DISPL, CCW	90-L-055-EA-1-BC-61-P-3-S1-C-00-GBA-35-35-24	SERIES 90	S90-055PV
94-2402	PUMP-VAR DISPL, CW	90-R-055-EA-1-NN-60-R-3-S1-C-03-GBA-32-32-24	SERIES 90	S90-055PV

94-2406	PUMP-VAR DISPL, CW	90-R-055-MA-1-BC-60-S-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
94-2409	PUMP-VAR DISPL, CCW	90-L-055-EA-1-BB-60-P-3-S1-C-03-GBA-32-32-24	SERIES 90	S90-055PV
94-2413	PUMP-VAR DISPL, CW	90-R-055-MA-1-NN-60-S-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
94-2425	PUMP-VAR DISPL, CW	90-R-055-EA-1-NN-60-S-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-055PV
94-2427	PUMP-VAR DISPL, CW	90-R-055-EA-1-NN-60-P-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
94-2428	PUMP-VAR DISPL, CW	90-R-055-MB-1-AB-60-S-3-S1-D-04-GBA-38-38-20	SERIES 90	S90-055PV
94-2430	PUMP-VAR DISPL, CCW	90-L-055-EA-1-AB-60-R-3-S1-L-03-GBA-42-42-24	SERIES 90	S90-055PV
94-2431	PUMP-VAR DISPL, CCW	90-L-055-MA-1-AB-60-R-3-S1-L-03-GBA-42-42-24	SERIES 90	S90-055PV
94-2435	PUMP-VAR DISPL, CCW	90-L-055-EA-1-NN-60-R-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
94-2437	PUMP-VAR DISPL, CCW	90-L-055-EA-1-BC-60-P-3-C6-C-04-GBA-26-26-24	SERIES 90	S90-055PV
94-2438	PUMP-VAR DISPL, CCW	90-L-055-EA-1-CD-60-S-4-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
94-2439	PUMP-VAR DISPL, CCW	90-L-055-EA-1-NN-60-S-4-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
94-2440	PUMP-VAR DISPL, CCW	90-L-055-EA-1-CD-80-S-4-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
94-2441	PUMP-VAR DISPL, CCW	90-R-055-ME-1-BB-60-S-3-C6-C-03-GBA-38-38-24	SERIES 90	S90-055PV
94-2444	PUMP-VAR DISPL, CCW	90-L-055-EA-1-BC-60-R-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
94-2448	PUMP-VAR DISPL, CCW	90-L-055-MB-1-BC-60-S-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
94-2458	PUMP-VAR DISPL, CW	90-R-055-MB-1-BB-60-D-3-S1-L-03-GBA-42-42-28	SERIES 90	S90-055PV
94-2461	PUMP-VAR DISPL, CCW	90-L-055-MA-1-NN-61-R-3-C6-D-00-GBA-32-32-24	SERIES 90	S90-055PV
94-2462	PUMP-VAR DISPL, CCW	90-L-055-EA-1-AB-60-P-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
94-2465	PUMP-VAR DISPL, CW	90-R-055-KA-1-CD-80-P-3-C6-D-04-GBA-42-42-24	SERIES 90	S90-055PV
94-2466	PUMP-VAR-DISPL CW 90PV055	90-R-055-KA-1-AD-80-P-3-S1-D-04-GBA-42-42-24	SERIES 90	S90-055PV
94-2468	PUMP-VAR DISPL, CCW	90-L-055-MA-1-CD-60-P-3-S1-C-03-GBA-17-17-24	SERIES 90	S90-055PV
94-2469	PUMP-VAR DISPL, CCW	90-L-055-MA-1-BC-60-P-3-S1-C-03-GBA-17-17-24	SERIES 90	S90-055PV
94-2470	PUMP-VAR DISPL, CW	90-R-055-MB-6-CD-80-P-3-C6-C-03-GBA-45-45-28	SERIES 90	S90-055PV
94-2472	PUMP-VAR DISPL, CCW	90-L-055-EA-1-BB-60-S-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
94-2473	PUMP-VAR DISPL, CCW	90-L-055-EA-1-CD-60-S-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
94-2474	PUMP-VAR DISPL, CCW	90-L-055-EA-1-BB-60-R-3-T1-C-03-GBA-38-38-24	SERIES 90	S90-055PV
94-2475	PUMP-VAR DISPL, CCW	90-L-055-EA-1-NN-80-S-4-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
94-2486	PUMP-VAR DISPL, CCW	90-L-055-EA-1-NN-60-P-3-S1-D-02-GBA-42-42-24	SERIES 90	S90-055PV
94-2487	PUMP-VAR-DISPL CW 90PV055	90-R-055-ME-1-BB-60-S-3-C6-C-03-GBA-38-38-20	SERIES 90	S90-055PV
94-2488	PUMP-VAR DISPL, CW	90-R-055-MA-1-NN-80-S-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
94-2489	PUMP-VAR DISPL, CW	90-R-055-EA-1-NN-80-S-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
94-2490	PUMP-VAR DISPL, CCW	90-L-055-EA-1-BB-60-R-3-C6-C-04-GBA-35-35-24	SERIES 90	S90-055PV
94-2492	PUMP-VAR DISPL CW	90-R-055-EP-1-AB-60-S-3-S1-C-00-GBA-29-29-24	SERIES 90	S90-055PV
94-2496	PUMP-VAR DISPL, CCW	90-L-055-EA-1-AB-60-L-4-S1-C-03-GBA-23-23-24	SERIES 90	S90-055PV
94-2497	PUMP-VAR DISPL, CCW	90-L-055-EA-1-NN-60-L-4-S1-C-03-GBA-23-23-24	SERIES 90	S90-055PV

94-2533	PUMP-VAR DISPL, CCW	90-L-055-EP-1-BK-80-P-3-S1-D-03-GBA-35-35-20	SERIES 90	S90-055PV
94-2535	PUMP-VAR DISPL, CW	90-R-055-MB-1-BC-60-S-3-S1-D-04-GEA-42-42-20	SERIES 90	S90-055PV
94-2536	PUMP-VAR DISPL, CW	90-R-055-MB-1-AB-60-S-3-S1-D-04-GEA-38-38-20	SERIES 90	S90-055PV
94-2538	PUMP-VAR DISPL CW	90-R-055-MA-1-NN-60-S-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
94-2546	PUMP-VAR DISPL, CW	90-R-055-EA-1-CD-60-P-3-C6-D-02-GBA-38-38-24	SERIES 90	S90-055PV
94-2547	PUMP-VAR DISPL, CW	90-R-055-EA-1-NN-60-P-3-S1-D-02-GBA-23-23-24	SERIES 90	S90-055PV
94-2549	PUMP-VAR DISPL, CW	90-R-055-EA-1-CD-60-S-3-S1-C-03-GBA-29-29-24	SERIES 90	S90-055PV
94-2566	PUMP-VAR DISPL, CW	90-R-055-MD-1-AB-60-S-3-S1-D-02-GEA-38-38-20	SERIES 90	S90-055PV
94-2567	PUMP-VAR DISPL, CW	90-R-055-MD-1-NN-60-S-3-S1-D-02-GEA-38-38-20	SERIES 90	S90-055PV
94-2573	PUMP-VAR DISPL, CCW	90-L-055-MB-1-NN-60-P-3-S1-D-04-GBA-42-42-24	SERIES 90	S90-055PV
94-2574	PUMP- VAR DISPL, CCW	90-L-055-EA-6-NN-60-P-3-S1-C-03-GBA-48-48-24	SERIES 90	S90-055PV
94-2575	PUMP-VAR DISPL, CW	90-R-055-MA-1-BC-60-S-3-C6-C-03-GBA-38-38-24	SERIES 90	S90-055PV
94-2576	PUMP-VAR DISPL, CCW	90-L-055-MA-1-NN-60-S-3-S1-C-05-GBA-32-32-24	SERIES 90	S90-055PV
94-2577	PUMP-VAR DISPL, CCW	90-L-055-EA-1-NN-60-P-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
94-2579	PUMP-VAR DISPL, CW	90-R-055-EA-1-BC-60-S-3-S1-C-03-GBA-23-23-24	SERIES 90	S90-055PV
94-2580	PUMP-VAR DISPL, CCW	90-L-055-EA-1-NN-61-P-3-S1-D-03-GBA-26-26-24	SERIES 90	S90-055PV
94-2581	PUMP-VAR DISPL, CW	90-R-055-EA-1-AB-60-P-3-S1-C-03-GBA-17-17-24	SERIES 90	S90-055PV
94-2583	PUMP-VAR DISPL , CCW	90-L-055-EA-1-AB-60-S-3-S1-C-03-GBA-42-42-28	SERIES 90	S90-055PV
94-2584	PUMP-VAR DISPL, CCW	90-L-055-EA-1-CD-60-P-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
94-2585	PUMP-VAR-DISPL CW 90PV055	90-R-055-MA-1-NN-60-S-3-S1-C-03-GBA-23-23-18	SERIES 90	S90-055PV
94-2586	PUMP-VAR DISPL, CCW	90-L-055-MA-1-CD-60-S-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-055PV
94-2588	PUMP-VAR DISPL, CCW	90-L-055-EA-1-AB-60-P-4-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
94-2590	PUMP-VAR DISPL, CCW	90-L-055-MA-1-AB-60-S-3-C6-C-04-GBA-42-42-24	SERIES 90	S90-055PV
94-2593	PUMP-VAR DISPL, CW	90-R-055-EA-1-NN-60-P-3-T1-C-03-GBA-38-14-20	SERIES 90	S90-055PV
94-2594	PUMP-VAR DISPL, CCW	90-L-055-CB-1-NN-60-R-3-C6-C-00-GBA-26-26-20	SERIES 90	S90-055PV
94-2595	PUMP-VAR DISPL, CCW	90-L-055-MK-1-AB-60-P-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
94-2596	PUMP-VAR DISPL, CCW	90-L-055-MK-1-AB-60-S-3-S1-C-05-GBA-42-42-24	SERIES 90	S90-055PV
94-2597	PUMP-VAR DISPL, CW	90-R-055-MA-1-BC-61-S-4-S1-D-03-GBA-26-26-24	SERIES 90	S90-055PV
94-2600	PUMP-VAR DISPL, CCW	90-L-055-MK-2-AB-60-P-3-S1-C-03-GBA-17-17-24	SERIES 90	S90-055PV
94-2601	PUMP-VAR DISPL, CW	90-R-055-EA-1-AB-60-S-3-S1-D-03-GBA-38-38-20	SERIES 90	S90-055PV
94-2602	PUMP-VAR DISPL, CW	90-R-055-EP-1-NN-60-S-3-S1-D-00-GBA-29-29-24	SERIES 90	S90-055PV
94-2603	PUMP-VAR DISPL, CW	90-R-055-CB-6-AB-60-R-3-C6-C-00-GBA-48-48-20	SERIES 90	S90-055PV
94-2604	PUMP-VAR DISPL, CCW	90-L-055-MA-1-BC-61-P-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
94-2605	PUMP-VAR DISPL, CCW	90-L-055-EA-1-NN-60-R-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-055PV
94-2608	PUMP-VAR DISPL, CW	90-R-055-EP-1-NN-80-S-3-S1-C-03-GBA-42-42-20	SERIES 90	S90-055PV
94-2612	PUMP-VAR DISPL, CCW	90-L-055-MA-6-NN-80-S-3-S1-C-04-GBA-45-45-24	SERIES 90	S90-055PV

94-2613	PUMP-VAR DISPL, CW	90-R-055-MA-1-NN-60-S-3-S1-D-03-GBA-14-14-20	SERIES 90	S90-055PV
94-2614	PUMP-VAR DISPL, CW	90-R-055-EA-1-AB-60-S-3-C6-D-04-GBA-35-35-24	SERIES 90	S90-055PV
94-2615	PUMP-VAR DISPL, CW	90-R-055-EA-1-BC-60-S-3-C6-D-04-GBA-35-35-24	SERIES 90	S90-055PV
94-2616	PUMP-VAR DISPL, CW	90-R-055-MA-1-AB-60-S-3-C6-D-04-GBA-35-35-24	SERIES 90	S90-055PV
94-2617	PUMP-VAR DISPL, CW	90-R-055-MA-1-BC-60-S-3-C6-D-04-GBA-35-35-24	SERIES 90	S90-055PV
94-2618	PUMP-VAR DISPL, CW	90-R-055-EA-1-BC-60-S-3-C6-D-03-GBA-35-35-18	SERIES 90	S90-055PV
94-2619	PUMP-VAR DISPL, CW	90-R-055-MA-1-BC-60-P-3-C6-C-03-GBA-42-42-24	SERIES 90	S90-055PV
94-2620	PUMP-VAR DISPL, CCW	90-L-055-EA-1-NN-60-P-3-C6-D-03-GBA-42-42-24	SERIES 90	S90-055PV
94-2622	PUMP-VAR DISPL, CW	90-R-055-EA-1-AB-60-R-3-S1-L-03-GBA-42-42-24	SERIES 90	S90-055PV
94-2623	PUMP-VAR DISPL, CW	90-R-055-EA-1-CD-60-S-3-C6-C-03-GBA-42-42-24	SERIES 90	S90-055PV
94-2625	PUMP-VAR DISPL, CW	90-R-055-EA-1-AB-60-S-3-T1-C-03-GBA-35-35-28	SERIES 90	S90-055PV
94-2626	PUMP-VAR DISPL, CW	90-R-055-EA-1-AD-80-P-4-C6-D-04-GBA-35-35-24	SERIES 90	S90-055PV
94-2627	PUMP-VAR DISPL, CW	90-R-055-EA-1-CD-60-R-3-S1-L-03-GBA-42-42-24	SERIES 90	S90-055PV
94-2628	PUMP-VAR-DISPL CW 90PV055	90-R-055-MA-1-BC-60-S-3-C6-C-03-GBA-35-35-20	SERIES 90	S90-055PV
94-2629	PUMP-VAR DISPL, CW	90-R-055-EA-1-NN-60-P-3-C6-D-00-GBA-29-29-20	SERIES 90	S90-055PV
94-2630	PUMP-VAR DISPL, CW	90-R-055-CB-1-AB-60-S-3-C6-D-00-GBA-42-42-20	SERIES 90	S90-055PV
94-2631	PUMP-VAR DISPL, CCW	90-L-055-EA-1-CD-60-L-3-S1-C-06-GBA-32-32-24	SERIES 90	S90-055PV
94-2632	PUMP-VAR DISPL, CCW	90-L-055-EA-1-NN-60-L-3-S1-C-06-GBA-32-32-24	SERIES 90	S90-055PV
94-2633	PUMP-VAR DISPL, CCW	90-L-055-EA-1-BC-60-S-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
94-2634	PUMP-VAR DISPL, CW	90-R-055-MK-1-NN-60-R-3-S1-C-05-GBA-35-35-24	SERIES 90	S90-055PV
94-2635	PUMP-VAR DISPL, CW	90-R-055-MA-1-AB-60-S-3-C6-C-03-GBA-35-35-20	SERIES 90	S90-055PV
94-2636	PUMP-VAR DISPL, CCW	90-L-055-MA-1-NN-60-S-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
94-2637	PUMP-VAR DISPL, CCW	90-L-055-MA-1-CD-60-S-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
94-2638	PUMP-VAR DISPL, CW	90-R-055-MK-1-NN-60-R-3-S1-C-05-GBA-38-38-24	SERIES 90	S90-055PV
94-2639	PUMP-VAR DISPL, CW	90-R-055-MB-1-BB-60-P-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
94-2640	PUMP-VAR DISPL, CW	90-R-055-MA-1-AB-60-S-3-S1-C-03-GBA-26-26-20	SERIES 90	S90-055PV
94-2642	PUMP-VAR DISPL, CW	90-R-055-MA-1-CD-80-S-3-S1-D-03-GBA-35-35-20	SERIES 90	S90-055PV
94-2643	PUMP-VAR DISPL, CW	90-R-055-EA-1-AB-61-P-4-S1-D-03-GBA-17-17-24	SERIES 90	S90-055PV
94-2644	PUMP-VAR DISPL, CCW	90-L-055-EA-1-AB-60-S-3-S1-D-03-GBA-35-35-20	SERIES 90	S90-055PV
94-2647	PUMP-VAR DISPL, CW	90-R-055-EA-1-CD-61-P-3-S1-C-00-GBA-35-35-24	SERIES 90	S90-055PV
94-2649	PUMP-VAR DISPL, CW	90-R-055-EA-1-NN-61-R-3-C6-C-03-GBA-20-20-24	SERIES 90	S90-055PV
94-2650	PUMP-VAR DISPL, CW	90-R-055-EA-1-BB-60-S-3-S1-C-03-GBA-26-26-20	SERIES 90	S90-055PV
94-2651	PUMP-VAR DISPL, CCW	90-L-055-EA-1-CD-60-R-3-S1-C-03-GBA-32-32-24	SERIES 90	S90-055PV
94-2652	PUMP-VAR DISPL, CW	90-R-055-MA-1-CD-60-R-3-T1-L-03-GBA-42-42-24	SERIES 90	S90-055PV
94-2653	PUMP-VAR DISPL, CW	90-R-055-MA-1-CD-60-R-3-S1-L-03-GBA-29-29-24	SERIES 90	S90-055PV
94-2654	PUMP-VAR DISPL, CCW	90-L-055-EA-1-AB-60-L-3-T1-C-00-GEA-38-38-24	SERIES 90	S90-055PV

94-2655	PUMP-VAR DISPL, CCW	90-L-055-EA-1-AB-60-L-3-T1-D-00-GEA-38-38-24	SERIES 90	S90-055PV
94-2656	PUMP-VAR DISPL, CW	90-R-055-EA-1-NN-80-P-3-S1-C-03-GBA-35-35-20	SERIES 90	S90-055PV
94-2657	PUMP-VAR DISPL, CW	90-R-055-MB-1-CD-60-S-3-S1-D-03-GBA-38-38-20	SERIES 90	S90-055PV
94-2658	PUMP-VAR-DISPL CCW 90PV055	90-L-055-EA-1-BC-60-S-3-S1-C-00-GBA-35-35-24	SERIES 90	S90-055PV
94-2659	PUMP-VAR DISPL, CCW	90-L-055-EA-1-NN-60-R-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
94-2660	PUMP-VAR DISPL, CCW	90-L-055-EA-1-CD-60-P-3-S1-C-03-GBA-17-17-24	SERIES 90	S90-055PV
94-2661	PUMP-VAR DISPL, CCW	90-L-055-EA-1-BC-60-P-3-S1-C-03-GBA-17-17-24	SERIES 90	S90-055PV
94-2662	PUMP-VAR DISPL, CCW	90-L-055-EA-1-CD-61-P-3-S1-C-00-GBA-35-35-24	SERIES 90	S90-055PV
94-2664	PUMP-VAR DISPL, CW	90-R-055-MA-1-NN-80-S-3-S1-C-03-GBA-35-35-20	SERIES 90	S90-055PV
94-2665	PUMP-VAR DISPL, CW	90-R-055-MK-1-NN-60-R-3-S1-C-04-GBA-29-29-24	SERIES 90	S90-055PV
94-2666	PUMP-VAR DISPL, CW	90-R-055-MK-1-NN-60-R-3-S1-C-04-GBA-42-42-24	SERIES 90	S90-055PV
94-2667	PUMP-VAR DISPL, CW	90-R-055-MA-1-CD-60-S-3-S1-C-03-GBA-42-42-20	SERIES 90	S90-055PV
94-2668	PUMP-VAR DISPL, CW	90-R-055-MA-1-NN-60-S-3-S1-C-03-GBA-42-42-20	SERIES 90	S90-055PV
94-2669	PUMP-VAR DISPL, CCW	90-L-055-MA-1-NN-60-S-3-C6-C-04-GBA-42-42-24	SERIES 90	S90-055PV
94-2672	PUMP-VAR DISPL, CCW	90-L-055-MB-1-AB-60-S-3-S1-D-03-GBA-38-38-20	SERIES 90	S90-055PV
94-2673	PUMP-VAR DISPL, CCW	90-L-055-MB-1-CD-60-S-3-S1-D-03-GBA-38-38-20	SERIES 90	S90-055PV
94-2674	PUMP-VAR DISPL, CCW	90-L-055-MB-6-BC-60-S-3-S1-C-03-GBA-48-48-24	SERIES 90	S90-055PV
94-2675	PUMP-VAR DISPL, CCW	90-L-055-EA-1-BC-60-S-3-S1-C-03-GBA-26-26-24	SERIES 90	S90-055PV
94-2676	PUMP-VAR DISPL, CW	90-R-055-EP-2-CD-80-R-3-S1-D-00-GBA-42-42-20	SERIES 90	S90-055PV
94-2679	PUMP-VAR DISPL, CCW	90-L-055-MA-1-NN-60-R-3-C6-L-03-GBA-42-42-24	SERIES 90	S90-055PV
94-2681	PUMP-VAR DISPL, CCW	90-L-055-MA-1-BC-61-P-3-S1-C-03-GBA-38-38-24	SERIES 90	S90-055PV
94-2682	PUMP-VAR DISPL, CCW	90-L-055-EA-1-CD-60-S-4-S1-C-03-GBA-42-42-20	SERIES 90	S90-055PV
94-2684	PUMP-VAR DISPL, CW	90-R-055-MA-1-AB-61-S-3-S1-D-03-GBA-23-23-20	SERIES 90	S90-055PV
94-2685	PUMP-VAR DISPL, CW	90-R-055-MB-1-NN-60-S-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
94-2686	PUMP-VAR DISPL, CW	90-R-055-MB-1-CD-60-P-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
94-2687	PUMP-VAR DISPL, CW	90-R-055-MA-1-AB-61-S-3-S1-D-03-GBA-26-26-20	SERIES 90	S90-055PV
94-2688	PUMP-VAR DISPL, CW	90-R-055-MA-1-AB-61-S-3-S1-D-03-GBA-26-26-24	SERIES 90	S90-055PV
94-2689	PUMP-VAR DISPL, CW	90-R-055-MA-1-AB-60-R-3-S1-L-03-GBA-29-29-24	SERIES 90	S90-055PV
94-2690	PUMP-VAR DISPL, CCW	90-L-055-MA-1-NN-60-R-3-C6-L-03-GBA-35-35-24	SERIES 90	S90-055PV
94-2692	PUMP-VAR DISPL, CCW	90-L-055-EA-1-CD-60-R-3-S1-D-02-GBA-42-42-24	SERIES 90	S90-055PV
94-2693	PUMP-VAR DISPL, CCW	90-L-055-EA-1-CD-80-R-3-T1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
94-2694	PUMP-VAR DISPL, CCW	90-L-055-EA-1-CD-80-R-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
94-2695	PUMP-VAR-DISPL CW 90PV055	90-R-055-ME-1-BB-60-S-3-C6-C-28-FAA-38-38-20	SERIES 90	S90-055PV
94-2697	PUMP-VAR DISPL, CCW	90-L-055-EA-1-AB-60-P-3-S1-C-03-GBA-42-42-28	SERIES 90	S90-055PV
94-2698	PUMP-VAR DISPL, CCW	90-L-055-MA-1-CD-60-R-3-T1-L-03-GBA-42-42-24	SERIES 90	S90-055PV
94-2699	PUMP-VAR DISPL, CCW	90-L-055-MA-1-AB-60-R-3-S1-L-03-GBA-29-29-24	SERIES 90	S90-055PV

94-2700	PUMP-VAR DISPL, CW	90-R-055-EA-1-BC-60-S-3-S1-C-03-GBA-20-20-24	SERIES 90	S90-055PV
94-2701	PUMP-VAR DISPL, CW	90-R-055-EA-1-CD-60-S-3-S1-C-03-GBA-20-20-20	SERIES 90	S90-055PV
94-2704	PUMP-VAR DISPL, CCW	90-L-055-EA-1-CD-60-S-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-055PV
94-2705	PUMP-VAR DISPL, CCW	90-L-055-EA-1-NN-60-S-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-055PV
94-2707	PUMP-VAR DISPL, CCW	90-L-055-EA-1-BB-60-R-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
94-2708	PUMP-VAR DISPL, CCW	90-L-055-EA-1-AB-60-P-4-S1-C-03-GBA-29-29-24	SERIES 90	S90-055PV
94-2709	PUMP-VAR DISPL, CW	90-R-055-MA-1-BG-81-S-4-S1-D-03-GBA-26-26-24	SERIES 90	S90-055PV
94-2711	PUMP-VAR DISPL, CCW	90-L-055-EA-1-AB-60-L-3-T1-C-02-GBA-38-38-24	SERIES 90	S90-055PV
94-2712	PUMP-VAR DISPL, CW	90-R-055-MA-1-AB-60-P-3-S1-D-03-GBA-26-26-20	SERIES 90	S90-055PV
94-2715	PUMP-VAR DISPL, CW	90-R-055-EA-1-BC-60-S-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
94-2719	PUMP-VAR DISPL, CW	90-R-055-DC-1-NN-80-D-4-S1-L-GB-GBA-42-42-24	SERIES 90	S90-055PV
94-2720	PUMP-VAR DISPL, CW	90-R-055-DC-1-NN-80-R-4-S1-B-GB-GBA-42-42-24	SERIES 90	S90-055PV
94-2722	PUMP-VAR DISPL, CW	90-R-055-MB-6-CD-80-P-3-C6-C-03-FAB-45-45-28	SERIES 90	S90-055PV
94-2723	PUMP-VAR DISPL, CW	90-R-055-MB-6-BK-80-P-3-S1-C-03-FAB-45-45-28	SERIES 90	S90-055PV
94-2724	PUMP-VAR DISPL, CW	90-R-055-EA-1-NN-61-P-4-S1-C-03-GBA-17-17-24	SERIES 90	S90-055PV
94-2725	PUMP-VAR DISPL, CW	90-R-055-EA-1-AD-80-R-3-C6-C-03-GBA-42-42-24	SERIES 90	S90-055PV
94-2726	PUMP-VAR DISPL, CW	90-R-055-EA-1-AB-60-S-3-C6-D-03-GBA-35-35-20	SERIES 90	S90-055PV
94-2729	PUMP-VAR DISPL, CW	90-R-055-EA-1-CD-60-R-3-S1-C-03-GBA-42-42-20	SERIES 90	S90-055PV
94-2730	PUMP-VAR DISPL, CW	90-R-055-MD-1-CD-80-S-3-S1-C-02-GBA-35-35-24	SERIES 90	S90-055PV
94-2731	PUMP-VAR DISPL, CW	90-R-055-MA-1-NN-60-S-3-S1-C-03-GBA-38-38-24	SERIES 90	S90-055PV
94-2732	PUMP-VAR DISPL, CW	90-R-055-EA-1-CD-60-S-3-C6-C-03-GBA-35-35-20	SERIES 90	S90-055PV
94-2734	PUMP-VAR DISPL, CW	90-R-055-EA-1-CD-60-S-3-S1-C-03-GBA-20-20-24	SERIES 90	S90-055PV
94-2735	PUMP-VAR DISPL, CW	90-R-055-EA-1-AD-80-S-3-C6-C-03-GBA-42-42-24	SERIES 90	S90-055PV
94-2737	PUMP-VAR DISPL, CW	90-R-055-MB-1-BC-60-R-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-055PV
94-2739	PUMP-VAR DISPL, CW	90-R-055-EA-1-AB-60-S-3-S1-C-03-GBA-26-26-24	SERIES 90	S90-055PV
94-2741	PUMP-VAR DISPL, CW	90-R-055-MA-1-AD-80-P-4-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
94-2742	PUMP-VAR DISPL, CW	90-R-055-MA-1-CD-80-P-3-C6-D-04-GBA-35-35-24	SERIES 90	S90-055PV
94-2743	PUMP-VAR DISPL, CW	90-R-055-MA-1-BG-80-P-3-S1-D-04-GBA-35-35-24	SERIES 90	S90-055PV
94-2744	PUMP-VAR DISPL, CW	90-R-055-MA-1-BC-60-S-4-S1-C-03-GBA-26-26-24	SERIES 90	S90-055PV
94-2745	PUMP-VAR DISPL, CW	90-R-055-MA-1-BG-80-S-4-S1-C-03-GBA-26-26-24	SERIES 90	S90-055PV
94-2747	PUMP-VAR DISPL, CW	90-R-055-EP-1-BC-60-S-3-S1-D-03-GBA-35-35-20	SERIES 90	S90-055PV
94-2748	PUMP-VAR DISPL, CW	90-R-055-EA-1-NN-80-S-4-K1-B-03-GBA-14-14-20	SERIES 90	S90-055PV
94-2750	PUMP-VAR DISPL, CW	90-R-055-MA-1-BC-60-P-3-C6-C-03-GBA-26-26-28	SERIES 90	S90-055PV
94-2751	PUMP-VAR DISPL, CW	90-R-055-MA-1-CD-60-R-3-T1-L-02-GBA-38-38-24	SERIES 90	S90-055PV
94-2752	PUMP-VAR DISPL, CW	90-R-055-DC-1-CD-60-S-3-S1-B-GF-GBA-26-26-24	SERIES 90	S90-055PV
94-2753	PUMP-VAR DISPL, CW	90-R-055-MK-1-CD-80-P-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV

94-2754	PUMP-VAR-DISPL CW 90PV055	90-R-055-DC-1-NN-80-R-4-S1-C-G8-GBA-20-32-20	SERIES 90	S90-055PV
94-2756	PUMP-VAR DISPL, CW	90-R-055-EA-1-BC-60-S-3-S1-C-03-GBA-32-32-20	SERIES 90	S90-055PV
94-2757	PUMP-VAR DISPL, CW	90-R-055-MA-1-AB-60-R-3-S1-L-02-GBA-26-26-24	SERIES 90	S90-055PV
94-2758	PUMP-VAR DISPL, CW	90-R-055-EA-1-AB-60-S-3-T1-C-03-FAB-20-20-24	SERIES 90	S90-055PV
94-2759	PUMP-VAR DISPL, CW	90-R-055-MB-1-CD-80-S-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
94-2760	PUMP-VAR DISPL, CW	90-R-055-EA-1-NN-60-P-3-S1-C-03-GBA-32-32-24	SERIES 90	S90-055PV
94-2761	PUMP-VAR DISPL, CW	90-R-055-EP-1-NN-61-R-4-S1-C-00-GBA-35-35-24	SERIES 90	S90-055PV
94-2763	PUMP-VAR DISPL, CW	90-R-055-EA-1-NN-60-S-3-S1-C-03-GBA-32-32-24	SERIES 90	S90-055PV
94-2764	PUMP-VAR DISPL, CW	90-R-055-EA-1-AB-60-S-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
94-2765	PUMP-VAR DISPL, CW	90-R-055-MB-1-AD-80-S-3-S1-C-03-GBA-35-35-20	SERIES 90	S90-055PV
94-2766	PUMP-VAR DISPL, CW	90-R-055-EA-1-NN-61-R-4-S1-C-00-GBA-35-35-24	SERIES 90	S90-055PV
94-2767	PUMP-VAR DISPL, CW	90-R-055-EA-1-NN-60-P-3-S1-C-02-GBA-42-42-20	SERIES 90	S90-055PV
94-2770	PUMP-VAR DISPL, CW	90-R-055-MD-1-BC-60-L-3-C6-C-02-GBA-35-35-24	SERIES 90	S90-055PV
94-2771	PUMP-VAR DISPL, CW	90-R-055-MD-1-BC-60-L-3-C6-D-02-GBA-35-35-24	SERIES 90	S90-055PV
94-2772	PUMP-VAR DISPL, CW	90-R-055-EA-1-CD-60-L-4-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
94-2774	PUMP-VAR-DISPL CW 90PV055	90-R-055-MB-1-BG-80-S-3-C6-C-03-GBA-42-42-24	SERIES 90	S90-055PV
94-2776	PUMP-VAR DISPL, CW	90-R-055-EA-1-NN-60-S-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
94-2778	PUMP-VAR-DISPL CW 90PV055	90-R-055-EA-6-AB-60-S-3-C6-C-02-EAB-48-48-24	SERIES 90	S90-055PV
94-2779	PUMP-VAR DISPL, CW	90-R-055-HF-1-CD-80-R-3-S1-D-03-GBA-38-38-24	SERIES 90	S90-055PV
94-2780	PUMP-VAR DISPL, CW	90-R-055-HK-1-NN-60-R-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
94-2781	PUMP-VAR DISPL, CW	90-R-055-HK-1-NN-60-D-3-S1-L-01-GBA-42-42-28	SERIES 90	S90-055PV
94-2782	PUMP-VAR DISPL, CW	90-R-055-HK-2-CD-60-R-3-S1-C-02-GBA-48-48-24	SERIES 90	S90-055PV
94-2783	PUMP-VAR DISPL, CW	90-R-055-EA-1-AB-60-S-4-C6-D-04-GBA-42-42-24	SERIES 90	S90-055PV
94-2784	PUMP-VAR DISPL, CW	90-R-055-MB-6-BC-60-S-3-C6-C-03-GBA-48-48-24	SERIES 90	S90-055PV
94-2785	PUMP-VAR DISPL, CW	90-R-055-EA-1-AB-60-S-3-C6-C-04-GBA-42-42-28	SERIES 90	S90-055PV
94-2786	PUMP-VAR DISPL, CW	90-R-055-HK-1-NN-60-P-3-S1-C-03-GBA-20-20-24	SERIES 90	S90-055PV
94-2787	PUMP-VAR DISPL, CW	90-R-055-MA-1-NN-60-S-3-D9-C-04-GBA-35-35-18	SERIES 90	S90-055PV
94-2788	PUMP-VAR-DISPL CW 90PV055	90-R-055-EA-1-NN-80-S-3-C6-B-35-GBA-42-42-24	SERIES 90	S90-055PV
94-2790	PUMP-VAR DISPL, CW	90-R-055-EA-1-BC-60-P-3-S1-C-00-GBA-35-35-24	SERIES 90	S90-055PV
94-2791	PUMP-VAR-DISPL CW 90PV055	90-R-055-EA-1-AD-80-S-3-C6-B-35-GBA-42-42-24	SERIES 90	S90-055PV
94-2792	PUMP-VAR DISPL, CW	90-R-055-EA-6-BC-60-S-3-S1-D-03-GBA-48-48-24	SERIES 90	S90-055PV
94-2793	PUMP-VAR DISPL, CW	90-R-055-EA-1-AB-60-R-3-K1-C-03-GBA-14-14-24	SERIES 90	S90-055PV
94-2794	PUMP-VAR DISPL, CW	90-R-055-EA-1-CD-60-S-3-T1-C-03-GBA-26-26-24	SERIES 90	S90-055PV
94-2796	PUMP-VAR DISPL, CW	90-R-055-MB-6-BK-80-P-3-S1-C-03-FAD-45-45-28	SERIES 90	S90-055PV
94-2797	PUMP-VAR DISPL, CW	90-R-055-MB-6-CD-80-P-3-C6-C-03-FAD-45-45-28	SERIES 90	S90-055PV
94-2798	PUMP-VAR DISPL, CW	90-R-055-MD-1-BC-60-R-3-C6-C-02-GBA-42-42-24	SERIES 90	S90-055PV

94-2801	PUMP-VAR DISPL, CW	90-R-055-MB-1-AD-80-S-3-S1-C-03-GBA-42-42-20	SERIES 90	S90-055PV
94-2802	PUMP-VAR-DISPL CW 90PV055	90-R-055-EA-6-BC-60-S-3-C6-D-03-GBA-48-48-24	SERIES 90	S90-055PV
94-2803	PUMP-VAR DISPL, CW	90-R-055-EA-1-BC-60-S-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
94-2805	PUMP-VAR DISPL, CW	90-R-055-EA-1-CD-61-R-3-S1-C-03-GBA-20-20-20	SERIES 90	S90-055PV
94-2806	PUMP-VAR DISPL, CW	90-R-055-EA-1-NN-60-P-4-S1-C-03-GBA-17-17-24	SERIES 90	S90-055PV
94-2807	PUMP-VAR DISPL, CW	90-R-055-MA-1-BG-80-S-3-C6-C-03-GBA-42-42-24	SERIES 90	S90-055PV
94-2808	PUMP-VAR DISPL, CW	90-R-055-EA-1-BG-80-R-3-C6-C-05-GBA-35-35-20	SERIES 90	S90-055PV
94-2809	PUMP-VAR DISPL, CW	90-R-055-EA-1-NN-80-P-1-C6-C-03-GBA-35-35-20	SERIES 90	S90-055PV
94-2810	PUMP-VAR-DISPL CW 90PV055	90-R-055-KA-1-NN-80-R-3-C6-C-05-FAB-35-35-20	SERIES 90	S90-055PV
94-2811	PUMP-VAR DISPL, CW	90-R-055-EA-1-CD-60-P-3-S1-C-03-GBA-35-35-20	SERIES 90	S90-055PV
94-2812	PUMP-VAR DISPL, CW	90-R-055-EA-1-NN-60-P-3-S1-C-03-GBA-35-35-20	SERIES 90	S90-055PV
94-2813	PUMP-VAR DISPL, CW	90-R-055-MB-1-BC-60-P-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
94-2814	PUMP-VAR DISPL, CW	90-R-055-EA-1-NN-61-S-3-S1-C-03-GBA-38-38-20	SERIES 90	S90-055PV
94-2816	PUMP-VAR DISPL, CW	90-R-055-HF-1-BG-81-R-3-S1-D-00-GBA-35-23-24	SERIES 90	S90-055PV
94-2817	PUMP-VAR DISPL, CW	90-R-055-EA-1-AB-60-P-3-S1-C-03-GBA-26-26-24	SERIES 90	S90-055PV
94-2818	PUMP-VAR DISPL, CW	90-R-055-EA-1-NN-60-S-3-S1-C-03-GBA-26-26-24	SERIES 90	S90-055PV
94-2819	PUMP-VAR-DISPL CW 90PV055	90-R-055-DD-1-NN-60-D-4-S1-L-GB-GBA-32-32-24	SERIES 90	S90-055PV
94-2820	PUMP-VAR DISPL, CW	90-R-055-EA-1-AD-80-P-3-C6-D-03-GBA-35-35-20	SERIES 90	S90-055PV
94-2821	PUMP-VAR DISPL, CW	90-R-055-EA-1-NN-80-S-4-S1-B-03-GBA-23-23-20	SERIES 90	S90-055PV
94-2822	PUMP-VAR DISPL, CW	90-R-055-DD-1-CD-60-S-3-T1-C-GB-GBA-42-42-20	SERIES 90	S90-055PV
94-2823	PUMP-VAR DISPL, CW	90-R-055-MA-1-NN-60-P-3-D9-C-04-GBA-35-35-18	SERIES 90	S90-055PV
94-2823C	PUMP-VAR-DISPL CW 90PV055	90-R-055-MA-1-NN-60-P-3-D9-C-04-GBA-35-35-18	SERIES 90	S90-055PV
94-2824	PUMP-VAR DISPL, CW	90-R-055-EA-1-AB-60-S-3-C6-C-04-GBA-38-38-20	SERIES 90	S90-055PV
9421050	PUMP-VAR DISPL, CCW	90-L-055-EP-1-NN-61-R-4-T1-C-00-GBA-35-35-24	SERIES 90	S90-055PV
9421144	PUMP-VAR-DISPL CCW 90PV055	90-L-055-MB-1-NN-60-S-3-C6-C-03-GBA-42-42-24	SERIES 90	S90-055PV
9421145	PUMP-VAR DISPL, CCW	90-L-055-EA-1-BG-80-S-4-C6-C-03-GBA-42-42-24	SERIES 90	S90-055PV
9421146	PUMP-VAR DISPL, CCW	90-L-055-EA-1-BG-80-S-4-S1-C-03-GBA-26-26-20	SERIES 90	S90-055PV
9421147	PUMP-VAR DISPL, CCW	90-L-055-DD-1-NN-60-S-3-S1-D-GB-GBA-20-20-24	SERIES 90	S90-055PV
9421148	PUMP-VAR DISPL, CCW	90-L-055-HK-2-CD-60-R-3-S1-C-02-GBA-48-48-24	SERIES 90	S90-055PV
9421149	PUMP-VAR DISPL, CCW	90-L-055-EP-1-AB-60-P-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-055PV
9421150	PUMP-VAR DISPL, CCW	90-L-055-EA-1-NN-60-S-3-C6-C-03-GBA-14-14-18	SERIES 90	S90-055PV
9421151	PUMP-VAR DISPL, CCW	90-L-055-MA-1-NN-80-P-3-S1-C-03-GBA-38-38-24	SERIES 90	S90-055PV
9421152	PUMP-VAR DISPL, CCW	90-L-055-DD-1-AD-81-D-4-C6-L-GB-GBA-42-42-20	SERIES 90	S90-055PV
9421153	PUMP-VAR DISPL, CCW	90-L-055-EA-1-BC-60-P-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
9421154	PUMP-VAR DISPL, CCW	90-L-055-MB-1-BG-80-R-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-055PV
9421155	PUMP-VAR DISPL, CCW	90-L-055-EA-1-NN-60-R-3-S1-C-00-GBA-35-35-24	SERIES 90	S90-055PV

9421156	PUMP-VAR DISPL, CCW	90-L-055-EA-1-AB-60-P-3-T1-C-03-GBA-35-14-24	SERIES 90	S90-055PV
9421157	PUMP-VAR DISPL, CCW	90-L-055-EA-7-BC-60-S-3-C6-C-04-GBA-45-45-24	SERIES 90	S90-055PV
9421158	PUMP-VAR DISPL, CCW	90-L-055-EA-7-BB-60-S-3-C6-C-04-GBA-45-45-24	SERIES 90	S90-055PV
9421159	PUMP-VAR DISPL, CCW	90-L-055-DD-1-AB-60-S-3-S1-C-GB-GBA-35-35-20	SERIES 90	S90-055PV
9421160	PUMP-VAR DISPL, CCW	90-L-055-EA-1-CD-80-R-3-S1-D-02-GBA-29-29-24	SERIES 90	S90-055PV
9421161	PUMP-VAR DISPL, CCW	90-L-055-EA-1-NN-80-R-4-S1-D-02-GBA-29-29-24	SERIES 90	S90-055PV
9421162	PUMP-VAR DISPL, CCW	90-L-055-EA-1-CD-60-S-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9421163	PUMP-VAR DISPL, CCW	90-L-055-EP-1-NN-80-R-3-C6-C-03-GBA-42-42-24	SERIES 90	S90-055PV
9421164	PUMP-VAR DISPL, CCW	90-L-055-EP-1-AB-60-S-4-S1-C-03-GBA-35-14-24	SERIES 90	S90-055PV
9421165	PUMP-VAR DISPL, CCW	90-L-055-DC-1-NN-80-R-3-C6-C-GB-GBA-42-42-24	SERIES 90	S90-055PV
9421166	PUMP-VAR DISPL, CCW	90-L-055-MC-1-CD-60-S-4-C6-D-40-GBA-35-35-24	SERIES 90	S90-055PV
9421167	PUMP-VAR DISPL, CCW	90-L-055-MC-1-NN-60-S-4-S1-D-40-GBA-35-35-24	SERIES 90	S90-055PV
9421169	PUMP-VAR-DISPL CCW 90PV055	90-L-055-DD-1-BC-60-S-3-S1-B-50-GBA-29-29-24	SERIES 90	S90-055PV
9421170	PUMP-VAR DISPL, CCW	90-L-055-DD-1-CD-80-S-3-C6-C-GF-GBA-35-35-24	SERIES 90	S90-055PV
9421171	PUMP-VAR DISPL, CCW	90-L-055-MA-1-NN-60-R-3-C6-L-03-GBA-42-42-20	SERIES 90	S90-055PV
9421172	PUMP-VAR DISPL, CCW	90-L-055-HF-1-AB-61-R-3-S1-D-00-GBA-35-35-20	SERIES 90	S90-055PV
9421173	PUMP-VAR DISPL, CCW	90-L-055-EA-1-AB-60-S-3-C6-D-03-GBA-35-35-20	SERIES 90	S90-055PV
9421176	PUMP-VAR DISPL, CCW	90-L-055-EA-1-BG-80-P-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9421177	PUMP-VAR-DISPL CCW 90PV055	90-L-055-DD-1-NN-60-S-4-S1-C-GB-GBA-32-32-20	SERIES 90	S90-055PV
9421178	PUMP-VAR DISPL, CCW	90-L-055-DD-1-CD-60-S-4-T1-C-GB-GBA-32-32-20	SERIES 90	S90-055PV
9421179	PUMP-VAR DISPL, CCW	90-L-055-EA-1-NN-80-P-4-S1-C-03-GBA-29-29-24	SERIES 90	S90-055PV
9421180	PUMP-VAR DISPL, CCW	90-L-055-EA-1-NN-60-R-3-S1-C-04-GBA-26-26-20	SERIES 90	S90-055PV
9421181	PUMP-VAR-DISPL CCW 90PV055	90-L-055-CB-5-NN-60-S-3-C6-C-00-GBA-00-00-00-P000	SERIES 90	S90-055PV
9421182	PUMP-VAR DISPL, CCW	90-L-055-DD-1-AB-60-S-3-S1-C-50-GBA-29-29-24	SERIES 90	S90-055PV
9421183	PUMP-VAR DISPL, CCW	90-L-055-EA-1-BC-60-S-3-T1-C-02-GBA-42-42-24	SERIES 90	S90-055PV
9421184	PUMP-VAR DISPL, CCW	90-L-055-EP-1-NN-60-S-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9421185	PUMP-VAR DISPL, CCW	90-L-055-EP-1-NN-60-P-3-S1-C-03-GBA-38-38-24	SERIES 90	S90-055PV
9421186	PUMP-VAR DISPL, CCW	90-L-055-EA-6-BC-60-S-3-C6-C-30-GBA-45-45-24	SERIES 90	S90-055PV
9421187	PUMP-VAR DISPL, CCW	90-L-055-EA-1-NN-60-P-3-C6-D-04-GBA-29-29-24	SERIES 90	S90-055PV
9421188	PUMP-VAR DISPL, CCW	90-L-055-EP-1-BG-80-P-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-055PV
9421189	PUMP-VAR-DISPL CCW 90PV055	90-L-055-CB-5-NN-80-S-3-C6-C-00-GBA-00-00-00-P000	SERIES 90	S90-055PV
9421190	PUMP-VAR DISPL, CCW	90-L-055-EA-1-BC-60-S-3-S1-C-03-GBA-29-29-24	SERIES 90	S90-055PV
9421191	PUMP-VAR-DISPL CCW 90PV055	90-L-055-EA-1-NN-80-P-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
9421192	PUMP-VAR-DISPL CCW 90PV055	90-L-055-CB-5-NN-80-S-3-S1-C-00-GBA-00-00-00-P000	SERIES 90	S90-055PV
9421193	PUMP-VAR-DISPL CCW 90PV055	90-L-055-CB-5-NN-60-S-3-S1-C-00-GBA-00-00-00-P000	SERIES 90	S90-055PV
9421194	PUMP-VAR DISPL, CCW	90-L-055-HF-1-NN-80-S-4-C6-D-02-GBA-42-42-28	SERIES 90	S90-055PV

9421195	PUMP-VAR DISPL, CCW	90-L-055-EA-1-NN-60-R-3-C6-C-03-GBA-29-29-20	SERIES 90	S90-055PV
9421196	PUMP-VAR-DISPL CCW 90PV055	90-L-055-EA-1-NN-80-D-3-C6-L-03-FAD-42-42-24	SERIES 90	S90-055PV
9421197	PUMP-VAR DISPL, CCW	90-L-055-HF-1-NN-80-S-4-C6-D-26-GBA-42-42-28	SERIES 90	S90-055PV
9421198	PUMP-VAR DISPL, CCW	90-L-055-MB-1-NN-80-S-3-S1-C-02-GBA-35-35-24	SERIES 90	S90-055PV
9421199	PUMP-VAR DISPL, CCW	90-L-055-EP-2-CD-60-L-3-C6-D-03-GBA-42-42-24	SERIES 90	S90-055PV
9421200	PUMP-VAR DISPL, CCW	90-L-055-EP-2-NN-60-L-3-S1-D-03-GFD-42-42-24	SERIES 90	S90-055PV
9421201	PUMP-VAR-DISPL CCW 90PV055	90-L-055-MA-1-NN-80-R-3-S1-C-03-GBA-26-26-24	SERIES 90	S90-055PV
9421202	PUMP-VAR DISPL, CCW	90-L-055-EA-1-BG-80-R-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
9421203	PUMP-VAR DISPL, CCW	90-L-055-HF-1-NN-60-L-3-S1-D-03-GBA-32-32-24	SERIES 90	S90-055PV
9421204	PUMP-VAR DISPL, CCW	90-L-055-MV-1-NN-80-S-3-S1-C-02-GBA-35-35-24	SERIES 90	S90-055PV
9421205	PUMP-VAR DISPL, CCW	90-L-055-MV-1-CD-80-S-3-S1-C-02-GBA-35-35-24	SERIES 90	S90-055PV
9421206	PUMP-VAR DISPL, CCW	90-L-055-EA-1-NN-80-R-4-S1-D-02-FAB-42-42-24	SERIES 90	S90-055PV
9421207	PUMP-VAR DISPL, CCW	90-L-055-MA-1-BC-61-R-4-S1-C-00-GBA-26-26-24	SERIES 90	S90-055PV
9421209	PUMP-VAR DISPL, CCW	90-L-055-EA-1-BK-80-S-3-S1-C-02-GBA-35-35-24	SERIES 90	S90-055PV
9421210	PUMP-VAR DISPL, CCW	90-L-055-EA-1-CD-80-S-3-S1-C-02-GBA-35-35-24	SERIES 90	S90-055PV
9421211	PUMP-VAR DISPL, CCW	90-L-055-MB-1-NN-60-R-4-C6-C-03-GBA-35-35-20	SERIES 90	S90-055PV
9421212	PUMP-VAR DISPL, CCW	90-L-055-MV-1-NN-80-S-3-S1-C-01-GBA-35-35-24	SERIES 90	S90-055PV
9421213	PUMP-VAR DISPL, CCW	90-L-055-MV-1-CD-80-S-3-S1-C-01-GBA-35-35-24	SERIES 90	S90-055PV
9421214	PUMP-VAR DISPL, CCW	90-L-055-EA-1-CD-80-S-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9421215	PUMP-VAR DISPL, CCW	90-L-055-EA-1-AD-80-S-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-055PV
9421216	PUMP-VAR DISPL, CCW	90-L-055-MA-1-NN-80-L-3-C6-D-03-GCA-42-42-24	SERIES 90	S90-055PV
9421221	PUMP-VAR DISPL, CCW	90-L-055-CB-6-NN-80-L-4-S1-D-01-GBA-45-45-24	SERIES 90	S90-055PV
9421222	PUMP-VAR DISPL, CCW	90-L-055-MA-1-BC-60-P-3-C6-C-03-GBA-32-32-20	SERIES 90	S90-055PV
9421224	PUMP-VAR DISPL, CCW	90-L-055-HP-1-CD-80-P-3-S1-C-02-GBA-35-35-24	SERIES 90	S90-055PV
9421225	PUMP-VAR DISPL, CCW	90-L-055-EA-2-NN-60-S-4-S1-C-33-GBA-32-32-24	SERIES 90	S90-055PV
9421227	PUMP-VAR DISPL, CCW	90-L-055-MK-2-NN-80-S-4-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9421229	PUMP-VAR DISPL, CCW	90-L-055-EA-1-BG-80-P-3-C6-C-03-GBA-42-42-20	SERIES 90	S90-055PV
9421230	PUMP-VAR DISPL, CCW	90-L-055-EP-7-CD-60-L-3-C6-D-03-GBA-48-48-24	SERIES 90	S90-055PV
9421231	PUMP-VAR DISPL, CCW	90-L-055-EP-7-NN-60-L-3-S1-D-03-GBA-48-48-24	SERIES 90	S90-055PV
9421232	PUMP-VAR-DISPL CCW 90PV055	90-L-055-KA-1-NN-60-S-3-C6-D-00-GCA-32-32-28	SERIES 90	S90-055PV
9421233	PUMP-VAR-DISPL CCW 90PV055	90-L-055-KA-1-AD-80-S-3-C6-D-05-GBA-42-42-24	SERIES 90	S90-055PV
9421234	PUMP-VAR DISPL, CCW	90-L-055-EA-1-NN-60-S-3-C6-C-03-EEC-14-14-20	SERIES 90	S90-055PV
9421235	PUMP-VAR-DISPL CCW 90PV055	90-L-055-EP-1-NN-80-P-4-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
9421237	PUMP-VAR DISPL, CCW	90-L-055-DC-1-NN-60-R-3-S1-C-GB-GBA-42-42-24	SERIES 90	S90-055PV
9421239	PUMP-VAR-DISPL CCW 90PV055	90-L-055-EP-1-AD-80-P-4-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
9421240	PUMP-VAR-DISPL CCW 90PV055	90-L-055-EA-1-BB-60-R-3-T1-C-03-GBA-38-38-22	SERIES 90	S90-055PV

9421241	PUMP-VAR DISPL, CCW	90-L-055-HF-1-CD-80-L-3-S1-C-03-GBA-23-23-24	SERIES 90	S90-055PV
9421242	PUMP-VAR DISPL, CCW	90-L-055-KP-1-NN-80-D-3-S1-L-03-GBA-42-42-XX-B020	SERIES 90	S90-055PV
9421243	PUMP-VAR DISPL, CCW	90-L-055-EA-2-NN-60-P-4-S1-C-33-GBA-32-32-24	SERIES 90	S90-055PV
9421244	PUMP-VAR DISPL, CCW	90-L-055-EP-1-CD-81-P-3-S1-C-03-GBA-35-35-20	SERIES 90	S90-055PV
9421245	PUMP-VAR DISPL, CCW	90-L-055-EP-1-NN-81-P-3-S1-C-03-GBA-35-35-20	SERIES 90	S90-055PV
9421246	PUMP-VAR DISPL, CCW	90-L-055-EA-1-AD-80-L-3-C6-C-03-GBA-20-20-24	SERIES 90	S90-055PV
9421247	PUMP-VAR DISPL, CCW	90-L-055-EA-1-BC-60-P-4-S1-C-03-GBA-26-26-24	SERIES 90	S90-055PV
9421248	PUMP-VAR DISPL, CCW	90-L-055-HK-1-NN-60-P-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9421249	PUMP-VAR DISPL, CCW	90-L-055-KA-1-BC-60-R-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9421250	PUMP-VAR DISPL, CCW	90-L-055-KA-1-CD-80-R-3-C6-D-02-GBA-29-29-24	SERIES 90	S90-055PV
9421251	PUMP-VAR-DISPL CCW 90PV055	90-L-055-KA-1-NN-80-S-3-C6-C-03-FAD-35-35-20	SERIES 90	S90-055PV
9421251C	PUMP-VAR-DISPL CCW 90PV055	90-L-055-KA-1-NN-80-S-3-C6-C-03-FAD-35-35-20	SERIES 90	S90-055PV
9421252	PUMP-VAR DISPL, CCW	90-L-055-HF-1-CD-80-S-3-S1-D-01-GBA-23-23-20	SERIES 90	S90-055PV
9421253	PUMP-VAR DISPL, CCW	90-L-055-HP-1-BG-80-P-3-S1-C-04-GBA-32-32-24	SERIES 90	S90-055PV
9421254	PUMP-VAR DISPL, CCW	90-L-055-KA-1-AF-80-L-3-C6-C-01-GBA-35-35-24	SERIES 90	S90-055PV
9421255	PUMP-VAR DISPL, CCW	90-L-055-HF-1-BG-80-R-4-S1-C-04-GBA-26-26-20	SERIES 90	S90-055PV
9421256	PUMP-VAR DISPL, CW	90-R-055-HF-1-BG-80-R-4-S1-C-04-GBA-26-26-20	SERIES 90	S90-055PV
9421257	PUMP-VAR DISPL, CCW	90-L-055-KP-1-CD-81-S-3-S1-C-03-GBA-29-29-20	SERIES 90	S90-055PV
9421258	PUMP-VAR DISPL, CCW	90-L-055-KP-1-NN-81-S-3-S1-C-03-GBA-29-29-20	SERIES 90	S90-055PV
9421259C	PUMP-VAR-DISPL CCW 90PV055	90-L-055-DD-1-NN-80-R-4-C6-C-GB-GBA-42-42-24	SERIES 90	S90-055PV
9421260	PUMP-VAR DISPL, CCW	90-L-055-KA-1-NN-80-D-4-S1-L-02-GBA-29-29-24	SERIES 90	S90-055PV
9421261	PUMP-VAR DISPL, CCW	90-L-055-KA-1-CD-80-S-3-S1-C-03-GBA-38-38-20	SERIES 90	S90-055PV
9421262	PUMP-VAR DISPL, CCW	90-L-055-KA-1-NN-80-S-3-S1-C-03-GBA-38-38-20	SERIES 90	S90-055PV
9421263	PUMP-VAR DISPL, CCW	90-L-055-KA-1-NN-80-R-3-S1-C-03-GBA-29-29-20	SERIES 90	S90-055PV
9421264	PUMP-VAR DISPL, CCW	90-L-055-MA-1-NN-80-S-3-S1-B-03-GBA-32-32-24	SERIES 90	S90-055PV
9421265	PUMP-VAR DISPL, CCW	90-L-055-KA-1-CD-60-S-3-S1-C-03-GBA-38-38-20	SERIES 90	S90-055PV
9421266	PUMP-VAR DISPL, CCW	90-L-055-KA-1-NN-60-S-3-S1-C-03-GBA-38-38-20	SERIES 90	S90-055PV
9421267	PUMP-VAR DISPL, CCW	90-L-055-KA-1-NN-60-L-3-S1-C-03-GBA-29-29-20	SERIES 90	S90-055PV
9421268	PUMP-VAR DISPL, CCW	90-L-055-KA-2-CD-60-S-3-S1-C-33-GBA-07-38-20	SERIES 90	S90-055PV
9421269	PUMP-VAR DISPL, CCW	90-L-055-KA-2-CD-80-S-3-S1-C-33-GBA-07-38-20	SERIES 90	S90-055PV
9421270	PUMP-VAR-DISPL CCW 90PV055	90-L-055-MA-2-BC-60-P-3-C6-C-03-GBA-42-42-24	SERIES 90	S90-055PV
9421271	PUMP-VAR DISPL, CCW	90-L-055-DD-1-AD-80-R-4-C6-C-GB-GBA-35-35-24	SERIES 90	S90-055PV
9421272	PUMP-VAR DISPL, CCW	90-L-055-MA-1-BG-81-S-4-S1-D-03-GBA-17-17-20	SERIES 90	S90-055PV
9421274	PUMP-VAR DISPL, CCW	90-L-055-M6-1-CD-60-S-4-C6-D-70-GFK-35-35-24-F027	SERIES 90	S90-055PV
9421278	PUMP-VAR DISPL, CCW	90-L-055-KA-1-BC-60-S-3-C6-C-03-GBA-42-42-20	SERIES 90	S90-055PV
9421279	PUMP-VAR DISPL, CCW	90-L-055-HS-1-NN-60-P-3-S1-C-03-GBA-20-20-24	SERIES 90	S90-055PV

9421280	PUMP-VAR DISPL, CCW	90-L-055-MA-1-BG-80-R-3-S1-B-03-GBA-38-38-24	SERIES 90	S90-055PV
9421282	PUMP-VAR DISPL, CCW	90-L-055-MA-1-BC-61-R-4-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9421283	PUMP-VAR DISPL, CCW	90-L-055-HS-1-NN-60-P-3-S1-C-03-GBA-23-23-24	SERIES 90	S90-055PV
9421284	PUMP-VAR DISPL, CCW	90-L-055-KP-6-BK-80-L-3-S1-C-03-GBA-45-45-24	SERIES 90	S90-055PV
9421285	PUMP-VAR DISPL, CCW	90-L-055-KA-6-NN-60-S-3-S1-D-09-GBA-45-45-24	SERIES 90	S90-055PV
9421286	PUMP-VAR-DISPL CCW 90PV055	90-L-055-KA-1-CD-80-S-3-S1-C-02-GBA-42-42-24	SERIES 90	S90-055PV
9421287	PUMP-VAR DISPL, CCW	90-L-055-KA-1-BK-80-S-3-S1-C-02-GBA-42-42-24	SERIES 90	S90-055PV
9421288	PUMP-VAR DISPL, CCW	90-L-055-HS-1-NN-60-L-3-S1-D-03-GBA-32-32-24	SERIES 90	S90-055PV
9421289	PUMP-VAR DISPL, CCW	90-L-055-DD-1-NN-80-R-4-C6-C-GB-GBA-35-35-24	SERIES 90	S90-055PV
9421290	PUMP-VAR DISPL, CCW	90-L-055-KA-1-NN-80-R-3-S1-D-02-GBA-29-29-24	SERIES 90	S90-055PV
9421291	PUMP-VAR DISPL, CCW	90-L-055-MA-1-NN-60-P-3-S1-C-03-GBA-23-23-24	SERIES 90	S90-055PV
9421292	PUMP-VAR DISPL, CCW	90-L-055-KA-1-AD-80-L-3-C6-C-03-GBA-20-20-24	SERIES 90	S90-055PV
9421293	PUMP-VAR DISPL, CCW	90-L-055-KA-1-NN-80-S-3-K1-C-03-GBA-23-23-24	SERIES 90	S90-055PV
9421294	PUMP-VAR DISPL, CCW	90-L-055-MB-1-CD-60-R-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9421295	PUMP-VAR DISPL, CCW	90-L-055-MB-1-NN-60-R-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9421296	PUMP-VAR DISPL, CCW	90-L-055-KA-1-BG-80-S-3-K1-C-03-GBA-23-23-24	SERIES 90	S90-055PV
9421297	PUMP-VAR DISPL, CCW	90-L-055-KA-1-NN-60-P-3-K1-C-00-GBA-32-32-20	SERIES 90	S90-055PV
9421298	PUMP-VAR DISPL, CCW	90-L-055-KA-1-AD-80-P-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
9421299	PUMP-VAR DISPL, CCW	90-L-055-KA-1-NN-80-P-3-S1-C-03-GBA-29-29-20	SERIES 90	S90-055PV
9421300	PUMP-VAR DISPL, CCW	90-L-055-KA-1-CD-80-R-3-S1-D-02-GBA-29-29-24	SERIES 90	S90-055PV
9421301	PUMP-VAR DISPL, CCW	90-L-055-M4-1-BB-60-S-3-C6-D-71-GBA-35-35-24	SERIES 90	S90-055PV
9421302	PUMP-VAR DISPL, CCW	90-L-055-MA-1-NN-80-S-3-C6-C-03-GBA-42-42-20	SERIES 90	S90-055PV
9421302C	PUMP-VAR-DISPL CCW 90PV055	90-L-055-MA-1-NN-80-S-3-C6-C-03-GBA-42-42-20	SERIES 90	S90-055PV
9421303	PUMP-VAR DISPL, CCW	90-L-055-MA-1-AB-60-S-3-C6-C-03-GBA-35-35-20	SERIES 90	S90-055PV
9421304	PUMP-VAR DISPL, CCW	90-L-055-KP-1-BC-60-S-3-S1-C-01-GBA-42-42-24	SERIES 90	S90-055PV
9421305	PUMP-VAR DISPL, CCW	90-L-055-KA-6-NN-80-S-4-S1-D-01-GBA-45-45-24	SERIES 90	S90-055PV
9421306	PUMP-VAR DISPL, CCW	90-L-055-KA-1-NN-60-P-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-055PV
9421307	PUMP-VAR DISPL, CCW	90-L-055-HF-1-CD-80-S-4-S1-D-01-GBA-23-23-24	SERIES 90	S90-055PV
9421308	PUMP-VAR DISPL, CCW	90-L-055-HF-1-NN-80-S-4-S1-D-03-GBA-23-23-24	SERIES 90	S90-055PV
9421309	PUMP-VAR DISPL, CCW	90-L-055-KP-1-CD-80-S-3-S1-D-01-GBA-35-35-24	SERIES 90	S90-055PV
9421310	PUMP-VAR DISPL, CCW	90-L-055-KP-1-NN-80-S-3-S1-C-01-GBA-35-35-24	SERIES 90	S90-055PV
9421311	PUMP-VAR DISPL, CCW	90-L-055-KA-1-BK-80-R-3-C6-D-02-GBA-29-17-28	SERIES 90	S90-055PV
9421312	PUMP-VAR DISPL, CCW	90-L-055-KA-1-BC-60-P-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9421313	PUMP-VAR DISPL, CCW	90-L-055-KA-1-NN-60-P-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
9421314	PUMP-VAR DISPL, CCW	90-L-055-KA-1-CD-60-P-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9421315	PUMP-VAR DISPL, CCW	90-L-055-KA-1-NN-60-R-3-S1-C-00-GBA-35-35-24	SERIES 90	S90-055PV

9421316	PUMP-VAR DISPL, CCW	90-L-055-MB-1-CD-80-S-3-S1-C-02-GBA-42-42-24	SERIES 90	S90-055PV
9421317	PUMP-VAR DISPL, CCW	90-L-055-MB-1-BK-80-S-3-S1-C-02-GBA-42-42-24	SERIES 90	S90-055PV
9421318	PUMP-VAR DISPL, CCW	90-L-055-MC-1-NN-60-S-3-S1-C-02-GBA-35-35-20	SERIES 90	S90-055PV
9421319	PUMP-VAR DISPL, CCW	90-L-055-KA-1-CD-60-P-4-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9421320	PUMP-VAR DISPL, CCW	90-L-055-KP-1-BG-80-S-3-S1-C-03-GBA-20-20-24	SERIES 90	S90-055PV
9421321	PUMP-VAR DISPL, CCW	90-L-055-KP-1-BB-60-R-3-S1-C-03-EEB-42-42-24	SERIES 90	S90-055PV
9421322	PUMP-VAR DISPL, CCW	90-L-055-KA-1-NN-61-P-3-S1-C-00-GBA-35-35-24	SERIES 90	S90-055PV
9421323	PUMP-VAR DISPL, CCW	90-L-055-HF-2-NN-60-S-F-S1-D-33-GBA-20-20-28	SERIES 90	S90-055PV
9421324	PUMP-VAR DISPL, CCW	90-L-055-HK-1-CD-80-S-3-S1-C-03-GBA-07-38-20	SERIES 90	S90-055PV
9421325	PUMP-VAR DISPL, CCW	90-L-055-HK-1-CD-80-S-3-S1-C-03-GBA-38-38-20	SERIES 90	S90-055PV
9421326	PUMP-VAR DISPL, CCW	90-L-055-HK-1-NN-80-S-3-S1-C-03-GBA-38-38-20	SERIES 90	S90-055PV
9421327	PUMP-VAR DISPL, CCW	90-L-055-HK-1-NN-80-P-3-S1-C-03-GBA-29-29-20	SERIES 90	S90-055PV
9421328	PUMP-VAR DISPL, CCW 90PV055	90-L-055-KP-1-CD-80-S-4-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
9421329	PUMP-VAR DISPL, CCW	90-L-055-KA-1-NN-80-R-4-S1-D-02-GBA-29-29-24	SERIES 90	S90-055PV
9421330	PUMP-VAR DISPL, CCW	90-L-055-MA-1-NN-60-S-3-C6-D-03-GBA-35-35-20	SERIES 90	S90-055PV
9421330C	PUMP-VAR-DISPL CCW 90PV055	90-L-055-MA-1-NN-60-S-3-C6-D-03-GBA-35-35-20	SERIES 90	S90-055PV
9421331	PUMP-VAR DISPL, CCW	90-L-055-KP-1-NN-80-S-4-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
9421332	PUMP-VAR DISPL, CCW	90-L-055-KA-1-CD-60-L-3-S1-C-01-GBA-38-38-24	SERIES 90	S90-055PV
9421333	PUMP-VAR DISPL, CCW	90-L-055-KA-1-NN-60-L-3-S1-C-01-GBA-38-38-24	SERIES 90	S90-055PV
9421334	PUMP-VAR DISPL, CCW	90-L-055-KP-1-NN-80-S-4-S1-C-01-GBA-38-38-24	SERIES 90	S90-055PV
9421335	PUMP-VAR DISPL, CCW	90-L-055-HS-1-CD-80-P-3-C6-D-02-GBA-29-29-24	SERIES 90	S90-055PV
9421337	PUMP-VAR-DISPL CCW 90PV055	90-L-055-KA-1-NN-80-P-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
9421338	PUMP-VAR DISPL, CCW	90-L-055-MA-1-AB-60-S-4-C6-C-03-GBA-35-35-20	SERIES 90	S90-055PV
9421339	PUMP-VAR DISPL, CCW	90-L-055-HF-1-BG-80-P-4-S1-C-03-GBA-32-32-24	SERIES 90	S90-055PV
9421340	PUMP-VAR DISPL, CCW	90-L-055-HF-1-NN-60-R-4-C6-C-00-GBA-35-35-20	SERIES 90	S90-055PV
9421341	PUMP-VAR DISPL, CCW	90-L-055-KP-1-CD-80-S-4-S1-C-03-GBA-32-32-24	SERIES 90	S90-055PV
9421342	PUMP-VAR DISPL, CCW	90-L-055-HF-1-BC-60-P-3-S1-C-03-GBA-29-29-28	SERIES 90	S90-055PV
9421343	PUMP-VAR DISPL, CCW	90-L-055-MV-1-NN-60-P-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9421344	PUMP-VAR DISPL, CCW	90-L-055-HK-1-BG-80-S-3-S1-C-03-GBA-38-38-20	SERIES 90	S90-055PV
9421346	PUMP-VAR DISPL, CCW	90-L-055-CB-1-BK-80-R-3-S1-C-00-GBA-35-35-24	SERIES 90	S90-055PV
9421347	PUMP-VAR DISPL, CCW	90-L-055-KA-1-CD-60-S-3-S1-C-03-GBA-38-38-24	SERIES 90	S90-055PV
9421348	PUMP-VAR DISPL, CCW	90-L-055-KA-1-NN-60-S-3-S1-C-03-GBA-38-38-24	SERIES 90	S90-055PV
9421349	PUMP-VAR DISPL, CCW	90-L-055-KA-2-CD-60-S-3-S1-C-33-GBA-07-38-24	SERIES 90	S90-055PV
9421350	PUMP-VAR DISPL, CCW	90-L-055-KA-2-CD-80-S-3-S1-C-03-GBA-07-38-20	SERIES 90	S90-055PV
9421351	PUMP-VAR DISPL, CCW	90-L-055-KA-1-NN-60-L-3-S1-C-03-GBA-29-29-24	SERIES 90	S90-055PV
9421352	PUMP-VAR DISPL, CCW	90-L-055-KA-1-NN-80-R-3-S1-C-03-GBA-29-29-24	SERIES 90	S90-055PV

9421353	PUMP-VAR DISPL, CCW	90-L-055-MD-1-CD-80-S-3-S1-C-02-GBA-42-42-24	SERIES 90	S90-055PV
9421354	PUMP-VAR DISPL, CCW	90-L-055-MD-1-BK-80-S-3-S1-C-02-GBA-42-42-24	SERIES 90	S90-055PV
9421355	PUMP-VAR DISPL, CCW	90-L-055-KP-1-NN-80-S-4-S1-C-05-GBA-32-32-24	SERIES 90	S90-055PV
9421356	PUMP-VAR DISPL, CCW	90-L-055-KP-1-CD-80-S-4-C6-C-05-GBA-32-32-24	SERIES 90	S90-055PV
9421357	PUMP-VAR DISPL, CCW	90-L-055-HK-1-CD-60-S-3-S1-C-03-GBA-38-38-20	SERIES 90	S90-055PV
9421358	PUMP-VAR DISPL, CCW	90-L-055-HK-1-NN-60-S-3-S1-C-03-GBA-38-38-20	SERIES 90	S90-055PV
9421359	PUMP-VAR DISPL, CCW	90-L-055-HK-1-NN-60-S-3-S1-C-03-GBA-07-38-20	SERIES 90	S90-055PV
9421360	PUMP-VAR DISPL, CCW	90-L-055-HK-1-CD-60-P-3-S1-C-03-GBA-38-38-20	SERIES 90	S90-055PV
9421361	PUMP-VAR DISPL, CCW	90-L-055-KP-1-CD-80-S-4-S1-D-03-GBA-23-23-24	SERIES 90	S90-055PV
9421362	PUMP-VAR DISPL, CCW	90-L-055-MA-1-NN-60-S-3-S1-D-03-GBA-32-32-24	SERIES 90	S90-055PV
9421363	PUMP-VAR DISPL, CCW	90-L-055-KA-1-CD-60-S-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
9421364	PUMP-VAR DISPL, CCW	90-L-055-HK-1-CD-60-S-3-S1-C-03-GBA-07-38-20	SERIES 90	S90-055PV
9421365	PUMP-VAR DISPL, CCW	90-L-055-KA-1-BG-80-P-4-C6-C-03-GBA-42-42-24	SERIES 90	S90-055PV
9421366	PUMP-VAR DISPL, CCW	90-L-055-KA-1-AD-80-P-4-C6-C-03-GBA-42-42-24	SERIES 90	S90-055PV
9421366C	PUMP-VAR-DISPL CCW 90PV055	90-L-055-KA-1-AD-80-P-4-C6-C-03-GBA-42-42-24	SERIES 90	S90-055PV
9421367	PUMP-VAR DISPL, CCW	90-L-055-KA-1-CD-80-P-4-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9421367C	PUMP-VAR-DISPL CCW 90PV055	90-L-055-KA-1-CD-80-P-4-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9421368	PUMP-VAR DISPL, CCW	90-L-055-KA-1-NN-80-P-4-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9421368C	PUMP-VAR-DISPL CCW 90PV055	90-L-055-KA-1-NN-80-P-4-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9421369	PUMP-VAR DISPL, CCW	90-L-055-KZ-1-BK-80-S-3-S1-C-02-GBA-42-42-24	SERIES 90	S90-055PV
9421370	PUMP-VAR DISPL, CCW	90-L-055-KA-1-AF-80-P-4-C6-C-03-GBA-42-42-24	SERIES 90	S90-055PV
9421370C	PUMP-VAR-DISPL CCW 90PV055	90-L-055-KA-1-AF-80-P-4-C6-C-03-GBA-42-42-24	SERIES 90	S90-055PV
9421371	PUMP-VAR DISPL, CCW	90-L-055-KA-1-BB-60-R-3-T1-C-03-GBA-38-38-24	SERIES 90	S90-055PV
9421372	PUMP-VAR DISPL, CCW	90-L-055-KA-1-NN-80-D-4-S1-L-02-GBA-42-42-24	SERIES 90	S90-055PV
9421373	PUMP-VAR DISPL, CCW	90-L-055-KP-1-NN-80-L-3-S1-D-03-GBA-29-29-24	SERIES 90	S90-055PV
9421374	PUMP-VAR DISPL, CCW	90-L-055-KA-1-BC-60-P-4-S1-C-03-GBA-29-29-24	SERIES 90	S90-055PV
9421375	PUMP-VAR DISPL, CCW	90-L-055-HK-1-NN-60-P-3-S1-C-03-GBA-29-29-20	SERIES 90	S90-055PV
9421376	PUMP-VAR-DISPL CCW 90PV055	90-L-055-KA-1-BG-80-S-3-C6-C-06-FAD-29-29-20	SERIES 90	S90-055PV
9421377	PUMP-VAR DISPL, CCW	90-L-055-HS-1-NN-80-R-3-S1-C-03-GBA-26-26-24	SERIES 90	S90-055PV
9421381	PUMP-VAR DISPL, CCW	90-L-055-EA-1-NN-80-S-3-S1-C-03-GBA-38-38-20	SERIES 90	S90-055PV
9421382	PUMP-VAR DISPL, CCW	90-L-055-KP-1-AD-80-S-4-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
9421383	PUMP-VAR DISPL, CCW	90-L-055-KA-1-CD-80-P-4-S1-C-01-GBA-29-29-20	SERIES 90	S90-055PV
9421384	PUMP-VAR DISPL, CCW	90-L-055-KA-1-AD-80-P-4-S1-C-01-GBA-29-29-20	SERIES 90	S90-055PV
9421385	PUMP-VAR DISPL, CCW	90-L-055-KA-1-BC-61-P-3-S1-C-00-GBA-35-35-24	SERIES 90	S90-055PV
9421386	PUMP-VAR DISPL, CCW	90-L-055-DC-1-NN-80-L-3-S1-C-GB-GBA-35-35-24	SERIES 90	S90-055PV
9421387	PUMP-VAR DISPL, CCW	90-L-055-EA-1-NN-80-P-3-S1-C-03-GBA-29-29-20	SERIES 90	S90-055PV

9421388	PUMP-VAR DISPL, CCW	90-L-055-KP-1-NN-80-S-4-S1-C-03-GBA-26-26-24	SERIES 90	S90-055PV
9421389	PUMP-VAR-DISPL CCW 90PV055	90-L-055-KA-1-NN-80-S-3-C6-C-03-GBA-42-42-24	SERIES 90	S90-055PV
9421390	PUMP-VAR DISPL, CCW	90-L-055-HK-1-CD-60-S-3-S1-C-00-GBA-07-38-20	SERIES 90	S90-055PV
9421391	PUMP-VAR DISPL, CCW	90-L-055-EA-2-CD-60-S-4-S1-C-33-GBA-07-38-20	SERIES 90	S90-055PV
9421392	PUMP-VAR DISPL, CCW	90-L-055-KP-1-CD-80-S-4-C6-C-26-GBA-32-32-24	SERIES 90	S90-055PV
9421393	PUMP-VAR DISPL, CCW	90-L-055-KP-1-NN-80-S-4-S1-C-26-GBA-32-32-24	SERIES 90	S90-055PV
9421394	PUMP-VAR DISPL, CCW	90-L-055-MA-1-BG-80-S-4-S1-C-03-GBA-26-26-24	SERIES 90	S90-055PV
9421395	PUMP-VAR DISPL, CCW	90-L-055-MA-1-NN-60-P-4-S1-C-03-GBA-23-23-24	SERIES 90	S90-055PV
9421396	PUMP-VAR-DISPL CCW 90PV055	90-L-055-KA-1-BB-60-P-3-C6-D-03-GBA-29-29-24	SERIES 90	S90-055PV
9421397	PUMP-VAR DISPL, CCW	90-L-055-KP-1-CD-80-R-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
9421398	PUMP-VAR DISPL, CCW	90-L-055-KP-1-NN-80-R-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
9421399	PUMP-VAR-DISPL CCW 90PV055	90-L-055-KA-1-NN-80-S-3-C6-C-06-FAD-29-29-20	SERIES 90	S90-055PV
9421400	PUMP-VAR DISPL, CCW	90-L-055-KP-2-AD-80-S-3-S1-D-05-GBA-42-42-24	SERIES 90	S90-055PV
9421401	PUMP-VAR DISPL, CCW	90-L-055-KP-2-AD-80-S-3-C6-D-05-GBA-42-42-24	SERIES 90	S90-055PV
9421402	PUMP-VAR DISPL, CCW	90-L-055-KA-1-NN-80-R-4-S1-D-02-FAB-29-29-24	SERIES 90	S90-055PV
9421403	PUMP-VAR DISPL, CCW	90-L-055-KA-1-NN-80-L-4-S1-D-03-GBA-23-23-24	SERIES 90	S90-055PV
9421404	PUMP-VAR DISPL, CCW	90-L-055-EG-1-BB-60-S-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
9421405	PUMP-VAR DISPL, CCW	90-L-055-EG-1-CD-60-P-3-S1-D-02-GBA-42-42-24	SERIES 90	S90-055PV
9421406	PUMP-VAR-DISPL CCW 90PV055	90-L-055-KA-1-AD-80-R-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9421407	PUMP-VAR DISPL, CCW	90-L-055-KZ-1-BK-80-S-3-S1-C-02-GBA-32-32-24	SERIES 90	S90-055PV
9421408	PUMP-VAR DISPL, CCW	90-L-055-KP-1-CD-80-L-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
9421409	PUMP-VAR DISPL, CCW	90-L-055-KP-1-NN-80-L-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
9421410	PUMP-VAR DISPL, CCW	90-L-055-KP-1-CD-80-S-3-S1-D-03-GBA-23-23-24	SERIES 90	S90-055PV
9421411	PUMP-VAR-DISPL CCW 90PV055	90-L-055-KA-5-BB-60-P-3-C6-D-03-GBA-23-23-22	SERIES 90	S90-055PV
9421412	PUMP-VAR-DISPL CCW 90PV055	90-L-055-KA-1-AB-60-R-3-C6-C-04-GBA-35-35-24	SERIES 90	S90-055PV
9421413	PUMP-VAR DISPL, CCW	90-L-055-HS-1-CD-60-P-3-S1-C-03-GBA-23-23-24	SERIES 90	S90-055PV
9421414	PUMP-VAR DISPL, CCW	90-L-055-MA-1-BC-60-P-4-S1-C-03-GBA-23-23-24	SERIES 90	S90-055PV
9421415	PUMP-VAR DISPL, CCW	90-L-055-MA-7-NN-80-S-3-T1-D-00-GBA-45-45-24	SERIES 90	S90-055PV
9421416	PUMP-VAR-DISPL CCW 90PV055	90-L-055-KA-1-BG-80-S-4-C6-C-03-GBA-35-35-20	SERIES 90	S90-055PV
9421417	PUMP-VAR DISPL, CCW	90-L-055-EK-1-CD-60-P-3-S1-D-03-GBA-45-45-24	SERIES 90	S90-055PV
9421418	PUMP-VAR DISPL, CCW	90-L-055-EK-1-NN-60-P-3-S1-D-03-GBA-45-45-24	SERIES 90	S90-055PV
9421419	PUMP-VAR DISPL, CCW	90-L-055-DC-1-CD-80-S-3-S1-D-G8-GBA-26-26-24	SERIES 90	S90-055PV
9421420	PUMP-VAR DISPL, CCW	90-L-055-DC-1-NN-80-S-3-S1-D-G8-GBA-26-26-24	SERIES 90	S90-055PV
9421421	PUMP-VAR DISPL, CCW	90-L-055-DC-1-CD-80-S-4-S1-D-GB-GBA-23-23-24	SERIES 90	S90-055PV
9421422	PUMP-VAR DISPL, CCW	90-L-055-DC-1-BG-80-S-4-S1-D-GB-GBA-23-23-24	SERIES 90	S90-055PV
9421423	PUMP-VAR DISPL, CCW	90-L-055-DC-1-NN-80-S-4-S1-D-GB-GBA-23-23-24	SERIES 90	S90-055PV

9421424	PUMP-VAR-DISPL CCW 90PV055	90-L-055-KA-1-NN-80-S-3-S1-C-42-GBA-42-42-24	SERIES 90	S90-055PV
9421425	PUMP-VAR DISPL, CCW	90-L-055-KA-1-AB-60-R-4-C6-D-03-GBA-42-35-24	SERIES 90	S90-055PV
9421426	PUMP-VAR DISPL, CCW	90-L-055-KP-1-CD-80-S-3-S1-D-02-GBA-26-26-24	SERIES 90	S90-055PV
9421427	PUMP-VAR DISPL, CCW	90-L-055-KP-1-NN-80-S-3-S1-D-02-GBA-26-26-24	SERIES 90	S90-055PV
9421428	PUMP-VAR DISPL, CCW	90-L-055-KP-1-BG-80-S-4-S1-C-01-GBA-23-23-24	SERIES 90	S90-055PV
9421429	PUMP-VAR DISPL, CCW	90-L-055-KP-1-NN-80-S-4-S1-C-01-GBA-29-29-24	SERIES 90	S90-055PV
9421430	PUMP-VAR DISPL, CCW	90-L-055-CA-6-NN-60-S-4-C6-D-00-GBA-48-48-20	SERIES 90	S90-055PV
9421431	PUMP-VAR DISPL, CCW	90-L-055-MA-1-CD-80-P-3-C6-D-03-GBA-38-38-24	SERIES 90	S90-055PV
9421432	PUMP-VAR DISPL, CCW	90-L-055-MA-1-NN-80-P-3-S1-D-03-GBA-38-38-24	SERIES 90	S90-055PV
9421433	PUMP-VAR DISPL, CCW	90-L-055-EA-1-BG-80-R-3-S1-D-03-GBA-20-20-24	SERIES 90	S90-055PV
9421434	PUMP-VAR DISPL, CCW	90-L-055-KP-G-CD-60-R-3-T1-C-03-GBA-23-23-24	SERIES 90	S90-055PV
9421435	PUMP-VAR DISPL, CCW	90-L-055-KP-G-NN-60-R-3-S1-C-03-GBA-23-23-24	SERIES 90	S90-055PV
9421436	PUMP-VAR DISPL, CCW	90-L-055-HF-6-NN-60-S-3-S1-B-03-GBA-48-48-24	SERIES 90	S90-055PV
9421438	PUMP-VAR DISPL, CCW	90-L-055-M4-1-NN-60-S-4-C6-D-71-GBA-35-35-24-F026	SERIES 90	S90-055PV
9421439	PUMP-VAR-DISPL CCW 90PV055	90-L-055-KA-5-BG-80-S-3-C6-C-06-FAC-32-32-20	SERIES 90	S90-055PV
9421440	PUMP-VAR-DISPL CCW 90PV055	90-L-055-KA-5-NN-80-S-3-C6-C-03-GBA-42-42-24	SERIES 90	S90-055PV
9421441	PUMP-VAR DISPL, CCW	90-L-055-KP-1-BG-80-R-4-S1-C-04-GBA-26-26-20	SERIES 90	S90-055PV
9421442	PUMP-VAR DISPL, CCW	90-L-055-KP-7-AD-80-S-3-T1-D-03-GBA-45-45-24	SERIES 90	S90-055PV
9421443	PUMP-VAR-DISPL CCW 90PV055	90-L-055-KA-5-BG-80-S-3-C6-C-03-GBA-42-42-24	SERIES 90	S90-055PV
9421444	PUMP-VAR DISPL, CCW	90-L-055-KP-1-CD-80-S-3-S1-C-01-GBA-35-35-24	SERIES 90	S90-055PV
9421445	PUMP-VAR DISPL, CCW	90-L-055-KA-1-NN-60-L-4-S1-C-03-GBA-23-23-24	SERIES 90	S90-055PV
9421446	PUMP-VAR DISPL, CCW	90-L-055-MV-1-NN-80-S-3-S1-C-01-GBA-38-38-24	SERIES 90	S90-055PV
9421449	PUMP-VAR DISPL, CCW	90-L-055-KA-1-NN-80-S-4-S1-C-03-GBA-38-38-24	SERIES 90	S90-055PV
9421450	PUMP-VAR DISPL, CCW	90-L-055-KP-1-CD-80-R-4-C6-C-26-GBA-32-32-24	SERIES 90	S90-055PV
9421454	PUMP-VAR DISPL, CCW	90-L-055-MS-2-BK-80-R-1-S1-D-03-GBA-42-23-20-F029	SERIES 90	S90-055PV
9421500	PUMP-VAR DISPL, CW	90-R-055-MA-1-BC-60-P-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9421501	PUMP-VAR DISPL, CW	90-R-055-MA-1-BC-61-R-4-S1-C-00-GBA-26-26-24	SERIES 90	S90-055PV
9421502	PUMP-VAR DISPL, CW	90-R-055-MA-1-AB-61-R-3-C6-D-03-GBA-35-35-24	SERIES 90	S90-055PV
9421503	PUMP-VAR DISPL, CW	90-R-055-MC-1-BC-60-R-4-S1-C-02-GBA-35-35-24	SERIES 90	S90-055PV
9421504	PUMP-VAR DISPL, CW	90-R-055-EA-1-BC-60-P-3-S1-C-00-GBA-23-23-24	SERIES 90	S90-055PV
9421505	PUMP-VAR DISPL, CW	90-R-055-EA-2-BK-80-P-4-T1-D-01-GBA-35-35-20	SERIES 90	S90-055PV
9421506	PUMP-VAR DISPL, CW	90-R-055-EP-1-NN-61-R-4-T1-C-00-GBA-35-35-24	SERIES 90	S90-055PV
9421509	PUMP-VAR DISPL, CW	90-R-055-MA-1-CD-60-S-3-S1-C-03-GBA-17-17-24	SERIES 90	S90-055PV
9421510	PUMP-VAR DISPL, CW	90-R-055-MA-1-BC-60-S-3-S1-C-03-GBA-17-17-24	SERIES 90	S90-055PV
9421511	PUMP-VAR DISPL, CW	90-R-055-EA-1-AB-60-L-3-T1-D-00-GEA-38-38-24	SERIES 90	S90-055PV
9421512	PUMP-VAR DISPL, CW	90-R-055-MA-1-NN-60-S-4-K1-C-03-GBA-29-29-20	SERIES 90	S90-055PV

9421513	PUMP-VAR DISPL, CW	90-R-055-MB-2-CD-80-R-4-C6-L-00-GBA-35-35-28	SERIES 90	S90-055PV
9421514	PUMP-VAR DISPL, CW	90-R-055-MB-2-AF-80-R-4-S1-L-00-GBA-35-35-28	SERIES 90	S90-055PV
9421515	PUMP-VAR DISPL, CW	90-R-055-EP-1-BC-60-S-3-S1-C-03-GBA-38-38-20	SERIES 90	S90-055PV
9421516	PUMP-VAR-DISPL CW 90PV055	90-R-055-CB-5-NN-60-S-3-S1-C-00-GBA-35-35-20-G002	SERIES 90	S90-055PV
9421517	PUMP-VAR DISPL, CW	90-R-055-EA-1-AB-60-P-4-C6-C-28-GBA-42-35-24	SERIES 90	S90-055PV
9421518	PUMP-VAR-DISPL CW 90PV055	90-R-055-MA-1-AB-60-P-3-C6-C-03-GBA-32-32-24	SERIES 90	S90-055PV
9421519	PUMP-VAR-DISPL CW 90PV055	90-R-055-EA-6-BC-60-S-3-S1-D-39-GBA-48-48-24	SERIES 90	S90-055PV
9421520	PUMP-VAR DISPL, CW	90-R-055-MA-2-NN-60-S-3-C6-C-61-FAB-45-45-24	SERIES 90	S90-055PV
9421521	PUMP-VAR DISPL, CW	90-R-055-ME-1-BB-60-D-3-C6-L-03-GBA-38-38-20	SERIES 90	S90-055PV
9421522	PUMP-VAR DISPL, CW	90-R-055-EA-1-BC-60-S-3-S1-C-03-GBA-32-32-24	SERIES 90	S90-055PV
9421523	PUMP-VAR DISPL, CW	90-R-055-DC-1-AB-60-D-4-S1-L-99-GBA-42-42-20	SERIES 90	S90-055PV
9421524	PUMP-VAR DISPL, CW	90-R-055-EP-1-AB-60-L-3-S1-C-00-GBA-42-42-24	SERIES 90	S90-055PV
9421526	PUMP-VAR DISPL, CW	90-R-055-EA-1-BC-60-R-3-S1-C-03-GBA-32-32-24	SERIES 90	S90-055PV
9421528	PUMP-VAR-DISPL CW 90PV055	90-R-055-EA-1-NN-60-S-3-C6-C-04-GBA-42-42-20	SERIES 90	S90-055PV
9421529	PUMP-VAR DISPL, CW	90-R-055-ME-1-BB-60-D-3-C6-L-03-GBA-42-42-24	SERIES 90	S90-055PV
9421530	PUMP-VAR DISPL, CW	90-R-055-EA-1-NN-80-R-3-K1-D-03-GBA-26-26-24	SERIES 90	S90-055PV
9421532	PUMP-VAR DISPL, CW	90-R-055-MB-1-CD-60-S-3-T1-C-03-FAC-35-38-24	SERIES 90	S90-055PV
9421533	PUMP-VAR DISPL, CW	90-R-055-MB-1-AB-60-S-3-S1-C-03-GBA-35-38-24	SERIES 90	S90-055PV
9421534	PUMP-VAR-DISPL CW 90PV055	90-R-055-MF-1-BB-60-D-3-S1-L-02-GBA-42-42-22-P000	SERIES 90	S90-055PV
9421535	PUMP-VAR DISPL, CW	90-R-055-MA-1-BG-80-P-3-K1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9421536	PUMP-VAR DISPL, CW	90-R-055-HK-1-CD-60-R-3-S1-C-02-GBA-42-42-24	SERIES 90	S90-055PV
9421537	PUMP-VAR-DISPL CW 90PV055	90-R-055-CB-5-NN-80-S-3-S1-C-00-GBA-00-00-00-P000	SERIES 90	S90-055PV
9421538	PUMP-VAR DISPL, CW	90-R-055-EA-1-BG-80-L-4-K1-C-03-GBA-23-23-24	SERIES 90	S90-055PV
9421539	PUMP-VAR DISPL, CW	90-R-055-EA-1-NN-80-P-3-C6-D-03-GBA-32-32-18	SERIES 90	S90-055PV
9421540	PUMP-VAR DISPL, CW	90-R-055-EA-1-AB-60-P-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-055PV
9421541	PUMP-VAR DISPL, CW	90-R-055-MB-1-CD-60-S-3-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9421542	PUMP-VAR DISPL, CW	90-R-055-MB-1-BC-60-S-3-S1-C-03-FAC-35-38-24	SERIES 90	S90-055PV
9421543	PUMP-VAR DISPL, CW	90-R-055-EA-1-CD-80-S-K-C6-D-04-GBA-35-35-24	SERIES 90	S90-055PV
9421544	PUMP-VAR DISPL, CW	90-R-055-EA-1-NN-60-P-3-C6-D-04-GBA-29-29-24	SERIES 90	S90-055PV
9421545	PUMP-VAR-DISPL CW 90PV055	90-R-055-CB-5-NN-80-S-3-C6-C-00-GBA-00-00-00-P000	SERIES 90	S90-055PV
9421547	PUMP-VAR DISPL, CW	90-R-055-MB-1-AD-80-S-3-S1-C-03-GCA-35-35-20	SERIES 90	S90-055PV
9421548	PUMP-VAR DISPL, CW	90-R-055-EA-1-AD-80-L-4-K1-C-03-GBA-35-35-20	SERIES 90	S90-055PV
9421549	PUMP-VAR DISPL, CW	90-R-055-HF-1-NN-80-P-4-S1-C-02-GBA-42-42-24	SERIES 90	S90-055PV
9421550	PUMP-VAR DISPL, CW	90-R-055-MA-1-NN-60-S-3-C6-D-03-GBA-35-35-24	SERIES 90	S90-055PV
9421551	PUMP-VAR-DISPL CW 90PV055	90-R-055-CB-5-NN-60-S-3-C6-C-00-GBA-00-00-00	SERIES 90	S90-055PV
9421553	PUMP-VAR DISPL, CW	90-R-055-MA-1-NN-80-R-3-C6-C-03-GBA-35-35-20	SERIES 90	S90-055PV

9421554	PUMP-VAR DISPL, CW	90-R-055-MA-1-NN-80-L-3-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9421554C	PUMP-VAR-DISPL CW 90PV055	90-R-055-MA-1-NN-80-L-3-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9421556	PUMP-VAR DISPL, CW	90-R-055-EA-1-NN-60-S-3-C6-D-03-GBA-23-23-24	SERIES 90	S90-055PV
9421557	PUMP-VAR DISPL, CW	90-R-055-EA-1-NN-60-S-3-T1-D-03-GBA-42-42-20	SERIES 90	S90-055PV
9421558	PUMP-VAR DISPL, CW	90-R-055-MB-1-CD-60-R-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9421559	PUMP-VAR DISPL, CW	90-R-055-DC-1-AB-60-L-4-S1-D-G4-GBA-35-35-20	SERIES 90	S90-055PV
9421560	PUMP-VAR DISPL, CW	90-R-055-MA-1-NN-80-S-3-S1-C-03-GBA-42-42-20	SERIES 90	S90-055PV
9421561	PUMP-VAR DISPL, CW	90-R-055-EA-1-AB-60-P-4-S1-C-03-GBA-17-17-20	SERIES 90	S90-055PV
9421562	PUMP-VAR-DISPL CW 90PV055	90-R-055-DD-1-NN-80-S-4-S1-C-52-FAD-42-42-20	SERIES 90	S90-055PV
9421563	PUMP-VAR DISPL, CW	90-R-055-EA-1-NN-80-R-3-S1-C-05-FAA-35-35-24	SERIES 90	S90-055PV
9421564	PUMP-VAR-DISPL CW 90PV055	90-R-055-EA-1-BB-60-S-3-C6-D-04-FAA-42-42-30	SERIES 90	S90-055PV
9421567	PUMP-VAR DISPL, CW	90-R-055-EA-1-NN-60-R-3-C6-C-03-FAD-38-38-24	SERIES 90	S90-055PV
9421570	PUMP-VAR DISPL, CW	90-R-055-EA-1-BB-60-S-3-S1-C-03-GBA-23-23-20	SERIES 90	S90-055PV
9421571	PUMP-VAR-DISPL CW 90PV055	90-R-055-DC-1-AD-80-D-4-S1-L-99-GBA-42-42-20	SERIES 90	S90-055PV
9421572	PUMP-VAR DISPL, CW	90-R-055-EA-1-BC-60-P-3-S1-C-03-GBA-35-35-20	SERIES 90	S90-055PV
9421573	PUMP-VAR DISPL, CW	90-R-055-EA-1-NN-60-P-3-S1-D-03-GBA-23-23-24	SERIES 90	S90-055PV
9421574	PUMP-VAR DISPL, CW	90-R-055-EA-1-CD-60-P-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-055PV
9421575	PUMP-VAR DISPL, CW	90-R-055-EP-1-BC-60-R-3-K1-D-00-GBA-14-14-20	SERIES 90	S90-055PV
9421576	PUMP-VAR DISPL, CW	90-R-055-MA-1-CD-60-P-3-C6-D-03-FAC-38-35-24	SERIES 90	S90-055PV
9421577	PUMP-VAR DISPL, CW	90-R-055-MB-1-BC-60-P-3-S1-C-03-FAC-38-35-24	SERIES 90	S90-055PV
9421578	PUMP-VAR DISPL, CW	90-R-055-EA-1-NN-80-P-3-S1-D-03-GBA-23-23-24	SERIES 90	S90-055PV
9421579	PUMP-VAR DISPL, CW	90-R-055-EA-1-CD-80-P-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-055PV
9421580	PUMP-VAR DISPL, CCW	90-L-055-EA-1-BK-80-P-3-T1-D-04-EAB-42-42-24	SERIES 90	S90-055PV
9421581	PUMP-VAR-DISPL CW 90PV055	90-R-055-EA-1-NN-80-S-4-C6-C-03-FAD-29-29-20	SERIES 90	S90-055PV
9421582	PUMP-VAR-DISPL CW 90PV055	90-R-055-DD-1-NN-80-S-4-S1-D-GB-FAD-42-42-24	SERIES 90	S90-055PV
9421583	PUMP-VAR DISPL, CW	90-R-055-EA-1-NN-80-R-3-S1-C-05-EEC-35-35-24	SERIES 90	S90-055PV
9421584	PUMP-VAR DISPL, CW	90-R-055-KA-1-BB-60-L-3-S1-C-26-GBA-32-32-24	SERIES 90	S90-055PV
9421585	PUMP-VAR DISPL, CW	90-R-055-HF-1-CD-60-R-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9421586	PUMP-VAR-DISPL CW 90PV055	90-R-055-EA-1-NN-60-S-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9421587	PUMP-VAR DISPL, CW	90-R-055-MA-B-BK-80-S-3-S1-C-03-GBA-32-42-24	SERIES 90	S90-055PV
9421589	PUMP-VAR DISPL, CW	90-R-055-EA-1-NN-60-P-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-055PV
9421592	PUMP-VAR DISPL, CW	90-R-055-MB-1-BK-80-D-3-C6-L-04-GBA-38-38-24	SERIES 90	S90-055PV
9421595	PUMP-VAR DISPL, CW	90-R-055-MA-1-BC-60-S-3-S1-B-03-GBA-42-42-24	SERIES 90	S90-055PV
9421598	PUMP-VAR-DISPL CW 90PV055	90-R-055-EA-1-NN-60-R-3-C6-C-06-FAD-38-38-24	SERIES 90	S90-055PV
9421599	PUMP-VAR DISPL, CW	90-R-055-MA-1-CD-60-P-3-K1-C-03-GBA-32-32-20	SERIES 90	S90-055PV
9421600	PUMP-VAR DISPL, CW	90-R-055-EA-1-NN-80-P-3-S1-D-00-GBA-23-23-24	SERIES 90	S90-055PV

9421601	PUMP-VAR DISPL, CW	90-R-055-EA-1-CD-80-P-3-S1-D-00-GBA-35-35-24	SERIES 90	S90-055PV
9421602	PUMP-VAR DISPL, CW	90-R-055-MA-1-CD-60-S-3-C6-C-03-GBA-42-42-20	SERIES 90	S90-055PV
9421603	PUMP-VAR DISPL, CW	90-R-055-MA-1-BC-60-S-3-S1-C-03-GBA-42-42-20	SERIES 90	S90-055PV
9421604	PUMP-VAR DISPL, CW	90-R-055-EP-1-BC-61-R-4-S1-C-00-GBA-35-35-24	SERIES 90	S90-055PV
9421605	PUMP-VAR-DISPL CW 90PV055	90-R-055-CB-1-NM-6L-S-K-C6-2-00-FAB-00-00-00-P000	SERIES 90	S90-055PV
9421607	PUMP-VAR DISPL, CW	90-R-055-MB-1-CD-60-P-3-C6-D-03-FAC-35-35-24	SERIES 90	S90-055PV
9421608	PUMP-VAR DISPL, CW	90-R-055-MA-1-BC-60-P-3-S1-C-03-FAC-35-35-24	SERIES 90	S90-055PV
9421609	PUMP-VAR DISPL, CW	90-R-055-MS-1-BG-80-P-3-S1-C-03-GBA-38-38-24	SERIES 90	S90-055PV
9421610	PUMP-VAR DISPL, CW	90-R-055-MA-1-NN-80-S-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-055PV
9421611	PUMP-VAR DISPL, CW	90-R-055-MA-2-CD-60-P-3-C6-D-03-GBA-35-35-20	SERIES 90	S90-055PV
9421612	PUMP-VAR DISPL, CW	90-R-055-MA-2-NN-60-P-3-S1-D-03-GBA-35-35-20	SERIES 90	S90-055PV
9421613	PUMP-VAR DISPL, CW	90-R-055-EA-1-BG-80-P-3-S1-C-00-GBA-35-35-24	SERIES 90	S90-055PV
9421616	PUMP-VAR DISPL, CW	90-R-055-M2-1-AD-80-S-3-S1-C-03-GFW-35-35-20	SERIES 90	S90-055PV
9421617	PUMP-VAR DISPL, CW	90-R-055-M2-1-CD-60-P-3-C6-D-03-FAC-35-35-24	SERIES 90	S90-055PV
9421618	PUMP-VAR DISPL, CW	90-R-055-M1-1-BC-60-P-3-S1-C-03-FAC-35-35-24	SERIES 90	S90-055PV
9421619	PUMP-VAR DISPL, CW	90-R-055-KA-1-CD-60-S-3-C6-D-05-EAB-42-42-24	SERIES 90	S90-055PV
9421620	PUMP-VAR DISPL, CW	90-R-055-KA-1-BG-80-S-4-S1-C-03-GBA-42-42-20	SERIES 90	S90-055PV
9421622	PUMP-VAR DISPL, CW	90-R-055-MB-1-BC-60-S-3-S1-C-03-FAC-42-42-24	SERIES 90	S90-055PV
9421623	PUMP-VAR DISPL, CW	90-R-055-ME-1-BB-60-D-7-C6-L-04-FAB-35-35-22	SERIES 90	S90-055PV
9421624	PUMP-VAR DISPL, CW	90-R-055-HK-2-CD-60-R-3-S1-C-02-GBA-42-42-24	SERIES 90	S90-055PV
9421625	PUMP-VAR DISPL, CW	90-R-055-MA-2-BC-60-P-3-S1-D-03-GBA-35-35-20	SERIES 90	S90-055PV
9421626	PUMP-VAR DISPL, CW	90-R-055-KP-1-NN-80-L-4-C6-C-01-GBA-26-26-20	SERIES 90	S90-055PV
9421626C	PUMP-VAR-DISPL CW 90PV055	90-R-055-KP-1-NN-80-L-4-C6-C-01-GBA-26-26-20	SERIES 90	S90-055PV
9421627	PUMP-VAR DISPL, CW	90-R-055-KA-1-NN-80-P-3-S1-D-00-GBA-38-38-24	SERIES 90	S90-055PV
9421628	PUMP-VAR DISPL, CW	90-R-055-KA-1-CD-80-P-3-S1-D-00-GBA-38-38-24	SERIES 90	S90-055PV
9421629	PUMP-VAR DISPL, CW	90-R-055-MA-1-CD-80-S-3-C6-C-03-GBA-29-29-20	SERIES 90	S90-055PV
9421630	PUMP-VAR DISPL, CW	90-R-055-MA-1-BK-80-S-3-S1-C-03-GBA-29-29-20	SERIES 90	S90-055PV
9421631	PUMP-VAR DISPL, CW	90-R-055-MA-1-BG-80-S-3-S1-C-03-GBA-29-29-20	SERIES 90	S90-055PV
9421632	PUMP-VAR DISPL, CW	90-R-055-HS-1-NN-60-P-3-S1-D-03-GBA-23-23-20	SERIES 90	S90-055PV
9421633	PUMP-VAR-DISPL CW 90PV055	90-R-055-KA-1-NN-60-S-3-C6-D-03-GBA-38-38-24	SERIES 90	S90-055PV
9421634	PUMP-VAR DISPL, CW	90-R-055-DC-1-NN-80-R-4-S1-B-GB-FAD-35-35-24	SERIES 90	S90-055PV
9421635	PUMP-VAR DISPL, CW	90-R-055-KA-1-CD-60-S-3-S1-C-00-GBA-20-20-24	SERIES 90	S90-055PV
9421636	PUMP-VAR DISPL, CW	90-R-055-KA-1-NN-80-S-4-C6-C-03-FAD-29-29-20	SERIES 90	S90-055PV
9421637	PUMP-VAR DISPL, CW	90-R-055-MB-1-BC-60-S-3-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9421637C	PUMP-VAR-DISPL CW 90PV055	90-R-055-MB-1-BC-60-S-3-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9421638	PUMP-VAR DISPL, CW	90-R-055-MB-1-BK-80-D-3-C6-L-03-GBA-38-38-24	SERIES 90	S90-055PV

9421638C	PUMP-VAR-DISPL CW 90PV055	90-R-055-MB-1-BK-80-D-3-C6-L-03-GBA-38-38-24	SERIES 90	S90-055PV
9421640	PUMP-VAR DISPL, CW	90-R-055-MA-1-CD-60-S-3-C6-C-03-GBA-35-35-20	SERIES 90	S90-055PV
9421641	PUMP-VAR DISPL, CW	90-R-055-MA-1-BC-60-S-3-S1-C-03-GBA-35-35-20	SERIES 90	S90-055PV
9421643	PUMP-VAR DISPL, CW	90-R-055-KA-1-AB-60-S-3-C6-C-04-GBA-42-42-20	SERIES 90	S90-055PV
9421644	PUMP-VAR DISPL, CW	90-R-055-KA-1-BC-60-R-3-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9421645	PUMP-VAR DISPL, CW	90-R-055-KA-1-BC-60-R-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9421647	PUMP-VAR DISPL, CW	90-R-055-MB-6-BG-80-P-3-S1-C-03-FAD-45-45-24	SERIES 90	S90-055PV
9421648	PUMP-VAR DISPL, CW	90-R-055-MB-6-BG-80-P-3-S1-C-03-FAD-45-45-28	SERIES 90	S90-055PV
9421649	PUMP-VAR DISPL, CW	90-R-055-MA-1-AB-60-S-3-S1-C-00-GBA-14-14-20	SERIES 90	S90-055PV
9421650	PUMP-VAR DISPL, CW	90-R-055-MA-1-NN-60-P-3-S1-C-03-GBA-26-26-20	SERIES 90	S90-055PV
9421651	PUMP-VAR DISPL, CW	90-R-055-KP-1-NN-61-R-4-T1-C-00-GBA-35-35-24	SERIES 90	S90-055PV
9421652	PUMP-VAR DISPL, CW	90-R-055-KA-1-NN-80-P-4-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
9421653	PUMP-VAR DISPL, CW	90-R-055-KP-1-BK-80-R-4-S1-C-00-GBA-35-35-24	SERIES 90	S90-055PV
9421654	PUMP-VAR-DISPL CW 90PV055	90-R-055-DC-1-NN-80-P-3-C6-C-GB-GBA-42-42-24	SERIES 90	S90-055PV
9421655	PUMP-VAR DISPL, CW	90-R-055-EA-1-BB-60-P-3-S1-C-72-GBA-38-38-24	SERIES 90	S90-055PV
9421656	PUMP-VAR DISPL, CW	90-R-055-KA-1-BC-60-L-4-S1-C-00-GBA-26-26-24	SERIES 90	S90-055PV
9421657	PUMP-VAR-DISPL CW 90PV055	90-R-055-MB-1-NN-60-S-3-C6-D-04-GBA-35-35-20	SERIES 90	S90-055PV
9421658	PUMP-VAR DISPL, CW	90-R-055-DC-1-AB-60-P-4-S1-C-GB-GBA-42-42-24	SERIES 90	S90-055PV
9421660	PUMP-VAR DISPL, CW	90-R-055-DC-1-AD-80-D-4-S1-L-GB-GBA-38-38-20	SERIES 90	S90-055PV
9421661	PUMP-VAR DISPL, CW	90-R-055-MA-1-NN-60-S-3-S1-C-02-GBA-35-35-24	SERIES 90	S90-055PV
9421662	PUMP-VAR DISPL, CW	90-R-055-KA-1-BG-80-P-4-S1-C-00-GBA-26-26-24	SERIES 90	S90-055PV
9421663	PUMP-VAR DISPL, CW	90-R-055-MA-1-AB-60-S-3-C6-C-03-GBA-42-42-20	SERIES 90	S90-055PV
9421664	PUMP-VAR DISPL, CW	90-R-055-KA-1-CD-80-R-3-S1-C-03-GBA-23-23-20	SERIES 90	S90-055PV
9421665	PUMP-VAR DISPL, CW	90-R-055-KA-1-BG-80-R-3-S1-C-03-GBA-23-23-20	SERIES 90	S90-055PV
9421666	PUMP-VAR DISPL, CW	90-R-055-MB-6-BG-80-P-3-S1-C-03-FAB-45-45-28	SERIES 90	S90-055PV
9421667	PUMP-VAR-DISPL CW 90PV055	90-R-055-CB-1-NN-8L-R-K-S1-B-00-FAB-00-00-00-P000	SERIES 90	S90-055PV
9421668	PUMP-VAR-DISPL CW 90PV055	90-R-055-KA-1-BC-60-R-3-C6-D-04-GBA-42-42-20	SERIES 90	S90-055PV
9421669	PUMP-VAR DISPL, CW	90-R-055-KA-1-BB-60-P-3-S1-C-22-GBA-42-42-24	SERIES 90	S90-055PV
9421670	PUMP-VAR-DISPL CW 90PV055	90-R-055-KA-1-BG-80-S-3-C6-C-35-FAD-35-35-20	SERIES 90	S90-055PV
9421671	PUMP-VAR-DISPL CW 90PV055	90-R-055-KA-1-NN-80-S-4-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9421673	PUMP-VAR-DISPL CW 90PV055	90-R-055-HF-2-BC-60-S-3-S1-C-03-GBA-32-32-24	SERIES 90	S90-055PV
9421674	PUMP-VAR DISPL, CW	90-R-055-KA-1-NN-80-S-3-K1-C-03-GBA-20-20-24	SERIES 90	S90-055PV
9421676	PUMP-VAR DISPL, CW	90-R-055-KA-1-AD-80-P-4-S1-D-04-GBA-42-42-24	SERIES 90	S90-055PV
9421677	PUMP-VAR DISPL, CW	90-R-055-KA-1-BC-60-R-3-S1-C-03-GBA-38-14-24	SERIES 90	S90-055PV
9421678	PUMP-VAR DISPL, CW	90-R-055-KP-1-CD-60-P-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9421679	PUMP-VAR DISPL, CW	90-R-055-KP-1-NN-60-P-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV

9421680	PUMP-VAR DISPL, CW	90-R-055-MA-1-AD-80-S-3-S1-C-00-GBA-35-35-24	SERIES 90	S90-055PV
9421681	PUMP-VAR DISPL, CW	90-R-055-KP-1-AD-80-L-3-S1-D-00-EBC-26-26-24	SERIES 90	S90-055PV
9421682	PUMP-VAR DISPL, CW	90-R-055-KP-1-CD-80-S-3-S1-C-03-GBA-38-38-24	SERIES 90	S90-055PV
9421683	PUMP-VAR-DISPL CW 90PV055	90-R-055-KA-1-NN-80-S-3-C6-C-02-FAD-42-42-20	SERIES 90	S90-055PV
9421684	PUMP-VAR DISPL, CW	90-R-055-KA-1-AB-60-P-3-T1-C-03-GBA-26-26-24	SERIES 90	S90-055PV
9421685	PUMP-VAR DISPL, CW	90-R-055-KA-1-AB-60-P-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9421686	PUMP-VAR DISPL, CW	90-R-055-KA-1-AB-60-P-3-T1-C-03-EBC-26-26-24	SERIES 90	S90-055PV
9421687	PUMP-VAR DISPL, CW	90-R-055-KA-1-NN-60-P-3-T1-C-03-EBC-26-26-24	SERIES 90	S90-055PV
9421688	PUMP-VAR-DISPL CW 90PV055	90-R-055-KA-1-NN-80-S-3-C6-C-75-FAD-42-42-20	SERIES 90	S90-055PV
9421689	PUMP-VAR DISPL, CW	90-R-055-KP-1-NN-80-P-4-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
9421690	PUMP-VAR DISPL, CW	90-R-055-MB-1-BG-60-S-3-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9421690C	PUMP-VAR-DISPL CW 90PV055	90-R-055-MB-1-BG-60-S-3-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9421691	PUMP-VAR DISPL, CW	90-R-055-KA-1-NN-60-P-3-T1-C-03-EEB-26-26-24	SERIES 90	S90-055PV
9421692	PUMP-VAR DISPL, CW	90-R-055-MA-1-CD-80-R-3-S1-D-03-GBA-38-38-24-P000	SERIES 90	S90-055PV
9421693	PUMP-VAR DISPL, CW	90-R-055-MA-1-NN-80-R-3-S1-D-03-GBA-38-38-24	SERIES 90	S90-055PV
9421694	PUMP-VAR DISPL, CW	90-R-055-KA-1-BB-60-P-3-S1-C-72-GBA-38-38-24	SERIES 90	S90-055PV
9421695	PUMP-VAR DISPL, CW	90-R-055-HF-1-NN-60-R-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9421696	PUMP-VAR DISPL, CW	90-R-055-MA-1-BG-80-R-3-S1-D-03-GBA-38-38-24-P000	SERIES 90	S90-055PV
9421697	PUMP-VAR DISPL, CW	90-R-055-KA-1-BC-60-S-3-S1-C-03-GBA-20-20-24	SERIES 90	S90-055PV
9421698	PUMP-VAR DISPL, CW	90-R-055-KA-1-CD-60-S-3-S1-C-03-GBA-20-20-24	SERIES 90	S90-055PV
9421699	PUMP-VAR DISPL, CW	90-R-055-ME-1-NN-82-L-3-C6-C-02-GBA-42-42-24	SERIES 90	S90-055PV
9421700	PUMP-VAR DISPL, CW	90-R-055-MB-6-CD-80-P-3-C6-C-06-FAD-45-45-28	SERIES 90	S90-055PV
9421701	PUMP-VAR-DISPL CW 90PV055	90-R-055-DD-1-NN-60-S-4-S1-C-Z1-GBA-35-35-22	SERIES 90	S90-055PV
9421703	PUMP-VAR DISPL, CW	90-R-055-MV-1-CD-80-R-3-S1-D-03-GBA-38-38-24	SERIES 90	S90-055PV
9421704	PUMP-VAR DISPL, CW	90-R-055-MV-1-BG-80-R-3-S1-D-03-GBA-38-38-24	SERIES 90	S90-055PV
9421705	PUMP-VAR DISPL, CW	90-R-055-MS-1-BG-80-P-3-S1-C-00-GBA-38-38-24	SERIES 90	S90-055PV
9421707	PUMP-VAR DISPL, CW	90-R-055-MS-6-CD-80-P-3-C6-C-06-FAD-45-45-28	SERIES 90	S90-055PV
9421708	PUMP-VAR DISPL, CW	90-R-055-MS-6-BG-80-P-3-S1-C-03-FAD-45-45-28	SERIES 90	S90-055PV
9421709	PUMP-VAR DISPL, CW	90-R-055-MB-1-BC-60-R-3-C6-D-03-GBA-38-38-24	SERIES 90	S90-055PV
9421709C	PUMP-VAR-DISPL CW 90PV055	90-R-055-MB-1-BC-60-R-3-C6-D-03-GBA-38-38-24	SERIES 90	S90-055PV
9421710	PUMP-VAR DISPL, CW	90-R-055-MA-1-AB-60-S-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-055PV
9421711	PUMP-VAR DISPL, CW	90-R-055-KA-1-NN-80-P-3-K1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
9421712	PUMP-VAR DISPL, CW	90-R-055-MA-1-NN-60-S-3-S1-D-03-GBA-29-29-24	SERIES 90	S90-055PV
9421713	PUMP-VAR DISPL, CW	90-R-055-MB-1-BC-60-L-3-C6-C-03-GBA-42-42-20	SERIES 90	S90-055PV
9421716	PUMP-VAR DISPL, CW	90-R-055-KA-1-CD-80-R-3-S1-C-03-GBA-23-23-24	SERIES 90	S90-055PV
9421717	PUMP-VAR DISPL, CW	90-R-055-MA-1-BK-80-S-3-S1-C-03-GBA-32-32-24	SERIES 90	S90-055PV

9421718	PUMP-VAR DISPL, CW	90-R-055-HF-1-BK-80-S-3-S1-C-03-GBA-32-32-24	SERIES 90	S90-055PV
9421719	PUMP-VAR DISPL, CW	90-R-055-MA-1-AD-80-S-3-S1-C-03-GBA-32-32-24	SERIES 90	S90-055PV
9421720	PUMP-VAR DISPL, CW	90-R-055-HF-1-CD-80-P-4-S1-C-01-GBA-26-26-20	SERIES 90	S90-055PV
9421721	PUMP-VAR DISPL, CW	90-R-055-KP-1-NN-60-P-3-S1-C-03-GBA-32-32-24	SERIES 90	S90-055PV
9421722	PUMP-VAR DISPL, CW	90-R-055-KA-1-CD-80-S-4-S1-C-02-GBA-26-26-24	SERIES 90	S90-055PV
9421723	PUMP-VAR DISPL, CW	90-R-055-KA-1-NN-80-S-4-S1-C-02-GBA-26-26-24	SERIES 90	S90-055PV
9421724	PUMP-VAR-DISPL CW 90PV055	90-R-055-KA-1-AD-80-S-3-C6-C-06-FAD-29-29-20	SERIES 90	S90-055PV
9421725	PUMP-VAR-DISPL CW 90PV055	90-R-055-KA-1-NN-60-P-3-T1-C-03-EBC-38-14-24	SERIES 90	S90-055PV
9421726	PUMP-VAR DISPL, CW	90-R-055-HF-1-NN-80-R-4-T1-C-03-GBA-29-29-24	SERIES 90	S90-055PV
9421727	PUMP-VAR DISPL, CW	90-R-055-KP-1-CD-80-L-3-S1-C-03-GBA-32-32-24	SERIES 90	S90-055PV
9421728	PUMP-VAR DISPL, CW	90-R-055-KP-1-AD-80-L-3-S1-C-03-GBA-32-32-24	SERIES 90	S90-055PV
9421729	PUMP-VAR DISPL, CW	90-R-055-MB-1-BC-60-L-4-C6-C-03-GBA-42-42-20	SERIES 90	S90-055PV
9421730	PUMP-VAR DISPL, CW	90-R-055-KA-1-BG-80-R-3-C6-C-05-FAB-35-35-24	SERIES 90	S90-055PV
9421731	PUMP-VAR DISPL, CW	90-R-055-EA-1-NN-80-P-3-S1-D-00-GBA-38-38-24	SERIES 90	S90-055PV
9421732	PUMP-VAR DISPL, CW	90-R-055-EA-1-CD-80-P-3-S1-D-00-GBA-38-38-24	SERIES 90	S90-055PV
9421733	PUMP-VAR-DISPL CW 90PV055	90-R-055-KA-1-BG-80-S-3-C6-C-03-GBA-42-42-24	SERIES 90	S90-055PV
9421734	PUMP-VAR DISPL, CW 90PV055	90-R-055-KA-1-NN-80-S-3-C6-C-03-GBA-42-42-24	SERIES 90	S90-055PV
9421735	PUMP-VAR DISPL, CW	90-R-055-DC-1-NN-60-S-4-S1-C-GJ-GBA-29-29-24	SERIES 90	S90-055PV
9421736	PUMP-VAR-DISPL CW 90PV055	90-R-055-FC-2-BC-60-P-7-C6-D-B1-GLA-45-45-30	SERIES 90	S90-055PV
9421737	PUMP-VAR DISPL, CW	90-R-055-KA-1-CD-80-P-3-S1-D-00-GBA-42-42-24	SERIES 90	S90-055PV
9421738	PUMP-VAR DISPL, CW	90-R-055-KA-1-CD-80-P-3-S1-D-00-GBA-29-29-24	SERIES 90	S90-055PV
9421739	PUMP-VAR DISPL, CW	90-R-055-KA-1-CD-80-P-3-S1-D-00-GBA-29-23-24	SERIES 90	S90-055PV
9421740	PUMP-VAR DISPL, CW	90-R-055-FC-6-NN-60-S-7-C6-C-B1-EFI-45-45-30	SERIES 90	S90-055PV
9421741	PUMP-VAR DISPL, CW	90-R-055-M1-2-CD-60-X-3-C6-D-03-GBA-35-35-24	SERIES 90	S90-055PV
9421742	PUMP-VAR DISPL, CW	90-R-055-M1-2-NN-60-X-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-055PV
9421743	PUMP-VAR DISPL, CW	90-R-055-M1-2-BC-60-X-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-055PV
9421745	PUMP-VAR DISPL, CW	90-R-055-KP-2-AD-80-S-3-T1-D-05-GBA-42-42-24	SERIES 90	S90-055PV
9421745C	PUMP-VAR-DISPL CW 90PV055	90-R-055-KP-2-AD-80-S-3-T1-D-05-GBA-42-42-24	SERIES 90	S90-055PV
9421747	PUMP-VAR-DISPL CW 90PV055	90-R-055-DC-F-NN-80-D-N-S1-L-Z1-FAD-40-40-24	SERIES 90	S90-055PV
9421748	PUMP-VAR DISPL, CW	90-R-055-KA-1-CD-80-P-3-S1-C-00-GBA-42-42-24	SERIES 90	S90-055PV
9421749	PUMP-VAR DISPL, CW	90-R-055-KA-1-CD-60-S-3-S1-C-03-GBA-23-23-24	SERIES 90	S90-055PV
9421750	PUMP-VAR DISPL, CW	90-R-055-KA-1-BC-60-S-3-S1-C-03-GBA-23-23-24	SERIES 90	S90-055PV
9421752	PUMP-VAR DISPL, CW	90-R-055-FC-7-NN-80-R-7-S1-C-B1-EFI-48-48-28	SERIES 90	S90-055PV
9421753	PUMP-VAR DISPL, CW	90-R-055-KP-1-NN-80-R-4-S1-C-00-GBA-35-35-24	SERIES 90	S90-055PV
9421754	PUMP-VAR DISPL, CW	90-R-055-EA-1-AB-60-P-3-S1-C-00-GBA-26-26-24	SERIES 90	S90-055PV
9421755	PUMP-VAR DISPL, CW	90-R-055-MV-B-BK-80-S-3-S1-C-03-GBA-32-42-24	SERIES 90	S90-055PV

9421756	PUMP-VAR DISPL, CW	90-R-055-KA-1-CD-60-R-3-S1-C-03-GBA-20-20-24	SERIES 90	S90-055PV
9421757	PUMP-VAR DISPL, CW	90-R-055-KA-1-NN-60-R-3-S1-D-03-EEB-20-20-24	SERIES 90	S90-055PV
9421758	PUMP-VAR-DISPL CW 90PV055	90-R-055-KA-1-NN-60-R-3-C6-C-05-FAD-38-38-24-P020	SERIES 90	S90-055PV
9421760	PUMP-VAR-DISPL CW 90PV055	90-R-055-MA-1-AB-60-S-3-C6-C-04-GBA-42-42-28	SERIES 90	S90-055PV
9421761	PUMP-VAR DISPL, CW	90-R-055-DC-1-AD-81-S-4-C6-C-G1-GBA-17-17-24	SERIES 90	S90-055PV
9421762	PUMP-VAR DISPL, CW	90-R-055-KP-1-AD-80-S-4-C6-C-00-GBA-17-17-24	SERIES 90	S90-055PV
9421763	PUMP-VAR DISPL, CW	90-R-055-KA-1-CD-60-S-3-S1-C-03-EBC-23-23-24	SERIES 90	S90-055PV
9421764	PUMP-VAR DISPL, CW	90-R-055-KA-1-NN-60-L-4-S1-C-03-GBA-20-20-24	SERIES 90	S90-055PV
9421765	PUMP-VAR-DISPL CW 90PV055	90-R-055-DD-1-NN-80-D-4-S1-L-Z1-FAD-40-40-28	SERIES 90	S90-055PV
9421766	PUMP-VAR DISPL, CW	90-R-055-KP-1-AB-60-L-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
9421767	PUMP-VAR DISPL, CW	90-R-055-KP-1-BG-80-P-4-S1-C-03-GBA-29-29-24	SERIES 90	S90-055PV
9421768	PUMP-VAR DISPL, CW	90-R-055-KA-1-NN-60-S-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
9421769	PUMP-VAR DISPL, CW	90-R-055-DC-1-NN-80-R-4-S1-B-G8-GBA-42-42-24	SERIES 90	S90-055PV
9421770	PUMP-VAR DISPL, CW	90-R-055-KP-1-CD-80-R-3-S1-C-03-GBA-29-35-24	SERIES 90	S90-055PV
9421771	PUMP-VAR DISPL, CW	90-R-055-KP-1-CD-80-R-4-S1-C-03-GBA-35-14-24	SERIES 90	S90-055PV
9421772	PUMP-VAR DISPL, CW	90-R-055-KP-1-NN-80-R-4-S1-C-03-GBA-29-29-24	SERIES 90	S90-055PV
9421773	PUMP-VAR DISPL, CW	90-R-055-KP-1-NN-82-R-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9421774	PUMP-VAR DISPL, CW	90-R-055-KP-1-CD-80-P-3-C6-C-00-GBA-32-32-24	SERIES 90	S90-055PV
9421775	PUMP-VAR DISPL, CW	90-R-055-KP-1-BG-80-P-3-S1-C-00-GBA-32-32-24	SERIES 90	S90-055PV
9421776	PUMP-VAR DISPL, CW	90-R-055-KA-1-AB-60-S-3-S1-C-02-GBA-35-35-24	SERIES 90	S90-055PV
9421777	PUMP-VAR DISPL, CW	90-R-055-KA-1-CD-60-L-3-S1-C-03-GBA-23-23-24	SERIES 90	S90-055PV
9421778	PUMP-VAR DISPL, CW	90-R-055-KA-1-NN-60-L-3-S1-C-03-GBA-23-23-24	SERIES 90	S90-055PV
9421779	PUMP-VAR DISPL, CW	90-R-055-KP-1-CD-80-P-3-S1-C-00-GBA-42-42-24	SERIES 90	S90-055PV
9421780	PUMP-VAR-DISPL CW 90PV055	90-R-055-KA-1-BG-80-S-3-C6-C-03-EHA-42-42-24	SERIES 90	S90-055PV
9421782	PUMP-VAR-DISPL CW 90PV055	90-R-055-MA-1-NN-80-P-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
9421783	PUMP-VAR-DISPL CW 90PV055	90-R-055-RU-1-BB-60-D-3-S1-L-A7-FBG-38-38-20	SERIES 90	S90-055PV
9421784	PUMP-VAR-DISPL CW 90PV055	90-R-055-KA-1-BG-80-S-3-C6-C-35-GBA-42-42-20	SERIES 90	S90-055PV
9421785	PUMP-VAR DISPL, CW	90-R-055-KP-1-BG-80-R-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
9421786	PUMP-VAR-DISPL CW 90PV055	90-R-055-MA-1-NN-80-S-3-C6-C-03-GBA-42-42-24	SERIES 90	S90-055PV
9421787	PUMP-VAR DISPL, CW	90-R-055-MA-1-CD-80-P-3-C6-D-03-GBA-38-38-24	SERIES 90	S90-055PV
9421788	PUMP-VAR DISPL, CW	90-R-055-MA-1-CD-80-P-3-S1-D-03-GBA-38-38-24	SERIES 90	S90-055PV
9421789	PUMP-VAR DISPL, CW	90-R-055-KP-1-AF-80-L-3-S1-C-03-EHA-42-42-24	SERIES 90	S90-055PV
9421790	PUMP-VAR DISPL, CW	90-R-055-KP-B-CD-80-P-4-S1-C-00-EBC-35-35-24	SERIES 90	S90-055PV
9421791	PUMP-VAR DISPL, CW	90-R-055-KA-1-CD-80-6-3-S1-C-03-GBA-20-20-34-N270	SERIES 90	S90-055PV
9421794	PUMP-VAR-DISPL CW 90PV055	90-R-055-KA-5-NN-80-R-3-S1-D-05-FAP-35-35-30	SERIES 90	S90-055PV
9421795	PUMP-VAR DISPL, CW	90-R-055-KP-1-CD-60-P-4-S1-C-00-EBC-35-35-24	SERIES 90	S90-055PV

9421796	PUMP-VAR DISPL, CW	90-R-055-KP-1-NN-80-P-4-S1-C-00-EBC-35-35-24	SERIES 90	S90-055PV
9421797	PUMP-VAR DISPL, CW	90-R-055-KP-1-BG-80-S-3-S1-C-03-GBA-32-32-24	SERIES 90	S90-055PV
9421799	PUMP-VAR-DISPL CW 90PV055	90-R-055-KA-5-NN-80-S-3-C6-C-03-GBA-42-42-24	SERIES 90	S90-055PV
9421800	PUMP-VAR-DISPL CW 90PV055	90-R-055-KA-5-BG-80-S-3-C6-C-03-EHA-42-42-24	SERIES 90	S90-055PV
9421802	PUMP-VAR DISPL, CW	90-R-055-MS-2-BK-80-R-1-S1-D-03-GBA-42-23-20	SERIES 90	S90-055PV
9421803	PUMP-VAR DISPL, CW	90-R-055-KP-1-BG-80-R-4-S1-C-04-GBA-26-26-20	SERIES 90	S90-055PV
9421804	PUMP-VAR DISPL, CW	90-R-055-KA-1-BG-80-D-3-S1-L-00-GBA-45-45-24	SERIES 90	S90-055PV
9421805	PUMP-VAR DISPL, CW	90-R-055-MA-1-BK-80-S-3-S1-D-03-GBA-32-32-24	SERIES 90	S90-055PV
9421806	PUMP-VAR DISPL, CW	90-R-055-HS-1-BK-80-S-3-S1-D-03-GBA-32-32-24	SERIES 90	S90-055PV
9421807	PUMP-VAR DISPL, CW	90-R-055-KP-1-NN-80-D-4-S1-L-03-GBA-42-42-20-F062	SERIES 90	S90-055PV
9421808	PUMP-VAR DISPL, CW	90-R-055-KA-H-NN-80-6-3-S1-D-03-EEB-AA-42-24-N270	SERIES 90	S90-055PV
9421809	PUMP-VAR DISPL, CW	90-R-055-KP-G-BC-60-P-3-S1-D-03-GBA-32-32-24	SERIES 90	S90-055PV
9421810	PUMP-VAR DISPL, CW	90-R-055-KA-1-BG-80-P-4-S1-C-03-GBA-38-38-24	SERIES 90	S90-055PV
9421811	PUMP-VAR DISPL, CW	90-R-055-KP-1-BG-80-L-3-S1-D-03-EBC-42-42-24	SERIES 90	S90-055PV
9421812	PUMP-VAR DISPL, CW	90-R-055-KP-1-NN-60-S-3-S1-C-00-GBA-17-17-20	SERIES 90	S90-055PV
9421813	PUMP-VAR DISPL, CW	90-R-055-MV-1-CD-80-L-3-C6-C-03-GBA-38-38-24	SERIES 90	S90-055PV
9421814	PUMP-VAR DISPL, CW	90-R-055-MA-1-BG-80-L-3-S1-C-03-GBA-38-38-24	SERIES 90	S90-055PV
9421815	PUMP-VAR DISPL, CW	90-R-055-KP-1-CD-80-P-4-S1-C-03-GBA-35-14-24	SERIES 90	S90-055PV
9421816	PUMP-VAR DISPL, CW	90-R-055-KP-1-NN-80-P-4-S1-C-03-GBA-29-29-24	SERIES 90	S90-055PV
9421817	PUMP-VAR DISPL, CW	90-R-055-KP-2-NN-60-S-3-S1-C-33-GBA-17-17-20	SERIES 90	S90-055PV
9421818	PUMP-VAR DISPL, CW	90-R-055-KP-1-BC-60-L-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9421819	PUMP-VAR DISPL, CW	90-R-055-MA-1-NN-60-S-3-C6-C-03-GBA-35-35-20	SERIES 90	S90-055PV
9421821	PUMP-VAR-DISPL CW 90PV055	90-R-055-KA-5-NN-60-D-3-S1-L-03-GBA-42-42-24	SERIES 90	S90-055PV
9421823	PUMP-VAR DISPL, CW	90-R-055-MC-1-BC-61-S-3-S1-D-02-GBA-23-23-20	SERIES 90	S90-055PV
9421824	PUMP-VAR DISPL, CW	90-R-055-KA-1-NN-60-S-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9421825	PUMP-VAR DISPL, CW	90-R-055-KA-H-NN-80-6-3-S1-D-03-EEB-AB-42-24-N270	SERIES 90	S90-055PV
9421826	PUMP-VAR DISPL, CW	90-R-055-KA-1-BG-80-R-4-S1-C-04-GBA-26-26-20	SERIES 90	S90-055PV
9421827	PUMP-VAR-DISPL CW 90PV055	90-R-055-KA-5-BC-60-D-3-C6-L-03-GBA-35-35-24	SERIES 90	S90-055PV
9421828	PUMP-VAR DISPL, CW	90-R-055-KP-1-CD-80-P-3-S1-C-00-GBA-29-17-24	SERIES 90	S90-055PV
9421829	PUMP-VAR DISPL, CW	90-R-055-DC-1-NN-60-S-3-S1-D-GB-GBA-42-42-24	SERIES 90	S90-055PV
9421831	PUMP-VAR DISPL, CW	90-R-055-KP-1-AB-60-L-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9421833	PUMP-VAR DISPL, CW	90-R-055-KP-1-BG-80-S-4-C6-C-03-GBA-42-42-24	SERIES 90	S90-055PV
9421834	PUMP-VAR DISPL, CW	90-R-055-KA-1-NN-60-L-3-S1-C-03-EBC-35-35-20	SERIES 90	S90-055PV
9421835	PUMP-VAR DISPL, CW	90-R-055-KA-1-CD-80-P-4-S1-C-02-GBA-26-26-20	SERIES 90	S90-055PV
9421837	PUMP-VAR DISPL, CW	90-R-055-KP-1-BC-60-P-4-S1-C-03-GBA-23-23-24	SERIES 90	S90-055PV
9421838	PUMP-VAR DISPL, CW	90-R-055-KP-1-CD-60-P-4-S1-C-03-GBA-23-23-24	SERIES 90	S90-055PV

9421839	PUMP-VAR DISPL, CW	90-R-055-DC-1-NN-60-S-4-S1-C-G1-GBA-32-32-24	SERIES 90	S90-055PV
9421840	PUMP-VAR DISPL, CW	90-R-055-KA-1-AC-60-P-4-S1-C-03-GBA-17-17-20	SERIES 90	S90-055PV
9421841	PUMP-VAR DISPL, CW	90-R-055-KA-1-AB-60-P-4-S1-C-03-GBA-17-17-20	SERIES 90	S90-055PV
9421842	PUMP-VAR DISPL, CW	90-R-055-MB-1-BC-60-S-3-S1-D-03-FAC-42-42-24	SERIES 90	S90-055PV
9421843	PUMP-VAR DISPL, CW	90-R-055-DC-1-BG-80-P-3-S1-D-GB-GBA-35-35-24	SERIES 90	S90-055PV
9421844	PUMP-VAR DISPL, CW	90-R-055-KP-1-NN-60-R-4-S1-C-03-GBA-23-23-24	SERIES 90	S90-055PV
9421845	PUMP-VAR DISPL, CW	90-R-055-KP-1-NN-60-R-4-S1-C-03-GBA-23-23-20	SERIES 90	S90-055PV
9421846	PUMP-VAR DISPL, CW	90-R-055-KP-1-NN-60-P-3-S1-D-03-GBA-32-32-24	SERIES 90	S90-055PV
9421848	PUMP-VAR DISPL, CW	90-R-055-MA-1-AB-60-S-3-S1-C-02-GBA-42-42-24	SERIES 90	S90-055PV
9421848C	PUMP-VAR-DISPL CW 90PV055	90-R-055-MA-1-AB-60-S-3-S1-C-02-GBA-42-42-24	SERIES 90	S90-055PV
9421849	PUMP-VAR DISPL, CW	90-R-055-HK-2-BB-60-R-3-S1-C-02-GBA-42-42-24	SERIES 90	S90-055PV
9421850	PUMP-VAR DISPL, CW	90-R-055-KP-2-NN-80-S-3-S1-C-03-GBA-26-26-24	SERIES 90	S90-055PV
9421851	PUMP-VAR DISPL, CW	90-R-055-KP-1-NN-80-P-3-C6-C-03-GBA-32-32-20	SERIES 90	S90-055PV
9421852	PUMP-VAR DISPL, CW	90-R-055-MA-2-NN-80-P-4-S1-C-03-GBA-20-20-24	SERIES 90	S90-055PV
9421853	PUMP-VAR-DISPL CW 90PV055	90-R-055-KA-5-NN-80-P-3-T1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
9421854	PUMP-VAR-DISPL CW 90PV055	90-R-055-DD-5-BG-80-P-3-T1-C-GB-GBA-42-42-24	SERIES 90	S90-055PV
9421855	PUMP-VAR-DISPL CW 90PV055	90-R-055-KA-5-BC-60-P-3-S1-C-04-GBA-42-42-20	SERIES 90	S90-055PV
9421856	PUMP-VAR-DISPL CW 90PV055	90-R-055-FC-6-AB-60-S-7-C6-C-B1-EFI-48-48-32	SERIES 90	S90-055PV
9421857	PUMP-VAR DISPL, CW	90-R-055-KP-1-BG-80-R-4-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
9421858	PUMP-VAR DISPL, CW	90-R-055-MB-1-AD-80-P-3-C6-C-03-GBA-14-14-24	SERIES 90	S90-055PV
9421859	PUMP-VAR-DISPL CW 90PV055	90-R-055-MB-5-NN-80-P-3-C6-C-C5-GBA-42-42-24	SERIES 90	S90-055PV
9421860	PUMP-VAR DISPL, CW	90-R-055-KP-1-BG-80-P-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9421861	PUMP-VAR-DISPL CW 90PV055	90-R-055-KA-5-BC-60-S-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-055PV
9421862	PUMP-VAR DISPL, CW	90-R-055-MB-1-AD-80-R-3-S1-C-03-GBA-23-23-24	SERIES 90	S90-055PV
9421863	PUMP-VAR DISPL, CW	90-R-055-MA-1-AD-80-P-3-S1-C-03-GBA-29-29-28	SERIES 90	S90-055PV
9421864	PUMP-VAR-DISPL CW 90PV055	90-R-055-MB-5-CD-80-R-3-S1-D-C5-GBA-35-35-24	SERIES 90	S90-055PV
9421865	PUMP-VAR DISPL, CW	90-R-055-LE-B-BK-80-S-3-S1-C-03-GBA-32-42-24	SERIES 90	S90-055PV
9421866	PUMP-VAR DISPL, CW	90-R-055-KP-1-BG-80-S-4-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
9421867	PUMP-VAR-DISPL CW 90PV055	90-R-055-DC-5-BC-60-S-4-S1-C-07-GBG-42-42-24	SERIES 90	S90-055PV
9421868	PUMP-VAR DISPL, CW	90-R-055-MD-1-CD-80-P-3-C6-C-02-GBA-38-38-24	SERIES 90	S90-055PV
9421869	PUMP-VAR DISPL, CW	90-R-055-MA-1-CD-80-P-3-S1-C-02-GBA-38-38-24	SERIES 90	S90-055PV
9421870	PUMP-VAR DISPL, CW	90-R-055-MA-1-AD-80-P-3-S1-C-03-GBA-29-29-24	SERIES 90	S90-055PV
9421871	PUMP-VAR-DISPL CW 90PV055	90-R-055-KA-5-NN-80-S-3-S1-D-05-FAP-35-35-42	SERIES 90	S90-055PV
9421872	PUMP-VAR-DISPL CW 90PV055	90-R-055-KA-5-BK-80-P-3-S1-C-05-GBA-20-20-24	SERIES 90	S90-055PV
9421873	PUMP-VAR DISPL, CW	90-R-055-KP-1-AD-80-R-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-055PV
9421874	PUMP-VAR DISPL, CW	90-R-055-MT-5-BC-61-S-3-S1-D-02-GBA-23-23-28	SERIES 90	S90-055PV

9421875	PUMP-VAR DISPL, CW	90-R-055-KA-1-BG-80-P-4-S1-C-02-GBA-26-26-24	SERIES 90	S90-055PV
9421876	PUMP-VAR DISPL, CW	90-R-055-MA-5-NN-80-S-3-S1-C-39-GBA-42-42-24	SERIES 90	S90-055PV
9421877	PUMP-VAR DISPL, CW	90-R-055-KP-5-NN-80-S-3-S1-C-39-GBA-42-42-24	SERIES 90	S90-055PV
9421878	PUMP-VAR DISPL, CW	90-R-055-KP-5-CD-60-L-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9421879	PUMP-VAR DISPL, CW	90-R-055-KP-5-NN-60-L-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9421880	PUMP-VAR DISPL, CW	90-R-055-KP-1-NN-80-S-4-S1-C-03-GBA-32-32-24	SERIES 90	S90-055PV
9421881	PUMP-VAR DISPL, CW	90-R-055-MV-1-BK-80-R-3-S1-B-26-GBA-42-42-24	SERIES 90	S90-055PV
9421882	PUMP-VAR DISPL, CW - DIST BASE MODEL	90-R-055-CB-1-NN-60-S-4-C6-C-00-GBA-35-35-24	SERIES 90	S90-055PV
9421883	PUMP-VAR DISPL, CW - DIST BASE MODEL	90-R-055-CB-1-NN-60-S-4-S1-C-00-GBA-35-35-24-P000	SERIES 90	S90-055PV
9421884	PUMP-VAR DISPL, CW - DIST BASE MODEL	90-R-055-CB-1-NN-80-S-4-S1-C-00-GBA-35-35-24-P000	SERIES 90	S90-055PV
9421885	PUMP-VAR DISPL, CW - DIST BASE MODEL	90-R-055-CB-1-NN-80-S-4-C6-C-00-GBA-35-35-24	SERIES 90	S90-055PV
9421886	PUMP-VAR DISPL, CW	90-R-055-KP-1-BC-60-S-3-S1-D-03-EAB-42-42-24	SERIES 90	S90-055PV
9421887	PUMP-VAR-DISPL CW 90PV055	90-R-055-HF-5-AB-60-S-4-C6-C-03-GBA-23-23-24	SERIES 90	S90-055PV
9421888	PUMP-VAR-DISPL CW 90PV055	90-R-055-DC-5-BC-60-S-4-S1-D-G8-GBG-42-42-24	SERIES 90	S90-055PV
9421889	PUMP-VAR DISPL, CW	90-R-055-KP-1-CD-60-P-3-K1-D-03-GBA-29-29-24	SERIES 90	S90-055PV
9421890	PUMP-VAR DISPL, CW	90-R-055-EA-1-BG-80-S-3-C6-B-35-GBA-42-42-24	SERIES 90	S90-055PV
9421891	PUMP-VAR DISPL, CW	90-R-055-KP-1-AF-80-P-3-S1-C-00-GBA-40-40-24	SERIES 90	S90-055PV
9421892	PUMP-VAR DISPL, CW	90-R-055-KP-1-CD-61-P-4-K1-D-03-GBA-29-29-24	SERIES 90	S90-055PV
9421893	PUMP-VAR DISPL, CW	90-R-055-KP-1-AD-80-R-3-C6-C-00-GBA-42-42-20	SERIES 90	S90-055PV
9421895	PUMP-VAR DISPL, CW	90-R-055-KP-1-CD-80-P-3-K1-C-03-GBA-29-29-24	SERIES 90	S90-055PV
9421896	PUMP-VAR-DISPL CW 90PV055	90-R-055-KA-1-BG-80-S-3-C6-B-35-GBA-42-42-24	SERIES 90	S90-055PV
9421897	PUMP-VAR DISPL, CW	90-R-055-JB-1-BC-60-S-3-C6-C-03-GBA-42-42-20	SERIES 90	S90-055PV
9421898	PUMP-VAR-DISPL CW 90PV055	90-R-055-KA-5-BK-80-D-3-C6-L-30-FAD-40-40-22	SERIES 90	S90-055PV
9421899	PUMP-VAR-DISPL CW 90PV055	90-R-055-FC-2-BC-60-S-7-C6-D-B1-GLA-45-45-30	SERIES 90	S90-055PV
9421961C	PUMP-VAR-DISPL CCW 90PV055	90-L-055-KP-1-BC-60-P-3-S1-C-03-GBA-38-38-24	SERIES 90	S90-055PV
9421962C	PUMP-VAR-DISPL CCW 90PV055	90-L-055-MA-1-AB-60-D-3-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9422000	PUMP-VAR DISPL, CCW	90-L-055-KP-1-NN-80-R-4-C6-C-26-GBA-32-32-24	SERIES 90	S90-055PV
9422001	PUMP-VAR DISPL, CCW	90-L-055-MV-1-CD-80-R-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
9422002	PUMP-VAR DISPL, CCW	90-L-055-MV-1-NN-80-R-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
9422003	PUMP-VAR DISPL, CCW	90-L-055-KP-1-BB-60-R-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9422004	PUMP-VAR DISPL, CCW	90-L-055-KP-1-NN-80-R-4-S1-C-26-GBA-32-32-24	SERIES 90	S90-055PV
9422005	PUMP-VAR DISPL, CCW	90-L-055-MV-1-CD-80-R-3-C6-C-26-GBA-32-32-24	SERIES 90	S90-055PV
9422006	PUMP-VAR DISPL, CCW	90-L-055-MV-1-NN-80-R-3-S1-C-26-GBA-32-32-24	SERIES 90	S90-055PV
9422007	PUMP-VAR-DISPL CCW 90PV055	90-L-055-KA-1-NN-80-S-3-C6-B-35-GBA-42-42-24	SERIES 90	S90-055PV
9422008	PUMP-VAR-DISPL CCW 90PV055	90-L-055-KA-1-AD-80-S-3-C6-B-35-GBA-42-42-24	SERIES 90	S90-055PV
9422009	PUMP-VAR DISPL, CCW	90-L-055-KP-2-CD-80-P-1-S1-C-03-GBA-23-23-24	SERIES 90	S90-055PV

9422010	PUMP-VAR DISPL, CCW	90-L-055-KP-2-NN-80-P-3-S1-C-03-GBA-23-23-24	SERIES 90	S90-055PV
9422011	PUMP-VAR-DISPL CCW 90PV055	90-L-055-KA-2-BC-60-P-4-S1-D-21-GBA-45-32-24	SERIES 90	S90-055PV
9422012	PUMP-VAR DISPL, CCW	90-L-055-EA-1-CD-60-S-4-S1-D-03-GBA-42-42-24	SERIES 90	S90-055PV
9422014	PUMP-VAR DISPL, CCW	90-L-055-KP-1-CD-60-R-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9422015	PUMP-VAR DISPL, CCW	90-L-055-HF-1-CD-80-P-4-S1-C-03-GBA-32-32-24	SERIES 90	S90-055PV
9422016	PUMP-VAR-DISPL CCW 90PV055	90-L-055-KA-5-AB-60-R-4-C6-C-28-FAP-42-35-24	SERIES 90	S90-055PV
9422017	PUMP-VAR DISPL, CCW	90-L-055-KA-1-BG-80-R-4-S1-C-04-GBA-26-26-20	SERIES 90	S90-055PV
9422018	PUMP-VAR-DISPL CCW 90PV055	90-L-055-KA-5-AB-60-S-3-C6-C-04-GBA-35-35-24	SERIES 90	S90-055PV
9422019	PUMP-VAR DISPL, CCW	90-L-055-KP-1-BG-80-S-3-S1-D-03-GBA-23-23-24	SERIES 90	S90-055PV
9422020	PUMP-VAR-DISPL CCW 90PV055	90-L-055-KA-5-BB-60-R-3-C6-C-21-GBA-35-35-24	SERIES 90	S90-055PV
9422021	PUMP-VAR DISPL, CCW	90-L-055-KA-1-NN-80-R-4-S1-D-02-FAD-29-29-24	SERIES 90	S90-055PV
9422022	PUMP-VAR DISPL, CCW	90-L-055-KA-1-CD-80-R-4-C6-D-02-GBA-29-29-24	SERIES 90	S90-055PV
9422023	PUMP-VAR DISPL, CCW	90-L-055-KP-1-BG-80-S-3-S1-C-03-GBA-23-23-24	SERIES 90	S90-055PV
9422024	PUMP-VAR DISPL, CCW	90-L-055-KN-1-NN-60-D-4-S1-L-03-GBA-35-35-28	SERIES 90	S90-055PV
9422025	PUMP-VAR DISPL, CCW	90-L-055-HF-1-BG-81-R-4-S1-C-03-GBA-45-45-24	SERIES 90	S90-055PV
9422026	PUMP-VAR DISPL, CCW	90-L-055-MB-1-CD-60-P-3-C6-D-03-GBA-45-45-24	SERIES 90	S90-055PV
9422027	PUMP-VAR DISPL, CCW	90-L-055-KP-1-CD-81-P-3-S1-C-03-GBA-35-35-20	SERIES 90	S90-055PV
9422028	PUMP-VAR DISPL, CCW	90-L-055-KP-1-NN-81-P-3-S1-C-03-GBA-35-35-20	SERIES 90	S90-055PV
9422029	PUMP-VAR-DISPL CCW 90PV055	90-L-055-KA-5-NN-60-L-3-C6-C-03-GBA-35-35-20	SERIES 90	S90-055PV
9422031	PUMP-VAR DISPL, CCW	90-L-055-MC-1-BK-80-R-3-S1-C-02-GBA-32-17-24	SERIES 90	S90-055PV
9422032	PUMP-VAR DISPL, CCW	90-L-055-KA-1-NN-80-R-4-S1-D-01-FAD-29-29-24	SERIES 90	S90-055PV
9422033	PUMP-VAR DISPL, CCW	90-L-055-MA-1-NN-80-P-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
9422034	PUMP-VAR-DISPL CCW 90PV055	90-L-055-KA-5-BB-60-P-3-S1-D-02-GBA-26-26-18	SERIES 90	S90-055PV
9422035	PUMP-VAR DISPL, CCW	90-L-055-MA-1-BK-80-R-3-S1-C-00-GBA-35-35-24	SERIES 90	S90-055PV
9422036	PUMP-VAR DISPL, CCW	90-L-055-KP-1-NN-80-S-4-S1-D-02-GBA-26-26-24	SERIES 90	S90-055PV
9422037	PUMP-VAR DISPL, CCW	90-L-055-KP-1-BG-80-R-4-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
9422038	PUMP-VAR DISPL, CCW	90-L-055-MB-1-CD-80-S-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-055PV
9422039	PUMP-VAR DISPL, CCW	90-L-055-MB-1-NN-80-S-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-055PV
9422040	PUMP-VAR DISPL, CCW	90-L-055-MC-1-NN-80-S-3-S1-C-02-GBA-42-42-24	SERIES 90	S90-055PV
9422041	PUMP-VAR DISPL, CCW	90-L-055-MC-1-CD-80-S-3-S1-C-02-GBA-42-42-24	SERIES 90	S90-055PV
9422042	PUMP-VAR DISPL, CCW	90-L-055-KA-1-NN-80-R-4-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
9422043	PUMP-VAR DISPL, CCW	90-L-055-KA-1-AB-60-P-4-S1-C-03-GBA-29-29-24	SERIES 90	S90-055PV
9422044	PUMP-VAR DISPL, CCW	90-L-055-KP-5-CD-80-L-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-055PV
9422045	PUMP-VAR DISPL, CCW	90-L-055-KP-5-BC-60-S-3-S1-C-01-GBA-42-42-24	SERIES 90	S90-055PV
9422046	PUMP-VAR-DISPL CCW 90PV055	90-L-055-KA-5-BK-80-P-3-S1-C-02-GBA-35-35-24	SERIES 90	S90-055PV
9422047	PUMP-VAR DISPL, CCW	90-L-055-CA-1-NN-80-S-3-S1-D-00-GBA-14-14-24	SERIES 90	S90-055PV

9422048	PUMP-VAR DISPL, CCW	90-L-055-HS-1-CD-60-L-3-S1-D-02-GBA-42-42-24	SERIES 90	S90-055PV
9422049	PUMP-VAR DISPL, CCW	90-L-055-HS-1-CD-80-L-3-S1-D-02-GBA-42-42-24	SERIES 90	S90-055PV
9422050	PUMP-VAR DISPL, CCW	90-L-055-HS-1-CD-80-L-3-S1-C-02-GBA-42-42-24	SERIES 90	S90-055PV
9422051	PUMP-VAR DISPL, CCW	90-L-055-MA-5-NN-60-S-3-S1-D-00-GBA-45-45-24	SERIES 90	S90-055PV
9422053	PUMP-VAR DISPL, CCW	90-L-055-KP-1-BC-60-R-3-S1-D-03-GBA-32-32-24	SERIES 90	S90-055PV
9422054	PUMP-VAR DISPL, CCW	90-L-055-DC-1-NN-80-L-3-S1-C-G8-GBA-38-38-24	SERIES 90	S90-055PV
9422055	PUMP-VAR DISPL, CCW	90-L-055-KP-1-NN-60-S-3-C6-C-03-GBA-40-40-24	SERIES 90	S90-055PV
9422056	PUMP-VAR DISPL, CCW	90-L-055-KA-1-BC-60-S-3-S1-C-00-GBA-29-29-24	SERIES 90	S90-055PV
9422057	PUMP-VAR DISPL, CCW	90-L-055-KP-1-CD-60-P-3-S1-D-03-GBA-17-17-24	SERIES 90	S90-055PV
9422058	PUMP-VAR DISPL, CCW	90-L-055-KP-1-CD-60-P-3-S1-D-03-GBA-29-29-24	SERIES 90	S90-055PV
9422060	PUMP-VAR-DISPL CCW 90PV055	90-L-055-KA-5-NN-60-P-3-S1-D-02-GBA-29-29-24	SERIES 90	S90-055PV
9422061	PUMP-VAR DISPL, CCW - DIST BASE MODEL	90-L-055-CB-1-NN-60-S-4-S1-C-00-GBA-35-35-24-P000	SERIES 90	S90-055PV
9422062	PUMP-VAR DISPL, CCW - DIST BASE MODEL	90-L-055-CB-1-NN-60-S-4-C6-C-00-GBA-35-35-24	SERIES 90	S90-055PV
9422063	PUMP-VAR DISPL, CCW 90PV055	90-L-055-CB-1-NN-80-S-4-S1-C-00-GBA-35-35-24-P000	SERIES 90	S90-055PV
9422064	PUMP-VAR DISPL, CCW - DIST BASE MODEL	90-L-055-CB-1-NN-80-S-4-C6-C-00-GBA-35-35-24-P000	SERIES 90	S90-055PV
9422065	PUMP-VAR DISPL, CCW	90-L-055-KP-5-CD-80-P-3-C6-C-00-GBA-32-32-24	SERIES 90	S90-055PV
9422066	PUMP-VAR DISPL, CCW	90-L-055-KP-5-CD-80-P-3-S1-C-00-GBA-32-32-24	SERIES 90	S90-055PV
9422069	PUMP-VAR-DISPL CCW 90PV055	90-L-055-KA-1-BG-80-D-3-C6-L-06-FAD-29-29-20	SERIES 90	S90-055PV
9422070	PUMP-VAR DISPL, CCW	90-L-055-KA-1-AB-60-L-3-C6-C-03-GBA-38-38-24	SERIES 90	S90-055PV
9422071	PUMP-VAR DISPL, CCW	90-L-055-KA-1-CD-60-L-3-C6-C-03-GBA-38-38-24	SERIES 90	S90-055PV
9422072	PUMP-VAR DISPL, CCW	90-L-055-HS-1-CD-80-P-4-S1-C-02-GBA-42-42-20	SERIES 90	S90-055PV
9422073	PUMP-VAR DISPL, CCW	90-L-055-DC-1-NN-80-P-3-S1-C-G8-GBA-42-42-20	SERIES 90	S90-055PV
9422074	PUMP-VAR DISPL, CCW	90-L-055-MA-7-AB-60-P-3-S1-C-03-GBA-45-45-20	SERIES 90	S90-055PV
9422075	PUMP-VAR DISPL, CCW	90-L-055-DC-1-CD-80-S-4-S1-C-G8-GBA-32-32-24	SERIES 90	S90-055PV
9422076	PUMP-VAR DISPL, CCW	90-L-055-KA-1-AB-60-S-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9422077	PUMP-VAR DISPL, CCW	90-L-055-HF-1-BG-80-S-3-C6-C-03-GBA-42-42-28	SERIES 90	S90-055PV
9422078	PUMP-VAR DISPL, CCW	90-L-055-KP-1-AD-80-P-3-S1-C-03-GBA-38-38-24	SERIES 90	S90-055PV
9422079	PUMP-VAR DISPL, CCW	90-L-055-HF-1-CD-60-S-3-S1-C-03-GBA-20-20-24	SERIES 90	S90-055PV
9422080	PUMP-VAR DISPL, CCW	90-L-055-HF-1-NN-60-S-3-S1-C-03-GBA-20-20-24	SERIES 90	S90-055PV
9422081	PUMP-VAR DISPL, CCW	90-L-055-KA-1-AB-60-R-4-S1-C-03-GBA-29-29-24	SERIES 90	S90-055PV
9422082	PUMP-VAR DISPL, CCW	90-L-055-HM-6-NN-60-S-4-S1-B-02-GBA-48-48-24-F027	SERIES 90	S90-055PV
9422083	PUMP-VAR DISPL, CCW	90-L-055-KP-1-BG-80-S-4-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
9422087	PUMP-VAR DISPL, CCW	90-L-055-KP-1-BG-80-L-4-S1-C-03-GBA-20-20-24	SERIES 90	S90-055PV
9422088	PUMP-VAR DISPL, CCW	90-L-055-KP-1-CD-80-L-4-S1-C-03-GBA-20-20-24	SERIES 90	S90-055PV
9422089	PUMP-VAR DISPL, CCW	90-L-055-KP-1-NN-80-L-4-S1-C-03-GBA-20-20-24	SERIES 90	S90-055PV
9422090	PUMP-VAR-DISPL CCW 90PV055	90-L-055-KA-1-CD-80-L-3-S1-C-03-GBA-32-32-24	SERIES 90	S90-055PV

9422091	PUMP-VAR DISPL, CCW	90-L-055-KA-1-AB-60-R-4-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9422092	PUMP-VAR-DISPL CCW 90PV055	90-L-055-KA-1-NN-60-S-3-S1-B-03-GBA-32-20-24	SERIES 90	S90-055PV
9422094	PUMP-VAR DISPL, CCW	90-L-055-EA-1-AD-80-R-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-055PV
9422095	PUMP-VAR DISPL, CCW	90-L-055-KP-1-NN-80-P-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-055PV
9422096	PUMP-VAR DISPL, CCW	90-L-055-KA-1-NN-60-R-3-S1-C-05-GBA-42-42-24	SERIES 90	S90-055PV
9422097	PUMP-VAR DISPL, CCW	90-L-055-DC-1-NN-80-P-3-S1-C-50-GBA-42-42-20	SERIES 90	S90-055PV
9422098	PUMP-VAR DISPL, CCW	90-L-055-KP-1-NN-80-S-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9422099	PUMP-VAR DISPL, CCW	90-L-055-KN-1-NN-80-R-4-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
9422100	PUMP-VAR DISPL, CCW	90-L-055-KP-2-NN-80-R-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9422101	PUMP-VAR DISPL, CCW	90-L-055-KA-1-CD-80-P-4-C6-C-03-GBA-32-32-24	SERIES 90	S90-055PV
9422101C	PUMP-VAR DISPL, CCW	90-L-055-KA-1-CD-80-P-4-C6-C-03-GBA-32-32-24	SERIES 90	S90-055PV
9422102	PUMP-VAR DISPL, CCW	90-L-055-KA-1-NN-80-P-4-S1-C-03-GBA-32-32-24	SERIES 90	S90-055PV
9422102C	PUMP-VAR DISPL, CCW	90-L-055-KA-1-NN-80-P-4-S1-C-03-GBA-32-32-24	SERIES 90	S90-055PV
9422104	PUMP-VAR-DISPL CCW 90PV055	90-L-055-KA-5-NN-80-S-3-C6-C-02-EEG-38-38-20	SERIES 90	S90-055PV
9422105	PUMP-VAR DISPL, CCW	90-L-055-KA-1-NN-80-S-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9422106	PUMP-VAR DISPL, CCW	90-L-055-MA-1-AB-60-S-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
9422107	PUMP-VAR DISPL, CCW	90-L-055-KA-1-BG-80-R-4-S1-C-03-GBA-32-32-24	SERIES 90	S90-055PV
9422108	PUMP-VAR DISPL, CCW	90-L-055-KA-1-CD-60-R-3-C6-C-00-GBA-42-42-24	SERIES 90	S90-055PV
9422109	PUMP-VAR DISPL, CCW	90-L-055-KA-1-NN-60-R-3-S1-C-00-GBA-42-42-24	SERIES 90	S90-055PV
9422110	PUMP-VAR DISPL, CCW	90-L-055-DD-5-BG-80-R-4-S1-C-GB-GBA-29-29-24	SERIES 90	S90-055PV
9422111	PUMP-VAR DISPL, CCW	90-L-055-KA-1-CD-80-S-3-C6-C-02-GBA-35-35-24	SERIES 90	S90-055PV
9422112	PUMP-VAR DISPL, CCW	90-L-055-KP-1-NN-80-L-4-S1-D-03-EBC-29-29-24	SERIES 90	S90-055PV
9422113	PUMP-VAR DISPL, CCW	90-L-055-KP-1-BG-80-R-3-K1-C-03-GBA-26-23-24	SERIES 90	S90-055PV
9422115	PUMP-VAR DISPL, CCW	90-L-055-KP-1-BK-80-R-3-S1-C-03-GBA-38-38-24	SERIES 90	S90-055PV
9422116	PUMP-VAR DISPL, CCW	90-L-055-MA-1-BG-81-S-4-S1-C-03-GBA-23-23-24	SERIES 90	S90-055PV
9422117	PUMP-VAR DISPL, CCW	90-L-055-HF-1-AB-60-P-4-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
9422118	PUMP-VAR DISPL, CCW	90-L-055-KP-1-NN-80-S-3-S1-C-03-GBA-32-32-24	SERIES 90	S90-055PV
9422119	PUMP-VAR DISPL, CCW	90-L-055-KA-1-NN-80-P-3-C6-C-00-GBA-42-42-24	SERIES 90	S90-055PV
9422120	PUMP-VAR DISPL, CCW	90-L-055-HF-6-BG-80-S-3-C6-C-03-GBA-48-48-24	SERIES 90	S90-055PV
9422121	PUMP-VAR DISPL, CCW	90-L-055-KA-1-NN-80-P-3-S1-C-00-GBA-42-42-24	SERIES 90	S90-055PV
9422122	PUMP-VAR-DISPL CCW 90PV055	90-L-055-HF-6-BG-80-S-3-C6-C-03-GBA-48-48-28	SERIES 90	S90-055PV
9422123	PUMP-VAR DISPL, CCW	90-L-055-KA-1-CD-80-P-3-C6-C-00-GBA-42-42-24	SERIES 90	S90-055PV
9422125	PUMP-VAR DISPL, CCW	90-L-055-KP-1-BG-80-R-3-S1-C-00-GBA-32-32-24	SERIES 90	S90-055PV
9422126	PUMP-VAR DISPL, CCW	90-L-055-KA-1-NN-60-S-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9422127	PUMP-VAR DISPL, CCW	90-L-055-KP-1-NN-80-P-3-C6-C-03-GBA-32-32-24	SERIES 90	S90-055PV
9422127C	PUMP-VAR-DISPL CCW 90PV055	90-L-055-KP-1-NN-80-P-3-C6-C-03-GBA-32-32-24	SERIES 90	S90-055PV

9422128	PUMP-VAR DISPL, CCW	90-L-055-KP-1-BG-80-P-3-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9422128C	PUMP-VAR-DISPL CCW 90PV055	90-L-055-KP-1-BG-80-P-3-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9422129	PUMP-VAR DISPL, CCW	90-L-055-KP-1-BC-60-P-3-C6-C-03-GBA-35-35-28	SERIES 90	S90-055PV
9422129C	PUMP-VAR-DISPL CCW 90PV055	90-L-055-KP-1-BC-60-P-3-C6-C-03-GBA-35-35-28	SERIES 90	S90-055PV
9422130	PUMP-VAR DISPL, CCW	90-L-055-KA-5-BG-80-S-3-C6-C-06-GBA-29-29-20	SERIES 90	S90-055PV
9422131	PUMP-VAR-DISPL CCW 90PV055	90-L-055-KA-5-BG-80-S-3-C6-C-06-FAD-29-29-20	SERIES 90	S90-055PV
9422132	PUMP-VAR DISPL, CCW	90-L-055-KP-1-NN-80-P-3-S1-C-03-GBA-32-32-24	SERIES 90	S90-055PV
9422132C	PUMP-VAR-DISPL CCW 90PV055	90-L-055-KP-1-NN-80-P-3-S1-C-03-GBA-32-32-24	SERIES 90	S90-055PV
9422133	PUMP-VAR DISPL, CCW 90PV055	90-L-055-HF-2-CD-60-S-3-S1-D-00-GBA-38-38-24	SERIES 90	S90-055PV
9422134	PUMP-VAR-DISPL CCW 90PV055	90-L-055-MA-5-AB-60-L-3-C6-C-C5-FAB-42-42-24	SERIES 90	S90-055PV
9422136	PUMP-VAR DISPL, CCW	90-L-055-KP-1-BG-80-S-3-C6-C-03-GBA-35-35-28	SERIES 90	S90-055PV
9422136C	PUMP-VAR-DISPL CCW 90PV055	90-L-055-KP-1-BG-80-S-3-C6-C-03-GBA-35-35-28	SERIES 90	S90-055PV
9422137	PUMP-VAR DISPL, CCW	90-L-055-KP-1-AF-80-P-3-C6-C-03-EBC-35-35-28	SERIES 90	S90-055PV
9422137C	PUMP-VAR-DISPL CCW 90PV055	90-L-055-KP-1-AF-80-P-3-C6-C-03-EBC-35-35-28	SERIES 90	S90-055PV
9422138	PUMP-VAR DISPL, CCW	90-L-055-KP-1-BC-60-S-3-C6-C-03-GBA-38-38-24	SERIES 90	S90-055PV
9422138C	PUMP-VAR-DISPL CCW 90PV055	90-L-055-KP-1-BC-60-S-3-C6-C-03-GBA-38-38-24	SERIES 90	S90-055PV
9422139	PUMP-VAR-DISPL CCW 90PV055	90-L-055-KA-1-NN-80-S-3-S1-C-02-GBA-42-42-24	SERIES 90	S90-055PV
9422140	PUMP-VAR DISPL, CCW	90-L-055-KP-1-NN-80-P-4-S1-C-03-GBA-35-35-20	SERIES 90	S90-055PV
9422141	PUMP-VAR DISPL, CCW	90-L-055-KP-1-NN-80-R-4-S1-C-03-GBA-35-35-20	SERIES 90	S90-055PV
9422142	PUMP-VAR-DISPL CCW 90PV055	90-L-055-KS-1-NN-60-S-3-S1-B-03-GBA-32-20-24	SERIES 90	S90-055PV
9422143	PUMP-VAR DISPL, CCW	90-L-055-KP-1-BG-80-P-3-C6-C-03-GBA-26-26-24	SERIES 90	S90-055PV
9422143C	PUMP-VAR-DISPL CCW 90PV055	90-L-055-KP-1-BG-80-P-3-C6-C-03-GBA-26-26-24	SERIES 90	S90-055PV
9422144	PUMP-VAR DISPL, CCW	90-L-055-MA-1-AD-80-S-4-S1-D-02-GBA-29-29-24	SERIES 90	S90-055PV
9422145	PUMP-VAR DISPL, CCW	90-L-055-MA-1-BG-80-R-3-S1-C-03-GBA-38-38-24	SERIES 90	S90-055PV
9422146	PUMP-VAR DISPL, CCW	90-L-055-M8-1-NN-80-P-3-S1-C-03-GBA-26-26-24	SERIES 90	S90-055PV
9422146C	PUMP-VAR-DISPL CCW 90PV055	90-L-055-M8-1-NN-80-P-3-S1-C-03-GBA-26-26-24	SERIES 90	S90-055PV
9422148	PUMP-VAR DISPL, CCW	90-L-055-KP-1-CD-80-P-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-055PV
9422149	PUMP-VAR DISPL, CCW	90-L-055-KP-1-NN-80-P-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-055PV
9422150	PUMP-VAR DISPL, CCW	90-L-055-KA-1-NN-80-R-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
9422151	PUMP-VAR DISPL, CCW	90-L-055-KP-1-NN-80-P-3-S1-C-03-GBA-14-35-24	SERIES 90	S90-055PV
9422152	PUMP-VAR DISPL, CCW	90-L-055-HS-1-BC-60-P-3-S1-C-03-GBA-17-17-24	SERIES 90	S90-055PV
9422153	PUMP-VAR DISPL, CCW	90-L-055-MA-7-CD-60-L-3-C6-D-03-GBA-48-48-24	SERIES 90	S90-055PV
9422154	PUMP-VAR DISPL, CCW	90-L-055-MA-7-NN-60-L-3-S1-D-03-GBA-48-48-24	SERIES 90	S90-055PV
9422155	PUMP-VAR DISPL, CCW	90-L-055-KT-5-BG-80-P-3-S1-C-00-GBA-42-42-20	SERIES 90	S90-055PV
9422156	PUMP-VAR-DISPL CCW 90PV055	90-L-055-KA-5-AD-80-S-3-S1-C-03-GBA-26-26-24	SERIES 90	S90-055PV
9422157	PUMP-VAR DISPL, CCW	90-L-055-HS-2-NN-80-P-3-C6-C-03-GBA-38-38-24	SERIES 90	S90-055PV

9422157C	PUMP-VAR-DISPL CCW 90PV055	90-L-055-HS-2-NN-80-P-3-C6-C-03-GBA-38-38-24	SERIES 90	S90-055PV
9422158	PUMP-VAR DISPL, CCW	90-L-055-HS-2-BG-80-P-3-C6-C-03-GBA-38-38-24	SERIES 90	S90-055PV
9422158C	PUMP-VAR-DISPL CCW 90PV055	90-L-055-HS-2-BG-80-P-3-C6-C-03-GBA-38-38-24	SERIES 90	S90-055PV
9422159	PUMP-VAR DISPL, CCW	90-L-055-KP-5-BG-80-R-4-S1-C-03-GBA-20-20-24	SERIES 90	S90-055PV
9422160	PUMP-VAR DISPL, CCW	90-L-055-KP-5-NN-80-R-4-S1-C-03-GBA-20-20-24	SERIES 90	S90-055PV
9422161	PUMP-VAR DISPL, CCW	90-L-055-EA-1-AD-80-R-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-055PV
9422162	PUMP-VAR DISPL, CCW	90-L-055-KP-1-AD-80-S-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
9422163	PUMP-VAR DISPL, CCW	90-L-055-MA-1-BG-80-R-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
9422164	PUMP-VAR DISPL, CCW	90-L-055-KP-1-CD-60-L-3-C6-C-06-GBA-42-42-20	SERIES 90	S90-055PV
9422165	PUMP-VAR DISPL, CCW	90-L-055-KP-1-BC-60-L-3-S1-C-06-GBA-42-42-20	SERIES 90	S90-055PV
9422166	PUMP-VAR DISPL, CCW	90-L-055-KA-1-CD-80-R-4-S1-C-03-GBA-26-26-24	SERIES 90	S90-055PV
9422167	PUMP-VAR DISPL, CCW	90-L-055-KA-1-AD-80-P-3-S1-C-03-GBA-35-14-24	SERIES 90	S90-055PV
9422168	PUMP-VAR DISPL, CCW	90-L-055-MA-1-BG-80-S-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-055PV
9422169	PUMP-VAR DISPL, CCW	90-L-055-KP-1-BG-80-R-3-S1-C-03-GBA-26-26-24	SERIES 90	S90-055PV
9422170	PUMP-VAR DISPL, CCW	90-L-055-KP-5-BG-80-R-3-S1-C-03-GBA-26-26-24	SERIES 90	S90-055PV
9422171	PUMP-VAR DISPL, CCW	90-L-055-FC-1-CD-60-L-3-S1-C-B2-GBA-29-29-28	SERIES 90	S90-055PV
9422172	PUMP-VAR DISPL, CCW	90-L-055-FC-1-NN-60-L-3-S1-C-B2-GBA-29-29-28	SERIES 90	S90-055PV
9422173	PUMP-VAR DISPL, CCW	90-L-055-MA-5-NN-80-S-4-S1-C-02-GBA-42-42-24	SERIES 90	S90-055PV
9422174	PUMP-VAR DISPL, CCW	90-L-055-KA-1-NN-60-R-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9422175	PUMP-VAR DISPL, CCW	90-L-055-KP-1-CD-80-P-3-S1-C-03-GBA-38-38-24	SERIES 90	S90-055PV
9422175C	PUMP-VAR-DISPL CCW 90PV055	90-L-055-KP-1-CD-80-P-3-S1-C-03-GBA-38-38-24	SERIES 90	S90-055PV
9422176	PUMP-VAR DISPL, CCW	90-L-055-HS-1-NN-60-P-3-S1-C-03-GBA-32-14-24	SERIES 90	S90-055PV
9422177C	PUMP-VAR-DISPL CCW 90PV055	90-L-055-KP-1-BC-60-P-3-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9422178	PUMP-VAR DISPL, CCW	90-L-055-MA-1-NN-61-P-4-S1-C-03-GBA-23-23-24	SERIES 90	S90-055PV
9422179	PUMP-VAR DISPL, CCW	90-L-055-DD-5-BB-60-S-3-C6-D-52-GBA-38-38-24	SERIES 90	S90-055PV
9422180	PUMP-VAR DISPL, CCW	90-L-055-HS-2-CD-80-P-3-C6-C-03-GBA-42-42-24	SERIES 90	S90-055PV
9422180C	PUMP-VAR-DISPL CCW 90PV055	90-L-055-HS-2-CD-80-P-3-C6-C-03-GBA-42-42-24	SERIES 90	S90-055PV
9422181	PUMP-VAR DISPL, CCW	90-L-055-HS-2-NN-80-P-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
9422181C	PUMP-VAR-DISPL CCW 90PV055	90-L-055-HS-2-NN-80-P-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
9422182	PUMP-VAR DISPL, CCW	90-L-055-DD-1-NN-80-P-4-S1-D-G4-GBA-35-35-20	SERIES 90	S90-055PV
9422182C	PUMP-VAR-DISPL CCW 90PV055	90-L-055-DD-1-NN-80-P-4-S1-D-G4-GBA-35-35-20	SERIES 90	S90-055PV
9422183	PUMP-VAR DISPL, CCW	90-L-055-KA-1-CD-60-S-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9422184	PUMP-VAR DISPL, CCW	90-L-055-PA-1-NN-80-R-4-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
9422185	PUMP-VAR DISPL, CCW	90-L-055-PA-1-CD-80-R-4-C6-C-03-GBA-42-42-24	SERIES 90	S90-055PV
9422186	PUMP-VAR DISPL, CCW	90-L-055-DD-5-BK-80-S-3-C6-D-52-GBA-38-38-24	SERIES 90	S90-055PV
9422187	PUMP-VAR DISPL, CCW	90-L-055-KA-1-AB-60-S-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV

9422188	PUMP-VAR DISPL, CCW	90-L-055-KP-1-BK-80-P-3-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9422188C	PUMP-VAR-DISPL CCW 90PV055	90-L-055-KP-1-BK-80-P-3-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9422189	PUMP-VAR DISPL, CCW	90-L-055-KN-1-CD-80-R-4-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
9422190	PUMP-VAR DISPL, CCW	90-L-055-KA-5-BB-60-S-3-C6-C-03-GBA-32-32-24	SERIES 90	S90-055PV
9422191	PUMP-VAR DISPL, CCW	90-L-055-KP-1-BC-60-R-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9422191C	PUMP-VAR-DISPL CCW 90PV055	90-L-055-KP-1-BC-60-R-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9422192	PUMP-VAR DISPL, CCW	90-L-055-MV-1-BG-80-P-3-S1-C-02-GBA-38-38-24	SERIES 90	S90-055PV
9422193	PUMP-VAR DISPL, CCW	90-L-055-KA-1-BG-80-S-3-K1-C-06-GBA-23-23-24	SERIES 90	S90-055PV
9422194	PUMP-VAR DISPL, CCW	90-L-055-KN-1-BG-80-R-3-S1-D-03-GBA-38-38-24	SERIES 90	S90-055PV
9422195	PUMP-VAR DISPL, CCW	90-L-055-EA-2-CD-80-S-3-S1-C-33-GBA-07-38-24	SERIES 90	S90-055PV
9422196	PUMP-VAR DISPL, CCW	90-L-055-EA-2-CD-80-S-3-S1-C-33-GBA-07-38-20	SERIES 90	S90-055PV
9422197	PUMP-VAR DISPL, CCW	90-L-055-KN-1-BG-80-R-3-S1-D-03-GBA-38-38-28	SERIES 90	S90-055PV
9422198	PUMP-VAR DISPL, CCW	90-L-055-MA-1-NN-60-R-3-T1-D-03-GBA-35-35-24	SERIES 90	S90-055PV
9422199	PUMP-VAR DISPL, CCW	90-L-055-KA-5-NN-60-S-3-C6-C-03-GBA-35-35-20	SERIES 90	S90-055PV
9422200	PUMP-VAR DISPL, CCW	90-L-055-MA-2-AB-60-P-3-S1-C-03-GBA-45-45-20	SERIES 90	S90-055PV
9422201	PUMP-VAR DISPL, CCW	90-L-055-KA-1-CD-80-R-3-C6-C-02-GBA-35-35-24	SERIES 90	S90-055PV
9422202	PUMP-VAR DISPL, CCW	90-L-055-KP-1-NN-80-L-4-S1-D-03-GBA-26-26-24	SERIES 90	S90-055PV
9422203	PUMP-VAR DISPL, CCW	90-L-055-MA-5-NN-80-R-3-S1-C-C5-GBA-26-26-24	SERIES 90	S90-055PV
9422204	PUMP-VAR DISPL, CCW	90-L-055-KP-1-BG-80-P-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9422204C	PUMP-VAR-DISPL CCW 90PV055	90-L-055-KP-1-BG-80-P-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9422205	PUMP-VAR DISPL, CCW	90-L-055-DD-1-NN-80-S-4-C6-C-GB-GBA-35-35-24	SERIES 90	S90-055PV
9422205C	PUMP-VAR-DISPL CCW 90PV055	90-L-055-DD-1-NN-80-S-4-C6-C-GB-GBA-35-35-24	SERIES 90	S90-055PV
9422206	PUMP-VAR DISPL, CCW	90-L-055-MA-1-BG-80-S-3-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9422206C	PUMP-VAR-DISPL CCW 90PV055	90-L-055-MA-1-BG-80-S-3-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9422207	PUMP-VAR DISPL, CCW	90-L-055-KP-1-CD-80-P-3-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9422207C	PUMP-VAR-DISPL CCW 90PV055	90-L-055-KP-1-CD-80-P-3-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9422208	PUMP-VAR DISPL, CCW	90-L-055-MA-5-NN-80-S-3-S1-C-C5-GBA-42-42-24	SERIES 90	S90-055PV
9422209	PUMP-VAR DISPL, CCW	90-L-055-KP-1-NN-80-R-3-S1-C-03-GBA-40-40-28	SERIES 90	S90-055PV
9422210	PUMP-VAR DISPL, CCW	90-L-055-KA-2-AD-80-S-3-S1-C-00-EBC-35-35-24	SERIES 90	S90-055PV
9422211	PUMP-VAR DISPL, CCW	90-L-055-HS-5-NN-80-S-3-S1-C-03-GBA-26-26-24	SERIES 90	S90-055PV
9422211C	PUMP-VAR-DISPL CCW 90PV055	90-L-055-HS-5-NN-80-S-3-S1-C-03-GBA-26-26-24	SERIES 90	S90-055PV
9422212	PUMP-VAR DISPL, CCW	90-L-055-KP-1-AD-80-S-3-S1-C-03-GBA-35-35-20	SERIES 90	S90-055PV
9422212C	PUMP-VAR-DISPL CCW 90PV055	90-L-055-KP-1-AD-80-S-3-S1-C-03-GBA-35-35-20	SERIES 90	S90-055PV
9422213	PUMP-VAR DISPL, CCW	90-L-055-MA-1-NN-80-S-3-S1-C-03-GBA-23-23-24	SERIES 90	S90-055PV
9422214	PUMP-VAR DISPL, CCW	90-L-055-MB-1-BG-80-P-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9422214C	PUMP-VAR-DISPL CCW 90PV055	90-L-055-MB-1-BG-80-P-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV

9422215	PUMP-VAR DISPL, CCW	90-L-055-HS-5-NN-80-L-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9422216	PUMP-VAR DISPL, CCW	90-L-055-KP-1-AD-80-P-3-C6-C-03-GBA-32-32-24	SERIES 90	S90-055PV
9422216C	PUMP-VAR-DISPL CCW 90PV055	90-L-055-KP-1-AD-80-P-3-C6-C-03-GBA-32-32-24	SERIES 90	S90-055PV
9422217	PUMP-VAR DISPL, CCW	90-L-055-KP-1-NN-80-P-3-S1-C-03-GBA-20-20-24	SERIES 90	S90-055PV
9422217C	PUMP-VAR-DISPL CCW 90PV055	90-L-055-KP-1-NN-80-P-3-S1-C-03-GBA-20-20-24	SERIES 90	S90-055PV
9422218	PUMP-VAR DISPL, CCW	90-L-055-HS-5-CD-80-S-3-S1-C-03-GBA-26-26-24	SERIES 90	S90-055PV
9422218C	PUMP-VAR-DISPL CCW 90PV055	90-L-055-HS-5-CD-80-S-3-S1-C-03-GBA-26-26-24	SERIES 90	S90-055PV
9422219	PUMP-VAR DISPL, CCW	90-L-055-MA-1-AD-80-R-3-S1-C-03-GBA-38-38-24	SERIES 90	S90-055PV
9422220	PUMP-VAR DISPL, CCW	90-L-055-DC-1-AD-80-S-3-S1-C-GB-GBA-29-29-24	SERIES 90	S90-055PV
9422221	PUMP-VAR DISPL, CCW	90-L-055-HS-5-CD-80-S-4-S1-C-03-GBA-26-26-24	SERIES 90	S90-055PV
9422221C	PUMP-VAR-DISPL CCW 90PV055	90-L-055-HS-5-CD-80-S-4-S1-C-03-GBA-26-26-24	SERIES 90	S90-055PV
9422222	PUMP-VAR DISPL, CCW	90-L-055-HS-5-NN-80-S-4-S1-C-03-GBA-26-26-24	SERIES 90	S90-055PV
9422222C	PUMP-VAR-DISPL CCW 90PV055	90-L-055-HS-5-NN-80-S-4-S1-C-03-GBA-26-26-24	SERIES 90	S90-055PV
9422223	PUMP-VAR DISPL, CCW	90-L-055-HF-1-AB-60-P-4-S1-C-00-GBA-32-32-24	SERIES 90	S90-055PV
9422224	PUMP-VAR DISPL, CCW	90-L-055-HF-1-NN-60-P-4-S1-C-00-GBA-32-32-24	SERIES 90	S90-055PV
9422225	PUMP-VAR DISPL, CCW	90-L-055-HF-1-NN-60-P-4-S1-D-00-GBA-35-35-24	SERIES 90	S90-055PV
9422226	PUMP-VAR DISPL, CCW	90-L-055-KA-5-CD-80-R-3-S1-L-03-GBA-42-17-24	SERIES 90	S90-055PV
9422227	PUMP-VAR DISPL, CCW	90-L-055-KA-5-NN-80-R-3-S1-L-03-GBA-42-17-24	SERIES 90	S90-055PV
9422228	PUMP-VAR DISPL, CCW	90-L-055-KA-1-NN-60-S-3-C6-C-03-GBA-32-35-24	SERIES 90	S90-055PV
9422229	PUMP-VAR DISPL, CCW	90-L-055-KA-1-BC-60-R-3-C6-D-02-GBA-42-42-24	SERIES 90	S90-055PV
9422230	PUMP-VAR DISPL, CCW	90-L-055-HK-1-CD-80-S-3-S1-C-03-GBA-38-38-24	SERIES 90	S90-055PV
9422231	PUMP-VAR DISPL, CCW	90-L-055-HK-1-NN-80-S-3-S1-C-03-GBA-38-38-24	SERIES 90	S90-055PV
9422232	PUMP-VAR DISPL, CCW	90-L-055-KA-1-NN-80-R-3-S1-C-03-GBA-14-14-18	SERIES 90	S90-055PV
9422233	PUMP-VAR DISPL, CCW	90-L-055-KA-5-BC-60-S-4-C6-C-06-GBA-35-35-24	SERIES 90	S90-055PV
9422234	PUMP-VAR DISPL, CCW	90-L-055-KP-1-NN-80-R-3-S1-C-03-GBA-35-35-20	SERIES 90	S90-055PV
9422235	PUMP-VAR DISPL, CCW	90-L-055-KA-5-BC-60-S-4-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9422236	PUMP-VAR DISPL, CCW	90-L-055-KP-1-BB-60-P-3-C6-C-03-GBA-32-32-24	SERIES 90	S90-055PV
9422236C	PUMP-VAR-DISPL CCW 90PV055	90-L-055-KP-1-BB-60-P-3-C6-C-03-GBA-32-32-24	SERIES 90	S90-055PV
9422237	PUMP-VAR DISPL, CCW	90-L-055-KA-1-NN-80-R-3-S1-B-03-GBA-42-42-24	SERIES 90	S90-055PV
9422238	PUMP-VAR DISPL, CCW	90-L-055-KP-1-BC-60-R-3-S1-C-03-GBA-35-35-20	SERIES 90	S90-055PV
9422239	PUMP-VAR DISPL, CCW	90-L-055-KP-5-NN-80-S-3-S1-C-03-GBA-29-29-20	SERIES 90	S90-055PV
9422240	PUMP-VAR DISPL, CCW	90-L-055-KP-5-CD-80-S-3-S1-C-03-GBA-29-29-20	SERIES 90	S90-055PV
9422241	PUMP-VAR DISPL, CCW	90-L-055-KA-2-BB-60-S-3-C6-C-03-GBA-32-32-24	SERIES 90	S90-055PV
9422242	PUMP-VAR DISPL, CCW	90-L-055-KA-5-NN-80-S-4-S1-D-05-GBA-40-40-20	SERIES 90	S90-055PV
9422243	PUMP-VAR DISPL, CCW	90-L-055-KP-1-AF-80-R-4-K1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9422244	PUMP-VAR DISPL, CCW	90-L-055-KA-5-NN-60-S-3-C6-D-03-GBA-32-32-24	SERIES 90	S90-055PV

9422245	PUMP-VAR DISPL, CCW	90-L-055-KP-1-AD-80-R-3-S1-C-03-GBA-20-20-24	SERIES 90	S90-055PV
9422246	PUMP-VAR DISPL, CCW	90-L-055-KP-1-CD-80-R-3-S1-C-03-GBA-20-20-24	SERIES 90	S90-055PV
9422247	PUMP-VAR DISPL, CCW	90-L-055-HF-5-CD-60-S-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9422248	PUMP-VAR DISPL, CCW	90-L-055-KA-1-AB-60-P-3-T1-C-03-GBA-35-14-24	SERIES 90	S90-055PV
9422249	PUMP-VAR DISPL, CCW	90-L-055-KA-5-NN-80-P-4-C6-D-03-GBA-29-29-24	SERIES 90	S90-055PV
9422250	PUMP-VAR DISPL, CCW	90-L-055-KA-5-NN-80-P-4-C6-D-03-GBA-32-32-24	SERIES 90	S90-055PV
9422251	PUMP-VAR DISPL, CCW	90-L-055-KP-7-CD-60-L-3-C6-D-03-GBA-48-48-24	SERIES 90	S90-055PV
9422252	PUMP-VAR DISPL, CCW	90-L-055-KP-7-NN-60-L-3-S1-D-03-GBA-48-48-24	SERIES 90	S90-055PV
9422253	PUMP-VAR DISPL, CCW	90-L-055-MA-5-NN-80-S-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
9422254	PUMP-VAR DISPL, CCW	90-L-055-KP-1-AD-80-R-4-K1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9422255	PUMP-VAR DISPL, CCW	90-L-055-KA-5-BC-60-P-3-C6-C-00-EAB-29-29-24	SERIES 90	S90-055PV
9422256	PUMP-VAR DISPL, CCW	90-L-055-MB-1-NN-80-S-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
9422257	PUMP-VAR DISPL, CCW	90-L-055-KP-1-NN-80-S-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
9422258	PUMP-VAR DISPL, CCW	90-L-055-DD-5-NN-80-S-4-C6-B-GB-GBA-38-38-20	SERIES 90	S90-055PV
9422259	PUMP-VAR DISPL, CCW	90-L-055-KA-5-BK-80-S-3-C6-B-03-GBA-40-40-24	SERIES 90	S90-055PV
9422265	PUMP-VAR DISPL, CCW	90-L-055-KP-1-NN-80-P-4-S1-C-03-GBA-26-26-20	SERIES 90	S90-055PV
9422266	PUMP-VAR DISPL, CCW	90-L-055-KA-5-NN-80-S-3-C6-B-03-GBA-40-40-24	SERIES 90	S90-055PV
9422268	PUMP-VAR DISPL, CCW	90-L-055-KA-5-BG-80-S-3-C6-D-03-GBA-29-29-24	SERIES 90	S90-055PV
9422269	PUMP-VAR DISPL, CCW	90-L-055-KA-1-CD-60-S-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-055PV
9422270	PUMP-VAR DISPL, CCW	90-L-055-KP-1-BK-80-P-3-S1-C-03-GBA-23-23-24	SERIES 90	S90-055PV
9422271	PUMP-VAR DISPL, CCW	90-L-055-KP-1-BG-80-R-4-S1-C-03-GBA-23-23-24	SERIES 90	S90-055PV
9422272	PUMP-VAR DISPL, CCW	90-L-055-KP-1-CD-80-R-4-S1-C-03-GBA-23-23-24	SERIES 90	S90-055PV
9422273	PUMP-VAR DISPL, CCW	90-L-055-KP-1-NN-80-R-4-S1-C-03-GBA-17-17-24	SERIES 90	S90-055PV
9422302	PUMP-VAR DISPL, CW	90-R-055-HF-1-BG-80-S-4-S1-C-03-GBA-20-20-20	SERIES 90	S90-055PV
9422303	PUMP-VAR-DISPL CW 90PV055	90-R-055-KA-5-AD-80-S-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9422304	PUMP-VAR-DISPL CW 90PV055	90-R-055-KA-1-BC-60-R-3-C6-D-02-GBA-42-42-24	SERIES 90	S90-055PV
9422305	PUMP-VAR DISPL, CW	90-R-055-KA-1-NN-80-L-4-S1-D-03-GBA-20-20-24	SERIES 90	S90-055PV
9422306	PUMP-VAR-DISPL CW 90PV055	90-R-055-KA-1-NN-60-S-3-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9422307	PUMP-VAR DISPL, CW	90-R-055-KP-1-AD-80-S-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9422308	PUMP-VAR-DISPL CW 90PV055	90-R-055-FC-5-BC-60-S-7-C6-C-B1-EFI-42-42-32	SERIES 90	S90-055PV
9422309	PUMP-VAR-DISPL CW 90PV055	90-R-055-PA-5-NN-80-S-3-S1-C-03-GBA-43-43-28	SERIES 90	S90-055PV
9422310	PUMP-VAR DISPL, CW	90-R-055-KP-2-CD-60-P-3-C6-D-03-GBA-42-42-24	SERIES 90	S90-055PV
9422311	PUMP-VAR DISPL, CW	90-R-055-KP-1-NN-60-P-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-055PV
9422312	PUMP-VAR DISPL, CW	90-R-055-KA-1-CD-80-L-4-S1-D-03-GBA-26-26-24	SERIES 90	S90-055PV
9422313	PUMP-VAR DISPL, CW	90-R-055-KP-1-CD-60-P-3-C6-D-03-GBA-42-42-24	SERIES 90	S90-055PV
9422314	PUMP-VAR DISPL, CW	90-R-055-HF-1-AD-80-R-4-S1-D-03-GBA-35-35-28	SERIES 90	S90-055PV

9422315	PUMP-VAR DISPL, CW	90-R-055-KP-1-CD-60-P-3-C6-D-03-EBC-42-42-24	SERIES 90	S90-055PV
9422316	PUMP-VAR DISPL, CW	90-R-055-KP-1-AF-80-R-3-S1-C-00-GBA-40-40-24	SERIES 90	S90-055PV
9422317	PUMP-VAR-DISPL CW 90PV055	90-R-055-FC-5-AD-80-S-7-C6-D-B2-EFI-42-42-32	SERIES 90	S90-055PV
9422318	PUMP-VAR DISPL, CW	90-R-055-KP-1-CD-80-P-3-S1-C-03-GBA-32-32-24	SERIES 90	S90-055PV
9422319	PUMP-VAR DISPL, CW	90-R-055-KP-1-NN-80-P-3-S1-C-03-GBA-32-32-24	SERIES 90	S90-055PV
9422320	PUMP-VAR-DISPL CW 90PV055	90-R-055-KA-5-BC-60-S-3-C6-D-04-GFD-35-35-24	SERIES 90	S90-055PV
9422321	PUMP-VAR-DISPL CW 90PV055	90-R-055-FD-5-NN-60-P-7-C6-C-B1-EEG-42-42-32	SERIES 90	S90-055PV
9422322	PUMP-VAR DISPL, CW	90-R-055-KP-1-NN-80-P-4-S1-C-03-GBA-35-35-20	SERIES 90	S90-055PV
9422323	PUMP-VAR DISPL, CW	90-R-055-MA-1-BC-60-S-4-S1-C-03-GBA-29-29-24	SERIES 90	S90-055PV
9422325	PUMP-VAR-DISPL CW 90PV055	90-R-055-KA-5-BC-60-P-3-C6-C-00-GCA-26-26-24	SERIES 90	S90-055PV
9422326	PUMP-VAR DISPL, CW	90-R-055-DD-1-NN-80-P-4-S1-C-GB-GBA-35-35-24	SERIES 90	S90-055PV
9422327	PUMP-VAR DISPL, CW	90-R-055-DD-1-BG-80-P-4-S1-C-GB-GBA-35-35-24	SERIES 90	S90-055PV
9422328	PUMP-VAR DISPL, CW	90-R-055-KA-1-CD-60-P-4-S1-C-03-GBA-20-20-18	SERIES 90	S90-055PV
9422329	PUMP-VAR DISPL, CW	90-R-055-KP-1-CD-60-S-3-S1-D-05-GBA-42-42-24	SERIES 90	S90-055PV
9422330	PUMP-VAR DISPL, CW	90-R-055-KP-1-BC-60-S-3-S1-D-05-GBA-42-42-24	SERIES 90	S90-055PV
9422331	PUMP-VAR DISPL, CW	90-R-055-KP-1-BC-60-S-3-S1-D-05-EAB-42-42-24	SERIES 90	S90-055PV
9422332	PUMP-VAR DISPL, CW	90-R-055-KP-1-CD-60-S-3-S1-D-05-EAB-42-42-24	SERIES 90	S90-055PV
9422333	PUMP-VAR DISPL, CW	90-R-055-KA-5-CD-80-R-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-055PV
9422334	PUMP-VAR DISPL, CW	90-R-055-KA-5-CD-80-P-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-055PV
9422335	PUMP-VAR-DISPL CW 90PV055	90-R-055-KP-1-AD-80-S-3-S1-C-03-GBA-23-23-24	SERIES 90	S90-055PV
9422336	PUMP-VAR DISPL, CW	90-R-055-HS-1-BC-60-P-3-S1-D-03-GBA-23-23-20	SERIES 90	S90-055PV
9422337	PUMP-VAR-DISPL CW 90PV055	90-R-055-KA-1-NN-60-S-3-C6-C-03-GBA-38-38-24	SERIES 90	S90-055PV
9422338	PUMP-VAR DISPL, CW	90-R-055-KP-1-NN-80-P-4-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9422339	PUMP-VAR DISPL, CW	90-R-055-KP-1-BG-80-P-4-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9422340	PUMP-VAR DISPL, CW	90-R-055-KP-1-NN-60-S-3-S1-C-03-GBA-14-14-24	SERIES 90	S90-055PV
9422341	PUMP-VAR DISPL, CW	90-R-055-KA-1-NN-60-P-4-S1-C-03-GBA-23-23-24	SERIES 90	S90-055PV
9422342	PUMP-VAR DISPL, CW	90-R-055-KP-1-NN-80-R-3-S1-C-03-GBA-32-32-24	SERIES 90	S90-055PV
9422343	PUMP-VAR-DISPL CW 90PV055	90-R-055-KA-5-NN-80-S-3-C6-C-03-GBA-38-38-20	SERIES 90	S90-055PV
9422344	PUMP-VAR DISPL, CW	90-R-055-KP-5-CD-80-S-3-S1-C-00-GBA-42-42-24	SERIES 90	S90-055PV
9422345	PUMP-VAR DISPL, CW	90-R-055-KP-5-NN-80-S-3-S1-C-00-GBA-42-42-24	SERIES 90	S90-055PV
9422346	PUMP-VAR DISPL, CW	90-R-055-DC-1-NN-80-P-3-S1-C-GB-GBA-38-38-24	SERIES 90	S90-055PV
9422347	PUMP-VAR DISPL, CW	90-R-055-KP-1-AF-80-P-3-S1-C-00-GBA-32-32-24	SERIES 90	S90-055PV
9422348	PUMP-VAR DISPL, CW	90-R-055-KP-1-AB-60-R-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
9422349	PUMP-VAR DISPL, CW	90-R-055-KP-1-BK-80-P-4-S1-C-03-GBA-32-32-24	SERIES 90	S90-055PV
9422350	PUMP-VAR DISPL, CW	90-R-055-KP-1-BK-80-P-4-S1-C-03-GBA-32-32-24-F066	SERIES 90	S90-055PV
9422351	PUMP-VAR DISPL, CW	90-R-055-MA-1-BC-60-D-3-S1-L-02-GBA-42-42-28	SERIES 90	S90-055PV

9422352	PUMP-VAR-DISPL CW 90PV055	90-R-055-FC-6-CD-60-S-7-C6-C-B1-EEG-40-40-30	SERIES 90	S90-055PV
9422353	PUMP-VAR-DISPL CW 90PV055	90-R-055-CA-5-NN-60-S-7-S1-C-00-EEG-40-40-30	SERIES 90	S90-055PV
9422354	PUMP-VAR DISPL, CW	90-R-055-MA-1-NN-80-P-4-K1-C-03-GBA-29-29-24	SERIES 90	S90-055PV
9422355	PUMP-VAR-DISPL CW 90PV055	90-R-055-FC-2-BC-60-S-7-C6-C-B1-EFI-42-42-32	SERIES 90	S90-055PV
9422356	PUMP-VAR DISPL, CW	90-R-055-KA-1-AD-80-P-4-S1-C-00-GBA-17-17-24	SERIES 90	S90-055PV
9422357	PUMP-VAR-DISPL CW 90PV055	90-R-055-KA-5-CD-60-R-3-C6-D-02-GBA-42-42-24	SERIES 90	S90-055PV
9422358	PUMP-VAR-DISPL CW 90PV055	90-R-055-KA-5-NN-60-R-3-S1-D-02-GBA-42-42-24	SERIES 90	S90-055PV
9422359	PUMP-VAR DISPL, CW	90-R-055-MA-1-BC-60-R-3-S1-C-03-GBA-26-26-24	SERIES 90	S90-055PV
9422360	PUMP-VAR-DISPL CW 90PV055	90-R-055-KA-5-BB-60-P-3-C6-D-03-GBA-29-29-24	SERIES 90	S90-055PV
9422361	PUMP-VAR-DISPL CW 90PV055	90-R-055-KA-1-BC-60-R-3-C6-D-02-GBA-42-42-24-N180	SERIES 90	S90-055PV
9422362	PUMP-VAR-DISPL CW 90PV055	90-R-055-MG-5-NN-60-S-3-S1-C-C5-GBA-42-42-20	SERIES 90	S90-055PV
9422363	PUMP-VAR DISPL, CW	90-R-055-KA-1-NN-80-P-3-S1-C-00-GBA-42-42-24	SERIES 90	S90-055PV
9422364	PUMP-VAR DISPL, CW	90-R-055-KP-1-BG-80-L-4-S1-C-03-GBA-35-35-30	SERIES 90	S90-055PV
9422365	PUMP-VAR-DISPL CW 90PV055	90-R-055-DC-5-BC-60-S-4-S1-D-G8-GLA-42-42-24	SERIES 90	S90-055PV
9422366	PUMP-VAR DISPL, CW	90-R-055-KP-1-AD-80-R-3-S1-D-03-EBC-35-35-24	SERIES 90	S90-055PV
9422367	PUMP-VAR DISPL, CW	90-R-055-KA-1-BC-60-L-3-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9422368	PUMP-VAR-DISPL CW 90PV055	90-R-055-KA-5-BK-80-P-3-C6-D-03-GBA-29-29-24	SERIES 90	S90-055PV
9422369	PUMP-VAR DISPL, CW	90-R-055-MA-1-BG-80-S-3-S1-C-00-GBA-29-17-24	SERIES 90	S90-055PV
9422370	PUMP-VAR DISPL, CW	90-R-055-KP-1-BG-80-R-3-S1-C-00-GBA-32-32-24	SERIES 90	S90-055PV
9422371	PUMP-VAR DISPL, CW	90-R-055-KP-1-BC-60-S-4-C6-C-03-EBC-35-35-24	SERIES 90	S90-055PV
9422371C	PUMP-VAR-DISPL CW 90PV055	90-R-055-KP-1-BC-60-S-4-C6-C-03-EBC-35-35-24	SERIES 90	S90-055PV
9422372	PUMP-VAR DISPL, CW	90-R-055-KP-5-CD-80-S-3-S1-C-00-GBA-38-38-24	SERIES 90	S90-055PV
9422373	PUMP-VAR DISPL, CW	90-R-055-KP-5-NN-80-S-3-S1-C-00-GBA-38-38-24	SERIES 90	S90-055PV
9422374	PUMP-VAR DISPL, CW	90-R-055-CB-1-NN-60-S-3-S1-C-00-GBA-35-35-24-P000	SERIES 90	S90-055PV
9422375	PUMP-VAR DISPL, CW	90-R-055-KP-1-CD-80-P-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9422376	PUMP-VAR DISPL, CW	90-R-055-KA-1-AD-80-L-4-S1-C-03-GBA-20-20-24	SERIES 90	S90-055PV
9422377	PUMP-VAR DISPL, CW	90-R-055-KA-1-CD-80-L-4-S1-C-03-GBA-20-20-24	SERIES 90	S90-055PV
9422378	PUMP-VAR-DISPL CW 90PV055	90-R-055-KA-1-CD-80-P-3-C6-C-03-GBA-32-32-24	SERIES 90	S90-055PV
9422380	PUMP-VAR DISPL, CW	90-R-055-KP-1-NN-80-P-4-S1-D-03-GBA-38-38-28	SERIES 90	S90-055PV
9422380C	PUMP-VAR-DISPL CW 90PV055	90-R-055-KP-1-NN-80-P-4-S1-D-03-GBA-38-38-28	SERIES 90	S90-055PV
9422381	PUMP-VAR-DISPL CW 90PV055	90-R-055-MA-5-BK-80-P-3-C6-C-04-GBA-42-42-24	SERIES 90	S90-055PV
9422382	PUMP-VAR DISPL, CW	90-R-055-KP-1-NN-80-S-3-S1-C-03-GBA-29-29-24	SERIES 90	S90-055PV
9422383	PUMP-VAR-DISPL CW 90PV055	90-R-055-KA-5-AD-80-P-3-S1-C-03-GBA-32-32-24	SERIES 90	S90-055PV
9422384	PUMP-VAR-DISPL CW 90PV055	90-R-055-MA-5-BK-80-P-3-C6-C-04-GBA-38-38-24	SERIES 90	S90-055PV
9422385	PUMP-VAR DISPL, CW	90-R-055-KP-5-CD-80-S-3-S1-C-03-GBA-38-38-24	SERIES 90	S90-055PV
9422386	PUMP-VAR DISPL, CW	90-R-055-KP-5-NN-80-S-3-S1-C-03-GBA-38-38-24	SERIES 90	S90-055PV

9422387	PUMP-VAR DISPL, CW	90-R-055-HK-1-NN-60-D-3-S1-L-03-GBA-42-42-24	SERIES 90	S90-055PV
9422388	PUMP-VAR DISPL, CW	90-R-055-MV-1-CD-80-P-4-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9422389	PUMP-VAR DISPL, CW	90-R-055-MV-1-BG-80-P-4-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9422390	PUMP-VAR DISPL, CW	90-R-055-MA-1-BG-80-S-4-S1-C-00-GBA-35-35-24	SERIES 90	S90-055PV
9422391	PUMP-VAR DISPL, CW	90-R-055-MA-1-BG-80-S-3-S1-C-02-GBA-42-42-24	SERIES 90	S90-055PV
9422392	PUMP-VAR DISPL, CW	90-R-055-HK-1-NN-60-D-3-S1-L-03-GBA-42-42-28	SERIES 90	S90-055PV
9422393	PUMP-VAR DISPL, CW	90-R-055-KA-1-NN-80-S-3-C6-C-02-GBA-42-42-20	SERIES 90	S90-055PV
9422393C	PUMP-VAR-DISPL CW 90PV055	90-R-055-KA-1-NN-80-S-3-C6-C-02-GBA-42-42-20	SERIES 90	S90-055PV
9422394	PUMP-VAR DISPL, CW	90-R-055-RU-1-CD-80-P-3-C6-C-02-GBA-38-38-24	SERIES 90	S90-055PV
9422395	PUMP-VAR DISPL, CW	90-R-055-MT-1-BG-80-P-4-S1-C-02-GBA-38-38-24	SERIES 90	S90-055PV
9422396	PUMP-VAR DISPL, CW	90-R-055-KN-1-AD-80-P-3-S1-D-03-GBA-35-35-20	SERIES 90	S90-055PV
9422397	PUMP-VAR DISPL, CW	90-R-055-MA-1-NN-60-P-4-S1-D-03-GBA-26-26-24	SERIES 90	S90-055PV
9422398	PUMP-VAR DISPL, CW	90-R-055-HF-1-BG-80-P-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
9422399	PUMP-VAR-DISPL CW 90PV055	90-R-055-HF-5-NN-80-R-4-C6-C-00-GCA-42-42-20	SERIES 90	S90-055PV
9422400	PUMP-VAR DISPL, CW	90-R-055-KP-1-BG-80-L-3-S1-D-03-EBC-29-29-24	SERIES 90	S90-055PV
9422401	PUMP-VAR DISPL, CW	90-R-055-KP-1-AF-80-R-3-S1-C-00-GBA-32-32-24	SERIES 90	S90-055PV
9422402	PUMP-VAR DISPL, CW	90-R-055-HF-1-BG-80-P-3-S1-C-02-GBA-42-42-24	SERIES 90	S90-055PV
9422403	PUMP-VAR DISPL, CW	90-R-055-KP-1-BB-60-S-3-S1-C-03-GBA-23-23-20	SERIES 90	S90-055PV
9422404	PUMP-VAR DISPL, CW	90-R-055-MA-1-NN-60-P-4-S1-B-03-GBA-26-26-24	SERIES 90	S90-055PV
9422405	PUMP-VAR DISPL, CW	90-R-055-KP-1-NN-80-P-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-055PV
9422406	PUMP-VAR-DISPL CW 90PV055	90-R-055-DC-5-BC-60-S-4-S1-D-G8-GLC-42-42-24	SERIES 90	S90-055PV
9422407	PUMP-VAR DISPL, CW	90-R-055-HK-2-CG-60-R-3-S1-C-02-GBA-42-42-24	SERIES 90	S90-055PV
9422408	PUMP-VAR DISPL, CW	90-R-055-KA-5-BG-60-R-3-S1-C-03-GBA-38-38-24	SERIES 90	S90-055PV
9422409	PUMP-VAR DISPL, CW	90-R-055-KA-1-BG-80-R-4-S1-C-02-GBA-26-26-24	SERIES 90	S90-055PV
9422410	PUMP-VAR DISPL, CW	90-R-055-KA-1-CD-80-R-4-S1-C-03-GBA-26-26-24	SERIES 90	S90-055PV
9422411	PUMP-VAR-DISPL CW 90PV055	90-R-055-FC-2-NN-60-S-7-C6-D-B1-GLA-45-45-30	SERIES 90	S90-055PV
9422412	PUMP-VAR-DISPL CW 90PV055	90-R-055-KA-6-AD-80-S-3-C6-C-03-GBA-48-48-24	SERIES 90	S90-055PV
9422413	PUMP-VAR DISPL, CW	90-R-055-MV-1-CD-80-P-3-C6-C-02-GBA-38-38-24	SERIES 90	S90-055PV
9422414	PUMP-VAR DISPL, CW	90-R-055-MV-1-CD-80-P-4-S1-C-02-GBA-38-38-24	SERIES 90	S90-055PV
9422415	PUMP-VAR DISPL, CW	90-R-055-ME-1-NN-80-P-3-C6-C-03-GBA-26-26-24	SERIES 90	S90-055PV
9422415C	PUMP-VAR-DISPL CW 90PV055	90-R-055-ME-1-NN-80-P-3-C6-C-03-GBA-26-26-24	SERIES 90	S90-055PV
9422416	PUMP-VAR DISPL, CW	90-R-055-HF-1-BG-80-R-4-S1-C-09-GBA-35-35-24	SERIES 90	S90-055PV
9422417	PUMP-VAR DISPL, CW	90-R-055-KP-1-NN-60-S-3-S1-D-00-GBA-17-17-20	SERIES 90	S90-055PV
9422418	PUMP-VAR DISPL, CW	90-R-055-DD-1-AD-80-R-4-S1-C-GB-GBA-35-35-24	SERIES 90	S90-055PV
9422418C	PUMP-VAR-DISPL CW 90PV055	90-R-055-DD-1-AD-80-R-4-S1-C-GB-GBA-35-35-24	SERIES 90	S90-055PV
9422419	PUMP-VAR DISPL, CW	90-R-055-DD-1-NN-60-P-4-S1-D-G4-GBA-35-35-20	SERIES 90	S90-055PV

9422419C	PUMP-VAR-DISPL CW 90PV055	90-R-055-DD-1-NN-60-P-4-S1-D-G4-GBA-35-35-20	SERIES 90	S90-055PV
9422420	PUMP-VAR DISPL, CW	90-R-055-KP-1-NN-80-P-3-S1-D-03-GBA-32-32-24	SERIES 90	S90-055PV
9422421	PUMP-VAR DISPL, CW	90-R-055-KA-5-BG-80-S-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
9422422	PUMP-VAR DISPL, CW	90-R-055-MV-1-BB-60-D-3-S1-L-02-GBA-42-42-28	SERIES 90	S90-055PV
9422423	PUMP-VAR DISPL, CW	90-R-055-HS-1-BC-60-P-4-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9422424	PUMP-VAR DISPL, CW	90-R-055-KA-P-BG-80-P-3-C6-C-03-FAB-48-48-24	SERIES 90	S90-055PV
9422425	PUMP-VAR DISPL, CW	90-R-055-MA-1-AD-80-P-3-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9422425C	PUMP-VAR-DISPL CW 90PV055	90-R-055-MA-1-AD-80-P-3-C6-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9422426	PUMP-VAR DISPL, CW	90-R-055-DC-2-AD-80-R-3-S1-C-GB-GBA-42-42-20	SERIES 90	S90-055PV
9422427	PUMP-VAR DISPL, CW	90-R-055-KP-1-AB-60-S-3-S1-C-00-GBA-17-17-20	SERIES 90	S90-055PV
9422428	PUMP-VAR DISPL, CW	90-R-055-CB-1-NN-60-S-4-S1-C-00-GBA-35-35-24	SERIES 90	S90-055PV
9422428C	PUMP-VAR-DISPL CW 90PV055	90-R-055-CB-1-NN-60-S-4-S1-C-00-GBA-35-35-24	SERIES 90	S90-055PV
9422429	PUMP-VAR DISPL, CW	90-R-055-CB-1-NN-80-S-4-S1-C-00-GBA-35-35-24	SERIES 90	S90-055PV
9422429C	PUMP-VAR-DISPL CW 90PV055	90-R-055-CB-1-NN-80-S-4-S1-C-00-GBA-35-35-24	SERIES 90	S90-055PV
9422430	PUMP-VAR DISPL, CW	90-R-055-KN-1-CD-80-P-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9422431	PUMP-VAR DISPL, CW	90-R-055-KN-1-BG-80-P-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9422432	PUMP-VAR DISPL, CW	90-R-055-CB-1-NN-60-S-3-S1-C-00-GBA-35-35-24	SERIES 90	S90-055PV
9422432C	PUMP-VAR-DISPL CW 90PV055	90-R-055-CB-1-NN-60-S-3-S1-C-00-GBA-35-35-24	SERIES 90	S90-055PV
9422434	PUMP-VAR DISPL, CW	90-R-055-KP-1-CD-60-P-4-S1-C-03-GBA-32-32-24	SERIES 90	S90-055PV
9422435	PUMP-VAR DISPL, CW	90-R-055-RU-1-CD-80-P-3-C6-C-00-GBA-38-38-24	SERIES 90	S90-055PV
9422436	PUMP-VAR DISPL, CW	90-R-055-RU-1-CD-80-P-4-S1-C-00-GBA-38-38-24	SERIES 90	S90-055PV
9422437	PUMP-VAR DISPL, CW	90-R-055-KP-1-NN-80-R-3-S1-D-03-GBA-29-29-24	SERIES 90	S90-055PV
9422437C	PUMP-VAR-DISPL CW 90PV055	90-R-055-KP-1-NN-80-R-3-S1-D-03-GBA-29-29-24	SERIES 90	S90-055PV
9422438	PUMP-VAR DISPL, CW	90-R-055-KP-6-NN-60-P-3-S1-C-00-GBA-48-48-24	SERIES 90	S90-055PV
9422438C	PUMP-VAR-DISPL CW 90PV055	90-R-055-KP-6-NN-60-P-3-S1-C-00-GBA-48-48-24	SERIES 90	S90-055PV
9422439	PUMP-VAR DISPL, CW	90-R-055-KP-6-NN-80-P-3-S1-C-00-GBA-48-48-24	SERIES 90	S90-055PV
9422439C	PUMP-VAR-DISPL CW 90PV055	90-R-055-KP-6-NN-80-P-3-S1-C-00-GBA-48-48-24	SERIES 90	S90-055PV
9422440	PUMP-VAR DISPL, CW	90-R-055-KA-1-AD-80-S-4-K1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
9422441	PUMP-VAR DISPL, CW	90-R-055-KA-1-NN-80-S-4-S1-C-00-GBA-29-29-20	SERIES 90	S90-055PV
9422442	PUMP-VAR DISPL, CW	90-R-055-FC-5-BK-80-S-N-C6-C-B1-GBA-42-42-24	SERIES 90	S90-055PV
9422443	PUMP-VAR DISPL, CW	90-R-055-MA-P-BK-80-S-3-C6-C-C5-GBA-48-48-24	SERIES 90	S90-055PV
9422444	PUMP-VAR DISPL, CW	90-R-055-KA-5-NN-80-R-4-K1-C-00-GBA-35-35-24	SERIES 90	S90-055PV
9422445	PUMP-VAR DISPL, CW	90-R-055-FC-5-AD-80-S-7-C6-D-B1-EFI-45-45-24	SERIES 90	S90-055PV
9422446	PUMP-VAR DISPL, CW	90-R-055-KA-5-AD-80-S-3-C6-C-03-GBA-42-42-24	SERIES 90	S90-055PV
9422447	PUMP-VAR DISPL, CW	90-R-055-KN-1-NN-60-D-4-S1-L-03-GBA-20-20-28	SERIES 90	S90-055PV
9422448	PUMP-VAR DISPL, CW	90-R-055-MB-5-AD-80-S-3-C6-C-C5-GBA-42-42-24	SERIES 90	S90-055PV

9422449	PUMP-VAR DISPL, CW	90-R-055-KP-1-AF-80-R-3-S1-C-03-GBA-23-23-24	SERIES 90	S90-055PV
9422450	PUMP-VAR DISPL, CW	90-R-055-MV-1-NN-80-D-4-S1-L-03-GBA-42-42-20-F062	SERIES 90	S90-055PV
9422451	PUMP-VAR DISPL, CW	90-R-055-MB-1-BG-80-S-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9422452	PUMP-VAR DISPL, CW	90-R-055-KA-5-BG-80-S-3-C6-C-03-GBA-48-48-24	SERIES 90	S90-055PV
9422453	PUMP-VAR DISPL, CW	90-R-055-HS-1-CD-80-R-3-S1-C-03-GBA-38-38-24	SERIES 90	S90-055PV
9422454	PUMP-VAR DISPL, CW	90-R-055-MB-1-NN-60-S-3-C6-D-04-GBA-35-35-24	SERIES 90	S90-055PV
9422455C	PUMP-VAR-DISPL CW 90PV055	90-R-055-MB-1-BC-60-R-3-C6-D-03-GBA-42-42-24	SERIES 90	S90-055PV
9422456	PUMP-VAR DISPL, CW	90-R-055-M8-1-BC-60-P-3-C6-C-03-GBA-42-42-24	SERIES 90	S90-055PV
9422456C	PUMP-VAR-DISPL CW 90PV055	90-R-055-M8-1-BC-60-P-3-C6-C-03-GBA-42-42-24	SERIES 90	S90-055PV
9422457	PUMP-VAR DISPL, CW	90-R-055-MA-5-NN-80-S-3-S1-C-C5-GBA-42-42-24	SERIES 90	S90-055PV
9422458	PUMP-VAR DISPL, CW	90-R-055-KP-5-BC-60-R-3-S1-D-03-GBA-38-38-24	SERIES 90	S90-055PV
9422459	PUMP-VAR DISPL, CW	90-R-055-CA-2-BC-60-P-7-S1-C-00-GLA-42-42-20	SERIES 90	S90-055PV
9422460	PUMP-VAR DISPL, CW	90-R-055-HS-2-CD-80-P-3-C6-C-03-GBA-38-38-24	SERIES 90	S90-055PV
9422460C	PUMP-VAR-DISPL CW 90PV055	90-R-055-HS-2-CD-80-P-3-C6-C-03-GBA-38-38-24	SERIES 90	S90-055PV
9422461	PUMP-VAR DISPL, CW	90-R-055-HS-2-NN-80-P-3-S1-C-03-GBA-38-38-24	SERIES 90	S90-055PV
9422461C	PUMP-VAR-DISPL CW 90PV055	90-R-055-HS-2-NN-80-P-3-S1-C-03-GBA-38-38-24	SERIES 90	S90-055PV
9422462	PUMP-VAR DISPL, CW	90-R-055-KA-1-NN-80-P-3-T1-C-03-GBA-26-26-24	SERIES 90	S90-055PV
9422463	PUMP-VAR DISPL, CW	90-R-055-KA-5-BG-80-P-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9422464	PUMP-VAR DISPL, CW	90-R-055-KA-1-CD-60-L-3-C6-C-03-FAB-38-38-24	SERIES 90	S90-055PV
9422465	PUMP-VAR DISPL, CW	90-R-055-KA-2-CG-60-R-3-S1-C-02-GBA-42-42-24	SERIES 90	S90-055PV
9422466	PUMP-VAR DISPL, CW	90-R-055-MB-1-CD-80-R-3-C6-C-03-GBA-42-42-20	SERIES 90	S90-055PV
9422466C	PUMP-VAR-DISPL CW 90PV055	90-R-055-MB-1-CD-80-R-3-C6-C-03-GBA-42-42-20	SERIES 90	S90-055PV
9422467	PUMP-VAR DISPL, CW	90-R-055-DD-1-NN-80-D-4-S1-L-GB-GBA-35-35-20	SERIES 90	S90-055PV
9422467C	PUMP-VAR-DISPL CW 90PV055	90-R-055-DD-1-NN-80-D-4-S1-L-GB-GBA-35-35-20	SERIES 90	S90-055PV
9422468	PUMP-VAR DISPL, CW	90-R-055-FC-2-BC-60-P-7-C6-D-B1-GLA-40-40-30	SERIES 90	S90-055PV
9422469	PUMP-VAR DISPL, CW	90-R-055-HF-5-NN-80-P-4-C6-C-00-GCA-42-42-20	SERIES 90	S90-055PV
9422470	PUMP-VAR DISPL, CW	90-R-055-KA-1-NN-80-P-4-C6-C-03-GBA-38-38-24	SERIES 90	S90-055PV
9422470C	PUMP-VAR-DISPL CW 90PV055	90-R-055-KA-1-NN-80-P-4-C6-C-03-GBA-38-38-24	SERIES 90	S90-055PV
9422471	PUMP-VAR DISPL, CW	90-R-055-KA-5-CD-60-R-3-C6-D-04-GBA-42-42-24	SERIES 90	S90-055PV
9422472	PUMP-VAR DISPL, CW	90-R-055-MA-5-BC-60-S-3-S1-D-C5-GBA-35-35-24	SERIES 90	S90-055PV
9422473	PUMP-VAR DISPL, CW (FOR VA TEST)	90-R-055-CB-1-NN-60-S-3-S1-C-00-GBA-43-43-24-G002	SERIES 90	S90-055PV
9422474	PUMP-VAR DISPL, CW	90-R-055-FC-1-BC-60-P-7-S1-D-B1-GLA-45-45-32	SERIES 90	S90-055PV
9422475	PUMP-VAR DISPL, CW	90-R-055-FC-1-BB-60-P-7-S1-D-B1-GLA-45-45-32	SERIES 90	S90-055PV
9422476	PUMP-VAR DISPL, CW	90-R-055-HF-1-BG-80-S-3-C6-C-03-GBA-23-23-24	SERIES 90	S90-055PV
9422477	PUMP-VAR DISPL, CW	90-R-055-KA-5-NN-80-P-3-S1-B-03-GBA-29-14-20	SERIES 90	S90-055PV
9422478	PUMP-VAR DISPL, CW	90-R-055-MA-5-BB-60-S-4-C6-D-C5-GBA-32-32-24	SERIES 90	S90-055PV

9422479	PUMP-VAR DISPL, CW	90-R-055-KA-1-NN-80-R-3-C6-C-03-GBA-42-42-24	SERIES 90	S90-055PV
9422479C	PUMP-VAR-DISPL CW 90PV055	90-R-055-KA-1-NN-80-R-3-C6-C-03-GBA-42-42-24	SERIES 90	S90-055PV
9422480	PUMP-VAR DISPL, CW	90-R-055-KA-5-BK-80-R-3-S1-C-03-GBA-35-35-20	SERIES 90	S90-055PV
9422481	PUMP-VAR DISPL, CW	90-R-055-FC-P-CD-60-P-7-S1-D-B1-GLA-45-45-32	SERIES 90	S90-055PV
9422482	PUMP-VAR DISPL, CW	90-R-055-KA-1-NN-80-L-3-C6-C-03-GBA-42-42-24	SERIES 90	S90-055PV
9422483	PUMP-VAR DISPL, CW	90-R-055-KA-5-BG-80-S-3-S1-C-03-GBA-29-29-24	SERIES 90	S90-055PV
9422484	PUMP-VAR DISPL, CW	90-R-055-KA-1-CD-80-L-4-S1-C-00-GBA-14-14-24	SERIES 90	S90-055PV
9422485	PUMP-VAR DISPL, CW	90-R-055-MA-5-BG-80-R-3-S1-C-C5-GBA-45-45-24	SERIES 90	S90-055PV
9422486	PUMP-VAR DISPL, CW	90-R-055-MA-1-AD-80-L-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-055PV
9422487	PUMP-VAR DISPL, CW	90-R-055-KA-5-NN-60-R-4-S1-C-03-GBA-14-14-20	SERIES 90	S90-055PV
9422488	PUMP-VAR DISPL, CW	90-R-055-DD-1-NN-60-P-4-S1-C-GB-GBA-38-38-24	SERIES 90	S90-055PV
9422488C	PUMP-VAR-DISPL CW 90PV055	90-R-055-DD-1-NN-60-P-4-S1-C-GB-GBA-38-38-24	SERIES 90	S90-055PV
9422489	PUMP-VAR DISPL, CW	90-R-055-MA-5-NN-80-S-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
9422490	PUMP-VAR DISPL, CW	90-R-055-KA-5-AD-80-S-4-C6-D-03-GBA-42-42-30	SERIES 90	S90-055PV
9422491	PUMP-VAR DISPL, CW	90-R-055-MA-5-NN-80-L-4-S1-C-02-GBA-23-23-24	SERIES 90	S90-055PV
9422492	PUMP-VAR DISPL, CW	90-R-055-DD-1-NN-80-R-4-S1-C-GB-GBA-35-35-24	SERIES 90	S90-055PV
9422493	PUMP-VAR DISPL, CW	90-R-055-KN-1-CD-80-P-3-C6-D-04-GBA-29-29-24	SERIES 90	S90-055PV
9422494	PUMP-VAR DISPL, CW	90-R-055-KA-5-NN-80-P-3-C6-C-03-GBA-26-26-24	SERIES 90	S90-055PV
9422495	PUMP-VAR DISPL, CW	90-R-055-MB-5-BC-60-S-4-C6-C-C5-FAB-42-42-24	SERIES 90	S90-055PV
9422498	PUMP-VAR DISPL, CW	90-R-055-CB-5-NN-60-S-3-C6-C-00-GBA-00-00-00-P000	SERIES 90	S90-055PV
9422499	PUMP-VAR DISPL, CW	90-R-055-KP-1-AD-80-P-3-C6-D-03-GBA-35-35-24	SERIES 90	S90-055PV
9422499C	PUMP-VAR-DISPL CW 90PV055	90-R-055-KP-1-AD-80-P-3-C6-D-03-GBA-35-35-24	SERIES 90	S90-055PV
9422500	PUMP-VAR DISPL, CW	90-R-055-KP-1-CD-60-S-3-S1-D-05-EEB-42-42-24	SERIES 90	S90-055PV
9422501	PUMP-VAR DISPL, CW	90-R-055-KP-1-BC-60-S-3-S1-D-05-EEB-42-42-24	SERIES 90	S90-055PV
9422502	PUMP-VAR DISPL, CW	90-R-055-DC-1-NN-80-R-4-S1-C-GB-GBA-29-29-24	SERIES 90	S90-055PV
9422502C	PUMP-VAR-DISPL CW 90PV055	90-R-055-DC-1-NN-80-R-4-S1-C-GB-GBA-29-29-24	SERIES 90	S90-055PV
9422503	PUMP-VAR DISPL, CW	90-R-055-KN-1-CD-80-P-4-S1-D-04-GBA-29-29-24-F034	SERIES 90	S90-055PV
9422504	PUMP-VAR DISPL, CW	90-R-055-DD-1-AD-80-P-4-S1-C-GB-GBA-35-35-24	SERIES 90	S90-055PV
9422504C	PUMP-VAR-DISPL CW 90PV055	90-R-055-DD-1-AD-80-P-4-S1-C-GB-GBA-35-35-24	SERIES 90	S90-055PV
9422505	PUMP-VAR DISPL, CW	90-R-055-KA-1-AB-60-P-3-C6-C-03-EBC-35-35-30	SERIES 90	S90-055PV
9422505C	PUMP-VAR-DISPL CW 90PV055	90-R-055-KA-1-AB-60-P-3-C6-C-03-EBC-35-35-30	SERIES 90	S90-055PV
9422506	PUMP-VAR DISPL, CW	90-R-055-KP-1-BG-80-P-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
9422506C	PUMP-VAR-DISPL CW 90PV055	90-R-055-KP-1-BG-80-P-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
9422507	PUMP-VAR DISPL, CW	90-R-055-HS-1-BG-80-P-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
9422507C	PUMP-VAR-DISPL CW 90PV055	90-R-055-HS-1-BG-80-P-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-055PV
9422508	PUMP-VAR DISPL, CW	90-R-055-HS-1-BC-60-S-3-S1-B-03-GBA-42-42-24	SERIES 90	S90-055PV

9422509	PUMP-VAR DISPL, CW	90-R-055-FC-5-BG-80-P-7-C6-C-B1-EFI-38-38-30	SERIES 90	S90-055PV
9422510	PUMP-VAR DISPL, CW	90-R-055-KA-5-NN-60-R-3-C6-C-03-GBA-26-26-20	SERIES 90	S90-055PV
9422512	PUMP-VAR DISPL, CW	90-R-055-KA-1-BC-60-R-4-S1-C-03-GBA-32-32-24	SERIES 90	S90-055PV
9422513	PUMP-VAR DISPL, CW	90-R-055-KA-5-BK-80-S-7-C6-C-21-EFI-45-45-24	SERIES 90	S90-055PV
9422514	PUMP-VAR DISPL, CW	90-R-055-FD-5-AD-80-P-7-C6-C-B1-EFI-48-48-24	SERIES 90	S90-055PV
9431098	MOTOR-FIX DISPL	90-M-055-NC-0-N-8-N-0-S1-W-00-EEA-00-00-E6	SERIES 90	S90-055MF
9431120C	MOTOR-FIXED-DISPL 90MF055	90-M-055-NC-A-N-J-N-0-C6-W-00-CBD-34-34-11-P020	SERIES 90	S90-055MF
9431513	MOTOR-FIXED-DISPL 90K055	90-K-055-NC-0-N-8-N-0-S1-W-00-NNN-00-00-E6	SERIES 90	S90-055MF
9441553	MOTOR-VAR-DISPL 90MC055	90-C-055-PT-0-0-8-N-040-S7-W-01-EFA-01-00-F3	SERIES 90	S90-055MV
9441558	MOTOR-VAR DISPL, CARTRIDGE	90-C-055-NH-0-0-8-N-025-S7-W-01-NNN-01-00-E6	SERIES 90	S90-055MV
95-21002	PUMP-VAR DISPL, CCW	90-L-075-EA-1-NN-60-S-4-S1-D-01-GBA-32-14-20	SERIES 90	S90-075PV
95-21003	PUMP-VAR DISPL, CCW	90-L-075-EA-1-NN-60-S-3-S1-D-01-GBA-32-14-20	SERIES 90	S90-075PV
95-21004	PUMP-VAR DISPL, CCW	90-L-075-EA-1-AB-60-S-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
95-21005	PUMP-VAR DISPL, CCW	90-L-075-MB-1-CD-60-R-4-S1-C-00-GBA-23-23-20	SERIES 90	S90-075PV
95-21006	PUMP-VAR DISPL, CCW	90-L-075-MB-1-NN-60-R-4-S1-C-00-GBA-23-23-20	SERIES 90	S90-075PV
95-21008	PUMP-VAR DISPL, CCW	90-L-075-MB-1-NN-60-P-3-S1-D-03-FAA-42-42-24	SERIES 90	S90-075PV
95-21009	PUMP-VAR DISPL, CCW	90-L-075-EA-1-BB-60-S-3-S1-D-03-GBA-26-26-20	SERIES 90	S90-075PV
95-21010	PUMP-VAR DISPL, CCW	90-L-075-DC-1-NN-80-R-3-S1-D-GB-GBA-35-35-20	SERIES 90	S90-075PV
95-21011	PUMP-VAR DISPL, CCW	90-L-075-MA-1-BC-61-S-4-S1-D-03-GBA-35-35-20	SERIES 90	S90-075PV
95-21012	PUMP-VAR DISPL, CCW	90-L-075-EA-1-NN-80-S-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
95-21014	PUMP-VAR DISPL, CCW	90-L-075-EA-1-AB-60-S-3-S1-D-02-GBA-38-38-24	SERIES 90	S90-075PV
95-21015	PUMP-VAR DISPL, CCW	90-L-075-MB-1-BB-61-S-4-C6-C-03-GBA-35-35-24	SERIES 90	S90-075PV
95-21016	PUMP-VAR DISPL, CCW	90-L-075-EA-1-CD-60-S-4-S1-E-00-GBA-42-42-24	SERIES 90	S90-075PV
95-21017	PUMP-VAR DISPL, CCW	90-L-075-EA-1-NN-60-S-4-S1-E-00-GBA-42-42-24	SERIES 90	S90-075PV
95-21019	PUMP-VAR DISPL, CCW	90-L-075-EP-6-NN-60-S-3-T2-C-01-GBA-48-48-24	SERIES 90	S90-075PV
95-21020	PUMP-VAR DISPL, CCW	90-L-075-EA-2-CD-60-S-3-S1-E-33-GBA-42-14-24	SERIES 90	S90-075PV
95-21021	PUMP-VAR DISPL, CCW	90-L-075-EA-2-NN-60-S-3-S1-E-33-GBA-42-14-24	SERIES 90	S90-075PV
95-21022	PUMP-VAR DISPL, CCW	90-L-075-EP-1-BC-60-P-3-S4-E-05-GBA-38-38-20	SERIES 90	S90-075PV
95-21023	PUMP-VAR DISPL, CCW	90-L-075-EA-1-AB-80-S-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
95-21024	PUMP-VAR DISPL, CCW	90-L-075-EP-1-BB-60-S-3-S1-D-03-GBA-23-23-20	SERIES 90	S90-075PV
95-21025	PUMP-VAR DISPL, CCW	90-L-075-CB-1-NN-60-S-3-S1-D-00-GBA-38-38-24	SERIES 90	S90-075PV
95-21026	PUMP-VAR DISPL, CCW	90-L-075-DC-1-NN-80-L-3-S1-D-GB-GBA-35-35-24	SERIES 90	S90-075PV
95-21027	PUMP-VAR DISPL, CCW	90-L-075-EA-1-NN-80-S-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
95-21028	PUMP-VAR DISPL, CCW	90-L-075-MA-1-NN-80-S-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
95-21029	PUMP-VAR DISPL, CCW	90-L-075-MB-1-AB-61-P-3-K2-D-03-GBA-35-35-24	SERIES 90	S90-075PV
95-21030	PUMP-VAR DISPL, CCW	90-L-075-EA-2-BB-80-S-4-S1-D-33-GBA-42-42-24	SERIES 90	S90-075PV

95-21031	PUMP-VAR DISPL, CCW	90-L-075-MA-1-BC-60-S-4-S1-D-03-GBA-20-20-24	SERIES 90	S90-075PV
95-21032	PUMP-VAR DISPL, CCW	90-L-075-MB-6-CD-81-P-3-S1-D-04-GBA-45-45-24	SERIES 90	S90-075PV
95-21033	PUMP-VAR DISPL, CCW	90-L-075-MB-6-NN-81-P-3-S1-D-04-GBA-45-45-24	SERIES 90	S90-075PV
95-21034	PUMP-VAR DISPL, CCW	90-L-075-MB-6-NN-81-P-3-S1-D-03-GBA-45-45-24	SERIES 90	S90-075PV
95-21036	PUMP-VAR DISPL, CCW	90-L-075-EP-1-NN-60-S-3-S1-D-01-GBA-42-42-24	SERIES 90	S90-075PV
95-21037	PUMP-VAR DISPL, CCW	90-L-075-EA-1-NN-60-R-4-S1-D-02-GBA-35-35-24	SERIES 90	S90-075PV
95-21038	PUMP-VAR DISPL, CCW	90-L-075-EA-1-NN-60-R-3-S1-D-02-GBA-35-35-24	SERIES 90	S90-075PV
95-21039	PUMP-VAR DISPL, CCW	90-L-075-DC-1-NN-80-R-4-S1-C-G8-GBA-20-32-20	SERIES 90	S90-075PV
95-21040	PUMP-VAR DISPL, CCW	90-L-075-MA-1-NN-80-S-3-C7-E-03-GBA-32-32-20	SERIES 90	S90-075PV
95-21041	PUMP-VAR DISPL, CCW	90-L-075-MB-1-NN-60-S-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
95-21043	PUMP-VAR DISPL, CCW	90-L-075-EA-1-BC-80-S-3-S1-D-03-GBA-38-38-20	SERIES 90	S90-075PV
95-21044	PUMP-VAR DISPL, CCW	90-L-075-MA-1-NN-60-S-3-S1-D-03-GFK-38-38-20	SERIES 90	S90-075PV
95-21045	PUMP-VAR DISPL, CCW	90-L-075-MA-1-NN-60-R-3-S1-L-03-GBA-42-42-24	SERIES 90	S90-075PV
95-21046	PUMP-VAR DISPL, CCW	90-L-075-MA-1-NN-61-S-3-C6-D-03-GBA-26-26-20	SERIES 90	S90-075PV
95-21048	PUMP-VAR DISPL, CCW	90-L-075-MB-1-NN-60-R-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
95-21049	PUMP-VAR DISPL, CCW	90-L-075-MB-1-AB-60-R-3-S1-D-03-GBA-38-38-24	SERIES 90	S90-075PV
95-21050	PUMP-VAR DISPL, CCW	90-L-075-EP-1-BC-60-P-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
95-21051	PUMP-VAR DISPL, CCW	90-L-075-MB-1-BC-60-P-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
95-21052	PUMP-VAR DISPL, CCW	90-L-075-EP-1-CD-80-P-3-S1-D-03-GBA-35-35-20	SERIES 90	S90-075PV
95-21053	PUMP-VAR DISPL, CCW	90-L-075-MB-1-NN-60-S-3-S1-D-05-GBA-32-32-24	SERIES 90	S90-075PV
95-21054	PUMP-VAR DISPL, CCW	90-L-075-EP-1-BC-60-S-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
95-21055	PUMP-VAR DISPL, CCW	90-L-075-MA-1-AB-60-R-3-S1-L-03-GBA-42-42-24	SERIES 90	S90-075PV
95-21057	PUMP-VAR DISPL, CCW	90-L-075-EA-2-BC-60-R-3-C6-E-00-GBA-35-35-24	SERIES 90	S90-075PV
95-21059	PUMP-VAR DISPL, CCW	90-L-075-MA-6-AB-80-S-4-S1-D-03-GBA-45-45-24	SERIES 90	S90-075PV
95-21060	PUMP-VAR DISPL, CCW	90-L-075-EP-1-BB-80-S-3-C6-D-03-GBA-29-29-20	SERIES 90	S90-075PV
95-21061	PUMP-VAR DISPL, CCW	90-L-075-EP-1-NN-60-S-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
95-21062	PUMP-VAR DISPL, CCW	90-L-075-EP-1-CD-60-L-3-S1-E-03-GBA-42-42-20	SERIES 90	S90-075PV
95-21063	PUMP-VAR DISPL, CCW	90-L-075-MB-6-BC-81-P-3-S1-D-03-GBA-45-45-24	SERIES 90	S90-075PV
95-21064	PUMP-VAR DISPL, CCW	90-L-075-MB-1-NN-60-S-3-C6-D-03-GBA-38-38-24	SERIES 90	S90-075PV
95-21065	PUMP-VAR DISPL, CCW	90-L-075-EA-1-AB-60-R-3-S1-L-03-FAB-42-42-24	SERIES 90	S90-075PV
95-21066	PUMP-VAR DISPL, CCW	90-L-075-HK-1-NN-80-R-3-S1-D-03-GBA-35-35-20	SERIES 90	S90-075PV
95-21067	PUMP-VAR DISPL, CCW	90-L-075-HK-1-NN-60-R-4-T2-D-03-GBA-35-35-20	SERIES 90	S90-075PV
95-21068	PUMP-VAR DISPL, CCW	90-L-075-HK-1-NN-60-R-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
95-21069	PUMP-VAR DISPL, CCW	90-L-075-HK-1-NN-80-R-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
95-21070	PUMP-VAR DISPL, CCW	90-L-075-HK-1-NN-60-R-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
95-21071	PUMP-VAR DISPL, CCW	90-L-075-HF-1-BC-80-P-3-S1-D-03-GBA-38-38-24	SERIES 90	S90-075PV

95-21072	PUMP-VAR DISPL, CCW	90-L-075-HK-1-BC-60-R-3-S1-E-05-GBA-35-35-24	SERIES 90	S90-075PV
95-21073	PUMP-VAR DISPL, CCW	90-L-075-HM-6-NN-80-S-4-K2-E-03-GBA-45-45-24	SERIES 90	S90-075PV
95-21074	PUMP-VAR DISPL, CCW	90-L-075-HF-1-BB-80-P-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
95-21075	PUMP-VAR DISPL, CCW	90-L-075-MA-1-AB-60-R-3-S1-L-03-FAB-42-42-24	SERIES 90	S90-075PV
95-21076	PUMP-VAR DISPL, CCW	90-L-075-EP-1-BC-80-R-3-S1-E-03-GBA-38-38-24	SERIES 90	S90-075PV
95-21077	PUMP-VAR DISPL, CCW	90-L-075-EA-1-NN-60-S-3-C6-D-03-GBA-35-35-24	SERIES 90	S90-075PV
95-21078	PUMP-VAR DISPL, CCW	90-L-075-EA-1-BC-80-S-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
95-21080	PUMP-VAR DISPL, CCW	90-L-075-MC-1-NN-81-S-3-S1-D-02-GBA-35-35-24	SERIES 90	S90-075PV
95-21081	PUMP-VAR DISPL, CCW	90-L-075-DC-1-NN-80-S-3-S1-D-GB-GBA-35-35-24	SERIES 90	S90-075PV
95-21083	PUMP-VAR DISPL, CCW	90-L-075-HK-1-NN-60-R-3-T2-E-03-GBA-26-26-24	SERIES 90	S90-075PV
95-21085	PUMP-VAR DISPL, CCW	90-L-075-HF-1-NN-60-S-3-S1-D-03-GBA-38-38-24	SERIES 90	S90-075PV
95-21087	PUMP-VAR DISPL, CCW	90-L-075-EA-1-AB-80-R-3-S1-D-03-FAB-42-42-28	SERIES 90	S90-075PV
95-21088	PUMP-VAR DISPL, CCW	90-L-075-EA-1-AB-60-R-3-S1-D-03-FAB-38-38-24	SERIES 90	S90-075PV
95-21090	PUMP-VAR DISPL, CCW	90-L-075-HM-1-NN-60-P-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-075PV
95-21091	PUMP-VAR DISPL, CCW	90-L-075-EP-1-NN-60-P-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-075PV
95-21092	PUMP-VAR DISPL, CCW	90-L-075-EA-1-CD-60-P-4-S1-D-02-GBA-42-42-24	SERIES 90	S90-075PV
95-21093	PUMP-VAR DISPL, CCW	90-L-075-EA-1-NN-60-P-4-S1-D-02-GBA-42-42-24	SERIES 90	S90-075PV
95-21094	PUMP-VAR DISPL, CCW	90-L-075-MA-6-BC-60-S-3-S1-D-03-GBA-48-48-24	SERIES 90	S90-075PV
95-21095	PUMP-VAR DISPL, CCW	90-L-075-MD-1-CD-60-S-3-S1-D-02-GBA-42-42-24	SERIES 90	S90-075PV
95-21096	PUMP-VAR DISPL, CCW	90-L-075-HK-1-BC-80-P-3-S1-D-03-GBA-38-38-24	SERIES 90	S90-075PV
95-21097	PUMP-VAR DISPL, CCW	90-L-075-HK-1-AB-60-R-3-S1-E-05-GBA-38-38-24	SERIES 90	S90-075PV
95-21098	PUMP-VAR DISPL, CCW	90-L-075-HK-1-AB-60-R-3-S1-D-04-GBA-38-38-24	SERIES 90	S90-075PV
95-21099	PUMP-VAR DISPL, CCW	90-L-075-MA-1-BC-60-R-3-S1-E-02-GBA-29-29-20	SERIES 90	S90-075PV
95-21100	PUMP-VAR DISPL, CCW	90-L-075-EA-1-CD-60-L-3-S1-D-06-GBA-38-38-20	SERIES 90	S90-075PV
95-21101	PUMP-VAR DISPL, CCW	90-L-075-EP-1-BC-60-L-3-S1-E-03-GFD-42-42-20	SERIES 90	S90-075PV
95-21102	PUMP-VAR DISPL, CCW	90-L-075-MA-1-NN-80-S-3-C7-D-04-FAC-38-38-24	SERIES 90	S90-075PV
95-21104	PUMP-VAR DISPL, CCW	90-L-075-HM-1-NN-80-S-3-C7-D-04-FAC-38-38-24	SERIES 90	S90-075PV
95-21105	PUMP-VAR DISPL, CCW	90-L-075-MB-6-CD-81-P-3-S1-D-03-GBA-45-45-24	SERIES 90	S90-075PV
95-21107	PUMP-VAR DISPL, CCW	90-L-075-MA-1-NN-60-S-3-T1-E-05-GBA-42-42-24	SERIES 90	S90-075PV
95-21108	PUMP-VAR DISPL, CCW	90-L-075-MB-1-BB-61-S-3-C6-E-03-GBA-35-35-24	SERIES 90	S90-075PV
95-21110	PUMP-VAR DISPL, CCW	90-L-075-MA-1-AB-60-R-3-S1-L-03-FAA-42-42-24	SERIES 90	S90-075PV
95-21118	PUMP-VAR DISPL, CCW	90-L-075-EA-1-AB-60-R-3-S1-L-03-FAA-42-42-24	SERIES 90	S90-075PV
95-21119	PUMP-VAR DISPL, CCW	90-L-075-EA-1-NN-80-S-3-C7-D-04-FAC-38-38-24	SERIES 90	S90-075PV
95-21120	PUMP-VAR DISPL, CCW	90-L-075-EA-1-BB-80-S-3-C6-D-03-GBA-38-38-20	SERIES 90	S90-075PV
95-21121	PUMP-VAR DISPL, CCW	90-L-075-EP-1-CD-80-S-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-075PV
95-21122	PUMP-VAR DISPL, CCW	90-L-075-MC-1-CD-60-R-3-S1-D-02-GBA-32-32-24	SERIES 90	S90-075PV

95-21123	PUMP-VAR DISPL, CCW	90-L-075-EA-A-BB-60-R-3-T1-C-03-GBA-38-38-24	SERIES 90	S90-075PV
95-21125	PUMP-VAR DISPL, CCW	90-L-075-EA-1-NN-81-S-3-T2-E-03-GBA-35-35-20	SERIES 90	S90-075PV
95-21126	PUMP-VAR DISPL, CCW	90-L-075-EA-1-AB-81-S-3-T2-E-03-GBA-35-35-20	SERIES 90	S90-075PV
95-21127	PUMP-VAR DISPL, CCW	90-L-075-EA-1-AB-80-S-3-C7-D-04-GBA-38-38-24	SERIES 90	S90-075PV
95-21127C	PUMP-VAR DISPL, CCW 90PV075	90-L-075-EA-1-AB-80-S-3-C7-D-04-GBA-38-38-24	SERIES 90	S90-075PV
95-21128	PUMP-VAR DISPL, CCW	90-L-075-EA-1-BC-60-P-3-C6-D-03-GBA-23-23-24	SERIES 90	S90-075PV
95-21129	PUMP-VAR DISPL, CCW	90-L-075-EP-1-BC-80-R-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-075PV
95-21130	PUMP-VAR DISPL, CCW	90-L-075-ME-1-NN-80-S-3-S1-E-03-GBA-35-35-20	SERIES 90	S90-075PV
95-21131	PUMP-VAR DISPL, CCW	90-L-075-MB-1-NN-80-S-3-S1-E-03-GBA-35-35-20	SERIES 90	S90-075PV
95-21133	PUMP-VAR DISPL, CCW	90-L-075-HF-1-CD-80-P-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-075PV
95-21134	PUMP-VAR DISPL, CCW	90-L-075-EP-1-BB-60-P-3-S4-E-05-GBA-38-38-20	SERIES 90	S90-075PV
95-21135	PUMP-VAR DISPL, CCW	90-L-075-EX-1-NN-60-S-3-S1-D-03-GBA-29-29-24	SERIES 90	S90-075PV
95-21136	PUMP-VAR DISPL, CCW	90-L-075-MB-1-AB-60-P-3-S1-D-03-FAB-42-42-24	SERIES 90	S90-075PV
95-21139	PUMP-VAR DISPL, CCW	90-L-075-EP-1-NN-60-P-3-S1-D-03-GBA-35-35-20	SERIES 90	S90-075PV
95-2230	PUMP-VAR DISPL, CCW	90-L-075-MB-1-NN-60-S-3-S1-D-05-GBA-42-42-24	SERIES 90	S90-075PV
95-2295	PUMP-VAR DISPL, CCW	90-L-075-EA-1-NN-80-S-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
95-2297	PUMP-VAR DISPL, CCW	90-L-075-MA-1-NN-60-R-3-S1-D-03-GBA-32-32-24	SERIES 90	S90-075PV
95-2298	PUMP-VAR DISPL, CW	90-R-075-MB-1-BC-60-S-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
95-2299	PUMP-VAR DISPL, CCW	90-L-075-MA-1-CD-61-S-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
95-2300	PUMP-VAR DISPL, CCW	90-L-075-EA-1-NN-60-S-3-S1-D-03-GBA-14-14-20	SERIES 90	S90-075PV
95-2301	PUMP-VAR DISPL, CW	90-R-075-EA-1-BC-60-S-3-S1-D-02-GBA-26-26-24	SERIES 90	S90-075PV
95-2302	PUMP-VAR DISPL, CCW	90-L-075-MB-1-CD-60-S-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
95-2303	PUMP-VAR DISPL, CCW	90-L-075-MB-1-AB-60-R-3-S1-D-03-GBA-32-32-24	SERIES 90	S90-075PV
95-2304	PUMP-VAR DISPL, CW	90-R-075-MA-1-NN-60-R-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
95-2305	PUMP-VAR DISPL, CCW	90-L-075-EA-1-BC-60-R-3-C7-D-03-GBA-32-32-24	SERIES 90	S90-075PV
95-2306	PUMP-VAR DISPL, CW	90-R-075-MA-1-NN-60-P-3-C7-D-02-GFK-42-42-24	SERIES 90	S90-075PV
95-2308	PUMP-VAR DISPL, CW	90-R-075-EA-1-NN-60-S-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
95-2309	PUMP-VAR DISPL, CW	90-R-075-MA-1-CD-60-R-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
95-2311	PUMP-VAR DISPL, CCW	90-L-075-MB-1-BC-60-S-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
95-2324	PUMP-VAR DISPL, CW	90-R-075-MA-1-BC-60-S-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
95-2325	PUMP-VAR DISPL, CW	90-R-075-MA-1-BC-60-S-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
95-2338	PUMP-VAR DISPL, CCW	90-L-075-MA-1-BC-81-S-3-S1-D-03-GBA-14-14-24	SERIES 90	S90-075PV
95-2339	PUMP-VAR DISPL, CW	90-R-075-EA-1-AB-80-P-3-S1-D-04-GBA-38-38-24	SERIES 90	S90-075PV
95-2342	PUMP-VAR DISPL, CCW	90-L-075-MA-1-BC-60-S-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
95-2343	PUMP-VAR DISPL, CW	90-R-075-EA-1-AB-60-S-3-S1-D-03-GBA-26-26-24	SERIES 90	S90-075PV
95-2344	PUMP-VAR DISPL, CCW	90-L-075-EA-1-CD-60-S-3-S1-D-03-GBA-42-14-24	SERIES 90	S90-075PV

95-2420	PUMP-VAR DISPL, CW	90-R-075-MB-1-NN-80-S-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-075PV
95-2422	PUMP-VAR DISPL, CCW	90-L-075-MA-1-NN-81-S-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
95-2423	PUMP-VAR DISPL, CW	90-R-075-MA-1-NN-61-S-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
95-2424	PUMP-VAR DISPL, CCW	90-L-075-MA-1-NN-61-S-3-C7-D-03-GBA-35-35-24	SERIES 90	S90-075PV
95-2426	PUMP-VAR DISPL, CCW	90-L-075-MA-1-BC-60-S-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
95-2427	PUMP-VAR DISPL, CCW	90-L-075-MA-1-CD-60-S-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
95-2428	PUMP-VAR DISPL, CCW	90-L-075-MA-1-NN-60-S-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
95-2430	PUMP-VAR DISPL, CW	90-R-075-MB-1-BC-60-S-3-S1-D-03-GBA-38-38-24	SERIES 90	S90-075PV
95-2431	PUMP-VAR DISPL, CCW	90-L-075-EA-1-BC-61-S-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
95-2432	PUMP-VAR DISPL, CW	90-R-075-MB-1-NN-60-S-3-S1-D-03-GBA-35-35-20	SERIES 90	S90-075PV
95-2434	PUMP-VAR DISPL, CCW	90-L-075-EA-1-NN-60-P-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
95-2435	PUMP-VAR DISPL, CW	90-R-075-MA-1-NN-60-S-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
95-2436	PUMP-VAR DISPL, CW	90-R-075-MA-1-BC-60-S-3-C7-E-03-GFK-35-35-20	SERIES 90	S90-075PV
95-2438	PUMP-VAR DISPL, CW	90-R-075-MB-1-BC-80-P-3-S1-D-03-GBA-23-23-20	SERIES 90	S90-075PV
95-2443	PUMP-VAR DISPL, CCW	90-L-075-EA-1-CD-60-S-3-S1-D-03-GBA-14-14-20	SERIES 90	S90-075PV
95-2444	PUMP-VAR DISPL, CW	90-R-075-MA-1-AB-60-S-3-S1-D-03-GBA-42-42-20	SERIES 90	S90-075PV
95-2445	PUMP-VAR DISPL, CCW	90-L-075-MB-1-BB-60-P-3-T2-D-03-GBA-42-42-24	SERIES 90	S90-075PV
95-2446	PUMP-VAR DISPL, CCW	90-L-075-EA-1-BB-60-S-3-C6-C-03-GBA-42-42-24	SERIES 90	S90-075PV
95-2447	PUMP-VAR DISPL, CCW	90-L-075-MA-1-BC-60-S-3-S1-D-03-GBA-38-38-24	SERIES 90	S90-075PV
95-2448	PUMP-VAR DISPL, CW	90-R-075-EA-1-BC-80-S-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-075PV
95-2450	PUMP-VAR DISPL, CW	90-R-075-EA-1-NN-80-S-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
95-2451	PUMP-VAR DISPL, CW	90-R-075-MA-1-NN-80-S-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
95-2451C	PUMP-VAR DISPL, CW	90-R-075-MA-1-NN-80-S-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
95-2452	PUMP-VAR DISPL, CCW	90-L-075-EA-1-NN-60-S-3-S1-D-03-GBA-42-14-24	SERIES 90	S90-075PV
95-2461	PUMP-VAR DISPL, CW	90-R-075-EA-1-BC-60-S-3-S1-D-03-GBA-26-26-24	SERIES 90	S90-075PV
95-2464	PUMP-VAR DISPL, CCW	90-L-075-EA-1-BC-60-S-3-S1-D-03-GBA-32-32-24	SERIES 90	S90-075PV
95-2466	PUMP-VAR DISPL, CCW	90-L-075-EA-1-CD-60-S-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
95-2470	PUMP-VAR DISPL, CCW	90-L-075-MC-1-BC-60-S-3-S1-D-02-GBA-42-42-24	SERIES 90	S90-075PV
95-2472	PUMP-VAR DISPL, CW	90-R-075-MC-1-AB-60-S-3-S1-D-02-GBA-42-42-24	SERIES 90	S90-075PV
95-2473	PUMP-VAR DISPL, CCW	90-L-075-MA-1-BC-61-S-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
95-2475	PUMP-VAR DISPL, CCW	90-L-075-EA-1-NN-60-S-3-S1-D-03-GBA-29-29-24	SERIES 90	S90-075PV
95-2477	PUMP-VAR DISPL, CW	90-R-075-MA-1-NN-61-S-3-S1-D-03-GBA-32-32-24	SERIES 90	S90-075PV
95-2478	PUMP-VAR DISPL, CCW	90-L-075-EP-1-CD-60-P-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
95-2479	PUMP-VAR DISPL, CCW	90-L-075-MB-1-AB-60-P-4-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
95-2480	PUMP-VAR DISPL, CCW	90-L-075-MA-1-AB-61-S-3-T2-D-03-GBA-35-35-24	SERIES 90	S90-075PV
95-2487	PUMP-VAR DISPL, CCW	90-L-075-EA-1-BB-60-S-3-C6-E-03-GBA-29-29-24	SERIES 90	S90-075PV

95-2488	PUMP-VAR DISPL, CCW	90-L-075-EA-1-CD-60-S-3-S1-E-03-GBA-42-14-24	SERIES 90	S90-075PV
95-2489	PUMP-VAR DISPL, CCW	90-L-075-EA-1-NN-60-S-3-S1-E-03-GBA-42-14-24	SERIES 90	S90-075PV
95-2490	PUMP-VAR DISPL, CCW	90-L-075-EA-1-NN-60-P-4-S1-D-02-GBA-35-35-24	SERIES 90	S90-075PV
95-2494	PUMP-VAR DISPL, CW	90-R-075-MB-1-BC-61-R-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
95-2495	PUMP-VAR DISPL, CCW	90-L-075-EP-1-BC-60-S-3-T2-D-03-GBA-32-32-24	SERIES 90	S90-075PV
95-2501	PUMP-VAR DISPL, CW	90-R-075-EA-1-NN-60-S-3-S1-D-00-GBA-35-35-24	SERIES 90	S90-075PV
95-2502	PUMP-VAR DISPL, CW	90-R-075-EA-1-CD-60-S-3-S1-D-00-GBA-35-35-24	SERIES 90	S90-075PV
95-2503	PUMP-VAR DISPL, CW	90-R-075-EA-1-AB-60-S-3-S1-D-00-GBA-35-35-24	SERIES 90	S90-075PV
95-2504	PUMP-VAR DISPL, CCW	90-L-075-EA-1-CD-60-R-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
95-2505	PUMP-VAR DISPL, CW	90-R-075-MA-1-CD-61-S-3-S1-E-03-GBA-35-35-20	SERIES 90	S90-075PV
95-2506	PUMP-VAR DISPL, CW	90-R-075-MA-1-BC-61-P-3-S1-D-03-GBA-35-35-20	SERIES 90	S90-075PV
95-2509	PUMP-VAR DISPL, CW	90-R-075-MB-1-BB-60-P-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
95-2510	PUMP-VAR DISPL, CCW	90-L-075-EA-1-BC-60-S-3-S1-D-03-GBA-35-35-20	SERIES 90	S90-075PV
95-2511	PUMP-VAR DISPL, CCW	90-L-075-EA-1-NN-60-S-3-S1-D-03-GBA-35-35-20	SERIES 90	S90-075PV
95-2514	PUMP-VAR DISPL, CW	90-R-075-MA-1-AB-61-S-3-S1-E-03-GBA-32-32-24	SERIES 90	S90-075PV
95-2520	PUMP-VAR DISPL, CW	90-R-075-MA-1-BC-60-S-3-S1-D-03-GBA-42-42-20	SERIES 90	S90-075PV
95-2525	PUMP-VAR DISPL, CCW	90-L-075-EA-6-BC-80-S-3-S1-D-03-GBA-45-45-24	SERIES 90	S90-075PV
95-2527	PUMP-VAR DISPL, CCW	90-L-075-EA-1-BC-60-S-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
95-2528	PUMP-VAR DISPL, CCW	90-L-075-EA-1-NN-60-S-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
95-2530	PUMP-VAR DISPL, CW	90-R-075-MA-1-NN-60-S-3-C7-D-03-GBA-42-42-20	SERIES 90	S90-075PV
95-2531	PUMP-VAR DISPL, CCW	90-L-075-MA-1-NN-61-S-3-C7-D-03-GBA-29-29-20	SERIES 90	S90-075PV
95-2532	PUMP-VAR DISPL, CCW	90-L-075-MA-1-BC-60-S-3-S1-D-03-GBA-35-35-20	SERIES 90	S90-075PV
95-2533	PUMP-VAR DISPL, CW	90-R-075-EA-1-CD-60-P-3-S1-D-03-GBA-23-23-24	SERIES 90	S90-075PV
95-2534	PUMP-VAR DISPL, CCW	90-L-075-EA-1-CD-60-S-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
95-2536	PUMP-VAR DISPL, CCW	90-L-075-EA-1-NN-61-P-3-S1-D-00-GBA-35-35-24	SERIES 90	S90-075PV
95-2537	PUMP-VAR DISPL, CCW	90-L-075-MA-1-NN-61-S-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
95-2539	PUMP-VAR DISPL, CCW	90-L-075-MB-1-BC-60-S-3-S1-E-05-GBA-35-35-24	SERIES 90	S90-075PV
95-2540	PUMP-VAR DISPL, CCW	90-L-075-EP-1-NN-60-S-3-T2-D-03-GBA-29-29-20	SERIES 90	S90-075PV
95-2541	PUMP-VAR DISPL, CCW	90-L-075-EA-1-NN-60-S-3-T2-C-04-GBA-42-42-20	SERIES 90	S90-075PV
95-2549	PUMP-VAR DISPL, CCW	90-L-075-EA-1-BC-60-L-3-S1-D-03-GBA-26-26-24	SERIES 90	S90-075PV
95-2550	PUMP-VAR DISPL, CW	90-R-075-EA-1-NN-60-P-3-S1-D-02-GBA-29-29-24	SERIES 90	S90-075PV
95-2551	PUMP-VAR DISPL, CCW	90-L-075-EA-1-NN-60-S-3-T1-D-03-GBA-26-26-20	SERIES 90	S90-075PV
95-2553	PUMP-VAR DISPL, CW	90-R-075-EA-1-NN-80-S-3-S1-D-03-GBA-26-26-20	SERIES 90	S90-075PV
95-2554	PUMP-VAR DISPL, CW	90-R-075-EA-1-BC-80-S-3-S1-D-03-GBA-26-26-20	SERIES 90	S90-075PV
95-2559	PUMP-VAR DISPL, CCW	90-L-075-MA-1-AB-80-S-3-S1-E-03-GBA-35-35-20	SERIES 90	S90-075PV
95-2560	PUMP-VAR DISPL, CCW	90-L-075-EA-1-AB-80-R-3-T2-E-03-GBA-35-35-20	SERIES 90	S90-075PV

95-2564	PUMP-VAR DISPL, CW	90-R-075-MB-1-BC-60-S-3-S1-D-03-GBA-35-35-20	SERIES 90	S90-075PV
95-2570	PUMP-VAR DISPL, CCW	90-L-075-EA-1-BC-60-R-3-S1-D-03-GBA-26-26-20	SERIES 90	S90-075PV
95-2573	PUMP-VAR DISPL, CW	90-R-075-EA-1-NN-60-S-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-075PV
95-2575	PUMP-VAR DISPL, CW	90-R-075-MA-1-BC-60-S-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-075PV
95-2576	PUMP-VAR DISPL, CW	90-R-075-MA-1-CD-60-S-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-075PV
95-2577	PUMP-VAR DISPL, CW	90-R-075-MB-1-NN-80-L-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-075PV
95-2578	PUMP-VAR DISPL, CW	90-R-075-EA-1-BC-61-R-4-S1-D-03-GBA-23-23-20	SERIES 90	S90-075PV
95-2579	PUMP-VAR DISPL, CCW	90-L-075-EP-1-BC-60-S-3-S1-D-03-GBA-23-23-20	SERIES 90	S90-075PV
95-2580	PUMP-VAR DISPL, CCW	90-L-075-EA-1-NN-60-S-3-S1-E-09-GBA-35-35-28	SERIES 90	S90-075PV
95-2581	PUMP-VAR DISPL, CW	90-R-075-MA-1-AB-61-S-3-S1-E-03-GBA-38-38-20	SERIES 90	S90-075PV
95-2582	PUMP-VAR DISPL, CCW	90-L-075-MA-1-BC-61-S-3-T1-D-03-GBA-23-23-20	SERIES 90	S90-075PV
95-2583	PUMP-VAR DISPL, CW	90-R-075-EA-1-AB-60-P-3-T2-D-03-GBA-38-14-28	SERIES 90	S90-075PV
95-2584	PUMP-VAR DISPL, CCW	90-L-075-EA-1-CD-80-P-4-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
95-2585	PUMP-VAR DISPL, CW	90-R-075-EA-1-NN-61-R-3-S1-D-00-GBA-42-42-24	SERIES 90	S90-075PV
95-2586	PUMP-VAR DISPL, CCW	90-L-075-EA-1-CD-80-P-4-C7-D-03-GBA-42-42-24	SERIES 90	S90-075PV
95-2588	PUMP-VAR DISPL, CW	90-R-075-EP-1-CD-80-R-3-S1-E-00-GBA-42-42-20	SERIES 90	S90-075PV
95-2589	PUMP-VAR DISPL, CW	90-R-075-EP-1-CD-80-R-3-C7-E-00-GBA-42-42-20	SERIES 90	S90-075PV
95-2590	PUMP-VAR DISPL, CW	90-R-075-MB-1-BC-60-S-3-C6-D-03-GBA-35-35-24	SERIES 90	S90-075PV
95-2591	PUMP-VAR DISPL, CW	90-R-075-MA-1-BC-61-S-3-S1-E-03-GBA-38-38-20	SERIES 90	S90-075PV
95-2592	PUMP-VAR DISPL, CCW	90-L-075-EP-1-NN-60-P-4-S1-E-02-GBA-32-14-24	SERIES 90	S90-075PV
95-2593	PUMP-VAR DISPL, CCW	90-L-075-MB-1-NN-61-R-3-S1-D-03-GBA-35-35-20	SERIES 90	S90-075PV
95-2594	PUMP-VAR DISPL, CW	90-R-075-EA-1-NN-61-S-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-075PV
95-2595	PUMP-VAR DISPL, CCW	90-L-075-EA-1-AB-60-R-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
95-2596	PUMP-VAR DISPL, CW	90-R-075-MB-1-AB-80-S-3-S1-D-03-GBA-42-42-20	SERIES 90	S90-075PV
95-2597	PUMP-VAR DISPL, CW	90-R-075-MB-1-BC-80-S-3-S1-D-03-GBA-42-42-20	SERIES 90	S90-075PV
95-2598	PUMP-VAR DISPL, CW	90-R-075-EP-1-NN-80-S-3-S1-D-03-GBA-42-42-20	SERIES 90	S90-075PV
95-2600	PUMP-VAR DISPL, CW	90-R-075-EA-1-NN-80-R-3-S1-D-03-GBA-38-38-24	SERIES 90	S90-075PV
95-2601	PUMP-VAR DISPL, CCW	90-L-075-MB-1-NN-60-S-3-S1-E-03-GBA-32-32-24	SERIES 90	S90-075PV
95-2602	PUMP-VAR DISPL, CW	90-R-075-MA-1-BC-61-S-3-S1-D-03-GBA-14-14-24	SERIES 90	S90-075PV
95-2603	PUMP-VAR DISPL, CCW	90-L-075-EA-1-CD-61-S-3-S1-D-03-GBA-42-42-20	SERIES 90	S90-075PV
95-2604	PUMP-VAR DISPL, CCW	90-L-075-EA-1-AB-61-S-3-S1-D-03-GBA-42-42-20	SERIES 90	S90-075PV
95-2605	PUMP-VAR DISPL, CCW	90-L-075-EP-1-AB-60-S-3-S1-D-03-GBA-35-35-20	SERIES 90	S90-075PV
95-2606	PUMP-VAR DISPL, CCW	90-L-075-EA-1-AB-60-R-4-S1-D-03-GBA-23-23-24	SERIES 90	S90-075PV
95-2607	PUMP-VAR DISPL, CW	90-R-075-MD-1-NN-80-S-3-S1-D-02-GBA-42-42-20	SERIES 90	S90-075PV
95-2608	PUMP-VAR DISPL, CCW	90-L-075-EP-1-BC-60-S-3-S1-D-03-GBA-38-38-20	SERIES 90	S90-075PV
95-2609	PUMP-VAR DISPL, CW	90-R-075-EA-1-AB-61-P-3-S1-E-03-GBA-17-17-24	SERIES 90	S90-075PV

95-2610	PUMP-VAR DISPL, CW	90-R-075-MA-1-BC-60-L-3-S1-D-06-GBA-35-35-24	SERIES 90	S90-075PV
95-2611	PUMP-VAR DISPL, CCW	90-L-075-EA-1-AB-60-R-3-S1-L-03-GBA-42-42-24	SERIES 90	S90-075PV
95-2612	PUMP-VAR DISPL, CW	90-R-075-MD-1-NN-60-S-3-S1-D-02-GBA-38-38-24	SERIES 90	S90-075PV
95-2613	PUMP-VAR DISPL, CCW	90-L-075-MB-1-BB-61-S-3-C6-C-03-GBA-42-42-24	SERIES 90	S90-075PV
95-2614	PUMP-VAR DISPL, CW	90-R-075-EA-1-AB-61-R-3-S1-D-03-GBA-32-32-24	SERIES 90	S90-075PV
95-2615	PUMP-VAR DISPL, CW	90-R-075-MB-1-BC-60-S-3-C6-D-03-GBA-42-42-24	SERIES 90	S90-075PV
95-2616	PUMP-VAR DISPL, CCW	90-L-075-MA-1-NN-61-S-3-C6-C-03-GBA-35-35-24	SERIES 90	S90-075PV
95-2617	PUMP-VAR DISPL, CCW	90-L-075-MA-1-BB-61-S-3-C6-C-03-GBA-35-35-24	SERIES 90	S90-075PV
95-2618	PUMP-VAR DISPL, CW	90-R-075-EA-1-NN-60-P-3-C7-D-02-GBA-42-42-24	SERIES 90	S90-075PV
95-2619	PUMP-VAR DISPL, CW	90-R-075-MA-1-CD-81-P-3-S1-D-03-GBA-32-32-20	SERIES 90	S90-075PV
95-2620	PUMP-VAR DISPL, CW	90-R-075-MA-1-NN-81-P-3-S1-D-03-GBA-32-32-20	SERIES 90	S90-075PV
95-2621	PUMP-VAR DISPL, CCW	90-L-075-EA-1-BB-80-S-4-S1-D-00-GBA-42-42-24	SERIES 90	S90-075PV
95-2622	PUMP-VAR DISPL, CCW	90-L-075-EA-1-BC-60-R-3-S4-E-05-GBA-38-38-20	SERIES 90	S90-075PV
95-2623	PUMP-VAR DISPL, CW	90-R-075-EP-1-BC-60-S-3-S1-D-03-GBA-32-32-20	SERIES 90	S90-075PV
95-2624	PUMP-VAR DISPL, CCW	90-L-075-CB-1-NN-60-L-3-S1-D-00-GBA-23-23-20	SERIES 90	S90-075PV
95-2625	PUMP-VAR DISPL, CW	90-R-075-EA-1-CD-60-S-3-C7-D-03-GBA-26-26-20	SERIES 90	S90-075PV
95-2626	PUMP-VAR DISPL, CCW	90-L-075-MB-1-AB-60-R-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
95-2627	PUMP-VAR DISPL CW	90-R-075-CB-1-NN-60-L-3-S1-D-00-GBA-35-35-24	SERIES 90	S90-075PV
95-2629	PUMP-VAR DISPL, CW	90-R-075-EA-1-AB-81-P-3-S1-D-03-GBA-35-35-20	SERIES 90	S90-075PV
95-2630	PUMP-VAR DISPL, CCW	90-L-075-MA-1-NN-81-R-3-S1-D-03-GBA-32-32-24	SERIES 90	S90-075PV
95-2631	PUMP-VAR DISPL, CCW	90-L-075-MA-1-NN-60-S-3-S1-D-03-GBA-38-38-24	SERIES 90	S90-075PV
95-2631C	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-1-NN-60-S-3-S1-D-03-GBA-38-38-24	SERIES 90	S90-075PV
95-2632	PUMP-VAR DISPL, CW	90-R-075-EA-1-CD-60-S-3-S1-D-03-GBA-26-26-24	SERIES 90	S90-075PV
95-2634	PUMP-VAR DISPL, CW	90-R-075-MK-1-BF-60-P-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
95-2635	PUMP-VAR DISPL, CW	90-R-075-EA-1-NN-61-L-3-S1-D-03-GBA-42-42-20	SERIES 90	S90-075PV
95-2636	PUMP-VAR DISPL, CW	90-R-075-EA-1-AB-61-L-3-S1-D-03-GBA-42-42-20	SERIES 90	S90-075PV
95-2637	PUMP-VAR DISPL, CCW	90-L-075-EA-1-BC-60-S-3-S1-D-03-GBA-26-26-24	SERIES 90	S90-075PV
95-2638	PUMP-VAR DISPL, CCW	90-L-075-MA-1-BC-60-P-3-S1-D-03-GBA-38-38-20	SERIES 90	S90-075PV
95-2639	PUMP-VAR DISPL, CW	90-R-075-EA-1-AB-60-P-3-T2-D-00-GBA-38-14-20	SERIES 90	S90-075PV
95-2640	PUMP-VAR DISPL, CW	90-R-075-MA-1-CD-81-P-3-S1-D-04-GBA-32-32-20	SERIES 90	S90-075PV
95-2641	PUMP-VAR DISPL, CW	90-R-075-EA-1-BC-60-S-3-S1-D-00-GBA-26-26-24	SERIES 90	S90-075PV
95-2642	PUMP-VAR DISPL, CW	90-R-075-EA-1-BB-60-S-3-S1-D-00-GBA-26-26-24	SERIES 90	S90-075PV
95-2644	PUMP-VAR DISPL, CCW	90-L-075-EA-1-AB-80-R-4-S1-E-03-GBA-23-23-24	SERIES 90	S90-075PV
95-2645	PUMP-VAR DISPL, CW	90-R-075-EA-1-NN-80-L-3-S1-D-03-GBA-42-42-20	SERIES 90	S90-075PV
95-2646	PUMP-VAR DISPL, CW	90-R-075-MA-1-NN-60-S-3-S1-D-03-GBA-42-42-20	SERIES 90	S90-075PV
95-2648	PUMP-VAR DISPL, CW	90-R-075-MA-1-BB-60-S-3-S1-D-03-GBA-26-26-20	SERIES 90	S90-075PV

95-2649	PUMP-VAR DISPL, CCW	90-L-075-EP-1-NN-60-S-3-S1-E-09-GBA-35-35-28	SERIES 90	S90-075PV
95-2650	PUMP-VAR DISPL, CW	90-R-075-MB-1-NN-60-P-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
95-2651	PUMP-VAR DISPL, CCW	90-L-075-MA-1-AB-60-P-3-S1-D-03-GBA-38-38-20	SERIES 90	S90-075PV
95-2652	PUMP-VAR DISPL, CW	90-R-075-MB-1-BC-60-L-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-075PV
95-2653	PUMP-VAR DISPL, CCW	90-L-075-EP-1-CD-60-S-3-S1-D-03-GBA-32-32-20	SERIES 90	S90-075PV
95-2654	PUMP-VAR DISPL, CCW	90-L-075-EA-1-NN-60-S-3-T2-D-00-GBA-17-17-24	SERIES 90	S90-075PV
95-2655	PUMP-VAR DISPL, CCW	90-L-075-MA-1-AB-80-P-3-S1-D-03-GBA-29-29-24	SERIES 90	S90-075PV
95-2656	PUMP-VAR DISPL, CCW	90-L-075-MA-1-AB-60-P-3-S1-D-03-GBA-29-29-24	SERIES 90	S90-075PV
95-2661	PUMP-VAR DISPL, CW	90-R-075-EA-1-NN-81-R-3-T2-E-03-GBA-35-35-20	SERIES 90	S90-075PV
95-2662	PUMP-VAR DISPL, CCW	90-L-075-EA-1-NN-81-R-3-T2-E-03-GBA-35-35-20	SERIES 90	S90-075PV
95-2663	PUMP-VAR DISPL, CW	90-R-075-EA-1-AB-81-R-3-T2-E-03-GBA-35-35-20	SERIES 90	S90-075PV
95-2664	PUMP-VAR DISPL, CCW	90-L-075-EA-1-AB-81-R-3-T2-E-03-GBA-35-35-20	SERIES 90	S90-075PV
95-2665	PUMP-VAR DISPL, CW	90-R-075-EA-1-BC-80-R-3-S1-D-00-GBA-42-42-24	SERIES 90	S90-075PV
95-2667	PUMP-VAR DISPL, CCW	90-L-075-EA-1-NN-60-R-3-S1-D-03-GBA-23-23-24	SERIES 90	S90-075PV
95-2669	PUMP-VAR DISPL, CCW	90-L-075-MB-1-NN-60-P-3-S1-D-05-GBA-42-42-24	SERIES 90	S90-075PV
95-2670	PUMP-VAR DISPL, CW	90-R-075-MB-1-BC-60-S-3-S1-D-03-GBA-35-14-24	SERIES 90	S90-075PV
95-2671	PUMP-VAR DISPL, CCW	90-L-075-EA-1-BC-61-P-4-C6-E-03-GBA-29-29-20	SERIES 90	S90-075PV
95-2672	PUMP-VAR DISPL, CW	90-R-075-EA-1-NN-60-S-4-S1-D-03-GBA-42-42-20	SERIES 90	S90-075PV
95-2673	PUMP-VAR DISPL, CCW	90-L-075-MB-1-CD-60-P-3-S1-D-03-GBA-32-32-24	SERIES 90	S90-075PV
95-2676	PUMP-VAR DISPL, CW	90-R-075-MB-1-NN-60-S-3-S1-D-05-GBA-42-42-24	SERIES 90	S90-075PV
95-2678	PUMP-VAR DISPL, CW	90-R-075-EA-1-BC-80-P-3-S1-D-04-GBA-38-38-24	SERIES 90	S90-075PV
95-2680	PUMP-VAR DISPL, CW	90-R-075-MA-1-NN-60-S-3-C7-C-22-GBA-42-42-20	SERIES 90	S90-075PV
95-2681	PUMP-VAR DISPL, CW	90-R-075-MA-1-NN-80-R-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
95-2682	PUMP-VAR DISPL, CW	90-R-075-EA-1-NN-80-S-4-S1-D-03-GBA-17-17-20	SERIES 90	S90-075PV
95-2683	PUMP-VAR DISPL, CW	90-R-075-EA-1-CD-60-S-3-S1-D-03-GBA-38-38-24	SERIES 90	S90-075PV
95-2684	PUMP-VAR DISPL, CW	90-R-075-EA-1-NN-60-S-3-S1-D-02-GBA-38-38-24	SERIES 90	S90-075PV
95-2685	PUMP-VAR DISPL, CW	90-R-075-MA-1-NN-60-R-3-S1-D-03-GBA-20-20-24	SERIES 90	S90-075PV
95-2686	PUMP-VAR DISPL, CW	90-R-075-EP-1-NN-80-S-4-S1-D-03-GBA-17-17-20	SERIES 90	S90-075PV
95-2687	PUMP-VAR DISPL, CW	90-R-075-MA-1-BC-60-S-4-S1-D-03-GBA-20-20-24	SERIES 90	S90-075PV
95-2688	PUMP-VAR DISPL, CW	90-R-075-MB-1-AB-60-L-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
95-2689	PUMP-VAR DISPL, CW	90-R-075-MB-1-CD-80-P-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
95-2690	PUMP-VAR DISPL, CW	90-R-075-EA-1-BC-60-P-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
95-2692	PUMP-VAR DISPL, CW	90-R-075-MA-1-CD-60-S-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
95-2693	PUMP-VAR DISPL, CW	90-R-075-MA-1-AB-60-S-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
95-2694	FUMP-VAR DISPL, CW	90-R-075-EA-1-AB-60-L-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-075PV
95-2695	PUMP-VAR DISPL, CW	90-R-075-EA-1-BC-60-L-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-075PV

95-2696	PUMP-VAR DISPL, CW	90-R-075-EP-1-BC-60-L-3-S1-E-00-GBA-35-35-24	SERIES 90	S90-075PV
95-2697	PUMP-VAR DISPL, CW	90-R-075-MB-1-AB-60-L-3-C7-D-03-GBA-42-42-24	SERIES 90	S90-075PV
95-2698	PUMP-VAR DISPL, CW	90-R-075-MK-1-NN-60-P-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
95-2699	PUMP-VAR DISPL, CW	90-R-075-EA-1-AB-61-R-3-S1-E-03-GBA-20-20-20	SERIES 90	S90-075PV
95-2700	PUMP-VAR DISPL, CW	90-R-075-MB-1-NN-60-L-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-075PV
95-2701	PUMP-VAR DISPL, CW	90-R-075-EA-1-AB-60-L-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
95-2702	PUMP-VAR DISPL, CW	90-R-075-MB-1-BC-60-L-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
95-2703	PUMP-VAR DISPL, CW	90-R-075-EP-1-BC-60-L-3-S1-D-00-GBA-23-23-20	SERIES 90	S90-075PV
95-2704	PUMP-VAR DISPL, CW	90-R-075-EA-1-BC-60-R-3-S1-D-00-GBA-42-42-24	SERIES 90	S90-075PV
95-2705	PUMP-VAR DISPL, CW	90-R-075-MA-1-BB-60-P-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-075PV
95-2706	PUMP-VAR DISPL, CW	90-R-075-CB-1-NN-80-S-3-S1-C-00-GBA-35-35-20	SERIES 90	S90-075PV
95-2708	PUMP-VAR DISPL, CW	90-R-075-EA-1-AB-60-S-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
95-2709	PUMP-VAR DISPL, CW	90-R-075-DC-1-NN-60-P-4-S1-D-GB-GBA-42-42-24	SERIES 90	S90-075PV
95-2710	PUMP-VAR DISPL, CW	90-R-075-MD-1-BC-60-L-3-C7-E-02-GBA-35-35-24	SERIES 90	S90-075PV
95-2713	PUMP-VAR DISPL, CW	90-R-075-MB-1-BC-80-S-3-C6-D-03-GBA-35-35-24	SERIES 90	S90-075PV
95-2714	PUMP-VAR DISPL, CW	90-R-075-EP-1-AB-60-L-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
95-2715	PUMP-VAR DISPL, CW	90-R-075-MB-1-BC-80-S-3-C6-D-03-GBA-35-35-20	SERIES 90	S90-075PV
95-2716	PUMP-VAR DISPL, CW	90-R-075-MB-1-BC-80-S-3-C6-D-02-GBA-35-35-20	SERIES 90	S90-075PV
95-2717	PUMP-VAR DISPL, CW	90-R-075-MD-1-BC-80-S-3-C6-D-02-GBA-35-35-20	SERIES 90	S90-075PV
95-2718	PUMP-VAR DISPL, CW	90-R-075-MA-1-NN-80-S-3-C6-D-03-GBA-35-35-24	SERIES 90	S90-075PV
95-2720	PUMP-VAR DISPL, CW	90-R-075-MA-1-AB-60-R-3-S1-L-02-FAB-38-38-24	SERIES 90	S90-075PV
95-2721	PUMP-VAR DISPL, CW	90-R-075-MB-1-CD-60-S-3-C7-D-03-GBA-38-38-20	SERIES 90	S90-075PV
95-2722	PUMP-VAR DISPL, CW	90-R-075-MB-1-AB-60-S-3-S1-D-03-GBA-38-38-24	SERIES 90	S90-075PV
95-2723	PUMP-VAR DISPL, CW	90-R-075-DC-1-NN-80-P-3-S1-E-GB-GBA-38-38-24	SERIES 90	S90-075PV
95-2724	PUMP-VAR DISPL, CW	90-R-075-MB-6-CD-80-P-3-C6-D-03-GBA-45-45-28	SERIES 90	S90-075PV
95-2725	PUMP-VAR DISPL, CW	90-R-075-MB-6-CD-80-P-3-S1-D-03-GBA-45-45-28	SERIES 90	S90-075PV
95-2726	PUMP-VAR DISPL, CW	90-R-075-MB-1-CD-80-L-4-C7-E-03-GBA-29-29-24	SERIES 90	S90-075PV
95-2727	PUMP-VAR DISPL, CW	90-R-075-MB-1-CD-80-L-4-S1-E-03-GBA-29-29-24	SERIES 90	S90-075PV
95-2728	PUMP-VAR DISPL, CW	90-R-075-EP-1-BC-60-R-3-S1-D-00-GBA-42-42-24	SERIES 90	S90-075PV
95-2729	PUMP-VAR DISPL, CW	90-R-075-MB-1-BC-60-S-3-S1-D-04-GBA-42-42-20	SERIES 90	S90-075PV
95-2731	PUMP-VAR DISPL, CW	90-R-075-EP-1-NN-80-P-3-S1-E-03-GBA-38-38-24	SERIES 90	S90-075PV
95-2732	PUMP-VAR DISPL, CW	90-R-075-HK-1-BC-60-S-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
95-2733	PUMP-VAR DISPL, CW	90-R-075-HK-1-NN-60-S-4-S1-C-03-GBA-29-29-20	SERIES 90	S90-075PV
95-2734	PUMP-VAR DISPL, CW	90-R-075-HK-1-CD-61-R-3-S1-E-03-GBA-20-20-24	SERIES 90	S90-075PV
95-2735	PUMP-VAR DISPL, CW	90-R-075-HK-1-NN-60-S-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
95-2736	PUMP-VAR DISPL, CW	90-R-075-HF-1-AB-80-R-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV

95-2737	PUMP-VAR DISPL, CW	90-R-075-HF-1-AB-60-S-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
95-2738	PUMP-VAR DISPL, CW	90-R-075-MB-1-AB-60-L-3-S1-D-03-GBA-42-42-20	SERIES 90	S90-075PV
95-2739	PUMP-VAR DISPL, CW	90-R-075-HK-1-NN-60-S-3-S1-D-03-GBA-23-23-24	SERIES 90	S90-075PV
95-2740	PUMP-VAR DISPL, CW	90-R-075-EP-1-BC-80-R-3-S1-E-03-GBA-38-38-24	SERIES 90	S90-075PV
95-2741	PUMP-VAR DISPL, CW	90-R-075-MA-1-NN-60-S-3-K2-D-03-GBA-35-35-24	SERIES 90	S90-075PV
95-2742	PUMP-VAR DISPL, CW	90-R-075-EA-1-NN-60-S-3-K2-D-03-GBA-35-35-24	SERIES 90	S90-075PV
95-2743	PUMP-VAR DISPL, CW	90-R-075-MB-1-AB-60-L-3-C7-D-03-GFK-42-42-20	SERIES 90	S90-075PV
95-2744	PUMP-VAR DISPL, CW	90-R-075-HK-1-NN-80-S-3-S1-D-02-GBA-14-23-24	SERIES 90	S90-075PV
95-2746	PUMP-VAR DISPL, CW	90-R-075-MB-1-CD-60-S-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
95-2747	PUMP-VAR DISPL, CW	90-R-075-EA-1-BC-80-L-3-S1-D-03-GBA-26-26-24	SERIES 90	S90-075PV
95-2748	PUMP-VAR DISPL, CW	90-R-075-EA-1-BC-60-L-3-S1-D-03-GBA-26-26-24	SERIES 90	S90-075PV
95-2749	PUMP-VAR DISPL, CW	90-R-075-HF-1-BB-60-L-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-075PV
95-2750	PUMP-VAR DISPL, CW	90-R-075-MB-6-BC-80-P-3-S1-D-03-GBA-45-45-28	SERIES 90	S90-075PV
95-2751	PUMP-VAR DISPL, CW	90-R-075-MB-6-BB-80-P-3-S1-D-03-GBA-45-45-28	SERIES 90	S90-075PV
95-2752	PUMP-VAR DISPL, CW	90-R-075-EP-1-CD-80-R-3-S1-E-03-GBA-38-38-24	SERIES 90	S90-075PV
95-2753	PUMP-VAR DISPL, CW	90-R-075-MA-1-NN-60-L-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
95-2754	PUMP-VAR DISPL, CW	90-R-075-MB-1-BB-60-L-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-075PV
95-2755	PUMP-VAR DISPL, CW	90-R-075-MA-1-BC-60-R-3-S1-E-02-GBA-29-29-20	SERIES 90	S90-075PV
95-2761	PUMP-VAR DISPL, CW	90-R-075-MB-6-CD-80-P-3-C6-D-02-GBA-45-45-28	SERIES 90	S90-075PV
95-2762	PUMP-VAR DISPL, CW	90-R-075-MB-6-BB-80-P-3-S1-D-02-GBA-45-45-28	SERIES 90	S90-075PV
95-2763	PUMP-VAR DISPL, CW	90-R-075-HM-6-NN-80-S-4-K2-E-03-GBA-45-45-24	SERIES 90	S90-075PV
95-2767	PUMP-VAR DISPL, CW	90-R-075-MB-1-BB-60-S-3-C6-D-03-GBA-38-38-24	SERIES 90	S90-075PV
95-2768	PUMP-VAR DISPL, CW	90-R-075-MA-1-AB-60-S-3-C6-D-03-GBA-42-42-24	SERIES 90	S90-075PV
95-2771	PUMP-VAR DISPL, CW	90-R-075-EA-1-NN-80-R-3-C7-D-04-GBA-38-38-24	SERIES 90	S90-075PV
95-2772	PUMP-VAR DISPL, CW	90-R-075-EP-1-BC-80-R-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-075PV
95-2773	PUMP-VAR DISPL, CW	90-R-075-EP-1-CD-80-R-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-075PV
95-2775	PUMP-VAR DISPL, CW	90-R-075-EA-1-NN-80-P-3-C6-D-03-GBA-35-35-24	SERIES 90	S90-075PV
95-2776	PUMP-VAR DISPL, CW	90-R-075-DC-1-BC-60-S-3-S1-D-GB-GBA-35-35-20	SERIES 90	S90-075PV
95-2777	PUMP-VAR DISPL, CW	90-R-075-EP-1-AC-80-R-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
95-2778	PUMP-VAR DISPL, CW	90-R-075-MB-1-NN-60-P-3-S1-D-03-FAB-42-42-24	SERIES 90	S90-075PV
95-2779	PUMP-VAR DISPL, CW	90-R-075-DC-1-CD-80-P-3-C7-E-GB-GBA-38-38-24	SERIES 90	S90-075PV
95-2780	PUMP-VAR DISPL, CW	90-R-075-MB-1-NN-60-S-3-S1-E-02-GBA-23-23-24	SERIES 90	S90-075PV
95-2781	PUMP-VAR DISPL, CW	90-R-075-EP-1-NN-80-P-3-S1-E-22-GBA-38-38-24	SERIES 90	S90-075PV
95-2782	PUMP-VAR DISPL, CW	90-R-075-EP-1-NN-80-P-3-S1-D-22-GBA-38-38-24	SERIES 90	S90-075PV
95-2783	PUMP-VAR DISPL, CW	90-R-075-MB-1-BC-60-S-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
95-2784	PUMP-VAR DISPL, CW	90-R-075-EP-1-CD-80-S-3-S1-D-03-GBA-29-29-20	SERIES 90	S90-075PV

95-2785	PUMP-VAR DISPL, CW	90-R-075-EP-1-BC-80-S-3-S1-D-03-GBA-29-29-20	SERIES 90	S90-075PV
95-2787	PUMP-VAR DISPL, CW	90-R-075-DC-1-AB-60-S-3-C6-D-GF-GBA-23-23-20	SERIES 90	S90-075PV
95-2788	PUMP-VAR DISPL, CW	90-R-075-DC-1-AB-60-S-4-C6-D-GB-GBA-23-23-20	SERIES 90	S90-075PV
95-2789	PUMP-VAR DISPL, CW	90-R-075-MC-1-AB-60-P-3-S1-D-02-GBA-42-42-24	SERIES 90	S90-075PV
95-2790	PUMP-VAR DISPL, CW	90-R-075-MA-1-CD-60-D-3-C7-L-03-GBA-38-38-24	SERIES 90	S90-075PV
95-2791	PUMP-VAR DISPL, CW	90-R-075-MA-1-BC-60-D-3-S1-L-03-GBA-38-38-24	SERIES 90	S90-075PV
95-3133	MOTOR-FIXED DISPL, 90MF075	90-M-075-NC-0-N-8-N-0-S1-W-00-JAG-00-00-20	SERIES 90	S90-075MF
9510229	OVERHAUL SEAL KIT-21 MV		SERIES 20	PARTS - S20 - Unique
9510241	OVERHAUL SEAL KIT-25 MV		SERIES 20	PARTS - S20 - Unique
9510271	BEARING-TRUNNION, 27 SERIES		SERIES 20	PARTS - S20 - Purchased Parts
9510318	OVERHAUL SEAL KIT-26 MV		SERIES 20	PARTS - S20 - Unique
9510329-0003	CHARGE PUMP KIT-18 SERIES, .72 CIR		SERIES 20	PARTS - S20 - Unique
9510368-2005	CONTROL KIT-MDC, 24 PV		SERIES 20	PARTS - S20 - Unique
9510368-2007	CONTROL KIT-MDC, 27 PV		SERIES 20	PARTS - S20 - Unique
9510369-2002	CONTROL KIT-MDC, 23 PV FOR POR		SERIES 20	PARTS - S20 - Unique
9510423-0005	SHIM KIT-24 SERIES		SERIES 20	PARTS - S20 - "No Name"
9510437-4000	MANIFOLD KIT-C'BAL,DUMMY HPRV PORT B		SERIES 20	PARTS - S20 - Purchased Parts
9510438-5000	VALVE KIT-HIGH PRESSURE RELIEF		SERIES 20	PARTS - S20 - Unique
9510482-2005	KIT -- CONTROL VALVE		SERIES 20	PARTS - S20 - Unique
9510648-JSBJ	KIT MANIFOLD VALVE		SERIES 20	PARTS - S20 - Unique
9510650-H	KIT HI PRESS RELIEF VALVE		SERIES 20	PARTS - S20 - Unique
9510650-L	KIT HI PRESS RELIEF VALVE		SERIES 20	PARTS - S20 - Unique
9510655-LD	KIT-CHARGE PUMP		SERIES 20	PARTS - S20 - Unique
9510657-RE	KIT-CHARGE PUMP		SERIES 20	PARTS - S20 - Unique
9510660-G	KIT-POR VALVE, 4000 PSI		SERIES 20	PARTS - S20 - Unique
9510666-5-RK	KIT-CHG PUMP CW		SERIES 20	PARTS - S20 - Unique
9510761	SWASHPLATE REPLACEMENT KIT, 23 SERIES		SERIES 20	PARTS - S20 - Unique
952-000045	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HS-1-AB-60-R-3-S1-E-03-GBA-42-42-30	SERIES 90	S90-075PV
952-000049	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HS-1-NN-60-R-3-S1-E-03-GBA-42-42-30	SERIES 90	S90-075PV
952-040018	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-2-NN-80-S-3-C6-E-06-GBA-42-42-24	SERIES 90	S90-075PV
952-040021	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-1-AB-80-S-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
952-040027	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-2-NN-80-S-3-C6-E-02-GBA-42-42-24	SERIES 90	S90-075PV
9521140	PUMP-VAR DISPL, CCW	90-L-075-MA-1-NN-80-S-3-S1-D-03-GBA-26-26-20	SERIES 90	S90-075PV
9521141	PUMP-VAR DISPL, CCW	90-L-075-EA-1-AB-60-S-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9521142	PUMP-VAR DISPL, CCW	90-L-075-EA-1-NN-60-L-4-S1-D-03-GBA-29-29-24	SERIES 90	S90-075PV
9521143	PUMP-VAR DISPL, CCW	90-L-075-CB-1-NN-60-S-3-S1-D-00-GBA-35-35-20	SERIES 90	S90-075PV

9521144	PUMP-VAR DISPL, CCW	90-L-075-MA-1-BC-80-P-3-S1-D-03-GBA-38-38-20	SERIES 90	S90-075PV
9521145	PUMP-VAR DISPL, CCW	90-L-075-HM-6-NN-80-S-4-K2-E-22-GBA-45-45-24	SERIES 90	S90-075PV
9521146	PUMP-VAR DISPL, CCW	90-L-075-EP-1-CD-80-S-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-075PV
9521147	PUMP-VAR DISPL, CCW	90-L-075-HF-1-NN-80-S-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-075PV
9521148	PUMP-VAR DISPL, CCW	90-L-075-EP-1-CD-80-S-3-C6-E-03-GBA-42-42-24	SERIES 90	S90-075PV
9521150	PUMP-VAR DISPL, CCW	90-L-075-MA-1-NN-60-S-3-S1-D-06-GBA-42-42-24	SERIES 90	S90-075PV
9521151	PUMP-VAR DISPL, CCW	90-L-075-HK-1-BC-80-R-3-S1-C-05-GBA-38-38-24	SERIES 90	S90-075PV
9521152	PUMP-VAR DISPL, CCW	90-L-075-MA-1-CD-80-S-3-S1-E-03-FAA-32-32-24	SERIES 90	S90-075PV
9521153	PUMP-VAR DISPL, CCW	90-L-075-EP-1-BC-80-R-3-S1-D-22-GBA-42-42-24	SERIES 90	S90-075PV
9521154	PUMP-VAR DISPL, CCW	90-L-075-HF-1-BC-80-R-3-S1-D-22-GBA-42-42-24	SERIES 90	S90-075PV
9521155	PUMP-VAR DISPL, CCW	90-L-075-EP-1-AB-80-S-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-075PV
9521156	PUMP-VAR DISPL, CCW	90-L-075-EP-1-AB-80-S-3-S1-D-22-GBA-35-35-24	SERIES 90	S90-075PV
9521157	PUMP-VAR DISPL, CCW	90-L-075-EA-1-CD-80-R-4-C6-E-02-GBA-29-29-24	SERIES 90	S90-075PV
9521158	PUMP-VAR DISPL, CCW	90-L-075-HF-1-AB-80-S-3-S1-D-00-GBA-23-23-20	SERIES 90	S90-075PV
9521160	PUMP-VAR DISPL, CCW	90-L-075-HF-1-AB-80-S-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-075PV
9521161	PUMP-VAR DISPL, CCW	90-L-075-EP-1-AB-80-R-3-S1-D-22-GBA-35-35-24	SERIES 90	S90-075PV
9521162	PUMP-VAR DISPL, CCW	90-L-075-EP-1-CD-80-S-3-C6-C-03-GBA-38-38-24	SERIES 90	S90-075PV
9521163	PUMP-VAR DISPL, CCW	90-L-075-EP-1-NN-80-S-3-S1-C-03-GBA-38-38-24	SERIES 90	S90-075PV
9521164	PUMP-VAR DISPL, CCW	90-L-075-HK-1-BC-80-R-3-S1-D-05-GBA-38-38-24	SERIES 90	S90-075PV
9521165	PUMP-VAR DISPL, CCW	90-L-075-EA-1-NN-60-S-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9521166	PUMP-VAR DISPL, CCW	90-L-075-EP-1-NN-80-S-3-S1-D-03-GBA-35-35-20	SERIES 90	S90-075PV
9521167	PUMP-VAR DISPL, CCW	90-L-075-HF-1-AB-61-R-3-S1-D-00-GBA-35-35-20	SERIES 90	S90-075PV
9521168	PUMP-VAR DISPL, CCW	90-L-075-EP-1-AB-60-S-3-T1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9521169	PUMP-VAR DISPL, CCW	90-L-075-EP-1-NN-60-P-1-S1-E-28-GBA-32-14-24-F024	SERIES 90	S90-075PV
9521170	PUMP-VAR DISPL, CCW	90-L-075-EA-1-BC-60-S-3-S1-D-03-GBA-29-29-24	SERIES 90	S90-075PV
9521171	PUMP-VAR DISPL, CCW	90-L-075-HM-1-BC-80-R-3-S1-D-22-GBA-42-42-24	SERIES 90	S90-075PV
9521172	PUMP-VAR DISPL, CCW	90-L-075-MB-1-NN-60-R-3-S1-D-04-GBA-35-35-20	SERIES 90	S90-075PV
9521173	PUMP-VAR DISPL, CCW	90-L-075-MA-1-AB-60-S-4-S1-D-05-GBA-35-35-24	SERIES 90	S90-075PV
9521174	PUMP-VAR DISPL, CCW	90-L-075-MA-1-AB-80-R-3-T1-E-03-GBA-26-26-24	SERIES 90	S90-075PV
9521175	PUMP-VAR DISPL, CCW	90-L-075-MA-1-AB-60-R-3-T1-E-03-GBA-26-26-24	SERIES 90	S90-075PV
9521176	PUMP-VAR DISPL, CCW	90-L-075-MA-1-NN-60-S-4-S1-D-05-GBA-35-35-24	SERIES 90	S90-075PV
9521177	PUMP-VAR DISPL, CCW	90-L-075-EP-1-NN-60-S-3-S1-D-00-GBA-42-42-24	SERIES 90	S90-075PV
9521178	PUMP-VAR DISPL, CCW	90-L-075-MA-7-AB-60-S-3-T1-E-03-GBA-45-45-24	SERIES 90	S90-075PV
9521179	PUMP-VAR DISPL, CCW	90-L-075-EP-1-NN-80-S-3-S1-D-00-GBA-42-42-24	SERIES 90	S90-075PV
9521180	PUMP-VAR DISPL, CCW	90-L-075-MB-6-NN-80-D-3-S1-L-03-GBA-45-45-24	SERIES 90	S90-075PV
9521181	PUMP-VAR DISPL, CCW	90-L-075-EP-1-BC-80-R-3-S1-E-03-GBA-29-29-24	SERIES 90	S90-075PV

9521182	PUMP-VAR DISPL, CCW	90-L-075-EP-1-CD-80-R-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-075PV
9521183	PUMP-VAR DISPL, CCW	90-L-075-MB-1-NN-80-D-3-S1-L-03-GBA-42-42-24	SERIES 90	S90-075PV
9521184	PUMP-VAR DISPL, CCW	90-L-075-HM-1-AB-80-S-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-075PV
9521185	PUMP-VAR DISPL, CCW	90-L-075-MA-1-AB-80-P-3-T1-E-03-GBA-42-42-24	SERIES 90	S90-075PV
9521186	PUMP-VAR DISPL, CCW	90-L-075-EP-1-BC-60-S-3-S1-D-03-EBC-42-42-18	SERIES 90	S90-075PV
9521187	PUMP-VAR DISPL, CCW	90-L-075-MA-1-NN-80-L-3-C6-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9521187C	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-1-NN-80-L-3-C6-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9521188	PUMP-VAR DISPL, CCW	90-L-075-MA-1-NN-60-S-3-C6-E-03-GBA-38-38-24	SERIES 90	S90-075PV
9521189	PUMP-VAR DISPL, CCW	90-L-075-MA-1-BC-80-S-3-C6-E-03-GBA-38-38-24	SERIES 90	S90-075PV
9521191	PUMP-VAR DISPL, CCW	90-L-075-EA-1-CD-60-R-3-S1-D-03-GBA-42-42-20	SERIES 90	S90-075PV
9521192	PUMP-VAR DISPL, CCW	90-L-075-EA-1-NN-60-R-3-S1-D-03-GBA-42-42-20	SERIES 90	S90-075PV
9521194	PUMP-VAR DISPL, CCW	90-L-075-EA-1-AB-60-P-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9521195	PUMP-VAR DISPL, CCW	90-L-075-EA-1-CD-80-S-4-C7-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9521196	PUMP-VAR DISPL, CCW	90-L-075-EA-1-BB-80-S-4-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9521197	PUMP-VAR DISPL, CCW	90-L-075-EA-2-CD-80-S-3-C7-D-33-GBA-42-42-24	SERIES 90	S90-075PV
9521198	PUMP-VAR DISPL, CCW	90-L-075-EA-2-BB-80-S-3-S1-D-33-GBA-42-14-24	SERIES 90	S90-075PV
9521199	PUMP-VAR DISPL, CCW	90-L-075-EA-1-CD-60-L-3-S1-D-03-GBA-38-38-20	SERIES 90	S90-075PV
9521200	PUMP-VAR DISPL, CCW	90-L-075-EA-1-NN-60-L-3-S1-D-03-GBA-38-38-20	SERIES 90	S90-075PV
9521201	PUMP-VAR DISPL, CCW	90-L-075-EP-1-NN-80-R-3-S1-D-22-GBA-35-35-24	SERIES 90	S90-075PV
9521202	PUMP-VAR DISPL, CCW	90-L-075-HS-1-BC-60-R-3-C6-D-04-GBA-35-35-24	SERIES 90	S90-075PV
9521203	PUMP-VAR DISPL, CCW	90-L-075-MA-1-BC-60-S-3-C7-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9521204	PUMP-VAR DISPL, CCW	90-L-075-EA-1-BC-60-S-3-T1-D-03-GBA-26-26-24	SERIES 90	S90-075PV
9521205	PUMP-VAR DISPL, CCW	90-L-075-MA-1-NN-81-S-3-T2-E-03-GBA-35-35-20	SERIES 90	S90-075PV
9521206	PUMP-VAR DISPL, CCW	90-L-075-MA-1-AB-81-S-3-T2-E-03-GBA-35-35-20	SERIES 90	S90-075PV
9521209	PUMP-VAR DISPL, CCW	90-L-075-MA-1-NN-60-S-3-S1-D-02-GFK-35-35-20	SERIES 90	S90-075PV
9521210	PUMP-VAR DISPL, CCW	90-L-075-CB-6-NN-80-L-4-K2-E-00-GBA-45-45-24	SERIES 90	S90-075PV
9521211	PUMP-VAR DISPL, CCW	90-L-075-CB-6-BC-80-L-4-K2-E-00-GBA-45-45-24	SERIES 90	S90-075PV
9521212	PUMP-VAR DISPL, CCW	90-L-075-EP-1-BB-80-R-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-075PV
9521213	PUMP-VAR DISPL, CCW	90-L-075-MA-1-BC-60-S-4-S1-D-05-GBA-35-35-24	SERIES 90	S90-075PV
9521214	PUMP-VAR DISPL, CCW	90-L-075-MT-1-NN-60-S-3-S1-D-02-GFK-35-35-20	SERIES 90	S90-075PV
9521215	PUMP-VAR DISPL, CCW	90-L-075-MB-1-CD-60-S-4-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9521216	PUMP-VAR DISPL, CCW	90-L-075-EP-1-NN-60-S-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9521219	PUMP-VAR DISPL, CCW	90-L-075-CB-6-CD-80-L-4-K2-E-02-GBA-45-45-24	SERIES 90	S90-075PV
9521220	PUMP-VAR DISPL, CCW	90-L-075-CB-6-CD-80-L-4-K2-E-00-GBA-45-45-24	SERIES 90	S90-075PV
9521221	PUMP-VAR DISPL, CCW	90-L-075-DC-1-BB-80-L-3-S1-D-G4-GBA-23-23-20	SERIES 90	S90-075PV
9521222	PUMP-VAR DISPL, CCW	90-L-075-KP-1-BC-80-S-3-S1-D-00-GBA-42-42-24	SERIES 90	S90-075PV

9521223	PUMP-VAR DISPL, CCW	90-L-075-EP-1-NN-60-R-3-S1-D-03-FAB-42-42-24	SERIES 90	S90-075PV
9521224	PUMP-VAR DISPL, CCW	90-L-075-EP-1-CD-60-R-3-S1-D-03-FAB-42-42-24	SERIES 90	S90-075PV
9521225	PUMP-VAR DISPL, CCW	90-L-075-EA-1-NN-80-R-4-S1-D-02-GBA-14-23-24	SERIES 90	S90-075PV
9521226	PUMP-VAR DISPL, CCW	90-L-075-EA-1-NN-80-P-3-S1-D-02-GBA-42-42-24	SERIES 90	S90-075PV
9521227	PUMP-VAR DISPL, CCW	90-L-075-MB-1-AB-61-P-3-T1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9521228	PUMP-VAR DISPL, CCW	90-L-075-MA-6-AB-60-S-3-T2-D-03-GBA-48-48-18	SERIES 90	S90-075PV
9521229	PUMP-VAR DISPL, CCW	90-L-075-EP-6-AB-60-S-3-T2-D-03-GBA-48-48-18	SERIES 90	S90-075PV
9521230	PUMP-VAR DISPL, CCW	90-L-075-HS-1-BB-80-R-3-S1-D-05-GBA-38-38-24	SERIES 90	S90-075PV
9521231	PUMP-VAR DISPL, CCW	90-L-075-EP-1-BB-80-R-3-S1-D-00-GBA-38-38-24	SERIES 90	S90-075PV
9521232	PUMP-VAR DISPL, CCW	90-L-075-EP-1-BC-60-L-3-S1-D-03-GBA-42-42-18	SERIES 90	S90-075PV
9521233	PUMP-VAR DISPL, CCW	90-L-075-EP-1-BC-60-S-3-S1-D-03-GBA-42-42-18	SERIES 90	S90-075PV
9521235	PUMP-VAR DISPL, CCW	90-L-075-HS-1-BB-80-R-3-S1-E-05-GBA-38-38-24	SERIES 90	S90-075PV
9521236	PUMP-VAR DISPL, CCW	90-L-075-EP-1-BB-80-R-3-S1-E-00-GBA-38-38-24	SERIES 90	S90-075PV
9521237	PUMP-VAR-DISPL CCW 90PV075	90-L-075-EP-1-NN-80-P-3-S1-D-02-GBA-42-42-24	SERIES 90	S90-075PV
9521238	PUMP-VAR DISPL, CCW	90-L-075-HS-1-BB-80-R-3-S1-E-02-GBA-38-38-24	SERIES 90	S90-075PV
9521239	PUMP-VAR DISPL, CCW	90-L-075-MK-1-BC-80-R-3-S1-D-04-GBA-38-38-24	SERIES 90	S90-075PV
9521240	PUMP-VAR DISPL, CCW	90-L-075-EA-1-AB-81-L-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9521241	PUMP-VAR DISPL, CCW	90-L-075-EA-1-NN-80-S-3-S1-D-03-GBA-26-26-20	SERIES 90	S90-075PV
9521243	PUMP-VAR DISPL, CCW	90-L-075-HF-1-AB-80-R-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-075PV
9521244	PUMP-VAR DISPL, CCW	90-L-075-DC-1-CD-60-R-3-S1-D-GB-GBA-42-42-24	SERIES 90	S90-075PV
9521245	PUMP-VAR DISPL, CCW	90-L-075-HF-1-AB-80-R-3-S1-D-02-GBA-35-35-24	SERIES 90	S90-075PV
9521247	PUMP-VAR DISPL, CCW	90-L-075-EA-1-AB-60-P-3-S1-D-03-GBA-23-23-24	SERIES 90	S90-075PV
9521248	PUMP-VAR DISPL, CCW	90-L-075-EA-1-NN-80-S-3-C7-D-04-GBA-38-38-24	SERIES 90	S90-075PV
9521249	PUMP-VAR DISPL, CCW	90-L-075-EP-1-AB-60-P-3-S1-D-03-GBA-23-23-24	SERIES 90	S90-075PV
9521250	PUMP-VAR DISPL, CCW	90-L-075-EP-1-BB-81-P-3-S1-D-03-GBA-35-35-20	SERIES 90	S90-075PV
9521251	PUMP-VAR DISPL, CCW	90-L-075-EP-1-CD-81-P-3-S1-D-03-GBA-35-35-20	SERIES 90	S90-075PV
9521252	PUMP-VAR DISPL, CCW	90-L-075-EA-1-NN-61-P-3-S1-D-03-GBA-35-35-20	SERIES 90	S90-075PV
9521253	PUMP-VAR DISPL, CCW	90-L-075-EP-6-CD-80-R-3-C6-E-03-FAC-48-48-XX-B020	SERIES 90	S90-075PV
9521254	PUMP-VAR DISPL, CCW	90-L-075-KP-6-AB-60-R-3-T1-E-03-GBA-48-48-18	SERIES 90	S90-075PV
9521255	PUMP-VAR DISPL, CCW	90-L-075-MB-1-NN-60-P-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9521256	PUMP-VAR DISPL, CCW	90-L-075-KP-6-AB-60-P-3-T1-E-03-GBA-48-48-18	SERIES 90	S90-075PV
9521257	PUMP-VAR DISPL, CCW	90-L-075-MA-1-NN-60-L-3-C6-E-03-GBA-35-35-24	SERIES 90	S90-075PV
9521257C	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-1-NN-60-L-3-C6-E-03-GBA-35-35-24	SERIES 90	S90-075PV
9521258	PUMP-VAR DISPL, CCW	90-L-075-EA-1-AB-80-L-3-C6-D-03-GBA-32-32-24	SERIES 90	S90-075PV
9521259	PUMP-VAR DISPL, CCW	90-L-075-EA-1-CD-60-S-3-T2-D-00-GBA-26-26-24	SERIES 90	S90-075PV
9521260	PUMP-VAR DISPL, CCW	90-L-075-EA-1-BC-60-S-3-S1-E-00-GBA-26-26-24	SERIES 90	S90-075PV

9521262	PUMP-VAR DISPL, CCW	90-L-075-HK-1-BC-60-R-3-S1-E-04-GBA-35-35-24	SERIES 90	S90-075PV
9521263	PUMP-VAR DISPL, CCW	90-L-075-EP-1-NN-80-P-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9521264	PUMP-VAR DISPL, CCW	90-L-075-EP-1-BC-80-P-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9521265	PUMP-VAR DISPL, CCW	90-L-075-ME-1-NN-80-S-3-S1-D-03-GBA-35-35-20	SERIES 90	S90-075PV
9521266	PUMP-VAR DISPL, CCW	90-L-075-KA-6-NN-80-L-4-K2-E-22-GBA-45-45-24	SERIES 90	S90-075PV
9521267	PUMP-VAR DISPL, CCW	90-L-075-KA-6-CD-80-L-4-K2-E-22-GBA-45-45-24	SERIES 90	S90-075PV
9521268	PUMP-VAR DISPL, CCW	90-L-075-MD-1-NN-60-S-3-S1-D-02-FAC-42-42-24	SERIES 90	S90-075PV
9521269	PUMP-VAR DISPL, CCW	90-L-075-KP-1-NN-60-S-3-K2-D-03-GBA-38-38-24	SERIES 90	S90-075PV
9521271	PUMP-VAR DISPL, CCW	90-L-075-KP-1-BC-80-R-3-S1-D-01-GBA-42-42-24	SERIES 90	S90-075PV
9521272	PUMP-VAR DISPL, CCW	90-L-075-HM-1-BC-80-R-3-S1-D-01-GBA-42-42-24	SERIES 90	S90-075PV
9521273	PUMP-VAR DISPL, CCW	90-L-075-KA-1-CD-80-S-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9521274	PUMP-VAR DISPL, CCW	90-L-075-KP-1-CD-80-S-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-075PV
9521276	PUMP-VAR DISPL, CCW	90-L-075-KP-1-NN-60-S-3-S1-E-09-GBA-35-35-28	SERIES 90	S90-075PV
9521277	PUMP-VAR DISPL, CCW	90-L-075-KP-1-NN-60-R-4-T1-D-03-GBA-29-29-20	SERIES 90	S90-075PV
9521278	PUMP-VAR DISPL, CCW	90-L-075-MA-1-NN-60-R-4-T1-D-03-GBA-29-29-20	SERIES 90	S90-075PV
9521279	PUMP-VAR DISPL, CCW	90-L-075-KP-1-CD-80-R-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-075PV
9521280	PUMP-VAR DISPL, CCW	90-L-075-KP-1-BC-80-R-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-075PV
9521281	PUMP-VAR DISPL, CCW	90-L-075-KP-1-BC-80-R-3-S1-E-03-GBA-29-29-24	SERIES 90	S90-075PV
9521282	PUMP-VAR DISPL, CCW	90-L-075-MA-1-NN-60-S-3-C6-E-03-GBA-35-35-24	SERIES 90	S90-075PV
9521283	PUMP-VAR DISPL, CCW	90-L-075-KP-1-BB-80-R-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-075PV
9521284	PUMP-VAR DISPL, CCW	90-L-075-KP-1-BE-82-S-3-S1-D-00-GBA-42-42-24	SERIES 90	S90-075PV
9521285	PUMP-VAR DISPL, CCW	90-L-075-KP-6-AB-60-S-3-T1-E-03-GBA-48-48-24	SERIES 90	S90-075PV
9521286	PUMP-VAR DISPL, CCW	90-L-075-KP-1-NN-80-R-3-S1-D-22-GBA-35-35-24	SERIES 90	S90-075PV
9521287	PUMP-VAR DISPL, CCW	90-L-075-KP-1-AB-80-R-3-S1-D-22-GBA-35-35-24	SERIES 90	S90-075PV
9521288	PUMP-VAR DISPL, CCW	90-L-075-MA-1-NN-80-L-3-C6-E-03-GBA-42-42-20	SERIES 90	S90-075PV
9521289	PUMP-VAR DISPL, CCW	90-L-075-KP-2-BC-80-P-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9521291	PUMP-VAR DISPL, CCW	90-L-075-KP-1-BB-80-P-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9521292	PUMP-VAR DISPL, CCW	90-L-075-KP-1-CD-80-S-3-C6-E-03-GBA-42-42-24	SERIES 90	S90-075PV
9521293	PUMP-VAR DISPL, CCW	90-L-075-KA-1-NN-80-D-4-S1-L-03-GBA-42-42-24	SERIES 90	S90-075PV
9521294	PUMP-VAR DISPL, CCW	90-L-075-HK-1-NN-80-S-3-S1-D-03-GBA-42-42-20	SERIES 90	S90-075PV
9521295	PUMP-VAR DISPL, CCW	90-L-075-KP-1-BE-82-S-3-S1-D-64-FAC-42-42-24	SERIES 90	S90-075PV
9521296	PUMP-VAR DISPL, CCW	90-L-075-KP-1-BC-60-L-3-S1-E-03-GBA-42-42-20	SERIES 90	S90-075PV
9521297	PUMP-VAR DISPL, CCW	90-L-075-MA-1-NN-80-S-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9521298	PUMP-VAR DISPL, CCW	90-L-075-KA-1-AB-80-R-3-S1-D-02-GBA-35-35-24	SERIES 90	S90-075PV
9521299	PUMP-VAR DISPL, CCW	90-L-075-KP-1-NN-60-R-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-075PV
9521300	PUMP-VAR DISPL, CCW	90-L-075-MD-1-CD-60-S-4-S1-D-02-GBA-42-42-24	SERIES 90	S90-075PV

9521301	PUMP-VAR DISPL, CCW	90-L-075-KA-1-AB-61-S-3-S1-E-03-GBA-20-20-24	SERIES 90	S90-075PV
9521302	PUMP-VAR DISPL, CCW	90-L-075-HU-1-BB-80-R-3-S1-E-04-GBA-38-38-24	SERIES 90	S90-075PV
9521303	PUMP-VAR DISPL, CCW	90-L-075-KP-1-NN-60-L-4-S1-E-02-GBA-35-14-24	SERIES 90	S90-075PV
9521304	PUMP-VAR DISPL, CCW	90-L-075-KP-1-NN-80-S-3-C7-D-04-FAC-38-38-24	SERIES 90	S90-075PV
9521305	PUMP-VAR DISPL, CCW	90-L-075-KP-1-BB-80-R-3-S1-E-00-GBA-38-38-24	SERIES 90	S90-075PV
9521306	PUMP-VAR DISPL, CCW	90-L-075-KA-1-NN-60-S-3-S4-E-05-GBA-38-38-20	SERIES 90	S90-075PV
9521307	PUMP-VAR DISPL, CCW	90-L-075-KP-2-CD-80-L-3-C6-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9521308	PUMP-VAR DISPL, CCW	90-L-075-KA-6-NN-60-S-3-S1-E-09-GBA-45-45-24	SERIES 90	S90-075PV
9521310	PUMP-VAR DISPL, CCW	90-L-075-MA-6-NN-60-S-3-S1-C-03-FAC-45-45-24	SERIES 90	S90-075PV
9521311	PUMP-VAR DISPL, CCW	90-L-075-KP-1-BE-82-U-3-S1-D-64-FAC-45-45-24-N057	SERIES 90	S90-075PV
9521312	PUMP-VAR DISPL, CCW	90-L-075-KA-1-AB-80-L-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9521313	PUMP-VAR DISPL, CCW	90-L-075-MB-1-BC-60-S-3-S1-E-04-GBA-42-42-24	SERIES 90	S90-075PV
9521314	PUMP-VAR DISPL, CCW	90-L-075-DC-1-CD-80-R-3-C7-C-GB-GBA-38-38-24	SERIES 90	S90-075PV
9521315	PUMP-VAR DISPL, CCW	90-L-075-MB-1-NN-80-S-3-S1-D-05-GBA-42-42-24	SERIES 90	S90-075PV
9521316	PUMP-VAR DISPL, CCW	90-L-075-KP-6-BB-80-R-3-C6-E-03-FAC-48-48-XX-B020	SERIES 90	S90-075PV
9521317	PUMP-VAR DISPL, CCW	90-L-075-KP-1-NN-80-R-3-S1-E-22-GBA-26-26-24	SERIES 90	S90-075PV
9521318	PUMP-VAR DISPL, CCW	90-L-075-MA-1-NN-80-L-3-C6-D-03-GBA-42-42-20	SERIES 90	S90-075PV
9521319	PUMP-VAR DISPL, CCW	90-L-075-MA-1-CD-80-S-3-C6-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9521320	PUMP-VAR DISPL, CCW	90-L-075-MA-1-NN-80-S-3-C6-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9521321	PUMP-VAR DISPL, CCW	90-L-075-KP-6-NN-60-L-4-K2-D-03-GBA-45-45-24	SERIES 90	S90-075PV
9521322	PUMP-VAR DISPL, CCW	90-L-075-MA-1-BC-60-S-3-C6-D-03-GBA-35-35-20	SERIES 90	S90-075PV
9521323	PUMP-VAR DISPL, CCW	90-L-075-HF-1-NN-60-P-4-S1-D-03-GBA-42-42-20	SERIES 90	S90-075PV
9521324	PUMP-VAR DISPL, CCW	90-L-075-KA-1-CD-80-R-4-C6-E-02-GBA-29-29-24	SERIES 90	S90-075PV
9521325	PUMP-VAR DISPL, CCW	90-L-075-LB-2-NN-60-S-3-S1-E-04-FAC-43-43-24	SERIES 90	S90-075PV
9521327	PUMP-VAR DISPL, CCW	90-L-075-KA-1-BC-60-R-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9521328	PUMP-VAR DISPL, CCW	90-L-075-MB-2-NN-60-S-3-S1-C-03-FAC-43-43-20	SERIES 90	S90-075PV
9521329	PUMP-VAR DISPL, CCW	90-L-075-EX-1-NN-80-R-4-S1-D-03-GBA-35-35-20	SERIES 90	S90-075PV
9521331	PUMP-VAR DISPL, CCW	90-L-075-KP-1-NN-80-R-3-T2-E-03-GBA-42-42-24	SERIES 90	S90-075PV
9521332	PUMP-VAR DISPL, CCW	90-L-075-KA-1-NN-60-S-3-S1-D-03-GBA-38-38-24	SERIES 90	S90-075PV
9521333	PUMP-VAR DISPL, CCW	90-L-075-KA-1-NN-60-S-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9521334	PUMP-VAR DISPL, CCW	90-L-075-KA-1-NN-60-P-3-S1-D-00-GBA-38-38-24	SERIES 90	S90-075PV
9521336	PUMP-VAR DISPL, CCW	90-L-075-KA-1-NN-60-S-3-S1-D-03-GBA-32-32-24	SERIES 90	S90-075PV
9521337	PUMP-VAR DISPL, CCW	90-L-075-DC-1-CD-60-R-3-C7-C-GB-GBA-38-38-24	SERIES 90	S90-075PV
9521339	PUMP-VAR DISPL, CCW	90-L-075-KP-2-CD-80-P-3-S1-E-03-EBC-42-42-24	SERIES 90	S90-075PV
9521340	PUMP-VAR DISPL, CCW	90-L-075-KP-1-BB-80-P-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-075PV
9521341	PUMP-VAR DISPL, CCW	90-L-075-CA-1-CD-80-S-4-S1-D-00-GBA-35-35-24	SERIES 90	S90-075PV

9521342	PUMP-VAR DISPL, CCW	90-L-075-CA-1-NN-80-S-4-S1-D-00-GBA-23-23-24	SERIES 90	S90-075PV
9521343	PUMP-VAR-DISPL CCW 90PV075	90-L-075-KA-1-CD-60-S-4-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9521344	PUMP-VAR DISPL, CCW	90-L-075-KP-1-AB-60-S-3-S1-D-03-EDC-42-42-24	SERIES 90	S90-075PV
9521345	PUMP-VAR DISPL, CCW	90-L-075-KA-1-NN-60-S-3-S1-D-03-EBC-38-38-24	SERIES 90	S90-075PV
9521349	PUMP-VAR DISPL, CCW	90-L-075-MB-1-CD-60-P-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9521350	PUMP-VAR DISPL, CCW	90-L-075-MB-1-NN-60-P-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9521351	PUMP-VAR DISPL, CCW	90-L-075-KN-1-AH-80-L-4-S1-F-03-GBA-26-26-24	SERIES 90	S90-075PV
9521352	PUMP-VAR DISPL, CCW	90-L-075-KA-1-NN-60-P-3-T2-D-03-GBA-38-26-24	SERIES 90	S90-075PV
9521353	PUMP-VAR DISPL, CCW	90-L-075-KA-1-NN-80-S-4-C7-E-03-GBA-17-17-24	SERIES 90	S90-075PV
9521354	PUMP-VAR DISPL, CCW	90-L-075-KA-1-AB-60-P-3-T2-D-03-GBA-38-26-24	SERIES 90	S90-075PV
9521355	PUMP-VAR DISPL, CCW	90-L-075-KA-2-BC-60-R-3-S1-E-00-GBA-35-35-24	SERIES 90	S90-075PV
9521357	PUMP-VAR DISPL, CCW	90-L-075-CA-1-NN-60-S-4-C6-E-00-GBA-42-42-20	SERIES 90	S90-075PV
9521358	PUMP-VAR DISPL, CCW	90-L-075-HF-1-AB-80-S-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9521359	PUMP-VAR DISPL, CCW	90-L-075-KA-1-BM-60-S-4-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9521360	PUMP-VAR DISPL, CCW	90-L-075-MA-1-AB-61-P-3-T1-D-03-GBA-32-32-24	SERIES 90	S90-075PV
9521361	PUMP-VAR DISPL, CCW	90-L-075-KP-1-NN-80-P-3-T2-E-03-GBA-42-42-24	SERIES 90	S90-075PV
9521362	PUMP-VAR DISPL, CCW	90-L-075-KP-1-NN-60-R-3-S1-D-03-FAB-42-42-24	SERIES 90	S90-075PV
9521363	PUMP-VAR DISPL, CCW	90-L-075-KP-1-CD-60-R-3-S1-D-03-FAB-42-42-24	SERIES 90	S90-075PV
9521364	PUMP-VAR DISPL, CCW	90-L-075-KP-1-NN-60-R-1-S1-E-28-GBA-32-14-24-F024	SERIES 90	S90-075PV
9521365	PUMP-VAR DISPL, CCW	90-L-075-MA-1-NN-60-L-4-S1-E-03-GBA-32-32-24	SERIES 90	S90-075PV
9521366	PUMP-VAR DISPL, CCW	90-L-075-HF-1-NN-60-L-3-S1-E-03-GBA-32-32-24	SERIES 90	S90-075PV
9521367	PUMP-VAR DISPL, CCW	90-L-075-HM-1-NN-60-P-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9521368	PUMP-VAR DISPL, CCW	90-L-075-KP-1-AB-60-P-4-S1-D-03-GBA-23-23-24	SERIES 90	S90-075PV
9521369	PUMP-VAR DISPL, CCW	90-L-075-KP-1-AB-60-S-3-S1-D-03-GBA-29-29-24	SERIES 90	S90-075PV
9521370	PUMP-VAR DISPL, CCW	90-L-075-KP-1-NN-60-L-3-K2-D-03-GBA-35-35-20	SERIES 90	S90-075PV
9521371	PUMP-VAR DISPL, CCW	90-L-075-KA-1-CD-60-L-3-S1-D-22-GBA-38-38-24	SERIES 90	S90-075PV
9521372	PUMP-VAR DISPL, CCW	90-L-075-KA-1-NN-60-L-3-S1-D-22-GBA-38-38-24	SERIES 90	S90-075PV
9521373	PUMP-VAR DISPL, CCW	90-L-075-HK-1-AC-60-R-3-S1-E-04-GBA-38-38-24	SERIES 90	S90-075PV
9521374	PUMP-VAR DISPL, CCW	90-L-075-HK-1-AC-60-R-3-S1-E-04-GBA-35-35-24	SERIES 90	S90-075PV
9521375	PUMP-VAR DISPL, CCW	90-L-075-MV-1-BC-80-S-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9521376	PUMP-VAR DISPL, CCW	90-L-075-HU-1-BB-80-R-3-S1-E-04-GBA-32-32-24	SERIES 90	S90-075PV
9521377	PUMP-VAR DISPL, CCW	90-L-075-HF-2-NN-60-S-F-S1-E-33-GBA-20-20-28	SERIES 90	S90-075PV
9521378	PUMP-VAR DISPL, CCW	90-L-075-KP-1-NN-60-R-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-075PV
9521379	PUMP-VAR DISPL, CCW	90-L-075-KP-1-AH-80-P-3-T2-F-03-GBA-42-42-24	SERIES 90	S90-075PV
9521380	PUMP-VAR DISPL, CCW	90-L-075-KA-6-NN-80-S-4-K2-E-22-GBA-45-45-24	SERIES 90	S90-075PV
9521381	PUMP-VAR DISPL, CCW	90-L-075-KP-1-BB-80-R-3-S1-E-00-GBA-32-32-24	SERIES 90	S90-075PV

9521383	PUMP-VAR DISPL, CCW	90-L-075-KP-7-AH-60-P-3-T1-F-03-GBA-45-45-24	SERIES 90	S90-075PV
9521386	PUMP-VAR DISPL, CCW	90-L-075-KP-1-NN-60-P-4-S1-E-03-GBA-23-23-24	SERIES 90	S90-075PV
9521387	PUMP-VAR DISPL, CCW	90-L-075-MB-1-CD-80-L-4-C7-D-03-GBA-38-38-24-F022	SERIES 90	S90-075PV
9521388	PUMP-VAR DISPL, CCW	90-L-075-KP-1-AB-80-S-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9521389	PUMP-VAR DISPL, CCW	90-L-075-KA-1-NN-60-L-3-S1-D-03-EBC-38-38-24	SERIES 90	S90-075PV
9521390	PUMP-VAR DISPL, CCW	90-L-075-HS-1-CD-60-S-3-S1-E-06-GBA-42-42-20	SERIES 90	S90-075PV
9521391	PUMP-VAR DISPL, CCW	90-L-075-HS-1-AB-60-S-3-S1-E-06-GBA-42-42-20	SERIES 90	S90-075PV
9521392	PUMP-VAR DISPL, CCW	90-L-075-KP-1-CD-80-S-3-S1-D-01-GBA-38-38-24	SERIES 90	S90-075PV
9521394	PUMP-VAR DISPL, CCW	90-L-075-KP-1-CD-80-S-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9521395	PUMP-VAR DISPL, CCW	90-L-075-KA-2-NN-80-S-3-S1-D-33-GBA-42-14-24	SERIES 90	S90-075PV
9521396	PUMP-VAR DISPL, CCW	90-L-075-KA-1-NN-60-R-3-S1-D-03-EBC-38-38-24	SERIES 90	S90-075PV
9521397	PUMP-VAR DISPL, CCW	90-L-075-MA-1-NN-60-S-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-075PV
9521398	PUMP-VAR DISPL, CCW	90-L-075-MB-1-CD-61-S-3-C7-C-03-GBA-35-35-24	SERIES 90	S90-075PV
9521399	PUMP-VAR DISPL, CCW	90-L-075-MB-1-NN-61-S-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-075PV
9521400	PUMP-VAR DISPL, CCW	90-L-075-MV-1-BB-80-S-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9521401	PUMP-VAR DISPL, CCW	90-L-075-KP-G-BC-60-S-3-S1-D-03-GBA-23-23-20	SERIES 90	S90-075PV
9521402	PUMP-VAR DISPL, CCW	90-L-075-MA-1-NN-60-S-3-C6-E-03-GBA-35-35-20	SERIES 90	S90-075PV
9521402C	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-1-NN-60-S-3-C6-E-03-GBA-35-35-20	SERIES 90	S90-075PV
9521403	PUMP-VAR DISPL, CCW	90-L-075-KP-1-NN-60-R-3-S1-D-03-GBA-29-29-24	SERIES 90	S90-075PV
9521404	PUMP-VAR DISPL, CCW	90-L-075-DC-1-NN-60-R-4-T1-D-GB-GBA-29-29-24	SERIES 90	S90-075PV
9521405	PUMP-VAR DISPL, CCW	90-L-075-MB-1-AB-60-P-3-S1-D-03-GBA-38-38-24	SERIES 90	S90-075PV
9521407	PUMP-VAR DISPL, CCW	90-L-075-KA-1-CD-80-R-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9521408	PUMP-VAR DISPL, CCW	90-L-075-HM-1-AC-60-P-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9521409	PUMP-VAR DISPL, CCW	90-L-075-KP-1-NN-80-R-3-S1-E-03-GBA-29-29-24	SERIES 90	S90-075PV
9521410	PUMP-VAR DISPL, CCW	90-L-075-MB-1-NN-60-P-3-C6-D-03-GBA-38-38-20	SERIES 90	S90-075PV
9521411	PUMP-VAR DISPL, CCW	90-L-075-HS-1-CD-60-S-3-S1-D-03-GBA-32-32-20	SERIES 90	S90-075PV
9521412	PUMP-VAR DISPL, CCW	90-L-075-KA-1-NN-60-P-3-S1-D-03-GBA-42-42-20	SERIES 90	S90-075PV
9521413	PUMP-VAR DISPL, CCW	90-L-075-KA-1-NN-60-S-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9521414	PUMP-VAR DISPL, CCW	90-L-075-MA-1-NN-80-S-3-T2-E-04-GBA-35-35-24	SERIES 90	S90-075PV
9521415	PUMP-VAR DISPL, CCW	90-L-075-HF-1-BB-80-P-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9521416	PUMP-VAR DISPL, CCW	90-L-075-HK-1-NN-60-S-3-S1-D-03-GBA-29-29-24	SERIES 90	S90-075PV
9521417	PUMP-VAR DISPL, CCW	90-L-075-KA-1-CD-60-S-3-T2-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9521418	PUMP-VAR DISPL, CCW	90-L-075-KP-1-CD-80-L-3-C6-E-03-GBA-29-29-24	SERIES 90	S90-075PV
9521419	PUMP-VAR DISPL, CCW	90-L-075-MA-6-NN-80-S-4-S1-E-03-GBA-45-45-24	SERIES 90	S90-075PV
9521420	PUMP-VAR DISPL, CCW	90-L-075-DC-1-NN-80-S-4-S1-D-GB-GBA-35-35-24	SERIES 90	S90-075PV
9521421	PUMP-VAR DISPL, CCW	90-L-075-KA-1-NN-80-R-3-S1-D-03-GBA-38-38-24	SERIES 90	S90-075PV

9521422	PUMP-VAR DISPL, CCW	90-L-075-HK-1-CD-60-P-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9521423	PUMP-VAR DISPL, CCW	90-L-075-MA-1-CD-80-P-4-S1-D-03-GBA-35-35-20	SERIES 90	S90-075PV
9521424	PUMP-VAR DISPL, CCW	90-L-075-KA-1-CD-80-R-3-S1-D-03-GBA-38-38-24	SERIES 90	S90-075PV
9521426	PUMP-VAR DISPL, CCW	90-L-075-EA-1-NN-60-P-3-S1-D-00-GBA-38-38-24	SERIES 90	S90-075PV
9521427	PUMP-VAR DISPL, CCW	90-L-075-EA-2-BC-60-R-3-S1-E-00-GBA-35-35-24	SERIES 90	S90-075PV
9521428	PUMP-VAR DISPL, CCW	90-L-075-KA-1-NN-80-R-4-S1-D-03-GBA-38-38-24	SERIES 90	S90-075PV
9521429	PUMP-VAR DISPL, CCW	90-L-075-KA-1-CD-80-R-4-S1-D-03-GBA-38-38-24	SERIES 90	S90-075PV
9521430	PUMP-VAR DISPL, CCW	90-L-075-EA-1-CD-80-R-3-C7-D-00-GBA-35-35-24	SERIES 90	S90-075PV
9521431	PUMP-VAR DISPL, CCW	90-L-075-EA-1-BC-80-R-3-S1-D-00-GBA-35-35-24	SERIES 90	S90-075PV
9521432	PUMP-VAR DISPL, CCW	90-L-075-KP-1-NN-60-L-3-S1-D-03-GBA-29-29-24	SERIES 90	S90-075PV
9521433	PUMP-VAR DISPL, CCW	90-L-075-HS-1-AB-80-R-3-K2-D-03-GBA-35-35-20	SERIES 90	S90-075PV
9521436	PUMP-VAR DISPL, CCW	90-L-075-HM-1-NN-60-X-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9521438	PUMP-VAR DISPL, CCW	90-L-075-KP-7-AH-60-P-3-T2-F-03-GBA-45-45-24	SERIES 90	S90-075PV
9521439	PUMP-VAR DISPL, CCW	90-L-075-EP-1-NN-80-S-3-S1-D-02-GBA-42-42-24	SERIES 90	S90-075PV
9521440	PUMP-VAR DISPL, CCW	90-L-075-KA-1-BC-61-S-3-S1-D-03-GBA-14-14-20	SERIES 90	S90-075PV
9521441	PUMP-VAR DISPL, CCW	90-L-075-KA-6-NN-80-S-4-K2-D-22-GBA-45-45-24	SERIES 90	S90-075PV
9521442	PUMP-VAR DISPL, CCW	90-L-075-MA-1-NN-60-S-3-S1-D-03-GBA-26-26-24	SERIES 90	S90-075PV
9521443	PUMP-VAR DISPL, CCW	90-L-075-HU-1-BB-80-R-4-S1-E-04-GBA-32-32-24	SERIES 90	S90-075PV
9521444	PUMP-VAR DISPL, CCW	90-L-075-KA-1-AB-60-R-3-S1-D-03-GBA-29-29-24	SERIES 90	S90-075PV
9521445	PUMP-VAR DISPL, CCW	90-L-075-MA-1-BC-81-S-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9521446	PUMP-VAR DISPL, CCW	90-L-075-MA-6-AB-80-S-3-C7-D-03-GBA-45-45-24	SERIES 90	S90-075PV
9521447	PUMP-VAR DISPL, CCW	90-L-075-KA-1-BC-80-S-3-S1-D-03-GBA-26-26-20	SERIES 90	S90-075PV
9521448	PUMP-VAR DISPL, CCW	90-L-075-MA-6-NN-80-S-4-S1-D-03-GBA-45-45-28	SERIES 90	S90-075PV
9521449	PUMP-VAR DISPL, CCW	90-L-075-HF-1-NN-60-P-3-C6-D-03-GBA-38-38-24	SERIES 90	S90-075PV
9521450	PUMP-VAR DISPL, CCW	90-L-075-KP-2-AH-80-P-3-T2-F-03-GBA-42-42-24	SERIES 90	S90-075PV
9521451	PUMP-VAR DISPL, CW	90-R-075-EP-1-AB-80-R-3-S1-D-03-EBC-38-38-24	SERIES 90	S90-075PV
9521452	PUMP-VAR DISPL, CCW	90-L-075-EA-1-BB-60-S-4-T1-D-03-GBA-35-35-20-F022	SERIES 90	S90-075PV
9521468	PUMP-VAR DISPL, CCW	90-L-075-KP-7-AH-60-S-3-T1-F-03-GBA-48-48-24	SERIES 90	S90-075PV
9521469	PUMP-VAR DISPL, CW	90-R-075-KP-7-AH-60-S-3-T1-F-03-GBA-48-48-24	SERIES 90	S90-075PV
9521470	PUMP-VAR DISPL, CCW	90-L-075-MA-7-AH-60-S-4-T1-F-03-GBA-48-48-24	SERIES 90	S90-075PV
9521471	PUMP-VAR DISPL, CCW	90-L-075-MC-7-AH-60-S-4-T1-F-03-GBA-48-48-24	SERIES 90	S90-075PV
9521472	PUMP-VAR DISPL, CW	90-R-075-MA-7-AH-60-S-4-T1-F-03-GBA-48-48-24	SERIES 90	S90-075PV
9521473	PUMP-VAR DISPL, CW	90-R-075-MC-7-AH-60-S-4-T1-F-03-GBA-48-48-24	SERIES 90	S90-075PV
9521502	PUMP-VAR DISPL, CW	90-R-075-MB-1-BC-60-R-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9521503	PUMP-VAR DISPL, CW	90-R-075-EA-1-NN-60-L-3-S1-D-03-GBA-17-17-20	SERIES 90	S90-075PV
9521504	PUMP-VAR DISPL, CW	90-R-075-EA-1-CD-60-S-4-S1-E-03-GBA-35-35-20	SERIES 90	S90-075PV

9521505	PUMP-VAR DISPL, CW	90-R-075-HF-1-BC-80-R-3-S1-E-A3-GBA-38-38-28	SERIES 90	S90-075PV
9521506	PUMP-VAR DISPL, CW	90-R-075-HF-1-CD-80-R-3-S1-E-A3-GBA-38-38-28	SERIES 90	S90-075PV
9521507	PUMP-VAR DISPL, CW	90-R-075-EA-1-AB-81-S-3-S1-D-03-GBA-26-26-20	SERIES 90	S90-075PV
9521508	PUMP-VAR DISPL, CW	90-R-075-EA-1-NN-80-S-3-C6-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9521509	PUMP-VAR DISPL, CW	90-R-075-MB-1-CD-80-S-3-C6-D-02-GBA-35-35-20	SERIES 90	S90-075PV
9521510	PUMP-VAR DISPL, CW	90-R-075-MB-1-BC-60-R-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9521511	PUMP-VAR DISPL, CW	90-R-075-EA-1-NN-60-R-3-S1-E-03-GBA-17-17-20	SERIES 90	S90-075PV
9521513	PUMP-VAR DISPL, CW	90-R-075-EP-1-AB-80-R-3-S1-D-03-GBA-38-38-24	SERIES 90	S90-075PV
9521514	PUMP-VAR DISPL, CW	90-R-075-HF-1-BC-80-S-3-S1-E-03-GBA-35-35-28	SERIES 90	S90-075PV
9521515	PUMP-VAR DISPL, CW	90-R-075-MB-1-NN-60-S-3-S1-D-03-GBA-29-29-20	SERIES 90	S90-075PV
9521516	PUMP-VAR DISPL, CW	90-R-075-MB-1-NN-60-S-3-C7-D-03-GBA-29-29-20	SERIES 90	S90-075PV
9521517	PUMP-VAR DISPL, CW	90-R-075-HF-1-AB-60-R-3-S1-E-00-GBA-23-23-24	SERIES 90	S90-075PV
9521519	PUMP-VAR DISPL, CW	90-R-075-EA-1-NN-80-P-3-C6-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9521520	PUMP-VAR DISPL, CW	90-R-075-MA-1-NN-80-S-3-C6-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9521521	PUMP-VAR DISPL, CW	90-R-075-DC-1-CD-60-L-4-S1-D-GB-GBA-20-20-24	SERIES 90	S90-075PV
9521522	PUMP-VAR DISPL, CW	90-R-075-EP-1-AB-80-S-3-S1-D-22-GBA-35-35-24	SERIES 90	S90-075PV
9521523	PUMP-VAR DISPL, CW	90-R-075-MB-1-BC-60-R-3-S1-D-01-GBA-35-35-24	SERIES 90	S90-075PV
9521525	PUMP-VAR DISPL, CW	90-R-075-MA-1-BB-60-L-3-S1-E-06-GBA-35-35-24	SERIES 90	S90-075PV
9521526	PUMP-VAR DISPL, CW	90-R-075-EP-1-AB-80-L-3-S1-D-03-GBA-29-29-24	SERIES 90	S90-075PV
9521527	PUMP-VAR DISPL, CW	90-R-075-EA-1-NN-60-S-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9521528	PUMP-VAR DISPL, CW	90-R-075-EP-1-AB-80-R-3-S1-D-22-GBA-35-35-24	SERIES 90	S90-075PV
9521529	PUMP-VAR DISPL, CW	90-R-075-EA-1-NN-80-S-3-C6-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9521530	PUMP-VAR DISPL, CW	90-R-075-MA-1-BC-80-S-3-S1-D-03-GBA-32-32-24	SERIES 90	S90-075PV
9521531	PUMP-VAR DISPL, CW	90-R-075-DD-1-CD-60-S-3-S1-E-GB-GBA-35-35-24	SERIES 90	S90-075PV
9521532	PUMP-VAR DISPL, CW	90-R-075-MA-1-AB-60-P-3-T2-E-03-GBA-42-42-24	SERIES 90	S90-075PV
9521533	PUMP-VAR DISPL, CW	90-R-075-MA-1-NN-80-R-3-T1-E-03-GBA-23-23-24	SERIES 90	S90-075PV
9521534	PUMP-VAR DISPL, CW	90-R-075-MA-1-NN-80-S-3-S1-D-03-GBA-42-42-20	SERIES 90	S90-075PV
9521535	PUMP-VAR DISPL, CW	90-R-075-MA-1-CD-60-P-3-C7-D-03-GBA-35-35-20	SERIES 90	S90-075PV
9521536	PUMP-VAR DISPL, CW	90-R-075-MA-1-NN-60-P-3-S1-D-03-GBA-35-35-20	SERIES 90	S90-075PV
9521537	PUMP-VAR DISPL, CW	90-R-075-MA-1-BC-60-P-3-S1-D-03-GBA-35-35-20	SERIES 90	S90-075PV
9521537C	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-BC-60-P-3-S1-D-03-GBA-35-35-20	SERIES 90	S90-075PV
9521538	PUMP-VAR DISPL, CW	90-R-075-EP-1-BC-60-S-3-S1-D-03-GBA-32-32-24	SERIES 90	S90-075PV
9521539	PUMP-VAR DISPL, CW	90-R-075-MD-1-BC-60-R-3-S1-D-02-GBA-35-35-24	SERIES 90	S90-075PV
9521540	PUMP-VAR DISPL, CW	90-R-075-HF-1-BC-80-S-3-S1-D-02-GBA-32-32-24	SERIES 90	S90-075PV
9521541	PUMP-VAR DISPL, CW	90-R-075-MS-6-BB-80-P-3-S1-D-03-GBA-45-45-28	SERIES 90	S90-075PV
9521542	PUMP-VAR DISPL, CW	90-R-075-MS-6-CD-80-P-3-C6-D-03-GBA-45-45-28	SERIES 90	S90-075PV

9521543	PUMP-VAR DISPL, CW	90-R-075-MB-6-BB-80-S-4-S1-E-03-GBA-48-20-24	SERIES 90	S90-075PV
9521544	PUMP-VAR DISPL, CW	90-R-075-MB-1-BC-61-R-3-S1-D-01-GBA-35-35-24	SERIES 90	S90-075PV
9521545	PUMP-VAR-DISPL CCW 90PV075	90-R-075-MS-6-CD-80-P-3-C6-D-02-GBA-45-45-28	SERIES 90	S90-075PV
9521546	PUMP-VAR-DISPL CW 90PV075	90-R-075-MS-6-BB-80-P-3-S1-D-02-GBA-45-45-28	SERIES 90	S90-075PV
9521547	PUMP-VAR DISPL, CW	90-R-075-EP-1-NN-80-L-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9521548	PUMP-VAR DISPL, CW	90-R-075-EA-1-CD-60-L-4-S1-D-02-GBA-29-29-24	SERIES 90	S90-075PV
9521549	PUMP-VAR DISPL, CW	90-R-075-MA-1-CD-60-P-3-C7-D-04-GBA-35-35-20	SERIES 90	S90-075PV
9521550	PUMP-VAR DISPL, CW	90-R-075-MA-1-NN-60-P-3-S1-D-04-GBA-35-35-20	SERIES 90	S90-075PV
9521551	PUMP-VAR DISPL, CW	90-R-075-MA-1-BC-60-P-3-S1-D-04-GBA-35-35-20	SERIES 90	S90-075PV
9521552	PUMP-VAR DISPL, CW	90-R-075-MA-1-NN-80-S-3-S1-C-03-GBA-35-35-20	SERIES 90	S90-075PV
9521553	PUMP-VAR DISPL, CW	90-R-075-EP-1-NN-80-R-4-S1-D-03-GBA-17-17-20	SERIES 90	S90-075PV
9521555	PUMP-VAR DISPL, CW	90-R-075-EA-1-CD-60-P-3-C7-E-03-GBA-26-26-24	SERIES 90	S90-075PV
9521556	PUMP-VAR DISPL, CW	90-R-075-EA-1-BC-60-P-3-S1-E-03-GBA-26-26-24	SERIES 90	S90-075PV
9521557	PUMP-VAR DISPL, CW	90-R-075-EA-1-AB-60-P-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9521559	PUMP-VAR DISPL, CW	90-R-075-MA-1-NN-80-R-3-S1-E-03-GBA-38-38-24	SERIES 90	S90-075PV
9521560	PUMP-VAR DISPL, CW	90-R-075-HS-1-BC-80-S-3-S1-E-03-GBA-35-35-28	SERIES 90	S90-075PV
9521561	PUMP-VAR DISPL, CW	90-R-075-EX-1-NN-60-R-3-S1-D-00-GBA-42-42-24	SERIES 90	S90-075PV
9521562	PUMP-VAR DISPL, CW	90-R-075-MA-1-NN-80-S-3-S1-D-03-GBA-35-35-20	SERIES 90	S90-075PV
9521563	PUMP-VAR DISPL, CW	90-R-075-DD-1-NN-60-S-3-S1-E-GB-GBA-35-35-24	SERIES 90	S90-075PV
9521564	PUMP-VAR DISPL, CW	90-R-075-EA-1-BC-60-S-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9521565	PUMP-VAR DISPL, CW	90-R-075-MK-6-BB-80-S-3-S1-D-03-GBA-45-17-24	SERIES 90	S90-075PV
9521566	PUMP-VAR DISPL, CW	90-R-075-MA-1-NN-80-R-3-C6-C-03-GBA-35-35-20	SERIES 90	S90-075PV
9521567	PUMP-VAR DISPL, CW	90-R-075-MA-1-NN-80-R-3-C6-D-03-GBA-35-35-20	SERIES 90	S90-075PV
9521568	PUMP-VAR DISPL, CW	90-R-075-MA-1-BC-60-S-3-S1-D-03-GBA-32-32-24	SERIES 90	S90-075PV
9521569	PUMP-VAR DISPL, CW	90-R-075-EA-1-NN-60-P-3-S1-D-03-GBA-20-20-20	SERIES 90	S90-075PV
9521570	PUMP-VAR DISPL, CW	90-R-075-MA-1-NN-60-P-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9521571	PUMP-VAR DISPL, CW	90-R-075-HF-1-NN-60-R-3-S1-E-03-GBA-38-38-28	SERIES 90	S90-075PV
9521572	PUMP-VAR DISPL, CW	90-R-075-MB-1-BC-80-S-3-C6-D-02-FBA-35-35-20	SERIES 90	S90-075PV
9521573	PUMP-VAR DISPL, CW	90-R-075-LC-1-BC-80-S-3-C6-D-02-FAC-35-35-20	SERIES 90	S90-075PV
9521574	PUMP-VAR DISPL, CW	90-R-075-EA-1-NN-80-R-3-S1-E-03-GBA-29-29-24	SERIES 90	S90-075PV
9521575	PUMP-VAR DISPL, CW	90-R-075-EA-1-NN-80-R-3-S1-E-00-GBA-42-42-24	SERIES 90	S90-075PV
9521576	PUMP-VAR DISPL, CW	90-R-075-DD-1-CD-80-R-3-S1-E-G1-GBA-35-35-24	SERIES 90	S90-075PV
9521577	PUMP-VAR DISPL, CW	90-R-075-MB-1-BB-60-S-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9521578	PUMP-VAR DISPL, CW	90-R-075-MB-1-AB-60-S-3-S1-E-02-GBA-32-32-20	SERIES 90	S90-075PV
9521579	PUMP-VAR DISPL, CW	90-R-075-EP-1-NN-80-R-3-S1-D-22-GBA-35-35-24	SERIES 90	S90-075PV
9521580	PUMP-VAR DISPL, CW	90-R-075-EP-1-NN-80-R-3-S1-D-03-EBC-42-42-24	SERIES 90	S90-075PV

9521581	PUMP-VAR DISPL, CW	90-R-075-MA-1-BC-60-S-3-C6-D-03-GBA-35-35-20	SERIES 90	S90-075PV
9521582	PUMP-VAR DISPL, CW	90-R-075-MA-6-NN-80-S-3-S1-E-03-GBA-48-48-24	SERIES 90	S90-075PV
9521583	PUMP-VAR DISPL, CW	90-R-075-EP-1-BB-60-L-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-075PV
9521584	PUMP-VAR DISPL, CW	90-R-075-MD-1-NN-60-S-3-S1-D-02-GBA-42-42-24	SERIES 90	S90-075PV
9521585	PUMP-VAR DISPL, CW	90-R-075-EA-1-NN-60-S-3-K2-E-03-GBA-29-29-24	SERIES 90	S90-075PV
9521586	PUMP-VAR DISPL, CW	90-R-075-MA-1-NN-81-S-3-T2-E-03-GBA-35-35-20	SERIES 90	S90-075PV
9521587	PUMP-VAR DISPL, CW	90-R-075-MA-1-AB-81-S-3-T2-E-03-GBA-35-35-20	SERIES 90	S90-075PV
9521588	PUMP-VAR DISPL, CW	90-R-075-EA-1-NN-81-S-3-T2-E-03-GBA-35-35-20	SERIES 90	S90-075PV
9521589	PUMP-VAR DISPL, CW	90-R-075-EA-1-AB-81-S-3-T2-E-03-GBA-35-35-20	SERIES 90	S90-075PV
9521590	PUMP-VAR DISPL, CW	90-R-075-MA-1-AB-80-R-3-T1-E-03-GBA-42-42-24	SERIES 90	S90-075PV
9521591	PUMP-VAR DISPL, CW	90-R-075-MB-1-CD-61-S-3-S1-E-03-GBA-35-35-20	SERIES 90	S90-075PV
9521592	PUMP-VAR DISPL, CW	90-R-075-CB-1-NN-60-S-3-C7-D-00-GBA-35-35-24	SERIES 90	S90-075PV
9521593	PUMP-VAR DISPL, CW	90-R-075-EA-1-NN-80-S-3-C6-E-03-GBA-42-42-24	SERIES 90	S90-075PV
9521594	PUMP-VAR DISPL, CW	90-R-075-MA-1-NN-80-S-3-C6-E-03-GBA-42-42-24	SERIES 90	S90-075PV
9521594C	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-NN-80-S-3-C6-E-03-GBA-42-42-24	SERIES 90	S90-075PV
9521595	PUMP-VAR DISPL, CW	90-R-075-EA-1-NN-80-P-3-S1-D-04-GBA-38-38-24	SERIES 90	S90-075PV
9521598	PUMP-VAR DISPL, CW	90-R-075-MA-1-NN-60-P-3-K2-D-03-GBA-17-17-20	SERIES 90	S90-075PV
9521599	PUMP-VAR DISPL, CW	90-R-075-EA-1-AC-80-S-3-S1-E-03-GBA-29-29-24	SERIES 90	S90-075PV
9521600	PUMP-VAR DISPL, CW	90-R-075-MA-1-NN-80-S-3-S1-D-03-GBA-32-32-24	SERIES 90	S90-075PV
9521601	PUMP-VAR DISPL, CW	90-R-075-HF-1-BC-61-S-3-S1-E-03-GBA-32-32-24	SERIES 90	S90-075PV
9521602	PUMP-VAR DISPL, CW	90-R-075-EP-1-NN-80-L-3-S1-D-03-GBA-20-20-24	SERIES 90	S90-075PV
9521603	PUMP-VAR DISPL, CW	90-R-075-MA-1-AB-80-S-3-K2-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9521604	PUMP-VAR DISPL, CW	90-R-075-EP-1-NN-80-P-3-S1-D-04-GBA-38-38-24	SERIES 90	S90-075PV
9521605	PUMP-VAR DISPL, CW	90-R-075-MA-1-NN-60-P-3-C6-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9521606	PUMP-VAR DISPL, CW	90-R-075-MA-1-NN-60-P-3-C6-D-03-GBA-35-35-18	SERIES 90	S90-075PV
9521607	PUMP-VAR DISPL, CW	90-R-075-EP-1-NN-80-L-3-K2-E-03-GBA-35-35-24	SERIES 90	S90-075PV
9521608	PUMP-VAR DISPL, CW	90-R-075-ME-1-BE-62-R-3-C7-D-03-GFK-35-35-24	SERIES 90	S90-075PV
9521609	PUMP-VAR DISPL, CW	90-R-075-MT-1-NN-80-P-3-C6-E-03-GBA-42-42-24	SERIES 90	S90-075PV
9521610	PUMP-VAR DISPL, CW	90-R-075-MD-1-AB-60-R-3-S1-E-02-GBA-32-32-24	SERIES 90	S90-075PV
9521611	PUMP-VAR DISPL, CW	90-R-075-EA-1-NN-60-P-4-C7-D-02-GBA-14-42-20	SERIES 90	S90-075PV
9521612	PUMP-VAR DISPL, CW	90-R-075-MA-1-BB-60-P-3-C6-D-03-GBA-38-38-20	SERIES 90	S90-075PV
9521613	PUMP-VAR DISPL, CW	90-R-075-MA-1-AB-60-P-3-C6-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9521614	PUMP-VAR DISPL, CW	90-R-075-EA-1-CD-60-P-3-S1-D-09-GBA-42-42-24	SERIES 90	S90-075PV
9521615	PUMP-VAR DISPL, CW	90-R-075-EA-1-AB-60-P-3-S1-D-09-GBA-42-42-24	SERIES 90	S90-075PV
9521617	PUMP-VAR DISPL, CW	90-R-075-MA-1-AB-60-P-3-C6-D-73-GBA-35-35-24	SERIES 90	S90-075PV
9521618	PUMP-VAR DISPL, CW	90-R-075-MA-1-NN-60-S-3-T1-E-03-GBA-42-42-24	SERIES 90	S90-075PV

9521619	PUMP-VAR DISPL, CW	90-R-075-EP-1-NN-60-S-3-K2-E-02-GBA-23-23-24	SERIES 90	S90-075PV
9521620	PUMP-VAR DISPL, CW	90-R-075-EA-1-CD-80-R-3-C7-D-00-GBA-35-35-24	SERIES 90	S90-075PV
9521621	PUMP-VAR DISPL, CW	90-R-075-EA-1-NN-80-R-3-S1-D-00-GBA-35-35-24	SERIES 90	S90-075PV
9521622	PUMP-VAR DISPL, CW	90-R-075-MA-1-NN-80-L-3-C6-E-03-GBA-42-42-24	SERIES 90	S90-075PV
9521622C	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-NN-80-L-3-C6-E-03-GBA-42-42-24	SERIES 90	S90-075PV
9521623	PUMP-VAR DISPL, CW	90-R-075-MS-6-BB-80-S-3-S1-D-03-GBA-45-17-24	SERIES 90	S90-075PV
9521624	PUMP-VAR DISPL, CW	90-R-075-MA-1-CD-60-S-3-C6-D-03-GBA-42-42-20	SERIES 90	S90-075PV
9521626	PUMP-VAR DISPL, CW	90-R-075-MT-1-NN-60-S-3-C6-E-02-GBA-38-38-24	SERIES 90	S90-075PV
9521627	PUMP-VAR DISPL, CW	90-R-075-KP-1-NN-60-R-3-S1-D-00-GBA-42-42-24	SERIES 90	S90-075PV
9521628	PUMP-VAR DISPL, CW	90-R-075-HF-1-NN-80-P-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-075PV
9521629	PUMP-VAR DISPL, CW	90-R-075-MA-2-CD-60-P-3-C7-E-04-GBA-35-35-20	SERIES 90	S90-075PV
9521630	PUMP-VAR DISPL, CW	90-R-075-MA-2-NN-60-P-3-S1-E-04-GBA-35-35-20	SERIES 90	S90-075PV
9521631	PUMP-VAR DISPL, CW	90-R-075-MA-2-BC-60-P-3-S1-E-04-GBA-35-35-20	SERIES 90	S90-075PV
9521632	PUMP-VAR DISPL, CW	90-R-075-KA-1-CD-80-S-4-S1-D-03-GBA-42-42-20	SERIES 90	S90-075PV
9521633	PUMP-VAR DISPL, CW	90-R-075-MA-A-NN-80-L-3-C6-D-03-GBA-42-42-20	SERIES 90	S90-075PV
9521635	PUMP-VAR DISPL, CW	90-R-075-MB-1-NN-80-S-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9521636	PUMP-VAR DISPL, CW	90-R-075-KP-6-AB-60-S-3-T1-E-03-GBA-48-48-24	SERIES 90	S90-075PV
9521637	PUMP-VAR DISPL, CW	90-R-075-KP-1-NN-80-P-3-S1-D-22-GBA-38-38-24	SERIES 90	S90-075PV
9521638	PUMP-VAR DISPL, CW	90-R-075-KP-1-NN-80-R-3-S1-D-22-GBA-35-35-24	SERIES 90	S90-075PV
9521639	PUMP-VAR DISPL, CW	90-R-075-KP-1-AB-80-R-3-S1-D-22-GBA-35-35-24	SERIES 90	S90-075PV
9521640	PUMP-VAR DISPL, CW	90-R-075-MA-1-NN-80-S-3-S1-E-03-GBA-38-38-24	SERIES 90	S90-075PV
9521641	PUMP-VAR DISPL, CW	90-R-075-MA-1-NN-80-L-3-C6-E-03-GBA-42-42-20	SERIES 90	S90-075PV
9521642	PUMP-VAR DISPL, CW	90-R-075-HF-1-NN-60-P-3-D9-D-03-GBA-35-35-18	SERIES 90	S90-075PV
9521642C	PUMP-VAR DISPL, CW 90PV075	90-R-075-HF-1-NN-60-P-3-D9-D-03-GBA-35-35-18	SERIES 90	S90-075PV
9521643	PUMP-VAR DISPL, CW	90-R-075-MA-1-NN-80-P-4-C6-E-03-GBA-42-42-24	SERIES 90	S90-075PV
9521643C	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-NN-80-P-4-C6-E-03-GBA-42-42-24	SERIES 90	S90-075PV
9521644	PUMP-VAR DISPL, CW	90-R-075-KP-1-NN-80-S-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9521645	PUMP-VAR DISPL, CW	90-R-075-MA-1-AB-80-S-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9521646	PUMP-VAR DISPL, CW	90-R-075-HS-1-NN-80-S-3-S1-E-03-GBA-35-35-28	SERIES 90	S90-075PV
9521647	PUMP-VAR DISPL, CW	90-R-075-MA-1-AC-80-L-3-C6-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9521648	PUMP-VAR DISPL, CW	90-R-075-KA-1-BB-61-P-4-S1-D-03-GBA-23-23-24	SERIES 90	S90-075PV
9521649	PUMP-VAR DISPL, CW	90-R-075-KP-1-NN-80-P-3-S1-D-03-GBA-38-38-24	SERIES 90	S90-075PV
9521650	PUMP-VAR DISPL, CW	90-R-075-MB-1-BC-60-S-3-S1-E-04-GBA-42-42-24	SERIES 90	S90-075PV
9521651	PUMP-VAR DISPL, CW	90-R-075-MB-1-BC-60-P-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9521652	PUMP-VAR DISPL, CW	90-R-075-MA-1-AB-60-L-3-S1-D-00-GBA-38-38-24	SERIES 90	S90-075PV
9521653	PUMP-VAR DISPL, CW	90-R-075-MB-1-BC-80-S-3-S1-D-03-GBA-26-26-24	SERIES 90	S90-075PV

9521654	PUMP-VAR DISPL, CW	90-R-075-KA-1-CD-60-L-3-S1-D-03-GBA-26-26-24	SERIES 90	S90-075PV
9521655	PUMP-VAR DISPL, CW	90-R-075-MB-1-BC-60-R-3-S1-E-02-GBA-35-35-24	SERIES 90	S90-075PV
9521656	PUMP-VAR DISPL, CW	90-R-075-MA-1-CD-80-S-3-C6-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9521657	PUMP-VAR DISPL, CW	90-R-075-MA-1-AB-80-S-3-C6-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9521658	PUMP-VAR DISPL, CW	90-R-075-CB-1-NN-60-R-3-S1-E-00-GBA-38-38-28	SERIES 90	S90-075PV
9521659	PUMP-VAR DISPL, CW	90-R-075-HF-1-NN-60-P-4-S1-D-03-GBA-42-42-20	SERIES 90	S90-075PV
9521659C	PUMP-VAR DISPL, CW 90PV075	90-R-075-HF-1-NN-60-P-4-S1-D-03-GBA-42-42-20	SERIES 90	S90-075PV
9521660	PUMP-VAR DISPL, CW	90-R-075-MS-6-CD-80-P-3-S1-D-02-GBA-45-45-28	SERIES 90	S90-075PV
9521661	PUMP-VAR DISPL, CW	90-R-075-KP-1-BC-80-L-4-S1-E-02-GBA-29-29-24	SERIES 90	S90-075PV
9521662	PUMP-VAR DISPL, CW	90-R-075-KP-1-CD-80-L-4-C7-E-02-GBA-29-29-24	SERIES 90	S90-075PV
9521663	PUMP-VAR DISPL, CW	90-R-075-MB-1-BB-60-S-3-C7-D-03-GBA-42-42-20	SERIES 90	S90-075PV
9521663C	PUMP-VAR DISPL, CW 90PV075	90-R-075-MB-1-BB-60-S-3-C7-D-03-GBA-42-42-20	SERIES 90	S90-075PV
9521664	PUMP-VAR DISPL, CW	90-R-075-KA-1-NN-60-S-3-C7-D-03-GBA-38-38-24	SERIES 90	S90-075PV
9521665	PUMP-VAR DISPL, CW	90-R-075-MA-6-CD-80-S-3-S1-D-00-GBA-45-45-24	SERIES 90	S90-075PV
9521666	PUMP-VAR DISPL, CW	90-R-075-MA-6-NN-80-S-3-S1-D-00-GBA-45-45-24	SERIES 90	S90-075PV
9521667	PUMP-VAR DISPL, CW	90-R-075-KA-1-NN-80-S-3-S1-E-03-GBA-29-29-24	SERIES 90	S90-075PV
9521668	PUMP-VAR DISPL, CW	90-R-075-KP-1-BB-80-R-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9521669	PUMP-VAR DISPL, CW	90-R-075-MA-1-CD-60-P-3-C6-E-03-FAC-35-35-24	SERIES 90	S90-075PV
9521670	PUMP-VAR DISPL, CW	90-R-075-MB-1-BC-60-P-3-S1-D-03-FAC-35-35-24	SERIES 90	S90-075PV
9521671	PUMP-VAR DISPL, CW	90-R-075-KA-1-CD-80-S-3-C7-E-03-GBA-20-20-24	SERIES 90	S90-075PV
9521672	PUMP-VAR DISPL, CW	90-R-075-KA-1-NN-80-S-3-S1-E-03-GBA-20-20-24	SERIES 90	S90-075PV
9521673	PUMP-VAR DISPL, CW	90-R-075-MA-1-NN-81-P-3-S1-D-04-GBA-32-32-20	SERIES 90	S90-075PV
9521674	PUMP-VAR DISPL, CW	90-R-075-KP-1-NN-80-P-3-S1-D-29-GBA-38-38-24	SERIES 90	S90-075PV
9521675	PUMP-VAR DISPL, CW	90-R-075-MA-1-NN-60-S-3-C7-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9521676	PUMP-VAR DISPL, CW	90-R-075-MR-1-BC-60-R-3-S1-D-02-GBA-35-35-24-C021	SERIES 90	S90-075PV
9521677	PUMP-VAR DISPL, CW	90-R-075-MA-1-NN-80-S-3-T1-E-03-GBA-42-42-24	SERIES 90	S90-075PV
9521677C	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-NN-80-S-3-T1-E-03-GBA-42-42-24	SERIES 90	S90-075PV
9521678	PUMP-VAR DISPL, CW	90-R-075-KP-2-CD-80-R-3-S1-E-00-EBC-37-37-20	SERIES 90	S90-075PV
9521679	PUMP-VAR DISPL, CW	90-R-075-KA-1-CD-80-R-3-C7-D-00-GBA-35-35-24	SERIES 90	S90-075PV
9521680	PUMP-VAR DISPL, CW	90-R-075-KA-1-CD-80-R-3-S1-D-00-GBA-35-35-24	SERIES 90	S90-075PV
9521681	PUMP-VAR DISPL, CW	90-R-075-MB-1-NN-80-R-3-S1-D-00-GBA-20-20-24	SERIES 90	S90-075PV
9521682	PUMP-VAR DISPL, CW	90-R-075-CB-1-NN-60-S-3-S1-D-00-GBA-35-35-20	SERIES 90	S90-075PV
9521683	PUMP-VAR DISPL, CW	90-R-075-MA-1-CD-60-E-3-C6-E-01-FAC-29-35-28	SERIES 90	S90-075PV
9521684	PUMP-VAR DISPL, CW	90-R-075-MB-1-BC-60-E-3-S1-D-01-FAC-29-35-28	SERIES 90	S90-075PV
9521685	PUMP-VAR DISPL, CW	90-R-075-KA-1-BC-60-P-3-K2-D-00-GBA-17-17-24	SERIES 90	S90-075PV
9521686	PUMP-VAR DISPL, CW	90-R-075-MT-6-NN-80-S-3-S1-E-03-GBA-48-48-24	SERIES 90	S90-075PV

9521687	PUMP-VAR DISPL, CW	90-R-075-MT-6-NN-80-S-3-S1-E-02-GBA-48-48-24	SERIES 90	S90-075PV
9521688	PUMP-VAR DISPL, CW	90-R-075-MB-1-BB-60-L-3-S1-E-03-GBA-32-32-24	SERIES 90	S90-075PV
9521689	PUMP-VAR DISPL, CW	90-R-075-KA-1-NN-80-R-3-S1-D-00-GBA-35-35-24	SERIES 90	S90-075PV
9521690	PUMP-VAR DISPL, CW	90-R-075-MD-1-AB-60-S-3-S1-E-02-GBA-35-35-20	SERIES 90	S90-075PV
9521691	PUMP-VAR DISPL, CW	90-R-075-KA-1-CD-80-R-3-C7-D-00-GBA-42-42-24	SERIES 90	S90-075PV
9521692	PUMP-VAR DISPL, CW	90-R-075-KA-1-CD-80-R-3-S1-D-00-GBA-42-42-24	SERIES 90	S90-075PV
9521693	PUMP-VAR DISPL, CW	90-R-075-KP-1-AB-80-S-3-C6-E-03-GBA-42-42-24	SERIES 90	S90-075PV
9521694	PUMP-VAR DISPL, CW	90-R-075-MB-1-CD-60-R-4-C7-D-03-GBA-35-35-24-F022	SERIES 90	S90-075PV
9521695	PUMP-VAR DISPL, CW	90-R-075-MB-1-BC-60-R-4-S1-D-03-GBA-35-35-24-F022	SERIES 90	S90-075PV
9521696	PUMP-VAR DISPL, CW	90-R-075-KP-1-AB-80-L-3-S1-E-00-EBC-35-35-24	SERIES 90	S90-075PV
9521697	PUMP-VAR DISPL, CW	90-R-075-KP-6-CD-80-P-3-C6-D-02-GBA-45-45-28	SERIES 90	S90-075PV
9521698	PUMP-VAR DISPL, CW	90-R-075-KP-6-CD-80-P-3-S1-D-02-GBA-45-45-28	SERIES 90	S90-075PV
9521699	PUMP-VAR DISPL, CW	90-R-075-HF-1-NN-60-R-3-C7-D-03-GBA-35-35-18	SERIES 90	S90-075PV
9521700	PUMP-VAR DISPL, CW	90-R-075-KP-6-NN-80-S-3-S1-E-03-GBA-48-48-24	SERIES 90	S90-075PV
9521701	PUMP-VAR DISPL, CW	90-R-075-HF-1-NN-60-R-3-C6-D-03-GBA-35-35-18	SERIES 90	S90-075PV
9521702	PUMP-VAR DISPL, CW	90-R-075-MB-1-BC-60-L-3-S1-E-03-GBA-32-32-24	SERIES 90	S90-075PV
9521703	PUMP-VAR DISPL, CW	90-R-075-MB-1-CD-80-L-4-C7-D-03-GBA-38-38-24	SERIES 90	S90-075PV
9521704	PUMP-VAR DISPL, CW	90-R-075-MA-1-BC-80-L-4-S1-D-03-GBA-38-38-24	SERIES 90	S90-075PV
9521705	PUMP-VAR DISPL, CW	90-R-075-KP-1-BB-80-R-3-S1-D-03-GBA-23-23-24	SERIES 90	S90-075PV
9521706	PUMP-VAR DISPL, CW	90-R-075-KA-1-CD-60-S-3-T1-D-02-GBA-32-32-20	SERIES 90	S90-075PV
9521707	PUMP-VAR DISPL, CW	90-R-075-MB-1-AB-61-S-3-S1-E-03-GBA-35-35-20	SERIES 90	S90-075PV
9521714	PUMP-VAR DISPL, CW	90-R-075-KA-1-BC-60-S-3-C6-D-03-GBA-35-35-20	SERIES 90	S90-075PV
9521715	PUMP-VAR DISPL, CW	90-R-075-MA-6-NN-80-S-3-C7-D-03-GBA-45-45-24	SERIES 90	S90-075PV
9521716	PUMP-VAR DISPL, CW	90-R-075-MA-1-NN-80-S-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9521717	PUMP-VAR DISPL, CW	90-R-075-MA-1-CD-60-S-3-C6-D-03-GBA-35-35-20	SERIES 90	S90-075PV
9521718	PUMP-VAR DISPL, CW	90-R-075-MA-1-BC-60-S-3-S1-D-03-GBA-35-35-20	SERIES 90	S90-075PV
9521719	PUMP-VAR DISPL, CW	90-R-075-CB-1-BC-80-S-3-S1-D-00-GBA-35-35-24	SERIES 90	S90-075PV
9521720	PUMP-VAR DISPL, CW	90-R-075-KP-1-BC-80-R-3-S1-E-03-GBA-29-29-24	SERIES 90	S90-075PV
9521721	PUMP-VAR DISPL, CW	90-R-075-KP-1-NN-80-R-3-S1-E-03-GBA-29-29-24	SERIES 90	S90-075PV
9521722	PUMP-VAR DISPL, CW	90-R-075-KP-6-CD-80-S-3-S1-D-00-GBA-45-45-24	SERIES 90	S90-075PV
9521723	PUMP-VAR DISPL, CW	90-R-075-KP-6-NN-80-S-3-S1-D-00-GBA-45-45-24	SERIES 90	S90-075PV
9521724	PUMP-VAR DISPL, CW	90-R-075-KN-1-NN-60-S-4-K2-D-03-GBA-29-26-24	SERIES 90	S90-075PV
9521725	PUMP-VAR DISPL, CW	90-R-075-MB-1-CD-80-L-4-C7-D-03-GBA-38-38-24-F022	SERIES 90	S90-075PV
9521726	PUMP-VAR DISPL, CW	90-R-075-MA-1-BC-80-L-4-S1-D-03-GBA-38-38-24-F022	SERIES 90	S90-075PV
9521727	PUMP-VAR DISPL, CW	90-R-075-HF-1-BC-81-P-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-075PV
9521728	PUMP-VAR DISPL, CW	90-R-075-MA-1-NN-60-S-4-K2-D-03-GBA-35-35-20	SERIES 90	S90-075PV

9521729	PUMP-VAR DISPL, CW	90-R-075-MB-B-BB-80-S-4-S1-E-03-GBA-20-48-24	SERIES 90	S90-075PV
9521730	PUMP-VAR DISPL, CW	90-R-075-KP-1-NN-60-R-3-S1-D-03-GBA-29-29-24	SERIES 90	S90-075PV
9521731	PUMP-VAR DISPL, CW	90-R-075-MA-H-CD-60-E-3-C6-E-01-FAC-AB-35-28	SERIES 90	S90-075PV
9521732	PUMP-VAR DISPL, CW	90-R-075-MB-H-BC-60-E-3-S1-D-01-FAC-AB-35-28	SERIES 90	S90-075PV
9521733	PUMP-VAR DISPL, CW	90-R-075-KP-1-AB-80-L-3-S1-E-00-GBA-26-26-24	SERIES 90	S90-075PV
9521734	PUMP-VAR DISPL, CW	90-R-075-KP-1-BC-80-L-3-S1-E-00-GBA-26-26-24	SERIES 90	S90-075PV
9521735	PUMP-VAR DISPL, CW	90-R-075-KA-1-CD-80-R-3-S1-E-03-GBA-20-20-24	SERIES 90	S90-075PV
9521736	PUMP-VAR DISPL, CW	90-R-075-MV-1-AB-60-S-3-S1-E-03-GBA-29-29-24	SERIES 90	S90-075PV
9521737	PUMP-VAR DISPL, CW	90-R-075-KA-1-CD-80-P-3-C7-E-03-GBA-20-20-24	SERIES 90	S90-075PV
9521738	PUMP-VAR DISPL, CW	90-R-075-KA-1-NN-80-P-3-S1-E-03-GBA-20-20-24	SERIES 90	S90-075PV
9521739	PUMP-VAR DISPL, CW	90-R-075-KA-1-CD-60-P-3-S1-D-03-GBA-26-26-24	SERIES 90	S90-075PV
9521740	PUMP-VAR DISPL, CW	90-R-075-KP-1-NN-60-P-4-S1-D-03-GBA-32-32-24	SERIES 90	S90-075PV
9521741	PUMP-VAR DISPL, CW	90-R-075-MA-6-AB-80-S-3-C7-D-03-GBA-45-45-24	SERIES 90	S90-075PV
9521742	PUMP-VAR DISPL, CW	90-R-075-EA-1-CD-80-R-3-C7-D-00-GBA-42-42-24	SERIES 90	S90-075PV
9521743	PUMP-VAR DISPL, CW	90-R-075-EA-1-CD-80-R-3-S1-D-00-GBA-42-42-24	SERIES 90	S90-075PV
9521744	PUMP-VAR DISPL, CW	90-R-075-MA-1-BC-80-L-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-075PV
9521745	PUMP-VAR DISPL, CW	90-R-075-KP-1-NN-80-P-1-T2-D-03-GBA-23-23-24	SERIES 90	S90-075PV
9521746	PUMP-VAR DISPL, CW	90-R-075-HF-1-AB-80-P-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9521747	PUMP-VAR DISPL, CW	90-R-075-HF-1-BC-80-S-3-K2-E-03-GBA-17-17-28	SERIES 90	S90-075PV
9521748	PUMP-VAR DISPL, CW	90-R-075-MB-1-BC-60-P-3-S1-D-22-GBA-35-35-24	SERIES 90	S90-075PV
9521749	PUMP-VAR DISPL, CW	90-R-075-KA-1-AB-80-S-3-S1-D-22-GBA-38-38-24	SERIES 90	S90-075PV
9521750	PUMP-VAR DISPL, CW	90-R-075-KA-1-AB-60-S-3-S1-D-22-GBA-38-38-24	SERIES 90	S90-075PV
9521751	PUMP-VAR DISPL, CW	90-R-075-MA-1-AB-81-D-3-K2-L-00-GBA-23-23-24	SERIES 90	S90-075PV
9521752	PUMP-VAR DISPL, CW	90-R-075-KA-1-CD-60-P-3-C7-E-00-GBA-32-32-24	SERIES 90	S90-075PV
9521753	PUMP-VAR DISPL, CW	90-R-075-KA-1-BC-60-P-3-S1-E-00-GBA-32-37-24	SERIES 90	S90-075PV
9521760	PUMP-VAR DISPL, CW	90-R-075-M1-2-CD-60-X-3-C7-E-04-GBA-35-35-24	SERIES 90	S90-075PV
9521761	PUMP-VAR DISPL, CW	90-R-075-M1-2-NN-60-X-3-S1-E-04-GBA-35-35-24	SERIES 90	S90-075PV
9521762	PUMP-VAR DISPL, CW	90-R-075-M1-2-BC-60-X-3-S1-E-04-GBA-35-35-24	SERIES 90	S90-075PV
9521763	PUMP-VAR DISPL, CW	90-R-075-MD-2-BC-60-R-3-S1-D-02-GBA-38-38-24	SERIES 90	S90-075PV
9521764	PUMP-VAR DISPL, CW	90-R-075-KP-1-BC-80-P-3-S1-D-03-GBA-38-38-24	SERIES 90	S90-075PV
9521765	PUMP-VAR DISPL, CW	90-R-075-MA-1-CD-60-S-4-K2-D-03-GBA-20-20-24	SERIES 90	S90-075PV
9521766	PUMP-VAR DISPL, CW	90-R-075-KP-1-CD-80-R-3-S1-D-03-GBA-26-26-24	SERIES 90	S90-075PV
9521767	PUMP-VAR DISPL, CW	90-R-075-KA-1-NN-60-R-3-S1-D-03-GBA-29-29-24	SERIES 90	S90-075PV
9521768	PUMP-VAR DISPL, CW	90-R-075-CB-6-CD-80-P-3-S1-D-00-GBA-45-45-28	SERIES 90	S90-075PV
9521769	PUMP-VAR DISPL, CW	90-R-075-CB-6-CD-80-P-3-C6-D-00-GBA-45-45-28	SERIES 90	S90-075PV
9521770C	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-CD-80-P-3-S1-E-00-GBA-32-32-24	SERIES 90	S90-075PV

9521771	PUMP-VAR DISPL, CW	90-R-075-KA-1-NN-80-P-3-S1-E-00-GBA-32-37-24	SERIES 90	S90-075PV
9521771C	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-NN-80-P-3-S1-E-00-GBA-32-37-24	SERIES 90	S90-075PV
9521772	PUMP-VAR DISPL, CW	90-R-075-KA-1-NN-60-S-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9521773	PUMP-VAR DISPL, CW	90-R-075-LG-1-CD-60-R-3-S1-D-02-GBA-20-20-24	SERIES 90	S90-075PV
9521774	PUMP-VAR DISPL, CW	90-R-075-MA-2-NN-80-S-3-C6-E-03-GBA-42-42-24	SERIES 90	S90-075PV
9521774C	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-2-NN-80-S-3-C6-E-03-GBA-42-42-24	SERIES 90	S90-075PV
9521775	PUMP-VAR DISPL, CW	90-R-075-KA-2-NN-80-S-3-C6-E-03-GBA-42-42-24	SERIES 90	S90-075PV
9521775C	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-2-NN-80-S-3-C6-E-03-GBA-42-42-24	SERIES 90	S90-075PV
9521776	PUMP-VAR DISPL, CW	90-R-075-MT-2-NN-60-S-3-C6-E-02-GBA-38-38-24	SERIES 90	S90-075PV
9521776C	PUMP-VAR DISPL, CW 90PV075	90-R-075-MT-2-NN-60-S-3-C6-E-02-GBA-38-38-24	SERIES 90	S90-075PV
9521777	PUMP-VAR DISPL, CW	90-R-075-KP-1-BC-80-L-3-S1-E-00-EBC-35-35-24	SERIES 90	S90-075PV
9521778	PUMP-VAR DISPL, CW	90-R-075-KP-6-CD-80-R-3-S1-E-03-GBA-45-45-24	SERIES 90	S90-075PV
9521779	PUMP-VAR DISPL, CW	90-R-075-KP-6-CD-80-R-3-J1-E-03-GBA-45-45-24	SERIES 90	S90-075PV
9521780	PUMP-VAR DISPL, CW	90-R-075-MB-1-NN-80-R-3-S1-D-02-GBA-20-20-24	SERIES 90	S90-075PV
9521781	PUMP-VAR DISPL, CW	90-R-075-MT-2-NN-80-S-3-C6-E-02-GBA-38-38-24	SERIES 90	S90-075PV
9521781C	PUMP-VAR DISPL, CW 90PV075	90-R-075-MT-2-NN-80-S-3-C6-E-02-GBA-38-38-24	SERIES 90	S90-075PV
9521782	PUMP-VAR DISPL, CW	90-R-075-KP-1-CD-80-P-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9521782C	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-CD-80-P-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9521783	PUMP-VAR DISPL, CW	90-R-075-MV-B-BB-80-S-3-S1-D-03-GBA-32-42-24	SERIES 90	S90-075PV
9521784	PUMP-VAR DISPL, CW	90-R-075-MA-1-CD-80-S-3-C7-D-03-GBA-29-29-20	SERIES 90	S90-075PV
9521785	PUMP-VAR DISPL, CW	90-R-075-MA-1-BC-80-S-3-S1-D-03-GBA-29-29-20	SERIES 90	S90-075PV
9521786	PUMP-VAR DISPL, CW	90-R-075-MA-1-BB-80-S-3-S1-D-03-GBA-29-29-20	SERIES 90	S90-075PV
9521787	PUMP-VAR DISPL, CW	90-R-075-KA-1-NN-60-P-3-S1-D-03-GBA-35-35-20	SERIES 90	S90-075PV
9521788	PUMP-VAR DISPL, CW	90-R-075-KA-1-CD-60-P-3-S1-D-03-GBA-35-35-20	SERIES 90	S90-075PV
9521789	PUMP-VAR DISPL, CW	90-R-075-KP-1-CD-80-R-3-S1-E-03-EBC-42-42-24	SERIES 90	S90-075PV
9521790	PUMP-VAR DISPL, CW	90-R-075-KD-4-CZ-8R-R-3-J8-Y-33-EDF-44-44-JJ-N065	SERIES 90	S90-075PV
9521792	PUMP-VAR DISPL, CW	90-R-075-KA-1-NN-60-S-3-T2-E-03-GBA-26-26-24	SERIES 90	S90-075PV
9521793	PUMP-VAR DISPL, CW	90-R-075-EA-1-NN-81-S-3-T2-E-03-GBA-26-26-20	SERIES 90	S90-075PV
9521794	PUMP-VAR DISPL, CW	90-R-075-EA-1-AB-81-S-3-T2-E-03-GBA-26-26-20	SERIES 90	S90-075PV
9521795	PUMP-VAR DISPL, CW	90-R-075-KA-1-NN-60-L-4-S1-D-03-GBA-20-20-24	SERIES 90	S90-075PV
9521796	PUMP-VAR DISPL, CW	90-R-075-MB-1-BC-80-S-3-C6-D-02-FBA-43-43-20	SERIES 90	S90-075PV
9521797	PUMP-VAR DISPL, CW	90-R-075-MV-1-AB-60-S-3-S1-E-03-GBA-32-32-24	SERIES 90	S90-075PV
9521798	PUMP-VAR DISPL, CW	90-R-075-DC-1-NN-80-P-7-S1-E-GF-GBA-38-38-24	SERIES 90	S90-075PV
9521799	PUMP-VAR DISPL, CW	90-R-075-MA-1-NN-80-L-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-075PV
9521800	PUMP-VAR DISPL, CW	90-R-075-MA-7-AH-80-S-3-T2-F-03-GBA-45-45-24	SERIES 90	S90-075PV
9521801	PUMP-VAR DISPL, CW	90-R-075-KP-7-AH-80-S-3-T2-F-03-GBA-45-45-24	SERIES 90	S90-075PV

9521802	PUMP-VAR DISPL, CW	90-R-075-HF-1-BC-80-S-1-K2-E-03-GBA-17-17-28	SERIES 90	S90-075PV
9521803	PUMP-VAR DISPL, CW	90-R-075-MA-2-NN-80-S-3-C6-E-02-GBA-38-38-24	SERIES 90	S90-075PV
9521803C	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-2-NN-80-S-3-C6-E-02-GBA-38-38-24	SERIES 90	S90-075PV
9521804	PUMP-VAR DISPL, CW	90-R-075-MA-2-NN-60-S-3-C6-E-02-GBA-38-38-24	SERIES 90	S90-075PV
9521804C	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-2-NN-60-S-3-C6-E-02-GBA-38-38-24	SERIES 90	S90-075PV
9521806	PUMP-VAR DISPL, CW	90-R-075-MA-1-NN-60-S-3-K2-D-03-GBA-35-35-20	SERIES 90	S90-075PV
9521807	PUMP-VAR DISPL, CW	90-R-075-KP-6-CD-80-P-3-C6-D-03-GBA-45-45-28	SERIES 90	S90-075PV
9521808	PUMP-VAR DISPL, CW	90-R-075-KP-6-CD-80-P-3-S1-D-03-GBA-45-45-28	SERIES 90	S90-075PV
9521809	PUMP-VAR DISPL, CW	90-R-075-MD-1-BC-61-S-3-S1-E-02-FAD-35-35-20	SERIES 90	S90-075PV
9521810	PUMP-VAR DISPL, CW	90-R-075-MB-1-NN-80-R-4-S1-D-02-GBA-20-20-24	SERIES 90	S90-075PV
9521811	PUMP-VAR DISPL, CW	90-R-075-M1-1-CD-60-X-3-C7-D-04-GBA-42-42-24	SERIES 90	S90-075PV
9521812	PUMP-VAR DISPL, CW	90-R-075-M1-1-NN-60-X-3-S1-D-04-GBA-42-42-24	SERIES 90	S90-075PV
9521813	PUMP-VAR DISPL, CW	90-R-075-MA-1-NN-80-P-3-S1-E-03-GBA-32-32-24	SERIES 90	S90-075PV
9521814	PUMP-VAR DISPL, CW	90-R-075-KA-1-BC-80-P-3-S1-D-03-GBA-42-42-20	SERIES 90	S90-075PV
9521815	PUMP-VAR DISPL, CW	90-R-075-KP-1-CD-60-R-4-C7-D-03-GBA-38-38-24-F060	SERIES 90	S90-075PV
9521816	PUMP-VAR DISPL, CW	90-R-075-KP-1-BC-60-R-4-S1-D-03-GBA-38-38-24-F060	SERIES 90	S90-075PV
9521817	PUMP-VAR DISPL, CW	90-R-075-KA-1-NN-60-R-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9521818	PUMP-VAR DISPL, CW	90-R-075-MD-1-BC-60-S-3-S1-E-04-GBA-42-42-24	SERIES 90	S90-075PV
9521819	PUMP-VAR DISPL, CW	90-R-075-MA-1-CD-80-P-3-S1-D-04-GBA-32-32-20	SERIES 90	S90-075PV
9521820	PUMP-VAR DISPL, CW	90-R-075-MA-1-NN-80-P-3-S1-D-04-GBA-32-32-20	SERIES 90	S90-075PV
9521821	PUMP-VAR DISPL, CW	90-R-075-MB-1-AB-60-3-3-C7-D-03-GFK-42-42-20	SERIES 90	S90-075PV
9521822	PUMP-VAR DISPL, CW	90-R-075-KA-1-NN-60-R-3-S1-D-05-GBA-42-42-24	SERIES 90	S90-075PV
9521823	PUMP-VAR DISPL, CW	90-R-075-MB-1-NN-60-L-3-C7-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9521823C	PUMP-VAR DISPL, CW 90PV075	90-R-075-MB-1-NN-60-L-3-C7-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9521824	PUMP-VAR DISPL, CW	90-R-075-MB-1-NN-80-R-1-S1-D-02-GBA-20-20-24-F053	SERIES 90	S90-075PV
9521825	PUMP-VAR DISPL, CW	90-R-075-HS-1-BC-60-P-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9521826	PUMP-VAR DISPL, CW	90-R-075-MA-1-CD-80-S-3-S1-D-03-GBA-32-32-24	SERIES 90	S90-075PV
9521827	PUMP-VAR DISPL, CW	90-R-075-KP-1-CD-80-R-3-S1-D-03-GBA-38-38-24	SERIES 90	S90-075PV
9521828	PUMP-VAR DISPL, CW	90-R-075-MA-2-CD-80-S-3-S1-D-00-GBA-42-42-24	SERIES 90	S90-075PV
9521829	PUMP-VAR DISPL, CW	90-R-075-DC-1-BC-60-R-4-T1-D-GB-GBA-32-32-24	SERIES 90	S90-075PV
9521830	PUMP-VAR DISPL, CW	90-R-075-ME-1-BE-62-R-3-C7-D-03-GFK-40-40-24	SERIES 90	S90-075PV
9521831	PUMP-VAR DISPL, CW	90-R-075-KN-7-AH-60-S-3-T1-F-03-GBA-48-48-28	SERIES 90	S90-075PV
9521832	PUMP-VAR DISPL, CW	90-R-075-KN-1-AB-60-R-3-S1-D-03-GBA-29-29-24	SERIES 90	S90-075PV
9521833	PUMP-VAR DISPL, CW	90-R-075-KA-1-AB-60-R-3-S1-D-03-GBA-29-29-24	SERIES 90	S90-075PV
9521835	PUMP-VAR DISPL, CW	90-R-075-DC-1-CD-60-P-3-S1-D-GB-GBA-42-42-24	SERIES 90	S90-075PV
9521836	PUMP-VAR DISPL, CW	90-R-075-KP-7-AB-80-S-3-T2-D-03-GBA-45-45-24	SERIES 90	S90-075PV

9521837	PUMP-VAR DISPL, CW	90-R-075-KP-1-BC-80-S-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9521838	PUMP-VAR DISPL, CW	90-R-075-KA-1-AB-60-P-4-S1-E-03-GBA-26-26-24	SERIES 90	S90-075PV
9521839	PUMP-VAR DISPL, CW	90-R-075-RR-2-BC-60-R-3-S1-D-02-GBA-38-38-24	SERIES 90	S90-075PV
9521840	PUMP-VAR DISPL, CW	90-R-075-RR-1-AB-60-R-3-S1-E-02-GBA-32-32-24	SERIES 90	S90-075PV
9521841	PUMP-VAR DISPL, CW	90-R-075-KN-7-AH-60-S-3-T2-F-03-GBA-48-48-28	SERIES 90	S90-075PV
9521843	PUMP-VAR DISPL, CW	90-R-075-MA-1-CD-60-S-3-C6-D-06-GBA-42-42-20	SERIES 90	S90-075PV
9521844	PUMP-VAR DISPL, CW	90-R-075-KP-1-NN-60-R-4-S1-D-03-GBA-32-32-24	SERIES 90	S90-075PV
9521845	PUMP-VAR DISPL, CW	90-R-075-MA-1-BC-80-S-3-S1-E-03-GBA-32-32-24	SERIES 90	S90-075PV
9521846	PUMP-VAR DISPL, CW	90-R-075-MA-1-CD-80-S-3-S1-E-03-GBA-32-32-24	SERIES 90	S90-075PV
9521847	PUMP-VAR DISPL, CW	90-R-075-KP-1-BC-80-S-3-S1-D-03-GBA-32-32-24	SERIES 90	S90-075PV
9521848	PUMP-VAR DISPL, CW	90-R-075-MS-2-CD-80-6-1-S1-E-03-GBA-23-42-20-F063	SERIES 90	S90-075PV
9521849	PUMP-VAR DISPL, CW	90-R-075-MS-1-AB-80-R-4-S1-E-03-GBA-35-35-20	SERIES 90	S90-075PV
9521850	PUMP-VAR DISPL, CW	90-R-075-MA-1-AB-60-P-3-C7-D-03-GBA-23-23-24	SERIES 90	S90-075PV
9521851	PUMP-VAR DISPL, CW	90-R-075-KP-1-BB-80-R-3-S1-E-03-GBA-26-26-24	SERIES 90	S90-075PV
9521852	PUMP-VAR DISPL, CW	90-R-075-KA-2-CD-60-L-3-C6-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9521853	PUMP-VAR DISPL, CW	90-R-075-KA-2-NN-60-L-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9521854	PUMP-VAR DISPL, CW	90-R-075-KT-1-BC-60-R-4-S1-D-03-EBC-38-38-24	SERIES 90	S90-075PV
9521855	PUMP-VAR DISPL, CW	90-R-075-KP-1-BC-80-R-3-S1-E-03-GBA-26-26-24	SERIES 90	S90-075PV
9521856	PUMP-VAR DISPL, CW	90-R-075-KP-1-NN-60-S-3-S1-D-00-GBA-17-17-20	SERIES 90	S90-075PV
9521857	PUMP-VAR DISPL, CW	90-R-075-KP-1-CD-80-P-4-S1-E-03-GBA-29-35-24	SERIES 90	S90-075PV
9521859	PUMP-VAR DISPL, CW	90-R-075-HF-1-CD-60-R-3-D9-D-03-GBA-35-35-18	SERIES 90	S90-075PV
9521860	PUMP-VAR DISPL, CW	90-R-075-HF-1-BC-80-S-3-S1-D-03-GBA-32-32-24	SERIES 90	S90-075PV
9521861	PUMP-VAR DISPL, CW	90-R-075-KP-1-CD-80-S-3-S1-D-03-GBA-26-26-24	SERIES 90	S90-075PV
9521862	PUMP-VAR DISPL, CW	90-R-075-MA-1-CD-80-S-3-S1-D-03-GBA-26-26-24	SERIES 90	S90-075PV
9521863	PUMP-VAR DISPL, CW	90-R-075-KP-1-NN-60-S-3-C6-D-03-GBA-35-35-20	SERIES 90	S90-075PV
9521863C	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-NN-60-S-3-C6-D-03-GBA-35-35-20	SERIES 90	S90-075PV
9521864	PUMP-VAR DISPL, CW	90-R-075-KN-1-BC-80-D-4-S1-L-03-GBA-29-29-24	SERIES 90	S90-075PV
9521865	PUMP-VAR DISPL, CW	90-R-075-MA-1-NN-60-S-4-S1-D-03-GBA-29-29-24	SERIES 90	S90-075PV
9521866	PUMP-VAR DISPL, CW	90-R-075-KP-G-CD-80-P-4-S1-E-03-GBA-29-35-24	SERIES 90	S90-075PV
9521868	PUMP-VAR DISPL, CW	90-R-075-HM-1-NN-60-S-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9521869	PUMP-VAR DISPL, CW	90-R-075-DC-1-CD-60-S-3-S1-D-GB-GBA-42-42-24	SERIES 90	S90-075PV
9521872	PUMP-VAR DISPL, CW	90-R-075-KP-1-NN-60-S-3-C6-D-02-GBA-26-26-20	SERIES 90	S90-075PV
9521873	PUMP-VAR DISPL, CW	90-R-075-HF-1-NN-81-L-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9521874	PUMP-VAR DISPL, CW	90-R-075-MA-1-NN-80-S-4-C6-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9521875	PUMP-VAR DISPL, CW	90-R-075-KA-1-CD-80-S-3-C7-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9521876	PUMP-VAR DISPL, CW	90-R-075-KA-1-AB-80-S-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV

9521877	PUMP-VAR DISPL, CW	90-R-075-HX-1-BC-80-S-3-S1-D-H1-GBA-32-32-24	SERIES 90	S90-075PV
9521879	PUMP-VAR DISPL, CW	90-R-075-KA-1-NN-60-S-3-C7-D-03-GBA-17-17-24	SERIES 90	S90-075PV
9521880	PUMP-VAR DISPL, CW	90-R-075-MD-2-AB-80-6-3-S1-E-02-GBA-37-37-20	SERIES 90	S90-075PV
9521881	PUMP-VAR DISPL, CW	90-R-075-HF-1-CD-60-P-3-C6-D-03-GBA-35-35-18	SERIES 90	S90-075PV
9521882	PUMP-VAR DISPL, CW	90-R-075-MV-6-BB-80-S-3-S1-D-03-GBA-45-17-24	SERIES 90	S90-075PV
9521883	PUMP-VAR DISPL, CW	90-R-075-KP-1-NN-80-S-3-C7-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9521884	PUMP-VAR DISPL, CW	90-R-075-KA-1-BC-80-P-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-075PV
9521885	PUMP-VAR DISPL, CW	90-R-075-KP-1-CD-80-P-3-S1-D-04-GBA-32-32-20	SERIES 90	S90-075PV
9521887	PUMP-VAR DISPL, CW	90-R-075-CA-1-NN-80-P-4-S1-C-00-GBA-35-14-24	SERIES 90	S90-075PV
9521888	PUMP-VAR DISPL, CW	90-R-075-KP-1-NN-60-S-3-S1-D-02-EBC-26-26-20	SERIES 90	S90-075PV
9521889	PUMP-VAR DISPL, CW	90-R-075-ME-1-BE-62-R-3-C7-D-02-GBA-42-42-24	SERIES 90	S90-075PV
9521890	PUMP-VAR DISPL, CW	90-R-075-HK-1-CD-60-S-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9521891	PUMP-VAR-DISPL CW 90PV075	90R075-MA-1-NN-60-S-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9521892	PUMP-VAR DISPL, CW	90-R-075-MA-1-BB-60-D-3-T1-L-26-FAC-42-42-24	SERIES 90	S90-075PV
9521893	PUMP-VAR DISPL, CW	90-R-075-EP-1-AB-60-S-4-S1-E-03-GBA-29-29-24	SERIES 90	S90-075PV
9521894	PUMP-VAR DISPL, CW	90-R-075-MA-1-AB-81-S-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9521895	PUMP-VAR DISPL, CW	90-R-075-HF-1-BC-60-L-3-S1-E-03-GBA-32-32-24	SERIES 90	S90-075PV
9521896	PUMP-VAR DISPL, CW	90-R-075-MA-1-NN-60-S-3-C6-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9521897	PUMP-VAR DISPL, CW	90-R-075-KP-1-NN-80-S-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9521898	PUMP-VAR DISPL, CW	90-R-075-KA-1-NN-60-R-3-S1-E-03-GBA-38-38-20	SERIES 90	S90-075PV
9521899	PUMP-VAR DISPL, CW	90-R-075-MA-1-BC-80-S-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9521985C	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-CD-80-P-3-C7-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9521986C	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-CD-80-P-3-C7-D-03-GBA-40-40-24	SERIES 90	S90-075PV
9522000	PUMP-VAR DISPL, CCW	90-L-075-KP-1-NN-80-S-3-S1-D-02-GBA-42-42-24	SERIES 90	S90-075PV
9522001	PUMP-VAR DISPL, CCW	90-L-075-MB-1-AB-60-L-3-K2-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9522002	PUMP-VAR DISPL, CCW	90-L-075-MC-1-BC-81-S-3-S1-D-02-GBA-35-35-24	SERIES 90	S90-075PV
9522003	PUMP-VAR DISPL, CCW	90-L-075-EP-1-NN-60-S-4-S1-D-03-EBC-42-42-24	SERIES 90	S90-075PV
9522004	PUMP-VAR DISPL, CCW	90-L-075-M1-6-NN-60-S-4-S1-C-03-FAC-45-45-28-F053	SERIES 90	S90-075PV
9522005	PUMP-VAR DISPL, CCW	90-L-075-KP-6-AB-60-S-3-T1-E-03-EBC-48-48-24	SERIES 90	S90-075PV
9522006	PUMP-VAR DISPL, CCW	90-L-075-KA-1-CD-80-R-4-C6-E-02-FAB-29-29-24	SERIES 90	S90-075PV
9522007	PUMP-VAR DISPL, CCW	90-L-075-KP-1-BC-60-S-4-S1-E-04-FAD-42-42-24	SERIES 90	S90-075PV
9522008	PUMP-VAR DISPL, CCW	90-L-075-KA-1-BC-60-S-3-S1-E-00-GBA-32-32-20	SERIES 90	S90-075PV
9522009	PUMP-VAR DISPL, CCW	90-L-075-KA-1-NN-80-D-3-S1-L-03-FAB-42-42-28	SERIES 90	S90-075PV
9522010	PUMP-VAR DISPL, CCW	90-L-075-KP-1-AB-60-R-3-S1-D-03-GBA-29-29-24	SERIES 90	S90-075PV
9522011	PUMP-VAR DISPL, CCW	90-L-075-MV-1-BC-80-S-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9522012	PUMP-VAR DISPL, CCW	90-L-075-KP-7-AH-80-S-3-T2-F-03-GBA-48-48-28	SERIES 90	S90-075PV

9522013	PUMP-VAR DISPL, CCW	90-L-075-EA-1-BB-60-S-3-C6-C-03-GBA-13-13-24	SERIES 90	S90-075PV
9522014	PUMP-VAR DISPL, CCW	90-L-075-EA-1-NN-81-S-3-T2-E-03-GBA-26-26-20	SERIES 90	S90-075PV
9522015	PUMP-VAR DISPL, CCW	90-L-075-EA-1-AB-81-S-3-T2-E-03-GBA-26-26-20	SERIES 90	S90-075PV
9522016	PUMP-VAR DISPL, CCW	90-L-075-KA-1-NN-60-P-3-S1-E-03-GBA-42-14-24	SERIES 90	S90-075PV
9522017	PUMP-VAR DISPL, CCW	90-L-075-KP-1-NN-81-P-3-S1-D-03-GBA-35-35-20	SERIES 90	S90-075PV
9522018	PUMP-VAR DISPL, CCW	90-L-075-HF-1-AB-60-R-3-S1-D-04-GBA-38-38-24	SERIES 90	S90-075PV
9522019	PUMP-VAR DISPL, CCW	90-L-075-EG-1-BB-60-S-3-S4-E-05-GBA-38-38-24	SERIES 90	S90-075PV
9522020	PUMP-VAR DISPL, CCW	90-L-075-KP-1-BC-80-P-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9522021	PUMP-VAR DISPL, CCW	90-L-075-KP-2-BB-80-P-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-075PV
9522022	PUMP-VAR DISPL, CCW	90-L-075-KP-1-NN-60-S-3-S1-D-03-GBA-29-29-24	SERIES 90	S90-075PV
9522023	PUMP-VAR DISPL, CCW	90-L-075-KP-7-AB-80-S-3-T2-D-03-GBA-48-48-24	SERIES 90	S90-075PV
9522024	PUMP-VAR DISPL, CCW	90-L-075-KP-7-AB-80-S-3-T2-D-03-GBA-48-48-28	SERIES 90	S90-075PV
9522025	PUMP-VAR DISPL, CCW	90-L-075-MV-1-BB-80-S-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9522026	PUMP-VAR DISPL, CCW	90-L-075-EP-1-NN-60-S-3-S1-E-03-GBA-14-38-20	SERIES 90	S90-075PV
9522027	PUMP-VAR DISPL, CCW	90-L-075-MB-1-NN-80-R-3-S1-D-03-GBA-42-42-20	SERIES 90	S90-075PV
9522028	PUMP-VAR DISPL, CCW	90-L-075-KP-7-AH-80-S-3-T2-F-03-GBA-45-45-24	SERIES 90	S90-075PV
9522029	PUMP-VAR DISPL, CCW	90-L-075-MA-7-AH-80-S-3-T2-F-03-GBA-45-45-24	SERIES 90	S90-075PV
9522030	PUMP-VAR DISPL, CCW	90-L-075-MB-1-BB-60-S-3-C6-C-03-GFK-35-35-24	SERIES 90	S90-075PV
9522031	PUMP-VAR DISPL, CCW	90-L-075-KP-1-CD-80-S-3-S1-D-03-GBA-23-23-24	SERIES 90	S90-075PV
9522032	PUMP-VAR DISPL, CCW	90-L-075-KP-1-CD-80-S-3-T2-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9522033	PUMP-VAR DISPL, CCW	90-L-075-EA-1-AB-61-S-3-S1-E-03-GBA-20-20-24	SERIES 90	S90-075PV
9522034	PUMP-VAR DISPL, CCW	90-L-075-KT-1-NN-60-S-3-S1-D-03-EBC-38-38-24	SERIES 90	S90-075PV
9522035	PUMP-VAR DISPL, CCW	90-L-075-DC-1-CD-80-S-3-S1-D-G8-GBA-35-35-24	SERIES 90	S90-075PV
9522036	PUMP-VAR DISPL, CCW	90-L-075-DC-1-CD-80-S-4-S1-D-G8-GBA-35-35-24	SERIES 90	S90-075PV
9522037	PUMP-VAR DISPL, CCW	90-L-075-KP-1-BC-80-R-3-S1-D-03-GBA-32-32-20	SERIES 90	S90-075PV
9522038	PUMP-VAR DISPL, CCW	90-L-075-EA-1-BB-60-R-3-T2-C-03-GBA-38-38-24	SERIES 90	S90-075PV
9522039	PUMP-VAR DISPL, CCW	90-L-075-KP-1-CD-80-S-4-S1-D-02-GBA-35-35-24	SERIES 90	S90-075PV
9522040	PUMP-VAR DISPL, CCW	90-L-075-KP-1-CD-80-L-3-S1-D-03-GBA-38-38-24	SERIES 90	S90-075PV
9522041	PUMP-VAR DISPL, CCW	90-L-075-KP-1-NN-80-L-3-S1-D-03-GBA-38-38-24	SERIES 90	S90-075PV
9522042	PUMP-VAR DISPL, CCW	90-L-075-MA-1-NN-80-S-3-T2-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9522043	PUMP-VAR DISPL, CCW	90-L-075-KA-6-BC-80-S-4-K2-E-22-GBA-45-45-24	SERIES 90	S90-075PV
9522045	PUMP-VAR DISPL, CCW	90-L-075-KN-1-NN-60-R-3-S1-D-03-GBA-29-29-24	SERIES 90	S90-075PV
9522046	PUMP-VAR DISPL, CCW	90-L-075-KA-1-NN-60-R-3-S1-D-03-GBA-29-29-24	SERIES 90	S90-075PV
9522048	PUMP-VAR DISPL, CCW	90-L-075-KP-1-CD-80-P-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9522049	PUMP-VAR DISPL, CCW	90-L-075-EA-1-BC-60-P-3-S1-D-03-GBA-38-38-24	SERIES 90	S90-075PV
9522050	PUMP-VAR DISPL, CCW	90-L-075-HF-1-CD-80-S-4-S1-E-28-GBA-32-32-24	SERIES 90	S90-075PV

9522051	PUMP-VAR DISPL, CCW	90-L-075-HS-1-AB-80-R-3-K2-D-02-GBA-35-35-20	SERIES 90	S90-075PV
9522052	PUMP-VAR DISPL, CCW	90-L-075-KP-1-AB-60-R-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-075PV
9522053	PUMP-VAR DISPL, CCW	90-L-075-KP-1-AB-61-P-3-T2-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9522054	PUMP-VAR DISPL, CCW	90-L-075-KA-1-CD-80-P-3-C7-E-00-EEB-42-42-24	SERIES 90	S90-075PV
9522055	PUMP-VAR DISPL, CCW	90-L-075-KA-1-NN-80-P-3-S1-E-00-GBA-42-42-24	SERIES 90	S90-075PV
9522056	PUMP-VAR DISPL, CCW	90-L-075-KP-1-NN-80-P-3-S1-D-03-GBA-26-26-24	SERIES 90	S90-075PV
9522057	PUMP-VAR DISPL, CCW	90-L-075-HF-1-AB-80-R-3-K2-D-02-FAD-35-35-24	SERIES 90	S90-075PV
9522058	PUMP-VAR DISPL, CCW	90-L-075-KT-1-BC-80-L-3-C7-E-00-GLA-38-38-28	SERIES 90	S90-075PV
9522059	PUMP-VAR DISPL, CCW	90-L-075-KT-1-BB-80-L-3-C7-E-00-GLA-38-38-28	SERIES 90	S90-075PV
9522060	PUMP-VAR DISPL, CCW	90-L-075-M1-6-NN-60-S-4-S1-C-03-FAC-45-45-28	SERIES 90	S90-075PV
9522061	PUMP-VAR-DISPL CCW 90PV075	90L075-KP-1-BB-80-P-3-S1-D-03-GBA-35-35-20	SERIES 90	S90-075PV
9522062	PUMP-VAR-DISPL CCW 90PV075	90-L-075-KP-1-CD-81-P-3-S1-D-03-GBA-35-35-20	SERIES 90	S90-075PV
9522064	PUMP-VAR DISPL, CCW	90-L-075-KT-1-NN-60-R-4-S1-D-03-EBC-38-38-24	SERIES 90	S90-075PV
9522065	PUMP-VAR DISPL, CCW	90-L-075-HF-1-NN-80-R-3-S1-D-00-GBA-42-42-24	SERIES 90	S90-075PV
9522066	PUMP-VAR DISPL, CCW	90-L-075-KA-2-CD-80-S-3-S1-D-33-GBA-42-14-24	SERIES 90	S90-075PV
9522068	PUMP-VAR DISPL, CCW	90-L-075-KP-1-AB-61-P-3-T1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9522069	PUMP-VAR DISPL, CCW	90-L-075-KP-1-AC-60-X-3-S1-D-00-GBA-42-42-24	SERIES 90	S90-075PV
9522070	PUMP-VAR DISPL, CCW	90-L-075-KH-6-BE-82-U-3-S1-E-64-FAC-45-45-24-N057	SERIES 90	S90-075PV
9522071	PUMP-VAR DISPL, CCW	90-L-075-MA-1-NN-80-P-4-S1-E-03-GBA-23-23-24	SERIES 90	S90-075PV
9522072	PUMP-VAR DISPL, CCW	90-L-075-HF-1-CD-80-P-4-S1-D-03-GBA-32-32-24	SERIES 90	S90-075PV
9522074	PUMP-VAR DISPL, CCW	90-L-075-HM-1-NN-80-P-3-S1-D-03-GBA-29-29-24	SERIES 90	S90-075PV
9522075	PUMP-VAR DISPL, CCW	90-L-075-HM-1-BC-80-P-3-S1-D-03-GBA-29-29-24	SERIES 90	S90-075PV
9522076	PUMP-VAR DISPL, CCW	90-L-075-EA-1-NN-60-P-3-S1-E-03-EBC-45-14-24	SERIES 90	S90-075PV
9522077	PUMP-VAR DISPL, CCW	90-L-075-DC-1-BC-80-S-4-S1-D-GB-GBA-35-35-24	SERIES 90	S90-075PV
9522078	PUMP-VAR DISPL, CCW	90-L-075-KP-1-NN-60-S-3-S1-C-03-GBA-35-35-24	SERIES 90	S90-075PV
9522079	PUMP-VAR DISPL, CCW	90-L-075-KP-2-CD-60-L-3-S1-D-03-FBC-42-42-28	SERIES 90	S90-075PV
9522080	PUMP-VAR DISPL, CCW	90-L-075-KP-2-NN-60-L-3-S1-D-03-FAD-42-42-28	SERIES 90	S90-075PV
9522081	PUMP-VAR DISPL, CCW	90-L-075-KP-1-NN-60-S-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9522082	PUMP-VAR DISPL, CCW	90-L-075-KP-1-CD-60-S-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9522083	PUMP-VAR DISPL, CCW	90-L-075-KA-1-NN-60-S-3-C6-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9522084	PUMP-VAR DISPL, CCW	90-L-075-KP-6-AB-80-S-3-S1-D-02-GBA-45-45-28	SERIES 90	S90-075PV
9522085	PUMP-VAR DISPL, CCW	90-L-075-KP-1-AB-80-S-4-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9522085C	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-AB-80-S-4-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9522086	PUMP-VAR DISPL, CCW	90-L-075-HF-1-BC-60-R-3-S1-E-04-GBA-38-38-24	SERIES 90	S90-075PV
9522087	PUMP-VAR DISPL, CCW	90-L-075-HF-1-BC-60-R-3-S1-E-04-GBA-35-35-24	SERIES 90	S90-075PV
9522088	PUMP-VAR DISPL, CCW	90-L-075-KP-1-AB-80-L-4-S1-D-03-GBA-29-29-24	SERIES 90	S90-075PV

9522089	PUMP-VAR DISPL, CCW	90-L-075-MC-1-CD-80-R-3-S1-D-02-GBA-32-17-24	SERIES 90	S90-075PV
9522090	PUMP-VAR DISPL, CCW	90-L-075-HF-1-AC-60-R-3-S1-E-04-GBA-35-35-24	SERIES 90	S90-075PV
9522091	PUMP-VAR DISPL, CCW	90-L-075-HF-1-AC-60-R-3-S1-E-04-GBA-38-38-24	SERIES 90	S90-075PV
9522093	PUMP-VAR DISPL, CCW	90-L-075-KA-1-CD-80-R-4-C6-E-02-FAD-42-42-24	SERIES 90	S90-075PV
9522094	PUMP-VAR DISPL, CCW	90-L-075-HK-1-NN-80-R-4-S1-E-03-GBA-29-29-24	SERIES 90	S90-075PV
9522095	PUMP-VAR DISPL, CCW	90-L-075-HF-1-BC-60-D-3-S1-L-04-GBA-38-38-24	SERIES 90	S90-075PV
9522096	PUMP-VAR DISPL, CCW	90-L-075-HF-1-BC-60-D-3-S1-L-04-GBA-35-35-24	SERIES 90	S90-075PV
9522098	PUMP-VAR DISPL, CCW	90-L-075-HF-1-AC-60-D-3-S1-L-04-GBA-35-35-24	SERIES 90	S90-075PV
9522099	PUMP-VAR DISPL, CCW	90-L-075-HF-1-AC-60-D-3-S1-L-04-GBA-38-38-24	SERIES 90	S90-075PV
9522100	PUMP-VAR DISPL, CCW	90-L-075-KP-1-NN-60-L-4-S1-D-03-GBA-35-35-20	SERIES 90	S90-075PV
9522101	PUMP-VAR DISPL, CCW	90-L-075-MA-1-NN-60-S-3-C6-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9522102	PUMP-VAR DISPL, CCW	90-L-075-KA-1-CD-80-R-4-C6-E-02-FAD-29-29-24	SERIES 90	S90-075PV
9522103	PUMP-VAR DISPL, CCW	90-L-075-MA-1-NN-80-S-3-C6-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9522104	PUMP-VAR DISPL, CCW	90-L-075-HK-1-CD-80-S-3-S1-D-03-GBA-38-38-24	SERIES 90	S90-075PV
9522105	PUMP-VAR DISPL, CCW	90-L-075-KN-1-NN-80-R-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9522106	PUMP-VAR DISPL, CCW	90-L-075-KP-1-AB-60-R-3-S1-D-03-GBA-14-29-24	SERIES 90	S90-075PV
9522107	PUMP-VAR DISPL, CCW	90-L-075-KP-1-AB-60-R-1-S1-E-28-GBA-32-14-24	SERIES 90	S90-075PV
9522108	PUMP-VAR DISPL, CCW	90-L-075-KP-1-BB-81-P-3-S1-D-03-GBA-35-35-20	SERIES 90	S90-075PV
9522109	PUMP-VAR DISPL, CCW	90-L-075-KP-1-BC-80-S-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9522110	PUMP-VAR DISPL, CCW	90-L-075-KP-1-BC-61-L-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-075PV
9522111	PUMP-VAR DISPL, CCW	90-L-075-KP-1-NN-60-R-3-T1-D-03-GBA-29-29-20	SERIES 90	S90-075PV
9522112	PUMP-VAR DISPL, CCW	90-L-075-HS-5-NN-60-R-3-S1-E-05-GBA-38-38-30	SERIES 90	S90-075PV
9522113	PUMP-VAR DISPL, CCW	90-L-075-KA-1-NN-80-R-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-075PV
9522114	PUMP-VAR DISPL, CCW	90-L-075-EA-1-BB-60-R-3-T2-C-03-GBA-42-38-24	SERIES 90	S90-075PV
9522115	PUMP-VAR DISPL, CCW	90-L-075-HF-1-BC-80-P-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9522116	PUMP-VAR DISPL, CCW	90-L-075-KN-1-NN-60-L-4-S1-D-03-GBA-35-35-20	SERIES 90	S90-075PV
9522117	PUMP-VAR DISPL, CCW	90-L-075-KP-1-BC-80-L-3-S1-D-03-EEB-26-26-24	SERIES 90	S90-075PV
9522118	PUMP-VAR DISPL, CCW	90-L-075-KP-1-NN-80-L-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9522119	PUMP-VAR DISPL, CCW	90-L-075-HF-1-BC-80-S-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9522120	PUMP-VAR DISPL, CCW	90-L-075-MA-1-AB-61-P-3-T1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9522121	PUMP-VAR DISPL, CCW	90-L-075-KP-1-AB-60-R-1-S1-E-28-GBA-26-14-24	SERIES 90	S90-075PV
9522122	PUMP-VAR DISPL, CCW	90-L-075-KP-6-NN-60-P-3-S1-D-03-GBA-48-48-24	SERIES 90	S90-075PV
9522123	PUMP-VAR DISPL, CCW	90-L-075-KP-1-CD-80-R-3-S1-E-03-EBC-42-42-24	SERIES 90	S90-075PV
9522125	PUMP-VAR DISPL, CCW	90-L-075-MA-5-CD-80-L-3-T2-E-03-GBA-17-17-24	SERIES 90	S90-075PV
9522126	PUMP-VAR DISPL, CCW	90-L-075-MA-5-CD-80-L-3-S1-E-03-GBA-17-17-24	SERIES 90	S90-075PV
9522127	PUMP-VAR DISPL, CCW	90-L-075-MB-5-BC-60-R-3-S1-E-02-GBA-35-35-24	SERIES 90	S90-075PV

9522128	PUMP-VAR DISPL, CCW	90-L-075-MA-1-CD-80-L-3-T2-E-03-GBA-17-17-24	SERIES 90	S90-075PV
9522129	PUMP-VAR DISPL, CCW	90-L-075-MA-1-CD-80-L-3-S1-E-03-GBA-17-17-24	SERIES 90	S90-075PV
9522130	PUMP-VAR DISPL, CCW	90-L-075-KP-1-BC-80-L-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-075PV
9522131	PUMP-VAR DISPL, CCW	90-L-075-HF-1-AC-60-R-3-S1-E-06-GBA-35-35-24	SERIES 90	S90-075PV
9522132	PUMP-VAR DISPL, CCW	90-L-075-KP-1-NN-80-S-3-S1-D-03-GBA-26-26-24	SERIES 90	S90-075PV
9522133	PUMP-VAR DISPL, CCW	90-L-075-KP-1-BC-60-P-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-075PV
9522134	PUMP-VAR DISPL, CCW	90-L-075-KP-1-NN-80-L-4-S1-E-02-GBA-29-29-24	SERIES 90	S90-075PV
9522137	PUMP-VAR DISPL, CCW	90-L-075-MT-1-AB-60-S-3-S1-D-02-GBA-42-42-24	SERIES 90	S90-075PV
9522139	PUMP-VAR DISPL, CCW	90-L-075-MA-5-BC-80-R-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9522140	PUMP-VAR DISPL, CCW	90-L-075-MA-5-CD-80-R-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9522141	PUMP-VAR DISPL, CCW	90-L-075-KP-2-NN-80-S-3-S1-D-33-GBA-42-14-24	SERIES 90	S90-075PV
9522142	PUMP-VAR DISPL, CCW	90-L-075-KA-1-BB-60-S-3-C6-C-03-GBA-13-13-24	SERIES 90	S90-075PV
9522143	PUMP-VAR DISPL, CCW	90-L-075-KA-1-BB-60-S-3-C6-C-03-GBA-35-35-24	SERIES 90	S90-075PV
9522146	PUMP-VAR DISPL, CCW	90-L-075-KP-5-BB-80-R-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9522147	PUMP-VAR DISPL, CCW	90-L-075-KP-5-CD-80-L-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9522148	PUMP-VAR DISPL, CCW	90-L-075-CA-1-NN-80-S-3-S1-D-00-GBA-14-14-24	SERIES 90	S90-075PV
9522149	PUMP-VAR DISPL, CCW	90-L-075-KP-1-CD-60-S-4-T2-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9522150	PUMP-VAR DISPL, CCW	90-L-075-KP-1-NN-60-S-4-S1-D-03-EBC-42-42-24	SERIES 90	S90-075PV
9522151	PUMP-VAR DISPL, CCW	90-L-075-DC-5-CD-80-S-3-C6-E-G8-GBA-38-38-24	SERIES 90	S90-075PV
9522152	PUMP-VAR DISPL, CCW	90-L-075-KA-1-CD-80-L-4-S1-D-00-GBA-14-14-24	SERIES 90	S90-075PV
9522153	PUMP-VAR DISPL, CCW	90-L-075-KA-1-NN-80-D-4-S1-L-00-GBA-20-20-24	SERIES 90	S90-075PV
9522154	PUMP-VAR DISPL, CCW	90-L-075-KP-G-BB-80-R-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-075PV
9522155	PUMP-VAR DISPL, CCW	90-L-075-MA-1-NN-60-S-3-C7-D-03-GBA-35-35-20	SERIES 90	S90-075PV
9522156	PUMP-VAR DISPL, CCW	90-L-075-DC-5-BC-80-S-3-S1-E-G8-GBA-38-38-24	SERIES 90	S90-075PV
9522157	PUMP-VAR DISPL, CCW	90-L-075-MA-1-CD-80-R-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9522158	PUMP-VAR DISPL, CCW	90-L-075-MA-1-BC-80-R-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9522159	PUMP-VAR DISPL, CCW	90-L-075-KP-7-AH-60-S-4-T1-F-03-GBA-48-48-24	SERIES 90	S90-075PV
9522161	PUMP-VAR DISPL, CCW	90-L-075-KP-1-NN-80-S-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9522162	PUMP-VAR DISPL, CCW	90-L-075-KA-5-NN-60-P-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9522163	PUMP-VAR DISPL, CCW	90-L-075-KA-5-AB-60-L-3-T1-D-00-GBA-29-29-24	SERIES 90	S90-075PV
9522164	PUMP-VAR DISPL, CCW	90-L-075-KP-5-NN-80-R-3-S1-D-00-GBA-35-35-20	SERIES 90	S90-075PV
9522165	PUMP-VAR DISPL, CCW	90-L-075-KP-1-AB-80-S-3-T1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9522166	PUMP-VAR DISPL, CCW	90-L-075-DC-5-CD-80-R-3-C6-E-G8-GBA-38-38-24	SERIES 90	S90-075PV
9522167	PUMP-VAR DISPL, CCW	90-L-075-DC-5-BC-80-R-3-S1-E-G8-GBA-38-38-24	SERIES 90	S90-075PV
9522168	PUMP-VAR DISPL, CCW	90-L-075-KP-1-AB-81-S-3-S1-E-03-GBA-32-32-24	SERIES 90	S90-075PV
9522169	PUMP-VAR DISPL, CCW	90-L-075-MT-1-BC-81-S-4-S1-D-02-GBA-35-35-24	SERIES 90	S90-075PV

9522170	PUMP-VAR DISPL, CCW	90-L-075-KP-5-NN-80-P-4-S1-E-03-GBA-23-23-24	SERIES 90	S90-075PV
9522171	PUMP-VAR DISPL, CCW	90-L-075-KP-7-AB-80-S-3-T1-E-03-GBA-48-48-24	SERIES 90	S90-075PV
9522172	PUMP-VAR DISPL, CCW	90-L-075-MC-1-CD-80-S-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9522173	PUMP-VAR DISPL, CCW	90-L-075-MC-1-NN-80-S-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9522174	PUMP-VAR DISPL, CCW	90-L-075-KP-7-AH-80-S-3-T1-F-03-GBA-48-48-24	SERIES 90	S90-075PV
9522175	PUMP-VAR DISPL, CCW	90-L-075-KA-1-AC-80-S-3-S1-E-00-GBA-42-42-24	SERIES 90	S90-075PV
9522176	PUMP-VAR DISPL, CCW	90-L-075-KP-G-NN-80-R-3-S1-E-03-GBA-29-29-24	SERIES 90	S90-075PV
9522177	PUMP-VAR DISPL, CCW - DIST BASE MODEL	90-L-075-CB-1-NN-60-S-4-S1-D-00-GBA-35-35-24-P000	SERIES 90	S90-075PV
9522178	PUMP-VAR DISPL, CCW - DIST BASE MODEL	90-L-075-CB-1-NN-60-S-4-C6-D-00-GBA-35-35-24-P000	SERIES 90	S90-075PV
9522179	PUMP-VAR DISPL, CCW - DIST BASE MODEL	90-L-075-CB-1-NN-80-S-4-S1-D-00-GBA-35-35-24-P000	SERIES 90	S90-075PV
9522180	PUMP-VAR DISPL, CCW - DIST BASE MODEL	90-L-075-CB-1-NN-80-S-4-C6-D-00-GBA-35-35-24-P000	SERIES 90	S90-075PV
9522181	PUMP-VAR DISPL, CCW	90-L-075-KA-1-AC-80-L-4-S1-D-00-GBA-35-35-24	SERIES 90	S90-075PV
9522182	PUMP-VAR DISPL, CCW	90-L-075-KP-5-NN-80-R-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-075PV
9522183	PUMP-VAR DISPL, CCW	90-L-075-MV-5-AB-80-S-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9522184	PUMP-VAR DISPL, CCW	90-L-075-KP-5-NN-80-R-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9522186	PUMP-VAR DISPL, CCW	90-L-075-KP-1-NN-80-R-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-075PV
9522187	PUMP-VAR DISPL, CCW	90-L-075-MA-1-NN-80-P-4-S1-E-03-GBA-35-35-20	SERIES 90	S90-075PV
9522188	PUMP-VAR DISPL, CCW	90-L-075-KA-1-BC-80-R-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9522189	PUMP-VAR DISPL, CCW	90-L-075-KY-1-BC-80-R-3-S1-D-01-GBA-42-42-24	SERIES 90	S90-075PV
9522192	PUMP-VAR DISPL, CCW	90-L-075-KA-1-AB-80-L-3-C6-D-03-GBA-32-32-24	SERIES 90	S90-075PV
9522193	PUMP-VAR DISPL, CCW	90-L-075-HF-1-BC-80-S-4-S1-D-03-GBA-20-20-20	SERIES 90	S90-075PV
9522194	PUMP-VAR DISPL, CCW	90-L-075-MA-1-AB-60-S-3-C6-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9522195	PUMP-VAR DISPL, CCW	90-L-075-MA-1-AC-80-S-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9522197	PUMP-VAR DISPL, CCW	90-L-075-KP-1-CD-80-R-3-C6-E-29-GBA-38-38-34	SERIES 90	S90-075PV
9522198	PUMP-VAR DISPL, CCW	90-L-075-HK-1-BC-80-S-3-S1-E-03-GBA-32-32-24	SERIES 90	S90-075PV
9522199	PUMP-VAR DISPL, CCW	90-L-075-LB-7-NN-60-R-3-S1-E-04-FAC-43-43-24-L001	SERIES 90	S90-075PV
9522200	PUMP-VAR DISPL, CCW	90-L-075-KA-1-BC-80-R-4-S1-D-00-GBA-35-35-24	SERIES 90	S90-075PV
9522201	PUMP-VAR DISPL, CCW	90-L-075-KP-1-NN-80-P-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9522201C	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-NN-80-P-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9522202	PUMP-VAR DISPL, CCW	90-L-075-KA-1-AB-60-L-3-T1-D-00-GBA-29-29-24	SERIES 90	S90-075PV
9522203	PUMP-VAR DISPL, CCW	90-L-075-HK-1-BC-60-R-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9522204	PUMP-VAR DISPL, CCW	90-L-075-MB-1-NN-60-S-3-S1-D-03-GBA-32-32-24	SERIES 90	S90-075PV
9522207	PUMP-VAR DISPL, CCW	90-L-075-LL-1-NN-80-S-4-S1-D-71-GBA-38-38-24-F052	SERIES 90	S90-075PV
9522208	PUMP-VAR DISPL, CCW	90-L-075-KP-1-BC-60-R-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9522209	PUMP-VAR DISPL, CCW	90-L-075-DC-1-AB-80-R-4-S1-E-GB-GBA-42-42-24	SERIES 90	S90-075PV
9522210	PUMP-VAR DISPL, CCW	90-L-075-KP-1-NN-60-R-1-T1-D-00-GBA-29-07-24-F024	SERIES 90	S90-075PV

9522211	PUMP-VAR DISPL, CCW	90-L-075-KP-1-NN-60-R-1-T1-D-00-GBA-29-29-24-F024	SERIES 90	S90-075PV
9522212	PUMP-VAR DISPL, CCW	90-L-075-KA-1-NN-80-S-3-S1-C-00-GBA-32-32-24	SERIES 90	S90-075PV
9522213	PUMP-VAR DISPL, CCW	90-L-075-KA-1-NN-80-S-3-S1-C-00-GBA-20-20-24	SERIES 90	S90-075PV
9522214	PUMP-VAR DISPL, CCW	90-L-075-MA-1-NN-80-P-4-S1-E-03-GBA-42-42-24	SERIES 90	S90-075PV
9522215	PUMP-VAR DISPL, CCW	90-L-075-KP-1-BC-80-P-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9522215C	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-BC-80-P-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9522216	PUMP-VAR DISPL, CCW	90-L-075-KN-1-NN-80-R-4-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9522217	PUMP-VAR DISPL, CCW	90-L-075-KN-1-CD-80-R-4-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9522218	PUMP-VAR DISPL, CCW	90-L-075-KP-1-NN-80-L-1-T1-D-00-GBA-29-29-24-F024	SERIES 90	S90-075PV
9522219	PUMP-VAR DISPL, CCW	90-L-075-DC-1-BC-60-P-4-C6-D-GB-GBA-35-35-24	SERIES 90	S90-075PV
9522220	PUMP-VAR DISPL, CCW	90-L-075-KP-1-AB-60-P-3-S1-D-03-GBA-29-29-24	SERIES 90	S90-075PV
9522221	PUMP-VAR DISPL, CCW	90-L-075-KP-2-NN-80-R-3-S1-D-29-GBA-42-42-24	SERIES 90	S90-075PV
9522222	PUMP-VAR DISPL, CCW	90-L-075-KP-2-NN-80-R-3-S1-D-29-EHA-42-42-24	SERIES 90	S90-075PV
9522223	PUMP-VAR DISPL, CCW	90-L-075-KP-1-BC-80-S-4-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9522224	PUMP-VAR DISPL, CCW	90-L-075-DC-1-BC-60-P-4-S1-D-GB-GBA-35-35-24	SERIES 90	S90-075PV
9522225	PUMP-VAR DISPL, CCW	90-L-075-MA-1-NN-80-S-4-S1-C-00-GBA-42-42-24	SERIES 90	S90-075PV
9522226	PUMP-VAR DISPL, CCW	90-L-075-KP-5-NN-80-S-4-S1-E-03-GBA-23-23-24	SERIES 90	S90-075PV
9522227	PUMP-VAR DISPL, CCW	90-L-075-MB-1-BC-80-S-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9522228	PUMP-VAR DISPL, CCW	90-L-075-KP-1-CD-80-S-3-S1-D-03-GBA-42-42-26	SERIES 90	S90-075PV
9522229	PUMP-VAR DISPL, CCW	90-L-075-KP-1-AB-80-S-3-S1-D-03-GBA-42-42-26	SERIES 90	S90-075PV
9522230	PUMP-VAR DISPL, CCW	90-L-075-KP-1-BC-60-S-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9522231	PUMP-VAR DISPL, CCW	90-L-075-KP-5-BC-80-S-3-S1-D-03-GBA-38-38-26	SERIES 90	S90-075PV
9522232	PUMP-VAR DISPL, CCW	90-L-075-KP-1-BC-60-P-3-S1-D-03-GBA-23-23-24	SERIES 90	S90-075PV
9522233	PUMP-VAR DISPL, CCW	90-L-075-MA-1-CD-60-S-3-C6-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9522234	PUMP-VAR DISPL, CCW	90-L-075-KP-1-CD-60-R-3-T2-C-03-GBA-42-38-24	SERIES 90	S90-075PV
9522235	PUMP-VAR DISPL, CCW	90-L-075-HK-1-AB-80-S-3-S1-D-03-GBA-38-38-24	SERIES 90	S90-075PV
9522236	PUMP-VAR DISPL, CCW	90-L-075-KP-1-BC-80-P-3-S1-D-00-GBA-35-35-24	SERIES 90	S90-075PV
9522237	PUMP-VAR DISPL, CCW	90-L-075-KA-1-NN-81-S-3-T2-E-00-GBA-35-35-20	SERIES 90	S90-075PV
9522238	PUMP-VAR DISPL, CCW	90-L-075-KA-1-AB-81-S-3-T2-E-00-GBA-35-35-20	SERIES 90	S90-075PV
9522239	PUMP-VAR DISPL, CCW	90-L-075-MB-1-AB-60-S-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-075PV
9522240	PUMP-VAR DISPL, CCW	90-L-075-MB-1-NN-60-S-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-075PV
9522241	PUMP-VAR DISPL, CCW	90-L-075-KP-1-CD-80-S-3-K2-D-03-GBA-26-26-24	SERIES 90	S90-075PV
9522242	PUMP-VAR DISPL, CCW	90-L-075-HF-1-CD-80-S-4-S1-D-03-GBA-35-35-20	SERIES 90	S90-075PV
9522243	PUMP-VAR DISPL, CCW	90-L-075-HM-6-NN-60-S-3-S1-C-02-GBA-48-48-24	SERIES 90	S90-075PV
9522244	PUMP-VAR DISPL, CCW	90-L-075-HF-5-AB-80-S-3-S1-D-03-GBA-20-20-24	SERIES 90	S90-075PV
9522245	PUMP-VAR DISPL, CCW	90-L-075-LB-7-NN-60-R-3-S1-E-04-FAC-45-45-24-L001	SERIES 90	S90-075PV

9522246	PUMP-VAR DISPL, CCW	90-L-075-CB-1-CD-60-R-7-S1-D-00-GBA-42-42-24	SERIES 90	S90-075PV
9522247	PUMP-VAR DISPL, CCW	90-L-075-CB-1-AB-60-R-7-S1-D-00-GBA-42-42-24	SERIES 90	S90-075PV
9522248	PUMP-VAR DISPL, CCW	90-L-075-KP-1-BC-60-S-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-075PV
9522249	PUMP-VAR DISPL, CCW	90-L-075-KA-5-NN-80-P-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9522250	PUMP-VAR DISPL, CCW	90-L-075-HF-1-NN-80-S-4-S1-D-00-GBA-38-38-24	SERIES 90	S90-075PV
9522251	PUMP-VAR DISPL, CCW	90-L-075-HK-1-NN-80-R-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-075PV
9522252	PUMP-VAR DISPL, CCW	90-L-075-MB-1-BC-80-P-3-C7-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9522252C	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MB-1-BC-80-P-3-C7-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9522253	PUMP-VAR DISPL, CCW	90-L-075-KP-5-BC-80-S-4-S1-D-03-GBA-29-29-24	SERIES 90	S90-075PV
9522254	PUMP-VAR DISPL, CCW	90-L-075-DD-1-NN-80-L-3-S1-E-G8-GBA-42-42-24	SERIES 90	S90-075PV
9522255	PUMP-VAR DISPL, CCW	90-L-075-MA-1-AB-80-R-3-C7-D-03-GBA-29-29-24	SERIES 90	S90-075PV
9522255C	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-1-AB-80-R-3-C7-D-03-GBA-29-29-24	SERIES 90	S90-075PV
9522256	PUMP-VAR DISPL, CCW	90-L-075-HS-1-NN-60-P-3-S1-D-03-GBA-32-14-24	SERIES 90	S90-075PV
9522257	PUMP-VAR DISPL, CCW	90-L-075-CB-1-CD-60-R-7-C7-D-00-GBA-42-42-24	SERIES 90	S90-075PV
9522258	PUMP-VAR DISPL, CCW	90-L-075-M8-1-NN-80-P-3-C6-D-03-GBA-26-26-24	SERIES 90	S90-075PV
9522258C	PUMP-VAR DISPL, CCW 90PV075	90-L-075-M8-1-NN-80-P-3-C6-D-03-GBA-26-26-24	SERIES 90	S90-075PV
9522259	PUMP-VAR DISPL, CCW	90-L-075-HS-1-BC-60-S-3-S1-E-00-GBA-23-23-24	SERIES 90	S90-075PV
9522260	PUMP-VAR DISPL, CCW	90-L-075-KP-1-CD-80-S-3-S1-C-03-GBA-42-42-24	SERIES 90	S90-075PV
9522261	PUMP-VAR DISPL, CCW	90-L-075-KA-5-CD-80-P-3-S1-E-03-EEB-42-42-24	SERIES 90	S90-075PV
9522262	PUMP-VAR DISPL, CCW	90-L-075-KP-1-NN-80-P-4-C6-D-03-GBA-23-23-24	SERIES 90	S90-075PV
9522263	PUMP-VAR DISPL, CCW	90-L-075-KP-1-NN-80-P-4-C6-D-03-GBA-23-23-28	SERIES 90	S90-075PV
9522263C	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-NN-80-P-4-C6-D-03-GBA-23-23-28	SERIES 90	S90-075PV
9522264	PUMP-VAR DISPL, CCW	90-L-075-KP-1-NN-60-P-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9522264C	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-NN-60-P-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9522265	PUMP-VAR DISPL, CCW	90-L-075-DD-1-BC-80-R-3-C7-D-GB-GBA-35-35-24	SERIES 90	S90-075PV
9522265C	PUMP-VAR DISPL, CCW 90PV075	90-L-075-DD-1-BC-80-R-3-C7-D-GB-GBA-35-35-24	SERIES 90	S90-075PV
9522266	PUMP-VAR DISPL, CCW	90-L-075-KA-1-NN-80-P-3-S1-D-03-EBC-35-14-24	SERIES 90	S90-075PV
9522267	PUMP-VAR DISPL, CCW	90-L-075-MB-1-NN-80-R-3-S1-D-03-GBA-38-38-24	SERIES 90	S90-075PV
9522268	PUMP-VAR DISPL, CCW	90-L-075-KP-1-BC-80-R-3-C7-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9522268C	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-BC-80-R-3-C7-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9522269	PUMP-VAR DISPL, CCW	90-L-075-DD-1-NN-80-L-4-S1-E-G8-GBA-42-42-24	SERIES 90	S90-075PV
9522270	PUMP-VAR DISPL, CCW	90-L-075-KA-1-CD-60-R-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-075PV
9522271	PUMP-VAR DISPL, CCW	90-L-075-CB-1-CD-60-R-7-S1-D-00-GBA-32-32-24	SERIES 90	S90-075PV
9522272	PUMP-VAR DISPL, CCW	90-L-075-CB-1-CD-60-R-7-C7-D-00-GBA-32-32-24	SERIES 90	S90-075PV
9522273	PUMP-VAR DISPL, CCW	90-L-075-KP-1-BC-80-R-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-075PV
9522274	PUMP-VAR DISPL, CCW	90-L-075-KP-1-NN-80-P-3-C6-D-03-GBA-38-38-30	SERIES 90	S90-075PV

9522274C	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-NN-80-P-3-C6-D-03-GBA-38-38-30	SERIES 90	S90-075PV
9522276	PUMP-VAR DISPL, CCW	90-L-075-KP-5-CD-80-R-3-S1-D-04-GBA-26-26-20	SERIES 90	S90-075PV
9522277	PUMP-VAR DISPL, CCW	90-L-075-KP-5-NN-80-R-3-S1-D-04-GBA-26-26-20	SERIES 90	S90-075PV
9522278	PUMP-VAR DISPL, CCW	90-L-075-KT-7-NN-60-R-3-S1-E-00-FAC-45-45-24	SERIES 90	S90-075PV
9522279	PUMP-VAR DISPL, CCW	90-L-075-MA-6-CD-60-L-3-T2-E-05-GBA-48-48-24	SERIES 90	S90-075PV
9522280	PUMP-VAR DISPL, CCW	90-L-075-MA-6-AB-60-L-3-S1-E-05-GBA-48-48-24	SERIES 90	S90-075PV
9522281	PUMP-VAR DISPL, CCW	90-L-075-LL-1-BB-60-S-3-C6-C-71-GBA-35-35-24	SERIES 90	S90-075PV
9522282	PUMP-VAR DISPL, CCW	90-L-075-MB-1-NN-60-S-3-S1-E-03-GBA-38-38-28	SERIES 90	S90-075PV
9522283	PUMP-VAR DISPL, CCW	90-L-075-KA-1-BC-80-S-3-C7-E-02-GBA-35-35-24	SERIES 90	S90-075PV
9522283C	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-1-BC-80-S-3-C7-E-02-GBA-35-35-24	SERIES 90	S90-075PV
9522284	PUMP-VAR DISPL, CCW	90-L-075-KP-1-AB-81-S-3-T2-E-00-EBC-35-35-20	SERIES 90	S90-075PV
9522285	PUMP-VAR DISPL, CCW	90-L-075-HS-1-BC-60-P-3-S1-C-03-GBA-17-17-24	SERIES 90	S90-075PV
9522286	PUMP-VAR DISPL, CCW	90-L-075-KA-1-BC-60-P-4-S1-E-03-GBA-26-26-24	SERIES 90	S90-075PV
9522286C	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KA-1-BC-60-P-4-S1-E-03-GBA-26-26-24	SERIES 90	S90-075PV
9522287	PUMP-VAR DISPL, CCW	90-L-075-KA-1-BC-60-S-3-S1-E-00-GBA-23-23-24	SERIES 90	S90-075PV
9522288	PUMP-VAR DISPL, CCW	90-L-075-HF-1-NN-80-R-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-075PV
9522289	PUMP-VAR DISPL, CCW	90-L-075-KP-1-BC-80-P-3-S1-D-00-GBA-38-38-24	SERIES 90	S90-075PV
9522290	PUMP-VAR DISPL, CCW	90-L-075-KP-1-NN-80-P-3-S1-D-03-GBA-29-29-24	SERIES 90	S90-075PV
9522290C	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-NN-80-P-3-S1-D-03-GBA-29-29-24	SERIES 90	S90-075PV
9522291	PUMP-VAR DISPL, CCW	90-L-075-KP-5-NN-80-R-4-S1-E-03-GBA-23-23-24	SERIES 90	S90-075PV
9522292	PUMP-VAR DISPL, CCW	90-L-075-KA-1-AB-60-P-3-T2-D-03-GBA-38-14-24	SERIES 90	S90-075PV
9522293	PUMP-VAR DISPL, CCW	90-L-075-KP-1-NN-80-S-3-S1-D-03-GBA-23-23-24	SERIES 90	S90-075PV
9522293C	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-NN-80-S-3-S1-D-03-GBA-23-23-24	SERIES 90	S90-075PV
9522294	PUMP-VAR DISPL, CCW	90-L-075-MA-5-NN-80-P-4-S1-E-03-GBA-35-35-20	SERIES 90	S90-075PV
9522295	PUMP-VAR DISPL, CCW	90-L-075-M8-1-NN-80-S-3-C6-D-03-GBA-40-40-24	SERIES 90	S90-075PV
9522295C	PUMP-VAR DISPL, CCW 90PV075	90-L-075-M8-1-NN-80-S-3-C6-D-03-GBA-40-40-24	SERIES 90	S90-075PV
9522296	PUMP-VAR DISPL, CCW	90-L-075-HF-1-AB-60-R-3-S1-E-04-GBA-35-35-24	SERIES 90	S90-075PV
9522297	PUMP-VAR DISPL, CCW	90-L-075-MA-1-NN-60-S-3-C7-D-03-GBA-26-26-24	SERIES 90	S90-075PV
9522297C	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-1-NN-60-S-3-C7-D-03-GBA-26-26-24	SERIES 90	S90-075PV
9522298	PUMP-VAR DISPL, CCW	90-L-075-HF-1-NN-80-P-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-075PV
9522299	PUMP-VAR DISPL, CCW	90-L-075-MA-5-NN-80-R-3-S1-D-C5-GBA-32-32-24	SERIES 90	S90-075PV
9522300	PUMP-VAR DISPL, CCW	90-L-075-CA-2-NN-80-R-7-S1-D-00-GBA-35-35-24	SERIES 90	S90-075PV
9522301	PUMP-VAR DISPL, CCW	90-L-075-CA-2-NN-80-R-7-S1-D-00-GCA-35-35-24	SERIES 90	S90-075PV
9522302	PUMP-VAR DISPL, CCW	90-L-075-HF-1-NN-80-P-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9522302C	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HF-1-NN-80-P-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9522303	PUMP-VAR DISPL, CCW	90-L-075-MA-1-NN-80-S-3-C7-D-03-GBA-35-35-24	SERIES 90	S90-075PV

9522303C	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MA-1-NN-80-S-3-C7-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9522304	PUMP-VAR DISPL, CCW	90-L-075-HS-1-CD-80-P-4-S1-D-04-GBA-42-42-24	SERIES 90	S90-075PV
9522305	PUMP-VAR DISPL, CCW	90-L-075-HS-1-NN-80-P-4-S1-D-04-GBA-42-42-24	SERIES 90	S90-075PV
9522306	PUMP-VAR DISPL, CCW	90-L-075-HF-1-NN-80-P-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-075PV
9522307	PUMP-VAR DISPL, CCW	90-L-075-KN-1-NN-80-R-3-S1-E-03-GBA-29-29-24	SERIES 90	S90-075PV
9522308	PUMP-VAR DISPL, CCW	90-L-075-HS-1-NN-80-R-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-075PV
9522309	PUMP-VAR DISPL, CCW	90-L-075-HS-5-NN-80-S-3-S1-D-03-GBA-29-29-24	SERIES 90	S90-075PV
9522309C	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HS-5-NN-80-S-3-S1-D-03-GBA-29-29-24	SERIES 90	S90-075PV
9522310	PUMP-VAR DISPL, CCW	90-L-075-DD-1-NN-60-P-3-S1-D-GB-GBA-42-42-24	SERIES 90	S90-075PV
9522310C	PUMP-VAR DISPL, CCW 90PV075	90-L-075-DD-1-NN-60-P-3-S1-D-GB-GBA-42-42-24	SERIES 90	S90-075PV
9522311	PUMP-VAR DISPL, CCW	90-L-075-MA-1-NN-80-S-4-S1-D-03-GBA-26-26-24	SERIES 90	S90-075PV
9522313	PUMP-VAR DISPL, CCW	90-L-075-KP-1-CD-80-P-3-C7-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9522313C	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-CD-80-P-3-C7-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9522314	PUMP-VAR DISPL, CCW	90-L-075-KA-1-BB-60-S-4-S1-E-03-GBA-20-20-24	SERIES 90	S90-075PV
9522315	PUMP-VAR DISPL, CCW	90-L-075-MA-5-BC-80-P-3-S1-D-03-GBA-32-32-24	SERIES 90	S90-075PV
9522316	PUMP-VAR DISPL, CCW	90-L-075-EA-2-CD-60-S-4-S1-E-33-GBA-42-42-24	SERIES 90	S90-075PV
9522317	PUMP-VAR DISPL, CCW	90-L-075-MA-5-CD-80-P-3-S1-D-29-GBA-35-35-24	SERIES 90	S90-075PV
9522318	PUMP-VAR DISPL, CCW	90-L-075-MB-1-NN-60-P-3-C7-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9522318C	PUMP-VAR DISPL, CCW 90PV075	90-L-075-MB-1-NN-60-P-3-C7-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9522323	PUMP-VAR DISPL, CCW	90-L-075-CA-1-NN-80-S-4-S1-D-00-GBA-14-14-24	SERIES 90	S90-075PV
9522324	PUMP-VAR DISPL, CCW	90-L-075-LB-7-NN-60-R-3-S1-E-04-FAC-43-43-24-L001	SERIES 90	S90-075PV
9522325	PUMP-VAR DISPL, CCW	90-L-075-LL-1-BB-60-S-4-C6-C-71-GBA-35-35-24	SERIES 90	S90-075PV
9522326	PUMP-VAR DISPL, CCW	90-L-075-MA-1-CD-60-L-3-S1-E-00-GBA-17-17-24	SERIES 90	S90-075PV
9522327	PUMP-VAR DISPL, CCW	90-L-075-KP-1-BC-80-L-3-S1-E-03-EBC-23-23-24	SERIES 90	S90-075PV
9522328	PUMP-VAR DISPL, CCW	90-L-075-HS-1-AB-60-R-3-S1-D-03-GBA-38-38-24	SERIES 90	S90-075PV
9522329	PUMP-VAR DISPL, CCW	90-L-075-HS-5-NN-80-S-4-S1-D-03-GBA-29-29-24	SERIES 90	S90-075PV
9522329C	PUMP-VAR DISPL, CCW 90PV075	90-L-075-HS-5-NN-80-S-4-S1-D-03-GBA-29-29-24	SERIES 90	S90-075PV
9522331	PUMP-VAR DISPL, CCW	90-L-075-MB-1-AB-80-S-3-C6-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9522332	PUMP-VAR DISPL, CCW	90-L-075-KA-1-CD-80-L-4-S1-D-00-GBA-35-35-24	SERIES 90	S90-075PV
9522334	PUMP-VAR DISPL, CCW	90-L-075-MA-1-AB-80-S-3-S1-D-00-GBA-29-29-24	SERIES 90	S90-075PV
9522335	PUMP-VAR DISPL, CCW	90-L-075-KK-6-BE-82-U-3-S1-E-64-FAC-45-45-24-N057	SERIES 90	S90-075PV
9522336	PUMP-VAR DISPL, CCW	90-L-075-KA-1-NN-80-R-3-S1-C-03-GBA-14-14-18	SERIES 90	S90-075PV
9522337	PUMP-VAR DISPL, CCW	90-L-075-KA-2-NN-60-R-3-S1-E-03-GBA-29-29-20	SERIES 90	S90-075PV
9522338	PUMP-VAR DISPL, CCW	90-L-075-MB-1-AB-80-S-4-S1-E-03-GBA-42-42-24	SERIES 90	S90-075PV
9522339	PUMP-VAR DISPL, CCW	90-L-075-MB-1-NN-80-S-4-S1-E-03-GBA-42-42-24	SERIES 90	S90-075PV
9522340	PUMP-VAR DISPL, CCW	90-L-075-KP-1-CD-80-R-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV

9522341	PUMP-VAR DISPL, CCW	90-L-075-KP-1-BC-60-P-3-S1-E-03-GBA-37-37-24	SERIES 90	S90-075PV
9522342	PUMP-VAR DISPL, CCW	90-L-075-KP-1-CD-80-R-3-S1-D-03-GBA-35-35-20	SERIES 90	S90-075PV
9522343	PUMP-VAR DISPL, CCW	90-L-075-MB-1-NN-80-P-3-S1-D-03-GBA-45-45-24	SERIES 90	S90-075PV
9522344	PUMP-VAR DISPL, CCW	90-L-075-KA-1-NN-60-R-4-S1-C-03-GBA-29-29-24	SERIES 90	S90-075PV
9522345	PUMP-VAR DISPL, CCW	90-L-075-EA-2-NN-60-R-3-S1-E-03-GBA-29-29-24	SERIES 90	S90-075PV
9522346	PUMP-VAR DISPL, CCW	90-L-075-KP-1-NN-60-P-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-075PV
9522347	PUMP-VAR DISPL, CCW	90-L-075-MB-1-CD-80-P-3-S1-D-03-GBA-45-45-24	SERIES 90	S90-075PV
9522348	PUMP-VAR DISPL, CCW	90-L-075-KP-1-CT-80-R-3-C7-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9522349	PUMP-VAR DISPL, CCW	90-L-075-HS-1-CD-80-P-4-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9522350	PUMP-VAR DISPL, CCW	90-L-075-HS-1-NN-80-P-4-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9522351	PUMP-VAR DISPL, CCW	90-L-075-KP-1-BC-80-P-3-C7-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9522351C	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-BC-80-P-3-C7-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9522352	PUMP-VAR DISPL, CCW	90-L-075-KP-1-NN-80-S-4-S1-E-03-GBA-42-42-24	SERIES 90	S90-075PV
9522353	PUMP-VAR DISPL, CCW	90-L-075-KP-1-AB-80-S-4-S1-E-03-GBA-42-42-24	SERIES 90	S90-075PV
9522354	PUMP-VAR DISPL, CCW	90-L-075-KP-2-CD-60-L-3-C6-D-03-FAD-42-42-28	SERIES 90	S90-075PV
9522355	PUMP-VAR DISPL, CCW	90-L-075-KP-1-CD-80-P-3-C7-D-03-GBA-38-38-24	SERIES 90	S90-075PV
9522355C	PUMP-VAR DISPL, CCW 90PV075	90-L-075-KP-1-CD-80-P-3-C7-D-03-GBA-38-38-24	SERIES 90	S90-075PV
9522356	PUMP-VAR DISPL, CCW	90-L-075-MB-1-NN-80-S-4-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9522357	PUMP-VAR DISPL, CCW	90-L-075-HF-1-NN-80-S-3-S1-D-03-GBA-42-42-20	SERIES 90	S90-075PV
9522359	PUMP-VAR DISPL, CCW	90-L-075-KP-1-BC-80-P-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9522366	PUMP-VAR DISPL, CCW	90-L-075-EA-1-BB-60-S-3-C6-C-03-GFK-13-13-24	SERIES 90	S90-075PV
9522367	PUMP-VAR DISPL, CCW	90-L-075-KP-2-NN-60-L-3-S1-D-03-FBC-42-42-28	SERIES 90	S90-075PV
9522368	PUMP-VAR DISPL, CCW	90-L-075-MD-1-AB-60-R-3-S1-D-02-GFK-42-42-20	SERIES 90	S90-075PV
9522370	PUMP-VAR DISPL, CCW	90-L-075-MA-5-NN-80-R-4-S1-E-C5-GBA-23-23-24	SERIES 90	S90-075PV
9522371	PUMP-VAR DISPL, CCW	90-L-075-CB-1-NN-80-P-4-S1-E-00-GBA-35-35-24	SERIES 90	S90-075PV
9522372	PUMP-VAR DISPL, CCW	90-L-075-KA-5-NN-60-R-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-075PV
9522373	PUMP-VAR DISPL, CCW	90-L-075-HF-1-NN-80-P-3-S1-E-03-GBA-42-42-32	SERIES 90	S90-075PV
9522374	PUMP-VAR DISPL, CCW	90-L-075-HK-1-CD-80-S-3-S1-E-03-GBA-40-40-24	SERIES 90	S90-075PV
9522375	PUMP-VAR DISPL, CCW	90-L-075-KT-5-AC-60-X-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9522376	PUMP-VAR DISPL, CCW	90-L-075-KT-5-BC-60-X-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9522377	PUMP-VAR DISPL, CCW	90-L-075-HK-1-NN-80-S-3-S1-E-03-GBA-40-40-24	SERIES 90	S90-075PV
9522379	PUMP-VAR DISPL, CCW	90-L-075-KD-1-NN-80-S-3-S1-D-03-GBA-13-29-24	SERIES 90	S90-075PV
9522380	PUMP-VAR DISPL, CCW	90-L-075-HF-5-AB-80-S-3-S1-D-03-GBA-20-20-24	SERIES 90	S90-075PV
9522381	PUMP-VAR DISPL, CCW	90-L-075-KA-1-NN-60-R-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9522382	PUMP-VAR DISPL, CCW	90-L-075-KN-1-BC-80-R-3-S1-E-03-GBA-29-29-24	SERIES 90	S90-075PV
9522502	PUMP-VAR DISPL, CW	90-R-075-MA-1-AB-80-R-4-S1-E-02-GBA-23-23-24	SERIES 90	S90-075PV

9522503	PUMP-VAR DISPL, CW	90-R-075-HF-1-NN-60-R-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9522504	PUMP-VAR DISPL, CW	90-R-075-HF-1-AB-60-R-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9522505	PUMP-VAR DISPL, CW	90-R-075-HS-1-BC-61-S-3-S1-E-03-GBA-32-32-24	SERIES 90	S90-075PV
9522506	PUMP-VAR DISPL, CW	90-R-075-KP-1-NN-80-L-4-S1-E-02-GBA-26-26-24	SERIES 90	S90-075PV
9522507	PUMP-VAR DISPL, CW	90-R-075-MA-1-AB-80-R-4-S1-E-02-GBA-26-26-24	SERIES 90	S90-075PV
9522508	PUMP-VAR DISPL, CW	90-R-075-KP-1-NN-80-L-4-S1-E-02-GBA-29-29-24	SERIES 90	S90-075PV
9522510	PUMP-VAR DISPL, CW	90-R-075-KP-5-BC-80-R-4-S1-E-06-GBA-26-26-24	SERIES 90	S90-075PV
9522512	PUMP-VAR DISPL, CW	90-R-075-HS-5-BC-80-S-3-S1-D-03-GBA-32-32-24	SERIES 90	S90-075PV
9522513	PUMP-VAR DISPL, CW	90-R-075-MA-1-AB-61-S-3-S1-E-00-GBA-29-29-24	SERIES 90	S90-075PV
9522514	PUMP-VAR DISPL, CW	90-R-075-KA-1-NN-60-S-3-T2-D-03-GBA-20-20-24	SERIES 90	S90-075PV
9522515	PUMP-VAR DISPL, CW	90-R-075-KT-1-CD-80-P-3-S1-E-03-EKA-45-45-24	SERIES 90	S90-075PV
9522516	PUMP-VAR DISPL, CW	90-R-075-KP-1-NN-80-P-3-S1-E-03-GBA-38-38-24	SERIES 90	S90-075PV
9522517	PUMP-VAR DISPL, CW	90-R-075-KP-1-BB-80-R-4-S1-E-03-GBA-42-42-24	SERIES 90	S90-075PV
9522518	PUMP-VAR DISPL, CW	90-R-075-KN-5-AB-80-L-4-S1-E-03-GBA-32-32-24	SERIES 90	S90-075PV
9522519	PUMP-VAR DISPL, CW	90-R-075-HS-1-BC-80-S-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-075PV
9522520	PUMP-VAR DISPL, CW	90-R-075-LE-6-BB-80-S-3-S1-D-03-GBA-45-17-24	SERIES 90	S90-075PV
9522521	PUMP-VAR DISPL, CW	90-R-075-HF-1-CD-60-P-3-D9-D-03-GBA-35-35-18	SERIES 90	S90-075PV
9522522	PUMP-VAR DISPL, CW	90-R-075-HS-1-AB-80-S-3-S1-E-03-GBA-38-38-24	SERIES 90	S90-075PV
9522524	PUMP-VAR DISPL, CW	90-R-075-KP-1-BC-60-S-3-S1-D-03-GBA-29-29-24	SERIES 90	S90-075PV
9522525	PUMP-VAR DISPL, CW	90-R-075-KA-1-CD-80-R-3-S4-D-00-GBA-23-23-24	SERIES 90	S90-075PV
9522526	PUMP-VAR DISPL, CW	90-R-075-HS-1-NN-80-S-3-S1-E-03-GBA-38-38-24	SERIES 90	S90-075PV
9522527	PUMP-VAR DISPL, CW	90-R-075-MA-1-BB-60-D-3-T1-L-26-GBA-42-42-24	SERIES 90	S90-075PV
9522536	PUMP-VAR DISPL, CW	90-R-075-MA-5-CD-80-L-3-S1-D-03-GBA-32-32-24	SERIES 90	S90-075PV
9522537	PUMP-VAR DISPL, CW	90-R-075-KP-1-NN-80-P-3-S1-D-03-GBA-23-23-24	SERIES 90	S90-075PV
9522538	PUMP-VAR DISPL, CW	90-R-075-HK-1-BC-60-R-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9522539	PUMP-VAR DISPL, CW	90-R-075-MV-1-CW-80-L-4-C7-D-03-GBA-38-38-24-F022	SERIES 90	S90-075PV
9522540	PUMP-VAR DISPL, CW	90-R-075-LE-B-BB-80-S-3-S1-D-03-GBA-32-42-24	SERIES 90	S90-075PV
9522541	PUMP-VAR DISPL, CW	90-R-075-KT-1-CD-80-R-3-S1-E-00-GBA-35-38-24	SERIES 90	S90-075PV
9522542	PUMP-VAR DISPL, CW	90-R-075-KT-H-NN-80-R-3-S1-E-00-GBA-AF-38-24	SERIES 90	S90-075PV
9522543	PUMP-VAR DISPL, CW	90-R-075-KT-1-CD-80-E-3-C7-E-00-FAC-42-42-28	SERIES 90	S90-075PV
9522544	PUMP-VAR DISPL, CW	90-R-075-KT-1-BC-80-E-3-S1-C-00-FAC-42-42-28	SERIES 90	S90-075PV
9522545	PUMP-VAR DISPL, CW	90-R-075-KP-1-CD-80-S-3-C6-D-03-GBA-45-45-28	SERIES 90	S90-075PV
9522546	PUMP-VAR DISPL, CW	90-R-075-KP-1-CD-80-S-3-S1-D-03-GBA-45-45-28	SERIES 90	S90-075PV
9522547	PUMP-VAR DISPL, CW	90-R-075-MV-1-AB-60-P-3-S1-D-03-GBA-38-38-24	SERIES 90	S90-075PV
9522548	PUMP-VAR DISPL, CW	90-R-075-KP-5-BB-80-R-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9522549	PUMP-VAR DISPL, CW	90-R-075-MA-5-BC-61-S-3-C6-C-03-GBA-29-29-20	SERIES 90	S90-075PV

9522550	PUMP-VAR DISPL, CW	90-R-075-KP-1-AC-80-P-3-S1-D-22-GBA-38-38-24	SERIES 90	S90-075PV
9522551	PUMP-VAR DISPL, CW	90-R-075-MA-1-NN-80-S-3-S1-D-03-GBA-38-38-24	SERIES 90	S90-075PV
9522552	PUMP-VAR DISPL, CW	90-R-075-KP-G-BB-80-R-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-075PV
9522553	PUMP-VAR DISPL, CW	90-R-075-MT-5-BC-60-S-4-S1-E-02-GBA-23-23-20	SERIES 90	S90-075PV
9522554	PUMP-VAR DISPL, CW	90-R-075-KA-1-AB-60-P-3-C7-D-03-GBA-29-29-20	SERIES 90	S90-075PV
9522556	PUMP-VAR DISPL, CW	90-R-075-KP-5-CD-80-S-3-C6-D-03-GBA-45-45-28	SERIES 90	S90-075PV
9522557	PUMP-VAR DISPL, CW	90-R-075-KP-5-CD-80-S-3-S1-D-03-GBA-45-45-28	SERIES 90	S90-075PV
9522558	PUMP-VAR DISPL, CW	90-R-075-MD-5-CD-61-S-3-S1-E-02-FAD-35-35-28	SERIES 90	S90-075PV
9522559	PUMP-VAR DISPL, CW	90-R-075-MD-5-BC-61-S-3-S1-E-02-FAD-35-35-28	SERIES 90	S90-075PV
9522560	PUMP-VAR DISPL, CW	90-R-075-MT-5-BC-61-S-4-S1-E-02-GBA-23-23-28	SERIES 90	S90-075PV
9522561	PUMP-VAR DISPL, CW	90-R-075-KP-5-BC-80-L-3-S1-E-03-GBA-32-32-24	SERIES 90	S90-075PV
9522562	PUMP-VAR DISPL, CW	90-R-075-KP-1-AB-80-R-3-S1-D-03-GBA-35-35-20	SERIES 90	S90-075PV
9522565	PUMP-VAR DISPL, CW	90-R-075-MA-1-BC-81-S-3-C6-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9522566	PUMP-VAR DISPL, CW	90-R-075-KP-1-BB-80-R-4-S1-E-03-GBA-23-23-24	SERIES 90	S90-075PV
9522567	PUMP-VAR DISPL, CW	90-R-075-MA-1-NN-60-S-3-S1-D-00-GBA-23-23-24	SERIES 90	S90-075PV
9522568	PUMP-VAR DISPL, CW	90-R-075-MV-1-CT-62-R-3-C7-E-03-GFK-42-42-20	SERIES 90	S90-075PV
9522570	PUMP-VAR DISPL, CW	90-R-075-MA-5-CD-80-S-3-S1-E-03-GBA-32-32-24	SERIES 90	S90-075PV
9522571	PUMP-VAR DISPL, CW	90-R-075-MA-1-BC-60-S-3-S1-D-03-GBA-26-42-24	SERIES 90	S90-075PV
9522572	PUMP-VAR DISPL, CW	90-R-075-MA-1-NN-80-S-4-S1-C-03-GBA-42-42-24	SERIES 90	S90-075PV
9522573	PUMP-VAR DISPL, CW - DIST BASE MODEL	90-R-075-CB-1-NN-60-S-4-S1-D-00-GBA-35-35-24-P000	SERIES 90	S90-075PV
9522574	PUMP-VAR DISPL, CW - DIST BASE MODEL	90-R-075-CB-1-NN-60-S-4-C6-D-00-GBA-35-35-24-P000	SERIES 90	S90-075PV
9522575	PUMP-VAR DISPL, CW - DIST BASE MODEL	90-R-075-CB-1-NN-80-S-4-S1-D-00-GBA-35-35-24-P000	SERIES 90	S90-075PV
9522576	PUMP-VAR DISPL, CW - DIST BASE MODEL	90-R-075-CB-1-NN-80-S-4-C6-D-00-GBA-35-35-24	SERIES 90	S90-075PV
9522577	PUMP-VAR DISPL, CW	90-R-075-DD-1-NN-60-L-4-S1-D-GB-GBA-20-20-24	SERIES 90	S90-075PV
9522578	PUMP-VAR DISPL, CW	90-R-075-MA-1-BC-61-S-3-S1-E-03-GBA-32-32-24	SERIES 90	S90-075PV
9522579	PUMP-VAR DISPL, CW	90-R-075-KA-1-NN-80-S-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9522580	PUMP-VAR DISPL, CW	90-R-075-KP-1-BC-81-S-3-S1-E-03-GBA-32-32-24	SERIES 90	S90-075PV
9522581	PUMP-VAR DISPL, CW	90-R-075-KP-5-BC-80-S-3-S1-D-03-GBA-45-45-28	SERIES 90	S90-075PV
9522582	PUMP-VAR DISPL, CW	90-R-075-KD-4-CV-8W-8-3-G2-E-33-EAV-37-37-JK-M001	SERIES 90	S90-075PV
9522584	PUMP-VAR DISPL, CW	90-R-075-KD-4-CV-8W-8-3-G2-E-33-GCU-37-37-JK-M001	SERIES 90	S90-075PV
9522585	PUMP-VAR DISPL, CW	90-R-075-KD-4-CV-8W-8-3-G2-E-33-EAV-40-40-JK-M001	SERIES 90	S90-075PV
9522587	PUMP-VAR DISPL, CW	90-R-075-KD-4-CV-8W-8-3-G2-E-33-GCU-40-40-JK-M001	SERIES 90	S90-075PV
9522588	PUMP-VAR DISPL, CW	90-R-075-KD-4-CV-8W-8-3-G2-E-33-EAV-44-44-JK-M001	SERIES 90	S90-075PV
9522590	PUMP-VAR DISPL, CW	90-R-075-KD-4-CZ-8W-8-3-J8-Y-33-EAV-44-44-JK-M001	SERIES 90	S90-075PV
9522592	PUMP-VAR DISPL, CW	90-R-075-KP-1-AB-80-P-3-S1-D-03-GBA-23-23-24	SERIES 90	S90-075PV
9522593	PUMP-VAR DISPL, CW	90-R-075-KP-1-CD-80-L-3-S1-E-03-GBA-29-29-24	SERIES 90	S90-075PV

9522594	PUMP-VAR DISPL, CW	90-R-075-HF-1-CD-80-P-3-S1-E-03-GBA-38-38-24	SERIES 90	S90-075PV
9522595	PUMP-VAR DISPL, CW	90-R-075-HF-1-AB-80-P-3-S1-E-03-GBA-38-38-24	SERIES 90	S90-075PV
9522596	PUMP-VAR DISPL, CW	90-R-075-KN-1-BC-60-S-4-K2-E-02-GBA-35-14-24-P000	SERIES 90	S90-075PV
9522597	PUMP-VAR DISPL, CW	90-R-075-MA-1-BC-60-S-3-S1-D-03-GBA-38-38-24	SERIES 90	S90-075PV
9522598	PUMP-VAR DISPL, CW	90-R-075-KP-1-CD-60-S-3-S1-D-00-GBA-17-17-20	SERIES 90	S90-075PV
9522599	PUMP-VAR DISPL, CW	90-R-075-KP-1-AB-60-S-3-S1-D-00-GBA-17-17-20	SERIES 90	S90-075PV
9522600	PUMP-VAR DISPL, CW	90-R-075-MT-5-BC-61-S-4-S1-D-02-GBA-23-23-28-F022	SERIES 90	S90-075PV
9522601	PUMP-VAR DISPL, CW	90-R-075-MS-1-BC-80-S-3-C6-D-02-FBA-43-43-20	SERIES 90	S90-075PV
9522602	PUMP-VAR DISPL, CW	90-R-075-MA-1-NN-60-R-3-S1-D-00-GBA-42-42-24	SERIES 90	S90-075PV
9522603	PUMP-VAR DISPL, CW	90-R-075-MA-1-NN-60-R-3-S1-D-00-GBA-23-23-24	SERIES 90	S90-075PV
9522604	PUMP-VAR DISPL, CW	90-R-075-KA-1-BC-80-R-4-S1-D-00-GBA-35-35-24	SERIES 90	S90-075PV
9522605	PUMP-VAR DISPL, CW	90-R-075-JC-5-BC-80-P-3-S1-E-03-GBA-32-32-24	SERIES 90	S90-075PV
9522607	PUMP-VAR DISPL, CW	90-R-075-KD-4-CV-8W-8-3-G2-E-33-GCU-44-44-JK-M001	SERIES 90	S90-075PV
9522608	PUMP-VAR DISPL, CW	90-R-075-KD-4-CZ-8W-8-3-J8-Y-33-GCU-44-44-JK-M001	SERIES 90	S90-075PV
9522609	PUMP-VAR DISPL, CW	90-R-075-MA-1-NN-60-S-3-C6-E-03-GBA-42-42-24	SERIES 90	S90-075PV
9522610	PUMP-VAR DISPL, CW	90-R-075-MA-1-NN-80-S-3-T1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9522611	PUMP-VAR DISPL, CW	90-R-075-KP-1-AB-80-L-4-C7-E-03-GBA-42-42-24	SERIES 90	S90-075PV
9522612	PUMP-VAR DISPL, CW	90-R-075-KA-1-AB-60-L-3-T1-D-00-GBA-29-29-24	SERIES 90	S90-075PV
9522613	PUMP-VAR DISPL, CW	90-R-075-MD-1-BC-60-D-3-S1-L-02-GBA-35-35-20	SERIES 90	S90-075PV
9522614	PUMP-VAR DISPL, CW	90-R-075-MV-1-CD-80-L-3-C7-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9522615	PUMP-VAR DISPL, CW	90-R-075-MA-1-NN-80-L-3-S1-D-02-GBA-42-13-24	SERIES 90	S90-075PV
9522616	PUMP-VAR DISPL, CW	90-R-075-MA-1-NN-80-L-4-S1-D-02-GBA-42-13-24	SERIES 90	S90-075PV
9522617	PUMP-VAR DISPL, CW	90-R-075-MA-1-NN-61-S-3-S1-D-35-GBA-42-42-24	SERIES 90	S90-075PV
9522618	PUMP-VAR DISPL, CW	90-R-075-KA-1-AB-80-R-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9522619	PUMP-VAR DISPL, CW	90-R-075-KP-2-NN-80-R-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9522620	PUMP-VAR DISPL, CW	90-R-075-KP-1-CD-60-S-4-C7-D-03-GBA-43-43-24-F060	SERIES 90	S90-075PV
9522621	PUMP-VAR DISPL, CW	90-R-075-KP-1-BC-60-S-4-S1-D-03-GBA-43-43-24-F060	SERIES 90	S90-075PV
9522622	PUMP-VAR DISPL, CW	90-R-075-KD-1-NN-80-S-3-K2-D-23-GBA-13-29-24	SERIES 90	S90-075PV
9522623	PUMP-VAR DISPL, CW	90-R-075-KE-4-CV-8W-8-3-G2-E-33-GCU-34-34-JK-M001	SERIES 90	S90-075PV
9522625	PUMP-VAR DISPL, CW	90-R-075-KE-4-CV-8W-8-3-G2-E-33-GCU-37-37-JK-M001	SERIES 90	S90-075PV
9522627	PUMP-VAR DISPL, CW	90-R-075-KE-4-CV-8W-8-3-G2-E-33-GCU-41-41-JK-M001	SERIES 90	S90-075PV
9522629	PUMP-VAR DISPL, CW	90-R-075-KE-4-CZ-8W-8-3-J8-Y-33-GCU-44-44-JK-M001	SERIES 90	S90-075PV
9522631	PUMP-VAR DISPL, CW	90-R-075-KP-1-CD-81-S-3-S1-E-03-GBA-32-32-24	SERIES 90	S90-075PV
9522633	PUMP-VAR DISPL, CW	90-R-075-CB-1-AB-60-P-4-S1-D-00-GBA-14-14-20	SERIES 90	S90-075PV
9522634	PUMP-VAR DISPL, CW	90-R-075-LE-B-CD-80-S-3-S1-D-03-GBA-32-48-24	SERIES 90	S90-075PV
9522635	PUMP-VAR DISPL, CW	90-R-075-LE-B-CD-80-S-3-S1-D-03-GBA-32-42-24	SERIES 90	S90-075PV

9522636	PUMP-VAR DISPL, CW	90-R-075-MA-1-BC-80-P-3-S1-D-03-GBA-23-26-24	SERIES 90	S90-075PV
9522637	PUMP-VAR DISPL, CW	90-R-075-MB-1-BC-80-S-3-S1-D-03-GBA-32-32-24	SERIES 90	S90-075PV
9522638	PUMP-VAR DISPL, CW	90-R-075-KP-1-CD-60-P-3-C7-D-03-EBC-42-42-24	SERIES 90	S90-075PV
9522639	PUMP-VAR DISPL, CW	90-R-075-KP-1-NN-60-P-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9522640	PUMP-VAR DISPL, CW	90-R-075-KP-5-BC-60-R-3-T2-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9522641	PUMP-VAR DISPL, CW	90-R-075-MB-2-BC-60-R-3-S1-D-02-GBA-38-38-24	SERIES 90	S90-075PV
9522642	PUMP-VAR DISPL, CW	90-R-075-MB-2-BC-60-R-3-S1-L-02-GBA-32-32-24	SERIES 90	S90-075PV
9522643	PUMP-VAR DISPL, CW	90-R-075-KP-1-BB-80-P-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-075PV
9522644	PUMP-VAR DISPL, CW	90-R-075-KP-1-BC-80-P-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9522645	PUMP-VAR DISPL, CW	90-R-075-MB-1-BC-80-S-3-S1-E-03-GBA-32-32-24	SERIES 90	S90-075PV
9522646	PUMP-VAR DISPL, CW	90-R-075-KP-1-BC-80-P-3-S1-D-03-GBA-23-26-24	SERIES 90	S90-075PV
9522647	PUMP-VAR DISPL, CW	90-R-075-KP-1-BC-60-S-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9522648	PUMP-VAR DISPL, CW	90-R-075-KA-1-NN-80-L-3-S1-D-03-GBA-20-20-24	SERIES 90	S90-075PV
9522650	PUMP-VAR DISPL, CW	90-R-075-KA-5-NN-80-S-4-C6-C-03-FAD-29-29-20	SERIES 90	S90-075PV
9522652	PUMP-VAR DISPL, CW	90-R-075-KA-1-NN-81-S-3-T2-E-00-GBA-35-35-20	SERIES 90	S90-075PV
9522653	PUMP-VAR DISPL, CW	90-R-075-KA-1-AB-81-S-3-T2-E-00-GBA-35-35-20	SERIES 90	S90-075PV
9522655	PUMP-VAR DISPL, CW	90-R-075-KA-1-NN-60-L-4-K2-D-03-GBA-23-23-24	SERIES 90	S90-075PV
9522656	PUMP-VAR DISPL, CW	90-R-075-LE-B-CD-80-S-3-S1-D-01-GBA-32-42-24	SERIES 90	S90-075PV
9522657	PUMP-VAR DISPL, CW	90-R-075-KP-2-CD-80-R-3-C6-E-28-GBA-32-32-24	SERIES 90	S90-075PV
9522658	PUMP-VAR DISPL, CW	90-R-075-HF-1-BC-80-S-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9522659	PUMP-VAR DISPL, CW	90-R-075-HF-1-BC-80-S-4-S1-D-03-GBA-35-35-20	SERIES 90	S90-075PV
9522660	PUMP-VAR DISPL, CW	90-R-075-KP-1-CD-80-R-4-S1-E-03-GBA-29-29-24	SERIES 90	S90-075PV
9522661	PUMP-VAR DISPL, CW	90-R-075-MA-1-BC-80-P-4-S1-D-03-GBA-20-20-24	SERIES 90	S90-075PV
9522662	PUMP-VAR DISPL, CW	90-R-075-MA-1-NN-80-R-4-S1-C-02-GBA-35-35-24	SERIES 90	S90-075PV
9522663	PUMP-VAR DISPL, CW	90-R-075-KP-1-BC-80-R-3-S1-E-03-EBC-35-35-24	SERIES 90	S90-075PV
9522664	PUMP-VAR DISPL, CW	90-R-075-KP-1-NN-80-P-3-S1-D-00-GBA-32-32-24	SERIES 90	S90-075PV
9522665	PUMP-VAR DISPL, CW	90-R-075-KP-1-AB-80-S-3-S1-D-03-GBA-45-45-28	SERIES 90	S90-075PV
9522666	PUMP-VAR DISPL, CW	90-R-075-DC-5-AB-80-P-3-S1-D-GB-GBA-35-35-24	SERIES 90	S90-075PV
9522667	PUMP-VAR DISPL, CW	90-R-075-MA-1-NN-60-S-3-S1-D-03-GBA-26-26-24	SERIES 90	S90-075PV
9522668	PUMP-VAR DISPL, CW	90-R-075-DC-G-AB-80-S-3-S1-D-GB-GBA-35-35-24	SERIES 90	S90-075PV
9522669	PUMP-VAR DISPL, CW	90-R-075-KP-1-NN-80-S-3-C6-E-03-GBA-35-35-24	SERIES 90	S90-075PV
9522669C	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-NN-80-S-3-C6-E-03-GBA-35-35-24	SERIES 90	S90-075PV
9522670	PUMP-VAR DISPL, CW	90-R-075-KP-1-BC-60-S-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-075PV
9522671	PUMP-VAR DISPL, CW	90-R-075-CB-1-CD-80-S-7-S1-D-B1-GCA-32-32-24	SERIES 90	S90-075PV
9522673	PUMP-VAR DISPL, CW	90-R-075-DC-5-AB-80-P-4-S1-D-GF-GBA-35-35-24	SERIES 90	S90-075PV
9522674	PUMP-VAR DISPL, CW	90-R-075-KP-1-CD-80-L-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-075PV

9522675	PUMP-VAR DISPL, CW	90-R-075-MA-1-AB-80-L-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9522677	PUMP-VAR DISPL, CW	90-R-075-MA-1-NN-80-R-4-K2-D-03-GBA-20-20-24	SERIES 90	S90-075PV
9522678	PUMP-VAR DISPL, CW	90-R-075-KT-1-BC-60-S-4-S1-D-03-GBA-43-43-24-F060	SERIES 90	S90-075PV
9522679	PUMP-VAR DISPL, CW	90-R-075-KT-1-CD-60-S-4-C7-D-03-GBA-43-43-24-F060	SERIES 90	S90-075PV
9522680	PUMP-VAR DISPL, CW	90-R-075-KP-1-AB-61-P-3-T1-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9522681	PUMP-VAR DISPL, CW	90-R-075-MA-2-NN-61-S-4-C6-C-04-GBA-26-26-20	SERIES 90	S90-075PV
9522682	PUMP-VAR DISPL, CW	90-R-075-MA-5-NN-80-S-3-S1-D-C5-GBA-17-17-24	SERIES 90	S90-075PV
9522683	PUMP-VAR DISPL, CW	90-R-075-LN-1-CD-60-R-3-S1-D-C8-GBA-20-20-24	SERIES 90	S90-075PV
9522684	PUMP-VAR DISPL, CW	90-R-075-DC-2-CD-80-P-4-C7-D-GB-GBA-32-32-24	SERIES 90	S90-075PV
9522685	PUMP-VAR DISPL, CW	90-R-075-CB-1-CD-80-S-7-S1-D-00-GCA-32-32-24	SERIES 90	S90-075PV
9522686	PUMP-VAR DISPL, CW	90-R-075-KN-1-BC-60-S-4-K2-D-02-GBA-38-38-32	SERIES 90	S90-075PV
9522687	PUMP-VAR DISPL, CW	90-R-075-KP-1-BB-80-R-4-S1-D-00-GBA-23-23-24	SERIES 90	S90-075PV
9522688	PUMP-VAR DISPL, CW	90-R-075-KA-5-AB-80-L-3-S1-D-03-GBA-35-14-24	SERIES 90	S90-075PV
9522689	PUMP-VAR DISPL, CW	90-R-075-KA-5-CD-80-L-3-S1-D-03-GBA-35-14-24	SERIES 90	S90-075PV
9522690	PUMP-VAR DISPL, CW	90-R-075-KN-1-BC-60-S-4-K2-D-02-GBA-14-32-32	SERIES 90	S90-075PV
9522691	PUMP-VAR DISPL, CW	90-R-075-KP-2-AB-80-R-3-S1-C-03-GBA-42-42-20	SERIES 90	S90-075PV
9522692	PUMP-VAR DISPL, CW	90-R-075-KA-5-CD-60-L-3-S1-D-06-GBA-20-20-20	SERIES 90	S90-075PV
9522693	PUMP-VAR DISPL, CW	90-R-075-MX-2-NN-80-S-3-C6-E-02-GBA-42-42-24	SERIES 90	S90-075PV
9522694	PUMP-VAR DISPL, CW	90-R-075-M8-1-BC-60-P-3-C7-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9522694C	PUMP-VAR DISPL, CW 90PV075	90-R-075-M8-1-BC-60-P-3-C7-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9522695	PUMP-VAR DISPL, CW	90-R-075-KP-1-NN-80-P-3-S1-D-03-GBA-17-17-20	SERIES 90	S90-075PV
9522695C	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-NN-80-P-3-S1-D-03-GBA-17-17-20	SERIES 90	S90-075PV
9522696	PUMP-VAR DISPL, CW	90-R-075-DD-1-AB-60-D-4-S1-L-G8-GBA-35-35-24	SERIES 90	S90-075PV
9522696C	PUMP-VAR DISPL, CW 90PV075	90-R-075-DD-1-AB-60-D-4-S1-L-G8-GBA-35-35-24	SERIES 90	S90-075PV
9522697	PUMP-VAR DISPL, CW	90-R-075-KP-5-NN-61-S-4-S1-D-03-GBA-35-35-20	SERIES 90	S90-075PV
9522698	PUMP-VAR DISPL, CW	90-R-075-LN-1-CD-60-R-3-S1-D-C8-GBA-07-20-24	SERIES 90	S90-075PV
9522700	PUMP-VAR DISPL, CW	90-R-075-KP-1-AB-80-S-4-S1-D-03-GBA-20-20-24	SERIES 90	S90-075PV
9522701	PUMP-VAR DISPL, CW	90-R-075-DD-1-NN-60-D-4-S1-L-G8-GBA-35-35-24	SERIES 90	S90-075PV
9522701C	PUMP-VAR DISPL, CW 90PV075	90-R-075-DD-1-NN-60-D-4-S1-L-G8-GBA-35-35-24	SERIES 90	S90-075PV
9522702	PUMP-VAR DISPL, CW	90-R-075-DC-5-AB-80-P-4-S1-D-GB-GBA-35-35-24	SERIES 90	S90-075PV
9522703	PUMP-VAR DISPL, CW	90-R-075-KP-1-NN-60-S-3-S1-C-03-GBA-32-32-24	SERIES 90	S90-075PV
9522703C	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-NN-60-S-3-S1-C-03-GBA-32-32-24	SERIES 90	S90-075PV
9522704	PUMP-VAR DISPL, CW	90-R-075-MA-1-AB-80-R-3-S1-E-03-GBA-35-35-20	SERIES 90	S90-075PV
9522705	PUMP-VAR DISPL, CW	90-R-075-MA-1-NN-60-S-3-C7-D-03-GBA-29-14-20	SERIES 90	S90-075PV
9522705C	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-NN-60-S-3-C7-D-03-GBA-29-14-20	SERIES 90	S90-075PV
9522706	PUMP-VAR DISPL, CW	90-R-075-LE-B-BB-80-S-3-S1-D-01-GBA-32-42-24	SERIES 90	S90-075PV

9522707	PUMP-VAR DISPL, CW	90-R-075-KP-1-NN-80-R-4-S1-D-03-EBC-35-35-24	SERIES 90	S90-075PV
9522707C	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-NN-80-R-4-S1-D-03-EBC-35-35-24	SERIES 90	S90-075PV
9522708	PUMP-VAR DISPL, CW	90-R-075-CB-1-NN-80-S-3-S1-D-00-GBA-35-35-24-P000	SERIES 90	S90-075PV
9522709	PUMP-VAR DISPL, CW	90-R-075-KP-1-NN-80-P-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9522709C	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-NN-80-P-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9522710	PUMP-VAR DISPL, CW	90-R-075-MV-1-CD-80-L-4-S1-D-03-GBA-23-23-24	SERIES 90	S90-075PV
9522711	PUMP-VAR DISPL, CW	90-R-075-KP-1-NN-60-S-3-S1-E-00-GBA-17-17-20	SERIES 90	S90-075PV
9522712	PUMP-VAR DISPL, CW	90-R-075-KP-1-BB-80-R-3-S1-E-03-GBA-32-32-24	SERIES 90	S90-075PV
9522713	PUMP-VAR DISPL, CW	90-R-075-KA-1-NN-80-S-3-C6-D-02-GBA-29-29-20	SERIES 90	S90-075PV
9522714	PUMP-VAR DISPL, CW	90-R-075-KT-H-CD-60-E-3-C7-D-03-FAC-AE-42-28	SERIES 90	S90-075PV
9522715	PUMP-VAR DISPL, CW	90-R-075-KT-H-BC-60-E-3-S1-D-03-FAC-AE-42-28	SERIES 90	S90-075PV
9522717	PUMP-VAR DISPL, CW	90-R-075-M8-1-CD-60-P-3-C7-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9522717C	PUMP-VAR DISPL, CW 90PV075	90-R-075-M8-1-CD-60-P-3-C7-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9522718	PUMP-VAR DISPL, CW	90-R-075-KA-1-NN-81-S-3-S1-E-00-GBA-35-35-20	SERIES 90	S90-075PV
9522719	PUMP-VAR DISPL, CW	90-R-075-KN-1-NN-80-P-3-S1-D-03-GBA-17-17-24	SERIES 90	S90-075PV
9522720	PUMP-VAR DISPL, CW	90-R-075-MB-1-CD-60-R-4-C7-D-22-GBA-35-35-24-F022	SERIES 90	S90-075PV
9522721	PUMP-VAR DISPL, CW	90-R-075-MB-1-BC-60-R-4-S1-D-22-GBA-35-35-24-F022	SERIES 90	S90-075PV
9522722	PUMP-VAR DISPL, CW	90-R-075-ME-1-BC-80-S-3-S1-D-03-GBA-35-32-24	SERIES 90	S90-075PV
9522723	PUMP-VAR DISPL, CW	90-R-075-KP-1-NN-80-P-3-S1-D-03-GBA-32-32-24	SERIES 90	S90-075PV
9522724	PUMP-VAR DISPL, CW	90-R-075-DC-2-AB-80-R-3-S1-C-G4-GBA-32-32-20	SERIES 90	S90-075PV
9522725	PUMP-VAR DISPL, CW	90-R-075-M8-1-CD-60-R-3-C7-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9522725C	PUMP-VAR DISPL, CW 90PV075	90-R-075-M8-1-CD-60-R-3-C7-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9522727	PUMP-VAR DISPL, CW	90-R-075-KA-1-NN-80-P-3-S1-D-03-EBC-35-14-24	SERIES 90	S90-075PV
9522728	PUMP-VAR DISPL, CW	90-R-075-CB-1-NN-60-S-4-S1-D-00-GBA-35-35-24	SERIES 90	S90-075PV
9522728C	PUMP-VAR DISPL, CW 90PV075	90-R-075-CB-1-NN-60-S-4-S1-D-00-GBA-35-35-24	SERIES 90	S90-075PV
9522729	PUMP-VAR DISPL, CW	90-R-075-KP-1-AB-81-S-3-T2-E-00-EBC-35-35-20	SERIES 90	S90-075PV
9522730	PUMP-VAR DISPL, CW	90-R-075-HF-1-AB-60-P-3-C7-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9522730C	PUMP-VAR DISPL, CW 90PV075	90-R-075-HF-1-AB-60-P-3-C7-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9522731	PUMP-VAR DISPL, CW	90-R-075-MA-1-NN-60-S-3-C7-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9522731C	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-NN-60-S-3-C7-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9522732	PUMP-VAR DISPL, CW	90-R-075-DC-1-BT-80-P-4-C7-D-GB-GBA-32-32-24	SERIES 90	S90-075PV
9522733	PUMP-VAR DISPL, CW	90-R-075-KP-6-NN-60-P-3-S1-D-00-GBA-48-48-24	SERIES 90	S90-075PV
9522733C	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-6-NN-60-P-3-S1-D-00-GBA-48-48-24	SERIES 90	S90-075PV
9522734	PUMP-VAR DISPL, CW	90-R-075-KP-6-NN-80-P-3-C7-D-00-GBA-48-48-24	SERIES 90	S90-075PV
9522734C	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-6-NN-80-P-3-C7-D-00-GBA-48-48-24	SERIES 90	S90-075PV
9522735	PUMP-VAR DISPL, CW	90-R-075-CB-1-BC-80-P-7-S1-E-00-GCA-32-32-24	SERIES 90	S90-075PV

9522736	PUMP-VAR DISPL, CW	90-R-075-MA-1-BC-80-S-3-S1-D-03-GBA-38-38-24	SERIES 90	S90-075PV
9522736C	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-BC-80-S-3-S1-D-03-GBA-38-38-24	SERIES 90	S90-075PV
9522737	PUMP-VAR DISPL, CW	90-R-075-KP-2-CD-80-6-1-S1-E-03-GBA-23-42-24-F063	SERIES 90	S90-075PV
9522738	PUMP-VAR DISPL, CW	90-R-075-KP-2-AB-80-6-3-S1-E-02-GBA-37-37-20	SERIES 90	S90-075PV
9522739	PUMP-VAR DISPL, CW	90-R-075-KP-1-AB-80-S-4-S1-E-03-GBA-20-20-24	SERIES 90	S90-075PV
9522740	PUMP-VAR DISPL, CW	90-R-075-M8-1-BC-60-S-3-C6-D-03-GBA-35-35-20	SERIES 90	S90-075PV
9522740C	PUMP-VAR DISPL, CW 90PV075	90-R-075-M8-1-BC-60-S-3-C6-D-03-GBA-35-35-20	SERIES 90	S90-075PV
9522741	PUMP-VAR DISPL, CW	90-R-075-MV-1-BC-80-P-3-S1-E-02-GBA-42-42-24	SERIES 90	S90-075PV
9522742	PUMP-VAR DISPL, CW	90-R-075-CA-1-BC-80-P-7-S1-E-00-GCA-32-32-24	SERIES 90	S90-075PV
9522743	PUMP-VAR DISPL, CW	90-R-075-M8-1-BC-60-R-3-C7-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9522743C	PUMP-VAR DISPL, CW 90PV075	90-R-075-M8-1-BC-60-R-3-C7-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9522744	PUMP-VAR DISPL, CW	90-R-075-KP-1-CD-80-L-3-S1-D-03-GBA-29-29-24	SERIES 90	S90-075PV
9522745	PUMP-VAR DISPL, CW	90-R-075-KP-1-BC-80-L-3-S1-D-03-GBA-29-29-24	SERIES 90	S90-075PV
9522746	PUMP-VAR DISPL, CW	90-R-075-LN-1-CD-60-R-2-S1-D-C8-GBA-07-20-24-F022	SERIES 90	S90-075PV
9522747	PUMP-VAR DISPL, CW	90-R-075-KA-1-NN-80-S-4-S1-D-03-GBA-26-26-24	SERIES 90	S90-075PV
9522748	PUMP-VAR DISPL, CW	90-R-075-KP-1-NN-80-S-4-S1-D-03-GBA-26-26-24	SERIES 90	S90-075PV
9522749	PUMP-VAR DISPL, CW	90-R-075-KP-1-CD-80-P-3-C7-D-02-GBA-35-35-24	SERIES 90	S90-075PV
9522749C	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-CD-80-P-3-C7-D-02-GBA-35-35-24	SERIES 90	S90-075PV
9522750	PUMP-VAR DISPL, CW	90-R-075-KP-1-AB-80-P-3-S1-D-02-GBA-35-35-24	SERIES 90	S90-075PV
9522750C	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-AB-80-P-3-S1-D-02-GBA-35-35-24	SERIES 90	S90-075PV
9522751	PUMP-VAR DISPL, CW	90-R-075-DD-5-BC-60-S-4-C7-D-GB-GBA-35-35-24	SERIES 90	S90-075PV
9522751C	PUMP-VAR DISPL, CW 90PV075	90-R-075-DD-5-BC-60-S-4-C7-D-GB-GBA-35-35-24	SERIES 90	S90-075PV
9522752	PUMP-VAR DISPL, CW	90-R-075-DD-1-AB-60-P-4-S1-C-G8-GBA-35-35-24	SERIES 90	S90-075PV
9522752C	PUMP-VAR DISPL, CW 90PV075	90-R-075-DD-1-AB-60-P-4-S1-C-G8-GBA-35-35-24	SERIES 90	S90-075PV
9522753	PUMP-VAR DISPL, CW	90-R-075-MA-1-CD-80-S-3-C7-D-03-GBA-38-38-24	SERIES 90	S90-075PV
9522753C	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-CD-80-S-3-C7-D-03-GBA-38-38-24	SERIES 90	S90-075PV
9522754	PUMP-VAR DISPL, CW	90-R-075-MA-1-NN-60-S-3-S1-D-03-GBA-38-38-24	SERIES 90	S90-075PV
9522754C	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-NN-60-S-3-S1-D-03-GBA-38-38-24	SERIES 90	S90-075PV
9522755	PUMP-VAR DISPL, CW	90-R-075-LE-1-BB-80-R-3-S1-D-03-GBA-45-17-28	SERIES 90	S90-075PV
9522756	PUMP-VAR DISPL, CW	90-R-075-MA-1-BB-60-S-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9522757	PUMP-VAR DISPL, CW	90-R-075-KA-1-CD-60-R-3-S1-E-09-GBA-35-35-28	SERIES 90	S90-075PV
9522758	PUMP-VAR DISPL, CW	90-R-075-MA-1-BC-80-S-3-C7-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9522758C	PUMP-VAR DISPL, CW 90PV075	90-R-075-MA-1-BC-80-S-3-C7-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9522759	PUMP-VAR DISPL, CW	90-R-075-MB-5-NN-80-L-3-S1-D-C5-GBA-35-35-24	SERIES 90	S90-075PV
9522760	PUMP-VAR DISPL, CW	90-R-075-KA-1-BC-80-P-3-S1-E-00-GBA-32-37-24	SERIES 90	S90-075PV
9522760C	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-BC-80-P-3-S1-E-00-GBA-32-37-24	SERIES 90	S90-075PV

9522761	PUMP-VAR DISPL, CW	90-R-075-KE-4-CV-8W-8-3-G2-E-33-GCU-34-34-JK-M001	SERIES 90	S90-075PV
9522763	PUMP-VAR DISPL, CW	90-R-075-KE-4-CV-8W-8-3-G2-E-33-GCU-37-37-JK-M001	SERIES 90	S90-075PV
9522765	PUMP-VAR DISPL, CW	90-R-075-KE-4-CV-8W-8-3-G2-E-33-GCU-41-41-JK-M001	SERIES 90	S90-075PV
9522769	PUMP-VAR DISPL, CW	90-R-075-KP-1-NN-80-S-4-S1-E-03-GBA-32-32-24	SERIES 90	S90-075PV
9522769C	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-NN-80-S-4-S1-E-03-GBA-32-32-24	SERIES 90	S90-075PV
9522770	PUMP-VAR DISPL, CW	90-R-075-HS-1-CD-80-P-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9522772	PUMP-VAR DISPL, CW	90-R-075-KA-1-NN-80-S-4-S1-E-03-GBA-32-32-24	SERIES 90	S90-075PV
9522772C	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-NN-80-S-4-S1-E-03-GBA-32-32-24	SERIES 90	S90-075PV
9522773	PUMP-VAR DISPL, CW	90-R-075-MA-1-CD-60-L-3-S1-E-00-GBA-17-17-24	SERIES 90	S90-075PV
9522774	PUMP-VAR DISPL, CW	90-R-075-KP-1-CD-60-S-4-S1-E-02-GBA-35-14-20	SERIES 90	S90-075PV
9522775	PUMP-VAR DISPL, CW	90-R-075-CB-1-NN-80-S-4-S1-D-00-GBA-35-35-24	SERIES 90	S90-075PV
9522775C	PUMP-VAR DISPL, CW 90PV075	90-R-075-CB-1-NN-80-S-4-S1-D-00-GBA-35-35-24	SERIES 90	S90-075PV
9522776	PUMP-VAR DISPL, CW	90-R-075-MA-5-NN-60-P-3-S1-D-C5-GBA-42-42-24	SERIES 90	S90-075PV
9522777	PUMP-VAR DISPL, CW	90-R-075-KP-G-BC-60-R-3-S1-E-03-GBA-32-32-24	SERIES 90	S90-075PV
9522778	PUMP-VAR DISPL, CW	90-R-075-KP-1-CD-60-S-4-K2-E-02-GBA-35-14-20	SERIES 90	S90-075PV
9522779	PUMP-VAR DISPL, CW	90-R-075-MA-1-CD-60-P-3-S1-D-03-GBA-38-38-24	SERIES 90	S90-075PV
9522780	PUMP-VAR DISPL, CW	90-R-075-KP-1-BC-80-L-3-S1-E-03-EBC-23-23-24	SERIES 90	S90-075PV
9522781	PUMP-VAR DISPL, CW	90-R-075-KD-1-NN-80-P-3-K2-D-23-GBA-13-29-24	SERIES 90	S90-075PV
9522782	PUMP-VAR DISPL, CW	90-R-075-KP-1-AB-60-S-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9522783	PUMP-VAR DISPL, CW	90-R-075-KP-1-CD-60-S-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9522784	PUMP-VAR DISPL, CW	90-R-075-HS-1-BC-80-P-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9522785	PUMP-VAR DISPL, CW	90-R-075-KA-5-CD-80-P-3-S1-C-03-GBA-42-42-20	SERIES 90	S90-075PV
9522786	PUMP-VAR DISPL, CW	90-R-075-KP-1-AB-80-P-3-S1-D-03-GBA-29-29-24	SERIES 90	S90-075PV
9522786C	PUMP-VAR DISPL, CW 90PV075	90-R-075-KP-1-AB-80-P-3-S1-D-03-GBA-29-29-24	SERIES 90	S90-075PV
9522787	PUMP-VAR DISPL, CW	90-R-075-M8-1-BC-60-S-3-C6-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9522787C	PUMP-VAR DISPL, CW 90PV075	90-R-075-M8-1-BC-60-S-3-C6-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9522788	PUMP-VAR DISPL, CW	90-R-075-KA-1-NN-60-P-3-C6-D-03-GBA-20-20-18	SERIES 90	S90-075PV
9522789	PUMP-VAR DISPL, CW	90-R-075-KP-1-CD-80-P-3-S1-D-00-GBA-42-42-24	SERIES 90	S90-075PV
9522790	PUMP-VAR DISPL, CW	90-R-075-KP-2-CD-80-P-1-S1-E-03-GBA-23-42-20	SERIES 90	S90-075PV
9522791	PUMP-VAR DISPL, CW	90-R-075-KP-2-AB-80-P-3-S1-E-03-GBA-37-37-20	SERIES 90	S90-075PV
9522792	PUMP-VAR DISPL, CW	90-R-075-KP-1-BC-60-P-3-S1-E-03-GBA-37-37-24	SERIES 90	S90-075PV
9522793	PUMP-VAR DISPL, CW	90-R-075-MA-1-BF-62-R-3-C7-E-03-GBA-42-42-20	SERIES 90	S90-075PV
9522794	PUMP-VAR DISPL, CW	90-R-075-KP-1-BC-80-P-4-S1-D-03-GBA-26-26-20	SERIES 90	S90-075PV
9522795	PUMP-VAR DISPL, CW	90-R-075-HF-1-CD-60-R-3-S1-D-03-GBA-26-26-24	SERIES 90	S90-075PV
9522797	PUMP-VAR DISPL, CW	90-R-075-KP-2-CD-80-P-3-S1-E-03-GBA-37-37-20	SERIES 90	S90-075PV
9522798	PUMP-VAR DISPL, CW	90-R-075-KP-2-AB-80-P-1-S1-E-03-GBA-23-42-20	SERIES 90	S90-075PV

9522799	PUMP-VAR DISPL, CW	90-R-075-KP-1-AB-80-R-4-C7-E-03-GBA-42-42-24	SERIES 90	S90-075PV
9522800	PUMP-VAR DISPL, CW	90-R-075-KA-1-NN-80-S-3-S1-D-03-GBA-17-17-24	SERIES 90	S90-075PV
9522801	PUMP-VAR DISPL, CW	90-R-075-MB-1-CD-60-P-3-C7-C-03-GBA-42-42-24	SERIES 90	S90-075PV
9522801C	PUMP-VAR DISPL, CW 90PV075	90-R-075-MB-1-CD-60-P-3-C7-C-03-GBA-42-42-24	SERIES 90	S90-075PV
9522802	PUMP-VAR DISPL, CW	90-R-075-KP-1-CD-81-P-4-K2-D-03-GBA-29-29-24	SERIES 90	S90-075PV
9522803	PUMP-VAR DISPL, CW	90-R-075-KA-1-BC-60-R-3-C7-D-04-GBA-42-42-20	SERIES 90	S90-075PV
9522803C	PUMP-VAR DISPL, CW 90PV075	90-R-075-KA-1-BC-60-R-3-C7-D-04-GBA-42-42-20	SERIES 90	S90-075PV
9522804	PUMP-VAR DISPL, CW	90-R-075-KA-1-BC-80-S-3-S1-D-03-GBA-35-35-20	SERIES 90	S90-075PV
9522805	PUMP-VAR DISPL, CW	90-R-075-MB-1-AB-60-S-3-S1-E-03-GBA-35-35-20	SERIES 90	S90-075PV
9522806	PUMP-VAR DISPL, CW	90-R-075-KP-1-BB-80-R-3-S1-C-03-GBA-29-29-24	SERIES 90	S90-075PV
9522807	PUMP-VAR DISPL, CW	90-R-075-MV-2-BB-80-R-4-C6-D-04-GBA-35-20-24	SERIES 90	S90-075PV
9522809	PUMP-VAR DISPL, CW	90-R-075-MA-1-NN-60-S-3-C7-C-22-GFK-42-42-20	SERIES 90	S90-075PV
9522810	PUMP-VAR DISPL, CW	90-R-075-EP-1-BC-60-R-3-S1-D-00-GFK-42-42-24	SERIES 90	S90-075PV
9522811	PUMP-VAR DISPL, CW	90-R-075-MB-1-BB-60-R-3-C7-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9522811C	PUMP-VAR DISPL, CW 90PV075	90-R-075-MB-1-BB-60-R-3-C7-D-03-GBA-42-42-24	SERIES 90	S90-075PV
9522812	PUMP-VAR DISPL, CW	90-R-075-MA-1-BC-80-S-3-S1-D-03-GBA-35-32-24	SERIES 90	S90-075PV
9522813	PUMP-VAR DISPL, CW	90-R-075-DD-1-NN-60-P-4-S1-D-G8-GBA-38-38-24	SERIES 90	S90-075PV
9522813C	PUMP-VAR DISPL, CW 90PV075	90-R-075-DD-1-NN-60-P-4-S1-D-G8-GBA-38-38-24	SERIES 90	S90-075PV
9522814	PUMP-VAR DISPL, CW	90-R-075-KP-1-BA-80-R-3-S1-F-03-GBA-32-35-24	SERIES 90	S90-075PV
9522815	PUMP-VAR DISPL, CW	90-R-075-KP-2-NN-81-R-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-075PV
9522816	PUMP-VAR DISPL, CW	90-R-075-MA-1-BC-80-P-3-S1-E-03-GBA-32-32-24	SERIES 90	S90-075PV
9522817	PUMP-VAR DISPL, CW	90-R-075-KP-1-BC-80-R-3-S1-E-03-GBA-17-17-24	SERIES 90	S90-075PV
9531091	MOTOR-FIX DISPL	90-M-075-NC-0-N-8-N-0-S1-W-00-EEK-00-00-F0	SERIES 90	S90-075MF
9531093C-5254	MOTOR-FIXED-DISPL 90MF075	90-M-075-NC-0-N-8-N-0-S1-W-00-NNN-00-00-F0	SERIES 90	S90-075MF
9531096	MOTOR-FIXED-DISPL 90MF075	90-M-075-NC-0-N-8-N-0-C6-W-00-NNN-00-00-E6	SERIES 90	S90-075MF
9531112	MOTOR-FIXED-DISPL 90MF075	90-M-075-NC-0-N-7-N-0-C6-W-00-NNN-00-00-F3	SERIES 90	S90-075MF
9541056	MOTOR-VAR DISPL, SAE FLANGE	90-V-075-NB-2-0-8-N-037-S1-N-01-NNN-01-00-00	SERIES 90	S90-075MV
96-2047	PUMP-VAR DISPL CW	90-R-100-HF-1-BC-80-R-3-S1-E-A3-GBA-38-38-28	SERIES 90	S90-100PV
96-2048	PUMP-VAR DISPL, CW	90-R-100-HF-1-CD-80-R-3-S1-E-A3-GBA-38-38-28	SERIES 90	S90-100PV
96-2049	PUMP-VAR DISPL, CCW	90-L-100-MA-1-BC-60-S-4-F1-E-03-GBA-20-20-20	SERIES 90	S90-100PV
96-2051	PUMP-VAR DISPL CW	90-R-100-HM-1-NN-60-P-3-F1-E-04-GBA-32-32-20	SERIES 90	S90-100PV
96-2052	PUMP-VAR DISPL CCW	90-L-100-HM-1-NN-60-P-3-F1-E-04-GBA-32-32-20	SERIES 90	S90-100PV
96-2054	PUMP-VAR DISPL, CCW	90-L-100-MB-1-NN-80-S-3-F1-F-02-GBA-38-38-24	SERIES 90	S90-100PV
96-21002	PUMP-VAR DISPL, CCW	90-L-100-MB-1-BC-60-S-3-F1-E-03-GBA-38-38-20	SERIES 90	S90-100PV
96-21003	PUMP-VAR DISPL, CCW	90-L-100-MA-1-NN-80-S-4-F1-F-03-GBA-38-38-24	SERIES 90	S90-100PV
96-21004	PUMP-VAR DISPL, CCW	90-L-100-MB-1-NN-60-S-3-F1-E-03-FAB-42-42-24	SERIES 90	S90-100PV

96-21006	PUMP-VAR DISPL, CCW	90-L-100-EA-1-BC-60-L-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
96-21008	PUMP-VAR DISPL, CCW	90-L-100-EP-1-CD-60-L-3-F1-E-03-GBA-32-32-20	SERIES 90	S90-100PV
96-21009	PUMP-VAR DISPL, CCW	90-L-100-EP-1-BC-60-L-3-S1-E-03-GBA-32-32-20	SERIES 90	S90-100PV
96-21010	PUMP-VAR DISPL, CCW	90-L-100-EA-1-CD-60-S-4-F1-F-00-GBA-42-42-24	SERIES 90	S90-100PV
96-21011	PUMP-VAR DISPL, CCW	90-L-100-EA-1-NN-60-S-4-S1-F-00-GBA-42-42-24	SERIES 90	S90-100PV
96-21012	PUMP-VAR DISPL, CCW	90-L-100-MA-1-NN-60-R-3-F1-E-03-FAB-42-42-24	SERIES 90	S90-100PV
96-21013	PUMP-VAR DISPL, CCW	90-L-100-MB-1-NN-80-S-4-F1-F-03-GBA-38-38-24	SERIES 90	S90-100PV
96-21014	PUMP-VAR DISPL, CCW	90-L-100-MA-1-BC-60-L-3-F1-F-00-GBA-42-42-28	SERIES 90	S90-100PV
96-21015	PUMP-VAR DISPL, CCW	90-L-100-MB-1-NN-80-S-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
96-21016	PUMP-VAR DISPL, CCW	90-L-100-EA-2-CD-60-S-3-F1-F-33-GBA-42-14-24	SERIES 90	S90-100PV
96-21017	PUMP-VAR DISPL, CCW	90-L-100-EA-2-NN-60-S-3-S1-F-33-GBA-42-14-24	SERIES 90	S90-100PV
96-21019	PUMP-VAR DISPL, CCW	90-L-100-EA-1-NN-60-S-3-F1-E-03-FAB-42-42-24	SERIES 90	S90-100PV
96-21021	PUMP-VAR DISPL, CCW	90-L-100-EA-1-AB-60-P-3-T2-E-00-GBA-32-32-24	SERIES 90	S90-100PV
96-21022	PUMP-VAR DISPL, CCW	90-L-100-EA-1-BC-80-S-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
96-21023	PUMP-VAR DISPL, CCW	90-L-100-EA-1-NN-60-P-4-F1-E-03-GBA-14-20-24	SERIES 90	S90-100PV
96-21024	PUMP-VAR DISPL, CCW	90-L-100-EA-1-NN-60-R-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
96-21025	PUMP-VAR DISPL, CCW	90-L-100-EP-1-NN-60-L-3-S1-E-03-GBA-23-23-20	SERIES 90	S90-100PV
96-21026	PUMP-VAR DISPL, CCW	90-L-100-EA-1-BC-80-S-3-F1-E-03-GBA-35-35-20	SERIES 90	S90-100PV
96-21027	PUMP-VAR DISPL, CCW	90-L-100-EA-1-NN-61-S-3-F1-E-03-GBA-29-29-20	SERIES 90	S90-100PV
96-21029	PUMP-VAR DISPL, CCW	90-L-100-EA-2-CD-80-S-4-F1-E-33-GBA-42-42-24	SERIES 90	S90-100PV
96-21029C	PUMP-VAR DISPL, CCW 90PV100	90-L-100-EA-2-CD-80-S-4-F1-E-33-GBA-42-42-24	SERIES 90	S90-100PV
96-21030	PUMP-VAR DISPL, CCW	90-L-100-EA-2-NN-80-S-4-S1-E-33-GBA-42-42-24	SERIES 90	S90-100PV
96-21031	PUMP-VAR DISPL, CCW	90-L-100-EA-1-BC-80-R-3-F1-E-03-GBA-38-38-20	SERIES 90	S90-100PV
96-21032	PUMP-VAR DISPL, CCW	90-L-100-MB-1-NN-80-S-3-F1-F-02-GBA-38-38-28	SERIES 90	S90-100PV
96-21035	PUMP-VAR DISPL, CCW	90-L-100-MB-1-NN-60-S-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
96-21037	PUMP-VAR DISPL, CCW	90-L-100-EA-1-CD-60-S-3-F1-E-03-GBA-23-23-24	SERIES 90	S90-100PV
96-21038	PUMP-VAR DISPL, CCW	90-L-100-EA-1-BC-60-P-3-S1-E-04-GBA-20-20-24	SERIES 90	S90-100PV
96-21039	PUMP-VAR DISPL, CCW	90-L-100-EP-1-CD-80-S-3-F1-E-03-GBA-42-42-20	SERIES 90	S90-100PV
96-21041	PUMP-VAR DISPL, CCW	90-L-100-MB-1-NN-80-S-3-F1-E-02-GBA-38-38-28	SERIES 90	S90-100PV
96-21042	PUMP-VAR DISPL, CCW	90-L-100-MA-1-NN-60-S-3-S1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
96-21044	PUMP-VAR DISPL, CCW	90-L-100-EP-6-AB-80-S-4-S1-E-03-GBA-45-45-24	SERIES 90	S90-100PV
96-21045	PUMP-VAR DISPL, CCW	90-L-100-MA-1-CD-80-S-3-F1-E-03-GBA-32-32-20	SERIES 90	S90-100PV
96-21046	PUMP-VAR DISPL, CCW	90-L-100-MA-1-NN-80-S-3-S1-E-03-GBA-32-32-20	SERIES 90	S90-100PV
96-21047	PUMP-VAR DISPL, CCW	90-L-100-EP-1-BB-80-S-3-F1-E-03-GBA-23-23-20	SERIES 90	S90-100PV
96-21048	PUMP-VAR DISPL, CCW	90-L-100-EA-2-BC-60-R-4-F1-F-00-GBA-35-35-24	SERIES 90	S90-100PV
96-21049	PUMP-VAR DISPL, CCW	90-L-100-MA-1-CD-60-S-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-100PV

96-21050	PUMP-VAR DISPL, CCW	90-L-100-CB-1-NN-60-P-4-T2-E-00-GBA-14-14-20	SERIES 90	S90-100PV
96-21051	PUMP-VAR DISPL, CCW	90-L-100-MB-1-NN-61-R-3-F1-F-05-GBA-32-32-24	SERIES 90	S90-100PV
96-21052	PUMP-VAR DISPL, CCW	90-L-100-EA-1-NN-61-S-3-F1-E-03-GBA-32-32-20	SERIES 90	S90-100PV
96-21053	PUMP-VAR DISPL, CCW	90-L-100-CB-1-NN-60-P-4-S1-E-00-GBA-14-14-20	SERIES 90	S90-100PV
96-21053C	PUMP-VAR DISPL, CCW 90PV100	90-L-100-CB-1-NN-60-P-4-S1-E-00-GBA-14-14-20	SERIES 90	S90-100PV
96-21054	PUMP-VAR DISPL, CCW	90-L-100-EP-2-AB-60-L-F-F1-E-33-GBA-29-29-20	SERIES 90	S90-100PV
96-21055	PUMP-VAR DISPL, CCW	90-L-100-EP-1-NN-80-S-3-F1-E-03-GBA-38-38-24	SERIES 90	S90-100PV
96-21056	PUMP-VAR DISPL, CCW	90-L-100-MA-1-CD-60-S-3-C7-E-03-GBA-38-38-24	SERIES 90	S90-100PV
96-21057	PUMP-VAR DISPL, CCW	90-L-100-EA-1-NN-60-R-3-F1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
96-21058	PUMP-VAR DISPL, CCW	90-L-100-EA-1-NN-60-R-3-F1-E-03-FAB-42-42-24	SERIES 90	S90-100PV
96-21060	PUMP-VAR DISPL, CCW	90-L-100-HK-1-BC-60-S-3-F1-E-03-GBA-38-38-24	SERIES 90	S90-100PV
96-21061	PUMP-VAR DISPL, CCW	90-L-100-HM-1-NN-80-S-4-S1-E-03-GBA-42-42-20	SERIES 90	S90-100PV
96-21062	PUMP-VAR DISPL, CCW	90-L-100-HM-1-AB-60-R-3-S1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
96-21063	PUMP-VAR DISPL, CCW	90-L-100-EA-1-BC-60-R-4-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
96-21064	PUMP-VAR DISPL, CCW	90-L-100-HM-1-NN-60-P-3-F1-E-04-GBA-32-32-24	SERIES 90	S90-100PV
96-21065	PUMP-VAR DISPL, CCW	90-L-100-EP-1-BC-80-R-3-F1-F-03-GBA-38-38-24	SERIES 90	S90-100PV
96-21066	PUMP-VAR DISPL, CCW	90-L-100-HF-1-BC-60-R-3-F1-E-03-GBA-32-32-24	SERIES 90	S90-100PV
96-21067	PUMP-VAR DISPL, CCW	90-L-100-HK-1-AB-60-R-3-F1-E-05-GBA-35-35-24	SERIES 90	S90-100PV
96-21069	PUMP-VAR DISPL, CCW	90-L-100-EP-1-BC-60-S-3-S1-E-03-GBA-32-32-20	SERIES 90	S90-100PV
96-21070	PUMP-VAR DISPL, CCW	90-L-100-CB-1-CD-60-S-3-F1-E-00-GBA-14-14-08	SERIES 90	S90-100PV
96-21071	PUMP-VAR DISPL, CCW	90-L-100-CB-1-BC-60-S-3-S1-E-00-GBA-14-14-08	SERIES 90	S90-100PV
96-21072	PUMP-VAR DISPL, CCW	90-L-100-EA-1-BC-80-R-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
96-21073	PUMP-VAR DISPL, CCW	90-L-100-EA-1-BC-80-S-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
96-21074	PUMP-VAR DISPL, CCW	90-L-100-CB-1-NN-80-S-3-S1-E-00-GBA-35-35-20	SERIES 90	S90-100PV
96-21075	PUMP-VAR DISPL, CCW	90-L-100-EA-1-NN-60-R-3-F1-E-03-FAD-42-42-24	SERIES 90	S90-100PV
96-21076	PUMP-VAR DISPL, CCW	90-L-100-EA-1-NN-60-R-3-F1-E-00-FAD-42-42-24	SERIES 90	S90-100PV
96-21079	PUMP-VAR DISPL, CCW	90-L-100-MA-6-BC-60-S-3-F1-F-06-GBA-45-45-24	SERIES 90	S90-100PV
96-21080	PUMP-VAR DISPL, CCW	90-L-100-EA-1-AB-60-R-3-F1-L-03-FAB-42-42-24	SERIES 90	S90-100PV
96-21081	PUMP-VAR DISPL, CCW	90-L-100-EA-1-AB-60-P-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
96-21082	PUMP-VAR DISPL, CCW	90-L-100-EA-1-NN-60-P-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
96-21083	PUMP-VAR DISPL, CCW	90-L-100-MC-1-BC-80-L-3-S1-E-02-GBA-23-23-24	SERIES 90	S90-100PV
96-21084	PUMP-VAR DISPL, CCW	90-L-100-CB-7-BC-60-L-F-F1-F-00-GBA-45-45-28	SERIES 90	S90-100PV
96-21085	PUMP-VAR DISPL, CCW	90-L-100-EA-1-NN-60-S-3-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
96-21086	PUMP-VAR DISPL, CCW	90-L-100-EA-1-CD-60-S-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
96-21087	PUMP-VAR DISPL, CCW	90-L-100-MB-1-CD-60-S-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
96-21088	PUMP-VAR DISPL, CCW	90-L-100-EA-1-BC-60-S-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV

96-21090	PUMP-VAR DISPL, CCW	90-L-100-EA-1-NN-60-S-3-F1-E-03-GBA-35-35-20	SERIES 90	S90-100PV
96-21091	PUMP-VAR DISPL, CCW	90-L-100-HF-1-BC-60-L-3-F1-E-03-GBA-38-38-24	SERIES 90	S90-100PV
96-21092	PUMP-VAR DISPL, CCW	90-L-100-EA-1-NN-60-L-3-F1-E-03-GBA-35-35-20	SERIES 90	S90-100PV
96-21093	PUMP-VAR DISPL, CCW	90-L-100-MA-1-CD-60-S-3-S1-F-03-GBA-29-29-20	SERIES 90	S90-100PV
96-21101	PUMP-VAR DISPL, CCW	90-L-100-MA-1-NN-80-S-3-S1-E-03-GBA-38-38-20	SERIES 90	S90-100PV
96-21102	PUMP-VAR DISPL, CCW	90-L-100-MA-1-CD-80-S-3-F1-E-03-GBA-38-38-20	SERIES 90	S90-100PV
96-21104	PUMP-VAR DISPL, CCW	90-L-100-HK-1-BC-60-L-3-F1-E-03-GBA-38-38-24	SERIES 90	S90-100PV
96-21106	PUMP-VAR DISPL, CCW	90-L-100-HK-1-NN-60-S-4-F1-E-03-GBA-42-42-28	SERIES 90	S90-100PV
96-21108	PUMP-VAR DISPL, CCW	90-L-100-MB-1-BC-61-S-3-F1-E-03-GBA-38-38-20	SERIES 90	S90-100PV
96-21110	PUMP-VAR DISPL, CCW	90-L-100-MA-1-NN-60-S-3-F1-E-03-GBA-29-29-24	SERIES 90	S90-100PV
96-21112	PUMP-VAR DISPL, CCW	90-L-100-MA-1-NN-60-R-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
96-21114	PUMP-VAR DISPL, CCW	90-L-100-MB-1-NN-80-S-3-F1-E-02-GBA-32-32-24	SERIES 90	S90-100PV
96-21117	PUMP-VAR DISPL, CCW	90-L-100-EA-1-AB-80-L-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
96-21118	PUMP-VAR DISPL, CCW	90-L-100-EA-1-BC-60-S-3-F1-E-05-GBA-42-42-24	SERIES 90	S90-100PV
96-21119	PUMP-VAR DISPL, CCW	90-L-100-EA-1-NN-60-S-3-T2-E-03-GBA-35-35-24	SERIES 90	S90-100PV
96-21120	PUMP-VAR DISPL, CCW	90-L-100-EA-1-NN-80-L-3-S1-E-03-GBA-35-35-20	SERIES 90	S90-100PV
96-21121	PUMP-VAR DISPL, CCW	90-L-100-EA-1-BB-80-S-3-F1-E-03-GBA-38-38-20	SERIES 90	S90-100PV
96-21122	PUMP-VAR DISPL, CCW	90-L-100-EP-1-CD-80-R-3-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
96-21123	PUMP-VAR DISPL, CCW	90-L-100-EP-1-NN-80-P-4-S1-E-03-GBA-29-29-24	SERIES 90	S90-100PV
96-21124	PUMP-VAR DISPL, CCW	90-L-100-EP-1-NN-80-R-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
96-21125	PUMP-VAR DISPL, CCW	90-L-100-EP-1-BB-80-L-3-F1-E-02-GBA-35-35-24	SERIES 90	S90-100PV
96-21126	PUMP-VAR DISPL, CCW	90-L-100-HK-1-AB-60-R-3-F1-E-05-GBA-38-38-24	SERIES 90	S90-100PV
96-21127	PUMP-VAR DISPL, CCW	90-L-100-HF-1-CD-60-R-3-F1-E-03-GBA-26-26-24	SERIES 90	S90-100PV
96-21128	PUMP-VAR DISPL, CCW	90-L-100-HF-1-NN-60-R-3-S1-E-03-GBA-26-26-24	SERIES 90	S90-100PV
96-21129	PUMP-VAR DISPL, CCW	90-L-100-HF-1-NN-60-R-4-T2-E-03-GBA-29-29-24	SERIES 90	S90-100PV
96-21130	PUMP-VAR DISPL, CCW	90-L-100-HK-1-BB-60-R-3-F1-E-05-GBA-38-38-24	SERIES 90	S90-100PV
96-21131	PUMP-VAR DISPL, CCW	90-L-100-HK-1-NN-60-S-4-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
96-21132	PUMP-VAR DISPL, CCW	90-L-100-HF-1-CD-61-R-3-F1-F-00-GBA-23-23-24	SERIES 90	S90-100PV
96-21133	PUMP-VAR DISPL, CCW	90-L-100-HF-1-NN-80-S-3-K3-E-03-GBA-32-32-20	SERIES 90	S90-100PV
96-21134	PUMP-VAR DISPL, CCW	90-L-100-EX-1-NN-60-S-3-F1-E-03-GBA-29-29-24	SERIES 90	S90-100PV
96-21135	PUMP-VAR DISPL, CCW	90-L-100-EX-1-CD-80-S-3-F1-E-03-GBA-42-42-20	SERIES 90	S90-100PV
96-21136	PUMP-VAR DISPL, CCW	90-L-100-HF-1-NN-80-S-4-S1-E-03-GBA-42-42-20	SERIES 90	S90-100PV
96-21137	PUMP-VAR DISPL, CCW	90-L-100-HF-1-NN-80-S-3-S1-E-03-GBA-42-42-20	SERIES 90	S90-100PV
96-21138	PUMP-VAR DISPL, CCW	90-L-100-MB-1-BC-60-P-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
96-21139	PUMP-VAR DISPL, CCW	90-L-100-MB-1-NN-60-R-3-S1-D-04-GBA-35-35-20	SERIES 90	S90-100PV
96-21140	PUMP-VAR DISPL, CCW	90-L-100-MB-1-CD-80-S-3-F1-E-02-GBA-32-32-24	SERIES 90	S90-100PV

96-21141	PUMP-VAR DISPL, CCW	90-L-100-EA-1-CD-80-L-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
96-21142	PUMP-VAR DISPL, CCW	90-L-100-EP-1-BB-60-R-3-S1-D-00-GBA-42-42-24	SERIES 90	S90-100PV
96-21143	PUMP-VAR DISPL, CCW	90-L-100-EA-1-CD-60-P-3-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
96-21144	PUMP-VAR DISPL, CCW	90-L-100-EA-1-NN-60-P-4-F1-E-02-GBA-38-14-20	SERIES 90	S90-100PV
96-21145	PUMP-VAR DISPL, CCW	90-L-100-EA-1-CD-60-L-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
96-21146	PUMP-VAR DISPL, CCW	90-L-100-EA-1-BC-60-P-3-F1-E-03-FAC-38-38-24	SERIES 90	S90-100PV
96-21147	PUMP-VAR DISPL, CCW	90-L-100-EA-1-BC-60-L-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
96-21148	PUMP-VAR DISPL, CCW	90-L-100-EA-1-NN-60-S-4-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
96-2134	PUMP-VAR DISPL, CCW	90-L-100-MA-1-CD-60-S-3-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
96-2135	PUMP-VAR DISPL, CCW	90-L-100-MA-1-AB-60-S-3-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
96-2162	PUMP-VAR DISPL, CCW	90-L-100-MA-1-NN-61-S-3-C7-D-04-GBA-35-35-20	SERIES 90	S90-100PV
96-2212	PUMP-VAR DISPL, CCW	90-L-100-MA-1-NN-61-S-3-TF-D-04-GBA-38-38-20	SERIES 90	S90-100PV
96-2266	PUMP-VAR DISPL, CCW	90-L-100-MA-1-NN-61-S-3-T2-D-03-FAB-38-38-20	SERIES 90	S90-100PV
96-2278	PUMP-VAR DISPL, CW	90-R-100-MA-1-NN-60-S-3-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
96-2279	PUMP-VAR DISPL, CCW	90-L-100-MA-1-NN-60-S-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
96-2279C	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MA-1-NN-60-S-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
96-2280	PUMP-VAR DISPL, CW	90-R-100-EA-1-NN-60-S-3-F1-F-00-GBA-26-26-24	SERIES 90	S90-100PV
96-2281	PUMP-VAR DISPL, CW	90-R-100-MA-1-CD-60-P-3-F1-E-03-GBA-32-32-24	SERIES 90	S90-100PV
96-2282	PUMP-VAR DISPL, CW	90-R-100-EA-1-NN-60-S-3-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
96-2283	PUMP-VAR DISPL, CCW	90-L-100-MA-1-BC-60-S-3-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
96-2288	PUMP-VAR DISPL, CW	90-R-100-EA-1-NN-60-L-4-S1-F-03-GBA-23-23-20	SERIES 90	S90-100PV
96-2336	PUMP-VAR DISPL, CCW	90-L-100-MA-1-NN-61-S-3-TF-D-03-FAB-38-38-20	SERIES 90	S90-100PV
96-2397	PUMP-VAR DISPL, CCW	90-L-100-M9-1-NN-61-S-3-T2-D-02-FAB-38-38-20	SERIES 90	S90-100PV
96-2398	PUMP-VAR DISPL, CCW	90-L-100-M9-1-NN-61-S-3-TF-D-02-FAB-38-38-20	SERIES 90	S90-100PV
96-2407	PUMP-VAR DISPL, CCW	90-L-100-M9-1-NN-61-S-3-C7-D-22-FAB-35-35-20	SERIES 90	S90-100PV
96-2418	PUMP-VAR DISPL, CW	90-R-100-MA-1-BC-60-S-3-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
96-2419	PUMP-VAR DISPL, CCW	90-L-100-MA-1-NN-60-S-3-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
96-2420	PUMP-VAR DISPL, CCW	90-L-100-MA-1-NN-61-S-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
96-2422	PUMP-VAR DISPL, CW	90-R-100-MA-1-BC-60-S-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
96-2424	PUMP-VAR DISPL, CCW	90-L-100-MA-1-CD-60-S-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
96-2425	PUMP-VAR DISPL, CCW	90-L-100-MA-1-BC-60-S-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
96-2426	PUMP-VAR DISPL, CCW	90-L-100-EA-1-BC-60-S-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
96-2427	PUMP-VAR DISPL, CCW	90-L-100-EA-1-CD-60-S-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
96-2428	PUMP-VAR DISPL, CCW	90-L-100-EA-1-NN-60-S-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
96-2433	PUMP-VAR DISPL, CW	90-R-100-EA-1-AB-60-P-3-F1-E-04-GBA-38-38-24	SERIES 90	S90-100PV
96-2434	PUMP-VAR DISPL, CCW	90-L-100-MB-1-CD-60-P-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV

96-2435	PUMP-VAR DISPL, CCW	90-L-100-EA-1-NN-61-P-3-F1-E-00-GBA-35-35-24	SERIES 90	S90-100PV
96-2437	PUMP-VAR DISPL, CCW	90-L-100-EA-1-BC-60-S-3-F1-E-03-GBA-23-23-20	SERIES 90	S90-100PV
96-2439	PUMP-VAR DISPL, CW	90-R-100-EA-1-CD-60-P-3-F1-E-03-GBA-38-38-24	SERIES 90	S90-100PV
96-2442	PUMP-VAR DISPL, CW	90-R-100-EA-1-NN-60-P-3-C7-E-03-GBA-32-32-24	SERIES 90	S90-100PV
96-2444	PUMP-VAR DISPL, CW	90-R-100-MB-1-BC-60-P-3-F1-F-03-GBA-38-38-24	SERIES 90	S90-100PV
96-2445	PUMP-VAR DISPL, CW	90-R-100-MB-1-NN-60-L-3-F1-E-03-GBA-23-14-28	SERIES 90	S90-100PV
96-2446	PUMP-VAR DISPL, CCW	90-L-100-MB-1-BC-60-S-3-S1-E-03-GBA-38-38-20	SERIES 90	S90-100PV
96-2447	PUMP-VAR DISPL, CCW	90-L-100-EA-1-NN-60-S-3-F1-E-03-GBA-38-38-24	SERIES 90	S90-100PV
96-2451	PUMP-VAR DISPL, CCW	90-L-100-MB-1-BC-60-L-3-S1-E-03-GBA-38-38-20	SERIES 90	S90-100PV
96-2453	PUMP-VAR DISPL, CCW	90-L-100-EA-1-CD-60-L-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
96-2456	PUMP-VAR DISPL, CCW	90-L-100-EA-1-CD-60-S-3-F1-E-03-GBA-38-38-24	SERIES 90	S90-100PV
96-2459	PUMP-VAR DISPL, CCW	90-L-100-EA-1-NN-60-S-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
96-2460	PUMP-VAR DISPL, CW	90-R-100-MA-1-BC-60-S-3-C7-E-03-GBA-38-38-20	SERIES 90	S90-100PV
96-2461	PUMP-VAR DISPL, CCW	90-L-100-MB-1-CD-60-S-3-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
96-2462	PUMP-VAR DISPL, CCW	90-L-100-EA-1-CD-60-P-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
96-2463	PUMP-VAR DISPL, CW	90-R-100-EA-1-CD-60-L-3-F1-E-03-GBA-32-32-24	SERIES 90	S90-100PV
96-2468	PUMP-VAR DISPL, CCW	90-L-100-EA-1-NN-60-S-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
96-2473	PUMP-VAR DISPL, CW	90-R-100-MA-1-NN-60-S-4-S1-E-03-GBA-32-32-24	SERIES 90	S90-100PV
96-2482	PUMP-VAR DISPL, CW	90-R-100-MB-1-BC-60-R-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
96-2489	PUMP-VAR DISPL, CW	90-R-100-EA-1-NN-61-R-3-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
96-2492	PUMP-VAR DISPL, CW	90-R-100-MA-1-AB-61-S-3-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
96-2496	PUMP-VAR DISPL, CW	90-R-100-MA-1-AB-60-S-3-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
96-2498	PUMP-VAR DISPL, CCW	90-L-100-EA-1-BC-60-R-3-F1-E-00-GBA-42-42-24	SERIES 90	S90-100PV
96-2504	PUMP-VAR DISPL, CCW	90-L-100-MA-1-NN-60-S-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
96-2508	PUMP-VAR DISPL, CCW	90-L-100-EA-1-CD-60-S-3-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
96-2513	PUMP-VAR DISPL, CCW	90-L-100-EA-1-NN-60-S-3-S1-F-03-GBA-42-14-24	SERIES 90	S90-100PV
96-2514	PUMP-VAR DISPL, CCW	90-L-100-EA-1-CD-60-S-3-F1-F-03-GBA-42-14-24	SERIES 90	S90-100PV
96-2515	PUMP-VAR DISPL, CCW	90-L-100-MA-1-NN-61-S-4-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
96-2516	PUMP-VAR DISPL, CCW	90-L-100-EA-1-CD-60-S-4-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
96-2517	PUMP-VAR DISPL, CW	90-R-100-MA-1-NN-60-D-3-C7-L-03-GBA-42-42-24	SERIES 90	S90-100PV
96-2520	PUMP-VAR DISPL, CCW	90-L-100-MB-1-BC-60-S-3-F1-E-05-GBA-35-35-24	SERIES 90	S90-100PV
96-2521	PUMP-VAR DISPL, CCW	90-L-100-EA-1-BB-60-P-3-F1-E-03-GBA-38-38-24	SERIES 90	S90-100PV
96-2523	PUMP-VAR DISPL, CW	90-R-100-MA-1-CD-60-S-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
96-2524	PUMP-VAR DISPL, CW	90-R-100-EA-1-NN-60-S-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
96-2525	PUMP-VAR DISPL, CW	90-R-100-MA-1-NN-60-S-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
96-2525C	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-NN-60-S-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV

96-2526	PUMP-VAR DISPL, CCW	90-L-100-EA-1-CD-60-S-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
96-2530	PUMP-VAR DISPL, CW	90-R-100-EA-1-AB-60-S-3-S1-D-00-GBA-35-35-24	SERIES 90	S90-100PV
96-2533	PUMP-VAR DISPL, CW	90-R-100-EA-1-BC-60-S-3-S1-E-00-GBA-35-35-20	SERIES 90	S90-100PV
96-2549	PUMP-VAR DISPL, CW	90-R-100-MA-1-CD-60-S-4-F1-E-03-GBA-32-32-24	SERIES 90	S90-100PV
96-2550	PUMP-VAR DISPL, CCW	90-L-100-MB-1-AB-60-S-3-F1-E-03-GBA-42-42-20	SERIES 90	S90-100PV
96-2551	PUMP-VAR DISPL, CW	90-R-100-MA-1-NN-60-S-3-F1-E-03-GBA-42-42-20	SERIES 90	S90-100PV
96-2555	PUMP-VAR DISPL, CCW	90-L-100-CB-1-NN-80-S-4-S1-F-00-GBA-42-42-20	SERIES 90	S90-100PV
96-2561	PUMP-VAR DISPL, CW	90-R-100-EA-1-NN-60-L-3-F1-D-03-GBA-35-35-24	SERIES 90	S90-100PV
96-2565	PUMP-VAR DISPL, CCW	90-L-100-EP-1-BC-60-S-3-F1-E-03-GBA-29-29-20	SERIES 90	S90-100PV
96-2570	PUMP-VAR DISPL, CCW	90-L-100-EA-1-BC-60-R-4-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
96-2572	PUMP-VAR DISPL, CCW	90-L-100-MA-1-NN-60-P-3-F1-E-03-GBA-32-32-24	SERIES 90	S90-100PV
96-2573	PUMP-VAR DISPL, CCW	90-L-100-EA-1-AB-60-S-3-F1-E-03-GBA-32-32-24	SERIES 90	S90-100PV
96-2575	PUMP-VAR DISPL, CCW	90-L-100-EA-1-NN-60-L-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
96-2576	PUMP-VAR DISPL, CCW	90-L-100-EA-1-BB-60-L-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
96-2581	PUMP-VAR DISPL, CCW	90-L-100-EA-1-CD-60-P-3-F1-F-00-GBA-42-42-24	SERIES 90	S90-100PV
96-2585	PUMP-VAR DISPL, CW	90-R-100-EA-1-CD-60-L-3-F1-E-02-GBA-42-42-24	SERIES 90	S90-100PV
96-2587	PUMP-VAR DISPL, CCW	90-L-100-CB-1-BC-60-P-3-F1-F-00-GBA-42-42-24	SERIES 90	S90-100PV
96-2588	PUMP-VAR DISPL, CCW	90-L-100-CB-1-NN-60-P-3-S1-F-00-GBA-42-42-24	SERIES 90	S90-100PV
96-2601	PUMP-VAR DISPL, CCW	90-L-100-MA-1-AB-60-P-3-F1-F-03-GFK-38-38-20	SERIES 90	S90-100PV
96-2603	PUMP-VAR DISPL, CCW	90-L-100-MA-1-NN-61-R-3-F1-F-00-GBA-32-32-24	SERIES 90	S90-100PV
96-2604	PUMP-VAR DISPL, CCW	90-L-100-MB-1-NN-60-S-3-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
96-2607	PUMP-VAR DISPL, CCW	90-L-100-EA-1-AB-60-R-3-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
96-2608	PUMP-VAR DISPL, CCW	90-L-100-EP-1-CD-60-S-3-T2-E-03-GBA-32-32-20	SERIES 90	S90-100PV
96-2609	PUMP-VAR DISPL, CCW	90-L-100-CB-1-NN-60-S-3-S1-E-00-GBA-32-32-20	SERIES 90	S90-100PV
96-2611	PUMP-VAR DISPL, CCW	90-L-100-EP-1-NN-60-R-3-K3-E-03-GBA-35-35-20	SERIES 90	S90-100PV
96-2612	PUMP-VAR DISPL, CW	90-R-100-MA-1-BC-60-S-3-F1-E-03-GBA-42-42-20	SERIES 90	S90-100PV
96-2615	PUMP-VAR DISPL, CCW	90-L-100-EP-6-NN-60-S-3-T2-D-03-GBA-48-48-24	SERIES 90	S90-100PV
96-2616	PUMP-VAR DISPL, CW	90-R-100-MA-1-BC-60-S-3-F1-E-03-GBA-20-20-20	SERIES 90	S90-100PV
96-2622	PUMP-VAR DISPL, CCW	90-L-100-EA-1-AB-60-R-3-F1-F-03-GBA-35-35-20	SERIES 90	S90-100PV
96-2627	PUMP-VAR DISPL, CW	90-R-100-MA-1-BC-60-S-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
96-2629	PUMP-VAR DISPL, CW	90-R-100-EA-1-NN-60-S-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
96-2632	PUMP-VAR DISPL, CCW	90-L-100-EA-1-BC-60-L-3-F1-F-00-GBA-42-42-28	SERIES 90	S90-100PV
96-2633	PUMP-VAR DISPL, CW	90-R-100-EA-1-NN-60-S-3-F1-E-03-GBA-42-42-20	SERIES 90	S90-100PV
96-2634	PUMP-VAR DISPL, CCW	90-L-100-MA-1-NN-60-R-3-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
96-2635	PUMP-VAR DISPL, CCW	90-L-100-EA-2-NN-60-R-3-F1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
96-2636	PUMP-VAR DISPL, CW	90-R-100-MA-1-NN-60-S-3-F1-E-04-GBA-38-38-24	SERIES 90	S90-100PV

96-2637	PUMP-VAR DISPL, CCW	90-L-100-EA-1-BB-60-S-3-F1-E-04-GBA-42-42-20	SERIES 90	S90-100PV
96-2638	PUMP-VAR DISPL, CCW	90-L-100-EA-1-NN-60-P-3-S1-E-03-GBA-20-20-24	SERIES 90	S90-100PV
96-2639	PUMP-VAR DISPL, CCW	90-L-100-MB-1-AB-60-S-3-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
96-2640	PUMP-VAR DISPL, CW	90-R-100-EA-1-NN-61-R-3-F1-E-00-GBA-42-42-24	SERIES 90	S90-100PV
96-2641	PUMP-VAR DISPL, CW	90-R-100-EP-1-CD-80-R-3-C7-E-00-GBA-42-42-20	SERIES 90	S90-100PV
96-2642	PUMP-VAR DISPL, CW	90-R-100-EP-1-CD-80-R-3-S1-E-00-GBA-42-42-20	SERIES 90	S90-100PV
96-2643	PUMP-VAR DISPL, CCW	90-L-100-EA-2-BC-60-R-3-F1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
96-2644	PUMP-VAR DISPL, CW	90-R-100-MB-1-BC-80-S-3-F1-E-03-GBA-42-42-20	SERIES 90	S90-100PV
96-2645	PUMP-VAR DISPL, CW	90-R-100-MB-1-CD-80-S-3-F1-E-03-GBA-42-42-20	SERIES 90	S90-100PV
96-2646	PUMP-VAR DISPL, CW	90-R-100-EP-1-NN-80-S-3-F1-E-03-GBA-42-42-20	SERIES 90	S90-100PV
96-2648	PUMP-VAR DISPL, CW	90-R-100-EA-1-NN-60-S-4-F1-E-03-GBA-29-29-24	SERIES 90	S90-100PV
96-2650	PUMP-VAR DISPL, CW	90-R-100-MA-1-NN-60-S-3-S1-E-03-GBA-20-20-20	SERIES 90	S90-100PV
96-2651	PUMP-VAR DISPL, CW	90-R-100-MA-1-CD-60-S-3-S1-E-03-GBA-20-20-20	SERIES 90	S90-100PV
96-2653	PUMP-VAR DISPL, CCW	90-L-100-MA-6-BC-60-S-3-F1-E-03-GBA-45-45-24	SERIES 90	S90-100PV
96-2654	PUMP-VAR DISPL, CCW	90-L-100-EP-1-BB-60-S-3-F1-E-04-GBA-35-35-20	SERIES 90	S90-100PV
96-2655	PUMP-VAR DISPL, CCW	90-L-100-EA-1-CD-60-R-4-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
96-2656	PUMP-VAR DISPL, CCW	90-L-100-EA-6-BC-80-S-3-F1-E-03-GBA-45-45-24	SERIES 90	S90-100PV
96-2657	PUMP-VAR DISPL, CCW	90-L-100-EA-1-BB-60-S-3-F1-E-04-GBA-35-35-20	SERIES 90	S90-100PV
96-2658	PUMP-VAR DISPL, CW	90-R-100-MA-1-CD-60-S-3-C7-E-03-GBA-38-38-20	SERIES 90	S90-100PV
96-2659	PUMP-VAR DISPL, CCW	90-L-100-MB-1-BC-60-S-3-F1-E-03-GBA-32-32-24	SERIES 90	S90-100PV
96-2660	PUMP-VAR DISPL, CCW	90-L-100-EA-1-BC-60-R-3-S1-E-03-GBA-29-29-24	SERIES 90	S90-100PV
96-2661	PUMP-VAR DISPL, CCW	90-L-100-EA-1-NN-60-R-3-S1-D-03-GBA-29-29-24	SERIES 90	S90-100PV
96-2662	PUMP-VAR DISPL, CCW	90-L-100-EA-1-CD-60-R-3-S1-D-03-GBA-29-29-24	SERIES 90	S90-100PV
96-2663	PUMP-VAR DISPL, CCW	90-L-100-EA-1-BC-60-R-3-S1-D-03-GBA-29-29-24	SERIES 90	S90-100PV
96-2664	PUMP-VAR DISPL, CW	90-R-100-MB-1-BC-61-L-3-F1-E-02-GBA-35-35-24	SERIES 90	S90-100PV
96-2665	PUMP-VAR DISPL, CCW	90-L-100-EA-1-CD-60-R-4-F1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
96-2666	PUMP-VAR DISPL, CW	90-R-100-EA-1-BC-60-P-3-F1-E-05-GBA-42-42-24	SERIES 90	S90-100PV
96-2667	PUMP-VAR DISPL, CCW	90-L-100-EA-1-BC-60-R-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
96-2668	PUMP-VAR DISPL, CCW	90-L-100-EA-1-BC-60-R-3-F1-F-03-GBA-32-32-24	SERIES 90	S90-100PV
96-2669	PUMP-VAR DISPL, CCW	90-L-100-EP-1-NN-60-S-3-S1-E-03-GBA-32-32-20	SERIES 90	S90-100PV
96-2670	PUMP-VAR DISPL, CCW	90-L-100-EP-1-BC-60-S-3-T2-E-03-GBA-32-32-20	SERIES 90	S90-100PV
96-2671	PUMP-VAR DISPL, CCW	90-L-100-EP-1-NN-60-S-3-T2-E-03-GBA-32-32-20	SERIES 90	S90-100PV
96-2672	PUMP-VAR DISPL, CW	90-R-100-MA-1-NN-80-R-3-F1-E-03-GBA-35-35-20	SERIES 90	S90-100PV
96-2673	PUMP-VAR DISPL, CCW	90-L-100-EA-1-BC-60-R-3-F1-E-03-GBA-42-42-20	SERIES 90	S90-100PV
96-2674	PUMP-VAR DISPL, CCW	90-L-100-EA-1-CD-80-S-4-F1-E-00-GBA-42-42-24	SERIES 90	S90-100PV
96-2675	PUMP-VAR DISPL, CCW	90-L-100-EA-1-CD-80-S-4-S1-E-00-GBA-42-42-24	SERIES 90	S90-100PV

96-2676	PUMP-VAR DISPL, CCW	90-L-100-EA-1-NN-80-S-4-S1-E-00-GBA-42-42-24	SERIES 90	S90-100PV
96-2677	PUMP-VAR DISPL, CCW	90-L-100-EA-1-NN-80-S-4-F1-E-00-GBA-42-42-24	SERIES 90	S90-100PV
96-2677C	PUMP-VAR DISPL, CCW 90PV100	90-L-100-EA-1-NN-80-S-4-F1-E-00-GBA-42-42-24	SERIES 90	S90-100PV
96-2678	PUMP-VAR DISPL, CCW	90-L-100-DC-1-NN-60-L-3-S1-E-GB-GBA-23-23-20	SERIES 90	S90-100PV
96-2679	PUMP-VAR DISPL, CW	90-R-100-EA-6-CD-60-R-4-F1-E-03-GBA-48-48-28	SERIES 90	S90-100PV
96-2680	PUMP-VAR DISPL, CCW	90-L-100-DC-1-NN-60-S-4-C7-E-GB-GBA-35-35-20	SERIES 90	S90-100PV
96-2681	PUMP-VAR DISPL, CCW	90-L-100-EA-1-BC-60-S-3-C7-E-04-GBA-29-29-24	SERIES 90	S90-100PV
96-2682	PUMP-VAR DISPL, CCW	90-L-100-EA-1-CD-60-P-3-F1-F-03-GBA-38-38-24	SERIES 90	S90-100PV
96-2683	PUMP-VAR DISPL, CCW	90-L-100-EA-1-NN-60-P-3-F1-F-03-GBA-38-38-24	SERIES 90	S90-100PV
96-2686	PUMP-VAR DISPL, CW	90-R-100-EA-1-BC-61-R-3-S1-E-02-GBA-38-38-24	SERIES 90	S90-100PV
96-2687	PUMP-VAR DISPL, CCW	90-L-100-EA-1-AB-60-R-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
96-2688	PUMP-VAR DISPL, CCW	90-L-100-EA-1-BC-60-L-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
96-2689	PUMP-VAR DISPL, CCW	90-L-100-EA-1-CD-60-R-3-S1-E-03-GBA-29-29-24	SERIES 90	S90-100PV
96-2690	PUMP-VAR DISPL, CW	90-R-100-EA-1-NN-61-L-3-F1-E-03-GBA-35-35-20	SERIES 90	S90-100PV
96-2691	PUMP-VAR DISPL, CCW	90-L-100-EA-1-NN-60-R-3-S1-E-03-GBA-29-29-24	SERIES 90	S90-100PV
96-2692	PUMP-VAR DISPL, CCW	90-L-100-EA-1-BC-60-R-4-F1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
96-2693	PUMP-VAR DISPL, CCW	90-L-100-EP-1-BB-60-P-3-F1-E-03-GBA-38-38-24	SERIES 90	S90-100PV
96-2694	PUMP-VAR DISPL, CW	90-R-100-EA-1-CD-60-P-3-T2-E-03-GBA-42-42-24	SERIES 90	S90-100PV
96-2697	PUMP-VAR DISPL, CW	90-R-100-EA-1-NN-60-R-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
96-2698	PUMP-VAR DISPL, CW	90-R-100-MA-1-NN-81-S-3-F1-E-03-GBA-42-42-20	SERIES 90	S90-100PV
96-2699	PUMP-VAR DISPL, CW	90-R-100-EA-1-BC-61-R-3-F1-F-00-GBA-42-42-28	SERIES 90	S90-100PV
96-2700	PUMP-VAR DISPL, CW	90-R-100-EA-1-BC-61-R-3-F1-F-00-GBA-20-20-24	SERIES 90	S90-100PV
96-2701	PUMP-VAR DISPL, CCW	90-L-100-EA-1-NN-60-P-3-S1-F-03-GBA-38-38-24	SERIES 90	S90-100PV
96-2702	PUMP-VAR DISPL, CCW	90-L-100-EA-1-BC-60-P-4-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
96-2703	PUMP-VAR DISPL, CW	90-R-100-EA-1-NN-60-R-3-F1-F-03-GBA-32-32-24	SERIES 90	S90-100PV
96-2704	PUMP-VAR DISPL, CW	90-R-100-EP-1-CD-60-L-3-F1-E-03-GBA-32-32-20	SERIES 90	S90-100PV
96-2705	PUMP-VAR DISPL, CW	90-R-100-EP-1-NN-60-L-3-S1-E-03-GBA-32-32-20	SERIES 90	S90-100PV
96-2706	PUMP-VAR DISPL, CCW	90-L-100-EA-1-BC-60-P-3-F1-E-03-GBA-35-35-20	SERIES 90	S90-100PV
96-2707	PUMP-VAR DISPL, CW	90-R-100-EA-1-NN-80-L-3-K3-E-03-GBA-35-35-24	SERIES 90	S90-100PV
96-2708	PUMP-VAR DISPL, CCW	90-L-100-EA-1-NN-60-R-3-S1-D-09-GBA-29-29-24	SERIES 90	S90-100PV
96-2709	PUMP-VAR DISPL, CCW	90-L-100-EA-1-CD-60-R-3-S1-D-09-GBA-29-29-24	SERIES 90	S90-100PV
96-2710	PUMP-VAR DISPL, CCW	90-L-100-EA-1-BC-60-R-3-S1-D-09-GBA-29-29-24	SERIES 90	S90-100PV
96-2711	PUMP-VAR DISPL, CW	90-R-100-EA-1-AB-60-R-3-S1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
96-2712	PUMP-VAR DISPL, CW	90-R-100-EA-1-NN-61-R-3-S1-E-00-GBA-42-42-24	SERIES 90	S90-100PV
96-2714	PUMP-VAR DISPL, CW	90-R-100-DD-1-NN-60-D-4-S1-L-GB-GBA-32-32-24	SERIES 90	S90-100PV
96-2715	PUMP-VAR DISPL, CCW	90-L-100-MA-1-AB-60-P-3-F1-E-03-GBA-38-38-24	SERIES 90	S90-100PV

96-2717	PUMP-VAR DISPL, CCW	90-L-100-MB-1-NN-80-S-3-F1-E-03-GBA-38-38-24	SERIES 90	S90-100PV
96-2718	PUMP-VAR DISPL, CCW	90-L-100-MB-1-NN-60-S-3-S1-E-03-GBA-32-32-24	SERIES 90	S90-100PV
96-2719	PUMP-VAR DISPL, CCW	90-L-100-EA-1-AB-60-R-4-F1-E-00-GBA-20-23-24	SERIES 90	S90-100PV
96-2720	PUMP-VAR DISPL, CCW	90-L-100-EA-1-AB-60-S-3-S1-E-03-GBA-32-32-24	SERIES 90	S90-100PV
96-2722	PUMP-VAR DISPL, CCW	90-L-100-EA-1-CD-60-S-3-F1-E-03-GBA-32-32-20	SERIES 90	S90-100PV
96-2723	PUMP-VAR DISPL, CW	90-R-100-MA-1-AB-61-S-3-K3-E-03-GBA-35-35-24	SERIES 90	S90-100PV
96-2724	PUMP-VAR DISPL, CCW	90-L-100-EA-1-CD-60-P-3-F1-F-03-GBA-14-14-20	SERIES 90	S90-100PV
96-2725	PUMP-VAR DISPL, CCW	90-L-100-MB-1-NN-60-S-3-F1-E-03-GBA-38-38-24	SERIES 90	S90-100PV
96-2728	PUMP-VAR DISPL, CW	90-R-100-MB-1-BC-61-L-3-F1-E-01-GBA-35-35-24	SERIES 90	S90-100PV
96-2730	PUMP-VAR DISPL, CW	90-R-100-EA-1-NN-60-P-3-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
96-2732	PUMP-VAR DISPL, CW	90-R-100-EA-1-CD-60-S-3-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
96-2733	PUMP-VAR DISPL, CW	90-R-100-MA-1-NN-80-R-4-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
96-2734	PUMP-VAR DISPL, CW	90-R-100-EP-1-AB-60-L-3-F1-E-00-GBA-32-32-20	SERIES 90	S90-100PV
96-2736	PUMP-VAR DISPL, CW	90-R-100-MA-1-CD-60-S-3-F1-E-03-GBA-20-20-24	SERIES 90	S90-100PV
96-2738	PUMP-VAR DISPL, CW	90-R-100-MB-1-CD-60-S-3-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
96-2739	PUMP-VAR DISPL, CW	90-R-100-MA-1-CD-60-S-3-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
96-2740	PUMP-VAR DISPL, CW	90-R-100-EA-1-AB-60-P-3-T2-E-00-GBA-32-32-24	SERIES 90	S90-100PV
96-2741	PUMP-VAR DISPL, CW	90-R-100-MA-1-NN-60-S-3-F1-E-03-GBA-38-38-20	SERIES 90	S90-100PV
96-2742	PUMP-VAR DISPL, CW	90-R-100-MA-1-AB-60-L-3-F1-E-03-GBA-20-20-20	SERIES 90	S90-100PV
96-2745	PUMP-VAR DISPL, CW	90-R-100-EA-1-AB-60-L-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
96-2746	PUMP-VAR DISPL, CW	90-R-100-EA-1-BC-60-L-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
96-2749	PUMP-VAR DISPL, CW	90-R-100-MB-1-CD-60-S-3-F1-E-03-GBA-35-35-20	SERIES 90	S90-100PV
96-2750	PUMP-VAR DISPL, CW	90-R-100-MA-1-BC-60-R-3-C7-E-03-GBA-42-42-20	SERIES 90	S90-100PV
96-2751	PUMP-VAR DISPL, CW	90-R-100-MA-1-CD-80-S-3-C7-E-03-GBA-32-32-24	SERIES 90	S90-100PV
96-2752	PUMP-VAR DISPL, CW	90-R-100-MA-1-NN-80-S-3-F1-E-03-GBA-32-32-24	SERIES 90	S90-100PV
96-2752C	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-NN-80-S-3-F1-E-03-GBA-32-32-24	SERIES 90	S90-100PV
96-2753	PUMP-VAR DISPL, CW	90-R-100-MB-1-BC-60-L-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
96-2754	PUMP-VAR DISPL, CW	90-R-100-MA-1-NN-60-S-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
96-2755	PUMP-VAR DISPL, CW	90-R-100-EA-1-NN-60-R-3-S1-F-03-GBA-20-20-24	SERIES 90	S90-100PV
96-2756	PUMP-VAR DISPL, CW	90-R-100-MA-1-BC-60-S-3-C7-E-04-GBA-42-42-24	SERIES 90	S90-100PV
96-2757	PUMP-VAR DISPL, CW	90-R-100-MA-1-NN-61-S-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
96-2758	PUMP-VAR DISPL, CW	90-R-100-EA-1-AB-80-R-3-S1-E-03-GBA-38-38-20	SERIES 90	S90-100PV
96-2759	PUMP-VAR DISPL, CW	90-R-100-CB-1-NN-80-S-3-S1-E-00-GBA-35-35-20	SERIES 90	S90-100PV
96-2760	PUMP-VAR DISPL, CW	90-R-100-EA-1-AB-60-S-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
96-2761	PUMP-VAR DISPL, CW	90-R-100-MA-1-BC-61-S-3-C7-F-00-GBA-29-29-28	SERIES 90	S90-100PV
96-2764	PUMP-VAR DISPL, CW	90-R-100-EA-1-CD-60-S-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV

96-2766	PUMP-VAR DISPL, CW	90-R-100-EP-1-AB-61-S-4-F1-E-03-GBA-38-38-20	SERIES 90	S90-100PV
96-2767	PUMP-VAR DISPL, CW	90-R-100-EA-1-NN-61-R-4-S1-E-03-FAB-35-35-24	SERIES 90	S90-100PV
96-2770	PUMP-VAR DISPL, CW	90-R-100-EA-1-NN-61-R-3-S1-E-03-FAB-35-35-24	SERIES 90	S90-100PV
96-2771	PUMP-VAR DISPL, CW	90-R-100-EP-1-AB-60-L-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
96-2773	PUMP-VAR DISPL, CW	90-R-100-EP-1-NN-60-S-3-S1-E-00-GBA-35-35-24	SERIES 90	S90-100PV
96-2774	PUMP-VAR DISPL, CW	90-R-100-EP-2-NN-60-L-F-F1-E-33-GBA-29-29-20	SERIES 90	S90-100PV
96-2775	PUMP-VAR DISPL, CW	90-R-100-EP-2-AB-60-L-F-F1-E-33-GBA-29-29-20	SERIES 90	S90-100PV
96-2776	PUMP-VAR DISPL, CW	90-R-100-EP-2-CD-60-L-F-F1-E-33-GBA-29-29-20	SERIES 90	S90-100PV
96-2777	PUMP-VAR DISPL, CW	90-R-100-HK-1-NN-60-S-4-F1-E-03-GBA-42-42-28	SERIES 90	S90-100PV
96-2778	PUMP-VAR DISPL, CW	90-R-100-HK-1-CD-60-L-4-F1-E-03-GBA-38-38-24	SERIES 90	S90-100PV
96-2779	PUMP-VAR DISPL, CW	90-R-100-HK-1-NN-60-R-3-F1-F-04-GBA-35-35-24	SERIES 90	S90-100PV
96-2780	PUMP-VAR DISPL, CW	90-R-100-HF-1-BC-60-S-4-F1-E-03-GBA-20-20-20	SERIES 90	S90-100PV
96-2781	PUMP-VAR DISPL, CW	90-R-100-HM-1-NN-60-P-3-F1-E-04-GBA-32-32-24	SERIES 90	S90-100PV
96-2782	PUMP-VAR DISPL, CW	90-R-100-EA-1-NN-61-L-4-F1-E-03-GBA-14-14-24	SERIES 90	S90-100PV
96-2783	PUMP-VAR DISPL, CW	90-R-100-MA-1-NN-60-S-3-C7-E-02-GBA-42-42-24	SERIES 90	S90-100PV
96-2783C	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-NN-60-S-3-C7-E-02-GBA-42-42-24	SERIES 90	S90-100PV
96-2784	PUMP-VAR DISPL, CW	90-R-100-MA-1-NN-60-L-3-F1-E-03-FAB-38-38-24	SERIES 90	S90-100PV
96-2785	PUMP-VAR DISPL, CW	90-R-100-EP-1-AB-81-S-4-F1-E-03-GBA-38-38-20	SERIES 90	S90-100PV
96-2786	PUMP-VAR DISPL, CW	90-R-100-HM-6-NN-80-S-4-K3-F-03-GBA-45-45-24	SERIES 90	S90-100PV
96-2787	PUMP-VAR DISPL, CW	90-R-100-MA-1-BC-61-S-3-C7-F-00-GBA-20-29-24	SERIES 90	S90-100PV
96-2788	PUMP-VAR DISPL, CW	90-R-100-MA-1-BC-61-S-3-C7-F-00-GBA-29-29-24	SERIES 90	S90-100PV
96-2789	PUMP-VAR DISPL, CW	90-R-100-MA-1-CD-60-S-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
96-2790	PUMP-VAR DISPL, CW	90-R-100-EA-1-NN-60-S-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
96-2793	PUMP-VAR DISPL, CW	90-R-100-EA-1-NN-60-S-3-T2-E-00-GBA-23-23-24	SERIES 90	S90-100PV
96-2795	PUMP-VAR DISPL, CW	90-R-100-EA-1-CD-80-L-3-F1-F-00-GBA-29-29-24	SERIES 90	S90-100PV
96-2796	PUMP-VAR DISPL, CW	90-R-100-EP-1-AB-60-L-F-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
96-2797	PUMP-VAR DISPL, CW	90-R-100-EP-1-NN-60-L-F-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
96-2798	PUMP-VAR DISPL, CW	90-R-100-MB-1-BC-60-R-F-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
96-2799	PUMP-VAR DISPL, CW	90-R-100-EA-1-CD-60-P-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
96-2800	PUMP-VAR DISPL, CW	90-R-100-MA-1-NN-60-S-3-K3-E-03-GBA-35-35-24	SERIES 90	S90-100PV
96-2802	PUMP-VAR DISPL, CW	90-R-100-EA-1-NN-60-S-3-K3-E-03-GBA-35-35-24	SERIES 90	S90-100PV
96-2803	PUMP-VAR DISPL, CW	90-R-100-MA-1-BC-60-S-3-C7-F-06-FAB-29-29-28	SERIES 90	S90-100PV
96-2805	PUMP-VAR DISPL, CW	90-R-100-MA-1-NN-60-S-3-F1-D-03-GBA-35-35-24	SERIES 90	S90-100PV
96-2808	PUMP-VAR DISPL, CW	90-R-100-HK-1-NN-60-S-3-F1-E-03-GBA-17-17-20	SERIES 90	S90-100PV
96-2809	PUMP-VAR DISPL, CW	90-R-100-EA-1-BC-61-S-4-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
96-2810	PUMP-VAR DISPL, CW	90-R-100-MA-1-NN-60-L-3-F1-E-03-FAC-38-38-24	SERIES 90	S90-100PV

96-2816	PUMP-VAR DISPL, CW	90-R-100-MB-1-BC-60-S-4-F1-F-02-GBA-38-38-24	SERIES 90	S90-100PV
96-2817	PUMP-VAR DISPL, CW	90-R-100-CA-1-NN-61-L-4-F1-E-00-GBA-14-14-24	SERIES 90	S90-100PV
96-2818	PUMP-VAR DISPL, CW	90-R-100-MA-1-NN-60-S-4-S1-E-03-GBA-23-23-24	SERIES 90	S90-100PV
96-2822	PUMP-VAR DISPL, CW	90-R-100-EA-1-BC-60-S-3-C7-F-06-FAB-29-29-28	SERIES 90	S90-100PV
96-2824	PUMP-VAR DISPL, CW	90-R-100-MB-1-NN-60-L-3-F1-E-03-GBA-14-26-28	SERIES 90	S90-100PV
96-2825	PUMP-VAR DISPL, CW	90-R-100-HF-1-BC-80-L-4-F1-F-01-FAD-38-38-24	SERIES 90	S90-100PV
96-2826	PUMP-VAR DISPL, CW	90-R-100-MA-1-CD-60-S-4-T2-E-03-FAA-35-35-24	SERIES 90	S90-100PV
96-2827	PUMP-VAR DISPL, CW	90-R-100-MA-1-BB-60-S-4-S1-E-03-FAA-35-35-24	SERIES 90	S90-100PV
96-2828	PUMP-VAR DISPL, CW	90-R-100-EA-1-BC-60-S-3-F1-F-00-GBA-38-38-24	SERIES 90	S90-100PV
96-2829	PUMP-VAR DISPL, CW	90-R-100-EA-1-CD-80-L-3-S1-E-00-GBA-35-35-24	SERIES 90	S90-100PV
96-2830	PUMP-VAR DISPL, CW	90-R-100-EP-1-NN-80-P-4-S1-E-03-GBA-29-29-24	SERIES 90	S90-100PV
96-2831	PUMP-VAR DISPL, CW	90-R-100-MB-1-CD-60-S-4-F1-F-02-GBA-38-38-24	SERIES 90	S90-100PV
96-2832	PUMP-VAR DISPL, CW	90-R-100-HF-1-AB-81-R-3-S1-F-00-GBA-35-35-24	SERIES 90	S90-100PV
96-2833	PUMP-VAR DISPL, CW	90-R-100-EP-1-BB-60-R-3-S1-E-00-GBA-42-42-24	SERIES 90	S90-100PV
96-2836	PUMP-VAR DISPL, CW	90-R-100-MB-1-BC-60-S-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
96-2837	PUMP-VAR DISPL, CW	90-R-100-EA-1-CD-60-R-3-F1-E-03-GBA-26-26-24	SERIES 90	S90-100PV
96-2838	PUMP-VAR DISPL, CW	90-R-100-HF-1-BC-60-R-3-F1-E-03-GBA-32-32-24	SERIES 90	S90-100PV
96-2839	PUMP-VAR DISPL, CW	90-R-100-MC-1-CD-60-S-3-F1-E-02-GBA-35-35-20	SERIES 90	S90-100PV
96-2840	PUMP-VAR DISPL, CW	90-R-100-MC-1-CD-60-S-3-F1-E-01-GBA-35-35-20	SERIES 90	S90-100PV
96-2841	PUMP-VAR DISPL, CW	90-R-100-MA-1-NN-60-L-3-K3-E-03-GBA-35-35-24	SERIES 90	S90-100PV
96-3154	MOTOR-FIXED DISPL, 90MF100	90-M-100-NC-0-N-8-N-0-S1-N-00-NNN-00-00-00	SERIES 90	S90-100MF
962-000074	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HS-1-BC-60-R-3-F1-F-03-GBA-42-42-30	SERIES 90	S90-100PV
962-000075	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-BB-60-R-3-F1-F-03-GBA-42-42-30	SERIES 90	S90-100PV
962-000076	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HS-1-NN-60-R-3-F1-F-03-GBA-42-42-30	SERIES 90	S90-100PV
962-000080	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-NN-60-R-3-F1-F-03-GBA-42-42-30	SERIES 90	S90-100PV
962-000094	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-CD-80-S-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
962-000095	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-NN-80-S-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9621050	PUMP-VAR DISPL, CCW	90-L-100-CA-1-BB-60-S-3-S1-E-00-GBA-17-17-20	SERIES 90	S90-100PV
9621051	PUMP-VAR DISPL CCW 90PV100	90-L-100-MS-1-AB-60-S-3-F1-E-04-FAD-42-42-24	SERIES 90	S90-100PV
9621150	PUMP-VAR DISPL, CCW	90-L-100-EA-1-CD-60-S-4-F1-E-03-GBA-23-23-20	SERIES 90	S90-100PV
9621152	PUMP-VAR DISPL, CCW	90-L-100-MA-1-AB-80-S-3-T2-F-03-GBA-38-38-20	SERIES 90	S90-100PV
9621153	PUMP-VAR DISPL, CCW	90-L-100-EA-1-BC-60-S-3-F1-E-03-GBA-20-20-24	SERIES 90	S90-100PV
9621154	PUMP-VAR DISPL, CCW	90-L-100-EP-1-CD-60-P-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9621155	PUMP-VAR DISPL, CCW	90-L-100-EP-1-NN-60-P-3-F1-E-03-GBA-32-32-24	SERIES 90	S90-100PV
9621156	PUMP-VAR DISPL, CCW	90-L-100-EX-1-AB-60-S-3-F1-E-03-GBA-29-29-24	SERIES 90	S90-100PV
9621157	PUMP-VAR DISPL, CCW	90-L-100-MA-6-AC-60-S-3-K3-E-03-GBA-45-45-24	SERIES 90	S90-100PV

9621158	PUMP-VAR DISPL, CCW	90-L-100-EP-1-NN-80-P-3-F1-E-03-GBA-32-14-20	SERIES 90	S90-100PV
9621159	PUMP-VAR DISPL, CCW	90-L-100-EA-1-AB-80-S-3-T2-F-03-GBA-38-38-20	SERIES 90	S90-100PV
9621160	PUMP-VAR DISPL, CCW	90-L-100-EP-1-NN-80-R-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
9621161	PUMP-VAR DISPL, CCW	90-L-100-EP-1-CD-60-P-3-F1-D-03-GBA-35-35-24	SERIES 90	S90-100PV
9621162	PUMP-VAR DISPL, CCW	90-L-100-EX-1-NN-60-S-3-F1-F-03-GBA-29-29-24	SERIES 90	S90-100PV
9621163	PUMP-VAR DISPL, CCW	90-L-100-MB-1-BC-60-R-4-S1-E-03-GBA-32-32-24	SERIES 90	S90-100PV
9621164	PUMP-VAR DISPL, CCW	90-L-100-MA-1-AB-60-L-3-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9621165	PUMP-VAR DISPL, CCW	90-L-100-MB-1-BB-60-S-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9621166	PUMP-VAR DISPL, CCW	90-L-100-EA-1-NN-60-P-3-F1-F-00-GBA-35-35-28	SERIES 90	S90-100PV
9621167	PUMP-VAR DISPL, CCW	90-L-100-MA-1-NN-80-S-3-F1-F-03-GBA-35-35-20	SERIES 90	S90-100PV
9621168	PUMP-VAR DISPL, CCW	90-L-100-MA-1-AB-80-S-3-F1-F-03-GBA-35-35-20	SERIES 90	S90-100PV
9621169	PUMP-VAR DISPL, CCW	90-L-100-MB-1-AB-80-S-3-F1-F-03-GBA-35-35-20	SERIES 90	S90-100PV
9621170	PUMP-VAR DISPL, CCW	90-L-100-MB-1-NN-80-S-3-F1-F-03-GBA-35-35-20	SERIES 90	S90-100PV
9621171	PUMP-VAR DISPL, CCW	90-L-100-EP-1-AB-80-S-3-F1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
9621172	PUMP-VAR DISPL, CCW	90-L-100-HM-1-NN-60-L-3-F1-E-04-GBA-32-32-24	SERIES 90	S90-100PV
9621173	PUMP-VAR DISPL, CCW	90-L-100-HK-1-NN-60-P-3-F1-E-03-GBA-38-38-24	SERIES 90	S90-100PV
9621174	PUMP-VAR DISPL, CCW	90-L-100-EA-1-BC-60-R-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9621176	PUMP-VAR DISPL, CCW	90-L-100-EA-1-NN-60-S-3-S1-E-03-GBA-32-32-24	SERIES 90	S90-100PV
9621177	PUMP-VAR DISPL, CCW	90-L-100-EA-1-CD-80-L-3-F1-E-03-FAC-38-38-24	SERIES 90	S90-100PV
9621179	PUMP-VAR DISPL, CCW	90-L-100-EP-1-BC-80-S-3-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9621180	PUMP-VAR DISPL, CCW	90-L-100-EP-1-BB-80-S-3-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9621182	PUMP-VAR DISPL, CCW	90-L-100-EP-1-NN-60-S-3-K3-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9621183	PUMP-VAR DISPL, CCW	90-L-100-HF-1-CD-80-R-4-F1-L-03-GBA-42-42-24	SERIES 90	S90-100PV
9621184	PUMP-VAR DISPL, CCW	90-L-100-HF-1-NN-80-R-4-S1-L-03-GBA-42-42-24	SERIES 90	S90-100PV
9621185	PUMP-VAR DISPL, CCW	90-L-100-DC-1-BB-60-L-3-F1-E-G4-GBA-23-23-24	SERIES 90	S90-100PV
9621186	PUMP-VAR DISPL, CCW	90-L-100-EP-1-NN-80-S-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9621187	PUMP-VAR DISPL, CCW	90-L-100-EP-1-BC-60-S-4-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9621188	PUMP-VAR DISPL, CCW	90-L-100-EA-1-CD-80-S-3-F1-E-03-GBA-26-26-24	SERIES 90	S90-100PV
9621189	PUMP-VAR DISPL, CCW	90-L-100-EA-1-NN-80-S-3-S1-E-03-GBA-26-26-24	SERIES 90	S90-100PV
9621190	PUMP-VAR DISPL, CCW	90-L-100-EP-1-CD-80-R-3-F1-E-04-GBA-42-42-24	SERIES 90	S90-100PV
9621191	PUMP-VAR DISPL, CCW	90-L-100-EA-1-BC-60-R-3-F1-E-03-GBA-07-45-24	SERIES 90	S90-100PV
9621193	PUMP-VAR DISPL, CCW	90-L-100-MA-1-AB-60-P-3-T2-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9621194	PUMP-VAR DISPL, CCW	90-L-100-MA-1-NN-80-S-3-F1-E-03-GBA-38-38-24	SERIES 90	S90-100PV
9621195	PUMP-VAR DISPL, CCW	90-L-100-EP-1-CD-80-S-3-F1-E-03-GBA-35-35-20	SERIES 90	S90-100PV
9621196	PUMP-VAR DISPL, CCW	90-L-100-MA-1-NN-60-S-3-K3-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9621197	PUMP-VAR DISPL, CCW	90-L-100-EA-1-AB-60-S-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV

9621198	PUMP-VAR DISPL, CCW	90-L-100-EA-1-NN-80-S-3-S1-E-03-GBA-38-38-20	SERIES 90	S90-100PV
9621199	PUMP-VAR DISPL, CCW	90-L-100-EA-1-CD-80-S-3-F1-E-03-GBA-38-38-20	SERIES 90	S90-100PV
9621200	PUMP-VAR DISPL, CCW	90-L-100-EP-1-NN-60-S-3-S1-E-00-GBA-42-42-24	SERIES 90	S90-100PV
9621201	PUMP-VAR DISPL, CCW	90-L-100-EA-1-AC-60-P-3-S1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
9621202	PUMP-VAR DISPL, CCW	90-L-100-EA-1-AB-60-P-3-S1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
9621204	PUMP-VAR DISPL, CCW	90-L-100-EA-1-CD-60-L-3-F1-D-04-FAD-38-38-24	SERIES 90	S90-100PV
9621205	PUMP-VAR DISPL, CCW	90-L-100-EA-1-NN-60-L-3-F1-D-04-FAD-38-38-24	SERIES 90	S90-100PV
9621206	PUMP-VAR DISPL, CCW	90-L-100-EA-1-AB-60-P-4-S1-E-01-GBA-23-23-24	SERIES 90	S90-100PV
9621207	PUMP-VAR DISPL, CCW	90-L-100-EA-1-BC-60-P-4-F1-E-03-GBA-26-26-24	SERIES 90	S90-100PV
9621208	PUMP-VAR DISPL, CCW	90-L-100-HF-1-NN-60-R-3-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9621209	PUMP-VAR DISPL, CCW	90-L-100-EP-1-CD-60-P-3-F1-E-03-GBA-38-38-24	SERIES 90	S90-100PV
9621210	PUMP-VAR DISPL, CCW	90-L-100-EA-1-BB-60-P-3-F1-F-03-GBA-29-29-20	SERIES 90	S90-100PV
9621211	PUMP-VAR DISPL, CCW	90-L-100-MB-1-NN-60-S-3-S1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
9621212	PUMP-VAR DISPL, CCW	90-L-100-MA-1-NN-60-S-3-S1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
9621213	PUMP-VAR DISPL, CCW	90-L-100-EA-1-BC-60-P-3-S1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
9621214	PUMP-VAR DISPL, CCW	90-L-100-MB-1-AB-60-R-3-F1-E-03-FAD-42-42-24	SERIES 90	S90-100PV
9621215	PUMP-VAR DISPL, CCW	90-L-100-MB-1-NN-60-R-3-F1-E-03-FAD-42-42-24	SERIES 90	S90-100PV
9621216	PUMP-VAR DISPL, CCW	90-L-100-EA-1-BC-60-P-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
9621217	PUMP-VAR DISPL, CCW	90-L-100-EA-1-AB-60-L-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9621218	PUMP-VAR DISPL, CCW	90-L-100-M9-1-NN-61-S-3-C7-D-02-FAB-35-35-20	SERIES 90	S90-100PV
9621220	PUMP-VAR DISPL, CCW	90-L-100-EA-2-BC-60-R-3-F1-F-00-GBA-42-42-24	SERIES 90	S90-100PV
9621221	PUMP-VAR DISPL, CCW	90-L-100-EA-1-BC-80-R-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9621222	PUMP-VAR DISPL CCW 90PV100	90-L-100-EA-1-AB-80-P-3-F1-E-00-FAD-42-42-24	SERIES 90	S90-100PV
9621223	PUMP-VAR DISPL CCW 90PV100	90-L-100-EA-1-CD-80-P-3-F1-E-00-FAD-42-42-24	SERIES 90	S90-100PV
9621225	PUMP-VAR DISPL, CCW	90-L-100-EP-1-AB-60-S-3-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9621226	PUMP-VAR DISPL, CCW	90-L-100-MA-1-BC-60-R-4-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9621227	PUMP-VAR DISPL, CCW	90-L-100-EA-1-NN-60-P-3-S1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
9621228	PUMP-VAR DISPL, CCW	90-L-100-EP-1-NN-60-L-F-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9621230	PUMP-VAR DISPL, CCW	90-L-100-MV-1-NN-80-S-3-F1-E-02-GBA-32-32-24	SERIES 90	S90-100PV
9621231	PUMP-VAR DISPL, CCW	90-L-100-MV-1-CD-80-S-3-F1-E-02-GBA-32-32-24	SERIES 90	S90-100PV
9621232	PUMP-VAR DISPL, CCW	90-L-100-MA-1-NN-61-S-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9621233	PUMP-VAR DISPL, CCW	90-L-100-M1-1-NN-60-X-3-F1-E-01-GBA-23-23-24	SERIES 90	S90-100PV
9621234	PUMP-VAR DISPL, CCW	90-L-100-MA-1-BC-60-L-3-F1-E-01-GBA-23-23-24	SERIES 90	S90-100PV
9621235	PUMP-VAR DISPL, CCW	90-L-100-HS-1-AB-60-L-3-F1-E-04-GBA-35-35-24	SERIES 90	S90-100PV
9621236	PUMP-VAR DISPL, CCW	90-L-100-EA-1-BB-60-S-3-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9621237	PUMP-VAR DISPL, CCW	90-L-100-EA-1-NN-60-S-3-F1-F-03-GBA-23-23-24	SERIES 90	S90-100PV

9621238	PUMP-VAR DISPL, CCW	90-L-100-EP-1-BB-60-L-3-F1-E-04-GBA-35-35-20	SERIES 90	S90-100PV
9621239	PUMP-VAR DISPL, CCW	90-L-100-EP-1-BC-80-R-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
9621240	PUMP-VAR DISPL, CCW	90-L-100-MA-1-AB-60-P-3-F1-F-02-GFK-35-35-20	SERIES 90	S90-100PV
9621243	PUMP-VAR DISPL, CCW	90-L-100-EA-1-NN-80-P-3-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9621244	PUMP-VAR DISPL, CCW	90-L-100-MB-1-NN-60-P-3-F1-E-03-GBA-35-35-20	SERIES 90	S90-100PV
9621245	PUMP-VAR DISPL, CCW	90-L-100-HF-1-CD-80-L-3-S1-F-00-GBA-23-23-24	SERIES 90	S90-100PV
9621246	PUMP-VAR DISPL, CCW	90-L-100-MT-1-AB-60-P-3-F1-F-02-GFK-35-35-20	SERIES 90	S90-100PV
9621247	PUMP-VAR DISPL, CCW	90-L-100-EA-1-NN-60-P-3-F1-E-03-FAD-42-42-24	SERIES 90	S90-100PV
9621250	PUMP-VAR DISPL, CCW	90-L-100-EA-1-BC-60-S-3-F1-E-00-GBA-23-23-24	SERIES 90	S90-100PV
9621252	PUMP-VAR DISPL, CCW	90-L-100-HK-1-NN-60-S-3-F1-E-03-GBA-32-32-20	SERIES 90	S90-100PV
9621253	PUMP-VAR DISPL, CCW	90-L-100-DC-1-NN-60-L-3-F1-E-G4-GBA-23-23-20	SERIES 90	S90-100PV
9621254	PUMP-VAR DISPL, CCW	90-L-100-MA-1-NN-80-S-3-T2-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9621254C	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MA-1-NN-80-S-3-T2-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9621255	PUMP-VAR DISPL, CCW	90-L-100-EA-1-NN-61-S-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9621256	PUMP-VAR-DISPL CCW 90PV100	90-L-100-MS-1-AB-80-P-3-F1-E-04-FAD-42-42-24	SERIES 90	S90-100PV
9621257	PUMP-VAR-DISPL CCW 90PV100	90-L-100-MS-1-CD-80-P-3-F1-E-04-FAD-42-42-24	SERIES 90	S90-100PV
9621258	PUMP-VAR DISPL, CCW	90-L-100-EA-1-BC-60-S-3-S1-E-00-GBA-23-23-24	SERIES 90	S90-100PV
9621259	PUMP-VAR DISPL, CCW	90-L-100-HS-1-NN-60-R-3-F1-F-04-GBA-35-35-24	SERIES 90	S90-100PV
9621260	PUMP-VAR DISPL, CCW	90-L-100-HF-6-NN-60-S-3-F1-E-03-GBA-45-45-24	SERIES 90	S90-100PV
9621261	PUMP-VAR DISPL, CCW	90-L-100-EA-1-AB-60-P-3-S1-F-22-GBA-42-42-24	SERIES 90	S90-100PV
9621262	PUMP-VAR DISPL, CCW	90-L-100-EA-1-NN-60-L-3-S1-D-04-FAD-38-38-24	SERIES 90	S90-100PV
9621263	PUMP-VAR DISPL, CCW	90-L-100-CB-1-NN-80-S-3-F1-E-00-FAC-38-38-24	SERIES 90	S90-100PV
9621264	PUMP-VAR DISPL, CCW	90-L-100-MA-1-NN-80-D-3-TF-L-03-FAD-42-42-28	SERIES 90	S90-100PV
9621265	PUMP-VAR DISPL, CCW	90-L-100-EA-1-NN-60-L-4-F1-E-03-GBA-29-20-24	SERIES 90	S90-100PV
9621267	PUMP-VAR DISPL, CCW	90-L-100-EA-1-AB-60-P-4-F1-E-03-GBA-26-26-24	SERIES 90	S90-100PV
9621268	PUMP-VAR DISPL, CCW	90-L-100-EP-1-CD-80-P-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9621269	PUMP-VAR DISPL, CCW	90-L-100-MB-1-AB-61-P-3-T2-F-03-GBA-42-42-20	SERIES 90	S90-100PV
9621270	PUMP-VAR DISPL, CCW	90-L-100-EP-1-NN-61-P-4-S1-E-03-GBA-29-29-24	SERIES 90	S90-100PV
9621272	PUMP-VAR DISPL, CCW	90-L-100-MA-1-NN-80-P-3-T2-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9621273	PUMP-VAR DISPL, CCW	90-L-100-HS-1-NN-60-R-3-F1-E-04-GBA-35-35-24	SERIES 90	S90-100PV
9621274	PUMP-VAR DISPL, CCW	90-L-100-EA-1-CD-80-P-3-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9621275	PUMP-VAR DISPL, CCW	90-L-100-EA-1-NN-80-P-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9621276	PUMP-VAR DISPL, CCW	90-L-100-EP-1-BC-60-R-3-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9621277	PUMP-VAR DISPL, CCW	90-L-100-HF-1-CD-60-L-3-K3-E-03-GBA-42-42-20	SERIES 90	S90-100PV
9621278	PUMP-VAR DISPL CCW 90PV100	90-L-100-EA-1-CD-80-P-3-F1-D-00-FAD-42-42-24	SERIES 90	S90-100PV
9621279	PUMP-VAR-DISPL CCW 90PV100	90-L-100-EA-1-AB-80-P-3-F1-D-00-FAD-42-42-24	SERIES 90	S90-100PV

9621282	PUMP-VAR-DISPL CCW 90PV100	90-L-100-CB-1-AB-80-P-3-F1-E-00-FAD-42-42-24	SERIES 90	S90-100PV
9621283	PUMP-VAR-DISPL CCW 90PV100	90-L-100-CB-1-CD-80-P-3-F1-E-00-FAD-42-42-24	SERIES 90	S90-100PV
9621284	PUMP-VAR DISPL, CCW	90-L-100-EP-1-NN-60-S-3-F1-E-03-GBA-23-23-24	SERIES 90	S90-100PV
9621285	PUMP-VAR DISPL, CCW	90-L-100-KP-1-BB-80-R-3-F1-F-03-FAC-42-42-XX-B020	SERIES 90	S90-100PV
9621286	PUMP-VAR DISPL, CCW	90-L-100-MB-1-AB-60-P-3-K3-F-03-GBA-35-35-20	SERIES 90	S90-100PV
9621286C	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MB-1-AB-60-P-3-K3-F-03-GBA-35-35-20	SERIES 90	S90-100PV
9621287	PUMP-VAR DISPL, CCW	90-L-100-MA-1-BC-80-S-3-T2-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9621288	PUMP-VAR DISPL, CCW	90-L-100-HS-1-AB-80-L-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9621289	PUMP-VAR DISPL, CCW	90-L-100-HS-1-BC-80-L-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9621290	PUMP-VAR DISPL, CCW	90-L-100-HK-1-BC-60-R-3-F1-E-05-GBA-35-35-24	SERIES 90	S90-100PV
9621291	PUMP-VAR DISPL, CCW	90-L-100-HK-1-BC-60-R-3-F1-E-05-GBA-38-38-24	SERIES 90	S90-100PV
9621292	PUMP-VAR DISPL, CCW	90-L-100-EP-1-AB-80-S-4-F1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
9621293	PUMP-VAR DISPL, CCW	90-L-100-MB-1-CD-60-L-3-S1-E-03-GBA-38-38-20	SERIES 90	S90-100PV
9621294	PUMP-VAR DISPL, CCW	90-L-100-MA-1-BC-60-S-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9621297	PUMP-VAR DISPL, CCW	90-L-100-KP-1-BB-60-L-3-F1-E-04-GBA-35-35-20	SERIES 90	S90-100PV
9621298	PUMP-VAR DISPL, CCW	90-L-100-HF-1-BC-60-R-3-F1-E-05-GBA-35-35-24	SERIES 90	S90-100PV
9621299	PUMP-VAR DISPL, CCW	90-L-100-CA-1-BB-60-L-3-F1-E-00-GBA-23-23-24	SERIES 90	S90-100PV
9621301	PUMP-VAR DISPL, CCW	90-L-100-KP-1-AB-81-S-4-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9621302	PUMP-VAR DISPL, CCW	90-L-100-KP-1-NN-81-P-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9621303	PUMP-VAR DISPL, CCW	90-L-100-KP-1-CD-80-R-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9621304	PUMP-VAR DISPL, CCW	90-L-100-KP-1-BC-80-R-3-F1-F-00-GBA-29-29-24	SERIES 90	S90-100PV
9621304C	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-BC-80-R-3-F1-F-00-GBA-29-29-24	SERIES 90	S90-100PV
9621305	PUMP-VAR DISPL, CCW	90-L-100-KP-1-NN-80-R-3-F1-F-00-GBA-29-29-24	SERIES 90	S90-100PV
9621305C	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-NN-80-R-3-F1-F-00-GBA-29-29-24	SERIES 90	S90-100PV
9621306	PUMP-VAR DISPL, CCW	90-L-100-KP-1-CD-61-S-4-S1-E-03-GBA-29-29-24	SERIES 90	S90-100PV
9621308	PUMP-VAR DISPL, CCW	90-L-100-KA-1-NN-80-S-3-K3-E-03-GBA-23-23-24	SERIES 90	S90-100PV
9621310	PUMP-VAR DISPL, CCW	90-L-100-KA-1-AB-80-L-4-S1-F-03-GBA-23-23-24	SERIES 90	S90-100PV
9621311	PUMP-VAR DISPL, CCW	90-L-100-KA-1-BC-61-P-3-F1-E-00-GBA-35-35-24	SERIES 90	S90-100PV
9621312	PUMP-VAR DISPL, CCW	90-L-100-KA-2-CD-80-S-4-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9621313	PUMP-VAR DISPL, CCW	90-L-100-KA-2-NN-80-S-4-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9621314	PUMP-VAR DISPL, CCW	90-L-100-KA-1-AC-61-P-4-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9621315	PUMP-VAR DISPL, CCW	90-L-100-KP-1-AB-80-S-4-F1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
9621316	PUMP-VAR DISPL, CCW	90-L-100-KA-2-NN-80-S-3-S1-F-33-GBA-38-07-20	SERIES 90	S90-100PV
9621317	PUMP-VAR DISPL, CCW	90-L-100-KP-1-NN-60-P-3-T2-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9621318	PUMP-VAR DISPL, CCW	90-L-100-KP-1-NN-61-S-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9621319	PUMP-VAR DISPL, CCW	90-L-100-KA-1-NN-61-P-4-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV

9621320	PUMP-VAR DISPL, CCW	90-L-100-MA-1-AB-60-S-3-K3-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9621321	PUMP-VAR DISPL, CCW	90-L-100-KA-1-BC-60-R-4-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9621323	PUMP-VAR DISPL, CCW	90-L-100-KP-6-CD-60-S-3-T2-D-02-GBA-48-48-24	SERIES 90	S90-100PV
9621324	PUMP-VAR DISPL, CCW	90-L-100-HS-1-NN-60-R-4-F1-E-04-EEB-35-35-24	SERIES 90	S90-100PV
9621325	PUMP-VAR DISPL, CCW	90-L-100-KP-1-NN-80-S-3-S1-E-03-GBA-32-32-24	SERIES 90	S90-100PV
9621326	PUMP-VAR DISPL, CCW	90-L-100-MA-1-BC-60-S-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9621327	PUMP-VAR DISPL, CCW	90-L-100-KA-1-BC-60-R-4-F1-E-01-GBA-35-35-24	SERIES 90	S90-100PV
9621328	PUMP-VAR DISPL, CCW	90-L-100-KP-1-AC-80-S-3-S1-E-03-GBA-32-32-24	SERIES 90	S90-100PV
9621329	PUMP-VAR DISPL, CCW	90-L-100-MA-1-NN-60-D-3-F1-L-03-GBA-29-29-24	SERIES 90	S90-100PV
9621330	PUMP-VAR DISPL, CCW	90-L-100-KP-1-BC-60-R-4-F1-E-03-GBA-26-26-24	SERIES 90	S90-100PV
9621331	PUMP-VAR DISPL, CCW	90-L-100-KA-1-CD-60-L-3-F1-D-02-FAD-38-38-24	SERIES 90	S90-100PV
9621332	PUMP-VAR DISPL, CCW	90-L-100-KA-1-NN-60-L-3-S1-D-02-FAD-38-38-24	SERIES 90	S90-100PV
9621333	PUMP-VAR DISPL, CCW	90-L-100-MV-1-NN-80-S-3-S1-E-02-GBA-32-32-24	SERIES 90	S90-100PV
9621334	PUMP-VAR DISPL, CCW	90-L-100-KP-6-CD-60-S-3-T2-D-04-GBA-48-48-24	SERIES 90	S90-100PV
9621335	PUMP-VAR DISPL, CCW	90-L-100-KA-6-NN-60-S-3-F1-F-09-GBA-45-45-24	SERIES 90	S90-100PV
9621336	PUMP-VAR DISPL, CCW	90-L-100-HF-1-AB-80-R-4-T2-E-03-GBA-32-32-24	SERIES 90	S90-100PV
9621337	PUMP-VAR DISPL, CCW	90-L-100-KA-1-AB-80-P-3-F1-E-04-FAD-42-42-24	SERIES 90	S90-100PV
9621338	PUMP-VAR DISPL, CCW	90-L-100-KA-1-CD-80-P-3-F1-E-04-FAD-42-42-24	SERIES 90	S90-100PV
9621339	PUMP-VAR DISPL CCW 90PV100	90L100-KA-1-CD-80-P-3-F1-D-03-FAD-42-42-24	SERIES 90	S90-100PV
9621340	PUMP-VAR DISPL, CCW	90-L-100-KA-1-AB-80-P-3-F1-D-03-FAD-42-42-24	SERIES 90	S90-100PV
9621341	PUMP-VAR DISPL, CCW	90-L-100-KA-1-AB-60-P-4-K3-E-01-GBA-23-23-24	SERIES 90	S90-100PV
9621342	PUMP-VAR DISPL, CCW	90-L-100-MB-1-NN-80-L-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
9621343	PUMP-VAR DISPL, CCW	90-L-100-KP-1-NN-60-P-3-F1-F-03-GBA-38-38-24	SERIES 90	S90-100PV
9621344	PUMP-VAR DISPL, CCW	90-L-100-KA-1-NN-80-S-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9621345	PUMP-VAR DISPL, CCW	90-L-100-MA-1-AB-80-P-3-F1-E-03-GBA-38-38-24	SERIES 90	S90-100PV
9621346	PUMP-VAR DISPL, CCW	90-L-100-KA-1-BC-80-P-3-F1-E-03-FAD-42-42-24	SERIES 90	S90-100PV
9621347	PUMP-VAR DISPL, CCW	90-L-100-KA-1-CD-80-P-3-F1-E-03-FAD-42-42-24	SERIES 90	S90-100PV
9621348	PUMP-VAR DISPL, CCW	90-L-100-MB-1-CD-80-P-3-F1-E-03-FAD-42-42-24	SERIES 90	S90-100PV
9621349	PUMP-VAR DISPL, CCW	90-L-100-MB-1-BC-80-P-3-F1-E-03-FAD-42-42-24	SERIES 90	S90-100PV
9621350	PUMP-VAR DISPL, CCW	90-L-100-KA-1-AB-80-L-3-F1-E-03-GBA-20-20-20	SERIES 90	S90-100PV
9621351	PUMP-VAR DISPL, CCW	90-L-100-MA-1-NN-60-S-4-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9621352	PUMP-VAR DISPL, CCW	90-L-100-KP-1-CD-80-R-3-F1-F-03-GBA-26-26-24	SERIES 90	S90-100PV
9621353	PUMP-VAR DISPL, CCW	90-L-100-DC-1-BC-60-P-4-F1-E-GB-GBA-42-42-24	SERIES 90	S90-100PV
9621354	PUMP-VAR DISPL, CCW	90-L-100-KA-6-AB-60-P-3-T2-E-03-EBC-45-45-28	SERIES 90	S90-100PV
9621355	PUMP-VAR DISPL, CCW	90-L-100-KA-1-NN-60-P-3-F1-F-03-GBA-32-32-20	SERIES 90	S90-100PV
9621356	PUMP-VAR DISPL, CCW	90-L-100-KP-2-CD-80-R-3-F1-F-03-GBA-26-26-24	SERIES 90	S90-100PV

9621357	PUMP-VAR DISPL, CCW	90-L-100-MB-1-NN-60-L-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9621357C	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MB-1-NN-60-L-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9621358	PUMP-VAR DISPL, CCW	90-L-100-KA-1-AB-60-P-3-F1-F-22-GBA-42-42-24	SERIES 90	S90-100PV
9621359	PUMP-VAR DISPL, CCW	90-L-100-KA-1-BC-60-P-3-F1-F-22-GBA-42-42-24	SERIES 90	S90-100PV
9621360	PUMP-VAR DISPL, CCW	90-L-100-HF-1-CD-60-P-3-T2-E-03-GBA-42-42-20	SERIES 90	S90-100PV
9621361	PUMP-VAR DISPL, CCW	90-L-100-HF-1-CD-60-P-3-S1-E-03-GBA-42-42-20	SERIES 90	S90-100PV
9621362	PUMP-VAR DISPL, CCW	90-L-100-KA-1-BC-60-S-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9621363	PUMP-VAR DISPL, CCW	90-L-100-DD-1-CD-80-R-3-C7-F-G1-GBA-35-35-24	SERIES 90	S90-100PV
9621364	PUMP-VAR DISPL, CCW	90-L-100-KA-1-NN-60-P-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
9621365	PUMP-VAR DISPL, CCW	90-L-100-MA-1-NN-8G-D-3-TF-M-03-FAD-42-42-28	SERIES 90	S90-100PV
9621366	PUMP-VAR DISPL, CCW	90-L-100-KP-1-BC-60-P-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
9621367	PUMP-VAR DISPL, CCW	90-L-100-KP-1-NN-80-S-3-F1-E-03-GBA-35-35-20	SERIES 90	S90-100PV
9621368	PUMP-VAR DISPL, CCW	90-L-100-CB-1-AB-60-D-3-F1-L-00-FAD-42-42-24	SERIES 90	S90-100PV
9621369	PUMP-VAR DISPL, CCW	90-L-100-KA-1-CD-80-R-4-F1-E-03-GBA-35-35-20	SERIES 90	S90-100PV
9621370	PUMP-VAR DISPL, CCW	90-L-100-KA-1-AB-60-P-3-F1-F-03-GBA-32-32-20	SERIES 90	S90-100PV
9621371	PUMP-VAR DISPL, CCW	90-L-100-MA-1-NN-61-S-3-T2-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9621372	PUMP-VAR DISPL, CCW	90-L-100-DD-1-NN-80-R-3-S1-F-G1-GBA-35-35-24	SERIES 90	S90-100PV
9621373	PUMP-VAR DISPL, CCW	90-L-100-MA-1-CD-80-S-3-C7-E-00-GBA-35-35-20	SERIES 90	S90-100PV
9621374	PUMP-VAR DISPL, CCW	90-L-100-HS-1-NN-60-R-4-F1-E-05-FBC-32-32-28-F023	SERIES 90	S90-100PV
9621375	PUMP-VAR DISPL, CCW	90-L-100-HS-1-AB-60-R-3-F1-E-05-FAD-32-32-28	SERIES 90	S90-100PV
9621376	PUMP-VAR DISPL, CCW	90-L-100-CB-1-CD-80-R-3-F1-F-00-GBA-35-35-28	SERIES 90	S90-100PV
9621377	PUMP-VAR DISPL, CCW	90-L-100-KA-1-CD-60-P-3-F1-E-00-GBA-42-42-24	SERIES 90	S90-100PV
9621379	PUMP-VAR DISPL, CCW	90-L-100-KA-2-CD-80-S-3-F1-E-33-GBA-20-42-24	SERIES 90	S90-100PV
9621380	PUMP-VAR DISPL, CCW	90-L-100-MA-1-AB-60-P-3-K3-F-03-GBA-35-35-20	SERIES 90	S90-100PV
9621381	PUMP-VAR DISPL, CCW	90-L-100-KA-2-BC-60-R-4-F1-F-00-GBA-35-35-24	SERIES 90	S90-100PV
9621382	PUMP-VAR DISPL, CCW	90-L-100-KA-2-BC-60-R-3-F1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
9621383	PUMP-VAR DISPL, CCW	90-L-100-KA-2-BC-60-R-3-F1-F-00-GBA-42-42-24	SERIES 90	S90-100PV
9621384	PUMP-VAR DISPL, CCW	90-L-100-KP-1-BC-60-P-3-K3-E-00-EHA-23-23-24	SERIES 90	S90-100PV
9621385	PUMP-VAR DISPL, CCW	90-L-100-KA-1-BC-60-R-3-F1-E-03-GBA-07-45-24	SERIES 90	S90-100PV
9621386	PUMP-VAR DISPL, CCW	90-L-100-KA-6-CD-60-S-3-F1-F-09-GBA-45-45-24	SERIES 90	S90-100PV
9621387	PUMP-VAR DISPL, CCW	90-L-100-KA-6-NN-60-S-3-S1-F-09-GBA-45-45-24	SERIES 90	S90-100PV
9621388	PUMP-VAR DISPL, CCW	90-L-100-KA-1-CD-60-L-3-F1-E-03-GBA-38-38-24	SERIES 90	S90-100PV
9621389	PUMP-VAR DISPL, CCW	90-L-100-KA-1-BC-60-L-3-S1-E-03-GBA-38-38-24	SERIES 90	S90-100PV
9621390	PUMP-VAR DISPL, CCW	90-L-100-KA-1-BC-60-P-4-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9621391	PUMP-VAR DISPL, CCW	90-L-100-MB-1-AB-60-P-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
9621392	PUMP-VAR DISPL, CCW	90-L-100-HK-1-NN-80-S-3-S1-F-03-GBA-38-07-20	SERIES 90	S90-100PV

9621393	PUMP-VAR DISPL, CCW	90-L-100-HK-1-CD-80-S-3-S1-F-03-GBA-38-07-20	SERIES 90	S90-100PV
9621394	PUMP-VAR DISPL, CCW	90-L-100-HF-1-BB-60-S-3-F1-E-03-GBA-23-23-24	SERIES 90	S90-100PV
9621395	PUMP-VAR DISPL, CCW	90-L-100-KA-1-NN-60-R-3-F1-E-03-FAB-42-42-24	SERIES 90	S90-100PV
9621396	PUMP-VAR DISPL, CCW	90-L-100-KA-1-BB-60-R-3-F1-E-03-FAB-42-42-28	SERIES 90	S90-100PV
9621397	PUMP-VAR DISPL, CCW	90-L-100-KP-1-BC-60-R-4-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9621398	PUMP-VAR DISPL, CCW	90-L-100-KP-1-NN-65-R-3-F3-F-00-GBA-29-29-20	SERIES 90	S90-100PV
9621399	PUMP-VAR DISPL, CCW	90-L-100-MS-1-BC-60-P-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
9621400	PUMP-VAR DISPL, CCW	90-L-100-KP-1-AB-60-S-3-F1-E-03-GBA-29-29-24	SERIES 90	S90-100PV
9621401	PUMP-VAR DISPL, CCW	90-L-100-KP-2-BC-80-R-3-S1-F-03-GBA-26-29-24	SERIES 90	S90-100PV
9621402	PUMP-VAR DISPL, CCW	90-L-100-KP-1-CD-80-R-3-F1-F-03-GBA-29-29-24	SERIES 90	S90-100PV
9621403	PUMP-VAR DISPL, CCW	90-L-100-HF-1-AB-80-P-4-F1-E-03-GBA-32-32-24	SERIES 90	S90-100PV
9621404	PUMP-VAR DISPL, CCW	90-L-100-HF-1-AB-80-R-4-S1-E-00-GBA-29-29-24	SERIES 90	S90-100PV
9621405	PUMP-VAR DISPL, CCW	90-L-100-HK-1-AC-60-R-3-F1-E-05-GBA-35-35-24	SERIES 90	S90-100PV
9621406	PUMP-VAR DISPL, CCW	90-L-100-HK-1-AC-60-R-3-F1-E-05-GBA-38-38-24	SERIES 90	S90-100PV
9621407	PUMP-VAR DISPL, CCW	90-L-100-MS-1-CD-80-P-3-F1-E-03-FAD-42-42-24	SERIES 90	S90-100PV
9621408	PUMP-VAR DISPL, CCW	90-L-100-MS-1-BC-80-P-3-F1-E-03-FAD-42-42-24	SERIES 90	S90-100PV
9621409	PUMP-VAR DISPL, CCW	90-L-100-KP-1-BC-60-R-3-S1-E-03-GBA-38-38-24	SERIES 90	S90-100PV
9621410	PUMP-VAR DISPL, CCW	90-L-100-EP-7-CD-80-R-3-F1-E-00-GBA-45-45-24	SERIES 90	S90-100PV
9621411	PUMP-VAR DISPL, CCW	90-L-100-EP-7-NN-80-R-3-S1-E-00-GBA-45-45-24	SERIES 90	S90-100PV
9621412	PUMP-VAR DISPL, CCW	90-L-100-MV-1-AB-80-S-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9621413	PUMP-VAR DISPL, CCW	90-L-100-KP-1-NN-60-S-3-S1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
9621414	PUMP-VAR DISPL, CCW	90-L-100-KP-1-CD-80-L-3-F1-E-03-GBA-29-29-24	SERIES 90	S90-100PV
9621415	PUMP-VAR DISPL, CCW	90-L-100-KA-1-CD-60-S-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9621416	PUMP-VAR DISPL, CCW	90-L-100-MA-1-NN-80-S-3-C7-E-00-GBA-35-35-20	SERIES 90	S90-100PV
9621417	PUMP-VAR DISPL, CCW	90-L-100-MA-1-NN-80-S-3-C7-E-00-GFD-35-35-24	SERIES 90	S90-100PV
9621418	PUMP-VAR DISPL, CCW	90-L-100-MA-1-CD-80-S-3-C7-E-00-GBA-35-35-24	SERIES 90	S90-100PV
9621419	PUMP-VAR DISPL, CCW	90-L-100-KP-1-BB-60-S-3-F1-E-04-GBA-35-35-20	SERIES 90	S90-100PV
9621420	PUMP-VAR DISPL, CCW	90-L-100-KA-6-AB-60-P-3-T2-E-03-GBA-45-45-28	SERIES 90	S90-100PV
9621423	PUMP-VAR DISPL, CCW	90-L-100-KA-1-NN-60-S-3-F1-E-00-GBA-35-35-24	SERIES 90	S90-100PV
9621424	PUMP-VAR DISPL, CCW	90-L-100-KP-1-CD-80-R-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9621425	PUMP-VAR DISPL, CCW	90-L-100-MA-1-AB-80-P-3-T2-F-03-GBA-42-42-24	SERIES 90	S90-100PV
9621426	PUMP-VAR DISPL, CCW	90-L-100-KP-1-BC-60-R-3-F1-E-03-GBA-38-38-24	SERIES 90	S90-100PV
9621427	PUMP-VAR DISPL, CCW	90-L-100-HE-1-CD-80-R-3-F1-F-06-GBA-35-35-28	SERIES 90	S90-100PV
9621428	PUMP-VAR DISPL, CCW	90-L-100-KA-1-CD-60-S-3-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9621429	PUMP-VAR DISPL, CCW	90-L-100-HK-1-NN-60-S-3-S1-F-03-GBA-38-07-20	SERIES 90	S90-100PV
9621430	PUMP-VAR DISPL, CCW	90-L-100-HK-1-CD-60-S-3-S1-F-03-GBA-38-07-20	SERIES 90	S90-100PV

9621431	PUMP-VAR DISPL, CCW	90-L-100-ME-1-NN-80-S-3-F1-E-00-GBA-35-35-24	SERIES 90	S90-100PV
9621432	PUMP-VAR DISPL, CCW	90-L-100-KA-2-NN-80-R-3-S1-E-00-GBA-42-20-24	SERIES 90	S90-100PV
9621433	PUMP-VAR DISPL, CCW	90-L-100-KA-2-BB-80-R-3-S1-E-00-GBA-42-20-24	SERIES 90	S90-100PV
9621434	PUMP-VAR DISPL, CCW	90-L-100-KA-1-BC-80-R-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9621435	PUMP-VAR DISPL, CCW	90-L-100-KP-1-CD-80-S-3-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9621441	PUMP-VAR DISPL, CCW	90-L-100-MB-1-NN-60-S-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9621442	PUMP-VAR DISPL, CCW	90-L-100-KA-G-BC-60-P-3-S1-E-03-GBA-20-20-24	SERIES 90	S90-100PV
9621443	PUMP-VAR DISPL, CCW	90-L-100-KP-G-BC-60-S-3-T2-E-03-GBA-32-32-20	SERIES 90	S90-100PV
9621444	PUMP-VAR DISPL, CCW	90-L-100-CB-G-CD-60-S-3-F1-E-00-GBA-14-14-08	SERIES 90	S90-100PV
9621445	PUMP-VAR DISPL, CCW	90-L-100-CB-G-BC-60-S-3-S1-E-00-GBA-14-14-08	SERIES 90	S90-100PV
9621446	PUMP-VAR DISPL, CCW	90-L-100-KP-G-BC-60-S-3-S1-E-03-GBA-32-32-20	SERIES 90	S90-100PV
9621447	PUMP-VAR DISPL, CCW	90-L-100-KP-G-CD-60-S-3-F1-E-00-GBA-14-14-08	SERIES 90	S90-100PV
9621448	PUMP-VAR DISPL, CCW	90-L-100-KP-G-BC-60-S-3-S1-E-00-GBA-14-14-08	SERIES 90	S90-100PV
9621449	PUMP-VAR DISPL, CCW	90-L-100-KP-G-CD-80-P-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9621450	PUMP-VAR DISPL, CCW	90-L-100-KA-G-BC-60-S-3-F1-E-03-GBA-23-23-20	SERIES 90	S90-100PV
9621453	PUMP-VAR DISPL, CCW	90-L-100-EP-1-CD-60-S-3-F1-E-00-GBG-14-14-08	SERIES 90	S90-100PV
9621454	PUMP-VAR DISPL, CCW	90-L-100-EP-1-BC-60-S-3-S1-E-00-GBG-14-14-08	SERIES 90	S90-100PV
9621459	PUMP-VAR DISPL, CCW	90-L-100-MA-6-NN-8G-D-3-TF-M-03-FAD-45-45-28	SERIES 90	S90-100PV
9621500	PUMP-VAR DISPL, CW	90-R-100-EP-1-BB-61-R-4-T2-E-00-GBA-35-35-24	SERIES 90	S90-100PV
9621501	PUMP-VAR DISPL, CW	90-R-100-MB-1-BC-60-R-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9621502	PUMP-VAR DISPL, CW	90-R-100-EA-1-NN-60-L-3-F1-E-03-GBA-17-17-20	SERIES 90	S90-100PV
9621503	PUMP-VAR DISPL, CW	90-R-100-EA-1-CD-60-S-3-C7-E-03-FAB-38-38-24	SERIES 90	S90-100PV
9621504	PUMP-VAR DISPL, CW	90-R-100-EA-1-BC-60-S-3-S1-E-03-FAB-38-38-24	SERIES 90	S90-100PV
9621505	PUMP-VAR DISPL, CW	90-R-100-EA-1-CD-60-L-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9621506	PUMP-VAR DISPL, CW	90-R-100-EP-1-NN-61-R-4-T2-E-00-GBA-35-35-24	SERIES 90	S90-100PV
9621507	PUMP-VAR DISPL, CW	90-R-100-EA-1-NN-60-S-4-T2-F-05-GBA-35-35-24	SERIES 90	S90-100PV
9621508	PUMP-VAR DISPL, CW	90-R-100-HF-1-CD-60-P-3-S1-F-03-GBA-38-38-24	SERIES 90	S90-100PV
9621509	PUMP-VAR DISPL, CW	90-R-100-EP-1-BC-60-L-3-S1-E-03-GBA-32-32-20	SERIES 90	S90-100PV
9621510	PUMP-VAR DISPL, CW	90-R-100-EP-1-NN-80-S-3-F1-E-06-GBA-23-23-20	SERIES 90	S90-100PV
9621511	PUMP-VAR DISPL, CW	90-R-100-EP-1-NN-80-P-3-S1-E-03-GBA-26-26-20	SERIES 90	S90-100PV
9621512	PUMP-VAR DISPL, CW	90-R-100-MA-1-NN-60-S-3-F1-E-03-GBA-32-32-24	SERIES 90	S90-100PV
9621513	PUMP-VAR DISPL, CW	90-R-100-EP-1-NN-80-S-3-F1-F-06-GBA-23-23-20	SERIES 90	S90-100PV
9621514	PUMP-VAR DISPL, CW	90-R-100-EA-1-NN-60-L-4-F1-E-03-GBA-14-26-24	SERIES 90	S90-100PV
9621515	PUMP-VAR DISPL, CW	90-R-100-MB-1-BC-60-R-4-S1-E-02-GBA-20-20-20	SERIES 90	S90-100PV
9621516	PUMP-VAR DISPL, CW	90-R-100-EA-1-CD-60-R-4-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9621517	PUMP-VAR DISPL, CW	90-R-100-CB-1-NN-60-L-3-F1-E-00-FAC-38-38-24	SERIES 90	S90-100PV

9621518	PUMP-VAR DISPL, CW	90-R-100-HM-6-NN-80-S-4-K3-F-02-GBA-45-45-24	SERIES 90	S90-100PV
9621519	PUMP-VAR DISPL, CW	90-R-100-HF-1-BC-60-R-3-F1-E-00-GBA-29-29-24	SERIES 90	S90-100PV
9621520	PUMP-VAR DISPL, CW	90-R-100-HM-1-NN-60-L-3-F1-E-04-GBA-32-32-24	SERIES 90	S90-100PV
9621521	PUMP-VAR DISPL, CW	90-R-100-EA-1-BC-60-S-3-S1-E-00-GBA-23-23-24	SERIES 90	S90-100PV
9621522	PUMP-VAR DISPL, CW	90-R-100-EA-1-BB-60-S-3-S1-E-00-GBA-23-23-24	SERIES 90	S90-100PV
9621523	PUMP-VAR DISPL, CW	90-R-100-MB-1-BC-60-S-3-F1-E-03-GBA-32-32-24	SERIES 90	S90-100PV
9621524	PUMP-VAR DISPL, CW	90-R-100-EA-1-BC-60-S-3-F1-E-00-GBA-23-23-24	SERIES 90	S90-100PV
9621525	PUMP-VAR DISPL, CW	90-R-100-EA-1-BB-60-S-3-F1-E-00-GBA-23-23-24	SERIES 90	S90-100PV
9621526	PUMP-VAR DISPL, CW	90-R-100-EP-1-BC-80-P-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9621527	PUMP-VAR DISPL, CW	90-R-100-MB-1-BC-60-S-3-S1-F-03-GBA-35-35-20	SERIES 90	S90-100PV
9621528	PUMP-VAR DISPL, CW	90-R-100-EA-1-CD-80-L-3-K3-E-03-GBA-17-17-20	SERIES 90	S90-100PV
9621529	PUMP-VAR DISPL, CW	90-R-100-EA-1-BC-60-R-3-S1-E-02-GBA-38-38-24	SERIES 90	S90-100PV
9621533	PUMP-VAR DISPL, CW	90-R-100-EA-1-NN-80-S-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9621534	PUMP-VAR DISPL, CW	90-R-100-EP-1-BC-60-S-3-S1-E-03-GBA-32-32-24	SERIES 90	S90-100PV
9621535	PUMP-VAR DISPL, CW	90-R-100-EA-1-NN-60-L-3-F1-D-03-GBA-38-38-24	SERIES 90	S90-100PV
9621536	PUMP-VAR DISPL, CW	90-R-100-EP-1-CD-80-L-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9621537	PUMP-VAR DISPL, CW	90-R-100-DC-1-BB-60-L-3-F1-E-G4-GBA-23-23-24	SERIES 90	S90-100PV
9621538	PUMP-VAR DISPL, CW	90-R-100-EA-1-BC-60-S-4-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9621539	PUMP-VAR DISPL, CW	90-R-100-EA-1-CD-60-R-3-F1-E-03-GBA-32-32-20	SERIES 90	S90-100PV
9621540	PUMP-VAR DISPL, CW	90-R-100-EA-1-NN-60-R-3-S1-E-03-GBA-32-32-20	SERIES 90	S90-100PV
9621541	PUMP-VAR DISPL, CW	90-R-100-EP-1-NN-80-R-4-F1-F-00-FAD-35-45-24	SERIES 90	S90-100PV
9621542	PUMP-VAR DISPL, CW	90-R-100-EA-1-CD-61-S-4-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9621543	PUMP-VAR DISPL, CW	90-R-100-EA-1-NN-60-P-3-F1-E-05-GBA-42-42-24	SERIES 90	S90-100PV
9621544	PUMP-VAR DISPL, CW	90-R-100-MA-1-BC-60-P-3-F1-E-05-GBA-42-26-24	SERIES 90	S90-100PV
9621545	PUMP-VAR DISPL, CW	90-R-100-EA-1-NN-60-S-3-T2-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9621546	PUMP-VAR DISPL, CW	90-R-100-EA-1-NN-60-S-3-S1-E-03-FAB-35-35-24	SERIES 90	S90-100PV
9621547	PUMP-VAR DISPL, CW	90-R-100-MA-1-BC-60-P-3-F1-E-05-GBA-42-42-24	SERIES 90	S90-100PV
9621548	PUMP-VAR DISPL, CW	90-R-100-EA-1-AB-60-S-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9621549	PUMP-VAR DISPL, CW	90-R-100-MA-1-BC-80-S-3-F1-E-00-GBA-29-29-20	SERIES 90	S90-100PV
9621550	PUMP-VAR DISPL, CW	90-R-100-MA-1-NN-80-R-3-C7-E-03-GBA-35-35-20	SERIES 90	S90-100PV
9621551	PUMP-VAR DISPL, CW	90-R-100-MA-1-NN-80-L-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9621556	PUMP-VAR DISPL, CW	90-R-100-MA-1-BC-60-S-4-F1-E-06-GBA-29-29-24	SERIES 90	S90-100PV
9621558	PUMP-VAR DISPL, CW	90-R-100-HF-1-NN-60-R-4-S1-F-03-GBA-38-38-28	SERIES 90	S90-100PV
9621559	PUMP-VAR DISPL, CW	90-R-100-MA-1-NN-60-R-4-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9621560	PUMP-VAR DISPL, CW	90-R-100-MB-1-CD-60-S-3-F1-F-03-GBA-35-35-20	SERIES 90	S90-100PV
9621561	PUMP-VAR DISPL, CW	90-R-100-MA-1-CD-60-L-3-F1-E-00-GBA-35-35-20	SERIES 90	S90-100PV

9621562	PUMP-VAR DISPL, CW	90-R-100-MA-1-CD-60-D-4-F1-L-03-GBA-35-35-24	SERIES 90	S90-100PV
9621563	PUMP-VAR DISPL, CW	90-R-100-MA-1-BC-60-D-4-S1-L-03-GBA-35-35-24	SERIES 90	S90-100PV
9621564	PUMP-VAR DISPL, CW	90-R-100-CB-1-CD-60-D-4-F1-L-00-GBA-35-35-24	SERIES 90	S90-100PV
9621565	PUMP-VAR DISPL, CW	90-R-100-CB-1-BC-60-D-4-S1-L-00-GBA-35-35-24	SERIES 90	S90-100PV
9621566	PUMP-VAR DISPL, CW	90-R-100-EA-1-CD-60-S-3-T2-E-00-GBA-23-23-24	SERIES 90	S90-100PV
9621567	PUMP-VAR DISPL, CW	90-R-100-MA-6-CD-80-S-3-F1-F-03-GBA-48-32-28	SERIES 90	S90-100PV
9621568	PUMP-VAR DISPL, CW	90-R-100-CB-6-NN-80-L-4-K3-E-00-GBA-45-45-24	SERIES 90	S90-100PV
9621569	PUMP-VAR DISPL, CW	90-R-100-HF-1-CD-80-L-3-S1-F-00-GBA-23-23-24	SERIES 90	S90-100PV
9621573	PUMP-VAR DISPL, CW	90-R-100-HS-1-BC-80-S-3-F1-E-03-GBA-35-35-28	SERIES 90	S90-100PV
9621574	PUMP-VAR DISPL, CW	90-R-100-EA-1-NN-60-R-3-T2-E-00-GBA-23-23-24	SERIES 90	S90-100PV
9621575	PUMP-VAR DISPL, CW	90-R-100-EP-1-BC-60-L-4-F1-E-03-GBA-26-26-24	SERIES 90	S90-100PV
9621576	PUMP-VAR DISPL, CW	90-R-100-MA-1-CD-80-S-3-F1-F-03-GBA-32-32-28	SERIES 90	S90-100PV
9621577	PUMP-VAR DISPL, CW	90-R-100-EP-1-BB-60-R-4-F1-E-03-GBA-26-26-24	SERIES 90	S90-100PV
9621578	PUMP-VAR DISPL, CW	90-R-100-EA-1-BC-80-L-3-S1-E-00-GBA-29-29-24	SERIES 90	S90-100PV
9621580	PUMP-VAR DISPL, CW	90-R-100-EA-1-CD-60-P-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9621581	PUMP-VAR DISPL, CW	90-R-100-HF-1-BC-61-S-3-S1-E-03-GBA-32-32-24	SERIES 90	S90-100PV
9621582	PUMP-VAR DISPL, CW	90-R-100-EA-1-CD-80-P-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9621583	PUMP-VAR DISPL, CW	90-R-100-EP-1-NN-80-L-3-F1-D-03-GBA-20-20-24	SERIES 90	S90-100PV
9621584	PUMP-VAR DISPL, CW	90-R-100-MA-1-BC-80-R-3-F1-E-00-GBA-29-29-20	SERIES 90	S90-100PV
9621586	PUMP-VAR DISPL, CW	90-R-100-EA-1-NN-60-L-3-F1-E-03-GBA-38-38-24	SERIES 90	S90-100PV
9621587	PUMP-VAR DISPL, CW	90-R-100-MA-1-AB-80-S-3-C7-E-03-GBA-32-32-24	SERIES 90	S90-100PV
9621587C	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-AB-80-S-3-C7-E-03-GBA-32-32-24	SERIES 90	S90-100PV
9621588	PUMP-VAR DISPL, CW	90-R-100-EP-1-NN-60-S-3-T2-E-00-GBA-26-26-20	SERIES 90	S90-100PV
9621589	PUMP-VAR DISPL, CW	90-R-100-MA-1-BC-80-S-3-C7-E-03-GBA-38-38-24	SERIES 90	S90-100PV
9621589C	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-BC-80-S-3-C7-E-03-GBA-38-38-24	SERIES 90	S90-100PV
9621590	PUMP-VAR DISPL, CW	90-R-100-EA-1-AB-61-S-3-T2-F-03-GBA-38-38-24	SERIES 90	S90-100PV
9621591	PUMP-VAR DISPL, CW	90-R-100-HF-1-BC-80-S-3-C7-E-03-GBA-38-38-24	SERIES 90	S90-100PV
9621594	PUMP-VAR DISPL, CW	90-R-100-EA-1-CD-80-P-3-C7-E-00-GBA-35-35-24	SERIES 90	S90-100PV
9621595	PUMP-VAR DISPL, CW	90-R-100-MA-1-NN-80-S-3-F1-E-04-FAC-38-38-24	SERIES 90	S90-100PV
9621596	PUMP-VAR DISPL, CW	90-R-100-MA-1-NN-80-S-3-F1-F-03-GBA-29-29-20	SERIES 90	S90-100PV
9621597	PUMP-VAR DISPL, CW	90-R-100-MB-1-CD-60-S-4-F1-F-03-GBA-38-38-24	SERIES 90	S90-100PV
9621598	PUMP-VAR DISPL, CW	90-R-100-EA-1-NN-80-S-4-F1-F-03-GBA-26-26-20	SERIES 90	S90-100PV
9621599	PUMP-VAR DISPL, CW	90-R-100-MA-1-CD-80-S-3-S1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
9621600	PUMP-VAR DISPL, CW	90-R-100-MA-1-NN-61-S-3-F1-F-03-GBA-38-14-20	SERIES 90	S90-100PV
9621601	PUMP-VAR DISPL, CW	90-R-100-MA-1-NN-61-S-3-F1-F-03-GBA-14-35-20	SERIES 90	S90-100PV
9621602	PUMP-VAR DISPL, CW	90-R-100-KP-1-CD-61-R-3-S1-E-00-GBA-35-35-24	SERIES 90	S90-100PV

9621603	PUMP-VAR DISPL, CW	90-R-100-MB-1-NN-60-S-3-F1-E-03-GBA-38-38-24	SERIES 90	S90-100PV
9621604	PUMP-VAR DISPL, CW	90-R-100-KP-1-NN-60-R-3-F1-E-00-GBA-23-23-24	SERIES 90	S90-100PV
9621605	PUMP-VAR DISPL, CW	90-R-100-KP-1-NN-80-P-3-S1-D-04-GBA-38-38-24	SERIES 90	S90-100PV
9621606	PUMP-VAR DISPL, CW	90-R-100-KP-1-NN-81-P-3-S1-E-03-GBA-26-26-20	SERIES 90	S90-100PV
9621607	PUMP-VAR DISPL, CW	90-R-100-KP-1-CD-60-R-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9621608	PUMP-VAR DISPL, CW	90-R-100-MA-1-NN-61-S-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9621609	PUMP-VAR DISPL, CW	90-R-100-MB-1-CD-60-L-3-F1-F-03-GBA-35-35-20	SERIES 90	S90-100PV
9621610	PUMP-VAR DISPL, CW	90-R-100-MA-6-CD-80-S-3-F1-F-03-GBA-32-48-28	SERIES 90	S90-100PV
9621611	PUMP-VAR DISPL, CW	90-R-100-MB-1-AB-60-L-3-C7-F-03-GBA-42-42-24	SERIES 90	S90-100PV
9621611C	PUMP-VAR DISPL, CW 90PV100	90-R-100-MB-1-AB-60-L-3-C7-F-03-GBA-42-42-24	SERIES 90	S90-100PV
9621612	PUMP-VAR DISPL, CW	90-R-100-MA-1-NN-60-S-4-F1-E-03-GBA-32-32-24	SERIES 90	S90-100PV
9621613	PUMP-VAR DISPL, CW	90-R-100-MA-1-NN-80-L-3-C7-F-03-GBA-35-35-24	SERIES 90	S90-100PV
9621614	PUMP-VAR DISPL, CW	90-R-100-KP-1-NN-80-L-3-C7-F-03-GBA-35-35-24	SERIES 90	S90-100PV
9621615	PUMP-VAR DISPL, CW	90-R-100-KA-1-CD-80-P-3-C7-E-00-GBA-38-38-24	SERIES 90	S90-100PV
9621616	PUMP-VAR DISPL, CW	90-R-100-KA-2-NN-60-P-3-S1-F-00-GBA-32-32-18	SERIES 90	S90-100PV
9621619	PUMP-VAR DISPL, CW	90-R-100-MA-1-AB-80-R-3-T2-F-03-GBA-42-42-24	SERIES 90	S90-100PV
9621620	PUMP-VAR DISPL, CW	90-R-100-KA-2-NN-60-S-4-F1-E-05-GBA-35-35-24	SERIES 90	S90-100PV
9621621	PUMP-VAR DISPL, CW	90-R-100-KA-6-NN-80-S-4-K3-E-02-GBA-45-45-24	SERIES 90	S90-100PV
9621624	PUMP-VAR DISPL, CW	90-R-100-KP-6-AB-60-S-3-T2-E-03-GBA-48-48-24	SERIES 90	S90-100PV
9621625	PUMP-VAR DISPL, CW	90-R-100-KA-1-CD-60-L-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9621626	PUMP-VAR DISPL, CW	90-R-100-KA-1-NN-61-L-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9621627	PUMP-VAR DISPL, CW	90-R-100-KA-1-NN-61-S-3-F1-F-03-GBA-14-35-20	SERIES 90	S90-100PV
9621627C	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-NN-61-S-3-F1-F-03-GBA-14-35-20	SERIES 90	S90-100PV
9621628	PUMP-VAR DISPL, CW	90-R-100-KP-1-NN-80-P-3-S1-D-03-GBA-38-38-24	SERIES 90	S90-100PV
9621629	PUMP-VAR DISPL, CW	90-R-100-CB-1-CD-60-D-4-F1-L-00-FAC-35-35-24	SERIES 90	S90-100PV
9621630	PUMP-VAR DISPL, CW	90-R-100-CB-1-BC-60-D-4-S1-L-00-FAC-35-35-24	SERIES 90	S90-100PV
9621631	PUMP-VAR DISPL, CW	90-R-100-MA-1-NN-60-S-3-C7-F-03-GBA-42-42-24	SERIES 90	S90-100PV
9621632	PUMP-VAR DISPL, CW	90-R-100-MA-1-AB-60-S-3-C7-E-03-GBA-35-35-20	SERIES 90	S90-100PV
9621633	PUMP-VAR DISPL, CW	90-R-100-MA-1-BC-60-R-4-S1-E-00-GBA-32-35-24	SERIES 90	S90-100PV
9621634	PUMP-VAR DISPL, CW	90-R-100-MA-1-AB-60-S-3-K3-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9621635	PUMP-VAR DISPL, CW	90-R-100-KA-1-AB-80-L-4-K3-F-03-GBA-35-35-24	SERIES 90	S90-100PV
9621636	PUMP-VAR DISPL, CW	90-R-100-KP-1-BC-80-R-4-S1-E-00-GBA-32-35-24	SERIES 90	S90-100PV
9621637	PUMP-VAR DISPL, CW	90-R-100-KA-1-NN-60-S-4-F1-F-05-GBA-35-35-24	SERIES 90	S90-100PV
9621638	PUMP-VAR DISPL, CW	90-R-100-KA-1-BB-60-R-3-S1-E-02-GBA-38-38-24	SERIES 90	S90-100PV
9621639	PUMP-VAR DISPL, CW	90-R-100-CB-1-NN-60-R-4-S1-F-00-GBA-38-38-28	SERIES 90	S90-100PV
9621640	PUMP-VAR DISPL, CW	90-R-100-KA-1-CD-60-L-4-F1-E-03-GBA-26-26-24	SERIES 90	S90-100PV

9621641	PUMP-VAR DISPL, CW	90-R-100-HF-1-NN-60-S-4-F1-E-03-GBA-23-17-24	SERIES 90	S90-100PV
9621642	PUMP-VAR DISPL, CW	90-R-100-KP-1-AC-80-S-3-S1-F-03-GBA-29-29-24	SERIES 90	S90-100PV
9621644	PUMP-VAR DISPL, CW	90-R-100-KP-1-BC-80-S-4-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9621645	PUMP-VAR DISPL, CW	90-R-100-HF-1-CD-60-P-3-T2-E-03-GBA-42-42-20	SERIES 90	S90-100PV
9621646	PUMP-VAR DISPL, CW	90-R-100-HF-1-CD-60-P-3-S1-E-03-GBA-42-42-20	SERIES 90	S90-100PV
9621647	PUMP-VAR DISPL, CW	90-R-100-CB-1-CD-60-S-3-F1-E-00-FAC-42-42-24	SERIES 90	S90-100PV
9621648	PUMP-VAR DISPL, CW	90-R-100-KA-1-BC-80-S-4-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9621650	PUMP-VAR DISPL, CW	90-R-100-M1-1-NN-60-X-3-F1-E-01-GBA-23-23-20	SERIES 90	S90-100PV
9621651	PUMP-VAR DISPL, CW	90-R-100-MA-1-NN-60-S-3-F1-E-02-GBA-35-35-24	SERIES 90	S90-100PV
9621652	PUMP-VAR DISPL, CW	90-R-100-MA-1-CD-60-S-3-F1-E-02-GBA-35-35-24	SERIES 90	S90-100PV
9621653	PUMP-VAR DISPL, CW	90-R-100-ME-1-CD-60-R-3-C7-D-03-GBA-42-42-30	SERIES 90	S90-100PV
9621653C	PUMP-VAR DISPL, CW 90PV100	90-R-100-ME-1-CD-60-R-3-C7-D-03-GBA-42-42-30	SERIES 90	S90-100PV
9621654	PUMP-VAR DISPL, CW	90-R-100-MB-1-CD-60-R-3-C7-D-03-GBA-42-42-30	SERIES 90	S90-100PV
9621654C	PUMP-VAR DISPL, CW 90PV100	90-R-100-MB-1-CD-60-R-3-C7-D-03-GBA-42-42-30	SERIES 90	S90-100PV
9621655	PUMP-VAR DISPL, CW	90-R-100-KA-1-CD-80-L-4-F1-E-03-GBA-26-26-24	SERIES 90	S90-100PV
9621656	PUMP-VAR DISPL, CW	90-R-100-KA-1-NN-80-S-4-S1-E-03-GBA-20-20-20	SERIES 90	S90-100PV
9621657	PUMP-VAR DISPL, CW	90-R-100-KA-1-CD-60-L-4-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9621658	PUMP-VAR DISPL, CW	90-R-100-KP-1-CD-80-S-3-F1-F-00-GBA-35-29-30	SERIES 90	S90-100PV
9621659	PUMP-VAR DISPL, CW	90-R-100-KP-1-NN-60-S-3-K3-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9621660	PUMP-VAR DISPL, CW	90-R-100-KP-1-AB-60-R-3-F1-E-03-GBA-26-26-24	SERIES 90	S90-100PV
9621661	PUMP-VAR DISPL, CW	90-R-100-HF-1-CD-80-S-3-S1-F-00-GBA-23-29-24	SERIES 90	S90-100PV
9621662	PUMP-VAR DISPL, CW	90-R-100-HF-1-CD-80-S-3-F1-F-00-GBA-23-29-24	SERIES 90	S90-100PV
9621663	PUMP-VAR DISPL, CW	90-R-100-KA-1-NN-60-S-3-K3-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9621664	PUMP-VAR DISPL, CW	90-R-100-HF-1-BC-80-S-3-S1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
9621665	PUMP-VAR DISPL, CW	90-R-100-MA-1-CD-80-P-4-S1-E-03-GBA-35-35-20	SERIES 90	S90-100PV
9621666	PUMP-VAR DISPL, CW	90-R-100-KP-1-NN-80-P-3-S1-D-29-GBA-38-38-24	SERIES 90	S90-100PV
9621667	PUMP-VAR DISPL, CW	90-R-100-HF-1-BC-80-R-3-S1-F-04-GBA-35-35-24	SERIES 90	S90-100PV
9621668	PUMP-VAR DISPL, CW	90-R-100-KA-1-CD-60-P-3-C7-F-00-FAD-38-38-24	SERIES 90	S90-100PV
9621669	PUMP-VAR DISPL, CW	90-R-100-KA-1-CD-80-P-3-C7-E-00-GBA-35-35-24	SERIES 90	S90-100PV
9621669C	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-CD-80-P-3-C7-E-00-GBA-35-35-24	SERIES 90	S90-100PV
9621670	PUMP-VAR DISPL, CW	90-R-100-KA-1-BB-60-L-3-T2-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9621671	PUMP-VAR DISPL, CW	90-R-100-HF-1-NN-80-R-3-S1-F-04-GBA-35-35-24	SERIES 90	S90-100PV
9621672	PUMP-VAR DISPL, CW	90-R-100-KA-1-BC-60-S-4-F1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
9621673	PUMP-VAR DISPL, CW	90-R-100-KA-1-CD-60-S-4-F1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
9621674	PUMP-VAR DISPL, CW	90-R-100-KA-1-BC-61-R-4-F1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
9621675	PUMP-VAR DISPL, CW	90-R-100-KA-1-CD-61-R-4-F1-F-03-GBA-35-35-24	SERIES 90	S90-100PV

9621676	PUMP-VAR DISPL, CW	90-R-100-KA-1-CD-80-L-4-F1-E-03-GBA-17-17-24	SERIES 90	S90-100PV
9621677	PUMP-VAR DISPL, CW	90-R-100-KA-1-BC-80-L-4-F1-E-03-GBA-17-17-24	SERIES 90	S90-100PV
9621679	PUMP-VAR DISPL, CW	90-R-100-KA-1-BC-60-S-3-S1-E-00-GBA-23-23-24	SERIES 90	S90-100PV
9621680	PUMP-VAR DISPL, CW	90-R-100-KP-1-NN-80-L-3-C7-F-01-GBA-29-29-20	SERIES 90	S90-100PV
9621682	PUMP-VAR DISPL, CW	90-R-100-KP-1-BC-60-L-3-F1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
9621683	PUMP-VAR DISPL, CW	90-R-100-KP-1-CD-60-S-3-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9621684	PUMP-VAR DISPL, CW	90-R-100-KA-1-NN-80-S-3-S1-E-03-GBA-20-20-24	SERIES 90	S90-100PV
9621685	PUMP-VAR DISPL, CW	90-R-100-KA-1-CD-80-S-3-F1-E-03-GBA-20-20-24	SERIES 90	S90-100PV
9621686	PUMP-VAR DISPL, CW	90-R-100-MA-B-CD-80-S-3-F1-F-01-GBA-32-48-28	SERIES 90	S90-100PV
9621687	PUMP-VAR DISPL, CW	90-R-100-MS-1-BE-62-R-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9621688	PUMP-VAR DISPL, CW	90-R-100-KA-1-AB-60-S-3-F1-F-00-GBA-35-35-20	SERIES 90	S90-100PV
9621689	PUMP-VAR DISPL, CW	90-R-100-KA-1-NN-60-S-3-F1-F-00-GBA-42-42-20	SERIES 90	S90-100PV
9621690	PUMP-VAR DISPL, CW	90-R-100-KA-1-NN-60-S-3-T2-E-00-GBA-23-23-24	SERIES 90	S90-100PV
9621695	PUMP-VAR DISPL, CW	90-R-100-LG-1-CD-60-X-3-S1-E-01-GBA-20-20-24	SERIES 90	S90-100PV
9621696	PUMP-VAR DISPL, CW	90-R-100-KA-1-NN-60-S-3-F1-E-00-GBA-23-23-24	SERIES 90	S90-100PV
9621697	PUMP-VAR DISPL, CW	90-R-100-KP-1-AC-80-P-3-S1-F-03-GBA-29-29-24	SERIES 90	S90-100PV
9621698	PUMP-VAR DISPL, CW	90-R-100-MB-1-AB-60-L-3-S1-E-02-GBA-23-23-24	SERIES 90	S90-100PV
9621701	PUMP-VAR DISPL, CW	90-R-100-KP-1-AC-80-P-3-S1-F-00-GBA-29-29-24	SERIES 90	S90-100PV
9621702	PUMP-VAR DISPL, CW	90-R-100-KA-1-NN-60-P-3-C7-F-00-FAD-38-38-24	SERIES 90	S90-100PV
9621703	PUMP-VAR DISPL, CW	90-R-100-KA-1-CD-60-L-3-C7-D-03-GBA-42-42-24	SERIES 90	S90-100PV
9621704	PUMP-VAR DISPL, CW	90-R-100-KA-1-AB-60-L-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9621705	PUMP-VAR DISPL, CW	90-R-100-MA-1-AB-80-S-3-C7-E-05-GBA-32-32-24	SERIES 90	S90-100PV
9621706	PUMP-VAR DISPL, CW	90-R-100-KP-1-NN-60-R-3-F1-E-03-GBA-29-29-24	SERIES 90	S90-100PV
9621707	PUMP-VAR DISPL, CW	90-R-100-HF-1-NN-80-P-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9621708	PUMP-VAR DISPL, CW	90-R-100-KA-1-NN-60-S-3-F1-F-03-GBA-14-35-20	SERIES 90	S90-100PV
9621708C	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-NN-60-S-3-F1-F-03-GBA-14-35-20	SERIES 90	S90-100PV
9621709	PUMP-VAR DISPL, CW	90-R-100-KA-1-NN-80-S-3-S1-E-00-GBA-32-32-24	SERIES 90	S90-100PV
9621710	PUMP-VAR DISPL, CW	90-R-100-MA-1-NN-60-P-3-S1-F-03-GBA-32-32-24	SERIES 90	S90-100PV
9621711	PUMP-VAR DISPL, CW	90-R-100-KP-1-CD-80-P-3-F1-F-00-GBA-35-29-30	SERIES 90	S90-100PV
9621712	PUMP-VAR DISPL, CW	90-R-100-KP-G-BC-80-P-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9621713	PUMP-VAR DISPL, CW	90-R-100-KA-1-NN-80-L-3-F1-D-03-GBA-20-20-24	SERIES 90	S90-100PV
9621714	PUMP-VAR DISPL, CW	90-R-100-KN-1-CD-60-D-4-F1-L-03-GBA-35-35-28	SERIES 90	S90-100PV
9621715	PUMP-VAR DISPL, CW	90-R-100-KA-1-CD-80-R-3-F1-F-03-GBA-20-20-24	SERIES 90	S90-100PV
9621716	PUMP-VAR DISPL, CW	90-R-100-KA-1-BC-60-S-3-S1-F-03-GBA-23-23-24	SERIES 90	S90-100PV
9621717	PUMP-VAR DISPL, CW	90-R-100-HF-1-CD-80-P-3-F1-F-00-GBA-23-29-24	SERIES 90	S90-100PV
9621718	PUMP-VAR DISPL, CW	90-R-100-KA-1-CD-60-L-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-100PV

9621719	PUMP-VAR DISPL, CW	90-R-100-KP-1-CD-60-L-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
9621720	PUMP-VAR DISPL, CW	90-R-100-MA-1-NN-80-S-3-C7-F-03-GBA-42-42-24	SERIES 90	S90-100PV
9621721	PUMP-VAR DISPL, CW	90-R-100-CB-1-NN-80-S-4-F1-E-00-FAC-38-38-24	SERIES 90	S90-100PV
9621722	PUMP-VAR DISPL, CW	90-R-100-MA-1-AB-80-S-3-C7-E-06-GBA-32-32-24	SERIES 90	S90-100PV
9621722C	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-AB-80-S-3-C7-E-06-GBA-32-32-24	SERIES 90	S90-100PV
9621724	PUMP-VAR DISPL, CW	90-R-100-KN-6-CD-60-P-4-K3-D-03-GBA-48-45-24	SERIES 90	S90-100PV
9621725	PUMP-VAR DISPL, CW	90-R-100-KA-1-BC-80-R-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9621726	PUMP-VAR DISPL, CW	90-R-100-KA-1-NN-60-L-3-S1-E-03-GBA-42-42-20	SERIES 90	S90-100PV
9621727	PUMP-VAR DISPL, CW	90-R-100-KP-1-BC-60-S-3-S1-E-06-EBC-42-42-24	SERIES 90	S90-100PV
9621728	PUMP-VAR DISPL, CW	90-R-100-KA-1-CD-60-P-3-F1-E-03-GBA-35-35-20	SERIES 90	S90-100PV
9621729	PUMP-VAR DISPL, CW	90-R-100-KA-1-NN-60-P-3-F1-E-03-GBA-35-35-20	SERIES 90	S90-100PV
9621730	PUMP-VAR DISPL, CW	90-R-100-MA-1-CD-80-S-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9621731	PUMP-VAR DISPL, CW	90-R-100-KA-1-NN-60-P-3-S1-E-03-GBA-35-35-20	SERIES 90	S90-100PV
9621732	PUMP-VAR DISPL, CW	90-R-100-KN-6-CD-60-P-4-K3-D-03-GBA-48-48-24	SERIES 90	S90-100PV
9621733	PUMP-VAR DISPL, CW	90-R-100-KN-6-NN-60-P-4-S1-D-03-GBA-48-48-24	SERIES 90	S90-100PV
9621734	PUMP-VAR DISPL, CW	90-R-100-KA-1-AB-60-P-3-S1-F-22-GBA-42-42-24	SERIES 90	S90-100PV
9621735	PUMP-VAR DISPL, CW	90-R-100-HF-1-NN-80-L-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9621736	PUMP-VAR DISPL, CW	90-R-100-HM-G-NN-60-P-3-F1-E-04-GBA-32-32-24	SERIES 90	S90-100PV
9621737	PUMP-VAR DISPL, CW	90-R-100-KP-1-NN-80-P-3-S1-E-29-GBA-38-38-24	SERIES 90	S90-100PV
9621738	PUMP-VAR DISPL, CW	90-R-100-KP-1-CD-80-P-3-S1-F-00-GBA-29-29-24	SERIES 90	S90-100PV
9621740	PUMP-VAR DISPL, CW	90-R-100-EH-2-CD-60-L-F-F1-E-33-GBA-38-38-24	SERIES 90	S90-100PV
9621741	PUMP-VAR DISPL, CW	90-R-100-EH-2-AB-60-R-F-S1-E-33-GBA-38-38-24	SERIES 90	S90-100PV
9621743	PUMP-VAR DISPL, CW	90-R-100-FC-1-BB-80-P-7-F1-F-B1-EDD-42-42-28	SERIES 90	S90-100PV
9621744	PUMP-VAR DISPL, CW	90-R-100-KA-1-BC-60-P-3-F1-F-22-GBA-42-42-24	SERIES 90	S90-100PV
9621745	PUMP-VAR DISPL, CW	90-R-100-KA-1-AB-60-P-3-F1-F-22-GBA-42-42-24	SERIES 90	S90-100PV
9621746	PUMP-VAR DISPL, CW	90-R-100-EA-2-BC-80-R-3-F1-F-00-GBA-35-35-24	SERIES 90	S90-100PV
9621747	PUMP-VAR DISPL, CW	90-R-100-HF-1-CD-80-P-3-F1-F-00-GBA-32-29-30	SERIES 90	S90-100PV
9621748	PUMP-VAR DISPL, CW	90-R-100-HF-1-BC-80-P-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9621749	PUMP-VAR DISPL, CW	90-R-100-KA-1-CD-60-L-3-C7-F-03-GBA-14-14-20	SERIES 90	S90-100PV
9621750	PUMP-VAR DISPL, CW	90-R-100-DC-1-BC-60-P-4-F1-E-GB-GBA-29-29-24	SERIES 90	S90-100PV
9621751	PUMP-VAR DISPL, CW	90-R-100-KA-1-NN-60-S-3-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9621752	PUMP-VAR DISPL, CW	90-R-100-KA-1-NN-80-S-3-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9621753	PUMP-VAR DISPL, CW	90-R-100-MA-1-AB-81-D-3-K3-L-00-GBA-23-23-24	SERIES 90	S90-100PV
9621754	PUMP-VAR DISPL, CW	90-R-100-KP-1-AB-80-S-4-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9621756	PUMP-VAR DISPL, CW	90-R-100-KA-1-CD-60-S-3-C7-E-03-GBA-32-32-20	SERIES 90	S90-100PV
9621756C	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-CD-60-S-3-C7-E-03-GBA-32-32-20	SERIES 90	S90-100PV

9621757	PUMP-VAR DISPL, CW	90-R-100-KA-1-CD-60-S-3-S1-E-02-GBA-26-26-30	SERIES 90	S90-100PV
9621757C	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-CD-60-S-3-S1-E-02-GBA-26-26-30	SERIES 90	S90-100PV
9621758	PUMP-VAR DISPL, CW	90-R-100-MA-1-CD-80-P-3-F1-E-03-GBA-29-29-24	SERIES 90	S90-100PV
9621760	PUMP-VAR DISPL, CW	90-R-100-FC-1-BC-80-P-7-S1-E-B1-EDD-35-35-28	SERIES 90	S90-100PV
9621761	PUMP-VAR DISPL, CW	90-R-100-MB-1-CD-60-R-4-C7-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9621762	PUMP-VAR DISPL, CW	90-R-100-KA-1-NN-80-L-3-K3-D-03-GBA-23-23-24	SERIES 90	S90-100PV
9621763	PUMP-VAR DISPL, CW	90-R-100-MA-1-BC-80-S-3-F1-E-00-GBA-38-38-24	SERIES 90	S90-100PV
9621764	PUMP-VAR DISPL, CW	90-R-100-HF-1-NN-80-L-3-S1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
9621765	PUMP-VAR DISPL, CW	90-R-100-KP-1-CD-80-R-4-K3-E-00-GBA-35-35-24	SERIES 90	S90-100PV
9621766	PUMP-VAR DISPL, CW	90-R-100-KA-1-NN-80-S-3-F1-E-03-GBA-20-20-24	SERIES 90	S90-100PV
9621767	PUMP-VAR DISPL, CW	90-R-100-KP-1-BC-80-P-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9621768	PUMP-VAR DISPL, CW	90-R-100-EA-1-BC-60-P-3-F1-E-05-GBA-23-23-24	SERIES 90	S90-100PV
9621769	PUMP-VAR DISPL, CW	90-R-100-MB-1-BB-80-L-3-F1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
9621770	PUMP-VAR DISPL, CW	90-R-100-MB-1-CD-80-L-3-F1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
9621771	PUMP-VAR DISPL, CW	90-R-100-KA-1-BB-60-S-3-F1-F-03-GBA-35-35-20	SERIES 90	S90-100PV
9621772	PUMP-VAR DISPL, CW	90-R-100-KA-2-CD-80-S-3-S1-E-33-GBA-42-42-24	SERIES 90	S90-100PV
9621773	PUMP-VAR DISPL, CW	90-R-100-KA-2-CD-80-S-3-F1-E-33-GBA-42-42-24	SERIES 90	S90-100PV
9621774	PUMP-VAR DISPL, CW	90-R-100-HF-1-NN-80-P-3-S1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
9621775	PUMP-VAR DISPL, CW	90-R-100-EH-2-CD-60-R-F-F1-E-33-GBA-38-38-24	SERIES 90	S90-100PV
9621776	PUMP-VAR DISPL, CW	90-R-100-EH-2-AB-60-L-F-F1-E-33-GBA-38-38-24	SERIES 90	S90-100PV
9621777	PUMP-VAR DISPL, CW	90-R-100-KA-1-CD-80-D-4-K3-L-03-GBA-35-35-24	SERIES 90	S90-100PV
9621778	PUMP-VAR DISPL, CW	90-R-100-KP-1-NN-60-R-3-K3-E-03-GBA-29-29-24	SERIES 90	S90-100PV
9621779	PUMP-VAR DISPL, CW	90-R-100-HF-1-NN-80-P-3-S1-F-02-GBA-35-35-24	SERIES 90	S90-100PV
9621780	PUMP-VAR DISPL, CW	90-R-100-EA-1-NN-80-S-3-S1-E-03-EBC-29-29-24	SERIES 90	S90-100PV
9621781	PUMP-VAR DISPL, CW	90-R-100-KA-1-NN-60-L-3-T2-F-03-GBA-35-35-24	SERIES 90	S90-100PV
9621782	PUMP-VAR DISPL, CW	90-R-100-KA-1-NN-60-L-3-K3-F-03-GBA-42-42-24	SERIES 90	S90-100PV
9621783	PUMP-VAR DISPL, CW	90-R-100-KA-1-NN-80-L-3-K3-F-03-GBA-35-35-24	SERIES 90	S90-100PV
9621784	PUMP-VAR DISPL, CW	90-R-100-MB-1-CD-80-L-3-F1-F-03-GBA-38-38-24	SERIES 90	S90-100PV
9621785	PUMP-VAR DISPL, CW	90-R-100-MA-1-BC-80-L-3-S1-F-03-GBA-38-38-24	SERIES 90	S90-100PV
9621788	PUMP-VAR DISPL, CW	90-R-100-EA-1-NN-60-P-3-F1-F-03-GBA-23-23-24	SERIES 90	S90-100PV
9621789	PUMP-VAR DISPL, CW	90-R-100-KA-1-NN-60-L-4-F1-E-03-GBA-20-20-24	SERIES 90	S90-100PV
9621792	PUMP-VAR DISPL, CW	90-R-100-DC-1-CD-60-L-3-F1-E-GB-GBA-42-42-24	SERIES 90	S90-100PV
9621794	PUMP-VAR DISPL, CW	90-R-100-KA-1-CD-80-S-3-S1-E-03-GBA-23-23-24	SERIES 90	S90-100PV
9621795	PUMP-VAR DISPL, CW	90-R-100-EG-1-BB-80-R-3-F1-F-03-GBA-35-35-20	SERIES 90	S90-100PV
9621796	PUMP-VAR DISPL, CW	90-R-100-EP-2-AB-60-L-F-F1-E-33-GBA-35-35-24	SERIES 90	S90-100PV
9621797	PUMP-VAR DISPL, CW	90-R-100-HF-5-CD-80-P-3-F1-F-00-GBA-32-26-30	SERIES 90	S90-100PV

9621798	PUMP-VAR DISPL, CW	90-R-100-HS-1-CD-80-S-3-S1-E-03-GBA-23-23-24	SERIES 90	S90-100PV
9621799	PUMP-VAR DISPL, CW	90-R-100-MB-1-CD-60-D-4-C7-L-03-GBA-42-42-24	SERIES 90	S90-100PV
9621800	PUMP-VAR DISPL, CW	90-R-100-HS-1-NN-80-P-3-S1-F-02-GBA-35-35-24	SERIES 90	S90-100PV
9621801	PUMP-VAR DISPL, CW	90-R-100-KP-1-NN-80-P-3-S1-F-02-GBA-35-35-24	SERIES 90	S90-100PV
9621802	PUMP-VAR DISPL, CW	90-R-100-KP-5-CD-80-P-3-F1-F-00-GBA-42-26-30	SERIES 90	S90-100PV
9621803	PUMP-VAR DISPL, CW	90-R-100-MA-1-NN-61-R-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9621804	PUMP-VAR DISPL, CW	90-R-100-KA-2-NN-60-S-3-S1-E-00-GBA-23-23-24	SERIES 90	S90-100PV
9621805	PUMP-VAR DISPL, CW	90-R-100-KA-1-CD-81-P-4-S1-E-03-FAD-38-38-24	SERIES 90	S90-100PV
9621806	PUMP-VAR DISPL, CW	90-R-100-KA-1-NN-81-P-4-S1-E-03-FAD-38-38-24	SERIES 90	S90-100PV
9621807	PUMP-VAR DISPL, CW	90-R-100-KP-5-CD-80-P-3-F1-F-00-GBA-32-26-30	SERIES 90	S90-100PV
9621808	PUMP-VAR DISPL, CW	90-R-100-MV-1-BC-80-S-3-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9621809	PUMP-VAR DISPL, CW	90-R-100-KP-1-CD-60-S-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9621809C	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-CD-60-S-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9621810	PUMP-VAR DISPL, CW	90-R-100-MV-1-BC-80-L-3-S1-F-03-GBA-38-38-24	SERIES 90	S90-100PV
9621811	PUMP-VAR DISPL, CW	90-R-100-EA-2-NN-80-R-3-S1-F-00-GBA-35-35-24	SERIES 90	S90-100PV
9621812	PUMP-VAR DISPL, CW	90-R-100-EA-1-CD-80-R-3-F1-F-00-GBA-42-42-24	SERIES 90	S90-100PV
9621813	PUMP-VAR DISPL, CW	90-R-100-EA-1-NN-80-R-3-S1-F-00-GBA-42-42-24	SERIES 90	S90-100PV
9621814	PUMP-VAR DISPL, CW	90-R-100-KA-1-CD-81-P-4-S1-E-02-FAD-38-38-24	SERIES 90	S90-100PV
9621815	PUMP-VAR DISPL, CW	90-R-100-KA-1-NN-81-P-4-S1-E-02-FAD-38-38-24	SERIES 90	S90-100PV
9621816	PUMP-VAR DISPL, CW	90-R-100-KP-1-CD-80-S-3-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9621817	PUMP-VAR DISPL, CW	90-R-100-KP-1-NN-80-P-3-S1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
9621818	PUMP-VAR DISPL, CW	90-R-100-RR-1-BC-60-R-3-F1-E-02-GBA-38-38-24	SERIES 90	S90-100PV
9621819	PUMP-VAR DISPL, CW	90-R-100-RR-1-BC-60-R-3-F1-E-04-FAD-38-38-24	SERIES 90	S90-100PV
9621820	PUMP-VAR DISPL, CW	90-R-100-MV-1-BC-80-P-3-F1-F-03-GBA-38-38-24	SERIES 90	S90-100PV
9621821	PUMP-VAR DISPL, CW	90-R-100-MA-1-CD-60-S-3-F1-E-03-GBA-26-26-24	SERIES 90	S90-100PV
9621822	PUMP-VAR DISPL, CW	90-R-100-KP-G-BC-80-P-3-S1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
9621823	PUMP-VAR DISPL, CW	90-R-100-KP-1-CD-80-R-3-S1-F-00-GBA-29-29-24	SERIES 90	S90-100PV
9621825	PUMP-VAR DISPL, CW	90-R-100-ME-1-CD-60-D-4-C7-L-03-GBA-42-42-24	SERIES 90	S90-100PV
9621827	PUMP-VAR DISPL, CW	90-R-100-MA-1-BC-80-P-3-F1-E-03-GBA-38-38-24	SERIES 90	S90-100PV
9621829	PUMP-VAR DISPL, CW	90-R-100-HS-2-BC-60-P-4-S1-F-03-GBA-14-26-24	SERIES 90	S90-100PV
9621830	PUMP-VAR DISPL, CW	90-R-100-HS-2-CD-60-P-4-F1-F-03-GBA-14-26-24	SERIES 90	S90-100PV
9621831	PUMP-VAR DISPL, CW	90-R-100-MV-1-CD-80-S-2-C7-E-03-GBA-38-17-28-F061	SERIES 90	S90-100PV
9621832	PUMP-VAR DISPL, CW	90-R-100-KA-2-CD-80-P-3-F1-E-03-GBA-20-20-24	SERIES 90	S90-100PV
9621833	PUMP-VAR DISPL, CW	90-R-100-KA-1-NN-80-P-3-S1-E-03-GBA-20-20-24	SERIES 90	S90-100PV
9621834	PUMP-VAR DISPL, CW	90-R-100-CB-1-AB-60-P-4-S1-E-00-GBA-14-14-20	SERIES 90	S90-100PV
9621835	PUMP-VAR DISPL, CW	90-R-100-CB-1-CD-60-P-4-S1-E-00-GBA-14-14-20	SERIES 90	S90-100PV

9621836	PUMP-VAR DISPL, CW	90-R-100-KP-1-NN-60-S-3-T2-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9621837	PUMP-VAR DISPL, CW	90-R-100-KP-1-CD-80-R-4-T2-F-03-GBA-38-38-24	SERIES 90	S90-100PV
9621838	PUMP-VAR DISPL, CW	90-R-100-MA-1-AB-60-S-3-F1-F-03-GBA-48-48-24	SERIES 90	S90-100PV
9621839	PUMP-VAR DISPL, CW	90-R-100-KA-1-NN-80-S-4-S1-F-03-GBA-17-17-24	SERIES 90	S90-100PV
9621840	PUMP-VAR DISPL, CW	90-R-100-MA-1-CD-60-P-3-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9621843	PUMP-VAR DISPL, CW	90-R-100-HF-1-CD-80-R-3-F1-F-00-GBA-32-26-30	SERIES 90	S90-100PV
9621844	PUMP-VAR DISPL, CW	90-R-100-KP-1-NN-60-L-3-F1-E-03-GBA-14-26-24	SERIES 90	S90-100PV
9621845	PUMP-VAR DISPL, CW	90-R-100-MA-1-NN-80-S-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9621846	PUMP-VAR DISPL, CW	90-R-100-KP-1-BC-60-S-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
9621846C	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-BC-60-S-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
9621847	PUMP-VAR DISPL, CW	90-R-100-KP-1-CD-80-P-3-F1-E-03-GBA-45-45-28	SERIES 90	S90-100PV
9621848	PUMP-VAR DISPL, CW	90-R-100-KP-1-NN-80-P-3-S1-E-03-GBA-45-45-28	SERIES 90	S90-100PV
9621849	PUMP-VAR DISPL, CW	90-R-100-KP-1-BC-80-R-3-S1-F-03-GBA-29-20-24	SERIES 90	S90-100PV
9621850	PUMP-VAR DISPL, CW	90-R-100-KP-1-NN-80-R-3-S1-F-03-GBA-29-20-24	SERIES 90	S90-100PV
9621851	PUMP-VAR DISPL, CW	90-R-100-KP-6-CD-80-P-3-F1-E-03-GBA-45-45-28	SERIES 90	S90-100PV
9621852	PUMP-VAR DISPL, CW	90-R-100-KP-6-NN-80-P-3-S1-E-03-GBA-45-45-28	SERIES 90	S90-100PV
9621853	PUMP-VAR DISPL, CW	90-R-100-KN-1-AB-80-S-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9621854	PUMP-VAR DISPL, CW	90-R-100-KN-1-AB-80-S-3-S1-E-03-EBC-35-35-24	SERIES 90	S90-100PV
9621855	PUMP-VAR DISPL, CW	90-R-100-KA-1-BB-80-S-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
9621856	PUMP-VAR DISPL, CW	90-R-100-JA-1-BC-80-S-3-F1-E-03-GBA-35-35-28	SERIES 90	S90-100PV
9621857	PUMP-VAR DISPL, CW	90-R-100-HX-1-BC-80-S-3-S1-E-H1-GBA-32-32-24	SERIES 90	S90-100PV
9621858	PUMP-VAR DISPL, CW	90-R-100-KP-1-AB-80-R-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9621859	PUMP-VAR DISPL, CW	90-R-100-MA-1-AB-81-D-4-K3-L-00-GBA-23-23-24	SERIES 90	S90-100PV
9621860	PUMP-VAR DISPL, CW	90-R-100-KA-1-NN-80-S-3-C7-E-03-GBA-32-32-24	SERIES 90	S90-100PV
9621861	PUMP-VAR DISPL, CW	90-R-100-MA-1-NN-80-P-3-F1-E-03-GBA-29-29-24	SERIES 90	S90-100PV
9621862	PUMP-VAR DISPL, CW	90-R-100-KP-1-CJ-80-R-3-F1-F-00-GBA-42-26-30	SERIES 90	S90-100PV
9621863	PUMP-VAR DISPL, CW	90-R-100-EA-1-NN-80-R-3-S1-E-03-GBA-14-14-24	SERIES 90	S90-100PV
9621864	PUMP-VAR DISPL, CW	90-R-100-HW-M-BE-6P-R-F-C7-F-77-GBA-40-40-22-N180	SERIES 90	S90-100PV
9621865	PUMP-VAR DISPL, CW	90-R-100-KP-1-AB-80-R-3-S1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
9621866	PUMP-VAR DISPL, CW	90-R-100-CB-1-CD-60-P-4-F1-E-00-GBA-14-14-20	SERIES 90	S90-100PV
9621868	PUMP-VAR DISPL, CW	90-R-100-MA-1-AB-60-P-3-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9621869	PUMP-VAR DISPL, CW	90-R-100-KP-1-NN-60-S-3-F1-E-02-EBC-26-26-20	SERIES 90	S90-100PV
9621870	PUMP-VAR DISPL, CW	90-R-100-ME-1-BE-62-R-3-C7-E-02-GBA-42-42-24	SERIES 90	S90-100PV
9621871	PUMP-VAR DISPL, CW	90-R-100-KP-1-CD-80-R-2-F1-F-00-GBA-32-26-30	SERIES 90	S90-100PV
9621872	PUMP-VAR DISPL, CW	90-R-100-MV-1-BE-80-R-3-C7-E-03-GFK-45-45-24	SERIES 90	S90-100PV
9621873	PUMP-VAR DISPL, CW	90-R-100-KP-1-AB-80-R-3-S1-F-03-GBA-38-38-24	SERIES 90	S90-100PV

9621874	PUMP-VAR DISPL, CW	90-R-100-MA-1-NN-81-S-3-S1-E-03-GBA-23-23-24	SERIES 90	S90-100PV
9621875	PUMP-VAR DISPL, CW	90-R-100-KA-1-NN-80-L-3-K3-E-00-GBA-23-23-24	SERIES 90	S90-100PV
9621876	PUMP-VAR DISPL, CW	90-R-100-HF-1-CD-60-S-3-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9621877	PUMP-VAR DISPL, CW	90-R-100-KP-1-NN-80-P-3-C7-E-03-GBA-26-26-24	SERIES 90	S90-100PV
9621878	PUMP-VAR DISPL, CW	90-R-100-HF-1-NN-60-R-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9621879	PUMP-VAR DISPL, CW	90-R-100-HF-1-BC-80-S-3-S1-E-04-GBA-32-32-24	SERIES 90	S90-100PV
9621880	PUMP-VAR DISPL, CW	90-R-100-KP-1-NN-80-P-3-S1-E-03-GBA-38-38-24	SERIES 90	S90-100PV
9621881	PUMP-VAR DISPL, CW	90-R-100-KA-1-CD-60-L-3-T2-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9621882	PUMP-VAR DISPL, CW	90-R-100-MA-1-NN-80-S-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9621883	PUMP-VAR DISPL, CW	90-R-100-KA-1-BC-80-S-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9621884	PUMP-VAR DISPL, CW	90-R-100-KP-1-CD-80-S-3-T2-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9621885	PUMP-VAR DISPL, CW	90-R-100-MA-1-BB-60-P-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9621886	PUMP-VAR DISPL, CW	90-R-100-MV-1-BE-62-R-3-C7-E-03-GFK-42-42-24	SERIES 90	S90-100PV
9621887	PUMP-VAR DISPL, CW	90-R-100-KM-A-CE-89-R-3-J2-G-33-EGA-42-42-JD-N210	SERIES 90	S90-100PV
9621888	PUMP-VAR DISPL, CW	90-R-100-KM-A-CE-89-R-3-J3-G-33-FBC-42-42-JD-N330	SERIES 90	S90-100PV
9621889	PUMP-VAR DISPL, CW	90-R-100-KP-5-BC-81-S-3-S1-F-03-GBA-17-17-24	SERIES 90	S90-100PV
9621890	PUMP-VAR DISPL, CW	90-R-100-KA-1-NN-80-P-3-F1-E-02-GBA-32-32-26	SERIES 90	S90-100PV
9621891	PUMP-VAR DISPL, CW	90-R-100-KP-1-CD-80-L-3-F1-F-03-EBC-38-38-24	SERIES 90	S90-100PV
9621892	PUMP-VAR DISPL, CW	90-R-100-KA-1-NN-60-S-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9621892C	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-NN-60-S-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9621893	PUMP-VAR DISPL, CW	90-R-100-EP-1-NN-60-S-3-S1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
9621894	PUMP-VAR DISPL, CW	90-R-100-LE-1-CD-80-S-2-C7-E-03-GBA-38-17-28-F061	SERIES 90	S90-100PV
9621895	PUMP-VAR DISPL, CW	90-R-100-KP-1-BC-80-R-4-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9621896	PUMP-VAR DISPL, CW	90-R-100-KA-1-CD-60-S-3-F1-E-00-GBA-23-23-24	SERIES 90	S90-100PV
9621897	PUMP-VAR DISPL, CW	90-R-100-MV-1-CD-60-S-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9621898	PUMP-VAR DISPL, CW	90-R-100-KA-5-NN-60-S-3-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9621899	PUMP-VAR DISPL, CW	90-R-100-KA-5-NN-60-P-3-C7-E-03-GBA-32-32-24	SERIES 90	S90-100PV
9621969C	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-NN-60-P-3-S1-E-03-GBA-38-38-24	SERIES 90	S90-100PV
9621970C	PUMP-VAR DISPL, CW 90PV100	90-R-100-HF-1-NN-80-S-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9622001	PUMP-VAR DISPL, CCW	90-L-100-KP-G-BC-60-S-3-F1-E-03-GBA-29-29-20	SERIES 90	S90-100PV
9622002	PUMP-VAR DISPL, CCW	90-L-100-KA-G-CD-60-S-4-F1-E-03-GBA-23-23-20	SERIES 90	S90-100PV
9622003	PUMP-VAR DISPL, CCW	90-L-100-KP-G-BB-60-P-3-F1-E-03-GBA-38-38-24	SERIES 90	S90-100PV
9622004	PUMP-VAR DISPL, CCW	90-L-100-KP-G-CD-60-S-3-T2-E-03-GBA-32-32-26	SERIES 90	S90-100PV
9622005	PUMP-VAR DISPL, CCW	90-L-100-KP-G-NN-60-S-3-S1-E-03-GBA-32-32-26	SERIES 90	S90-100PV
9622006	PUMP-VAR DISPL, CCW	90-L-100-MA-1-BC-60-S-3-K3-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9622007	PUMP-VAR DISPL, CCW	90-L-100-KP-1-CD-80-S-3-F1-E-02-GBA-38-38-24	SERIES 90	S90-100PV

9622008	PUMP-VAR DISPL, CCW	90-L-100-KP-1-NN-80-S-3-S1-E-02-GBA-38-38-24	SERIES 90	S90-100PV
9622009	PUMP-VAR DISPL, CCW	90-L-100-KP-1-NN-60-R-3-F1-E-03-GBA-29-29-24	SERIES 90	S90-100PV
9622010	PUMP-VAR DISPL, CCW	90-L-100-KP-1-BC-80-R-3-F1-F-03-GBA-38-38-24	SERIES 90	S90-100PV
9622011	PUMP-VAR DISPL, CCW	90-L-100-KP-2-NN-80-R-3-F1-F-03-GBA-38-38-24	SERIES 90	S90-100PV
9622012	PUMP-VAR DISPL, CCW	90-L-100-MA-1-BC-60-S-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9622013	PUMP-VAR DISPL, CCW	90-L-100-CB-1-NN-80-S-4-F1-E-00-FAC-38-38-24	SERIES 90	S90-100PV
9622014	PUMP-VAR DISPL, CCW	90-L-100-KA-7-BC-60-L-3-F1-F-00-GBA-45-45-28	SERIES 90	S90-100PV
9622015	PUMP-VAR DISPL, CCW	90-L-100-KP-1-NN-65-R-3-F3-F-00-GBA-35-29-18	SERIES 90	S90-100PV
9622017	PUMP-VAR DISPL, CCW	90-L-100-KA-1-CD-60-R-3-F1-E-03-FAB-42-42-24	SERIES 90	S90-100PV
9622018	PUMP-VAR DISPL, CCW	90-L-100-KP-1-CD-80-R-3-F1-F-03-GBA-38-38-24	SERIES 90	S90-100PV
9622019	PUMP-VAR DISPL, CCW	90-L-100-KP-1-BC-80-R-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-100PV
9622020	PUMP-VAR DISPL, CCW	90-L-100-HF-1-BC-60-R-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9622021	PUMP-VAR DISPL, CCW	90-L-100-KA-1-NN-60-L-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9622022	PUMP-VAR DISPL, CCW	90-L-100-KA-1-NN-60-P-3-F1-E-03-GBA-35-35-20	SERIES 90	S90-100PV
9622023	PUMP-VAR DISPL, CCW	90-L-100-KP-1-NN-80-S-3-T2-E-03-GBA-38-38-24	SERIES 90	S90-100PV
9622024	PUMP-VAR DISPL, CCW	90-L-100-CB-1-NN-60-L-3-F1-E-00-FAC-38-38-24	SERIES 90	S90-100PV
9622025	PUMP-VAR DISPL, CCW	90-L-100-KA-6-BC-60-P-3-T2-E-03-GBA-45-45-28	SERIES 90	S90-100PV
9622026	PUMP-VAR DISPL, CCW	90-L-100-KP-1-CD-80-R-3-F1-E-03-GBA-35-35-20	SERIES 90	S90-100PV
9622027	PUMP-VAR DISPL, CCW	90-L-100-MA-6-CD-80-S-4-F1-F-03-GBA-45-45-24	SERIES 90	S90-100PV
9622028	PUMP-VAR DISPL, CCW	90-L-100-HM-G-NN-60-P-3-F1-E-04-GBA-32-32-24	SERIES 90	S90-100PV
9622030	PUMP-VAR DISPL, CCW	90-L-100-KA-1-NN-80-R-4-F1-D-03-GBA-38-38-24	SERIES 90	S90-100PV
9622031	PUMP-VAR DISPL, CCW	90-L-100-EA-1-CD-60-P-3-F1-E-00-GBA-42-42-24	SERIES 90	S90-100PV
9622032	PUMP-VAR DISPL, CCW	90-L-100-KP-1-NN-80-P-3-T2-E-03-GBA-23-23-24	SERIES 90	S90-100PV
9622033	PUMP-VAR DISPL, CCW	90-L-100-KP-1-NN-80-P-4-T2-E-03-GBA-23-23-24	SERIES 90	S90-100PV
9622034	PUMP-VAR DISPL, CCW	90-L-100-KP-1-CD-80-P-3-F1-E-04-GBA-42-42-24	SERIES 90	S90-100PV
9622035	PUMP-VAR DISPL CCW 90PV100	90-L-100-KP-1-AB-80-P-3-F1-E-04-FAD-42-42-24	SERIES 90	S90-100PV
9622036	PUMP-VAR DISPL CCW 90PV100	90-L-100-KP-1-CD-80-P-3-F1-E-04-FAD-42-42-24	SERIES 90	S90-100PV
9622037	PUMP-VAR DISPL, CCW	90-L-100-KP-1-CD-80-P-3-F1-D-03-FAD-42-42-24	SERIES 90	S90-100PV
9622038	PUMP-VAR DISPL, CCW	90-L-100-KP-1-AB-80-P-3-F1-D-03-FAD-42-42-24	SERIES 90	S90-100PV
9622039	PUMP-VAR-DISPL CCW 90PV100	90L100-KP-1-CD-80-S-3-F1-D-03-FAD-42-42-24	SERIES 90	S90-100PV
9622040	PUMP-VAR-DISPL CCW 90PV100	90L100-KP-1-AB-80-S-3-F1-D-03-FAD-42-42-24	SERIES 90	S90-100PV
9622041	PUMP-VAR DISPL, CCW	90-L-100-KP-1-NN-60-L-3-F1-E-03-GBA-29-29-24	SERIES 90	S90-100PV
9622042	PUMP-VAR DISPL, CCW	90-L-100-KP-1-NN-80-R-3-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9622043	PUMP-VAR DISPL, CCW	90-L-100-EA-2-NN-80-S-3-S1-F-33-GBA-38-07-20	SERIES 90	S90-100PV
9622044	PUMP-VAR DISPL, CCW	90-L-100-KA-1-AB-80-L-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9622045	PUMP-VAR DISPL, CCW	90-L-100-KA-1-NN-80-L-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV

9622048	PUMP-VAR DISPL, CCW	90-L-100-CB-1-CD-80-R-3-F1-F-00-GBA-26-26-24	SERIES 90	S90-100PV
9622049	PUMP-VAR DISPL, CCW	90-L-100-KP-G-CD-60-R-3-T2-E-03-GBA-35-35-26	SERIES 90	S90-100PV
9622050	PUMP-VAR DISPL, CCW	90-L-100-KP-G-NN-60-R-3-S1-E-03-GBA-35-35-26	SERIES 90	S90-100PV
9622051	PUMP-VAR DISPL, CCW	90-L-100-KP-1-NN-80-R-3-T2-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9622052	PUMP-VAR DISPL, CCW	90-L-100-HK-1-NN-60-S-3-S1-F-00-GBA-07-38-20	SERIES 90	S90-100PV
9622053	PUMP-VAR DISPL, CCW	90-L-100-HK-1-CD-60-S-3-S1-F-00-GBA-38-07-20	SERIES 90	S90-100PV
9622054	PUMP-VAR DISPL, CCW	90-L-100-EP-1-CD-60-L-3-F1-E-03-GBA-29-29-24	SERIES 90	S90-100PV
9622055	PUMP-VAR DISPL, CCW	90-L-100-KA-1-BC-60-P-3-F1-E-03-GBA-32-32-24	SERIES 90	S90-100PV
9622056	PUMP-VAR DISPL, CCW	90-L-100-MA-1-CD-80-S-3-F1-F-06-GBA-32-26-24	SERIES 90	S90-100PV
9622057	PUMP-VAR DISPL, CCW	90-L-100-DC-1-NN-60-S-3-F1-E-GB-GBA-23-23-24	SERIES 90	S90-100PV
9622059	PUMP-VAR DISPL, CCW	90-L-100-EA-2-NN-60-S-3-S1-F-33-GBA-07-38-20	SERIES 90	S90-100PV
9622060	PUMP-VAR DISPL, CCW	90-L-100-KP-1-BC-60-L-3-F1-E-03-GBA-38-38-24	SERIES 90	S90-100PV
9622061	PUMP-VAR DISPL, CCW	90-L-100-MA-1-NN-60-S-3-S1-E-03-GBA-26-26-24	SERIES 90	S90-100PV
9622062	PUMP-VAR DISPL, CCW	90-L-100-KP-1-CD-60-S-4-C6-F-04-EBE-42-42-24	SERIES 90	S90-100PV
9622063	PUMP-VAR DISPL, CCW	90-L-100-EP-1-NN-60-S-3-S1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
9622064	PUMP-VAR DISPL, CCW	90-L-100-KP-1-BC-80-P-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9622065	PUMP-VAR DISPL, CCW	90-L-100-MA-6-CD-80-S-4-F1-E-03-GBA-45-45-28	SERIES 90	S90-100PV
9622066	PUMP-VAR DISPL, CCW	90-L-100-KP-1-BC-60-R-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9622067	PUMP-VAR DISPL, CCW	90-L-100-KP-1-CD-60-R-3-T2-E-03-GBA-32-32-26	SERIES 90	S90-100PV
9622068	PUMP-VAR DISPL, CCW	90-L-100-KP-1-CD-60-R-3-S1-E-03-GBA-32-32-26	SERIES 90	S90-100PV
9622069	PUMP-VAR DISPL, CCW	90-L-100-KP-1-CD-60-R-3-T2-E-03-GBA-26-26-26	SERIES 90	S90-100PV
9622070	PUMP-VAR DISPL, CCW	90-L-100-KP-1-CD-60-R-3-S1-E-03-GBA-26-26-26	SERIES 90	S90-100PV
9622071	PUMP-VAR DISPL, CCW	90-L-100-KP-1-NN-60-R-3-S1-E-03-GBA-32-32-26	SERIES 90	S90-100PV
9622071C	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-NN-60-R-3-S1-E-03-GBA-32-32-26	SERIES 90	S90-100PV
9622072	PUMP-VAR DISPL, CCW	90-L-100-KP-1-NN-60-R-3-S1-E-03-GBA-26-26-26	SERIES 90	S90-100PV
9622073	PUMP-VAR DISPL, CCW	90-L-100-KP-G-CD-60-R-3-T2-E-03-GBA-26-26-26	SERIES 90	S90-100PV
9622074	PUMP-VAR DISPL, CCW	90-L-100-KP-G-NN-60-R-3-S1-E-03-GBA-26-26-26	SERIES 90	S90-100PV
9622075	PUMP-VAR DISPL, CCW	90-L-100-KP-1-BB-80-R-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9622077	PUMP-VAR DISPL, CCW	90-L-100-KP-1-NN-80-R-3-F1-F-03-GBA-26-26-24	SERIES 90	S90-100PV
9622078	PUMP-VAR DISPL, CCW	90-L-100-EA-2-BC-80-R-3-F1-F-00-GBA-35-35-24	SERIES 90	S90-100PV
9622079	PUMP-VAR DISPL, CCW	90-L-100-MA-1-NN-80-S-3-T2-F-03-GBA-35-35-24	SERIES 90	S90-100PV
9622080	PUMP-VAR DISPL, CCW	90-L-100-KA-1-NN-80-S-3-F1-E-00-GBA-32-32-24	SERIES 90	S90-100PV
9622081	PUMP-VAR DISPL, CCW	90-L-100-KA-2-NN-80-S-4-S1-E-33-GBA-42-42-24	SERIES 90	S90-100PV
9622082	PUMP-VAR DISPL, CCW	90-L-100-KP-G-BC-60-S-3-S1-E-00-GBG-14-14-08	SERIES 90	S90-100PV
9622083	PUMP-VAR DISPL, CCW	90-L-100-KP-G-CD-60-S-3-F1-E-00-GBG-14-14-08	SERIES 90	S90-100PV
9622084	PUMP-VAR DISPL, CCW	90-L-100-EH-2-AB-60-L-F-F1-E-33-GBA-38-38-24	SERIES 90	S90-100PV

9622085	PUMP-VAR DISPL, CCW	90-L-100-KA-1-AB-80-S-3-F1-E-00-GBA-32-32-24	SERIES 90	S90-100PV
9622086	PUMP-VAR DISPL, CCW	90-L-100-KA-1-CD-80-S-3-F1-E-00-GBA-32-32-24	SERIES 90	S90-100PV
9622089	PUMP-VAR DISPL, CCW	90-L-100-HS-1-AB-60-S-4-S3-E-03-GBA-38-38-24	SERIES 90	S90-100PV
9622090	PUMP-VAR DISPL, CCW	90-L-100-HS-1-NN-60-S-4-S3-E-03-GBA-38-38-24	SERIES 90	S90-100PV
9622091	PUMP-VAR DISPL, CCW	90-L-100-KP-1-NN-60-R-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9622091C	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-NN-60-R-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9622092	PUMP-VAR DISPL, CCW	90-L-100-MA-1-CD-60-S-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9622093	PUMP-VAR DISPL, CCW	90-L-100-KA-1-CD-60-R-3-K3-F-03-GBA-38-38-24	SERIES 90	S90-100PV
9622094	PUMP-VAR DISPL, CCW	90-L-100-KP-2-CD-60-L-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9622095	PUMP-VAR DISPL, CCW	90-L-100-KP-2-NN-60-L-3-S1-E-03-GFD-42-42-28	SERIES 90	S90-100PV
9622096	PUMP-VAR DISPL, CCW	90-L-100-KP-1-AB-60-R-3-F1-E-03-GBA-29-29-24	SERIES 90	S90-100PV
9622097	PUMP-VAR DISPL, CCW	90-L-100-KP-2-CD-60-L-3-C7-E-03-GBA-42-42-28	SERIES 90	S90-100PV
9622099	PUMP-VAR DISPL, CCW	90-L-100-EA-1-NN-60-P-3-S1-D-03-GBA-35-35-24	SERIES 90	S90-100PV
9622100	PUMP-VAR DISPL, CCW	90-L-100-KP-1-CD-80-S-3-F1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
9622101	PUMP-VAR DISPL, CCW	90-L-100-HF-1-AB-80-S-3-S1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
9622102	PUMP-VAR DISPL, CCW	90-L-100-KP-2-AB-80-S-3-T2-F-03-GBA-48-48-28	SERIES 90	S90-100PV
9622103	PUMP-VAR DISPL, CCW	90-L-100-KA-1-CD-60-R-3-F1-F-03-FAB-42-42-28	SERIES 90	S90-100PV
9622104	PUMP-VAR DISPL, CCW	90-L-100-KN-1-NN-60-R-3-S1-E-03-GBA-42-42-26	SERIES 90	S90-100PV
9622105	PUMP-VAR DISPL, CCW	90-L-100-MV-1-AB-80-S-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
9622106	PUMP-VAR DISPL, CCW	90-L-100-KP-1-BC-80-R-3-F1-E-02-GBA-42-42-24	SERIES 90	S90-100PV
9622107	PUMP-VAR DISPL, CCW	90-L-100-HM-1-BC-80-R-3-F1-E-02-GBA-42-42-24	SERIES 90	S90-100PV
9622108	PUMP-VAR DISPL, CCW	90-L-100-KP-1-NN-80-S-4-C7-F-04-FAD-42-42-24	SERIES 90	S90-100PV
9622109	PUMP-VAR DISPL, CCW	90-L-100-KP-2-NN-60-L-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9622110	PUMP-VAR DISPL, CCW	90-L-100-MA-1-BC-80-P-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9622111	PUMP-VAR DISPL, CCW	90-L-100-EP-2-AB-60-L-F-F1-E-33-GBA-35-35-24	SERIES 90	S90-100PV
9622112	PUMP-VAR DISPL, CCW	90-L-100-EA-1-BC-60-P-3-T2-E-03-GBA-42-14-24	SERIES 90	S90-100PV
9622113	PUMP-VAR DISPL, CCW	90-L-100-KP-6-CD-60-S-3-TF-D-02-GBA-48-48-24	SERIES 90	S90-100PV
9622114	PUMP-VAR DISPL, CCW	90-L-100-KP-1-BB-80-L-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9622115	PUMP-VAR DISPL, CCW	90-L-100-KP-1-CD-80-S-3-F1-F-03-GBA-38-38-24	SERIES 90	S90-100PV
9622116	PUMP-VAR DISPL, CCW	90-L-100-DC-1-CD-80-S-4-F1-F-GB-GBA-23-23-24	SERIES 90	S90-100PV
9622118	PUMP-VAR DISPL, CCW	90-L-100-EA-1-NN-60-S-4-S1-F-03-GBA-23-23-30	SERIES 90	S90-100PV
9622119	PUMP-VAR DISPL, CCW	90-L-100-MB-1-NN-60-P-4-S1-E-03-GBA-32-32-24	SERIES 90	S90-100PV
9622119C	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MB-1-NN-60-P-4-S1-E-03-GBA-32-32-24	SERIES 90	S90-100PV
9622120	PUMP-VAR DISPL, CCW	90-L-100-KP-1-BC-60-R-4-F1-F-03-GBA-26-26-24	SERIES 90	S90-100PV
9622121	PUMP-VAR DISPL, CCW	90-L-100-KP-1-BC-60-R-4-F1-F-03-GBA-23-23-24	SERIES 90	S90-100PV
9622124	PUMP-VAR DISPL, CCW	90-L-100-MA-1-AB-60-S-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-100PV

9622125	PUMP-VAR DISPL, CCW	90-L-100-EK-7-CD-80-R-3-F1-F-33-GBA-45-45-24	SERIES 90	S90-100PV
9622126	PUMP-VAR DISPL, CCW	90-L-100-EK-7-NN-80-R-3-S1-F-33-GBA-45-45-24	SERIES 90	S90-100PV
9622127	PUMP-VAR DISPL, CCW	90-L-100-KP-1-CD-80-S-3-S1-D-03-GBA-23-23-24	SERIES 90	S90-100PV
9622128	PUMP-VAR DISPL, CCW	90-L-100-KP-1-BC-60-S-4-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9622129	PUMP-VAR DISPL, CCW	90-L-100-MT-1-AB-60-3-3-F1-F-02-GFK-35-35-20	SERIES 90	S90-100PV
9622130	PUMP-VAR DISPL, CCW	90-L-100-EP-H-CD-80-R-3-F1-E-64-GBA-AD-42-24	SERIES 90	S90-100PV
9622131	PUMP-VAR DISPL, CCW	90-L-100-EP-H-NN-80-R-3-S1-E-64-GBA-AD-42-24	SERIES 90	S90-100PV
9622134	PUMP-VAR DISPL, CCW	90-L-100-KP-G-CD-60-R-3-T2-E-03-GBA-23-23-24	SERIES 90	S90-100PV
9622135	PUMP-VAR DISPL, CCW	90-L-100-KP-G-NN-60-R-3-S1-E-03-GBA-23-23-24	SERIES 90	S90-100PV
9622136	PUMP-VAR DISPL, CCW	90-L-100-KP-G-CD-60-R-3-T2-E-03-GBA-32-32-24	SERIES 90	S90-100PV
9622137	PUMP-VAR DISPL, CCW	90-L-100-KP-G-NN-60-R-3-S1-E-03-GBA-32-32-24	SERIES 90	S90-100PV
9622138	PUMP-VAR DISPL, CCW	90-L-100-MA-1-NN-60-L-3-C7-E-03-GBA-20-20-24	SERIES 90	S90-100PV
9622138C	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MA-1-NN-60-L-3-C7-E-03-GBA-20-20-24	SERIES 90	S90-100PV
9622139	PUMP-VAR DISPL, CCW	90-L-100-KP-1-CD-80-S-3-F1-D-02-GBA-23-23-24	SERIES 90	S90-100PV
9622140	PUMP-VAR DISPL, CCW	90-L-100-KP-5-NN-80-R-4-F1-F-03-GBA-32-32-24	SERIES 90	S90-100PV
9622141	PUMP-VAR DISPL, CCW	90-L-100-KP-1-CD-80-S-3-F1-E-02-GBA-35-35-24	SERIES 90	S90-100PV
9622142	PUMP-VAR DISPL, CCW	90-L-100-KP-2-NN-60-L-3-S1-E-03-FBC-42-42-28	SERIES 90	S90-100PV
9622143	PUMP-VAR DISPL, CCW	90-L-100-KP-2-CD-60-L-3-F1-E-03-FBC-42-42-28	SERIES 90	S90-100PV
9622144	PUMP-VAR DISPL, CCW	90-L-100-MA-1-AB-80-S-3-T2-E-03-GBA-32-32-24	SERIES 90	S90-100PV
9622145	PUMP-VAR DISPL, CW	90-R-100-KT-1-CD-80-P-3-S1-F-03-EKA-45-45-24	SERIES 90	S90-100PV
9622146	PUMP-VAR DISPL, CCW	90-L-100-EA-1-BC-60-S-3-F1-E-03-GBA-38-38-24	SERIES 90	S90-100PV
9622147	PUMP-VAR DISPL, CCW	90-L-100-KP-6-CD-60-S-3-TF-F-03-GBA-48-48-24	SERIES 90	S90-100PV
9622148	PUMP-VAR DISPL, CCW	90-L-100-MA-1-NN-60-P-3-F1-E-00-GBA-42-42-24	SERIES 90	S90-100PV
9622150	PUMP-VAR DISPL, CCW	90-L-100-KA-1-NN-60-S-3-S1-E-03-GBA-32-32-24	SERIES 90	S90-100PV
9622151	PUMP-VAR DISPL, CCW	90-L-100-KP-7-AB-80-S-3-T2-F-03-GBA-45-45-24	SERIES 90	S90-100PV
9622154	PUMP-VAR DISPL, CCW	90-L-100-KP-G-CD-80-P-3-S1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
9622155	PUMP-VAR DISPL, CCW	90-L-100-M1-1-NN-80-S-3-TF-E-03-FAC-45-45-28	SERIES 90	S90-100PV
9622156	PUMP-VAR DISPL, CCW	90-L-100-MB-1-NN-80-R-3-F1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
9622157	PUMP-VAR DISPL, CCW	90-L-100-KA-1-NN-80-P-3-S1-E-00-GBA-42-42-24	SERIES 90	S90-100PV
9622158	PUMP-VAR DISPL, CCW	90-L-100-KA-1-CD-80-P-3-C7-E-00-EEB-42-42-24	SERIES 90	S90-100PV
9622159	PUMP-VAR DISPL, CCW	90-L-100-HK-5-AC-60-R-3-F1-E-05-GBA-35-35-24	SERIES 90	S90-100PV
9622160	PUMP-VAR DISPL, CCW	90-L-100-MA-1-NN-60-S-3-F1-E-03-GBA-26-26-24	SERIES 90	S90-100PV
9622161	PUMP-VAR DISPL, CCW	90-L-100-KP-1-AB-80-S-3-F1-E-04-FAD-42-42-24	SERIES 90	S90-100PV
9622162	PUMP-VAR DISPL, CCW	90-L-100-KP-1-CD-80-S-3-F1-E-04-FAD-42-42-24	SERIES 90	S90-100PV
9622164	PUMP-VAR DISPL, CCW	90-L-100-KP-1-CD-80-P-3-F1-E-03-GBA-26-26-24	SERIES 90	S90-100PV
9622165	PUMP-VAR DISPL, CCW	90-L-100-KP-1-BC-80-R-3-F1-F-00-GBA-35-35-24	SERIES 90	S90-100PV

9622166	PUMP-VAR DISPL, CCW	90-L-100-KA-1-NN-80-S-3-K3-E-06-GBA-23-23-24	SERIES 90	S90-100PV
9622167	PUMP-VAR DISPL, CCW	90-L-100-KA-1-CD-80-P-3-F1-E-00-EEB-42-42-24	SERIES 90	S90-100PV
9622168	PUMP-VAR-DISPL CCW 90PV100	90-L-100-KP-1-NN-81-P-4-S1-D-03-GBA-35-35-24	SERIES 90	S90-100PV
9622169	PUMP-VAR DISPL, CCW	90-L-100-MS-1-NN-80-L-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
9622170	PUMP-VAR DISPL, CCW	90-L-100-KP-1-CD-80-R-4-T2-F-03-GBA-38-38-24	SERIES 90	S90-100PV
9622171	PUMP-VAR DISPL, CCW	90-L-100-MA-1-AC-60-S-3-T2-E-03-GBA-45-45-24	SERIES 90	S90-100PV
9622172	PUMP-VAR DISPL, CCW	90-L-100-KP-1-BC-80-R-4-T2-F-03-GBA-38-38-24	SERIES 90	S90-100PV
9622173	PUMP-VAR DISPL, CCW	90-L-100-KP-1-BB-60-R-3-F1-E-03-GBA-14-35-24	SERIES 90	S90-100PV
9622174	PUMP-VAR DISPL, CCW	90-L-100-MB-1-BC-60-L-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
9622176	PUMP-VAR DISPL, CCW	90-L-100-MV-1-NN-80-S-3-S1-E-02-GBA-38-38-24	SERIES 90	S90-100PV
9622177	PUMP-VAR DISPL, CCW	90-L-100-MA-1-NN-80-S-4-S1-E-03-GBA-38-38-24	SERIES 90	S90-100PV
9622178	PUMP-VAR DISPL, CCW	90-L-100-MA-1-CD-80-S-4-F1-E-03-GBA-38-38-24	SERIES 90	S90-100PV
9622179	PUMP-VAR DISPL, CCW	90-L-100-KA-1-CD-80-S-4-F1-E-03-GBA-38-38-24	SERIES 90	S90-100PV
9622180	PUMP-VAR DISPL, CCW	90-L-100-DC-1-NN-80-P-3-T2-E-GB-GBA-35-35-24	SERIES 90	S90-100PV
9622181	PUMP-VAR DISPL, CCW	90-L-100-MV-1-BC-80-R-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9622182	PUMP-VAR DISPL, CCW	90-L-100-KA-1-AB-61-P-3-F1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
9622183	PUMP-VAR DISPL, CCW	90-L-100-MV-1-BC-80-R-3-S1-E-29-GBA-42-42-24	SERIES 90	S90-100PV
9622184	PUMP-VAR DISPL, CCW	90-L-100-KP-1-BC-80-S-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9622185	PUMP-VAR DISPL, CCW	90-L-100-KP-1-CD-80-L-3-F1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
9622186	PUMP-VAR DISPL, CCW	90-L-100-KP-1-CD-80-L-3-S1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
9622187	PUMP-VAR DISPL, CCW	90-L-100-MA-1-BC-80-L-3-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9622188	PUMP-VAR DISPL, CCW	90-L-100-KP-1-NN-60-S-3-T2-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9622189	PUMP-VAR DISPL, CCW	90-L-100-KP-2-BB-80-P-3-F1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
9622190	PUMP-VAR DISPL, CCW	90-L-100-KP-2-BB-80-P-3-S1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
9622191	PUMP-VAR DISPL, CCW	90-L-100-KP-2-CD-80-P-3-F1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
9622192	PUMP-VAR DISPL, CCW	90-L-100-KP-1-BC-60-R-4-F1-F-02-GBA-23-23-24	SERIES 90	S90-100PV
9622193	PUMP-VAR DISPL, CCW	90-L-100-KP-1-BB-80-L-3-S1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
9622195	PUMP-VAR DISPL, CCW	90-L-100-HS-1-NN-60-R-4-F1-E-05-FBC-32-32-28	SERIES 90	S90-100PV
9622196	PUMP-VAR DISPL, CCW	90-L-100-HF-5-NN-80-R-3-F1-F-04-GBA-43-43-30	SERIES 90	S90-100PV
9622197	PUMP-VAR DISPL, CCW	90-L-100-KP-1-BC-60-R-3-S1-E-00-GBA-38-38-24	SERIES 90	S90-100PV
9622198	PUMP-VAR DISPL, CCW	90-L-100-MB-1-NN-80-S-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9622199	PUMP-VAR DISPL, CCW	90-L-100-MV-2-CD-80-P-4-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9622200	PUMP-VAR DISPL, CCW	90-L-100-MA-1-BB-60-R-3-F1-E-03-FAD-42-42-24	SERIES 90	S90-100PV
9622201	PUMP-VAR DISPL, CCW	90-L-100-KP-1-NN-80-R-3-F1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
9622202	PUMP-VAR DISPL, CCW	90-L-100-KP-5-NN-80-R-3-F1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
9622203	PUMP-VAR DISPL, CCW	90-L-100-EP-1-NN-60-S-3-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV

9622204	PUMP-VAR DISPL, CCW	90-L-100-EP-1-BB-80-L-3-F1-F-02-GBA-35-35-24	SERIES 90	S90-100PV
9622205	PUMP-VAR DISPL, CCW	90-L-100-EP-1-BB-80-R-3-F1-F-02-GBA-35-35-24	SERIES 90	S90-100PV
9622206	PUMP-VAR DISPL, CCW	90-L-100-MV-2-CD-80-L-4-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9622207	PUMP-VAR DISPL, CCW	90-L-100-MV-2-NN-80-L-4-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9622208	PUMP-VAR DISPL, CCW	90-L-100-KA-1-NN-80-R-4-F1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
9622209	PUMP-VAR DISPL, CCW	90-L-100-MA-1-NN-80-L-3-F1-F-03-GBA-38-38-24	SERIES 90	S90-100PV
9622210	PUMP-VAR DISPL, CCW	90-L-100-FA-5-NN-60-R-7-F1-F-B1-GCA-42-42-28	SERIES 90	S90-100PV
9622211	PUMP-VAR DISPL, CCW	90-L-100-KN-1-NN-80-R-4-F1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
9622212	PUMP-VAR DISPL, CCW	90-L-100-HF-1-BC-60-R-3-F1-E-05-GBA-38-38-24	SERIES 90	S90-100PV
9622213	PUMP-VAR DISPL, CCW	90-L-100-MV-1-NN-80-R-3-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9622214	PUMP-VAR DISPL, CCW	90-L-100-MV-1-BB-60-R-3-F1-E-03-FAD-42-42-24	SERIES 90	S90-100PV
9622215	PUMP-VAR DISPL, CCW	90-L-100-MV-1-NN-80-R-3-F1-E-03-FAD-42-42-24	SERIES 90	S90-100PV
9622216	PUMP-VAR DISPL, CCW	90-L-100-KP-1-NN-80-L-4-S1-E-02-GBA-29-29-24	SERIES 90	S90-100PV
9622216C	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-NN-80-L-4-S1-E-02-GBA-29-29-24	SERIES 90	S90-100PV
9622217	PUMP-VAR DISPL, CCW	90-L-100-KP-1-NN-80-S-3-S1-E-03-GBA-40-40-24	SERIES 90	S90-100PV
9622219	PUMP-VAR DISPL, CCW	90-L-100-HF-1-AC-60-R-3-F1-E-05-GBA-38-38-24	SERIES 90	S90-100PV
9622220	PUMP-VAR DISPL, CCW	90-L-100-HF-1-AC-60-R-3-F1-E-05-GBA-35-35-24	SERIES 90	S90-100PV
9622222	PUMP-VAR DISPL, CCW	90-L-100-JA-1-NN-60-R-4-F1-E-05-FAD-32-32-28-F023	SERIES 90	S90-100PV
9622223	PUMP-VAR DISPL, CCW	90-L-100-JA-1-AB-60-R-3-F1-E-05-FAD-32-32-28	SERIES 90	S90-100PV
9622224	PUMP-VAR DISPL, CCW	90-L-100-KP-1-NN-80-R-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
9622226	PUMP-VAR DISPL, CCW	90-L-100-KP-1-CD-60-L-4-F1-E-03-GBA-29-29-24	SERIES 90	S90-100PV
9622227	PUMP-VAR DISPL, CCW	90-L-100-HM-1-CD-60-L-4-S1-E-03-GBA-29-29-24	SERIES 90	S90-100PV
9622228	PUMP-VAR DISPL, CCW	90-L-100-KA-1-CD-60-R-3-F1-F-03-FAD-42-42-28	SERIES 90	S90-100PV
9622229	PUMP-VAR DISPL, CCW	90-L-100-KA-1-NN-60-R-3-F1-E-03-FAD-42-42-28	SERIES 90	S90-100PV
9622230	PUMP-VAR DISPL, CCW	90-L-100-KA-1-CD-60-R-3-F1-E-03-FAD-42-42-28	SERIES 90	S90-100PV
9622231	PUMP-VAR DISPL, CCW	90-L-100-HS-5-NN-80-R-3-F1-F-04-GBA-43-43-30	SERIES 90	S90-100PV
9622232	PUMP-VAR DISPL, CCW	90-L-100-KP-G-CD-60-R-3-F1-F-03-GBA-23-23-24	SERIES 90	S90-100PV
9622233	PUMP-VAR DISPL, CCW	90-L-100-KP-G-CD-60-R-3-F1-F-03-GBA-32-32-24	SERIES 90	S90-100PV
9622234	PUMP-VAR DISPL, CCW	90-L-100-KP-1-CD-60-P-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9622235	PUMP-VAR DISPL, CCW	90-L-100-HS-5-NN-80-R-4-F1-F-03-GBA-43-43-30	SERIES 90	S90-100PV
9622236	PUMP-VAR DISPL, CCW	90-L-100-HF-1-BC-60-D-3-F1-L-05-GBA-38-38-24	SERIES 90	S90-100PV
9622237	PUMP-VAR DISPL, CCW	90-L-100-HF-1-BC-60-D-3-F1-L-05-GBA-35-35-24	SERIES 90	S90-100PV
9622238	PUMP-VAR DISPL, CCW	90-L-100-KN-1-CD-80-P-4-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9622239	PUMP-VAR DISPL, CCW	90-L-100-HF-1-AC-60-D-3-F1-L-05-GBA-38-38-24	SERIES 90	S90-100PV
9622240	PUMP-VAR DISPL, CCW	90-L-100-HF-1-AC-60-D-3-F1-L-05-GBA-35-35-24	SERIES 90	S90-100PV
9622242	PUMP-VAR DISPL, CCW	90-L-100-KP-1-BC-80-S-3-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV

9622243	PUMP-VAR DISPL, CCW	90-L-100-KP-T-NN-80-R-4-F1-F-03-GBA-AG-AG-24	SERIES 90	S90-100PV
9622244	PUMP-VAR DISPL, CCW	90-L-100-KP-1-AC-60-R-3-F1-E-03-GBA-14-32-24	SERIES 90	S90-100PV
9622245	PUMP-VAR DISPL, CCW	90-L-100-KP-6-CD-60-S-3-TF-D-00-GBA-48-48-24	SERIES 90	S90-100PV
9622246	PUMP-VAR DISPL, CCW	90-L-100-KP-G-NN-60-R-3-S1-F-03-GBA-23-23-24	SERIES 90	S90-100PV
9622247	PUMP-VAR DISPL, CCW	90-L-100-KP-G-NN-60-R-3-S1-F-03-GBA-32-32-24	SERIES 90	S90-100PV
9622248	PUMP-VAR DISPL, CCW	90-L-100-KA-1-AB-80-R-3-F1-E-03-GBA-23-23-24	SERIES 90	S90-100PV
9622249	PUMP-VAR DISPL, CCW	90-L-100-KA-1-AB-81-P-3-F1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
9622250	PUMP-VAR DISPL, CCW	90-L-100-KA-1-NN-80-L-3-S1-E-00-GBA-38-14-24	SERIES 90	S90-100PV
9622251	PUMP-VAR DISPL, CCW	90-L-100-KA-1-NN-80-R-4-F1-F-03-GBA-23-23-24	SERIES 90	S90-100PV
9622252	PUMP-VAR DISPL, CCW	90-L-100-KA-1-BC-80-S-3-F1-E-03-GBA-29-29-28	SERIES 90	S90-100PV
9622253	PUMP-VAR DISPL, CCW	90-L-100-CB-1-BC-80-S-3-F1-E-00-GBA-29-29-28	SERIES 90	S90-100PV
9622254	PUMP-VAR DISPL, CCW	90-L-100-KP-1-BB-80-P-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9622255	PUMP-VAR DISPL, CCW	90-L-100-KP-1-CD-80-R-3-F1-D-03-GBA-42-42-24	SERIES 90	S90-100PV
9622256	PUMP-VAR DISPL, CCW	90-L-100-KP-1-CD-80-S-3-F1-D-03-FAD-45-45-24	SERIES 90	S90-100PV
9622257	PUMP-VAR DISPL, CCW	90-L-100-KP-1-AB-80-S-3-F1-D-03-FAD-45-45-24	SERIES 90	S90-100PV
9622258	PUMP-VAR DISPL, CCW	90-L-100-KP-1-NN-80-P-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9622259	PUMP-VAR DISPL, CCW	90-L-100-KP-1-AB-80-P-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9622260	PUMP-VAR DISPL, CCW	90-L-100-MS-1-AB-60-P-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
9622261	PUMP-VAR DISPL, CCW	90-L-100-MV-1-BB-80-R-3-F1-E-03-FAD-42-42-24	SERIES 90	S90-100PV
9622262	PUMP-VAR DISPL, CCW	90-L-100-MS-1-AB-80-S-3-F1-E-04-FAD-42-42-24	SERIES 90	S90-100PV
9622263	PUMP-VAR DISPL, CCW	90-L-100-MS-1-CD-80-S-3-F1-E-04-FAD-42-42-24	SERIES 90	S90-100PV
9622264	PUMP-VAR DISPL, CCW	90-L-100-KA-1-CD-60-L-3-F1-E-02-FAD-38-38-24	SERIES 90	S90-100PV
9622265	PUMP-VAR DISPL, CCW	90-L-100-KA-1-NN-60-L-3-S1-E-02-FAD-38-38-24	SERIES 90	S90-100PV
9622266	PUMP-VAR DISPL, CCW	90-L-100-KP-1-BC-80-P-3-F1-E-04-FAD-42-42-24	SERIES 90	S90-100PV
9622267	PUMP-VAR DISPL, CCW	90-L-100-HS-5-NN-60-R-3-F1-F-05-GBA-32-32-24	SERIES 90	S90-100PV
9622268	PUMP-VAR DISPL, CCW	90-L-100-MA-6-AB-60-L-3-S1-F-03-GBA-48-48-24	SERIES 90	S90-100PV
9622269	PUMP-VAR DISPL, CCW	90-L-100-KP-1-NN-80-P-3-F1-E-04-FAD-42-42-24	SERIES 90	S90-100PV
9622270	PUMP-VAR DISPL, CCW	90-L-100-KA-1-BB-60-L-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9622271	PUMP-VAR DISPL, CCW	90-L-100-KA-1-BB-60-L-3-T2-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9622272	PUMP-VAR DISPL, CCW	90-L-100-KP-1-BC-60-S-3-S1-E-03-GBA-38-38-24	SERIES 90	S90-100PV
9622273	PUMP-VAR DISPL, CCW	90-L-100-DC-1-NN-60-S-3-S1-E-GB-GBA-35-35-24	SERIES 90	S90-100PV
9622274	PUMP-VAR DISPL, CCW	90-L-100-KP-1-BC-60-S-4-S1-E-03-GBA-38-38-24	SERIES 90	S90-100PV
9622275	PUMP-VAR DISPL, CCW	90-L-100-KP-1-NN-60-P-3-S1-D-03-GBA-26-26-20	SERIES 90	S90-100PV
9622277	PUMP-VAR DISPL, CCW	90-L-100-HS-1-AB-80-R-4-F1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
9622278	PUMP-VAR DISPL, CCW	90-L-100-KP-1-CD-80-R-3-F1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
9622280	PUMP-VAR DISPL, CCW	90-L-100-MA-1-AB-60-S-3-F1-E-03-GBA-38-38-20	SERIES 90	S90-100PV

9622280C	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MA-1-AB-60-S-3-F1-E-03-GBA-38-38-20	SERIES 90	S90-100PV
9622281	PUMP-VAR DISPL, CCW	90-L-100-KA-5-CD-60-L-3-F1-E-02-FAD-38-38-24	SERIES 90	S90-100PV
9622282	PUMP-VAR DISPL, CCW	90-L-100-KA-5-NN-60-L-3-S1-E-02-FAD-38-38-24	SERIES 90	S90-100PV
9622283	PUMP-VAR DISPL, CCW	90-L-100-HS-1-NN-60-P-3-F1-E-03-GBA-38-38-24	SERIES 90	S90-100PV
9622283C	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HS-1-NN-60-P-3-F1-E-03-GBA-38-38-24	SERIES 90	S90-100PV
9622284	PUMP-VAR DISPL, CCW	90-L-100-KA-2-AB-81-P-3-F1-F-00-GBA-35-35-24	SERIES 90	S90-100PV
9622285	PUMP-VAR DISPL, CCW	90-L-100-KA-1-AB-81-P-3-F1-F-00-GBA-35-35-24	SERIES 90	S90-100PV
9622286	PUMP-VAR DISPL, CCW	90-L-100-KP-1-BC-80-R-4-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9622287	PUMP-VAR DISPL, CCW	90-L-100-KP-1-BC-80-R-4-C7-E-02-GBA-35-35-24	SERIES 90	S90-100PV
9622288	PUMP-VAR DISPL, CCW	90-L-100-KA-2-CD-80-S-4-F1-E-33-GBA-42-20-24	SERIES 90	S90-100PV
9622289	PUMP-VAR DISPL, CCW	90-L-100-KA-2-BB-80-S-4-F1-E-33-GBA-42-20-24	SERIES 90	S90-100PV
9622292	PUMP-VAR DISPL, CCW	90-L-100-KA-2-BB-80-S-4-F1-E-33-GBA-42-20-24-F064	SERIES 90	S90-100PV
9622293	PUMP-VAR DISPL, CCW	90-L-100-KA-5-NN-60-S-3-F1-E-03-GBA-26-26-24	SERIES 90	S90-100PV
9622294	PUMP-VAR DISPL, CCW	90-L-100-KA-1-NN-80-S-4-S1-E-00-GBA-42-42-24	SERIES 90	S90-100PV
9622295	PUMP-VAR DISPL, CCW	90-L-100-KP-1-NN-81-P-3-S1-E-06-GBA-35-35-24	SERIES 90	S90-100PV
9622296	PUMP-VAR DISPL, CCW	90-L-100-MA-1-NN-60-S-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9622296C	PUMP-VAR DISPL, CCW	90-L-100-MA-1-NN-60-S-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9622297	PUMP-VAR DISPL, CCW	90-L-100-KP-1-CD-80-L-3-K3-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9622298	PUMP-VAR DISPL, CCW	90-L-100-MA-6-CD-60-L-3-C7-F-03-GBA-48-48-24	SERIES 90	S90-100PV
9622299	PUMP-VAR DISPL, CCW	90-L-100-GA-H-CD-80-R-3-F1-F-64-GBA-AD-42-24	SERIES 90	S90-100PV
9622300	PUMP-VAR DISPL, CCW	90-L-100-GA-H-NN-80-R-3-S1-F-64-GBA-AD-42-24	SERIES 90	S90-100PV
9622301	PUMP-VAR DISPL, CCW	90-L-100-KP-1-NN-80-L-4-S1-F-00-GBA-29-29-24	SERIES 90	S90-100PV
9622303	PUMP-VAR DISPL, CCW	90-L-100-KP-1-NN-65-R-3-F3-F-00-GBA-35-32-18	SERIES 90	S90-100PV
9622306	PUMP-VAR DISPL, CCW	90-L-100-MA-1-NN-80-S-4-F1-E-03-GBA-23-23-24	SERIES 90	S90-100PV
9622307	PUMP-VAR DISPL, CCW	90-L-100-KA-1-CD-60-R-4-S1-E-03-GBA-32-32-24	SERIES 90	S90-100PV
9622308	PUMP-VAR DISPL, CCW	90-L-100-KA-1-CD-80-S-3-C7-F-03-GBA-20-20-24	SERIES 90	S90-100PV
9622309	PUMP-VAR DISPL, CCW	90-L-100-KA-1-AB-80-S-3-C7-F-03-GBA-20-20-24	SERIES 90	S90-100PV
9622310	PUMP-VAR DISPL, CCW	90-L-100-CB-5-NN-60-S-3-F1-E-00-GBA-45-45-24	SERIES 90	S90-100PV
9622311	PUMP-VAR DISPL, CCW	90-L-100-MA-5-NN-60-S-3-S1-E-00-GBA-45-45-24	SERIES 90	S90-100PV
9622312	PUMP-VAR DISPL, CCW	90-L-100-KA-1-BC-80-S-3-C7-E-03-FAC-42-42-24	SERIES 90	S90-100PV
9622313	PUMP-VAR DISPL, CCW	90-L-100-KA-1-NN-80-S-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9622314	PUMP-VAR DISPL, CCW	90-L-100-KP-1-NN-80-S-3-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9622315	PUMP-VAR DISPL, CCW	90-L-100-KP-1-BC-60-L-3-F1-E-02-GBA-38-38-24	SERIES 90	S90-100PV
9622316	PUMP-VAR DISPL, CCW	90-L-100-EA-1-AB-60-S-3-K3-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9622317	PUMP-VAR DISPL, CCW	90-L-100-KP-1-BC-60-R-3-F1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
9622318	PUMP-VAR DISPL, CCW	90-L-100-DC-1-AB-80-S-3-T2-E-GB-GBA-32-32-24	SERIES 90	S90-100PV

9622319	PUMP-VAR DISPL, CCW	90-L-100-KP-1-NN-80-P-3-F1-E-03-GBA-38-38-24	SERIES 90	S90-100PV
9622320	PUMP-VAR DISPL, CCW	90-L-100-EA-1-NN-60-S-3-K3-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9622321	PUMP-VAR DISPL, CCW	90-L-100-HF-5-BC-80-L-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9622322	PUMP-VAR DISPL, CCW	90-L-100-HF-5-NN-80-L-3-F1-E-03-GBA-38-38-24	SERIES 90	S90-100PV
9622323	PUMP-VAR DISPL, CCW	90-L-100-HE-1-CD-80-R-4-F1-F-06-GBA-35-35-24	SERIES 90	S90-100PV
9622324	PUMP-VAR DISPL, CCW	90-L-100-KA-1-AB-60-P-3-T2-E-00-GBA-32-32-24	SERIES 90	S90-100PV
9622325	PUMP-VAR DISPL, CCW	90-L-100-KP-5-NN-60-L-3-S1-E-03-GBA-35-35-28	SERIES 90	S90-100PV
9622326	PUMP-VAR DISPL, CCW	90-L-100-KA-1-AB-60-R-4-F1-E-00-GBA-20-20-24	SERIES 90	S90-100PV
9622327	PUMP-VAR DISPL, CCW	90-L-100-KA-1-NN-80-S-4-F1-E-00-GBA-42-42-24	SERIES 90	S90-100PV
9622328	PUMP-VAR DISPL, CCW	90-L-100-KP-1-BC-60-P-3-K3-E-00-EBC-20-20-24	SERIES 90	S90-100PV
9622329	PUMP-VAR DISPL, CCW	90-L-100-KP-2-CD-80-L-3-F1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
9622330	PUMP-VAR DISPL, CCW	90-L-100-KP-G-NN-80-R-3-S1-E-03-GBA-29-29-24	SERIES 90	S90-100PV
9622331	PUMP-VAR DISPL, CCW - DIST BASE MODEL	90-L-100-CB-1-NN-60-S-4-F1-E-00-GBA-35-35-24-P000	SERIES 90	S90-100PV
9622332	PUMP-VAR DISPL, CCW - DIST BASE MODEL	90-L-100-CB-1-NN-60-S-4-S1-E-00-GBA-35-35-24-P000	SERIES 90	S90-100PV
9622333	PUMP-VAR DISPL, CCW - DIST BASE MODEL	90-L-100-CB-1-NN-60-S-4-T2-E-00-GBA-35-35-24	SERIES 90	S90-100PV
9622334	PUMP-VAR DISPL, CCW - DIST BASE MODEL	90-L-100-CB-1-NN-80-S-4-F1-E-00-GBA-35-35-24-P000	SERIES 90	S90-100PV
9622335	PUMP-VAR DISPL, CCW - DIST BASE MODEL	90-L-100-CB-1-NN-80-S-4-S1-E-00-GBA-35-35-24-P000	SERIES 90	S90-100PV
9622336	PUMP-VAR DISPL, CCW - DIST BASE MODEL	90-L-100-CB-1-NN-80-S-4-T2-E-00-GBA-35-35-24	SERIES 90	S90-100PV
9622337	PUMP-VAR DISPL, CCW	90-L-100-KP-1-BC-80-L-3-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9622338	PUMP-VAR DISPL, CCW	90-L-100-MA-1-AB-80-P-3-T2-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9622339	PUMP-VAR DISPL, CCW	90-L-100-HE-1-CD-80-R-4-F1-F-06-GBA-35-35-28	SERIES 90	S90-100PV
9622340	PUMP-VAR DISPL, CCW	90-L-100-KP-1-BC-80-L-3-F1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
9622341	PUMP-VAR DISPL, CCW	90-L-100-KA-1-NN-80-L-3-S1-F-03-GBA-14-38-24	SERIES 90	S90-100PV
9622342	PUMP-VAR DISPL, CCW	90-L-100-KP-1-BC-80-S-3-F1-E-02-GBA-38-38-24	SERIES 90	S90-100PV
9622343	PUMP-VAR DISPL, CCW	90-L-100-MA-5-CD-60-R-3-F1-E-03-FAD-42-42-28	SERIES 90	S90-100PV
9622344	PUMP-VAR DISPL, CCW	90-L-100-KP-1-AB-65-R-3-F3-F-00-GBA-40-35-20	SERIES 90	S90-100PV
9622345	PUMP-VAR DISPL, CCW	90-L-100-KA-1-NN-80-L-4-K3-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9622346	PUMP-VAR DISPL, CCW	90-L-100-KP-1-AB-80-R-3-F1-E-03-GBA-14-35-24	SERIES 90	S90-100PV
9622347	PUMP-VAR DISPL, CCW	90-L-100-MA-1-AB-80-L-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9622348	PUMP-VAR DISPL, CCW	90-L-100-MA-1-NN-80-L-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9622349	PUMP-VAR DISPL, CCW	90-L-100-MB-5-NN-60-R-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9622350	PUMP-VAR DISPL, CCW	90-L-100-KA-5-NN-60-L-3-F1-E-03-GBA-26-26-24	SERIES 90	S90-100PV
9622351	PUMP-VAR DISPL, CCW	90-L-100-KP-1-AB-80-P-3-S1-E-03-GBA-38-38-24	SERIES 90	S90-100PV
9622352	PUMP-VAR DISPL, CCW	90-L-100-MA-5-NN-80-S-4-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9622353	PUMP-VAR DISPL, CCW	90-L-100-HF-1-BC-80-S-4-S1-E-03-GBA-23-23-20	SERIES 90	S90-100PV
9622354	PUMP-VAR DISPL, CCW	90-L-100-KA-1-BC-80-P-3-S1-D-05-GBA-29-29-24	SERIES 90	S90-100PV

9622355	PUMP-VAR DISPL, CCW	90-L-100-KP-1-BC-80-R-3-F1-E-03-GBA-14-35-24	SERIES 90	S90-100PV
9622356	PUMP-VAR DISPL, CCW	90-L-100-KP-1-NN-80-R-3-F1-E-03-GBA-14-35-24	SERIES 90	S90-100PV
9622358	PUMP-VAR DISPL, CCW	90-L-100-KA-6-NN-60-P-3-S1-E-03-GBA-48-48-24	SERIES 90	S90-100PV
9622359	PUMP-VAR DISPL, CCW	90-L-100-KA-6-CD-60-P-3-F1-E-03-GBA-48-48-24	SERIES 90	S90-100PV
9622360	PUMP-VAR DISPL, CCW	90-L-100-KP-1-NN-80-S-3-S1-E-02-GBA-42-42-24	SERIES 90	S90-100PV
9622361	PUMP-VAR DISPL, CCW	90-L-100-KP-1-CD-80-S-3-F1-E-02-GBA-42-42-24	SERIES 90	S90-100PV
9622362	PUMP-VAR DISPL, CCW	90-L-100-KA-1-NN-60-P-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9622363	PUMP-VAR DISPL, CCW	90-L-100-KP-1-NN-80-R-3-S1-F-29-GBA-40-40-34	SERIES 90	S90-100PV
9622365	PUMP-VAR DISPL, CCW	90-L-100-KP-1-BC-60-P-3-K3-E-00-EHA-20-20-24	SERIES 90	S90-100PV
9622366	PUMP-VAR DISPL, CCW	90-L-100-HS-1-NN-60-R-3-F1-E-05-FAD-32-32-28	SERIES 90	S90-100PV
9622367	PUMP-VAR DISPL, CCW	90-L-100-KP-1-NN-65-R-3-F3-F-00-GBA-40-35-20	SERIES 90	S90-100PV
9622368	PUMP-VAR DISPL, CCW	90-L-100-KP-1-AC-60-R-3-F1-E-03-GBA-14-35-24	SERIES 90	S90-100PV
9622369	PUMP-VAR DISPL, CCW	90-L-100-HS-1-NN-80-P-3-F1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
9622370	PUMP-VAR DISPL, CCW	90-L-100-KP-1-AB-80-P-3-T2-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9622374	PUMP-VAR DISPL, CCW	90-L-100-HF-1-NN-60-S-4-F1-E-03-GBA-42-42-28	SERIES 90	S90-100PV
9622375	PUMP-VAR DISPL, CCW	90-L-100-MV-2-NN-80-R-3-S1-E-04-GBA-14-35-20	SERIES 90	S90-100PV
9622376	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-1-CD-80-L-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
9622377	PUMP-VAR-DISPL CCW 90PV100	90L100-KA-1-CD-80-L-3-S1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
9622378	PUMP-VAR DISPL, CCW	90-L-100-MB-1-CD-60-L-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9622379	PUMP-VAR DISPL, CCW	90-L-100-MA-1-NN-60-R-3-F1-E-03-FAD-42-42-28	SERIES 90	S90-100PV
9622380	PUMP-VAR DISPL, CCW	90-L-100-HF-1-CD-60-S-3-F1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
9622381	PUMP-VAR DISPL, CCW	90-L-100-KP-1-NN-61-S-3-S1-E-03-GBA-32-32-24	SERIES 90	S90-100PV
9622382	PUMP-VAR DISPL, CCW	90-L-100-KP-5-BC-60-L-3-S1-E-03-GBA-35-35-28	SERIES 90	S90-100PV
9622383	PUMP-VAR DISPL, CCW	90-L-100-EP-2-AB-60-L-F-F1-E-33-GBA-38-38-24	SERIES 90	S90-100PV
9622384	PUMP-VAR DISPL, CCW	90-L-100-KP-5-NN-80-P-3-S1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
9622385	PUMP-VAR DISPL, CCW	90-L-100-KT-1-CD-80-L-3-C7-F-00-GBA-42-42-28	SERIES 90	S90-100PV
9622386	PUMP-VAR DISPL, CCW	90-L-100-KT-1-BC-80-L-3-J3-F-00-GBA-42-42-28	SERIES 90	S90-100PV
9622387	PUMP-VAR DISPL, CCW	90-L-100-KP-5-CD-80-R-3-F1-E-03-GBA-45-45-24	SERIES 90	S90-100PV
9622388	PUMP-VAR DISPL, CCW	90-L-100-KP-5-NN-80-R-3-F1-E-03-GBA-45-45-24	SERIES 90	S90-100PV
9622389	PUMP-VAR DISPL, CCW	90-L-100-HF-1-CD-80-P-4-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9622390	PUMP-VAR DISPL, CCW	90-L-100-KP-1-CD-80-S-4-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9622391	PUMP-VAR DISPL, CCW	90-L-100-HF-1-AB-60-S-3-F1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
9622392	PUMP-VAR DISPL, CCW	90-L-100-KP-1-BC-60-P-3-F1-F-03-GBA-38-38-24	SERIES 90	S90-100PV
9622393	PUMP-VAR DISPL, CCW	90-L-100-MB-5-AB-61-S-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9622394	PUMP-VAR DISPL, CCW	90-L-100-HS-5-BC-61-S-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9622395	PUMP-VAR DISPL, CCW	90-L-100-DD-1-NN-81-L-3-F1-E-GB-GBA-42-42-24	SERIES 90	S90-100PV

9622396	PUMP-VAR DISPL, CCW	90-L-100-CB-1-NN-60-S-3-S1-F-00-GBA-35-35-24-P000	SERIES 90	S90-100PV
9622397	PUMP-VAR DISPL, CCW	90-L-100-DD-1-NN-81-L-4-F1-E-GB-GBA-42-42-24	SERIES 90	S90-100PV
9622398	PUMP-VAR DISPL, CCW	90-L-100-KN-1-NN-80-R-4-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9622399	PUMP-VAR DISPL, CCW	90-L-100-DC-5-AB-60-P-4-S1-E-G8-GBA-35-35-24	SERIES 90	S90-100PV
9622400	PUMP-VAR DISPL, CCW	90-L-100-DC-5-CD-60-P-4-T2-E-G8-GBA-35-35-24	SERIES 90	S90-100PV
9622401	PUMP-VAR DISPL, CCW	90-L-100-KN-1-BC-80-L-3-S1-F-03-GBA-14-14-24	SERIES 90	S90-100PV
9622402	PUMP-VAR DISPL, CCW	90-L-100-MA-1-AB-80-S-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9622403	PUMP-VAR DISPL, CCW	90-L-100-KA-1-NN-80-L-4-S1-E-03-GCA-23-23-24	SERIES 90	S90-100PV
9622404	PUMP-VAR DISPL, CCW	90-L-100-KP-1-BC-60-L-4-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9622405	PUMP-VAR DISPL, CCW	90-L-100-MA-1-CD-60-P-3-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9622406	PUMP-VAR DISPL, CCW	90-L-100-HS-1-BC-80-S-3-S1-E-03-GBA-35-35-28	SERIES 90	S90-100PV
9622407	PUMP-VAR DISPL, CCW	90-L-100-KP-2-BC-80-R-3-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9622408	PUMP-VAR DISPL, CCW	90-L-100-KP-2-NN-80-R-3-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9622409	PUMP-VAR DISPL, CCW	90-L-100-CB-2-CD-80-D-4-F1-L-00-GBA-20-20-24	SERIES 90	S90-100PV
9622410	PUMP-VAR DISPL, CCW	90-L-100-CB-2-CD-80-D-4-S1-L-00-GBA-20-20-24	SERIES 90	S90-100PV
9622411	PUMP-VAR DISPL, CCW	90-L-100-KA-1-NN-80-S-3-F1-F-00-GBA-42-42-24	SERIES 90	S90-100PV
9622412	PUMP-VAR DISPL, CCW	90-L-100-KP-1-CD-80-S-3-F1-F-03-GBA-45-45-24	SERIES 90	S90-100PV
9622413	PUMP-VAR DISPL, CCW	90-L-100-KP-1-AB-80-D-3-S1-L-03-GBA-45-45-24	SERIES 90	S90-100PV
9622414	PUMP-VAR DISPL, CCW	90-L-100-DD-1-NN-80-L-4-F1-E-GB-GBA-42-42-24	SERIES 90	S90-100PV
9622415	PUMP-VAR DISPL, CCW	90-L-100-MA-1-BC-60-R-4-F1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
9622416	PUMP-VAR DISPL, CCW	90-L-100-KP-1-BC-80-R-3-S1-D-03-GBA-23-23-30	SERIES 90	S90-100PV
9622417	PUMP-VAR DISPL, CCW	90-L-100-MB-1-BC-60-S-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9622418	PUMP-VAR DISPL, CCW	90-L-100-MB-1-AB-60-P-4-S1-E-03-GBA-32-32-24	SERIES 90	S90-100PV
9622419	PUMP-VAR DISPL, CCW	90-L-100-EP-2-AB-60-L-F-F1-F-33-GBA-38-38-24	SERIES 90	S90-100PV
9622420	PUMP-VAR DISPL, CCW	90-L-100-HF-1-BC-80-R-4-F1-L-03-GBA-38-38-24	SERIES 90	S90-100PV
9622423	PUMP-VAR DISPL, CCW	90-L-100-HF-1-NN-80-R-4-F1-L-03-GBA-38-38-24	SERIES 90	S90-100PV
9622424	PUMP-VAR DISPL, CCW	90-L-100-KA-1-CD-60-L-3-F1-D-02-GBA-26-26-20	SERIES 90	S90-100PV
9622425	PUMP-VAR DISPL, CCW	90-L-100-KA-1-NN-60-L-3-S1-D-02-GBA-26-26-20	SERIES 90	S90-100PV
9622426	PUMP-VAR DISPL, CCW	90-L-100-KP-7-AB-80-S-3-T2-F-03-GBA-48-48-24	SERIES 90	S90-100PV
9622427	PUMP-VAR DISPL, CCW	90-L-100-MA-6-BC-80-L-3-F1-F-05-GBA-48-48-24	SERIES 90	S90-100PV
9622428	PUMP-VAR DISPL, CCW	90-L-100-CB-1-CD-80-S-3-F1-D-00-FAD-45-45-24	SERIES 90	S90-100PV
9622429	PUMP-VAR DISPL, CCW	90-L-100-CB-1-AB-80-S-3-F1-E-00-FAD-42-42-24	SERIES 90	S90-100PV
9622430	PUMP-VAR DISPL, CCW	90-L-100-CB-1-CD-80-S-3-F1-E-00-FAD-42-42-24	SERIES 90	S90-100PV
9622431	PUMP-VAR DISPL, CCW	90-L-100-DD-1-NN-60-R-4-C7-F-GJ-GBA-32-32-24	SERIES 90	S90-100PV
9622432	PUMP-VAR DISPL, CCW	90-L-100-HF-1-AB-60-R-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9622433	PUMP-VAR DISPL, CCW	90-L-100-CB-1-AB-80-S-3-F1-D-00-FAD-45-45-24	SERIES 90	S90-100PV

9622434	PUMP-VAR DISPL, CCW	90-L-100-KP-1-CD-60-L-3-F1-D-02-GBA-26-26-20	SERIES 90	S90-100PV
9622435	PUMP-VAR DISPL, CCW	90-L-100-KP-1-NN-60-L-3-S1-D-02-GBA-26-26-20	SERIES 90	S90-100PV
9622436	PUMP-VAR DISPL, CCW	90-L-100-KP-5-CD-80-P-3-F1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
9622437	PUMP-VAR DISPL, CCW	90-L-100-KA-1-CD-60-S-3-T2-E-00-GBA-23-23-24	SERIES 90	S90-100PV
9622438	PUMP-VAR DISPL, CCW	90-L-100-HF-1-CD-80-S-4-F1-E-03-GBA-35-35-20	SERIES 90	S90-100PV
9622439	PUMP-VAR DISPL, CCW	90-L-100-KP-1-BB-60-L-3-F1-F-04-GBA-35-35-20	SERIES 90	S90-100PV
9622440	PUMP-VAR DISPL, CCW	90-L-100-MB-5-BC-60-R-3-F1-E-C5-GBA-35-35-24	SERIES 90	S90-100PV
9622441	PUMP-VAR DISPL, CCW	90-L-100-DD-1-BC-80-L-4-F1-E-GB-GBA-42-42-24	SERIES 90	S90-100PV
9622442	PUMP-VAR DISPL, CCW	90-L-100-MB-1-AB-80-S-3-F1-D-03-FAD-45-45-24	SERIES 90	S90-100PV
9622443	PUMP-VAR DISPL, CCW	90-L-100-MB-1-CD-80-S-3-F1-D-03-FAD-45-45-24	SERIES 90	S90-100PV
9622444	PUMP-VAR DISPL, CCW	90-L-100-KP-1-CD-60-R-3-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9622445	PUMP-VAR DISPL, CCW	90-L-100-MV-1-CD-60-R-3-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9622446	PUMP-VAR DISPL, CCW	90-L-100-CB-1-CD-60-R-7-S1-D-00-GBA-42-42-24	SERIES 90	S90-100PV
9622448	PUMP-VAR DISPL, CCW	90-L-100-MA-1-NN-80-S-3-F1-E-02-GBA-42-42-24	SERIES 90	S90-100PV
9622449	PUMP-VAR DISPL, CCW	90-L-100-HF-1-NN-60-R-4-F1-E-05-FAD-32-32-32	SERIES 90	S90-100PV
9622450	PUMP-VAR DISPL, CCW	90-L-100-KP-1-AB-80-L-3-T2-E-03-GBA-23-23-28	SERIES 90	S90-100PV
9622451	PUMP-VAR DISPL, CCW	90-L-100-KA-1-CD-60-L-3-F1-F-03-GBA-38-38-24	SERIES 90	S90-100PV
9622452	PUMP-VAR DISPL, CCW	90-L-100-KP-1-BC-80-L-3-F1-E-02-GBA-35-35-24	SERIES 90	S90-100PV
9622454	PUMP-VAR DISPL, CCW	90-L-100-CB-1-BC-60-S-3-S1-E-00-GBA-14-14-20	SERIES 90	S90-100PV
9622455	PUMP-VAR DISPL, CCW	90-L-100-KP-1-BB-80-L-3-F1-E-02-GBA-35-35-24	SERIES 90	S90-100PV
9622456	PUMP-VAR DISPL, CCW	90-L-100-HS-1-BC-60-S-3-S1-E-00-GBA-23-23-24	SERIES 90	S90-100PV
9622457	PUMP-VAR DISPL, CCW	90-L-100-MA-6-AB-80-L-3-S1-F-05-GBA-48-48-24	SERIES 90	S90-100PV
9622458	PUMP-VAR DISPL, CCW	90-L-100-KP-1-CD-80-R-3-F1-E-03-GBA-23-40-24	SERIES 90	S90-100PV
9622458C	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-CD-80-R-3-F1-E-03-GBA-23-40-24	SERIES 90	S90-100PV
9622459	PUMP-VAR DISPL, CCW	90-L-100-KA-1-NN-80-R-3-S1-E-03-GBA-42-42-28	SERIES 90	S90-100PV
9622460	PUMP-VAR DISPL, CCW	90-L-100-HS-1-NN-60-P-3-F1-E-03-GBA-32-14-24	SERIES 90	S90-100PV
9622461	PUMP-VAR DISPL, CCW	90-L-100-KP-1-BC-80-S-3-F1-E-04-FAD-42-42-24	SERIES 90	S90-100PV
9622462	PUMP-VAR DISPL, CCW	90-L-100-DC-1-CD-80-S-4-C7-E-GB-GBA-35-35-24-F023	SERIES 90	S90-100PV
9622463	PUMP-VAR DISPL, CCW	90-L-100-DC-1-BC-80-S-4-S1-E-GB-GBA-35-35-24-F023	SERIES 90	S90-100PV
9622464	PUMP-VAR DISPL, CCW	90-L-100-KP-1-CD-60-P-3-F1-E-03-GBA-29-29-24	SERIES 90	S90-100PV
9622464C	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-CD-60-P-3-F1-E-03-GBA-29-29-24	SERIES 90	S90-100PV
9622465	PUMP-VAR DISPL, CCW	90-L-100-DC-1-CD-80-S-4-F1-E-GB-GBA-35-35-24-F023	SERIES 90	S90-100PV
9622466	PUMP-VAR DISPL, CCW	90-L-100-KP-5-CD-80-R-3-S1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
9622467	PUMP-VAR DISPL, CCW	90-L-100-KP-6-NN-60-S-3-T2-D-02-GBA-48-48-24	SERIES 90	S90-100PV
9622467C	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-6-NN-60-S-3-T2-D-02-GBA-48-48-24	SERIES 90	S90-100PV
9622468	PUMP-VAR DISPL, CCW	90-L-100-KP-1-NN-60-R-3-F1-E-03-GBA-38-38-24	SERIES 90	S90-100PV

9622470	PUMP-VAR DISPL, CCW	90-L-100-KP-1-NN-60-R-3-S1-E-03-GBA-38-38-24	SERIES 90	S90-100PV
9622471	PUMP-VAR DISPL, CCW	90-L-100-M8-1-NN-80-L-3-C7-E-03-GBA-23-23-24	SERIES 90	S90-100PV
9622471C	PUMP-VAR DISPL, CCW 90PV100	90-L-100-M8-1-NN-80-L-3-C7-E-03-GBA-23-23-24	SERIES 90	S90-100PV
9622472	PUMP-VAR DISPL, CCW	90-L-100-KP-1-NN-60-R-3-S1-E-03-GBA-38-38-20	SERIES 90	S90-100PV
9622473	PUMP-VAR DISPL, CCW	90-L-100-KP-1-CD-60-P-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9622473C	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-CD-60-P-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9622474	PUMP-VAR DISPL, CCW	90-L-100-MS-1-AB-60-R-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
9622475	PUMP-VAR DISPL, CCW	90-L-100-MA-1-BC-80-S-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9622476	PUMP-VAR DISPL, CCW	90-L-100-KP-6-CD-60-S-4-TF-D-02-GBA-48-48-24	SERIES 90	S90-100PV
9622477	PUMP-VAR DISPL, CCW	90-L-100-KP-6-NN-60-S-4-S1-D-02-GBA-48-48-24	SERIES 90	S90-100PV
9622478	PUMP-VAR DISPL, CCW	90-L-100-MA-1-BC-60-P-3-S1-E-03-GBA-20-20-24	SERIES 90	S90-100PV
9622479	PUMP-VAR DISPL, CCW	90-L-100-HS-1-NN-60-P-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9622480	PUMP-VAR DISPL, CCW	90-L-100-KP-1-NN-80-S-3-TF-E-03-FAC-45-45-28	SERIES 90	S90-100PV
9622481	PUMP-VAR DISPL, CCW	90-L-100-KA-1-NN-80-P-3-S1-F-00-GBA-42-42-24	SERIES 90	S90-100PV
9622482	PUMP-VAR DISPL, CCW	90-L-100-HS-1-NN-60-R-3-F1-F-05-GBA-42-42-28	SERIES 90	S90-100PV
9622483	PUMP-VAR DISPL, CCW	90-L-100-KA-1-NN-60-R-3-S1-E-03-GBA-45-45-24	SERIES 90	S90-100PV
9622484	PUMP-VAR DISPL, CCW	90-L-100-KP-1-AB-81-S-3-T2-F-00-EBC-35-35-20	SERIES 90	S90-100PV
9622485	PUMP-VAR DISPL, CCW	90-L-100-KP-5-AC-80-S-4-C7-E-03-GBA-20-20-24	SERIES 90	S90-100PV
9622485C	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-5-AC-80-S-4-C7-E-03-GBA-20-20-24	SERIES 90	S90-100PV
9622486	PUMP-VAR DISPL, CCW	90-L-100-HF-1-BC-80-R-3-S1-E-09-GBA-38-38-24	SERIES 90	S90-100PV
9622487	PUMP-VAR DISPL, CCW	90-L-100-KA-1-BC-80-R-3-S1-E-09-GBA-35-35-24	SERIES 90	S90-100PV
9622488	PUMP-VAR DISPL, CCW	90-L-100-MA-5-NN-80-S-3-F1-E-02-GBA-42-42-24	SERIES 90	S90-100PV
9622489	PUMP-VAR DISPL, CCW	90-L-100-KA-1-CD-60-R-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9622490	PUMP-VAR DISPL, CCW	90-L-100-MV-2-BC-60-D-3-F1-L-03-GBA-35-35-24	SERIES 90	S90-100PV
9622491	PUMP-VAR DISPL, CCW	90-L-100-KP-1-AB-80-S-3-S1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
9622492	PUMP-VAR DISPL, CCW	90-L-100-MA-6-CD-60-L-3-C7-F-05-GBA-48-48-24	SERIES 90	S90-100PV
9622493	PUMP-VAR DISPL, CCW	90-L-100-MA-6-AB-60-L-3-S1-F-05-GBA-48-48-24	SERIES 90	S90-100PV
9622494	PUMP-VAR DISPL, CCW	90-L-100-KP-1-AB-80-P-3-F1-E-03-GBA-38-38-24	SERIES 90	S90-100PV
9622496	PUMP-VAR DISPL, CCW	90-L-100-KP-1-NN-60-L-4-F1-E-02-GBA-32-32-24	SERIES 90	S90-100PV
9622497	PUMP-VAR DISPL, CCW	90-L-100-KP-5-CD-80-L-3-F1-F-03-GBA-32-32-24	SERIES 90	S90-100PV
9622498	PUMP-VAR DISPL, CCW	90-L-100-MA-6-CD-60-L-3-T2-F-05-GBA-48-48-24	SERIES 90	S90-100PV
9622499	PUMP-VAR DISPL, CCW	90-L-100-HS-1-BC-60-R-4-F1-E-05-FAD-32-32-28	SERIES 90	S90-100PV
9622500	PUMP-VAR DISPL, CW	90-R-100-MV-1-CD-80-L-3-F1-F-03-GBA-38-38-24	SERIES 90	S90-100PV
9622501	PUMP-VAR DISPL, CW	90-R-100-KP-7-AB-60-S-3-T2-F-03-GBA-48-48-24	SERIES 90	S90-100PV
9622502	PUMP-VAR DISPL, CW	90-R-100-HF-5-NN-80-R-4-S1-E-00-GBA-32-32-20	SERIES 90	S90-100PV
9622503	PUMP-VAR DISPL, CW	90-R-100-KN-2-NN-60-R-4-S1-E-03-GBA-17-17-20	SERIES 90	S90-100PV

9622504	PUMP-VAR DISPL, CW	90-R-100-KT-T-CE-80-R-3-F1-G-00-GBA-AF-AF-24	SERIES 90	S90-100PV
9622505	PUMP-VAR DISPL, CW	90-R-100-HF-1-BC-80-S-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9622506	PUMP-VAR DISPL, CW	90-R-100-KA-5-CD-60-L-3-T2-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9622507	PUMP-VAR DISPL, CW	90-R-100-KA-5-BB-60-L-3-T2-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9622508	PUMP-VAR DISPL, CW	90-R-100-MA-5-CD-60-S-4-F1-E-06-GBA-29-29-24	SERIES 90	S90-100PV
9622511	PUMP-VAR DISPL, CW	90-R-100-HS-1-AB-60-S-4-S1-F-03-GBA-23-23-28	SERIES 90	S90-100PV
9622512	PUMP-VAR DISPL, CW	90-R-100-MA-5-NN-80-P-4-T2-E-03-GBA-26-26-24	SERIES 90	S90-100PV
9622513	PUMP-VAR DISPL, CW	90-R-100-KP-2-BC-81-S-3-S1-F-03-GBA-20-20-24	SERIES 90	S90-100PV
9622514	PUMP-VAR DISPL, CW	90-R-100-KP-5-CD-80-S-3-K3-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9622515	PUMP-VAR DISPL, CW	90-R-100-KT-1-CD-80-P-3-C7-E-00-FAC-42-42-28	SERIES 90	S90-100PV
9622516	PUMP-VAR DISPL, CW	90-R-100-KT-1-BC-80-P-3-S1-E-00-FAC-42-42-28	SERIES 90	S90-100PV
9622517	PUMP-VAR DISPL, CW	90-R-100-KP-5-CD-60-S-3-F1-E-03-GBA-29-29-24	SERIES 90	S90-100PV
9622518	PUMP-VAR DISPL, CW	90-R-100-KN-2-CD-60-S-4-F1-E-03-FAD-42-14-24	SERIES 90	S90-100PV
9622519	PUMP-VAR DISPL, CW	90-R-100-KN-2-NN-60-S-4-S1-E-03-FAD-42-14-24	SERIES 90	S90-100PV
9622520	PUMP-VAR DISPL, CW	90-R-100-MA-1-CD-60-L-3-C7-E-03-GBA-32-32-24	SERIES 90	S90-100PV
9622523	PUMP-VAR DISPL, CW	90-R-100-KP-1-NN-80-R-4-F1-F-00-FAD-35-45-24	SERIES 90	S90-100PV
9622524	PUMP-VAR DISPL, CW	90-R-100-KP-5-BC-80-S-3-F1-F-04-EBC-42-42-24	SERIES 90	S90-100PV
9622525	PUMP-VAR DISPL, CW	90-R-100-KP-7-AB-80-S-3-T2-F-03-GBA-45-45-24	SERIES 90	S90-100PV
9622526	PUMP-VAR DISPL, CW	90-R-100-HF-5-BC-80-L-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9622527	PUMP-VAR DISPL, CW	90-R-100-KP-1-AB-80-R-3-S1-E-03-GBA-35-35-20	SERIES 90	S90-100PV
9622528	PUMP-VAR DISPL, CW	90-R-100-MA-5-NN-80-L-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9622529	PUMP-VAR DISPL, CW	90-R-100-HF-1-BC-80-S-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9622530	PUMP-VAR DISPL, CW	90-R-100-KP-2-BC-80-P-3-F1-F-05-GBA-42-42-24	SERIES 90	S90-100PV
9622531	PUMP-VAR DISPL, CW	90-R-100-KP-2-CD-80-P-3-F1-F-05-GBA-42-42-24	SERIES 90	S90-100PV
9622532	PUMP-VAR DISPL, CW	90-R-100-MB-1-CD-60-L-3-F1-F-03-GBA-42-42-20	SERIES 90	S90-100PV
9622533	PUMP-VAR DISPL, CW	90-R-100-KP-1-NN-60-S-4-S1-E-00-GBA-23-23-24	SERIES 90	S90-100PV
9622534	PUMP-VAR DISPL, CW	90-R-100-KP-1-BC-60-P-3-C7-F-00-GBA-35-35-20	SERIES 90	S90-100PV
9622535	PUMP-VAR DISPL, CW	90-R-100-KP-1-CD-62-R-3-C7-E-03-GBA-42-42-20	SERIES 90	S90-100PV
9622536	PUMP-VAR DISPL, CW	90-R-100-MV-1-CD-62-R-3-C7-F-03-GBA-42-42-20	SERIES 90	S90-100PV
9622537	PUMP-VAR DISPL, CW	90-R-100-KP-5-CD-80-S-2-T2-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9622538	PUMP-VAR DISPL, CW	90-R-100-MA-1-BC-60-S-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9622539	PUMP-VAR DISPL, CW	90-R-100-MA-1-BB-60-S-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9622540	PUMP-VAR DISPL, CW	90-R-100-KP-5-CD-80-L-3-K3-E-03-GBA-38-38-20	SERIES 90	S90-100PV
9622541	PUMP-VAR DISPL, CW	90-R-100-MA-1-AB-80-S-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9622542	PUMP-VAR DISPL, CW	90-R-100-KP-1-NN-60-L-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
9622543	PUMP-VAR DISPL, CW	90-R-100-KA-1-AB-60-S-3-K3-E-03-GBA-35-35-24	SERIES 90	S90-100PV

9622544	PUMP-VAR DISPL, CW - DIST BASE MODEL	90-R-100-CB-1-NN-60-S-4-F1-E-00-GBA-35-35-24-P000	SERIES 90	S90-100PV
9622545	PUMP-VAR DISPL, CW - DIST BASE MODEL	90-R-100-CB-1-NN-60-S-4-S1-E-00-GBA-35-35-24-P000	SERIES 90	S90-100PV
9622546	PUMP-VAR DISPL, CW - DIST BASE MODEL	90-R-100-CB-1-NN-60-S-4-T2-E-00-GBA-35-35-24	SERIES 90	S90-100PV
9622547	PUMP-VAR DISPL, CW - DIST BASE MODEL	90-R-100-CB-1-NN-80-S-4-F1-E-00-GBA-35-35-24-P000	SERIES 90	S90-100PV
9622548	PUMP-VAR DISPL, CW - DIST BASE MODEL	90-R-100-CB-1-NN-80-S-4-S1-E-00-GBA-35-35-24-P000	SERIES 90	S90-100PV
9622549	PUMP-VAR DISPL, CW - DIST BASE MODEL	90-R-100-CB-1-NN-80-S-4-T2-E-00-GBA-35-35-24	SERIES 90	S90-100PV
9622550	PUMP-VAR DISPL, CW	90-R-100-KP-1-BC-80-R-4-C7-E-02-GBA-35-35-24	SERIES 90	S90-100PV
9622551	PUMP-VAR DISPL, CW	90-R-100-MV-1-CD-80-P-3-F1-F-03-GBA-38-38-24	SERIES 90	S90-100PV
9622552	PUMP-VAR DISPL, CW	90-R-100-KA-1-BB-61-R-4-F1-F-03-FAD-35-35-24	SERIES 90	S90-100PV
9622553	PUMP-VAR DISPL, CW	90-R-100-KA-1-BC-61-R-4-F1-F-03-FAD-35-35-24	SERIES 90	S90-100PV
9622555	PUMP-VAR DISPL, CW	90-R-100-LE-1-CA-80-L-4-F1-F-03-GBA-38-38-24-F068	SERIES 90	S90-100PV
9622556	PUMP-VAR DISPL, CW	90-R-100-MA-1-BC-80-L-4-S1-F-03-GBA-38-38-24-F068	SERIES 90	S90-100PV
9622559	PUMP-VAR DISPL, CW	90-R-100-KN-1-BC-60-S-4-K3-E-02-GBA-35-14-24-P000	SERIES 90	S90-100PV
9622561	PUMP-VAR DISPL, CW	90-R-100-CB-1-BB-60-P-4-S1-E-00-GBA-14-14-20	SERIES 90	S90-100PV
9622564	PUMP-VAR DISPL, CW	90-R-100-MA-1-NN-60-R-3-S1-E-00-GBA-29-29-24	SERIES 90	S90-100PV
9622566	PUMP-VAR DISPL, CW	90-R-100-MA-1-BC-60-S-3-C7-E-03-GFK-42-42-24	SERIES 90	S90-100PV
9622568	PUMP-VAR DISPL, CW	90-R-100-KP-1-NN-80-L-3-F1-E-29-GBA-38-38-24	SERIES 90	S90-100PV
9622569	PUMP-VAR DISPL, CW	90-R-100-KP-1-NN-60-R-3-S1-E-00-GBA-29-29-24	SERIES 90	S90-100PV
9622570	PUMP-VAR DISPL, CW	90-R-100-MV-1-CE-80-R-4-C7-G-03-GBA-40-38-24-F023	SERIES 90	S90-100PV
9622571	PUMP-VAR DISPL, CW	90-R-100-EP-2-AB-60-L-F-F1-E-33-GBA-38-38-24	SERIES 90	S90-100PV
9622573	PUMP-VAR DISPL, CW	90-R-100-MA-1-AB-80-S-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9622574	PUMP-VAR DISPL, CW	90-R-100-MA-1-CD-80-S-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9622575	PUMP-VAR DISPL, CW	90-R-100-LE-1-BC-80-S-3-C7-D-02-FAC-43-43-20	SERIES 90	S90-100PV
9622576	PUMP-VAR DISPL, CW	90-R-100-KP-5-NN-80-R-3-S1-F-03-GBA-38-38-24	SERIES 90	S90-100PV
9622577	PUMP-VAR DISPL, CW	90-R-100-DD-1-NN-81-L-3-F1-E-GB-GBA-42-42-24	SERIES 90	S90-100PV
9622578	PUMP-VAR DISPL, CW	90-R-100-KA-1-AB-60-P-3-T2-E-00-GBA-32-32-24	SERIES 90	S90-100PV
9622579	PUMP-VAR DISPL, CW	90-R-100-EP-2-AB-60-L-F-F1-F-33-GBA-38-38-24	SERIES 90	S90-100PV
9622581	PUMP-VAR DISPL, CW	90-R-100-KA-1-BB-61-R-4-F1-F-00-FAD-35-35-24	SERIES 90	S90-100PV
9622582	PUMP-VAR DISPL, CW	90-R-100-KA-1-BC-61-R-4-F1-F-00-FAD-35-35-24	SERIES 90	S90-100PV
9622583	PUMP-VAR DISPL, CW	90-R-100-KP-5-BC-80-P-3-S1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
9622584	PUMP-VAR DISPL, CW	90-R-100-MA-1-BC-60-S-3-K3-E-04-GBA-29-29-20	SERIES 90	S90-100PV
9622585	PUMP-VAR DISPL, CW	90-R-100-KP-2-AB-81-S-3-S1-F-03-GBA-20-20-24	SERIES 90	S90-100PV
9622586	PUMP-VAR DISPL, CW	90-R-100-KA-1-BC-61-R-4-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9622587	PUMP-VAR DISPL, CW	90-R-100-KA-5-AB-80-R-4-S1-F-03-GBA-38-38-24	SERIES 90	S90-100PV
9622588	PUMP-VAR DISPL, CW	90-R-100-KP-5-BC-80-L-3-F1-F-03-GBA-32-32-24	SERIES 90	S90-100PV
9622590	PUMP-VAR DISPL, CW	90-R-100-KA-1-NN-80-S-3-F1-F-00-GBA-42-42-24	SERIES 90	S90-100PV

9622591	PUMP-VAR DISPL, CW	90-R-100-KP-5-NN-80-L-4-K3-F-03-GBA-17-17-24	SERIES 90	S90-100PV
9622594	PUMP-VAR DISPL, CW	90-R-100-KP-1-NN-60-S-4-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9622595	PUMP-VAR DISPL, CW	90-R-100-DC-1-CD-80-P-3-F1-E-GB-GBA-38-38-24	SERIES 90	S90-100PV
9622596	PUMP-VAR DISPL, CW	90-R-100-MB-2-BC-60-R-3-F1-E-04-FAD-38-38-24	SERIES 90	S90-100PV
9622597	PUMP-VAR DISPL, CW	90-R-100-DC-5-AB-60-P-4-S1-E-G8-GBA-35-35-24	SERIES 90	S90-100PV
9622598	PUMP-VAR DISPL, CW	90-R-100-DC-5-CD-60-P-4-T2-E-G8-GBA-35-35-24	SERIES 90	S90-100PV
9622599	PUMP-VAR DISPL, CW	90-R-100-KP-1-BB-80-P-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9622600	PUMP-VAR DISPL, CW	90-R-100-KA-1-NN-60-L-3-F1-D-02-GBA-42-42-20	SERIES 90	S90-100PV
9622602	PUMP-VAR DISPL, CW	90-R-100-MB-1-BC-80-P-3-S1-E-03-GBA-32-32-24	SERIES 90	S90-100PV
9622603	PUMP-VAR DISPL, CW	90-R-100-MA-1-NN-60-S-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9622604	PUMP-VAR DISPL, CW	90-R-100-MA-1-BC-60-S-4-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9622605	PUMP-VAR DISPL, CW	90-R-100-MA-1-CD-60-S-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9622606	PUMP-VAR DISPL, CW	90-R-100-KP-1-NN-60-L-3-F1-D-02-GBA-42-42-20	SERIES 90	S90-100PV
9622607	PUMP-VAR DISPL, CW	90-R-100-KA-1-CD-80-P-4-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9622608	PUMP-VAR DISPL, CW	90-R-100-MA-1-BC-80-S-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9622609	PUMP-VAR DISPL, CW	90-R-100-KP-5-BC-80-R-3-S1-F-03-GBA-26-26-24	SERIES 90	S90-100PV
9622610	PUMP-VAR DISPL, CW	90-R-100-HF-1-AB-80-L-4-F1-F-00-GBA-29-14-24	SERIES 90	S90-100PV
9622611	PUMP-VAR DISPL, CW	90-R-100-CB-1-NN-80-S-3-F1-E-00-GBA-35-35-24-P000	SERIES 90	S90-100PV
9622612	PUMP-VAR DISPL, CW	90-R-100-HF-1-BC-80-S-4-F1-E-03-GBA-35-35-20	SERIES 90	S90-100PV
9622614	PUMP-VAR DISPL, CW	90-R-100-KA-1-BC-80-R-3-S1-E-09-GBA-35-35-24	SERIES 90	S90-100PV
9622615	PUMP-VAR DISPL, CW	90-R-100-KP-1-BC-80-R-3-F1-F-03-EBC-35-35-24	SERIES 90	S90-100PV
9622616	PUMP-VAR DISPL, CW	90-R-100-KP-1-AB-80-L-3-T2-E-03-GBA-23-23-28	SERIES 90	S90-100PV
9622617	PUMP-VAR DISPL, CW	90-R-100-KP-1-CD-80-L-3-S1-E-03-GBA-38-38-24	SERIES 90	S90-100PV
9622618	PUMP-VAR DISPL, CW	90-R-100-KP-1-NN-80-P-4-S1-E-03-EBC-38-38-28	SERIES 90	S90-100PV
9622618C	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-NN-80-P-4-S1-E-03-EBC-38-38-28	SERIES 90	S90-100PV
9622619	PUMP-VAR DISPL, CW	90-R-100-KA-1-NN-60-S-3-S1-F-00-GBA-35-35-24	SERIES 90	S90-100PV
9622619C	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-NN-60-S-3-S1-F-00-GBA-35-35-24	SERIES 90	S90-100PV
9622620	PUMP-VAR DISPL, CW	90-R-100-MA-1-BC-60-L-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9622621	PUMP-VAR DISPL, CW	90-R-100-KP-1-CD-80-R-4-F1-F-00-GBA-32-32-30	SERIES 90	S90-100PV
9622621C	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-CD-80-R-4-F1-F-00-GBA-32-32-30	SERIES 90	S90-100PV
9622622	PUMP-VAR DISPL, CW	90-R-100-MA-1-AB-80-S-3-S1-E-02-GBA-35-35-24	SERIES 90	S90-100PV
9622623	PUMP-VAR DISPL, CW	90-R-100-MA-1-CD-80-S-3-C7-E-02-GBA-35-35-24	SERIES 90	S90-100PV
9622624	PUMP-VAR DISPL, CW	90-R-100-KP-1-BB-80-P-3-F1-E-03-GBA-14-32-24	SERIES 90	S90-100PV
9622625	PUMP-VAR DISPL, CW	90-R-100-MV-1-BC-80-P-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9622626	PUMP-VAR DISPL, CW	90-R-100-MV-1-CD-80-P-4-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9622627	PUMP-VAR DISPL, CW	90-R-100-KP-1-CD-80-P-3-C7-F-03-GBA-35-35-24	SERIES 90	S90-100PV

9622627C	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-CD-80-P-3-C7-F-03-GBA-35-35-24	SERIES 90	S90-100PV
9622628	PUMP-VAR DISPL, CW	90-R-100-MV-1-CE-80-L-3-C7-G-04-GBA-42-42-30	SERIES 90	S90-100PV
9622629	PUMP-VAR DISPL, CW	90-R-100-MV-1-CE-80-L-3-J3-G-04-GBA-42-42-30	SERIES 90	S90-100PV
9622630	PUMP-VAR DISPL, CW	90-R-100-MB-1-CD-80-R-3-F1-E-03-GBA-29-29-24	SERIES 90	S90-100PV
9622630C	PUMP-VAR DISPL, CW 90PV100	90-R-100-MB-1-CD-80-R-3-F1-E-03-GBA-29-29-24	SERIES 90	S90-100PV
9622631	PUMP-VAR DISPL, CW	90-R-100-KP-1-CD-80-R-3-K3-E-02-GBA-23-23-24	SERIES 90	S90-100PV
9622632	PUMP-VAR DISPL, CW	90-R-100-HS-2-CD-60-P-3-F1-E-03-GBA-38-38-24	SERIES 90	S90-100PV
9622632C	PUMP-VAR DISPL, CW 90PV100	90-R-100-HS-2-CD-60-P-3-F1-E-03-GBA-38-38-24	SERIES 90	S90-100PV
9622633	PUMP-VAR DISPL, CW	90-R-100-HS-2-AB-60-P-3-S1-E-03-GBA-38-38-24	SERIES 90	S90-100PV
9622633C	PUMP-VAR DISPL, CW 90PV100	90-R-100-HS-2-AB-60-P-3-S1-E-03-GBA-38-38-24	SERIES 90	S90-100PV
9622634	PUMP-VAR DISPL, CW	90-R-100-KP-1-NN-80-P-3-F1-E-03-GBA-17-17-24	SERIES 90	S90-100PV
9622634C	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-NN-80-P-3-F1-E-03-GBA-17-17-24	SERIES 90	S90-100PV
9622636	PUMP-VAR DISPL, CW	90-R-100-KP-1-CD-60-P-3-C7-E-03-GBA-38-38-24	SERIES 90	S90-100PV
9622636C	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-CD-60-P-3-C7-E-03-GBA-38-38-24	SERIES 90	S90-100PV
9622637	PUMP-VAR DISPL, CW	90-R-100-LS-1-BA-80-L-3-J3-G-04-GBA-44-44-30	SERIES 90	S90-100PV
9622638	PUMP-VAR DISPL, CW	90-R-100-LS-1-CE-80-L-3-C7-G-04-GBA-44-44-30	SERIES 90	S90-100PV
9622639	PUMP-VAR DISPL, CW	90-R-100-HS-1-NN-60-S-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9622639C	PUMP-VAR DISPL, CW 90PV100	90-R-100-HS-1-NN-60-S-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9622640	PUMP-VAR DISPL, CW	90-R-100-DC-1-CD-80-S-4-F1-E-GB-GBA-35-35-24-F023	SERIES 90	S90-100PV
9622641	PUMP-VAR DISPL, CW	90-R-100-DC-1-BC-80-S-4-S1-E-GB-GBA-35-35-24-F023	SERIES 90	S90-100PV
9622642	PUMP-VAR DISPL, CW	90-R-100-KP-1-NN-60-S-3-C7-E-03-GBA-40-40-24	SERIES 90	S90-100PV
9622642C	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-NN-60-S-3-C7-E-03-GBA-40-40-24	SERIES 90	S90-100PV
9622643	PUMP-VAR DISPL, CW	90-R-100-KP-1-CD-60-R-3-C7-E-03-GBA-38-38-24	SERIES 90	S90-100PV
9622643C	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-CD-60-R-3-C7-E-03-GBA-38-38-24	SERIES 90	S90-100PV
9622644	PUMP-VAR DISPL, CW	90-R-100-HS-1-BC-80-S-3-S1-E-03-GBA-32-32-24	SERIES 90	S90-100PV
9622645	PUMP-VAR DISPL, CW	90-R-100-HF-1-BC-60-S-4-C7-F-04-GBA-26-26-18	SERIES 90	S90-100PV
9622645C	PUMP-VAR DISPL, CW 90PV100	90-R-100-HF-1-BC-60-S-4-C7-F-04-GBA-26-26-18	SERIES 90	S90-100PV
9622646	PUMP-VAR DISPL, CW	90-R-100-DC-1-CD-80-S-4-C7-E-GB-GBA-35-35-24	SERIES 90	S90-100PV
9622647	PUMP-VAR DISPL, CW	90-R-100-KP-1-BC-80-R-3-S1-F-03-EBC-35-35-24	SERIES 90	S90-100PV
9622648	PUMP-VAR DISPL, CW	90-R-100-KP-1-BC-80-R-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
9622649	PUMP-VAR DISPL, CW	90-R-100-MA-1-BB-80-S-3-C7-E-03-GBA-38-38-24	SERIES 90	S90-100PV
9622651	PUMP-VAR DISPL, CW	90-R-100-MB-1-NN-80-L-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9622652	PUMP-VAR DISPL, CW	90-R-100-HS-1-BB-60-R-4-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9622653	PUMP-VAR DISPL, CW	90-R-100-KP-1-AB-81-S-3-T2-F-00-EBC-35-35-20	SERIES 90	S90-100PV
9622654	PUMP-VAR DISPL, CW	90-R-100-KP-5-CD-80-R-3-F1-E-02-GBA-35-35-24	SERIES 90	S90-100PV
9622655	PUMP-VAR DISPL, CW	90-R-100-KP-5-BC-80-R-3-S1-E-02-GBA-35-35-24	SERIES 90	S90-100PV

9622656	PUMP-VAR DISPL, CW	90-R-100-KP-1-CD-80-L-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9622657	PUMP-VAR DISPL, CW	90-R-100-HF-1-BC-80-R-3-S1-E-09-GBA-38-38-24	SERIES 90	S90-100PV
9622658	PUMP-VAR DISPL, CW	90-R-100-KP-1-CD-80-P-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9622659	PUMP-VAR DISPL, CW	90-R-100-KP-5-CD-80-L-3-F1-F-03-GBA-32-32-24	SERIES 90	S90-100PV
9622660	PUMP-VAR DISPL, CW	90-R-100-KP-1-AB-80-S-3-S1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
9622661	PUMP-VAR DISPL, CW	90-R-100-HF-1-AB-60-P-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9622661C	PUMP-VAR DISPL, CW 90PV100	90-R-100-HF-1-AB-60-P-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9622662	PUMP-VAR DISPL, CW	90-R-100-KA-2-NN-60-S-4-F1-F-03-GBA-23-23-20	SERIES 90	S90-100PV
9622663	PUMP-VAR DISPL, CW	90-R-100-HS-5-BC-60-S-4-S1-F-03-GBA-23-23-24	SERIES 90	S90-100PV
9622664	PUMP-VAR DISPL, CW	90-R-100-KP-5-AB-80-R-3-S1-E-03-GBA-38-38-24	SERIES 90	S90-100PV
9622665	PUMP-VAR DISPL, CW	90-R-100-HS-5-BC-60-S-4-S1-F-03-GBA-23-23-28	SERIES 90	S90-100PV
9622666	PUMP-VAR DISPL, CW	90-R-100-KP-1-AB-80-L-3-T2-E-00-GBA-26-26-28	SERIES 90	S90-100PV
9622669	PUMP-VAR DISPL, CW	90-R-100-MA-1-CD-80-S-3-F1-E-00-GBA-35-35-24	SERIES 90	S90-100PV
9622670	PUMP-VAR DISPL, CW	90-R-100-KA-5-NN-60-S-3-K3-F-00-EBC-35-35-24	SERIES 90	S90-100PV
9622672	PUMP-VAR DISPL, CW	90-R-100-KP-1-CD-60-S-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9622672C	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-CD-60-S-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9622673	PUMP-VAR DISPL, CW	90-R-100-CB-1-NN-60-S-4-F1-E-00-GBA-35-35-24	SERIES 90	S90-100PV
9622673C	PUMP-VAR DISPL, CW 90PV100	90-R-100-CB-1-NN-60-S-4-F1-E-00-GBA-35-35-24	SERIES 90	S90-100PV
9622674	PUMP-VAR DISPL, CW	90-R-100-KN-5-BC-80-R-3-F1-F-03-EEB-13-13-20	SERIES 90	S90-100PV
9622675C	PUMP-VAR DISPL, CW 90PV100	90-R-100-CB-1-NN-80-S-4-F1-E-00-GBA-35-35-24	SERIES 90	S90-100PV
9622676	PUMP-VAR DISPL, CW	90-R-100-MA-1-CD-60-P-3-F1-E-00-GBA-35-35-20	SERIES 90	S90-100PV
9622676C	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-CD-60-P-3-F1-E-00-GBA-35-35-20	SERIES 90	S90-100PV
9622677	PUMP-VAR DISPL, CW	90-R-100-MA-1-NN-60-L-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9622677C	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-NN-60-L-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9622678	PUMP-VAR DISPL, CW	90-R-100-HK-1-CD-60-S-3-F1-E-03-GBA-17-17-20	SERIES 90	S90-100PV
9622679	PUMP-VAR DISPL, CW	90-R-100-KP-1-AB-60-S-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9622679C	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-AB-60-S-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9622680	PUMP-VAR DISPL, CW	90-R-100-MA-1-BC-80-S-3-F1-E-00-GBA-42-42-24	SERIES 90	S90-100PV
9622681	PUMP-VAR DISPL, CW	90-R-100-KP-1-AB-60-R-3-F1-E-03-GBA-38-38-24	SERIES 90	S90-100PV
9622682	PUMP-VAR DISPL, CW	90-R-100-KP-6-NN-60-P-3-F1-E-00-GBA-48-48-24	SERIES 90	S90-100PV
9622682C	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-6-NN-60-P-3-F1-E-00-GBA-48-48-24	SERIES 90	S90-100PV
9622683	PUMP-VAR DISPL, CW	90-R-100-KP-6-NN-80-P-3-S1-E-00-GBA-48-48-24	SERIES 90	S90-100PV
9622683C	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-6-NN-80-P-3-S1-E-00-GBA-48-48-24	SERIES 90	S90-100PV
9622684	PUMP-VAR DISPL, CW	90-R-100-HF-1-CD-60-R-4-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9622685	PUMP-VAR DISPL, CW	90-R-100-MB-1-BC-60-R-3-F1-E-C5-GBA-35-35-24	SERIES 90	S90-100PV
9622686	PUMP-VAR DISPL, CW	90-R-100-KP-1-BC-80-L-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV

9622687	PUMP-VAR DISPL, CW	90-R-100-KN-1-NN-60-D-4-F1-L-03-GBA-29-29-28	SERIES 90	S90-100PV
9622688	PUMP-VAR DISPL, CW	90-R-100-KA-1-NN-60-P-4-C7-F-03-GBA-38-38-24	SERIES 90	S90-100PV
9622689	PUMP-VAR DISPL, CW	90-R-100-MB-5-BC-60-R-3-F1-E-C5-GBA-35-35-24	SERIES 90	S90-100PV
9622690	PUMP-VAR DISPL, CW	90-R-100-LE-1-CD-80-R-2-C7-F-03-GBA-38-17-28-F061	SERIES 90	S90-100PV
9622691	PUMP-VAR DISPL, CW	90-R-100-CB-1-BC-80-P-7-S1-E-00-GCA-32-32-24-P000	SERIES 90	S90-100PV
9622692	PUMP-VAR DISPL, CW	90-R-100-KA-1-NN-60-P-3-S1-E-03-GBA-32-32-24	SERIES 90	S90-100PV
9622695	PUMP-VAR DISPL, CW	90-R-100-KA-1-CD-60-R-4-F1-E-03-GBA-26-26-24	SERIES 90	S90-100PV
9622696	PUMP-VAR DISPL, CW	90-R-100-KP-1-BC-80-R-4-T2-E-02-GBA-26-26-24	SERIES 90	S90-100PV
9622697	PUMP-VAR DISPL, CW	90-R-100-KP-1-BC-60-S-3-C7-E-03-GBA-20-20-20	SERIES 90	S90-100PV
9622698	PUMP-VAR DISPL, CW	90-R-100-HF-5-CD-80-R-3-F1-E-02-GBA-35-35-24	SERIES 90	S90-100PV
9622699	PUMP-VAR DISPL, CW	90-R-100-HF-5-BC-80-R-3-S1-E-02-GBA-35-35-24	SERIES 90	S90-100PV
9622700	PUMP-VAR DISPL, CCW	90-L-100-MA-1-NN-60-R-4-S1-E-03-GBA-14-35-24	SERIES 90	S90-100PV
9622701	PUMP-VAR DISPL, CCW	90-L-100-KA-1-CD-60-S-3-F1-E-03-GBA-42-14-24	SERIES 90	S90-100PV
9622702	PUMP-VAR DISPL, CCW	90-L-100-HS-1-BC-60-R-4-F1-E-05-FAD-32-32-28-F023	SERIES 90	S90-100PV
9622703	PUMP-VAR DISPL, CCW	90-L-100-KP-1-AB-80-L-3-T2-E-00-GBA-26-26-28	SERIES 90	S90-100PV
9622704	PUMP-VAR DISPL, CCW	90-L-100-MA-6-AB-80-L-3-S1-F-05-GBA-45-45-24	SERIES 90	S90-100PV
9622705	PUMP-VAR DISPL, CCW	90-L-100-KP-1-NN-80-R-3-S1-F-03-EBC-35-35-24	SERIES 90	S90-100PV
9622706	PUMP-VAR DISPL, CCW	90-L-100-KA-1-CD-80-L-4-S1-E-03-GBA-23-23-24	SERIES 90	S90-100PV
9622708	PUMP-VAR DISPL, CCW	90-L-100-KP-5-AB-80-S-4-C7-E-03-GBA-20-20-24	SERIES 90	S90-100PV
9622708C	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-5-AB-80-S-4-C7-E-03-GBA-20-20-24	SERIES 90	S90-100PV
9622709	PUMP-VAR DISPL, CCW	90-L-100-KN-1-NN-80-R-4-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9622710	PUMP-VAR DISPL, CCW	90-L-100-DC-1-CD-80-R-4-F1-E-GB-GBA-42-42-24	SERIES 90	S90-100PV
9622711	PUMP-VAR DISPL, CCW	90-L-100-HF-5-NN-80-L-4-F1-E-03-GBA-38-38-24	SERIES 90	S90-100PV
9622712	PUMP-VAR DISPL, CCW	90-L-100-MA-6-AB-60-L-3-T2-F-05-GBA-48-48-24	SERIES 90	S90-100PV
9622713	PUMP-VAR DISPL, CCW	90-L-100-KP-5-BC-80-R-3-S1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
9622714	PUMP-VAR DISPL, CCW	90-L-100-CB-1-NN-60-S-4-F1-E-00-GBA-35-35-24	SERIES 90	S90-100PV
9622714C	PUMP-VAR DISPL, CCW 90PV100	90-L-100-CB-1-NN-60-S-4-F1-E-00-GBA-35-35-24	SERIES 90	S90-100PV
9622715	PUMP-VAR DISPL, CCW	90-L-100-KT-1-BC-80-L-3-C7-F-00-GBA-44-44-34	SERIES 90	S90-100PV
9622716	PUMP-VAR DISPL, CCW	90-L-100-DD-1-BC-80-R-4-F1-E-GB-GBA-42-42-24	SERIES 90	S90-100PV
9622717	PUMP-VAR DISPL, CCW	90-L-100-KP-1-NN-60-P-3-S1-F-03-GBA-38-38-24	SERIES 90	S90-100PV
9622718	PUMP-VAR DISPL, CCW	90-L-100-MB-1-NN-80-R-3-S1-D-03-GBA-42-42-24	SERIES 90	S90-100PV
9622719	PUMP-VAR DISPL, CCW	90-L-100-CB-1-NN-60-S-3-F1-E-00-GBA-35-35-24	SERIES 90	S90-100PV
9622720	PUMP-VAR DISPL, CCW	90-L-100-HF-1-NN-60-S-3-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9622721	PUMP-VAR DISPL, CCW	90-L-100-KP-1-CD-80-P-3-C7-E-03-EHA-35-35-24	SERIES 90	S90-100PV
9622721C	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-CD-80-P-3-C7-E-03-EHA-35-35-24	SERIES 90	S90-100PV
9622722	PUMP-VAR DISPL, CCW	90-L-100-KA-1-BC-60-S-3-S1-E-00-GBA-23-23-24	SERIES 90	S90-100PV

9622723	PUMP-VAR DISPL, CCW	90-L-100-HS-1-BB-80-L-3-F1-E-03-GBA-35-35-30	SERIES 90	S90-100PV
9622724	PUMP-VAR DISPL, CCW	90-L-100-HF-1-CD-60-S-4-F1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
9622725	PUMP-VAR DISPL, CCW	90-L-100-KA-1-NN-60-S-4-S1-E-00-GBA-42-42-24	SERIES 90	S90-100PV
9622726	PUMP-VAR DISPL, CCW	90-L-100-HF-5-AB-60-L-4-F1-E-03-GBA-38-38-24	SERIES 90	S90-100PV
9622727	PUMP-VAR DISPL, CCW	90-L-100-KP-1-AB-80-R-3-F1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
9622728	PUMP-VAR DISPL, CCW	90-L-100-HF-5-AB-80-L-4-F1-E-03-GBA-38-38-24	SERIES 90	S90-100PV
9622729	PUMP-VAR DISPL, CCW	90-L-100-LS-1-BL-80-R-3-J3-G-04-GBA-42-42-34	SERIES 90	S90-100PV
9622730	PUMP-VAR DISPL, CCW	90-L-100-LS-1-CE-80-R-3-C7-G-04-GBA-42-42-34	SERIES 90	S90-100PV
9622731	PUMP-VAR DISPL, CCW	90-L-100-KP-1-BB-80-S-3-F1-E-04-FAD-42-42-24	SERIES 90	S90-100PV
9622732	PUMP-VAR DISPL, CCW	90-L-100-M1-1-BC-80-S-3-TF-E-03-FAC-45-45-28	SERIES 90	S90-100PV
9622733	PUMP-VAR DISPL, CCW	90-L-100-LS-1-CE-80-R-3-C7-G-04-GBA-42-42-40	SERIES 90	S90-100PV
9622734	PUMP-VAR DISPL, CCW	90-L-100-LS-1-BL-80-R-3-J3-G-04-GBA-42-42-40	SERIES 90	S90-100PV
9622735	PUMP-VAR DISPL, CCW	90-L-100-KA-1-BC-80-S-3-C7-E-02-GBA-35-35-24	SERIES 90	S90-100PV
9622735C	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-BC-80-S-3-C7-E-02-GBA-35-35-24	SERIES 90	S90-100PV
9622736	PUMP-VAR DISPL, CCW	90-L-100-MB-1-CD-80-R-3-F1-E-03-GBA-29-29-24	SERIES 90	S90-100PV
9622736C	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MB-1-CD-80-R-3-F1-E-03-GBA-29-29-24	SERIES 90	S90-100PV
9622737	PUMP-VAR DISPL, CCW	90-L-100-CB-1-BC-80-P-7-S1-E-00-GCA-32-32-24-P000	SERIES 90	S90-100PV
9622738	PUMP-VAR DISPL, CCW	90-L-100-KP-1-NN-80-S-3-S1-E-03-EBC-29-29-24	SERIES 90	S90-100PV
9622739	PUMP-VAR DISPL, CCW	90-L-100-KP-1-AB-80-P-3-F1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
9622740	PUMP-VAR DISPL, CCW	90-L-100-KP-1-CD-80-P-3-F1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
9622741	PUMP-VAR DISPL, CCW	90-L-100-PE-5-NN-80-R-3-F1-E-00-GBA-23-23-20	SERIES 90	S90-100PV
9622742	PUMP-VAR DISPL, CCW	90-L-100-M8-1-NN-80-S-3-C7-E-03-GBA-40-40-24	SERIES 90	S90-100PV
9622742C	PUMP-VAR DISPL, CCW 90PV100	90-L-100-M8-1-NN-80-S-3-C7-E-03-GBA-40-40-24	SERIES 90	S90-100PV
9622743	PUMP-VAR DISPL, CCW	90-L-100-KA-1-BC-60-P-3-F1-E-03-GBA-35-35-20	SERIES 90	S90-100PV
9622744	PUMP-VAR DISPL, CCW	90-L-100-KA-1-NN-80-R-4-S1-E-03-GBA-23-23-24	SERIES 90	S90-100PV
9622745	PUMP-VAR DISPL, CCW	90-L-100-KP-1-CD-80-P-3-C7-F-03-EHA-35-35-24	SERIES 90	S90-100PV
9622745C	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-CD-80-P-3-C7-F-03-EHA-35-35-24	SERIES 90	S90-100PV
9622746	PUMP-VAR DISPL, CCW	90-L-100-KP-1-CD-80-R-3-F1-F-02-GBA-35-35-24	SERIES 90	S90-100PV
9622747	PUMP-VAR DISPL, CCW	90-L-100-KP-1-CD-80-P-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
9622749	PUMP-VAR DISPL, CCW	90-L-100-KP-1-CD-80-R-3-F1-E-03-GBA-40-40-28	SERIES 90	S90-100PV
9622750	PUMP-VAR DISPL, CCW	90-L-100-KP-1-BC-60-L-3-F1-F-03-GBA-38-38-24	SERIES 90	S90-100PV
9622751	PUMP-VAR DISPL, CCW	90-L-100-KA-1-AB-80-L-4-F1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
9622752	PUMP-VAR DISPL, CCW	90-L-100-DD-1-CD-60-P-3-C7-E-GB-GBA-42-42-24	SERIES 90	S90-100PV
9622752C	PUMP-VAR DISPL, CCW 90PV100	90-L-100-DD-1-CD-60-P-3-C7-E-GB-GBA-42-42-24	SERIES 90	S90-100PV
9622753	PUMP-VAR DISPL, CCW	90-L-100-KP-1-BC-80-P-3-S1-E-03-GBA-38-38-24	SERIES 90	S90-100PV
9622754	PUMP-VAR DISPL, CCW	90-L-100-MA-1-AB-80-L-4-F1-E-03-GBA-26-26-24	SERIES 90	S90-100PV

9622755	PUMP-VAR DISPL, CCW	90-L-100-KP-1-BC-80-P-3-T2-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9622756	PUMP-VAR DISPL, CCW	90-L-100-KA-1-NN-60-S-3-C7-E-03-GBA-23-23-24	SERIES 90	S90-100PV
9622756C	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-NN-60-S-3-C7-E-03-GBA-23-23-24	SERIES 90	S90-100PV
9622758	PUMP-VAR DISPL, CCW	90-L-100-KN-1-BC-60-P-3-F1-E-03-GBA-35-35-20	SERIES 90	S90-100PV
9622759	PUMP-VAR DISPL, CCW	90-L-100-KA-1-NN-60-P-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9622760	PUMP-VAR DISPL, CCW	90-L-100-KA-1-BB-60-P-3-F1-E-03-GBA-23-23-24	SERIES 90	S90-100PV
9622761	PUMP-VAR DISPL, CCW	90-L-100-KP-1-CD-80-P-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9622761C	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-CD-80-P-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9622763	PUMP-VAR DISPL, CCW	90-L-100-KA-1-AB-60-P-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9622764	PUMP-VAR DISPL, CCW	90-L-100-KA-6-NN-80-P-3-S1-F-00-GBA-48-48-24	SERIES 90	S90-100PV
9622765	PUMP-VAR DISPL, CCW	90-L-100-KN-1-BC-60-P-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9622766	PUMP-VAR DISPL, CCW	90-L-100-KP-5-CD-80-S-3-F1-F-02-GBA-42-42-24	SERIES 90	S90-100PV
9622767	PUMP-VAR DISPL, CCW	90-L-100-MA-5-NN-80-S-3-F1-E-C5-GBA-42-42-24	SERIES 90	S90-100PV
9622768	PUMP-VAR DISPL, CCW	90-L-100-MA-1-AC-60-S-3-F1-E-03-GBA-38-38-20	SERIES 90	S90-100PV
9622768C	PUMP-VAR DISPL, CCW	90-L-100-MA-1-AC-60-S-3-F1-E-03-GBA-38-38-20	SERIES 90	S90-100PV
9622769	PUMP-VAR DISPL, CCW	90-L-100-KA-1-NN-60-S-3-S1-E-00-GBA-23-23-24	SERIES 90	S90-100PV
9622770	PUMP-VAR DISPL, CCW	90-L-100-DC-2-BC-60-R-4-F1-E-G1-GBA-35-35-24	SERIES 90	S90-100PV
9622771	PUMP-VAR DISPL, CCW	90-L-100-KP-1-NN-60-S-3-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9622772	PUMP-VAR DISPL, CCW	90-L-100-HF-1-NN-80-P-3-S1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
9622773	PUMP-VAR DISPL, CCW	90-L-100-KP-1-BC-80-S-3-F1-D-03-FAD-42-42-24	SERIES 90	S90-100PV
9622774	PUMP-VAR DISPL, CCW	90-L-100-HS-2-NN-60-P-3-F1-E-03-GBA-38-38-24	SERIES 90	S90-100PV
9622774C	PUMP-VAR DISPL, CCW 90PV100	90-L-100-HS-2-NN-60-P-3-F1-E-03-GBA-38-38-24	SERIES 90	S90-100PV
9622775	PUMP-VAR DISPL, CCW	90-L-100-MB-1-NN-60-L-4-C7-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9622775C	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MB-1-NN-60-L-4-C7-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9622776	PUMP-VAR DISPL, CCW	90-L-100-HK-1-BC-80-S-3-S1-D-03-GBA-38-38-24	SERIES 90	S90-100PV
9622777	PUMP-VAR DISPL, CCW	90-L-100-EA-2-CD-60-S-4-F1-F-33-GBA-42-42-24	SERIES 90	S90-100PV
9622778	PUMP-VAR DISPL, CCW	90-L-100-HF-1-NN-80-P-3-F1-E-00-GBA-35-35-24	SERIES 90	S90-100PV
9622779	PUMP-VAR DISPL, CCW	90-L-100-KP-5-BC-80-R-3-S1-F-00-GBA-35-35-24	SERIES 90	S90-100PV
9622780	PUMP-VAR DISPL, CCW	90-L-100-KA-1-NN-80-R-3-S1-E-03-GBA-14-14-18	SERIES 90	S90-100PV
9622781	PUMP-VAR DISPL, CCW	90-L-100-MA-1-NN-80-L-4-F1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
9622782	PUMP-VAR DISPL, CCW	90-L-100-KP-1-CD-80-R-4-F1-E-03-GBA-35-35-20	SERIES 90	S90-100PV
9622783	PUMP-VAR DISPL, CCW	90-L-100-LS-1-CE-80-R-3-C7-G-04-FAP-42-42-40	SERIES 90	S90-100PV
9622784	PUMP-VAR DISPL, CCW	90-L-100-LS-1-BL-80-R-3-J3-G-04-FAP-42-42-40	SERIES 90	S90-100PV
9622785	PUMP-VAR DISPL, CCW	90-L-100-KA-5-NN-60-S-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9622785C	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-5-NN-60-S-3-S1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9622786	PUMP-VAR DISPL, CCW	90-L-100-LS-1-CD-80-L-3-C7-F-04-FAP-44-44-30	SERIES 90	S90-100PV

9622787	PUMP-VAR DISPL, CCW	90-L-100-LS-1-BC-80-L-3-J3-F-04-FAP-44-44-30	SERIES 90	S90-100PV
9622788	PUMP-VAR DISPL, CCW	90-L-100-MV-1-BC-80-P-4-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9622789	PUMP-VAR DISPL, CCW	90-L-100-KT-1-BC-80-L-3-C7-F-00-FAP-44-44-34	SERIES 90	S90-100PV
9622790	PUMP-VAR DISPL, CCW	90-L-100-KP-2-CD-60-R-4-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9622791	PUMP-VAR DISPL, CCW	90-L-100-KP-2-AB-60-R-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9622792	PUMP-VAR DISPL, CCW	90-L-100-KP-1-BC-80-S-3-F1-D-03-EBD-42-42-24	SERIES 90	S90-100PV
9622793	PUMP-VAR DISPL, CCW	90-L-100-MA-1-NN-80-S-3-C7-E-03-GBA-29-29-24	SERIES 90	S90-100PV
9622793C	PUMP-VAR DISPL, CCW 90PV100	90-L-100-MA-1-NN-80-S-3-C7-E-03-GBA-29-29-24	SERIES 90	S90-100PV
9622794	PUMP-VAR DISPL, CCW	90-L-100-KP-2-NN-60-P-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9622795	PUMP-VAR DISPL, CCW	90-L-100-KA-1-NN-60-S-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9622795C	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KA-1-NN-60-S-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9622796	PUMP-VAR DISPL, CCW	90-L-100-KP-1-NN-80-P-4-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9622797	PUMP-VAR DISPL, CCW	90-L-100-KP-1-NN-80-R-3-F1-D-03-GBA-14-14-18	SERIES 90	S90-100PV
9622798	PUMP-VAR DISPL, CCW	90-L-100-KP-1-CD-80-P-3-C7-F-03-GBA-35-35-24	SERIES 90	S90-100PV
9622798C	PUMP-VAR DISPL, CCW 90PV100	90-L-100-KP-1-CD-80-P-3-C7-F-03-GBA-35-35-24	SERIES 90	S90-100PV
9622802	PUMP-VAR DISPL, CCW	90-L-100-KP-1-AB-60-R-4-F1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
9622803	PUMP-VAR DISPL, CCW	90-L-100-KP-1-CD-80-P-3-F1-F-03-GBA-42-42-32	SERIES 90	S90-100PV
9622804	PUMP-VAR DISPL, CCW	90-L-100-HF-1-NN-80-P-3-S1-F-03-GBA-42-42-32	SERIES 90	S90-100PV
9622805	PUMP-VAR DISPL, CCW	90-L-100-HF-1-NN-60-L-3-F1-E-03-GBA-32-32-24	SERIES 90	S90-100PV
9622806	PUMP-VAR DISPL, CCW	90-L-100-CB-1-BC-80-L-4-S1-E-00-GBA-29-29-20	SERIES 90	S90-100PV
9622807	PUMP-VAR DISPL, CCW	90-L-100-KP-1-BC-80-P-3-S1-F-09-GBA-32-32-24	SERIES 90	S90-100PV
9622808	PUMP-VAR DISPL, CCW	90-L-100-KA-1-CD-80-R-3-F1-F-03-GBA-42-42-24	SERIES 90	S90-100PV
9622809	PUMP-VAR DISPL, CCW	90-L-100-KP-5-AB-80-S-3-F1-E-03-FAD-45-45-24	SERIES 90	S90-100PV
9622810	PUMP-VAR DISPL, CCW	90-L-100-KP-5-CD-80-S-3-F1-E-03-FAD-45-45-24	SERIES 90	S90-100PV
9622811	PUMP-VAR DISPL, CCW	90-L-100-KP-1-BC-80-R-4-T2-F-03-GBA-26-26-24	SERIES 90	S90-100PV
9622812	PUMP-VAR DISPL, CCW	90-L-100-HS-5-AB-60-R-3-F1-E-05-GBA-42-42-28	SERIES 90	S90-100PV
9623200	PUMP-VAR DISPL, CW	90-R-100-KP-1-BC-80-P-3-S1-E-03-GBA-38-38-24	SERIES 90	S90-100PV
9623201	PUMP-VAR DISPL, CW	90-R-100-MA-1-AB-60-P-3-C7-E-03-GBA-32-32-24	SERIES 90	S90-100PV
9623201C	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-AB-60-P-3-C7-E-03-GBA-32-32-24	SERIES 90	S90-100PV
9623202	PUMP-VAR DISPL, CW	90-R-100-KT-5-BC-80-P-3-S1-F-03-GBA-35-35-24	SERIES 90	S90-100PV
9623203	PUMP-VAR DISPL, CW	90-R-100-KT-5-BL-81-L-3-S1-G-03-GBA-35-35-24	SERIES 90	S90-100PV
9623204	PUMP-VAR DISPL, CW	90-R-100-HF-1-NN-80-L-4-F1-E-03-GBA-26-26-24	SERIES 90	S90-100PV
9623205	PUMP-VAR DISPL, CW	90-R-100-MA-1-AB-60-P-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9623205C	PUMP-VAR DISPL, CW 90PV100	90-R-100-MA-1-AB-60-P-3-C7-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9623206	PUMP-VAR DISPL, CW	90-R-100-MB-5-NN-60-S-3-C7-E-C5-GBA-20-20-24	SERIES 90	S90-100PV
9623207	PUMP-VAR DISPL, CW	90-R-100-MB-5-CD-80-L-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV

9623209	PUMP-VAR DISPL, CW	90-R-100-KP-1-BC-60-L-3-S1-E-03-GBA-23-23-24	SERIES 90	S90-100PV
9623210	PUMP-VAR DISPL, CW	90-R-100-MA-1-NN-80-S-3-F1-E-03-GBA-20-20-24	SERIES 90	S90-100PV
9623211	PUMP-VAR DISPL, CW	90-R-100-KP-1-BC-80-P-3-T2-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9623212	PUMP-VAR DISPL, CW	90-R-100-KA-1-NN-80-S-4-S1-E-03-GBA-17-17-20	SERIES 90	S90-100PV
9623213	PUMP-VAR DISPL, CW	90-R-100-CB-1-NN-80-S-4-F1-E-00-GBA-42-42-24	SERIES 90	S90-100PV
9623214	PUMP-VAR DISPL, CW	90-R-100-KA-1-BC-60-S-3-F1-F-06-GBA-42-42-24	SERIES 90	S90-100PV
9623216	PUMP-VAR DISPL, CW	90-R-100-HS-2-CD-60-P-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9623216C	PUMP-VAR DISPL, CW 90PV100	90-R-100-HS-2-CD-60-P-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9623217	PUMP-VAR DISPL, CW	90-R-100-HS-2-AB-60-P-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9623217C	PUMP-VAR DISPL, CW 90PV100	90-R-100-HS-2-AB-60-P-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9623218	PUMP-VAR DISPL, CW	90-R-100-MA-1-BC-80-S-3-S1-E-02-GBA-35-35-24	SERIES 90	S90-100PV
9623220	PUMP-VAR DISPL, CW	90-R-100-KA-1-BC-60-P-3-S1-E-03-GBA-32-32-24	SERIES 90	S90-100PV
9623220C	PUMP-VAR DISPL, CW 90PV100	90-R-100-KA-1-BC-60-P-3-S1-E-03-GBA-32-32-24	SERIES 90	S90-100PV
9623221	PUMP-VAR DISPL, CW	90-R-100-KP-1-BC-80-S-3-F1-D-03-FAD-42-42-24	SERIES 90	S90-100PV
9623222	PUMP-VAR DISPL, CW	90-R-100-KP-1-BC-80-P-3-F1-F-00-GBA-45-14-24	SERIES 90	S90-100PV
9623223	PUMP-VAR DISPL, CW	90-R-100-HS-1-AB-60-S-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9623223C	PUMP-VAR DISPL, CW 90PV100	90-R-100-HS-1-AB-60-S-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9623224	PUMP-VAR DISPL, CW	90-R-100-DD-1-BC-80-L-4-S1-E-GB-GBA-26-26-24	SERIES 90	S90-100PV
9623224C	PUMP-VAR DISPL, CW 90PV100	90-R-100-DD-1-BC-80-L-4-S1-E-GB-GBA-26-26-24	SERIES 90	S90-100PV
9623225	PUMP-VAR DISPL, CW	90-R-100-DC-1-AB-80-R-4-S1-E-GB-GBA-26-26-24	SERIES 90	S90-100PV
9623226	PUMP-VAR DISPL, CW	90-R-100-KA-1-CD-80-P-4-F1-E-00-GBA-32-32-24	SERIES 90	S90-100PV
9623227	PUMP-VAR DISPL, CW	90-R-100-KA-1-AB-80-L-4-F1-F-04-GBA-35-14-24	SERIES 90	S90-100PV
9623228	PUMP-VAR DISPL, CW	90-R-100-LS-1-CE-80-L-3-C7-G-04-FAP-44-44-30	SERIES 90	S90-100PV
9623229	PUMP-VAR DISPL, CW	90-R-100-LS-1-BA-80-L-3-J3-G-04-FAP-44-44-30	SERIES 90	S90-100PV
9623231	PUMP-VAR DISPL, CW	90-R-100-HK-1-BC-80-S-3-S1-D-03-GBA-38-38-24	SERIES 90	S90-100PV
9623232	PUMP-VAR DISPL, CW	90-R-100-KA-1-CD-60-R-4-S1-E-03-GBA-32-32-24	SERIES 90	S90-100PV
9623233	PUMP-VAR DISPL, CW	90-R-100-KP-1-CD-80-L-4-S1-E-03-GBA-23-23-24	SERIES 90	S90-100PV
9623233C	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-CD-80-L-4-S1-E-03-GBA-23-23-24	SERIES 90	S90-100PV
9623234	PUMP-VAR DISPL, CW	90-R-100-KA-1-CD-80-L-4-F1-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9623235	PUMP-VAR DISPL, CW	90-R-100-KA-1-CD-80-L-4-F1-E-03-GBA-14-14-24	SERIES 90	S90-100PV
9623236	PUMP-VAR DISPL, CW	90-R-100-KP-1-CD-80-P-4-F1-E-00-GBA-32-32-24	SERIES 90	S90-100PV
9623237	PUMP-VAR DISPL, CW	90-R-100-KP-1-AB-80-L-4-S1-E-00-EBC-35-35-24	SERIES 90	S90-100PV
9623238	PUMP-VAR DISPL, CW	90-R-100-HK-1-BC-80-S-3-S1-E-03-GBA-38-38-24	SERIES 90	S90-100PV
9623239	PUMP-VAR DISPL, CW	90-R-100-MB-1-BC-60-S-3-F1-E-03-GBA-35-35-20	SERIES 90	S90-100PV
9623240	PUMP-VAR DISPL, CW	90-R-100-KP-1-CD-80-P-3-F1-F-03-GBA-26-26-24	SERIES 90	S90-100PV
9623240C	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-CD-80-P-3-F1-F-03-GBA-26-26-24	SERIES 90	S90-100PV

9623241	PUMP-VAR DISPL, CW	90-R-100-MB-1-CD-60-S-3-C7-F-03-GBA-42-42-24	SERIES 90	S90-100PV
9623244	PUMP-VAR DISPL, CW	90-R-100-M8-1-CD-60-P-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9623244C	PUMP-VAR DISPL, CW 90PV100	90-R-100-M8-1-CD-60-P-3-C7-E-03-GBA-42-42-24	SERIES 90	S90-100PV
9623245	PUMP-VAR DISPL, CW	90-R-100-KP-1-AB-80-P-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9623245C	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-AB-80-P-3-F1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9623246	PUMP-VAR DISPL, CW	90-R-100-KP-1-NN-80-P-3-S1-F-09-GBA-32-32-24	SERIES 90	S90-100PV
9623247	PUMP-VAR DISPL, CW	90-R-100-KP-5-CD-80-S-3-F1-E-03-GBA-45-45-24	SERIES 90	S90-100PV
9623248	PUMP-VAR DISPL, CW	90-R-100-KP-5-AB-80-S-3-S1-E-03-GBA-45-45-28	SERIES 90	S90-100PV
9623249	PUMP-VAR DISPL, CW	90-R-100-KP-5-CD-80-S-3-F1-E-03-GBA-45-45-28	SERIES 90	S90-100PV
9623250	PUMP-VAR DISPL, CW	90-R-100-KP-1-NN-60-R-3-C7-E-03-GBA-38-38-24	SERIES 90	S90-100PV
9623250C	PUMP-VAR DISPL, CW 90PV100	90-R-100-KP-1-NN-60-R-3-C7-E-03-GBA-38-38-24	SERIES 90	S90-100PV
9623251	PUMP-VAR DISPL, CW	90-R-100-KA-1-NN-61-S-3-F1-F-03-GBA-14-35-20	SERIES 90	S90-100PV
9623252	PUMP-VAR DISPL, CW	90-R-100-KP-1-CD-80-R-4-T2-F-03-GBA-26-26-24	SERIES 90	S90-100PV
9623253	PUMP-VAR DISPL, CW	90-R-100-KP-5-CD-80-R-3-S1-E-03-GBA-35-35-24	SERIES 90	S90-100PV
9623254	PUMP-VAR DISPL, CW	90-R-100-KP-5-CD-80-R-3-F1-E-02-GBA-35-35-24	SERIES 90	S90-100PV
9623255	PUMP-VAR DISPL, CW	90-R-100-KP-5-CD-80-R-3-S1-E-02-GBA-35-35-24	SERIES 90	S90-100PV
9631052	MOTOR-FIXED-DISPL 90MF100	90-M-100-NC-0-N-8-N-0-S1-W-00-EAA-00-00-F3	SERIES 90	S90-100MF
9631091	MOTOR-FIXED-DISPL 90MF100	90-M-100-NC-0-N-7-N-0-C7-W-00-NNN-00-00-E6	SERIES 90	S90-100MF
9631103	MOTOR-FIX DISPL	90-M-100-NC-0-N-7-N-0-C7-W-00-EAA-00-00-F3	SERIES 90	S90-100MF
9631112	MOTOR-FIX DISPL	90-M-100-NC-0-N-8-N-0-F1-W-00-EEA-00-00-G0	SERIES 90	S90-100MF
9631122	MOTOR-FIX DISPL	90-M-100-NC-0-N-8-N-0-C7-W-00-NNN-00-00-G0	SERIES 90	S90-100MF
9631128	MOTOR-FIXED DISPL, 90MF100	90-M-100-NC-0-N-8-N-0-F1-W-00-EBA-00-00-E4	SERIES 90	S90-100MF
972-040010	PUMP-VAR DISPL, CW 90PV130	90-R-130-KP-1-CD-80-S-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-130PV
9721052	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-1-BC-80-R-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-130PV
9721094	PUMP-VAR-DISPL CCW 90PV130	90L130-EA-1-CD-80-S-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-130PV
9721096	PUMP-VAR-DISPL CCW 90PV130 BASE MODEL	90L130-CB-1-NN-80-S-3-F1-F-00-EEB-35-35-24-P000	SERIES 90	S90-130PV
9721115	PUMP-VAR-DISPL CCW 90PV130	90L130-EA-1-AB-80-R-3-F1-F-04-GBA-42-42-24	SERIES 90	S90-130PV
9721116	PUMP-VAR-DISPL CCW 90PV130	90L130-MA-1-BC-80-S-3-T4-F-03-GBA-42-42-24	SERIES 90	S90-130PV
9721120	PUMP-VAR-DISPL CCW 90PV130	90L130-EA-1-NN-80-L-3-F1-H-03-GBA-35-35-24	SERIES 90	S90-130PV
9721126	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-1-BB-80-L-3-F1-H-05-GBA-42-42-24	SERIES 90	S90-130PV
9721137	PUMP-VAR-DISPL CCW 90PV130	90L130-HF-1-NN-80-R-3-F1-H-03-GBA-35-35-24	SERIES 90	S90-130PV
9721140	PUMP-VAR-DISPL CCW 90PV130	90L130-HF-1-NN-80-R-3-C8-H-01-GBA-32-32-24	SERIES 90	S90-130PV
9721143	PUMP-VAR-DISPL CCW 90PV130	90L130-MA-1-AB-80-L-3-F1-F-00-GBA-38-38-24	SERIES 90	S90-130PV
9721156	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-1-AB-80-L-3-F1-F-00-GBA-38-38-24	SERIES 90	S90-130PV
9721164	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-1-BC-80-R-3-F1-F-03-GBA-14-14-20	SERIES 90	S90-130PV
9721177	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-1-BC-80-R-3-F1-F-03-GBA-07-38-24	SERIES 90	S90-130PV

9721183	PUMP-VAR-DISPL CCW 90PV130	90L130-HF-1-NN-80-R-4-T4-H-00-GBA-17-35-24	SERIES 90	S90-130PV
9721195	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-1-BC-80-R-3-F1-F-00-EBA-38-38-24	SERIES 90	S90-130PV
9721198	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-1-CD-80-R-3-F1-H-03-GBA-38-38-24	SERIES 90	S90-130PV
9721216	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-1-NN-80-P-3-F1-H-03-GBA-38-38-24	SERIES 90	S90-130PV
9721225	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-1-NN-80-S-3-F1-F-03-GBA-35-35-24	SERIES 90	S90-130PV
9721226	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-1-DE-80-L-3-F1-H-03-GBA-42-42-24	SERIES 90	S90-130PV
9721227	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-1-NN-80-L-3-F1-H-03-GBA-42-42-24	SERIES 90	S90-130PV
9721229	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-1-NN-80-P-3-F1-F-03-GBA-45-45-24	SERIES 90	S90-130PV
9721230	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-CD-80-R-3-F1-H-03-GBA-35-35-24	SERIES 90	S90-130PV
9721232	PUMP-VAR-DISPL CCW 90PV130	90L130-KN-1-CD-80-R-3-F1-H-03-GBA-35-35-24	SERIES 90	S90-130PV
9721234	PUMP-VAR-DISPL CCW 90PV130	90L130-HS-5-NN-80-R-3-F1-H-04-HDA-43-43-30	SERIES 90	S90-130PV
9721236	PUMP-VAR-DISPL CCW 90PV130	90L130-MB-1-NN-80-R-3-F1-H-03-GBA-42-42-24	SERIES 90	S90-130PV
9721237	PUMP-VAR-DISPL CCW 90PV130	90L130-MB-1-AB-80-S-3-F1-F-02-GBA-38-38-24	SERIES 90	S90-130PV
9721240	PUMP-VAR-DISPL CCW 90PV130	90L130-MV-1-BC-80-R-3-F1-F-29-GBA-42-42-24	SERIES 90	S90-130PV
9721244	PUMP-VAR-DISPL CCW 90PV130	90L130-MA-5-NN-80-R-3-F1-F-00-GBA-23-29-24-E112	SERIES 90	S90-130PV
9721252	PUMP-VAR-DISPL CCW 90PV130	90L130-HS-5-AB-80-R-3-F1-H-03-GBA-35-35-24	SERIES 90	S90-130PV
9721253	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-1-NN-80-R-4-F1-H-03-GBA-35-14-24	SERIES 90	S90-130PV
9721254	PUMP-VAR-DISPL CCW 90PV130	90L130-DC-1-NN-80-L-3-T4-F-GB-GBA-32-32-24	SERIES 90	S90-130PV
9721259	PUMP-VAR-DISPL CCW 90PV130	90L130-FH-1-NN-80-S-B-F1-F-B1-EBA-45-45-28	SERIES 90	S90-130PV
9721262	PUMP-VAR-DISPL CCW 90PV130	90L130-HS-1-CD-80-L-3-F1-F-03-GBA-14-32-20	SERIES 90	S90-130PV
9721272	PUMP-VAR-DISPL CCW 90PV130	90L130-CA-1-NN-80-L-3-T4-F-00-GBA-32-32-24	SERIES 90	S90-130PV
9721273	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-1-CD-80-R-3-F1-F-03-GBA-38-38-24	SERIES 90	S90-130PV
9721274	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-CD-80-R-4-F1-F-03-GBA-35-35-24	SERIES 90	S90-130PV
9721276	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-NN-80-P-4-F1-F-03-EEB-29-29-20	SERIES 90	S90-130PV
9721279	PUMP-VAR-DISPL CCW 90PV130	90L130-HF-5-NN-80-R-3-C8-L-01-GBA-32-32-24	SERIES 90	S90-130PV
9721283	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-BC-80-R-3-F1-F-03-GBA-14-35-24	SERIES 90	S90-130PV
9721289	PUMP-VAR-DISPL CCW 90PV130	90L130-MA-5-NN-80-S-3-C8-H-03-GBA-42-42-24	SERIES 90	S90-130PV
9721292	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-NN-80-L-4-F1-F-03-EEB-26-26-24	SERIES 90	S90-130PV
9721297	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-BC-80-L-4-F1-F-03-GBA-42-42-24	SERIES 90	S90-130PV
9721301	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-BC-80-R-3-F1-F-00-GBA-38-38-20	SERIES 90	S90-130PV
9721309	PUMP-VAR-DISPL CCW 90PV130	90L130-MA-1-AB-80-P-3-F1-F-03-GBA-45-45-24	SERIES 90	S90-130PV
9721310	PUMP-VAR-DISPL CCW 90PV130	90L130-HF-5-AB-80-R-4-T4-H-03-GBA-17-35-24	SERIES 90	S90-130PV
9721312	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-BC-80-S-3-T4-F-03-GBA-42-42-24	SERIES 90	S90-130PV
9721316	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-AB-80-L-4-F1-F-03-GBA-42-42-24	SERIES 90	S90-130PV
9721322	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-NN-85-R-3-F1-H-09-GBA-42-42-20	SERIES 90	S90-130PV
9721323	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-NN-85-R-R-F1-H-09-GBA-42-42-20	SERIES 90	S90-130PV

9721325	PUMP-VAR-DISPL CCW 90PV130	90L130-MA-5-CD-80-S-3-F1-H-C4-GBA-26-26-24	SERIES 90	S90-130PV
9721326	PUMP-VAR-DISPL CCW 90PV130	90L130-MA-5-BC-80-L-3-F1-F-C5-GBA-42-42-24	SERIES 90	S90-130PV
9721327	PUMP-VAR-DISPL CCW 90PV130	90L130-MA-5-DE-80-L-3-F1-F-C5-GBA-42-42-24	SERIES 90	S90-130PV
9721328	PUMP-VAR-DISPL CCW 90PV130	90L130-CB-1-NN-80-R-4-T4-F-00-GBA-32-32-24	SERIES 90	S90-130PV
9721329	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-2-NN-80-R-3-F1-H-00-GBA-42-42-24	SERIES 90	S90-130PV
9721335	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-1-NN-80-L-3-F1-F-00-GBA-35-35-24	SERIES 90	S90-130PV
9721336	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-CD-80-S-3-T4-F-00-GBA-38-38-24	SERIES 90	S90-130PV
9721339	PUMP-VAR-DISPL CCW 90PV130	90L130-DD-5-CD-80-R-4-F1-H-GB-GBA-23-38-24	SERIES 90	S90-130PV
9721341	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-1-BB-80-R-3-T4-F-03-GBA-35-35-24	SERIES 90	S90-130PV
9721342	PUMP-VAR-DISPL CCW 90PV130	90L130-KA-5-NN-80-S-4-F1-H-04-GBA-20-20-24	SERIES 90	S90-130PV
9721343	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-NT-80-L-3-F5-R-03-GBA-32-32-28	SERIES 90	S90-130PV
9721344	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-DE-80-R-4-C8-H-29-GBA-42-42-30	SERIES 90	S90-130PV
9721345	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-1-NN-80-L-3-T4-F-02-GBA-20-20-20	SERIES 90	S90-130PV
9721346	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-5-CD-80-R-3-F1-H-29-GBA-40-40-30	SERIES 90	S90-130PV
9721347	PUMP-VAR-DISPL CCW 90PV130	90L130-KP-2-NN-80-R-3-F1-F-03-GBA-32-32-24	SERIES 90	S90-130PV
9721353	PUMP-VAR-DISPL CCW 90P130	90L130-KP-1-CD-80-R-3-F1-F-00-GBA-38-38-20	SERIES 90	S90-130PV
9721363	PUMP-VAR-DISPL CCW 90P130	90L130-KP-1-NN-80-L-4-F1-F-03-EBA-35-35-24	SERIES 90	S90-130PV
9721505	PUMP-VAR-DISPL CW 90PV130	90R130-MA-1-BB-80-S-3-F1-F-03-GBA-42-42-24	SERIES 90	S90-130PV
9721513	PUMP-VAR-DISPL CW 90PV130 BASE MODEL	90R130-CB-1-NN-80-S-3-F1-F-00-EEB-35-35-24-P000	SERIES 90	S90-130PV
9721525	PUMP-VAR-DISPL CW 90PV130	90R130-HF-1-NN-80-S-4-F1-H-03-GBA-35-35-24-F001	SERIES 90	S90-130PV
9721548	PUMP-VAR-DISPL CW 90PV130	90R130-KP-1-NN-80-R-3-F1-F-00-GBA-23-29-24	SERIES 90	S90-130PV
9721577	PUMP-VAR-DISPL CW 90PV130	90R130-KA-1-NN-80-L-3-F1-F-03-GBA-42-42-24	SERIES 90	S90-130PV
9721578	PUMP-VAR-DISPL CW 90PV130	90R130-KA-1-NN-80-L-4-F1-H-04-GBA-35-14-20	SERIES 90	S90-130PV
9721580	PUMP-VAR-DISPL CW 90PV130	90R130-KA-6-NN-80-S-4-F1-H-03-GBA-45-45-24	SERIES 90	S90-130PV
9721583	PUMP-VAR-DISPL CW 90PV130	90R130-KP-1-CD-80-L-4-F1-F-03-GBA-35-35-24	SERIES 90	S90-130PV
9721590	PUMP-VAR-DISPL CW 90PV130	90R130-KA-1-AB-80-P-3-F1-F-22-GBA-42-42-24	SERIES 90	S90-130PV
9721600	PUMP-VAR-DISPL CW 90PV130	90R130-MB-1-BC-80-R-4-F1-F-03-GBA-35-35-24-F055	SERIES 90	S90-130PV
9721610	PUMP-VAR-DISPL CW 90PV130	90R130-KA-1-CD-80-R-3-F1-H-03-GBA-35-35-24	SERIES 90	S90-130PV
9721620	PUMP-VAR-DISPL CW 90PV130	90R130-MA-1-BB-80-L-3-F1-H-02-GBA-42-42-30	SERIES 90	S90-130PV
9721626	PUMP-VAR-DISPL CW 90PV130	90R130-KP-1-NN-80-P-3-F1-H-03-GBA-38-38-24	SERIES 90	S90-130PV
9721627	PUMP-VAR-DISPL CW 90PV130	90R130-MA-B-CD-80-S-3-F1-H-02-GBA-32-48-24	SERIES 90	S90-130PV
9721628	PUMP-VAR-DISPL CW 90PV130	90R130-CB-1-NN-80-S-3-F1-F-00-EEB-35-35-24	SERIES 90	S90-130PV
9721633	PUMP-VAR-DISPL CW 90PV130	90R130-KA-1-BC-80-R-4-F1-F-03-GBA-35-35-24	SERIES 90	S90-130PV
9721635	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-BC-80-R-4-F1-F-02-GBA-35-35-24	SERIES 90	S90-130PV
9721636	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-CD-80-R-4-F1-F-02-GBA-35-35-24	SERIES 90	S90-130PV
9721637	PUMP-VAR-DISPL CW 90PV130	90R130-KA-1-NN-80-R-4-F1-F-03-GBA-32-32-24	SERIES 90	S90-130PV

9721638	PUMP-VAR-DISPL CW 90PV130	90R130-KP-1-CD-80-R-4-F1-H-00-GBA-29-38-24	SERIES 90	S90-130PV
9721639	PUMP-VAR-DISPL CW 90PV130	90R130-MA-1-NN-80-R-3-F1-F-00-GBA-23-29-24	SERIES 90	S90-130PV
9721650	PUMP-VAR-DISPL CW 90PV130	90R130-KA-1-NN-80-L-3-F1-H-03-GBA-42-42-24	SERIES 90	S90-130PV
9721651	PUMP-VAR-DISPL CW 90PV130	90R130-MA-1-AB-80-L-3-F1-F-03-GBA-38-38-24	SERIES 90	S90-130PV
9721653	PUMP-VAR-DISPL CW 90PV130	90R130-KP-1-BC-80-R-3-T4-F-03-EEB-35-35-24	SERIES 90	S90-130PV
9721658	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-BC-80-P-3-F1-F-00-GBA-38-38-20	SERIES 90	S90-130PV
9721661	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-NN-80-P-4-F1-F-03-EEB-29-29-20	SERIES 90	S90-130PV
9721662	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-CD-80-R-4-F1-H-02-GBA-35-35-24	SERIES 90	S90-130PV
9721663	PUMP-VAR-DISPL CW 90PV130	90R130-KA-5-BC-80-R-4-F1-H-02-GBA-35-35-24	SERIES 90	S90-130PV
9721664	PUMP-VAR-DISPL CW 90PV130	90R130-FH-5-NN-80-S-B-F1-F-B1-EHA-45-45-28	SERIES 90	S90-130PV
9721665	PUMP-VAR-DISPL CW 90PV130	90R130-HF-5-NN-80-D-3-C8-N-01-GBA-32-32-24	SERIES 90	S90-130PV
9721674	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-BC-80-R-3-F1-H-03-GBA-38-38-24	SERIES 90	S90-130PV
9721686	PUMP-VAR-DISPL CW 90PV130	90R130-FH-5-NN-80-S-B-F1-H-B1-EHA-45-45-28	SERIES 90	S90-130PV
9721689	PUMP-VAR-DISPL CW 90PV130	90R130-KP-P-BC-80-S-3-F1-F-04-EBA-48-48-24	SERIES 90	S90-130PV
9721690	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-DE-80-P-3-F1-F-04-GBA-38-38-24	SERIES 90	S90-130PV
9721691	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-BC-80-P-3-F1-F-04-GBA-38-38-24	SERIES 90	S90-130PV
9721693	PUMP-VAR-DISPL CW 90PV130	90R130-FH-5-NN-80-S-B-F1-H-B1-EHB-42-42-28	SERIES 90	S90-130PV
9721698	PUMP-VAR-DISPL CW 90PV130	90R130-HF-1-NN-80-R-4-F1-F-02-GBA-26-14-24	SERIES 90	S90-130PV
9721699	PUMP-VAR-DISPL CW 90PV130	90R130-KP-1-CD-80-P-3-F1-F-03-GBA-35-35-20	SERIES 90	S90-130PV
9721702	PUMP-VAR-DISPL CW 90PV130	90R130-CB-5-BC-80-P-4-F1-F-00-GBA-14-14-20	SERIES 90	S90-130PV
9721703	PUMP-VAR-DISPL CW 90PV130	90R130-KP-1-CD-80-P-3-F1-F-03-GBA-20-20-20	SERIES 90	S90-130PV
9721709	PUMP-VAR-DISPL CW 90PV130	90R130-KP-1-CD-80-P-3-F1-F-00-GBA-38-38-20	SERIES 90	S90-130PV
9721712	PUMP-VAR DISPL, CW	90R130-KT-5-DE-80-P-3-F1-H-04-GBA-38-38-24	SERIES 90	S90-130PV
9721713	PUMP-VAR DISPL, CW	90R130-KT-5-BC-80-P-3-F1-H-04-GBA-38-38-24	SERIES 90	S90-130PV
9721719	PUMP-VAR-DISPL CW 90PV130	90R130-MA-B-CD-80-S-3-F1-H-29-GBA-32-48-24	SERIES 90	S90-130PV
9721721	PUMP-VAR-DISPL CW 90PV130	90R130-HS-1-CD-80-R-4-F1-H-03-GBA-35-35-20	SERIES 90	S90-130PV
9721722	PUMP-VAR-DISPL CW 90PV130	90R130-KP-5-CD-80-R-3-F1-H-03-GBA-38-38-30	SERIES 90	S90-130PV
9731000	MOTOR-FIXED-DISPL 90MF130	90-M-130-NC-0-N-8-N-0-F1-W-00-EBA-00-00-G3	SERIES 90	S90-130MF
9731051	MOTOR-FIXED DISPL, 90MF130	90-M-130-NC-0-N-8-N-0-F1-N-00-NNN-00-00-00	SERIES 90	S90-130MF
9731057	MOTOR-FIXED-DISPL 90MF130	90-M-130-NC-0-N-8-N-0-F1-W-00-EBA-00-00-F0	SERIES 90	S90-130MF
9731058	MOTOR-FIXED-DISPL 90MF130	90-M-130-NC-0-N-8-N-0-F1-W-00-NNN-00-00-G3	SERIES 90	S90-130MF
9731059	MOTOR-FIXED-DISPL 90MF130	90-M-130-NC-0-N-8-N-0-C8-N-00-EBA-00-00-00	SERIES 90	S90-130MF
9731060	MOTOR-FIXED-DISPL 90MF130	90-M-130-NC-0-N-8-N-0-F1-W-00-NNN-00-00-F0	SERIES 90	S90-130MF
9731061	MOTOR-FIXED-DISPL 90MF130	90-M-130-NC-0-N-8-N-0-F1-W-00-EEA-00-00-F0	SERIES 90	S90-130MF
9731062	MOTOR-FIXED-DISPL 90MF130	90-M-130-NC-0-N-8-N-0-F1-W-00-EBA-00-00-G0	SERIES 90	S90-130MF
9731063	MOTOR-FIXED-DISPL 90MF130	90-M-130-NC-0-N-8-N-0-F1-N-00-EEA-00-00-00	SERIES 90	S90-130MF

9731067	MOTOR-FIXED-DISPL 90MF130	90-M-130-NC-0-N-8-N-0-L7-W-00-NNN-00-00-F3	SERIES 90	S90-130MF
9731068	MOTOR-FIXED-DISPL 90MF130	90-M-130-NC-0-N-8-N-0-F1-W-00-EEA-00-00-E6	SERIES 90	S90-130MF
9801615	SHAFT CHG PUMP		SERIES 20	PARTS - S20 - Unique
9801781-2006	CONTROL-MDC, 25-26 PV		SERIES 20	PARTS - S20 - Unique
9802028	VALVE ASSY CHECK		SERIES 20	PARTS - S20 - Unique
9803518	PLUNGER		SERIES 20	PARTS - S20 - Unique
9820120	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-1-NN-80-S-3-F1-H-03-NNN-35-35-24	SERIES 90	S90-180PV
9820146	PUMP-VAR-DISPL CCW 90PV180	90L180-KA-1-NN-80-T-C-F1-J-03-NNN-29-29-24	SERIES 90	S90-180PV
9820151	PUMP-VAR-DISPL CCW 90PV180 BASE MODEL	90L180-CB-1-NN-80-S-C-F1-H-00-FAC-42-42-28-P000	SERIES 90	S90-180PV
9820152	PUMP-VAR-DISPL CCW 90PV180	90L180-KP-5-NN-80-T-C-F1-J-03-FAC-42-42-24	SERIES 90	S90-180PV
9820161	PUMP-VAR-DISPL CCW 90PV180	90L180-KP-1-CD-80-T-C-C8-J-03-FAC-42-42-24	SERIES 90	S90-180PV
9820163	PUMP-VAR-DISPL CCW 90PV180	90L180-KN-1-CD-80-R-M-F1-H-05-FAC-35-35-28	SERIES 90	S90-180PV
9820166	PUMP-VAR-DISPL CCW 90PV180	90L180-KT-1-CD-80-T-P-F1-J-03-NNN-13-32-28-F056	SERIES 90	S90-180PV
9820167	PUMP-VAR-DISPL CCW 90PV180	90L180-KT-1-BC-80-T-P-F1-J-03-NNN-32-13-28-F024	SERIES 90	S90-180PV
9820170	PUMP-VAR-DISPL CCW 90PV180	90L180-KN-1-AB-80-T-C-F1-J-03-FAC-42-42-24	SERIES 90	S90-180PV
9820171	PUMP-VAR-DISPL CCW 90PV180	90L180-KP-1-NN-80-S-C-F1-H-03-FAC-26-26-24	SERIES 90	S90-180PV
9820173	PUMP-VAR-DISPL CCW 90PV180	90L180-KP-2-AB-80-T-M-F1-L-00-FAC-32-32-24	SERIES 90	S90-180PV
9820177	PUMP-VAR-DISPL CCW 90PV180	90L180-HF-5-NN-80-T-C-C8-L-00-FAC-35-35-24	SERIES 90	S90-180PV
9820188	PUMP-VAR-DISPL CCW 90PV180	90L180-MA-1-BC-80-T-C-F1-H-03-FAC-42-42-24	SERIES 90	S90-180PV
9820189	PUMP-VAR-DISPL CCW 90PV180	90L180-MA-1-EF-80-T-C-F1-H-03-FAC-42-42-24	SERIES 90	S90-180PV
9820190	PUMP-VAR-DISPL CCW 90PV180	90L180-KP-5-CD-80-T-C-C8-J-05-FAC-32-32-30	SERIES 90	S90-180PV
9820505	PUMP-VAR-DISPL CW 90PV180	90R180-EA-1-AB-80-R-4-F1-H-03-NNN-20-20-28	SERIES 90	S90-180PV
9820525	PUMP-VAR-DISPL CW 90PV180	90R180-MA-1-NN-80-S-3-F1-H-03-NNN-35-35-24	SERIES 90	S90-180PV
9820552	PUMP-VAR-DISPL CW 90PV180	90R180-MB-1-BB-80-T-M-F1-J-03-NNN-35-35-24-P020	SERIES 90	S90-180PV
9820557	PUMP-VAR-DISPL CW 90PV180 BASE MODEL	90R180-CB-1-NN-80-S-C-F1-H-00-FAC-42-42-28-P000	SERIES 90	S90-180PV
9820558	PUMP-VAR-DISPL CW 90PV180	90R180-KA-2-BC-80-T-C-C8-J-00-FAC-35-35-24	SERIES 90	S90-180PV
9820559	PUMP-VAR-DISPL CW 90PV180	90R180-HF-1-BC-80-S-M-F1-H-05-FAC-17-17-24	SERIES 90	S90-180PV
9820564	PUMP-VAR-DISPL CW 90PV180	90R180-KA-1-NN-80-S-M-F1-H-03-FAC-32-32-24	SERIES 90	S90-180PV
9820568	PUMP-VAR-DISPL CW 90PV180	90R180-KA-1-AB-80-T-C-F1-J-05-FAC-20-20-24	SERIES 90	S90-180PV
9820569	PUMP-VAR-DISPL CW 90PV180	90R180-KA-1-NN-80-T-C-C8-J-03-FAC-35-35-20	SERIES 90	S90-180PV
9820580	PUMP-VAR-DISPL CW 90PV180	90R180-MA-1-NN-80-S-C-F1-H-03-FAC-42-42-24	SERIES 90	S90-180PV
9820584	PUMP-VAR-DISPL CW 90PV180	90R180-KN-1-AB-80-T-C-F1-J-05-FAC-29-29-24	SERIES 90	S90-180PV
9820585	PUMP-VAR-DISPL CW 90PV180	90R180-KA-1-NN-80-S-C-F1-H-03-FAC-26-26-20	SERIES 90	S90-180PV
9820586	PUMP-VAR-DISPL CW 90PV180	90R180-KA-1-NN-80-T-C-F1-J-05-FAC-35-35-24	SERIES 90	S90-180PV
9820588	PUMP-VAR-DISPL CW 90PV180	90R180-KA-2-CD-80-T-C-C8-J-00-FAC-35-35-24	SERIES 90	S90-180PV
9820589	PUMP-VAR-DISPL CW 90PV180	90R180-KP-1-NN-80-T-C-F1-J-03-FAC-38-38-24	SERIES 90	S90-180PV

9820590	PUMP-VAR-DISPL CW 90PV180	90R180-KP-1-BC-80-T-C-F1-J-03-FAC-38-38-24	SERIES 90	S90-180PV
9820591	PUMP-VAR-DISPL CW 90PV180	90R180-KP-1-EF-80-T-M-C8-H-03-FAC-38-38-24	SERIES 90	S90-180PV
9820592	PUMP-VAR-DISPL CW 90PV180	90R180-KP-1-NN-80-T-M-F1-H-03-FAC-38-38-24	SERIES 90	S90-180PV
9820595	PUMP-VAR-DISPL CW 90PV180	90R180-MV-1-BC-80-S-C-F1-J-00-FAC-42-42-28	SERIES 90	S90-180PV
9820596	PUMP-VAR-DISPL CW 90PV180	90R180-KA-5-CD-80-S-C-F1-H-03-FAC-35-35-24	SERIES 90	S90-180PV
9820597	PUMP-VAR-DISPL CW 90PV180	90R180-KP-5-NN-80-S-C-F1-H-04-FAC-32-32-24	SERIES 90	S90-180PV
9820598	PUMP-VAR-DISPL CW 90PV180	90R180-KP-5-CD-80-T-C-F1-H-03-FAC-20-20-24	SERIES 90	S90-180PV
9820600	PUMP-VAR-DISPL CW 90PV180	90R180-KP-5-NN-80-S-C-F1-H-04-FAC-35-35-24	SERIES 90	S90-180PV
9820613	PUMP-VAR-DISPL CW 90PV180	90R180-KP-5-DE-80-T-C-C8-J-05-FAC-35-35-30	SERIES 90	S90-180PV
9920100	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-1-BC-80-T-4-C8-K-03-NNN-42-42-24	SERIES 90	S90-250PV
9920102	PUMP-VAR-DISPL CCW 90PV250	90L250-MA-1-NN-80-S-4-C8-K-03-NNN-42-42-24-F001	SERIES 90	S90-250PV
9920110	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-1-NN-80-S-4-F1-J-03-NNN-32-32-24	SERIES 90	S90-250PV
9920111	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-1-BC-80-T-4-F1-K-03-NNN-23-23-24	SERIES 90	S90-250PV
9920112	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-1-BC-80-T-4-F1-K-03-NNN-26-26-24	SERIES 90	S90-250PV
9920119	PUMP-VAR-DISPL CCW 90PV250	90L250-KP-1-CD-80-T-3-F1-K-03-NNN-35-35-24	SERIES 90	S90-250PV
9920125	PUMP-VAR-DISPL CCW 90PV250	90L250-KP-5-NN-80-T-4-F1-K-03-NNN-29-29-24	SERIES 90	S90-250PV
9920127	PUMP-VAR-DISPL CCW 90PV250	90L250-KP-2-CD-80-T-3-C8-K-04-NNN-32-32-24	SERIES 90	S90-250PV
9920129	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-1-BC-80-T-4-C8-K-03-NNN-26-26-24	SERIES 90	S90-250PV
9920132	PUMP-VAR-DISPL CCW 90PV250	90L250-HF-1-NN-80-T-4-C8-K-03-NNN-20-20-24	SERIES 90	S90-250PV
9920137	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-5-CD-80-T-4-F1-J-05-NNN-38-38-24	SERIES 90	S90-250PV
9920138	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-2-NN-80-S-3-F1-J-03-NNN-48-48-24	SERIES 90	S90-250PV
9920143	PUMP-VAR-DISPL CCW 90PV250 BASE MODEL	90L250-CB-5-NN-80-S-4-F1-J-00-NNN-42-42-24-P000	SERIES 90	S90-250PV
9920144	PUMP-VAR-DISPL CCW 90PV250	90L250-KA-5-NN-80-T-3-F1-J-03-NNN-32-32-24	SERIES 90	S90-250PV
9920147	PUMP-VAR-DISPL CCW 90PV250	90L250-KP-5-BC-80-T-3-F1-K-03-NNN-35-14-24	SERIES 90	S90-250PV
9920148	PUMP-VAR-DISPL CCW 90PV250	90L250-KP-5-BC-80-T-3-F1-J-03-NNN-38-38-24	SERIES 90	S90-250PV
9920149	PUMP-VAR-DISPL CCW 90PV250	90L250-KP-5-EF-80-T-3-C8-J-03-NNN-38-38-24	SERIES 90	S90-250PV
9920500	PUMP-VAR-DISPL CW 90PV250	90R250-MA-1-NN-80-S-3-F1-J-03-NNN-35-35-28	SERIES 90	S90-250PV
9920505	PUMP-VAR-DISPL CW 90PV250	90R250-HF-1-CD-80-S-4-F1-J-03-NNN-32-32-24	SERIES 90	S90-250PV
9920530	PUMP-VAR-DISPL CW 90PV250	90R250-HF-1-CD-80-T-3-F1-J-03-NNN-42-42-24	SERIES 90	S90-250PV
9920540	PUMP-VAR-DISPL CW 90PV250	90R250-KP-1-NN-80-T-3-F1-J-03-NNN-38-38-24	SERIES 90	S90-250PV
9920541	PUMP-VAR-DISPL CW 90PV250	90R250-KA-1-NN-80-T-4-F1-J-03-NNN-20-20-20	SERIES 90	S90-250PV
9920542	PUMP-VAR-DISPL CW 90PV250	90R250-MA-1-BC-80-T-4-F1-K-03-NNN-26-26-24	SERIES 90	S90-250PV
9920543	PUMP-VAR-DISPL CW 90PV250	90R250-KP-1-NN-80-T-3-F1-K-03-NNN-35-35-20	SERIES 90	S90-250PV
9920546	PUMP-VAR-DISPL CW 90PV250	90R250-KA-1-DE-80-S-3-F1-K-03-NNN-35-35-20	SERIES 90	S90-250PV
9920547	PUMP-VAR-DISPL CW 90PV250	90R250-KA-1-BC-80-T-3-F1-K-03-NNN-35-35-28	SERIES 90	S90-250PV
9920548	PUMP-VAR-DISPL CW 90PV250	90R250-MA-5-NN-80-S-4-C8-J-03-NNN-26-26-24	SERIES 90	S90-250PV

9920549	PUMP-VAR-DISPL CW 90PV250	90R250-CB-P-NN-80-T-4-F1-J-00-NNN-48-48-24	SERIES 90	S90-250PV
9920550	PUMP-VAR-DISPL CW 90PV250	90R250-KA-5-NN-80-S-4-F1-J-03-NNN-42-42-24	SERIES 90	S90-250PV
9920552	PUMP-VAR-DISPL CW 90PV250	90R250-CB-P-NN-80-T-4-F1-K-00-NNN-48-48-24	SERIES 90	S90-250PV
9920558	PUMP-VAR-DISPL CW 90PV250	90R250-MA-5-AB-80-T-3-F1-J-C6-NNN-35-35-24	SERIES 90	S90-250PV
9920559	PUMP-VAR-DISPL CW 90PV250 BASE MODEL	90R250-CB-5-NN-80-S-4-F1-J-00-NNN-42-42-24-P000	SERIES 90	S90-250PV
H1B060_CM	MOTOR-VAR-DISPL H1B060	H1B060_CM-H1-B-060	H1-HP MOTORS	H1-060MB1
H1B080_CM	MOTOR-VAR-DISPL H1B080	H1B080_CM-H1-B-080	H1-HP MOTORS	H1-080MB1
H1B110_CM	MOTOR-VAR-DISPL H1B110	H1B110_CM-H1-B-110	H1-HP MOTORS	H1-110MB1
H1B160_CM	MOTOR-VAR-DISPL H1B160	H1B160_CM-H1-B-160	H1-HP MOTORS	H1-160MB1
H1B250_CM	MOTOR-VAR-DISPL H1B250	H1B250_CM-H1-B-250	H1-HP MOTORS	H1-250MB1
H1P045L_CM	PUMP-VAR DISPL CCW H1P045L	H1-P-045-L-H1P045L_CM	H1-MP PUMPS	H1-045PV/053PV
H1P045R_CM	PUMP-VAR DISPL CW H1P045R	H1-P-045-R-H1P045R_CM	H1-MP PUMPS	H1-045PV/053PV
H1P053L_CM	PUMP-VAR DISPL CCW H1P053L	H1-P-053-L-H1P053L_CM	H1-MP PUMPS	H1-045PV/053PV
H1P053R_CM	PUMP-VAR DISPL CW H1P053R	H1-P-053-R-H1P053R_CM	H1-MP PUMPS	H1-045PV/053PV
H1P060L_CM	PUMP-VAR DISPL CCW H1P060L	H1-P-060-L-H1P060L_CM	H1-MP PUMPS	H1-060PV/068PV
H1P060R_CM	PUMP-VAR DISPL CW H1P060R	H1-P-060-R-H1P060R_CM	H1-MP PUMPS	H1-060PV/068PV
H1P068L_CM	PUMP-VAR DISPL CCW H1P068L	H1-P-068-L-H1P068L_CM	H1-MP PUMPS	H1-060PV/068PV
H1P068R_CM	PUMP-VAR DISPL CW H1P068R	H1-P-068-R-H1P068R_CM	H1-MP PUMPS	H1-060PV/068PV
H1P069L_CM	PUMP-VAR-DISPL CCW H1PV069	H1-P-069-L-H1P069L_CM	H1-HP PUMPS	H1-069PV/078PV
H1P069R_CM	PUMP-VAR-DISPL CW H1PV069	H1-P-069-R-H1P069R_CM	H1-HP PUMPS	H1-069PV/078PV
H1P078L_CM	PUMP-VAR DISPL CCW H1PV078	H1-P-078-L-H1P078L_CM	H1-HP PUMPS	H1-069PV/078PV
H1P078R_CM	PUMP-VAR-DISPL CW H1PV078	H1-P-078-R-H1P078R_CM	H1-HP PUMPS	H1-069PV/078PV
H1P089L_CM	PUMP-VAR-DISPL CCW H1PV089	H1-P-089-L-H1P089L_CM	H1-HP PUMPS	H1-089PV/100PV
H1P089R_CM	PUMP-VAR-DISPL CW H1PV089	H1-P-089-R-H1P089R_CM	H1-HP PUMPS	H1-089PV/100PV
H1P100L_CM	PUMP-VAR-DISPL CCW H1PV100	H1-P-100-L-H1P100L_CM	H1-HP PUMPS	H1-089PV/100PV
H1P100R_CM	PUMP-VAR-DISPL CW H1PV100	H1-P-100-R-H1P100R_CM	H1-HP PUMPS	H1-089PV/100PV
H1P115L_CM	PUMP-VAR-DISPL CCW H1PV115	H1-P-115-L-H1P115L_CM	H1-HP PUMPS	H1-115PV/130PV
H1P115R_CM	PUMP-VAR-DISPL CW H1PV115	H1-P-115-R-H1P115R_CM	H1-HP PUMPS	H1-115PV/130PV
H1P130L_CM	PUMP-VAR-DISPL CCW H1PV130	H1-P-130-L-H1P130L_CM	H1-HP PUMPS	H1-115PV/130PV
H1P130R_CM	PUMP-VAR-DISPL CW H1PV130	H1-P-130-R-H1P130R_CM	H1-HP PUMPS	H1-115PV/130PV
H1P147L_CM	PUMP-VAR-DISPL CCW H1PV147	H1-P-147-L-H1P147L_CM	H1-HP PUMPS	H1-147PV/165PV
H1P147R_CM	PUMP-VAR-DISPL CW H1PV147	H1-P-147-R-H1P147R_CM	H1-HP PUMPS	H1-147PV/165PV
H1P165L_CM	PUMP-VAR-DISPL CCW H1PV165	H1-P-165-L-H1P165L_CM	H1-HP PUMPS	H1-147PV/165PV
H1P165R_CM	PUMP-VAR-DISPL CW H1PV165	H1-P-165-R-H1P165R_CM	H1-HP PUMPS	H1-147PV/165PV
H1P210L_CM	PUMP-VAR DISPL, CCW H1PV210	H1-P-210-L-H1P210L_CM	H1-HP PUMPS	H1-210PV/250PV
H1P210R_CM	PUMP-VAR DISPL, CW H1PV210	H1-P-210-R-H1P210R_CM	H1-HP PUMPS	H1-210PV/250PV

H1P250L_CM	PUMP-VAR DISPL, CCW H1PV250	H1-P-250-L-H1P250L_CM	H1-HP PUMPS	H1-210PV/250PV
H1P250R_CM	PUMP-VAR DISPL, CW H1PV250	H1-P-250-R-H1P250R_CM	H1-HP PUMPS	H1-210PV/250PV
H1T045L_CM	PUMP-TANDEM, VAR DISPL CCW H1T045L	H1-T-045-L-H1T045L_CM	H1-MP PUMPS	H1-045PT/053PT
H1T045R_CM	PUMP-TANDEM, VAR DISPL CW H1T045R	H1-T-045-R-H1T045R_CM	H1-MP PUMPS	H1-045PT/053PT
H1T053L_CM	PUMP-TANDEM, VAR DISPL CCW H1T053L	H1-T-053-L-H1T053L_CM	H1-MP PUMPS	H1-045PT/053PT
H1T053R_CM	PUMP-TANDEM, VAR DISPL CW H1T053R	H1-T-053-R-H1T053R_CM	H1-MP PUMPS	H1-045PT/053PT
L23-7005	PUMP VAR CCW		DAIKIN	Daikin PUMPS
L38-7046	PUMP VAR CCW		DAIKIN	Daikin PUMPS
L38-7056	PUMP VAR CCW		DAIKIN	Daikin PUMPS
L38-7070	PUMP VAR CW		DAIKIN	Daikin PUMPS
L38-7089	PUMP VAR CCW		DAIKIN	Daikin PUMPS
LPV_CM	PUMP- VARIABLE, DIRECT DISPLACMENT	LPV_CM	LPV	LPV
M25-2050	PUMP-VAR DISPL	MPV-025-C-B-A-A-L-A-E-NN-A-A-BDD-DR-A-FF-A-NNN-***	LIGHT DUTY	025PV
M25-2051	PUMP-VAR DISPL	MPV-025-C-B-A-A-R-A-F-NN-A-A-BDD-DR-A-FF-A-NNN-***	LIGHT DUTY	025PV
M25-2052	PUMP-VAR DISPL	MPV-025-C-B-A-A-L-A-F-NN-A-A-BDD-DR-A-FF-A-NNN-***	LIGHT DUTY	025PV
M25-2053	PUMP-VAR DISPL	MPV-025-C-B-A-A-R-A-E-NN-A-A-BFF-DR-A-FF-A-NNN-***	LIGHT DUTY	025PV
M25-2054	PUMP-VAR DISPL	MPV-025-C-B-A-A-R-A-E-NN-A-A-BDD-DR-A-FF-A-NNN-***	LIGHT DUTY	025PV
M25-2055	PUMP-VAR DISPL	MPV-025-C-B-A-Y-R-A-E-NN-A-A-BBB-DR-A-FF-A-NNN-***	LIGHT DUTY	025PV
M25-2056	PUMP-VAR DISPL	MPV-025-C-B-A-A-R-A-N-NN-A-A-BFF-DR-A-FF-A-NNN-***	LIGHT DUTY	025PV
M25-2057	PUMP-VAR-DISPL MPV025	MPV-025-C-B-A-A-R-A-N-NN-A-A-BFF-DL-A-FF-A-NNN-***	LIGHT DUTY	025PV
M25-2059	PUMP-VAR-DISPL MPV025	MPV-025-C-B-A-A-R-A-G-NN-A-A-BGG-DL-A-FF-A-NNN-***	LIGHT DUTY	025PV
M25-2060	PUMP-VAR-DISPL MPV025	MPV-025-C-B-A-A-R-A-G-NN-A-A-BJJ-DL-A-FF-A-NNN-***	LIGHT DUTY	025PV
M25-2061	PUMP-VAR DISPL	MPV-025-C-B-A-A-R-A-E-NN-A-A-BDD-DL-A-FF-A-NNN-***	LIGHT DUTY	025PV
M25-2063	PUMP-VAR DISPL	MPV-025-C-B-A-A-R-A-E-NN-A-A-BGG-DL-A-FF-A-NNN-***	LIGHT DUTY	025PV
M25-2064	PUMP-VAR DISPL	MPV-025-C-B-A-A-R-A-F-NN-A-A-BFF-DR-A-FF-A-NNN-***	LIGHT DUTY	025PV
M25-2065	PUMP-VAR-DISPL MPV025	MPV-025-C-B-A-A-R-A-G-NN-A-A-BFF-DR-A-FF-A-NNN-***	LIGHT DUTY	025PV
M25-2066	PUMP-VAR DISPL	MPV-025-C-B-A-A-W-A-E-NN-A-A-BGG-DR-A-FF-A-NNN-***	LIGHT DUTY	025PV
M25-2069	PUMP-VAR DISPL	MPV-025-C-B-A-A-W-A-G-NN-A-A-BGG-DL-A-FF-A-NNN-***	LIGHT DUTY	025PV
M25-2071	PUMP-VAR-DISPL MPV025	MPV-025-C-B-A-A-R-A-G-NN-A-A-BBB-DL-A-FF-A-NNN-***	LIGHT DUTY	025PV
M25-2072	PUMP-VAR DISPL	MPV-025-C-B-A-A-W-A-G-NN-A-A-BJJ-DL-A-FF-A-NNN-***	LIGHT DUTY	025PV
M25-2073	PUMP-VAR DISPL	MPV-025-C-B-A-A-R-A-G-NN-A-A-BDD-DL-A-FF-A-NNN-***	LIGHT DUTY	025PV
M25-2074	PUMP-VAR DISPL	MPV-025-C-B-A-A-R-A-G-NN-A-A-BDD-DR-A-FF-A-NNN-***	LIGHT DUTY	025PV
M25-2075	PUMP-VAR-DISPL MPV025	MPV-025-C-B-A-A-R-A-R-NN-A-A-BDD-DR-A-FF-A-NNN-***	LIGHT DUTY	025PV
M25-2076	PUMP-VAR DISPL	MPV-025-C-B-A-A-W-A-G-NN-A-A-BEE-DL-A-FF-A-NNN-***	LIGHT DUTY	025PV
M25-2077	PUMP-VAR DISPL	MPV-025-C-B-A-A-W-A-G-NN-A-A-BDD-DL-A-FF-D-NNN-***	LIGHT DUTY	025PV
M25-2078	PUMP-VAR DISPL	MPV-025-C-B-A-A-R-A-V-NN-A-A-BMM-DL-A-FF-A-NNN-***	LIGHT DUTY	025PV

M25-2079	PUMP-VAR DISPL	MPV-025-C-B-A-A-L-A-E-NN-A-A-BFF-DR-A-FF-A-NNN-***	LIGHT DUTY	025PV
M25-2080	PUMP-VAR DISPL	MPV-025-C-B-A-A-R-A-G-NN-A-A-BFF-DL-A-FF-D-NNN-***	LIGHT DUTY	025PV
M25-2081	PUMP-VAR-DISPL MPV025	MPV-025-C-B-A-A-W-A-E-NN-A-A-BDD-DL-A-FF-A-NNN-***	LIGHT DUTY	025PV
M25-2084	PUMP-VAR DISPL	MPV-025-C-B-A-A-Z-A-E-NN-A-A-BGG-DR-A-FF-A-NNN-***	LIGHT DUTY	025PV
M25-2085	PUMP-VAR-DISPL MPV025	MPV-025-C-B-A-A-Z-A-V-NN-A-A-BDD-DR-A-FF-A-NNN-***	LIGHT DUTY	025PV
M25-2087	PUMP-VAR-DISPL MPV025	MPV-025-C-B-A-A-R-A-V-NN-A-A-BFG-DR-A-FF-D-NNN-***	LIGHT DUTY	025PV
M25-2088	PUMP-VAR DISPL	MPV-025-C-B-A-A-R-A-E-NN-A-A-BEE-DR-A-FF-A-NNN-***	LIGHT DUTY	025PV
M25-2089	PUMP-VAR-DISPL MPV025	MPV-025-C-B-A-A-R-A-V-NN-A-A-BFF-DR-A-FF-D-NNN-***	LIGHT DUTY	025PV
M25-2090	PUMP-VAR DISPL	MPV-025-C-B-A-A-R-A-E-NN-A-A-BGG-DR-A-FF-A-NNN-***	LIGHT DUTY	025PV
M25-2091	PUMP-VAR DISPL	MPV-025-C-B-A-A-R-A-G-NN-A-A-BBB-DR-A-FF-A-NNN-***	LIGHT DUTY	025PV
M25-2092	PUMP-VAR DISPL	MPV-025-C-B-A-A-W-A-E-NN-A-A-BFF-DL-A-FF-A-NNN-***	LIGHT DUTY	025PV
M25-2093	PUMP-VAR DISPL	MPV-025-C-B-A-A-R-A-G-NN-A-A-BJJ-DR-A-FF-A-NNN-***	LIGHT DUTY	025PV
M25-2094	PUMP-VAR DISPL	MPV-025-C-B-A-Y-L-A-G-NN-A-A-BEE-DR-A-FF-D-NNN-***	LIGHT DUTY	025PV
M25-2095	PUMP-VAR DISPL	MPV-025-C-B-A-A-R-A-G-NN-A-A-BMM-DL-A-FF-A-NNN-***	LIGHT DUTY	025PV
M25-2096	PUMP-VAR DISPL	MPV-025-C-B-A-A-Z-A-G-NN-A-A-BDD-DL-A-FF-A-NNN-***	LIGHT DUTY	025PV
M25-2097	PUMP-VAR DISPL	MPV-025-C-B-A-A-L-A-G-NN-A-A-BGG-DL-A-FF-A-NNN-***	LIGHT DUTY	025PV
M25-2098	PUMP-VAR DISPL	MPV-025-C-B-A-Y-R-A-G-NN-A-A-BJJ-DR-A-FF-A-NNN-***	LIGHT DUTY	025PV
M25-2099	PUMP-VAR DISPL	MPV-025-C-B-A-A-W-A-C-NN-A-A-BDD-DR-A-FF-A-NNN-***	LIGHT DUTY	025PV
M25-2102	PUMP-VAR DISPL	MPV-025-C-B-A-A-L-A-G-NN-A-A-BJJ-DL-A-FF-A-NNN-***	LIGHT DUTY	025PV
M25-2104	PUMP-VAR DISPL	MPV-025-C-B-A-Y-L-A-G-NN-A-A-BEE-DR-A-FF-A-NNN-***	LIGHT DUTY	025PV
M25-2105	PUMP-VAR DISPL	MPV-025-C-B-A-Y-L-A-N-NN-A-A-BEE-DR-A-FF-A-NNN-***	LIGHT DUTY	025PV
M25-2106	PUMP-VAR DISPL	MPV-025-C-B-A-A-L-A-N-NN-A-A-BEE-DR-A-FF-A-NNN-***	LIGHT DUTY	025PV
M25-2107	PUMP-VAR DISPL	MPV-025-C-B-A-A-W-A-E-NN-A-A-BFF-DR-A-FF-D-NNN-***	LIGHT DUTY	025PV
M25-2108	PUMP-VAR DISPL	MPV-025-C-B-A-A-R-A-C-NN-A-A-BBB-DR-A-FF-A-NNN-***	LIGHT DUTY	025PV
M25-2109	PUMP-VAR DISPL	MPV-025-C-B-A-A-R-A-N-NN-A-A-BBB-DR-A-FF-A-NNN-***	LIGHT DUTY	025PV
M25-2111	PUMP-VAR-DISPL MPV025	MPV-025-C-B-A-A-L-A-C-NN-A-A-BJJ-DL-A-FF-A-NNN-***	LIGHT DUTY	025PV
M25-2112	PUMP-VAR DISPL	MPV-025-C-B-A-A-L-A-G-NN-A-A-BDD-DR-A-FF-A-NNN-***	LIGHT DUTY	025PV
M25-2113	PUMP-VAR DISPL	MPV-025-C-B-A-A-W-A-E-NN-A-A-BFF-DL-A-FF-D-NNN-***	LIGHT DUTY	025PV
M25-2115	PUMP-VAR DISPL	MPV-025-C-B-A-A-L-A-N-NN-A-A-BFF-DR-A-FF-A-NNN-***	LIGHT DUTY	025PV
M25-2116	PUMP-VAR DISPL	MPV-025-C-B-A-Y-R-A-G-NN-A-A-BDD-DR-A-FF-A-NNN-***	LIGHT DUTY	025PV
M25-2117	PUMP-VAR DISPL	MPV-025-C-B-A-A-R-A-F-NN-A-A-BMM-DR-A-FF-A-NNN-***	LIGHT DUTY	025PV
M25-2118	PUMP-VAR-DISPL MPV025	MPV-025-C-B-A-A-R-A-N-NN-A-A-BJJ-DR-A-FF-A-NNN-***	LIGHT DUTY	025PV
M25-2119	PUMP-VAR DISPL	MPV-025-C-B-A-Y-R-A-G-NN-A-A-BFF-DR-A-FF-A-NNN-***	LIGHT DUTY	025PV
M25-2121	PUMP-VAR DISPL	MPV-025-C-B-A-Y-L-A-E-NN-A-A-BJJ-DR-A-FF-A-NNN-***	LIGHT DUTY	025PV
M25-2122	PUMP-VAR DISPL	MPV-025-C-B-A-Y-L-A-E-NN-A-A-BJJ-DL-A-FF-A-NNN-***	LIGHT DUTY	025PV
M25-2123	PUMP-VAR-DISPL MPV025	MPV-025-C-B-A-A-W-A-G-NN-A-A-BDD-DL-A-FF-A-NNN-***	LIGHT DUTY	025PV

M25-2124	PUMP-VAR DISPL	MPV-025-C-B-A-Y-L-A-G-NN-A-A-BFF-DR-A-FF-A-NNN-***	LIGHT DUTY	025PV
M25-2125	PUMP-VAR-DISPL MPV025	MPV-025-C-B-A-A-R-A-E-NN-A-A-BJJ-DR-A-FF-A-NNN-***	LIGHT DUTY	025PV
M25-2126	PUMP-VAR DISPL	MPV-025-C-B-A-A-R-A-E-NN-A-A-BMM-DR-A-FF-D-NNN-***	LIGHT DUTY	025PV
M25-2127	PUMP-VAR DISPL	MPV-025-C-B-A-Y-Y-A-E-NN-A-A-BFF-DL-A-FF-A-NNN-***	LIGHT DUTY	025PV
M25-2128	PUMP-VAR DISPL	MPV-025-C-B-A-Y-Y-A-E-NN-A-A-BFF-DR-A-FF-A-NNN-***	LIGHT DUTY	025PV
M25-2129	PUMP-VAR DISPL	MPV-025-C-B-A-A-R-A-F-NN-A-A-BBB-DR-A-FF-D-NNN-***	LIGHT DUTY	025PV
M25-2130	PUMP-VAR DISPL	MPV-025-C-B-A-A-R-A-G-NN-A-A-BEE-DR-A-FF-A-NNN-***	LIGHT DUTY	025PV
M25-2131	PUMP-VAR DISPL	MPV-025-C-B-A-Y-Y-A-E-NN-A-A-BGG-DL-A-FF-A-NNN-***	LIGHT DUTY	025PV
M25-2132	PUMP-VAR DISPL	MPV-025-C-B-A-Y-Y-A-E-NN-A-A-BGG-DR-A-FF-A-NNN-***	LIGHT DUTY	025PV
M25-2133	PUMP-VAR DISPL	MPV-025-C-B-A-A-R-A-E-NN-A-A-BHF-DR-A-FF-A-NNN-***	LIGHT DUTY	025PV
M25-2134	PUMP-VAR DISPL	MPV-025-C-B-A-A-R-A-F-NN-A-A-BGG-DR-A-FF-A-NNN-***	LIGHT DUTY	025PV
M25-2135	PUMP-VAR DISPL	MPV-025-C-B-A-Y-R-A-E-NN-A-A-BDD-DR-A-FF-A-NNN-***	LIGHT DUTY	025PV
M25-2136	PUMP-VAR DISPL	MPV-025-C-B-A-Y-R-A-C-NN-A-A-BDD-DR-A-FF-A-NNN-***	LIGHT DUTY	025PV
M25-2137	PUMP-VAR DISPL	MPV-025-C-B-A-A-W-A-G-NN-A-A-BJJ-DR-A-FF-A-NNN-***	LIGHT DUTY	025PV
M46-20005	PUMP-VAR DISPL	MPV-046-C-B-A-B-R-B-A-AA-A-A-BMM-AB-U-BA-A-NNN-***	M46	M46-046PV
M46-20006	PUMP-VAR DISPL	MPV-046-C-B-A-A-R-B-A-BA-A-A-BHH-AB-U-BA-C-NNN-***	M46	M46-046PV
M46-20008	PUMP-VAR DISPL	MPV-046-C-B-B-A-L-B-A-BA-A-A-BFF-CD-A-HH-C-NNN-***	M46	M46-046PV
M46-20010	PUMP-VAR DISPL	MPV-046-C-B-B-S-L-A-M-BC-G-A-BFF-CE-A-TT-B-NNR-***	M46	M46-046PV
M46-20011	PUMP-VAR DISPL	MPV-046-C-B-B-H-R-B-A-AA-A-A-BJJ-CE-A-HH-A-NNN-***	M46	M46-046PV
M46-20012	PUMP-VAR DISPL	MPV-046-C-B-A-H-R-B-A-AA-A-A-BJJ-AB-U-BB-A-NNN-***	M46	M46-046PV
M46-20013	PUMP-VAR DISPL	MPV-046-C-B-B-H-R-B-A-BA-A-A-BJJ-CB-A-HH-A-NNN-***	M46	M46-046PV
M46-20014	PUMP-VAR DISPL	MPV-046-C-B-B-D-L-B-A-AA-A-A-BGG-CD-A-GG-B-NNN-***	M46	M46-046PV
M46-20015	PUMP-VAR DISPL	MPV-046-C-B-B-P-R-B-A-AA-A-A-BFF-CD-A-RR-A-NNN-***	M46	M46-046PV
M46-20018	PUMP-VAR DISPL	MPV-046-C-B-A-D-R-B-A-AA-A-A-BFF-AB-U-ZR-B-NNN-***	M46	M46-046PV
M46-20019	PUMP-VAR DISPL	MPV-046-C-B-A-K-R-B-A-AA-C-A-BJJ-AB-U-DD-B-NNN-***	M46	M46-046PV
M46-20020	PUMP-VAR DISPL	MPV-046-C-B-B-D-L-B-A-AA-A-A-BBB-CD-A-GG-B-NNN-***	M46	M46-046PV
M46-20021	PUMP-VAR DISPL	MPV-046-C-B-A-K-L-B-A-AA-A-A-BMM-AB-U-ED-B-NNN-***	M46	M46-046PV
M46-20023	PUMP-VAR DISPL	MPV-046-C-B-B-D-L-B-A-AA-A-A-BCC-CD-A-JJ-B-NNN-***	M46	M46-046PV
M46-20025	PUMP-VAR DISPL	MPV-046-C-B-A-G-L-B-A-AA-A-A-BDD-AB-U-ED-C-NNN-***	M46	M46-046PV
M46-20027	PUMP-VAR DISPL	MPV-046-C-B-B-A-R-B-A-AA-A-A-BGG-DA-A-HH-C-NNN-***	M46	M46-046PV
M46-20028	PUMP-VAR DISPL	MPV-046-C-B-B-P-R-B-A-AA-A-A-BFF-CB-A-RR-A-NNN-***	M46	M46-046PV
M46-20029	PUMP-VAR DISPL	MPV-046-C-B-A-H-R-B-C-AA-A-A-BEE-AB-U-ZR-A-NNN-***	M46	M46-046PV
M46-20030	PUMP-VAR DISPL	MPV-046-C-B-A-D-R-B-A-BA-A-A-BHH-AB-U-ED-B-NNN-***	M46	M46-046PV
M46-20031	PUMP-VAR DISPL	MPV-046-C-B-A-H-R-B-A-AA-A-A-BEE-AB-U-ZM-A-NNN-***	M46	M46-046PV
M46-20032	PUMP-VAR DISPL	MPV-046-C-B-A-G-R-B-A-AA-G-A-BEE-AB-U-ZM-C-NNN-***	M46	M46-046PV
M46-20034	PUMP-VAR DISPL	MPV-046-C-B-A-V-R-B-A-AA-A-A-BJJ-AB-U-BB-C-NNN-***	M46	M46-046PV

M46-20035	PUMP-VAR DISPL	MPV-046-C-B-B-R-B-A-AA-R-A-BFF-CB-A-HH-A-NNN-***	M46	M46-046PV
M46-20037	PUMP-VAR DISPL	MPV-046-C-B-A-A-R-B-A-AA-A-A-BJJ-AB-U-BB-C-NNN-***	M46	M46-046PV
M46-20038	PUMP-VAR DISPL	MPV-046-C-B-A-K-R-B-A-BA-A-A-BJJ-AB-U-DD-B-NNN-***	M46	M46-046PV
M46-20039	PUMP-VAR DISPL	MPV-046-C-B-B-H-R-B-A-BA-G-B-BFF-CB-A-GG-A-NNN-***	M46	M46-046PV
M46-20040	PUMP-VAR DISPL	MPV-046-C-B-A-A-L-B-A-AA-A-A-BFF-AB-U-AA-C-NNN-***	M46	M46-046PV
M46-20041	PUMP-VAR DISPL	MPV-046-C-B-B-G-L-B-A-AA-A-A-BDD-DB-A-SS-C-NNN-***	M46	M46-046PV
M46-20043	PUMP-VAR DISPL	MPV-046-C-B-B-V-R-B-A-BA-G-A-BEE-CB-A-HH-C-NNN-***	M46	M46-046PV
M46-20048	PUMP-VAR DISPL	MPV-046-C-B-A-G-L-B-A-AA-A-A-BJJ-AB-U-FA-C-NNN-***	M46	M46-046PV
M46-20049	PUMP-VAR DISPL	MPV-046-C-B-A-B-R-B-A-BA-A-A-BJJ-AB-D-AA-A-NNN-***	M46	M46-046PV
M46-20050	PUMP-VAR DISPL	MPV-046-C-B-B-G-R-B-A-AA-G-A-BBB-CB-A-JJ-C-NNN-***	M46	M46-046PV
M46-20051	PUMP-VAR DISPL	MPV-046-C-B-A-G-R-B-A-AA-A-A-BDD-AB-U-BA-C-NNN-***	M46	M46-046PV
M46-20052	PUMP-VAR DISPL	MPV-046-C-B-B-W-R-B-A-AA-A-A-BBB-CD-A-HH-A-NNN-***	M46	M46-046PV
M46-20053	PUMP-VAR DISPL	MPV-046-C-B-B-G-L-B-J-BA-A-A-BJJ-BA-A-HH-C-NNN-***	M46	M46-046PV
M46-20054	PUMP-VAR DISPL	MPV-046-C-B-B-G-L-B-A-AA-G-A-BGG-DA-A-ZF-C-NNN-***	M46	M46-046PV
M46-20055	PUMP-VAR DISPL	MPV-046-C-B-A-A-L-A-J-BC-A-A-BCC-AB-D-ZW-C-NNN-***	M46	M46-046PV
M46-20056	PUMP-VAR DISPL	MPV-046-C-B-A-A-L-B-A-BA-A-A-BGG-AB-D-BD-C-NNN-***	M46	M46-046PV
M46-20057	PUMP-VAR DISPL	MPV-046-C-B-A-S-L-A-M-BC-G-A-BFF-AB-D-ZW-B-NNR-***	M46	M46-046PV
M46-20058	PUMP-VAR DISPL	MPV-046-C-B-A-W-R-B-A-AA-A-A-BDD-AB-D-FF-A-NNN-***	M46	M46-046PV
M46-20059	PUMP-VAR DISPL	MPV-046-C-B-A-B-R-B-A-AA-A-A-BJJ-AB-D-DD-A-NNN-***	M46	M46-046PV
M46-2006	MPV046C-BAH-LBA-AAAA-BFF-	MPV-046-C-B-A-H-L-B-A-AA-A-A-BFF-AB-U-BD-A-NNN-***	M46	M46-046PV
M46-20060	PUMP-VAR DISPL	MPV-046-C-B-B-B-R-B-A-BA-G-A-BEE-CB-A-HH-A-NNN-***	M46	M46-046PV
M46-20061	PUMP-VAR DISPL	MPV-046-C-B-A-D-L-B-A-BA-A-A-BEE-AB-U-ED-B-NNN-***	M46	M46-046PV
M46-20062	PUMP-VAR DISPL	MPV-046-C-B-A-D-L-B-A-BA-A-A-BHH-AB-U-ED-B-NNN-***	M46	M46-046PV
M46-20063	PUMP-VAR DISPL	MPV-046-C-B-B-K-L-B-A-BA-A-A-BBB-CD-A-GG-B-NNN-***	M46	M46-046PV
M46-20064	PUMP-VAR DISPL	MPV-046-C-B-A-H-R-B-A-AA-A-A-BFF-AB-U-CD-A-NNN-***	M46	M46-046PV
M46-20065	PUMP-VAR DISPL	MPV-046-C-B-A-H-R-B-A-AA-A-A-BJJ-AB-U-CD-A-NNN-***	M46	M46-046PV
M46-20066	PUMP-VAR DISPL	MPV-046-C-B-A-H-R-B-A-BA-G-A-BFF-AC-U-AA-A-NNN-***	M46	M46-046PV
M46-20071	PUMP-VAR DISPL	MPV-046-C-B-A-S-T-A-M-BC-G-A-BGG-AB-D-ZW-B-NNR-***	M46	M46-046PV
M46-20072	PUMP-VAR DISPL	MPV-046-C-B-A-B-R-B-A-AA-A-A-BHH-AB-D-AA-A-NNN-***	M46	M46-046PV
M46-20073	PUMP-VAR DISPL	MPV-046-C-B-A-B-R-B-A-AA-A-A-BGG-AB-D-AA-A-NNN-***	M46	M46-046PV
M46-20075	PUMP-VAR DISPL	MPV-046-C-B-A-A-L-B-A-AA-A-A-BJJ-AB-U-BB-C-NNN-***	M46	M46-046PV
M46-20076	PUMP-VAR DISPL	MPV-046-C-B-A-K-R-B-A-AA-A-A-BJJ-AB-D-BB-B-NNN-***	M46	M46-046PV
M46-20077	PUMP-VAR DISPL	MPV-046-C-B-B-A-R-B-A-BA-A-A-BGG-CD-A-HH-C-NNN-***	M46	M46-046PV
M46-20079	PUMP-VAR DISPL	MPV-046-C-B-A-B-L-A-A-BC-A-A-BDD-AB-D-ED-A-NNN-***	M46	M46-046PV
M46-2008	MPV046C-BAH-LBA-AACA-BFF-	MPV-046-C-B-A-H-L-B-A-AA-C-A-BFF-AB-U-BD-A-NNN-***	M46	M46-046PV
M46-20080	PUMP-VAR DISPL	MPV-046-C-B-B-L-A-A-BC-A-A-BDD-BC-A-GG-A-NNN-***	M46	M46-046PV

M46-20081	PUMP-VAR DISPL	MPV-046-C-B-A-H-L-B-A-AA-A-A-BFF-AB-U-ED-A-NNN-***	M46	M46-046PV
M46-20082	PUMP-VAR DISPL	MPV-046-C-B-A-A-L-B-A-AA-A-A-BHH-AB-U-ED-C-NNN-***	M46	M46-046PV
M46-20083	PUMP-VAR DISPL	MPV-046-C-B-B-D-L-B-A-BA-A-A-BMM-CB-A-GG-B-NNN-***	M46	M46-046PV
M46-20084	PUMP-VAR DISPL	MPV-046-C-B-B-V-R-B-A-BA-A-A-BCC-CB-A-GG-C-NNN-***	M46	M46-046PV
M46-20085	PUMP-VAR DISPL	MPV-046-C-B-A-H-R-B-A-AA-A-A-BHH-AB-U-ED-A-NNN-***	M46	M46-046PV
M46-20086	PUMP-VAR DISPL	MPV-046-C-B-A-B-R-B-C-AA-G-A-BFF-AB-U-ED-A-NNN-***	M46	M46-046PV
M46-20087	PUMP-VAR DISPL	MPV-046-C-B-A-K-L-B-A-AA-A-A-BHH-AB-U-ED-B-NNN-***	M46	M46-046PV
M46-20088	PUMP-VAR DISPL	MPV-046-C-B-A-H-L-B-A-AA-D-A-BGG-AB-U-ED-A-NNN-***	M46	M46-046PV
M46-20089	PUMP-VAR DISPL	MPV-046-C-B-B-H-L-B-A-AA-A-A-BFF-CD-A-JJ-A-NNN-***	M46	M46-046PV
M46-2009	PUMP-VAR DISPL	MPV-046-C-B-A-H-R-B-A-BA-A-A-BHH-AB-U-FF-A-NNN-***	M46	M46-046PV
M46-20090	PUMP-VAR DISPL	MPV-046-C-B-B-G-R-B-A-AA-G-A-BBB-CD-A-JJ-C-NNN-***	M46	M46-046PV
M46-20092	PUMP-VAR DISPL	MPV-046-C-B-A-H-R-B-A-BA-A-A-BFF-AB-U-ED-A-NNN-***	M46	M46-046PV
M46-20093	PUMP-VAR DISPL	MPV-046-C-B-B-R-B-A-AA-C-A-BFF-CB-A-HH-A-NNN-***	M46	M46-046PV
M46-20094	PUMP-VAR DISPL	MPV-046-C-B-A-H-R-B-C-AA-A-A-BEE-AB-U-DD-A-NNN-***	M46	M46-046PV
M46-20095	PUMP-VAR DISPL	MPV-046-C-B-B-H-R-B-A-BA-A-A-BCC-BA-A-GG-A-NNN-***	M46	M46-046PV
M46-20096	PUMP-VAR DISPL	MPV-046-C-B-B-H-R-B-A-BA-A-A-BFF-BA-A-GG-A-NNN-***	M46	M46-046PV
M46-20100	PUMP-VAR DISPL	MPV-046-C-B-B-K-R-B-A-AA-A-A-BHH-BA-A-HH-B-NNN-***	M46	M46-046PV
M46-20103	PUMP-VAR DISPL	MPV-046-C-B-B-H-L-B-A-BA-A-A-BHH-CB-A-JJ-A-NNN-***	M46	M46-046PV
M46-20104	PUMP-VAR DISPL	MPV-046-C-B-A-G-L-B-A-AA-D-A-BGG-AB-U-ED-C-NNN-***	M46	M46-046PV
M46-20105	PUMP-VAR DISPL	MPV-046-C-B-B-A-L-B-A-AA-A-A-BHH-DA-A-GG-C-NNN-***	M46	M46-046PV
M46-20106	PUMP-VAR DISPL	MPV-046-C-B-B-A-L-B-A-AA-G-A-BCC-BA-A-GG-C-NNN-***	M46	M46-046PV
M46-20111	PUMP-VAR DISPL	MPV-046-C-B-B-H-R-B-A-BA-A-A-BHH-CE-A-JJ-A-NNN-***	M46	M46-046PV
M46-20112	PUMP-VAR DISPL	MPV-046-C-B-B-H-L-B-A-BA-A-A-BHH-CE-A-JJ-A-NNN-***	M46	M46-046PV
M46-20113	PUMP-VAR DISPL	MPV-046-C-B-A-A-R-B-A-AA-G-A-BEE-AB-U-ZM-C-NNN-***	M46	M46-046PV
M46-20114	PUMP-VAR DISPL	MPV-046-C-B-A-B-R-B-A-AA-A-A-BEE-AB-U-ZM-A-NNN-***	M46	M46-046PV
M46-20115	PUMP-VAR DISPL	MPV-046-C-B-B-R-B-D-BA-A-A-BFF-CB-A-HH-A-NNN-***	M46	M46-046PV
M46-20116	PUMP-VAR DISPL	MPV-046-C-B-B-K-R-B-D-BA-A-A-BFF-CB-A-HH-B-NNN-***	M46	M46-046PV
M46-20118	PUMP-VAR DISPL	MPV-046-C-B-B-K-R-B-B-BA-A-A-BFF-CB-A-HH-B-NNN-***	M46	M46-046PV
M46-20119	PUMP-VAR DISPL	MPV-046-C-B-B-P-L-B-A-AA-A-A-BEE-CD-A-HH-A-NNN-***	M46	M46-046PV
M46-20120	PUMP-VAR DISPL	MPV-046-C-B-A-H-R-B-A-AA-A-B-BJJ-AB-U-FF-A-NNN-***	M46	M46-046PV
M46-20121	PUMP-VAR DISPL	MPV-046-C-B-B-W-R-B-A-AA-G-A-BCC-BA-A-GG-A-NNN-***	M46	M46-046PV
M46-20122	PUMP-VAR DISPL	MPV-046-C-B-A-H-R-B-A-AA-A-BJJ-AB-U-ZR-A-NNN-***	M46	M46-046PV
M46-20125	PUMP-VAR DISPL	MPV-046-C-B-B-R-B-A-BA-A-A-BDD-CE-A-GG-A-NNN-***	M46	M46-046PV
M46-20126	PUMP-VAR DISPL	MPV-046-C-B-B-A-L-B-A-AA-A-A-BCC-CE-A-GG-C-NNN-***	M46	M46-046PV
M46-20127	PUMP-VAR DISPL	MPV-046-C-B-A-H-R-B-J-BA-A-A-BJJ-AB-U-FA-A-NNN-***	M46	M46-046PV
M46-20129	PUMP-VAR DISPL	MPV-046-C-B-B-A-R-B-A-BA-A-A-BHH-CB-A-HH-C-NNN-***	M46	M46-046PV

M46-2013	PUMP-VAR DISPL	MPV-046-C-B-A-H-R-B-A-AA-A-A-BJJ-AB-U-FF-A-NNN-***	M46	M46-046PV
M46-20130	PUMP-VAR DISPL	MPV-046-C-B-B-A-R-B-A-BA-G-A-BHH-CB-A-HH-C-NNN-***	M46	M46-046PV
M46-20131	PUMP-VAR DISPL	MPV-046-C-B-B-H-L-B-M-BA-A-A-BFF-CG-A-GG-A-NNN-***	M46	M46-046PV
M46-20132	PUMP-VAR DISPL	MPV-046-C-B-A-K-S-B-A-AA-A-A-BGG-AB-U-ZR-B-NNN-***	M46	M46-046PV
M46-20133	PUMP-VAR DISPL	MPV-046-C-B-B-A-R-B-A-AA-G-A-BBB-BA-A-GG-C-NNN-***	M46	M46-046PV
M46-20134	PUMP-VAR DISPL	MPV-046-C-B-A-A-R-B-A-AA-A-A-BFF-AB-U-ZK-C-NNN-***	M46	M46-046PV
M46-20135	PUMP-VAR DISPL	MPV-046-C-B-A-P-R-B-A-AA-A-A-BEE-AB-D-AA-A-NNN-***	M46	M46-046PV
M46-20136	PUMP-VAR DISPL	MPV-046-C-B-B-H-R-B-B-BA-A-A-BFF-CB-A-HH-A-NNN-***	M46	M46-046PV
M46-20137	PUMP-VAR DISPL	MPV-046-C-B-A-A-R-B-A-AA-L-A-BEE-AB-U-ZM-C-NNN-***	M46	M46-046PV
M46-20139	PUMP-VAR DISPL	MPV-046-C-B-B-A-R-B-A-AA-A-A-BBB-CG-A-JJ-C-NNN-***	M46	M46-046PV
M46-20140	PUMP-VAR DISPL	MPV-046-C-B-B-S-L-A-A-BC-A-A-BBB-CE-A-JJ-B-NNR-***	M46	M46-046PV
M46-20141	PUMP-VAR DISPL	MPV-046-C-B-B-S-L-A-J-BC-A-A-BBB-CE-A-JJ-B-NNR-***	M46	M46-046PV
M46-20142	PUMP-VAR DISPL	MPV-046-C-B-B-D-R-B-A-BA-A-A-BJJ-CB-A-GG-B-NNN-***	M46	M46-046PV
M46-20143	PUMP-VAR DISPL	MPV-046-C-B-B-A-L-B-A-BA-A-A-BHH-CB-A-GG-C-NNN-***	M46	M46-046PV
M46-20145	PUMP-VAR-DISPL MPV046	MPV-046-C-B-A-U-T-A-M-BC-S-A-BDD-AB-D-ZW-B-NNR-***	M46	M46-046PV
M46-20147	PUMP-VAR DISPL	MPV-046-C-B-B-S-T-A-M-BC-A-A-BFF-CE-A-TT-B-NNR-***	M46	M46-046PV
M46-20155	PUMP-VAR DISPL	MPV-046-C-B-A-H-R-B-A-BA-G-A-BFF-AC-U-ZY-A-NNN-***	M46	M46-046PV
M46-20156	PUMP-VAR DISPL	MPV-046-C-B-B-L-B-A-AA-A-A-BHH-DA-A-RR-A-NNN-***	M46	M46-046PV
M46-20157	PUMP-VAR DISPL	MPV-046-C-B-B-R-B-A-AA-A-A-BHH-DA-A-SS-A-NNN-***	M46	M46-046PV
M46-20158	PUMP-VAR DISPL	MPV-046-C-B-A-K-L-B-A-AA-A-A-BHH-AB-U-ZK-B-NNN-***	M46	M46-046PV
M46-20159	PUMP-VAR DISPL	MPV-046-C-B-B-A-L-B-A-AA-A-A-BHH-CE-A-GG-C-NNN-***	M46	M46-046PV
M46-20160	PUMP-VAR DISPL	MPV-046-C-B-A-K-S-B-B-AA-A-A-BGG-AB-U-ZR-B-NNN-***	M46	M46-046PV
M46-20161	PUMP-VAR DISPL	MPV-046-C-B-A-D-R-B-A-AA-A-A-BBB-AB-D-AA-B-NNN-***	M46	M46-046PV
M46-20162	PUMP-VAR-DISPL MPV046	MPV-046-C-B-A-K-L-B-A-AA-G-A-BHH-AB-U-ZK-B-NNN-***	M46	M46-046PV
M46-20164	PUMP-VAR DISPL	MPV-046-C-B-B-B-R-B-A-AA-G-A-BHH-DA-A-SS-A-NNN-***	M46	M46-046PV
M46-20166	PUMP-VAR DISPL	MPV-046-C-B-B-H-L-B-A-BA-A-A-BJJ-CE-A-GG-A-NNN-***	M46	M46-046PV
M46-20167	PUMP-VAR DISPL	MPV-046-C-B-A-K-L-B-J-AA-A-A-BHH-AB-U-ED-B-NNN-***	M46	M46-046PV
M46-20168	PUMP-VAR DISPL	MPV-046-C-B-A-K-R-B-J-AA-A-A-BHH-AB-U-ED-B-NNN-***	M46	M46-046PV
M46-20173	PUMP-VAR DISPL	MPV-046-C-B-A-B-R-B-A-BA-A-A-BMM-AB-U-ED-A-NNN-***	M46	M46-046PV
M46-20174	PUMP-VAR DISPL	MPV-046-C-B-B-P-L-B-A-AA-A-A-BEE-CG-A-HH-A-NNN-***	M46	M46-046PV
M46-20176	PUMP-VAR DISPL	MPV-046-C-B-A-D-R-B-A-AA-A-A-BHH-AB-U-ED-B-NNN-***	M46	M46-046PV
M46-20177	PUMP-VAR DISPL	MPV-046-C-B-A-H-R-B-A-AA-A-A-BGG-AB-D-AA-A-NNN-***	M46	M46-046PV
M46-20178	PUMP-VAR DISPL	MPV-046-C-B-A-W-R-B-A-AA-A-A-BFF-AB-U-DD-A-NNN-***	M46	M46-046PV
M46-20179	PUMP-VAR DISPL	MPV-046-C-B-B-W-R-B-A-AA-A-A-BFF-CD-A-GG-A-NNN-***	M46	M46-046PV
M46-20180	PUMP-VAR DISPL	MPV-046-C-B-B-H-R-B-A-BA-G-A-BFF-DA-A-RR-A-NNN-***	M46	M46-046PV
M46-20181	PUMP-VAR DISPL	MPV-046-C-B-B-A-R-B-A-BA-A-A-BBB-CG-A-JJ-C-NNN-***	M46	M46-046PV

M46-20183	PUMP-VAR DISPL	MPV-046-C-B-B-D-R-B-A-BA-A-A-BCC-CB-A-GG-B-NNN-***	M46	M46-046PV
M46-20184	PUMP-VAR DISPL	MPV-046-C-B-B-A-R-A-J-BC-R-A-BCC-DA-A-TT-C-NNN-***	M46	M46-046PV
M46-20185	PUMP-VAR DISPL	MPV-046-C-B-B-A-R-A-J-BC-R-A-BCC-DB-A-TT-C-NNN-***	M46	M46-046PV
M46-20187	PUMP-VAR DISPL	MPV-046-C-B-B-B-L-B-A-AA-A-A-BFF-CD-A-GG-A-NNN-***	M46	M46-046PV
M46-20188	PUMP-VAR DISPL	MPV-046-C-B-A-S-R-B-A-AA-A-A-BCC-AB-U-FF-B-NNR-***	M46	M46-046PV
M46-20189	PUMP-VAR DISPL	MPV-046-C-B-B-B-R-B-A-BA-A-A-BJJ-CD-A-GG-A-NNN-***	M46	M46-046PV
M46-20190	PUMP-VAR DISPL	MPV-046-C-B-B-B-L-B-A-AA-A-A-BGG-CB-A-GG-A-NNN-***	M46	M46-046PV
M46-20191	PUMP-VAR DISPL	MPV-046-C-B-B-H-R-B-A-AA-A-A-BGG-CD-A-HH-A-NNN-***	M46	M46-046PV
M46-20194	PUMP-VAR DISPL	MPV-046-C-B-B-A-S-A-T-BC-R-A-BCC-DB-A-TT-C-NNN-***	M46	M46-046PV
M46-20195	PUMP-VAR DISPL	MPV-046-C-B-B-J-S-A-T-BC-S-A-BDD-DB-A-TT-A-NNN-***	M46	M46-046PV
M46-20196	PUMP-VAR DISPL	MPV-046-C-B-B-N-R-B-A-AA-A-A-BBB-CE-A-GG-C-NNN-***	M46	M46-046PV
M46-20197	PUMP-VAR DISPL	MPV-046-C-B-A-D-R-B-A-BA-A-A-BFF-AB-U-ED-B-NNN-***	M46	M46-046PV
M46-20199	PUMP-VAR DISPL	MPV-046-C-B-B-S-T-B-J-BA-S-A-BFF-DB-A-TT-B-NNR-***	M46	M46-046PV
M46-20200	PUMP-VAR DISPL	MPV-046-C-B-A-S-R-B-A-BA-A-A-BCC-AB-U-FF-B-NNR-***	M46	M46-046PV
M46-20201	PUMP-VAR DISPL	MPV-046-C-B-A-A-R-B-A-BA-A-A-BJJ-AB-U-AA-C-NNN-***	M46	M46-046PV
M46-20202	PUMP-VAR DISPL	MPV-046-C-B-A-D-T-B-A-BA-A-A-BJJ-AB-U-FF-B-NNN-***	M46	M46-046PV
M46-20203	PUMP-VAR DISPL	MPV-046-C-B-A-G-R-B-A-AA-A-A-BBB-AB-U-AB-C-NNN-***	M46	M46-046PV
M46-20204	PUMP-VAR DISPL	MPV-046-C-B-B-D-R-B-A-AA-A-A-BJJ-CB-A-GG-B-NNN-***	M46	M46-046PV
M46-20205	PUMP-VAR DISPL	MPV-046-C-B-A-U-T-A-U-BC-A-A-BFF-AB-D-ZW-B-NNR-***	M46	M46-046PV
M46-20206	PUMP-VAR DISPL	MPV-046-C-B-B-D-L-B-A-BA-G-A-BMM-CB-A-GG-B-NNN-***	M46	M46-046PV
M46-20207	PUMP-VAR DISPL	MPV-046-C-B-B-K-R-B-A-AA-A-A-BJJ-BB-A-GG-B-NNN-***	M46	M46-046PV
M46-20210	PUMP-VAR DISPL	MPV-046-C-B-A-S-R-B-A-AA-A-A-BHH-AB-U-ZZ-B-NNR-***	M46	M46-046PV
M46-20211	PUMP-VAR DISPL	MPV-046-C-B-A-S-L-B-A-AA-A-A-BJJ-AB-U-ED-B-NNR-***	M46	M46-046PV
M46-20212	PUMP-VAR DISPL	MPV-046-C-B-B-S-T-B-J-BA-A-A-BFF-DB-A-TT-B-NNR-***	M46	M46-046PV
M46-20213	PUMP-VAR DISPL	MPV-046-C-B-B-K-R-B-A-BA-A-A-BJJ-CE-A-HH-B-NNN-***	M46	M46-046PV
M46-20214	PUMP-VAR DISPL	MPV-046-C-B-A-D-R-B-A-AA-A-A-BHH-AB-U-BB-B-NNN-***	M46	M46-046PV
M46-20217	PUMP-VAR DISPL	MPV-046-C-B-B-B-L-B-A-BA-A-A-BFF-CB-A-GG-A-NNN-***	M46	M46-046PV
M46-20218	PUMP-VAR DISPL	MPV-046-C-B-B-D-L-B-A-BA-A-A-BFF-CB-A-GG-B-NNN-***	M46	M46-046PV
M46-20219	PUMP-VAR DISPL	MPV-046-C-B-B-B-L-B-A-BA-G-A-BFF-CD-A-GG-A-NNN-***	M46	M46-046PV
M46-20220	PUMP-VAR DISPL	MPV-046-C-B-B-K-L-B-A-BA-G-A-BJJ-CD-A-GG-B-NNN-***	M46	M46-046PV
M46-20221	PUMP-VAR DISPL	MPV-046-C-B-B-B-L-B-A-BA-G-A-BJJ-CD-A-GG-A-NNN-***	M46	M46-046PV
M46-20223	PUMP-VAR DISPL	MPV-046-C-B-A-S-T-A-M-BC-A-A-BDD-AB-D-ZW-B-NNR-***	M46	M46-046PV
M46-20225	PUMP-VAR DISPL	MPV-046-C-B-B-B-R-B-A-BA-A-A-BJJ-CB-A-HH-A-NNN-***	M46	M46-046PV
M46-20226	PUMP-VAR DISPL	MPV-046-C-B-B-H-R-B-A-AA-A-A-BGG-CB-A-HH-A-NNN-***	M46	M46-046PV
M46-20227	PUMP-VAR DISPL	MPV-046-C-B-B-W-R-B-A-AA-A-A-BDD-CD-A-GG-A-NNN-***	M46	M46-046PV
M46-20228	PUMP-VAR DISPL	MPV-046-C-B-B-K-R-B-B-BA-A-A-BGG-CE-A-HH-B-NNN-***	M46	M46-046PV

M46-2023	PUMP-VAR DISPL	MPV-046-C-B-A-H-R-B-A-AA-A-A-BJJ-AB-U-DD-A-NNN-***	M46	M46-046PV
M46-20231	PUMP-VAR DISPL	MPV-046-C-B-A-W-R-B-A-AA-A-A-BJJ-AB-U-BB-A-NNN-***	M46	M46-046PV
M46-20232	PUMP-VAR DISPL	MPV-046-C-B-A-K-R-B-A-BA-G-A-BDD-AB-U-AB-B-NNN-***	M46	M46-046PV
M46-20233	PUMP-VAR DISPL	MPV-046-C-B-A-S-R-B-U-BA-A-A-BCC-AB-U-FF-B-NNR-***	M46	M46-046PV
M46-20234	PUMP-VAR DISPL	MPV-046-C-B-A-A-R-B-A-AA-A-A-BCC-AB-D-FF-C-NNN-***	M46	M46-046PV
M46-20239	PUMP-VAR-DISPL MPV046	MPV-046-C-B-B-H-S-A-C-BC-G-A-BJJ-DA-A-ZA-A-NNN-***	M46	M46-046PV
M46-20241	PUMP-VAR DISPL	MPV-046-C-B-A-A-R-B-A-AA-G-A-BMM-AB-U-AA-C-NNN-***	M46	M46-046PV
M46-20243	PUMP-VAR DISPL	MPV-046-C-B-A-K-R-B-A-AA-A-A-BFF-AB-D-DD-B-NNN-***	M46	M46-046PV
M46-20244	PUMP-VAR DISPL	MPV-046-C-B-B-H-R-B-A-BA-A-A-BJJ-CB-A-GG-A-NNN-***	M46	M46-046PV
M46-20245	PUMP-VAR DISPL	MPV-046-C-B-B-D-R-B-A-AA-A-A-BGG-CB-A-GG-B-NNN-***	M46	M46-046PV
M46-20248	PUMP-VAR DISPL	MPV-046-C-B-A-V-R-B-A-BA-A-A-BBB-AB-U-ED-C-NNN-***	M46	M46-046PV
M46-20249	PUMP-VAR DISPL	MPV-046-C-B-B-A-L-A-A-BC-A-A-BMM-CB-A-HH-C-NNN-***	M46	M46-046PV
M46-20250	PUMP-VAR DISPL	MPV-046-C-B-A-K-R-A-A-BC-A-A-BJJ-AC-U-ED-B-NNN-***	M46	M46-046PV
M46-20251	PUMP-VAR DISPL	MPV-046-C-B-A-G-R-A-A-BC-A-A-BJJ-AC-U-ED-C-NNN-***	M46	M46-046PV
M46-20252	PUMP-VAR DISPL	MPV-046-C-B-B-H-R-B-B-BA-A-A-BFF-CB-A-ZB-3-NNN-***	M46	M46-046PV
M46-20253	PUMP-VAR-DISPL MPV046	MPV-046-C-B-B-H-R-B-A-AA-C-A-BFF-DA-A-RR-A-NNN-***	M46	M46-046PV
M46-20255	PUMP-VAR DISPL	MPV-046-C-B-A-H-R-B-B-BA-A-A-BJJ-AB-D-BF-A-NNN-***	M46	M46-046PV
M46-20256	PUMP-VAR DISPL	MPV-046-C-B-B-P-R-B-A-AA-G-A-BBB-CE-A-GG-A-NNN-***	M46	M46-046PV
M46-20257	PUMP-VAR DISPL	MPV-046-C-B-B-N-L-B-A-AA-A-A-BEE-CG-A-HH-C-NNN-***	M46	M46-046PV
M46-20262	PUMP-VAR DISPL	MPV-046-C-B-A-B-R-B-A-BA-R-A-BMM-AB-U-AB-A-NNN-***	M46	M46-046PV
M46-20263	PUMP-VAR DISPL	MPV-046-C-B-B-K-R-B-B-BA-A-A-BGG-CE-A-GG-B-NNN-***	M46	M46-046PV
M46-20264	PUMP-VAR DISPL	MPV-046-C-B-B-G-R-A-A-BC-A-A-BJJ-CB-A-GG-C-NNN-***	M46	M46-046PV
M46-20268	PUMP-VAR DISPL	MPV-046-C-B-A-B-R-B-A-BA-G-A-BFM-AB-U-AB-A-NNN-***	M46	M46-046PV
M46-20269	PUMP-VAR DISPL	MPV-046-C-B-A-B-R-B-A-BA-R-A-BFM-AB-U-AB-A-NNN-***	M46	M46-046PV
M46-20270	PUMP-VAR DISPL	MPV-046-C-B-A-B-R-B-A-AA-A-A-BHH-AB-U-BA-A-NNN-***	M46	M46-046PV
M46-20273	PUMP-VAR DISPL	MPV-046-C-B-B-K-R-B-B-BA-A-A-BDD-CE-A-GG-B-NNN-***	M46	M46-046PV
M46-20274	PUMP-VAR DISPL	MPV-046-C-B-B-B-R-B-B-BA-A-A-BDD-CE-A-GG-A-NNN-***	M46	M46-046PV
M46-20275	PUMP-VAR DISPL	MPV-046-C-B-B-A-L-B-A-AA-G-A-BHH-DA-A-RR-C-NNN-***	M46	M46-046PV
M46-20277	PUMP-VAR DISPL	MPV-046-C-B-B-B-R-B-A-BA-A-A-BEE-CB-A-HH-A-NNN-***	M46	M46-046PV
M46-20278	PUMP-VAR DISPL	MPV-046-C-B-A-S-S-B-A-AA-A-A-BGG-AB-U-AA-B-NNN-***	M46	M46-046PV
M46-20279	PUMP-VAR DISPL	MPV-046-C-B-B-K-S-B-B-AA-A-A-BGG-CB-A-HH-B-NNN-***	M46	M46-046PV
M46-2028	PUMP-VAR DISPL	MPV-046-C-B-A-H-L-B-A-AA-B-A-BJJ-AB-U-BD-A-NNN-***	M46	M46-046PV
M46-20280	PUMP-VAR DISPL	MPV-046-C-B-B-S-B-B-AA-A-A-BMM-CB-A-HH-A-NNN-***	M46	M46-046PV
M46-20281	PUMP-VAR DISPL	MPV-046-C-B-A-H-R-B-A-BA-A-A-BGG-AB-U-AB-A-NNN-***	M46	M46-046PV
M46-20283	PUMP-VAR DISPL	MPV-046-C-B-B-B-R-B-B-BA-B-A-BFF-DA-A-HH-A-NNN-***	M46	M46-046PV
M46-20284	PUMP-VAR DISPL	MPV-046-C-B-B-S-B-C-BA-A-A-BEE-CB-A-HH-A-NNN-***	M46	M46-046PV

M46-20287	PUMP-VAR DISPL	MPV-046-C-B-A-B-L-B-A-AA-G-A-BHH-AB-U-ZK-A-NNN-***	M46	M46-046PV
M46-20288	PUMP-VAR DISPL	MPV-046-C-B-B-D-L-B-A-AA-A-A-BGG-CE-A-GG-B-NNN-***	M46	M46-046PV
M46-20289	PUMP-VAR DISPL	MPV-046-C-B-B-H-R-A-M-BC-G-A-BJJ-DA-A-ZD-A-NNN-***	M46	M46-046PV
M46-20292	PUMP-VAR DISPL	MPV-046-C-B-B-B-T-B-A-BA-A-A-BHH-BA-A-HH-A-NNN-***	M46	M46-046PV
M46-20293	PUMP-VAR DISPL	MPV-046-C-B-B-G-S-B-B-BA-A-A-BGG-CD-A-HH-C-NNN-***	M46	M46-046PV
M46-20294	PUMP-VAR-DISPL MPV046	MPV-046-C-B-B-H-T-B-J-BA-A-A-BFF-CG-A-GG-A-NNN-***	M46	M46-046PV
M46-20295	PUMP-VAR DISPL	MPV-046-C-B-B-G-L-A-A-BC-A-A-BJJ-CE-A-HH-C-NNN-***	M46	M46-046PV
M46-20296	PUMP-VAR DISPL	MPV-046-C-B-B-G-S-A-A-BC-A-A-BJJ-CB-A-GG-C-NNN-***	M46	M46-046PV
M46-20297	PUMP-VAR DISPL	MPV-046-C-B-B-G-S-A-J-BC-A-A-BJJ-CB-A-GG-C-NNN-***	M46	M46-046PV
M46-20298	PUMP-VAR DISPL	MPV-046-C-B-A-J-S-B-B-BA-A-A-BJJ-AB-U-ED-A-NNN-***	M46	M46-046PV
M46-20300	PUMP-VAR DISPL	MPV-046-C-B-B-B-T-B-A-AA-G-A-BJJ-DA-A-SS-A-NNN-***	M46	M46-046PV
M46-20301	PUMP-VAR DISPL	MPV-046-C-B-B-A-R-B-A-AA-A-A-BMM-BA-A-JJ-C-NNN-***	M46	M46-046PV
M46-20302	PUMP-VAR DISPL	MPV-046-C-B-A-B-R-B-J-BA-A-A-BJJ-AB-D-AA-A-NNN-***	M46	M46-046PV
M46-20303	PUMP-VAR DISPL	MPV-046-C-B-B-B-S-B-B-AA-A-A-BFF-CB-A-HH-H-NNA-***	M46	M46-046PV
M46-20305	PUMP-VAR DISPL	MPV-046-C-B-B-A-T-B-B-AA-A-A-BHH-CB-A-GG-C-NNA-***	M46	M46-046PV
M46-20306	PUMP-VAR DISPL	MPV-046-C-B-B-W-R-B-A-BA-A-A-BFF-CD-A-GG-A-NNN-***	M46	M46-046PV
M46-20308	PUMP-VAR DISPL	MPV-046-C-B-B-B-L-B-A-AA-G-A-BJJ-DA-A-HH-A-NNN-***	M46	M46-046PV
M46-20309	PUMP-VAR DISPL	MPV-046-C-B-A-H-T-B-B-BA-A-A-BEE-AB-U-FF-A-NNN-***	M46	M46-046PV
M46-20310	PUMP-VAR DISPL	MPV-046-C-B-A-G-T-B-B-BA-A-A-BEE-AB-U-FF-C-NNN-***	M46	M46-046PV
M46-20311	PUMP-VAR DISPL	MPV-046-C-B-B-G-S-B-A-AA-A-A-BDD-DB-A-SS-C-NNN-***	M46	M46-046PV
M46-20312	PUMP-VAR DISPL	MPV-046-C-B-B-A-L-B-A-AA-G-A-BHH-DA-A-ZD-C-NNN-***	M46	M46-046PV
M46-20313	PUMP-VAR DISPL	MPV-046-C-B-A-D-R-B-A-AA-G-A-BHH-AB-U-EB-B-NNN-***	M46	M46-046PV
M46-20314	PUMP-VAR DISPL	MPV-046-C-B-B-H-S-B-B-BA-A-A-BHH-CE-A-JJ-A-NNN-***	M46	M46-046PV
M46-20315	PUMP-VAR DISPL	MPV-046-C-B-B-H-T-B-B-BA-A-A-BHH-CE-A-JJ-A-NNN-***	M46	M46-046PV
M46-20316	PUMP-VAR DISPL	MPV-046-C-B-B-G-S-B-B-BA-A-A-BHH-CB-A-JJ-C-NNN-***	M46	M46-046PV
M46-20317	PUMP-VAR DISPL	MPV-046-C-B-B-G-T-B-B-BA-A-A-BHH-CB-A-JJ-C-NNN-***	M46	M46-046PV
M46-20318	PUMP-VAR DISPL	MPV-046-C-B-A-G-T-B-B-AA-A-A-BJJ-AC-U-EF-C-NNR-***	M46	M46-046PV
M46-20319	PUMP-VAR DISPL	MPV-046-C-B-A-J-R-B-A-AA-A-C-BJJ-AB-U-AF-A-NNN-***	M46	M46-046PV
M46-2032	PUMP-VAR DISPL	MPV-046-C-B-A-H-R-B-A-AA-A-A-BBB-AB-U-ED-A-NNN-***	M46	M46-046PV
M46-20321	PUMP-VAR DISPL	MPV-046-C-B-B-H-T-B-B-BA-A-A-BHH-BA-A-HH-A-NNN-***	M46	M46-046PV
M46-20322	PUMP-VAR DISPL	MPV-046-C-B-B-V-R-B-A-BA-A-A-BMM-CE-A-GG-C-NNN-***	M46	M46-046PV
M46-20327	PUMP-VAR DISPL	MPV-046-C-B-A-H-S-B-U-AA-A-A-BJJ-AK-U-DF-A-NNN-***	M46	M46-046PV
M46-20328	PUMP-VAR DISPL	MPV-046-C-B-B-A-R-B-B-BA-A-A-BFF-CE-A-GG-C-NNN-***	M46	M46-046PV
M46-20329	PUMP-VAR DISPL	MPV-046-C-B-B-B-S-B-B-BA-A-A-BGG-CE-A-HH-A-NNN-***	M46	M46-046PV
M46-20330	PUMP-VAR DISPL	MPV-046-C-B-B-D-R-B-A-AA-A-A-BDD-CB-A-JJ-B-NNN-***	M46	M46-046PV
M46-20331	PUMP-VAR DISPL	MPV-046-C-B-B-A-R-B-A-AA-A-A-BDD-CB-A-JJ-C-NNN-***	M46	M46-046PV

M46-20334	PUMP-VAR DISPL	MPV-046-C-B-B-H-R-B-B-AA-G-A-BGG-CD-A-ZG-A-NNN-***	M46	M46-046PV
M46-20336	PUMP-VAR DISPL	MPV-046-C-B-A-J-S-B-J-AA-A-A-BJJ-AC-D-ED-A-NNN-***	M46	M46-046PV
M46-20337	PUMP-VAR DISPL	MPV-046-C-B-A-B-S-B-J-BA-A-A-BJJ-AB-D-AA-A-NNN-***	M46	M46-046PV
M46-20338	PUMP-VAR DISPL	MPV-046-C-B-A-K-S-B-C-AA-G-A-BJJ-AB-U-DD-B-NNN-***	M46	M46-046PV
M46-20339	PUMP-VAR DISPL	MPV-046-C-B-B-H-R-B-C-AA-A-A-BFF-CB-A-HH-A-NNN-***	M46	M46-046PV
M46-20340	PUMP-VAR DISPL	MPV-046-C-B-B-B-R-B-C-AA-A-A-BGG-CB-A-GG-A-NNN-***	M46	M46-046PV
M46-20341	PUMP-VAR DISPL	MPV-046-C-B-B-A-R-B-C-BA-A-A-BJJ-CE-A-JJ-C-NNN-***	M46	M46-046PV
M46-20342	PUMP-VAR DISPL	MPV-046-C-B-B-A-S-B-B-AA-A-A-BHH-CE-A-HH-C-NNN-***	M46	M46-046PV
M46-20343	PUMP-VAR DISPL	MPV-046-C-B-A-D-R-B-C-AA-A-A-BJJ-AB-U-AA-B-NNN-***	M46	M46-046PV
M46-20344	PUMP-VAR DISPL	MPV-046-C-B-A-A-S-B-J-BA-A-A-BJJ-AB-U-AA-C-NNN-***	M46	M46-046PV
M46-20345	PUMP-VAR DISPL	MPV-046-C-B-B-B-R-B-C-BA-A-A-BJJ-CE-A-JJ-A-NNN-***	M46	M46-046PV
M46-20347	PUMP-VAR DISPL	MPV-046-C-B-B-H-L-B-C-AA-B-A-BGG-CD-A-GG-A-NNN-***	M46	M46-046PV
M46-20348	PUMP-VAR DISPL	MPV-046-C-B-B-D-S-B-C-BA-A-A-BEE-CB-A-HH-B-NNN-***	M46	M46-046PV
M46-20350	PUMP-VAR DISPL	MPV-046-C-B-B-B-T-B-C-AA-A-A-BEE-CD-A-JJ-A-NNN-***	M46	M46-046PV
M46-20351	PUMP-VAR DISPL	MPV-046-C-B-B-H-S-B-B-BA-A-A-BGG-CE-A-HH-3-NNN-***	M46	M46-046PV
M46-20354	PUMP-VAR DISPL	MPV-046-C-B-B-H-S-B-J-BA-A-A-BJJ-BA-A-HH-A-NNN-***	M46	M46-046PV
M46-20355	PUMP-VAR DISPL	MPV-046-C-B-A-K-S-B-B-AA-A-A-BJJ-AB-U-AB-B-NNN-***	M46	M46-046PV
M46-20356	PUMP-VAR DISPL	MPV-046-C-B-B-A-T-B-B-AA-A-A-BGG-CB-A-HH-C-NNN-***	M46	M46-046PV
M46-20357	PUMP-VAR DISPL	MPV-046-C-B-B-H-S-B-B-BA-A-A-BFF-CB-A-HH-3-NNN-***	M46	M46-046PV
M46-20358	PUMP-VAR DISPL	MPV-046-C-B-B-H-S-B-B-BA-A-A-BFF-CB-A-ZB-A-NNN-***	M46	M46-046PV
M46-20359	PUMP-VAR DISPL	MPV-046-C-B-A-B-T-A-B-BC-A-A-BBB-AB-U-CD-A-NNN-***	M46	M46-046PV
M46-20360	PUMP-VAR DISPL	MPV-046-C-B-B-G-T-B-B-AA-A-A-BGG-CB-A-HH-C-NNN-***	M46	M46-046PV
M46-20361	PUMP-VAR DISPL	MPV-046-C-B-A-H-S-B-U-AA-A-A-BJJ-AB-U-DF-A-NNN-***	M46	M46-046PV
M46-20362	PUMP-VAR DISPL	MPV-046-C-B-A-X-S-B-J-BA-A-A-BJJ-AB-U-AB-B-NNN-***	M46	M46-046PV
M46-20364	PUMP-VAR DISPL	MPV-046-C-B-B-B-S-B-B-AA-A-A-BFF-CB-A-HH-A-NNN-***	M46	M46-046PV
M46-20365	PUMP-VAR DISPL	MPV-046-C-B-B-B-S-B-B-AA-G-A-BFF-CB-A-HH-A-NNN-***	M46	M46-046PV
M46-20366	PUMP-VAR DISPL	MPV-046-C-B-A-B-S-B-B-AA-A-A-BJJ-AB-D-AA-A-NNN-***	M46	M46-046PV
M46-20367	PUMP-VAR DISPL	MPV-046-C-B-B-H-S-B-B-BA-A-A-BGG-CD-A-HH-A-NNN-***	M46	M46-046PV
M46-20368	PUMP-VAR DISPL	MPV-046-C-B-A-B-S-B-J-AA-A-A-BGG-AB-U-ZT-A-NNN-***	M46	M46-046PV
M46-20369	PUMP-VAR DISPL	MPV-046-C-B-A-H-S-B-A-AA-A-B-BJJ-AB-U-ZX-A-NNN-***	M46	M46-046PV
M46-20372	PUMP-VAR DISPL	MPV-046-C-B-A-G-T-B-S-AA-A-A-BJJ-AC-U-CF-C-NNR-***	M46	M46-046PV
M46-20373	PUMP-VAR DISPL	MPV-046-C-B-B-A-S-B-B-BA-A-A-BGG-CD-A-HH-C-NNN-***	M46	M46-046PV
M46-20374	PUMP-VAR DISPL	MPV-046-C-B-A-D-S-B-J-AA-A-A-BHH-AB-U-BB-B-NNN-***	M46	M46-046PV
M46-20378	PUMP-VAR DISPL	MPV-046-C-B-A-K-T-A-B-BC-A-A-BHH-AB-U-BD-B-NNN-***	M46	M46-046PV
M46-20380	PUMP-VAR DISPL	MPV-046-C-B-A-K-S-B-B-AA-A-A-BHH-AB-U-BA-B-NNN-***	M46	M46-046PV
M46-20382	PUMP-VAR DISPL	MPV-046-C-B-A-B-S-B-B-AA-B-A-BFF-AB-U-BD-A-NNN-***	M46	M46-046PV

M46-20384	PUMP-VAR DISPL	MPV-046-C-B-A-B-S-B-B-AA-A-A-BMM-AB-U-AA-A-NNN-***	M46	M46-046PV
M46-20385	PUMP-VAR DISPL	MPV-046-C-B-A-S-S-B-B-AA-A-A-BJJ-AB-D-DD-B-NNN-***	M46	M46-046PV
M46-20386	PUMP-VAR DISPL	MPV-046-C-B-A-B-S-B-B-BA-A-A-BGG-AB-D-AA-A-NNN-***	M46	M46-046PV
M46-20388	PUMP-VAR DISPL	MPV-046-C-B-B-K-S-B-B-BA-A-A-BEE-CM-A-GG-B-NNN-***	M46	M46-046PV
M46-20389	PUMP-VAR DISPL, MPV046	MPV-046-C-B-B-K-T-B-B-BA-A-A-BEE-CM-A-GG-B-NNN-***	M46	M46-046PV
M46-20390	PUMP-VAR DISPL	MPV-046-C-B-B-V-T-B-B-BA-A-A-BHH-CD-A-GG-C-NNN-***	M46	M46-046PV
M46-20392	PUMP-VAR DISPL	MPV-046-C-B-A-H-S-B-B-AA-A-A-BJJ-AB-D-BF-A-NNN-***	M46	M46-046PV
M46-20393	PUMP-VAR-DISPL MPV046	MPV-046-C-B-B-H-S-B-B-AA-G-A-BFF-CD-A-ZG-A-NNN-***	M46	M46-046PV
M46-20396	PUMP-VAR DISPL	MPV-046-C-B-A-K-S-B-J-BA-A-A-BMM-AB-U-AA-B-NNN-***	M46	M46-046PV
M46-20397	PUMP-VAR DISPL	MPV-046-C-B-B-A-S-B-B-AA-A-A-BMM-CD-A-GG-C-NNN-***	M46	M46-046PV
M46-20398	PUMP-VAR DISPL	MPV-046-C-B-A-X-S-B-B-AA-A-A-BJJ-AB-U-AB-A-NNN-***	M46	M46-046PV
M46-20399	PUMP-VAR DISPL	MPV-046-C-B-B-P-T-B-B-AA-A-A-BEE-CG-A-HH-A-NNN-***	M46	M46-046PV
M46-20400	PUMP-VAR DISPL	MPV-046-C-B-A-D-S-B-B-AA-A-A-BJJ-AB-U-ED-B-NNN-***	M46	M46-046PV
M46-20403	PUMP-VAR DISPL	MPV-046-C-B-A-K-S-B-B-AA-A-A-BCC-AB-U-AA-B-NNN-***	M46	M46-046PV
M46-20404	PUMP-VAR DISPL	MPV-046-C-B-B-K-S-B-B-BA-A-A-BGG-CE-A-GG-B-NNN-***	M46	M46-046PV
M46-20405	PUMP-VAR DISPL	MPV-046-C-B-A-B-S-B-B-BA-R-A-BFM-AB-U-AB-A-NNN-***	M46	M46-046PV
M46-20406	PUMP-VAR DISPL	MPV-046-C-B-A-A-S-B-B-AA-A-A-BJJ-AB-U-AD-C-NNN-***	M46	M46-046PV
M46-20410	PUMP-VAR DISPL	MPV-046-C-B-A-J-S-B-B-AA-G-B-BDD-AB-U-ZX-A-NNN-***	M46	M46-046PV
M46-20411	PUMP-VAR-DISPL MPV046	MPV-046-C-B-B-P-S-B-B-AA-A-A-BFF-CB-A-RR-A-NNN-***	M46	M46-046PV
M46-20412	PUMP-VAR DISPL	MPV-046-C-B-B-K-T-B-B-BA-A-A-BFF-CE-A-GG-B-NNN-***	M46	M46-046PV
M46-20413	PUMP-VAR DISPL	MPV-046-C-B-B-H-S-B-J-BA-A-A-BJJ-BB-A-HH-A-NNN-***	M46	M46-046PV
M46-20414	PUMP-VAR DISPL	MPV-046-C-B-B-H-S-A-S-BC-A-A-BFF-DB-A-TT-A-NNN-***	M46	M46-046PV
M46-20416	PUMP-VAR DISPL	MPV-046-C-B-B-G-S-A-M-BC-G-A-BJJ-DA-A-ZD-C-NNN-***	M46	M46-046PV
M46-20418	PUMP-VAR DISPL	MPV-046-C-B-B-H-S-B-B-BA-A-A-BFF-CE-A-ZF-A-NNN-***	M46	M46-046PV
M46-20419	PUMP-VAR DISPL	MPV-046-C-B-A-H-S-B-B-AA-A-A-BJJ-AB-U-ZX-A-NNN-***	M46	M46-046PV
M46-2042	PUMP-VAR DISPL	MPV-046-C-B-A-K-L-B-A-BA-A-A-BJJ-AB-U-ED-B-NNN-***	M46	M46-046PV
M46-20420	PUMP-VAR DISPL	MPV-046-C-B-B-B-T-B-B-BA-A-A-BFF-CB-A-GG-A-NNN-***	M46	M46-046PV
M46-20421	PUMP-VAR DISPL	MPV-046-C-B-A-K-T-B-B-BA-A-A-BJJ-AB-U-ED-B-NNN-***	M46	M46-046PV
M46-20422	PUMP-VAR DISPL	MPV-046-C-B-B-H-T-B-B-AA-A-A-BFF-CB-A-JJ-A-NNN-***	M46	M46-046PV
M46-20423	PUMP-VAR DISPL	MPV-046-C-B-B-K-T-B-J-BA-A-A-BJJ-CE-A-HH-B-NNG-***	M46	M46-046PV
M46-20424	PUMP-VAR DISPL	MPV-046-C-B-B-H-T-B-J-BA-A-A-BJJ-CE-A-TT-A-NNG-***	M46	M46-046PV
M46-20425	PUMP-VAR DISPL	MPV-046-C-B-B-D-T-B-B-BA-G-A-BFF-BA-A-HH-B-NNN-***	M46	M46-046PV
M46-20426	PUMP-VAR DISPL	MPV-046-C-B-B-D-S-B-B-BA-G-A-BFF-BA-A-HH-B-NNN-***	M46	M46-046PV
M46-20427	PUMP-VAR DISPL	MPV-046-C-B-A-B-S-B-B-AA-A-A-BBB-AB-D-ZY-A-NNN-***	M46	M46-046PV
M46-20428	PUMP-VAR DISPL	MPV-046-C-B-A-A-S-A-T-BC-A-A-BHH-AB-D-CD-C-NNN-***	M46	M46-046PV
M46-20429	PUMP-VAR DISPL	MPV-046-C-B-B-H-S-B-B-BA-A-A-BFF-CB-A-TT-A-NNN-***	M46	M46-046PV

M46-20430	PUMP-VAR DISPL	MPV-046-C-B-A-G-S-A-J-BC-A-A-BJJ-AB-U-ZP-C-NNN-***	M46	M46-046PV
M46-20431	PUMP-VAR-DISPL MPV046	MPV-046-C-B-A-H-S-B-B-AA-A-A-BHH-AB-U-BD-A-NNN-***	M46	M46-046PV
M46-20433	PUMP-VAR DISPL	MPV-046-C-B-A-V-T-B-B-AA-A-A-BCC-AB-U-DD-C-NNN-***	M46	M46-046PV
M46-20434	PUMP-VAR DISPL	MPV-046-C-B-A-N-S-B-B-BA-A-A-BJJ-AB-D-DD-C-NNN-***	M46	M46-046PV
M46-20435	PUMP-VAR DISPL	MPV-046-C-B-B-A-S-B-B-AA-A-A-BGG-CB-A-GG-C-NNN-***	M46	M46-046PV
M46-20436	PUMP-VAR DISPL	MPV-046-C-B-A-W-S-B-B-AA-A-A-BJJ-AB-U-ZX-A-NNN-***	M46	M46-046PV
M46-20437	PUMP-VAR DISPL	MPV-046-C-B-B-B-S-B-B-AA-A-A-BDD-CE-A-HH-A-NNN-***	M46	M46-046PV
M46-20443	PUMP-VAR-DISPL MPV046	MPV-046-C-B-A-J-S-B-B-AA-G-B-BDD-AB-U-YG-A-NNN-***	M46	M46-046PV
M46-20444	PUMP-VAR DISPL	MPV-046-C-B-B-T-B-B-BA-A-A-BHH-CB-A-HH-A-NNN-***	M46	M46-046PV
M46-20446	PUMP-VAR DISPL	MPV-046-C-B-B-A-T-B-B-AA-A-A-BGG-CB-A-GG-C-NNN-***	M46	M46-046PV
M46-20447	PUMP-VAR DISPL	MPV-046-C-B-A-G-T-B-B-AA-A-A-BHH-AB-U-ED-C-NNN-***	M46	M46-046PV
M46-20448	PUMP-VAR DISPL	MPV-046-C-B-A-K-T-B-B-AA-A-A-BJJ-AB-U-ED-B-NNN-***	M46	M46-046PV
M46-20449	PUMP-VAR DISPL	MPV-046-C-B-B-H-T-B-B-BA-A-A-BHH-CD-A-HH-A-NNN-***	M46	M46-046PV
M46-20450	PUMP-VAR DISPL	MPV-046-C-B-B-G-S-B-B-BA-A-A-BJJ-CD-A-JJ-C-NNN-***	M46	M46-046PV
M46-20452	PUMP-VAR DISPL	MPV-046-C-B-B-H-S-B-B-BA-A-A-BJJ-CB-A-HH-A-NNN-***	M46	M46-046PV
M46-20453	PUMP-VAR DISPL	MPV-046-C-B-B-H-T-B-B-BA-A-A-BHH-CB-A-HH-A-NNN-***	M46	M46-046PV
M46-20454	PUMP-VAR DISPL	MPV-046-C-B-A-A-S-B-B-AA-A-A-BCC-AB-U-BB-C-NNN-***	M46	M46-046PV
M46-20455	PUMP-VAR DISPL	MPV-046-C-B-A-K-S-B-B-AA-A-A-BJJ-AB-U-CF-B-NNN-***	M46	M46-046PV
M46-20456	PUMP-VAR DISPL	MPV-046-C-B-B-K-S-B-M-BA-A-A-BGG-CE-A-HH-4-NNN-***	M46	M46-046PV
M46-20458	PUMP-VAR DISPL	MPV-046-C-B-A-H-S-B-B-AA-A-A-BJJ-AB-U-AB-A-NNN-***	M46	M46-046PV
M46-20459	PUMP-VAR DISPL	MPV-046-C-B-A-A-S-B-B-AA-A-A-BJJ-AB-D-AA-C-NNN-***	M46	M46-046PV
M46-20460	PUMP-VAR DISPL	MPV-046-C-B-A-B-S-B-B-AA-A-A-BFF-AB-U-BF-A-NNN-***	M46	M46-046PV
M46-20461	PUMP-VAR DISPL	MPV-046-C-B-B-K-S-B-B-BA-A-A-BJJ-CB-A-JJ-B-NNN-***	M46	M46-046PV
M46-20463	PUMP-VAR DISPL	MPV-046-C-B-A-D-S-B-B-AA-A-A-BJJ-AB-U-AA-B-NNN-***	M46	M46-046PV
M46-20464	PUMP-VAR DISPL	MPV-046-C-B-A-A-T-B-B-AA-A-A-BBB-AB-U-ED-C-NNN-***	M46	M46-046PV
M46-20465	PUMP-VAR DISPL	MPV-046-C-B-B-A-T-B-B-BA-A-A-BCC-CE-A-GG-C-NNN-***	M46	M46-046PV
M46-20466	PUMP-VAR DISPL	MPV-046-C-B-A-A-T-B-J-BA-T-A-BJJ-AB-U-AA-C-NNN-***	M46	M46-046PV
M46-20468	PUMP-VAR DISPL	MPV-046-C-B-A-B-S-B-B-AA-A-A-BHH-AB-U-BD-A-NNN-***	M46	M46-046PV
M46-20469	PUMP-VAR DISPL	MPV-046-C-B-A-V-S-B-B-AA-A-A-BEE-AB-U-DD-C-NNN-***	M46	M46-046PV
M46-2047	PUMP-VAR DISPL, MPV046	MPV-046-C-B-A-A-R-B-A-AA-A-A-BFF-AB-U-ED-C-NNN-***	M46	M46-046PV
M46-20470	PUMP-VAR DISPL	MPV-046-C-B-A-B-S-A-B-BC-A-A-BGG-AB-U-ED-A-NNN-***	M46	M46-046PV
M46-20473	PUMP-VAR DISPL	MPV-046-C-B-A-E-S-B-B-AA-A-A-BJJ-AB-U-AB-A-NNN-***	M46	M46-046PV
M46-20474	PUMP-VAR DISPL	MPV-046-C-B-B-H-S-B-M-BA-A-A-BGG-CE-A-HH-3-NNN-***	M46	M46-046PV
M46-20475	PUMP-VAR DISPL	MPV-046-C-B-A-K-S-B-B-BA-A-A-BFF-AB-U-FF-B-NNN-***	M46	M46-046PV
M46-20476	PUMP-VAR DISPL	MPV-046-C-B-A-C-T-A-J-BC-A-A-BRR-GB-B-BA-A-NNG-***	M46	M46-046PV
M46-20477	PUMP-VAR DISPL	MPV-046-C-B-A-G-S-B-B-AA-A-A-BGG-AB-U-BD-C-NNN-***	M46	M46-046PV

M46-20478	PUMP-VAR DISPL	MPV-046-C-B-B-S-T-A-M-BC-P-A-BFF-CE-A-TT-B-NNN-***	M46	M46-046PV
M46-2048	PUMP-VAR DISPL	MPV-046-C-B-B-H-R-B-A-AA-A-A-BJJ-BA-A-GG-A-NNN-***	M46	M46-046PV
M46-20480	PUMP-VAR DISPL	MPV-046-C-B-A-W-S-B-B-AA-A-A-BJJ-AB-U-AA-A-NNN-***	M46	M46-046PV
M46-20481	PUMP-VAR DISPL	MPV-046-C-B-A-J-S-B-B-AA-A-A-BJJ-AB-U-ED-A-NNN-***	M46	M46-046PV
M46-20482	PUMP-VAR DISPL	MPV-046-C-B-A-K-S-B-B-AA-A-A-BHH-AB-U-ED-B-NNN-***	M46	M46-046PV
M46-20483	PUMP-VAR DISPL	MPV-046-C-B-A-H-S-B-B-BA-A-A-BFF-AB-U-FF-A-NNN-***	M46	M46-046PV
M46-20484	PUMP-VAR DISPL	MPV-046-C-B-B-K-T-B-B-BA-A-A-BHH-CE-A-GG-B-NNN-***	M46	M46-046PV
M46-20485	PUMP-VAR DISPL	MPV-046-C-B-A-A-S-B-B-AA-A-A-BJJ-AB-U-YH-C-NNN-***	M46	M46-046PV
M46-20488	PUMP-VAR DISPL	MPV-046-C-B-B-D-T-B-B-BA-A-A-BFF-CD-A-GG-B-NNN-***	M46	M46-046PV
M46-20490	PUMP-VAR DISPL	MPV-046-C-B-A-B-S-B-B-BA-D-A-BFM-AB-U-AB-A-NNN-***	M46	M46-046PV
M46-20491	PUMP-VAR DISPL	MPV-046-C-B-A-B-S-B-B-AA-A-A-BGG-AB-U-BB-A-NNN-***	M46	M46-046PV
M46-20492	PUMP-VAR DISPL	MPV-046-C-B-B-J-S-A-T-BC-W-A-BDD-DB-A-TT-A-NNN-***	M46	M46-046PV
M46-20494	PUMP-VAR DISPL	MPV-046-C-B-B-A-T-B-B-AA-A-A-BGG-CE-A-GG-C-NNN-***	M46	M46-046PV
M46-20495	PUMP-VAR DISPL	MPV-046-C-B-B-A-S-B-B-AA-A-A-BGG-CE-A-GG-C-NNN-***	M46	M46-046PV
M46-20500	PUMP-VAR DISPL	MPV-046-C-B-A-J-S-B-B-AA-G-B-BDD-GB-B-BB-A-NNN-***	M46	M46-046PV
M46-20501	PUMP-VAR DISPL	MPV-046-C-B-B-B-S-B-B-AA-D-A-BFF-CB-A-HH-A-NNN-***	M46	M46-046PV
M46-20502	PUMP-VAR DISPL	MPV-046-C-B-B-B-S-B-B-BA-A-A-BHH-CB-A-GG-A-NNN-***	M46	M46-046PV
M46-20503	PUMP-VAR DISPL	MPV-046-C-B-B-B-S-B-B-AA-A-A-BGG-CE-A-HH-A-NNN-***	M46	M46-046PV
M46-20504	PUMP-VAR DISPL	MPV-046-C-B-B-D-T-B-B-BA-G-A-BEE-CB-A-GG-B-NNN-***	M46	M46-046PV
M46-20505	PUMP-VAR DISPL	MPV-046-C-B-A-D-T-B-B-BA-A-A-BDD-AB-U-DD-B-NNN-***	M46	M46-046PV
M46-20506	PUMP-VAR DISPL	MPV-046-C-B-B-D-S-B-B-BA-A-A-BGG-CD-A-GG-B-NNN-***	M46	M46-046PV
M46-20508	PUMP-VAR DISPL	MPV-046-C-B-A-K-S-A-B-BC-A-A-BFF-GB-B-BA-B-NNN-***	M46	M46-046PV
M46-20509	PUMP-VAR DISPL	MPV-046-C-B-B-G-T-B-B-AA-A-A-BDD-BA-A-JJ-C-NNN-***	M46	M46-046PV
M46-2051	PUMP-VAR DISPL	MPV-046-C-B-A-H-R-B-A-BA-A-A-BCC-AB-U-DD-A-NNN-***	M46	M46-046PV
M46-20510	PUMP-VAR DISPL	MPV-046-C-B-B-B-S-B-B-AA-D-A-BFF-DA-A-HH-A-NNN-***	M46	M46-046PV
M46-20511	PUMP-VAR DISPL	MPV-046-C-B-B-B-S-B-B-BA-A-A-BFF-DA-A-HH-A-NNN-***	M46	M46-046PV
M46-20513	PUMP-VAR DISPL	MPV-046-C-B-B-K-T-B-B-AA-A-A-BGG-CB-A-GG-B-NNN-***	M46	M46-046PV
M46-20516	PUMP-VAR DISPL	MPV-046-C-B-A-J-S-B-B-AA-G-B-BEE-AB-U-YG-A-NNN-***	M46	M46-046PV
M46-20517	PUMP-VAR DISPL	MPV-046-C-B-B-B-T-B-B-AA-V-A-BJJ-DA-A-SS-A-NNN-***	M46	M46-046PV
M46-20518	PUMP-VAR DISPL	MPV-046-C-B-B-B-T-B-B-AA-G-A-BJJ-DA-A-HH-A-NNN-***	M46	M46-046PV
M46-20520	PUMP-VAR DISPL	MPV-046-C-B-A-W-S-B-B-AA-G-A-BFF-GB-B-EA-A-NNN-***	M46	M46-046PV
M46-20526	PUMP-VAR DISPL	MPV-046-C-B-A-V-T-B-B-AA-A-A-BGG-AB-U-ED-C-NNN-***	M46	M46-046PV
M46-20527	PUMP-VAR DISPL	MPV-046-C-B-B-B-T-B-B-AA-A-A-BJJ-CB-A-HH-A-NNN-***	M46	M46-046PV
M46-20528	PUMP-VAR DISPL	MPV-046-C-B-B-B-T-B-B-BA-A-A-BJJ-CB-A-HH-A-NNN-***	M46	M46-046PV
M46-20529	PUMP-VAR DISPL	MPV-046-C-B-B-B-S-B-B-BA-A-A-BFF-CB-A-HH-A-NNN-***	M46	M46-046PV
M46-20530	PUMP-VAR DISPL	MPV-046-C-B-B-H-S-B-S-BA-A-A-BGG-CE-A-VV-3-NNN-***	M46	M46-046PV

M46-20534	PUMP-VAR DISPL	MPV-046-C-B-B-G-T-B-B-AA-A-A-BJJ-CE-A-JJ-C-NNN-***	M46	M46-046PV
M46-20536	PUMP-VAR DISPL	MPV-046-C-B-B-S-B-S-B-BA-V-A-BFF-DA-A-HH-A-NNN-***	M46	M46-046PV
M46-20537	PUMP-VAR DISPL	MPV-046-C-B-A-D-T-B-B-BA-A-A-BMM-AB-U-BB-B-NNN-***	M46	M46-046PV
M46-20538	PUMP-VAR DISPL	MPV-046-C-B-B-G-T-B-B-BA-A-A-BCC-CE-A-GG-C-NNN-***	M46	M46-046PV
M46-20540	PUMP-VAR DISPL	MPV-046-C-B-A-D-S-B-B-AA-A-A-BJB-AB-U-FF-B-NNN-***	M46	M46-046PV
M46-20541	PUMP-VAR DISPL	MPV-046-C-B-A-B-S-B-B-AA-A-A-BFF-AB-U-DD-A-NNN-***	M46	M46-046PV
M46-20542	PUMP-VAR DISPL	MPV-046-C-B-B-H-T-A-B-BC-A-A-BHH-CB-A-JJ-A-NNN-***	M46	M46-046PV
M46-20543	PUMP-VAR DISPL	MPV-046-C-B-B-H-T-B-B-BA-A-A-BHH-CB-A-JJ-A-NNN-***	M46	M46-046PV
M46-20545	PUMP-VAR DISPL	MPV-046-C-B-A-G-S-B-B-BA-G-A-BDD-AB-U-YG-C-NNN-***	M46	M46-046PV
M46-20547	PUMP-VAR DISPL	MPV-046-C-B-A-J-S-B-B-AA-D-B-BDD-GB-B-FF-A-NNG-***	M46	M46-046PV
M46-20550	PUMP-VAR DISPL	MPV-046-C-B-B-K-S-B-M-BA-A-A-BGG-CE-A-VV-4-NNN-***	M46	M46-046PV
M46-20551	PUMP-VAR-DISPL MPV046	MPV-046-C-B-A-A-S-B-B-AA-A-A-BFF-AB-U-ED-C-NNN-***	M46	M46-046PV
M46-20552	PUMP-VAR DISPL	MPV-046-C-B-A-D-T-B-B-AA-A-A-BHH-AB-U-ED-B-NNN-***	M46	M46-046PV
M46-20553	PUMP-VAR DISPL	MPV-046-C-B-A-K-S-B-B-AA-G-A-BHH-AB-U-ED-B-NNN-***	M46	M46-046PV
M46-20554	PUMP-VAR DISPL	MPV-046-C-B-A-W-S-B-B-AA-W-A-BFF-GB-B-EA-A-NNN-***	M46	M46-046PV
M46-20555	PUMP-VAR DISPL	MPV-046-C-B-B-D-T-B-B-BA-A-A-BDD-BA-A-GG-B-NNN-***	M46	M46-046PV
M46-20558	PUMP-VAR DISPL	MPV-046-C-B-A-V-S-B-B-AA-A-A-BHH-AB-U-CD-C-NNN-***	M46	M46-046PV
M46-20559	PUMP-VAR DISPL	MPV-046-C-B-B-H-T-B-B-AA-A-A-BGG-CB-A-GG-A-NNN-***	M46	M46-046PV
M46-20560	PUMP-VAR DISPL	MPV-046-C-B-A-K-T-B-B-AA-A-A-BJJ-AB-U-DD-B-NNN-***	M46	M46-046PV
M46-20561	PUMP-VAR DISPL	MPV-046-C-B-A-A-T-B-B-AA-A-A-BGG-AB-D-BB-C-NNN-***	M46	M46-046PV
M46-20564	PUMP-VAR DISPL	MPV-046-C-B-A-J-S-B-B-AA-A-A-BJJ-AB-D-AA-A-NNN-***	M46	M46-046PV
M46-20566	PUMP-VAR DISPL	MPV-046-C-B-A-B-S-B-B-BA-A-A-BGG-AB-U-ED-A-NNN-***	M46	M46-046PV
M46-20569	PUMP-VAR-DISPL MPV046	MPV-046-C-B-A-J-S-A-B-BC-A-A-BFF-GB-B-LA-A-NNN-***	M46	M46-046PV
M46-2057	PUMP-VAR DISPL	MPV-046-C-B-A-G-L-B-A-AA-A-A-BGG-AB-U-ED-C-NNN-***	M46	M46-046PV
M46-20570	PUMP-VAR DISPL	MPV-046-C-B-A-G-S-B-B-AA-G-A-BDD-AB-U-YG-C-NNN-***	M46	M46-046PV
M46-20571	PUMP-VAR DISPL	MPV-046-C-B-A-J-S-B-B-AA-A-A-BFD-GB-B-BA-A-NNG-***	M46	M46-046PV
M46-20572	PUMP-VAR DISPL	MPV-046-C-B-B-H-L-B-J-BA-A-A-BFF-CG-A-GG-B-NNN-***	M46	M46-046PV
M46-20573	PUMP-VAR DISPL	MPV-046-C-B-B-S-B-B-BA-A-A-BJJ-CB-A-HH-A-NNN-***	M46	M46-046PV
M46-20576	PUMP-VAR DISPL	MPV-046-C-B-B-H-R-B-A-AA-A-A-BJJ-DB-A-SS-A-NNN-***	M46	M46-046PV
M46-20577	PUMP-VAR DISPL	MPV-046-C-B-B-V-T-B-B-BA-A-A-BFF-CE-A-GG-C-NNN-***	M46	M46-046PV
M46-20579	PUMP-VAR DISPL	MPV-046-C-B-B-D-T-B-B-BA-G-A-BMM-CB-A-GG-B-NNN-***	M46	M46-046PV
M46-2058	PUMP-VAR-DISPL MPV046	MPV-046-C-B-A-H-R-B-A-AA-A-A-BGG-AB-U-ED-A-NNN-***	M46	M46-046PV
M46-20580	PUMP-VAR DISPL	MPV-046-C-B-B-H-S-A-A-BC-V-A-BFF-DB-A-TT-A-NNN-***	M46	M46-046PV
M46-20581	PUMP-VAR DISPL	MPV-046-C-B-B-V-T-B-B-BA-A-A-BHH-CB-A-GG-C-NNN-***	M46	M46-046PV
M46-20582	PUMP-VAR DISPL	MPV-046-C-B-B-A-S-B-B-AA-1-A-BHH-DA-A-SS-C-NNN-***	M46	M46-046PV
M46-20583	PUMP-VAR DISPL	MPV-046-C-B-B-T-B-B-AA-A-A-BHH-CB-A-GG-A-NNN-***	M46	M46-046PV

M46-20584	PUMP-VAR DISPL	MPV-046-C-B-B-A-R-B-A-AA-A-A-BCC-CB-A-GG-C-NNN-***	M46	M46-046PV
M46-20586	PUMP-VAR DISPL	MPV-046-C-B-A-G-S-B-B-AA-G-A-BGG-AB-D-AA-A-NNN-***	M46	M46-046PV
M46-20589	PUMP-VAR DISPL	MPV-046-C-B-B-S-B-A-BA-A-A-BHH-CB-A-HH-A-NNN-***	M46	M46-046PV
M46-20590	PUMP-VAR DISPL	MPV-046-C-B-B-K-T-B-A-BA-A-A-BDD-CB-A-GG-B-NNN-***	M46	M46-046PV
M46-20591	PUMP-VAR DISPL	MPV-046-C-B-B-T-B-B-BA-A-A-BDD-BA-A-GG-A-NNN-***	M46	M46-046PV
M46-20592	PUMP-VAR DISPL	MPV-046-C-B-A-G-S-B-B-AA-A-A-BFF-AB-U-DD-C-NNN-***	M46	M46-046PV
M46-20593	PUMP-VAR DISPL	MPV-046-C-B-B-S-B-B-AA-A-A-BJJ-CB-A-HH-A-NNN-***	M46	M46-046PV
M46-20595	PUMP-VAR DISPL	MPV-046-C-B-B-G-T-B-B-AA-V-A-BJJ-DB-A-HH-C-NNN-***	M46	M46-046PV
M46-20596	PUMP-VAR DISPL	MPV-046-C-B-B-G-T-B-B-AA-V-A-BJJ-DA-A-HH-C-NNN-***	M46	M46-046PV
M46-20598	PUMP-VAR DISPL	MPV-046-C-B-A-B-S-B-J-BA-A-A-BJJ-GB-B-AA-A-NNN-***	M46	M46-046PV
M46-20599	PUMP-VAR DISPL	MPV-046-C-B-A-A-T-B-B-AA-A-A-BFF-AB-U-FF-C-NNN-***	M46	M46-046PV
M46-2060	PUMP-VAR-DISPL MPV046	MPV-046-C-B-A-K-R-B-A-AA-A-A-BGG-AB-U-ED-B-NNN-***	M46	M46-046PV
M46-20601	PUMP-VAR DISPL	MPV-046-C-B-A-D-S-A-B-BA-A-A-BJJ-AB-D-FF-B-NNN-***	M46	M46-046PV
M46-20602	PUMP-VAR DISPL	MPV-046-C-B-B-K-S-B-J-AA-A-A-BJJ-DB-A-TT-B-NNR-***	M46	M46-046PV
M46-20603	PUMP-VAR DISPL	MPV-046-C-B-B-H-T-B-B-AA-A-A-BGG-CD-A-HH-A-NNN-***	M46	M46-046PV
M46-20604	PUMP-VAR DISPL	MPV-046-C-B-B-G-S-B-B-AA-A-A-BJJ-DA-A-HH-C-NNN-***	M46	M46-046PV
M46-20605	PUMP-VAR DISPL	MPV-046-C-B-B-G-S-B-J-BA-G-A-BJJ-DA-A-HH-C-NNN-***	M46	M46-046PV
M46-20606	PUMP-VAR DISPL	MPV-046-C-B-A-N-S-B-B-AA-A-A-BDD-AB-D-BB-C-NNN-***	M46	M46-046PV
M46-20607	PUMP-VAR DISPL	MPV-046-C-B-B-G-S-B-B-AA-V-A-BJJ-DA-A-HH-C-NNN-***	M46	M46-046PV
M46-20608	PUMP-VAR DISPL	MPV-046-C-B-B-H-S-B-B-BA-A-A-BHH-CB-A-JJ-A-NNN-***	M46	M46-046PV
M46-20609	PUMP-VAR DISPL	MPV-046-C-B-B-K-T-B-B-BA-A-A-BBB-CB-A-GG-B-NNN-***	M46	M46-046PV
M46-20610	PUMP-VAR DISPL	MPV-046-C-B-A-N-S-B-B-BA-A-A-BDD-AB-D-BB-C-NNN-***	M46	M46-046PV
M46-20614	PUMP-VAR DISPL	MPV-046-C-B-A-A-T-B-B-BA-A-A-BJJ-AB-U-BB-C-NNN-***	M46	M46-046PV
M46-20615	PUMP-VAR DISPL	MPV-046-C-B-B-A-T-B-B-AA-A-A-BHH-CE-A-GG-C-NNN-***	M46	M46-046PV
M46-20616	PUMP-VAR DISPL	MPV-046-C-B-B-S-B-B-AA-A-A-BCC-CH-A-HH-A-NNN-***	M46	M46-046PV
M46-20617	PUMP-VAR DISPL	MPV-046-C-B-B-A-S-B-B-BA-A-A-BMM-CD-A-HH-C-NNN-***	M46	M46-046PV
M46-20618	PUMP-VAR DISPL	MPV-046-C-B-B-K-R-B-S-AA-A-A-BCC-CB-A-GG-B-NNN-***	M46	M46-046PV
M46-20619	PUMP-VAR DISPL	MPV-046-C-B-B-A-S-B-B-AA-V-A-BJJ-DB-A-HH-C-NNN-***	M46	M46-046PV
M46-20620	PUMP-VAR DISPL	MPV-046-C-B-B-A-S-A-M-BC-X-A-BJJ-DB-A-HH-C-NNR-***	M46	M46-046PV
M46-20621	PUMP-VAR DISPL	MPV-046-C-B-A-A-T-B-B-BA-A-A-BDD-AB-U-ED-C-NNN-***	M46	M46-046PV
M46-20622	PUMP-VAR DISPL	MPV-046-C-B-B-J-S-B-B-BA-A-A-BGG-CB-A-HH-A-NNN-***	M46	M46-046PV
M46-20623	PUMP-VAR DISPL	MPV-046-C-B-B-A-T-B-B-BA-G-A-BMM-CE-A-HH-C-NNN-***	M46	M46-046PV
M46-20624	PUMP-VAR DISPL	MPV-046-C-B-B-A-T-B-B-BA-A-A-BFF-DA-A-HH-C-NNA-***	M46	M46-046PV
M46-20625	PUMP-VAR DISPL	MPV-046-C-B-A-G-S-B-J-BA-A-A-BFF-AB-D-ED-C-NNN-***	M46	M46-046PV
M46-20626	PUMP-VAR DISPL	MPV-046-C-B-A-H-S-B-J-BA-A-A-BFF-AB-D-ED-A-NNN-***	M46	M46-046PV
M46-20628	PUMP-VAR DISPL	MPV-046-C-B-B-D-T-B-J-AA-G-A-BFF-CB-A-HH-B-NNN-***	M46	M46-046PV

M46-2063	PUMP-VAR DISPL	MPV-046-C-B-B-G-L-B-A-AA-A-A-BGG-CD-A-GG-C-NNN-***	M46	M46-046PV
M46-20630	PUMP-VAR DISPL	MPV-046-C-B-A-K-S-A-B-AA-A-A-BJJ-AB-D-BD-B-NNN-***	M46	M46-046PV
M46-20631	PUMP-VAR DISPL	MPV-046-C-B-A-G-S-B-J-BA-V-A-BJJ-DA-A-TT-C-NNN-***	M46	M46-046PV
M46-20632	PUMP-VAR DISPL	MPV-046-C-B-B-R-B-A-BA-A-A-BRR-BA-A-HH-C-NNN-***	M46	M46-046PV
M46-20633	PUMP-VAR DISPL	MPV-046-C-B-B-J-S-B-J-BA-A-A-BGG-CB-A-TT-A-NNN-***	M46	M46-046PV
M46-20634	PUMP-VAR DISPL	MPV-046-C-B-B-V-T-B-J-AA-V-A-BJJ-DA-A-GG-C-NNN-***	M46	M46-046PV
M46-20635	PUMP-VAR-DISPL MPV046	MPV-046-C-B-B-K-S-B-J-AA-A-A-BRF-DB-A-TT-B-NNR-***	M46	M46-046PV
M46-20637	PUMP-VAR DISPL	MPV-046-C-B-A-K-S-B-B-AA-A-A-BBB-AB-U-ED-B-NNN-***	M46	M46-046PV
M46-20639	PUMP-VAR DISPL	MPV-046-C-B-A-H-S-B-J-AA-A-A-BJJ-AB-D-ED-A-NNN-***	M46	M46-046PV
M46-2064	PUMP-VAR-DISPL MPV046	MPV-046-C-B-B-H-L-B-A-AA-A-A-BGG-CD-A-GG-A-NNN-***	M46	M46-046PV
M46-20640	PUMP-VAR DISPL	MPV-046-C-B-A-H-S-B-J-AA-A-A-BFF-AB-D-FF-A-NNN-***	M46	M46-046PV
M46-20641	PUMP-VAR DISPL	MPV-046-C-B-B-A-S-A-B-BC-V-A-BJJ-DB-A-HH-A-NNN-***	M46	M46-046PV
M46-20642	PUMP-VAR DISPL	MPV-046-C-B-A-B-S-B-B-AA-A-A-BFF-AB-U-BD-A-NNA-***	M46	M46-046PV
M46-20643	PUMP-VAR DISPL	MPV-046-C-B-B-A-S-B-J-BA-A-A-BGG-BA-A-HH-C-NNN-***	M46	M46-046PV
M46-20644	PUMP-VAR DISPL	MPV-046-C-B-B-G-R-B-B-AA-A-A-BCC-CB-A-HH-C-NNN-***	M46	M46-046PV
M46-20645	PUMP-VAR DISPL	MPV-046-C-B-A-V-R-B-B-AA-A-A-BEE-AB-U-ZM-C-NNN-***	M46	M46-046PV
M46-20646	PUMP-VAR DISPL	MPV-046-C-B-B-S-B-B-AA-A-A-BGG-CD-A-JJ-A-NNN-***	M46	M46-046PV
M46-20647	PUMP-VAR DISPL	MPV-046-C-B-A-G-S-B-B-AA-A-A-BJJ-AB-D-BB-A-NNN-***	M46	M46-046PV
M46-20648	PUMP-VAR DISPL	MPV-046-C-B-B-A-L-B-B-AA-A-A-BBB-CB-A-GG-C-NNN-***	M46	M46-046PV
M46-20649	PUMP-VAR DISPL	MPV-046-C-B-B-D-L-B-B-AA-A-A-BGG-CD-A-GG-B-NNN-***	M46	M46-046PV
M46-20650	PUMP-VAR DISPL	MPV-046-C-B-B-K-T-B-B-AA-A-A-BMM-CE-A-HH-B-NNN-***	M46	M46-046PV
M46-20651	PUMP-VAR-DISPL MPV046	MPV-046-C-B-A-J-S-B-B-AA-G-B-BEJ-AB-U-YG-A-NNN-***	M46	M46-046PV
M46-20652	PUMP-VAR DISPL	MPV-046-C-B-B-G-S-B-B-AA-A-A-BGG-CB-A-HH-C-NNN-***	M46	M46-046PV
M46-20653	PUMP-VAR DISPL	MPV-046-C-B-B-S-B-B-AA-C-A-BFF-DA-A-HH-H-NNA-***	M46	M46-046PV
M46-20654	PUMP-VAR DISPL	MPV-046-C-B-B-S-B-B-AA-B-A-BFF-DA-A-HH-H-NNN-***	M46	M46-046PV
M46-20655	PUMP-VAR DISPL	MPV-046-C-B-B-G-S-B-B-AA-A-A-BFF-CB-A-GG-C-NNN-***	M46	M46-046PV
M46-20656	PUMP-VAR DISPL	MPV-046-C-B-A-N-S-B-B-BA-G-A-BDD-AB-D-BB-C-NNN-***	M46	M46-046PV
M46-20657	PUMP-VAR DISPL	MPV-046-C-B-B-H-T-B-J-AA-A-A-BHH-CB-A-GG-A-NNN-***	M46	M46-046PV
M46-20658	PUMP-VAR DISPL	MPV-046-C-B-B-J-S-B-S-BA-A-A-BGG-CP-A-VV-3-NNN-***	M46	M46-046PV
M46-20659	PUMP-VAR DISPL	MPV-046-C-B-B-S-B-B-AA-Y-A-BFF-DA-A-HH-H-NNA-***	M46	M46-046PV
M46-20660	PUMP-VAR DISPL	MPV-046-C-B-B-S-B-B-AA-Y-A-BFF-CE-A-HH-H-NNA-***	M46	M46-046PV
M46-20663	PUMP-VAR DISPL	MPV-046-C-B-B-A-T-B-B-AA-G-A-BFF-CE-A-GG-C-NNN-***	M46	M46-046PV
M46-20665	PUMP-VAR DISPL	MPV-046-C-B-B-T-B-B-AA-G-A-BHH-DB-A-HH-A-NNN-***	M46	M46-046PV
M46-20666	PUMP-VAR DISPL	MPV-046-C-B-A-B-S-B-B-AA-A-A-BJJ-AB-U-AD-A-NNN-***	M46	M46-046PV
M46-20667	PUMP-VAR DISPL	MPV-046-C-B-A-A-S-B-B-AA-G-A-BBB-AB-U-JJ-C-NNN-***	M46	M46-046PV
M46-20668	PUMP-VAR DISPL	MPV-046-C-B-A-B-S-B-B-AA-A-A-BFF-AB-U-AA-A-NNN-***	M46	M46-046PV

M46-20669	PUMP-VAR DISPL	MPV-046-C-B-B-T-B-B-AA-A-A-BJJ-BB-A-GG-A-NNN-***	M46	M46-046PV
M46-20674	PUMP-VAR DISPL	MPV-046-C-B-A-K-S-B-B-AA-A-A-BGG-AB-U-FF-B-NNN-***	M46	M46-046PV
M46-20675	PUMP-VAR DISPL	MPV-046-C-B-B-H-S-B-J-BA-A-A-BFF-CN-A-HH-B-NNN-***	M46	M46-046PV
M46-20676	PUMP-VAR DISPL	MPV-046-C-B-B-K-S-B-J-BA-A-A-BFF-CN-A-HH-B-NNN-***	M46	M46-046PV
M46-20677	PUMP-VAR DISPL	MPV-046-C-B-B-S-B-B-AA-G-A-BHH-DB-A-HH-A-NNN-***	M46	M46-046PV
M46-20678	PUMP-VAR DISPL	MPV-046-C-B-B-A-T-B-B-BA-A-A-BHH-CE-A-GG-C-NNN-***	M46	M46-046PV
M46-20679	PUMP-VAR DISPL	MPV-046-C-B-B-T-B-B-AA-G-A-BHH-DB-A-HH-K-GSP-***	M46	M46-046PV
M46-2068	PUMP-VAR DISPL	MPV-046-C-B-B-H-R-B-A-AA-A-A-BGG-BA-A-GG-A-NNN-***	M46	M46-046PV
M46-20680	PUMP-VAR DISPL	MPV-046-C-B-B-D-T-B-B-BA-A-A-BFF-CB-A-GG-B-NNN-***	M46	M46-046PV
M46-20681	PUMP-VAR DISPL	MPV-046-C-B-B-A-T-B-B-AA-A-A-BFF-CB-A-HH-A-NNN-***	M46	M46-046PV
M46-20682	PUMP-VAR DISPL	MPV-046-C-B-B-T-B-B-AA-A-A-BFF-CB-A-HH-A-NNA-***	M46	M46-046PV
M46-20684	PUMP-VAR DISPL	MPV-046-C-B-A-G-T-B-S-AA-A-B-BJJ-AC-D-FF-C-NNN-***	M46	M46-046PV
M46-20686	PUMP-VAR DISPL	MPV-046-C-B-B-A-S-B-B-AA-A-A-BMM-CB-A-JJ-C-NNN-***	M46	M46-046PV
M46-20687	PUMP-VAR DISPL	MPV-046-C-B-B-T-B-B-BA-G-A-BHH-CE-A-HH-A-NNN-***	M46	M46-046PV
M46-20688	PUMP-VAR DISPL	MPV-046-C-B-B-H-S-B-B-BA-G-A-BCC-CE-A-HH-A-NNN-***	M46	M46-046PV
M46-20689	PUMP-VAR DISPL	MPV-046-C-B-B-K-S-B-B-BA-A-A-BJJ-CE-A-JJ-B-NNN-***	M46	M46-046PV
M46-2069	PUMP-VAR DISPL	MPV-046-C-B-B-K-R-B-A-AA-A-A-BGG-BA-A-GG-B-NNN-***	M46	M46-046PV
M46-20691	PUMP-VAR DISPL	MPV-046-C-B-B-A-T-B-J-BA-A-A-BJJ-CB-A-HH-C-NNN-***	M46	M46-046PV
M46-20692	PUMP-VAR DISPL	MPV-046-C-B-A-V-S-B-B-AA-A-A-BJJ-AB-U-GG-C-NNN-***	M46	M46-046PV
M46-20693	PUMP-VAR DISPL	MPV-046-C-B-A-V-S-B-B-AA-A-A-BJJ-CB-A-GG-C-NNN-***	M46	M46-046PV
M46-20694	PUMP-VAR DISPL	MPV-046-C-B-B-V-S-B-B-AA-A-A-BJJ-CB-A-GG-C-NNN-***	M46	M46-046PV
M46-20695	PUMP-VAR DISPL	MPV-046-C-B-A-B-S-B-B-AA-A-A-BFF-AB-U-BA-A-NNN-***	M46	M46-046PV
M46-20698	PUMP-VAR DISPL	MPV-046-C-B-A-K-T-B-B-BA-A-A-BMM-AB-U-BB-B-NNN-***	M46	M46-046PV
M46-20699	PUMP-VAR DISPL	MPV-046-C-B-B-G-S-B-B-AA-A-A-BHH-CB-A-GG-C-NNN-***	M46	M46-046PV
M46-20700	PUMP-VAR DISPL	MPV-046-C-B-B-J-S-B-M-BA-A-A-BGG-CE-A-HH-3-NNN-***	M46	M46-046PV
M46-20701	PUMP-VAR DISPL	MPV-046-C-B-B-A-S-B-B-BA-G-A-BDD-CD-A-HH-C-NNN-***	M46	M46-046PV
M46-20703	PUMP-VAR DISPL	MPV-046-C-B-B-S-B-B-AA-Z-A-BFF-CE-A-HH-H-NNA-***	M46	M46-046PV
M46-20704	PUMP-VAR DISPL	MPV-046-C-B-B-S-B-B-AA-Z-A-BFF-DA-A-HH-H-NNN-***	M46	M46-046PV
M46-20705	PUMP-VAR DISPL	MPV-046-C-B-B-S-B-B-AA-X-A-BFF-DA-A-HH-H-NNN-***	M46	M46-046PV
M46-20706	PUMP-VAR DISPL	MPV-046-C-B-B-G-S-B-J-AA-A-A-BJJ-CE-A-JJ-1-NNN-***	M46	M46-046PV
M46-20707	PUMP-VAR DISPL	MPV-046-C-B-B-S-A-M-BC-X-A-BJJ-DB-A-HH-A-NNR-***	M46	M46-046PV
M46-20708	PUMP-VAR DISPL	MPV-046-C-B-B-G-T-B-B-AA-G-A-BFF-CD-A-GG-C-NNN-***	M46	M46-046PV
M46-20709	PUMP-VAR DISPL	MPV-046-C-B-B-J-T-B-B-BA-G-A-BDD-BB-A-HH-A-NNN-***	M46	M46-046PV
M46-2071	PUMP-VAR DISPL	MPV-046-C-B-A-H-R-B-A-AA-A-A-BJJ-AB-U-BD-A-NNN-***	M46	M46-046PV
M46-20710	PUMP-VAR DISPL	MPV-046-C-B-B-J-T-B-B-BA-G-A-BGG-BB-A-HH-A-NNN-***	M46	M46-046PV
M46-20711	PUMP-VAR DISPL	MPV-046-C-B-B-K-S-B-B-AA-A-A-BJJ-CB-A-GG-B-NNN-***	M46	M46-046PV

M46-20713	PUMP-VAR DISPL	MPV-046-C-B-A-B-S-B-AA-G-A-BDD-AB-U-FF-A-NNN-***	M46	M46-046PV
M46-20714	PUMP-VAR DISPL	MPV-046-C-B-B-H-T-B-B-AA-A-A-BDD-CB-A-GG-A-NNN-***	M46	M46-046PV
M46-20715	PUMP-VAR DISPL	MPV-046-C-B-A-H-S-B-B-BA-A-A-BJJ-AB-U-DD-A-NNN-***	M46	M46-046PV
M46-20716	PUMP-VAR DISPL	MPV-046-C-B-A-G-T-B-B-AA-A-A-BDD-AB-U-FF-C-NNN-***	M46	M46-046PV
M46-20717	PUMP-VAR DISPL	MPV-046-C-B-B-H-S-A-S-BC-2-A-BFF-DB-A-TT-K-GSR-***	M46	M46-046PV
M46-20718	PUMP-VAR DISPL	MPV-046-C-B-B-H-T-B-B-BA-G-A-BGG-BB-A-HH-A-NNN-***	M46	M46-046PV
M46-20719	PUMP-VAR DISPL	MPV-046-C-B-B-J-S-B-B-AA-A-A-BHH-BA-A-JJ-A-NNN-***	M46	M46-046PV
M46-20720	PUMP-VAR DISPL	MPV-046-C-B-A-K-S-B-B-AA-A-A-BBB-AB-D-ED-B-NNN-***	M46	M46-046PV
M46-20721	PUMP-VAR DISPL	MPV-046-C-B-A-G-S-B-B-AA-A-A-BGG-AB-D-BD-C-NNN-***	M46	M46-046PV
M46-20723	PUMP-VAR DISPL	MPV-046-C-B-B-W-S-B-B-AA-A-A-BJJ-BA-A-GG-A-NNN-***	M46	M46-046PV
M46-20725	PUMP-VAR DISPL	MPV-046-C-B-B-A-T-B-B-BA-G-A-BEE-CE-A-HH-C-NNN-***	M46	M46-046PV
M46-20726	PUMP-VAR-DISPL MPV046	MPV-046-C-B-B-H-S-B-B-AA-A-A-BJJ-BA-A-GG-A-NNN-***	M46	M46-046PV
M46-20727	PUMP-VAR DISPL	MPV-046-C-B-B-A-T-B-B-AA-A-A-BJJ-CB-A-GG-C-NNN-***	M46	M46-046PV
M46-20728	PUMP-VAR DISPL	MPV-046-C-B-A-H-S-B-B-BA-A-A-BJJ-AB-U-AA-A-NNN-***	M46	M46-046PV
M46-20730	PUMP-VAR DISPL	MPV-046-C-B-B-B-S-B-B-AA-Z-A-BJJ-DA-A-HH-H-NNA-***	M46	M46-046PV
M46-20731	PUMP-VAR DISPL	MPV-046-C-B-B-A-S-B-B-BA-A-A-BFF-CB-A-HH-C-NNN-***	M46	M46-046PV
M46-20733	PUMP-VAR DISPL	MPV-046-C-B-B-B-S-B-B-BA-A-A-BEE-DA-A-GG-A-NNN-***	M46	M46-046PV
M46-20734	PUMP-VAR DISPL	MPV-046-C-B-B-B-S-B-J-BA-A-A-BGG-CE-A-HH-A-NNN-***	M46	M46-046PV
M46-20735	PUMP-VAR DISPL	MPV-046-C-B-A-D-T-B-B-AA-A-A-BMM-AB-U-FF-B-NNN-***	M46	M46-046PV
M46-20736	PUMP-VAR DISPL	MPV-046-C-B-A-D-S-B-B-AA-A-A-BMM-AB-U-FF-B-NNN-***	M46	M46-046PV
M46-20737	PUMP-VAR DISPL	MPV-046-C-B-B-D-T-B-B-AA-A-A-BMM-CD-A-GG-B-NNN-***	M46	M46-046PV
M46-20738	PUMP-VAR DISPL	MPV-046-C-B-B-A-T-B-J-BA-V-A-BJJ-CB-A-HH-C-NNN-***	M46	M46-046PV
M46-20739	PUMP-VAR DISPL	MPV-046-C-B-B-J-S-B-J-BA-A-A-BFF-CE-A-HH-3-NNN-***	M46	M46-046PV
M46-20740	PUMP-VAR DISPL	MPV-046-C-B-B-G-S-B-B-AA-A-A-BGG-CE-A-HH-C-NNN-***	M46	M46-046PV
M46-20741	PUMP-VAR DISPL	MPV-046-C-B-B-B-S-B-B-AA-G-A-BHH-DB-A-HH-C-NNN-***	M46	M46-046PV
M46-20742	PUMP-VAR DISPL	MPV-046-C-B-B-A-T-B-J-BA-A-A-BFF-CE-A-JJ-C-NNN-***	M46	M46-046PV
M46-20743	PUMP-VAR DISPL	MPV-046-C-B-A-J-S-B-B-AA-A-A-BJJ-AB-U-AB-A-NNN-***	M46	M46-046PV
M46-20744	PUMP-VAR DISPL	MPV-046-C-B-B-J-S-B-B-AA-V-A-BJJ-CG-A-DS-A-NNN-***	M46	M46-046PV
M46-20746	PUMP-VAR DISPL	MPV-046-C-B-A-B-S-B-B-AA-G-A-BFF-GB-B-EA-A-NNN-***	M46	M46-046PV
M46-20749	PUMP-VAR DISPL	MPV-046-C-B-B-K-S-B-J-BA-A-A-BFF-CE-A-HH-3-NNN-***	M46	M46-046PV
M46-2075	PUMP-VAR DISPL	MPV-046-C-B-A-H-L-B-A-AA-A-A-BJJ-AB-U-ED-A-NNN-***	M46	M46-046PV
M46-20750	PUMP-VAR DISPL	MPV-046-C-B-A-H-S-B-B-BA-A-A-BFF-AB-U-AB-A-NNN-***	M46	M46-046PV
M46-20751	PUMP-VAR DISPL	MPV-046-C-B-B-H-T-B-B-BA-A-A-BFF-CB-A-GG-A-NNN-***	M46	M46-046PV
M46-20752	PUMP-VAR DISPL	MPV-046-C-B-A-J-S-B-B-AA-A-A-BHH-AB-U-ED-A-NNN-***	M46	M46-046PV
M46-20754	PUMP-VAR DISPL	MPV-046-C-B-A-J-S-B-B-AA-A-A-BFF-GB-B-LA-A-NNN-***	M46	M46-046PV
M46-20755	PUMP-VAR DISPL	MPV-046-C-B-A-K-S-B-B-AA-A-A-BHH-AB-U-BD-B-NNN-***	M46	M46-046PV

M46-20756	PUMP-VAR DISPL	MPV-046-C-B-B-S-B-B-AA-A-A-BBB-CE-A-HH-A-NNN-***	M46	M46-046PV
M46-20757	PUMP-VAR DISPL	MPV-046-C-B-B-H-S-B-B-AA-A-A-BEE-CE-A-GG-C-NNN-***	M46	M46-046PV
M46-20758	PUMP-VAR-DISPL MPV046	MPV-046-C-B-A-K-S-B-J-BA-A-A-BJJ-AB-U-AB-B-NNN-***	M46	M46-046PV
M46-20759	PUMP-VAR DISPL	MPV-046-C-B-A-K-S-B-J-AA-A-A-BRF-AB-U-AA-B-NNR-***	M46	M46-046PV
M46-20760	PUMP-VAR DISPL	MPV-046-C-B-B-A-T-B-B-BA-A-A-BJJ-CE-A-GG-C-NNN-***	M46	M46-046PV
M46-20762	PUMP-VAR DISPL	MPV-046-C-B-B-T-B-B-BA-A-A-BHH-CE-A-HH-C-NNN-***	M46	M46-046PV
M46-20763	PUMP-VAR DISPL	MPV-046-C-B-B-H-S-B-B-AA-A-A-BJJ-CE-A-HH-H-NNN-***	M46	M46-046PV
M46-20765	PUMP-VAR DISPL	MPV-046-C-B-B-G-T-B-J-BA-A-A-BJJ-CE-A-JJ-C-NNN-***	M46	M46-046PV
M46-20766	PUMP-VAR DISPL	MPV-046-C-B-B-K-T-B-J-BA-A-A-BJJ-CE-A-JJ-A-NNN-***	M46	M46-046PV
M46-20767	PUMP-VAR DISPL	MPV-046-C-B-A-H-T-B-B-AA-V-A-BDD-DA-A-TT-A-NNN-***	M46	M46-046PV
M46-20768	PUMP-VAR DISPL	MPV-046-C-B-B-Q-T-B-B-BA-A-A-BJG-CE-A-JJ-A-NNN-***	M46	M46-046PV
M46-20769	PUMP-VAR DISPL	MPV-046-C-B-B-K-T-B-B-BA-G-A-BJJ-CB-A-RR-B-NNN-***	M46	M46-046PV
M46-20770	PUMP-VAR DISPL	MPV-046-C-B-B-T-B-B-BA-G-A-BJJ-CB-A-RR-A-NNN-***	M46	M46-046PV
M46-20771	PUMP-VAR DISPL	MPV-046-C-B-B-T-B-B-BA-G-A-BFF-CB-A-GG-A-NNN-***	M46	M46-046PV
M46-20772	PUMP-VAR-DISPL MPV046	MPV-046-C-B-B-J-S-B-B-AA-G-A-BJJ-CG-A-DS-A-NNN-***	M46	M46-046PV
M46-20773	PUMP-VAR DISPL	MPV-046-C-B-A-V-S-B-B-AA-A-A-BFF-AB-U-BB-C-NNN-***	M46	M46-046PV
M46-20775	PUMP-VAR DISPL	MPV-046-C-B-A-B-T-B-B-AA-A-A-BFF-AB-U-AA-B-NNN-***	M46	M46-046PV
M46-20776	PUMP-VAR DISPL	MPV-046-C-B-B-K-T-B-B-BA-G-A-BMM-CE-A-HH-B-NNN-***	M46	M46-046PV
M46-20777	PUMP-VAR-DISPL MPV046	MPV-046-C-B-B-H-S-B-B-AA-G-A-BDD-CD-A-ZG-A-NNN-***	M46	M46-046PV
M46-20779	PUMP-VAR DISPL	MPV-046-C-B-B-J-S-B-S-BA-T-A-BGG-CP-A-HH-A-NNN-***	M46	M46-046PV
M46-20780	PUMP-VAR DISPL	MPV-046-C-B-B-G-T-B-B-AA-G-A-BHH-DB-A-HH-C-NNN-***	M46	M46-046PV
M46-20782	PUMP-VAR DISPL	MPV-046-C-B-B-K-T-B-J-AA-A-A-BJJ-DA-A-HH-B-NNN-***	M46	M46-046PV
M46-20783	PUMP-VAR-DISPL MPV046	MPV-046-C-B-B-H-S-B-B-AA-A-A-BJJ-CD-A-GG-A-NNN-***	M46	M46-046PV
M46-20784	PUMP-VAR DISPL	MPV-046-C-B-B-S-B-B-BA-A-A-BFF-CE-A-GG-A-NNN-***	M46	M46-046PV
M46-20785	PUMP-VAR DISPL	MPV-046-C-B-A-H-T-B-J-AA-A-A-BMM-AB-U-DD-A-NNN-***	M46	M46-046PV
M46-20787	PUMP-VAR DISPL	MPV-046-C-B-B-S-B-B-BA-Z-A-BJJ-DA-A-HH-H-NNA-***	M46	M46-046PV
M46-20788	PUMP-VAR-DISPL MPV046	MPV-046-C-B-A-J-S-B-B-AA-A-A-BFD-GB-B-AA-A-NNN-***	M46	M46-046PV
M46-20789	PUMP-VAR DISPL	MPV-046-C-B-B-H-T-B-J-BA-A-A-BJJ-CE-A-JJ-A-NNN-***	M46	M46-046PV
M46-2079	PUMP-VAR DISPL	MPV-046-C-B-A-H-R-B-A-AA-A-A-BHH-AB-U-BA-A-NNN-***	M46	M46-046PV
M46-20790	PUMP-VAR DISPL	MPV-046-C-B-A-A-S-B-B-AA-G-A-BBB-AB-U-ED-C-NNN-***	M46	M46-046PV
M46-20791	PUMP-VAR DISPL	MPV-046-C-B-B-H-S-B-J-BA-A-A-BHH-CE-A-GG-A-NNN-***	M46	M46-046PV
M46-20793	PUMP-VAR DISPL	MPV-046-C-B-B-V-S-B-J-BA-G-A-BFF-CD-A-HH-A-NNN-***	M46	M46-046PV
M46-20794	PUMP-VAR DISPL	MPV-046-C-B-B-A-S-B-J-BA-G-A-BFF-CD-A-HH-C-NNN-***	M46	M46-046PV
M46-20795	PUMP-VAR DISPL	MPV-046-C-B-B-T-B-J-AA-A-A-BHH-DA-A-HH-C-NNN-***	M46	M46-046PV
M46-20796	PUMP-VAR DISPL	MPV-046-C-B-A-H-S-B-B-BA-G-A-BMJ-AB-U-BB-A-NNN-***	M46	M46-046PV
M46-20797	PUMP-VAR DISPL	MPV-046-C-B-A-G-T-B-B-BA-A-A-BDD-AB-U-FF-C-NNN-***	M46	M46-046PV

M46-20798	PUMP-VAR DISPL	MPV-046-C-B-A-H-T-B-B-AA-A-A-BHH-AB-U-BB-A-NNN-***	M46	M46-046PV
M46-20801	PUMP-VAR-DISPL MPV046	MPV-046-C-B-A-J-S-B-B-AA-G-A-BJJ-AB-U-AB-A-NNN-***	M46	M46-046PV
M46-20802	PUMP-VAR DISPL	MPV-046-C-B-B-K-S-B-B-BA-G-A-BDD-CE-A-HH-B-NNN-***	M46	M46-046PV
M46-20803	PUMP-VAR DISPL	MPV-046-C-B-B-B-T-B-B-AA-G-A-BJJ-DA-A-HH-K-GSA-***	M46	M46-046PV
M46-20807	PUMP-VAR DISPL	MPV-046-C-B-A-A-S-B-B-AA-A-A-BDD-AB-U-AA-C-NNN-***	M46	M46-046PV
M46-20808	PUMP-VAR-DISPL MPV046	MPV-046-C-B-B-K-S-B-B-AA-A-A-BJJ-CG-A-GG-B-NNN-***	M46	M46-046PV
M46-20809	PUMP-VAR DISPL	MPV-046-C-B-B-K-T-B-B-AA-A-A-BFF-CE-A-GG-B-NNN-***	M46	M46-046PV
M46-20810	PUMP-VAR DISPL	MPV-046-C-B-B-A-T-B-J-AA-G-A-BHH-DA-A-HH-C-NNN-***	M46	M46-046PV
M46-20811	PUMP-VAR DISPL	MPV-046-C-B-A-H-T-B-B-AA-A-A-BGG-DA-A-SS-A-NNN-***	M46	M46-046PV
M46-20812	PUMP-VAR DISPL	MPV-046-C-B-A-Y-T-B-S-AA-A-A-BJJ-GG-B-MF-3-NNR-***	M46	M46-046PV
M46-20814	PUMP-VAR-DISPL MPV046	MPV-046-C-B-B-G-S-B-S-BA-G-A-BJJ-DA-A-ZA-C-NNN-***	M46	M46-046PV
M46-20816	PUMP-VAR DISPL	MPV-046-C-B-A-H-T-B-B-BA-G-A-BMJ-AB-U-BB-A-NNN-***	M46	M46-046PV
M46-20817	PUMP-VAR DISPL	MPV-046-C-B-B-H-T-B-B-BA-G-A-BBB-BB-A-HH-A-NNN-***	M46	M46-046PV
M46-20820	PUMP-VAR DISPL	MPV-046-C-B-B-H-S-B-M-BA-A-A-BFF-CE-A-HH-3-NNN-***	M46	M46-046PV
M46-20821	PUMP-VAR DISPL	MPV-046-C-B-B-K-T-B-B-AA-G-A-BDD-CE-A-GG-B-NNN-***	M46	M46-046PV
M46-20822	PUMP-VAR-DISPL MPV046	MPV-046-C-B-B-H-S-B-J-AA-G-A-BJJ-DA-A-ZG-A-NNN-***	M46	M46-046PV
M46-20824	PUMP-VAR DISPL	MPV-046-C-B-B-G-T-B-J-AA-G-A-BHH-DB-A-HH-C-NNN-***	M46	M46-046PV
M46-20825	PUMP-VAR DISPL	MPV-046-C-B-B-S-B-B-AA-G-A-BHH-DA-A-HH-A-NNN-***	M46	M46-046PV
M46-20826	PUMP-VAR DISPL	MPV-046-C-B-A-G-T-B-S-AA-A-A-BJJ-GG-B-KF-C-NNR-***	M46	M46-046PV
M46-20827	PUMP-VAR DISPL	MPV-046-C-B-A-Z-T-B-S-AA-A-A-BJJ-GG-B-KF-C-NNR-***	M46	M46-046PV
M46-20828	PUMP-VAR DISPL	MPV-046-C-B-B-K-S-B-J-AA-A-A-BDD-DA-A-ZA-B-NNN-***	M46	M46-046PV
M46-20829	PUMP-VAR-DISPL MPV046	MPV-046-C-B-B-K-S-B-B-AA-J-A-BRR-DA-A-GG-B-NNN-***	M46	M46-046PV
M46-2083	PUMP-VAR DISPL	MPV-046-C-B-A-A-L-B-A-BA-A-A-BJJ-AB-U-ED-C-NNN-***	M46	M46-046PV
M46-20830	PUMP-VAR-DISPL MPV046	MPV-046-C-B-B-H-S-B-B-AA-J-A-BHH-DA-A-ZG-A-NNN-***	M46	M46-046PV
M46-20831	PUMP-VAR DISPL	MPV-046-C-B-A-B-S-B-B-BA-A-A-BJJ-AB-U-AA-A-NNN-***	M46	M46-046PV
M46-20832	PUMP-VAR DISPL	MPV-046-C-B-B-A-S-B-B-BA-A-A-BGG-CD-A-RR-C-NNN-***	M46	M46-046PV
M46-20833	PUMP-VAR DISPL	MPV-046-C-B-A-K-S-B-B-AA-B-A-BFF-AB-U-BD-B-NNN-***	M46	M46-046PV
M46-20834	PUMP-VAR DISPL	MPV-046-C-B-B-K-S-B-B-BA-J-A-BJJ-DA-A-ZF-B-NNN-***	M46	M46-046PV
M46-20837	PUMP-VAR-DISPL MPV046	MPV-046-C-B-B-A-R-B-A-AA-G-A-BHH-DA-A-ZH-C-NNN-***	M46	M46-046PV
M46-20838	PUMP-VAR DISPL	MPV-046-C-B-B-A-T-B-B-AA-R-A-BFF-CB-A-HH-C-NNA-***	M46	M46-046PV
M46-20840	PUMP-VAR-DISPL MPV046	MPV-046-C-B-B-H-S-B-B-AA-G-A-BJJ-CD-A-YC-A-NNN-***	M46	M46-046PV
M46-20841	PUMP-VAR-DISPL MPV046	MPV-046-C-B-B-S-B-B-AA-A-A-BJF-CD-A-GG-A-NNN-***	M46	M46-046PV
M46-20842	PUMP-VAR-DISPL MPV046	MPV-046-C-B-B-A-S-B-B-AA-D-A-BHH-DA-A-WB-C-NNN-***	M46	M46-046PV
M46-20844	PUMP-VAR DISPL	MPV-046-C-B-B-H-S-B-J-BA-A-A-BFF-CE-A-HH-2-GRN-***	M46	M46-046PV
M46-20846	PUMP-VAR DISPL	MPV-046-C-B-B-A-S-B-B-BA-X-A-BFF-DA-A-HH-C-NNN-***	M46	M46-046PV
M46-20847	PUMP-VAR DISPL	MPV-046-C-B-B-K-S-B-B-AA-G-A-BDD-CE-A-GG-B-NNN-***	M46	M46-046PV

M46-20848	PUMP-VAR DISPL	MPV-046-C-B-A-K-S-B-B-AA-A-A-BDD-AB-U-DD-B-NNN-***	M46	M46-046PV
M46-20851	PUMP-VAR DISPL	MPV-046-C-B-B-H-S-B-B-AA-3-A-BFF-DA-A-RR-A-NNN-***	M46	M46-046PV
M46-20853	PUMP-VAR-DISPL MPV046	MPV-046-C-B-A-A-T-B-B-AA-G-A-BFF-AB-U-ZK-C-NNN-***	M46	M46-046PV
M46-20854	PUMP-VAR DISPL	MPV-046-C-B-B-K-T-B-B-AA-A-A-BCC-CB-A-GG-B-NNN-***	M46	M46-046PV
M46-20855	PUMP-VAR DISPL	MPV-046-C-B-B-D-S-B-J-BA-A-A-BJJ-BA-A-GG-B-NNN-***	M46	M46-046PV
M46-20856	PUMP-VAR DISPL	MPV-046-C-B-B-K-S-B-J-BA-A-A-BJJ-BA-A-GG-B-NNN-***	M46	M46-046PV
M46-20857	PUMP-VAR DISPL	MPV-046-C-B-B-G-S-B-B-AA-A-A-BJJ-CG-A-GG-C-NNN-***	M46	M46-046PV
M46-20858	PUMP-VAR DISPL	MPV-046-C-B-B-H-S-B-B-AA-A-A-BHH-CE-A-JJ-A-NNN-***	M46	M46-046PV
M46-20859	PUMP-VAR DISPL	MPV-046-C-B-A-G-S-B-B-AA-A-A-BFF-AB-U-BB-C-NNN-***	M46	M46-046PV
M46-2086	PUMP-VAR DISPL	MPV-046-C-B-A-H-R-B-A-AA-A-A-BDD-AB-U-FD-A-NNN-***	M46	M46-046PV
M46-20860	PUMP-VAR DISPL	MPV-046-C-B-B-J-S-A-J-BC-V-A-BHH-DB-A-TT-A-NNN-***	M46	M46-046PV
M46-20861	PUMP-VAR DISPL	MPV-046-C-B-B-V-S-B-B-AA-A-A-BDD-CD-A-JJ-C-NNN-***	M46	M46-046PV
M46-20862	PUMP-VAR-DISPL MPV046	MPV-046-C-B-B-S-B-B-BA-A-A-BCC-CH-A-HH-A-NNN-***	M46	M46-046PV
M46-20863	PUMP-VAR DISPL	MPV-046-C-B-B-K-S-B-J-BA-A-A-BFF-CE-A-HH-3-NBN-***	M46	M46-046PV
M46-20864	PUMP-VAR DISPL	MPV-046-C-B-B-K-S-B-M-BA-A-A-BFF-CE-A-VV-B-NNN-***	M46	M46-046PV
M46-20865	PUMP-VAR DISPL	MPV-046-C-B-B-D-T-B-J-BA-V-A-BJJ-CB-A-HH-B-NNN-***	M46	M46-046PV
M46-20866	PUMP-VAR DISPL	MPV-046-C-B-B-K-S-B-M-BA-A-A-BFF-CE-A-HH-B-NNN-***	M46	M46-046PV
M46-20867	PUMP-VAR DISPL	MPV-046-C-B-A-B-S-B-B-AA-A-A-BHH-AB-U-AA-A-NNN-***	M46	M46-046PV
M46-20868	PUMP-VAR-DISPL MPV046	MPV-046-C-B-B-H-S-B-B-BA-J-A-BJJ-DA-A-GG-A-NNN-***	M46	M46-046PV
M46-20869	PUMP-VAR DISPL	MPV-046-C-B-B-K-S-B-B-AA-G-A-BEE-CG-A-GG-B-NNN-***	M46	M46-046PV
M46-2087	PUMP-VAR DISPL	MPV-046-C-B-A-H-L-B-A-AA-A-A-BDD-AB-U-ED-A-NNN-***	M46	M46-046PV
M46-20870	PUMP-VAR DISPL	MPV-046-C-B-B-D-S-B-J-AA-A-A-BFF-CB-A-GG-B-NNN-***	M46	M46-046PV
M46-20871	PUMP-VAR DISPL	MPV-046-C-B-B-H-S-B-M-BA-A-A-BGG-CE-A-SS-3-NNN-***	M46	M46-046PV
M46-20872	PUMP-VAR DISPL	MPV-046-C-B-B-S-B-B-BA-A-A-BEE-CB-A-HH-A-NNN-***	M46	M46-046PV
M46-20874	PUMP-VAR DISPL	MPV-046-C-B-B-J-S-B-J-BA-A-A-BFF-CE-A-HH-2-GTA-***	M46	M46-046PV
M46-20875	PUMP-VAR DISPL	MPV-046-C-B-B-K-S-B-J-BA-A-A-BFF-CE-A-HH-2-GDN-***	M46	M46-046PV
M46-20879	PUMP-VAR-DISPL MPV046	MPV-046-C-B-B-H-S-B-B-AA-G-A-BGG-CD-A-JJ-A-NNN-***	M46	M46-046PV
M46-20880	PUMP-VAR-DISPL MPV046	MPV-046-C-B-A-K-T-B-B-AA-G-A-BHH-AB-U-ZK-B-NNN-***	M46	M46-046PV
M46-20881	PUMP-VAR DISPL	MPV-046-C-B-B-S-B-B-J-AA-A-A-BEE-CE-A-HH-A-NNN-***	M46	M46-046PV
M46-20882	PUMP-VAR DISPL	MPV-046-C-B-B-S-B-B-AA-A-A-BJJ-CG-A-GG-A-NNN-***	M46	M46-046PV
M46-20883	PUMP-VAR DISPL	MPV-046-C-B-B-A-S-B-B-AA-X-A-BHH-DA-A-SS-C-NNN-***	M46	M46-046PV
M46-20885	PUMP-VAR DISPL	MPV-046-C-B-B-H-S-B-B-AA-A-A-BGG-CE-A-HH-A-NNN-***	M46	M46-046PV
M46-20886	PUMP-VAR DISPL	MPV-046-C-B-B-D-T-B-B-BA-T-A-BMM-CB-A-GG-B-NNN-***	M46	M46-046PV
M46-20887	PUMP-VAR DISPL	MPV-046-C-B-B-S-B-B-J-AA-A-A-BJJ-BA-A-HH-A-NNN-***	M46	M46-046PV
M46-20888	PUMP-VAR DISPL	MPV-046-C-B-B-D-T-A-B-BC-A-A-BHH-CN-A-GG-B-NNN-***	M46	M46-046PV
M46-20889	PUMP-VAR DISPL	MPV-046-C-B-B-A-T-A-B-BC-A-A-BDD-CN-A-GG-C-NNN-***	M46	M46-046PV

M46-20891	PUMP-VAR DISPL	MPV-046-C-B-B-J-S-B-B-AA-A-A-BFD-CB-A-RR-A-NNN-***	M46	M46-046PV
M46-20892	PUMP-VAR DISPL	MPV-046-C-B-B-G-T-B-B-BA-A-A-BHH-CD-A-GG-C-NNN-***	M46	M46-046PV
M46-20893	PUMP-VAR-DISPL MPV046	MPV-046-C-B-B-A-S-B-B-AA-1-A-BHH-DA-A-ZH-C-NNN-***	M46	M46-046PV
M46-20894	PUMP-VAR-DISPL MPV046	MPV-046-C-B-B-H-S-B-B-BA-J-A-BJJ-DA-A-HH-A-NNN-***	M46	M46-046PV
M46-20895	PUMP-VAR DISPL	MPV-046-C-B-B-G-S-B-J-BA-V-A-BDD-DB-A-TT-C-NNN-***	M46	M46-046PV
M46-20897	PUMP-VAR DISPL	MPV-046-C-B-B-T-B-B-AA-A-A-BBB-CB-A-GG-A-NNN-***	M46	M46-046PV
M46-20898	PUMP-VAR DISPL	MPV-046-C-B-A-X-S-B-B-AA-A-A-BDD-AB-U-AA-B-NNN-***	M46	M46-046PV
M46-20899	PUMP-VAR DISPL	MPV-046-C-B-A-G-S-B-B-AA-A-A-BEE-AB-U-AA-C-NNN-***	M46	M46-046PV
M46-20900	PUMP-VAR DISPL	MPV-046-C-B-B-D-T-A-B-BC-A-A-BHH-CH-A-GG-B-NNN-***	M46	M46-046PV
M46-20901	PUMP-VAR DISPL	MPV-046-C-B-B-A-T-A-B-BC-A-A-BDD-CH-A-GG-C-NNN-***	M46	M46-046PV
M46-20902	PUMP-VAR DISPL	MPV-046-C-B-A-K-T-B-B-BA-A-A-BMJ-AB-U-BB-B-NNN-***	M46	M46-046PV
M46-20903	PUMP-VAR DISPL	MPV-046-C-B-B-S-B-B-AA-G-A-BJJ-BB-A-HH-A-NNN-***	M46	M46-046PV
M46-20904	PUMP-VAR DISPL	MPV-046-C-B-B-K-S-B-B-AA-G-A-BJJ-BB-A-HH-B-NNN-***	M46	M46-046PV
M46-20905	PUMP-VAR DISPL	MPV-046-C-B-A-J-S-B-B-AA-A-A-BJJ-AC-D-FD-A-NNN-***	M46	M46-046PV
M46-20906	PUMP-VAR DISPL	MPV-046-C-B-A-D-S-B-B-BA-A-A-BBB-AB-U-AA-B-NNN-***	M46	M46-046PV
M46-20908	PUMP-VAR DISPL	MPV-046-C-B-A-H-T-B-J-AA-A-A-BJJ-AB-U-ED-A-NNN-***	M46	M46-046PV
M46-2091	PUMP-VAR DISPL	MPV-046-C-B-B-L-B-A-BA-A-A-BEE-BA-A-GG-A-NNN-***	M46	M46-046PV
M46-20910	PUMP-VAR DISPL	MPV-046-C-B-B-D-S-B-B-BA-A-A-BFF-CE-A-HH-B-NNN-***	M46	M46-046PV
M46-20911	PUMP-VAR-DISPL MPV046	MPV-046-C-B-B-S-B-S-AA-A-C-BHH-CD-A-GG-A-NNN-***	M46	M46-046PV
M46-20912	PUMP-VAR DISPL	MPV-046-C-B-A-C-S-B-B-AA-A-A-BFF-GB-B-LA-A-NNG-***	M46	M46-046PV
M46-20913	PUMP-VAR-DISPL MPV046	MPV-046-C-B-B-H-S-B-B-AA-G-A-BJJ-BB-A-HH-A-NNN-***	M46	M46-046PV
M46-20914	PUMP-VAR DISPL	MPV-046-C-B-A-A-T-B-B-AA-A-A-BEE-AB-U-BA-C-NNN-***	M46	M46-046PV
M46-20916	PUMP-VAR DISPL	MPV-046-C-B-A-J-S-B-J-AA-A-A-BHH-AB-U-ZR-A-NNN-***	M46	M46-046PV
M46-20917	PUMP-VAR-DISPL MPV046	MPV-046-C-B-B-H-S-A-B-BC-J-A-BHH-DA-A-ZA-A-NNN-***	M46	M46-046PV
M46-20918	PUMP-VAR DISPL	MPV-046-C-B-B-V-S-B-B-AA-A-A-BDD-CE-A-GG-C-NNN-***	M46	M46-046PV
M46-20919	PUMP-VAR DISPL	MPV-046-C-B-A-K-S-B-B-BA-A-A-BBB-AB-U-FF-B-NNN-***	M46	M46-046PV
M46-20920	PUMP-VAR DISPL	MPV-046-C-B-B-G-S-B-S-BA-J-A-BRR-DA-A-HH-C-NNR-***	M46	M46-046PV
M46-20921	PUMP-VAR DISPL	MPV-046-C-B-A-C-S-B-B-AA-A-A-BFF-GB-B-AD-A-NNG-***	M46	M46-046PV
M46-20922	PUMP-VAR DISPL	MPV-046-C-B-A-K-S-B-B-BA-G-A-BMJ-AB-U-BB-B-NNN-***	M46	M46-046PV
M46-20923	PUMP-VAR DISPL	MPV-046-C-B-A-K-T-B-B-BA-G-A-BMJ-AB-U-BB-B-NNN-***	M46	M46-046PV
M46-20924	PUMP-VAR-DISPL MPV046	MPV-046-C-B-B-K-S-B-U-BA-W-A-BJJ-DA-A-ZG-B-NNN-***	M46	M46-046PV
M46-20926	PUMP-VAR DISPL	MPV-046-C-B-A-G-S-B-B-AA-A-A-BCC-AB-U-FF-C-NNN-***	M46	M46-046PV
M46-20927	PUMP-VAR DISPL	MPV-046-C-B-B-K-T-B-B-AA-A-A-BJJ-BA-A-HH-B-NNN-***	M46	M46-046PV
M46-20928	PUMP-VAR DISPL	MPV-046-C-B-B-A-T-B-B-BA-A-A-BGG-CE-A-GG-C-NNN-***	M46	M46-046PV
M46-20930	PUMP-VAR DISPL	MPV-046-C-B-A-D-S-B-J-BA-A-A-BHH-AB-U-BB-B-NNN-***	M46	M46-046PV
M46-20931	PUMP-VAR DISPL	MPV-046-C-B-A-K-S-B-B-AA-A-A-BDD-AB-U-CB-B-NNN-***	M46	M46-046PV

M46-20932	PUMP-VAR DISPL	MPV-046-C-B-A-D-S-B-B-AA-A-A-BDD-AB-U-AA-B-NNN-***	M46	M46-046PV
M46-20933	PUMP-VAR-DISPL MPV046	MPV-046-C-B-B-G-S-B-B-AA-J-A-BFF-DA-A-RR-C-NNN-***	M46	M46-046PV
M46-20934	PUMP-VAR-DISPL MPV046	MPV-046-C-B-B-S-B-B-J-AA-A-A-BJJ-CD-A-GG-A-NNN-***	M46	M46-046PV
M46-20936	PUMP-VAR DISPL	MPV-046-C-B-B-A-T-B-B-BA-V-A-BHH-DA-A-GG-C-NNN-***	M46	M46-046PV
M46-20938	PUMP-VAR DISPL	MPV-046-C-B-A-H-S-B-B-AA-A-A-BFF-AB-U-DD-A-NNN-***	M46	M46-046PV
M46-20939	PUMP-VAR-DISPL MPV046	MPV-046-C-B-B-H-S-A-B-BC-J-A-BJJ-DA-A-ZA-A-NNN-***	M46	M46-046PV
M46-20940	PUMP-VAR DISPL	MPV-046-C-B-B-D-T-B-J-BA-V-A-BDD-CB-A-HH-B-NNN-***	M46	M46-046PV
M46-20941	PUMP-VAR DISPL	MPV-046-C-B-A-V-S-B-B-AA-G-A-BBB-AB-U-CD-C-NNN-***	M46	M46-046PV
M46-20942	PUMP-VAR-DISPL MPV046	MPV-046-C-B-B-H-S-B-J-AA-J-A-BJJ-DA-A-YA-A-NNR-***	M46	M46-046PV
M46-20943	PUMP-VAR DISPL	MPV-046-C-B-B-K-S-B-J-AA-D-A-BDD-DA-A-ZA-B-NNN-***	M46	M46-046PV
M46-20944	PUMP-VAR DISPL	MPV-046-C-B-A-H-S-B-J-AA-A-A-BDD-AB-U-YE-A-NNN-***	M46	M46-046PV
M46-20945	PUMP-VAR DISPL	MPV-046-C-B-B-H-T-B-B-AA-G-A-BHH-CB-A-RR-A-NNN-***	M46	M46-046PV
M46-20946	PUMP-VAR DISPL	MPV-046-C-B-A-J-S-B-B-AA-A-A-BHH-AB-U-BD-A-NNN-***	M46	M46-046PV
M46-20947	PUMP-VAR DISPL	MPV-046-C-B-A-H-S-B-J-AA-A-A-BFF-AB-U-ZT-A-NNN-***	M46	M46-046PV
M46-20948	PUMP-VAR-DISPL MPV046	MPV-046-C-B-B-H-S-B-U-BA-W-A-BJJ-DA-A-ZG-A-NNN-***	M46	M46-046PV
M46-20949	PUMP-VAR-DISPL MPV046	MPV-046-C-B-A-H-S-B-B-AA-G-A-BJJ-GA-B-AA-A-NNN-***	M46	M46-046PV
M46-20950	PUMP-VAR-DISPL MPV046	MPV-046-C-B-B-H-S-B-U-BA-A-A-BJJ-DA-A-ZG-A-NNN-***	M46	M46-046PV
M46-20951	PUMP-VAR DISPL	MPV-046-C-B-B-D-T-B-B-BA-A-A-BBB-CB-A-GG-B-NNN-***	M46	M46-046PV
M46-20952	PUMP-VAR DISPL	MPV-046-C-B-B-K-T-B-J-BA-A-A-BGG-DB-A-HH-B-NNN-***	M46	M46-046PV
M46-20953	PUMP-VAR DISPL	MPV-046-C-B-B-K-S-A-T-BC-G-A-BEE-BA-A-HH-B-NNN-***	M46	M46-046PV
M46-20955	PUMP-VAR-DISPL MPV046	MPV-046-C-B-B-J-S-B-B-AA-G-A-BJJ-CG-A-DT-A-NNN-***	M46	M46-046PV
M46-20956	PUMP-VAR DISPL	MPV-046-C-B-A-H-S-B-J-AA-A-A-BDD-AB-U-YF-A-NNN-***	M46	M46-046PV
M46-20957	PUMP-VAR DISPL	MPV-046-C-B-A-B-S-B-B-BA-A-A-BFF-AB-U-DA-A-NNN-***	M46	M46-046PV
M46-20958	PUMP-VAR DISPL	MPV-046-C-B-A-H-S-B-J-AA-A-A-BFF-AB-U-YF-A-NNN-***	M46	M46-046PV
M46-20959	PUMP-VAR DISPL	MPV-046-C-B-A-G-T-B-B-AA-A-A-BGG-AB-U-ED-C-NNN-***	M46	M46-046PV
M46-20960	PUMP-VAR DISPL	MPV-046-C-B-A-V-T-B-B-AA-A-A-BDD-AB-U-BD-C-NNN-***	M46	M46-046PV
M46-20961	PUMP-VAR DISPL	MPV-046-C-B-B-K-T-B-B-BA-G-A-BDD-CE-A-HH-B-NNN-***	M46	M46-046PV
M46-20962	PUMP-VAR DISPL	MPV-046-C-B-B-K-S-A-J-BC-V-A-BFF-DB-A-TT-B-NNN-***	M46	M46-046PV
M46-20963	PUMP-VAR-DISPL MPV046	MPV-046-C-B-B-K-S-B-J-AA-A-A-BJF-DB-A-TT-B-NNR-***	M46	M46-046PV
M46-20965	PUMP-VAR DISPL	MPV-046-C-B-A-B-S-B-B-AA-A-A-BGG-AB-U-DD-A-NNN-***	M46	M46-046PV
M46-20966	PUMP-VAR DISPL	MPV-046-C-B-B-A-S-B-B-AA-A-A-BJJ-CB-A-GG-C-NNN-***	M46	M46-046PV
M46-20967	PUMP-VAR DISPL	MPV-046-C-B-B-K-S-B-J-BA-A-A-BJJ-CE-A-HH-B-NNN-***	M46	M46-046PV
M46-20968	PUMP-VAR DISPL	MPV-046-C-B-A-J-S-B-B-AA-A-A-BFD-AB-U-AD-A-NNN-***	M46	M46-046PV
M46-20969	PUMP-VAR DISPL	MPV-046-C-B-B-K-S-B-B-AA-A-A-BJJ-BA-A-HH-B-NNN-***	M46	M46-046PV
M46-20970	PUMP-VAR DISPL	MPV-046-C-B-B-A-S-B-B-AA-A-A-BJJ-CN-A-GG-C-NNN-***	M46	M46-046PV
M46-20971	PUMP-VAR DISPL	MPV-046-C-B-B-A-S-B-B-BA-A-A-BHH-CB-A-HH-C-NNN-***	M46	M46-046PV

M46-20972	PUMP-VAR DISPL	MPV-046-C-B-B-K-S-B-J-AA-V-A-BHH-CG-A-GG-B-NNN-***	M46	M46-046PV
M46-20973	PUMP-VAR DISPL	MPV-046-C-B-B-A-S-B-B-BA-A-A-BJJ-CN-A-GG-C-NNN-***	M46	M46-046PV
M46-20974	PUMP-VAR DISPL	MPV-046-C-B-B-G-T-B-J-AA-A-A-BFF-CE-A-HH-C-NNN-***	M46	M46-046PV
M46-20975	PUMP-VAR DISPL	MPV-046-C-B-B-K-S-B-B-AA-A-A-BJJ-CE-A-GG-B-NNN-***	M46	M46-046PV
M46-20976	PUMP-VAR DISPL	MPV-046-C-B-A-A-T-B-B-BA-V-A-BDD-AB-D-AA-C-NNN-***	M46	M46-046PV
M46-20978	PUMP-VAR DISPL	MPV-046-C-B-A-H-S-B-B-BA-A-A-BGB-AB-U-FA-A-NNN-***	M46	M46-046PV
M46-20980	PUMP-VAR DISPL	MPV-046-C-B-B-S-B-J-AA-A-A-BJF-CG-A-GG-A-NNN-***	M46	M46-046PV
M46-20981	PUMP-VAR DISPL	MPV-046-C-B-A-K-S-B-B-AA-A-A-BJJ-AB-U-ED-B-NNN-***	M46	M46-046PV
M46-20982	PUMP-VAR DISPL	MPV-046-C-B-A-K-S-B-B-BA-A-A-BJJ-AB-U-DD-B-NNN-***	M46	M46-046PV
M46-20984	PUMP-VAR DISPL	MPV-046-C-B-B-H-S-B-U-BA-A-B-BJJ-DA-A-ZG-A-NNN-***	M46	M46-046PV
M46-20985	PUMP-VAR DISPL	MPV-046-C-B-B-K-S-B-U-BA-W-B-BJJ-DA-A-ZG-B-NNN-***	M46	M46-046PV
M46-20986	PUMP-VAR DISPL	MPV-046-C-B-B-H-S-B-U-BA-W-B-BJJ-DA-A-ZG-A-NNN-***	M46	M46-046PV
M46-20987	PUMP-VAR DISPL	MPV-046-C-B-B-G-T-B-B-AA-A-A-BGG-CD-A-GG-C-NNN-***	M46	M46-046PV
M46-20988	PUMP-VAR DISPL	MPV-046-C-B-B-G-T-B-B-AA-A-A-BFF-CD-A-GG-C-NNN-***	M46	M46-046PV
M46-20990	PUMP-VAR DISPL	MPV-046-C-B-B-H-S-A-B-BC-A-A-BJJ-CE-A-GG-A-NNN-***	M46	M46-046PV
M46-20991	PUMP-VAR DISPL	MPV-046-C-B-B-K-T-B-B-AA-A-A-BJJ-CE-A-GG-B-NNN-***	M46	M46-046PV
M46-20992	PUMP-VAR DISPL	MPV-046-C-B-B-T-B-B-AA-G-A-BHH-CB-A-GG-A-NNN-***	M46	M46-046PV
M46-20993	PUMP-VAR DISPL	MPV-046-C-B-B-K-T-B-J-BA-A-A-BGG-CE-A-HH-B-NNN-***	M46	M46-046PV
M46-20994	PUMP-VAR DISPL	MPV-046-C-B-B-T-B-B-BA-G-A-BHH-CB-A-GG-A-NNN-***	M46	M46-046PV
M46-20995	PUMP-VAR DISPL	MPV-046-C-B-A-H-S-B-B-AA-G-A-BGG-GA-B-AA-A-NNN-***	M46	M46-046PV
M46-20997	PUMP-VAR DISPL	MPV-046-C-B-A-A-S-B-B-AA-A-A-BFF-AB-D-FF-C-NNN-***	M46	M46-046PV
M46-20999	PUMP-VAR DISPL	MPV-046-C-B-B-T-B-B-BA-A-A-BJJ-CE-A-JJ-A-NNN-***	M46	M46-046PV
M46-21001	PUMP-VAR DISPL	MPV-046-C-B-B-T-B-B-AA-A-A-BBB-CE-A-GG-A-NNN-***	M46	M46-046PV
M46-21002	PUMP-VAR DISPL	MPV-046-C-B-A-H-S-B-J-BA-A-A-BJJ-AB-D-AA-A-NNN-***	M46	M46-046PV
M46-21003	PUMP-VAR DISPL	MPV-046-C-B-B-A-S-B-B-AA-G-A-BGG-BA-A-JJ-C-NNN-***	M46	M46-046PV
M46-21005	PUMP-VAR DISPL	MPV-046-C-B-B-H-S-B-U-BA-A-B-BRR-DA-A-ZG-A-NNN-***	M46	M46-046PV
M46-21006	PUMP-VAR DISPL	MPV-046-C-B-B-T-B-B-BA-A-A-BBB-CE-A-GG-A-NNN-***	M46	M46-046PV
M46-21007	PUMP-VAR DISPL	MPV-046-C-B-B-K-S-B-B-AA-A-A-BFF-CD-A-GG-B-NNN-***	M46	M46-046PV
M46-21008	PUMP-VAR DISPL	MPV-046-C-B-B-H-S-B-B-AA-A-A-BFF-CD-A-GG-A-NNN-***	M46	M46-046PV
M46-21009	PUMP-VAR DISPL	MPV-046-C-B-A-J-T-B-J-AA-A-A-BJJ-AB-U-ED-A-NNN-***	M46	M46-046PV
M46-2101	PUMP-VAR-DISPL MPV046	MPV-046-C-B-B-A-L-B-A-AA-A-A-BBB-CD-A-GG-C-NNN-***	M46	M46-046PV
M46-21010	PUMP-VAR DISPL	MPV-046-C-B-A-K-R-A-B-BC-A-A-BHH-AB-U-BA-B-NNN-***	M46	M46-046PV
M46-21011	PUMP-VAR DISPL	MPV-046-C-B-A-K-S-A-B-BC-A-A-BHH-AB-U-BA-B-NNN-***	M46	M46-046PV
M46-21012	PUMP-VAR DISPL	MPV-046-C-B-B-H-S-B-B-BA-A-A-BGG-CE-A-HH-A-NNN-***	M46	M46-046PV
M46-21013	PUMP-VAR DISPL	MPV-046-C-B-B-D-L-B-B-BA-A-A-BGG-CD-A-GG-B-NNN-***	M46	M46-046PV
M46-21014	PUMP-VAR DISPL	MPV-046-C-B-B-H-S-B-B-AA-J-A-BGG-CB-A-ZG-A-NNN-***	M46	M46-046PV

M46-21015	PUMP-VAR DISPL	MPV-046-C-B-B-H-S-B-U-BA-A-A-BHH-DA-A-ZG-A-NNN-***	M46	M46-046PV
M46-21016	PUMP-VAR DISPL	MPV-046-C-B-B-K-T-B-B-AA-A-A-BHH-CD-A-GG-B-NNN-***	M46	M46-046PV
M46-21017	PUMP-VAR DISPL	MPV-046-C-B-B-A-T-B-J-AA-V-A-BFF-CB-A-HH-C-NNN-***	M46	M46-046PV
M46-21018	PUMP-VAR DISPL	MPV-046-C-B-B-B-S-B-B-BA-G-A-BHH-DB-A-HH-A-NNN-***	M46	M46-046PV
M46-21019	PUMP-VAR DISPL	MPV-046-C-B-B-K-T-B-J-BA-G-A-BGG-DB-A-HH-B-NNN-***	M46	M46-046PV
M46-21020	PUMP-VAR DISPL	MPV-046-C-B-A-A-S-B-B-BA-A-A-BJJ-AB-U-DD-C-NNN-***	M46	M46-046PV
M46-21022	PUMP-VAR DISPL	MPV-046-C-B-B-G-S-B-J-BA-G-A-BJJ-DB-A-HH-C-NNN-***	M46	M46-046PV
M46-21023	PUMP-VAR DISPL	MPV-046-C-B-B-H-R-B-M-AA-A-A-BFF-CB-A-ZG-A-NNN-***	M46	M46-046PV
M46-21024	PUMP-VAR DISPL	MPV-046-C-B-B-H-S-B-U-BA-A-B-BHH-DA-A-ZG-A-NNN-***	M46	M46-046PV
M46-21025	PUMP-VAR DISPL	MPV-046-C-B-B-K-R-B-M-AA-A-A-BHH-CB-A-HH-B-NNN-***	M46	M46-046PV
M46-21026	PUMP-VAR DISPL	MPV-046-C-B-A-B-S-B-B-AA-A-A-BDD-AB-U-BB-A-NNN-***	M46	M46-046PV
M46-21029	PUMP-VAR DISPL	MPV-046-C-B-A-V-T-B-J-AA-G-A-BFF-AB-U-AA-C-NNN-***	M46	M46-046PV
M46-21030	PUMP-VAR DISPL	MPV-046-C-B-A-G-S-B-B-BA-A-A-BJJ-AB-D-DD-C-NNN-***	M46	M46-046PV
M46-21031	PUMP-VAR DISPL	MPV-046-C-B-B-K-T-B-B-AA-A-A-BJJ-CB-A-GG-B-NNN-***	M46	M46-046PV
M46-21033	PUMP-VAR DISPL	MPV-046-C-B-B-H-S-A-J-BC-V-A-BFF-DA-A-TT-A-NNN-***	M46	M46-046PV
M46-21034	PUMP-VAR DISPL	MPV-046-C-B-B-B-T-B-B-BA-A-A-BGG-CB-A-GG-A-NNN-***	M46	M46-046PV
M46-21035	PUMP-VAR DISPL	MPV-046-C-B-B-B-T-B-B-AA-G-A-BHH-DB-A-HH-K-GSA-***	M46	M46-046PV
M46-21036	PUMP-VAR DISPL	MPV-046-C-B-A-A-S-B-B-BA-A-A-BHH-AB-U-AA-C-NNN-***	M46	M46-046PV
M46-21037	PUMP-VAR DISPL	MPV-046-C-B-A-A-R-B-B-AA-A-A-BDD-AB-U-CB-C-NNN-***	M46	M46-046PV
M46-21038	PUMP-VAR DISPL	MPV-046-C-B-A-Y-T-B-M-AA-A-A-BJJ-GG-B-MF-3-NNR-***	M46	M46-046PV
M46-21039	PUMP-VAR DISPL	MPV-046-C-B-A-Z-T-B-M-AA-A-A-BJJ-GG-B-MF-5-NNL-***	M46	M46-046PV
M46-21040	PUMP-VAR DISPL	MPV-046-C-B-A-Y-T-B-M-AA-A-A-BJJ-GG-B-MF-2-NNJ-***	M46	M46-046PV
M46-21042	PUMP-VAR DISPL	MPV-046-C-B-B-K-S-B-B-BA-A-A-BJJ-CB-A-HH-B-NNN-***	M46	M46-046PV
M46-21043	PUMP-VAR DISPL	MPV-046-C-B-A-D-S-B-B-AA-A-A-BFF-AB-U-AA-B-NNN-***	M46	M46-046PV
M46-21045	PUMP-VAR DISPL	MPV-046-C-B-B-K-S-A-A-BC-V-A-BFF-DB-A-TT-B-NNN-***	M46	M46-046PV
M46-21046	PUMP-VAR DISPL	MPV-046-C-B-B-K-S-B-B-BA-A-A-BJJ-CE-A-HH-B-NNN-***	M46	M46-046PV
M46-21047	PUMP-VAR DISPL	MPV-046-C-B-B-A-T-B-B-BA-A-A-BJJ-CN-A-GG-C-NNN-***	M46	M46-046PV
M46-21048	PUMP-VAR DISPL	MPV-046-C-B-B-A-T-B-B-AA-A-A-BMM-CB-A-GG-C-NNN-***	M46	M46-046PV
M46-21049	PUMP-VAR DISPL	MPV-046-C-B-B-K-S-B-B-AA-J-A-BRR-DA-A-ZG-B-NNN-***	M46	M46-046PV
M46-2105	PUMP-VAR DISPL	MPV-046-C-B-A-H-R-B-A-BA-A-A-BJJ-AB-U-ED-A-NNN-***	M46	M46-046PV
M46-21051	PUMP-VAR DISPL	MPV-046-C-B-A-J-S-B-B-AA-G-A-BJJ-AW-U-AB-A-NNN-***	M46	M46-046PV
M46-21052	PUMP-VAR DISPL	MPV-046-C-B-A-D-S-B-B-AA-A-A-BHH-AB-U-AA-B-NNN-***	M46	M46-046PV
M46-21053	PUMP-VAR DISPL	MPV-046-C-B-B-H-S-B-B-BA-A-A-BDD-CB-A-GG-A-NNN-***	M46	M46-046PV
M46-21055	PUMP-VAR DISPL	MPV-046-C-B-B-K-S-B-B-BA-A-A-BGG-CB-A-GG-B-NNN-***	M46	M46-046PV
M46-21056	PUMP-VAR DISPL	MPV-046-C-B-A-J-S-B-B-BA-A-A-BJJ-AB-U-ZX-A-NNN-***	M46	M46-046PV
M46-21057	PUMP-VAR DISPL	MPV-046-C-B-B-V-R-B-B-AA-A-A-BEE-CD-A-JJ-C-NNN-***	M46	M46-046PV

M46-21058	PUMP-VAR DISPL	MPV-046-C-B-B-K-T-B-J-AA-G-A-BDD-CD-A-GG-B-NNN-***	M46	M46-046PV
M46-21059	PUMP-VAR DISPL	MPV-046-C-B-B-W-R-B-A-AA-A-A-BEE-CD-A-JJ-A-NNN-***	M46	M46-046PV
M46-21060	PUMP-VAR DISPL	MPV-046-C-B-B-H-S-A-J-BC-4-A-BFF-DB-A-TT-A-NNN-***	M46	M46-046PV
M46-21061	PUMP-VAR DISPL	MPV-046-C-B-B-K-S-A-J-BC-4-A-BFF-DB-A-TT-B-NNN-***	M46	M46-046PV
M46-21062	PUMP-VAR DISPL	MPV-046-C-B-B-H-S-A-J-BC-4-A-BFF-DA-A-TT-A-NNN-***	M46	M46-046PV
M46-21063	PUMP-VAR DISPL	MPV-046-C-B-B-K-S-B-J-BA-A-A-BEE-BC-A-GG-B-NNN-***	M46	M46-046PV
M46-21064	PUMP-VAR DISPL	MPV-046-C-B-B-D-S-B-J-BA-A-A-BEE-BC-A-GG-B-NNN-***	M46	M46-046PV
M46-21067	PUMP-VAR DISPL	MPV-046-C-B-A-H-L-B-A-AA-A-A-BFF-AB-U-BD-A-NND-***	M46	M46-046PV
M46-21071	PUMP-VAR DISPL	MPV-046-C-B-A-H-L-B-A-AA-B-A-BJJ-AB-U-BD-A-NND-***	M46	M46-046PV
M46-21073	PUMP-VAR DISPL	MPV-046-C-B-A-B-R-B-A-AA-A-A-BEE-AB-U-BD-A-NND-***	M46	M46-046PV
M46-21074	PUMP-VAR DISPL	MPV-046-C-B-A-B-R-B-A-AA-B-A-BFF-AB-U-BD-A-NND-***	M46	M46-046PV
M46-21075	PUMP-VAR DISPL	MPV-046-C-B-A-B-R-B-A-AA-A-A-BFF-AB-U-BD-A-NND-***	M46	M46-046PV
M46-21077	PUMP-VAR DISPL	MPV-046-C-B-B-A-L-B-A-AA-A-A-BHH-CB-A-GG-C-NND-***	M46	M46-046PV
M46-21078	PUMP-VAR DISPL	MPV-046-C-B-B-H-L-B-J-BA-A-A-BJJ-CE-A-TT-A-NND-***	M46	M46-046PV
M46-21083	PUMP-VAR DISPL	MPV-046-C-B-A-J-S-A-B-BC-A-A-BFF-GB-B-LA-A-NNG-***	M46	M46-046PV
M46-21085	PUMP-VAR DISPL	MPV-046-C-B-A-G-R-B-A-AA-A-A-BJJ-AB-U-AA-C-NNG-***	M46	M46-046PV
M46-21087	PUMP-VAR DISPL	MPV-046-C-B-B-S-B-B-AA-G-A-BJJ-CB-A-GG-A-NNN-***	M46	M46-046PV
M46-21088	PUMP-VAR DISPL	MPV-046-C-B-B-T-B-S-AA-A-A-BJJ-BB-A-GG-A-NNN-***	M46	M46-046PV
M46-21089	PUMP-VAR DISPL	MPV-046-C-B-B-G-T-B-J-AA-G-A-BGG-DB-A-TT-C-NNN-***	M46	M46-046PV
M46-2109	PUMP-VAR DISPL	MPV-046-C-B-A-B-R-B-A-AA-A-A-BEE-AB-U-BD-A-NNN-***	M46	M46-046PV
M46-21090	PUMP-VAR DISPL	MPV-046-C-B-B-H-S-B-B-AA-G-A-BJJ-CB-A-GG-A-NNN-***	M46	M46-046PV
M46-21092	PUMP-VAR DISPL	MPV-046-C-B-B-N-T-B-B-AA-J-A-BGG-DA-A-GG-C-NNN-***	M46	M46-046PV
M46-21094	PUMP-VAR DISPL	MPV-046-C-B-A-H-S-B-B-AA-G-A-BJJ-AB-U-ZX-A-NNN-***	M46	M46-046PV
M46-21096	PUMP-VAR DISPL	MPV-046-C-B-B-G-R-B-A-AA-A-A-BFF-CB-A-GG-C-NND-***	M46	M46-046PV
M46-2110	PUMP-VAR DISPL	MPV-046-C-B-A-B-R-A-A-BC-C-A-BGG-AB-U-ED-A-NNN-***	M46	M46-046PV
M46-2112	PUMP-VAR DISPL	MPV-046-C-B-A-D-R-B-A-BA-A-A-BJJ-AB-U-ED-B-NNN-***	M46	M46-046PV
M46-2113	PUMP-VAR DISPL	MPV-046-C-B-A-A-L-B-A-BA-A-A-BFF-AB-D-ED-C-NNN-***	M46	M46-046PV
M46-2115	PUMP-VAR DISPL	MPV-046-C-B-A-B-R-A-A-BC-A-A-BFF-AB-U-ED-A-NNN-***	M46	M46-046PV
M46-2118	PUMP-VAR DISPL	MPV-046-C-B-B-K-R-B-A-BA-A-A-BGG-BA-A-GG-B-NNN-***	M46	M46-046PV
M46-2119	PUMP-VAR DISPL	MPV-046-C-B-A-K-R-B-A-AA-A-A-BJJ-AB-U-DD-B-NNN-***	M46	M46-046PV
M46-2121	PUMP-VAR DISPL	MPV-046-C-B-A-H-R-A-A-BC-A-A-BHH-AB-U-BA-A-NNN-***	M46	M46-046PV
M46-2131	PUMP-VAR DISPL	MPV-046-C-B-A-B-R-B-A-AA-D-A-BJJ-AB-U-BD-A-NNN-***	M46	M46-046PV
M46-2133	PUMP-VAR DISPL	MPV-046-C-B-A-H-R-A-A-BC-A-A-BGG-AB-U-BA-A-NNN-***	M46	M46-046PV
M46-2134	PUMP-VAR DISPL	MPV-046-C-B-A-P-R-A-A-BC-A-A-BGG-AB-U-BA-A-NNN-***	M46	M46-046PV
M46-2135	PUMP-VAR DISPL	MPV-046-C-B-A-B-R-A-A-BC-A-A-BGG-AB-U-BA-A-NNN-***	M46	M46-046PV
M46-2136	PUMP-VAR DISPL	MPV-046-C-B-A-D-R-A-A-BC-A-A-BJJ-AB-U-BA-B-NNN-***	M46	M46-046PV

M46-2139	PUMP-VAR DISPL	MPV-046-C-B-A-B-R-B-A-AA-A-A-BHH-AB-U-DD-A-NNN-***	M46	M46-046PV
M46-2140	PUMP-VAR DISPL	MPV-046-C-B-A-N-R-B-A-BA-A-A-BJJ-AB-U-BD-C-NNN-***	M46	M46-046PV
M46-2142	PUMP-VAR DISPL	MPV-046-C-B-A-B-R-B-A-AA-B-A-BFF-AB-U-BD-A-NNN-***	M46	M46-046PV
M46-2143	PUMP-VAR DISPL	MPV-046-C-B-A-D-R-B-A-AA-A-A-BGG-AB-U-ED-B-NNN-***	M46	M46-046PV
M46-2144	PUMP-VAR DISPL	MPV-046-C-B-A-A-R-B-A-AA-A-A-BDD-AB-U-ED-C-NNN-***	M46	M46-046PV
M46-2149	PUMP-VAR DISPL	MPV-046-C-B-A-W-R-B-A-BA-A-A-BGG-AB-U-ED-A-NNN-***	M46	M46-046PV
M46-2150	PUMP-VAR DISPL	MPV-046-C-B-A-H-R-B-A-AA-A-A-BEE-AB-U-FF-A-NNN-***	M46	M46-046PV
M46-2155	PUMP-VAR DISPL	MPV-046-C-B-B-A-L-B-A-BA-A-A-BBB-BA-A-GG-C-NNN-***	M46	M46-046PV
M46-2160	PUMP-VAR DISPL	MPV-046-C-B-A-K-R-B-A-BA-A-A-BBB-AB-U-ED-B-NNN-***	M46	M46-046PV
M46-2161	PUMP-VAR DISPL	MPV-046-C-B-B-G-L-B-A-BA-A-A-BBB-CG-A-GG-C-NNN-***	M46	M46-046PV
M46-2167	PUMP-VAR DISPL	MPV-046-C-B-A-H-L-B-A-BA-A-A-BFF-AB-U-ED-A-NNN-***	M46	M46-046PV
M46-2169	PUMP-VAR-DISPL MPV046	MPV-046-C-B-A-H-R-B-A-AA-A-A-BFF-AB-U-BD-A-NNN-***	M46	M46-046PV
M46-2172	PUMP-VAR DISPL	MPV-046-C-B-A-G-R-B-A-AA-A-A-BHH-AB-U-BD-C-NNN-***	M46	M46-046PV
M46-2174	PUMP-VAR DISPL	MPV-046-C-B-A-V-R-B-A-BA-A-A-BGG-AB-U-ED-C-NNN-***	M46	M46-046PV
M46-2177	PUMP-VAR DISPL	MPV-046-C-B-A-A-R-B-A-BA-A-A-BJJ-AB-U-ED-C-NNN-***	M46	M46-046PV
M46-2178	PUMP-VAR DISPL	MPV-046-C-B-A-G-L-B-A-BA-A-A-BJJ-AB-U-ED-C-NNN-***	M46	M46-046PV
M46-2179	PUMP-VAR DISPL	MPV-046-C-B-A-D-R-B-A-AA-A-A-BHH-AB-U-CD-B-NNN-***	M46	M46-046PV
M46-2183	PUMP-VAR DISPL	MPV-046-C-B-A-N-R-B-A-BA-A-A-BJJ-AB-D-BB-C-NNN-***	M46	M46-046PV
M46-2186	PUMP-VAR DISPL	MPV-046-C-B-A-B-R-B-A-AA-B-A-BJJ-AB-U-BD-A-NNN-***	M46	M46-046PV
M46-2188	PUMP-VAR DISPL	MPV-046-C-B-A-A-L-B-A-AA-A-A-BFF-AB-U-ED-C-NNN-***	M46	M46-046PV
M46-2189	PUMP-VAR DISPL	MPV-046-C-B-A-A-L-B-A-AA-A-A-BBB-AB-U-ED-C-NNN-***	M46	M46-046PV
M46-2192	PUMP-VAR DISPL	MPV-046-C-B-A-B-R-B-A-AA-A-A-BFF-AB-U-DD-A-NNN-***	M46	M46-046PV
M46-2193	PUMP-VAR DISPL	MPV-046-C-B-A-K-R-A-A-BC-A-A-BJJ-AB-U-ED-B-NNN-***	M46	M46-046PV
M46-2194	PUMP-VAR DISPL	MPV-046-C-B-B-D-L-B-A-AA-A-A-BGG-BA-A-GG-B-NNN-***	M46	M46-046PV
M46-2197	PUMP-VAR DISPL	MPV-046-C-B-A-H-R-B-A-BA-A-A-BHH-AB-U-ED-A-NNN-***	M46	M46-046PV
M46-2199	PUMP-VAR-DISPL MPV046	MPV-046-C-B-B-K-L-B-A-BA-A-A-BJJ-BA-A-GG-B-NNN-***	M46	M46-046PV
M46-2200	PUMP-VAR DISPL	MPV-046-C-B-A-K-R-B-A-BA-A-A-BHH-AB-U-ED-B-NNN-***	M46	M46-046PV
M46-2202	PUMP-VAR DISPL	MPV-046-C-B-A-B-R-B-A-AA-A-A-BFF-AB-U-AB-A-NNN-***	M46	M46-046PV
M46-2203	PUMP-VAR DISPL	MPV-046-C-B-A-G-R-A-A-BC-B-A-BFF-AB-U-ED-C-NNN-***	M46	M46-046PV
M46-2210	PUMP-VAR DISPL	MPV-046-C-B-B-G-R-B-A-BA-A-A-BGB-CE-A-GG-C-NNN-***	M46	M46-046PV
M46-2214	PUMP-VAR DISPL	MPV-046-C-B-B-A-R-B-A-AA-A-A-BGG-CG-A-GG-C-NNN-***	M46	M46-046PV
M46-2220	PUMP-VAR DISPL	MPV-046-C-B-A-G-L-B-A-AA-A-A-BBB-AB-U-ED-C-NNN-***	M46	M46-046PV
M46-2221	PUMP-VAR DISPL	MPV-046-C-B-B-A-R-B-A-BA-A-A-BBB-CD-A-GG-C-NNN-***	M46	M46-046PV
M46-2227	PUMP-VAR DISPL	MPV-046-C-B-A-A-R-B-A-BA-A-A-BCC-AB-U-ED-C-NNN-***	M46	M46-046PV
M46-2228	PUMP-VAR DISPL	MPV-046-C-B-A-K-R-B-A-BA-A-A-BGG-AB-U-ED-B-NNN-***	M46	M46-046PV
M46-2229	PUMP-VAR DISPL	MPV-046-C-B-A-V-R-B-A-BA-A-A-BJJ-AB-U-CD-C-NNN-***	M46	M46-046PV

M46-2234	PUMP-VAR DISPL	MPV-046-C-B-B-R-B-A-AA-R-A-BFF-CB-A-HH-H-NNA-***	M46	M46-046PV
M46-2235	PUMP-VAR DISPL	MPV-046-C-B-B-R-B-A-AA-A-A-BFF-CB-A-HH-H-NNA-***	M46	M46-046PV
M46-2237	PUMP-VAR DISPL	MPV-046-C-B-A-J-S-A-B-BC-A-A-BFF-GB-B-BA-A-NNN-***	M46	M46-046PV
M46-2242	PUMP-VAR DISPL	MPV-046-C-B-A-Z-T-B-S-AA-A-A-BJJ-GG-B-MF-5-NNL-***	M46	M46-046PV
M46-2243	PUMP-VAR DISPL	MPV-046-C-B-A-Y-T-B-S-AA-A-A-BJJ-GG-B-MF-2-GDB-***	M46	M46-046PV
M46-2244	PUMP-VAR DISPL	MPV-046-C-B-A-Y-T-B-S-AA-A-A-BJJ-GG-B-MF-2-GDD-***	M46	M46-046PV
M46-2246	PUMP-VAR DISPL	MPV-046-C-B-A-Y-T-B-S-AA-A-A-BJJ-GG-B-MF-2-NNJ-***	M46	M46-046PV
M46-2302	PUMP-VAR DISPL	MPV-046-C-B-A-H-R-B-A-AA-A-A-BHH-AB-U-AB-A-NNN-***	M46	M46-046PV
M46-2303	PUMP-VAR DISPL	MPV-046-C-B-A-D-R-B-A-BA-A-A-BGG-AB-U-ED-B-NNN-***	M46	M46-046PV
M46-2304	PUMP-VAR-DISPL MPV046	MPV-046-C-B-A-H-R-B-A-AA-A-A-BJJ-AB-U-ED-A-NNN-***	M46	M46-046PV
M46-2305	PUMP-VAR DISPL	MPV-046-C-B-A-W-L-B-A-AA-A-A-BBB-AB-U-ED-A-NNN-***	M46	M46-046PV
M46-2307	PUMP-VAR DISPL	MPV-046-C-B-A-A-R-B-A-AA-A-A-BFF-AB-U-BA-C-NNN-***	M46	M46-046PV
M46-2311	PUMP-VAR DISPL	MPV-046-C-B-A-B-L-B-A-AA-A-A-BJJ-AB-U-ED-A-NNN-***	M46	M46-046PV
M46-2312	PUMP-VAR DISPL	MPV-046-C-B-A-P-L-A-A-BC-A-A-BBB-AB-U-CD-A-NNN-***	M46	M46-046PV
M46-2313	PUMP-VAR DISPL	MPV-046-C-B-A-B-R-A-B-BC-A-A-BHH-AB-D-FF-A-NNN-***	M46	M46-046PV
M46-2314	PUMP-VAR DISPL	MPV-046-C-B-B-G-R-B-A-AA-A-A-BJJ-CE-A-GG-C-NNN-***	M46	M46-046PV
M46-2318	PUMP-VAR DISPL	MPV-046-C-B-A-D-R-B-A-AA-A-A-BDD-AB-U-ED-B-NNN-***	M46	M46-046PV
M46-2319	PUMP-VAR DISPL	MPV-046-C-B-A-H-R-B-A-AA-L-A-BEE-AB-U-AA-A-NNN-***	M46	M46-046PV
M46-2320	PUMP-VAR DISPL	MPV-046-C-B-B-P-L-B-A-BA-A-A-BHH-CD-A-JJ-A-NNN-***	M46	M46-046PV
M46-2321	PUMP-VAR DISPL	MPV-046-C-B-A-K-R-B-A-AA-A-A-BJJ-AB-U-AA-B-NNN-***	M46	M46-046PV
M46-2323	PUMP-VAR DISPL	MPV-046-C-B-A-G-R-A-A-BC-B-A-BFF-AB-U-ZZ-C-NNN-***	M46	M46-046PV
M46-2324	PUMP-VAR DISPL	MPV-046-C-B-A-H-R-B-A-AA-A-A-BFF-AB-U-AB-A-NNN-***	M46	M46-046PV
M46-2325	PUMP-VAR DISPL	MPV-046-C-B-A-H-R-B-B-AA-A-A-BFF-AB-U-ED-A-NNN-***	M46	M46-046PV
M46-2327	PUMP-VAR DISPL	MPV-046-C-B-A-H-R-B-A-AA-A-A-BHH-AB-U-EF-A-NNN-***	M46	M46-046PV
M46-2331	PUMP-VAR DISPL	MPV-046-C-B-A-K-R-B-A-AA-A-A-BJJ-AB-D-AA-B-NNN-***	M46	M46-046PV
M46-2332	PUMP-VAR DISPL	MPV-046-C-B-A-B-R-B-A-AA-A-A-BJJ-AB-D-ED-A-NNN-***	M46	M46-046PV
M46-2338	PUMP-VAR DISPL	MPV-046-C-B-A-H-R-B-A-BA-A-A-BDD-AB-U-AB-A-NNN-***	M46	M46-046PV
M46-2340	PUMP-VAR DISPL	MPV-046-C-B-B-G-L-B-A-BA-A-A-BBB-CD-A-GG-C-NNN-***	M46	M46-046PV
M46-2341	PUMP-VAR-DISPL MPV046	MPV-046-C-B-A-B-R-B-A-AA-A-A-BFF-AB-U-BD-A-NNN-***	M46	M46-046PV
M46-2343	PUMP-VAR DISPL	MPV-046-C-B-B-G-R-B-A-AA-A-A-BBB-CD-A-GG-C-NNN-***	M46	M46-046PV
M46-2344	PUMP-VAR DISPL	MPV-046-C-B-A-B-R-A-A-BC-A-A-BGG-AB-U-ZY-A-NNN-***	M46	M46-046PV
M46-2348	PUMP-VAR DISPL	MPV-046-C-B-A-H-R-B-A-AA-D-A-BFF-AB-U-AA-A-NNA-***	M46	M46-046PV
M46-2349	PUMP-VAR DISPL	MPV-046-C-B-A-G-R-B-A-AA-A-A-BJJ-AB-U-FA-C-NNN-***	M46	M46-046PV
M46-2350	PUMP-VAR DISPL	MPV-046-C-B-A-H-R-B-A-AA-A-A-BHH-AB-U-ZY-A-NNN-***	M46	M46-046PV
M46-2355	PUMP-VAR DISPL	MPV-046-C-B-A-H-L-B-A-BA-A-A-BHH-AB-U-ED-A-NNN-***	M46	M46-046PV
M46-2361	PUMP-VAR DISPL	MPV-046-C-B-A-B-R-A-A-BC-A-A-BJJ-AB-U-FA-A-NNN-***	M46	M46-046PV

M46-2363	PUMP-VAR DISPL	MPV-046-C-B-A-B-R-B-A-AA-A-A-BJJ-AB-U-AA-A-NNN-***	M46	M46-046PV
M46-2366	PUMP-VAR DISPL	MPV-046-C-B-A-B-R-A-A-BC-A-A-BGG-AB-U-ZV-A-NNN-***	M46	M46-046PV
M46-2367	PUMP-VAR-DISPL MPV046	MPV-046-C-B-B-G-L-B-A-AA-G-A-BHH-DA-A-RR-C-NNN-***	M46	M46-046PV
M46-2368	PUMP-VAR DISPL	MPV-046-C-B-A-K-L-B-A-BA-B-A-BFF-AB-U-FF-B-NNN-***	M46	M46-046PV
M46-2369	PUMP-VAR DISPL	MPV-046-C-B-B-A-L-B-A-AA-A-A-BFF-CD-A-HH-C-NNN-***	M46	M46-046PV
M46-2370	PUMP-VAR-DISPL MPV046	MPV-046-C-B-A-H-R-B-A-AA-A-B-BBB-AB-U-ZU-A-NNN-***	M46	M46-046PV
M46-2373	PUMP-VAR DISPL	MPV-046-C-B-B-H-L-B-A-AA-A-A-BJJ-CB-A-GG-A-NNN-***	M46	M46-046PV
M46-2375	PUMP-VAR DISPL	MPV-046-C-B-A-P-L-B-A-AA-A-A-BBB-AB-D-AA-A-NNN-***	M46	M46-046PV
M46-2377	PUMP-VAR DISPL	MPV-046-C-B-A-D-L-B-A-BA-A-A-BBB-AB-U-DD-B-NNN-***	M46	M46-046PV
M46-2378	PUMP-VAR DISPL	MPV-046-C-B-A-H-R-B-A-AA-A-A-BJJ-AB-U-ZY-A-NNN-***	M46	M46-046PV
M46-2379	PUMP-VAR-DISPL MPV046	MPV-046-C-B-B-K-R-B-A-AA-A-A-BJJ-CD-A-GG-B-NNN-***	M46	M46-046PV
M46-2380	PUMP-VAR DISPL	MPV-046-C-B-A-G-L-B-A-BA-A-A-BGG-AB-U-ED-C-NNN-***	M46	M46-046PV
M46-2381	PUMP-VAR DISPL	MPV-046-C-B-A-G-L-B-A-BA-A-A-BBB-AB-U-ED-C-NNN-***	M46	M46-046PV
M46-2382	PUMP-VAR DISPL	MPV-046-C-B-A-H-R-B-A-AA-A-A-BFF-AB-U-AA-A-NNN-***	M46	M46-046PV
M46-2387	PUMP-VAR DISPL	MPV-046-C-B-A-G-L-B-A-BA-A-A-BHH-AB-D-FF-C-NNN-***	M46	M46-046PV
M46-2389	PUMP-VAR DISPL	MPV-046-C-B-A-K-L-B-C-AA-A-A-BJJ-AB-U-ZT-A-NNN-***	M46	M46-046PV
M46-2393	PUMP-VAR DISPL	MPV-046-C-B-B-K-R-B-A-BA-A-A-BGG-CE-A-GG-B-NNN-***	M46	M46-046PV
M46-2394	PUMP-VAR DISPL	MPV-046-C-B-A-D-R-B-J-AA-A-A-BJJ-AB-U-AA-B-NNN-***	M46	M46-046PV
M46-2398	PUMP-VAR DISPL	MPV-046-C-B-A-A-L-B-A-AA-A-A-BHH-AB-U-BB-C-NNN-***	M46	M46-046PV
M46-2399	PUMP-VAR DISPL	MPV-046-C-B-B-V-R-B-A-BA-A-A-BFF-CD-A-JJ-C-NNN-***	M46	M46-046PV
M46-2516	PUMP-VAR DISPL	MPV-046-C-B-A-K-R-B-A-AA-A-A-BBB-AB-U-ED-B-NNN-***	M46	M46-046PV
M46-2520	PUMP-VAR DISPL	MPV-046-C-B-B-K-L-B-A-AA-A-A-BDD-CG-A-JJ-B-NNN-***	M46	M46-046PV
M46-2521	PUMP-VAR DISPL	MPV-046-C-B-A-K-R-B-A-AA-A-C-BJJ-AB-U-AF-B-NNN-***	M46	M46-046PV
M46-2531	PUMP-VAR DISPL	MPV-046-C-B-A-B-L-B-A-AA-A-A-BHH-AB-U-ED-A-NNN-***	M46	M46-046PV
M46-2532	PUMP-VAR DISPL	MPV-046-C-B-A-P-R-A-A-BC-A-A-BBB-AB-U-CD-A-NNN-***	M46	M46-046PV
M46-2541	PUMP-VAR DISPL	MPV-046-C-B-A-B-R-B-A-AA-B-A-BHH-AB-U-BD-A-NNN-***	M46	M46-046PV
M46-2542	PUMP-VAR DISPL	MPV-046-C-B-A-B-R-B-B-BA-A-A-BCC-AB-U-ED-A-NNN-***	M46	M46-046PV
M46-2544	PUMP-VAR DISPL	MPV-046-C-B-B-G-L-B-A-AA-A-A-BGG-CB-A-GG-C-NNN-***	M46	M46-046PV
M46-2550	PUMP-VAR DISPL	MPV-046-C-B-A-H-R-B-A-AA-A-A-BJJ-AB-D-ED-A-NNN-***	M46	M46-046PV
M46-2555	PUMP-VAR DISPL	MPV-046-C-B-A-G-R-B-A-AA-A-A-BHH-AB-U-ZY-C-NNN-***	M46	M46-046PV
M46-2558	PUMP-VAR DISPL	MPV-046-C-B-A-A-R-B-A-AA-A-A-BGG-AB-U-BA-C-NNN-***	M46	M46-046PV
M46-2559	PUMP-VAR DISPL	MPV-046-C-B-A-D-L-B-A-AA-A-A-BJJ-AB-U-ED-B-NNN-***	M46	M46-046PV
M46-2563	PUMP-VAR DISPL	MPV-046-C-B-B-B-L-B-A-BA-A-A-BBJ-CB-A-GG-A-NNN-***	M46	M46-046PV
M46-2566	PUMP-VAR DISPL	MPV-046-C-B-B-A-R-B-A-AA-G-A-BBB-CD-A-HH-C-NNN-***	M46	M46-046PV
M46-2568	PUMP-VAR DISPL	MPV-046-C-B-B-A-L-B-A-BA-A-A-BJJ-CE-A-GG-C-NNN-***	M46	M46-046PV
M46-2569	PUMP-VAR DISPL	MPV-046-C-B-A-K-L-B-A-AA-A-A-BDD-AB-U-ED-B-NNN-***	M46	M46-046PV

M46-2570	PUMP-VAR DISPL	MPV-046-C-B-B-G-L-B-A-BA-A-A-BJJ-CB-A-GG-C-NNN-***	M46	M46-046PV
M46-2573	PUMP-VAR DISPL	MPV-046-C-B-B-G-R-B-A-AA-A-A-BGG-CB-A-GG-C-NNN-***	M46	M46-046PV
M46-2574	PUMP-VAR DISPL	MPV-046-C-B-B-V-R-B-A-BA-A-A-BDD-CB-A-GG-C-NNN-***	M46	M46-046PV
M46-2576	PUMP-VAR DISPL	MPV-046-C-B-B-W-L-B-A-BA-A-A-BJB-CB-A-GG-A-NNN-***	M46	M46-046PV
M46-2579	PUMP-VAR DISPL	MPV-046-C-B-B-H-L-B-A-AA-A-A-BFF-CB-A-JJ-A-NNN-***	M46	M46-046PV
M46-2581	PUMP-VAR DISPL	MPV-046-C-B-B-H-L-B-A-BA-A-A-BJJ-CB-A-GG-A-NNN-***	M46	M46-046PV
M46-2582	PUMP-VAR DISPL	MPV-046-C-B-B-K-R-B-A-BA-A-A-BGG-CB-A-GG-B-NNN-***	M46	M46-046PV
M46-2583	PUMP-VAR DISPL	MPV-046-C-B-B-V-R-B-A-BA-A-A-BFF-CB-A-JJ-C-NNN-***	M46	M46-046PV
M46-2584	PUMP-VAR DISPL	MPV-046-C-B-B-D-L-B-A-AA-A-A-BBB-CB-A-GG-B-NNN-***	M46	M46-046PV
M46-2585	PUMP-VAR-DISPL MPV046	MPV-046-C-B-B-G-R-B-A-AA-A-A-BFF-CB-A-GG-C-NNN-***	M46	M46-046PV
M46-2586	PUMP-VAR DISPL	MPV-046-C-B-A-B-R-B-A-AA-A-A-BDD-AB-U-AA-A-NNN-***	M46	M46-046PV
M46-2587	PUMP-VAR DISPL	MPV-046-C-B-A-H-R-B-A-AA-A-A-BHH-AB-U-ZR-A-NNN-***	M46	M46-046PV
M46-2588	PUMP-VAR DISPL	MPV-046-C-B-B-B-R-B-A-BA-A-A-BFF-CB-A-HH-A-NNN-***	M46	M46-046PV
M46-2590	PUMP-VAR DISPL	MPV-046-C-B-A-A-R-B-A-AA-A-A-BJJ-AB-U-BD-C-NNN-***	M46	M46-046PV
M46-2591	PUMP-VAR DISPL	MPV-046-C-B-B-H-L-B-J-BA-A-A-BJJ-CE-A-HH-A-NNG-***	M46	M46-046PV
M46-2592	PUMP-VAR DISPL	MPV-046-C-B-B-G-L-B-J-BA-A-A-BJJ-CE-A-HH-C-NNG-***	M46	M46-046PV
M46-2593	PUMP-VAR DISPL	MPV-046-C-B-B-K-L-B-J-BA-A-A-BJJ-CE-A-HH-B-NNN-***	M46	M46-046PV
M46-2594	PUMP-VAR DISPL	MPV-046-C-B-A-G-R-B-A-AA-A-A-BJJ-AB-U-LA-C-NNN-***	M46	M46-046PV
M46-2596	PUMP-VAR DISPL	MPV-046-C-B-A-A-R-B-B-BA-A-A-BBB-AB-U-AA-C-NNN-***	M46	M46-046PV
M46-2598	PUMP-VAR DISPL	MPV-046-C-B-A-P-L-B-A-AA-A-A-BDD-AB-D-AA-A-NNN-***	M46	M46-046PV
M46-2601	PUMP-VAR DISPL	MPV-046-C-B-B-B-R-B-A-BA-A-A-BJJ-CB-A-GG-A-NNN-***	M46	M46-046PV
M46-2606	PUMP-VAR DISPL	MPV-046-C-B-A-H-R-B-A-AA-G-A-BJJ-AB-U-ED-A-NNN-***	M46	M46-046PV
M46-2608	PUMP-VAR DISPL	MPV-046-C-B-A-D-R-B-A-BA-A-A-BEE-AB-U-ED-B-NNN-***	M46	M46-046PV
M46-2609	PUMP-VAR	MPV-046-C-B-A-B-R-B-A-AA-B-A-BFF-AB-U-ZP-A-NNA-***	M46	M46-046PV
M46-2610	PUMP-VAR DISPL	MPV-046-C-B-B-H-L-B-A-AA-G-A-BEE-CB-A-JJ-A-NNN-***	M46	M46-046PV
M46-2617	PUMP-VAR DISPL	MPV-046-C-B-B-B-R-B-A-BA-G-A-BGG-CE-A-HH-A-NNN-***	M46	M46-046PV
M46-2621	PUMP-VAR DISPL	MPV-046-C-B-B-D-L-B-A-BA-A-A-BHH-CB-A-JJ-B-NNN-***	M46	M46-046PV
M46-2623	PUMP-VAR DISPL	MPV-046-C-B-A-A-R-B-A-AA-A-A-BBB-AB-U-ED-C-NNN-***	M46	M46-046PV
M46-2630	PUMP-VAR DISPL	MPV-046-C-B-B-B-R-B-A-AA-A-A-BJJ-CB-A-HH-A-NNN-***	M46	M46-046PV
M46-2634	PUMP-VAR DISPL	MPV-046-C-B-A-B-L-B-A-BA-A-A-BDD-AB-U-ED-A-NNN-***	M46	M46-046PV
M46-2635	PUMP-VAR DISPL	MPV-046-C-B-A-V-R-B-A-AA-A-A-BJJ-AB-U-AA-C-NNN-***	M46	M46-046PV
M46-2637	PUMP-VAR DISPL	MPV-046-C-B-B-B-R-B-A-AA-G-A-BBB-CD-A-HH-A-NNN-***	M46	M46-046PV
M46-2639	PUMP-VAR DISPL	MPV-046-C-B-B-B-R-B-A-AA-A-A-BJJ-CB-A-GG-A-NNN-***	M46	M46-046PV
M46-2640	PUMP-VAR DISPL	MPV-046-C-B-A-G-L-B-A-BA-A-A-BFF-AB-D-ED-C-NNN-***	M46	M46-046PV
M46-2644	PUMP-VAR-DISPL MPV046	MPV-046-C-B-B-B-R-B-A-AA-G-A-BHH-DA-A-RR-A-NNN-***	M46	M46-046PV
M46-2647	PUMP-VAR DISPL	MPV-046-C-B-B-W-R-B-A-AA-A-A-BDD-CD-A-HH-A-NNN-***	M46	M46-046PV

M46-2648	PUMP-VAR DISPL	MPV-046-C-B-A-B-R-A-A-BC-A-B-BGG-AB-U-ZV-A-NNN-***	M46	M46-046PV
M46-2650	PUMP-VAR DISPL	MPV-046-C-B-B-W-L-B-J-BA-A-A-BFF-CB-A-HH-A-NNN-***	M46	M46-046PV
M46-2651	PUMP-VAR DISPL	MPV-046-C-B-B-G-L-B-A-AA-A-A-BFF-CB-A-GG-C-NNN-***	M46	M46-046PV
M46-2654	PUMP-VAR DISPL	MPV-046-C-B-A-K-R-B-A-AA-G-A-BJJ-AB-U-ZS-B-NNN-***	M46	M46-046PV
M46-2655	PUMP-VAR DISPL	MPV-046-C-B-A-H-L-A-A-BC-A-A-BGG-AB-U-FB-A-NNN-***	M46	M46-046PV
M46-2656	PUMP-VAR DISPL	MPV-046-C-B-B-B-L-B-A-BA-A-A-BDD-CE-A-JJ-A-NNN-***	M46	M46-046PV
M46-2660	PUMP-VAR DISPL	MPV-046-C-B-B-B-R-B-A-BA-A-A-BDD-CE-A-JJ-A-NNN-***	M46	M46-046PV
M46-2662	PUMP-VAR DISPL	MPV-046-C-B-B-H-R-B-A-AA-A-A-BJJ-CD-A-GG-A-NNN-***	M46	M46-046PV
M46-2664	PUMP-VAR DISPL	MPV-046-C-B-A-K-R-B-A-AA-A-A-BGG-AB-U-ZR-B-NNN-***	M46	M46-046PV
M46-2665	PUMP-VAR-DISPL MPV046	MPV-046-C-B-A-A-R-B-A-AA-A-A-BJJ-AB-U-ED-C-NNN-***	M46	M46-046PV
M46-2666	PUMP-VAR DISPL	MPV-046-C-B-A-K-L-B-A-BA-A-A-BBB-AB-U-ED-B-NNN-***	M46	M46-046PV
M46-2667	PUMP-VAR DISPL	MPV-046-C-B-B-G-L-B-A-BA-A-A-BGG-CB-A-GG-C-NNN-***	M46	M46-046PV
M46-2668	PUMP-VAR DISPL	MPV-046-C-B-B-W-R-B-A-AA-A-A-BDD-CG-A-HH-A-NNN-***	M46	M46-046PV
M46-2669	PUMP-VAR DISPL	MPV-046-C-B-A-K-L-B-A-AA-A-A-BJJ-AB-D-ED-B-NNN-***	M46	M46-046PV
M46-2670	PUMP-VAR DISPL	MPV-046-C-B-A-G-R-B-A-AA-A-A-BJJ-AB-U-AA-C-NNN-***	M46	M46-046PV
M46-2673	PUMP-VAR DISPL	MPV-046-C-B-A-H-R-B-A-AA-A-A-BJJ-AB-U-AB-A-NNN-***	M46	M46-046PV
M46-2675	PUMP-VAR DISPL	MPV-046-C-B-A-B-R-B-A-BA-A-A-BCC-AB-U-BA-A-NNN-***	M46	M46-046PV
M46-2676	PUMP-VAR DISPL	MPV-046-C-B-A-B-L-A-A-BC-A-A-BFF-AB-U-ED-A-NNN-***	M46	M46-046PV
M46-2677	PUMP-VAR DISPL	MPV-046-C-B-A-V-L-B-A-AA-A-A-BDD-AB-U-FF-C-NNN-***	M46	M46-046PV
M46-2678	PUMP-VAR DISPL	MPV-046-C-B-A-B-L-B-A-AA-A-A-BDD-AB-U-ED-A-NNN-***	M46	M46-046PV
M46-2680	PUMP-VAR DISPL	MPV-046-C-B-B-B-L-B-A-BA-A-A-BBB-BA-A-GG-A-NNN-***	M46	M46-046PV
M46-2681	PUMP-VAR DISPL	MPV-046-C-B-A-K-L-B-A-AA-A-A-BJJ-AB-D-FF-B-NNN-***	M46	M46-046PV
M46-2682	PUMP-VAR DISPL	MPV-046-C-B-A-G-L-B-A-AA-A-A-BJJ-AB-U-FF-C-NNN-***	M46	M46-046PV
M46-2685	PUMP-VAR DISPL	MPV-046-C-B-B-N-L-B-A-AA-A-A-BBB-CB-A-GG-C-NNN-***	M46	M46-046PV
M46-2687	PUMP-VAR DISPL	MPV-046-C-B-B-P-L-B-A-AA-A-A-BDD-CB-A-HH-A-NNN-***	M46	M46-046PV
M46-2688	PUMP-VAR DISPL	MPV-046-C-B-A-H-R-B-A-BA-B-A-BFF-AB-U-AA-A-NNN-***	M46	M46-046PV
M46-2689	PUMP-VAR DISPL	MPV-046-C-B-A-B-R-B-B-AA-G-A-BFF-AB-U-BD-A-NNN-***	M46	M46-046PV
M46-2690	PUMP-VAR DISPL	MPV-046-C-B-B-H-L-B-A-BA-A-A-BDD-CD-A-GG-A-NNN-***	M46	M46-046PV
M46-2691	PUMP-VAR DISPL	MPV-046-C-B-A-H-R-B-A-AA-G-A-BFF-AB-U-AA-A-NNN-***	M46	M46-046PV
M46-2692	PUMP-VAR DISPL	MPV-046-C-B-A-A-R-B-A-BA-A-A-BBB-AB-U-AA-C-NNN-***	M46	M46-046PV
M46-2693	PUMP-VAR DISPL	MPV-046-C-B-B-D-R-B-A-AA-A-A-BHH-CD-A-GG-B-NNN-***	M46	M46-046PV
M46-2700	PUMP-VAR DISPL	MPV-046-C-B-A-H-R-B-A-AA-G-A-BJJ-AB-U-ZS-A-NNN-***	M46	M46-046PV
M46-2701	PUMP-VAR DISPL	MPV-046-C-B-B-K-L-B-A-BA-A-A-BFF-CD-A-GG-B-NNN-***	M46	M46-046PV
M46-2702	PUMP-VAR DISPL	MPV-046-C-B-B-G-L-B-A-AA-A-A-BJJ-CB-A-GG-C-NNN-***	M46	M46-046PV
M46-2704	PUMP-VAR DISPL	MPV-046-C-B-A-V-R-B-A-AA-A-A-BGG-AB-U-BB-C-NNN-***	M46	M46-046PV
M46-2705	PUMP-VAR DISPL	MPV-046-C-B-A-V-L-B-A-AA-A-A-BGG-AB-U-BB-C-NNN-***	M46	M46-046PV

M46-2706	PUMP-VAR DISPL	MPV-046-C-B-B-H-L-B-A-AA-A-A-BDD-CE-A-HH-A-NNN-***	M46	M46-046PV
M46-2709	PUMP-VAR DISPL	MPV-046-C-B-B-G-L-B-A-AA-A-A-BJJ-CG-A-GG-C-NNN-***	M46	M46-046PV
M46-2710	PUMP-VAR DISPL	MPV-046-C-B-A-K-L-B-A-AA-G-A-BJJ-AB-U-ED-B-NNN-***	M46	M46-046PV
M46-2711	PUMP-VAR DISPL	MPV-046-C-B-A-A-L-B-C-AA-A-A-BDD-AB-U-ED-C-NNN-***	M46	M46-046PV
M46-2713	PUMP-VAR-DISPL MPV046	MPV-046-C-B-B-A-R-B-A-AA-A-A-BJJ-CD-A-GG-C-NNN-***	M46	M46-046PV
M46-2715	PUMP-VAR DISPL	MPV-046-C-B-B-A-R-B-A-AA-A-A-BFF-CD-A-GG-C-NNN-***	M46	M46-046PV
M46-2716	PUMP-VAR-DISPL MPV046	MPV-046-C-B-B-B-R-B-A-AA-A-A-BFF-CD-A-GG-A-NNN-***	M46	M46-046PV
M46-2717	PUMP-VAR DISPL	MPV-046-C-B-A-H-R-A-A-BC-A-A-BJJ-AB-U-ZR-A-NNN-***	M46	M46-046PV
M46-2721	PUMP-VAR DISPL	MPV-046-C-B-B-A-L-B-A-AA-A-A-BGG-CD-A-GG-C-NNN-***	M46	M46-046PV
M46-2722	PUMP-VAR DISPL	MPV-046-C-B-A-A-R-B-A-AA-A-A-BGG-AB-U-ZY-C-NNN-***	M46	M46-046PV
M46-2723	PUMP-VAR DISPL	MPV-046-C-B-A-B-R-B-A-AA-A-A-BEE-AB-U-FA-A-NNN-***	M46	M46-046PV
M46-2724	PUMP-VAR DISPL	MPV-046-C-B-A-A-R-B-A-AA-A-B-BGG-AB-D-CA-C-NNN-***	M46	M46-046PV
M46-2725	PUMP-VAR DISPL	MPV-046-C-B-A-V-R-B-A-AA-A-A-BJJ-AB-U-ED-C-NNN-***	M46	M46-046PV
M46-2726	PUMP-VAR DISPL	MPV-046-C-B-A-H-R-B-A-BA-A-A-BJJ-AB-U-AB-A-NNN-***	M46	M46-046PV
M46-2727	PUMP-VAR DISPL	MPV-046-C-B-B-B-L-B-A-AA-A-A-BDD-CD-A-JJ-A-NNN-***	M46	M46-046PV
M46-2728	PUMP-VAR DISPL	MPV-046-C-B-A-G-R-B-A-BA-A-A-BHH-AB-D-ED-C-NNN-***	M46	M46-046PV
M46-2729	PUMP-VAR DISPL	MPV-046-C-B-B-B-L-B-A-AA-A-A-BGG-CD-A-JJ-A-NNN-***	M46	M46-046PV
M46-2730	PUMP-VAR DISPL	MPV-046-C-B-A-G-R-B-A-BA-A-A-BGG-AC-U-ED-C-NNN-***	M46	M46-046PV
M46-2731	PUMP-VAR DISPL	MPV-046-C-B-B-D-R-B-A-AA-A-A-BBB-CB-A-GG-B-NNN-***	M46	M46-046PV
M46-2732	PUMP-VAR DISPL	MPV-046-C-B-A-G-R-B-A-BA-A-A-BJJ-AC-U-ED-C-NNN-***	M46	M46-046PV
M46-2733	PUMP-VAR DISPL	MPV-046-C-B-B-B-R-B-A-AA-G-A-BDD-CD-A-HH-A-NNN-***	M46	M46-046PV
M46-2734	PUMP-VAR DISPL	MPV-046-C-B-A-A-L-B-A-AA-A-A-BCC-AB-U-DD-C-NNN-***	M46	M46-046PV
M46-2735	PUMP-VAR DISPL	MPV-046-C-B-B-K-L-B-A-BA-A-A-BBB-CE-A-GG-B-NNN-***	M46	M46-046PV
M46-2736	PUMP-VAR DISPL	MPV-046-C-B-B-K-L-B-A-BA-A-A-BBB-CB-A-GG-B-NNN-***	M46	M46-046PV
M46-2737	PUMP-VAR DISPL	MPV-046-C-B-B-K-L-B-A-BA-A-A-BGG-CE-A-GG-B-NNN-***	M46	M46-046PV
M46-2739	PUMP-VAR DISPL	MPV-046-C-B-A-K-L-B-A-BA-A-A-BEE-AB-U-ED-B-NNN-***	M46	M46-046PV
M46-2740	PUMP-VAR DISPL	MPV-046-C-B-A-K-R-B-A-BA-A-A-BEE-AB-U-ED-B-NNN-***	M46	M46-046PV
M46-2741	PUMP-VAR DISPL	MPV-046-C-B-A-D-L-B-A-AA-A-A-BCC-AB-U-DD-B-NNN-***	M46	M46-046PV
M46-2744	PUMP-VAR DISPL	MPV-046-C-B-B-K-L-B-A-AA-A-A-BDD-CD-A-JJ-B-NNN-***	M46	M46-046PV
M46-2746	PUMP-VAR DISPL	MPV-046-C-B-B-A-R-B-A-AA-A-A-BJJ-CB-A-GG-C-NNN-***	M46	M46-046PV
M46-2748	PUMP-VAR DISPL	MPV-046-C-B-A-G-R-B-A-BA-A-A-BJB-AC-D-ED-C-NNN-***	M46	M46-046PV
M46-2750	PUMP-VAR DISPL	MPV-046-C-B-A-G-R-B-A-AA-A-A-BJJ-AB-U-ZM-C-NNN-***	M46	M46-046PV
M46-2751	PUMP-VAR DISPL	MPV-046-C-B-A-G-R-B-A-BA-A-A-BHH-AB-U-ED-C-NNN-***	M46	M46-046PV
M46-2753	PUMP-VAR DISPL	MPV-046-C-B-A-A-R-B-A-AA-A-B-BGG-AB-D-ZL-C-NNN-***	M46	M46-046PV
M46-2754	PUMP-VAR DISPL	MPV-046-C-B-A-H-L-B-A-AA-G-A-BJJ-AB-U-BB-A-NNN-***	M46	M46-046PV
M46-2755	PUMP-VAR DISPL	MPV-046-C-B-A-A-R-B-A-AA-A-A-BJJ-AB-U-AD-C-NNN-***	M46	M46-046PV

M46-2756	PUMP-VAR DISPL	MPV-046-C-B-A-D-L-B-A-BA-A-A-BFF-AB-U-ED-B-NNN-***	M46	M46-046PV
M46-2757	PUMP-VAR DISPL	MPV-046-C-B-A-K-R-A-A-BC-A-A-BFF-AB-D-FF-B-NNN-***	M46	M46-046PV
M46-2758	PUMP-VAR DISPL	MPV-046-C-B-A-G-L-B-A-AA-A-A-BCC-AB-U-DD-C-NNN-***	M46	M46-046PV
M46-2759	PUMP-VAR DISPL	MPV-046-C-B-A-K-L-B-A-AA-A-A-BCC-AB-U-DD-B-NNN-***	M46	M46-046PV
M46-2762	PUMP-VAR DISPL	MPV-046-C-B-B-V-L-B-A-BA-A-A-BHH-CB-A-GG-C-NNN-***	M46	M46-046PV
M46-2763	PUMP-VAR DISPL	MPV-046-C-B-B-G-R-B-A-BA-A-A-BHH-CB-A-GG-C-NNN-***	M46	M46-046PV
M46-2764	PUMP-VAR DISPL	MPV-046-C-B-A-K-R-A-A-BC-A-A-BFF-AB-U-AA-B-NNN-***	M46	M46-046PV
M46-2765	PUMP-VAR DISPL	MPV-046-C-B-B-A-L-B-A-AA-A-A-BGG-CB-A-GG-C-NNN-***	M46	M46-046PV
M46-2766	PUMP-VAR DISPL	MPV-046-C-B-B-H-L-B-A-AA-G-A-BEE-CB-A-RR-A-NNN-***	M46	M46-046PV
M46-2768	PUMP-VAR DISPL	MPV-046-C-B-B-D-R-B-A-BA-G-A-BEE-BA-A-HH-B-NNN-***	M46	M46-046PV
M46-2769	PUMP-VAR DISPL	MPV-046-C-B-B-D-R-B-A-AA-G-A-BEE-CE-A-HH-B-NNN-***	M46	M46-046PV
M46-2770	PUMP-VAR DISPL	MPV-046-C-B-B-A-R-B-A-BA-A-A-BBB-BA-A-HH-C-NNN-***	M46	M46-046PV
M46-2772	PUMP-VAR DISPL	MPV-046-C-B-B-B-R-B-A-BA-A-A-BDD-CB-A-GG-A-NNN-***	M46	M46-046PV
M46-2773	PUMP-VAR DISPL	MPV-046-C-B-A-A-R-B-B-AA-A-A-BGG-AB-U-ZY-C-NNN-***	M46	M46-046PV
M46-2774	PUMP-VAR DISPL	MPV-046-C-B-A-B-R-A-A-BC-A-A-BFF-AB-U-ZT-A-NNN-***	M46	M46-046PV
M46-2775	PUMP-VAR DISPL	MPV-046-C-B-A-B-R-B-A-AA-A-A-BHJ-AB-U-CA-A-NNN-***	M46	M46-046PV
M46-2776	PUMP-VAR DISPL	MPV-046-C-B-A-B-L-B-A-BA-A-A-BGG-AB-U-AB-A-NNN-***	M46	M46-046PV
M46-2778	PUMP-VAR DISPL	MPV-046-C-B-A-J-R-B-A-BA-A-A-BEE-AB-U-AA-A-NNN-***	M46	M46-046PV
M46-2779	PUMP-VAR DISPL	MPV-046-C-B-B-A-L-B-A-AA-A-A-BDD-CB-A-GG-C-NNN-***	M46	M46-046PV
M46-2800	PUMP-VAR DISPL	MPV-046-C-B-B-A-R-B-A-AA-A-A-BHH-CD-A-GG-C-NNN-***	M46	M46-046PV
M46-2801	PUMP-VAR DISPL	MPV-046-C-B-B-V-R-B-A-AA-A-A-BFF-CD-A-TT-C-NNN-***	M46	M46-046PV
M46-2803	PUMP-VAR DISPL	MPV-046-C-B-B-H-R-B-A-AA-A-A-BDD-CB-A-HH-A-NNN-***	M46	M46-046PV
M46-2804	PUMP-VAR DISPL	MPV-046-C-B-A-H-L-B-A-BA-A-A-BHH-AB-U-BB-A-NNN-***	M46	M46-046PV
M46-2805	PUMP-VAR DISPL	MPV-046-C-B-B-H-L-B-A-BA-A-A-BFF-CG-A-GG-A-NNN-***	M46	M46-046PV
M46-2806	PUMP-VAR DISPL	MPV-046-C-B-B-A-L-B-A-AA-A-A-BMM-CD-A-GG-C-NNN-***	M46	M46-046PV
M46-2807	PUMP-VAR DISPL	MPV-046-C-B-B-H-R-B-A-AA-A-A-BHH-CD-A-GG-A-NNN-***	M46	M46-046PV
M46-2808	PUMP-VAR DISPL	MPV-046-C-B-A-B-L-B-A-BA-A-A-BJJ-AB-U-BD-A-NNN-***	M46	M46-046PV
M46-2813	PUMP-VAR DISPL	MPV-046-C-B-B-K-L-B-A-BA-A-A-BJJ-CG-A-GG-B-NNN-***	M46	M46-046PV
M46-2814	PUMP-VAR DISPL	MPV-046-C-B-B-K-L-B-A-AA-A-A-BFF-CG-A-GG-B-NNN-***	M46	M46-046PV
M46-2815	PUMP-VAR DISPL	MPV-046-C-B-B-A-L-B-A-BA-A-A-BMM-CD-A-GG-C-NNN-***	M46	M46-046PV
M46-2816	PUMP-VAR DISPL	MPV-046-C-B-B-D-R-B-J-BA-A-A-BFF-CB-A-HH-B-NNN-***	M46	M46-046PV
M46-2819	PUMP-VAR DISPL	MPV-046-C-B-B-H-R-B-A-BA-A-A-BDD-CB-A-HH-A-NNN-***	M46	M46-046PV
M46-2821	PUMP-VAR DISPL	MPV-046-C-B-B-B-L-B-A-AA-A-A-BGG-CD-A-GG-A-NNN-***	M46	M46-046PV
M46-2822	PUMP-VAR DISPL	MPV-046-C-B-A-B-L-B-A-BA-A-A-BBB-AB-U-ED-A-NNN-***	M46	M46-046PV
M46-2825	PUMP-VAR DISPL	MPV-046-C-B-B-A-R-B-A-AA-A-A-BBB-CB-A-GG-C-NNN-***	M46	M46-046PV
M46-2826	PUMP-VAR DISPL	MPV-046-C-B-A-G-L-B-A-AA-A-A-BJJ-AB-D-ED-C-NNN-***	M46	M46-046PV

M46-2827	PUMP-VAR DISPL	MPV-046-C-B-A-G-L-B-D-BA-A-A-BHH-AC-D-ED-C-NNN-***	M46	M46-046PV
M46-2828	PUMP-VAR DISPL	MPV-046-C-B-B-G-L-B-A-BA-G-A-BJJ-CD-A-TT-C-NNN-***	M46	M46-046PV
M46-2829	PUMP-VAR DISPL	MPV-046-C-B-B-H-L-B-A-BA-G-A-BBB-CD-A-GG-A-NNN-***	M46	M46-046PV
M46-2830	PUMP-VAR DISPL	MPV-046-C-B-A-H-R-B-A-AA-G-A-BJJ-AB-U-AA-A-NNN-***	M46	M46-046PV
M46-2831	PUMP-VAR DISPL	MPV-046-C-B-A-B-L-B-C-AA-A-A-BHH-AB-U-ED-A-NNN-***	M46	M46-046PV
M46-2832	PUMP-VAR DISPL	MPV-046-C-B-A-H-L-B-C-AA-A-A-BJJ-AB-U-ED-A-NNN-***	M46	M46-046PV
M46-2833	PUMP-VAR DISPL	MPV-046-C-B-B-H-R-B-A-AA-A-A-BGG-BB-A-GG-A-NNN-***	M46	M46-046PV
M46-2835	PUMP-VAR DISPL	MPV-046-C-B-A-B-R-B-A-AA-A-A-BMM-AB-U-ED-A-NNN-***	M46	M46-046PV
M46-2836	PUMP-VAR DISPL	MPV-046-C-B-A-A-R-B-A-BA-A-A-BHH-AB-U-ED-C-NNN-***	M46	M46-046PV
M46-2838	PUMP-VAR DISPL	MPV-046-C-B-B-H-L-B-A-AA-A-A-BDD-CB-A-GG-A-NNN-***	M46	M46-046PV
M46-2839	PUMP-VAR DISPL	MPV-046-C-B-B-H-R-B-A-AA-A-A-BDD-CB-A-GG-A-NNN-***	M46	M46-046PV
M46-2840	PUMP-VAR DISPL	MPV-046-C-B-A-H-R-B-A-AA-A-A-BJJ-AB-U-ZM-A-NNN-***	M46	M46-046PV
M46-2841	PUMP-VAR-DISPL MPV046	MPV-046-C-B-B-K-L-B-A-AA-A-A-BDD-CD-A-GG-B-NNN-***	M46	M46-046PV
M46-2842	PUMP-VAR DISPL	MPV-046-C-B-B-K-R-B-A-AA-A-A-BDD-CD-A-GG-B-NNN-***	M46	M46-046PV
M46-2843	PUMP-VAR DISPL	MPV-046-C-B-B-B-R-B-A-AA-A-A-BDD-CD-A-JJ-A-NNN-***	M46	M46-046PV
M46-2845	PUMP-VAR DISPL	MPV-046-C-B-A-H-L-B-A-AA-D-A-BHH-AB-U-ED-A-NNN-***	M46	M46-046PV
M46-2846	PUMP-VAR DISPL	MPV-046-C-B-A-B-R-B-A-AA-A-A-BJJ-AB-D-AA-A-NNN-***	M46	M46-046PV
M46-2847	PUMP-VAR DISPL	MPV-046-C-B-B-L-B-A-BA-A-A-BHH-BA-A-HH-A-NNN-***	M46	M46-046PV
M46-2848	PUMP-VAR DISPL	MPV-046-C-B-B-P-R-B-A-AA-A-A-BFF-CD-A-GG-A-NNN-***	M46	M46-046PV
M46-2849	PUMP-VAR DISPL	MPV-046-C-B-B-H-L-B-J-BA-A-A-BJJ-CB-A-TT-A-NNN-***	M46	M46-046PV
M46-2852	PUMP-VAR DISPL	MPV-046-C-B-B-K-L-B-A-AA-A-A-BJJ-CD-A-JJ-B-NNN-***	M46	M46-046PV
M46-2853	PUMP-VAR-DISPL MPV046	MPV-046-C-B-B-K-L-B-A-AA-A-A-BFF-CD-A-JJ-B-NNN-***	M46	M46-046PV
M46-2854	PUMP-VAR DISPL	MPV-046-C-B-B-K-L-B-A-AA-A-A-BDD-CB-A-GG-B-NNN-***	M46	M46-046PV
M46-2855	PUMP-VAR DISPL	MPV-046-C-B-B-B-R-B-A-AA-G-A-BHH-DA-A-ZH-A-NNN-***	M46	M46-046PV
M46-2857	PUMP-VAR DISPL	MPV-046-C-B-B-G-R-B-A-AA-G-A-BDD-CD-A-GG-C-NNN-***	M46	M46-046PV
M46-2859	PUMP-VAR DISPL	MPV-046-C-B-B-G-R-B-A-AA-G-A-BBB-CD-A-GG-C-NNN-***	M46	M46-046PV
M46-2860	PUMP-VAR DISPL	MPV-046-C-B-B-G-L-B-A-BA-A-A-BGG-BA-A-HH-C-NNN-***	M46	M46-046PV
M46-2864	PUMP-VAR DISPL	MPV-046-C-B-B-A-R-B-A-BA-G-A-BDD-CB-A-HH-C-NNN-***	M46	M46-046PV
M46-2865	PUMP-VAR DISPL	MPV-046-C-B-A-G-L-B-B-AA-A-A-BFF-AB-U-ED-C-NNN-***	M46	M46-046PV
M46-2866	PUMP-VAR DISPL	MPV-046-C-B-A-W-L-B-A-AA-A-A-BBB-AB-D-DD-A-NNN-***	M46	M46-046PV
M46-2867	PUMP-VAR DISPL	MPV-046-C-B-B-B-R-B-J-BA-A-A-BBB-CB-A-HH-A-NNN-***	M46	M46-046PV
M46-2868	PUMP-VAR DISPL	MPV-046-C-B-B-B-R-B-A-BA-A-A-BCC-BA-A-JJ-A-NNN-***	M46	M46-046PV
M46-2869	PUMP-VAR DISPL	MPV-046-C-B-B-H-R-B-A-AA-A-A-BJJ-CD-A-HH-A-NNN-***	M46	M46-046PV
M46-2870	PUMP-VAR DISPL	MPV-046-C-B-B-B-R-B-A-BA-G-A-BBB-CB-A-HH-A-NNN-***	M46	M46-046PV
M46-2872	PUMP-VAR DISPL	MPV-046-C-B-A-G-R-B-A-BA-A-A-BBB-AB-D-AB-C-NNN-***	M46	M46-046PV
M46-2874	PUMP-VAR DISPL	MPV-046-C-B-A-B-L-B-A-AA-A-A-BHH-AB-U-BB-A-NNN-***	M46	M46-046PV

M46-2875	PUMP-VAR DISPL	MPV-046-C-B-A-A-R-B-A-BA-A-A-BBB-AB-D-AB-C-NNN-***	M46	M46-046PV
M46-2876	PUMP-VAR DISPL	MPV-046-C-B-B-A-R-B-A-AA-A-A-BBB-BA-A-GJ-C-NNN-***	M46	M46-046PV
M46-2877	PUMP-VAR DISPL	MPV-046-C-B-B-R-B-A-BA-A-A-BBB-CD-A-HH-A-NNN-***	M46	M46-046PV
M46-2878	PUMP-VAR DISPL	MPV-046-C-B-B-G-L-B-C-BA-G-A-BJJ-CD-A-TT-C-NNN-***	M46	M46-046PV
M46-2879	PUMP-VAR DISPL	MPV-046-C-B-A-G-R-B-A-BA-A-A-BEE-AC-U-ED-C-NNN-***	M46	M46-046PV
M46-2880	PUMP-VAR DISPL	MPV-046-C-B-A-K-R-B-A-BA-A-A-BFF-AC-U-ED-B-NNN-***	M46	M46-046PV
M46-2881	PUMP-VAR DISPL	MPV-046-C-B-A-V-L-B-A-BA-A-A-BFF-AC-D-ED-C-NNN-***	M46	M46-046PV
M46-2882	PUMP-VAR DISPL	MPV-046-C-B-A-D-L-B-A-BA-A-A-BJJ-AB-U-FF-B-NNN-***	M46	M46-046PV
M46-2884	PUMP-VAR DISPL	MPV-046-C-B-B-G-L-B-A-BA-A-A-BHH-CB-A-JJ-C-NNN-***	M46	M46-046PV
M46-2885	PUMP-VAR DISPL	MPV-046-C-B-B-G-R-B-A-BA-A-A-BHH-CB-A-JJ-C-NNN-***	M46	M46-046PV
M46-2886	PUMP-VAR DISPL	MPV-046-C-B-A-B-R-B-A-AA-G-A-BFF-AB-U-BD-A-NNN-***	M46	M46-046PV
M46-2889	PUMP-VAR-DISPL MPV046	MPV-046-C-B-B-H-R-B-A-AA-G-A-BJJ-DA-A-GG-A-NNN-***	M46	M46-046PV
M46-2892	PUMP-VAR DISPL	MPV-046-C-B-B-H-R-B-A-AA-A-A-BMM-CB-A-HH-A-NNN-***	M46	M46-046PV
M46-2893	PUMP-VAR DISPL	MPV-046-C-B-B-A-R-B-A-BA-A-A-BFF-CB-A-GG-C-NNN-***	M46	M46-046PV
M46-2898	PUMP-VAR DISPL	MPV-046-C-B-B-A-R-B-A-BA-A-A-BJJ-CD-A-JJ-C-NNN-***	M46	M46-046PV
M46-2899	PUMP-VAR DISPL	MPV-046-C-B-A-G-R-B-A-BA-A-A-BJJ-AB-U-LA-C-NNN-***	M46	M46-046PV
M46-3013	MOTOR-FIXED-DISPL MMF046	MMF-046-C-A-K-A-B-B-NNN	M46	M46-046MF
M46-3021	MOTOR-FIXED-DISPL MMF046	MMF-046-C-A-E-B-B-B-NNN	M46	M46-046MF
M46-3109	MOTOR-FIXED		M46	M46-046MF
M46-3138	MOTOR-FIX DISPL		M46	M46-046MF
M46-4002	MOTOR-VAR-DISPL MMV046	MMV-046-C-A-A-B-C-AA-NNN-***	M46	M46-046MV
M46-4005	MOTOR-VAR-DISPL MMV046	MMV-046-C-A-E-B-A-AA-NNN-***	M46	M46-046MV
M46-4009	MOTOR-VAR DISPL	MMV-046-C-A-J-D-A-AA-NNN-***	M46	M46-046MV
M46-4010	MOTOR-VAR-DISPL MMV046	MMV-046-C-A-E-B-C-AA-NNN-***	M46	M46-046MV
M46-4012	MOTOR VAR-DISPL	MMV-046-C-A-A-A-A-AA-NNN-***	M46	M46-046MV
M46-4013	MOTOR-VAR DISPL	MMV-046-C-A-E-H-E-AA-NNN-***	M46	M46-046MV
M46-4014	MOTOR-VAR DISPL	MMV-046-C-A-A-D-A-AA-NNN-***	M46	M46-046MV
M46-4015	MOTOR-VAR DISPL	MMV-046-C-A-A-E-A-AA-NNN-***	M46	M46-046MV
M46-4016	MOTOR-VAR DISPL	MMV-046-C-A-E-E-A-AA-NNN-***	M46	M46-046MV
M46-4018	MOTOR-VAR DISPL	MMV-046-C-A-A-E-B-AA-NNN-***	M46	M46-046MV
M46-4019	MOTOR-VAR DISPL	MMV-046-C-A-A-B-A-AA-NNN-***	M46	M46-046MV
M46-4024	MOTOR-VAR DISPL	MMV-046-C-A-A-F-A-AA-NNN-***	M46	M46-046MV
M46-4025	MOTOR-VAR DISPL	MMV-046-C-A-E-D-A-AA-NNN-***	M46	M46-046MV
M46-4026	MOTOR-VAR DISPL	MMV-046-C-A-J-B-A-AA-NNN-***	M46	M46-046MV
M46-4030	MOTOR-VAR DISPL	MMV-046-C-A-E-A-A-AA-NNN-***	M46	M46-046MV
M46-4033	MOTOR-VAR-DISPL MMV046	MMV-046-C-A-E-F-A-AA-NNN-***	M46	M46-046MV

M46-4047	MOTOR-VAR DISPL	MMV-046-C-B-G-F-A-AD-NNN-***	M46	M46-046MV
M46-4051	MOTOR-VAR DISPL	MMV-046-C-A-A-B-X-AA-NNN-***	M46	M46-046MV
M46-4053	MOTOR-VAR DISPL	MMV-046-C-B-G-M-B-AP-NNN-***	M46	M46-046MV
M46-4055	MOTOR-VAR DISPL	MMV-046-C-B-G-M-B-AZ-NNN-***	M46	M46-046MV
M46-4101	MOTOR-VAR DISPL	MMV-046-C-A-J-A-A-AA-NNN-***	M46	M46-046MV
M46-4102	MOTOR-VAR DISPL	MMV-046-C-A-A-A-B-AA-NNN-***	M46	M46-046MV
M46-4104	MOTOR-VAR DISPL	MMV-046-C-A-E-E-B-AA-NNN-***	M46	M46-046MV
M46-4106	MOTOR-VAR-DISPL MMV046	MMV-046-C-A-E-D-C-AA-NNN-***	M46	M46-046MV
M46-4107	MOTOR-VAR DISPL	MMV-046-C-A-A-L-A-AA-NNN-***	M46	M46-046MV
M46-4108	MOTOR-VAR DISPL	MMV-046-C-A-A-D-B-AA-NNN-***	M46	M46-046MV
M46-4109	MOTOR-VAR DISPL	MMV-046-C-A-E-D-B-AA-NNN-***	M46	M46-046MV
M46-4110	MOTOR-VAR DISPL	MMV-046-C-A-E-B-B-AA-NNN-***	M46	M46-046MV
M46-4113	MOTOR-VAR DISPL	MMV-046-C-A-J-D-B-AA-NNN-***	M46	M46-046MV
M46-4114	MOTOR-VAR DISPL	MMV-046-C-A-A-M-A-AA-NNN-***	M46	M46-046MV
M46-4115	MOTOR-VAR DISPL	MMV-046-C-A-E-A-C-AA-NNN-***	M46	M46-046MV
M46-4116	MOTOR-VAR DISPL	MMV-046-C-A-A-A-C-AA-NNN-***	M46	M46-046MV
M46-4117	MOTOR-VAR DISPL	MMV-046-C-A-A-B-B-AA-NNN-***	M46	M46-046MV
M46-4119	MOTOR-VAR DISPL	MMV-046-C-A-E-D-E-AA-NNN-***	M46	M46-046MV
M46-4120	MOTOR-VAR DISPL	MMV-046-C-A-A-B-E-AA-NNN-***	M46	M46-046MV
M46-4129	MOTOR-VAR DISPL	MMV-046-C-A-A-C-F-AA-NNN-***	M46	M46-046MV
M46-4131	MOTOR-VAR DISPL	MMV-046-C-A-E-F-B-AA-NNN-***	M46	M46-046MV
M46-4132	MOTOR-VAR DISPL	MMV-046-C-A-E-B-D-AA-NNN-***	M46	M46-046MV
M46-4133	MOTOR-VAR-DISPL MMV046	MMV-046-C-A-E-M-C-AA-NNN-***	M46	M46-046MV
M46-4135	MOTOR-VAR DISPL	MMV-046-C-A-E-M-B-AA-NNN-***	M46	M46-046MV
M46-4136	MOTOR-VAR DISPL	MMV-046-C-B-B-L-A-AD-NNN-***	M46	M46-046MV
M46-4137	MOTOR-VAR DISPL	MMV-046-C-B-B-L-B-AD-NNN-***	M46	M46-046MV
M46-4139	MOTOR-VAR DISPL	MMV-046-C-B-B-B-A-AD-NNN-***	M46	M46-046MV
M46-4140	MOTOR-VAR DISPL	MMV-046-C-B-B-D-C-AD-NNN-***	M46	M46-046MV
M46-4141	MOTOR-VAR DISPL	MMV-046-C-B-F-B-B-AD-NNN-***	M46	M46-046MV
M46-4144	MOTOR-VAR DISPL	MMV-046-C-B-B-F-A-AD-NNN-***	M46	M46-046MV
M46-4145	MOTOR-VAR DISPL	MMV-046-C-A-E-T-A-AA-NNN-***	M46	M46-046MV
M46-4146	MOTOR-VAR DISPL	MMV-046-C-A-E-N-A-AA-NNN-***	M46	M46-046MV
M46-4148	MOTOR-VAR DISPL	MMV-046-C-A-A-M-B-AA-NNN-***	M46	M46-046MV
M46-4149	MOTOR-VAR DISPL	MMV-046-C-B-B-A-A-AD-NNN-***	M46	M46-046MV
M46-4150	MOTOR-VAR DISPL	MMV-046-C-A-A-F-C-AA-NNN-***	M46	M46-046MV
M46-4152	MOTOR-VAR DISPL	MMV-046-C-A-A-D-C-AA-NNN-***	M46	M46-046MV

M46-4153	MOTOR-VAR DISPL	MMV-046-C-A-E-A-B-AA-NNN-***	M46	M46-046MV
M46-4154	MOTOR-VAR DISPL	MMV-046-C-A-A-A-A-AE-NNN-***	M46	M46-046MV
M46-4155	MOTOR-VAR DISPL	MMV-046-C-A-A-F-B-AA-NNN-***	M46	M46-046MV
M46-4156	MOTOR-VAR-DISPL MMV046	MMV-046-C-A-E-H-E-AF-NNN-***	M46	M46-046MV
M46-4157	MOTOR-VAR DISPL	MMV-046-C-A-E-P-H-AA-NNN-***	M46	M46-046MV
M46-4158	MOTOR-VAR DISPL	MMV-046-C-A-E-F-C-AF-NNN-***	M46	M46-046MV
M46-4159	MOTOR-VAR DISPL	MMV-046-C-A-E-A-D-AF-NNN-***	M46	M46-046MV
M46-4161	MOTOR-VAR DISPL	MMV-046-C-A-E-F-D-AF-NNN-***	M46	M46-046MV
M46-4162	MOTOR-VAR DISPL	MMV-046-C-A-A-A-B-AF-NNN-***	M46	M46-046MV
M46-4164	MOTOR-VAR DISPL	MMV-046-C-A-E-A-A-AE-NNN-***	M46	M46-046MV
M46-4165	MOTOR-VAR DISPL	MMV-046-C-A-E-A-A-AF-NNN-***	M46	M46-046MV
M46-4167	MOTOR-VAR DISPL	MMV-046-C-A-A-E-B-AE-NNN-***	M46	M46-046MV
M46-4168	MOTOR-VAR DISPL	MMV-046-C-A-A-A-A-AF-NNN-***	M46	M46-046MV
M46-4169	MOTOR-VAR-DISPL MMV046	MMV-046-C-A-E-H-E-AJ-NNN-***	M46	M46-046MV
M46-4170	MOTOR-VAR DISPL	MMV-046-C-A-A-D-A-AF-NNN-***	M46	M46-046MV
M46-4172	MOTOR-VAR-DISPL MMV046	MMV-046-C-A-E-N-C-AK-NNN-***	M46	M46-046MV
M46-4173	MOTOR-VAR DISPL	MMV-046-C-A-A-F-E-AA-NNN-***	M46	M46-046MV
M46-4175	MOTOR-VAR DISPL	MMV-046-C-A-A-P-H-AA-NNN-***	M46	M46-046MV
M46-4176	MOTOR-VAR DISPL	MMV-046-C-A-E-B-B-AF-NNN-***	M46	M46-046MV
M46-4177	MOTOR-VAR DISPL	MMV-046-C-A-A-F-A-A6-NNN-***	M46	M46-046MV
M46-4178	MOTOR-VAR DISPL	MMV-046-C-A-A-L-A-AM-NNN-***	M46	M46-046MV
M46-4180	MOTOR-VAR DISPL	MMV-046-C-A-A-M-B-AU-VNB-***	M46	M46-046MV
M46-4181	MOTOR-VAR DISPL	MMV-046-C-B-B-M-A-AD-NNN-***	M46	M46-046MV
M46-4182	MOTOR-VAR DISPL	MMV-046-C-A-A-D-B-AM-NNN-***	M46	M46-046MV
M46-4183	MOTOR-VAR DISPL	MMV-046-C-A-A-D-B-AN-NNN-***	M46	M46-046MV
M46-4184	MOTOR-VAR DISPL	MMV-046-C-A-A-D-A-AM-NNN-***	M46	M46-046MV
M46-4188	MOTOR-VAR DISPL	MMV-046-C-A-A-E-X-AH-NNN-***	M46	M46-046MV
M46-4189	MOTOR-VAR DISPL	MMV-046-C-B-G-M-B-AD-NNN-***	M46	M46-046MV
M46-4190	MOTOR-VAR DISPL	MMV-046-C-A-A-H-A-AA-NNN-***	M46	M46-046MV
M46-4191	MOTOR-VAR DISPL	MMV-046-C-A-A-B-A-AK-NNN-***	M46	M46-046MV
M46-4194	MOTOR-VAR DISPL	MMV-046-C-A-A-F-A-AM-NNN-***	M46	M46-046MV
M46-4195	MOTOR-VAR DISPL	MMV-046-C-A-A-B-A-AJ-NNN-***	M46	M46-046MV
M46-4196	MOTOR-VAR DISPL	MMV-046-C-A-E-B-D-AU-VNA-***	M46	M46-046MV
M46-4197	MOTOR-VAR DISPL	MMV-046-C-A-E-D-C-AH-NNN-***	M46	M46-046MV
M46-4198	MOTOR-VAR DISPL	MMV-046-C-B-B-M-A-AP-NNN-***	M46	M46-046MV
M46-4199	MOTOR-VAR DISPL	MMV-046-C-B-B-F-A-AP-NNN-***	M46	M46-046MV

M46-4200	MOTOR-VAR DISPL	MMV-046-C-A-E-B-D-AH-NNN-***	M46	M46-046MV
M46-4201	MOTOR-VAR DISPL	MMV-046-C-A-A-M-B-AV-VNB-***	M46	M46-046MV
M46-4202	MOTOR-VAR DISPL	MMV-046-C-A-E-F-B-AF-NNN-***	M46	M46-046MV
M46-4203	MOTOR-VAR DISPL	MMV-046-C-A-A-B-S-AA-NNN-***	M46	M46-046MV
M46-4204	MOTOR-VAR DISPL	MMV-046-C-A-A-F-A-AF-NNN-***	M46	M46-046MV
M46-4206	MOTOR-VAR DISPL	MMV-046-C-A-E-F-A-AN-NNN-***	M46	M46-046MV
M46-4207	MOTOR-VAR DISPL	MMV-046-C-A-E-D-B-AK-NNF-***	M46	M46-046MV
M46-4208	MOTOR-VAR DISPL	MMV-046-C-A-A-D-A-AK-NNN-***	M46	M46-046MV
M46-4209	MOTOR-VAR DISPL	MMV-046-C-A-A-E-A-AH-NNN-***	M46	M46-046MV
M46-4211	MOTOR-VAR DISPL	MMV-046-C-A-E-L-A-AH-NNN-***	M46	M46-046MV
M46-4212	MOTOR-VAR DISPL	MMV-046-C-B-G-B-B-AD-NNN-***	M46	M46-046MV
M46-4213	MOTOR-VAR DISPL	MMV-046-C-B-G-B-B-AZ-NNN-***	M46	M46-046MV
M46-4214	MOTOR-VAR DISPL	MMV-046-C-A-A-B-B-AV-VNB-***	M46	M46-046MV
M46-4215	MOTOR-VAR DISPL	MMV-046-C-A-E-E-X-AH-NNN-***	M46	M46-046MV
M46-4216	MOTOR-VAR DISPL	MMV-046-C-A-A-H-A-AH-NNN-***	M46	M46-046MV
M46-4218	MOTOR-VAR DISPL	MMV-046-C-A-E-R-H-AV-VNB-***	M46	M46-046MV
M46-4219	MOTOR-VAR DISPL	MMV-046-C-A-A-B-A-AH-NNN-***	M46	M46-046MV
M46-4220	MOTOR-VAR DISPL	MMV-046-C-A-A-M-A-AF-NNN-***	M46	M46-046MV
M46-4221	MOTOR-VAR DISPL	MMV-046-C-A-A-A-E-AA-NNN-***	M46	M46-046MV
M46-4222	MOTOR-VAR DISPL	MMV-046-C-A-A-M-A-AK-NNN-***	M46	M46-046MV
M46-4223	MOTOR-VAR DISPL	MMV-046-C-A-E-A-B-AK-NNN-***	M46	M46-046MV
M46-4224	MOTOR-VAR DISPL	MMV-046-C-A-E-N-B-AK-NNN-***	M46	M46-046MV
M46-4225	MOTOR-VAR DISPL	MMV-046-C-A-E-E-A-AY-NNN-***	M46	M46-046MV
M46-4226	MOTOR-VAR DISPL	MMV-046-C-A-E-A-A-AM-NNN-***	M46	M46-046MV
M46-4227	MOTOR-VAR DISPL	MMV-046-C-B-F-A-A-AZ-NNN-***	M46	M46-046MV
M46-4228	MOTOR-VAR DISPL	MMV-046-C-A-E-D-A-AY-NNN-***	M46	M46-046MV
M46-4229	MOTOR-VAR DISPL	MMV-046-C-A-E-F-A-AY-NNN-***	M46	M46-046MV
M46-4230	MOTOR-VAR DISPL	MMV-046-C-A-A-D-A-AH-NNN-***	M46	M46-046MV
M46-4232	MOTOR-VAR DISPL	MMV-046-C-A-E-E-E-AY-NNN-***	M46	M46-046MV
M46-4233	MOTOR-VAR DISPL	MMV-046-C-A-A-F-B-AJ-NNN-***	M46	M46-046MV
M46-4234	MOTOR-VAR DISPL	MMV-046-C-A-A-H-B-AA-NNN-***	M46	M46-046MV
M46-4235	MOTOR-VAR DISPL	MMV-046-C-A-A-F-B-AE-NNN-***	M46	M46-046MV
M46-4236	MOTOR-VAR DISPL	MMV-046-C-A-A-N-B-AE-NNN-***	M46	M46-046MV
M46-4238	MOTOR-VAR DISPL	MMV-046-C-A-A-A-C-AH-NNN-***	M46	M46-046MV
M46-4239	MOTOR-VAR DISPL	MMV-046-C-A-E-F-B-AK-NNN-***	M46	M46-046MV
M46-4240	MOTOR-VAR DISPL	MMV-046-C-A-A-D-A-AY-NNN-***	M46	M46-046MV

M46-4241	MOTOR-VAR DISPL	MMV-046-C-A-A-F-B-AM-NNN-***	M46	M46-046MV
M46-4242	MOTOR-VAR DISPL	MMV-046-C-A-A-D-X-AH-NNN-***	M46	M46-046MV
M46-4243	MOTOR-VAR DISPL	MMV-046-C-A-J-T-D-AA-NNN-***	M46	M46-046MV
M46-4244	MOTOR-VAR DISPL	MMV-046-C-A-A-F-A-A4-VNC-***	M46	M46-046MV
M46-4247	MOTOR-VAR DISPL	MMV-046-C-A-A-E-C-AA-NNN-***	M46	M46-046MV
M46-4248	MOTOR-VAR DISPL	MMV-046-C-A-A-E-C-AM-NNN-***	M46	M46-046MV
M46-4251	MOTOR-VAR DISPL	MMV-046-C-A-A-W-B-AV-VNB-***	M46	M46-046MV
M46-4252	MOTOR-VAR DISPL	MMV-046-C-A-E-E-E-AJ-NNN-***	M46	M46-046MV
M46-4253	MOTOR-VAR DISPL	MMV-046-C-A-A-F-A-AU-VNC-***	M46	M46-046MV
M46-4256	MOTOR-VAR DISPL	MMV-046-C-A-A-F-A-AV-NNN-***	M46	M46-046MV
M46-4257	MOTOR-VAR DISPL	MMV-046-C-A-A-D-E-AH-NNN-***	M46	M46-046MV
M46-4258	MOTOR-VAR DISPL	MMV-046-C-A-A-B-A-A4-VNB-***	M46	M46-046MV
M46-4259	MOTOR-VAR DISPL	MMV-046-C-A-A-F-A-A4-VNB-***	M46	M46-046MV
M46-4261	MOTOR-VAR DISPL	MMV-046-C-A-E-F-D-A4-VNB-***	M46	M46-046MV
M46-4262	MOTOR-VAR DISPL	MMV-046-C-B-F-F-B-AD-NNN-***	M46	M46-046MV
M46-4263	MOTOR-VAR DISPL	MMV-046-C-A-A-A-A-AY-NNN-***	M46	M46-046MV
M46-4264	MOTOR-VAR-DISPL MMV046	MMV-046-C-A-E-B-A-AY-NNN-***	M46	M46-046MV
M46-4265	MOTOR-VAR DISPL	MMV-046-C-A-A-M-A-AY-NNN-***	M46	M46-046MV
M46-4266	MOTOR-VAR DISPL	MMV-046-C-A-E-W-E-AE-VNC-***	M46	M46-046MV
M46-4267	MOTOR-VAR DISPL	MMV-046-C-A-E-A-A-AH-NNN-***	M46	M46-046MV
M46-4269	MOTOR-VAR DISPL	MMV-046-C-A-A-E-A-AM-NNN-***	M46	M46-046MV
M46-4271	MOTOR-VAR DISPL	MMV-046-C-A-A-T-E-AA-NNN-***	M46	M46-046MV
M46-4272	MOTOR-VAR DISPL	MMV-046-C-A-E-T-E-AA-NNN-***	M46	M46-046MV
M46-4273	MOTOR-VAR DISPL	MMV-046-C-A-E-N-A-AY-NNN-***	M46	M46-046MV
M46-4274	MOTOR-VAR DISPL	MMV-046-C-A-A-M-A-AM-NNN-***	M46	M46-046MV
M46-4275	MOTOR-VAR DISPL	MMV-046-C-A-E-E-B-AE-NNN-***	M46	M46-046MV
M46-4277	MOTOR-VAR DISPL	MMV-046-C-A-A-L-A-A6-NNN-***	M46	M46-046MV
M46-4278	MOTOR-VAR DISPL	MMV-046-C-A-A-E-A-A6-NNN-***	M46	M46-046MV
M46-4279	MOTOR-VAR DISPL	MMV-046-C-A-A-F-D-AK-NNH-***	M46	M46-046MV
M46-4280	MOTOR-VAR DISPL	MMV-046-C-A-A-L-A-AE-NNN-***	M46	M46-046MV
M46-4281	MOTOR-VAR DISPL	MMV-046-C-A-A-L-A-AY-NNN-***	M46	M46-046MV
M46-4282	MOTOR-VAR DISPL	MMV-046-C-A-E-B-A-AH-NNN-***	M46	M46-046MV
M46-4284	MOTOR-VAR DISPL	MMV-046-C-A-A-E-A-AE-NNN-***	M46	M46-046MV
M46-4285	MOTOR-VAR DISPL	MMV-046-C-A-E-A-A-AY-NNN-***	M46	M46-046MV
M46-4286	MOTOR-VAR DISPL	MMV-046-C-A-A-E-S-AE-VNC-***	M46	M46-046MV
M46-4287	MOTOR-VAR DISPL	MMV-046-C-A-E-F-A-AF-NNN-***	M46	M46-046MV

M46-4289	MOTOR-VAR DISPL	MMV-046-C-A-E-B-A-AM-NNN-***	M46	M46-046MV
M46-4290	MOTOR-VAR DISPL	MMV-046-C-A-A-A-C-AK-NNN-***	M46	M46-046MV
M46-4291	MOTOR-VAR DISPL	MMV-046-C-A-E-H-B-AE-NNN-***	M46	M46-046MV
M46-4294	MOTOR-VAR DISPL	MMV-046-C-A-A-D-A-AV-VNB-***	M46	M46-046MV
M46-4295	MOTOR-VAR DISPL	MMV-046-C-A-A-D-B-AV-VNB-***	M46	M46-046MV
M46-4296	MOTOR-VAR DISPL	MMV-046-C-A-A-M-A-AV-VNB-***	M46	M46-046MV
M46-4298	MOTOR-VAR DISPL	MMV-046-C-A-E-A-A-AE-VNB-***	M46	M46-046MV
M46-4299	MOTOR-VAR DISPL	MMV-046-C-A-E-A-B-AE-VNB-***	M46	M46-046MV
M46-4300	MOTOR-VAR DISPL	MMV-046-C-A-E-B-A-AE-VNB-***	M46	M46-046MV
M46-4301	MOTOR-VAR DISPL	MMV-046-C-A-E-B-B-AE-VNB-***	M46	M46-046MV
M46-4302	MOTOR-VAR DISPL	MMV-046-C-A-E-F-A-AK-VNA-***	M46	M46-046MV
M46-4303	MOTOR-VAR DISPL	MMV-046-C-A-A-M-B-AU-VNA-***	M46	M46-046MV
M46-4304	MOTOR-VAR DISPL	MMV-046-C-A-A-E-D-AU-VNA-***	M46	M46-046MV
M46-4305	MOTOR-VAR DISPL	MMV-046-C-A-A-E-D-AV-VNA-***	M46	M46-046MV
M46-4306	MOTOR-VAR DISPL	MMV-046-C-A-A-B-B-AK-NNN-***	M46	M46-046MV
M46-4307	MOTOR-VAR DISPL	MMV-046-C-A-E-F-C-AH-NNN-***	M46	M46-046MV
M46-4308	MOTOR-VAR DISPL	MMV-046-C-A-E-B-B-A5-NND-***	M46	M46-046MV
M46-4309	MOTOR-VAR DISPL	MMV-046-C-A-A-E-B-AV-VNA-***	M46	M46-046MV
M46-4310	MOTOR-VAR DISPL	MMV-046-C-A-E-2-A-AR-NNN-***	M46	M46-046MV
M46-4311	MOTOR-VAR DISPL	MMV-046-C-A-A-L-A-AV-NNN-***	M46	M46-046MV
M46-4312	MOTOR-VAR DISPL	MMV-046-C-A-A-L-A-AK-NNN-***	M46	M46-046MV
M46-4313	MOTOR-VAR DISPL	MMV-046-C-B-B-E-E-AP-NNN-***	M46	M46-046MV
M46-4314	MOTOR-VAR DISPL	MMV-046-C-A-A-F-A-AK-NNN-***	M46	M46-046MV
M46-4316	MOTOR-VAR DISPL	MMV-046-C-A-E-L-A-AA-NNN-***	M46	M46-046MV
M46-4317	MOTOR-VAR DISPL	MMV-046-C-A-E-H-B-AV-NNJ-***	M46	M46-046MV
M46-4318	MOTOR DISPL	MMV-046-C-A-A-E-U-AE-VNC-***	M46	M46-046MV
M46-4319	MOTOR-VAR DISPL	MMV-046-C-A-A-R-A-AA-NNN-***	M46	M46-046MV
M46-4320	MOTOR-VAR DISPL	MMV-046-C-A-A-L-A-AV-VNB-***	M46	M46-046MV
M46-4321	MOTOR-VAR DISPL	MMV-046-C-A-A-E-A-A5-NNN-***	M46	M46-046MV
M46-4322	MOTOR-VAR DISPL	MMV-046-C-A-A-E-A-A5-VNC-***	M46	M46-046MV
M46-4323	MOTOR-VAR DISPL	MMV-046-C-A-E-F-A-AV-VNA-***	M46	M46-046MV
M46-4324	MOTOR-VAR DISPL	MMV-046-C-A-A-F-A-AU-VNB-***	M46	M46-046MV
M46-4326	MOTOR-VAR DISPL	MMV-046-C-A-E-3-B-AK-NNN-***	M46	M46-046MV
M46-4328	MOTOR-VAR DISPL	MMV-046-C-A-A-F-A-AH-NNN-***	M46	M46-046MV
M46-4329	MOTOR-VAR DISPL	MMV-046-C-A-A-F-E-AV-VNA-***	M46	M46-046MV
M46-4330	MOTOR-VAR DISPL	MMV-046-C-A-A-T-D-AF-NNN-***	M46	M46-046MV

M46-4331	MOTOR-VAR DISPL	MMV-046-C-A-A-F-C-AK-NNN-***	M46	M46-046MV
M46-4332	MOTOR-VAR DISPL	MMV-046-C-A-E-D-S-AM-NNN-***	M46	M46-046MV
M46-4333	MOTOR-VAR DISPL	MMV-046-C-A-E-D-X-AM-NNN-***	M46	M46-046MV
M46-4334	MOTOR-VAR DISPL	MMV-046-C-A-E-D-S-AW-NNN-***	M46	M46-046MV
M46-4335	MOTOR-VAR DISPL	MMV-046-C-A-E-3-A-AE-VNC-***	M46	M46-046MV
M46-4336	MOTOR-VAR DISPL	MMV-046-C-A-A-L-E-AM-NNN-***	M46	M46-046MV
M46-4337	MOTOR-VAR DISPL	MMV-046-C-A-E-3-A-A5-VNC-***	M46	M46-046MV
M46-4338	MOTOR-VAR DISPL	MMV-046-C-A-E-T-A-AE-NNN-***	M46	M46-046MV
M46-4340	MOTOR-VAR DISPL	MMV-046-C-A-A-L-E-A6-NNN-***	M46	M46-046MV
M46-4341	MOTOR-VAR DISPL	MMV-046-C-A-A-B-A-AF-VNA-***	M46	M46-046MV
M46-4342	MOTOR-VAR DISPL	MMV-046-C-A-E-H-B-AH-VNA-***	M46	M46-046MV
M46-4343	MOTOR-VAR DISPL	MMV-046-C-A-E-H-B-AU-VNA-***	M46	M46-046MV
M46-4344	MOTOR-VAR DISPL	MMV-046-C-A-A-W-A-AH-NNN-***	M46	M46-046MV
M46-4345	MOTOR-VAR DISPL	MMV-046-C-A-A-W-A-A4-NNN-***	M46	M46-046MV
M46-4346	MOTOR-VAR DISPL	MMV-046-C-A-A-L-A-AW-NNN-***	M46	M46-046MV
M46-4347	MOTOR-VAR DISPL	MMV-046-C-A-A-H-B-AU-VNA-***	M46	M46-046MV
M46-4348	MOTOR-VAR DISPL	MMV-046-C-A-A-L-X-AE-NNN-***	M46	M46-046MV
M46-4349	MOTOR-VAR DISPL	MMV-046-C-A-A-D-E-AA-NNN-***	M46	M46-046MV
M46-4350	MOTOR-VAR DISPL	MMV-046-C-A-E-2-A-AE-NNN-***	M46	M46-046MV
M46-4351	MOTOR-VAR DISPL	MMV-046-C-A-E-B-C-AY-NNN-***	M46	M46-046MV
M46-4352	MOTOR-VAR DISPL	MMV-046-C-A-A-A-A-AH-NNN-***	M46	M46-046MV
M46-4355	MOTOR-VAR DISPL	MMV-046-C-A-A-M-A-AA-NNC-***	M46	M46-046MV
M46-4356	MOTOR-VAR DISPL	MMV-046-C-A-A-A-C-AA-NNF-***	M46	M46-046MV
M91-2314	PUMP-TANDEM-VAR DISPL S10PT16		OSK S10/S15/S16/S	023PT
M91-25111	PUMP-TANDEM, VAR DISPL	MPT-025-C-S-R-A-E-NN-B-A-A-A-BDD-DL-A-FF-B-C-A-A-BDD-DR-A-FF-A-NNN-*	LIGHT DUTY	025PT
M91-25115	PUMP-TANDEM, VAR DISPL	MPT-025-C-S-R-A-E-NN-B-A-A-A-BGG-DL-A-FF-B-C-A-A-BGG-DL-A-FF-A-NNN-*	LIGHT DUTY	025PT
M91-25116	PUMP-TANDEM-VAR-DISPL MPT025	MPT-025-C-S-R-A-G-NN-B-A-A-A-BHH-DR-A-FF-B-C-A-A-BHH-DL-A-FF-A-NNN-*	LIGHT DUTY	025PT
M91-25122	PUMP-TANDEM, VAR DISPL	MPT-025-C-C-R-A-E-NN-B-A-A-A-BFF-DL-A-FF-B-C-A-A-BFF-DL-A-FF-A-NNN-***	LIGHT DUTY	025PT
M91-25124	PUMP-TANDEM-VAR-DISPL MPT025	MPT-025-C-S-R-A-G-NN-B-A-A-A-BJJ-DR-A-FF-B-C-A-A-BJJ-DL-A-FF-A-NNN-***	LIGHT DUTY	025PT
M91-25125	PUMP-TANDEM, VAR DISPL	MPT-025-C-C-L-A-G-NN-B-A-A-A-BFF-DR-A-FF-B-C-A-A-BFF-DR-A-FF-A-NNN-***	LIGHT DUTY	025PT
M91-25127	PUMP-TANDEM, VAR DISPL	MPT-025-C-S-R-A-G-NN-B-A-A-A-BMM-DL-A-FF-B-C-A-A-BMM-DL-A-FF-A-NNN	LIGHT DUTY	025PT
M91-25129	PUMP-TANDEM, VAR DISPL	MPT-025-C-S-R-A-E-NN-B-A-A-A-BBB-DR-A-FF-B-C-A-A-BBB-DR-A-FF-A-NNN-*	LIGHT DUTY	025PT
M91-25130	PUMP-TANDEM, VAR DISPL	MPT-025-C-C-L-A-E-NN-B-A-A-A-BFF-DL-A-FF-B-C-A-A-BFF-DL-A-FF-A-NNN-***	LIGHT DUTY	025PT
M91-25131	PUMP-TANDEM, VAR DISPL	MPT-025-C-S-R-A-E-NN-B-A-A-A-BFF-DL-A-FF-B-C-A-A-BFF-DL-A-FF-A-NNN-***	LIGHT DUTY	025PT
M91-25133	PUMP-TANDEM, VAR DISPL	MPT-025-C-S-R-A-E-NN-B-A-A-A-BDD-DL-A-FF-B-C-A-A-BDD-DL-A-FF-A-NNN-*	LIGHT DUTY	025PT
M91-25134	PUMP-TANDEM, VAR DISPL	MPT-025-C-S-R-A-E-NN-B-A-A-A-BHH-DL-A-FF-B-C-A-A-BHH-DR-A-FF-A-NNN-*	LIGHT DUTY	025PT

M91-25135	PUMP-TANDEM, VAR DISPL	MPT-025-C-S-R-A-E-NN-B-A-A-A-BDD-DR-A-FF-B-C-A-A-BDD-DR-A-FF-A-NNN-*	LIGHT DUTY	025PT
M91-25137	PUMP-TANDEM, VAR DISPL	MPT-025-C-S-R-A-E-NN-B-A-A-A-BDD-DR-A-FF-B-C-A-A-BDD-DL-A-FF-A-NNN-*	LIGHT DUTY	025PT
M91-25138	PUMP-TANDEM-VAR-DISPL MPT025	MPT-025-C-S-R-A-F-NN-B-A-A-A-BDD-DR-A-FF-B-C-A-A-BDD-DL-A-FF-A-NNN-*	LIGHT DUTY	025PT
M91-25139	PUMP-TANDEM, VAR DISPL	MPT-025-C-S-R-A-E-NN-B-A-A-A-BEE-DL-A-FF-B-C-A-A-BEE-DL-A-FF-A-NNN-***	LIGHT DUTY	025PT
M91-25141	PUMP-TANDEM, VAR DISPL	MPT-025-C-S-R-A-F-NN-B-A-A-A-BJJ-DL-A-FF-B-C-A-A-BJJ-DL-A-FF-A-NNN-***	LIGHT DUTY	025PT
M91-25142	PUMP-TANDEM, VAR DISPL	MPT-025-C-S-R-A-E-NN-B-A-A-A-BJJ-DL-A-FF-B-C-A-A-BJJ-DR-A-FF-A-NNN-***	LIGHT DUTY	025PT
M91-25144	PUMP-TANDEM, VAR DISPL	MPT-025-C-S-R-A-E-NN-B-A-A-A-BFF-DR-A-FF-B-C-A-A-BFF-DR-A-FF-A-NNN-**	LIGHT DUTY	025PT
M91-25145	PUMP-TANDEM, VAR DISPL	MPT-025-C-S-R-A-G-NN-B-A-A-A-BMM-DR-A-FF-B-C-A-A-BMM-DR-A-FF-A-NNN	LIGHT DUTY	025PT
M91-25146	PUMP-TANDEM, VAR DISPL	MPT-025-C-S-R-A-G-NN-B-A-A-A-BHH-DL-A-FF-B-C-A-A-BHH-DR-A-FF-A-NNN-*	LIGHT DUTY	025PT
M91-25148	PUMP-TANDEM, VAR DISPL	MPT-025-C-S-L-A-E-NN-B-A-A-A-BJJ-DL-A-FF-B-C-A-A-BJJ-DL-A-FF-A-NNN-***	LIGHT DUTY	025PT
M91-25149	PUMP-TANDEM, VAR DISPL	MPT-025-C-S-R-A-J-NN-B-A-A-A-BHH-DL-A-FF-B-C-A-A-BHH-DR-A-FF-A-NNN-*	LIGHT DUTY	025PT
M91-25152	PUMP-TANDEM, VAR DISPL	MPT-025-C-K-R-A-E-NN-B-A-A-A-BMM-DR-A-FF-B-C-A-A-BMM-DR-A-FF-A-NNN	LIGHT DUTY	025PT
M91-25153	PUMP-TANDEM, VAR DISPL	MPT-025-C-S-R-A-E-NN-B-A-A-A-BJJ-DR-A-FF-B-C-A-A-BJJ-DR-A-FF-A-NNN-***	LIGHT DUTY	025PT
M91-25154	PUMP-TANDEM, VAR DISPL	MPT-025-C-S-L-A-G-NN-B-A-A-A-BHH-DR-A-FF-B-C-A-A-BHH-DR-A-FF-A-NNN-*	LIGHT DUTY	025PT
M91-25155	PUMP-TANDEM, VAR DISPL	MPT-025-C-S-R-A-E-NN-B-A-A-A-BBB-DR-A-FF-B-C-A-A-BBB-DR-A-FF-D-NNN-*	LIGHT DUTY	025PT
M91-25156	PUMP-TANDEM, VAR DISPL	MPT-025-C-C-R-A-G-NN-B-A-A-A-BGG-DR-A-FF-B-A-A-A-BGG-DR-A-FF-A-NNN-	LIGHT DUTY	025PT
M91-25157	PUMP-TANDEM, VAR DISPL	MPT-025-C-C-R-A-E-NN-B-A-A-A-BFF-DR-A-FF-B-C-A-A-BFF-DR-A-FF-A-NNN-**	LIGHT DUTY	025PT
M91-25158	PUMP-TANDEM, VAR DISPL	MPT-025-C-C-R-A-G-NN-B-A-A-A-BGG-DR-A-FF-B-C-A-A-BGG-DR-A-FF-A-NNN-	LIGHT DUTY	025PT
M91-25159	PUMP-TANDEM, VAR DISPL	MPT-025-C-K-R-A-G-NN-B-A-A-A-BMM-DR-A-FF-B-C-A-A-BMM-DR-A-FF-A-NNN	LIGHT DUTY	025PT
M91-25160	PUMP-TANDEM, VAR DISPL	MPT-025-C-S-R-A-C-NN-B-A-A-A-BDD-DL-A-FF-B-C-A-A-BDD-DR-A-FF-A-NNN-*	LIGHT DUTY	025PT
M91-25162	PUMP-TANDEM, VAR DISPL	MPT-025-C-S-R-A-H-NN-B-A-A-A-BDD-DL-A-FF-B-C-A-A-BDD-DR-A-FF-A-NNN-*	LIGHT DUTY	025PT
M91-25166	PUMP-TANDEM-VAR-DISPL MPT025	MPT-025-C-S-R-A-V-NN-B-A-A-A-BFF-DR-A-FF-B-C-A-A-BMM-DR-A-FF-A-NNN-	LIGHT DUTY	025PT
M91-25167	PUMP-TANDEM, VAR DISPL	MPT-025-C-K-R-A-E-NN-B-A-A-A-BDD-DR-A-FF-B-C-A-A-BDD-DR-A-FF-A-NNN-*	LIGHT DUTY	025PT
M91-25168	PUMP-TANDEM, VAR DISPL	MPT-025-C-K-L-A-E-NN-B-A-A-A-BDD-DR-A-FF-B-C-A-A-BDD-DR-A-FF-A-NNN-*	LIGHT DUTY	025PT
M91-25170	PUMP-TANDEM, VAR DISPL	MPT-025-C-C-Y-A-E-NN-B-A-A-A-BGG-DL-A-FF-B-C-A-A-BGG-DL-A-FF-A-NNN-*	LIGHT DUTY	025PT
M91-25177	PUMP-TANDEM-VAR-DISPL MPT025	MPT-025-C-S-R-A-G-NN-B-A-A-A-BDD-DR-A-FF-B-C-A-A-BDD-DR-A-FF-A-NNN-*	LIGHT DUTY	025PT
M91-25178	PUMP-TANDEM, VAR DISPL	MPT-025-C-U-W-A-G-NN-B-A-A-A-BCC-DR-A-FF-B-C-A-A-BCC-DR-A-FF-R-GPR-*	LIGHT DUTY	025PT
M91-25179	PUMP-TANDEM, VAR DISPL	MPT-025-C-S-R-A-G-NN-B-A-A-A-BFF-DR-A-FF-B-C-A-A-BFF-DR-A-FF-A-NNN-**	LIGHT DUTY	025PT
M91-25180	PUMP-TANDEM, VAR DISPL	MPT-025-C-S-R-A-C-NN-B-A-A-A-BFF-DR-A-FF-B-C-A-A-BFF-DR-A-FF-A-NNN-**	LIGHT DUTY	025PT
M91-25181	PUMP-TANDEM, VAR DISPL	MPT-025-C-U-W-A-G-NN-B-A-A-A-BJJ-DR-A-FF-B-C-A-A-BJJ-DR-A-FF-R-GPR-***	LIGHT DUTY	025PT
M91-25182	PUMP-TANDEM, VAR DISPL	MPT-025-C-S-R-A-C-NN-B-A-A-A-BJJ-DR-A-FF-B-C-A-A-BJJ-DR-A-FF-A-NNN-***	LIGHT DUTY	025PT
M91-25183	PUMP-TANDEM, VAR DISPL	MPT-025-C-S-L-A-G-NN-B-A-A-A-BMM-DL-A-FF-B-C-A-A-BMM-DL-A-FF-A-NNN	LIGHT DUTY	025PT
M91-25184	PUMP-TANDEM, VAR DISPL	MPT-025-C-S-R-A-G-NN-B-A-A-A-BGG-DL-A-FF-B-C-A-A-BGG-DR-A-FF-A-NNN-*	LIGHT DUTY	025PT
M91-25185	PUMP-TANDEM, VAR DISPL	MPT-025-C-S-L-A-E-NN-B-A-A-A-BDD-DR-A-FF-B-C-A-A-BDD-DR-A-FF-A-NNN-*	LIGHT DUTY	025PT
M91-25186	PUMP-TANDEM, VAR DISPL	MPT-025-C-U-W-A-G-NN-B-A-A-A-EFF-DR-A-FF-B-C-A-A-EFF-DR-A-FF-R-GPR-*	LIGHT DUTY	025PT
M91-25187	PUMP-TANDEM, VAR DISPL	MPT-025-C-C-Y-A-G-NN-B-A-A-A-BDD-DR-A-FF-B-C-A-A-BDD-DL-A-FF-A-NNN-*	LIGHT DUTY	025PT

M91-25188	PUMP-TANDEM, VAR DISPL	MPT-025-C-K-Y-A-G-NN-B-A-A-A-BDD-DR-A-FF-B-C-A-A-BDD-DL-A-FF-H-NNN-*	LIGHT DUTY	025PT
M91-25189	PUMP-TANDEM, VAR DISPL	MPT-025-C-U-7-A-G-NN-B-A-A-A-BGG-DR-A-FF-B-C-A-A-BGG-DR-A-FF-R-GPR-*	LIGHT DUTY	025PT
M91-25191	PUMP-TANDEM, VAR DISPL	MPT-025-C-S-W-A-E-NN-B-A-A-A-BGG-DL-A-FF-B-C-A-A-BGG-DL-A-FF-A-NNN-*	LIGHT DUTY	025PT
M91-25192	PUMP-TANDEM, VAR DISPL	MPT-025-C-K-Y-A-E-NN-B-A-A-A-BDD-DL-A-FF-B-C-A-A-BDD-DR-A-FF-A-NNN-*	LIGHT DUTY	025PT
M91-25193	PUMP-TANDEM, VAR DISPL	MPT-025-C-U-W-A-G-NN-B-A-A-A-EDD-DR-A-FF-B-C-A-A-EDD-DR-A-FF-R-GPR-*	LIGHT DUTY	025PT
M91-25194	PUMP-TANDEM, VAR DISPL	MPT-025-C-S-W-A-V-NN-B-A-A-A-BJJ-DL-A-FF-B-C-A-A-BJJ-DL-A-FF-A-NNN-***	LIGHT DUTY	025PT
M91-25196	PUMP-TANDEM, VAR DISPL	MPT-025-C-S-R-A-H-NN-B-A-A-A-BJJ-DR-A-FF-B-C-A-A-BJJ-DR-A-FF-A-NNN-***	LIGHT DUTY	025PT
M91-25197	PUMP-TANDEM-VAR-DISPL MPT025	MPT-025-C-S-7-A-G-NN-B-A-A-A-BJJ-DL-A-FF-B-C-A-A-BJJ-DL-A-FF-A-NNN-***	LIGHT DUTY	025PT
M91-25198	PUMP-TANDEM, VAR DISPL	MPT-025-C-S-R-A-G-NN-B-A-A-A-BHH-DR-A-FF-B-C-A-A-BHH-DR-A-FF-A-NNN-*	LIGHT DUTY	025PT
M91-25200	PUMP-TANDEM, VAR DISPL	MPT-025-C-S-R-A-H-NN-B-A-A-A-BDD-DR-A-FF-B-C-A-A-BDD-DL-A-FF-A-NNN-*	LIGHT DUTY	025PT
M91-25201	PUMP-TANDEM, VAR DISPL	MPT-025-C-K-R-A-G-NN-B-A-A-A-BBB-DL-A-FF-B-C-A-A-BBB-DL-A-FF-A-NNN-*	LIGHT DUTY	025PT
M91-25202	PUMP-TANDEM-VAR-DISPL MPT025	MPT-025-C-S-R-A-G-NN-B-A-A-A-BFF-DR-A-FF-B-C-A-A-BFF-DL-A-FF-A-NNN-**	LIGHT DUTY	025PT
M91-25203	PUMP-TANDEM, VAR DISPL	MPT-025-C-C-7-A-G-NN-B-A-A-A-BJJ-DL-A-FF-B-C-A-A-BJJ-DL-A-FF-D-NNN-***	LIGHT DUTY	025PT
M91-25204	PUMP-TANDEM, VAR DISPL	MPT-025-C-S-W-A-G-NN-B-A-A-A-BHH-DR-A-FF-B-C-A-A-BHH-DR-A-FF-A-NNN-*	LIGHT DUTY	025PT
M91-25206	PUMP-TANDEM, VAR DISPL	MPT-025-C-S-R-A-3-NN-B-A-A-A-BJJ-DR-A-FF-B-C-A-A-BJJ-DR-A-FF-A-NNN-***	LIGHT DUTY	025PT
M91-25207	PUMP-TANDEM, VAR DISPL	MPT-025-C-C-7-A-G-NN-B-A-A-A-BJJ-DR-A-FF-B-C-A-A-BJJ-DR-A-FF-A-NNN-***	LIGHT DUTY	025PT
M91-25208	PUMP-TANDEM, VAR DISPL	MPT-025-C-S-R-A-G-NN-B-A-A-A-BDD-DL-A-FF-B-C-A-A-BDD-DR-A-FF-A-NNN-*	LIGHT DUTY	025PT
M91-25209	PUMP-TANDEM, VAR DISPL	MPT-025-C-U-W-A-C-NN-B-A-A-A-EDD-DR-A-FF-B-C-A-A-EDD-DR-A-FF-R-GPR-*	LIGHT DUTY	025PT
M91-25210	PUMP-TANDEM, VAR DISPL	MPT-025-C-C-Y-A-H-NN-B-A-A-A-BJJ-DL-A-FF-B-C-A-A-BJJ-DL-A-FF-D-NNN-***	LIGHT DUTY	025PT
M91-25211	PUMP-TANDEM, VAR DISPL	MPT-025-C-S-7-A-H-NN-B-A-A-A-BJJ-DR-A-FF-B-C-A-A-BJJ-DR-A-FF-D-NNN-***	LIGHT DUTY	025PT
M91-25212	PUMP-TANDEM, VAR DISPL	MPT-025-C-S-W-A-E-NN-B-A-A-A-BDD-DR-A-FF-B-C-A-A-BDD-DR-A-FF-A-NNN-*	LIGHT DUTY	025PT
M91-25213	PUMP-TANDEM, VAR DISPL	MPT-025-C-K-Y-A-G-NN-B-A-A-A-BDD-DL-A-FF-B-C-A-A-BDD-DR-A-FF-A-NNN-*	LIGHT DUTY	025PT
M91-25214	PUMP-TANDEM, VAR DISPL	MPT-025-C-S-7-A-H-NN-B-A-A-A-BJJ-DR-A-FF-B-C-A-A-BJJ-DR-A-FF-A-NNN-***	LIGHT DUTY	025PT
M91-25215	PUMP-TANDEM-VAR-DISPL MPT025	MPT-025-C-S-W-A-A-NN-B-A-A-A-BGG-DL-A-FF-B-C-A-A-BGG-DL-A-FF-A-NNN-*	LIGHT DUTY	025PT
M91-25217	PUMP-TANDEM, VAR DISPL	MPT-025-C-S-7-A-3-NN-B-A-A-A-BHH-DR-A-FF-B-C-A-A-BHH-DR-A-FF-D-NNN-*	LIGHT DUTY	025PT
M91-25219	PUMP-TANDEM, VAR DISPL	MPT-025-C-S-L-A-G-NN-B-A-A-A-BDD-DR-A-FF-B-C-A-A-BDD-DR-A-FF-A-NNN-*	LIGHT DUTY	025PT
M91-25220	PUMP-TANDEM, VAR DISPL	MPT-025-C-S-L-A-G-NN-B-A-A-A-BDD-DL-A-FF-B-C-A-A-BDD-DL-A-FF-A-NNN-*	LIGHT DUTY	025PT
M91-25221	PUMP-TANDEM, VAR DISPL	MPT-025-C-U-7-A-F-NN-B-A-A-A-BHH-DL-A-FF-B-C-A-A-BHH-DL-A-FF-R-GPR-*	LIGHT DUTY	025PT
M91-25222	PUMP-TANDEM, VAR DISPL	MPT-025-C-K-R-A-E-NN-B-A-A-A-BFF-DR-A-FF-B-C-A-A-BFF-DR-A-FF-A-NNN-**	LIGHT DUTY	025PT
M91-25224	PUMP-TANDEM-VAR-DISPL MPT025	MPT-025-C-S-7-A-G-NN-B-A-A-A-BCC-DR-A-FF-B-C-A-A-BCC-DR-A-FF-A-NNN-*	LIGHT DUTY	025PT
M91-25225	PUMP-TANDEM, VAR DISPL	MPT-025-C-S-W-A-G-NN-B-A-A-A-BDD-DL-A-FF-B-C-A-A-BDD-DL-A-FF-A-NNN-*	LIGHT DUTY	025PT
M91-25226	PUMP-TANDEM, VAR DISPL	MPT-025-C-C-L-A-V-NN-B-A-A-A-BGG-DR-A-FF-B-C-A-A-BGG-DR-A-FF-A-NNN-*	LIGHT DUTY	025PT
M91-25227	PUMP-TANDEM, VAR DISPL	MPT-025-C-S-Y-A-G-NN-B-A-A-A-BDD-DL-A-FF-B-C-A-A-BDD-DL-A-FF-A-NNN-*	LIGHT DUTY	025PT
M91-25228	PUMP-TANDEM, VAR DISPL	MPT-025-C-S-R-A-E-NN-B-A-A-A-BCC-DR-A-FF-B-C-A-A-BCC-DR-A-FF-D-NNN-*	LIGHT DUTY	025PT
M91-25229	PUMP-TANDEM, VAR DISPL	MPT-025-C-S-R-A-G-NN-B-A-A-A-BJJ-DL-A-FF-B-C-A-A-BJJ-DL-A-FF-A-NNN-***	LIGHT DUTY	025PT
M91-25231	PUMP-TANDEM, VAR DISPL	MPT-025-C-S-W-A-E-NN-B-A-A-A-BJJ-DR-A-FF-B-C-A-A-BJJ-DR-A-FF-A-NNN-***	LIGHT DUTY	025PT

M91-25232	PUMP-TANDEM, VAR DISPL	MPT-025-C-C-7-A-G-NN-B-A-A-A-BBB-DL-A-FF-B-C-A-A-BBB-DL-A-FF-D-NNN-*	LIGHT DUTY	025PT
M91-25234	PUMP-TANDEM, VAR DISPL	MPT-025-C-S-W-A-J-NN-B-A-A-A-BBB-DR-A-FF-B-C-A-A-BBB-DR-A-FF-A-NNN-*	LIGHT DUTY	025PT
M91-25235	PUMP-TANDEM, VAR DISPL	MPT-025-C-S-W-A-G-NN-B-A-A-A-BHH-DR-A-FF-B-C-A-A-BHH-DL-A-FF-A-NNN-	LIGHT DUTY	025PT
M91-25236	PUMP-TANDEM, VAR DISPL	MPT-025-C-S-W-A-G-NN-B-A-A-A-BHH-DR-A-FF-B-C-A-A-BFF-DL-A-FF-A-NNN-*	LIGHT DUTY	025PT
M91-25237	PUMP-TANDEM, VAR DISPL	MPT-025-C-S-W-A-E-NN-B-A-A-A-BGG-DR-A-FF-B-C-A-A-BGG-DR-A-FF-A-NNN-	LIGHT DUTY	025PT
M91-25238	PUMP-TANDEM, VAR DISPL	MPT-025-C-S-W-A-C-NN-B-A-A-A-BFF-DL-A-FF-B-C-A-A-BFF-DL-A-FF-A-NNN-*	LIGHT DUTY	025PT
M91-25239	PUMP-TANDEM, VAR DISPL	MPT-025-C-S-L-A-J-NN-B-A-A-A-BBB-DL-A-FF-B-A-A-A-BBB-DL-A-FF-D-NNN-*	LIGHT DUTY	025PT
M91-25240	PUMP-TANDEM, VAR DISPL	MPT-025-C-K-W-A-G-NN-B-A-A-A-BDD-DL-A-FF-B-C-A-A-BDD-DL-A-FF-A-NNN-	LIGHT DUTY	025PT
M91-25242	PUMP-TANDEM, VAR DISPL	MPT-025-C-S-R-A-J-NN-B-A-A-A-BBB-DL-A-FF-B-A-A-A-BBB-DL-A-FF-A-NNN-*	LIGHT DUTY	025PT
M91-25243	PUMP-TANDEM, VAR DISPL	MPT-025-C-S-R-A-G-NN-B-A-A-A-BHH-DL-A-FF-B-C-A-A-BHH-DL-A-FF-A-NNN-*	LIGHT DUTY	025PT
M91-25904	PUMP-TANDEM CW	MPT-025-C-C-R-A-E-NN-B-A-A-A-BFF-DL-A-FF-B-C-A-A-BFF-DL-A-FF-H-GRC-***	LIGHT DUTY	025PT
M91-25909	PUMP-TANDEM CW	MPT-025-C-U-W-A-G-NN-B-A-A-A-BFF-DR-A-FF-B-C-A-A-BFF-DR-A-FF-R-GPR-*	LIGHT DUTY	025PT
M91-46102	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-BA-B-A-A-A-BGG-AB-U-ED-B-C-A-A-BGG-AB-D-ED-C-NNN-	M46	M46-046PT
M91-46108	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-D-C-A-BA-B-A-A-A-BJJ-AB-U-DD-B-C-A-A-BJJ-AB-D-DD-B-NNN-*	M46	M46-046PT
M91-46109	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-D-C-A-BA-B-A-A-A-BGG-AB-U-ED-B-C-A-A-BGG-AB-U-ED-A-NNN-	M46	M46-046PT
M91-46113	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-AA-B-A-A-A-BHH-AB-U-CD-B-C-A-A-BBB-AB-D-CD-A-NNN-	M46	M46-046PT
M91-46126	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-B-BA-B-A-A-A-BJJ-AB-U-ED-B-C-A-A-BJJ-AB-D-ED-C-NNN-*	M46	M46-046PT
M91-46132	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-V-C-J-BA-B-A-A-A-BJJ-AC-D-ZC-B-C-A-A-BJJ-AC-U-ZC-C-NNN-***	M46	M46-046PT
M91-46138	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-V-C-U-AA-B-A-A-B-BHH-AD-U-FF-B-C-A-B-BHH-AB-D-FF-C-NNN-*	M46	M46-046PT
M91-46139	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-V-C-U-AA-B-A-B-C-BDD-AE-U-PF-B-C-B-C-BDD-AB-D-PF-C-NNN-*	M46	M46-046PT
M91-4614	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-BA-B-A-A-A-BJJ-AB-U-ED-B-C-A-A-BJJ-AB-D-ED-B-NNN-*	M46	M46-046PT
M91-46140	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-V-C-U-AA-B-A-A-C-BGG-AB-U-PF-B-C-A-C-BGG-AB-D-PF-C-NNN-*	M46	M46-046PT
M91-46145	PUMP-TANDEM VAR DISPL	MPT-046-C-E-V-C-M-AA-B-A-A-B-BJJ-GE-U-KF-B-C-A-B-BJJ-GE-D-KF-C-ANN-***	M46	M46-046PT
M91-46147	PUMP-TANDEM VAR DISPL	MPT-046-C-E-V-C-S-AA-B-A-A-A-BHH-GG-B-KF-B-C-A-A-BHH-GG-B-KF-Y-NNL-*	M46	M46-046PT
M91-46148	PUMP-TANDEM VAR DISPL	MPT-046-C-E-V-C-S-AA-B-A-A-A-BJJ-GG-B-KF-B-C-A-A-BJJ-GG-B-KF-Y-NAB-***	M46	M46-046PT
M91-46155	PUMP-TANDEM VAR DISPL	MPT-046-C-E-V-C-S-AA-B-A-A-A-BJJ-GG-B-KF-B-C-A-A-BJJ-GG-B-KF-B-NAC-***	M46	M46-046PT
M91-46156	PUMP-TANDEM VAR DISPL	MPT-046-C-E-V-C-S-AA-B-A-C-A-BHH-GG-B-KF-B-C-C-A-BHH-GG-B-KF-Y-GDG-*	M46	M46-046PT
M91-46157	PUMP-TANDEM VAR DISPL	MPT-046-C-E-V-C-S-AA-B-A-C-A-BHH-GG-B-KF-B-C-C-A-BHH-GG-B-KF-B-NNA-*	M46	M46-046PT
M91-4617	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-BA-B-A-A-A-BFF-AB-U-ED-B-C-A-A-BFF-AB-U-ED-A-NNN-*	M46	M46-046PT
M91-46201	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-D-C-A-AA-B-A-A-A-BFF-AB-U-ED-B-C-A-A-BFF-AB-U-ED-C-NNN-*	M46	M46-046PT
M91-46204	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-D-C-A-AA-B-A-A-A-BBB-AB-U-ED-B-C-A-A-BGG-AB-U-ED-C-NNN-	M46	M46-046PT
M91-46205	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-D-C-A-AA-B-A-A-A-BFF-AB-U-ED-B-C-A-A-BFF-AB-U-ED-A-NNN-*	M46	M46-046PT
M91-46206	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-C-C-A-AA-B-A-A-B-BCC-AB-U-EF-B-C-A-B-BCC-AB-D-EF-C-NNN-*	M46	M46-046PT
M91-4621	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-D-C-A-BA-B-A-A-A-BJJ-AB-U-ED-B-C-A-A-BJJ-AB-U-ED-A-NNN-*	M46	M46-046PT
M91-46216	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-D-C-A-BA-B-A-G-A-BBB-AB-D-AA-B-C-G-A-BBB-AB-D-AA-A-NNN-	M46	M46-046PT
M91-46219	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-AA-B-A-A-A-BJJ-AB-U-CD-B-C-A-A-BBB-AB-D-CD-A-NNC-*	M46	M46-046PT

M91-46224	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-G-A-A-BC-B-A-A-A-BJJ-AB-U-CD-B-C-A-A-BJJ-AB-D-CD-A-NNN-**	M46	M46-046PT
M91-46227	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-D-C-A-BA-B-A-A-A-BBB-AB-U-ED-B-C-A-A-BBB-AB-D-ED-B-NNN-*	M46	M46-046PT
M91-46228	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-D-C-A-AA-B-A-A-A-BBB-AB-U-ED-B-C-A-A-BBB-AB-D-ED-B-NNN-*	M46	M46-046PT
M91-46231	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-D-C-A-AA-B-A-A-A-BGB-AB-U-AA-B-C-A-A-BGB-AB-U-AA-C-NNN-	M46	M46-046PT
M91-46233	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-D-C-A-AA-B-A-A-A-BJJ-AB-U-FF-B-C-A-A-BJJ-AB-D-FF-A-NNN-***	M46	M46-046PT
M91-46234	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-D-C-A-AA-B-A-A-A-BGB-AB-U-AA-B-C-A-A-BGB-AB-U-AA-A-NNN-	M46	M46-046PT
M91-46235	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-C-C-B-AA-B-A-B-C-BFF-AB-U-PF-B-C-B-C-BFF-AB-D-PF-C-NNN-***	M46	M46-046PT
M91-46236	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-D-C-A-AA-B-A-A-A-BBB-AB-D-AA-B-C-A-A-BBB-AB-D-AA-B-NNN-;	M46	M46-046PT
M91-46239	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-AA-B-A-A-A-BBB-AB-D-AA-B-C-A-A-BBB-AB-D-AA-B-NNN-;	M46	M46-046PT
M91-46241	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-C-C-A-AA-B-A-A-A-BBB-AB-D-AA-B-C-A-A-BBB-AB-D-AA-B-NNN-*	M46	M46-046PT
M91-46245	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-D-C-A-AA-B-A-A-A-BJJ-AB-U-DD-B-C-A-A-BJJ-AB-U-DD-C-NNN-*	M46	M46-046PT
M91-46247	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-C-C-A-AA-B-A-A-A-BJJ-AB-U-AA-B-C-A-A-BJJ-AB-U-AA-B-NNN-***	M46	M46-046PT
M91-46248	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-C-C-A-AA-B-A-A-A-BJJ-AB-U-AA-B-C-A-A-BJJ-AB-U-AA-D-NNN-**	M46	M46-046PT
M91-46249	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-D-C-A-BA-B-A-A-A-BJJ-AB-U-ED-B-C-A-A-BJJ-AB-D-ED-C-NNN-***	M46	M46-046PT
M91-46250	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-D-C-A-AA-B-B-A-A-BFF-CD-A-GG-B-D-A-A-BFF-CD-A-GG-A-NNN-;	M46	M46-046PT
M91-46253	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-G-A-A-BC-B-A-A-A-BJJ-AB-U-ED-B-C-A-A-BJJ-AB-D-ED-C-NNN-***	M46	M46-046PT
M91-46254	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-C-C-A-AA-B-A-A-A-BJJ-AB-U-ED-B-C-A-A-BJJ-AB-D-ED-C-NNN-***	M46	M46-046PT
M91-46255	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-AA-B-A-A-A-BCC-AB-U-BB-B-C-A-A-BCC-AB-U-BB-A-NNN-*	M46	M46-046PT
M91-46256	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-AA-B-A-A-A-BCC-AB-U-BB-B-C-A-A-BCC-AB-U-BB-C-NNN-*	M46	M46-046PT
M91-46261	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-C-C-B-AA-B-A-B-C-BDD-AB-U-PF-B-C-B-BDD-AB-D-PF-C-NNN-*	M46	M46-046PT
M91-46264	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-D-C-A-AA-B-A-A-A-BEE-AB-D-DD-B-C-A-A-BEE-AB-D-DD-A-NNN-;	M46	M46-046PT
M91-46266	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-J-A-BC-B-A-A-A-BJJ-AB-U-ED-B-D-G-A-BGG-DA-A-GG-A-NNN-*	M46	M46-046PT
M91-46270	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-AA-B-A-A-A-BDD-AB-U-DB-B-C-A-A-BDD-AB-D-DB-A-NNN-	M46	M46-046PT
M91-46272	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-AA-B-A-A-A-BJJ-AB-D-FD-B-C-A-A-BJJ-AB-D-FD-A-NNN-***	M46	M46-046PT
M91-46275	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-C-C-J-AA-B-A-A-A-BJJ-AB-U-AA-B-C-A-A-BJJ-AB-U-AA-B-NNN-***	M46	M46-046PT
M91-46281	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-C-C-A-AA-B-A-A-A-BJJ-AB-U-ED-B-C-A-A-BJJ-AB-U-ED-B-NNN-***	M46	M46-046PT
M91-46282	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-C-C-J-AA-B-A-A-A-BJJ-AB-U-ED-B-C-A-A-BJJ-AB-U-ED-B-NNN-***	M46	M46-046PT
M91-46283	PUMP-TANDEM, VAR	MPT-046-C-A-C-C-A-BA-B-A-A-B-BFF-AB-D-CF-B-C-A-B-BFF-AB-U-CF-A-NNN-**	M46	M46-046PT
M91-46285	PUMP-TANDEM VAR DISPL	MPT-046-C-E-C-C-B-AA-B-A-A-C-BGG-AB-U-PF-B-C-A-C-BGG-AB-D-PF-C-NNN-*	M46	M46-046PT
M91-46286	PUMP-TANDEM VAR DISPL	MPT-046-C-A-C-C-A-BA-B-A-A-A-BBB-AB-U-ED-B-C-A-A-BBB-AB-D-ED-C-NNN-*	M46	M46-046PT
M91-46287	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-G-A-A-BC-B-A-A-A-BGG-AB-D-DD-B-C-A-A-BGG-AB-U-DD-C-NNN	M46	M46-046PT
M91-46288	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-BA-B-A-A-B-BBB-AB-U-ED-B-C-A-B-BBB-AB-U-ED-C-NNN-*	M46	M46-046PT
M91-46289	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-BA-B-A-A-A-BBB-AB-U-ED-B-C-A-A-BBB-AB-U-ED-C-NNN-*	M46	M46-046PT
M91-46290	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-D-C-A-BA-B-B-A-A-BBB-CD-A-GG-B-D-A-A-BBB-CD-A-GG-A-NNN-	M46	M46-046PT
M91-46291	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-D-C-A-BA-B-B-A-A-BBB-CG-A-GG-B-D-A-A-BBB-CG-A-GG-A-NNN-	M46	M46-046PT
M91-46292	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-C-C-A-BA-B-A-A-B-BHH-AB-U-FD-B-C-A-B-BHH-AB-D-FD-C-NNN-*	M46	M46-046PT

M91-46294	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-D-C-A-AA-B-A-A-A-BJJ-AB-U-AA-B-C-A-A-BJJ-AB-U-AA-A-NNN-*	M46	M46-046PT
M91-46295	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-C-C-A-BA-B-A-A-B-BHH-AB-U-FD-B-C-A-B-BHH-AB-D-FD-C-ANN-*	M46	M46-046PT
M91-46296	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-BA-B-A-A-A-BJJ-AB-U-FF-B-C-A-A-BJJ-AB-U-FF-B-NNN-***	M46	M46-046PT
M91-46297	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-AA-B-A-A-A-BHH-AB-D-BF-B-C-A-A-BHH-AB-D-BF-A-NNN-*	M46	M46-046PT
M91-46298	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-BA-B-A-A-A-BHH-AB-U-ED-B-C-A-A-BHH-AB-U-ED-D-NNN-	M46	M46-046PT
M91-46299	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-D-C-A-AA-B-A-A-A-BBG-AB-U-AA-B-C-A-A-BGB-AB-U-AA-C-NNN-	M46	M46-046PT
M91-46300	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-D-C-A-AA-B-A-A-A-BBG-AB-U-AA-B-C-A-A-BGB-AB-U-AA-B-NNN-	M46	M46-046PT
M91-46301	PUMP-TANDEM, VAR DISPL	MPT-046-C-D-D-C-A-AA-B-A-A-A-BBG-AB-U-AA-B-C-A-A-BGB-AB-U-AA-B-NNN-	M46	M46-046PT
M91-46302	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-D-C-A-AA-B-A-A-A-BBG-AB-U-AA-B-C-A-A-BGB-AB-U-AA-A-NNN-	M46	M46-046PT
M91-46303	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-G-A-A-BC-B-A-A-A-BDD-AB-U-ED-B-C-A-A-BDD-AB-U-ED-A-NNN-	M46	M46-046PT
M91-46304	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-AA-B-A-A-A-BHH-AB-D-BF-B-C-A-A-BHH-AB-D-BF-B-NNN-*	M46	M46-046PT
M91-46307	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-C-C-A-BA-B-A-A-A-BGG-AB-D-DD-B-C-A-A-BGG-AB-U-DD-A-NNN-	M46	M46-046PT
M91-46308	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-C-C-A-BA-B-A-A-A-BGG-AB-D-DD-B-C-A-A-BGG-AB-U-DD-D-NNN-	M46	M46-046PT
M91-46309	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-BA-B-B-A-A-BFF-BA-A-GG-B-D-A-A-BFF-BA-A-GG-B-NNN-*	M46	M46-046PT
M91-46311	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-BA-B-A-G-A-BBB-AB-D-AA-B-C-G-A-BBB-AB-D-AA-A-NNN-	M46	M46-046PT
M91-46312	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-BA-B-B-A-A-BGG-CD-A-GG-B-D-A-A-BGG-CD-A-GG-C-NNN-	M46	M46-046PT
M91-46315	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-D-C-A-BA-B-B-A-A-BHH-CB-A-GG-B-D-A-A-BHH-CB-A-GG-B-NNN-	M46	M46-046PT
M91-46316	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-D-C-A-AA-B-B-A-A-BHH-CB-A-GG-B-D-A-A-BHH-CB-A-GG-C-NNN-	M46	M46-046PT
M91-46317	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-AA-B-B-A-A-BGG-CB-A-GG-B-D-A-A-BGG-CB-A-GG-C-NNN-	M46	M46-046PT
M91-46318	PUMP-TANDEM-VAR-DISPL MPT046	MPT-046-C-A-D-C-A-AA-B-B-A-A-BGG-CB-A-GG-B-D-A-A-BGG-CB-A-GG-B-NNN-	M46	M46-046PT
M91-46320	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-AA-B-A-A-A-BGG-AB-U-ED-B-D-A-A-BGG-CB-A-GG-A-NNN-	M46	M46-046PT
M91-46323	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-BA-B-B-A-A-BGG-CB-A-HH-B-D-A-A-BGG-CB-A-GG-B-NNN-	M46	M46-046PT
M91-46324	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-D-C-A-AA-B-B-A-A-BDD-CB-A-GG-B-D-A-A-BDD-CB-A-GG-C-NNN-	M46	M46-046PT
M91-46326	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-BA-B-A-A-A-BJJ-AB-U-ED-B-C-A-A-BJB-AB-U-ED-A-NNN-*	M46	M46-046PT
M91-46327	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-C-C-B-AA-B-A-A-C-BGG-AB-U-PF-B-C-A-C-BGG-AB-D-PF-C-ANN-*	M46	M46-046PT
M91-46328	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-D-C-A-BA-B-B-A-A-BHH-CE-A-GG-B-D-A-A-BHH-CE-A-GG-B-NNN-	M46	M46-046PT
M91-46330	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-C-C-A-BA-B-A-A-A-BFF-AB-U-BB-B-C-A-A-BFF-AB-D-BB-A-NNN-*	M46	M46-046PT
M91-46331	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-AA-B-A-A-A-BFF-AB-U-ED-B-C-A-A-BFF-AB-U-ED-D-NNN-*	M46	M46-046PT
M91-46332	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-AA-B-A-A-A-BJJ-AB-U-ZP-B-C-A-A-BBB-AB-D-ZP-A-NNN-*	M46	M46-046PT
M91-46334	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-D-C-A-BA-B-B-A-A-BHH-CB-A-GG-B-D-A-A-BHH-CB-A-GG-D-NNN-	M46	M46-046PT
M91-46336	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-AA-B-A-A-A-BFF-AB-U-DB-B-C-A-A-BFF-AB-U-DB-A-NNN-*	M46	M46-046PT
M91-46337	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-D-C-A-AA-B-B-A-A-BEE-CB-A-GG-B-D-A-A-BEE-CB-A-GG-B-NNN-*	M46	M46-046PT
M91-46338	PUMP-TANDEM-VAR-DISPL MPT046	MPT-046-C-A-C-C-A-BA-B-B-A-A-BHH-CB-A-JJ-B-D-A-A-BHH-CB-A-JJ-B-NNN-*	M46	M46-046PT
M91-46339	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-BA-B-B-A-A-BHH-CB-A-GG-B-D-A-A-BHH-CB-A-GG-B-NNN-	M46	M46-046PT
M91-4634	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-AA-B-A-A-A-BJJ-AB-U-ED-B-C-A-A-BJJ-AB-U-ED-A-NNN-*	M46	M46-046PT
M91-46342	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-D-C-A-AA-B-B-G-A-BEE-CB-A-GG-B-D-G-A-BEE-CB-A-GG-B-NNN-	M46	M46-046PT

M91-46343	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-AA-B-B-G-A-BEE-CB-A-GG-B-D-G-A-BEE-CB-A-GG-B-NNN-*	M46	M46-046PT
M91-46347	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-D-C-D-BA-B-A-A-A-BDD-AB-U-ED-B-C-A-A-BJB-AB-D-FF-A-NNN-*	M46	M46-046PT
M91-46348	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-BA-B-B-A-A-BFF-CB-A-GG-B-D-A-A-BFF-CB-A-GG-A-NNN-*	M46	M46-046PT
M91-46351	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-G-A-A-BC-B-A-A-B-BJJ-AB-U-FD-B-C-A-B-BJJ-AB-D-FD-B-ANN-***	M46	M46-046PT
M91-46353	PUMP-TANDEM, VAR DISPL	MPT-046-C-D-D-C-A-AA-B-B-A-A-BEE-CD-A-HH-B-D-A-A-BEE-CD-A-HH-A-NNN-	M46	M46-046PT
M91-46354	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-BA-B-A-A-A-BGG-AB-U-EA-B-C-A-A-BGG-AB-U-EA-A-NNN-	M46	M46-046PT
M91-46355	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-BA-B-B-A-A-BDD-CD-A-GG-B-D-A-A-BDD-CD-A-GG-B-NNN	M46	M46-046PT
M91-46356	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-D-C-A-AA-B-B-A-A-BJJ-CB-A-GG-B-D-A-A-BJJ-CB-A-GG-C-NNN-**	M46	M46-046PT
M91-46357	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-D-C-A-AA-B-B-A-A-BJJ-CE-A-GG-B-D-A-A-BJJ-CE-A-GG-C-NNN-**	M46	M46-046PT
M91-46358	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-AA-B-B-A-A-BJJ-CB-A-HH-B-D-A-A-BJJ-CB-A-HH-C-NNN-**	M46	M46-046PT
M91-46359	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-BA-B-B-A-B-BJJ-CE-A-GG-B-D-A-B-BJJ-CE-A-GG-B-NNN-***	M46	M46-046PT
M91-4636	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-D-C-A-AA-B-A-A-A-BGG-AB-U-ED-B-C-A-A-BGG-AB-U-ED-A-NNN	M46	M46-046PT
M91-46361	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-D-C-A-BA-B-B-A-A-BBF-DA-A-RR-B-D-A-A-BBF-DA-A-RR-C-ANN-*	M46	M46-046PT
M91-46362	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-C-C-A-BA-B-A-A-A-BDD-AB-U-AB-B-C-A-A-BGG-AB-D-FB-A-NNN-	M46	M46-046PT
M91-46363	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-D-C-A-BA-B-B-A-A-BBF-DA-A-RR-B-D-A-A-BBF-DA-A-RR-C-ANN-*	M46	M46-046PT
M91-46364	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-BA-B-B-A-A-BGG-CB-A-GG-B-D-A-A-BGG-CB-A-GG-B-NNN	M46	M46-046PT
M91-46365	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-BA-B-B-A-A-BBB-CG-A-GG-B-D-A-A-BBB-CG-A-GG-A-NNN-	M46	M46-046PT
M91-46366	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-D-C-A-BA-B-A-A-A-BHH-AB-U-AD-B-C-A-A-BHH-AB-U-AD-C-NNN	M46	M46-046PT
M91-46367	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-BA-B-B-A-A-BBB-CG-A-GG-B-D-A-A-BBB-CG-A-GG-C-NNN-	M46	M46-046PT
M91-4637	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-AA-B-B-A-A-A-BGG-AB-U-ED-B-C-A-A-BGG-AB-U-ED-B-NNN-	M46	M46-046PT
M91-46370	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-D-C-A-BA-B-B-A-A-BJJ-CD-A-GG-B-D-A-A-BJJ-CD-A-GG-B-NNN-*	M46	M46-046PT
M91-46372	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-D-C-A-AA-B-A-A-A-BBG-AB-D-FF-B-C-A-A-BBG-AB-U-FF-A-NNN-*	M46	M46-046PT
M91-46373	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-D-C-A-AA-B-A-A-A-BHH-AB-U-DB-B-C-A-A-BHH-AB-U-DB-B-NNN-	M46	M46-046PT
M91-46374	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-D-C-A-BA-B-B-A-A-BJJ-CB-A-GG-B-D-A-A-BJJ-CB-A-GG-B-NNN-**	M46	M46-046PT
M91-46375	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-AA-B-B-A-A-BGG-BA-A-GG-B-D-A-A-BGG-BA-A-GG-C-NNN	M46	M46-046PT
M91-46376	PUMP-TANDEM, VAR DISPL	MPT-046-C-T-D-C-M-AA-B-B-A-A-BJJ-CG-A-GG-B-D-A-A-BDD-CG-A-GG-A-NNN-	M46	M46-046PT
M91-46377	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-AA-B-B-A-A-BBB-BA-A-GG-B-D-A-A-BBB-BA-A-GG-C-NNN-	M46	M46-046PT
M91-46379	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-D-C-A-AA-B-A-A-A-BJJ-AB-U-ED-B-C-A-A-BJJ-AB-U-ED-C-NNN-**	M46	M46-046PT
M91-4638	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-D-C-A-AA-B-A-A-A-BGG-AB-U-ED-B-C-A-A-BGG-AB-U-ED-B-NNN-	M46	M46-046PT
M91-46380	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-BA-B-B-A-A-BJJ-AB-U-EA-B-C-A-A-BJJ-AB-U-EA-A-NNN-***	M46	M46-046PT
M91-46382	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-AA-B-B-A-A-BFF-BA-A-GG-B-D-A-A-BFF-BA-A-GG-C-NNN-*	M46	M46-046PT
M91-46383	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-BA-B-A-A-A-BHH-AB-D-BF-B-C-A-A-BHH-AB-D-BF-A-NNN-*	M46	M46-046PT
M91-46388	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-D-C-A-AA-B-A-A-A-BDD-AB-U-ED-B-C-A-A-BDD-AB-D-ED-C-NNN-	M46	M46-046PT
M91-4639	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-AA-B-B-A-A-BGG-CD-A-GG-B-D-A-A-BGG-CD-A-GG-A-NNN	M46	M46-046PT
M91-46390	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-AA-B-A-A-A-BFF-AB-U-ED-B-C-A-A-BFF-AB-D-ED-B-NNN-*	M46	M46-046PT
M91-46391	PUMP-TANDEM-VAR-DISPL MPT046	MPT-046-C-A-D-C-A-AA-B-B-A-A-BFF-CD-A-GG-B-D-A-A-BFF-CD-A-GG-B-NNN-*	M46	M46-046PT

M91-46392	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-AA-B-A-A-A-BJJ-AB-U-ED-B-C-A-A-BJJ-AB-D-ED-C-NNN-***	M46	M46-046PT
M91-46393	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-BA-B-A-A-A-BDD-AB-D-ED-B-C-A-A-BDD-AB-D-ED-A-NNN-	M46	M46-046PT
M91-46396	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-G-A-A-BC-B-A-A-A-BHH-AB-U-ED-B-C-A-A-BHH-AB-D-ED-D-NNN-	M46	M46-046PT
M91-46398	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-AA-B-A-G-A-BEE-AB-U-ED-B-C-A-A-BEE-AB-U-ED-B-NNN-*	M46	M46-046PT
M91-46399	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-AA-B-A-A-A-BEE-AB-U-ED-B-C-A-A-BEE-AB-U-ED-B-NNN-*	M46	M46-046PT
M91-4640	PUMP-TANDEM-VAR-DISPL MPT046	MPT-046-C-A-D-C-A-AA-B-B-A-A-BGG-CD-A-GG-B-D-A-A-BGG-CD-A-GG-A-NNN	M46	M46-046PT
M91-46400	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-D-C-A-BA-B-B-A-A-BGG-CB-A-JJ-B-D-A-A-BGG-CB-A-JJ-B-NNN-**	M46	M46-046PT
M91-46401	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-BA-B-B-A-A-BGG-CB-A-JJ-B-D-A-A-BGG-CB-A-JJ-B-NNN-**	M46	M46-046PT
M91-46402	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-D-C-A-AA-B-A-A-A-BJJ-AB-D-BB-B-C-A-A-BJJ-AB-D-BB-A-NNN-***	M46	M46-046PT
M91-46403	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-D-C-D-BA-B-A-A-A-BDD-AC-U-ED-B-C-A-A-BBJ-AC-D-FF-A-NNN-*	M46	M46-046PT
M91-46405	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-C-C-A-BA-B-B-A-A-BBB-CG-A-GG-B-D-A-A-BBB-CG-A-GG-C-NNN-	M46	M46-046PT
M91-46406	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-C-C-A-BA-B-A-A-A-BJJ-AB-U-ED-B-C-A-A-BJB-AB-U-EA-A-NNN-**	M46	M46-046PT
M91-46409	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-B-AA-B-A-A-A-BJJ-AB-D-FF-B-C-A-A-BJJ-AB-U-FF-B-NNN-***	M46	M46-046PT
M91-46410	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-G-A-A-BC-B-A-A-BGG-AB-D-EF-B-C-A-B-BGG-AB-U-EF-C-NNN-*	M46	M46-046PT
M91-46411	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-D-C-A-AA-B-A-A-A-BJJ-AB-U-ED-B-C-A-A-BJJ-AB-D-ED-A-NNN-**	M46	M46-046PT
M91-46412	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-AA-B-A-A-A-BFF-AB-U-ED-B-D-A-A-BFF-CB-A-HH-A-NNN-*	M46	M46-046PT
M91-46413	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-D-C-A-AA-B-A-A-A-BGG-AB-U-BB-B-C-A-A-BGG-AB-U-BB-C-NNN-	M46	M46-046PT
M91-46417	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-C-C-J-AA-B-A-A-A-BFF-AB-U-ED-B-C-A-A-BFF-AB-U-ED-B-NNN-**	M46	M46-046PT
M91-46419	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-AA-B-A-A-A-BHH-AB-U-ED-B-C-A-A-BHH-AB-D-ED-A-NNN-	M46	M46-046PT
M91-46420	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-C-C-A-AA-B-A-A-A-BHH-AB-U-DF-B-C-A-A-BHH-AB-D-DF-C-NNN-	M46	M46-046PT
M91-46421	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-D-C-D-BA-B-A-A-A-BDD-AC-U-ED-B-C-A-A-BJB-AC-D-FF-A-NNN-*	M46	M46-046PT
M91-46423	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-D-C-A-AA-B-B-A-A-BFF-CB-A-GG-B-D-A-A-BFF-CB-A-GG-C-NNN-*	M46	M46-046PT
M91-46424	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-C-C-A-BA-B-A-A-BDD-AB-U-FD-B-C-A-B-BDD-AB-D-FD-C-ANN-*	M46	M46-046PT
M91-46425	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-B-AA-B-A-A-A-BJJ-AB-U-FF-B-C-A-A-BJJ-AB-D-FF-B-NNN-***	M46	M46-046PT
M91-46426	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-AA-B-A-A-A-BGG-AB-U-FF-B-C-A-A-BGG-AB-U-FF-B-NNN-*	M46	M46-046PT
M91-46428	PUMP-TANDEM, VAR DISPL	MPT-046-C-D-C-C-A-BA-B-B-A-A-BHH-CG-A-GG-B-D-A-A-BHH-CG-A-GG-C-NNN	M46	M46-046PT
M91-4643	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-G-A-A-BC-B-A-A-A-BJJ-AB-U-ED-B-D-A-A-BGG-CD-A-GG-A-NNN-*	M46	M46-046PT
M91-46431	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-D-C-A-BA-B-B-A-A-BGG-CB-A-HH-B-D-A-A-BGG-CB-A-GG-B-NNN	M46	M46-046PT
M91-46432	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-AA-B-B-A-A-BGG-CD-A-GG-B-D-A-A-BBB-CD-A-JJ-C-NNN-*	M46	M46-046PT
M91-46433	PUMP-TANDEM, VAR DISPL	MPT-046-C-D-D-C-A-AA-B-B-A-A-BMM-CG-A-JJ-B-D-A-A-BGG-CG-A-JJ-A-NNN-*	M46	M46-046PT
M91-46436	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-C-C-A-BA-B-A-A-A-BJJ-AB-U-ZW-B-C-A-A-BJJ-AB-U-ED-C-NNN-**	M46	M46-046PT
M91-46439	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-D-C-A-AA-B-B-A-A-BGG-CD-A-GG-B-D-A-A-BGG-DA-A-RR-B-NNN	M46	M46-046PT
M91-46440	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-D-C-A-AA-B-B-A-A-BFF-CB-A-HH-B-D-A-A-BFF-CB-A-HH-B-NNN-*	M46	M46-046PT
M91-46441	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-D-C-A-AA-B-A-A-A-BMM-AB-U-ED-B-C-A-A-BDD-AB-D-ED-B-NNN	M46	M46-046PT
M91-46443	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-AA-B-B-A-A-BDD-CB-A-HH-B-D-A-A-BBB-CB-A-HH-A-NNN-	M46	M46-046PT
M91-46450	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-BA-B-B-A-A-BJJ-BA-A-GG-B-D-A-A-BFF-BA-A-GG-A-NNN-*	M46	M46-046PT

M91-46451	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-C-C-A-BA-B-A-A-A-BJJ-AB-U-ED-B-C-A-A-BJJ-AB-U-ED-D-NNN-***	M46	M46-046PT
M91-46453	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-AA-B-B-G-A-BGG-CG-A-GG-B-D-G-A-BGG-CG-A-GG-A-NNN	M46	M46-046PT
M91-46455	PUMP-TANDEM-VAR-DISPL MPT046	MPT-046-C-A-D-C-A-AA-B-A-A-A-BJJ-AB-U-ED-B-C-A-A-BJJ-AB-D-ED-C-NNN-***	M46	M46-046PT
M91-46456	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-C-C-A-BA-B-A-A-A-BJJ-AC-D-AA-B-C-A-A-BJJ-AC-U-AA-C-NNN-***	M46	M46-046PT
M91-46457	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-C-C-J-AA-B-A-A-A-BHH-AB-U-ED-B-C-A-A-BHH-AB-U-ED-B-NNN-*	M46	M46-046PT
M91-46458	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-D-C-A-BA-B-B-A-A-BFF-CB-A-GG-B-D-A-A-BFF-CB-A-GG-A-NNN-*	M46	M46-046PT
M91-46459	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-D-C-A-AA-B-A-A-A-BJJ-AB-D-AA-B-C-A-A-BJJ-AB-D-AA-C-NNN-***	M46	M46-046PT
M91-4646	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-D-C-A-AA-B-A-A-A-BFF-AB-U-ED-B-C-A-A-BFF-AB-U-ED-C-NNN-*	M46	M46-046PT
M91-46460	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-B-BA-B-A-A-A-BJJ-AB-U-ED-B-C-A-A-BJJ-AB-U-ED-B-NNN-***	M46	M46-046PT
M91-46461	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-D-C-A-AA-B-B-A-A-BJJ-CD-A-GG-B-B-A-A-BJJ-CD-A-GG-A-NNN-***	M46	M46-046PT
M91-46462	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-BA-B-A-A-A-BGG-AC-U-ED-B-C-A-A-BFF-AC-D-BD-A-NNN-*	M46	M46-046PT
M91-46463	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-D-C-A-AA-B-B-A-A-BGG-CB-A-GG-B-D-A-A-BGG-CB-A-GG-A-NNN	M46	M46-046PT
M91-46467	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-C-C-A-AA-B-B-A-A-BFF-CB-A-GG-B-D-A-A-BFF-CB-A-GG-A-NNN-*	M46	M46-046PT
M91-46468	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-D-C-A-BA-B-A-A-A-BDD-AB-U-CD-B-C-A-A-BDD-AB-D-CD-A-ANN-	M46	M46-046PT
M91-46469	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-BA-B-A-A-A-BGG-AC-U-ED-B-C-A-A-BFF-AC-D-AB-A-NNN-*	M46	M46-046PT
M91-4647	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-D-C-A-BA-B-A-A-A-BHH-AB-U-ED-B-C-A-A-BBB-AB-U-ED-C-NNN-	M46	M46-046PT
M91-46470	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-AA-B-A-A-A-BGG-AC-U-ED-B-C-A-A-BFF-AC-D-AB-A-NNN-*	M46	M46-046PT
M91-46471	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-D-C-A-AA-B-B-A-A-BFF-DB-A-SS-B-D-A-A-BFF-DB-A-SS-C-NNN-***	M46	M46-046PT
M91-46472	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-H-A-J-BC-B-A-A-A-BHH-AB-U-ED-B-C-A-A-BHH-AB-U-ED-B-NNN-*	M46	M46-046PT
M91-46473	PUMP-TANDEM, VAR DISPL	MPT-046-C-D-D-C-A-AA-B-B-A-A-BMM-CG-A-JJ-B-D-A-A-BGG-CG-A-JJ-B-NNN-*	M46	M46-046PT
M91-46474	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-H-A-J-BC-B-A-A-A-BHH-AB-U-ED-B-C-A-A-BHH-AB-U-ED-B-NNN-*	M46	M46-046PT
M91-46475	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-D-C-A-AA-B-B-A-A-BJJ-BA-A-GG-B-D-A-A-BJJ-BA-A-GG-C-NNN-***	M46	M46-046PT
M91-46476	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-D-C-A-AA-B-B-A-A-BFF-CB-A-HH-B-D-A-A-BFF-CB-A-HH-A-NNN-*	M46	M46-046PT
M91-46478	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-BA-B-B-G-A-BFF-BA-A-GG-B-D-G-A-BFF-BA-A-GG-A-NNN-*	M46	M46-046PT
M91-46479	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-C-BA-B-A-A-A-BGG-AB-D-ED-B-C-A-A-BGG-AB-U-ED-A-NNN-	M46	M46-046PT
M91-46482	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-J-AA-B-B-A-A-BFF-CB-A-GG-B-D-A-A-BJD-CB-A-GG-A-NNN-***	M46	M46-046PT
M91-46484	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-D-C-A-BA-B-A-G-A-BHH-AB-U-BD-B-C-G-A-BHH-AB-U-BD-B-NNN	M46	M46-046PT
M91-46485	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-BA-B-A-G-A-BHH-AB-U-BD-B-C-G-A-BHH-AB-U-BD-A-NNN	M46	M46-046PT
M91-46487	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-BA-B-B-G-A-BHH-BA-A-GG-B-D-G-A-BHH-BA-A-GG-A-NNN	M46	M46-046PT
M91-46488	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-D-C-A-AA-B-B-A-A-BDD-CB-A-GG-B-D-A-A-BBB-CB-A-GG-B-NNN-	M46	M46-046PT
M91-46489	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-G-A-A-BC-B-A-A-B-BGG-AB-U-FD-B-C-A-B-BGG-AB-D-FD-B-ANN-	M46	M46-046PT
M91-46490	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-BA-B-B-A-A-BHH-BA-A-GG-B-D-A-A-BHH-BA-A-GG-B-NNN	M46	M46-046PT
M91-46492	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-V-C-B-AA-B-A-A-B-BHH-AD-U-FF-B-C-A-B-BHH-AB-D-FF-C-NNN-*	M46	M46-046PT
M91-46493	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-V-C-B-AA-B-A-B-C-BDD-AE-U-PF-B-C-B-C-BDD-AB-D-PF-C-NNN-*	M46	M46-046PT
M91-46494	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-V-C-B-AA-B-A-A-C-BGG-AB-U-PF-B-C-A-C-BGG-AB-D-PF-C-NNN-*	M46	M46-046PT
M91-46495	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-BA-B-A-A-A-BFF-AB-D-DF-B-C-A-A-BFF-AB-U-DF-A-NNN-***	M46	M46-046PT

M91-46497	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-AA-B-B-A-A-BDD-CE-A-HH-B-D-A-A-BDD-CE-A-HH-A-NNN-	M46	M46-046PT
M91-46498	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-C-C-A-AA-B-A-A-A-BMM-AB-U-BB-B-C-A-A-BMM-AB-U-BB-B-NN	M46	M46-046PT
M91-46499	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-AA-B-A-A-A-BHH-AB-D-DF-B-C-A-A-BHH-AB-U-DF-D-NNN-	M46	M46-046PT
M91-4650	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-BA-B-A-A-A-BGG-AB-U-ED-B-C-A-A-BGG-AB-U-ED-B-NNN-	M46	M46-046PT
M91-46501	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-BA-B-A-A-A-BFF-AB-D-DF-B-C-A-A-BFF-AB-U-BF-A-NNN-*	M46	M46-046PT
M91-46502	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-D-C-A-BA-B-A-A-A-BJJ-AC-D-AA-B-C-A-A-BJJ-AC-U-AA-C-NNN-*	M46	M46-046PT
M91-46503	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-C-C-A-BA-B-A-A-A-BJJ-AB-D-ED-B-C-A-A-BJJ-AB-D-ED-B-NNN-*	M46	M46-046PT
M91-46504	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-G-A-A-BC-B-A-A-B-BGG-AB-U-FD-B-C-A-B-BGG-AB-D-FD-A-ANN-	M46	M46-046PT
M91-46505	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-AA-B-B-G-A-BBB-DB-A-SS-B-D-G-A-BBB-DB-A-SS-B-NNN-*	M46	M46-046PT
M91-46506	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-D-C-A-AA-B-B-A-A-BGG-CE-A-GG-B-D-A-A-BBB-CE-A-GG-C-NNN-	M46	M46-046PT
M91-46507	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-V-C-S-AA-B-A-A-B-BHH-AD-U-FF-B-C-A-B-BHH-AB-D-FF-C-NNN-*	M46	M46-046PT
M91-46508	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-V-C-S-AA-B-A-B-C-BDD-AE-U-PF-B-C-B-C-BDD-AB-D-PF-C-NNN-*	M46	M46-046PT
M91-46509	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-V-C-S-AA-B-A-A-C-BGG-AB-U-PF-B-C-A-C-BGG-AB-D-PF-C-NNN-*	M46	M46-046PT
M91-4651	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-D-C-A-AA-B-A-A-A-BDD-AB-D-CD-B-C-A-A-BDD-AB-D-CD-C-NNN-	M46	M46-046PT
M91-46510	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-C-C-A-AA-B-A-A-A-BHH-AB-U-DD-B-C-A-A-BHH-AB-U-DD-B-NNN-	M46	M46-046PT
M91-46512	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-AA-B-A-A-A-BJJ-AB-U-CF-B-C-A-A-BJJ-AB-D-CF-B-NNN-*	M46	M46-046PT
M91-46513	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-AA-B-A-A-A-BFF-AB-U-ED-B-C-A-A-BFF-AB-U-ED-A-NNN-*	M46	M46-046PT
M91-46514	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-D-C-A-AA-B-B-A-A-BDD-CE-A-GG-B-D-A-A-BDD-CE-A-GG-C-NNN-	M46	M46-046PT
M91-46515	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-M-AA-B-A-A-A-BGG-AC-U-ED-B-C-A-A-BFF-AC-D-AB-A-NNN-	M46	M46-046PT
M91-46516	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-D-C-A-BA-B-B-A-A-BGG-CE-A-GG-B-D-A-A-BGG-CE-A-GG-C-NNN-	M46	M46-046PT
M91-46517	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-AA-B-A-A-A-BMG-AC-U-ED-B-C-A-A-BFF-AC-D-AB-A-NNN-	M46	M46-046PT
M91-46519	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-AA-B-A-A-A-BJJ-AB-U-FF-B-C-A-A-BJJ-AB-U-FF-C-NNN-*	M46	M46-046PT
M91-46520	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-AA-B-A-A-A-BJJ-AB-U-DD-B-C-A-A-BJJ-AB-U-DD-C-NNN-*	M46	M46-046PT
M91-46522	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-BA-B-A-A-A-BJJ-AB-U-CD-B-C-A-A-BBB-AB-D-ZP-A-NNC-*	M46	M46-046PT
M91-46523	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-AA-B-B-A-A-BGG-CE-A-HH-B-D-A-A-BGG-CE-A-HH-A-NNN-	M46	M46-046PT
M91-46525	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-C-C-A-AA-B-A-A-A-BHH-AB-U-ED-B-C-A-A-BHH-AB-U-ED-B-NNN-	M46	M46-046PT
M91-46526	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-AA-B-A-A-A-BJJ-AB-U-BB-B-C-A-A-BJJ-AB-D-BB-A-NNN-*	M46	M46-046PT
M91-46528	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-D-C-A-BA-B-A-A-A-BJJ-AB-U-BD-B-C-A-A-BJJ-AB-U-BD-C-NNN-*	M46	M46-046PT
M91-46529	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-BA-B-A-A-A-BJJ-AB-U-BD-B-C-A-A-BJJ-AB-U-BD-A-NNN-*	M46	M46-046PT
M91-46530	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-D-C-A-BA-B-B-A-A-BJJ-CB-A-HH-B-D-A-A-BJJ-CB-A-HH-A-NNN-*	M46	M46-046PT
M91-46531	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-D-C-A-BA-B-A-A-A-BJJ-AB-U-BB-B-C-A-A-BJJ-AB-D-BB-A-NNN-*	M46	M46-046PT
M91-46532	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-C-C-A-AA-B-A-A-A-BHH-AB-U-ED-B-C-G-A-BGG-AB-U-AA-B-NNN-	M46	M46-046PT
M91-46534	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-BA-B-A-A-A-BDD-AB-D-ED-B-C-A-A-BDD-AB-U-ED-B-NNE-	M46	M46-046PT
M91-46535	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-AA-B-B-A-A-BFF-CB-A-HH-B-D-A-A-BJJ-CB-A-HH-C-NNN-*	M46	M46-046PT
M91-46536	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-AA-B-A-A-A-BMM-AB-U-BB-B-C-A-A-BMM-AB-U-BB-A-NN	M46	M46-046PT
M91-46537	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-B-BA-B-A-A-A-BEE-AK-D-BF-B-C-A-A-BEE-AK-U-BF-A-NNN-*	M46	M46-046PT

M91-46540	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-V-C-J-BA-B-A-A-A-BJJ-AC-D-AA-B-C-A-A-BJJ-AC-U-AA-C-NNN-***	M46	M46-046PT
M91-46541	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-D-C-A-BA-B-A-A-A-BJJ-AB-U-BB-B-C-A-A-BJJ-AB-D-BB-A-ANN-***	M46	M46-046PT
M91-46542	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-D-C-A-AA-B-B-A-A-BDD-CB-A-GG-B-D-A-A-BDD-CB-A-GG-A-NNN	M46	M46-046PT
M91-46543	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-D-C-A-BA-B-B-G-A-BBJ-CB-A-GG-B-D-G-A-BJJ-CB-A-GG-C-NNN-*	M46	M46-046PT
M91-46545	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-J-AA-B-A-A-A-BFF-AB-D-ED-B-C-A-A-BFF-AB-D-ED-B-NNN-**	M46	M46-046PT
M91-46546	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-BA-B-A-A-A-BGG-AB-U-BB-B-C-A-A-BGG-AB-U-BB-A-NNN-	M46	M46-046PT
M91-46547	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-BA-B-A-B-A-BGG-AB-U-BB-B-C-B-A-BGG-AB-U-BB-A-NNN-	M46	M46-046PT
M91-46548	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-BA-B-A-A-A-BHH-AB-D-CD-B-C-A-A-BHH-AB-U-CD-A-NNN-	M46	M46-046PT
M91-46549	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-C-C-D-BA-B-A-A-A-BHH-AB-D-DD-B-C-A-A-BHH-AB-U-DD-D-ANN-	M46	M46-046PT
M91-4655	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-BA-B-A-A-A-BGG-AB-U-ED-B-C-A-A-BGG-AB-U-ED-A-NNN-	M46	M46-046PT
M91-46552	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-C-C-A-BA-B-B-A-A-BJJ-CE-A-GG-B-D-A-A-BHH-CE-A-GG-A-NNN-*	M46	M46-046PT
M91-46553	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-S-A-T-BC-B-B-R-A-BCC-CE-A-HH-B-C-A-A-BHH-AB-D-CD-C-NNN-*	M46	M46-046PT
M91-46554	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-D-C-A-BA-B-A-A-A-BFF-AB-U-ED-B-C-A-A-BFF-AB-U-ED-A-NNN-*	M46	M46-046PT
M91-46555	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-A-AA-B-A-A-A-BMG-AC-U-ED-B-C-A-A-BFF-AC-D-AB-A-NNN-	M46	M46-046PT
M91-46556	PUMP-TANDEM, VAR DISPL	MPT-046-C-T-D-C-M-AA-B-B-A-A-BJJ-CG-A-GG-B-D-A-A-BDD-CG-A-GG-D-NNN-	M46	M46-046PT
M91-46558	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-S-A-A-BC-B-A-A-A-BMG-AC-U-ED-B-C-A-A-BFF-AC-D-AB-A-NNN-	M46	M46-046PT
M91-46559	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-D-C-A-AA-B-A-A-A-BEE-AB-D-AA-B-C-A-A-BEE-AB-D-AA-B-NNN-*	M46	M46-046PT
M91-46560	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-C-C-A-AA-B-A-A-A-BEE-AB-D-AA-B-C-A-A-BEE-AB-D-AA-B-NNN-*	M46	M46-046PT
M91-46561	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-C-C-A-AA-B-A-A-A-BEE-AC-D-AA-B-C-A-A-BEE-AC-D-AA-B-NNN-*	M46	M46-046PT
M91-46562	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-D-C-A-BA-B-B-A-A-BHH-CE-A-GG-B-D-A-A-BHH-CE-A-GG-A-NNN-	M46	M46-046PT
M91-46563	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-V-C-A-AA-B-A-A-A-BEE-AC-D-AA-B-C-A-A-BEE-AC-D-AA-B-NNN-*	M46	M46-046PT
M91-46564	PUMP-TANDEM-VAR-DISPL MPT046	MPT-046-C-A-D-C-A-AA-B-A-A-A-BGG-AB-U-ED-B-C-A-A-BDD-AB-U-ED-C-NNN-	M46	M46-046PT
M91-46565	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-S-A-S-BC-B-A-A-A-BMG-AC-U-ED-B-C-A-A-BFF-AC-D-AB-S-NNN-*	M46	M46-046PT
M91-46567	PUMP-TANDEM-VAR-DISPL MPT046	MPT-046-C-A-V-C-J-AA-B-A-A-A-BJJ-AB-D-ED-B-C-A-A-BJJ-AB-D-ED-B-NNN-***	M46	M46-046PT
M91-46571	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-V-C-S-AA-B-A-A-A-BHH-AK-U-FF-B-C-A-A-BHH-AK-D-FF-C-NNN-*	M46	M46-046PT
M91-46575	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-J-BA-B-A-A-A-BEE-AK-D-BF-B-C-A-A-BEE-AK-U-BF-A-NNN-**	M46	M46-046PT
M91-46576	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-C-C-A-BA-B-B-A-A-BJJ-CE-A-HH-B-D-A-C-BHH-CE-A-HH-A-NNN-*	M46	M46-046PT
M91-46577	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-Z-C-B-BA-B-B-A-A-BGG-CD-A-HH-B-D-A-A-BGG-CD-A-HH-A-NNN-	M46	M46-046PT
M91-46578	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-V-C-B-BA-B-B-A-A-BGG-CD-A-HH-B-D-A-A-BGG-CD-A-HH-A-NNN-	M46	M46-046PT
M91-46579	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-C-C-A-BA-B-B-A-C-BJJ-CE-A-HH-B-D-A-C-BHH-CE-A-HH-A-NNN-*	M46	M46-046PT
M91-46582	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-B-BA-B-B-A-A-BJJ-CE-A-GG-B-D-A-A-BJJ-CE-A-GG-A-NNN-***	M46	M46-046PT
M91-46584	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-G-A-A-BC-B-A-A-B-BGG-AB-D-EF-B-C-A-B-BGG-AB-U-EF-D-NNN-*	M46	M46-046PT
M91-46586	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-B-BA-B-A-A-A-BJJ-AB-U-CD-B-C-A-A-BBB-AB-D-ZP-A-NNC-**	M46	M46-046PT
M91-46587	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-C-AA-B-B-A-A-BGG-CE-A-HH-B-D-A-A-BGG-CE-A-HH-A-NNN-	M46	M46-046PT
M91-46588	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-C-C-B-AA-B-A-A-A-BHH-AB-U-ED-B-C-A-A-BHH-AB-U-EB-B-NNN-	M46	M46-046PT
M91-46591	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-C-C-B-AA-B-A-A-A-BHH-AB-U-ED-B-C-G-A-BHH-AB-U-EB-B-NNN-	M46	M46-046PT

M91-46592	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-D-C-A-BA-B-B-A-C-BHH-CE-A-GG-B-D-A-C-BHH-CE-A-GG-A-NNN-	M46	M46-046PT
M91-46593	PUMP-TANDEM, VAR DISPL	MPT-046-C-T-D-C-M-AA-B-B-A-A-BJJ-CG-A-GG-B-D-A-A-BDD-CG-A-GG-B-NNN-	M46	M46-046PT
M91-46594	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-C-C-A-BA-B-A-A-BDD-AB-U-CD-B-C-A-A-BGG-AB-D-FB-A-NNN-	M46	M46-046PT
M91-46595	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-S-A-S-BC-B-A-A-B-BGG-AB-D-EF-B-C-A-B-BGG-AB-U-EF-C-ANN-*	M46	M46-046PT
M91-46596	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-Z-C-C-BA-B-A-A-A-BJJ-AB-D-BB-B-C-A-A-BJJ-AB-U-BB-A-ANN-***	M46	M46-046PT
M91-46597	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-V-C-A-BA-B-B-A-A-BDD-CB-A-JJ-B-C-A-A-BGG-AB-D-FB-A-NNN-*	M46	M46-046PT
M91-46599	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-C-C-C-BA-B-B-A-A-BDD-CB-A-HH-B-C-A-A-BGG-AB-D-FB-A-NNN-*	M46	M46-046PT
M91-46600	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-J-AA-B-B-A-A-BFF-CB-A-GG-B-D-A-A-BJF-CB-A-GG-A-NNN-*	M46	M46-046PT
M91-46601	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-C-C-J-AA-B-B-A-A-BFF-BA-A-GG-B-D-A-A-BFF-BA-A-GG-B-NNN-*	M46	M46-046PT
M91-46602	PUMP-TANDEM, VAR DISPL	MPT-046-C-H-Z-C-B-BA-B-A-A-A-BHH-AB-U-ED-B-C-A-A-BJB-AB-D-FF-C-NNN-*	M46	M46-046PT
M91-46603	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-AA-B-B-A-A-BBB-CE-A-GG-B-D-A-A-BBB-CE-A-GG-B-NNN-*	M46	M46-046PT
M91-46604	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-C-BA-B-B-A-A-BJJ-CD-A-HH-B-D-A-A-BJJ-CD-A-HH-B-NNN-*	M46	M46-046PT
M91-46605	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-J-BA-B-B-A-A-BDD-CE-A-GG-B-D-A-A-BDD-CE-A-GG-A-NNN-*	M46	M46-046PT
M91-46607	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-J-BA-B-B-A-A-BDD-CE-A-GG-B-D-A-A-BDD-CE-A-GG-A-NNN-*	M46	M46-046PT
M91-46609	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-B-AA-B-B-G-A-BBB-CE-A-GG-B-D-G-A-BBB-CE-A-GG-B-NNN-*	M46	M46-046PT
M91-46610	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-S-A-B-BC-B-A-A-A-BRR-AB-U-DD-B-C-A-A-BRR-AB-U-DD-B-NNN-*	M46	M46-046PT
M91-46611	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-Z-C-B-AA-B-A-A-A-BRR-AB-U-DD-B-C-A-A-BRR-AB-U-DD-D-NNN-	M46	M46-046PT
M91-46612	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-B-AA-B-A-A-A-BRR-AB-U-DD-B-C-A-A-BRR-AB-U-DD-G-NNN-	M46	M46-046PT
M91-46613	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-G-A-A-BC-B-A-A-B-BGG-AB-D-EF-B-C-A-B-BGG-AB-U-EF-C-ANN-*	M46	M46-046PT
M91-46614	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-G-A-A-BC-B-A-A-B-BGG-AB-D-EF-B-C-A-B-BGG-AB-U-EF-D-ANN-*	M46	M46-046PT
M91-4662	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-BA-B-A-A-A-BHH-AB-U-ED-B-C-A-A-BHH-AB-U-ED-A-NNN-	M46	M46-046PT
M91-46620	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-Z-C-B-BA-B-B-A-A-BGG-CB-A-GG-B-D-A-A-BGG-CB-A-GG-C-NNN-	M46	M46-046PT
M91-46623	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-Z-C-B-AA-B-A-A-A-BRR-AB-U-PF-B-C-A-A-BRR-AB-D-PF-D-NNN-*	M46	M46-046PT
M91-46624	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-J-AA-B-A-A-A-BJJ-AB-D-AA-B-C-A-A-BJJ-AB-D-AA-A-NNN-***	M46	M46-046PT
M91-46625	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-BA-B-A-A-A-BEE-AB-D-ED-B-C-A-A-BEE-AB-U-ED-B-NNE-*	M46	M46-046PT
M91-46626	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-S-AA-B-A-A-A-BMG-AC-U-ED-B-C-A-A-BFF-AC-D-AB-A-NNN-	M46	M46-046PT
M91-46629	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-V-C-B-AA-B-A-A-A-BCC-AB-U-ED-B-C-G-A-BCC-AB-U-AA-B-NNN-*	M46	M46-046PT
M91-4663	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-D-C-A-AA-B-B-A-A-BFF-CD-A-GG-B-D-A-A-BFF-CD-A-GG-C-NNN-*	M46	M46-046PT
M91-46631	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-S-C-B-AA-B-A-A-A-BFF-AB-U-DD-B-C-A-A-BFF-AB-U-DD-A-NNN-*	M46	M46-046PT
M91-46632	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-J-AA-B-B-A-A-BFF-CB-A-GG-B-D-A-A-BFD-CB-A-GG-A-NNN-*	M46	M46-046PT
M91-46633	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-J-AA-B-B-A-A-BFF-CB-A-GG-B-D-A-A-BJF-CB-A-GG-A-NNN-*	M46	M46-046PT
M91-46635	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-B-BA-B-B-G-A-BBB-CE-A-GG-B-D-G-A-BBB-CE-A-GG-B-NNN-*	M46	M46-046PT
M91-46638	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-B-AA-B-B-A-A-BJJ-CD-A-GG-B-D-A-A-BJJ-CD-A-GG-C-NNN-*	M46	M46-046PT
M91-46639	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-V-C-S-AA-B-A-A-A-BGG-AB-U-PF-B-C-A-A-BGG-AB-D-PF-D-NNN-*	M46	M46-046PT
M91-4664	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-AA-B-A-A-A-BJJ-AB-U-ED-B-C-A-A-BJJ-AB-U-ED-B-NNN-***	M46	M46-046PT
M91-46640	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-Z-C-B-BA-B-B-A-A-BJJ-CB-A-GG-B-D-A-A-BJJ-CB-A-GG-C-NNN-***	M46	M46-046PT

M91-46642	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-B-AA-B-A-A-A-BJJ-AB-U-FF-B-C-A-A-BJJ-AB-D-FF-B-NNN-***	M46	M46-046PT
M91-46643	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-Z-C-B-BA-B-B-A-A-BGG-CE-A-GG-B-D-A-A-BGG-CE-A-GG-A-NNN-	M46	M46-046PT
M91-46645	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-S-A-S-BC-B-A-A-B-BGG-AB-D-EF-B-C-A-B-BGG-AB-U-EF-D-ANN-*	M46	M46-046PT
M91-46646	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-Z-C-B-AA-B-B-A-A-BGG-CB-A-GG-B-D-A-A-BGG-CB-A-GG-A-NNN-	M46	M46-046PT
M91-46647	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-V-C-S-AA-B-A-A-B-BGG-AB-D-EF-B-C-A-B-BGG-AB-U-EF-D-ANN-*	M46	M46-046PT
M91-46648	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-V-C-J-AA-B-B-A-A-BFF-CE-A-GG-B-D-A-A-BFF-CE-A-GG-B-NNN-*	M46	M46-046PT
M91-46649	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-Z-C-B-BA-B-A-A-A-BJJ-AC-U-ED-B-C-A-A-BJB-AC-D-FF-A-NNN-***	M46	M46-046PT
M91-46650	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-V-C-B-BA-B-A-A-A-BJJ-AC-U-ED-B-C-A-A-BJB-AC-D-FF-A-NNN-***	M46	M46-046PT
M91-46655	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-B-AA-B-A-A-A-BGG-AB-U-FF-B-C-A-A-BGG-AB-D-FF-B-NNN-*	M46	M46-046PT
M91-46656	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-Z-C-B-AA-B-A-A-A-BGG-AB-U-FF-B-C-A-A-BGG-AB-D-FF-B-NNN-*	M46	M46-046PT
M91-46660	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-Z-C-B-BA-B-B-A-A-BJJ-CD-A-HH-B-D-A-A-BJJ-CD-A-HH-C-NNN-**	M46	M46-046PT
M91-46661	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-B-AA-B-A-A-A-BFF-AB-U-EA-B-C-A-A-BFF-AB-U-EA-A-NNN-*	M46	M46-046PT
M91-46662	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-B-BA-B-A-A-A-BGG-AC-U-ED-B-C-A-A-BFF-AC-D-BD-A-NNN-*	M46	M46-046PT
M91-46663	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-B-BA-B-A-A-A-BDD-AB-U-AA-B-C-A-A-BDD-AB-U-AA-C-NNN-	M46	M46-046PT
M91-46665	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-Z-C-B-AA-B-B-A-A-BDD-CB-A-GG-B-D-A-A-BBB-CB-A-GG-B-NNN-	M46	M46-046PT
M91-46666	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-B-AA-B-A-A-A-BJJ-AW-U-FF-B-C-A-A-BJJ-AW-D-FF-B-NNN-*	M46	M46-046PT
M91-46668	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-J-BA-B-B-A-A-BGG-CE-A-GG-B-D-A-A-BGG-CE-A-GG-A-NNN-	M46	M46-046PT
M91-46669	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-V-C-B-BA-B-B-A-A-BDD-CB-A-JJ-B-D-A-A-BEE-CB-A-JJ-A-NNN-***	M46	M46-046PT
M91-4667	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-C-C-A-BA-B-A-A-A-BJJ-AB-U-ED-B-C-A-A-BJJ-AB-U-ED-B-NNN-***	M46	M46-046PT
M91-46671	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-B-BA-B-A-A-A-BGG-AB-D-ED-B-C-A-A-BGG-AB-U-ED-A-NNN-	M46	M46-046PT
M91-46672	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-B-BA-B-A-A-A-BEE-AB-D-ED-B-C-A-A-BEE-AB-U-ED-B-NNE-*	M46	M46-046PT
M91-46675	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-Z-C-B-AA-B-B-A-A-BHH-CB-A-HH-B-D-A-A-BHH-CB-A-HH-A-NNN-	M46	M46-046PT
M91-46676	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-V-C-B-BA-B-B-A-C-BJJ-CE-A-HH-B-D-A-C-BHH-CE-A-HH-A-NNN-*	M46	M46-046PT
M91-46677	PUMP-TANDEM, VAR DISPL	MPT-046-C-D-Z-C-B-AA-B-B-A-A-BMM-CG-A-JJ-B-D-A-A-BGG-CG-A-JJ-B-NNN-*	M46	M46-046PT
M91-46678	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-Z-C-B-AA-B-A-A-A-BBG-AB-U-AA-B-C-A-A-BGB-AB-U-AA-C-NNN-	M46	M46-046PT
M91-46679	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-Z-C-B-BA-B-A-A-A-BBG-AB-U-AA-B-C-A-A-BGB-AB-U-AA-C-NNN-	M46	M46-046PT
M91-46680	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-Z-C-B-AA-B-B-A-A-BHH-CB-A-HH-B-D-A-A-BHH-CB-A-HH-C-NNN-	M46	M46-046PT
M91-46681	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-B-AA-B-A-A-A-BJJ-AB-U-AA-B-C-A-A-BJJ-AB-U-AA-A-NNN-*	M46	M46-046PT
M91-46682	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-B-AA-B-B-A-A-BJJ-CB-A-GG-B-D-A-A-BJJ-CB-A-GG-A-NNN-*	M46	M46-046PT
M91-46687	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-Z-C-B-BA-B-B-A-C-BHH-CE-A-GG-B-D-A-C-BHH-CE-A-GG-A-NNN-	M46	M46-046PT
M91-46688	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-B-BA-B-B-A-A-BFF-CE-A-GG-B-D-A-A-BDD-CE-A-GG-A-NNN-*	M46	M46-046PT
M91-46691	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-B-AA-B-A-A-A-BFF-AB-U-BB-B-C-A-A-BFF-AB-U-BB-A-NNN-*	M46	M46-046PT
M91-46692	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-B-AA-B-B-A-A-BFF-CB-A-HH-B-D-A-A-BFF-CB-A-HH-A-NNN-*	M46	M46-046PT
M91-46693	PUMP-TANDEM, VAR DISPL	MPT-046-C-H-V-C-B-AA-B-A-A-A-BFF-AB-U-BF-B-C-A-A-BFF-AB-U-BF-C-NNN-*	M46	M46-046PT
M91-46695	PUMP-TANDEM-VAR-DISPL MPT046	MPT-046-C-A-Z-C-B-AA-B-B-A-A-BGG-CG-A-HH-B-D-A-A-BGG-CG-A-HH-A-NNN-	M46	M46-046PT
M91-46696	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-Z-C-B-BA-B-A-A-A-BJJ-AB-U-DB-B-C-A-A-BJJ-AB-U-DB-B-NNN-***	M46	M46-046PT

M91-46701	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-Z-C-B-BA-B-B-A-A-BDD-CE-A-GG-B-D-A-A-BDD-CE-A-GG-A-NNN-	M46	M46-046PT
M91-46702	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-B-BA-B-B-A-A-BEE-CE-A-HH-B-D-A-A-BEE-CE-A-HH-B-NNE-*	M46	M46-046PT
M91-46703	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-V-C-B-AA-B-A-A-B-BHH-AB-U-EF-B-C-A-B-BHH-AB-D-EF-C-NNN-*	M46	M46-046PT
M91-46705	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-V-C-M-AA-B-A-A-B-BHH-AD-U-FF-B-C-A-B-BHH-AB-D-FF-C-NNN-	M46	M46-046PT
M91-46706	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-V-C-M-AA-B-A-B-C-BDD-AE-U-PF-B-C-B-C-BDD-AB-D-PF-C-NNN-*	M46	M46-046PT
M91-46707	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-V-C-M-AA-B-A-A-C-BGG-AB-U-PF-B-C-A-C-BGG-AB-D-PF-C-NNN-	M46	M46-046PT
M91-46708	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-V-C-M-AA-B-A-A-B-BHH-AD-U-FF-B-C-A-B-BHH-AB-D-FF-C-NNN-	M46	M46-046PT
M91-46709	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-B-AA-B-A-A-A-BRR-AA-U-CD-B-C-A-A-BRR-AA-D-CD-D-NNN-	M46	M46-046PT
M91-4671	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-D-C-A-AA-B-A-A-A-BJJ-AB-U-ED-B-C-A-A-BJJ-AB-D-ED-B-NNN-**	M46	M46-046PT
M91-46710	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-B-AA-B-A-A-A-BJJ-AA-U-CD-B-C-A-A-BJJ-AA-D-CD-D-NNN-**	M46	M46-046PT
M91-46711	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-V-C-J-BA-B-B-A-A-BGG-CE-A-GG-B-D-A-A-BGG-CE-A-GG-B-NNN-	M46	M46-046PT
M91-46712	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-V-C-B-AA-B-A-A-A-BHH-AB-U-ED-B-C-A-A-BCC-AB-U-AA-B-NNN-	M46	M46-046PT
M91-46713	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-B-AA-B-A-A-A-BHH-AB-U-ED-B-C-A-A-BCC-AB-U-AA-C-NNN-	M46	M46-046PT
M91-46715	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-B-BA-B-B-A-A-BJJ-CG-A-HH-B-D-A-A-BJJ-CG-A-HH-B-NNN-**	M46	M46-046PT
M91-46716	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-Z-C-J-AA-B-B-A-A-BJJ-CD-A-GG-B-D-A-A-BJJ-CD-A-GG-C-NNN-**	M46	M46-046PT
M91-46721	PUMP-TANDEM, VAR DISPL	MPT-046-C-T-Z-C-J-AA-B-B-A-A-BJJ-CG-A-GG-B-D-A-A-BDD-CG-A-GG-A-NNN-*	M46	M46-046PT
M91-46722	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-Z-C-B-AA-B-A-A-A-BEE-AB-U-AA-B-C-A-A-BEE-AB-U-AA-C-NNN-*	M46	M46-046PT
M91-46723	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-Z-C-B-BA-B-B-A-C-BHH-CE-A-GG-B-D-A-C-BHH-CE-A-GG-D-NNN-	M46	M46-046PT
M91-46724	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-Z-C-B-AA-B-B-A-A-BGG-CE-A-HH-B-D-A-A-BGG-CE-A-HH-B-NNN-	M46	M46-046PT
M91-46725	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-B-AA-B-A-A-A-BGG-AB-U-AA-B-C-A-A-BGG-AB-U-AA-A-NNN-	M46	M46-046PT
M91-46726	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-Z-C-B-AA-B-B-A-A-BGG-CB-A-HH-B-D-A-A-BGG-CB-A-HH-B-NNN-	M46	M46-046PT
M91-46730	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-S-A-B-BC-B-A-G-A-BGG-AB-U-FD-B-C-G-A-BGG-AB-D-FD-B-ANN-*	M46	M46-046PT
M91-46740	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-Z-C-J-AA-B-B-A-A-BFF-CD-A-GG-B-D-A-A-BFF-CD-A-GG-C-NNN-*	M46	M46-046PT
M91-46743	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-V-C-B-AA-B-A-A-A-BHH-AB-U-EF-B-C-A-A-BHH-AB-U-EF-C-NNN-*	M46	M46-046PT
M91-46744	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-Z-C-B-AA-B-B-A-A-BJJ-CG-A-HH-B-D-A-A-BJJ-CG-A-HH-B-NNN-**	M46	M46-046PT
M91-46745	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-V-C-B-AA-B-A-A-A-BDD-AB-U-FF-B-C-A-A-BDD-AB-U-FF-B-NNN-*	M46	M46-046PT
M91-46748	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-B-BA-B-B-A-A-BGG-AB-D-EF-B-C-A-A-BGG-AB-U-EF-B-NNN-*	M46	M46-046PT
M91-46749	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-B-BA-B-B-A-A-BFF-AB-U-BB-B-C-A-A-BFF-AB-U-BB-A-NNN-*	M46	M46-046PT
M91-4675	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-BA-B-B-A-A-BGG-BA-A-GG-B-D-A-A-BGG-BA-A-GG-B-NNN-	M46	M46-046PT
M91-46750	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-B-BA-B-B-A-A-BJJ-CB-A-GG-B-D-A-A-BJJ-CB-A-GG-C-NNN-**	M46	M46-046PT
M91-46751	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-V-C-B-AA-B-A-A-B-BHH-AB-U-FF-B-C-A-B-BHH-AB-D-FF-C-NNN-*	M46	M46-046PT
M91-46753	PUMP-TANDEM, VAR DISPL	MPT-046-C-H-Z-C-B-BA-B-A-C-A-BHH-AB-U-ED-B-C-A-A-BJB-AB-D-FF-C-NNN-*	M46	M46-046PT
M91-46754	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-B-BA-B-B-A-A-BEE-AB-U-CD-B-C-A-A-BEE-AB-U-CD-A-NNN-*	M46	M46-046PT
M91-46755	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-V-C-B-BA-B-B-A-A-BDD-AB-U-FF-B-C-A-A-BDD-AB-U-FF-A-NNN-*	M46	M46-046PT
M91-46756	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-Z-C-S-AA-B-B-A-A-BJJ-CG-A-HH-B-D-A-A-BJJ-CG-A-HH-B-NNN-**	M46	M46-046PT
M91-46759	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-Z-C-B-AA-B-B-A-B-BGG-CB-A-GG-B-D-A-B-BGG-CB-A-GG-A-NNA-	M46	M46-046PT

M91-4676	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-AA-B-A-A-A-BHH-AB-U-ED-B-C-A-A-BHH-AB-U-ED-C-NNN-	M46	M46-046PT
M91-46760	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-V-C-B-AA-B-A-A-A-BHH-AB-U-EF-B-C-A-A-BHH-AB-U-EF-C-NNN-*	M46	M46-046PT
M91-46761	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-T-A-B-BC-B-A-A-A-BDD-AB-U-AA-B-C-A-A-BDD-AB-U-AA-C-NNN-	M46	M46-046PT
M91-46765	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-Z-C-B-AA-B-B-A-A-BJJ-CD-A-GG-B-D-A-A-BGG-CD-A-GG-C-NNN-*	M46	M46-046PT
M91-46766	PUMP-TANDEM-VAR-DISPL MPT046	MPT-046-C-A-Z-C-B-AA-B-A-A-A-BJJ-AB-U-ED-B-C-A-A-BGG-AB-U-ED-C-NNN-*	M46	M46-046PT
M91-46769	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-B-BA-B-A-A-C-BDD-AB-U-AA-B-C-A-A-BDD-AB-U-AA-C-NNN-	M46	M46-046PT
M91-4677	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-D-C-A-AA-B-A-A-A-BDD-AB-D-CD-B-C-A-A-BDD-AB-D-CD-A-NNN-	M46	M46-046PT
M91-46772	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-V-C-M-AA-B-A-A-B-BJJ-GE-U-FF-B-C-A-B-BJJ-GE-D-FF-C-ANN-***	M46	M46-046PT
M91-46776	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-V-C-M-AA-B-A-A-B-BRR-GE-U-FF-B-C-A-B-BRR-GE-D-FF-C-NNN-*	M46	M46-046PT
M91-46777	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-S-A-S-BC-B-A-A-A-BRR-AK-D-CF-B-C-A-A-BRR-AK-D-CF-G-NNN-*	M46	M46-046PT
M91-46780	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-V-C-B-BA-B-A-G-A-BJJ-AB-D-BB-B-C-G-A-BJJ-AB-U-BB-A-ANN-***	M46	M46-046PT
M91-46782	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-B-BA-B-A-A-A-BJJ-AA-U-CD-B-C-A-A-BJJ-AA-D-CD-D-NNN-*	M46	M46-046PT
M91-46788	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-V-C-J-BA-B-A-A-A-BJJ-AB-U-FF-B-C-A-A-BJJ-AB-U-FF-B-NNN-***	M46	M46-046PT
M91-46789	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-V-C-J-BA-B-A-A-A-BBJ-AB-U-FF-B-C-A-A-BBJ-AB-U-FF-C-NNN-***	M46	M46-046PT
M91-46790	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-B-AA-B-B-A-A-BHH-CE-A-GG-B-D-A-A-BHH-CE-A-GG-A-NNN-	M46	M46-046PT
M91-46791	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-V-C-B-AA-B-A-A-A-BGG-AW-U-EF-B-C-A-A-BGG-AW-D-EF-B-NNN-	M46	M46-046PT
M91-46792	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-V-C-B-AA-B-B-A-A-BFF-CD-A-HH-B-D-A-A-BFF-CD-A-HH-A-NNN-*	M46	M46-046PT
M91-46794	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-B-AA-B-A-A-A-BDD-AB-D-ED-B-C-A-A-BDD-AB-D-ED-A-NNN-	M46	M46-046PT
M91-46795	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-V-C-B-BA-B-A-G-A-BHH-AB-D-BB-B-C-G-A-BHH-AB-U-BB-A-ANN-	M46	M46-046PT
M91-46797	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-B-AA-B-B-A-A-BDD-CB-A-HH-B-D-A-A-BDD-CB-A-HH-A-NNN-	M46	M46-046PT
M91-46798	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-V-C-S-BA-B-A-A-A-BRR-AA-U-CD-B-C-A-A-BRR-AA-D-CD-B-NNN-*	M46	M46-046PT
M91-46799	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-Z-C-B-AA-B-B-A-A-BJJ-CD-A-HH-B-D-A-A-BGG-CD-A-HH-C-NNN-*	M46	M46-046PT
M91-46800	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-Z-C-B-AA-B-B-A-A-BGG-CD-A-HH-B-D-A-A-BGG-CD-A-HH-A-NNN-	M46	M46-046PT
M91-46801	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-S-BA-B-A-A-A-BRR-AA-U-CD-B-C-A-A-BRR-AA-D-CD-B-NNN-*	M46	M46-046PT
M91-46803	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-B-AA-B-A-A-A-BHH-AB-U-CD-B-C-A-A-BHH-AB-U-CD-A-NNN-	M46	M46-046PT
M91-46804	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-V-C-B-BA-B-B-A-A-BBB-CD-A-HH-B-D-A-A-BBB-CD-A-HH-B-NNN-	M46	M46-046PT
M91-46806	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-V-C-M-AA-B-A-A-C-BGG-AB-U-PF-B-C-A-C-BGG-AB-D-PF-C-NBN-	M46	M46-046PT
M91-46808	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-V-C-B-BA-B-A-A-A-BJJ-AC-U-ED-B-C-A-A-BJJ-AC-D-FF-A-NBN-***	M46	M46-046PT
M91-46809	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-Z-C-B-BA-B-B-A-A-BJJ-CB-A-JJ-B-D-A-A-BJJ-CB-A-JJ-B-NNN-***	M46	M46-046PT
M91-4681	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-AA-B-A-A-A-BJJ-AB-U-ED-B-C-A-A-BJJ-AB-U-ED-C-NNN-***	M46	M46-046PT
M91-46810	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-B-AA-B-B-A-A-BJJ-BA-A-HH-B-D-A-A-BJJ-BA-A-HH-C-NNN-*	M46	M46-046PT
M91-46812	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-V-C-M-AA-B-A-A-B-BJJ-GE-U-KF-B-C-A-B-BJJ-GE-D-KF-C-NBA-***	M46	M46-046PT
M91-46813	PUMP-TANDEM-VAR-DISPL MPT046	MPT-046-C-A-Z-C-B-AA-B-B-A-A-BGG-CD-A-HH-B-D-A-A-BGG-CD-A-HH-B-NNN-	M46	M46-046PT
M91-46814	PUMP-TANDEM, VAR DISPL	MPT-046-C-T-Z-C-J-AA-B-B-A-A-BJJ-CG-A-GG-B-D-A-A-BDD-CG-A-GG-B-NNN-*	M46	M46-046PT
M91-46817	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-B-AA-B-B-A-A-BHH-CE-A-HH-B-D-A-A-BHH-CE-A-HH-B-NNN-	M46	M46-046PT
M91-46818	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-V-C-B-BA-B-A-G-A-BGG-AB-D-BB-B-C-G-A-BGG-AB-U-BB-A-ANN-	M46	M46-046PT

M91-46819	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-V-C-M-AA-B-A-A-B-BJ-GE-U-FF-B-C-A-B-BJ-GE-D-FF-C-NBA-***	M46	M46-046PT
M91-4682	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-G-A-A-BC-B-A-A-A-BGG-AB-U-BA-B-C-A-A-BGG-AB-D-BA-A-NNN-	M46	M46-046PT
M91-46820	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-V-C-B-BA-B-B-G-A-BHH-CE-A-HH-B-D-G-A-BHH-CE-A-HH-C-NNN-	M46	M46-046PT
M91-46821	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-Z-C-B-BA-B-B-G-A-BBB-CE-A-HH-B-D-G-A-BBB-CE-A-HH-C-NNN-*	M46	M46-046PT
M91-46822	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-V-C-B-BA-B-B-G-A-BHH-BA-A-GG-B-D-G-A-BHH-BA-A-GG-A-NNN	M46	M46-046PT
M91-46826	PUMP-TANDEM-VAR-DISPL MPT046	MPT-046-C-A-Z-C-C-AA-B-B-A-A-BGG-DA-A-GG-B-D-A-A-BGG-DA-A-GG-C-NNN	M46	M46-046PT
M91-46827	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-B-AA-B-A-A-A-BGG-AB-U-BB-B-C-A-A-BGG-AB-U-BB-C-NNN-	M46	M46-046PT
M91-46828	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-S-A-B-BC-B-A-G-A-BHH-AB-U-BB-B-C-G-A-BHH-AB-U-BB-D-NNN-	M46	M46-046PT
M91-46829	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-S-A-B-BC-B-A-G-A-BHH-AB-D-BB-B-C-G-A-BHH-AB-D-BB-D-ANN-*	M46	M46-046PT
M91-46830	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-B-AA-B-A-A-A-BJJ-AB-U-DD-B-C-A-A-BJJ-AB-D-DD-A-NNN-**	M46	M46-046PT
M91-46833	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-Z-C-B-AA-B-B-A-A-BHH-CB-A-GG-B-D-A-A-BHH-CB-A-GG-C-NNN-	M46	M46-046PT
M91-46834	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-Z-C-B-AA-B-B-A-A-BMM-CE-A-HH-B-D-A-A-BMM-CE-A-HH-C-NN-	M46	M46-046PT
M91-46836	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-Z-C-B-AA-B-B-A-A-BFF-CE-A-GG-B-D-A-A-BFF-CE-A-GG-C-NNN-*	M46	M46-046PT
M91-46837	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-Z-C-B-AA-B-B-A-A-BFF-CE-A-GG-B-D-A-A-BFF-CE-A-GG-B-NNN-*	M46	M46-046PT
M91-46838	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-B-BA-B-B-A-A-BFF-CB-A-JJ-B-D-A-A-BFF-CB-A-JJ-A-NNN-***	M46	M46-046PT
M91-46839	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-Z-C-J-BA-B-B-A-A-BJJ-CE-A-HH-B-D-A-A-BJJ-CE-A-HH-A-NNN-***	M46	M46-046PT
M91-46840	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-B-BA-B-B-A-A-BHH-BA-A-HH-B-D-A-A-BHH-BA-A-HH-B-NNN-	M46	M46-046PT
M91-46841	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-V-C-M-AA-B-A-A-C-BJJ-GE-U-KF-B-C-A-C-BJJ-GE-D-KF-C-NNF-***	M46	M46-046PT
M91-46842	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-V-C-J-AA-B-B-A-A-BHH-CB-A-HH-B-D-A-A-BHH-CB-A-HH-C-NNN-	M46	M46-046PT
M91-46843	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-V-C-J-AA-B-B-A-A-BFF-CB-A-HH-B-D-A-A-BFF-CB-A-HH-C-NNN-*	M46	M46-046PT
M91-46845	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-V-C-B-BA-B-B-G-A-BDD-CE-A-HH-B-D-G-A-BBB-CE-A-HH-C-NNN-	M46	M46-046PT
M91-46846	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-Z-C-B-AA-B-B-A-A-BFF-CB-A-HH-B-D-A-A-BFF-CB-A-HH-B-NNN-*	M46	M46-046PT
M91-46849	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-Z-C-B-AA-B-B-A-A-BFF-CB-A-GG-B-D-A-A-BFF-CB-A-GG-C-NNN-*	M46	M46-046PT
M91-46850	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-B-AA-B-B-A-A-BGG-CE-A-GG-B-D-A-A-BGG-CE-A-GG-C-NNN-	M46	M46-046PT
M91-46851	PUMP-TANDEM-VAR-DISPL MPT046	MPT-046-C-A-Z-C-B-AA-B-B-A-A-BDD-CB-A-GG-B-D-A-A-BDD-CB-A-GG-B-NNN-	M46	M46-046PT
M91-46852	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-Z-C-B-AA-B-B-A-A-BBB-AB-U-FF-B-C-A-A-BBB-AB-U-FF-A-NNN-*	M46	M46-046PT
M91-46853	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-B-BA-B-B-A-A-BJJ-AB-D-CD-B-C-A-A-BJJ-AB-U-CD-A-NNN-**	M46	M46-046PT
M91-46854	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-B-AA-B-B-A-A-BGG-CB-A-HH-B-D-A-A-BMM-CB-A-HH-C-NNN-	M46	M46-046PT
M91-46857	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-B-AA-B-B-A-A-BHH-AB-U-ED-B-C-A-A-BHH-AB-U-ED-A-NNN-	M46	M46-046PT
M91-46860	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-B-BA-B-B-A-A-BJJ-AB-U-CD-B-D-A-A-BBB-DA-A-HH-A-NNC-*	M46	M46-046PT
M91-46861	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-J-AA-B-B-A-A-BCC-CE-A-GG-B-D-A-A-BMM-CE-A-GG-A-NNN-	M46	M46-046PT
M91-46862	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-J-BA-B-B-A-A-BEE-CB-A-GG-B-D-A-A-BEE-CB-A-GG-B-NNN-*	M46	M46-046PT
M91-46863	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-J-AA-B-B-A-A-BEF-CE-A-GG-B-D-A-A-BMM-CE-A-GG-A-NNN-	M46	M46-046PT
M91-46865	PUMP-TANDEM-VAR-DISPL MPT046	MPT-046-C-A-Z-C-B-AA-B-B-A-A-BJJ-CD-A-GG-B-D-A-A-BGG-CD-A-GG-B-NNN-*	M46	M46-046PT
M91-46867	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-V-C-M-AA-B-A-A-C-BJJ-GE-U-KF-B-C-A-B-BJJ-GE-D-KF-B-NNN-***	M46	M46-046PT
M91-46868	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-V-C-M-AA-B-A-A-C-BJJ-GE-U-KF-B-C-A-B-BJJ-GE-D-KF-Y-NBA-***	M46	M46-046PT

M91-46871	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-Z-C-J-AA-B-A-A-A-BHH-AB-U-ED-B-C-A-A-BHH-AB-U-ED-A-NNN-*	M46	M46-046PT
M91-46872	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-J-AA-B-A-A-A-BHH-AB-U-ED-B-C-A-A-BHH-AB-U-ED-A-NNN-*	M46	M46-046PT
M91-46873	PUMP-TANDEM, VAR DISPL	MPT-046-C-H-Z-C-J-BA-B-B-A-A-BJJ-CE-A-HH-B-D-A-A-BJJ-CE-A-HH-A-NNN-***	M46	M46-046PT
M91-46874	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-Z-C-B-AA-B-B-V-A-BGG-DA-A-GG-B-D-V-A-BGG-DA-A-GG-C-NNN	M46	M46-046PT
M91-46875	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-V-C-S-AA-B-A-A-A-BHH-GG-B-KF-B-C-A-A-BHH-GG-B-KF-B-NBA-*	M46	M46-046PT
M91-46877	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-Z-C-J-BA-B-B-A-A-BHH-BA-A-JJ-B-D-A-A-BHH-BA-A-JJ-C-NNN-***	M46	M46-046PT
M91-46878	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-V-C-J-BA-B-B-A-C-BJJ-CE-A-HH-B-D-A-C-BHH-CE-A-HH-A-NNN-**	M46	M46-046PT
M91-46879	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-Z-C-B-AA-B-B-A-A-BEE-CB-A-SS-B-D-A-A-BEE-CB-A-SS-C-NNN-***	M46	M46-046PT
M91-46880	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-Z-C-B-AA-B-B-A-A-BEE-CB-A-HH-B-D-A-A-BEE-CB-A-HH-C-NNN-*	M46	M46-046PT
M91-46881	PUMP-TANDEM-VAR-DISPL MPT046	MPT-046-C-A-Z-C-B-AA-B-B-V-A-BEE-DA-A-GG-B-D-V-A-BEE-DA-A-GG-C-NNN-*	M46	M46-046PT
M91-46882	PUMP-TANDEM, VAR DISPL	MPT-046-C-T-Z-C-J-BA-B-B-A-A-BJJ-CE-A-HH-B-D-A-A-BJJ-CE-A-HH-A-NNN-***	M46	M46-046PT
M91-46883	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-J-BA-B-B-A-A-BEE-CB-A-JJ-B-D-A-A-BEE-CB-A-JJ-B-NNN-***	M46	M46-046PT
M91-46884	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-B-BA-B-B-A-A-BEE-CE-A-JJ-B-D-A-A-BEE-CE-A-JJ-B-NNN-***	M46	M46-046PT
M91-46885	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-J-BA-B-B-A-A-BEE-CB-A-JJ-B-D-A-A-BED-CB-A-JJ-B-NNN-***	M46	M46-046PT
M91-46886	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-B-BA-B-B-A-A-BJJ-AB-U-CD-B-A-A-A-BBB-AB-U-ZP-A-NNC-**	M46	M46-046PT
M91-46887	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-V-C-S-AA-B-A-A-A-BJJ-GG-B-KF-B-C-A-A-BJJ-GG-B-KF-B-NBA-***	M46	M46-046PT
M91-46888	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-V-C-S-AA-B-A-A-B-BJJ-AB-D-KF-B-C-A-B-BJJ-AB-U-KF-Y-NBA-***	M46	M46-046PT
M91-4689	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-G-A-A-BC-B-A-A-B-BFF-AB-D-CF-B-C-A-B-BFF-AB-U-CF-A-NNN-**	M46	M46-046PT
M91-46890	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-Z-C-J-AA-B-A-A-A-BHH-AB-U-ED-B-C-A-A-BHH-AB-U-ED-D-NNN-*	M46	M46-046PT
M91-46892	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-V-C-J-AA-B-B-A-C-BJJ-CE-A-HH-B-D-A-C-BHH-CE-A-HH-A-NNN-**	M46	M46-046PT
M91-46893	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-Z-C-B-AA-B-B-A-A-BGG-AB-U-AA-B-C-A-A-BGG-AB-U-AA-C-NNN-	M46	M46-046PT
M91-46894	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-J-BA-B-B-A-A-BDD-CB-A-JJ-B-D-A-A-BEE-CB-A-JJ-B-NNN-***	M46	M46-046PT
M91-46896	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-V-C-B-BA-B-B-A-A-BJJ-CB-A-GG-B-D-A-A-BJJ-CB-A-GG-A-NNN-**	M46	M46-046PT
M91-46897	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-V-C-S-AA-B-B-A-A-BFF-BA-A-HH-B-D-A-A-BJD-BA-A-GG-D-NNN-*	M46	M46-046PT
M91-46898	PUMP-TANDEM, VAR DISPL	MPT-046-C-E-Z-C-B-BA-B-B-B-A-BFF-CB-A-GG-B-D-B-A-BFF-CB-A-GG-A-NNN-**	M46	M46-046PT
M91-46899	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-V-C-B-BA-B-B-A-A-BJJ-AB-U-BB-B-C-A-A-BJJ-AB-U-BB-C-NNN-***	M46	M46-046PT
M91-4690	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-C-C-A-AA-B-A-A-A-BGG-AB-U-ED-B-C-A-A-BGG-AB-D-ED-A-NNN-	M46	M46-046PT
M91-4692	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-D-C-A-AA-B-B-G-A-BBB-CD-A-GG-B-D-G-A-BBB-CD-A-GG-C-NNN-	M46	M46-046PT
M91-4695	PUMP-TANDEM, VAR DISPL	MPT-046-C-A-D-C-A-BA-B-B-A-A-BGG-CE-A-GG-B-D-A-A-BGG-CE-A-GG-A-NNN-	M46	M46-046PT
M91-4696	PUMP-TANDEM, VAR DISPL	MPT-046-C-B-D-C-A-BA-B-B-A-A-BDD-AB-U-ED-B-C-A-A-BDD-AB-U-ED-C-NNN-	M46	M46-046PT
MF18-607	MOTOR-FIXED-DISPL MF18		OSK S10/S15/S16/S	O18MF
MVKC_CM	MOTOR-VARIABLE CARTRIDGE K	K-C-MVKC_CM-Y-Y-N	LV / KV MOTORS	L/K-MV
MVKV_CM	MOTOR-VARIABLE DISPL SAE_K	K-V-MVKV_CM-Y-Y-N	LV / KV MOTORS	L/K-MV
MVLC_CM	MOTOR-VARIABLE CARTRIDGE L	L-C-MVLC_CM-Y-Y-N	LV / KV MOTORS	L/K-MV
MVLV_CM	MOTOR-VARIABLE DISPL SAE_L	L-V-MVLV_CM-Y-Y-N	LV / KV MOTORS	L/K-MV
PV10-625	PUMP-VAR DISPL, PV10		OSK S10/S15/S16/S	O10PV

PV10-629	PUMP-VAR DISPL, PV10		OSK S10/S15/S16/S	S010PV
PV10-632	PUMP-VAR DISPL, PV10		OSK S10/S15/S16/S	S010PV
PV100-676ED	PUMP-VAR DISPL 90PV100	90R100-KA-1-CD-60-R-3-C7-E-00-FAD-17-17-24	SERIES 90	S90-100PV
PVM28-504	PISTON PUMP-VAR DISPL S42PVM28	42-R-28-D-ZNA8-10-A-N-N-N-E-N-A-34-34-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
PVM28-505	PISTON PUMP-VAR DISPL S42PVM28	42-R-28-D-ZNA8-10-A-N-N-N-E-N-A-34-34-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
PVM28-506ED	PISTON PUMP-VAR DISPL S42PVM28	42-R-28-C-E1A5-00-A-N-A-2-C-N-A-34-34-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
PVM28-507ED	PISTON PUMP-VAR DISPL S42PVM28	42-L-28-D-E1A5-00-A-N-A-2-F-N-B-30-30-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
PVM28-508ED	PISTON PUMP-VAR DISPL S42PVM28	42-R-28-C-E1A5-00-A-N-N-N-C-N-G-25-25-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
PVM28-625	PISTON PUMP-VAR DISPL S42PVM28	42-R-28-D-G2A1-55-V-N-F-2-H-5-N-B8-B8-N-0-0-NNN-ENN	SERIES 42	S42-028PV/032PV
PVM28-704	PUMP-VAR DISPL, CCW	42-L-28-C-NDNB-NN-A-N-N-N-H-N-B-23-23-N-A-A-NNN-CNN	SERIES 42	S42-028PV/032PV
PVM28-705	PUMP-VAR DISPL, CCW	42-L-28-C-NDNA-NN-A-N-A-2-E-N-N-28-28-N-N-N-NNN-CNN	SERIES 42	S42-028PV/032PV
PVM28-706	PUMP-VAR DISPL, CCW	42-L-28-D-NDNB-NN-B-D-B-2-C-N-N-21-21-N-N-N-NNN-CNN	SERIES 42	S42-028PV/032PV
PVM28-707	PUMP-VAR DISPL, CCW	42-L-28-D-NDNB-NN-C-2-A-2-F-N-B-30-30-B-N-N-NNN-CNN	SERIES 42	S42-028PV/032PV
PVM28-708	PUMP-VAR DISPL, CCW	42-L-28-C-NDNB-NN-C-2-A-2-F-N-N-30-30-B-N-N-NNN-CNN	SERIES 42	S42-028PV/032PV
PVM28-709	PUMP-VAR DISPL, CCW	42-L-28-D-NDNB-NN-C-3-N-N-H-N-B-25-25-N-N-N-NNN-CNN	SERIES 42	S42-028PV/032PV
PVM28-710	PUMP-VAR DISPL, CCW	42-L-28-C-NDNA-NN-D-N-F-2-E-N-N-34-34-N-N-N-NNN-CNN	SERIES 42	S42-028PV/032PV
PVM28-711	PUMP-VAR DISPL, CW	42-R-28-C-NDNB-NN-A-N-N-N-C-N-A-30-30-N-A-A-NNN-CNN	SERIES 42	S42-028PV/032PV
PVM28-712	PUMP-VAR DISPL, CW	42-R-28-D-NDNA-NN-B-2-B-3-F-N-B-34-34-N-N-N-NNN-CNN	SERIES 42	S42-028PV/032PV
PVM28-713	PUMP-VAR DISPL, CW, S42PV028	42-R-28-D-NDNB-NN-B-D-B-2-H-N-N-28-28-N-N-N-NNN-CNN	SERIES 42	S42-028PV/032PV
PVM28-714	PUMP-VAR DISPL, CW	42-R-28-C-NDNB-NN-B-D-X-N-H-N-T-34-34-N-A-A-NNN-CNN	SERIES 42	S42-028PV/032PV
PVM28-715	PUMP-VAR DISPL, CW	42-R-28-D-NDNB-NN-C-5-A-2-C-N-A-28-28-N-N-N-NNN-CNN	SERIES 42	S42-028PV/032PV
PVM28-716	PUMP-VAR DISPL, CW	42-R-28-C-NDNB-NN-D-N-F-2-F-N-N-28-28-N-N-N-NNN-CNN	SERIES 42	S42-028PV/032PV
PVM28-718	PISTON PUMP-VAR DISPL S42PVM28	42-R-28-C-G3AN-50-P-2-B-2-H-1-B-38-38-N-0-0-NNN-NNN	SERIES 42	S42-028PV/032PV
PVM28-719	PISTON PUMP-VAR DISPL S42PVM28	42-R-28-D-G3AN-50-P-2-B-2-H-1-B-38-38-N-0-0-NNN-NNN	SERIES 42	S42-028PV/032PV
PVM28-720	PUMP-VAR-DISPL, CW, S42PV028, NFPE	42-R-28-D-G2A2-53-V-N-F-2-H-2-T-28-28-N-T-T-NNN-NNN	SERIES 42	S42-028PV/032PV
PVM28-721	PUMP-VAR-DISPL, CW, S42PV028, MDC	42-R-28-D-ANNA-10-C-3-A-2-F-N-N-34-34-B-N-N-NNN-NGJ	SERIES 42	S42-028PV/032PV
PVM28-723	PUMP-VAR-DISPL, CW, S42PV028, MDC	42-R-28-C-ANN3-03-D-N-F-2-E-N-A-30-30-B-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
PVM28-724	PUMP-VAR-DISPL, CW, S42PV028, MDC	42-R-28-C-ANN3-03-D-N-F-2-F-N-A-23-23-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
PVM28-725	PUMP-VAR-DISPL, CW, S42PV028, NFPE	42-R-28-D-G2A1-52-V-N-F-2-F-5-A-34-34-B-0-0-NNN-NNN	SERIES 42	S42-028PV/032PV
PVM28-726	PUMP-VAR DISPL, CW, S42PV028	42-R-2A-D-G2A1-50-U-2-B-2-E-1-A-28-28-B-1-1-AAA-NNN	SERIES 42	S42-028PV/032PV
PVM28-727	S42 PUMP, VARIABLE CW S42	42-R-28-C-ANN3-03-A-N-A-2-F-N-B-21-21-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
PVM28-729	PUMP-VAR-DISPL, CW, S42PV028	42-R-28-D-ANN3-03-A-N-A-2-F-N-N-30-30-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
PVM28-730	PUMP-VAR-DISPL, CW, S42PV028	42-R-28-D-ANNB-02-C-2-A-2-E-N-A-34-34-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
PVM28-731	PUMP-VAR-DISPL, CW, S42PV028, NFPH	42-R-28-C-G3AN-53-T-N-D-2-C-5-A-21-21-B-1-1-NNN-NNN	SERIES 42	S42-028PV/032PV
PVM28-732	PUMP-VAR DISPL, S42 PVM28	42-R-2A-D-G2A1-50-U-2-B-2-E-1-A-32-32-B-1-1-AAA-NNN	SERIES 42	S42-028PV/032PV
PVM28-733	PUMP-VAR-DISPL, CW, S42PV028, MDC	42-R-28-C-ANNB-02-B-D-C-2-F-N-A-25-25-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV

PVM28-735	PUMP-VAR DISPL, CW	42-R-28-C-ANN3-02-C-3-A-2-F-N-A-30-30-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
PVM28-736	PUMP-VAR DISPL, CW, S42PV028	42-R-28-D-ANNB-02-B-3-G-2-E-N-A-41-41-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
PVM28-737	PUMP-VAR DISPL, CW, S42PV028	42-R-28-D-ZNN8-11-C-2-N-A-F-N-Z-38-38-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
PVM28-738	PUMP-VAR-DISPL, CW, S42PV028, NFPE	42-R-28-C-G2A1-52-U-2-G-2-F-5-A-21-21-B-0-0-NNN-NNN	SERIES 42	S42-028PV/032PV
PVM28-739	PISTON PUMP-VAR DISPL S42PVM28	42-R-28-D-A1N5-02-C-2-N-A-G-N-Z-30-30-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
PVM28-740	PISTON PUMP-VAR DISPL S42PVM28	42-R-28-D-F6NN-53-U-4-G-2-C-N-B-34-34-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
PVM28-741	PUMP-VAR-DISPL_CW_42PV028	42-R-28-D-F7NN-53-U-2-B-2-F-N-B-21-21-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
PVM28-742	PUMP-VAR-DISPL_CW_42PV028	42-R-28-D-L7J5-11-A-N-N-N-F-N-A-34-34-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
PVM28-746	PUMP-VAR-DISPL, CW, S42PV028, MDC	42-L-28-D-ANN3-02-A-N-A-3-C-N-B-25-25-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
PVM28-747	PUMP-VAR-DISPL, CW, S42PV028, MDC	42-L-28-C-ANN3-02-A-N-A-3-C-N-N-25-25-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
PVM28-748	PUMP-VAR-DISPL, CW, S42PV028, MDC	42-R-28-D-A7J5-03-C-4-A-3-C-N-B-25-25-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
PVM28-749	PUMP-VAR-DISPL, CW, S42PV028, MDC	42-R-28-C-A7J5-03-C-4-A-3-C-N-A-25-25-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
PVM28-752	PUMP-VAR DISPL, CW, S42PV028	42-R-28-C-A1N5-03-A-N-A-2-F-N-T-34-34-B-H-H-NNN-NNN	SERIES 42	S42-028PV/032PV
PVM28-753	PUMP-VAR DISPL, CCW, S42PV028	42-L-28-D-G3AN-52-P-D-G-2-F-1-A-38-38-B-0-0-NNN-NNN	SERIES 42	S42-028PV/032PV
PVM28-754	PUMP-VAR-DISPL, CW, S42PV028	42-R-28-C-ANNB-03-C-3-A-3-E-N-N-34-34-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
PVM28-755	PUMP-VAR-DISPL, CW, S42PV028	42-R-28-C-G2A1-53-U-D-G-2-H-5-N-NN-NN-N-1-1-NNN-NNN	SERIES 42	S42-028PV/032PV
PVM28-756	PUMP-VAR-DISPL_CW_42PV028	42-R-28-D-ANNB-02-A-N-A-2-C-N-A-28-28-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
PVM28-758	PUMP-VAR-DISPL_CW_42PV028	42-L-28-D-NDNB-NN-C-D-A-A-F-N-Z-30-30-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
PVM28-759	PUMP-VAR-DISPL_CW_42PV028	42-R-28-D-NDNB-NN-C-D-A-A-F-N-Z-30-30-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
PVM28-760	PUMP-VAR-DISPL_CW_42PV028	42-L-28-D-NDNB-NN-B-D-G-A-F-N-Z-30-30-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
PVM28-761	PUMP-VAR-DISPL_CW_42PV028	42-R-28-D-NDNB-NN-B-D-G-A-F-N-Z-30-30-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
PVM28-762	PUMP-VAR-DISPL_CW_42PV028	42-L-28-D-NDNB-NN-D-N-F-A-F-N-Z-30-30-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
PVM28-763	PUMP-VAR-DISPL_CW_42PV028	42-R-28-D-NDNB-NN-D-N-F-A-F-N-Z-30-30-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
PVM28-765	PISTON PUMP-VAR DISPL S42PVM28	42-L-28-D-G3AN-52-P-D-B-3-H-5-N-34-34-N-1-1-NNN-NNN	SERIES 42	S42-028PV/032PV
PVM28-768	PUMP-VAR-DISPL_CCW_42PV028	42-R-28-D-G3AN-52-P-D-G-2-H-1-B-41-41-N-0-0-NNN-NNN	SERIES 42	S42-028PV/032PV
PVM28-769	PUMP-VAR-DISPL_CCW_42PV028	42-R-28-D-G3AN-52-P-D-G-2-H-1-B-19-19-N-0-0-NNN-NNN	SERIES 42	S42-028PV/032PV
PVM28-770	PUMP-VAR-DISPL_CCW_42PV028	42-R-28-C-ANN3-03-B-D-B-2-F-N-A-23-23-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
PVM28-771	PUMP-VAR-DISPL_CCW_42PV028	42-L-28-D-ANN3-03-A-N-A-2-F-N-N-30-30-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
PVM28-772	PUMP-VAR DISPL, CW, S42PV028	42-R-28-D-ANN5-02-C-2-A-2-E-N-A-34-34-N-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
PVM28-773	PUMP-VAR DISPL, CW, S42PV028	42-R-28-C-ANN3-03-C-3-A-2-F-N-N-34-34-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
PVM28-774	PUMP-VAR-DISPL_CW_42PV028	42-R-28-C-ANN3-02-A-N-A-2-F-N-A-21-21-B-N-N-NNN-NNN	SERIES 42	S42-028PV/032PV
PVM28-775	PUMP-VAR-DISPL, CW, S42PV028	42-R-28-C-F6NN-53-U-3-G-2-F-N-N-28-28-N-A-A-NNN-NNN	SERIES 42	S42-028PV/032PV
PVM41-611	PISTON PUMP-VAR DISPL S42PVM41	42-R-41-K-ANJ5-01-C-2-A-3-H-N-A-B1-B1-N-N-N-NNN-ENN	SERIES 42	S42-041PV/051PV
PVM41-701	PUMP-VAR DISPL, CW, S42PV041	42-R-4A-D-G1A1-72-J-D-B-2-F-5-A-34-34-N-0-0-AAA-NNN	SERIES 42	S42-041PV/051PV
PVM41-703	PUMP-VAR DISPL, CW S42PV041	42-R-41-D-NDNB-NN-B-2-X-A-E-N-Z-34-34-N-A-A-NNN-CNN	SERIES 42	S42-041PV/051PV
PVM41-704	PUMP-VAR DISPL, CCW S42PV041	42-L-41-D-NDNB-NN-B-D-X-A-F-N-Z-30-30-N-A-A-NNN-CNN	SERIES 42	S42-041PV/051PV

PVM41-705	PUMP-VAR-DISPL, CW, S42PV041, NFPE	42-R-41-C-G1A1-73-J-D-B-3-F-5-B-28-28-B-0-0-NNN-NNN	SERIES 42	S42-041PV/051PV
PVM41-706	PUMP-VAR-DISPL, CW, S42PV041, NFPE	42-R-41-C-G1A1-73-J-D-B-3-F-5-N-28-28-B-0-0-NNN-NNN	SERIES 42	S42-041PV/051PV
PVM41-707	PUMP-VAR DISPL, CW S42PV041	42-R-41-D-ANNA-03-B-2-G-2-F-N-A-41-41-B-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
PVM41-708	PISTON PUMP-VAR DISPL S42PVM41	42-R-41-D-F2NN-73-J-3-G-2-C-N-N-34-34-N-A-A-NNN-NNN	SERIES 42	S42-041PV/051PV
PVM41-709	PUMP-VAR DISPL, CW S42PV041	42-R-41-C-G3AN-53-P-3-G-3-H-1-A-25-25-B-1-1-NNN-NNN	SERIES 42	S42-041PV/051PV
PVM41-711	PUMP-VAR DISPL, CCW S42PV041	42-L-41-D-G3AN-53-P-3-G-3-H-5-A-34-34-B-0-0-NNN-NNN	SERIES 42	S42-041PV/051PV
PVM41-713	PUMP-VAR DISPL, CW S42PV041	42-R-41-D-F4NN-73-J-3-C-2-F-N-N-28-28-N-A-A-NNN-NNN	SERIES 42	S42-041PV/051PV
PVM41-715	PUMP-VAR-DISPL, CW, S42PV041	42-R-41-D-ANNB-02-B-2-G-2-C-N-N-25-25-N-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
PVM41-716	PUMP-VAR-DISPL, CW, S42PV041	42-R-41-D-A7J5-03-C-4-A-3-C-N-V-25-25-N-A-A-NNN-NNN	SERIES 42	S42-041PV/051PV
PVM41-717	PUMP-VAR-DISPL, CW, S42PV041	42-R-41-D-A7J5-03-C-4-A-2-C-N-A-25-25-N-A-A-NNN-NNN	SERIES 42	S42-041PV/051PV
PVM41-718	PUMP-VAR-DISPL, CW, S42PV041	42-R-41-D-A3AB-03-B-5-B-2-C-N-B-34-34-B-N-N-NNN-NNN	SERIES 42	S42-041PV/051PV
PVM4141-601	PUMP-TANDEM-VAR DISPL S42PT041		SERIES 42	S42-041PT/051PT Bolted Tandem
PVM51-616	PISTON PUMP-VAR DISPL S42PVM51	42-R-51-D-G1A1-73-J-2-B-2-H-5-T-C2-C2-B-1-1-NNN-ENN	SERIES 42	S42-041PV/051PV
PVM51-703	PUMP-VAR DISPL, CCW S42PV051	42-L-51-E-F4NN-73-J-5-B-3-D-N-V-23-23-B-A-A-NNN-NNN	SERIES 42	S42-041PV/051PV
PVM51-704	PISTON PUMP-VAR DISPL S42PVM51	42-L-51-D-G3AN-52-P-D-B-3-H-5-B-25-25-N-1-1-NNN-NNN	SERIES 42	S42-041PV/051PV
PVM5151-601	PUMP-TANDEM-VAR DISPL S42PT051		SERIES 42	S42-041PT/051PT Bolted Tandem
PVM5151-603	PUMP-TANDEM-VAR DISPL S42PT051		SERIES 42	S42-041PT/051PT Bolted Tandem
S40MF025C_CM	MOTOR-FIXED DISPL MMF025C	MMF-025-C-S40MF025C_CM	LIGHT DUTY	025MF
S40MF035D_CM	MOTOR-FIX DISPL MMF035D	MMF-035-D-S40MF035D_CM	M35/44	035MF
S40MF044D_CM	MOTOR-FIX DISPL MMF044D	MMF-044-D-S40MF044D_CM	M35/44	044MF
S40MV035D_CM	MOTOR-VAR DISPL MMV035D	MMV-035-D-S40MV035D_CM	M35/44	035MV
S40MV044D_CM	MOTOR-VAR DISPL MMV044D	MMV-044-D-S40MV044D_CM	M35/44	044MV
S40MV046C_CM	MOTOR-VAR DISPL MMV046C	MMV-046-C-S40MV046C_CM	M46	M46-046MV
S40PT025C_CM	PUMP-TANDEM, VAR DISPL MPT025C	MPT-025-C-S40PT025C_CM	LIGHT DUTY	025PT
S40PT035D_CM	PUMP-TANDEM, VAR DISPL MPT035D	MPT-035-D-S40PT035D_CM	M35/44	035PT
S40PT044D_CM	PUMP-TANDEM, VAR DISPL MPT044D	MPT-044-D-S40PT044D_CM	M35/44	044PT
S40PT046C_CM	PUMP-TANDEM, VAR DISPL MPT046C	MPT-046-C-S40PT046C_CM	M46	M46-046PT
S40PV025C_CM	PUMP-VAR DISPL MPV025C	MPV-025-C-S40PV025C_CM	LIGHT DUTY	025PV
S40PV035D_CM	PUMP-VAR DISPL MPV035D	MPV-035-D-S40PV035D_CM	M35/44	035PV
S40PV044D_CM	PUMP-VAR DISPL MPV044D	MPV-044-D-S40PV044D_CM	M35/44	044PV
S40PV046C_CM	PUMP-VAR DISPL MPV046C	MPV-046-C-S40PV046C_CM	M46	M46-046PV
S51C060_MOTORS_CM	MOTOR-VAR-DISPL 51MC060	Y-S51C060_MOTORS_CM	SERIES 51	S51-060MV
S51C080_MOTORS_CM	MOTOR-VAR-DISPL 51MC080	Y-S51C080_MOTORS_CM	SERIES 51	S51-080MV
S51C110_MOTORS_CM	MOTOR-VAR-DISPL 51MC110	Y-S51C110_MOTORS_CM-Y	SERIES 51	S51-110MV
S51C160_MOTORS_CM	MOTOR-VAR-DISPL 51MC160	Y-S51C160_MOTORS_CM	SERIES 51	S51-160MV
S51D060_MOTORS_CM	MOTOR-VAR-DISPL 51MD060	Y-S51D060_MOTORS_CM	SERIES 51	S51-060MV

S51D080_MOTORS_CM	MOTOR-VAR-DISPL 51MD080	Y-S51D080_MOTORS_CM	SERIES 51	S51-080MV
S51D110_MOTORS_CM	MOTOR-VAR-DISPL 51MD110	Y-S51D110_MOTORS_CM-Y	SERIES 51	S51-110MV
S51D160_MOTORS_CM	MOTOR-VAR-DISPL 51MD160	Y-S51D160_MOTORS_CM-Y	SERIES 51	S51-160MV
S51V060_MOTORS_CM	MOTOR-VAR-DISPL 51MV060	Y-S51V060_MOTORS_CM-Y-S51V060_MOTORS_CM	SERIES 51	S51-060MV
S51V080_MOTORS_CM	MOTOR-VAR-DISPL 51MV080	Y-S51V080_MOTORS_CM	SERIES 51	S51-080MV
S51V110_MOTORS_CM	MOTOR-VAR-DISPL 51MV110	Y-S51V110_MOTORS_CM-Y	SERIES 51	S51-110MV
S51V160_MOTORS_CM	MOTOR-VAR-DISPL 51MV160	Y-S51V160_MOTORS_CM-Y	SERIES 51	S51-160MV
S51V250_MOTORS_CM	MOTOR-VAR-DISPL 51MV250	Y-S51V250_MOTORS_CM-Y	SERIES 51	S51-250MV
S51_1_C060_MOT_CM	MOTOR-VAR-DISPL 51MC060-1	Y-S51_1_C060_MOT_CM	SERIES 51	S51-060MV-1
S51_1_C080_MOT_CM	MOTOR-VAR-DISPL 51MC080-1	Y-S51_1_C080_MOT_CM	SERIES 51	S51-080MV-1
S51_1_C110_MOT_CM	MOTOR-VAR-DISPL 51MC110-1	Y-S51_1_C110_MOT_CM	SERIES 51	S51-110MV-1
S51_1_D060_MOT_CM	MOTOR-VAR-DISPL 51MD060-1	Y-S51_1_D060_MOT_CM	SERIES 51	S51-060MV-1
S51_1_D080_MOT_CM	MOTOR-VAR-DISPL 51MD080-1	Y-S51_1_D080_MOT_CM	SERIES 51	S51-080MV-1
S51_1_D110_MOT_CM	MOTOR-VAR-DISPL 51MD110-1	Y-S51_1_D110_MOT_CM	SERIES 51	S51-110MV-1
S51_1_V060_MOT_CM	MOTOR-VAR-DISPL 51MV060-1	Y-S51_1_V060_MOT_CM	SERIES 51	S51-060MV-1
S51_1_V080_MOT_CM	MOTOR-VAR-DISPL 51MV080-1	Y-S51_1_V080_MOT_CM	SERIES 51	S51-080MV-1
S51_1_V110_MOT_CM	MOTOR-VAR-DISPL 51MV110-1	Y-S51_1_V110_MOT_CM	SERIES 51	S51-110MV-1
S90L042_PUMPS_CM	PUMP-VAR-DISPL CCW 90PV042	S90L042_PUMPS_CM	SERIES 90	S90-042PV
S90L075_PUMPS_CM	PUMP-VAR-DISPL CCW 90PV075	S90L075_PUMPS_CM	SERIES 90	S90-075PV
S90L100_PUMPS_CM	PUMP-VAR-DISPL CCW 90PV100	S90L100_PUMPS_CM	SERIES 90	S90-100PV
S90L130_PUMPS_CM	PUMP-VAR-DISPL CCW 90PV130	S90L130_PUMPS_CM	SERIES 90	S90-130PV
S90L180_PUMPS_CM	PUMP-VAR-DISPL CCW 90PV180	S90L180_PUMPS_CM	SERIES 90	S90-180PV
S90L250_PUMPS_CM	PUMP-VAR-DISPL CCW 90PV250	S90L250_PUMPS_CM	SERIES 90	S90-250PV
S90MF055_SHC_CM	MOTOR-FIX DISPL 90MF055	90-M-055-S90MF055_SHC_CM-N-N-Y	SERIES 90	S90-055MF
S90MF075_SHC_CM	MOTOR-FIX DISPL 90MF075	90-M-075-S90MF075_SHC_CM-N-N-Y	SERIES 90	S90-075MF
S90MF100_NMS_CM	MOTOR-FIX DISPL 90MF100	90-M-100-S90MF100_NMS_CM-Y-N-N	SERIES 90	S90-100MF
S90MF130_NMS_CM	MOTOR-FIX DISPL 90MF130	90-M-130-S90MF130_NMS_CM-Y-N-N	SERIES 90	S90-130MF
S90PV055L_CM	PUMP-VAR DISPL, CCW 90PV055	90-L-055-S90PV055L_CM	SERIES 90	S90-055PV
S90PV055R_CM	PUMP-VAR DISPL, CW 90PV055	90-R-055-S90PV055R_CM	SERIES 90	S90-055PV
S90PV075L_CM	PUMP-VAR DISPL, CCW 90PV075	90-L-075-S90PV075L_CM	SERIES 90	S90-075PV
S90PV075R_CM	PUMP-VAR DISPL, CW 90PV075	90-R-075-S90PV075R_CM	SERIES 90	S90-075PV
S90PV100L_CM	PUMP-VAR DISPL, CCW 90PV100	90-L-100-S90PV100L_CM	SERIES 90	S90-100PV
S90PV100R_CM	PUMP-VAR DISPL, CW 90PV100	90-R-100-S90PV100R_CM	SERIES 90	S90-100PV
S90R042_PUMPS_CM	PUMP-VAR-DISPL CW 90PV042	S90R042_PUMPS_CM	SERIES 90	S90-042PV
S90R075_PUMPS_CM	PUMP-VAR-DISPL CW 90PV075	S90R075_PUMPS_CM	SERIES 90	S90-075PV
S90R100_PUMPS_CM	PUMP-VAR-DISPL CW 90PV100	S90R100_PUMPS_CM	SERIES 90	S90-100PV

S90R130_PUMPS_CM	PUMP-VAR-DISPL CW 90PV130	S90R130_PUMPS_CM	SERIES 90	S90-130PV
S90R180_PUMPS_CM	PUMP-VAR-DISPL CW 90PV180	S90R180_PUMPS_CM	SERIES 90	S90-180PV
S90R250_PUMPS_CM	PUMP-VAR-DISPL CW 90PV250	S90R250_PUMPS_CM	SERIES 90	S90-250PV
SP-1011053	PC VALVE SET		LIGHT DUTY	PARTS - Low Power
SP1775-R07	G-1257 GEAR PUMP		SERIES 20	PARTS - S20 - Unique
SZ02323	PUMP-VAR-DISPL CW 20PV089	GR089EH6P/20DCC13C00	SERIES 20	S20-GR089 (NO NAME)