


## VC1 and SD700 pulse routines

### 一、The wiring diagram



### SD700 parameter Settings:

pn204=0, pn206=10000, pn001=1 (Internal enabled)。

### VC1 program explanation:

Send 50000 pulses at 10000Hz, make the servo motor turn 5 times, To reverse, close M1