


HV2.015 – HV4.040



HV4.055 – HV4.110

# Hydrovar

Spare Parts / Accessories HV2.015 – HV4.110

**ASSEMBLING INSTRUCTION MANUAL**

## INDEX


HV 2.015-4.110 .....	3
1. Open unit.....	3
2. Exchange display (part# 709910500).....	3
3. Exchange relay card (part# 709910400).....	5
4. Exchange control card (part# 709910200).....	7
5. Installation of B-filter - HV4.055-4.110 - Hardware Size II (part# 7099910310).....	11
5.1. Master Inverter.....	11
5.2. Basic Inverter .....	14
6. Close unit.....	15



# HV 2.015-4.110

## 1. Open Unit









## 2. Exchange display (part# 709910500)














**3. Exchange relay card (part# 709910400)**













4. Exchange control card (part# 709910200)



















### 5. Installation of B-filter - HV4.055-4.110 - Hardware Size II (part# 7099910310)



#### 5.1. Master Inverter





Hydrovar Assembling Instructions


2x M3x6 (included in kit)



5.2. Basic Inverter



2x M3x6 (included in kit)



**6. Close Unit**



## LIMITED WARRANTY

This warranty applies to this Xylem Inc. product.

Any part or parts found to be defective within the warranty period shall be replaced at no charge to the dealer during the warranty period. The warranty period shall exist for a period of twenty-four (24) months from date of installation or thirty (30) months from date of manufacture, whichever period is shorter.

A dealer who believes that a warranty claim exists must contact the authorized Xylem Inc. distributor from whom the equipment was purchased and furnish complete details regarding the claim. The distributor is authorized to adjust any warranty claims utilizing the Xylem Inc. Customer Service Department.

**The warranty excludes:**

- (a) Labor, transportation and related costs incurred by the dealer;
- (b) Reinstallation costs of repaired equipment;
- (c) Reinstallation costs of replacement equipment;
- (d) Consequential damages of any kind; and,
- (e) Reimbursement for loss caused by interruption of service.

**For purposes of this warranty, the following terms have these definitions:**

- (1) "Distributor" means any individual, partnership, corporation, association, or other legal relationship that stands between Xylem Inc. and the dealer in purchases, consignments or contracts for sale of the subject equipment.
- (2) "Dealer" means any individual, partnership, corporation, association, or other legal relationship which engages in the business of selling or leasing equipment to customers.
- (3) "Customer" means any entity who buys or leases the subject equipment from a dealer. The "customer" may mean an individual, partnership, corporation, limited liability company, association or other legal entity which may engage in any type of business.

**THIS WARRANTY EXTENDS TO THE DEALER ONLY.**



Xylem Inc.  
2881 East Bayard Street Ext., Suite A  
Seneca Falls, NY 13148  
Phone: (800) 453-6777  
Fax: (888) 322-5877