

# Operating Instructions

## Rxn-45 Raman spectroscopic probe





## Table of Contents

<b>1 About this document.....</b>	<b>4</b>		
1.1 Warnings.....	4		
1.2 Symbols on the device.....	4		
1.3 U.S. export compliance .....	4		
1.4 Glossary .....	5		
<b>2 Basic safety instruction .....</b>	<b>6</b>		
2.1 Requirements for personnel .....	6		
2.2 Designated use .....	6		
2.3 Workplace safety.....	6		
2.4 Operational safety.....	6		
2.5 Laser safety .....	7		
2.6 Service safety .....	7		
2.7 Important safeguards .....	7		
2.8 Product safety.....	8		
<b>3 Product description .....</b>	<b>9</b>		
3.1 Rxn-45 probe .....	9		
3.2 Benefits of the probe design .....	9		
3.3 Short data collection zone .....	9		
<b>4 Incoming product acceptance and product identification .....</b>	<b>10</b>		
4.1 Incoming acceptance.....	10		
4.2 Product identification .....	10		
		4.3 Scope of delivery .....	10
		<b>5 Probe and fiber optic connection .....</b>	<b>11</b>
		<b>6 Installation .....</b>	<b>12</b>
		6.1 Installation process.....	12
		<b>7 Commissioning.....</b>	<b>14</b>
		7.1 Receipt of probe .....	14
		7.2 Probe calibration and verification .....	14
		<b>8 Operation .....</b>	<b>15</b>
		<b>9 Diagnostics and troubleshooting.....</b>	<b>16</b>
		<b>10 Maintenance.....</b>	<b>17</b>
		10.1 Cleaning the Rxn-45 probe <i>in situ</i> .....	17
		10.2 Cleaning the probe window .....	17
		10.3 Inspecting and cleaning the optical fibers .....	18
		<b>11 Repair .....</b>	<b>19</b>
		<b>12 Technical data .....</b>	<b>20</b>
		12.1 General specifications .....	20
		12.2 Maximum permissible exposure .....	21
		<b>13 Supplementary documentation .....</b>	<b>22</b>
		<b>14 Index.....</b>	<b>23</b>

# 1 About this document

## 1.1 Warnings




Structure of Information	Meaning
 <b>WARNING</b> <b>Causes (/consequences)</b> If necessary, consequences of non-compliance (if applicable) ▶ Corrective action	This symbol alerts you to a dangerous situation. Failure to avoid the dangerous situation can result in a fatal or serious injury.
 <b>CAUTION</b> <b>Causes (/consequences)</b> If necessary, consequences of non-compliance (if applicable) ▶ Corrective action	This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in minor or more serious injuries.
 <b>NOTICE</b> <b>Cause/situation</b> If necessary, consequences of non-compliance (if applicable) ▶ Action/note	This symbol alerts you to situations which may result in damage to property.

Table 1. Warnings

## 1.2 Symbols on the device





Symbol	Description
	The Laser Radiation symbol is used to alert the user to the danger of exposure to hazardous visible laser radiation when using the system.
	The High Voltage symbol that alerts people to the presence of electric potential large enough to cause injury or damage. In certain industries, high voltage refers to voltage above a certain threshold. Equipment and conductors that carry high voltage warrant special safety requirements and procedures.
	The WEEE symbol indicates that the product should not be discarded as unsorted waste but must be sent to separate collection facilities for recovery and recycling.
	The CE Marking indicates conformity with health, safety, and environmental protection standards for products sold within the European Economic Area (EEA).

Table 2. Symbols

## 1.3 U.S. export compliance

The policy of Endress+Hauser is strict compliance with U.S. export control laws as detailed in the website of the [Bureau of Industry and Security](#) at the U.S. Department of Commerce.

## 1.4 Glossary

Term	Description
ANSI	<a href="#">American National Standards Institute</a>
°C	Celsius
CDRH	<a href="#">Center for Devices and Radiological Health</a>
CIP	clean-in-place
CFR	<a href="#">Code of Federal Regulations</a>
cGMP	current good manufacturing practices
cm	centimeter
CSA	<a href="#">Canadian Standards Association</a>
EO	electro-optical
°F	Fahrenheit
ft.	feet
FWHM	full width at half maximum
HCA	Raman Calibration Accessory
IEC	<a href="#">International Electrotechnical Commission</a>
in.	inches
kg	kilogram
m	meter
μin	microinches
μm	micrometer
mm	millimeter
MPE	maximum permissible exposure
mW	milliwatt
nm	nanometer
psi	pounds per square inch
SIP	steam-in-place
WEEE	<a href="#">Waste Electrical and Electronic Equipment</a>

Table 3. Glossary

## 2 Basic safety instruction

### 2.1 Requirements for personnel

- Installation, commissioning, operation, and maintenance of the measuring system may be carried out only by specially trained technical personnel.
- The technical personnel must be authorized by the plant operator to carry out the specified activities.
- The technical personnel must have read and understood these Operating Instructions and must follow the instructions contained herein.
- The facility must designate a laser safety officer who ensures staff are trained on all Class 3B laser operating and safety procedures.
- Faults at the measuring point may only be rectified by properly authorized and trained personnel. Repairs not described in this document must be carried out only directly at the manufacturer's site or by the service organization.

### 2.2 Designated use

The Rxn-45 Raman spectroscopic probe is designed for the needs of bioprocessing pilot and manufacturing sites.

Recommended applications include:

- **Cell culture:** glucose, lactate, amino acids, cell density, titer, and more
- **Fermentation:** glucose, glycerol, acetate, methanol, ethanol, biomass, and more

Use of the device for any purpose other than that described, poses a threat to the safety of people and of the entire measuring system and invalidates any warranty.

### 2.3 Workplace safety

As the user, you are responsible for complying with the following safety conditions:

- Installation guidelines
- Local standards and regulations for electromagnetic compatibility

The product has been tested for electromagnetic compatibility in accordance with the applicable international standards for industrial applications.

The electromagnetic compatibility indicated applies only to a product that has been properly connected to the analyzer.

### 2.4 Operational safety

Before commissioning the entire measuring point:

1. Verify that all connections are correct.
2. Ensure that electro-optical cables are undamaged.
3. Ensure fluid level is sufficient for probe/optics immersion (if applicable).
4. Do not operate damaged products, and protect them against unintentional operation.
5. Label damaged products as defective.

During operation:

1. If faults cannot be rectified, products must be taken out of service and protected against unintentional operation.
2. When working with laser devices, always follow all local laser safety protocols which may include the use of personal protective equipment and limiting device access to authorized users.

## 2.5 Laser safety

The Raman Rxn analyzers use Class 3B lasers as defined in the following:

- [American National Standards Institute](#) (ANSI) Z136.1, American National Standard for Safe Use of Lasers
- [International Electrotechnical Commission](#) (IEC) 60825-1, Safety of Laser Products – Part 1

### **⚠ WARNING**

#### **Laser radiation**


- ▶ Avoid exposure to beam
- ▶ Class 3B laser product

### **⚠ CAUTION**

**Laser beams can cause ignition of certain substances such as volatile organic compounds.**


The two possible mechanisms for ignition are direct heating of the sample to a point causing ignition and the heating of a contaminant (such as dusts) to a critical point leading to ignition of the sample.

The laser configuration presents further safety concerns because the radiation is nearly invisible. Always be aware of the initial direction and possible scattering paths of the laser. The use of laser safety glasses with OD3 or greater is highly recommended for 532 nm and 785 nm excitation wavelengths and OD4 or greater for a 993 nm excitation wavelength.



A0048421

Figure 1. Laser safety glasses

For more assistance with taking appropriate precautions and setting the proper controls when dealing with lasers and their hazards, refer to the most current version of ANSI Z136.1 or IEC 60825-14. See Section 12 →  of this document for relevant parameters to enable calculation of maximum permissible exposure (MPE).

## 2.6 Service safety

Follow your company's safety instructions when removing a process probe from the process interface for service. Always wear proper protective equipment when servicing the equipment.

## 2.7 Important safeguards

- Do not use the Rxn-45 probe for anything other than its intended use.
- Do not look directly into the laser beam.
- Do not point the laser at a mirrored/shiny surface or a surface that may cause diffuse reflections. The reflected beam is as harmful as the direct beam.
- Do not leave attached and unused probes uncapped or unblocked.
- Always use a laser beam block to avoid inadvertent scatter of laser radiation.

## 2.8 Product safety

This product is designed to meet all current safety requirements, has been tested, and shipped from the factory in a safe operating condition. The relevant regulations and international standards have been observed. Devices connected to an analyzer must also comply with the applicable analyzer safety standards.

Endress+Hauser Raman spectroscopy systems incorporate the following safety features to conform to the United States Government requirements 21 [Code of Federal Regulations](#) (CFR) Chapter 1, Subchapter J as administered by the [Center for Devices and Radiological Health](#) (CDRH) and IEC-60825-1 as administered by the [International Electrotechnical Commission](#).

### 2.8.1 CDRH and IEC compliance

Endress+Hauser Raman analyzers are certified by Endress+Hauser to meet CDRH requirements, as well as IEC 60825-1 safety standards for international use.

Endress+Hauser Raman analyzers have been registered with the CDRH. Any unauthorized modifications to an existing Raman Rxn analyzer or accessory may result in hazardous radiation exposure. Such modifications may result in the system being no longer in conformance with Federal requirements as certified by Endress+Hauser.

### 2.8.2 Laser safety interlock

The Rxn-45 probe, as installed, forms part of the interlock circuit. The interlock circuit is a low-current electrical loop. If the fiber cable is severed, the laser will turn off within milliseconds of the breakage.

#### NOTICE

#### Handle probes and cables with care.

Fiber cables should NOT be kinked and should be routed to maintain the minimum bend radius of 152.4 mm (6 in.).

- ▶ Permanent damage may result if cables are not routed appropriately.

The electro-optical (EO) fiber cable with its embedded interlock loop must be plugged into the back of the Raman Rxn analyzer for the appropriate channel. The interlock loop is complete when the probe side of the EO fiber cable is plugged into the Rxn-45 probe.

When there is potential for the laser to be energized, the laser interlock indicator light on the probe body is illuminated.




Figure 2. Location of laser interlock indicator light

A0049112



## 3 Product description

### 3.1 Rxn-45 probe

The Rxn-45 Raman spectroscopic probe, powered by Kaiser Raman technology, is a clean-in-place (CIP)/steam-in-place (SIP) compatible probe designed for *in situ* monitoring and control of bioprocess applications in development and manufacturing settings. This probe is ideally suited for side-port entry into a bioreactor or fermentor, and is compatible with Endress+Hauser Raman Rxn analyzers operating at 785 nm and 993 nm.

The Rxn-45 probe has a 120 mm (4.73 in.) immersion length with a 12 mm (0.48 in.) outer diameter and a surface finish of Ra 0.38  $\mu\text{m}$  (Ra 15  $\mu\text{in}$ ) or better. The PG13.5 connector allows for installation with multiple port types, using industry standard sensor housings for 25 mm (0.98 in.) side ports. Welded port connectors and flanges are also available in multiple brands and sizes.




Figure 3. Rxn-45 probe

### 3.2 Benefits of the probe design

The Rxn-45 probe offers the following benefits:

- Measures multiple components in real-time for automated 24/7 process feedback
- Provides long-term measurement stability
- Offers a suitable surface finish for cGMP manufacturing
- Provides compatibility with industry standard bioreactor side ports and sensor housings
- Offers the flexibility of being installed in development and production reactors
- Compatible with CIP/SIP standards for reduced sterilization and cleaning burdens

### 3.3 Short data collection zone

All versions of the Rxn-45 probe utilize short data collection zones. The short data collection zone maximizes spectral reproducibility by minimizing the impact of sample opacity, sample color, and transient particulates on the measured Raman spectrum.

## 4 Incoming product acceptance and product identification

### 4.1 Incoming acceptance

1. Verify that the packaging is undamaged. Notify the supplier of any damage to the packaging. Keep the damaged packaging until the issue has been resolved.
2. Verify that the contents are undamaged. Notify the supplier of any damage to the delivery contents. Keep the damaged goods until the issue has been resolved.
3. Check that the delivery is complete and nothing is missing. Compare the shipping documents with your order.
4. Pack the product for storage and transportation in such a way that it is protected against impact and moisture. The original packaging offers the best protection. Make sure to comply with the permitted ambient conditions.

If you have any questions, please contact your supplier or your local sales center.

#### NOTICE

**Probe may be damaged during transport if packaged inadequately.**

### 4.2 Product identification

#### 4.2.1 Label

At a minimum, the probe/tag is labeled with the following information:

- Endress+Hauser branding
- Serial number

Where size allows, the following information is also included:

- Product identification (e.g., Rxn-45)
- Extended order code
- Manufacturer information
- Key functional aspects of the probe (e.g., material, wavelength, focal depth)
- Safety warnings and certification information, as applicable

Compare the information on the label/tag with the order.

#### 4.2.2 Manufacturer address

Endress+Hauser  
371 Parkland Plaza  
Ann Arbor, MI 48103 USA

### 4.3 Scope of delivery

The scope of delivery comprises:

- Rxn-45 probe
- *Rxn-45 Raman spectroscopic probe Operating Instructions* manual
- Certificate of Product Performance
- Local declarations of conformity, if applicable
- Rxn-45 probe optional accessories, if applicable
- Material certificates, if applicable

If you have any queries: Please contact your supplier or local sales center.

## 5 Probe and fiber optic connection

The Rxn-45 probe is compatible with Endress+Hauser Raman Rxn analyzers operating at 785 nm and 993 nm. The probe connects to the Raman Rxn analyzer via a user-removable electro-optical (EO) fiber cable. The EO fiber cable connects the Rxn-45 probe to the analyzer with a single, robust connector that contains the excitation and collection fiber optics as well as an electrical laser interlock. The fiber cable is sold separately.


Refer to the applicable Raman Rxn analyzer operating instructions for analyzer connection details.

### NOTICE

**Connection of the probe to the fiber optic cable must be conducted by a qualified Endress+Hauser engineer or specially trained technical personnel.**

- ▶ Unless trained by qualified personnel, customer attempts to connect the probe to the fiber optic cable can result in damage and may void the warranty.
- ▶ Contact your local Endress+Hauser service representative for additional support regarding the probe and fiber cable connection.

Fiber cable is available in 5 m (16.4 ft.) increments up to 200 m (656.2 ft.), with the length limited by the application.



A0048938

Figure 4. EO fiber cable showing connector for analyzer

## 6 Installation

During installation, standard eye and skin safety precautions for Class 3B laser products (as per EN 60825/IEC 60825-14) should be observed. Additionally, observe the following:

<b>⚠ WARNING</b>	<b>Standard precautions for laser products should be observed.</b> ▶ Probes should always be capped or pointed away from people toward a diffuse target if not installed in a sample chamber.
<b>⚠ CAUTION</b>	<b>If stray light is allowed to enter an unused probe, it will interfere with data collected from a used probe and may cause calibration failure or measurement errors.</b> ▶ Unused probes should ALWAYS be capped to prevent stray light from entering the probe.
<b>NOTICE</b>	<b>When installing the probe <i>in situ</i>, the user must provide the strain relief to the fiber optic cable at the probe installation location.</b>

### 6.1 Installation process


#### NOTICE

**When installing the probe *in situ*, the user must provide the strain relief to the fiber optic cable at the probe installation location.**

To install an Rxn-45 probe, follow the steps below. Refer to the figure below to disconnect and re-connect the fiber optic cable from the probe.

1. If the Rxn-45 probe is currently attached to a Raman Rxn analyzer, use the laser key on the front of the base unit to turn the laser OFF or power down the analyzer prior to probe installation.
2. Disconnect the fiber optic cable from the Rxn-45 probe.
  - Unlatch the connector clip. **(A)**
  - Grasp the gray part of the EO connector and, with your other hand, pull straight down to disconnect the fiber optic cable. **(B)**
3. Screw the appropriate adapter onto the Rxn-45 probe and secure in place using the PG13.5 thread process connector.
4. Insert the Rxn-45 probe into a side-port on the vessel.
5. Screw the adapter that is now attached to the Rxn-45 probe into a side-port on the vessel such that the fiber connector interface remains facing downward.
6. Re-connect the fiber optic cable to the Rxn-45 probe.
  - Open the spring-loaded fiber connector cap at the base of the Rxn-45 probe. **(C)**
  - Insert the fiber cable EO connector into the base of the probe and push up until secure.
  - Re-latch the connector clip.
7. When ready to use the analyzer and probe, power ON the laser or analyzer.
8. After a minute, verify that the laser interlock indicator on the probe is illuminated.

The Rxn-45 probe is now ready for CIP/SIP using standard bio-process water or steam cleaning processes prior to vessel filling.




A0049114

Figure 5. Disconnecting and re-connecting the fiber optic cable

## 7 Commissioning

The Rxn-45 probe is delivered ready to connect to the Raman Rxn analyzer. No additional alignment or adjustment to the probe is required. Follow the instructions below to commission the probe for use.

### 7.1 Receipt of probe

Perform the steps for incoming product acceptance described in Section 4.1 → .

### 7.2 Probe calibration and verification

The probe and the analyzer must be calibrated before use. Use the Raman Calibration Accessory (HCA) to perform an intensity calibration for the probe.

Refer to the applicable Raman Rxn analyzer operating instructions for steps to:

- Perform internal analyzer calibration; may include alignment calibration, full wavelength calibration, or full laser wavelength calibration depending on status of analyzer
- Perform probe calibration; requires HCA
- Perform probe verification; verifies the calibration results using a standard reference sample
- View calibration and verification reports

The Raman RunTime software will not allow spectra to be collected without passing internal analyzer and probe calibrations. Passing the probe verification step is not required but highly recommended.

Raman Rxn analyzer operating instructions are available by searching the Downloads area of the Endress+Hauser web site: <https://endress.com/downloads>

## 8 Operation

The Endress+Hauser Rxn-45 probe is a compact probe designed for the needs of bioprocessing pilot and manufacturing sites. The probe is compatible with Endress+Hauser Raman Rxn analyzers operating at 785 nm and 993 nm.

**⚠ CAUTION**

**Do NOT use the Rxn-45 probe with hydrocarbon solvents, including ketones and aromatics.**

These solvents can damage the window material, degrade probe performance, and invalidate the warranty.

Refer to the applicable Raman Rxn analyzer operating instructions for additional instructions for use.

## 9 Diagnostics and troubleshooting

Refer to the table below when troubleshooting issues with the Rxn-45 probe. If the probe is damaged, isolate the probe from the process and turn off the laser prior to evaluation. Contact your service representative as needed for assistance.


Symptom	Possible cause	Action	
1	Substantial reduction in signal or signal-to-noise ratio	Window fouling	1. Carefully remove probe from the process, decontaminate, and inspect optical window at tip of probe. 2. If necessary, clean the window before returning it to service. Refer to Section 10.2 →  .
	Cracked but intact fiber	Verify condition of fiber and contact your service representative for replacement.	
2	Complete loss of signal while laser is powered and laser interlock indicator is lit	Broken fiber without interlock wire breakage	Ensure all fiber connections are secure. Verify condition of fiber and contact your service representative for replacement.
3	Laser interlock indicator on probe is not lit	Damaged fiber assembly	Look for signs of breakage in fiber. Contact your service representative for replacement.
		Fiber cable EO connector not secured/latched	Ensure EO connector is properly connected and latched at the probe (if applicable) and at the analyzer.
		Remote interlock connector disconnected	Ensure the twist-lock remote interlock connector at the rear of analyzer (next to fiber EO connector) is connected.
4	Unstable signal and contamination visible behind window	Window seal failure	1. Examine the area inside the window for moisture or condensation. 2. Examine the probe for fluid penetration or signs of sample fluid in the probe body (e.g., corrosion, residue). 3. Look for any sign of spectral deviation. 4. If any of the above are noted, contact your service representative to return the probe to the manufacturer.
5	Decreased laser power or collection efficiency	Contaminated fiber connection	Carefully clean the fiber ends at the probe. Refer to the applicable Raman Rxn analyzer operating instructions for cleaning instructions and steps for starting up a new probe.
6	Laser interlock on analyzer causes laser to shut down	Laser interlock activated	Check for fiber breakage on all connected fiber optic cable channels and ensure remote interlock connectors are in place on each channel.
7	Unrecognized bands or patterns in the spectra	Cracked but intact fiber	Verify possible causes and contact your service representative to return the damaged product.
		Contaminated probe tip	
8	Other unexplained negative performance of the probe	Physical damage to probe	Contact your service representative to return the damaged product.

Table 4. Troubleshooting



## 10 Maintenance

### 10.1 Cleaning the Rxn-45 probe *in situ*

There are two aspects to cleaning an installed Rxn-45 probe:

- Cleaning the wetted parts
- Cleaning the non-wetted parts

#### 10.1.1 Cleaning the wetted probe parts

No special precautions are required to clean the wetted parts of the Rxn-45 probe. The probe may be cleaned in place using bio-processing industry standard SIP and CIP processes.

The Rxn-45 probe is rated for 50 SIP/CIP cycles. After that, the probe must be returned for service. Contact your local Endress+Hauser service provider for additional information

#### 10.1.2 Cleaning the non-wetted probe parts

To clean the non-wetted parts of the Rxn-45 probe (the components exterior to the bioreactor or fermentor), follow the steps below.

1. Blow off the surface with clean compressed air to remove any loose particles.
2. Wipe the surface using a **lightly** dampened wipe or cloth.
3. Wipe the surface dry with a dry wipe or cloth.
4. Blow with clean compressed air to remove any wipe or cloth remnants.
5. Repeat the previous steps as necessary.

For service other than surface cleaning, return the Rxn-45 probe to the manufacturer or service organization.

### 10.2 Cleaning the probe window

This process is performed when the Rxn-45 probe is removed from the vessel. Note the following:

- The probe should be cleaned after immersion in phosphate buffer solutions to avoid particle deposit contamination.
- Extra care must be taken to ensure that the window surface is not further contaminated during the cleaning process.
- If the window is damaged, discontinue probe use and contact your local Endress+Hauser service provider for additional information.

To clean the probe window:

1. Ensure that the laser is turned **OFF** or the probe is disconnected from the analyzer.
2. Blow off the surface with clean compressed air to remove any loose particles.
3. Wipe the surface using a swab **lightly** dampened with a solvent appropriate for the substance to be cleaned.
  - Do not clean the Rxn-45 probe window with hydrocarbon solvents (including ketones and aromatics) as these can damage the window material, degrade probe performance and invalidate the warranty.
  - Do not allow the solvent to drip behind the retaining components.
4. Wipe the surface dry with a dry swab.
5. Repeat the cleaning with an additional solvent, if needed, and wipe the surface dry with a dry swab.
6. Blow with clean compressed air to remove any swab remnants.
7. Inspect the surface to verify the effectiveness of the cleaning.

Verification with an inspection microscope in the cleaning process is highly recommended to look for smeared contaminants, swab remnants, etc., that may cause increased spectrum background.

8. Repeat the previous steps as necessary.

### **10.3 Inspecting and cleaning the optical fibers**

The optical fiber connectors in the cable must be clean and free of debris and oil to achieve optimal performance. If cleaning is required, refer to the applicable Raman Rxn analyzer operating instructions or fiber optic cables operating instructions.

## 11 Repair

Repairs not described in this document must be carried out only directly at the manufacturer's site or by the service organization. For Technical Service, refer to our website (<https://endress.com/contact>) for the list of local sales channels in your area.

If a product must be returned for repair or replacement, follow all decontamination procedures indicated by your service provider.

**⚠ WARNING**

**Failure to properly decontaminate wetted parts before return can result in a fatal or serious injury.**

To ensure swift, safe and professional product returns, please contact your service organization.

For additional product return information, refer to the following site and select the applicable market/region:  
<https://www.endress.com/en/instrumentation-services/instrumentation-repair>

## 12 Technical data

### 12.1 General specifications

Note: Max service pressure ratings do not include the ratings of any fittings or flanges used to mount the probe into the process system. These items need to be independently evaluated and may lower the maximum service pressure of the probe.

Item	Description	
Laser wavelength	785 nm or 993 nm	
Spectral coverage	probe spectral coverage is limited by the coverage of the analyzer being used	
Maximum laser power into probe	< 499 mW	
Relative humidity	Up to 95 %, non-condensing	
Maximum service pressure (at tip)	13.8 barg (200 psig)	
Process connection	PG13.5 thread for industry standard sensor housings; welded port connectors available	
Rating	IP-65	
Depth of field	0.33 mm (0.013 in.) FWHM	
Chemical resistance	limited by materials of construction	
Sterilization protocol compatibility	SIP/CIP	
Probe temperature	window, at tip	-30 to 150 °C (-22 to 302 °F)
	probe body	up to 150 °C (302 °F)
	temperature ramp	≤ 30 °C/min (≤ 54 °F/min)
Probe measurements	immersion length	120 mm (4.73 in.)
	diameter	12 mm (0.48 in.)
	dimensions (with EO connector cap open)	306 x 127 x 34 mm (12.05 x 5.0 x 1.34 in.)
Materials of construction (wetted, in contact with sample)	probe body	316L stainless steel
	window	proprietary material, optimized for bioprocesses
	adhesive	USP Class VI and ISO993 compatible
	surface finish	Ra 0.38 µm (Ra 15 µin) with electropolish
	fiber optic cable	design: PVC jacketed, proprietary construction connections: proprietary electro-optic (EO) or FC to EO fiber converter(s) for non-embedded systems
Fiber optic cable (cable sold separately)	length	EO cable available in 5 m (16.4 ft.) increments up to 200 m (656.2 ft.), with the length limited by the application
	minimum bend radius	152.4 mm (6 in.)
	temperature	-40 to 70 °C (-40 to 158 °F)
	flame resistance	certified: CSA-C/US AWM I/II, A/B, 80C, 30V, FT1, FT2, VW-1, FT4 rated: AWM I/II A/B 80C 30V FT4

Table 5. General specifications

## 12.2 Maximum permissible exposure

The maximum permissible exposure (MPE) is the maximum level of laser radiation exposure that can occur before causing ocular or skin damage. The MPE is calculated using the laser wavelength ( $\lambda$ ) in nanometers, the duration of the exposure in seconds ( $t$ ), and the energy involved ( $\text{J}\cdot\text{cm}^{-2}$  or  $\text{W}\cdot\text{cm}^{-2}$ ).

A correction factor ( $C_A$ ) may also be required and can be determined below.

Wavelength $\lambda$ (nm)	Correction Factor $C_A$
400 to 700	1
700 to 1050	$10^{0.002(\lambda-700)}$
1050 to 1400	5

Table 6. Wavelength dependent correction factor  $C_A$

### 12.2.1 MPE for ocular exposure

The ANSI Z136.1 standard provides means to perform MPE for ocular exposure. Please refer to the standard to calculate the relevant MPE levels for the case of laser exposure from the Rxn-45 probe and from the unlikely occurrence of laser exposure from a broken optical fiber.

MPE for point source ocular exposure to a laser beam				
Wavelength $\lambda$ (nm)	Exposure duration $t$ (s)	MPE calculation		MPE where $C_A = 1.4791$
		( $\text{J}\cdot\text{cm}^{-2}$ )	( $\text{W}\cdot\text{cm}^{-2}$ )	
785 and 993	$10^{-13}$ to $10^{-11}$	$1.5 C_A \times 10^{-8}$	-	$2.2 \times 10^{-8}$ ( $\text{J}\cdot\text{cm}^{-2}$ )
	$10^{-11}$ to $10^{-9}$	$2.7 C_A t^{0.75}$	-	Insert time ( $t$ ) and calculate
	$10^{-9}$ to $18 \times 10^{-6}$	$5.0 C_A \times 10^{-7}$	-	$7.40 \times 10^{-7}$ ( $\text{J}\cdot\text{cm}^{-2}$ )
	$18 \times 10^{-6}$ to 10	$1.8 C_A t^{0.75} \times 10^{-3}$	-	Insert time ( $t$ ) and calculate
	10 to $3 \times 10^4$	-	$C_A \times 10^{-3}$	$1.4971 \times 10^{-3}$ ( $\text{W}\cdot\text{cm}^{-2}$ )

Table 7. MPE for ocular exposure with 785 nm or 993 nm laser emission

### 12.2.2 MPE for skin exposure

The ANSI Z136.1 standard provides means to perform MPE for skin exposure. Please refer to the standard to calculate the relevant MPE levels for the case of laser exposure from the Rxn-45 probe and from the unlikely occurrence of laser exposure from a broken optical fiber.

MPE for skin exposure to a laser beam				
Wavelength $\lambda$ (nm)	Exposure duration $t$ (s)	MPE calculation		MPE where $C_A = 1.4791$
		( $\text{J}\cdot\text{cm}^{-2}$ )	( $\text{W}\cdot\text{cm}^{-2}$ )	
785 and 993	$10^{-9}$ to $10^{-7}$	$2 C_A \times 10^{-2}$	-	$2.9582 \times 10^{-2}$ ( $\text{J}\cdot\text{cm}^{-2}$ )
	$10^{-7}$ to 10	$1.1 C_A t^{0.25}$	-	Insert time ( $t$ ) and calculate
	10 to $3 \times 10^4$	-	$0.2 C_A$	$2.9582 \times 10^{-1}$ ( $\text{W}\cdot\text{cm}^{-2}$ )

Table 8. MPE for skin exposure with 785 nm or 993 nm laser emission

## 13 Supplementary documentation

All documentation is available:

- On the Endress+Hauser Operations App for smartphone/tablet
- In the Downloads area of the Endress+Hauser website: <https://endress.com/downloads>

Part number	Document Type	Document Title
KA01549C	Brief Operating Instructions	Rxn-45 Raman spectroscopic probe Brief Operating Instructions
TI01633C	Technical Information	Rxn-45 Raman spectroscopic probe Technical Information

Table 9. Supplementary documentation

## 14 Index

- accessories, 10, 14
- adapters, 12
- CDRH compliance, 5, 8
- certification, 8
  - compliance, 5, 8
  - CSA, 5
  - IECEX, 5, 7, 8, 12
- data collection zone, 9
- electrical connection, 6
- export compliance, 4
- fiber cable
  - cleaning, 18
  - EO, 8, 11
  - length, 20
  - minimum bend radius, 8, 20
  - temperature, 20
- glossary, 5
- IEC compliance, 5, 7, 8, 12
- laser interlock, 8, 11, 12, 16
- MPE
  - ocular exposure, 21
  - skin exposure, 21
- personnel requirements, 6
- probe
  - additional documents, 22
  - calibration, 14
  - cleaning, 9, 17
  - designated use, 6
  - installation, 12
  - materials of construction, 20
  - operation, 15
  - receipt, 10, 14
  - troubleshooting, 16
  - verification, 14
  - window cleaning, 17
- Raman RunTime, 14
- repair, 19
- safety, 7
  - basic, 6
  - eye, 7, 12, 21
  - laser, 7, 8
  - operational, 6
  - product, 8
  - service, 7
  - skin, 12, 21
  - workplace, 6
- specifications
  - diameter, 9, 20
  - humidity, 20
  - laser power, 20
  - length, 9, 20
  - pressure, 20
  - spectral coverage, 20
  - temperature, 20
- symbols, 4
- technical data, 20

[www.addresses.endress.com](http://www.addresses.endress.com)

---