


- (EN) Manual changeover switch
- (FR) Commutateur manuel
- (DE) Manueller Umschalter
- (ES) Conmutador manual
- (PT) Interruptor manual
- (NL) Handmatige omschakelaar




# HI4xx

## 800 - 1600A

800A	1000A	1250A	1600A
HI460	HI461	HI462	HI464




800A	1000A	1250A	1600A
HI460	HI461	HI462	HI464






Ensure that the product is installed on a flat rigid surface  
 Assurez-vous que le produit soit installé sur une surface plane et rigide  
 Stellen Sie sicher, dass das Produkt auf einer flachen starren Oberfläche installiert ist  
 Asegúrese de que el producto esté instalado en una superficie plana y rígida  
 Certifique-se de que o produto esteja instalado em uma superfície plana e rígida  
 Zorg ervoor dat het product op een vlakke, stijve ondergrond wordt geïnstalleerd




800-1600A


$$L = X - 370,5 \pm 2 \text{ mm}$$




800-1000A





1250A



1600A




	800A	1000A	1250A	1600A
	HI460	HI461	HI462	HI464
<b>A</b>	466		466	598
<b>B</b>	321		330	288
<b>C</b>		303		
<b>H</b>		230		
<b>H1</b>		293		
<b>J</b>		51,5		
<b>J1</b>	335		335	467
<b>K</b>		250		
<b>K1</b>		125		
<b>Y</b>	66,5		66,5	67,5
<b>Y1</b>		253,5		



OFF

800-1250A HZI204



1600A HZI205







1600A HZ164



IS 537181C / Printing size: A3 / Recto-verso / Black/a0g/m² / Final size A4