



ASSEMBLY INSTRUCTION FOR BC-074


①




②



③



④



Ax1



Bx4



Cx1



Dx1



Ex1



Fx1



Gx1

