







# AVANTE ACHROMIC SPEAKER FREQUENCY CHARTS




## A10 - FREQUENCY CHARTS




# A12 - FREQUENCY CHARTS




# A15 - FREQUENCY CHARTS




# A15S - FREQUENCY CHARTS



Map  
— 2: A15S - Normal+Normal  
— 3: A15S - Enforce+Normal



Map  
— 5: A15S - Normal+Cardioid  
— 6: A15S - Enforce+Cardioid



Map  
— 8: A15S - Normal+Endfire  
— 9: A15S - Enforce+Endfire

# A18S - FREQUENCY CHARTS

