

## JC09 Battle robot specification

Thank you for using our toy products, in order to make you have a better understanding of this product, please read the following instructions before using, which will bring you a different operating experience.

### Know before use

- Electronic control product: this product is suitable for children aged 8 and above. It should be assembled and charged by adults before children can play.
- Please use the product under the supervision of adults, do not disassemble or modify the product without authorization, any modification may cause the product can not be used normally.

### Points for Attention in Use

1. The robot uses a 3.7V rechargeable modular lithium battery and the remote uses two 1.5V "AA" non-rechargeable batteries.
2. Battery removal and loading should be operated correctly according to the polarity and voltage in the battery box.
3. Rechargeable batteries must be charged under adult supervision.
4. The rechargeable battery must be taken out of the machine before it can be charged.
5. Different types of batteries or old and new batteries in the remote control should not be used together.
6. The battery of the body must be charged with the battery configured by the original factory and the USB charging cable distributed.
7. The original factory should be removed from the machine. If it is not used for a long time, please remove the battery from the machine.
8. Power terminal shall not be short-circuited.
9. UnscREW the screw on the battery cover of the remote control with a screwdriver and load the battery in accordance with the correct polarity cord in accordance with the correct polarity.
10. The product is composed of plastic, hardware and electronic components, and shall not be placed or used in water or in a wet environment for a long time. Check regularly whether there are defects in wires, plugs, and body parts, and stop using them until they are fully repaired.


### 2.4G code description

1. When the battery is installed on the remote control, the indicator light of the remote control flashes, the robot will enter the connection state after the battery is installed and the switch is pressed. When the connection is successful, the remote control indicator is on. If the connection fails, repeat the preceding steps.
2. Each remote control can only connect one robot. When the connection is successful, each robot will not interfere with each other. Multiple robots cannot be connected at the same time.
3. When pairing with other remote control or robots of the same model, take out the battery of the remote control and turn off the power switch of the robot before pairing again.

### Operating hints


- When you are operating, the battery light of the body is steady on and on, if the battery light of the body is off, it is off.
- When the battery power is consumed, the left and right steering is not sensitive, and the forward and backward are slow, the modular battery needs to be taken off and charged.
- The effective remote control distance of the robot is about 30 meters. When the distance is exceeded, the robot may stop or be uncontrolled.

### Battle robot graphic



### Operating instruction

1. Left rocker push up/down, robot forward/backward.
2. Right rocker push left, robot turns left. Keep pushing to left, robot rotates to left.
3. Right rocker push right, robot turns right. Keep pushing to right, robot rotates to right.



4. Long press the key, the robot moves horizontally to the left.
5. Long press the key, the robot moves horizontally to the right.
6. Short press the key, the robot can walk in a square path to the right
7. Short press the key, robot spray.
8. Short press the key, robot shots water bomb.
9. Short press the key to switch songs, long press to close sound effects.

### 45° diagonal walking description

1. Long press the key "Drip" and enter the diagonal walking mode. Long press "Drip" again to exit the mode.
2. Push the left rocker up and push the right rocker left at the same time, and the robot walks 45° to the upper left corner.
3. Push the left rocker up and push the right rocker right at the same time, and the robot walks 45° to the upper right corner.

### Battle mode description

1. Short press the key and enter the battle mode after hearing "Di-Di".
  2. Next key can use the remote control to control the robot for shooting battles. In battle mode, you need to hit the front area of the robot to count points, not the side and back.
  3. Short press the battle key to hear a "Di" to exit the battle mode
- Effective region
2. Next key can use the remote control to control the robot for shooting battles. In battle mode, you need to hit the front area of the robot to count points, not the side and back.
- In Battle mode, each health lamp represents 2 health, and there are 6 health per game.
  - If the robot is hit once, a life light will blink. If it is hit twice, a life light will go out.
  - When the robot is hit 6 times, the life lights will all go out and the game is over.
  - Long press the Revive button to restart the battle.

### Buttons on the watch control of the remote

