


Кухонний куточок «Фронт»

Kitchen corner «Frant»
















Д-1600, Ш-1200, В-860, мм.

L-1600, W-1200, H-860, mm.




Інструкція збірки
Assembly instruction

Фронт/Frant




 x8	№	довжина(мм) length(mm)	ширина(мм) width(mm)	кількість quantity	 x8	№	довжина(мм) length(mm)	ширина(мм) width(mm)	кількість quantity
 x56	1.	808*	540*	2	 x1	10	970**	75	1
 x28	2.	808*	540*	2	 x1	11	570*	70	1
 x1	3.	970**	250	1	 x1	12	570**	75	1
 x14	4.	570**	250	1	 x1	13	967	340	1
 x7	5.	570**	250	1	 x1	14	567	340	1
 x8	6.	970**	250	1	 x1	15			1
 x4	7.	968	278	1	 x8	16			1
 x10	8.	568	278	1	 x7	17	962	420	1
 x10	9	970*	70	1		18	562	420	1




1.




2.









3.



5

4.



5.

