


Кухонний куточок «Президент»

Kitchen corner «Prezident»










Д-1600, Ш-1200, В-840, мм.




L-1600, W-1200, H-840, mm.

Інструкція збірки
Assembly instruction



Президент/Prezident




№	довжина(мм) length(mm)	ширина(мм) width(mm)	кількість quantity
1.	850*	400*	2
2.	850*	400*	2
3.	570**	250	1
4.	570**	240	1
5.	970**	250	1
6.	970**	240	1
7.	968	292	1
8.	568	292	1
9.	970**	120	1








№	довжина(мм) length(mm)	ширина(мм) width(mm)	кількість quantity
10	570**	120	1
11	970*	120	1
12	570*	120	1
13	965	350	1
14	565	350	1
15	967	290	1
16	567	290	1
17	970*	75	1
18	570*	75	1
19	970*	45	1
20	570*	45	1
21			
22			









1.










x2








2.





4.



6

5.

