




说明书尺寸 60+40__60+160mm

<p>AI Universal Remote Control</p>  <p>User Guide</p>	<p>Thank you very much for purchasing and using this product. Please read the instructions carefully and use it correctly!</p> <p>Product Feature</p> <ul style="list-style-type: none"> - One key distribution network. - Mobile APP remote control. - Support air conditioning, TV, set top box. - Expand the learning function to include more classifications (38K bit rate signal learning is supported). - No dead Angle signal coverage in all directions. - Extensible support Tmall wizard, small degree, ruogi, ding dong, ALEXA, Google assistant voice control. - Intelligent scene cont. 	<p>Subsequent Support</p> <ul style="list-style-type: none"> - Cloud timing. - Expand more categories (DVD electric fan, power amplifier, etc.). - Set-top box channel error correction feedback. <p>Product Parameters</p> <p>Product Nmae: AI Universal Remote Input Voltage: DC 5V/1A IR frequency: 38KHz IR Range: ≤10 Meter Wireless Range: 2.4GHz Working Temperature: 0°C-55°C Working Humidity: 10%-85%RH</p>	<p>Product Illustration</p> 
---	---	--	--

2.Compatibility mode:

<p>Installation Guide</p> <p>Power Supply Method: Directly plug into the router/socket/ computer USB interface (5V/1A and above specifications are recommended)</p> <p>Download the APP: Scan the QR code below to download or search "Tuya Smart" or "Smart Life" in the app store to download and install the app, complete the registration and log in your account.</p> 	<p>Access Network Settings</p> <p>1.Default mode of network distribution: Open the "Home" Page of the APP, and click the "+" button in the upper right corner of the page. Click the "others" button and select the "infrared Universal Remote control". Long press the reset button for more than 8s, until the network configuration indicator light flashes, and configure the network according to the prompts. After the successful addition, you can find the Universal Remote Control in the "my home" list.</p> <p>2.Compatibility mode:</p>	<p>Open the"Home" Page of the APP, and click the "+" button in the upper right corner of the page. Click the "others" button and select the "infrared Universal Remote control". Long press the reset button for more than 8s, until the network configuration indicator light flashes. Long press the reset button again for more than 8s, until the indicator light into the slow flash state. Enter the APP, then click the upper right corner "compatibility mode" to configure the network according to the prompts. After the successful addition, you can find the Universal Remote Control in the "my home" list.</p>	<p>Pay Attention To:</p> <p>This version only supports 38K code rate signal learning. if you find that the Universal Remote Control can not accept the instructions of the electrical remote control, it may be that the code rate signal of the electrical remote control does not match. When using the learning function, in order to ensure that the Universal Remote Control can receive instructions normally. do not press the electric remote control for long to send signals to the Universal Remote Control, just press it for short.</p>
--	---	--	--