


Wireless connection

Press and hold the top button for 7 seconds, the scanner will continuously send out a pairing voice prompt, insert the receiver into the USB port of the computer, the voice prompt is paired successfully, and the screen will display the icon  when the connection is successful

After the Bluetooth connection

scanner is powered on, open the Bluetooth search at the receiving end, find the device with the Bluetooth name "BARCODE SCANNER", click to connect, and the x behind the Bluetooth mode will disappear after success. (Bluetooth mode can be set by the code below, and the corresponding name will be displayed on the screen).

Bluetooth settings



Bluetooth HID



Bluetooth SPP



Bluetooth BLE



Clear the pairing information

Toggle the configuration code setting on/off



Factory reset



Software version number



All barcodes can be read



The total number of scans is zeroed

Communication mode settings



**USB HID mode



Virtual serial port mode

Common ending character settings



** Enter



Carriage return to wrap



Tab



No terminator

Reading mode settings



** Manual reading mode



Induction mode



Continuous mode

Instruction Manual

LCD Screen Wireless 2D Scanner V1.3

Dear users, thank you for choosing our products. We will serve you with high-quality products, in order to ensure that you use this product better, please read this manual carefully before use!

Tone settings



**Turn on the tone



Turn off the tone



** Turn on speech



Turn off speech



Low volume



** Medium volume



High volume

Wireless function settings

Double-click the function button at the top of the scanner to switch between normal mode and inventory mode, which is normal mode by default




Data uploads



Clear data

Instructions:

- 1.Normal mode: In this mode, the scan results will be uploaded to the computer in time (this mode is the default mode).
- 2.Inventory mode: In this mode, the scan results are stored in the internal memory, and the inventory mode icon  will be displayed on the screen (when the internal memory is occupied, the buzzer will beep for a long time to prompt).
- 3.Data upload: Scan the barcode to upload the data stored in the internal memory to the computer in turn (applicable in inventory mode, please ensure that the wireless signal is normal when uploading data, and there will be voice prompts for successful and failed data upload).
4. Clear data: Scanning the barcode will erase all the data in the internal memory.

Sleep time setting

Note: Scan the sleep time SET first, and then scan the time you want to set



Sleep time SET



30 seconds



**60 seconds



2 minutes



5 minutes



No dormancy

Language settings



** United States



Belgium



Brazil



Canada



Croatia



Czech Republic



Slovakia



Denmark



Finland



France



Germany



Hungary



Italy



Latin America



Netherlands



Norway



Poland



Portugal



Serbia



Slovenia



Spain



Sweden



Swiss-French



Swiss-German



United Kingdom



Turkey-F



Turkey-Q



Japanese



Romanian



Greece



Hebrew



Russia



Universal keyboard

Inverted color code settings



** Turn off inverted color recognition



Turn on inverted color recognition