

Wireless Range Extender 8

Quick manual V3

1 Plug in your wifi extender and wait for 30s

AX1800 / AC1200
After power on, you will find the LED light will change from **Green** to **Blue** color. Then you can start to set up.

AX3000 / AX1500
After power on, you will find the LED light will change **Red** color. Then you can start to set up.

*** If Abnormal, please reset:**
Press "RST" button on the side of the product for 8s ,or contact seller.

2 Connect your Extender SSID

Choose WIFI_2.4G_XXXX
Or **wifi-2.4g-XXXX** to setting

*** NOTE:**
Please remember to turn off your mobile network data. You have no access to Internet until you finish all setting steps. If your phone prompts that the network cannot be connected, click to continue

*** NOTE:**
Jump to step 3 after step 2
If you click connect on the phone, no jumping interface will appear. You can manually enter the URL **192.168.188.1** in the browser.

3 Select the WIFI SSID from the main router you want to extend.

4 Enter the WiFi password of your main router into the password box. Click "Next"

5 Set the new Wireless names and passwords for the Extender

Default SSID:
original SSID-PRO-2.4G can be changed

Default SSID:
original SSID-PRO-5G can be changed

6 Confirm the new wireless names and passwords again.

7 Wait 60 seconds.

After the setting is completed, please observe the signal indicator. If it lights up, it means that the relay is successful. Please connect Test001-PRO-2.4G Test001-PRO-5G to the Internet! otherwise reconnect.

Please wait 17 seconds

8 Congratulations ! The indicator lights on means the WiFi Extender has been set up

***NOTE:**

Green color means greater signal

If the color is not, please restore the factory reset

9 Reselect and reconnect to your Extender WiFi

FAQ

1. My Wi-Fi says connected but i have no internet connection.
* If the Wi-Fi is connected . but there is no internet ,check that the router's Wi-Fi is actively working.
* If the Extender indicator light keeps flashing off, that means the connection failed, and you may have entered the wrong password. It could also be for some other reasons, so try to restore factory settings. To do that,press the RST button for about10 seconds. Set up the Extender again.

2. What is the username and password for setting up the Extender?
No username and password need to enter the setting webpage of the Extender. But after Setting UP, you can not enter the setting page unless you restore factory settings by pressing RESET/WPS button for 10 seconds

1 If you need AP mode, please do RESET then follow STEP 1 to STEP 2

AP mode

2 Set Wireless Password

setting wireless name and password

Click 【Apply】

3 Plug the Ethernet cable to the LAN port directly then you can access the internet.

AP mode

3. Why are some devices at home (Printer, CCTV, camera,TV , Phone) unable to connect to the Extender?
* This means the device does not recognize the Extender.
* The device should be in the same network as your main router

4. Why am i unable to enter the webpage?
* You can not enter the setup webpage with URL 192.168.188.1 after extender setting, please press the RESET/WPS button for about 10 seconds to restore factory settings and then try again.
* Check if you have connected to the Extender's WIFI during setup.
* Disable your mobile's data during setup
* Use another mobile or PC to try