

FERRO CONCEPTS

Back Panel Liberty Table of Contents

Product Overview 1

Back Panel Liberty Installation 2-5

Back Panel Liberty General Purpose Pockets 6-7

Back Panel Liberty Internal Pocket 8-9

Back Panel Liberty Beaver Tail and Passthrough 10-14

Back Panel Liberty Side Charge Quivers 15-16



Back Panel Liberty



Back Panel Liberty | Product Overview

The Back Panel Liberty is a combination of our most popular back panels and accessories along with several new features designed into one versatile solution. Built for the Assaulter, this back panel adds substantial carry capability to your FCPC or other UCAS-compatible plate carriers.

The overall focus was with operational reality in mind: as your mission sets evolve, your kit must adapt seamlessly. Missions evolve. Your gear should too. The end result being a clear focus on scalable storage.

Features:

TOP

- General Purpose Pocket -Velcro 6x6 for versatile storage option, loop lined with large Velcro flap and external elastic retention to reduce contents shifting
- Top section features three snap tabs for customizable, secure tool storage and internal access
- Two hangers on backside for a quick setup while maintaining security

INTERNAL

- Hook and Loop closure for securing internal section together
- Internal elastic retention holds up to 2 radios and 4 ETC charges
- Internal stretch pocket for a hydration bladder

SIDE

- Integral Charge Quivers on both left and right sides that feature an internal envelope closure for a closed bottom or tucked away for a pass through
- Dual bungee retention for charges and gear
- 1/2" vertical webbing on the outside of the quivers for mounting extra charges, flags, etc.

BOTTOM

- Large general-purpose pouch sized for panoramic NVGs, with tie-in point for securing sensitive items on the inside of the pocket and loop lining for organization. Also features an adjustable bungee retention to keep contents secure
- Storable X-PAC beaver tail for running bolt cutters or large charges
- Pass-through pocket designed specifically for stowing a Hoolie tool or sledgehammer. When not hosting a tool, the opening doubles as a mounting point for the Dangler® AR
- "Zipper Bowtie" System - locks the UCAS zippers down so they don't work their way up under kinetic movement
- UCAS compatible
- Berry Compliant
- Made in USA

Components:

- Back Panel Liberty



Back Panel Liberty (Front)



Back Panel Liberty (Back)

Back Panel Liberty | Installation

Installing the Back Panel Liberty onto the FCPC



1. Start by passing the top two hangers of the Back Panel Liberty through the top laser-cut MOLLE row on rear plate bag of the FCPC.



2. Pass the bottom two tuck tabs of the Back Panel Liberty into the 11th laser-cut MOLLE row.

Back Panel Liberty | Installation

Installing the Back Panel Liberty onto the FCPC



3. Connect zipper pull tab on the Back Panel Liberty to the rear plate bag on the FCPC.



4. Zip pull tab all the way to the bottom of the rear plate bag.

Back Panel Liberty | Installation

Installing the Back Panel Liberty onto the FCPC



5. Locate the zipper bow tie at the bottom of the Back Panel Liberty, near the zipper pull tab.



6. Pinch one end of the zipper bow tie for ease of insertion into the zipper pull tab opening.

Back Panel Liberty | Installation

Installing the Back Panel Liberty onto the FCPC



7. Insert the pinched side of the zipper bow tie through the zipper pull tab opening, and pull through. Make sure the zipper bowtie is fully passed through the zipper pull tab opening for secure installation.



8. Repeat steps 3-7 on the opposite side of the Back Panel Liberty.

Back Panel Liberty | General Purpose Pockets

Adding items into the General Purpose Pockets on the Back Panel Liberty



1. Open the top velcro closure flap to access the top General Purpose Pocket - Velcro 6x6. Featured is the Bang Insert - Triple (sold separately).



2. The top velcro closure flap on the General Purpose Pocket - Velcro 6x6 can be staged open for quick access to items inside.

Back Panel Liberty | General Purpose Pockets

Adding items into the General Purpose Pockets on the Back Panel Liberty



3. The bottom general purpose pocket features tie-in points for securing items inside the pocket, along with velcro loop for additional organization. Adjustable bungee retention ensures sensitive items are more secure inside the pocket interior.



4. The bottom general purpose pocket is sized for panoramic night vision, but can fit many other mission-essential items.

Back Panel Liberty | Internal Pocket

Adding items into the Internal Pocket



1. Release the three snaps and pull apart the velcro closure at the top of the Back Panel Liberty to access the internal pocket.



2. The internal pocket of the Back Panel Liberty features elastic retention with room for up to 2 radios and 4 ETC charges.

Back Panel Liberty | Internal Pocket

Adding items into the Internal Pocket



3. Insert radio or ETC charges into the corresponding elastic retention slot in the interior pocket.

Back Panel Liberty | Beaver Tail and Passthrough

Using the Beaver Tail or Passthrough for larger breaching items



1. To open the beaver tail, release the velcro closure flap on the bottom of the Back Panel Liberty.



2. Pull out the stowable beaver tail from the open pocket on the bottom of the Back Panel Liberty.

Back Panel Liberty | Beaver Tail and Passthrough

Using the Beaver Tail or Passthrough for larger breaching items



3. Insert tool into the top internal pocket of the Back Panel Liberty. Slide the tool to the bottom of the beaver tail and ensure it is fully seated.



4. The beaver tail is ideal for items such as bolt cutters and large charges.

Back Panel Liberty | Beaver Tail and Passthrough

Using the Beaver Tail or Passthrough for larger breaching items



5. When not in use, the beaver tail can be stowed by pushing the material back up into the Back Panel Liberty. Secure bottom Velcro closure to retain beaver tail.



6. The passthrough can be utilized for longer tools, start by inserting tool into the top internal pocket of the Back Panel Liberty.

Back Panel Liberty | Beaver Tail and Passthrough

Using the Beaver Tail or Passthrough for larger breaching items



7. Release the Velcro hook and loop interior on the bottom of the Back Panel Liberty to allow longer tools to fully passthrough.



8. Snap together corresponding button snaps on the top of the internal pocket on the Back Panel Liberty, to ensure proper fitment.

Back Panel Liberty | Beaver Tail and Passthrough

Using the Beaver Tail or Passthrough for larger breaching items



9. The passthrough location can also be used for installing a Dangler® AR when the passthrough is not in use. To install Dangler® AR, release velcro hook and loop on the bottom of the Back Panel Liberty and slot the Dangler® AR into the bottom.



10. Adjust the Dangler® AR velcro panel up until it is fully seated at the bottom of the Back Panel Liberty.

Back Panel Liberty | Side Charge Quivers

Adding items in the Side Charge Quivers on the Back Panel Liberty



1. The Back Panel Liberty features external charge quivers on both sides. Place items into side charge quivers. Retention can be adjusted by synching the shock cord on the top and bottom of the charge quivers.



2. Both charge quivers feature an internal envelope closure on the bottom to retain items.

Back Panel Liberty | Side Charge Quivers

Adding items in the Side Charge Quivers on the Back Panel Liberty



3. Additionally, the internal envelope closures can be adjusted to allow longer items to fully pass through the charge quivers on the Back Panel Liberty.