

# Wilo-IF-Modul Stratos CAN



Fig. 1

- (D) Einbau- und Betriebsanleitung
- (GB) Installation and operating instructions
- (F) Notice de montage et de mise en service
- (NL) Inbouw- en bedieningsvoorschriften
- (E) Instrucciones de instalación y funcionamiento
- (I) Istruzioni di montaggio, uso e manutenzione
- (FIN) Asennus- ja käyttöohje
- (S) Monterings- och skötselanvisning
- (H) Beépítési és üzemeltetési utasítás
- (GR) Οδηγίες εγκατάστασης και λειτουργίας
- (CZ) Návod k montáži a obsluze
- (PL) Instrukcja montażu i obsługi
- (RUS) Инструкция по монтажу и эксплуатации
- (DK) Monterings- og driftsvejledning
- (N) Montasje- og bruksanvisning



[www.wilo.com/automation](http://www.wilo.com/automation)

Fig. 2



2 066 600

Fig. 3

Wilo-Stratos/Stratos-Z

+ 1 x Wilo-IF-Modul Stratos CAN (Art.-Nr. 2 066 600)



Fig. 4

Wilo-Stratos-D

+ 1 x Wilo-IF-Modul Stratos CAN (Art.-Nr. 2 066 600)  
+ 1 x Wilo-IF-Modul Stratos DP (Art.-Nr. 2 105 254)



# Wilo-IF-Modul Stratos CAN

Fig. 5




Fig. 6

