Version: 12.06.2017









Stone Care

PRODUCT DESCRIPTION

Routine cleaner for stone floors. The floor is cleaned and provided with care treatment in one step.

- Creates a mat, anti-slip protective finish.
- Dirt-repellent.
- Treated surfaces remain slip-proof.

AREAS OF APPLICATION 2

Natural and artificial stone floors (marble, granite, clinker, slate, terracotta, terrazzo) glazed and non glazed tiles.

Please pay attention to our technical instructions specifically for floors and buildings under www.dr-schutz.com

METHOD OF APPLICATION

Daily Cleaning and Care

Dilute Stone Care in a ratio of 1:200 to 1:400 (25-50 ml into 10 litres water) and clean the floor with this solution. In order to maintain the floor's anti-slip properties, do not rewipe with clear water, but allow to dry and pay attention to exact dosage.

Note:

Regular buffing will increase the wear resistance of the protective film. Over dosage or too much moisture may lead to less slip resistance of the surface

CONSUMPTION

Daily Cleaning and care: about 0,1 litre per 100 m² (dilution 1:200)

STORAGE

Store in cool, dry conditions in well sealed receptacles. Store under lock and key and out of the reach of children.

TECHNICAL DATA

Ingredients: contains under 5% non ionic tensides, under 5% ionic tensides. Contains perfumes (D-LIMONENE, CITRONELLOL, GERANIOL), solvants, care components.

pH value: 9,5 (concentrate)

ADR/RID: no dangerous good according ADR

CLP: The product is not classified according to the CLP regulation.

Even when using low-pollution products, the usual safetz measures are to be observed. Completely emptied canisters can be disposed of in domestic waste or taken to a recycling centre.

Version: 12.06.2017









Stone Care



Please pay attention to our technical instructions specifically for floors and buildings under www.dr-schutz.com

CROSS-REFERENCE

Our following publications in their updated form are valid as an integral part of this fact sheet:

- General notes on the application of Dr. Schutz finishes
- Safety data sheet available on request.

The quoted printed matter, as well as this product information in its updated form, is available on our homepage www.dr-schutz.com or on request from the address quoted below.

Dr. Schutz - We Care About Floors

Headquarter Dr. Schutz GmbH Holheinstraße 17 D-53175 Bonn Tel.: +49 (0)228 / 95 35 2-40

Fax: +49 (0)228 / 95 35 2-46 E-Mail: export@dr-schutz.com www.dr-schutz.com

Dr. Schutz U.K Ltd. Unit 24. Anglo Business Park. Smeaton Close, Aylesbury Bucks HP19 8UP

Contact: Richard Nelson Tel.: +44 (0)1296 437827 Fax: +44 (0)1296 334219 E-Mail: richard@dr-schutz.com Ireland Dr. Schutz Ireland 35 Pic Du Jer Park. Ballinlough, Cork

Contact: Paul O'Reardon Mobile: 0877678388 E-Mail: drschutzireland@gmail.com

North America Schutz NA 4701 Bath St 46 Philadelphia, PA 19137

Contact: Sam Jamison Tel.: +1(877) 272-4889 Mobile: +1(215) 510-7874 E-Mail: sam@schutzNA.com

The above advice for technical application is given to the best of our knowledge and according to the latest state of technology. Therefore, if our products are used carefully heeding the advice given on their application, as well as following our suggested procedures with the materials intended for use with these products, no damage shall occur. However, our products are used outside and beyond our possible control, and are therefore subject to your own responsibility, which does not release you from the obligation to check for yourself whether our supplied products are suitable for your intended purpose and procedure. Therefore our notes and advice are not legally binding and cannot be used against us as grounds for liability - which includes the rights and protection of any third party. The relevant recommendations, guidelines and standard norms are to be observed, as well as the recognized technical rules. On publication, this product information replaces and supersedes the validity of any previous versions.