# CAM
## CROSS COUNTRY RACING SERIES

## 1. Downloading And Installation Instructions Of The App:



**iphone OS:** Please scan the QR code for installation

**Android system:** Please scan the QR code for installation

## 2. Link instructions:

Open the power switch of this car, and then access into "SETTING" in the mobile, open the "WIFI" and find the "LH Car-######" which corresponds to LH Car for connecting. When the link is successfully connected, please exit from the Setting Option. (Please keep away from other WiFi signals as far as possible when driving.)

## 3. Component Name Of Remote Controller:



Power indicator

Forward/Backward

Fast mode

Slow mode

Turn left/Turn right

Photos

Video

Power switch

**Special Note:** When the RC car replaces the battery, please press the power switch to re-align the frequency.

## 4. Function Introduction Of App's Control Interface:



Video

Photos

Return

Forward control

Gravity sensor mode

Camera inversion

VR split screen mode

Display/Hide control interface

Right turn control

Backward control

Photos and video store

Left turn control

High/low speed

**Special Note:** When the power of remote control car is low, the light inside the body will be dimmed and the APP will not be able to control it, please charge it in time.

## 5. Battery Installation:



Remote control car bottombattery installation

Remove the bottom screw of the remote control car and open the battery cover

**Special Note:** When the RC car replaces the battery, please press the power switch to re-align the frequency.

Remote control battery installation

Remove the remote control battery cover screw and open the battery cover

2x1.5V "AA" battery (not included)

## 6. Linking instructions:

The car body power on indicator light is on, the remote control power is on and the indicator light flashes, the linking complete indicator light is off, and the indicator light is on during operation.

**Tip:** Please turn off the switch after using the product to avoid the power of storage battery use out.

## 7. Basic operation method:



Forward

Backward

Turn left

Turn right

## 8. Gravity sensing operation method:

Tap the gravity sensor icon on the screen, hold the phone as horizontally as possible, and tilt the phone forward/backward/left/right slowly (the angle must be greater than 15 degrees) to control the remote control car to move forward/backward/turn left/turn right.



Forward

Backward

Turn left

Turn right