



FERRO CONCEPTS - KWIK SINGLE AR (KSAR) INSTRUCTIONS

PROCEDURES FOR MOLLE COMPATIBLE INTERFACES AND UP TO 2" BELT MOUNTING


1" WEBBING TO SIMULATE
MOLLE PAL ROWS




1. MOLLE MOUNTING: WEAVE THE STRAPS THROUGH THE DESIRED MOLLE ROW AND INTO THE FIRST SLOTS AND OUT OF THE SECOND SLOTS OF THE POUCH.




2. WEAVE THE STRAPS THROUGH THE NEXT MOLLE ROW AND THEN TUCK THE TUCK TABS UPWARDS INTO THE THIRD SLOTS OF THE POUCH.



3. THE KSAR POUCH IS NOW SECURE AND READY TO BE USED ON YOUR MOLLE PLATFORM.



1. BELT MOUNTING: WEAVE STRAPS OVER THE BELT AND INTO THE SECOND SLOTS AND THEN OUT OF THE THIRD SLOTS. MAKE SURE PULL TABS ARE FULLY THROUGH.



PULL TABS ARE FULLY
THROUGH AND LOCKED

2. TUCK THE TUCK TABS INTO THE BOTTOM SLOTS. THE POUCH IS NOW READY TO BE USED ON YOUR BELT.