



六折 单 35*60mm 展开 210*60mm

SOS Button Sound-light alarm

Wi-Fi Zigbee



Product Diagram



1. **Speaker:** 130DB volume.
2. **LED Light:** Red and blue light flashing.
3. **Set key:** Click alarm; Double click to cancel the sound; Press and hold for 8 seconds to reset.

Download APP

Scan the QR code below to download App Store Search "Tuya Smart / Smart Life"

[Tuya Smart]



[Smart Life]



Wi-Fi Version

1. Connect the mobile phone Wi-Fi/4G signal/ turn on Bluetooth.
2. Enter the distribution network state long press the setting key for about 6 seconds, and the LED light continues to blink.
3. Open the APP and click "Add Device".
4. Discover the device, click Add, and wait until the device is added.
5. To display the completion of the addition, click "Next" and click "Finish".



Zigbee Version

1. **Prerequisites**
Operates and is compatible with Zigbee smart gateway Settings.
Zigbee Smart Gateway Open the Smart Life app and tap Zigbee Gateway, tap Add Subdevice, then select a SOS Button Sound-light alarm or other sensor and follow the on-screen instructions to continue.
2. Make sure your phone is connected to the Wi-Fi network and the detector is as close as possible to the Zigbee smart gateway. Press the SOS Button Sound-light alarm, the LED indicator flashes quickly, and then enter the automatic networking mode.



Note:

WiFi model needs to connect 2.4GWiFi; ZigBee models require a Tuya gateway.



APP Application

- Alarm volume/Duration Settings. (Figure 1, 2)
- Push notifications, alarms or normal. (Figure 3, 4, 5)
- View historical records, scene linkage. (Figure 6, 7)
- Share devices/Automate/Change nicknames. (Figure 8)




Install

1. Battery installation:

Push the back cover upward to open, put the AAA*2 battery, align the buckle, and close the back cover;

2. Double-sided tape fixed installation:

1. Remove the release paper of the double-sided tape and paste the double-sided tape on the fixed surface of the SOS button Sound-light alarm; Remove the release paper from the back of the double-sided tape and fix it in the position required for installation.
2. Directly place the SOS button Sound-light alarm on the desktop, bedside, etc



Product Parameter

Alarm volume: 130DB
Standby current: <10uA
Battery: AAA*2
Operating Temperature:
-10 Celsius-40 Celsius (14degF-104degF)
Operating Humidity: 20%-85%
Storage Temperature:
-10 Celsius -60 Celsius (14degF-140degF)
Storage Humidity: 0%-90%
Standby time: 12 months

Packing List

- SOS button Sound-light alarm x 1
- Instructions *1
- Double-sided tape x 1

