
SERVICE MANUAL

SECOH AIR PUMPS

Models covered in this manual: SLL-20, 30, 40 & 50 EL-60, 80-15, 80-17 & 100 EL-120W, 150 & 200



Contents

- 1. Prior to maintenance and Service
- 2. Maintenance
- 3. Air filter cleaning / replacement
- 4. Valve box and diaphragm replacement
- 5. Resetting auto stopper
- 6. Magnet replacement
- 7. Diagnosis of failures
- 8. Technical Specification
- 9. Test data (resistance table)
- 10. Spares Kits and replacement parts

1. Prior to maintenance and service

- Prior to maintenance and service, read and keep this manual carefully.
- Follow the safety instructions!
- Servicing and maintenance as described in this manual should be carried out by an authorised service facility.

DANGER

- Always disconnect power supply before servicing. Failure to do so could result in electrical shock, personal injury or death.
- Do not touch live parts. Touching live parts will result in electric shock.

2. Maintenance

Cleaning the air filter

The air filter <u>must</u> be cleaned every 3 to 4 months to insure correct operation and replaced regularly.

Occasional checks

- Is air blowing out properly?
- Is the air pump making abnormal noise or vibrations?
- Is the temperature of the air pump not abnormally high?
- Is the power cord or plug damaged or discoloured?
 - → If any irregularity is found, read DIAGNOSIS OF FAILURES.


3. Filter element cleaning or replacement

- a) Undo the truss head screw of the filter cover.
- b) Remove the filter cover, by firmly pulling it off.
- c) Remove the filter element and brush off any dust particles by hand.

If heavily clogged with dust, wash in a neutral detergent followed by a thorough rinsing in water. Allow to dry in the shade.


Note: Do not use benzene or thinner to clean filter element as it can be damaged!

- d) After cleaning reassemble the filter element back in place. Make sure to put the harder side of the filter facing downwards. Press in the filter cover.
- e) Secure the filter cover by the truss head screw.



4. Valve box and diaphragm replacement

- a) Undo the 4 corner bolts of the overall cover.
- b) Remove the overall cover. If it is hard to remove, insert a screwdriver in the slot provided.
- c) Pull out the bushing.
- d) Remove the shock absorber





e) Undo the 4 screws of the holder cover.

Note:


It is easier to change one diaphragm at a time.

f) Insert the magnet support jig in the 4 corners, between the magnet and the core.


Note: The magnet support jig (carton strips) is included in the service repair kit.




g) Undo the 4 screws of the valve box.



h) Slide down the hose clamp, pull off the connecting pipe and remove the valve box.



 Undo the nut or bolt and remove the diaphragm (Nut: SLL series & EL-60, 80-15 & 120W - Bolt: EL-80-17, 100, 150 & 200).



j) Set the new diaphragm and fix it by the nut or bolt (torque, see table at appendix).



Screw

k) Insert the magnet supporter jig in the 4 corners between the magnet and the core.

Note: Make sure that the magnet is in the centre of the solenoids.

- Install the new valve box and secure into position using the 4 corner screws.
- m) Replace opposite diaphragm following the above procedure.






- n) Pull out the magnet support jig.
- o) Check the magnet is in a central position.

Note: The tolerance of the centring of the magnet is within +/- 0.5 mm (see dimension "d" of sketch in appendix).

- p) Push on the connecting pipe and refit the hose clamp.
- q) Reset the auto stopper (If necessary)
- r) Connect power cord to confirm proper operation.

Danger: Do not touch live parts. Touching live parts will result in electric shock!

s) Fasten the holder cover with the screws.



t) Put the shock absorber back into place.





u) Insert the power cord bushing into the location notch.

Note: It locates into the inner slot!

- v) Replace the overall cover and secure by using the nuts and bolts.
- w) Replace air filter as previously described.

Secure filter cover using the truss head screw.




5. Reset auto stopper (protective switch)

Function of auto stopper


A running pump with a broken diaphragm may cause a major break down and excessive repair cost. To prevent this from occurring, ELseries pumps are equipped with a protective switch.

If the diaphragm is broken, the magnet reciprocates with abnormal amplitude and the projection of the magnet hits the slider of the auto stopper. The contact is interrupted and power is cut off.




Auto stopper reset

- a) Follow the procedure of chapter 4 from a) to e)
- b) Set the slider at the position L1 = L2.
- c) Follow the procedure of section 4 from point r) to point w).




6. Magnet replacement


- a) Follow the procedure of section 4 from a) to i).
- b) Remove diaphragm and pull out opposite diaphragm and magnet from other side.






c) Assemble new magnet and diaphragm with nut or bolt.







- e) Install replacement diaphragm to opposite side.
- f) Follow the procedure of chapter 4 from k) to w).

7. Diagnosis of Failures

Problem	Cause	Action
Pump does not work	Power plug is disconnected	Plug in and check if electricity is available
	Cord is broken (Internal wiring damaged)	Check electrical continuity with circuit tester
	Auto stopper activated	Open cover to check for damage on diaphragm
Excessive noise	Valves or diaphragm are damaged	Open cover to check for damage or disconnection
	L-Tube is damaged or disconnected	Re-connect or replace L-Tube
	Pump is in touch with surrounding articles.	Re-position pump
Discharged air volume decreases	Air filter is clogged	Clean or replace air filter
	Air diffuser or pipe is clogged	Clean air diffuser and check piping
Abnormal temperature arises	Air filter is clogged	Clean or replace air filter
	Air diffuser or pipe is clogged	Un-block air diffuser or pipe
Pump sometimes operates and sometimes not. *	Air filter is or diffuser is clogged	Clean or replace air filter or diffuser

^{*}A decrease in airflow (caused by clogged air filter or air diffuser) may lead to an extraordinary rise in operating temperature. This will activate a thermal protector and stop the pump. When the temperature reduces, the pump will automatically restart.

If in doubt about any service or maintenance procedures, please call http://ledoed.com.ua/

8. Technical Specifications

Model		SLL-20	SLL-30	SLL-40	SLL-50	
Voltage	V	As shown in the name plate				
Frequency	Hz	Applied to 50				
Optimal Press.	bar	0.2 0.2				
Open Flow	L/min	52	75			
Max Power	W	As shown in the name plate				
Outlet dia.	mm	OD 19 mm				
Weight	kg	4.5				
Standard accessories L-Joint hose (with hose band)			•			

Model		EL-60	EL-80-15	EL-80-17	EL-100		
Voltage	V	As shown in the name plate					
Frequency	Hz	Applied to 50					
Optimal Press.	bar	0.2 0.2 0.2 0					
Open Flow	L/min	105	145				
Max Power	W	As shown in the name plate					
Outlet dia.	mm	OD 19 mm					
Weight	kg	8.5					
Standard accessories L-Joint hose (with hose band)							

Model		EL-120W	EL-150	EL-200			
Voltage	V	As shown in the name plate					
Frequency	Hz	Applied to 50					
Optimal Press.	bar		0.25				
Open Flow	L/min	225 265 310					
Max Power	W	As shown in the name plate					
Outlet dia.	mm	OD 27 mm					
Weight	kg	16					
Standard accessories L-Joint hose (with hose band)		and)					

9. Testing Data

a) Solenoid resistance table

Voltage: 230V, 50Hz Tolerance: +/- 10%

SLL-20 & 30 models: Solenoids are in series connection Other models: Solenoids are in parallel connection

	Total R	Single R
SLL-40	86.5	173.0
SLL-50	60.8	121.7
EL-60	36.7	73.4
EL-80-15	21.9	43.7
EL-80-17	33.1	66.2
EL-100	20.0	40.0
EL-120W	16.2	64.7
EL-150	16.6	66.2
EL-200	10.0	40.0

10. Spare Part Kits

Only use <u>genuine</u> SECOH replacement parts. Non-standard parts will have a detrimental effect on overall pump life and performance.

In order to ensure long service and operation, it is recommended diaphragms and valve boxes are replaced once a year.

All parts; magnets, filters, service kits and diaphragms are available from http://ledoed.com.ua/ online site and can be despatched immediately.

We also stock a complete range of Secoh pumps for replacement purposes and these can also be used to replace defective pumps of other brands with ease.

		SLL S	BER	IES				
Kit Name Part No.		Contents Parts Qty		Pos No	Required kit Qty			
	Codo	included	Qty	110	SLL20	SLL30	SLL40	SLL50
		Diaphragm	2	10				
		Diaphragm holder	2	9				
		Nut	2	24				
Diaphragm repair kit	K-SLL-D EM-0359025	Valve box & valve	2	11	1	1	1	1
		Filter element	1	3				
		Filter cover packing	1	2				
		Tank base packing	1	17				
Magnet	K-SLL-M	Magnet	1	8	1	1	1	1
iviagnet	EM-0351008	Nut	2	24	ı			
		EL S	ERI	ES				
		Contents			Required kit			
Kit name	Part No.	Parts included	Qty	Pos No	Qty			
Rit Hame	Code				EL60 EL80-15	EL80-17 EL100	EL120W	EL150 EL200
		Diaphragm	2	11				
D'ankanan	W. E.L. D	Diaphragm holder	2	10	1	1	2	2
Diaphragm repair kit	K-EL-D EM-0377007	Nut	2	23				
ropan kit		Valve box & valve	2	12				
		Filter element	1	2				
	K-EL60,80-15-M	Magnet	1	9	4		2	
Magnet EM-	EM-0374008	Nut	2	23	1			
	K-EL80-17,100-M	Magnet	1	9		1		2
	EM-0405000	Screw	2	23		ı		2
Auto stopper	S-EL60,80-15,120W EM-0433004	Auto stopper	1	6	1		2	
	S-EL80-17,150,200 EM-0434000	Auto stopper	1	6		1		2