


# Assembly Instructions

Parts and Tools list

NO.	Name	Qty	NO.	Name	Qty
1	Lifting System	1set	11	M6*12 Screw	8
2	Foot Pad	4	12	Rubber Cushion	6
3	Foot Margin	2	13	ST3.5*19 Screw	2
4	M8*16 Screw	8	14	ST4.8*19 Screw	8
5	Bracket	2			
6	M6*14 Screw	8			
7	M6*10 Screw	8			
8	Support Beam	1			
9	4mm Hex Spanner	1			
10	5mm Hex Spanner	1			



**1** Loosen the 4 screws of beam using 4MM hex spanner, adjust the beam to proper position to fit the desktop

4mm Hex Spanner

**2** Attach legs to the beam using 8 of M6\*14 screws and 4 of M6\*12 screws

M6\*14 screw 8PCS

4mm Hex Spanner

M6\*12 screw 4PCS

**3** Attach feet to the legs using 8 of M8\*16 screws, attach the 4 of levelling foot pads to the feet by hand

5mm Hex Spanner

M8\*16 screw 8PCS

Foot Pad 4PCS

**4** Overturn frame and attach brackets to beam using 4 of M6\*12 screws, and then fit the rubber cushions to the brackets and beams

4mm Hex Spanner

Rubber Cushion 6PCS

M6\*12 screw 4PCS

**5** Adjust the width of desk frame to fit the desktop by sliding the beam, we recommend leaving at least 5-8CM of the desktop width (on each end) protruding beyond the frame width and centering the side brackets fore and aft

4mm Hex Spanner

M6\*10 screw 8PCS

5-8cm

**6** Attach the control box to the underside of the desktop using 8 of ST4.8 self-tapping screws, attach handset to the underside of desktop using 2 of ST3.5 self-tapping screw

**7** Connect the control box to the handset and to the motor